

TMS320C54x Simulator Getting Started Guide

Literature Number: SPRU137B
Manufacturing Part Number: 2617683-9741 revision C
November 1996



IMPORTANT NOTICE

Texas Instruments (TI) reserves the right to make changes to its products or to discontinue any semiconductor product or service without notice, and advises its customers to obtain the latest version of relevant information to verify, before placing orders, that the information being relied on is current.

TI warrants performance of its semiconductor products and related software to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are utilized to the extent TI deems necessary to support this warranty. Specific testing of all parameters of each device is not necessarily performed, except those mandated by government requirements.

Certain applications using semiconductor products may involve potential risks of death, personal injury, or severe property or environmental damage ("Critical Applications").

TI SEMICONDUCTOR PRODUCTS ARE NOT DESIGNED, INTENDED, AUTHORIZED, OR WARRANTED TO BE SUITABLE FOR USE IN LIFE-SUPPORT APPLICATIONS, DEVICES OR SYSTEMS OR OTHER CRITICAL APPLICATIONS.

Inclusion of TI products in such applications is understood to be fully at the risk of the customer. Use of TI products in such applications requires the written approval of an appropriate TI officer. Questions concerning potential risk applications should be directed to TI through a local SC sales office.

In order to minimize risks associated with the customer's applications, adequate design and operating safeguards should be provided by the customer to minimize inherent or procedural hazards.

TI assumes no liability for applications assistance, customer product design, software performance, or infringement of patents or services described herein. Nor does TI warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right of TI covering or relating to any combination, machine, or process in which such semiconductor products or services might be or are used.

Read This First

About This Manual

The *TMS320C54x Simulator Getting Started Guide* tells you how to install the TMS320C54x simulator debugging tools on your system. It also gives you the following information:

- How to set environment variables for parameters that you use often
- How to verify the software installation
- How to define and use a memory map for the TMS320C54x to simulate ports

How to Use This Manual

The goal of this book is to get you started using the simulator specifically designed for the TMS320C54x. Following are the topics covered in this getting started guide:

For information about ...	See ...
Setting up the debugger on a PC™ running Windows™ 3.1: installing the simulator and debugger software, setting environment variables, and verifying the installation	Chapter 1
Setting up the debugger on a SPARCstation™ running SunOS™: installing the simulator and debugger software, setting environment variables, and verifying the installation	Chapter 2
Setting up the debugger on a an HP™ workstation running HP-UX™: installing the simulator and debugger software, setting environment variables, and verifying the installation	Chapter 3
Release notes and enhancements	Chapter 4
Defining and using a memory map for the TMS320C54x to simulate ports	Chapter 5

Notational Conventions

- The abbreviation 'C54x refers to any and all TMS320C54x devices except where individually noted. The devices are:

TMS320C541	TMS320C542	TMS320C543	TMS320C545
TMS320C546	TMS320C548	TMS320C545LP	TMS320LC541
TMS320LC542	TMS320LC543	TMS320LC545	TMS320LC546
TMS320LC548	TMS320VC541	TMS320VC542	TMS320VC543
TMS320VC545	TMS320VC546	TMS320VC548	

- Program listings, program examples, and interactive displays are shown in a *special typeface*. Examples use a **bold version** of the special typeface for emphasis; interactive displays use a **bold version** of the special typeface to distinguish commands that you enter from items that the system displays (such as prompts, command output, error messages, etc.).

Here is an example of a command that you might enter:

```
cd /cdrom/hp
```

- In syntax descriptions, the instruction, command, or directive is in a **bold typeface** font and parameters are in an *italic typeface*. Portions of a syntax that are in **bold** should be entered as shown; portions of a syntax that are in *italics* describe the type of information that should be entered. Here is an example of a command syntax:

```
wd index number [, window name]
```

wd is the command. This command has two parameters, *index number* and *window name*.

- Square brackets ([and]) identify an optional parameter. If you use an optional parameter, you specify the information within the brackets; you don't enter the brackets themselves. Here's an example of a command that has an optional parameter:

```
emurst [options]
```

This command allows you to specify one or more options.

- Braces ({ and }) indicate a list. The symbol | (read as *or*) separates items within the list. Here's an example of a list:

```
map { on | off }
```

This provides two choices: **map on** or **map off**.

Unless the list is enclosed in square brackets, you must choose one item from the list.

Related Documentation From Texas Instruments

The following books describe the TMS320C54x devices and related support tools. To obtain a copy of any of these TI documents, call the Texas Instruments Literature Response Center at (800) 477–8924. When ordering, please identify the book by its title and literature number.

TMS320C5xx C Source Debugger User's Guide (literature number SPRU099) tells you how to invoke the 'C54x emulator, EVM, and simulator versions of the C source debugger interface. This book discusses various aspects of the debugger interface, including window management, command entry, code execution, data management, and breakpoints. It also includes a tutorial that introduces basic debugger functionality.

TMS320C54x Assembly Language Tools User's Guide (literature number SPRU102) describes the assembly language tools (assembler, linker, and other tools used to develop assembly language code), assembler directives, macros, common object file format, and symbolic debugging directives for the 'C54x generation of devices.

TMS320C54x Optimizing C Compiler User's Guide (literature number SPRU103) describes the 'C54x C compiler. This C compiler accepts ANSI standard C source code and produces TMS320 assembly language source code for the 'C54x generation of devices.

TMS320C54x DSP Reference Set is composed of four volumes that can be ordered as a set with literature number SPRU210. To order an individual book, use the document-specific literature number:

TMS320C54x DSP Reference Set, Volume 1: CPU and Peripherals

(literature number SPRU131) describes the TMS320C54x 16-bit, fixed-point, general-purpose digital signal processors. Covered are its architecture, internal register structure, data and program addressing, the instruction pipeline, DMA, and on-chip peripherals. Also includes development support information, parts lists, and design considerations for using the XDS510 emulator.

TMS320C54x DSP Reference Set, Volume 2: Mnemonic Instruction Set

(literature number SPRU172) describes the TMS320C54x digital signal processor mnemonic instructions individually. Also includes a summary of instruction set classes and cycles.

TMS320C54x DSP Reference Set, Volume 3: Algebraic Instruction Set

(literature number SPRU179) describes the TMS320C54x digital signal processor algebraic instructions individually. Also includes a summary of instruction set classes and cycles.

TMS320C54x DSP Reference Set, Volume 4: Applications Guide

(literature number SPRU173) describes software and hardware applications for the TMS320C54x digital signal processor. Also includes development support information, parts lists, and design considerations for using the XDS510 emulator.

Trademarks

320 Hotline On-line is a trademark of Texas Instruments Incorporated.

HP, HP-UX, HP 9000 Series 700, and PA-RISC are trademarks of Hewlett-Packard Company.

IBM, PC, PC/AT, and PC-DOS are trademarks of International Business Machines Corp.

Microsoft, MS-DOS, and Windows are registered trademarks of Microsoft Corporation.

OpenWindows, SunOS, Solaris, Sun Type 4, and Sun Type 5 are trademarks of Sun Microsystems, Inc.

SPARC and SPARCstation are trademarks of SPARC International, Inc. and are licensed exclusively to Sun Microsystems, Inc.

UNIX is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company Limited.

X Window System is a trademark of the Massachusetts Institute of Technology.

If You Need Assistance . . .

World-Wide Web Sites

TI Online	http://www.ti.com
Semiconductor Product Information Center (PIC)	http://www.ti.com/sc/docs/pic/home.htm
DSP Solutions	http://www.ti.com/dsps
320 Hotline On-line™	http://www.ti.com/sc/docs/dsps/support.html

North America, South America, Central America

Product Information Center (PIC)	(972) 644-5580	
TI Literature Response Center U.S.A.	(800) 477-8924	
Software Registration/Upgrades	(214) 638-0333	Fax: (214) 638-7742
U.S.A. Factory Repair/Hardware Upgrades	(281) 274-2285	
U.S. Technical Training Organization	(972) 644-5580	
DSP Hotline	(281) 274-2320	Fax: (281) 274-2324 Email: dsph@ti.com
DSP Modem BBS	(281) 274-2323	
DSP Internet BBS via anonymous ftp to ftp://ftp.ti.com/mirrors/tms320bbs		

Europe, Middle East, Africa

European Product Information Center (EPIC) Hotlines:

Multi-Language Support	+33 1 30 70 11 69	Fax: +33 1 30 70 10 32	Email: epic@ti.com
Deutsch	+49 8161 80 33 11 or +33 1 30 70 11 68		
English	+33 1 30 70 11 65		
Francais	+33 1 30 70 11 64		
Italiano	+33 1 30 70 11 67		
EPIC Modem BBS	+33 1 30 70 11 99		
European Factory Repair	+33 4 93 22 25 40		
Europe Customer Training Helpline		Fax: +49 81 61 80 40 10	

Asia-Pacific

Literature Response Center	+852 2 956 7288	Fax: +852 2 956 2200
Hong Kong DSP Hotline	+852 2 956 7268	Fax: +852 2 956 1002
Korea DSP Hotline	+82 2 551 2804	Fax: +82 2 551 2828
Korea DSP Modem BBS	+82 2 551 2914	
Singapore DSP Hotline		Fax: +65 390 7179
Taiwan DSP Hotline	+886 2 377 1450	Fax: +886 2 377 2718
Taiwan DSP Modem BBS	+886 2 376 2592	

Japan

Product Information Center	+0120-81-0026 (in Japan)	Fax: +0120-81-0036 (in Japan)
	+03-3457-0972 or (INTL) 813-3457-0972	Fax: +03-3457-1259 or (INTL) 813-3457-1259
DSP Hotline	+03-3769-8735 or (INTL) 813-3769-8735	Fax: +03-3457-7071 or (INTL) 813-3457-7071
DSP BBS via Nifty-Serve	Type "Go TIASP"	

Documentation

When making suggestions or reporting errors in documentation, please include the following information that is on the title page: the full title of the book, the publication date, and the literature number.

Mail: Texas Instruments Incorporated	Email: comments@books.sc.ti.com
Technical Documentation Services, MS 702	
P.O. Box 1443	
Houston, Texas 77251-1443	

Note: When calling a Literature Response Center to order documentation, please specify the literature number of the book.

Contents

1	Installing the Simulator and C Source Debugger With Windows 3.1	1-1
	<i>Lists the hardware and software you need to install the simulator and C source debugger; provides installation instructions for PC systems running Windows 3.1.</i>	
1.1	System Requirements	1-2
	Hardware checklist	1-2
	Software checklist	1-3
1.2	Step 1: Installing the Simulator and Debugger Software	1-4
1.3	Step 2: Setting Up the Debugger Environment	1-5
	Modifying the PATH statement	1-6
	Setting up the environment variables	1-6
	Invoking the modified or new batch file	1-7
1.4	Step 3: Verifying the Installation	1-8
2	Installing the Simulator and C Source Debugger With SunOS	2-1
	<i>Lists the hardware and software you need to install the simulator and C source debugger; provides installation instructions for SPARCstations running SunOS.</i>	
2.1	System Requirements	2-2
	Hardware checklist	2-2
	Software checklist	2-2
2.2	Step 1: Installing the Simulator and Debugger Software	2-4
	Mounting the CD-ROM	2-4
	Copying the files	2-5
	Unmounting the CD-ROM	2-5
2.3	Step 2: Setting Up the Debugger Environment	2-6
	Modifying the path statement	2-6
	Setting up the environment variables	2-6
	Reinitializing your shell	2-8
2.4	Step 3: Verifying the Installation	2-9
2.5	Using the Debugger With the X Window System	2-10
	Using the special keys on the keyboard	2-10
	Changing the debugger font	2-11
	Color mappings on monochrome screens	2-11

3	Installing the Simulator and C Source Debugger With HP-UX	3-1
	<i>Lists the hardware and software you need to install the simulator and C source debugger; provides installation instructions for HP workstations running HP-UX.</i>	
3.1	System Requirements	3-2
	Hardware checklist	3-2
	Software checklist	3-3
3.2	Step 1: Installing the Simulator and Debugger Software	3-4
	Mounting the CD-ROM	3-4
	Copying the files and setting up the simulator	3-4
	Unmounting the CD-ROM	3-5
3.3	Step 2: Setting Up the Debugger Environment	3-6
	Modifying the path statement	3-6
	Setting up the environment variables	3-6
	Reinitializing your shell	3-8
3.4	Step 3: Verifying the Installation	3-9
3.5	Using the Debugger With the X Window System	3-10
	Using the special keys on the keyboard	3-10
	Changing the debugger font	3-11
	Color mappings on monochrome screens	3-11
4	Release Notes	4-1
	<i>Details the features added or changed for this release.</i>	
	COFF version 2	4-1
	Multiple MEMORY windows	4-1
	Multiple WATCH windows	4-2
	New and updated debugger commands	4-3
	Changes to the TMS320C5xx C Source Debugger User's Guide	4-4
5	Defining a Memory Map	5-1
	<i>Provides instructions for defining and using a memory map to simulate 'C54x ports. The memory map tells the debugger which areas of memory it can and cannot access. This chapter replaces Chapter 6, Defining a Memory Map, in the TMS320C5xx C Source Debugger User's Guide.</i>	
5.1	The Memory Map: What It Is and Why You Must Define It	5-2
	Defining the memory map in a batch file	5-2
	Potential memory map problems	5-3
5.2	A Sample Memory Map	5-4
5.3	Identifying Usable Memory Ranges	5-5
	Notes on using the MA command	5-6
	Memory mapping with the simulator (PCs only)	5-8
5.4	Customizing the Memory Map	5-9
	Mapping on-chip dual-access RAM from data memory to program memory	5-10
	Simulating data memory (ROM)	5-10
	Programming your memory	5-11

5.5	Enabling Memory Mapping	5-12
5.6	Checking the Memory Map	5-13
5.7	Modifying the Memory Map During a Debugging Session	5-14
	Returning to the original memory map	5-15
5.8	Using Multiple Memory Maps for Multiple Target Systems (Emulator Only)	5-16
5.9	Simulating I/O Space (Simulator Only)	5-17
	Connecting an I/O port	5-17
	Disconnecting an I/O port	5-21
5.10	Simulating External Interrupts (Simulator Only)	5-22
	Setting up your input file	5-22
	Programming the simulator	5-24
5.11	Simulating Peripherals (Simulator Only)	5-26
5.12	Simulating Standard Serial Ports (Simulator Only)	5-27
	Setting up your transmit and receive operations	5-28
	Connecting I/O files	5-29
	Programming the simulator	5-30
5.13	Simulating Buffered Serial Ports (Simulator Only)	5-31
	Setting up your transmit and receive operations	5-32
	Connecting I/O files	5-33
	Programming the simulator	5-33
5.14	Simulating TDM Serial Ports (Simulator Only)	5-34
	Setting up your transmit and receive operations	5-35
	Connecting I/O files	5-36
	Programming the simulator	5-36

Examples

- 5-1 Sample Initialization Batch File for Use With the TMS320C54x Simulator 5-4
- 5-2 Sample Memory Map for the TMS320C54x Using Memory Cache Capabilities 5-8
- 5-3 Connecting Input and Output Ports to Input or Output Files 5-19
- 5-4 Connecting an Input Port to an Input File 5-20
- 5-5 Using the PINC Command to Connect the Input File 5-24

Installing the Simulator and C Source Debugger With Windows 3.1

This chapter helps you install the TMS320C54x simulator and the C source debugger on PC systems running Microsoft™ Windows 3.1. After completing the installation, see the *TMS320C5xx C Source Debugger User's Guide* for instructions on using the debugger.

With Windows, you can freely move or resize the debugger display on the screen. If the resized display is bigger than the debugger requires, the extra space is not used. If the resized display is smaller than the debugger requires, the display is clipped. When the display is clipped, it cannot be scrolled.

You may want to create an icon to make it easier to invoke the debugger from within the Windows environment. Refer to your Windows manual for details.

You should run Windows in either the standard mode or the 386-enhanced mode to get the best results when using the 'C54x simulator.

Topic	Page
1.1 System Requirements	1-2
1.2 Step 1: Installing the Simulator and Debugger Software	1-4
1.3 Step 2: Setting Up the Debugger Environment	1-5
1.4 Step 3: Verifying the Installation	1-8

1.1 System Requirements

The following checklists detail items that are shipped with the 'C54x C source debugger and simulator and any additional items you need to use these tools.

Hardware checklist

- | | | |
|--------------------------|--------------------------------|---|
| <input type="checkbox"/> | Host | An IBM™ PC/AT™ or 100% compatible ISA/EISA-based PC™ with a hard-disk system and a 1.2M-byte floppy-disk drive; a 386 or higher is highly recommended |
| <input type="checkbox"/> | Memory | Minimum of 640K bytes and at least 256K bytes of extended memory |
| <input type="checkbox"/> | Monitor | Monochrome or color monitor (color recommended) |
| <input type="checkbox"/> | Optional hardware | A Microsoft-compatible mouse |
| <input type="checkbox"/> | | An EGA- or VGA-compatible graphics display card and a large (17-inch or 19-inch) monitor. The debugger has several options that allow you to change the overall size of the debugger display. To use a larger screen size, you must invoke the debugger with the appropriate option. For more information about options, see the invocation information in the <i>TMS320C5xx C Source Debugger User's Guide</i> . |
| <input type="checkbox"/> | Miscellaneous materials | Blank, formatted disks |

Software checklist

- Operating system** Windows version 3.1
- Software tools** 'C54x assembler and linker
Optional: 'C54x C compiler
- Optional files included with the debugger package** *siminit.cmd* is a general-purpose batch file that contains debugger commands. This batch file, shipped with the debugger, defines a 'C54x memory map. If this file is not present when you invoke the debugger, then all memory is invalid at first. When you first start using the debugger, this memory map should be sufficient for your needs. Later, you may want to define your own memory map. For information about defining your own memory map, see Chapter 5, *Defining a Memory Map*.
- sim54x.cmd* batch files (*sim541.cmd*, *sim542.cmd*, *sim543.cmd*, *sim545.cmd*, *sim546.cmd*, *sim548.cmd*, and *sim545lp.cmd*) contain commands that configure a memory map. Each file simulates a different device—'C541, 'C542, 'C543, 'C545, 'C546, 'C548, or 'C545LP.
- init.clr* is a general-purpose screen configuration file. If *init.clr* isn't present when you invoke the debugger, the debugger uses the default screen configuration.
- init.25*, *init.43*, and *init.50* have been provided for basic 80×25, 80×43, and 80×50 screen sizes, respectively. The *init.clr* file brings up the debugger in 80×25 mode. To bring up the debugger in another mode, copy one of the *init.xx* files to the *init.clr* file. When you first invoke the debugger, the default screen configuration should be sufficient for your needs. Later, you may want to define your own custom configuration.
- The default configuration is for color monitors; an additional file, *mono.clr*, can be used for monochrome monitors. When you first start to use the debugger, the default screen configuration should be sufficient for your needs. Later, you may want to define your own custom configuration.

For information about these files and about setting up your own screen configuration, see the information about customizing the debugger display in the *TMS320C5xx C Source Debugger User's Guide*.

1.2 Step 1: Installing the Simulator and Debugger Software

This section explains how to install the simulator and debugger on a hard-disk system.

- 1) Make a backup copy of each product disk.
- 2) On your hard disk or system disk, create a directory named sim54x. This directory will contain the 'C54x software. Type:

```
MD C:\sim54x
```

- 3) Insert the debugger product disk into drive A. Copy the contents of the disk:

```
COPY A:\*.* C:\sim54x\*.* /V
```

The Windows version of the debugger executable is called sim54xw.exe.

1.3 Step 2: Setting Up the Debugger Environment

To ensure that your debugger works correctly, you must:

- Modify the PATH statement to identify the sim54x directory.
- Define environment variables so that the debugger can find the files it needs.

Note:

Not only must you do these things before you invoke the debugger for the first time, *you must do them any time you power up or reboot your PC.*

You can accomplish these tasks by entering individual DOS commands, but it is simpler to put the commands in a batch file. You can edit your system's autoexec.bat file to accomplish these tasks. In some cases, however, modifying the autoexec.bat may interfere with other applications running on your PC, so you can create a separate batch file that performs these tasks.

Figure 1–1 (a) shows an example of an autoexec.bat file that contains the suggested modifications (highlighted in bold type). Figure 1–1 (b) shows a sample batch file that you could create instead of editing the autoexec.bat file. For the purpose of discussion, assume that this sample file is named *initdb.bat*. The subsections following the figure explain these modifications.

Figure 1–1. DOS-Command Setup for the Debugger

(a) Sample autoexec.bat file to use with the debugger and simulator

PATH statement	→	<pre> DATE TIME ECHO OFF PATH=C:\DOS;C:\c5xxtool;C:\sim54x </pre>
Environment variables	→	<pre> SET D_DIR=C:\sim54x SET D_SRC=C:\c54xtool SET D_OPTIONS=-b SET C_DIR=C:\c54xcode CLS </pre>

(b) Sample batch file, *initdb.bat*, to use with the debugger and simulator

PATH statement	→	<pre> PATH=C:\sim54x;%PATH% </pre>
Environment variables	→	<pre> SET D_DIR=C:\sim54x SET D_SRC=C:\c54xcode SET D_OPTIONS=-b </pre>

Modifying the PATH statement

Define a path to the debugger directory. The general format for doing this is:

```
PATH=C:\sim54x
```

This allows you to invoke the debugger without specifying the name of the directory that contains the debugger executable file.

- If you are modifying an autoexec.bat that already contains a PATH statement, simply include **;C:\sim54x** at the end of the statement, as shown in Figure 1-1 (a).
- If you are creating an initdb.bat file, use a different format for the PATH statement:

```
PATH=C:\sim54x;%PATH%
```

The addition of **;%path%** ensures that this PATH statement will not undo PATH statements in any other batch files (including the autoexec.bat file).

Setting up the environment variables

An environment variable is a special system symbol that a program uses for finding or obtaining certain types of information. The debugger uses three environment variables, named D_DIR, D_SRC, and D_OPTIONS. Set up these environment variables in your batch file as described in the following list. The format for doing this is the same whether you edit the autoexec.bat file or create an initdb.bat file.

- Identify the sim54x directory with D_DIR. Enter:

```
SET D_DIR=C:\sim54x
```

(Be careful not to precede the equal sign with a space.)

This directory contains auxiliary files (such as siminit.cmd) that the debugger needs.

- Identify with D_SRC any directories that contain program source files that you want to look at while you are debugging code. The general format for doing this is:

```
SET D_SRC=pathname1;pathname2...
```

(Be careful not to precede the equal sign with a space.)

For example, if your 'C54x programs were in a directory named *csource* on drive C, the D_SRC setup would be:

```
SET D_SRC=C:\CSOURCE
```

- Identify with D_OPTIONS the invocation options that you want to use regularly. Use this format:

SET D_OPTIONS= [*filename*] [*options*]

(Be careful not to precede the equal sign with a space.)

The *filename* identifies the optional object file for the debugger to load, and *options* list the options you want to use at invocation. These are the options that you can identify with D_OPTIONS:

Option	Brief Description
-b	Select a screen size of 80 characters by 43 lines (EGA or VGA)
-bb	Select a screen size of 80 characters by 50 lines (VGA only)
-bl#	Select a screen length of # lines (default is 25)
-bw#	Select a screen width of # characters (default is 80)
-i <i>pathname</i>	Identify additional directories
-min	Select the minimal debugging mode
-mv <i>version</i>	Specify the memory map to use with the simulator
-profile	Enter profiling environment
-s	Load the symbol table only
-t <i>filename</i>	Identify a new initialization file
-v	Load without the symbol table

You can override D_OPTIONS by invoking the debugger with the -x option.

For more information about options, see the invocation instructions in the *TMS320C5xx C Source Debugger User's Guide*.

Invoking the modified or new batch file

- If you modify the autoexec.bat file, be sure to invoke it before invoking the debugger for the first time. To invoke this file, enter:

AUTOEXEC 

- If you create an initdb.bat file, you must invoke it *before* entering Windows. You must invoke initdb.bat any time that you power up or reboot your PC. To invoke this file, enter:

INITDB 

1.4 Step 3: Verifying the Installation

To ensure that you have correctly installed the simulator and debugger software, follow these steps:

- 1) Start Windows.
- 2) In the Program Manager or File Manager, select Run... from the File menu.
- 3) In the Command Line field of the Run dialog box, enter:

```
c:\sim54x\sim54xw sample
```

You should see a display similar to this one:

The screenshot displays the C54x Debugger interface with the following sections:

- DISASSEMBLY:** A list of assembly instructions with addresses, hex values, mnemonics, and operands.

0119	7718	c_int00:	SIM	#0011dh,SP
011b	6bf8		ADDM	003ffh,*(SP)
011e	68f8		ANDM	0fffh,*(SP)
0121	f7b8		SSBX	SXM
0122	f7be		SSBX	CPL
0123	f020		LD	#00173h,0,A
0125	f100		ADD	#00001h,0,A,B
0127	f84d		BC	0013ch,BEQ
0129	f073		B	00136h
012b	7ef8		READA	*(AR2)
012d	f000		ADD	#00001h,0,A,A
012f	47f8		RPT	*(AR1)
0131	7e92		READA	*AR2+
0132	00f8		ADD	*(AR1),A
0134	f000		ADD	#00001h,0,A,A
- CPU:** A table of CPU registers and their values.

AG	00	AHL	00000000
BG	00	BHL	00000000
PC	0119	SP	0000
AR0	0000	AR1	0000
AR2	0000	AR3	0000
AR4	0000	AR5	0000
AR6	0000	AR7	0000
BK	0000	BRC	0000
RSA	0000	REA	0000
ST0	1800	ST1	2900
IMR	0000	IFR	0000
T	0000	TRN	0000
PMST	ffc0	RPTC	0000
- COMMAND:** A text window showing the debugger's status and user input.


```
C54x Debugger Version 2.15b
Copyright (c) 1989-1996 Texas Ins
Loading sample.out
 35 Symbols loaded
Done
>>>
```
- MEMORY:** A table showing memory contents at various addresses.

0000	0000	0000	0000	0000	0000	0000	1800
0007	2900	0000	0000	0000	0000	0000	0000
000e	0000	0000	0000	0000	0000	0000	0000
0015	0000	0000	0000	0000	0000	0000	0000
001c	0000	ffc0	0000	0000	0000	0000	0000
0023	0000	ffff	ffff	0000	0000	0000	0000

If you do not see a display, then your debugger or simulator may not be installed properly. Go back through the installation instructions and be sure that you have followed each step correctly, then reenter the command above.

Installing the Simulator and C Source Debugger With SunOS

This chapter helps you install the TMS320C54x simulator and the C source debugger on a SPARCstation running SunOS. After completing the installation, see the *TMS320C5xx C Source Debugger User's Guide* for instructions on using the debugger.

Topic	Page
2.1 System Requirements	2-2
2.2 Step 1: Installing the Simulator and Debugger Software	2-4
2.3 Step 2: Setting Up the Debugger Environment	2-6
2.4 Step 3: Verifying the Installation	2-9
2.5 Using the Debugger With the X Window System	2-10

2.1 System Requirements

The following checklists detail items that are shipped with the 'C54x C source debugger and simulator and additional items you need to use these tools.

Hardware checklist

- | | | |
|--------------------------|--------------------------|--|
| <input type="checkbox"/> | Host | A SPARCstation or a system that is 100% compatible with a SPARCstation 2 class or higher |
| <input type="checkbox"/> | Monitor | Monochrome or color monitor (color recommended) |
| <input type="checkbox"/> | Disk space | 2M bytes of disk space |
| <input type="checkbox"/> | Required hardware | CD-ROM drive |
| <input type="checkbox"/> | Optional hardware | Mouse |

Software checklist

- | | | |
|--------------------------|--|---|
| <input type="checkbox"/> | Operating system | SunOS version 4.1.3 (or higher) or SunOS version 5.x (also known as Solaris™ 2.x) using an X Window System type window manager, such as OpenWindows™ version 3.0 (or higher). If you are using SunOS 5.x, you must have the Binary Compatibility Package (BCP) installed; if you don't, get your system administrator's help. |
| <input type="checkbox"/> | Root privileges | If you are running SunOS 4.1.x, 5.0, or 5.1, you <i>must</i> have root privileges to mount and unmount the CD-ROM. If you do not have root privileges, get help from your system administrator. |
| <input type="checkbox"/> | Software tools | 'C54x assembler and linker
Optional: 'C54x C compiler |
| <input type="checkbox"/> | Optional files included with the debugger package | <i>siminit.cmd</i> is a general-purpose batch file that contains debugger commands. This batch file, shipped with the debugger, defines a 'C54x memory map. If this file is not present when you invoke the debugger, then all memory is invalid at first. When you first start using the debugger, this memory map should be sufficient for your needs. Later, you may want to define your own memory map. For information about defining your own memory map, see Chapter 5, <i>Defining a Memory Map</i> . |
| <input type="checkbox"/> | | <i>sim54x.cmd</i> batch files (<i>sim541.cmd</i> , <i>sim542.cmd</i> , <i>sim543.cmd</i> , <i>sim545.cmd</i> , <i>sim546.cmd</i> , <i>sim548.cmd</i> , and <i>sim545lp.cmd</i>) contain commands that configure a memory map. Each file simulates a different device—'C541, 'C542, 'C543, 'C545, 'C546, 'C548, or 'C545LP. |
| <input type="checkbox"/> | | <i>init.clr</i> is a general-purpose screen configuration file. If <i>init.clr</i> isn't present when you invoke the debugger, the debugger uses the default screen configuration. |



init.25, *init.43*, and *init.50* have been provided for basic 80×25, 80×43, and 80×50 screen sizes, respectively. The *init.clr* file brings up the debugger in 80×25 mode. To bring up the debugger in another mode, copy one of the *init.xx* files to the *init.clr* file. When you first invoke the debugger, the default screen configuration should be sufficient for your needs. Later, you may want to define your own custom configuration.



The default configuration is for color monitors; an additional file, *mono.clr*, can be used for monochrome monitors. When you first start to use the debugger, the default screen configuration should be sufficient for your needs. Later, you may want to define your own custom configuration.

For information about these files and about setting up your own screen configuration, see the information about customizing the debugger display in the *TMS320C5xx C Source Debugger User's Guide*.

2.2 Step 1: Installing the Simulator and Debugger Software

This section explains how to install the simulator and debugger software on your hard-disk system. The software package is shipped on a CD-ROM. To install the software, you must mount the CD-ROM, copy the files, and unmount the CD-ROM.

Note:

If you are running SunOS 4.1.x, 5.0, or 5.1, you *must* have root privileges to mount or unmount the CD-ROM. If you do not have root privileges, get help from your system administrator.

Mounting the CD-ROM

The steps to mount the CD-ROM vary according to your operating system version:

- If you have a SunOS 4.1.x, load the CD-ROM into the drive. As root, enter the following from a command shell:

```
mount -rt hsfs /dev/sr0 /cdrom   
exit   
cd /cdrom/sparc 
```

- If you have SunOS 5.0 or 5.1, load the CD-ROM into the drive. As root, enter the following from a command shell:

```
mount -rF hsfs /dev/sr0 /cdrom   
exit   
cd /cdrom/cdrom0/sparc 
```

- If you have SunOS 5.2 or higher:

- If your CD-ROM drive is already attached, load the CD-ROM into the drive and enter the following from a command shell:

```
cd /cdrom/cdrom0/sparc 
```

- If you do not have a CD-ROM drive attached, you must shut down your system to the PROM level, attach the CD-ROM drive, and enter the following:

```
boot -r 
```

After you log into your system, load the CD-ROM into the drive and enter the following from a command shell:

```
cd /cdrom/cdrom0/sparc 
```

Copying the files

After you have mounted the CD-ROM, you must create the directory that will contain the debugger software and copy the software to that directory.

- 1) Create a directory named `sim54x` on your hard disk. To create this directory, enter:

```
mkdir /your_pathname/sim54x
```

- 2) Copy the files from the CD-ROM to your hard-disk system:

```
cp -r * /your_pathname/sim54x
```

Unmounting the CD-ROM

You must unmount the CD-ROM after copying the files.

- If you have SunOS 4.1.x, 5.0, or 5.1, as root, enter the following from a command shell:

```
cd  
umount /cdrom  
eject /dev/sr0  
exit
```

- If you have SunOS 5.2 or higher, enter the following from a command shell:

```
cd  
eject
```

2.3 Step 2: Setting Up the Debugger Environment

To ensure that your debugger works correctly, you must:

- Modify the shell path variable to include the sim54x directory.
- Define environment variables so that the debugger can find the files it needs.
- Reinitialize your shell.

Modifying the path statement

You must include the debugger directory in your shell path. To do this, you must modify the shell configuration file in your home directory (for example, the .cshrc file for a C shell). This file must include the pathname to your sim54x directory in your path if it is not already there. The following statement is an example of what a typical path-variable definition looks like:

```
set path = (. /bin /usr/ucb /usr/contrib/bin /usr/bin \  
/usr/openwin/bin)
```

Following is an example of that path variable modified to include the pathname to sim54x. The part of the path in bold type is the modification:

```
set path = (. /bin /usr/ucb /usr/contrib/bin /usr/bin \  
/usr/openwin/bin /user/fred/sim54x)
```

You would use the path to your home directory in place of `/user/fred`.

Setting up the environment variables

An environment variable is a special system symbol that a program uses for finding or obtaining certain types of information. The debugger uses four environment variables, named D_DIR, D_SRC, D_OPTIONS, and DISPLAY (X Window System™ only). You can set up these environment variables in your shell configuration file. Follow these steps to set up the environment variables:

- Identify the sim54x directory with D_DIR. This directory contains auxiliary files (such as siminit.cmd) that the debugger needs. The general format for doing this is:

```
setenv D_DIR "pathname"
```

For example, if the files are in a directory named `/user/fred/sim54x`, the D_DIR setup would be:

```
setenv D_DIR "/user/fred/sim54x"
```

(Be sure to enclose the directory name within quotes.)

- Identify with `D_SRC` any directories that contain program source files that you want to look at while you are debugging code. The general format for doing this is:

```
setenv D_SRC "pathname1;pathname2..."
```

(Be sure to enclose the path names within one set of quotes.)

For example, if your 'C54x programs were in a directory named `/user/fred/c54xsource`, the `D_SRC` setup would be:

```
setenv D_SRC "/user/fred/c54xsource"
```

- Identify with `D_OPTIONS` the invocation options that you want to use regularly. Use this format:

```
setenv D_OPTIONS "[filename] [options]"
```

(Be sure to enclose the filename and options within one set of quotes.)

The *filename* identifies the optional object file for the debugger to load, and *options* list the options you want to use at invocation. These are the options that you can identify with `D_OPTIONS`:

Option	Brief Description
<code>-b</code>	Select a screen size of 80 characters by 43 lines (EGA or VGA)
<code>-bb</code>	Select a screen size of 80 characters by 50 lines (VGA only)
<code>-d machine name</code>	Display debugger on a different machine
<code>-i pathname</code>	Identify additional directories
<code>-min</code>	Select the minimal debugging mode
<code>-mv version</code>	Specify the memory map to use with the simulator
<code>-profile</code>	Enter profiling environment
<code>-s</code>	Load the symbol table only
<code>-t filename</code>	Identify a new initialization file
<code>-v</code>	Load without the symbol table

You can override `D_OPTIONS` by invoking the debugger with the `-x` option.

For more information about options, see the invocation instructions in the *TMS320C5xx C Source Debugger User's Guide*.

- If you are using the X Window System, you can display the debugger on a different machine than the one the parallel debug manager and simulator core are running on. To do so, you need to set up two environment variables:

- Be sure that the LD_LIBRARY_PATH environment variable is set to the following:

```
LD_LIBRARY_PATH $OPENWINHOME/lib
```

If the LD_LIBRARY_PATH variable is not set correctly, use this command:

```
setenv LD_LIBRARY_PATH "$OPENWINHOME/lib"
```

- Set up the DISPLAY environment variable. The general format for doing this is:

```
setenv DISPLAY "machinename"
```

You can also specify a different machine by using the `-d` debugger option (see the *TMS320C5xx C Source Debugger User's Guide* for more information). If you use both the DISPLAY environment variable and `-d`, the `-d` option overrides DISPLAY.

Reinitializing your shell

When you modify your shell configuration file, you must ensure that the changes are made to your current session. For example, if you are using a C shell, use this command to reread the `.cshrc` file:

```
source ~/.cshrc 
```

2.4 Step 3: Verifying the Installation

To ensure that you have correctly installed the simulator and debugger software, enter this command at the system prompt:

```
sim54x sample
```

You should see a display similar to this one:

The screenshot displays the C54x Debugger interface with the following sections:

- DISASSEMBLY:** A list of instructions with addresses, hex values, mnemonics, and operands. A watch window shows 'c_int00:'.
- CPU:** A table of register values.
- COMMAND:** A text window showing the debugger's startup sequence.
- MEMORY:** A table of memory addresses and their corresponding hex values.

Address	Hex	Mnemonic	Operand
0119	7718	SIM	#001dh,SP
011b	6bf8	ADDM	003fh,*(SP)
011e	68f8	ANDM	0fffh,*(SP)
0121	f7b8	SSBX	SXM
0122	f7be	SSBX	CPL
0123	f020	LD	#00173h,0,A
0125	f100	ADD	#00001h,0,A,B
0127	f84d	BC	0013ch,BEQ
0129	f073	B	00136h
012b	7ef8	READA	*(AR2)
012d	f000	ADD	#00001h,0,A,A
012f	47f8	RPT	*(AR1)
0131	7e92	READA	*AR2+
0132	00f8	ADD	*(AR1),A
0134	f000	ADD	#00001h,0,A,A

Register	Value	Register	Value
AG	00	AHL	00000000
BG	00	BHL	00000000
PC	0119	SP	0000
AR0	0000	AR1	0000
AR2	0000	AR3	0000
AR4	0000	AR5	0000
AR6	0000	AR7	0000
BK	0000	BRC	0000
RSA	0000	REA	0000
ST0	1800	ST1	2900
IMR	0000	IFR	0000
T	0000	TRN	0000
PMST	ffc0	RPTC	0000


```

COMMAND
C54x Debugger Version 2.15b
Copyright (c) 1989-1996 Texas Ins
Loading sample.out
  35 Symbols loaded
Done
_
>>>

```


Address	Hex	Address	Hex
0000	0000	0000	0000
0007	2900	0000	0000
000e	0000	0000	0000
0015	0000	0000	0000
001c	0000	ffc0	0000
0023	0000	ffff	ffff

If you do not see a display, then your debugger or simulator may not be installed properly. Go back through the installation instructions and be sure that you have followed each step correctly, then reenter the command above.

2.5 Using the Debugger With the X Window System

If you use the X Window System to run the 'C54x debugger, you need to know about the keyboard's special keys, the debugger font, and using the debugger on a monochrome monitor.

Using the special keys on the keyboard

The debugger uses some special keys that you can map differently than your particular keyboard. Some keyboards, such as the Sun Type 5™ keyboard, may have these special symbols on separate keys. Other keyboards, such as the Sun Type 4™ keyboard, do not have the special keys, but the functions are available.

The special keys that the debugger uses are shown in the following table with their corresponding keysym. A *keysym* is a label that interprets a keystroke; it allows you to modify the action of a key on the keyboard.

Debugger Key Needed	Keysym for That Function
(F1) to (F10)	F1 to F10
PAGE UP	Prior
PAGE DOWN	Next
HOME	Home
END	End
INSERT	Insert
→	Right
←	Left
↑	Up
↓	Down

Use the X utility `xev` to check the keysyms associated with your keyboard. If you need to change the keysym definitions, use the `xmodmap` utility. For example, you could create a file that contains the following commands and use that file with `xmodmap` to map a Sun Type 4 keyboard to the keys listed above:

```

keycode 13 = End
keycode 50 = Down
keycode 35 = Next
keycode 51 = Left
keycode 52 = Right
keycode 27 = Home
keycode 39 = Up
keycode 29 = Prior
keycode 45 = Insert

```

Refer to your X Window System documentation for more information about using `xev` and `xmodmap`.

Changing the debugger font

You can change the font of the debugger screen by using the `xrdb` utility and modifying the `.Xdefaults` file in your root directory. For example, to change the 'C54x debugger font to Courier, add the following line to the `.Xdefaults` file:

```
sim54x*font:courier
```

For more information about using `xrdb` to change the font, refer to your X Window System documentation.

Color mappings on monochrome screens

Although a color monitor is recommended, you can use a monochrome monitor. The following table shows the color mappings for monochrome screens:

Color	Appearance on Monochrome Screen
black	black
blue	black
green	white
cyan	white
red	black
magenta	black
yellow	white
white	white

Installing the Simulator and C Source Debugger With HP-UX

This chapter helps you install the TMS320C54x simulator and the C source debugger on a HP 9000 series 700™ PA-RISC™ system running HP-UX. After completing the installation, see the *TMS320C5xx C Source Debugger User's Guide* for instructions on using the debugger.

Topic	Page
3.1 System Requirements	3-2
3.2 Step 1: Installing the Simulator and Debugger Software	3-4
3.3 Step 2: Setting Up the Debugger Environment	3-6
3.4 Step 3: Verifying the Installation	3-9
3.5 Using the Debugger With the X Window System	3-10

3.1 System Requirements

The following checklists detail items that are shipped with the 'C54x C source debugger and simulator and additional items you need to use these tools.

Hardware checklist

- | | | |
|--------------------------|--------------------------|---|
| <input type="checkbox"/> | Host | An HP 9000 Series 700 PA-RISC system |
| <input type="checkbox"/> | Monitor | Monochrome or color (color recommended) |
| <input type="checkbox"/> | Disk space | 2M bytes of disk space |
| <input type="checkbox"/> | Required hardware | CD-ROM drive |
| <input type="checkbox"/> | Optional hardware | Mouse |

Software checklist

- | | | |
|--------------------------|--|--|
| <input type="checkbox"/> | Operating system | HP-UX 9.x or later |
| <input type="checkbox"/> | Root privileges | You <i>must</i> have root privileges to mount and unmount the CD-ROM. If you do not have root privileges, get help from your system administrator. |
| <input type="checkbox"/> | Software tools | 'C54x assembler and linker
Optional: 'C54x C compiler |
| <input type="checkbox"/> | Optional files included with the debugger package | <i>siminit.cmd</i> is a general-purpose batch file that contains debugger commands. This batch file, shipped with the debugger, defines a 'C54x memory map. If this file is not present when you invoke the debugger, then all memory is invalid at first. When you first start using the debugger, this memory map should be sufficient for your needs. Later, you may want to define your own memory map. For information about defining your own memory map, see Chapter 5, <i>Defining a Memory Map</i> . |
| <input type="checkbox"/> | | <i>sim54x.cmd</i> batch files (<i>sim541.cmd</i> , <i>sim542.cmd</i> , <i>sim543.cmd</i> , <i>sim545.cmd</i> , <i>sim546.cmd</i> , <i>sim548.cmd</i> , and <i>sim545lp.cmd</i>) contain commands that configure a memory map. Each file simulates a different device—'C541, 'C542, 'C543, 'C545, 'C546, 'C548, or 'C545LP. |
| <input type="checkbox"/> | | <i>init.clr</i> is a general-purpose screen configuration file. If <i>init.clr</i> isn't present when you invoke the debugger, the debugger uses the default screen configuration. |
| <input type="checkbox"/> | | <i>init.25</i> , <i>init.43</i> , and <i>init.50</i> have been provided for basic 80×25, 80×43, and 80×50 screen sizes, respectively. The <i>init.clr</i> file brings up the debugger in 80×25 mode. To bring up the debugger in another mode, copy one of the <i>init.xx</i> files to the <i>init.clr</i> file. When you first invoke the debugger, the default screen configuration should be sufficient for your needs. Later, you may want to define your own custom configuration. |
| <input type="checkbox"/> | | The default configuration is for color monitors; an additional file, <i>mono.clr</i> , can be used for monochrome monitors. When you first start to use the debugger, the default screen configuration should be sufficient for your needs. Later, you may want to define your own custom configuration.

For information about these files and about setting up your own screen configuration, see the information about customizing the debugger display in the <i>TMS320C5xx C Source Debugger User's Guide</i> . |

3.2 Step 1: Installing the Simulator and Debugger Software

This section explains how to install the simulator and debugger software on your hard-disk system. The software package is shipped on a CD-ROM. To install the software, you must mount the CD-ROM, copy the files, and unmount the CD-ROM.

Note:

You *must* have root privileges to mount or unmount the CD-ROM. If you do not have root privileges, get help from your system administrator.

Mounting the CD-ROM

As root, you can mount the CD-ROM using the UNIX™ mount command or the SAM (system administration manager):

- To use the UNIX mount command, enter:

```
mount -rt cdfs /dev/dsk/your_cdrom_device /cdrom   
exit 
```

Make the hp directory on the CD-ROM the current directory. For example, if the CD-ROM is mounted at /cdrom, enter:

```
cd /cdrom/hp 
```

- To use SAM to mount the CD-ROM, see the instructions in the HP documentation about SAM.

Copying the files and setting up the simulator

After you have mounted the CD-ROM, you must create the directory that will contain the debugger software and copy the software to that directory.

- 1) Create a directory named sim54x on your hard disk. To create this directory, enter:

```
mkdir sim54x 
```

- 2) Make the hp directory on the CD-ROM the current directory. For example, if the CD-ROM is mounted at /cdrom, enter:

```
cd /cdrom/hp 
```

- 3) Copy the files from the CD-ROM to your hard-disk system:

```
cp -r * sim54x 
```

Unmounting the CD-ROM

You must unmount the CD-ROM after copying the files. As root, enter:

```
cd [2]  
umount /cdrom [2]  
exit [2]
```

3.3 Step 2: Setting Up the Debugger Environment

To ensure that your debugger works correctly, you must:

- Modify the shell path variable to include the sim54x directory.
- Define environment variables so that the debugger can find the files it needs.
- Reinitialize your shell.

Modifying the path statement

You must include the debugger directory in your shell path. To do this, you must modify the shell configuration file in your home directory (for example, the .cshrc file for a C shell). This file must include the pathname to your sim54x directory in your path if it is not already there. The following statement is an example of what a typical path-variable definition looks like:

```
set path = (. /bin /usr/ucb /usr/contrib/bin /usr/bin \  
/usr/openwin/bin)
```

Following is an example of that path variable modified to include the pathname to sim54x. The part of the path in bold type is the modification:

```
set path = (. /bin /usr/ucb /usr/contrib/bin /usr/bin \  
/usr/openwin/bin /user/fred/sim54x)
```

You would use the path to your home directory in place of `/user/fred`.

Setting up the environment variables

An environment variable is a special system symbol that the debugger uses for finding or obtaining certain types of information. The debugger uses four environment variables, named D_DIR, D_SRC, D_OPTIONS, and DISPLAY (X Window System only). You can set up these environment variables in your shell configuration file. Follow these steps to set up the environment variables:

- Identify the sim54x directory with D_DIR. This directory contains auxiliary files (such as siminit.cmd) that the debugger needs. The general format for doing this is:

```
setenv D_DIR "pathname"
```

For example, if the files are in a directory named `/user/fred/sim54x`, the D_DIR setup would be:

```
setenv D_DIR "/user/fred/sim54x"
```

(Be sure to enclose the directory name within quotes.)

- Identify any directories that contain program source files that you want to look at while you are debugging code with D_SRC. The general format for doing this is:

```
setenv D_SRC "pathname1;pathname2..."
```

(Be sure to enclose the path names within one set of quotes.)

For example, if your C54x programs were in a directory named `/user/fred/c54xsource`, the D_SRC setup would be:

```
setenv D_SRC "/user/fred/c54xsource"
```

- Identify with D_OPTIONS the invocation options that you want to use regularly. Use this format:

```
setenv D_OPTIONS "[filename] [options]"
```

(Be sure to enclose the filename and options within one set of quotes.)

The *filename* identifies the optional object file for the debugger to load, and *options* list the options you want to use at invocation. These are the options that you can identify with D_OPTIONS:

Option	Brief Description
-b	Select a screen size of 80 characters by 43 lines (EGA or VGA)
-bb	Select a screen size of 80 characters by 50 lines (VGA only)
-d <i>machine name</i>	Display debugger on a different machine
-i <i>pathname</i>	Identify additional directories
-min	Select the minimal debugging mode
-mv <i>version</i>	Specify the memory map to use with the simulator
-profile	Enter profiling environment
-s	Load the symbol table only
-t <i>filename</i>	Identify a new initialization file
-v	Load without the symbol table

You can override D_OPTIONS by invoking the debugger with the `-x` option.

For more information about options, see the invocation instructions in the *TMS320C5xx C Source Debugger User's Guide*.

- If you are using the X Window System, you can display the debugger on a different machine than the one the parallel debug manager and simulator core are running on. To do so, you need to set up two environment variables:

- Be sure that the LD_LIBRARY_PATH environment variable is set to the following:

```
LD_LIBRARY_PATH $OPENWINHOME/lib
```

If the LD_LIBRARY_PATH variable is not set correctly, use this command:

```
setenv LD_LIBRARY_PATH "$OPENWINHOME/lib"
```

- Set up the DISPLAY environment variable. The general format for doing this is:

```
setenv DISPLAY "machinename"
```

You can also specify a different machine by using the `-d` debugger option (see the *TMS320C5xx C Source Debugger User's Guide* for more information). If you use both the DISPLAY environment variable and `-d`, the `-d` option overrides DISPLAY.

Reinitializing your shell

When you modify your shell configuration file, you must ensure that the changes are made to your current session. For example, if you are using a C shell, use this command to reread the `.cshrc` file:

```
source ~/.cshrc 
```

3.4 Step 3: Verifying the Installation

To ensure that you have correctly installed the simulator and debugger software, enter this command at the system prompt:

```
sim54x sample
```

You should see a display similar to this one:

The screenshot displays the C54x Debugger interface with the following sections:

- DISASSEMBLY:** A list of assembly instructions with addresses and hex values. A watch window shows 'c_int00:'.
- CPU:** A table of CPU registers and their values.
- COMMAND:** A log of commands and status messages.
- MEMORY:** A dump of memory contents at various addresses.

Address	Hex	Instruction	Comment
0119	7718	SIM	#001dh,SP
011b	6bf8	ADDM	003ffh,*(SP)
011e	68f8	ANDM	0fffh,*(SP)
0121	f7b8	SSBX	SXM
0122	f7be	SSBX	CPL
0123	f020	LD	#00173h,0,A
0125	f100	ADD	#00001h,0,A,B
0127	f84d	BC	0013ch,BEQ
0129	f073	B	00136h
012b	7ef8	READA	*(AR2)
012d	f000	ADD	#00001h,0,A,A
012f	47f8	RPT	*(AR1)
0131	7e92	READA	*AR2+
0132	00f8	ADD	*(AR1),A
0134	f000	ADD	#00001h,0,A,A

Register	Value
AG	00
BG	00
PC	0119
AR0	0000
AR2	0000
AR4	0000
AR6	0000
BK	0000
RSA	0000
ST0	1800
IMR	0000
T	0000
PMST	ffc0
AHL	00000000
BHL	00000000
SP	0000
AR1	0000
AR3	0000
AR5	0000
AR7	0000
BRC	0000
REA	0000
ST1	2900
IFR	0000
TRN	0000
RPTC	0000


```

COMMAND
C54x Debugger Version 2.15b
Copyright (c) 1989-1996 Texas Ins
Loading sample.out
  35 Symbols loaded
Done
>>>

```


Address	Hex						
0000	0000	0000	0000	0000	0000	0000	1800
0007	2900	0000	0000	0000	0000	0000	0000
000e	0000	0000	0000	0000	0000	0000	0000
0015	0000	0000	0000	0000	0000	0000	0000
001c	0000	ffc0	0000	0000	0000	0000	0000
0023	0000	ffff	ffff	0000	0000	0000	0000

If you do not see a display, then your debugger or simulator may not be installed properly. Go back through the installation instructions and be sure that you have followed each step correctly, then reenter the command above.

3.5 Using the Debugger With the X Window System

If you use the X Window System to run the 'C54x debugger, you need to know about the keyboard's special keys, the debugger font, and using the debugger on a monochrome monitor.

Using the special keys on the keyboard

The debugger uses some special keys that you can map differently than your particular keyboard. Some keyboards, such as the Sun Type 5 keyboard, may have these special symbols on separate keys. Other keyboards, such as the Sun Type 4 keyboard, do not have the special keys, but the functions are available.

The special keys that the debugger uses are shown in the following table with their corresponding keysym. A *keysym* is a label that interprets a keystroke; it allows you to modify the action of a key on the keyboard.

Debugger Key Needed	Keysym for That Function
(F1) to (F10)	F1 to F10
(PAGE UP)	Prior
(PAGE DOWN)	Next
(HOME)	Home
(END)	End
(INSERT)	Insert
(→)	Right
(←)	Left
(↑)	Up
(↓)	Down

Use the X utility `xev` to check the keysyms associated with your keyboard. If you need to change the keysym definitions, use the `xmodmap` utility. For example, you could create a file that contains the following commands and use that file with `xmodmap` to map a Sun Type 4 keyboard to the keys listed above:

```

keycode 13 = End
keycode 50 = Down
keycode 35 = Next
keycode 51 = Left
keycode 52 = Right
keycode 27 = Home
keycode 39 = Up
keycode 29 = Prior
keycode 46 = Insert

```

Refer to your X Window System documentation for more information about using `xev` and `xmodmap`.

Changing the debugger font

You can change the font of the debugger screen by using the `xrdb` utility and modifying the `.Xdefaults` file in your root directory. For example, to change the 'C54x debugger font to Courier, add the following line to the `.Xdefaults` file:

```
sim54x*font:courier
```

For more information about using `xrdb` to change the font, refer to your X Window System documentation.

Color mappings on monochrome screens

Although a color monitor is recommended, you can use a monochrome monitor. The following table shows the color mappings for monochrome screens:

Color	Appearance on Monochrome Screen
black	black
blue	black
green	white
cyan	white
red	black
magenta	black
yellow	white
white	white

Release Notes

This release of the TMS320C54x debugger contains general enhancements as well as enhancements specific to the 'C54x simulator version of the debugger. The following sections describe these enhancements.

COFF version 2

This release supports an expanded object file format called COFF2. The debugger can handle COFF object files developed with assembly language tools using the COFF0, COFF1, or COFF2 formats.

Multiple MEMORY windows

You can now open as many MEMORY windows as you want. The MEM command has a new, optional *window name* parameter. When you open an additional MEMORY window using the window name parameter, the debugger appends the *window name* to the MEMORY window label. The new basic syntax for the MEM command is:

```
mem expression [, display format] [, window name]
```

You can use the MEM command to:

- Open an additional MEMORY window
- Display a new memory range in an open MEMORY window

The *window name* parameter is optional if you are displaying a different memory range in the default MEMORY window. Use the *window name* parameter when you want to display a new memory range in one of the additional MEMORY windows.

Multiple WATCH windows

You can now access multiple WATCH windows. Use the *window name* parameter as described for each WATCH window command.

- The WA command has a new, optional *window name* parameter. When you open a WATCH window using the window name parameter, the debugger appends the *window name* to the WATCH window label. You can create as many WATCH windows as you need. The basic syntax for the WA command is:

```
wa expression [, [label] [, [display format] [, window name] ] ]
```

If you omit the *window name* parameter, the debugger displays the expression in the default WATCH window (labeled WATCH).

- The WD command deletes a specific item from the WATCH window. The WD command's *index number* parameter must correspond to one of the watch indexes listed in the WATCH window. The optional *window name* parameter is used to specify a particular WATCH window. If you do not use the *window name* parameter, the WD command deletes the item from the default WATCH window. The basic syntax for the WD command is:

```
wd index number [, window name]
```

- The WR command deletes all items from a WATCH window and closes the window.

- To close the default WATCH window, enter:

```
wr
```

- To close one of the additional WATCH windows, use this syntax:

```
wr window name
```

- To close all WATCH windows, enter:

```
wr *
```

New and updated debugger commands

The debugger now supports the following commands on all platforms.

cd, chdir	<i>Change Directory</i>
Syntax	cd [<i>directory name</i>] chdir [<i>directory name</i>]
Menu selection	none
Environments	<input checked="" type="checkbox"/> basic debugger <input type="checkbox"/> PDM <input checked="" type="checkbox"/> profiling
Description	<p>The CD or CHDIR command changes the current working directory from within the debugger. You can use relative pathnames as part of the <i>directory name</i>. If you don't use a <i>directory name</i>, the CD command displays the name of the current directory. This command can affect any other command whose parameter is a filename, such as the FILE, LOAD, and TAKE commands, when used with the USE command. You can also use the CD command to change the current drive. For example:</p> <pre>cd c: cd d:\csource cd c:\sim54x</pre>
dir	<i>List Directory Contents</i>
Syntax	dir [<i>directory name</i>]
Menu selection	none
Environments	<input checked="" type="checkbox"/> basic debugger <input type="checkbox"/> PDM <input checked="" type="checkbox"/> profiling
Description	<p>The DIR command displays a directory listing in the display area of the COMMAND window. If you use the optional <i>directory name</i> parameter, the debugger displays a list of the specified directory's contents. If you don't use a <i>directory name</i>, the debugger lists the contents of the current directory.</p> <p>You can list only files that match a specific format within a directory by using the asterisk (*) wildcard character. If the <i>directory name</i> ends in a partial filename with an asterisk, the debugger lists only the files which match the wildcard string. For example, to list every file in the home directory that has a .cmd extension, you would enter:</p> <pre>DIR /home/*.cmd</pre>

safehalt

Toggle Safehalt Mode

Syntax

safehalt {on | off}

Menu selection

none

Environments

basic debugger PDM profiling

Description

This new command, SAFEHALT, places the debugger in safehalt mode. When safehalt mode is off (the default), you can halt a running target device either by pressing **ESC** or by clicking a mouse button. When safehalt mode is on, you can halt a running target device only by pressing **ESC**; mouse clicks are ignored.

Changes to the TMS320C5xx C Source Debugger User's Guide

The *Debugger Options* section in the *TMS320C5xx C source Debugger User's Guide* describes the options that you can use when invoking the debugger. The `-mv` option has been added for the simulator version of the debugger.

The `-mv` option specifies which memory map the simulator loads. By default, the simulator loads the memory map contained in the `siminit.cmd` file, which is a generic memory map. Each of the provided memory maps simulates a different 'C54x device, as described in the following table:

Option	Device Simulated	Initialization File Used	Peripherals Simulated
<code>-mv541</code>	'C541	<code>sim541.cmd</code>	Serial port 0, serial port 1, timer
<code>-mv542</code>	'C542	<code>sim542.cmd</code>	Buffered serial port, TDM serial port, timer
<code>-mv543</code>	'C543	<code>sim543.cmd</code>	Buffered serial port, TDM serial port, timer
<code>-mv545</code>	'C545	<code>sim545.cmd</code>	Buffered serial port, serial port 1, timer
<code>-mv546</code>	'C546	<code>sim546.cmd</code>	Buffered serial port, serial port 1, timer
<code>-mv548</code>	'C548	<code>sim548.cmd</code>	2 Buffered serial ports, TDM serial port, timer, HPI
<code>-mv545lp</code>	'C545LP	<code>sim545lp.cmd</code>	Buffered serial port, serial port 1, timer, HPI

Defining a Memory Map

Note:

This chapter replaces Chapter 6, *Defining a Memory Map*, in the *TMS320C5xx C Source Debugger User's Guide*.

Before you begin a debugging session, you must supply the debugger with a memory map. The memory map tells the debugger which areas of memory it can and cannot access. You can use the Memory pulldown menu to enter the commands described in this chapter.

Topic	Page
5.1 The Memory Map: What It Is and Why You Must Define It	5-2
5.2 A Sample Memory Map	5-4
5.3 Identifying Usable Memory Ranges	5-5
5.4 Customizing the Memory Map	5-9
5.5 Enabling Memory Mapping	5-12
5.6 Checking the Memory Map	5-13
5.7 Modifying the Memory Map During a Debugging Session	5-14
5.8 Using Multiple Memory Maps for Multiple Target Systems (Emulator Only)	5-16
5.9 Simulating I/O Space (Simulator Only)	5-17
5.10 Simulating External Interrupts (Simulator Only)	5-22
5.11 Simulating Peripherals (Simulator Only)	5-26
5.12 Simulating Standard Serial Ports (Simulator Only)	5-27
5.13 Simulating Buffered Serial Ports (Simulator Only)	5-31
5.14 Simulating TDM Serial Ports (Simulator Only)	5-34

5.1 The Memory Map: What It Is and Why You Must Define It

A memory map tells the debugger which areas of memory it can and cannot access. Memory maps vary, depending on the application. Typically, the map matches the MEMORY definition in your linker command file.

Note:

When the debugger compares memory accesses against the memory map, it performs this checking in software, not hardware. The debugger cannot prevent your program from attempting to access nonexistent memory.

A special default initialization batch file included with the debugger package defines a memory map for your version of the debugger. This memory map may be sufficient when you first begin using the debugger. However, the debugger provides a complete set of memory-mapping commands that let you modify the default memory map or define a new memory map.

You can define the memory map interactively by entering the memory-mapping commands while you are using the debugger. However, this can be inconvenient because, in most cases, you will set up one memory map before you begin debugging and will use this map for all of your debugging sessions. The easiest method of defining a memory map is to put the memory-mapping commands in a batch file.

Defining the memory map in a batch file

There are two methods for defining the memory map in a batch file:

- Redefine the memory map defined in the initialization batch file.
- Define the memory map in a separate batch file of your own.

When you invoke the debugger, it follows these steps to find the batch file that defines your memory map:

- 1) The debugger checks whether you have used the `-t` debugger option. If the debugger finds the `-t` option, it executes the specified file. (Use the `-t` option to specify a batch file other than the initialization batch file shipped with the debugger.)

- 2) If you have not used the `-t` option, the debugger looks for the default initialization batch file. The batch filename differs for each version of the debugger:
 - For the emulator, this file is called *emuinit.cmd*.
 - For the EVM, this file is called *evminit.cmd*.
 - For the simulator, this file is called *siminit.cmd*.If the debugger finds the file corresponding to your tool, it executes the file.
- 3) If the debugger does not find the `-t` option or the initialization batch file, it looks for a file called *init.cmd*. This search mechanism allows you to have one initialization batch file for more than one debugger tool. To set up this file, you can use the IF/ELSE/ENDIF commands (for more details, see the *Entering and Using Commands* chapter in the *TMS320C5xx C Source Debugger User's Guide*) to indicate which memory map applies to each tool.

Potential memory map problems

You may experience these problems if the memory map is not correctly defined and enabled:

- Accessing invalid memory addresses.** If you do not supply a batch file containing memory-map commands, then the debugger is initially unable to access any target memory locations. Invalid memory addresses and their contents are highlighted in the data-display windows. (On color monitors, invalid memory locations, by default, are displayed in red.)
- Accessing an undefined or protected area.** When memory mapping is enabled, the debugger checks each of its memory accesses against the memory map. If you attempt to access an undefined or protected area, the debugger displays an error message. For specific error messages, see the *Debugger and PDM Messages* appendix in the *TMS320C5xx C Source Debugger User's Guide*.
- Loading a COFF file with sections that cross a memory range.** Be sure that the map ranges you specify in a COFF file match those that you define with the MA command (described on page 5-5). Alternatively, you can turn memory mapping off during a load by using the MAP OFF command (see page 5-12).
- Accessing conflict and extra cycles (simulator only).** If two memory read access requests occur simultaneously during an execution, the simulator may be unable to complete both requests within the same clock cycle. If both locations belong to the same physical memory block and the block is single-access memory, both requests cannot be processed within the same clock cycle.

5.2 A Sample Memory Map

Because you must define a memory map before you can run any programs, it is convenient to define the memory map in the initialization batch files. Example 5–1 shows the memory map commands that are defined in the initialization batch file that accompanies the simulator. You can use the file as is, edit it, or create your own memory map batch file. The files shipped with the emulator and EVM are similar to that of the simulator.

Example 5–1. Sample Initialization Batch File for Use With the TMS320C54x Simulator

```

ma 0x0000, 0, 0x80, EX|RAM
ma 0xc000, 0, 0x1000, ROM
ma 0xd000, 0, 0x1000, EX|RAM

ma 0x0000, 1, 0x0060, RAM
ma 0x0060, 1, 0x0020, RAM
ma 0x0080, 1, 0x0380, RAM|DA
ma 0x0400, 1, 0x0400, EX|RAM
    
```

The MA commands (shown in Example 5–1) define valid memory ranges and identify the read/write characteristics of the memory ranges. The MAP command enables mapping (see Section 5.5, *Enabling Memory Mapping*, on page 5-12). By default, mapping is enabled when you invoke the debugger. Figure 5–1 illustrates the memory map defined in Example 5–1.

Figure 5–1. Sample Memory Map for Use With the TMS320C54x Simulator

Program memory		Data memory	
0x0000 to 0x007F	External single-access RAM	0x0000 to 0x005F	Internal RAM for MMR
0x0080 to 0xBFFF	Available	0x0060 to 0x007F	Internal RAM scratch pad
0xC000 to 0xCFFF	Internal single-access ROM	0x0080 to 0x03FF	Internal dual-access RAM
0xD000 to 0xDFFF	External single-access RAM	0x0400 to 0x07FF	External single-access RAM
0xE000 to 0xFFFF	Available	0x0800 to 0xFFFF	Available

5.3 Identifying Usable Memory Ranges



ma The debugger's MA (memory add) command identifies valid ranges of target memory. The syntax for this command is:

ma *address, page, length, type*

- The *address* parameter defines the starting address of a range. This parameter can be an absolute address, any C expression, the name of a C function, or an assembly language label.

A new memory map must not overlap an existing entry. If you define a range that overlaps an existing range, the debugger ignores the new range and displays this error message in the display area of the COMMAND window:

```
Conflicting map range
```

- The *page* parameter is a 1-digit number that identifies the type of memory (program, data, or I/O) that a range occupies:

To identify this page . . .	Use this value as the <i>page</i> parameter
Program memory	0
Data memory	1
I/O space	2

- The *length* parameter defines the length of the range. This parameter can be any C expression.
- The *type* parameter identifies the read/write characteristics of the memory range. The *type* must be one of these keywords:

To identify this kind of memory . . .	Use this keyword as the <i>type</i> parameter
Read-only memory	R or ROM
Write-only memory	W or WOM
Read/write memory	R W or RAM
Read/write external memory	RAM EX or R W EX
Read-only port	P R
Read/write port	P R W
Single-access memory	SA
Dual-access memory	DA

Notes on using the MA command

- ❑ The debugger caches memory that is not defined as a port type (P|R, P|W, or P|R|W). For ranges that you do not want cached, be sure to map them as ports.
- ❑ When you are using the simulator, you can use the parameter values P|R, P|W, and P|R|W to simulate I/O ports. See Section 5.9, *Simulating I/O Space*, on page 5-17.

- ❑ Be sure that the map ranges that you specify in a common object file format (COFF) file match those that you define with the MA command. Moreover, a command sequence such as:

```
ma x,y,ram; ma x+y,z,ram
```

does not equal

```
ma x,y+z,ram
```

If you were planning to load two COFF blocks, where the first block spanned the length of y and the second block spanned the length of z, you would use the first MA command example. However, if you were planning to load a COFF block that spanned the length of y + z, you would use the second MA command example.

Alternatively, you could turn memory mapping off during a load by using the MAP OFF command. Although the MAP OFF command can be useful, you need to be sure that you use it correctly. See Section 5.5, *Enabling Memory Mapping*, on page 5-12 for more information about using the MAP OFF command.

- ❑ Although the address range for both of the following MA commands is the same (0x0400 to 0x0800), one range is internal and the other range is external.

```
ma 0x0400, 0, 0x0800, ROM 
```

```
ma 0x0400, 0, 0x0800, EX|ROM 
```

When the simulator is operating in microcomputer mode ($MP/\overline{MC} = 0$), the internal program ROM is accessed. Otherwise, the external program memory module is used.

- ❑ If a range of memory is configured as dual-access RAM (using the DA attribute with the MA command), it means two simultaneous accesses (read/write) can be performed during the same cycle to the block.

For example, the following command creates one dual-access RAM as a data page. If an instruction performs two simultaneous accesses to two addresses in this block, both accesses execute in one cycle.

```
ma 0x0100, 1, 0x0100, R|W|DA 
```

- If a range of memory is configured as single-access RAM (using the SA attribute with the MA command), it means only one access (read/write) can be performed on any address in the block in one cycle. You can configure more than one single-access RAM block. Simultaneous accesses to different single-access RAM blocks during the same cycle are permitted.

For example, the following commands create two single-access RAM blocks. The blocks are 0x100 in size. If an instruction performs two accesses, one in the first block (for example, address 0x110) and another in the second block (for example, address 0x230), the instruction executes in only one cycle.

```
ma 0x0100, 1, 0x0100, R|W|SA   
ma 0x0200, 1, 0x0100, R|W|SA 
```

Contrarily, if the blocks were combined into one block and configured as one single block of 0x200 words (as shown in the following command), simultaneous accesses to addresses 0x110 and 0x230 would take two cycles to complete.

```
ma 0x100, 1, 0x200, R|W|SA 
```

Memory mapping with the simulator (PCs only)

Unlike the emulator and EVM, the 'C54x simulator has memory cache capabilities that allow you to allocate as much memory as you need. However, to use memory cache capabilities effectively with the 'C54x, do not allocate more than 20K words of memory in your memory map. For example, the memory map shown in Example 5–2 allocates 20K words of 'C54x program memory.

Example 5–2. Sample Memory Map for the TMS320C54x Using Memory Cache Capabilities

```
MA 0,0,0x2000,R|W
MA 0x2000,0,0x2000,R|W
MA 0xc000,0,0x1000,R|W
```

The simulator creates temporary files in a separate directory on your disk. For example, when you enter an MA (memory add) command, the simulator creates a temporary file in the root directory of your current disk. Therefore, if you are currently running your simulator on the C drive, temporary files are placed in the C:\ directory. This prevents the processor from running out of memory space while you are executing the simulator.

Note:

If you execute the simulator from a floppy drive (for example, drive A), the temporary files are created in the root directory of that floppy drive (for example, the A:\ directory).

All temporary files are deleted when you exit the simulator using the QUIT command. If, however, you exit the simulator with a soft reboot of your computer, the temporary files are not deleted; you must delete these files manually. (Temporary files usually have numbers for names.)

With the memory cache capabilities of the simulator, your memory map is now restricted only by your PC's capabilities. As a result, there should be sufficient free space on your disk to run any memory map you want to use. If you use the MA command to allocate 20K words (40K bytes) of memory in your memory map, then your disk should have at least 40K bytes of free space available. To do this, you can enter:

```
ma 0x0, 0, 0x5000, ram 
```

Note:

You can also use the memory-cache capability feature for the data memory.

5.4 Customizing the Memory Map

The customizable 'C54x (cDSP) debugger allows you maximum flexibility in configuring a memory map. Because the size and address of the memory map is not fixed in the debugger, you can select any amount of ROM or RAM internally, externally, or both.

The following example shows how you can have both RAM and ROM mapped to the same address:

```
ma 0xc000, 0, 0x1000, R      ;Internal (on-chip) program ROM
ma 0xc000, 0, 0x1000, R|EX ;External (off-chip) program ROM
```

During execution or when the debugger performs memory accesses, the block of memory accessed is based on the 'C54x MP/ \overline{MC} bit located in the PMST register. When this bit is set to 0, the on-chip program ROM is enabled. When it is set to 1, the off-chip program RAM is enabled.

The next example shows two blocks of RAM, one internal (on-chip) and one external (off-chip), mapped to the same address.

```
ma 0x0080, 0, 0x0380, R|W   ;Internal (on-chip) program RAM
ma 0x0080, 0, 0x0380, R|W|EX;External (off-chip) program RAM
```

For the above example, the block of memory is accessed based on the OVLY bit located in the PMST register during execution or when the debugger performs memory accesses. When this bit is set to 1, the on-chip dual-access data RAM is mapped to internal program space. When it is cleared to 0, the off-chip program RAM is enabled.

The debugger accesses the three types of memory (data, program ROM, and program RAM) according to the type of memory and the values of the MP/ \overline{MC} bits. The following table summarizes how the debugger accesses memory:

Type of Memory	Memory Access
Data	Accesses internal memory block, then external memory block.
Program ROM	If MP/ \overline{MC} is set to 0, accesses internal memory block, then external memory block; if MP/ \overline{MC} is set to 1, accesses external memory block.
Program RAM	If OVLY is set to 1, accesses internal memory block, then external memory block; if OVLY is set to 0, accesses external memory block.

Mapping on-chip dual-access RAM from data memory to program memory

You can configure on-chip dual-access RAM as data memory or program memory. The following steps describe how to map a block of data memory to program memory:

Step 1: Set OVLY (the overlay bit) in the PMST register to 1.

Step 2: Define the data-memory map before you define the program-memory map. It is essential to define the data-memory map for the overlay mode.

Step 3: Add a dummy program-memory map in the same region as the external memory. To do this, use the EX attribute for the MA command.

Note:

The sizes of the data-memory map and the program-memory map must be the same.

The following is an example of mapping the on-chip dual-access RAM to program memory. The example shows the commands to set the mode to overlay.

```
ma 0x0080, 1, 0x0f80, R|W|DA
ma 0x0080, 0, 0x0f80, R|W|EX
?pmst=0xffc0 ; mp/mc=0, ovly=1
```

Simulating data memory (ROM)

With the 'C54x simulator, you can simulate the DROM bit in the 'C541, 'C543, 'C545, or 'C546 processor. This simulation allows you to map the on-chip program memory (ROM) to the data memory. To map the program memory (ROM) to the data memory, follow these steps:

Step 1: Set the DROM bit (bit 3) in the PMST register to 1.

Step 2: Invoke the simulator with the appropriate `-mv54x` option.

The following example shows how to set the DROM bit to 1 from the debugger:

```
?pmst=0x08 ; DROM bit is set to 1
```

Programming your memory

The most convenient time to set up your memory is during the initialization process. However, you can edit your memory map while your program is running.

Use the OVLY and MP/ \overline{MC} bits of the PMST register to set the amount of external and internal program memory you need. The values for the OVLY and MP/ \overline{MC} bits are as follows:

- OVLY bit
 - 0 = external program memory
 - 1 = internal program memory

- MP/ \overline{MC} bit
 - 0 = internal program memory (ROM)
 - 1 = external program memory

You can edit the the values of the OVLY and MP/ \overline{MC} bits by using the debugger or by programming the PMST register. To use the debugger to edit the values of these bits, scroll down the CPU window until you see the PMST register. The CPU window is editable; you can enter the values for each bit.

5.5 Enabling Memory Mapping



map By default, mapping is enabled when you invoke the debugger. In some instances, you may want to enable or disable memory explicitly. You can use the MAP command to do this; the syntax for this command is:

map {on | off}

Disabling memory mapping can cause bus fault problems in the target system because the debugger may attempt to access nonexistent memory.

Note:

When memory mapping is enabled, you cannot:

- Access memory locations that are not defined by an MA command.
- Modify memory areas that are defined as read only or as protected.

If you attempt to access memory in these situations, the debugger displays this message in the COMMAND window display area:

```
Error in expression
```

5.6 Checking the Memory Map



ml If you want to see which memory ranges are defined, use the ML (memory list) command. The syntax for this command is:

ml

The ML command lists the page, starting address, ending address, and read/write characteristics of each defined memory range.

For example, assume you issue the following MA commands:

```
ma 0,0, 0x3000, ROM
ma 0x4000, 0, 0x2000, EX|RAM
ma 0, 1, 0x4000, RAM
ma 0x8000, 1, 0x2000, EX|RAM
ma 0x6, 2, 0x3, P|R
```

If you enter the ML command, the debugger displays the following information in the display area of the COMMAND window:

<u>Page</u>	<u>Memory range</u>	<u>Attributes</u>
0	0000 - 2fff	R
0	4000 - 5fff	R W EX
1	0000 - 3fff	R W
1	8000 - 9fff	R W EX
2	0006 - 0008	P R

↑ starting address ↑ ending address

page 0 = program memory
page 1 = data memory
page 2 = I/O space

5.7 Modifying the Memory Map During a Debugging Session



If you need to modify the memory map during a debugging session, use these commands.

md To delete a range of memory from the memory map, use the MD (memory delete) command. The syntax for this command is:

md *address, page*

- The *address* parameter identifies the starting address of the range of program, data, or I/O memory. If you supply an *address* that is not the starting address of a range, the debugger displays this error message in the display area of the COMMAND window:

```
Specified map not found
```

- The *page* parameter is a 1-digit number that identifies the type of memory (program, data, or I/O) that the range occupies:

To identify this page,	Use this value as the <i>page</i> parameter
Program memory	0
Data memory	1
I/O space	2

Note:

If you are using the simulator and want to use the MD command to remove a simulated I/O port, you must first disconnect the port with the MI command (see *Disconnecting an I/O port*, page 5-21).

mr If you want to delete all defined memory ranges from the memory map, use the MR (memory reset) command. The syntax for this command is:

mr

This resets the debugger memory map.

ma If you want to add a memory range to the memory map, use the MA (memory add) command. The syntax for this command is:

ma *address, page, length, type*

The MA command is described in detail on page 5-5.

Returning to the original memory map

If you modify the memory map, you may want to go back to the original memory map without quitting and reinvoking the debugger. You can do this by resetting the memory map and then using the TAKE command to read in your original memory map from a batch file.

Suppose, for example, that you had set up your memory map in a batch file named *mem.map*. You could enter these commands to go back to this map:

```
mr  Reset the memory map  
take mem.map  Reread the default memory map
```

The MR command resets the memory map. (You could put the MR command in the batch file, preceding the commands that define the memory map.) The TAKE command tells the debugger to execute commands from the specified batch file.

5.8 Using Multiple Memory Maps for Multiple Target Systems (Emulator Only)

If you are debugging multiple applications, you may need a memory map for each target system. Here is the simplest method for handling this situation.

Step 1: Let the initialization batch file define the memory map for one of your applications.

Step 2: Create a separate batch file that defines the memory map for the additional target system. The filename is unimportant, but for this example assume that the file is named *filename.x*. The general format of this file's contents should be:

```
mr                               Reset the memory map  
MA commands                   Define the new memory map  
map on                          Enable mapping
```

(Of course, you can include any other appropriate commands in this batch file.)

Step 3: Invoke the debugger as usual.

Step 4: The debugger reads the initialization batch file during invocation. Before you begin debugging, read in the commands from the new batch file:

```
take filename.x 
```

This redefines the memory map for the current debugging session.

You can also use the `-t` option instead of the TAKE command when you invoke the debugger. The `-t` option allows you to specify a new batch file to use instead of the default initialization batch file.

5.9 Simulating I/O Space (Simulator Only)

In addition to adding memory ranges to the memory map, you can use the MA command to add I/O ports to the memory map. To do this, use P|R (input port) or P|R|W (input/output port) as the memory type. Use page 2 to simulate I/O space. Then you can use the MC command to connect a port to an input or output file. This simulates external I/O cycle reads and writes by allowing you to read data in from a file and/or write data out to a file. Use page 1 for file connects to data memory.

Connecting an I/O port



mc The MC (memory connect) command connects P|R or P|R|W to an input or output file. MC also allows you to connect any data memory location (except 0x0000–0x001F) to an input or output file to read data from or write data into the file. The syntax for this command is:

mc *portaddress, page, length, filename, fileaccess*

- The *portaddress* parameter defines the address of the I/O space or data memory. This parameter can be an absolute address, any C expression, the name of a C function, or an assembly language label.

The *portaddress* must be previously defined with the MA command (described on page 5-5) and have a keyword of either P|R (input port) or P|R|W (input/output port). The length of the address range defined for the port (or peripheral frame) can be 0x1000 to 0x1FFF bytes and does not have to be a multiple of 16.

- The *page* parameter is a 1-digit number that identifies the type of memory (data or I/O) that the address occupies:

To identify this page . . .	Use this value as the <i>page</i> parameter
Data memory	1
I/O space	2

- The *length* parameter defines the length of the range. This parameter can be any C expression.
- The *filename* parameter can be any file name. If you connect a port or memory location to read from a file, the file must exist, or the MC command will fail.

- The *fileaccess* parameter identifies the access characteristics of the I/O memory and data memory. The file access must be one of the keywords identified below:

To identify this file access type . . .	Use this keyword as the <i>fileaccess</i> parameter
Input port (I/O space)	P R
Simulator halt at EOF of input space (I/O space)	R P NR
Output port (I/O space)	P W
Read-only internal memory	R
Read-only external memory	EX R
Simulator halt at EOF of input file for internal memory	R NR
Simulator halt at EOF of input file for external memory	EX R NR
Write-only internal memory	W
Write-only external memory	EX W

For I/O memory locations, the file is accessed during a read or write instruction to the associated port address. You can connect any I/O port to a file. A maximum of one input and one output file can be connected to a single port; however, multiple ports can be connected to a single file.

For data memory locations, the debugger accesses the data as follows:

- When you are executing code:
 - If you have specified a file, the debugger reads the data from the file and updates the memory location with that data.
 - If you have specified a file, the debugger writes the data to the memory location, as well as to the file.
- When you are using the debugger:
 - The debugger reads the data value from the memory location, *not* from the connected file.
 - If you have specified a file, the debugger writes the data to the memory location, as well as to the file.

If you use the NR parameter, the simulator halts execution when it reads an EOF. The debugger displays the appropriate message in the display area of the COMMAND window:

```
<addr> EOF reached - connected at port(I/O_PAGE)
or
<addr> EOF reached - connected at location (DATA_PAGE)
```

At this point, you can disconnect the file by using the MI command and attach a new file by using the MC command. If you do not do anything, the file pointer resets automatically to the beginning of the input file, and execution continues until EOF is read.

If you do not specify the NR parameter, execution does not halt, and you are not notified when EOF is reached. The file pointer resets automatically to the beginning of the input file, and the simulator resumes reading from the file.

Example 5–3 shows how input and output ports can be connected to specific memory blocks.

Example 5–3. Connecting Input and Output Ports to Input or Output Files

Assume that you have two data-memory blocks:

```
ma 0x100,1, 0x10, EX|RAM ;block1
ma 0x200,1, 0x10, RAM ;block2
```

- You could use the MC command to set up and connect an input file to block1:

```
mc 0x100, 1, 0x1, my_input.dat, EX|R
```

- You could use the MC command to set up and connect an output file to block2:

```
mc 0x205, 1, 0x1, my_output.dat, W
```

- You could use the MC command to halt simulator at EOF of input file:

```
mc 0x100, 1, 0x1, my_input.dat, EX|R|NR
```

or

```
mc 0x100, 1, 0x1, my_input.dat, R|NR
```

Example 5–4 shows how to connect an input port to an input file named in.dat.

Example 5–4. Connecting an Input Port to an Input File

Assume that the file in.dat contains words of data in hexadecimal format, one per line, like this:

```
0A00
1000
2000
.
.
.
```

Use MA and MC commands to set up and connect an input port:

```
MA    0x50, 2, 0x1, R|P           Configure port address 50h
                                   as an input port.
MC    0x50, 2, 0x1, in.dat, R     Open file in.dat and
                                   connect it to port address 50.
```

Assume that the following instruction is part of your program; it reads from the file in.dat:

```
PORTR 050, data_mem              Read file in.dat, and put the
                                   value into the DATA_MEM location.
```

Notes:

- 1) You can connect a file only to configured location(s).
 - 2) You cannot connect a file to program memory (page 0) locations.
 - 3) You cannot connect a file to the core-memory map register area (0x0000 to 0x001F) of data memory (page 1).
 - 4) While connecting a file to a set of locations:
 - Locations must not spread across memory block boundaries.
 - Two read-only files must not overlap.
 - Two write-only files must not overlap.
-

Disconnecting an I/O port

Before you can use the MD command to delete a port from the memory map, you must use the MI command to disconnect the port.



mi The MI (memory disconnect) command disconnects a file from an I/O port. The syntax for this command is:

mi *portaddress, page, {R | W | EX}*

The *portaddress* and *page* identify the port that will be closed. The read/write/execute characteristics must match the parameter used when the port was connected.

5.10 Simulating External Interrupts (Simulator Only)

The 'C54x simulator allows you to simulate the external interrupt signals $\overline{\text{INT0}}$ to $\overline{\text{INT3}}$ and allows you to select the clock cycle where you want an interrupt to occur. To do this, you create a data file and connect it to one of the interrupt pins, $\overline{\text{INT0}}$ to $\overline{\text{INT3}}$ or the $\overline{\text{BIO}}$ pin.

Note:

The interrupt interval is expressed as a function of CPU clock cycles. Simulation begins at the first clock cycle.

Setting up your input file

To simulate interrupts, you must first set up an input file that lists interrupt intervals. Your file must contain a clock cycle in one of the following formats:

For the $\overline{\text{INT0}}$, $\overline{\text{INT1}}$, $\overline{\text{INT2}}$, and $\overline{\text{INT3}}$ pins, use this format:

clock cycle [**rpt** {*n* | **EOS**}]

For the $\overline{\text{BIO}}$ pin, you must enter the square brackets around the clock cycle and logic value. Use this format:

[*clock cycle, logic value*] [**rpt** {*n* | **EOS**}]

- The *clock cycle* parameter represents the CPU clock cycle in which you want an interrupt to occur.

You can have two types of CPU clock cycles:

- **Absolute.** To use an absolute clock cycle, your cycle value must represent the actual CPU clock cycle in which you want to simulate an interrupt. For example:

12 34 56

Interrupts are simulated at the 12th, 34th, and 56th CPU clock cycles. No operation is performed on the clock cycle value; the interrupt occurs exactly as the clock cycle value is written.

- **Relative.** You can also select a clock cycle that is relative to the time at which the last event occurred. For example:

12 +34 55

This example shows three interrupts being simulated: at the 12th, 46th (12 + 34), and 55th CPU clock cycles. A plus sign (+) before a clock cycle adds that value to the total clock cycles preceding it. You can mix both relative and absolute values in your input file.

- ❑ The *logic value* parameter is only for the $\overline{\text{BIO}}$ pin. You can force the signal to go high or low at specified clock cycles. A value of 1 forces the signal to go high, and a value of 0 forces the signal to go low. For example:

```
[12,1] [23,0] [45,1]
```

This causes the $\overline{\text{BIO}}$ pin to go high at the 12th cycle, low at the 23rd cycle, and high again at the 45th cycle.

- ❑ The **rpt** {*n* | **EOS**} parameter is optional and represents a repetition value. You can use two forms of repetition in simulating interrupts:

- **Repeat a fixed number of times.** You can format your input file to repeat a particular pattern a fixed number of times. For example:

```
5 (+10 +20) rpt 2
```

The values inside the parentheses represent the portion that is repeated. Therefore, an interrupt is simulated at the 5th, 15th (5 + 10), 35th (15 + 20), 45th (35 + 10), and 65th (45 + 20) CPU clock cycles.

The parameter *n* is a positive integer value.

- **Repeat to the end of simulation.** To repeat the same pattern throughout the simulation, add the string EOS to the line. For example:

```
10 (+5 +20) rpt EOS
```

Interrupts are simulated at the 10th, 15th (10+5), 35th (15 + 20), 40th (35 + 5), 60th (40 + 20), 65th (60 + 5), and 85th (65 + 20) CPU cycles, continuing in that pattern until the end of simulation.

Programming the simulator

After creating your input file, you can use debugger commands to:

- Connect the interrupt pin to your input file
- List the interrupt pins
- Disconnect an interrupt pin from a file

Use these commands as described below, or use them from the PIN pulldown menu.



pinc To connect your input file to the pin, use the following command:

pinc *pinname, filename*

- The *pinname* identifies the pin and must be one of the following: INT0, INT1, INT2, INT3, or BIO.
- The *filename* is the name of your input file. Make sure you have set up your input file as described in *Setting up your input file* on page 5-22.

Example 5–5 shows you how to connect your input file using the PINC command.

Example 5–5. Using the PINC Command to Connect the Input File

Suppose you want to generate an $\overline{\text{INT2}}$ external interrupt at the 12th, 34th, 56th, and 89th clock cycles.

First, create a data file with an arbitrary name, such as *myfile*:

```
12 34 56 89
```

Then use the PINC command in the pin pulldown menu to connect the input file to the $\overline{\text{INT2}}$ pin.

```
pinc int2, myfile
```


*Connects your data file
to the specific interrupt pin*

This command connects *myfile* to the $\overline{\text{INT2}}$ pin. As a result, the simulator generates an $\overline{\text{INT2}}$ external interrupt at the 12th, 34th, 56th, and 89th clock cycles.

pinl To verify that your input file is connected to the correct pin, use the PINL command. The syntax for this command is:

pinl

The PINL command displays all of the unconnected pins first, followed by the connected pins. For a pin that is connected, it displays the name of the pin and the absolute pathname of the file in the COMMAND window.



When you want to connect another file to an interrupt pin, the PINL command is useful for looking up an unconnected pin.

pind To end the interrupt simulation, disconnect the pin. You can do this with the following command:

pind *pinname*

The *pinname* parameter identifies the interrupt pin and must be one of the following: INT0, INT1, INT2, INT3, or BIO. The PIND command detaches the file from the input pin. After executing this command, you can connect another file to the same pin.

5.11 Simulating Peripherals (Simulator Only)

With the 'C54x simulator, you can simulate the timer, a standard serial port, a buffered serial port, or a TDM serial port, depending on the device you choose to simulate. Each 'C54x device has a different set of peripherals. You can select the peripheral that you want to simulate by using the `-mv` option. Table 5–1 lists the option for each 'C54x device and the peripherals associated with that option/device.

Table 5–1. Debugger Options for Loading a Simulator Memory Map

Option	Device Simulated	Peripherals Simulated
<code>-mv541</code>	'C541	Serial port 0, serial port 1, timer
<code>-mv542</code>	'C542	Buffered serial port, TDM serial port, timer
<code>-mv543</code>	'C543	Buffered serial port, TDM serial port, timer
<code>-mv545</code>	'C545	Buffered serial port, serial port 1, timer
<code>-mv546</code>	'C546	Buffered serial port, serial port 1, timer
<code>-mv548</code>	'C548	2 Buffered serial ports, TDM serial port, timer, HPI
<code>-mv545lp</code>	'C545LP	Buffered serial port, serial port 1, timer, HPI

Detailed information about simulating the different types of serial ports is discussed in the following sections:

Type of Serial Port	See This Section
Standard	5.12 on page 5-27
Buffered	5.13 on page 5-31
TDM	5.14 on page 5-34

5.12 Simulating Standard Serial Ports (Simulator Only)

The 'C54x simulator supports standard serial port transmission and reception by reading data from and writing data to the files associated with the DXR/TDXR and DRR/TDRR registers, respectively.

The simulator also provides limited support for the simulation of the serial port control signals (frame synchronization signals) with the help of external event simulation capability. Frame synchronization signal values for receive and transmit operations at various instants of time are fed through the files associated with the pins.

The 'C54x simulator supports the following operations in the standard serial port simulation:

- Internal clocks (1/4 CPU clock) and external clocks for the transmit and receive operations.** External clocks are simulated by using the DIVIDE command (described on page 5-28) in the files connected to the FSX/TFSX and FSR/TFSR pins.
- External frame synchronization pulses** (FSX/TFSX transmit and FSR/TFSR receive frame synchronization pulses). Transmit and receive operations are initiated when these signals go high.
- The operations associated with the following memory-mapped registers:

Register	Memory	Bits Used	Description
SPC	0x22	FO	Format specifier (8/16 bits)
TSPC	0x32	MCM XRST/RRST XRDY/RRDY XSREEMPTY RSRFULL	Internal/external clock Transmit/receive reset Transmit/receive ready Transmit register empty flag Receive register full flag
DXR TDXR	0x20 0x30	All bits are used	Transmit data register
DRR TDRR	0x21 0x31	All bits are used	Receive data register

Setting up your transmit and receive operations

The 'C54x simulator supports the simulation of the following pins using external event simulation. The pulses occurring on the FSX and FSR pins initiate the standard serial port transmit and receive operations, respectively.

- FSR/TFSR**—Frame synchronization pulses for the receive operation
- FSX/TFSX**—Frame synchronization pulses for the transmit operation

Connect the files to the pins using the PINC (pin connect) command (described on page 5-24). Use the following command syntax, selecting the appropriate command for the pin you want:

```
pinc FSX, filename
pinc TFSX, filename
pinc FSR, filename
pinc TFSR, filename
```

The *filename* is the name of the file that contains the CPU clock cycle values at which the pin value goes high. Use the following syntax in the files to define clock cycles:

```
[clock cycle] rpt {n | EOS}
```

The square brackets are used only with logic values for the $\overline{\text{BIO}}$ pin. For more information about defining clock cycles, see Section 5.10 on page 5-22.

Additionally, you can use the DIVIDE command to specify the divide-down ratio for the device clock. Use the following syntax for the DIVIDE command in the files:

DIVIDE *r*

The parameter *r* is a real number or integer specifying the ratio of the CPU clock rate to the serial port clock rate. Use the divide ratio when the serial port is configured to use the external clock. When you use the DIVIDE command, it must be the first command in the file.

The following example specifies the clock ratio of the transmit clock and the clock cycles for the occurrence of TFSX pulses (if this file is connected to the TFSX pin):

```
DIVIDE 5
100 +200 +100
```

The DIVIDE command specifies the divide-down ratio of the clock against the CPU clock. That is, the CLKX frequency is 1/5 of the CPU clock. The second line indicates that the TFSX should go high at the 100th, 300th (100 + 200), and 400th (300 + 100) CPU cycles. The TFSX pin goes high in the 500th, 1500th, and 2000th cycles of the serial port clock.

Connecting I/O files

Input and output files are connected to DRR/TDRR and DXR/TDXR registers for receive and transmit operations, respectively. To simulate the transmit operation, data is written to the file that is connected to the DXR/TDXR register. To simulate the receive operation, data is read from the file that is connected to the DRR/TDRR register.

The input and output file formats for the standard serial port operation requires at least one line containing an hexadecimal number. The following is an acceptable format for an input file:

```
0055  
aa55  
efef  
dead
```

Note:

To simulate the standard serial port 0, use the DXR and DRR registers and the FSX and FSR pins. To simulate the standard serial port 1, use the TDXR and TDRR registers and the TFSX and TFSR pins.

Programming the simulator

To simulate the standard serial port, configure the DXR/TDXR and DRR/TDRR registers as the output port (OPORT) and the input port (IPORT), respectively. Connect these ports to an output file and an input file. Also, connect files to the TFSX/FSX and TFSR/FSR pins to specify the clock cycles during which the frame synchronization pins go high.

To make these connections, use the following commands in the simulator initialization batch file (siminit.cmd):

```
ma DRR,1,1,R|P
ma DXR,1,1,W|P

mc DRR,1,1,receive filename,READ
mc DXR,1,1,transmit filename,WRITE

pinc FSX,fsx timing filename
pinc FSR,fsr timing filename
```

Variable	Description
<i>receive filename</i>	The file to read data from, which simulates the input port
<i>transmit filename</i>	The file to write data to, which simulates the output port
<i>fsx timing filename</i>	The file that contains the CPU cycles at which the FSX frame synchronization pin goes high
<i>fsr timing filename</i>	The file that contains the CPU cycles at which the FSR frame synchronization pin goes high

5.13 Simulating Buffered Serial Ports (Simulator Only)

The 'C54x simulator supports buffered serial port transmission and reception by reading data from and writing data to the files associated with the DXR and DRR registers, respectively.

The simulator also provides limited support for the simulation of the serial port control signals (frame synchronization signals) with the help of external event simulation capability. Frame synchronization signal values for receive and transmit operations at various instants of time are fed through the files associated with the pins. The 'C54x simulator supports the following operations in the buffered serial port simulation:

- Automatic buffering and standard serial port modes**
- Internal clocks ($1/(\text{CLKDV} + 1)$ CPU clock) and external clocks for the transmit and receive operations.** CLKDV is the clock divide-down ratio.
- External frame synchronization pulses** (FSX and FSR frame synchronization pulses): transmit and receive operations are initiated when these signals go high.
- The operations associated with the following memory-mapped registers:

Register	Memory	Bits Used	Description
SPC	0x22	FO	Format specifier (8/16 bits)
		MCM	Internal/external clock
		XRST/RRST	Transmit/receive reset
		XRDY/RRDY	Transmit/receive ready
		XSREMPY	Transmit register empty flag
		RSRFULL	Receive register full flag
DXR	0x21	All bits are used	Transmit data register
DRR	0x20	All bits are used	Receive data register
SPCE	0x23	CLKDV	Clock divide-down ratio
		FE	Extended format specifier
		RH/TH	Buffer half received or transmitted
		BXE/BRE	Enable/disable automatic buffering
		HALTX/HALTR	Switch to standalone mode after the current half is transmitted/received
AXR	0x38	All bits are used	Address register for transmit
ARR	0x3a	All bits are used	Address register for receive
BKX	0x39	All bits are used	Block size register for the transmit
BKR	0x3b	All bits are used	Block size register for the receive

Setting up your transmit and receive operations

The 'C54x simulator supports the simulation of the following pins using external event simulation. The pulses occurring on the FSX and FSR pins initiate the buffered serial port transmit and receive operations, respectively.

- FSR**—Frame synchronization pulses for the receive operation
- FSX**—Frame synchronization pulses for the transmit operation

Connect the files to the pins using the PINC (pin connect) command (described on page 5-24). Use the following command syntax, selecting the appropriate command for the pin you want:

```
pinc FSX, filename
pinc FSR, filename
```

The *filename* is the name of the file that contains the CPU clock cycle values at which the pin value goes high. Use the following syntax in the files to define clock cycles:

```
[clock cycle] rpt {n | EOS}
```

The square brackets are used only with logic values for the $\overline{\text{BI0}}$ pin. For more information about defining clock cycles, see Section 5.10 on page 5-22.

Additionally, you can use the DIVIDE command to specify the divide-down ratio for the device clock. Use the following syntax for the DIVIDE command in the files:

DIVIDE *r*

The parameter *r* is a real number or integer specifying the ratio of the CPU clock rate to the serial port clock rate. Use the divide ratio when the serial port is configured to use the external clock. When you use the DIVIDE command, it must be the first command in the file.

The following example specifies the clock ratio of the transmit clock and the clock cycles for the occurrence of TFSX pulses (if this file is connected to the TFSX pin):

```
DIVIDE 5
100 +200 +100
```

The DIVIDE command specifies the divide-down ratio of the clock against the CPU clock. That is, the CLKX frequency is 1/5 of the CPU clock. The second line indicates that the TFSX should go high at the 100th, 300th (100 + 200), and 400th (300 + 100) CPU cycles. The TFSX pin goes high in the 500th, 1500th, and 2000th cycles of the serial port clock.

Connecting I/O files

Input and output files are connected to DRR and DXR registers for receive and transmit operations, respectively. To simulate the transmit operation, data is written to the file that is connected to the DXR register. To simulate the receive operation, data is read from the file that is connected to the DRR register.

The input and output file formats for the buffered serial port operation requires at least one line containing a hexadecimal number. The following example shows an acceptable format for an input file:

```
0055
aa55
efef
dead
```

Programming the simulator

To simulate the buffered serial port, configure the DXR and DRR registers as the output port (OPORT) and the input port (IPORT), respectively. Connect these ports to an output file and an input file. Also, connect files to the TFSX/FSX and TFSR/FSR pins to specify the clock cycles during which the frame synchronization pins go high.

To make these connections, use the following commands in the simulator initialization batch file (siminit.cmd):

```
ma DRR,1,1,R|P
ma DXR,1,1,W|P

mc DRR,1,1,receive filename,READ
mc DXR,1,1,transmit filename,WRITE

pinc FSX,fsx timing filename
pinc FSR,fsr timing filename
```

Variable	Description
<i>receive filename</i>	The file to read data from, which simulates the input port
<i>transmit filename</i>	The file to write data to, which simulates the output port
<i>fsx timing filename</i>	The file that contains the CPU cycles at which the FSX frame synchronization pin goes high
<i>fsr timing filename</i>	The file that contains the CPU cycles at which the FSR frame synchronization pin goes high

5.14 Simulating TDM Serial Ports (Simulator Only)

The 'C54x simulator supports TDM serial port transmission and reception by reading data from and writing data to the files associated with the TDXR and TDRR registers, respectively.

The simulator also provides limited support for the simulation of the TDM port control signals (frame synchronization signals) with the help of external event simulation capability. Frame synchronization signal values for receive and transmit operations at various instants of time are fed through the files associated with the pins.

The 'C54x simulator supports the following operations in the TDM serial port simulation:

- TDM and standard serial port modes**
- Internal clocks (1/4 CPU clock) and external clocks for the transmit and receive operations.** External clocks are simulated by using the DIVIDE command in the files connected to the TFSX and TFSR pins.
- External frame synchronization pulses** (TFSX transmit and TFSR receive frame synchronization pulses). Transmit and receive operations are initiated when the signals for these values go high.
- The operations associated with the following memory-mapped registers:

Register	Memory	Bits Used	Description
TSPC	0x32	TDM MCM XRST/RRST XRDY/RRDY XSREMPY RSRFULL	Multiprocessor/normal mode Internal/external clock Transmit/receive reset Transmit/receive ready Transmit register empty flag Receive register full flag
TCSR	0x33	All bits are used	Channel select register
TRTA	0x34	All bits are used	Receive/transmit address register
TRAD	0x35	All bits are used	Receive address register
TDXR	0x31	All bits are used	Transmit data register
TDRR	0x30	All bits are used	Receive data register

Setting up your transmit and receive operations

The 'C54x simulator supports the simulation of the following pins using external event simulation. The pulses occurring on the TFSX and TFSR pins initiate the TDM serial port transmit and receive operations, respectively.

- TFSR**—Frame synchronization pulses for the receive operation
- TFSX**—Frame synchronization pulses for the transmit operation

Connect the files to the pins using the PINC (pin connect) command (described on page 5-24). Use the following command syntax, selecting the appropriate command for the pin you want:

```
pinc TFSX, filename
pinc TFSR, filename
```

The *filename* is the name of the file that contains the CPU clock cycle values at which the pin value goes high. Use the following syntax in the files to define clock cycles:

```
[clock cycle] rpt {n | EOS}
```

The square brackets are used only with logic values for the $\overline{\text{BIO}}$ pin. For more information about defining clock cycles, see Section 5.10 on page 5-22.

Additionally, you can use the DIVIDE command to specify the divide-down ratio for the device clock. Use the following syntax for the DIVIDE command in the files:

DIVIDE *r*

The parameter *r* is a real number or integer specifying the ratio of the CPU clock rate to the serial port clock rate. Use the divide ratio when the serial port is configured to use the external clock. When you use the DIVIDE command, it must be the first command in the file.

The following example specifies the clock ratio of the transmit clock and the clock cycles for the occurrence of TFSX pulses (if this file is connected to the TFSX pin):

```
DIVIDE 5
100 +200 +100
```

The DIVIDE command specifies the divide-down ratio of the clock against the CPU clock. That is, the CLKX frequency is 1/5 of the CPU clock. The second line indicates that the TFSX should go high at the 100th, 300th (100 + 200), and 400th (300 + 100) CPU cycles. The TFSX pin goes high in the 500th, 1500th, and 2000th cycles of the serial port clock.

Connecting I/O files

Input and output files are connected to TDRR and TDXR registers for receive and transmit operations, respectively. To simulate the transmit operation, data is written to the file that is connected to the TDXR register. To simulate the receive operation, data is read from the file that is connected to the TDRR register. Use the following syntax to create the files:

channel-address data

The parameter *channel-address* specifies the TDM channel in which transmission/reception takes place. The parameter *data* specifies the value that is written or read from the file. Each field is in hexadecimal format and the fields are separated by spaces. The following is an acceptable format for an input file:

```
10 0055
34 aa55
80 efef
01 dead
```

Programming the simulator

To simulate the TDM serial port, configure the TDXR and TDRR registers as the output port (OPORT) and the input port (IPORT), respectively. Connect these ports to an output file and an input file. Also, connect files to the TFSX/FSX and TFSR/FSR registers to specify the clock cycles during which the frame synchronization pins go high.

To make these connections, use the following commands in the simulator initialization batch file (siminit.cmd):

```
ma TDRR,1,1,R|P
ma TDXR,1,1,W|P

mc TDRR,1,1,receive filename,READ
mc TDXR,1,1,transmit filename,WRITE

pinc TFSX,fsx timing filename
pinc TFSR,fsr timing filename
```

Variable	Description
<i>receive filename</i>	The file to read data from, which simulates the input port
<i>transmit filename</i>	The file to write data to, which simulates the output port
<i>fsx timing filename</i>	The file that contains the CPU cycles at which the FSX frame synchronization pin goes high
<i>fsr timing filename</i>	The file that contains the CPU cycles at which the FSR frame synchronization pin goes high

Index

A

- absolute clock cycle 5-22
- addresses
 - accessible locations 5-2
 - I/O address space, simulator 5-17 to 5-21
 - invalid memory 5-3
 - nonexistent memory locations 5-2
 - protected areas 5-3, 5-12
 - undefined areas 5-3, 5-12
- arrow keys
 - for HP workstations 3-10
 - for SPARCstations 2-10
- assembler
 - for HP workstations 3-3
 - for PC systems 1-3
 - for SPARCstations 2-2
- assistance from TI viii
- autoexec.bat file
 - environmental variables 1-6
 - interfering with other applications 1-5
 - invoking 1-7
 - modifying 1-6
 - sample 1-5

B

- b debugger option
 - for HP workstations 3-7
 - for PC systems 1-7
 - for SPARCstations 2-7
- batch files
 - autoexec.bat 1-5 to 1-7
 - .cshrc
 - for HP workstations 3-6 to 3-8
 - for SPARCstations 2-6 to 2-8
 - emuinit.cmd 5-16

- batch files (continued)
 - init.clr
 - for HP workstations 3-3
 - for PC systems 1-3
 - for SPARCstations 2-2
 - init.cmd 5-3
 - initdb.bat 1-5 to 1-7
 - initialization
 - init.cmd 5-3
 - siminit.cmd 1-3, 2-2, 3-3
 - mem.map 5-15
 - memory map 5-15, 5-16
 - mono.clr
 - for HP workstations 3-3
 - for PC systems 1-3
 - for SPARCstations 2-2, 2-3
 - screen sizes
 - for HP workstations 3-3
 - for PC systems 1-3
 - for SPARCstations 2-3
 - sim54x.cmd
 - for HP workstations 3-3
 - for PC systems 1-3
 - for SPARCstations 2-2
 - siminit.cmd
 - for HP workstations 3-3
 - for PC systems 1-3
 - for SPARCstations 2-2
 - TAKE command 5-15, 5-16
- bb debugger option
 - for HP workstations 3-7
 - for PC systems 1-7
 - for SPARCstations 2-7
- BIO pseudoregister 5-22 to 5-25
- bl debugger option 1-7

buffered serial port
 connecting I/O files 5-33
 programming the simulator 5-33
 setting up transmit and receive operations 5-32 to 5-33
 simulating 5-31 to 5-33
-bw debugger option 1-7

C

CD-ROM
 mounting
 for HP workstations 3-4
 for SPARCstations 2-4
 requirements
 for HP workstations 3-2
 for SPARCstations 2-2
 retrieving files from
 for HP workstations 3-4
 for SPARCstations 2-5
 unmounting
 for HP workstations 3-5
 for SPARCstations 2-5
CH (CHDIR) command 4-3
changes to the *TMS320C5xx C Source Debugger User's Guide* 4-4
CHDIR (CD) command 4-3
clock cycle types 5-22
COFF
 formats accepted 4-1
 loading 5-3
 version 2, 4-1
color mapping with X Windows
 for HP workstations 3-11
 for SPARCstations 2-11
commands
 memory 5-5 to 5-16
 new for debugger 4-4
 updated for debugger 4-3
compiler
 for HP workstations 3-3
 for PC systems 1-3
 for SPARCstations 2-2
connecting an I/O port 5-17 to 5-21
connecting I/O files
 buffered serial ports 5-33
 standard serial port 5-29

connecting I/O files (continued)
 TDM serial ports 5-36
contacting Texas Instruments viii
.cshrc file
 for HP workstations 3-6 to 3-8
 for SPARCstations 2-6 to 2-8
current directory, changing 4-3
customizing the display
 for HP workstations 3-3, 3-11
 for PC systems 1-2, 1-3
 for SPARCstations 2-2, 2-3, 2-11

D

-d debugger option
 for HP workstations 3-7
 for SPARCstations 2-7
D_OPTIONS environment variable
 for HP workstations 3-7
 for PC systems 1-7, 2-7
D_SRC environment variable
 for HP workstations 3-7
 for PC systems 1-6
 for SPARCstations 2-7
D_DIR environment variable
 for HP workstations 3-6
 for PC systems 1-6
 for SPARCstations 2-6
DA keyword 5-5
 See also MA command
data memory
 adding to memory map 5-5
 deleting from memory map 5-14
 simulating 5-10
debugger
 displaying on a different machine 2-8, 3-8
 enhancements 4-1 to 4-4
 environment setup
 for HP workstations 3-6 to 3-8
 for PC systems 1-5 to 1-7
 for SPARCstations 2-6 to 2-8
 font changes
 for HP workstations 3-11
 for PC systems 1-2
 for SPARCstations 2-11
 installation of software
 for HP workstations 3-4
 for PC systems 1-4
 for SPARCstations 2-4

- debugger (continued)
 - installation verification
 - for HP workstations 3-9
 - for PC systems 1-8
 - for SPARCstations 2-9
 - using with the X Window System
 - for HP workstations 3-10 to 3-11
 - for SPARCstations 2-10 to 2-11
 - using with Windows 1-1
 - default
 - memory map
 - See also *memory map, default*
 - for HP workstations 3-3
 - for PC systems 1-3
 - for SPARCstations 2-2
 - screen configuration file
 - for HP workstations 3-3
 - for PC systems 1-3
 - for SPARCstations 2-2
 - defining a memory map. See *memory map*
 - DIR command 4-3
 - directories
 - auxiliary files
 - for HP workstations 3-6
 - for PC systems 1-6
 - for SPARCstations 2-6
 - changing current directory 4-3
 - debugger software
 - for HP workstations 3-4, 3-6
 - for PC systems 1-4, 1-6
 - for SPARCstations 2-5, 2-6
 - identifying additional source directories
 - for HP workstations 3-7
 - for PC systems 1-6
 - for SPARCstations 2-7
 - listing contents of current directory 4-3
 - relative pathnames 4-3
 - sim54x
 - for HP workstations 3-4, 3-6
 - for PC systems 1-4, 1-6
 - for SPARCstations 2-5, 2-6
 - disconnecting an I/O port 5-21
 - disk space requirements
 - for HP workstations 3-2
 - for SPARCstations 2-2
 - display
 - color mappings on monochrome
 - for HP workstations 3-11
 - for SPARCstations 2-11
 - display (continued)
 - font changes
 - for HP workstations 3-11
 - for PC systems 1-2
 - for SPARCstations 2-11
 - requirements
 - for HP workstations 3-2
 - for PC systems 1-2
 - for SPARCstations 2-2
 - DISPLAY environment variable
 - for HP workstations 3-8
 - for SPARCstations 2-8
 - DIVIDE command 5-28, 5-32, 5-35
 - divide-down ratio 5-28, 5-32, 5-35
 - DOS-command setup for the debugger 1-5
 - DROM bit in PMST register 5-10
- E**
- emunit.cmd file 5-3
 - end key
 - for HP workstations 3-10
 - for SPARCstations 2-10
 - environment setup
 - for HP workstations 3-6 to 3-8
 - for PC systems 1-5 to 1-7
 - for SPARCstations 2-6 to 2-8
 - evmunit.cmd file 5-3
 - EX attribute 5-5
 - See also *MA command*
 - EX|R keyword 5-18
 - EX|R|NR keyword 5-18
 - external frame synchronization signals
 - buffered serial port 5-32
 - standard serial port 5-28
 - TDM serial port 5-35
 - external interrupts 5-22 to 5-25
 - connecting input file 5-24
 - disconnecting pins 5-25
 - listing pins 5-25
 - PINC command 5-24
 - PIND command 5-25
 - PINL command 5-25
 - programming simulator 5-24 to 5-25
 - setting up input files 5-22 to 5-23
 - clock cycles* 5-22
 - repetition of a pattern* 5-23
 - simulating 5-22 to 5-25
 - EX|W keyword 5-18

F

- file access keywords 5-18
- FILE command, changing the current directory 4-3
- files
 - connecting to
 - buffered serial port* 5-33
 - I/O port* 5-17 to 5-20
 - standard serial port* 5-29
 - TDM serial port* 5-36
 - disconnecting from I/O port 5-21
- font changes
 - for HP workstations 3-11
 - for PC systems 1-2
 - for SPARCstations 2-11
- frame synchronization pins
 - buffered serial port 5-32
 - standard serial port 5-28
 - TDM serial port 5-35
- function key mapping
 - for HP workstations 3-10
 - for SPARCstations 2-10

G

- graphics card requirements, for PC systems 1-2

H

- hardware checklist
 - for HP workstations 3-2
 - for PC systems 1-2
 - for SPARCstations 2-2
- home key
 - for HP workstations 3-10
 - for SPARCstations 2-10
- host system
 - for HP workstations 3-2
 - for PC systems 1-2
 - for SPARCstations 2-2
- HP systems
 - installation
 - software* 3-4 to 3-5
 - verifying* 3-9
 - requirements 3-2 to 3-3
 - setting up debugger environment 3-6 to 3-8

I

- i debugger option
 - for HP workstations 3-7
 - for PC systems 1-7
 - for SPARCstations 2-7
- I/O memory
 - adding to memory map 5-5
 - deleting from memory map 5-14
 - simulating 5-17 to 5-21
- I/O port
 - connecting 5-17 to 5-20
 - disconnecting 5-21
- I/O space, simulating 5-17
- identifying sim54x directory. *See* modifying PATH statement
- identifying usable memory ranges 5-5 to 5-8
- IF/ELSE/ENDIF commands 5-3
- init.25
 - for HP workstations 3-3
 - for PC systems 1-3
 - for SPARCstations 2-3
- init.43
 - for HP workstations 3-3
 - for PC systems 1-3
 - for SPARCstations 2-3
- init.50
 - for HP workstations 3-3
 - for PC systems 1-3
 - for SPARCstations 2-3
- init.clr file
 - for HP workstations 3-3
 - for PC systems 1-3
 - for SPARCstations 2-2
- init.cmd file 5-3
- initdb.bat file
 - invoking 1-7
 - sample 1-5
- initialization batch files
 - for HP workstations 3-3
 - for memory mapping 5-2 to 5-4
 - for PC systems 1-3
 - for SPARCstations 2-2
- init.cmd 5-3
- insert key
 - for HP workstations 3-10
 - for SPARCstations 2-10

installation
 software
 for HP workstations 3-4
 for PC systems 1-4
 for SPARCstations 2-4
 verifying
 for HP workstations 3-9
 for PC systems 1-8
 for SPARCstations 2-9
 interrupt pins 5-22 to 5-25
 interrupts, simulating 5-22 to 5-25
 invalid memory addresses 5-3, 5-12
 invoking the simulator
 autoexec.bat file 1-7
 .cshrc file
 for HP workstations 3-8
 for SPARCstations 2-8
 initdb.bat file 1-7

K

keyboard mapping
 for HP workstations 3-10
 for SPARCstations 2-10
 keysym labels
 for HP workstations 3-10
 for SPARCstations 2-10

L

LD_LIBRARY_PATH environment variable
 for HP workstations 3-8
 for SPARCstations 2-8
 linker
 command files, MEMORY definition 5-2
 for HP workstations 3-3
 for PC systems 1-3
 for SPARCstations 2-2
 loading, COFF files, restrictions 5-3

M

MA command 5-4, 5-5, 5-9, 5-14
 MAP command 5-12
 mapping keys for use with X Windows
 for HP workstations 3-10
 for SPARCstations 2-10

mapping on-chip dual-access RAM to program
 memory 5-10
 MC command 5-17 to 5-20
 MD command 5-14
 MEM command 4-1
 memory
 batch file search order 5-2 to 5-3
 commands
 MA command 5-4, 5-5, 5-9, 5-14
 MAP command 5-12
 MC command 5-17 to 5-20
 MD command 5-14
 MI command 5-21
 ML command 5-13
 MR command 5-14
 data memory, simulating 5-10
 default map
 for HP workstations 3-3
 for PC systems 1-3
 for SPARCstations 2-2
 identifying usable ranges 5-5 to 5-8
 invalid addresses 5-3
 invalid locations 5-12
 nonexistent locations 5-2
 protected areas 5-3, 5-12
 requirements, for PC systems 1-2
 simulating
 I/O memory 5-17 to 5-21
 MC command 5-17 to 5-20
 MI command 5-21
 undefined areas 5-3, 5-12
 valid types 5-5
 MEMORY definition 5-2
 memory map
 adding ranges 5-5
 batch file 5-15
 checking 5-13
 customizing 5-9 to 5-11
 default 5-4
 defining 5-2 to 5-8
 deleting ranges 5-14
 enabling/disabling 5-12
 for HP workstations 3-3
 for PC systems 1-3
 for SPARCstations 2-2
 listing current map 5-13
 MA command 5-4, 5-5, 5-9, 5-14
 MD command 5-14
 ML command 5-13
 modifying 5-2 to 5-14

memory map (continued)
MR command 5-14
multiple maps 5-16
potential problems 5-3
resetting 5-14
returning to default/original 5-15
sample 5-4
simulating I/O ports 5-17 to 5-20, 5-21

MEMORY window 4-1

memory-cache capability 5-8

MI command 5-21

-min debugger option
for HP workstations 3-7
for PC systems 1-7
for SPARCstations 2-7

ML command 5-13

modifying
batch file (autoexec.bat) 1-5 to 1-6
current directory 4-3
memory map 5-2 to 5-14
PATH statement
for HP workstations 3-6
for PC systems 1-6
for SPARCstations 2-6

mono.clr file
for HP workstations 3-3
for PC systems 1-3
for SPARCstations 2-2, 2-3

monochrome monitor color mapping with X Windows
for HP workstations 3-11
for SPARCstations 2-11

mounting CD-ROM
for HP workstations 3-4
for SPARCstations 2-4

mouse requirements
for HP workstations 3-2
for PC systems 1-2
for SPARCstations 2-2

MP/MC bit in PMST register 5-9, 5-11

MR command 5-14

multiple MEMORY windows 4-1

multiple WATCH windows 4-2

-mv debugger option 4-4, 5-26
for HP workstations 3-7
for PC systems 1-7
for SPARCstations 2-7

N

new or updated debugger commands 4-3 to 4-4
nonexistent memory locations 5-2
notational conventions iv
notes on using the MA command 5-6 to 5-7

O

operating system
for HP workstations 3-3
for PC systems 1-3
for SPARCstations 2-2

optional files
for HP workstations 3-3
for PC systems 1-3
for SPARCstations 2-2

OVLY bit in PMST register 5-9, 5-10, 5-11

P

page parameter
in MA command 5-5
in MC command 5-17
in MD command 5-14

page-down key
for HP workstations 3-10
for SPARCstations 2-10

page-up key
for HP workstations 3-10
for SPARCstations 2-10

PATH statement
for HP workstations 3-6
for PC systems 1-6
for SPARCstations 2-6

PC systems
installation
software 1-4
verifying 1-8
requirements 1-2 to 1-3
setting up debugger environment 1-5 to 1-7

peripherals, simulating 5-26
See also buffered serial port; standard serial port;
TDM serial port

permissions
for HP workstations 3-3
for SPARCstations 2-2

PINC command 5-24

PIND command 5-25
 PINL command 5-25
 port address, simulator 5-17 to 5-21
 ports, simulating 5-17 to 5-20
 P|R keyword 5-5, 5-18
 -profile debugger option
 for HP workstations 3-7
 for PC systems 1-7
 for SPARCstations 2-7
 program memory
 adding to memory map 5-5
 deleting from memory map 5-14
 programming the simulator
 for simulating a buffered serial port 5-33
 for simulating a standard serial port 5-30
 for simulating a TDM serial port 5-36
 for simulating external interrupts 5-24 to 5-25
 programming your memory 5-11
 P|R|W keyword 5-5
 P|W keyword 5-18

R

R keyword 5-5, 5-18
 RAM, on-chip dual-access, mapping 5-10
 RAM|EX (R|W|EX) keyword 5-5
 read-access conflict 5-3
 receive operation
 buffered serial port simulation 5-32
 standard serial port simulation 5-28
 TDM serial port simulation 5-35
 reinitializing the shell
 for HP workstations 2-8
 for SPARCstations 3-8
 related documentation v to vi
 relative clock cycle 5-22
 relative pathnames 4-3
 repetition in simulating interrupts 5-23
 requirements. *See* hardware checklist; software checklist
 retrieving files from CD-ROM
 for HP workstations 3-4
 for SPARCstations 2-5
 R|NR keyword 5-18

root privileges
 for HP workstations 3-3
 for SPARCstations 2-2
 R|P|NR keyword 5-18
 R|W keyword 5-5

S

-s debugger option
 for HP workstations 3-7
 for PC systems 1-7
 for SPARCstations 2-7
 SA keyword 5-5
 SAFEHALT command 4-4
 sample batch file 5-4
 sample memory maps 5-4, 5-8
 serial ports
 programming
 buffered 5-33
 standard 5-30
 TDM 5-36
 simulating
 buffered 5-31 to 5-33
 standard 5-27 to 5-30
 TDM 5-34 to 5-36
 setting up transmit and receive operations
 buffered serial port 5-32
 standard serial port 5-28
 TDM serial port 5-35
 shell, reinitializing
 for HP workstations 3-8
 for SPARCstations 2-8
 sim54x
 command options
 for HP workstations 3-7
 for PC systems 1-7, 2-7
 directory
 for HP workstations 3-4
 for PC systems 1-4, 1-6
 for SPARCstations 2-5
 verifying the software installation
 for HP workstations 3-9
 for PC systems 1-8
 for SPARCstations 2-9
 sim54x directory
 for HP workstations 3-6
 for PC systems 1-6
 for SPARCstations 2-6

sim54x.cmd file
 for HP workstations 3-3
 for PC systems 1-3
 for SPARCstations 2-2

sim54xw.exe 1-4

siminit.cmd file
 for HP workstations 3-3, 5-3
 for PC systems 1-3, 5-3
 for SPARCstations 2-2, 5-3

simulating
 buffered serial port 5-31 to 5-33
 data memory 5-10
 I/O space 5-17
 interrupts 5-22 to 5-25
 peripherals 5-26 to 5-34
 standard serial port 5-27 to 5-30
 TDM serial port 5-34 to 5-36

simulator
 enhancements 4-1 to 4-4
 environment setup
 for HP workstations 3-6 to 3-8
 for PC systems 1-5 to 1-7
 for SPARCstations 2-6 to 2-8
 I/O memory 5-17 to 5-21
 installation of software
 for HP workstations 3-4
 for PC systems 1-4
 for SPARCstations 2-4
 installation verification
 for HP workstations 3-9
 for PC systems 1-8
 for SPARCstations 2-9
 programming
 buffered serial port 5-33
 external interrupts 5-24 to 5-25
 standard serial ports 5-30
 TDM serial port 5-36

software checklist
 for HP workstations 3-3
 for PC systems 1-3
 for SPARCstations 2-2

SPARCstations
 installation
 software 2-4 to 2-5
 verifying 2-9
 requirements 2-2 to 2-3
 setting up debugger environment 2-6 to 2-8

special keys
 for HP workstations 3-10
 for SPARCstations 2-10

standard serial port
 connecting I/O files 5-29 to 5-30
 programming the simulator 5-30
 setting up transmit and receive operations 5-28
 simulating 5-27 to 5-30

synchronization, external frame
 buffered serial port 5-32
 standard serial port 5-28
 TDM serial port 5-35

system commands
 CD command 4-3
 DIR command 4-3
 SAFEHALT command 4-4
 TAKE command 5-15

system requirements. *See* hardware checklist; software checklist

T

-t debugger option
 during debugger invocation 5-2
 for HP workstations 3-7
 for PC systems 1-7
 for SPARCstations 2-7

TAKE command 5-15
 reading new memory map 5-16

target system, SAFEHALT command 4-4

TDM serial port
 connecting I/O files 5-36
 programming the simulator 5-36
 setting up transmit and receive operations 5-35
 simulating 5-34 to 5-36

technical support viii

transmit operation
 buffered serial port simulation 5-32
 standard serial port simulation 5-28
 TDM serial port simulation 5-35

U

utilities
 xev
 for HP workstations 3-10
 for SPARCstations 2-10

utilities (continued)

- xmodmap
 - for HP workstations 3-10
 - for SPARCstations 2-10
- xrdb
 - for HP workstations 3-11
 - for SPARCstations 2-11

V

- v debugger option
 - for HP workstations 3-7
 - for PC systems 1-7
 - for SPARCstations 2-7
- verifying the software installation
 - for HP workstations 3-9
 - for PC systems 1-8
 - for SPARCstations 2-9

W

- W keyword 5-5, 5-18
- WA command 4-2
- WATCH window 4-2
- WD command 4-2

- window name parameter
 - MEMORY window 4-1
 - WATCH window 4-2
- Windows systems. *See* PC systems
- WR command 4-2

X

- x debugger option
 - for HP workstations 3-7
 - for PC systems 1-7
 - for SPARCstations 2-7
- X Window System
 - displaying debugger on a different machine 2-8, 3-8
 - for HP workstations 3-10 to 3-11
 - for SPARCstations 2-10 to 2-11
- .Xdefaults file
 - for HP workstations 3-11
 - for SPARCstations 2-11
- xev utility
 - for HP workstations 3-10
 - for SPARCstations 2-10
- xmodmap utility
 - for HP workstations 3-10
 - for SPARCstations 2-10
- xrdb utility
 - for HP workstations 3-11
 - for SPARCstations 2-11