


**Certainty 210 Series
Flexible Disk Storage System**



62947909

**CDC® 80210-10/80240
Flexible Disk Drive**

**HARDWARE MAINTENANCE MANUAL
(Site Information)**



FLEXIBLE DISK STORAGE SYSTEM HARDWARE MAINTENANCE


**Certainty 210 Series
Flexible Disk Storage System**



62947909

**CDC® 80210-10/80240
Flexible Disk Drive**

**HARDWARE MAINTENANCE MANUAL
(Site Information)**



FLEXIBLE DISK STORAGE SYSTEM HARDWARE MAINTENANCE

REVISION RECORD

REVISION	DESCRIPTION
<p style="text-align: center;">A (03-28-80)</p>	<p>Manual released. Includes product verification changes.</p>
<p style="text-align: center;">B (03-16-81)</p>	<p>Manual revised per ECOs 01096, 01143, 01173, 01181, 01182, 01270, 01282, 01286, 01293, and 01319. This revision changes series code, text, spare parts lists, and SAMS. Pages changed are: ii, iii/iv, v/vi, vii, xii, 1-2, 1-8, 2-3, 2-4, 2-4.1, 2-4.2, 2-6, 2-7, 3-2, 3-4, 3-6, 3-7, 3-11, 4-1, 4-5, 4-6, SAM 4670-4, SAM 4673-1, and comment sheet.</p>

Publication No.
62947909

C1989-2

Address comments concerning this manual to:

REVISION LETTERS I, O, Q AND X ARE NOT USED

Control Data Corporation
Plymouth Publications Department
2200 Berkshire Lane
Plymouth, Minnesota 55441

©1980, 1981

by Control Data Corporation
Printed in the United States of America

or use Comment Sheer in the back
of this manual.

MANUAL TO EQUIPMENT LEVEL CORRELATION SHEET

This manual reflects the equipment configurations listed below.

EXPLANATION: Locate the equipment type and series number, as shown on the equipment FCO log, in the list below. Immediately to the right of the series number is an FCO number. If that number and all of the numbers underneath it match all of the numbers on the equipment FCO log, then this manual accurately reflects the equipment.

EQUIPMENT TYPE	SERIES	WITH FCO'S	COMMENTS
BR808-A	01 02 03	01181	Update by ECO 01319 only
BR808-B	01 02 03	01181	Update by ECO 01319 only
BR812-A	01 02 03	01181	Update by ECO 01319 only
BR812-B	01 02 03	01181	Update by ECO 01319 only
FA741-A	01 02 03 04	00952 01096 01270	Associated ECOs are 01096, 01143, and 01173
MA453-H	01		

LIST OF EFFECTIVE PAGES

New features, as well as changes, deletions, and additions to information in this manual are indicated by bars in the margins or by a dot near the page number if the entire page is affected. A bar by the page number indicates pagination rather than content has changed.

PAGE	REV	PAGE	REV	PAGE	REV
Front Cover	-	3-8 thru 3-10	A	SAM 4603-4	A
Title Page	-	3-11	B	SAM 4603-5	A
ii	B	3-12 thru 3-62	A	SAM 4603-6	A
iii/iv	B	4-1	B	SAM 4610-1	A
v	B	4-2 thru 4-4	A	SAM 4610-2	A
vi	B	4-5, 4-6	B	SAM 4610-3	A
vii	B	A-1 thru A-16	A	SAM 4610-4	A
viii thru xi	A	Notice	-	SAM 4610-5	A
xii	B	SAM 4600-1	A	SAM 4610-6	A
1-1	A	SAM 4600-2	A	SAM 4610-7	A
1-2	B	SAM 4600-3	A	SAM 4610-8	A
1-3 thru 1-7	A	SAM 4600-4	A	SAM 4610-9	A
1-8	B	SAM 4600-5	A	SAM 4611-1	A
1-9 thru 1-12	A	SAM 4600-6	A	SAM 4611-2	A
2-1 thru 2-2	A	SAM 4601-1	A	SAM 4611-3	A
2-3	B	SAM 4601-2	A	SAM 4611-4	A
2-4 thru 2-5	A	SAM 4601-3	A	SAM 4611-5	A
2-6	B	SAM 4601-4	A	SAM 4611-6	A
2-6.1/.2	B	SAM 4601-5	A	SAM 4611-7	A
2-7	B	SAM 4601-6	A	SAM 4611-8	A
2-8 thru 2-17	A	SAM 4602-1	A	SAM 4611-9	A
3-1	A	SAM 4602-2	A	SAM 4620-1	A
3-2	B	SAM 4602-3	A	SAM 4620-2	A
3-3	A	SAM 4603-1	A	SAM 4620-3	A
3-4	B	SAM 4603-2	A	SAM 4620-4	A
3-5	A	SAM 4603-3	A	SAM 4620-5	A
3-6, 3-7	B				

PAGE	REV
SAM 4620-6	A
SAM 4621-1	A
SAM 4621-2	A
SAM 4621-3	A
SAM 4621-4	A
SAM 4621-5	A
SAM 4670-1	A
SAM 4670-2	A
SAM 4670-3	A
SAM 4670-4	B
SAM 4671-1	A
SAM 4671-2	A
SAM 4672-1	A
SAM 4672-2	A
SAM 4673-1	B
SAM 4673-2	A
SAM 4673-3	A
Comment Sheet	B
Mailer	-
Back Cover	-

PAGE	REV
------	-----

PAGE	REV
------	-----

PREFACE

This manual provides information to aid in the installation, checkout, and on-site maintenance of the CDC 80210-10/80240 Flexible Disk Drive (FDD). The 80210-10 FDD is a standalone unit. The 80240 is a unit that has a FDD combined with a mini module drive (MMD). Site information for the MMD is contained in another manual (refer to listing on next page).

The standalone and combination versions of the FDD are functionally the same. Both include an attachment card and the necessary cabling to interface with an IBM* Series/1 computer. Product and equipment number correlation is as follows:

<u>Product Number</u>	<u>Equipment Number</u>	<u>Description</u>
80210-10	BR808-A/B**	FDD
	FA741-A	FDD Attachment Card
	MA453-H	BASIC Diskette (P/N 663107XX)
80240-Series	BR812-A/B**	FDD
	FA741-A	FDD Attachment Card
	BG702-Series	MMD
	FA740-C	MMD Attachment Card
	MA453-H	BASIC Diskette (P/N 663107XX)

Organization of this manual is divided into four sections plus an appendix.

- Section 1 - General Description
- Section 2 - Installation and Checkout
- Section 3 - Maintenance
- Section 4 - Spare Parts Lists
- Appendix A - Diagnostic Aids

*Registered trademark of International Business Machines Corporation.

**BR808-A and BR812-A operate with 208/230-V ac input; BR808-B and BR812-B operate with 120-V ac input.

The structured analysis method (SAM) listings contained in the appendix may be removed from this manual and inserted in the lefthand side of the associated IBM MAP/MIM maintenance logic manual (MLM) binder. The remainder of this manual may then be inserted in the righthand side of the same MLM. This allows for easy cross-referencing between the SAMs and associated procedures contained in section 3 of this manual when performing maintenance.

Additional manuals providing reference and support-level information on the FDD, MMD, and associated attachment cards are included in the list that follows. All manuals may be ordered from:

Control Data Corporation
Literature and Distribution Services
304 North Dale Street
St. Paul, Minnesota 55103

<u>Title</u>	<u>Publication Number</u>
80210 Flexible Disk Drive and 80230/80240 Mini Module Drive Reference Manual	62947908
Flexible Disk Drive Attachment Feature FA741-A, 80210 Flexible Disk Drive Cabinet, and 80210/80240 Flexible Disk Drive Power Supply Hardware Maintenance Manual (Support Information)	62947910
Flexible Disk Drive, Model 9406 Hardware Maintenance Manual (Support Information)	75888335
80230/80240 Mini Module Drive Hardware Maintenance Manual (Site Information)	62947905
80230/80240 Mini Module Drive and Mini Module Drive Attachment Feature FA740-C Hardware Maintenance Manual (Support Information)	62947907
Certainty Series System Test and Freelance Reference Manual	62947920
Standalone Utilities Users Guide	62981800

CONTENTS

1.	GENERAL DESCRIPTION	
	FDD Physical Description	1-3
	Attachment Card Physical Description	1-4
	FDD Functional Description	1-4
	FDD Assembly Functions	1-5
	Status Monitoring	1-6
	FDD Ready	1-6
	Diskette Type and Write Protect	1-6
	Index	1-7
	Heads at Cylinder 00	1-7
	Write Fault	1-7
	Command Execution	1-7
	Head Movement and Selection	1-8
	Head Load and Read/Write	1-8
	Power Supply Functions	1-8
	Attachment Card Functional Description	1-9
	Overall Functions	1-9
	Initial Program Load (IPL)	1-12
2.	INSTALLATION AND CHECKOUT	
	Packaging	2-1
	Installation	2-1
	Installing Standalone FDD	2-2
	Installing Attachment Card and Cabling	2-4
	Checkout	2-10
	Configuring Basic Diskette	2-10
	Diagnostic Checkout	2-17
3.	MAINTENANCE	
3.0	General Maintenance Information	3-2
3.0.1	Precautions for Safety and Equipment	3-2
3.0.2	Troubleshooting Philosophy	3-3
3.0.3	Maintenance Tools and Materials	3-4
3.0.4	FDD Controls and Indicators	3-4
3.0.5	Physical Location Codes	3-6
3.0.6	Operating FDD	3-8
3.0.6.1	Powering On/Off FDD	3-8
3.0.6.2	Installing a Diskette	3-8
3.1	Accessing FDD for Maintenance	3-10
3.1.1	Accessing FDD in a Standalone Unit	3-10

- 3.1.2 Accessing FDD in a Combination Unit 3-12
- 3.2 FDD Assembly (B3) 3-14
- 3.2.1 Removal-Replacement of FDD Assembly in a Standalone Unit 3-14
- 3.2.2 Removal-Replacement of FDD Assembly in a Combination Unit 3-16
- 3.3 FDD Power Supply (B1) 3-18
- 3.3.1 Removal-Replacement of FDD Power Supply in a Standalone Unit 3-18
- 3.3.2 Removal-Replacement of FDD Power Supply in a Combination Unit 3-21
- 3.4 Spindle-Drive Belt 3-22
- 3.4.1 Removal-Replacement of Spindle-Drive Belt in a Standalone Unit 3-22
- 3.4.2 Removal-Replacement of Spindle-Drive Belt in a Combination Unit 3-25
- 3.5 On/Off-Switch Box (B2) 3-26
- 3.5.1 Removal-Replacement of On/Off-Switch Box in a Standalone Unit 3-26
- 3.6 CDC Basic Diskette Diagnostics 3-28
- 3.6.1 IPL and Running FDD Diagnostics with no other FDD Available Except Unit to be Tested . . . 3-30
- 3.6.2 IPL and Running FDD Diagnostics with Another FDD Available 3-34
- 3.7 Configurator Table Information 3-42
- 3.7.1 Changing Configurator Table Manually Using Operator/Programmer Panel 3-42
- 3.7.2 Configure System (Option 0C) Using Operator/Programmer Panel 3-44
- 3.7.3 Configurator Table Entries 3-44
- 3.7.3.1 Definition of Entry 00 (System Entry) . . . 3-45
- 3.7.3.2 Definition of Entries 01-XX (Device Entries) 3-46
- 3.7.3.3 Configurator Table Layout (Shown as Stored in Memory) 3-48
- 3.8 Entering Commands 3-49
- 3.8.1 Single Character Commands (No Data) 3-49
- 3.8.2 Commands that use a Program Number (Commands B and C) 3-50
- 3.8.3 Command to set Option Bits On (Command D) . . 3-50
- 3.8.4 Command to Enter Variable Data (Reply to a Program, Command F) 3-51
- 3.9 Common Halt List 3-52
- 3.9.1 Diagnostic Control Program (DCP) Halts . . . 3-52
- 3.9.2 Configurator Halts 3-53
- 3.9.3 MAP Diagnostic Integration (MDI) Halts . . . 3-58
- 3.10 Error Abort Message 3-60

- 4. SPARE PARTS LISTS 4-1

APPENDIX

A. DIAGNOSTIC AIDS

Explanation of SAM Format	A-1
Diagnostic Program SAM	A-2
Paper-Only SAM	A-3
Description of Diagnostic Tests	A-4
FDD Auto-Diagnostic Tests	A-4
4600 Channel Interface Test	A-4
4601 Attachment Test	A-4
4602 Seek and Read Sector ID Test	A-5
4603 Seek and Read Data Test	A-6
FDD Manual Diagnostic Tests	A-6
4610 Write Sector ID and Data Test	A-6
4611 Write/Read Address Marker Test	A-7
4620 Cycle Steal Status Analysis Routine	A-8
4621 Continuation of Cycle Steal Status Analysis	A-8
Description of Cycle Steal Status Words	A-9
Cycle Steal Status Word 0 (Residual Address)	A-9
Cycle Steal Status Word 1 (FDD Status)	A-9
Cycle Steal Status Words 2 and 3 (Search Argument)	A-11
Cycle Steal Status Word 4 (Additional FDD Status and Error Log)	A-11
Cycle Steal Status Word 5 (FDD Health Parameters)	A-16

FIGURES

1. GENERAL DESCRIPTION

1-1	FDD and Attachment Card	1-1
1-2	Combination and Standalone Units	1-3
1-3	Physical Relationship of Attachment Card	1-4
1-4	Major Components of FDD Assembly	1-5

2. INSTALLATION AND CHECKOUT

2-1	Installation of Standalone FDD	2-3
2-1.1	FDD Power Supply Programming Plug (J02)	2-4
2-1.2	MMD/FDD Diagram with Jumper Location Codes	2-4.1
2-2	Attachment Card Switches	2-5
2-3	Overcurrent Potentiometer and Attachment Card Cabling	2-7
2-4	Backpanel Pin Configuration	2-9
2-5	Minimum Load Switch (4952-A)	2-10

A. DIAGNOSTIC AIDS

A-1	Diagnostic Program SAM Example	A-2
A-2	Paper-Only SAM Example	A-3

TABLES

1. GENERAL DESCRIPTION

1-1	FDD Specifications	1-2
1-2	Seek, Read, and Write Operations	1-10

2. INSTALLATION AND CHECKOUT


2-1	IBM/CDC Device-Type Assignments	2-16
-----	---	------

A. DIAGNOSTIC AIDS

A-1	Cycle Steal Status Word 1 Definition	A-9
A-2	Cycle Steal Status Word 4, Byte 1 Definition	A-11
A-3	Cycle Steal Status Word 4, Byte 2 Definition	A-12
A-4	Cycle Steal Status Word 5 Definition	A-16

The flexible disk drive (FDD, figure 1-1) is a random-access storage, program-load device that interfaces with an IBM Series/1 computer via an attachment card. The FDD mounts in the IBM Series/1 4997 Rack Enclosure and may be combined with a mini module drive (MMD) or may be mounted alone. The attachment card for the FDD is installed either in the Series/1 processor unit or I/O expansion unit. Two cables connect the FDD to the attachment card, an I/O cable that carries signal interchange and an attachment power cable that provides +20 V to the attachment card.

The FDD uses the double-frequency-coded method of recording data and can read/write on CDC 421 and IBM Diskette 1 one-sided diskettes and CDC 424 and IBM Diskette 2 two-sided diskettes that are soft sector. Each diskette side contains 77 tracks, 75 for storage and 2 reserved as alternates. Track numbering begins at the outer edge with 00 and ends in the center with 76. Formatting of tracks is programmable and may be eight 512-byte sectors, fifteen 256-byte sectors, or twenty six 128-byte sectors.



03439-3

Figure 1-1. FDD and Attachment Card

Table 1-1 lists the FDD specifications. The remainder of this section provides a brief physical and functional description of the FDD and its attachment card. For more detailed descriptions, refer to the hardware maintenance manuals listed in the preface.

TABLE 1-1. FDD SPECIFICATIONS


Characteristic	Specification	
<u>Size</u>	<u>Standalone</u>	<u>Nonstandalone</u>
Height	352 mm (13.87 in)	295 mm (11.63 in)
Width	235 mm (9.25 in)	143 mm (5.63 in)
Length	565 mm (22.25 in)	549 mm (21.63 in)
Mass	11.3 kg (25 lb)	11.3 kg (25 lb)
<u>Temperature</u>		
<u>Storage</u>		
Range	-35°C to 65°C (-30°F to 150°F)	
Maximum change	33°C/hr (60°F/hr)	
<u>Operating</u>		
Range	10°C to 40.5°C (50°F to 105°F)	
Maximum change	6.7°C/hr (12°F/hr)	
<u>Humidity</u>		
<u>Storage</u>	5% to 95%, no condensation	
Operating	20% to 80%, no condensation	
<u>Altitude</u>		
<u>Operating</u>	305 m (1000 ft) below sea level to 3048 m (10,000 ft) above sea level	
Transit	305 m (1000 ft) below sea level to 4560 m (15,000 ft) above sea level	
<u>Power Requirements</u>		
AC power input	208/230 V, 60 \pm 1.2 Hz (BR808-A, BR812-A) 120 V, 60 \pm 1.2 Hz (BR808-B, BR812-B)	
<u>Recording, Physical</u>		
<u>Bits/byte</u>	8	
<u>Tracks/surface</u>	77	
<u>Sectors/track</u>	8, 15, or 26 (format dependent)	
<u>Density (nominal)</u>		
Head 0 outer track	1835 b/i (72 b/mm)	
inner track	3268 b/i (129 b/mm)	
Head 1 outer track	1879 b/i (74 b/mm)	
inner track	3408 b/i (134 b/mm)	
<u>Data Capacity*</u>		
<u>Surfaces</u>	2, maximum	
<u>Index</u>	1	
<u>Tracks</u>	154, maximum (77 cylinders, 2 tracks/cylinder)	
<u>Tracks/inch</u>	48	
<u>Sectors/track</u>	8, 15, or 26 (format dependent)	
<u>Bytes/sector</u>	4096, 3840, or 3328 (format dependent)	
<u>Bits/inch</u>	3268	
<u>Unformatted Data Capacity*</u>		
<u>Bytes/track</u>	5,208	
<u>Bits/track</u>	41,664	
<u>Bits/surface</u>	3,208,128	
<u>Total capacity (bits)</u>	6,416,256	

TABLE 1-1. FDD SPECIFICATIONS (CONTD)

Characteristic	Specification
<u>Performance</u>	
Diskette rotation	360 +12.6 r/min
Data transfer rate	249,984 b/s
<u>Latency**</u>	
Average	83.33 ms
Maximum	166.7 ms
<u>Positioning time</u>	
Single track	6 ms, plus 10 ms head setting
Random average	160 ms
Maximum	466 ms
Start/Stop	Less than 2 seconds, maximum
*Based on 8-bit bytes.	
**Latency is time required for a particular sector to be located at the selected read/write head after positioning has been completed.	

FDD PHYSICAL DESCRIPTION

The FDD is comprised of two field-replacable assemblies, a FDD assembly and a power supply. Figure 1-2 shows the FDD in a combination unit (with a MMD) and in a standalone unit. With the combination unit, the FDD is housed within the MMD cabinet and the front panel On/Off switch controls power to both devices. With the standalone unit, the FDD is housed in a separate cabinet with a separate On/Off switch.




03515

Figure 1-2. Combination and Standalone Units

ATTACHMENT CARD PHYSICAL DESCRIPTION

The attachment card consists of a printed-circuit (PC) card containing large-scale integrated circuits that interface the FDD to the Series/1 processor (figure 1-3). The card is installed either in the Series/1 processor unit or I/O expansion unit and plugs directly into the backpanel I/O connectors. Connection with the FDD is via the I/O cable, which connects to the front of the card.

The card receives its required power from two sources, +5 V and -5 V from the Series/1 power supply via the backpanel and +20 V from the FDD power supply via the attachment power cable. A voltage regulator on the card regulates the +20 V to +12 V to power an integrated circuit that functions as a FDD controller.



03630

Figure 1-3. Physical Relationship of Attachment Card


FDD FUNCTIONAL DESCRIPTION

The following paragraphs describe the functions of the FDD assembly and power supply that comprise the FDD.

FDD ASSEMBLY FUNCTIONS

The FDD assembly contains the circuits and electromechanical parts necessary to recover and record diskette data. This along with preliminary head movement, head loading, and head selection are all done under direction of the attachment card. The major parts of the assembly (figure 1-4) include the following:

- A spindle and drive motor that holds and rotates the diskette.
- Two carriage-mounted read/write heads (one for each diskette side) designated as heads 0 and 1 that detect magnetized bits on the diskette during a read and record magnetized bits on the diskette during a write. Head 0 is on the right side of the diskette; head 1, on the left.
- A stepping motor that moves the read/write heads back and forth between the inner and outer cylinders of the diskette. (The term cylinder refers to the same track position on two diskette sides.)



03446-3

Figure 1-4. Major Components of FDD Assembly

- A head-load solenoid that places the heads against the diskette.
- A PC logic board that monitors operating status for the attachment card and executes its commands.

The next paragraphs describe the status monitoring and command execution done by the logic board.

Status Monitoring

Following a power-on, the logic board keeps the attachment card informed of the following status:

- FDD ready
- Diskette type and write protect
- Index
- Heads at cylinder 00
- Write fault

FDD Ready

The logic board sends the attachment card a Ready signal when a diskette is installed, door is closed, and rotation of the diskette is above 70 percent of nominal 360 rpm. A switch detects if the door is closed and the rate of Index pulses denote diskette speed. The Index pulses come from a phototransistor that picks up the light of a light-emitting diode (LED) each time the index hole in the diskette rotates between them.

Diskette Type and Write Protect

Diskette Type and Write Protect signals inform the attachment card whether the installed diskette is one-sided or two-sided and if it is write protected. These characteristics are detected by three pairs of LEDs and phototransistors; two of which generate the previously mentioned Index pulse. The different location of the index hole in one-sided and two-sided diskettes results in only one detector outputting an Index pulse, thus distinguishing diskette type.

The third LED and phototransistor senses whether the write-protect slot in the diskette jacket is open or covered (only CDC diskettes contain this slot). If the slot is open (not covered with opaque tape), the logic board inhibits any writing on the diskette.

Index

The Index pulse is sent to the attachment card to indicate the starting point of the tracks on the diskette and for additional monitoring of diskette speed.

Heads at Cylinder 00

The logic board sends a Track 00 signal when a LED and phototransistor sense that the carriage containing the heads is fully retracted. In this position, the heads are at cylinder 00 (the outer most cylinder) on the diskette.

Write Fault

If any of the following conditions occur, the logic board sends a Write Fault signal to notify the attachment card that data cannot be properly written:

- Write Enable signal received from attachment card when heads are not loaded.
- Write Enable signal received but no write data.
- Write Enable signal received without erase current being present.

Command Execution

Commands from the attachment card direct all logic board operations. These operations include the following:

- Head movement and selection
- Head load and read/write

Head Movement and Selection

When performing a seek, the attachment card issues a Direction signal and Step pulses to move the heads and a Head Select signal that specifies which head is to be used in the subsequent read/write. For each Step pulse, the logic board alternately energizes two of the four phases of the stepper motor, moving the heads one cylinder in or out in accordance with the Direction signal.

Head Load and Read/Write

To begin a read or write, the attachment card issues a Head-Load signal that loads the heads against the diskette. The attachment card then specifies, via a Write Enable signal, whether the selected head is to read or write. If a read, the recorded bits sensed by the read/write winding of that head are serially transferred to the attachment card.

If a write, the erase winding on the selected head is energized to erase previously recorded data and a write current is applied to its read/write winding. The polarity of the write current reverses with each low-to-high transition of the data pulses received from the attachment card. If the head is on a track that is 43 or greater, a Low Current signal from the attachment card causes the write current to be reduced on these more densely recorded tracks.

After the read or write is complete, the attachment card drops the Head-Load signal, which retracts the heads from the diskette.

POWER SUPPLY FUNCTIONS

There are two types of power supplies, one that operates with 120-V ac input and another that operates with 208/230-V ac input. The input voltage comes from the Series/1 ac distribution panel and is controlled by the On/Off switch on the cabinet housing the FDD.

The power supply contains a line filter, a transformer, a rectifier/regulator board, and an ac-entry circuit breaker. The circuit breaker provides overcurrent protection and has an auxiliary coil that trips if any dc output of the power supply goes exceedingly high. Power supply outputs include the following, none of which are adjustable:

- +1.5 V that lights the LED adjacent to the On/Off switch to indicate that FDD power is on.
- 104 to 127 V ac that powers the FDD spindle-drive motor.
- +20 V that goes to the attachment card via the attachment power cable.
- +5 V and +24 V that powers the FDD logic board and associated electromechanical parts.

ATTACHMENT CARD FUNCTIONAL DESCRIPTION

The following paragraphs describe the overall functions of the attachment card and its performance during an initial program load (IPL).

OVERALL FUNCTIONS

The attachment card interfaces the FDD to the Series/1 processor and serves as the FDD controller. The attachment card interprets the commands from the processor, checks its status and status of the FDD, performs the instructed operation, and responds with condition codes and interrupt information to indicate if the operation completed successfully. Except during an IPL, all seek, read, and write operations listed in table 1-2 are initiated when the attachment card receives a start command. The accompanying instructions in the start-command device control block (DCB) specify the operation to be performed and contain parameters that govern the operation. Parameters include:

- Seek difference, seek direction, and head selection - given for all seeks except a recalibration seek. These seek parameters specify the number of cylinders the heads are to move, the direction, and the head that is selected for subsequent read/write operations.
- Sector length and cylinder number - given for all read/write operations. Sector length specifies the length of sectors on the diskette, or if a write format, the format that is to be written (eight 512-byte sectors, fifteen 256-byte sectors, or twenty six 128-byte sectors). In conjunction with the head that is selected, the cylinder number indicates the track location for the read/write.

- Sector number - given for all read/write operations except read sector ID and write format. The sector number indicates the starting sector location for the read/write.
- Byte quantity and data address - given for all read/write operations except read-verify and write format. Byte quantity specifies the number of data bytes that are to be read or written. The data address indicates the Series/1 memory location where the first two data bytes read are to be transferred, or if a write, where the first two write-data bytes are to be retrieved. Other data bytes are transferred to/from successive address locations until the byte quantity is satisfied.

TABLE 1-2. SEEK, READ, AND WRITE OPERATIONS

OPERATION	FUNCTION
Recalibration seek	Moves heads to cylinder 00 and selects head 0.
Seek	Moves heads and selects head per seek parameters.
Read sector ID	Transfers data from the first sector ID field read into Series/1 memory.
Read data	Transfers data from sector data field(s) into Series/1 memory. If the attachment card encounters a control-address marker, reading automatically halts at the end of that sector and the attachment card returns a unit-exception interrupt condition code and sets bit 3 of cycle steal status word 1.
Read-verify	The attachment card reads and checks the accuracy of the data written in the previous operation. No data is transferred to the Series/1 and the attachment card disregards control-address markers.
Write data with data-address marker	Writes data from Series/1 memory in sector data field(s), and attachment card automatically inserts a data-address marker (FB ₁₆ byte) preceding the data in each sector written. If a written data field is not full, the attachment card pads the remainder of the field with zeros.

TABLE 1-2. SEEK, READ, AND WRITE OPERATIONS (CONTD)

OPERATION	FUNCTION
Write data with control-address marker	Same as other write-data operation except that the attachment card inserts a control address marker (F8 ₁₆ byte) instead of a data-address marker.
Write format	Initializes a track per the format specified in sector-length parameter and fills the data fields of each sector written with a selected data pattern. If the program loaded in the Series/1 determines the track is defective (read-verify of track unsuccessful), the track is formatted into twenty six 128-byte sectors with FF ₁₆ bytes in every sector ID.

For an operation to be performed, the DCB must contain legal parameters, write data retrieved from Series/1 memory must be free of parity errors, and status of the FDD and attachment card must show that no error condition exists. If any of the preceding errors occur, the attachment card returns an interrupt condition code of unit exception and indicates the reason for unsuccessful completion in cycle steal status (significance of the cycle steal status words is described in appendix A).

In performing the operations, the attachment card issues the necessary commands to the FDD, finds the specified sector for the read or write, assembles the serial data that is read into 16-bit words, serializes the data words that are written, and transfers the data to/from the Series/1 memory. Accuracy of data transfers between the attachment card and Series/1 memory are verified by two parity bits that accompany each word that is transferred. Accuracy of diskette data is verified by two cyclic-redundancy-check (CRC) bytes that are recorded at the end of each sector ID and data field.

When performing a write, the attachment card checks the parity of words retrieved from memory, deletes the parity bits, and automatically calculates and inserts a CRC checksum in each field written. When performing a read, the attachment card adds parity bits to words transferred to memory, calculates a CRC as data is read, and compares the calculated checksum with the previously recorded CRC bytes. If the checksums do not compare, reading automatically halts and the attachment card returns a unit-exception interrupt condition code and sets bit 7 of cycle steal status word 1.

INITIAL PROGRAM LOAD (IPL)

The IPL sequence provides the Series/1 processor with the necessary program data to begin operations. For the sequence to occur, the diskette containing program data must be installed in the FDD, the Series/1 IPL Source switch set to correspond with the IPL assignment of the FDD (primary or alternate), and Series/1 Load switch pressed. The latter two actions cause the Series/1 processor to issue an appropriate IPL selection code on the Status Bus lines and output an Initiate IPL signal. Upon receipt, the attachment card automatically performs a recalibration seek, placing the heads at cylinder 00 and selecting head 0. When the next Index pulse occurs, the attachment card does an automatic read-data operation using a byte quantity of 256 (two 128-byte sectors) and a data address of 0000_{16} . If the 255th and 256th bytes read equal a word of $83C4_{16}$, the attachment card continues the operation until the data from the remaining 24 sectors on cylinder 00, head 0, has been transferred to Series/1 memory. The automatic reading of 26 sectors occurs when loading the diagnostic programs from the BASIC diskette.

If the attachment card detects an error condition during the sequence, it stores a 6410, 6411, 6412, 6420, or 6421_{16} code in memory location 0000_{16} to indicate that IPL was unsuccessful. Processor receipt of any of these codes result in $00E5_{16}$ being shown on the Series/1 operator/programmer panel indicators. (Corrective action for these circumstances is given in paper-only SAMs in appendix A.)

This section contains packaging, installation, and checkout information for the FDD.

CAUTION

MOS circuit-handling precautions are given in the maintenance section under Precautions for Safety and Equipment (para 3.0.1). Observe these precautions when handling or packaging the attachment card.

PACKAGING

The following packaging information only applies to the stand-alone FDD. Packaging of the MMD/FDD combination is covered in the MMD site information manual (refer to preface for publication number).

The FDD, mounting parts, and attachment card are shipped in corrugated containers and no unpackaging instructions are necessary. If the FDD is reshipped, it must be packaged as it was at the factory. Packaging material and/or instructions may be obtained from:

Control Data Corporation
Corporate Traffic
8100 34th Avenue South
Minneapolis, Minnesota 55440

When ordering packaging material, specify the exact equipment number and series code of the FDD as shown on its equipment identification label.

INSTALLATION

This portion of the section provides instructions for:

- Installing standalone FDD
- Installing attachment card and cabling

INSTALLING STANDALONE FDD


The following installation instructions only apply to the stand-alone FDD. Installation of the MMD/FDD combination is covered in the MMD site information manual.

1. Unpackage FDD, mounting parts, and attachment card and inspect for shipping damage. File promptly any claim for damage with the transporter involved. If a claim is filed, save original packaging materials.

CAUTION

Do not use a "lead" pencil to set rocker switches. Graphite dust from pencil can cause an equipment malfunction.

2. Look through perforated cover and verify that the eight rocker switches on FDD PC board are set in the following positions. If not, remove perforated cover (para 3.1.1 in maintenance section) and set switches using a ball-point pen. Replace cover when done.
 - Switches 1 and 5 in ON position (ON side of switch pressed down).
 - Other switches in OFF position (OFF side of switch pressed down).
3. Install equipment identification label and FCO log for attachment card on FDD as shown in figure 2-1.
4. Remove front panel from Series/1 rack enclosure where FDD is to be installed.
5. If mounting location already contains a mounting rack, go to step 6. Otherwise, position mounting rack in frame and fasten in front with four screws on each side (figure 2-1).
6. Rectangular cutout in bottom of FDD frame engages with one of the retaining clips on mounting rack. Be careful not to damage power cord or cables and engage FDD in desired side of mounting rack.
7. Route power cord, I/O cable, and attachment power cable to rear of Series/1 cabinet.




03636-4

Figure 2-1. Installation of Standalone FDD


8. Using two screws at top and bottom, fasten FDD to front of mounting rack.
9. If other half of mounting rack is vacant, install filler cover:
 - a. Position filler-cover mounting plate over vacant side of mounting rack as shown in figure 2-1 and fasten with four screws.
 - b. Press filler cover onto mounting plate.

10. Hook bottom of front cover on FDD frame and snap cover into place.
11. If unit is rated for 120 V, go to step 13. See figure 2-1.1 for 120 V, 60 Hz programming plug configuration.
12. For 208 V or 230 V units, proceed as follows:
 - a. Measure ac source voltage at outlet to which FDD is to be connected.
 - b. If the source voltage is less than or equal to 220 V, then go to step 13. See figure 2-1.1 for 208 V, 60 Hz programming plug configuration.
 - c. If the source voltage is greater than 220 V, then the FDD programming plug at location J02 on the power supply must be restrapped for 230 V, 60 Hz. Using a pin extractor (part number 51876100), restrap programming plug using figures 2-1.1 and 2-1.2 as references.
13. Verify that on/off switch for FDD is pressed to OFF and open rear door of Series 1 cabinet. Connect power cord from FDD to Series 1 ac distribution panel, but leave switch off.



PPG-0412-1A

Figure 2-1.1 FDD Power Supply Programming Plug (J02)



⚠ IF UNIT IS A STAND-ALONE MMD THIS CABLE IS CONNECTED AT A3 AS INDICATED BY DOTTED LINE. IF UNIT IS MMD/FDD COMBO THIS CABLE IS CONNECTED AT J06 ON FDD POWER SUPPLY

PPG-0414-1C

Figure 2-1.2 MMD/FDD Diagram with Jumper Location Codes

INSTALLING ATTACHMENT CARD AND CABLING

Install attachment card and cabling as follows:

NOTE

The attachment card requires +5-V and -5-V power from the I/O channel. The card cannot be installed in card location A (extreme left location in chassis) unless the unit is a 4952-A. A 4952-A is the only model that has both voltages in location A.

1. Confer with customer to determine required location of attachment card in Series/1 (either in processor unit or I/O expansion unit), required device address, and whether FDD is to be assigned as primary or alternate IPL device.

NOTE

Priority is established in order of placement from right to left within each chassis. The processor unit has higher priority than the I/O expansion unit.

CAUTION

Do not use a "lead" pencil to set rocker switches. Graphite dust from pencil can cause an equipment malfunction.

2. Set rocker switches on attachment card for FDD device address and IPL assignment (figure 2-2). For example, to assign device address 13₁₆, set switches S1-6, S1-9, and S1-10 so that OPEN side of switch is pressed down (logical 1), and set switches S1-3, S1-4, S1-5, S1-7, and S1-8 so that closed sides are pressed down (logical 0). To assign FDD as primary IPL device, set S1-1 to closed position and set S1-2 to OPEN position.

3. Power off processor unit or I/O expansion unit, as applicable, by pressing associated On/Off switch at front of unit.
4. Remove snap-on cover from front of processor unit or I/O expansion unit as applicable and loosen I/O cable retaining bracket at top of unit.
5. Open rear door of Series/1 cabinet and route I/O cable and attachment power cable through retaining bracket to front of chassis. Allow enough cable to reach attachment card and retighten retaining bracket.
6. Connect attachment power cable to connector on side of attachment card (connector orientation is not important).
7. Install attachment card in chassis not more than two card locations away from any existing card.




Figure 2-2. Attachment Card Switches

NOTE

If the attachment card is being installed between cards that are separated by more than one open card slot, remove the poll-propagate jumper (back-panel pins M11 and M12) from the slot containing attachment card. In some units, poll-propagate jumpers may be installed even though an expansion chassis is not present. Refer to Poll-Propagate Wiring in the applicable processor theory manual for additional information.

8. Observe direction of arrow (I/O cable is installed so that arrow points up to red stripe) on I/O cable connector and connect I/O cable to front of attachment card (figure 2-3).

CAUTION

Existing cables are marked with arrow pointing up when correctly installed. Newer cables are keyed to be installed one way only.

9. Press FDD On/Off switch to On and check that adjacent LED lights. If not, go to rear of cabinet and change position of circuit breaker on FDD power supply through access hole in perforated cover.
10. If attachment card is being installed in a 4952-A, skip the following and go to step 11. For all other models, adjust overcurrent and +5-V potentiometers as follows:
 - a. Apply power to unit in which attachment card is installed.

NOTE

If chassis power does not come up, turn overcurrent potentiometer (figure 2-3) clockwise one full turn; press unit On/Off switch to Off, then to On. Keep repeating this clockwise adjustment and power sequencing until power comes up.

- b. Turn overcurrent potentiometer slowly counterclockwise until power goes off. Then turn potentiometer as follows:
 - 4953-A/C (125 watt supply) - eight-full turns clockwise.




Figure 2-3. Overcurrent Potentiometer and Attachment Card Cabling

- 4953-B/D, 4955-A/B/C/D, and 4959 (300-watt supply) - four-full turns clockwise.
 - 4952-B, 4955-E (400-watt supply) - seven-full turns clockwise.
- c. Press unit On/Off switch to Off, then to On. If Check indicator on Series/1 operator/programmer panel lights following power application, an electrical malfunction exists on attachment card or problem has developed in the Series/1. Replace attachment card and retry. If error persists, remove attachment card and retry to determine if problem is in Series/1.
- d. Press On/Off switch to Off and remove backpanel cover from unit logic chassis.

CAUTION

If probes short a signal pin and voltage pin with power applied, logic circuits will be damaged.

- e. Connect voltmeter to following backpanel pins (figure 2-4):
- +5-V pin at A2D03
 - Ground pin at A2D08
- f. Press On/Off switch to On and adjust +5-V potentiometer for $+5 \pm 0.5$ V (figure 2-4). Adjust as close to nominal as possible.
- g. Press On/Off switch to Off, disconnect voltmeter, and replace backpanel cover.
- h. Press On/Off switch to On.




Figure 2-4. Backpanel Pin Configuration

11. The following applies only to a 4952-A model. Verify Minimum Load switch is set correctly:
 - a. Remove rear cover of power supply and lower hinged transformer box to view switch (figure 2-5).
 - b. If four cards or less are installed in logic chassis, set switch to On (up) position. If five or more cards are installed, set switch to Off (down) position.
 - c. Swing up transformer box and replace cover.
 - d. Press unit On/Off switch to On. If Check indicator on Series/1 operator/programmer panel lights following power application, an electrical malfunction exists on attachment card or problem has developed in the Series/1. Replace attachment card and retry. If error persists, remove attachment card and retry to determine if problem is in Series/1.




Figure 2-5. Minimum Load Switch (4952-A)

12. Verify that red LED on attachment card is not lit (LED stays on if self-test error occurs). Replace attachment card if LED remains lit.
13. Replace front snap-on panel and close rear door of Series/1 cabinet.

CHECKOUT

Checkout of the FDD involves:

- Configuring BASIC diskette
- Diagnostic checkout

CONFIGURATING BASIC DISKETTE

The FDD must be added to the system configurator table on the applicable CDC BASIC diskette. The configurator table on each diskette must as a minimum contain the configuration information for all devices to be tested by that diskette. The following

procedure describes the steps to be used for updating the configurator table by either adding the devices individually, or by performing the configure system option (0C).

NOTE

The configurators on IBM diskettes do not recognize CDC devices. Therefore, do not attempt to use an IBM configurator to construct the configurator table on a CDC BASIC diskette. All CDC devices will be configured wrong.

1. Install CDC BASIC diskette, part number 663107XX, in FDD (para 3.0.6.2 in maintenance section).

NOTE

The CDC BASIC diskette has a pre-assigned alternate console selected for either a CDC 80610 display or an IBM 4979 display (AATT = 0442).

2. Place IPL Source switch on Series/1 operator/programmer panel to Alternate or Primary position as applicable to enable loading from diskette.
3. Place Mode switch on Series/1 operator/programmer panel to Diagnostic position.
4. Press Load switch on Series/1 operator/programmer panel. This starts IPL execution. Execution time is approximately twenty two seconds. Go to step 4a, 4b, 4c, or 4d as applicable.

NOTE

To enter commands from an assigned alternate console, key in the command characters and press ENTER key if a display station or Carriage Return key if a TTY.

- a. If an alternate console is assigned per the pre-configured diskette (see note of step 1), all messages appear on assigned alternate console and on operator/programmer panel if present.

- If a configurator error message appears on console screen (3822₁₆ on operator/programmer panel), this signifies that configurator table does not match system configuration. Go to step 5 to update table.
 - If a secure customer interface message appears on screen, (382A₁₆ on operator/programmer panel), go to step 11.
 - If any other message appears on screen (38XX₁₆ on operator/programmer panel), that condition must be corrected before continuing. Refer to para 3.9 for list of halt codes.
- b. If either a 80610, 4978, 4979, or TTY display device is present, but no message appears on screen, and an operator/programmer panel is not available, do the following to assign an alternate console:
- Install an existing diskette (IBM or CDC) that has an alternate console assigned correctly.
 - Press Load switch to IPL diskette.
 - When IPL is complete, message appears on screen. Remove diskette and install diskette that is to be configured.
 - Enter B38F9 (menu appears on screen).
 - Enter F02 to select patch program option.
 - Enter F38F1 (data set name).
 - Enter F3008 (start address).
 - Enter F0001 (word count).
 - Enter device address and device type of desired alternate console using format of FAATT where:
AA = device address.
TT = device type of alternate console as follows:
40 for a TTY device.
42 for either a CDC 80610 or an IBM 4979 display.
45 for an IBM 4978 display.
 - A patch-complete message indicates that new alternate console assignment has been written on diskette.

- Press Load switch. After IPL is complete, all messages will now appear on assigned alternate console. Go to step 5 to update configurator table.

- c. If a display station or TTY is present, and a 3801₁₆ halt code appears on operator/programmer panel, but no message appears on screen, do the following to assign an alternate console:

NOTE

(B) = Data Buffer switch
 (I) = Console Interrupt switch

- Enter (B),6,(I),(I) to continue.
- Next halt code is a 382A (secure customer interface), a 3822 (configuration errors on system), or a 382E (option table available for entry).
 - If a 382A halt code, secure customer interface and enter:
 (B),6,(I),(I) to advance to 3822 or 382E.
 - If a 3822 halt code, enter:
 (B),1F,(I),(B),0300,(I),(I) to advance to 382E.
 - If a 382E halt code, enter:
 (B),1F,(I),(B),0400,(I),(I) to select alternate console option.
- Next halt code is a 3821 (enter alternate console device address and device type). Enter:
 (B),1F,(I),(B),AATT,(I),(I) where: AA = device address and TT = device type. If a 3829 (no device) halt occurs, an entry error has been made. Enter:
 (B),6,(I),(I) to continue and reselect alternate console option.
- Next halt code is a 382E (option table is available for entry). Enter:
 (B),1F,(I),(B),0D00,(I),(I) to write new alternate console assignment on diskette.
- Next halt code is a 382C (copy configurator table to another diskette?). Enter:
 (B),1F,(I),(B),0500,(I),(I) to terminate.
- A 3800 or 3805 halt code indicates completion of program terminate function.

- Press Load switch to re-IPL. All messages will now appear on assigned alternate console. Go to step 5 to update configurator table.
- d. If no display station or TTY console is present and a 3801₁₆ halt code appears on operator/programmer panel, perform the following to change configurator table using operator/programmer panel:

NOTE

(B) = Data Buffer switch
(I) = Console Interrupt switch

- Enter (B),6,(I),(I) to continue.
- Next halt code is a 382A (secure customer interface), a 3822 (configuration errors on system), or a 382E (option table available for entry).
 - If a 382A halt code, secure customer interface and enter:
(B),6,(I),(I) to advance to 3822 or 382E.
 - If a 3822 halt code, enter:
(B),1F,(I),(B),0300,(I),(I) to advance to 382E.
 - If a 382E halt code, enter:
(B),1F,(I),(B),0400,(I),(I) to select assign alternate console option.
- Next halt code is a 3821 (enter alternate console device address and device type). Enter:
(B),1F,(I),(B),0000,(I),(I) to assign operator/programmer panel as alternate console.
- Next halt code is a 3832 (operator/programmer panel is the assigned alternate console).
- Enter (B),6,(I),(I) to continue.
- Next halt code is a 382E (option table is available for entry). Enter:
(B),1F,(I),(B),0D00,(I),(I) to write new alternate console assignment on diskette.
- Next halt code is a 382C (copy configurator table to another diskette?). Enter:
(B),1F,(I),(B),0500,(I),(I) to terminate.

- A 3800 (ready) halt code indicates system is ready for any valid input. Go to para 3.7.1 to update configurator table manually, or to para 3.7.2 to perform configure system option (0C).

5. Enter F03 to display option table.
6. Enter F0B to bypass option table display.
7. Skip steps 8 through 15 if configurator table is to be updated manually and go directly to step 16.
8. Enter F0C to select configure system option and follow series of prompts on alternate console. The new configurator table will automatically be written on diskette.
9. An option to write configurator table on another diskette or to terminate then appears on screen. Terminate by entering F05. A PT RDY ENTER then displays on screen.
10. Enter B38F0 to display option table.
11. Enter F0B to bypass option table display.

NOTE

Some CDC and IBM devices have the same read ID codes assigned. The configure system option assigns CDC device types to all IBM devices that have the same read ID code as the CDC devices. These IBM devices must be manually changed in the configurator table. Also, if a CDC 80270 or 80271 storage module drive having a read ID of 3007 is present in the configurator table, the device type must be changed from 72 to 70. To determine which device types in the table require changing, enter F09 (print system equipment) to display all system devices contained. Compare this listing with customer equipment list to determine which device types to change.

12. Enter F01 to display configurator table.
13. Enter F03 to select modify option.

14. Enter correct device type for each table entry to be modified by following prompts on alternate console. Refer to table 2-1 for device-type assignments.
15. Go to step 19.
16. Enter F01 to display configurator table.
17. Enter F0A (add option), F02 (delete option), F03 (modify option), or any other desired option from option table as applicable to make changes or additions to configurator table.

TABLE 2-1. IBM/CDC DEVICE-TYPE ASSIGNMENTS

READ ID	IBM PRODUCT/DEVICE TYPE		CDC PRODUCT/DEVICE TYPE	
0406	4979	44	80610	42
0206	4974	64	80420	62
0106	4964	48	80210	46
00AA	4962	78	80230	72
00CA	4962	78	80230	72
0306	4973	68	80450	66

18. Enter FDD device parameters per the following format:

F XX46 0000 0106 0000 0000 0000 0000 0106

Device Type

Device Address (use address that was established by switch settings on attachment card)

Response to above input is:

FUNCTION
ENTER

NOTE

Configuration information for all other CDC devices contained in the system may be entered at this time. Refer to the applicable site information manual for individual device-entry parameters.

19. Enter F01 to display configuration table. Verify that parameters were correctly entered.
20. Enter F0D to write new configuration information on diskette. If additional diskettes are to be written, install diskette and repeat this step for each diskette.
21. Enter F05 to terminate program. A PT ENTER message appears. Diskette is ready for running diagnostic tests.

DIAGNOSTIC CHECKOUT

Check out the FDD and attachment card as follows:

1. Run the following FDD diagnostic tests (para 3.6):
 - Auto-diagnostic tests 4600 through 4603
 - Manual diagnostic tests 4611 and 4610
2. Run CDC system test and freelance (diskette part number 663092XX) to verify correct system operation. System test and freelance reference manual contains instructions (refer to preface for publication number).

NOTE

New IBM diskettes are formatted,
whereas new CDC diskettes are not.

3. If customer will be using CDC diskettes, be sure that operating personnel are aware that new diskettes require formatting before data storage use. Customer may format diskettes using a standard utility of an operating system, or if a 128-byte-sector format is to be used, diskettes may be formatted using IBM Series/1 Stand-Alone Utilities described in IBM publication GC34-0070.



This section contains on-site maintenance information for the FDD. This information is divided into the following major paragraph groups:

NOTE

There is no preventive maintenance for the FDD.

- 3.0 General Maintenance Information - Contains information that maintenance personnel should be familiar with before doing maintenance: precautions for safety and equipment (3.0.1); troubleshooting philosophy (3.0.2); maintenance tools and materials (3.0.3); FDD controls and indicators (3.0.4); physical location codes (3.0.5); operating FDD (3.0.6).
- 3.1 Accessing FDD for Maintenance - Contains procedures for accessing the FDD in a standalone unit and in a combination unit.
- 3.2 through 3.5 - Contain removal and replacement procedures for the field replacable parts of the FDD. These procedures are associated with the SAM (structured analysis method) listings contained in appendix A.
- 3.6 CDC BASIC Diskette Diagnostics - Gives instructions for loading and running the FDD diagnostics.
- 3.7 and groups thereafter - Provide a summary of pertinent MAP 0010 Diagnostic Service Guide information.

3.0 GENERAL MAINTENANCE INFORMATION

3.0.1 Precautions for Safety and Equipment

WARNING

Observe the following precautions at all times. Failure to do so may cause damage and and/or personal injury.

- When at all possible, do maintenance work with the FDD On/Off switch Off. With the switch On, line voltage (120 or 208/230 V ac) is present at the FDD power supply and 104 to 127 V ac from the power supply goes to the spindle-drive motor.
- Always turn off power when disconnecting/connecting cables.
- Do not install a diskette in the FDD without power being on. Failure to do so may damage the diskette or cause the spindle-drive belt to slip off.
- The attachment card contains metal-oxide semiconductor (MOS) integrated circuits. MOS circuits are susceptible to damage from static electricity and require the following handling:
 - Turn off power to Series/1 and FDD before reseating, removing, or installing the attachment card.
 - Ensure that any item that comes in contact with the card is electrically grounded.
 - Touch logic chassis to bleed off any accumulated static charge before handling the card and continue to touch chassis while removing or installing it.
 - Handle only a noncircuit portion of the card. Connector pins and circuit paths must not be touched.
 - When the card is removed and is to be carried to another location or is to be shipped, wrap it in static protective material, such as aluminum foil or conductive foam.

3.0.2 Troubleshooting Philosophy

Aids for troubleshooting the FDD consist of the 46XX diagnostic tests residing on CDC BASIC diskette part number 663107XX and the SAMs contained in appendix A. When a diagnostic test detects an error, the corresponding SAM describes the applicable corrective action. This may involve doing one of the remove and replace procedures in this section or going to one of the supplemental paper-only SAMs to further define the problem.

If another FDD is available, use a scratch diskette (a diskette that does not contain any wanted information) in the unit to be tested and load the diagnostics on the BASIC diskette from the other unit. This assures that the problem in the test unit will not interfere with program loading. Instructions for loading and running the diagnostics in this way are given under para 3.6, which also includes similar instructions for when no other unit is available.

When no other unit is available, the problem in the FDD may make it impossible to load the diagnostics so they can be used for troubleshooting. If this occurs, use the following paper-only SAMs as applicable:

- SAM 4670 (Power-On and IPL Problems) is to be used when IPL of the BASIC diskette cannot be accomplished.
- SAM 4672 (Not Ready Status) is for when IPL is successful, but diagnostics do not execute, end abnormally (with or without a message), or end with a meaningless abort message.

Regardless of the troubleshooting method, always run the FDD diagnostics afterward to verify that the problem is corrected.

3.0.3 Maintenance Tools and Materials

Besides the usual hand tools (screwdrivers, wrenches, etc.), FDD maintenance requires the items listed in the following table.

MAINTENANCE TOOLS AND MATERIALS




DESCRIPTION	PART NUMBER
Voltohmmer	Ballantine 345 or equivalent
Extender, card*	CDC 61408349
Pin Extractor	CDC 51876100
*For use with FDD attachment card	

3.0.4 FDD Controls and Indicators

The controls and indicators on the FDD are shown on the next page and the following table explains their functions.

CONTROL/INDICATOR FUNCTIONS

CONTROL/INDICATOR	FUNCTION
On/Off Switch and LED (Light-Emitting Diode)	Pressing the switch to On applies power to the FDD, provides +20 V to the FDD attachment card, lights the LED, and if a combination unit, applies power to the associated MMD. Pressing switch to Off removes power and extinguishes the LED.
Circuit Breaker (2.5 A/120 V ac, 1.5 A/208/230 V ac)	Provides overcurrent protection for the FDD power supply and contains an auxiliary coil that trips if any dc voltage goes exceedingly high.
Rocker Switches	These switches numbered 1 through 8 control the gating of Unit Select and Ready signals to/from the FDD. Switches 1 and 5 must be pressed down in the ON position and the others pressed down in the OFF position.




03818

3.0.5 Physical Location Codes

The physical location codes assigned to parts of the FDD are shown below. The abbreviations used are as follows:

- P = connector, plug
- J = connector, receptacle





NOTE

One of two different types of B3J1 connectors on the FDD printed circuit board may be encountered when performing maintenance. One connector type is keyed to prevent incorrect installation of the I/O cable to the B3J1 connector. The other type is not (and cannot be) keyed. If the I/O cable is not correctly installed to this type of connector, damage to diskettes could result. Install the I/O cable with the red stripe up (arrow on cable should point up to red stripe).

WARNING

ENSURE CABLE IS INSTALLED SO THAT RED STRIPE IS UP. INCORRECT INSTALLATION MAY DESTROY DATA ON DISKETTE.



03613-4

3.0.6 Operating FDD

The following paragraphs describe powering on/off the FDD and installing a diskette.

3.0.6.1 Powering On/Off FDD

CAUTION

Do not install a diskette before power is on. Failure to do so may damage the diskette or cause the spindle-drive belt to slip off.

1. To power on FDD, press On/Off switch for FDD to On. LED next to switch lights and spindle-drive motor starts running.
2. Apply power to Series/1. Attachment card fully retracts heads after a short delay.
3. To power off FDD, remove installed diskette and press On/Off switch to Off. If Series/1 is to be powered off, then remove power from Series/1.

3.0.6.2 Installing a Diskette

1. With power on, open door of FDD.
2. Remove diskette from storage envelope, being careful not to touch recording surface exposed by diskette jacket.
3. If diskette is to be written on and is a CDC diskette, place opaque tape over write-protect slot in jacket.


NOTE

Only two-sided diskettes (the BASIC diskette or a scratch diskette) are installed when running FDD diagnostics.

4. Insert diskette into FDD as shown in the following illustration until jacket is solidly against stops.
5. Close door and ensure that door latches securely.
6. When diskette is to be removed, leave power on and open door. Opening door automatically stops diskette rotation, allowing removal.


INDEX HOLE IN
TWO-SIDED
DISKETTE

WRITE-PROTECT SLOT
(WRITING ON DISKETTE IS
DISABLED WHEN UNCOVERED)



LOCATION OF
INDEX HOLE IN
ONE-SIDED
DISKETTE

EXPOSED
RECORDING
SURFACE



03612

3.1 ACCESSING FDD FOR MAINTENANCE

To access the FDD for maintenance, refer to the following paragraphs as applicable:

- Para 3.1.1 if the FDD is mounted in a standalone unit
- Para 3.1.2 if the FDD is mounted in a combination unit

3.1.1 Accessing FDD in a Standalone Unit


1. Remove installed diskette and press On/Off switch for FDD to Off.
2. Lift bottom of front cover to release cover from unit.
3. Remove four screws securing unit to front of mounting rack.
4. Open rear door of Series/1 cabinet and make sure that FDD power cord and cables are free to extend forward when unit is removed.

CAUTION


Watch slack in cables during next step.

5. Pull unit forward out of mounting rack and set on floor or on a table.
6. Remove eight screws securing perforated cover to frame.
7. Cut cable tie at rear of perforated cover and remove tie and cable plate.
8. Lift perforated cover from frame.
9. To reinstall unit, do the preceding steps in reverse order and action. When replacing perforated cover, fasten cable plate over cables using a new cable tie (CDC part number 94277422) as shown in illustration.

FOUR SCREWS SECURING
UNIT TO MOUNTING RACK




03636-3




03640-1

3.1.2 Accessing FDD in a Combination Unit

1. Remove installed diskette from FDD and press unit On/Off switch to Off.
2. Insert an allen wrench into access hole and turn to release front cover latch.
3. Swing front cover out and lift to remove.
4. Remove four front mounting screws.
5. Slide unit forward until slide locks engage. Spring releases on slides must be pressed to disengage locks when unit is to be slid back.
6. Remove mounting screws and nuts from covers and lift covers off.
7. Release 1/4-turn fastener on top-left side of unit and lower MMD logic chassis to horizontal position.
8. If FDD assembly, FDD power supply, or spindle-drive belt is to be replaced, remove FDD mounting frame from unit as follows:
 - a. Open rear door of Series/1 cabinet and disconnect unit power cord from Series/1 ac distribution panel.
 - b. Disconnect ac power cable from front of FDD power supply.
 - c. Disconnect LED power cable from J6 on FDD power supply board. Pin 1 (white dot) of cable connector must mate with lower pin of J6 during reassembly.
 - d. Disconnect attachment power cable from J7 on power supply board. Connector orientation is unimportant during reassembly.
 - e. Disconnect I/O (flat ribbon) cable from FDD PC board.
 - f. Remove two retaining screws from lower front of FDD mounting frame.
 - g. Watch that cables do not snag against MMD power supply and slide FDD mounting frame forward to remove from unit.
9. To reinstall unit, do the preceding steps in reverse order and action.



03519



03446-4

3.2 FDD ASSEMBLY (B3)

To remove and replace the FDD assembly, refer to the following paragraphs as applicable:

- Para 3.2.1 if the FDD assembly is in a standalone unit
- Para 3.2.2 if the FDD assembly is in a combination unit

3.2.1 Removal-Replacement of FDD Assembly in a Standalone Unit

1. Access FDD (para 3.1.1).
2. Open rear door of Series/1 cabinet and disconnect FDD power cord from Series/1 ac distribution panel.
3. Disconnect the following cables from FDD assembly:
 - I/O (flat ribbon) cable from PC board
 - 7-pin B1P4 from PC board
 - 3-pin B1P1 from right side
4. Remove screw securing ground wire at top of assembly.
5. Remove two shock mount screws underneath mounting frame.
6. Remove two screws securing shock mount bracket to frame.
7. Remove assembly through front of frame.
8. Remove shock mount screw at top of assembly and remove bracket and attached shock mount for mounting on new assembly.


CAUTION

Do not use a "lead" pencil to set rocker switches. Graphite dust from pencil can cause an equipment malfunction.

9. Set the eight switches on PC board of new FDD assembly to the following positions using a ball-point pen:

- Switches 1 and 5 to ON position (ON side of switch pressed down)
- Other switches to OFF position (OFF side of switch pressed down)

10) To replace assembly, do steps 1 through 8 in reverse order and action.



03446-5


3.2.2 Removal-Replacement of FDD Assembly in a Combination Unit

1. Access FDD and remove FDD mounting frame from unit (para 3.1.2).
2. Disconnect the following cables from FDD assembly:
 - 7-pin B1P4 from PC board
 - 3-pin B1P1 from right side
3. Remove screw securing ground wire at top of assembly.
4. Remove two shock mount screws underneath mounting frame.
5. Remove shock mount screw at top of assembly and remove assembly through front of frame.

CAUTION

Do not use a "lead" pencil to set rocker switches. Graphite dust from pencil can cause an equipment malfunction.

6. Set the eight switches on PC board of new FDD assembly to the following positions using a ball-point pen:
 - Switches 1 and 5 to ON position (ON side of switch pressed down)
 - Other switches to OFF position (OFF side of switch pressed down)
7. To replace assembly, do steps 1 through 5 in reverse order and action.



03446-6


3.3 FDD POWER SUPPLY (B1)

To remove and replace the FDD power supply, refer to the following paragraphs as applicable:

- Para 3.3.1 if the power supply is in a standalone unit
- Para 3.3.2 if the power supply is in a combination unit

3.3.1 Removal-Replacement of FDD Power Supply in a Standalone Unit

1. Access FDD (para 3.1.1).
2. Open rear door of Series/1 cabinet and disconnect FDD power cord from Series/1 ac distribution panel.
3. Disconnect 7-pin B1P4 and 3-pin B1P1 connectors from FDD assembly.
4. Disconnect the following cables from power supply:
 - AC power cable from connector at front of base
 - LED power cable from J6 on power supply board. Pin 1 (white dot) of cable connector must mate with lower pin of J6 during reassembly.
 - Attachment power cable from J7 on power supply board. Connector orientation is unimportant during reassembly.
5. Remove four mounting nuts from base of power supply and lift supply from mounting frame.
6. Press circuit breaker on new power supply toward rear of supply (in On position).
7. To replace power supply, do steps 1 through 5 in reverse order and action.




03446-7

INTENTIONALLY BLANK

3.3.2 Removal-Replacement of FDD Power Supply in a Combination Unit

1. Access FDD and remove FDD mounting frame from unit (para 3.1.2).
2. Disconnect 7-pin B1P4 and 3-pin B1P1 connectors from FDD assembly.
3. Remove four mounting nuts from base of power supply and lift supply from mounting frame.
4. Press circuit breaker on new power supply toward rear of supply (in On position).
5. To replace power supply, do steps 1, 2, and 3 in reverse order and action.



03446-8


3.4 SPINDLE-DRIVE BELT

To remove and replace the spindle-drive belt on the FDD, refer to the following paragraphs as applicable:

- Para 3.4.1 if the FDD is in a standalone unit
- Para 3.4.2 if the FDD is in a combination unit

3.4.1 Removal-Replacement of Spindle-Drive Belt in a Standalone Unit


1. Access FDD (para 3.1.1).
2. Open rear door of Series/1 cabinet and disconnect FDD power cord from Series/1 ac distribution panel.
3. Disconnect I/O (flat ribbon) cable and 7-pin B1P4 connector from FDD PC board.
4. Remove two mounting screws from PC board.
5. Remove screw securing ground wire at top of FDD assembly.
6. Compress four retaining clips to release board from FDD assembly.
7. Disconnect three connectors from top of board.
8. Leave two connectors at bottom of board connected and tip board outward and remove drive belt.
9. Install new drive belt to the inside of motor pulley and center on spindle.
10. To reassemble FDD, do steps 1 through 7 in reverse order and action.



INTENTIONALLY BLANK

3.4.2 Removal-Replacement of Spindle-Drive Belt in a Combination Unit

1. Access FDD and remove FDD mounting frame from unit (para 3.1.2).
2. Disconnect 7-pin B1P4 connector from FDD PC board.
3. Remove two mounting screws from PC board.
4. Remove screw securing ground wire at top of FDD assembly.
5. Compress four retaining clips to release board from FDD assembly.
6. Disconnect three connectors from top of board.
7. Leave two connectors at bottom of board connected and tip board outward and remove drive belt.
8. Install new drive belt to the inside of motor pulley and center on spindle.
9. To reassemble FDD, do steps 1 through 6 in reverse order and action.




03613-2

3.5 ON/OFF-SWITCH BOX (B2)

The following paragraph contains removal and replacement instructions for the On/Off-switch box of a standalone unit. Similar instructions for the On/Off-switch box of a combination unit are contained in the MMD site information manual (refer to preface for publication number).

3.5.1 Removal-Replacement of On/Off-Switch Box in a Standalone Unit

1. Access FDD (para 3.1.1).
2. Open rear door of Series/1 cabinet and disconnect FDD power cord from Series/1 ac distribution panel.
3. Disconnect LED power cable from J6 on FDD power supply board. Pin 1 (white dot) of cable connector must mate with lower pin of J6 during reassembly.
4. Disconnect ac power cable from front of FDD power supply.
5. Remove two mounting screws from top of mounting frame to unfasten switch box.
6. Remove power cord and cables attached to switch box through front of frame.
7. Route power cord and cables of new switch box as shown in illustration.
8. To replace switch box, do steps 1 through 5 in reverse order and action.



03819

3.6 CDC BASIC DISKETTE DIAGNOSTICS

The following tables list the FDD auto-diagnostic and manual diagnostic tests that are on the CDC BASIC diskette (part number 663107XX). The auto-diagnostic tests are linked together and load and execute in succession until last test 4603 finishes or an error is detected. Manual diagnostic tests 4610 and 4611 are not linked together and each requires operator interaction.

To IPL the BASIC diskette and run these tests, refer to the following paragraphs as applicable:

- Para 3.6.1 if no other FDD is available except the unit to be tested
- Para 3.6.2 if another FDD is available

NOTE

Before diagnostics can be run, the system configurator table must be written on the BASIC diskette as described under Configuring BASIC Diskette in section 2.

FDD AUTO-DIAGNOSTIC TESTS

TEST NO.	TITLE AND PURPOSE*
4600	Channel interface - checks the interface between the attachment card and Series/1 and verifies that the attachment card and FDD are ready.
4601	Attachment - verifies that the attachment card responds properly to illegal device-control blocks (DCBs).
4602	Seek and read sector ID - checks if the FDD and attachment card can do seek and read sector ID operations.
4603	Seek and read data - expands on the testing done in test 4602 and checks if the FDD and attachment card can perform read data instructions.

FDD AUTO-DIAGNOSTIC TESTS (CONTD)

TEST NO.	TITLE AND PURPOSE*
4620	Cycle steal status analysis - automatically executes only if an improper condition is detected in one of the preceding auto-tests or in manual tests 4610 or 4611. When the test executes, it displays cycle steal status words on the screen of the assigned alternate console, analyzes the status, and indicates the result.
4621	Continuation of cycle steal status analysis - executes only when test 4620 is unable to fully analyze cycle steal status.

*Appendix A contains a more detailed test description.

FDD MANUAL DIAGNOSTIC TESTS

TEST NO.	TITLE AND PURPOSE*
4610	Write sector ID and data - checks if the FDD and attachment card can format sectors and write data.
4611	Write/read address markers - checks if the FDD and attachment card can write data-address markers and control-address markers and if the attachment card reacts correctly when the markers are read back. After completion, test 4610 must be run to delete the control-address markers from the diskette.
4620 and 4621	Cycle steal status analysis - these tests, which are also listed with the auto-tests, can be called up by entering B4620. However, this is only to be done when another test (auto or manual) stops and gives instructions to do so.

*Appendix A contains a more detailed test description.

3.6.1 IPL and Running FDD Diagnostics with No Other FDD Available Except Unit to be Tested

When no other FDD is available to load the diagnostics, IPL and run the diagnostic tests as follows:

1. Power-on FDD (para 3.0.6.1) and install CDC BASIC diskette, part number 663107XX (para 3.0.6.2).
2. Place Series/1 operator/programmer panel switches as follows:
 - IPL Source switch to Alternate or Primary as applicable to enable loading from diskette
 - Mode switch to Diagnostic
3. Press operator/programmer panel Load switch. This starts execution of IPL diagnostic. Assuming no problem occurs, IPL completes in approximately twenty two seconds with:
 - A message displayed on screen of alternate console (if a display station or TTY console is present and assigned)
 - On operator/programmer panel: a 38XX₁₆ halt code shown, Stop indicator extinguished, and Wait indicator lit

If the preceding indications do not occur, press Reset switch, then Load switch to try to IPL again. If second attempt is still unsuccessful, go to paper-only SAM 4670 (Power-On and IPL Problems) for corrective action.

NOTE

If a combination of both CDC and IBM devices having identical ID codes are configured on the same BASIC diskette (either a CDC or IBM diskette), the following configuration error will appear:

- On screen, CONFIG ERROR - TABLE DEVICE TYPE VS TABLE READ ID
- On operator/programmer panel, halt code 3842₁₆ (configuration error)

Ignore this error. It is the result of both the CDC and IBM devices having the same read ID code.

4. If the halt indications being displayed are not the following, go to common halt list (para 3.9) for meaning and appropriate action. When the following indications are obtained, proceed to step 5.

- RDY ENTER displayed on screen
- 3800₁₆ displayed on operator/programmer panel

5. Use assigned alternate console and enter B4600 as follows to load and run FDD auto-tests:

- If alternate console is a display station or a TTY, key in B4600 and press ENTER key if a display station, Carriage Return key if a TTY.

NOTE

(B) = Data Buffer switch
(I) = Console Interrupt switch

- If operator/programmer panel is alternate console, enter: (B), B, (I), (B), 4600, (I), (I).

Auto-tests now sequentially load and execute. Running time of tests is approximately two minutes. While tests are running, Run indicator lights and number of current test appears on screen and on operator/programmer panel. When tests stop, result is shown as follows:

- Successful completion indicated by:
 - PT ENTER display on screen
 - 3805₁₆ displayed on operator/programmer panel
- Error stoppage indicated by:
 - An error message displayed on screen that gives failing test and step numbers
 - Number of failing test displayed on operator/programmer panel

- Error abort indicated by:
 - An abort test message displayed on screen.
 - 46FE₁₆ displayed on operator/programmer panel

If tests did not load and execute or stopped without one of these indications, enter B4600 again. If problem persists, go to paper-only SAM 4672 (Not Ready Status) for corrective action.

6. If auto-tests ended with error stoppage or error abort, do as follows:
 - If error stoppage occurred, go to SAM that has same number as failing test and find failing step number in listing for corrective action. If using operator/programmer panel, obtain failing step number by pressing Stop switch, Level 3 switch, then R0 switch. This displays failing step number on panel indicators.
 - If error abort occurred, use error abort message to determine cause (para 3.10).

CAUTION

Manual tests 4611 and 4610 write on the CE (scratch) cylinders of the BASIC diskette. However, a malfunction may destroy program data on other cylinders. For a safeguard, do not run these manual tests unless an auto-test stops and instructs to do so or until auto-tests complete successfully.

7. Load and run FDD manual tests 4611 and 4610 by doing the following:
 - a. Enter B4611 at assigned alternate console to load test 4611:
 - If using a display station or a TTY, key in B4611 and press ENTER key if a display station, Carriage Return key if a TTY.
 - If using operator/programmer panel, enter:
(B),B,(I),(B),4611,(I),(I).

When loaded, test displays:

- A prompt on screen that asks if test should run and write on the CE cylinders of the diskette
- Test number 4611₁₆ on operator/programmer panel

If these indications do not appear, enter B4611 again. If second attempt is still unsuccessful, go to paper-only SAM 4672 (Not Ready Status) for corrective action.

- b. If BASIC diskette in FDD has the write-protect slot in its jacket uncovered, remove the diskette and cover slot with opaque tape. Then reinstall the diskette.
- c. Start test by answering yes to question being asked (if using operator/programmer panel, displayed test number represents question):
 - If using a display station or a TTY, key in 1 and press ENTER key if a display station, Carriage Return key if a TTY.
 - If using operator/programmer panel, enter: (B),1,(I),(I). Code FFFF₁₆ displays on panel indicators and Run indicator lights.

NOTE

When manual tests 4611 and 4610 detect certain errors, an automatic loading and running of test 4620 occurs to analyze cycle steal status. If required, this is followed by the automatic loading and running of test 4621. Therefore, error stoppage or error abort can occur in either of these linked tests or in the originally entered manual test.

When test stops, result is indicated the same as previously described under step 5 in the running of auto-tests. If test ended with error stoppage or error abort, take the action given in step 6. If test ended abnormally (with or without a message), rerun the test. If second attempt ends abnormally, go to paper-only SAM 4672 (Not Ready Status) for corrective action.

- d. Repeat steps a and c and enter B4610 to load and run test 4610.

3.6.2 IPL and Running FDD Diagnostics with Another FDD Available

When another FDD is available to load the diagnostics, IPL and run the diagnostic tests as follows:

1. Power-on both FDDs (para 3.0.6.1).
2. Install CDC BASIC diskette, part number 663107XX, in unit that is to do the loading and a two-sided scratch diskette in unit that is to be tested (para 3.0.6.2). If the scratch diskette is a CDC diskette, make sure that opaque tape is covering the write-protect slot in jacket before installing (writing enabled).
3. Place Series/1 operator/programmer panel switches as follows:
 - IPL Source switch to Alternate or Primary as applicable to enable loading from load unit
 - Mode switch to Diagnostic
4. Press operator/programmer panel Load switch. This starts execution of IPL diagnostic. Assuming no other halt occurs, IPL completes in approximately twenty two seconds with:
 - RDY ENTER displayed on screen of alternate console (if a display station or TTY console is present and assigned)
 - 3800₁₆ displayed on operator/programmer panel

NOTE

If a combination of both CDC and IBM devices having identical ID codes are configured on the same BASIC diskette (either a CDC or IBM diskette), the following configuration error will appear:

- On screen, CONFIG ERROR - TABLE
DEVICE TYPE VS TABLE READ ID
- On operator/programmer panel, halt
code 3842₁₆ (configuration error)

Ignore this error. It is the result of both the CDC and IBM devices having the same read ID code.

If any other halt indication appears, go to common halt list (para 3.9) for meaning and appropriate action. When the preceding indications are obtained, proceed to step 5.

NOTE

To run FDD diagnostic tests, the scratch diskette in test unit must be formatted. If contents of the scratch diskette are unknown or if its a new CDC diskette, it needs to be formatted before tests are run.

5. If scratch diskette in test unit requires formatting, do the following; if not, go to step 6.

NOTE

After the following substeps are performed, the scratch diskette will be formatted into 128-byte sectors on cylinder 00 and 256-byte sectors on all other cylinders and all data fields will be filled with zeros.

- a. Use assigned alternate console and enter B38F9 as follows to load general utility program:
 - If alternate console is a display station or a TTY, key in B38F9 and press ENTER key if a display station, Carriage Return key if a TTY. Program menu appears on screen.

NOTE

(B) = Data Buffer switch
(I) = Console Interrupt switch

- If operator/programmer panel is alternate console, enter: (B),B,(I),(B),38F9,(I),(I). Code 388B₁₆ appears on panel indicators.
- b. Enter F0A to load format routine:
 - If using a display station or TTY, key in F0A and press ENTER key if a display station, Carriage Return key if a TTY. A prompt asks if the diskette to be formatted is in IPL device.

- If using operator/programmer panel, enter:
(B),lF,(I),(B),0A00,(I),(I). Code 3879₁₆ appears.
- c. Replace BASIC diskette in load unit with scratch diskette from test unit.
- d. Start format routine by answering yes to question being asked (if using operator/programmer panel, code 3879₁₆ represents question):
- If using a display station or TTY, key in F1 and press ENTER key if a display station, Carriage Return key if a TTY.
 - If using operator/programmer panel, enter:
(B),F1,(I),(I).

When formatting is complete, program displays the following:

- On screen, SELECT ONE OPTION
 - On operator/programmer panel, code 388B₁₆
- e. To permit loading of read-verify routine that is to be run next, remove scratch diskette and return BASIC diskette to load unit.
- f. Enter F0C to load read-verify routine:
- If using a display station or TTY, key in F0C and press ENTER key if a display station, Carriage Return key if a TTY. A prompt appears that either requests a device address or asks if the diskette to be verified is in IPL device.
 - If using operator/programmer panel, enter:
(B),lF,(I),(B),0C00,(I),(I). Either code 388A₁₆ or 3879₁₆ appears.
- g. If prompt is requesting a device address (388A₁₆ displayed on operator/programmer panel), enter the hexadecimal, two-digit device address of the load unit:
- If using a display station or TTY, key in address and press ENTER key if a display station, Carriage Return key if a TTY.
 - If using operator/programmer panel, enter:
(B),lF,(I),(B),XX (device address) 00,(I),(I).
- h. Replace BASIC diskette in load unit with scratch diskette.

- i. Answer yes to prompt that asks if the diskette to be verified is in IPL device (3879₁₆ displayed on operator/programmer panel):
 - If using a display station or TTY, key in F1 and press ENTER key if a display station, Carriage Return key if a TTY. A prompt asks if it is desired to retry on each error.
 - If using operator/programmer panel, enter: (B),F1,(I),(I). Code 387B₁₆ appears.
- j. Reply no to retry on each error (387B₁₆ displayed on operator/programmer panel).
 - If using a display station or TTY, key in F0 and press ENTER key if a display station, Carriage Return key if a TTY.
 - If using operator/programmer panel, enter: (B),F0,(I),(I).

Entering the preceding reply starts the read-verify routine. If an error is detected, the assigned alternate console gives the following indication as applicable. Record all errors for reference when FDD diagnostic tests are run. Any error stoppage in a read/write at these locations during testing is to be ignored.

- On screen, the following type of error message is displayed and routine continues until completion:

```

CYL  HEAD  SECT  SECTOR  FORMAT
04    0    05      256

```

- On operator/programmer panel, code 3878₁₆ displays and routine stops. To read error message from memory (see preceding example for screen), do as follows:
 - Press Stop switch, Level 3 switch, then R3 switch. This displays starting memory address of error message.
 - Press SAR switch.
 - Enter: (B),1F,(I),(B),XXXX (hexadecimal memory address), (I),(I).

- Press Store switch then Main Storage switch. Contents of first memory address is displayed in EBCDIC.
- Continue pressing Main Storage switch until message is complete. Message is stored in memory in the same format (including spaces) as shown in the preceding example.
- When message is complete, continue routine by entering: (B),6,(I),(I).

When verifying is complete, program displays the following:

- On screen, SELECT ONE OPTION
 - On operator/programmer panel, code 388B₁₆
- k. Enter F09 to exit from general utility program:
- If using a display station or TTY, key in F09 and press ENTER key if a display station, Carriage Return key if a TTY. PT ENTER appears.
 - If using operator/programmer panel, enter: (B),1F,(I),(B),0900,(I),(I). Code 3805₁₆ appears.
- l. Return BASIC diskette to load unit and scratch diskette to test unit.
6. Use assigned alternate console and enter the following to run FDD auto-tests on test unit:
- a. Enter C4600 as follows:
- If using a display station or TTY, key in C4600 and press ENTER key if a display station, Carriage Return key if a TTY.

NOTE

(B) = Data Buffer switch
(I) = Console Interrupt switch

- If using operator/programmer panel, enter: (B),C,(I),(B),4600,(I),(I).

Program waits for option selection.

b. Enter option selection D4000:

- If using a display station or TTY, key in D4000 and press ENTER key if a display station, Carriage Return key if a TTY. A prompt requests device address.
- If using operator/programmer panel, enter:
(B),1D,(I),(B),4000,(I),(I). Code 3C01₁₆ appears.

c. Enter the hexadecimal, two-digit device address of the FDD to be tested:

- If using a display station or TTY, key in address and press ENTER key if a display station, Carriage Return key if a TTY.
- If using operator/programmer panel, enter:
(B),1F,(I),(B),XX (device address) 00,(I),(I).

d. Enter A to start auto-tests:

- If using a display station or TTY, key in A and press ENTER key if a display station, Carriage Return key if a TTY.
- If using operator/programmer panel, enter:
(B),A,(I),(I).

Auto-tests now sequentially load and execute. Running time of tests is approximately two minutes. While tests are running, Run indicator lights and number of current test appears on screen and on operator/programmer panel. When tests stop, result is shown as follows:

- Successful completion indicated by:
 - PT ENTER displayed on screen
 - 3805₁₆ displayed on operator/programmer panel
- Error stoppage indicated by:
 - An error message displayed on screen that gives failing test and step numbers
 - Number of failing test displayed on operator/programmer panel

- Error abort indicated by:
 - An abort test message displayed on screen
 - 46FE₁₆ displayed on operator/programmer panel

If tests did not stop with one of these indications, reseal attachment card of test unit and rerun auto-tests. If problem persists, replace attachment card and I/O cable of test unit one at a time until problem is corrected.*

7. If auto-tests ended with error stoppage or error abort, do as follows:

- If error stoppage occurred, go to SAM that has same number as failing test and find failing step number in listing for corrective action. If using operator/programmer panel, obtain failing step number by pressing Stop switch, Level 3 switch, then R0 switch. This displays failing step number on panel indicators.
- If error abort occurred, use error abort message to determine cause (para 3.10).

8. Enter the following to run FDD manual tests 4611 and 4610 on test unit:

a. Enter C4611 at assigned alternate console as follows:

- If using a display station or TTY, key in C4611 and press ENTER key if a display station, Carriage Return key if a TTY.
- If using operator/programmer panel, enter:
(B),C,(I),(B),4611,(I),(I).

Program waits for option selection.

b. Enter option selection D4000:

- If using a display station or TTY, key in D4000 and press ENTER key if a display station, Carriage Return key if a TTY. A prompt requests device address.
- If using operator/programmer panel, enter:
(B),1D,(I),(B),4000,(I),(I). Code 3C01₁₆ appears.

*Set switches on new attachment card for device address and IPL assignment (Installing Attachment Card and Cabling, section 2).

c. Enter the hexadecimal, two-digit device address of the FDD to be tested:

- If using a display station or TTY, key in address and press ENTER key if a display station, Carriage Return key if a TTY.
- If using operator/programmer panel, enter: (B),lF,(I),(B),XX (device address) 00,(I),(I).

d. Enter A:

- If using a display station or TTY, key in A and press ENTER key if a display station, Carriage Return key if a TTY. A prompt asks if test should run and write on the CE cylinders of the diskette.
- If using operator/programmer panel, enter: (B),A,(I),(I). Test number 4611₁₆ appears.

e. Start test 4611 by answering yes to question being asked (if using operator/programmer panel, displayed test number represents question):

- If using a display station or TTY, key in 1 and press ENTER key if a display station, Carriage Return key if a TTY.
- If using operator/programmer panel, enter: (B),1,(I),(I). Code FFFF₁₆ appears and Run indicator lights.

NOTE

When manual tests 4611 and 4610 detect certain errors, an automatic running of test 4620 occurs to analyze cycle steal status. If required, this is followed by the automatic running of test 4621. Therefore, error stoppage or error abort can occur in either of these linked tests or in the originally entered manual test.

When test stops, result is indicated the same as previously described under step 6 in the running of auto-tests. If test ended with error stoppage or error abort, take the action given in step 7.

f. Repeat steps a through e and enter C4610 in step a to run test 4610.

3.7 CONFIGURATOR TABLE INFORMATION

NOTE

- (B) = Data Buffer switch
 (I) = Console Interrupt switch

3.7.1 Changing Configurator Table Manually Using Operator/Programmer Panel

This procedure assumes that the operator/programmer panel has already been assigned as alternate console on the BASIC diskette (Configuring BASIC Diskette, section 2). To change the table manually using operator/programmer panel, do as follows:

1. Press Load switch to load configurator program.
2. View and record contents of configurator table per the following:
 - Press Stop switch.
 - Press SAR (Storage Address Register) switch.
 - Enter 3000 via input switches.
 - Press Store switch.
 - Press Main Storage switch to display first word of entry 00 in configurator table. Record contents.
 - Continue pressing Main Storage switch to view and record each word of entry.

NOTE

Each configurator table entry consists of eight words. Refer to para 3.7.3 for entry format. Entry 00 is the system entry and entries 01 through XX are the device entries. The last entry in the table will contain a 1 in the bit 2 position of byte 02/03 as follows:

02	03
0010 0000	0000 0000

- Continue logging information from configurator table until complete.
3. Press Load switch. Either a 382A (secure customer interface), a 3822 (configuration errors on system), or a 382E (option table available for entry) halt will occur.
 - If a 382A halt code, enter:
(B),6,(I),(I) to advance to halt 3822 or 382E.
 - If a 3822 halt code, enter:
(B),1F,(I),(B),0300,(I),(I) to advance to halt 382E.
 - If a 382E halt code, go to step 4.
 4. Enter one of the following options as applicable:
 - (B),1F,(I),(B),0200,(I),(I) to delete entire entry from configurator table.
 - (B),1F,(I),(B),0300,(I),(I) to change any portion of an entry in configurator table.
 - (B),1F,(I),(B),0A00,(I),(I) to add a new entry in configurator table.
 5. If a 383A halt code occurs (signifying that an 02 or 03 option was selected), enter table number as follows:
(B),1F,(I),(B),XX00,(I),(I) where XX = entry number.
 6. If a 383B or 3846 halt code occurs (signifying that an 03 or 0A option was selected), enter new configurator table data for table entries 01 through XX as follows:
(B),8F,(I),(B),AATT,(I),(B),0000,(I),(B),IDID,(I),(B),0000,(I),(B),0000,(I),(B),0000,(I),(B),0000,(I),(B),IDID,(I),(I)
where: AA = device address
TT = device type
IDID = device read ID
 7. Repeat steps 4 through 6 until all additions, deletions, and corrections are complete.
 8. Write new configurator table on diskette when complete (halt code 382E), enter:
(B),1F,(I),(B),0D00,(I),(I).
 9. Next halt code will be a 382C (copy table to another diskette?) Terminate program by entering:
(B),1F,(I),(B),0500,(I),(I).
 10. Successful termination of configurator program is indicated by a 3800 (ready) halt code. Diskette is then ready for running diagnostic tests.

3.7.2 Configure System (Option 0C) Using Operator/Programmer Panel

This procedure assumes that the operator/programmer panel has already been assigned as alternate console on the BASIC diskette (Configuring BASIC diskette, section 2). To configure the system automatically using operator/programmer panel, do as follows:

1. Enter (B),B,(I),(B),38F0,(I),(I) to load configurator program. When loaded, a 38XX halt code displays. If a 382A halt code occurs, enter: (B),6,(I),(I).
2. If a 3822 halt code occurs, enter:
(B),1F,(I),(B),0300,(I),(I).
A 382E halt will then occur to allow option selection.
3. Enter (B),1F,(I),(B),0C00,(I),(I) to select configure system option 0C. Refer to para 3.9 for specific instructions pertaining to halt codes being displayed.
4. Continue entering appropriate parameters until a 3800 or 3805 halt code displays. This indicates that diskette configuration is complete and diagnostic tests can be run.

NOTE

Some IBM and CDC devices have the same read ID codes. These IBM devices are all assigned CDC device types in the configurator table and must be manually changed to the correct device ID before executing diagnostic tests. Also, if a CDC 80270 or 80271 storage module drive having a read ID of 3007 is present in the configurator table, the device type must be changed from 72 to 70. Refer to table under Check-out in section 2 for a listing of device types that have the same read IDs. To make changes, follow instructions in para 3.7.1.

3.7.3 Configurator Table Entries

The configurator table contains a system entry (entry 00), and one entry for each device address used (entries 01-XX). The formats of the system entry and the device entries are defined in the next two paragraphs (3.7.3.1 and 3.7.3.2). Para 3.7.3.3 contains a blank table for assembling the entries required for your system.

3.7.3.1 Definition of Entry 00 (System Entry)

Only bytes 05 through 09 of entry 00 are to be changed. All other information is entered by the configurator program.

<u>Byte</u>	<u>Definition</u>
00 and 01	Constant 00
02	Entry number of last entry in table
03	Configurator flags Bit 00 through 06 are reserved Bit 07 a 1 = diskette has been configured Bit 07 a 0 = diskette has not been configured
04	Not used
05	Processor type ① 22 = 4952 23 = 4953 35 = 4955
06 and 07	Storage word X Y Y Y ABBBBBBBBBBB A binary number indicating the number of 16K units of outer storage installed A = 0 No address translator A = 1 Address translator installed { 3 = 16K of inner storage installed { 7 = 32K of inner storage installed { B = 48K of inner storage installed { F = 64K of inner storage installed

NOTES

1. Storage word = F803 indicates 112K of total storage installed.
2. If BBBBBBBBBBBB is greater than 0, then A must equal 1 and address translator feature must be installed.
3. Inner storage can be addressed only by the storage address register.
4. Outer storage can be addressed only by the address translator feature.

① Several device MAPs measure time. Instruction execution time is indicated to the MAPs by processor type. The wrong processor-type code will cause MAP failures.

5. Storage word = 7802 indicates one 32K card or two 16K cards installed as inner storage, one 32K card or two 16K cards installed as outer storage, and the address translator installed.

08 and 09 Alternate console address and type (AATT)
 0A through 0E Not used
 0F Release level of this configuration record

3.7.3.2 Definition of Entries 01-XX (Device Entries)

<u>Byte</u>	<u>Definition</u>
00	Device address
01	Device type
02	Flag byte Bit 0 is used by DCP and is always 0. Bit 1 = 1 indicates entry is chained to next entry. Bit 2 = 1 indicates last entry in configurator table. Bit 3 = 1 indicates last entry in sector. Bits 4 through 6 are reserved. Bit 7 = 1 indicates last available entry in configurator table.

NOTES

1. Ignore bits 2, 3, and 7 when making adds or changes. The configurator program will set/reset them at sort time.
2. Chain bit (byte 02 bit 1) is used to pass two or more entries to a MAP program or diagnostic. Wrong use of the chain bit can cause MAP failures. For example: a missing chain bit causes needed information not to be available to the MAP. Extra chain bits can cause MAPs to be bypassed during an auto run.

03 through 09 Device-dependent data. Describes the device to its associated MAPs/diagnostics. If it is wrong, failures will occur. The auto-verify performed when the configurator loads does not check device-dependent data.

0A through 0D Reserved

0E through 0F Device ID word

The device entries for alternate console devices are:

```
TTY Console
DA 40 00 00 00 10 00 00 00 00 00 00 00 00 00 10

4979 Display Station*
DA 42 00 00 04 06 00 00 00 00 00 00 00 00 04 06

4978 Display Station
DA 45 00 00 04 0E 00 00 00 00 00 00 00 00 04 0E

4974 Matrix Printer**
DA 62 00 00 02 06 00 00 00 00 00 00 00 00 02 06

80610 Display Station*
DA 42 00 00 04 06 00 00 00 00 00 00 00 00 04 06

80420 Matrix Printer**
DA 62 00 00 02 06 00 00 00 00 00 00 00 00 02 06

80450 Band Printer
DA 66 00 00 03 06 00 00 00 00 00 00 00 00 03 06
```

The device entries for load devices are:

```
4964 Diskette
DA 48 00 00 01 06 00 00 00 00 00 00 00 00 01 06

80210 Flexible Disk drive***
DA 46 00 00 01 06 00 00 00 00 00 00 00 00 01 06
```

NOTE

The configurators on IBM diskettes do not recognize CDC devices. Therefore, do not try to use an IBM configurator to construct the configuration table on a CDC BASIC diskette. All CDC devices will be configured wrong.

-
- *Device type 44 must be used when configuring an IBM diskette.
 - **Device type 64 must be used when configuring an IBM diskette.
 - ***Format also applies to 80240 series MMDs (contains an FDD packaged in the MMD enclosure).

3.8 ENTERING COMMANDS

The commands are described here as they are entered from the operator/programmer panel. These same commands can be entered from an alternate console by keying in the command character followed by data, where applicable, and pressing the ENTER key (Carriage Return key on TTY). No commas are required.

3.8.1 Single Character Commands (No Data)

Enter as follows, where: (B) = Data Buffer switch, (I) = Console Interrupt switch.

NOTE

Commands must be entered in bits 12 through 15 of the data buffer.

<u>Command</u>	<u>Key Sequence</u>	<u>Result</u>
5	(B),5,(I),(I)	Disable alternate console and assign operator/programmer panel.
6	(B),6,(I),(I)	Continue program execution.
9	(B),9,(I),(I)	Terminate program.
A	(B),A,(I),(I)	Start execution.
0*	(B),0,(I),(I)	Answer question no.
1*	(B),1,(I),(I)	Answer question yes.

*Commands 0 and 1 apply to test program responses only. Use the F command to answer yes or no to a question in a utility program, for example: F1 = yes, F0 = no.


3.8.2 Commands that use a Program Number (Commands B and C)

These commands load a program. The program number (XXXX) must be entered with one of the following commands:


<u>Command</u>	<u>Key Sequence</u>	<u>Result</u>
B	(B) , B, (I) , (B) , XXXX, (I) , (I)	Program XXXX loads and goes.
C	(B) , C, (I) , (B) , XXXX, (I) , (I)	Program XXXX loads and waits for option selection command D.

3.8.3 Command to set Option Bits On (Command D)

Enter: (B) , 1D, (I) , (B) , XXXX, (I) , (I)



Option bits are as follows:



This command must be followed by the A command to start the execution of the program.

3.8.4 Command to Enter Variable Data (Reply to a Program,
Command F)

Enter: (B),XF,(I),(B),XXXX,(I),(B),XXXX,(I),(I)

Second consecutive
interrupt termi-
nates the entry.

Enter up to 15 words
of data.

First word of entry - if less than
four characters, they must be
followed with zero(s).

Number of 16-bit words in this entry (must be a value
between 1 and F). Used only when F command is entered
from operator/programmer panel.

3.9 COMMON HALT LIST

Halts are identified by the Wait indicator on the operator/programmer panel being lit.

3.9.1 Diagnostic Control Program (DCP) Halts

- 3800 Ready - enter any valid command.
- 3801 Bad condition code received from alternate console.
Enter continue command: (B),6,(I),(I).
- 3802 Program check - see MAP 3871.
- 3803 Machine check - see MAP 3871.
- 3804 Power thermal warning.
- 3805 Program terminated - enter any valid command.
- 3806 Invalid request - enter any valid command.
- 3807 Alternate console is off during testing.
- 3808 Alternate console is on and test is complete.
- 3809 Unexpected interrupt - R0 level 3 contains the interrupt status byte. Location 180A contains the MAP number.
- 380A Start - the program has started.
- 380B Diskette error - IPL and try again. If it still fails, try a different diskette.
- 380C Program not found - there is no VTOC entry for the requested program.
- 3810 Was not expecting reply (F command) data.
- 3813 Received a command sequence - to execute, press the Console Interrupt switch. To delete the command, change the buffer contents and press the Console Interrupt switch. Halt 3814 displays and the command can be entered again.
- 3814 Enter data.
- 3815 Cannot continue execution - IPL and try again. If it still fails call for assistance.

- 3816 Change keyboard definition for 4978 display. Press any key within 15 seconds and halt 3817 displays.
- 3817 Press the key requested for keyboard definition.
- FFFF Command or reply has been accepted.

3.9.2 Configurator Halts

- 3820 This diskette has not been configured before. Enter continue command: (B),6,(I),(I).
- 3821 Enter alternate console device address and device type.
Example:
(B),1F,(I),(B),0040,(I),(I) to assign TTY as alternate console, or (B),1F,(I),(B),0000,(I),(I) to assign programmer panel as alternate console.
- 3822 Configuration error(s) on system. Reply with one of the following:
01 = Terminate
02 = Print all errors
03 = Print options
04 = Bypass TCS errors
(B),1F,(I),(B),XX00,(I),(I) where XX = chosen option.
- 3823 Invalid entry. Enter the correct entry.
- 3826 Changes not saved. Enter 0D to save the configuration table: (B),1F,(I),0D00,(I),(I) or enter 05 to terminate (changes made are lost): (B),1F,(I),0500,(I),(I).
- 3827 Enter correct processor type.
22 = 4952 processor
23 = 4953 processor
25 = 4955 processor
(B),1F,(I),(B),XX00,(I),(I) where XX = processor type.
- 3829 Device address or type incorrectly entered. Enter correct parameter.
- 382A Secure the customer interface. Enter continue command when customer interface is secure: (B),6,(I),(I).
- 382B Is an OEMI card installed? Reply 00 = no, 01 = yes:
(B),1F,(I),(B),0000 or 0100,(I),(I).
- 382C Copy configuration table to another diskette? Reply 0D to copy table or 05 to terminate:
(B),1F,(I),(B),0D00 or 0500,(I),(I).
- 382D Is floating point feature installed? Reply 00 = no, 01 = yes: (B),1F,(I),(B),0000 or 0100,(I),(I).

- 382E Option table is available for entry. Enter option table information per the following:
01 = Print table
02 = Delete
03 = Modify
04 = Alternate console*
05 = Terminate
06 = Processor type
07 = Two channel switch
08 = Storage size
09 = Print system equipment
0A = Add
0B = Bypass option table
0C = Configure system*
0D = Diskette write*
0E = OEMI
0F = Floating point
10 = Merge
(B),1F,(I),(B),XX00,(I),(I) where XX = chosen option.
- 382F Initial auto configuration. The diskette has an alternate console assigned. The initial auto configuration must be completed. Enter 6 to continue:
(B),6,(I),(I).
- 3831 Enter station address ID = XY. X = cable address (0 to 3), Y = station address (0 to 3).
- 3832 Programmer or CE console is assigned alternate console. Enter 6 to continue: (B),6,(I),(I).
- 3833 OIO (operator I/O) condition code. R3 = condition code and R4 = AATT where: AA = device address and TT = device type.
- 3834 Error - more than one two-channel switch disappeared after a select switch was changed. If there is no alternate console, enter 6 to continue:
(B),6,(I),(I).
- 3835 Interrupt condition code. R3 = interrupt condition code and R4 = AATT where: AA = device address and TT = device type.
- 3836 Is customer using common I/O? Reply 00 = no, 01 = yes:
(B),1F,(I),(B),0000 or 0100,(I),(I).

*A new alternate console definition or system configuration must be followed by a diskette write to save the new information on the diskette.

- 3837 Error -- a two-channel switch did not disappear after a select switch was changed. If there is no alternate console, enter 6 to continue: (B),6,(I),(I).
- 3838 RPQ diagnostics are installed on system.
- 383A Select entry number in configurator table to be altered. Enter (B),1F,(I),(B),XX00,(I),(I) where: XX = table entry number.
- 383B Enter the desired entry. Format is: (B),8F,(I),(B),AATT,(I),(B),0000,(I),(B),IDID,(I),(B),0000(I),(B),0000,(I),(B),0000,(I),(B),0000,(I),(B),IDID,(I),(I) where: AA = device address, TT = device type, IDID = device read ID code.
- 383C Error - cannot find reflected two-channel switch. If there is no alternate console, enter 6 to continue: (B),6,(I),(I).
- 383D Install the from diskette. Used with the merge function (10) and the print configuration function (20). Install the from diskette and answer 01 when complete: (B),1F,(I),(B),0100,(I),(I).
- 383E Install the BASIC diskette. Used with the merge function (10) and the print configuration function (20). Replace the from diskette with the BASIC diskette and answer 01 when complete: (B),1F,(I),(B),0100,(I),(I).
- 3840 Error - a device is in the hardware, but not in the configuration table. Level 3, R3 contains the address (AA00). Level 3, R4 contains the ID word. Record the contents of R3 and R4, then enter continue command: (B),6,(I),(I).
- 3841 Error - a device is in the table, but not in the hardware. Level 3, R3 contains the device address and configuration table entry number (AAEE). Record the contents of R3 and enter continue command: (B),6,(I),(I).
- 3842 Error - the ID word received does not match the ID word stored in the configurator table for this address. Level 3, R3 contains the device address and configuration table entry number (AAEE). Level 3, R4 contains the ID word received. Record the contents of R3 and R4 and enter continue command: (B),6,(I),(I).

- 3843 Error - an entry in the configurator table has a device type and device ID that do not match.
Level 3, R3 contains the device address and configuration table entry number (AAEE).
Record the contents of R3 and enter continue command:
(B),6,(I),(I).
- 3844 Error - received a bad condition code in response to a read ID command.
Level 3, R3 contains the device address and condition code (AACC).
Record the contents of R3 and enter continue command:
(B),6,(I),(I).
- 3845 Error - two-channel switch was in the wrong position.
If there is no alternate console, enter 6 to continue:
(B),6,(I),(I).
- 3846 Enter new configurator table data:
(B),8F,(I),(B),0001,(I),(B),0203,(I),(B),0405,(I),(B),0607,(I),(B),0809,(I),(B),0A0B,(I),(B),0C0D,(I),(B),0E0F,(I),(I).
- 3848 Error - entries do not agree. R1 = entry address of from table and R2 = entry address of to table.
- 3849 Alternate console error. The response from the alternate console to a read ID command does not match that of a supported console device.
Level 3, R3 contains the device address and type read from the configurator table (AATT).
R4 contains the response from the read ID command.
Record the contents of R3 and R4 and enter continue command: (B),6,(I),(I).
Halt 382E displays.
If R3 has the correct device address and type for the alternate console, the console is returning a bad ID.
Enter: (B),1F,(I),(B),0500,(I),(I), the configurator then terminates at halt 3800.
Enter the assign programmer console command:
(B),0005,(I),(I), this disables the alternate console.
If R3 does not contain the correct information, change the alternate console bytes at address 3008 and 3009 to the address and type for the console device.
To write the record to the diskette, enter:
(B),1F,(I),(B),0100,(I),(I).
- 384A Configuration table is full.
- 384B Configurator chain (byte 02 bit 1) is too long. See MAP 3880.
- 384C Configuration display message. See alternate console display for message.

- 384D The VTOC does not contain a configurator table (U38F1). Load the general utility program (38F9) and copy 38F1 from another diskette.
- 384F Duplicate address AA, entry EE and EE. There is a duplicate address in the configuration table. If there is no alternate console assigned, Level 3 R2 has the device address, R3 and R4 have the table entry numbers. Enter 6 to continue: (B),6,(I),(I).
- 3850 Enter inner storage size:
03 = 16K
07 = 32K
0B = 48K
0F = 64K
(B),1F,(I),(B),XX00,(I),(I) where XX = 03,07,0B, or 0F.
- 3851 Is address translator installed? Reply 01 = yes,
00 = no: (B),1F,(I),(B),0000 or 0100,(I),(I).
- 3852 Enter outer storage size. OXXX = decimal number of 16K
outer storage blocks:
(B),1F,(I),(B),OXXX,(I),(I).
- 3853 ACCA SL installed (asynchronous control communication
adapter, single line). See MAP 13.
- 3854 AACA ML installed (asynchronous control communication
adapter, multiline) See MAP 13
- 3855 BSCA SL installed (bisync communication adapter, single
line). See MAP 13.
- 3856 BSCA ML installed (bisync communication adapter,
multiline). See MAP 13.
- 3857 SDLC installed (synchronous data-link control).
See MAP 13.
- 3858 Error - the specify code entered is not correct.
- 3859 Error - the specify code entered is correct but does
not match the card.
- 385A Remote IPL? Reply 00 = no, 01 = yes:
(B),1F,(I),(B),0000 or 0100,(I),(I).
- 385B Error - a multiline controller has an address domain.
See MAP 13.
- 385C Error - no interrupt. See MAP 13.
- 385D Two-channel switch console message. Change the select
switch to the processor you are using. See MAP 13.

- 385E Two-channel switch console message. There is more than one two-channel switch console installed. See MAP 13.
- 385F Two-channel switch console message. There is at least one two-channel switch console installed. See MAP 13.
- 3860 Programmable communications subsystem error message. See MAP 13.
- 3861 Programmable communications subsystem error message. See MAP 13.
- 3862 Programmable communications subsystem entry. See MAP 13.
- 3863 Is alternate console being used installed as common I/O? Reply 00 = no, 01 = yes:
(B),1F,(I),(B),0000 or 0100,(I),(I).
- 3864 Is a programmer or CE console installed on the processor being used? Reply 00 = no, 01 = yes:
(B),1F,(I),(B),0000 or 0100,(I),(I).
- 3865 Is alternate console being used installed in farthest common I/O? Reply 00 = no, 01 = yes:
(B),1F,(I),(B),0000 or 0100,(I),(I).
- 3866 The alternate console disappeared after the two-channel switch was changed. See MAP 13.
- 3867 The alternate console did not appear after the two-channel switch was changed. See MAP 13.
- 3868 The alternate console did not disappear after the two-channel switch was changed. See MAP 13.
- 3869 Obtain a programmer or CE console. The configuration program needs a programmer or CE console to continue. The configuration program has been terminated.
- 386A ML COMM installed (multiline communication). See MAP 13.

3.9.3 MAP Diagnostic Integration (MDI) Halts

3C01 Enter address of device to be tested.

- From operator/programmer panel:
(B),1F,(I),(B),XX00,(I),(I).
- From alternate console: FXX.

3C05 Enter starting step number for loop

- From operator/programmer panel:
(B),1F,(I),(B),XXXX,(I),(I).
- From alternate console: FXXXX.

3C06 Enter ending step number for loop - same procedure as halt 3C05.

3C08 Device at address entered in halt 3C01 is not the type address tested by the requested program.
Enter the correct address.

3C0E No device of that type was found in the configurator table, or the MAP executed and attempted to load a MAP not in VTOC.

3.10 ERROR ABORT MESSAGE

When a diagnostic is aborted, an error abort message is generated. If a display station or TTY is assigned as the alternate console, the abort message is displayed as shown in the following format:

```

      ABORT TEST
TEST  EXIT  DEV   CC     ISB   STEP
4602  309E  0002  0703  0024  0001   4040   4040
DCB0  DCB1  DCB2  DCB3  DCB4  DCB5   DCB6   DCB7
0000  0000  0000  0000  0000  0000   0000   3694
CSS0  CSS1  CSS2  CSS3  CSS4  CSS5   CSS6   CSS7
36E3  0000  0000  0000  0000  0000   4040   4040
CSS8  CSS9  CSSA  CSSB  CSSC  CSSD   CSSE   CSSF
4040  4040  4040  4040  4040  4040   4040   4040
I3C00  MAP=4602  STEP=0001

```

Where:

- TEST = Number of the test executing at time of abort.
To determine the operation that was in process, go to the SAM for that test and find the step that was being executed.
- EXIT = Exit address (last address entered in R6 by a branch and link instruction).
- DEV = Device address.
- CC = Condition code.
- ISB = Interrupt status byte returned, if any.
- STEP = Step number being executed at time of abort.
- DCB0 - DCB7 = Device control block bytes.
- CSS0 - CSSF = Cycle steal status words if available.
See Description of Cycle Steal Status Words, appendix A, for significance (with the FDD, only words 0 through 5 are valid).

NOTE

If abort message is meaningless, do the following as applicable:

- If diagnostics are being loaded from the FDD being tested, retry test that was executing. If problem persists, go to paper-only SAM 4672 (Not Ready Status).
- If another FDD is doing loading, reseal attachment card of test unit before retrying test. If problem persists, replace attachment card and I/O cable of test unit one at a time. Replacing attachment card requires that switches on new card be set for device address and IPL assignment (Installing Attachment Card and Cabling, section 2).

If operator/programmer panel is the assigned alternate console, an error abort is indicated by 46FE₁₆ being displayed on indicators. The error abort message can be read from memory as follows:

NOTE

Level 3 registers R0 through R3 contain the following information:

R0 = Step number
R1 = Test number
R2 = Device address
R3 = Starting address of abort message

1. Press Stop switch. Stop indicator lights.
2. Press Level 3 switch.
3. Press R3 switch. This displays the starting memory address of the error abort message.

NOTE

The first word at this address contains the test number. The remaining words shown in the example message follow in sequence.

4. Press SAR switch.
5. Enter memory address via input switches.
6. Press Store switch.
7. Press Main Storage switch. Contents of first memory address displays on indicators.
8. Continue pressing Main Storage switch to view each word in sequence.

This section contains the spare parts lists for the FDD and its attachment card. The spare parts lists (SPLs) for the FDD and attachment card are correlated as follows:

- SPL 66308079 applies to the BR808-A (standalone, 208-V ac input) FDD
- SPL 66308617 applies to the BR808-B (standalone, 120-V ac input) FDD
- SPL 66304591 applies to the BR812-A (combination, 208-V ac input) FDD
- SPL 66304592 applies to the BR812-B (combination, 120-V ac input) FDD
- SPL 66308078 applies to the FA741-A (Flex Disk) attachment cards.

DWN	R. Trautman	2-79	 CONTROL DATA CORPORATION	TITLE	SPARE PARTS LIST FDD		PREFIX	DOCUMENT NO.	REV.
CHKD	R. Trautman	10-11-79		FIRST USED ON	SPL	66308079	A		
ENG	J. K. ...	10-11-79		BRADAA	SHEET		1 of 2		
MFG	J. K. ...	10-16-79		CODE IDENT					
APPR	S. H. ...	10-22-79		15920					

SHEET REVISION STATUS				REVISION RECORD					
				REV	ECO	DESCRIPTION	DRFT	DATE	APP
			2 1	A	13471-45	RELEASED CLASS 'A'	/	10/26/79	Mch
			A A	A	10117-76	TRANSFER TO PSG	/	12/1/79	TRD

PSG Division
controls this document
as of 12-1-79
AA4291

NOTES:
EQUIPMENT CONFIGURATOR -----15631529
TOP LEVEL ASSEMBLY -----15631579

DETACHED LISTS

AA3180 REV. 8-71

PRINTED IN U.S.A.

CONTROL DATA		CODE IDENT	SHEET	DOCUMENT NO.	REV.
		15920	2 of 2	66308079	A

FIND NO.	PART IDENTIFICATION	QUANTITY REQUIRED				UNIT OF MEAS	NOMENCLATURE OR DESCRIPTION	SPECIFICATIONS, NOTES, OR MATERIAL
1	77618000	1					FDD Assy	
2	61408154	1					Power Supply Assy	
3	61408480	1					Switch Assy	
4	75293203	1					Belt - Flat	

AA3181 REV. 8-71

PRINTED IN U.S.A.

DWN	R Trautman	4-79	CONTROL DATA	TITLE	PREFIX	DOCUMENT NO.	REV.
CHKD	<i>R Trautman</i>	4-25-79	IDENTIFICATION	SPARE PARTS LIST FDD 120V	SPL	66308617	A
ENG	<i>C. H. H. H.</i>	4-25-79		FIRST USED ON			
HFC	<i>W. H. H.</i>	10-11-79		BR808B		SHEET	1 of 2
APPR	<i>W. H. H.</i>	1-22-77	CODE IDENT				
	<i>W. H. H.</i>	4-23-79	15920				

SHEET REVISION STATUS				REVISION RECORD						
REV	ECO	DESCRIPTION	DRFT	DATE	APP					
A	A	13471-45	Released Class	A	1/26/79	Meh				
A	A	10117-86	TRANSFER TO	PLVOPS	1/11/79	PLVOPS				

NOTES: Equipment Configurator....15631530
Top Level Assembly.....15631580

PSG Division controls this document as of 12-17-79
AA4291

DETACHED LISTS

AA3180 REV. 8/71

PRINTED IN U.S.A.

CONTROL DATA			CODE IDENT	SHEET	SPL	DOCUMENT NO.	REV.
			15920	2		66308617	A
FIND NO.	PART IDENTIFICATION	QUANTITY REQUIRED	UNIT OF MEAS	NOMENCLATURE OR DESCRIPTION		SPECIFICATIONS, NOTES, OR MATERIAL	
1	77618000	1		FDD Assy			
2	61408155	1		Power Supply Assy			
3	61408479	1		Switch Assy			
4	75293203	1		Belt Flat			

AA3181 REV. 8/71

PRINTED IN U.S.A.

This appendix contains:

- Explanation of SAM format - Describes the format and use of the SAM (structured analysis method) listings.
- Description of diagnostic tests - Briefly describes each of the FDD diagnostic programs on the CDC BASIC diskette.
- Description of cycle steal status words - Describes significance of the FDD cycle steal status words.
- SAMS covering the FDD diagnostic tests and paper-only troubleshooting. The SAMS are categorically numbered as follows:
 - SAMS 4600 through 4621 correspond to the FDD diagnostic tests on the CDC BASIC diskette. Each SAM and corresponding diagnostic program have the same number.
 - SAMS 4670 through 4673 are paper-only listings that supplement the diagnostic program SAMS.

EXPLANATION OF SAM FORMAT

A SAM is a formatted listing that documents the flow of a diagnostic program and presents troubleshooting information in a logical manner. Each SAM contains a sequential listing of questions that can be answered yes or no. The response made to a particular question either leads to the next question or to the specific action (or numerical sequence of actions) that is to be taken to correct the problem.

Two types of SAMS are contained in this appendix. One type documents diagnostic programs, and the other gives troubleshooting information on problems diagnostic programs cannot isolate (paper-only SAMS). Both are structured in the same basic format. Each SAM is identified by a title and four-digit number at the bottom of the page. If a SAM contains more than one page, a hyphen and number follows the four-digit number to identify the pages within the SAM.

PAPER-ONLY SAM

Before entering a paper-only SAM (figure A-2), verify that the assumed conditions given at the top of the page are present and observe any preliminary instructions. Enter listing and answer yes (Y) or no (N) to the question asked or condition being tested. Follow down appropriate Y or N column. Column either leads to another question, or to action numbers. If column leads to action numbers, perform corresponding actions in numerical order to correct the problem.




Figure A-2. Paper-Only SAM Example

DESCRIPTION OF DIAGNOSTIC TESTS

The following paragraphs describe the FDD auto-diagnostic tests and FDD manual diagnostic tests that are on the CDC BASIC diskette (part number 663107XX).

FDD AUTO-DIAGNOSTIC TESTS

The following FDD auto-diagnostic tests 4600 through 4603 are linked together. Execution starts with the test that is called up. Each following test then executes in succession until last test 4603 finishes or an error occurs.

4600 Channel Interface Test

Test 4600 checks the operation of the attachment card under direct program control (DPC) using all legal DCP commands and various illegal command codes. Condition codes returned are checked for command acceptance or rejection as applicable. The test then issues a start diagnostic 1 command and verifies that:

- The read-only memory (ROM) on attachment card outputs the correct checksum.
- The diskette in the FDD is rotating at the correct speed.
- The attachment card and FDD are ready.

If an incorrect speed or not-ready condition exists, the test reads cycle steal status and an automatic branch to routine 4620 occurs to define the problem.

This test automatically branches to test 4601.

4601 Attachment Test

Test 4601 checks if the attachment card responds properly to illegal device-control blocks (DCBs). After verifying that no preset error condition exists, the test issues various invalid DCBs in cycle steal mode. For each DCB issued, the test checks that the attachment card:

- Returns an interrupt condition code of unit exception.
- Sets bit 3 of the interrupt status byte for DCB specification check.
- Indicates the proper error condition in the error-log byte (second byte) of cycle steal status word 4.

If a preset error condition is present at the beginning of the test, an automatic branch to routine 4620 occurs to define the problem.

This test automatically branches to test 4602.

4602 Seek and Read Sector ID Test

Test 4602 checks if the FDD and attachment card can do seek and read sector ID operations correctly. The seek instructions issued by the test cause the following head movement sequence:

- Recalibration seek (heads to cylinder 00).
- One-track incremental seeks from cylinder 00 to cylinder 74, followed by one-track decremental seeks back to cylinder 00 using head 0.
- Repeat of one-track incremental/decremental seeks using head 1.
- Forward and reverse seeks starting from cylinder 00 to cylinder 74 using head 0, then to cylinder 01, cylinder 73, cylinder 02, cylinder 72, etc until cylinder 26 is reached.
- Repeat of forward/reverse seeks using head 1.

To verify that the selected head is on the correct cylinder, the test chains each seek with a read sector ID and samples the cylinder number of the ID field that is read. If a seek and read sector ID operation is not completed, the test reads cycle steal status and an automatic branch to routine 4620 occurs to define the problem.

This test automatically branches to test 4603.

4603 Seek and Read Data Test

This last auto-test expands on the seek and read sector ID testing done in test 4602. In addition to seeking and read sector ID, this test checks if the FDD and attachment card can execute read data instructions. After seeking to the designated cylinder and verifying the position of the selected head, the test issues a DCB containing read data instructions. The test then checks that the returned interrupt condition code is device end (successful completion). If a seek, read sector ID, or read data operation is not completed, the test reads cycle steal status and an automatic branch to routine 4620 occurs to define the problem.

The data fields in the following diskette locations are read by both heads during the test:

- Sectors 01 and 15 of cylinder 74.
- Sector 01 of cylinders 01, 73, 02, 72, 03, and 71.

FDD MANUAL DIAGNOSTIC TESTS

Descriptions of the FDD manual diagnostic tests follow. These tests fall into two categories:

- Tests 4610 and 4611 - not linked together and each requires operator interaction.
- Tests 4620 and 4621 - linked tests that do not require operator interaction.

4610 Write Sector ID and Data Test

Test 4610 checks if the FDD and attachment card can format sectors and write data correctly. If the test is run on a CDC diskette (the BASIC diskette or a scratch diskette), the write-protect slot of the diskette jacket must be covered with a piece of opaque tape. The writing done in the test occurs on cylinders 01, 02, 03, 74, 75, and 76. On the BASIC diskette, these cylinders are allotted for scratch use (CE cylinders).

The sequence of the test is as follows:

- A recalibration seek is done to place the heads at cylinder 00.
- A seek is made to cylinder 01 using head 0 and a read sector ID performed to verify head position.
- Cylinder 01 is formatted into 15 sectors using head 0 and words of 5555_{16} are written in each data field. The sector IDs and data that has been written is then read-verified by the attachment card.
- The data field in sector 01 of the newly formatted track is read back and the 5555_{16} words verified by the test.
- Head 1 is selected and that track of the cylinder is formatted and verified the same.
- The test then continues to cylinder 02 and the process is repeated. At the end of the test, cylinders 01, 02, 03, 74, 75, and 76 are all reformatted.

If the formatting/read-verifying of a track is not completed, the test reads cycle steal status and an automatic branch to routine 4620 occurs to define the problem.

4611 Write/Read Address Marker Test

This test checks if the FDD and attachment card can write data-address markers and control-address markers in data fields correctly, and if the attachment card reacts correctly when the markers are read back in a read data operation. The sequence of the test is similar to test 4610, except that:

- Instead of writing sector format and 5555_{16} data words, the test writes random data and either a data-address marker or a control-address marker in the first sector of the cylinders that are CE cylinders on the BASIC diskette. Data-address markers are written on cylinders 01, 03, and 75 and control-address markers on cylinders 02, 74, and 76.
- Instead of reading back written data for verification, the test does a read data following each write to check attachment card reaction to the address marker. On cylinders that a data-address marker is written, the test checks that an interrupt condition code of device end is returned and that the interrupt status byte equals 00_{16} . On cylinders that a control-address marker is written, the test checks that an interrupt condition code of unit exception is returned and that the interrupt status byte equals 80_{16} (device status available).

- Following each read data, the test reads cycle steal status to check status word 1. On cylinders with a data-address marker, the test checks that word 1 equals 0000_{16} . On cylinders with a control-address marker, the test checks that word 1 equals 1000_{16} (control-address marker found).

After the test is completed, test 4610 must be run to delete the control-address markers that have been written on the diskette. Otherwise, later use of that diskette will cause error stoppage in auto-test 4603.

4620 Cycle Steal Status Analysis Routine

This routine analyzes cycle steal status word 5 and the error-log byte of word 4 that has been read from the attachment card. (These and the other status words are defined in the Description of Cycle Steal Status Words that follows.) The start cycle steal status command that transfers this information from the attachment card is issued in the auto-test or manual test that was in process before this routine. That test may either stop and instruct the running of this routine or enter it automatically through branching.

Sequentially, the routine:

- Displays the six cycle steal status words in hexadecimal on the assigned alternate console.
- Analyzes the FDD health parameters given in status word 5 and, if a failure is recorded, the routine stops and indicates the failure.
- If no failure is recorded in status word 5, the routine continues and decodes the error-log byte of status word 4 and indicates the result. If necessary, an automatic branch to routine 4621 occurs to complete the decoding.

4621 Continuation of Cycle Steal Status Analysis

This routine only executes when the decoding of the error-log byte cannot be completed by routine 4620.

DESCRIPTION OF CYCLE STEAL STATUS WORDS

A start cycle steal status command transfers status words to the Series/1 processor. The significance of the six status words for the FDD is described in the following paragraphs.

CYCLE STEAL STATUS WORD 0 (Residual Address)

When a cycle steal transfer is halted, the processor storage address where the last cycle steal of data occurred remains in the address counter of the attachment card. This is the residual address and is accessible as cycle steal status word 0. If the last attempted transfer was a word, the residual address is the address of the odd byte of the word. Execution of a start cycle steal status command does not affect this address.

CYCLE STEAL STATUS WORD 1 (FDD Status)

This word provides the status at the time of the terminating interrupt of the last start command (table A-1).

TABLE A-1. CYCLE STEAL STATUS WORD 1 DEFINITION

BIT	TITLE	SIGNIFICANCE
0	Not used	
1	No data field found	Set to 1 if the sector specified in a read-data or read-verify operation was located, but not the associated data field.
2	Overrun	Set to 1 if the processor did not service the cycle steal request within 48 microseconds during a cycle steal transfer operation. This occurs when demands for I/O activity exceeds the capability of the system channel.
3	Control-address marker found	Set to 1 if a control-address marker was found in front of the specified data field. The read-data operation ends after the sector data field containing the control-address marker has been transferred into processor storage. (No check for control-address markers is made during a read-verify operation.)

TABLE A-1. CYCLE STEAL STATUS WORD 1 DEFINITION (CONTD)

BIT	TITLE	SIGNIFICANCE
4	File not ready	Set to 1 if the FDD is not ready to execute or drops ready while executing a seek, recalibration-seek, write-data, read-data, read-verify, read-sector ID, or format-track operation.
5	No record found	Set to 1 if the sector specified in the operation was not found after at least one revolution of the diskette. If the bit is set after a read sector ID operation, the FDD did not find any sector IDs on the track (suspect an unformatted or defective track).
6	End of track	Set to 1 if the last logical sector on track is detected before completing a multiple-sector operation.
7	File data check	Set to 1 if a data error is detected on diskette. Cyclic-redundancy-check bytes are recorded at the end of each sector ID and data field to provide error detection.
8	Index pulse at incorrect time	Set to 1 if diskette speed differs more than 3.5 percent from 360-rpm nominal speed.
9	Invalid diskette side selected	Set to 1 if head 1 is selected for a seek operation on a single-sided diskette.
10	Not used	
11	Not used	
12	Not used	
13	Not used	
14	Not used	
15	Not used	

CYCLE STEAL STATUS WORDS 2 AND 3 (Search Argument)

If a read-data, write-data, or read-verify operation preceded the reading of status, words 2 and 3 contain the search argument used in that operation. If the operation was not completed, the words indicate the sector location that was being accessed when the operation ended. This information is useful if the operation failed because of a data error (bit 7 of status word 1 set). The words indicate the search argument as follows:

- Word 2 - the first byte (bits 0 through 7) indicates the sector length (00₁₆ for 128-byte sector, 01₁₆ for 256-byte sector, or 02₁₆ for 512-byte sector), the second byte (bits 8 through 15) indicates the cylinder number (00 through 4C₁₆).
- Word 3 - the first byte indicates the selected head (00₁₆ for head 0, 01₁₆ for head 1), the second byte indicates the sector number (01 through 1A₁₆ for 128-byte sectors, 00 through 0F₁₆ for 256-byte sectors, or 00 through 08₁₆ for 512-byte sectors).

CYCLE STEAL STATUS WORD 4 (Additional FDD Status and Error Log)

Bits 0 through 7 of word 4 supplement the FDD status given in word 1. The significance of these bits is defined in table A-2.

Bits 8 through 15 of word 4 contain a code that indicates the type of error encountered during execution of the last command. This code is defined in table A-3.

TABLE A-2. CYCLE STEAL STATUS WORD 4, BYTE 1 DEFINITION

BIT	TITLE	SIGNIFICANCE
0	Index	Index pulse was detected when cycle steal status words were updated.
1	Write protect active	The diskette in FDD has the write-protect slot in its jacket uncovered thus activating write protect.
2	Heads engaged	Attachment card has instructed the FDD to load heads.
3	Seek error	The attachment card was unable to verify that the desired cylinder was reached in seek.

TABLE A-2. CYCLE STEAL STATUS WORD 4, BYTE 1 DEFINITION (CONTD)

BIT	TITLE	SIGNIFICANCE
4	Write fault	A fault caused data to be improperly written on diskette. Possible faults are: <ul style="list-style-type: none"> ● Write enabled without heads loaded ● Write enabled without write data ● Write enabled without erase current
5	Track 00	The FDD heads are positioned at cylinder 00.
6	DRQ	Data request is active on attachment card indicating FDD is still attempting to transfer data.
7	FDC busy	The FDD controller chip on attachment card was executing a command when cycle steal status words were updated.

TABLE A-3. CYCLE STEAL STATUS WORD 4, BYTE 2 DEFINITION

HEXADECIMAL ERROR CODE	SIGNIFICANCE
00	No error occurred.
01	DCB input flag set in output operation.
02	DCB input flag not set in input operation.
03	Illegal control word modifier contained in DCB.
04	FDD was not ready when command was issued.
05	A forward seek was specified beyond cylinder 76.
06	A backward seek was specified beyond cylinder 00.
07	DCB byte count not equal to 4 in a read sector ID instruction.
08	A read or write was attempted beyond end of track.
09	The sector register in FDD controller chip on attachment card did not load correctly.
0A	The data register in FDD controller chip on attachment card did not load correctly.
0B	The head-select register on attachment card is incorrect.

TABLE A-3. CYCLE STEAL STATUS WORD 4, BYTE 2 DEFINITION (CONTD)

HEXADECIMAL ERROR CODE	SIGNIFICANCE
0C	Invalid diskette side specified in DCB.
0D	FDD dropped ready during execution of last command.
0E	A FDD write fault occurred.
0F	A FDD seek error occurred.
10	No sector ID field was found.
11	No data field was found.
12	A CRC error occurred.
13	Data was lost in FDD controller chip on attachment card due to overrun.
14	The starting sector in DCB was out of range.
15	The starting storage address in DCB was odd.
16	The byte count in DCB was odd.
17	The sector length in DCB was greater than 02 ₁₆ .
18	A write was attempted on a write-protected diskette.
19	An invalid format data word was given in DCB word 2.
1A	An invalid N byte (sector length) was given in DCB word 3 of a format track instruction.
1B	An invalid C byte (cylinder number) was given in DCB word 3 of a format track instruction.
1C	A command was received from the processor during a FDD malfunction. The problem is identified in cycle steal status word 5.
1D	The DCB head byte differs from the head that is selected.
1E	The track register in FDD controller chip on attachment card did not load correctly.
1F	The diskette-initialize latch on attachment card failed to set for a format track operation.

TABLE A-3. CYCLE STEAL STATUS WORD 4, BYTE 2 DEFINITION (CONTD)

HEXADECIMAL ERROR CODE	SIGNIFICANCE
20	Index was detected before a format track operation was completed on track.
21	The FDD write-enable latch on attachment card failed to set for a write operation.
22	The FDD write-enable latch on attachment card failed to clear after a write operation.
23	The last command was not executed within 1.5 seconds and attachment card aborted the operation.
24 to 80	Not used.
81	The processor issued an interface data check to attachment card.
82	Protect check. The storage-access key given in DCB is invalid.
83	Invalid storage address given in DCB.
84	Storage data check. Data accessed from processor memory was out of parity.
85	Not used.
86	DPC command not accepted by attachment card.
87	Not used.
88	Not used.
89	The attachment card issued an interface data check to the processor.
8A	Not used.
8B	Odd DCB address given in IDCB for a start command (70XX).
8C	Odd chaining address given in DCB for a start command (70XX).
8D to 8F	Not used.
90	Odd DCB address given in IDCB for a start diagnostic 1 command (7DXX).

TABLE A-3. CYCLE STEAL STATUS WORD 4, BYTE 2 DEFINITION (CONTD)

HEXADECIMAL ERROR CODE	SIGNIFICANCE
91	Not used.
92	DCB input flag was not set in a start diagnostic 1 command (7DXX).
93	Odd byte count given in DCB for a start diagnostic 1 command (7DXX).
94	Excessive byte count given in DCB for a start diagnostic 1 command (7DXX).
95	Odd storage address given in DCB for a start diagnostic 1 command (7DXX).
96	Odd DCB address given in IDCB for a start diagnostic 2 command (7EXX).
97	Not used.
98	DCB input flag was set in a start diagnostic 2 command (7EXX).
99	Odd byte count given in DCB for a start diagnostic 2 command (7EXX).
9A	Excessive byte count given in DCB for a start diagnostic 2 command (7EXX).
9B	Odd data address given in DCB for a start diagnostic 2 command (7EXX).
9C to A2	Not used.
A3	Odd DCB address given in IDCB for a start cycle steal status command (7FXX).
A4	Not used.
A5	DCB input flag not set in a start cycle steal status command (7FXX).
A6	Odd byte count given in DCB for a start cycle steal status command (7FXX).
A7	Excessive byte count given in DCB for a start cycle steal status command (7FXX).
A8	Odd storage address given in DCB for a start cycle steal status command (7FXX).

CYCLE STEAL STATUS WORD 5 (FDD Health Parameters)

Word 5 contains a record of the FDD health parameters that are monitored by the attachment card when no commands are being executed (table A-4).

TABLE A-4. CYCLE STEAL STATUS WORD 5 DEFINITION

BIT	SIGNIFICANCE
0	Set to 1 if FDD is not ready - door open, power not on, or diskette speed 70 percent below nominal 360 rpm.
1	Not used.
2	Set to 1 if FDD I/O cable is disconnected or open.
3	Set to 1 if diskette speed is too high - speed exceeds nominal 360 rpm by more than 3.5 percent.
4	Set to 1 if diskette speed is too low - speed below nominal 360 rpm by more than 3.5 percent.
5	Set to 1 if FDD write-fault latch is stuck on.
6	Set to 1 if +20 V from FDD power supply is low.
7	Set to 1 if attachment card 12-V power supply is low.
8	Set to 1 if attachment card reset latch is stuck on.
9	Set to 1 if attachment card test-mode latch is stuck on.
10	Set to 1 if attachment card diskette-initialize latch is stuck on.
11	Set to 1 if attachment card write-fault reset latch is stuck on.
12	Set to 1 if attachment card write-enable latch is stuck on.
13	Set to 1 if attachment card write-enable latch is stuck clear.
14	Set to 1 if attachment card write-request latch is stuck on.
15	Set to 1 if attachment card read-request latch is stuck on.

NOTICE

Before running the FDD diagnostic tests, read and understand the following:

- If diagnostics are to be loaded from a FDD other than the one to be tested, use the instructions in para 3.6.2 and observe the following:
 - The scratch diskette in test unit must be two-sided and formatted. If contents of the scratch diskette are unknown or if its a new CDC diskette, it must be formatted before running diagnostics (para 3.6.2 contains instructions).
 - If diagnostic tests end abnormally (with or without a message) or with a meaningless abort message, reseal the attachment card of the test unit and rerun tests. If the problem persists, replace the attachment card and I/O cable of the test unit one at a time until problem is corrected.*
- If diagnostics are to be loaded from the FDD to be tested, use the instructions in para 3.6.1 and observe the following:
 - A scratch diskette cannot be substituted for the BASIC diskette after IPL. Each diagnostic test is read off the BASIC diskette as it is called up or branched to by the program.
 - If IPL cannot be accomplished from the test unit, go to paper-only SAM 4670 (Power-On and IPL Problems) for troubleshooting information.

*Replacing attachment card requires that switches on new card be set for device address and IPL assignment (refer to Installing Attachment Card and Cabling, section 2). Replacing I/O cable requires accessing FDD (para 3.1) and routing new cable (refer to section 2 of this manual if a standalone unit or section 2 of MMD site information manual if a combination unit).

- If diagnostic tests do not execute, end abnormally (with or without a message), or end with a meaningless abort message, go to paper-only SAM 4672 (Not Ready Status).

- Diagnostic tests assume that the Series/1 I/O bus is providing +5 +0.5 V and -5 +0.5 V to the attachment card. To verify +5 V is correct, refer to Installing Attachment Card and Cabling, section 2. To verify the -5 V, take the precautions given for measuring +5 V and measure between pins G06 and J08 (ground) at the backpanel location of the attachment card. The -5 V is not adjustable on any model Series/1.

- Diagnostic test halts - when the halt code is a diagnostic test number, level 3 registers contain the following:
 - R0 - Step number
 - R1 - Device address and type code (AATT)
 - R3 - If an abort, pointer to starting address in memory containing additional information

- Always turn off power to equipment when reseating/replacing the attachment card or I/O cable.

- Rerun diagnostic tests after troubleshooting to verify proper operation.


```

A B
1 1
: :
014 : Y N CC = 1?
: :
015 : : 1 Device hung busy. Reseat/replace attachment
: : card. (1)
: :
: 1 Go to step 016.
:
016 1 Delay for reset to end.
:
017 Y N Prepare command. CC = 7?
: :
018 : Y N Other than CC = 5?
: :
019 : : 1 Interface data check. Replace attachment card. (1)
: :
020 : Y N Other than CC = 3?
: :
021 : : 1 Prepare command rejected. Replace attachment
: : card. (1)
: :
022 : Y N Other than CC = 2?
: :
023 : : 1 Device hung busy after reset. Replace attachment
: : card. (1)
: :
024 : Y N Other than CC = 0?
: :
025 : : 1 Device not attached. Reseat attachment card and
: : check that the device address specified by attach-
: : ment card switches matches the FDD device address in
: : configurator table. Enter B38F0 to call up con-
: : figurator table and refer to Installing Attachment
: : Card and Cabling, section 2, for switch assignments.
: : If error persists, replace attachment card. (1)
: :
026 : Y N Other than CC = 1?
: :
027 : : 1 Device hung busy. Reseat/replace attachment
: : card. (1)
: :
028 : 1 Unexpected condition code returned. If front panel
: LED for FDD has extinguished, go to paper-only
: SAM 4670 (Power-On and IPL problems). Otherwise,
: access FDD (para 3.1) and check power cable connec-
: tions at J7 on FDD power supply board and at attach-
: ment card. If connections are secure, verify that
: +20 +2.4 V is present between return J7-2 and J7-1
: and J7-3 on power supply board. If voltage is OK,
: replace attachment card (1); if voltage is bad, go to
: paper-only SAM 4673 (Bad Power Supply Voltages).
:
3

```

A

```

A
2
:
029 Y N Prepare command, level 3. CC = 7?
: :
: 1 Go to step 034.
:
030 Y N Prepare command, level 2. CC = 7?
: :
: 1 Go to step 034
:
031 Y N Prepare command, level 1. CC = 7?
: :
: 1 Go to step 034.
:
032 Y N Prepare command, level 0. CC = 7?
: :
: 1 Go to step 034.
:
033 Y N Prepare command with odd parity. CC = 7?
: :
034 : Y N Other than CC = 5?
: : :
035 : : 1 Interface data check. Replace attachment card. (1)
: : :
036 : Y N Other than CC = 3?
: : :
037 : : 1 Prepare command rejected. Replace attachment
: : card. (1)
: :
038 : Y N Other than CC = 2?
: : :
039 : : 1 Device hung busy after reset. Replace attachment
: : card. (1)
: :
040 : Y N Other than CC = 0?
: : :
041 : : 1 Device not attached. Reseat attachment card and
: : check that the device address specified by attach-
: : ment card switches matches the FDD device address in
: : configurator table. Enter B38F0 to call up con-
: : figurator table and refer to Installing Attachment
: : Card and Cabling, section 2, for switch assignments.
: : If error persists, replace attachment card. (1)
: :
042 : Y N Other than CC = 1?
: : :
043 : : 1 Device hung busy. Reseat/replace attachment
: : card. (1)
: :
: :
: :
4 4
A B

```

```

A B
3 3
:
:
044 : 1 Unexpected condition code returned. If front panel LED
: for FDD has extinguished, go to paper-only SAM 4670
: (Power-On and IPL problems). Otherwise, access FDD
: (para 3.1) and check power cable connections at J7 on
: FDD power supply board and at attachment card. If
: connections are secure, verify that +20 +2.4 V is
: present between return J7-2 and J7-1 and J7-3 on
: power supply board. If voltage is OK, replace attach-
: ment card (1); if voltage is bad, go to paper-only
: SAM 4673 (Bad Power Supply Voltages).
:
045 Y N Illegal command 00. CC = 3?
:
:
046 : 1 Unexpected condition code returned. If front panel LED
: for FDD has extinguished, go to paper-only SAM 4670
: (Power-On and IPL problems). Otherwise, access FDD
: (para 3.1) and check power cable connections at J7 on
: FDD power supply board and at attachment card. If
: connections are secure, verify that +20 +2.4 V is
: present between return J7-2 and J7-1 and J7-3 on
: power supply board. If voltage is OK, replace attach-
: ment card (1); if voltage is bad, go to paper-only
: SAM 4673 (Bad Power Supply Voltages).
:
047 Y N Illegal command 10. CC = 3?
:
:
048 : 1 Unexpected condition code returned. If front panel LED
: for FDD has extinguished, go to paper-only SAM 4670
: (Power-On and IPL problems). Otherwise, access FDD
: (para 3.1) and check power cable connections at J7 on
: FDD power supply board and at attachment card. If
: connections are secure, verify that +20 +2.4 V is
: present between return J7-2 and J7-1 and J7-3 on
: power supply board. If voltage is OK, replace attach-
: ment card (1); if voltage is bad, go to paper-only
: SAM 4673 (Bad Power Supply Voltages).
:
049 Y N Illegal command 3F. CC = 3?
:
:
050 : 1 Unexpected condition code returned. If front panel LED
: for FDD has extinguished, go to paper-only SAM 4670
: (Power-On and IPL problems). Otherwise, access FDD
: (para 3.1) and check power cable connections at J7 on
: FDD power supply board and at attachment card. If
: connections are secure, verify that +20 +2.4 V is
: present between return J7-2 and J7-1 and J7-3 on
: power supply board. If voltage is OK, replace attach-
: ment card (1); if voltage is bad, go to paper-only
: SAM 4673 (Bad Power Supply Voltages).
:
051 Y N Device reset command. CC = 7?
:
:
5 5
A B

```

```

A B
4 4
:
:
052 : 1 Unexpected condition code returned. If front panel LED
: for FDD has extinguished, go to paper-only SAM 4670
: (Power-On and IPL problems). Otherwise, access FDD
: (para 3.1) and check power cable connections at J7 on
: FDD power supply board and at attachment card. If
: connections are secure, verify that +20 +2.4 V is
: present between return J7-2 and J7-1 and J7-3 on
: power supply board. If voltage is OK, replace attach-
: ment card (1); if voltage is bad, go to paper-only
: SAM 4673 (Bad Power Supply Voltages).
:
053 : 1 Delay for reset to end.
:
054 : Y N Start diagnostic 1 command. CC = 0703 and ROM (read-
: : only memory) checksum correct?
: :
055 : Y N CC = 0703?
: :
056 : : 1 Unexpected condition code returned. If front
: : panel LED for FDD has extinguished, go to paper-
: : only SAM 4670 (Power-On and IPL problems). Other-
: : wise, access FDD (para 3.1) and check power cable
: : connections at J7 on FDD power supply board and at
: : attachment card. If connections are secure, verify
: : that +20 +2.4 V is present between return J7-2 and
: : J7-1 and J7-3 on power supply board. If voltage is
: : OK, replace attachment card (1); if voltage is bad,
: : to to paper-only SAM 4673 (Bad Power Supply
: : Voltages).
: :
057 : Y N Checksum for ROM 1 correct?
: :
058 : : 1 Checksum for ROM 1 incorrect. Replace attachment
: : card. (1)
: :
059 : 1 Checksum for ROM 2 incorrect. Replace attachment
: : card. (1)
: :
060 : Y N Word 5 = 6000 in diagnostic 1 response (diskette speed
: : OK)?
: :
061 : Y N Start cycle steal status command. CC = 0703?
: :
062 : : 1 Cycle steal status failed. Replace attachment
: : card (1).
: :
063 : 1 Branch to test 4620 (SAM 4620).
:
:
:

```

6
A

A
5
:
064 Y N Word 6 other than 0040 (not ready status) in diag-
: : nostic 1 response?
:
065 : Y N Start cycle steal status command. CC = 0703?
:
066 : : 1 Cycle steal status failed. replace attachment
: : card. (1)
:
067 : 1 Branch to test 4620 (SAM 4620).
:
068 Y N Word 7 = 6E00 in diagnostic 1 response?
:
069 : 1 Word 7 incorrect. Replace attachment card. (1)
:
070 1 Branch to test 4601 (SAM 4601).

(1) Set switches on new attachment card for FDD device address and IPL assignment (Installing Attachment Card and Cabling, section 2).

This test links from test 4600 (SAM 4600). If cycle steal status word 4 or 5 indicates an improper FDD condition in step 008 of this test, an automatic branch to routine 4620 (SAM 4620) occurs to define the problem.

```

001  1  Start command with DCB specifying a recalibration seek
      :  to reset cycle steal status word 1.
      :
002  Y N  Start cycle steal status command.  CC = 0703?
      :
003  : 1  Incorrect condition code for cycle steal status after
      :  reset.  Replace attachment card. (1)
      :
004  Y N  ISB = 0000?
      :
005  : 1  Incorrect interrupt status byte.  Replace attachment
      :  card. (1)
      :
006  Y N  Cycle steal status word 1 = 0000?
      :
007  : 1  Incorrect cycle steal status word 1.  Replace attach-
      :  ment card. (1)
      :
008  Y N  Cycle steal status word 4 = XX00 and word 5 = 0000?
      :
009  : 1  Branch to test 4620 (SAM 4620).
      :
010  Y N  Start cycle steal status command with input flag bit
      :  off in DCB.  CC = 0702 and ISB bit on for DCB specifi-
      :  cation check?
      :
011  : 1  Incorrect condition code or interrupt status byte.
      :  Replace attachment card. (1)
      :
012  Y N  Cycle steal status word 4 = XXA5?
      :
013  : 1  Incorrect cycle steal status word 4.  Run test 4620
      :  (SAM 4620) to decode status.
      :
014  Y N  Start cycle steal status command with odd byte count
      :  in DCB.  CC = 0702 and ISB bit on for DCB specifica-
      :  tion check?
      :
015  : 1  Incorrect condition code or interrupt status byte.
      :  Replace attachment card. (1)
      :
016  Y N  Cycle steal status word 4 = XXA6?
      :
017  : 1  Incorrect cycle steal status word 4.  Run test 4620
      :  (SAM 4620) to decode status.

```

2
A

ATTACHMENT TEST SAM 4601-1

- A
- 1
- :
- 018 Y N Start cycle steal status command with too large a byte
: : count in DCB. CC = 0702 and ISB bit on for DCB
: : specification check?
- :
- 019 : 1 Incorrect condition code or interrupt status byte.
: Replace attachment card. (1)
- :
- 020 Y N Cycle steal status word 4 = XXA7?
- :
- 021 : 1 Incorrect cycle steal status word 4. Run test 4620
: (SAM 4620) to decode status.
- :
- 022 Y N Start cycle steal status command with odd data address
: : in DCB. CC = 0702 and ISB bit on for DCB specifica-
: : tion check?
- :
- 023 : 1 Incorrect condition code or interrupt status byte.
: Replace attachment card. (1)
- :
- 024 Y N Cycle steal status word 4 = XXA8?
- :
- 025 : 1 Incorrect cycle steal status word 4. Run test 4620
: (SAM 4620) to decode status.
- :
- 026 Y N Start diagnostic 1 command with input flag bit off in
: : DCB. CC = 0702 and ISB bit on for DCB specification
: : check?
- :
- 027 : 1 Incorrect condition code or interrupt status byte.
: Replace attachment card. (1)
- :
- 028 Y N Start cycle steal status command. Cycle steal status
: : word 4 = XX92?
- :
- 029 : 1 Incorrect cycle steal status word 4. Run test 4620
: (SAM 4620) to decode status.
- :
- 030 Y N Start diagnostic 1 command with odd byte count in DCB.
: : CC = 0702 and ISB bit on for DCB specification check?
- :
- 031 : 1 Incorrect condition code or interrupt status byte.
: Replace attachment card. (1)
- :
- 032 Y N Start cycle steal status command. Cycle steal status
: : word 4 = XX94?
- :
- 033 : 1 Incorrect cycle steal status word 4. Run test 4620
: (SAM 4620) to decode status.

3
A

A
2
:
034 Y N Start diagnostic 1 command with too large a byte count
: : in DCB. CC = 0702 and ISB bit on for DCB specifica-
: : tion check?
: :
035 : 1 Incorrect condition code or interrupt status byte.
: Replace attachment card. (1)
:
036 Y N Start cycle steal status command. Cycle steal status
: : word 4 = XX94?
: :
037 : 1 Incorrect cycle steal status word 4. Run test 4620
: (SAM 4620) to decode status.
:
038 Y N Start diagnostic 1 command with odd data address in
: : DCB. CC = 0702 and ISB bit on for DCB specification
: : check?
: :
039 : 1 Incorrect condition code or interrupt status byte.
: Replace attachment card. (1)
:
040 Y N Start cycle steal status command. Cycle steal status
: : word 4 = XX95?
: :
041 : 1 Incorrect cycle steal status word 4. Run test 4620
: (SAM 4620) to decode status.
:
042 Y N Start diagnostic 2 command with input flag bit on in
: : DCB. CC = 0702 and ISB bit on for DCB specification
: : check?
: :
043 : 1 Incorrect condition code or interrupt status byte.
: Replace attachment card. (1)
:
044 Y N Start cycle steal status command. Cycle steal status
: : word 4 = XX98?
: :
045 : 1 Incorrect cycle steal status word 4. Run test 4620
: (SAM 4620) to decode status.
:
046 Y N Start diagnostic 2 command with odd byte count in DCB.
: : CC = 0702 and ISB bit on for DCB specification check?
: :
047 : 1 Incorrect condition code or interrupt status byte.
: Replace attachment card. (1)
:
:
:
:
:
:
4
A


```

A B
4 4
: :
063 : 1 Incorrect condition code or interrupt status byte.
      : Replace attachment card. (1)
      :
064 Y N Start cycle steal status command. Cycle steal status
      : : word 4 = XX07?
      : :
065 : 1 Incorrect cycle steal status word 4. Run test 4620
      : (SAM 4620) to decode status.
      :
066 Y N Start command with DCB specifying too high a sector
      : : number. CC = 0702 and ISB bit on for DCB specifica-
      : : tion check?
      : :
067 : 1 Incorrect condition code or interrupt status byte.
      : Replace attachment card. (1)
      :
068 Y N Start cycle steal status command. Cycle steal status
      : : word 4 = XX14?
      : :
069 : 1 Incorrect cycle steal status word 4. Run test 4620
      : (SAM 4620) to decode status.
      :
070 Y N Start command with odd data address in DCB. CC = 0702
      : : and ISB bit on for DCB specification check?
      : :
071 : 1 Incorrect condition code or interrupt status byte.
      : Replace attachment card. (1)
      :
072 Y N Start cycle steal status command. Cycle steal status
      : : word 4 = XX15?
      : :
073 : 1 Incorrect cycle steal status word 4. Run test 4620
      : (SAM 4620) to decode status.
      :
074 Y N Start command with odd byte count in DCB. CC = 0702
      : : and ISB bit on for DCB specification check?
      : :
075 : 1 Incorrect condition code or interrupt status byte.
      : Replace attachment card. (1)
      :
076 Y N Start cycle steal status command. Cycle steal status
      : : word 4 = XX16?
      : :
077 : 1 Incorrect cycle steal status word 4. Run test 4620
      : (SAM 4620) to decode status.
      :
078 Y N Start command with illegal sector length in DCB.
      : : CC = 0702 and ISB bit on for DCB specification check?
      : :
6 6
A B

```

```

A B
5 5
:
:
079 : 1 Incorrect condition code or interrupt status byte.
: Replace attachment card. (1)
:
080 Y N Start cycle steal status command. Cycle steal status
: : word 4 = XX17?
: :
081 : 1 Incorrect cycle steal status word 4. Run test 4620
: (SAM 4620) to decode status.
:
082 Y N Start command with odd data address in DCB. CC = 0702
: : and ISB bit on for DCB specification check?
: :
083 : 1 Incorrect condition code or interrupt status byte.
: Replace attachment card. (1)
:
084 Y N Start cycle steal status command. Cycle steal status
: : word 4 = XX8B?
: :
085 : 1 Incorrect cycle steal status word 4. Run test 4620
: (SAM 4620) to decode status.
:
086 Y N Start command with odd chain address in DCB. CC = 0702
: : and ISB bit on for DCB specification check?
: :
087 : 1 Incorrect condition code or interrupt status byte.
: Replace attachment card. (1)
:
088 Y N Start cycle steal status command. Cycle steal status
: : word 4 = XX8C?
: :
089 : 1 Incorrect cycle steal status word 4. Run test 4620
: (SAM 4620) to decode status.
:
090 1 Branch to test 4602 (SAM 4602).

```

(1) Set switches on new attachment card for FDD device address and IPL assignment (Installing Attachment Card and Cabling, section 2).

This test links from test 4601 (SAM 4601). If a seek/read-sector-ID operation fails in the test, a start cycle steal status command is issued. If the attachment card accepts the command, an automatic branch to routine 4620 (SAM 4620) occurs to define the problem.

```

001  Y N  Start command with DCB specifying recalibration seek
      : :  (head 0 to cylinder 00).  CC = 0703 and ISB = 00?
      : :
002  : Y N  Start cycle steal status command.  CC = 0703?
      : : :
003  : : 1  Cycle steal status failed.  Replace attachment
      : :   card. (1)
      : :
004  : Y N  Cycle steal status word 4 = XX00 and word 5 = 0000?
      : : :
005  : : 1  Branch to test 4620 (SAM 4620).
      : :
006  : 1  Recalibration seek failed.  Replace attachment
      :   card. (1)
      :
007  1  Delay for seek to end.
      :
008  Y N  Start command with DCB specifying read sector ID.
      : :  CC = 0703 and ISB = 00?
      : :
009  : Y N  Start cycle steal status command.  CC = 0703 and
      : :   ISB = 00?
      : : :
010  : : 1  Cycle steal status failed.  Test aborted.  Replace
      : :   attachment card. (1)
      : :
011  : Y N  Cycle steal status word 4 = XX00 and word 5 = 0000?
      : : :
012  : : 1  Branch to test 4620 (SAM 4620).
      : :
013  : 1  Read sector ID failed.  Replace attachment card. (1)
      :
014  Y N  Head 0 at cylinder 00 following recalibration seek?
      : :
015  : 1  Wrong cylinder location for head 0 following recalibration
      :   seek.  Go to paper-only SAM 4672 (Not Ready
      :   Status).
      :
016  Y N  Start command with chained DCBs specifying one-track
      : :  seeks to cylinder 74 using head 0, followed by one-
      : :  track seeks back to cylinder 00.  A read sector ID is
      : :  done between each seek.  Final CC = 0703?
      : :
      2 2
A B

```

A B

62947909

1 1
:
:
017 : Y N Start cycle steal status command. CC = 0703?
:
:
018 : : 1 Cycle steal status failed. Test aborted. Replace
attachment card. (1)
:
:
019 : Y N Cycle steal status word 4 = XX00 and word 5 = 0000?
:
:
020 : : 1 Branch to test 4620 (SAM 4620).
:
:
021 : 1 Incremental/decremental seeks with head 0 failed.
Replace attachment card. (1)
:
:
022 Y N Head 0 at cylinder 00 following incremental/
decremental seeks?
:
:
023 : 1 Head 0 on wrong cylinder after seeks. Go to paper-
only SAM 4672 (Not Ready Status).
:
:
024 Y N Start command with chained DCBs specifying one-track
seeks to cylinder 74 using head 1, followed by one-
track seeks back to cylinder 00. A read sector ID is
done between each seek. Final CC = 0703?
:
:
025 : Y N Start cycle steal status command. CC = 0703?
:
:
026 : : 1 Cycle steal status failed. Test aborted. Replace
attachment card. (1)
:
:
027 : Y N Cycle steal status word 4 = XX00 and word 5 = 0000?
:
:
028 : : 1 Branch to test 4620 (SAM 4620).
:
:
029 : 1 Incremental/decremental seeks with head 1 failed.
Replace attachment card. (1)
:
:
030 Y N Head 1 at cylinder 00 following incremental/decremental
seeks?
:
:
031 : 1 Head 1 on wrong cylinder after seeks. Replace FDD
assembly (para 3.2).
:
:
032 Y N Start command with chained DCBs specifying forward and
reverse seeks using head 0. Final CC = 0703?
:
:
033 : Y N Start cycle steal status command. CC = 0703?
:
:
034 : : 1 Cycle steal status failed. Test aborted. Replace
attachment card. (1)
:
:
:
3 3

A B


SEEK AND READ SECTOR ID TEST (CONTD) SAM 4602-2

A B

62947909

2 2
:
:
035 : Y N Cycle steal status word 4 = XX00 and word 5 = 0000?
:
:
036 : : 1 Branch to test 4620 (SAM 4620).
:
:
037 : 1 Forward/reverse seeks with head 0 failed. Replace
: attachment card. (1)
:
038 Y N Head 0 at cylinder 26 following forward/reverse seeks?
:
:
039 : 1 Head 0 on wrong cylinder after seeks. Replace FDD
: assembly (para 3.2).
:
040 Y N Start command with chained DCBs specifying forward and
: : reverse seeks using head 1. Final CC = 0703?
:
:
041 : Y N Start cycle steal status command. CC = 0703?
:
:
042 : : 1 Cycle steal status failed. Test aborted. Replace
: : attachment card. (1)
:
:
043 : Y N Cycle steal status word 4 = XX00 and word 5 = 0000?
:
:
044 : : 1 Branch to test 4620 (SAM 4620).
:
:
045 : 1 Forward/reverse seeks with head 1 failed. Replace
: attachment card. (1)
:
046 Y N Head 1 at cylinder 26 following forward/reverse seeks?
:
:
047 : 1 Head 1 on wrong cylinder after seeks. Replace FDD
: assembly (para 3.2).
:
:
048 1 Branch to test 4603 (SAM 4603).

(1) Set switches on new attachment card for FDD device address and IPL assignment (Installing Attachment Card and Cabling, section 2).




```

A
2
:
030 Y N Start command with DCB selecting head 1.  CC = 0703?
:
: 1 Go to step 061.
:
031 Y N Start command with DCB specifying read data from
: : cylinder 01, sector 01.
:
: 1 Go to step 067.
:
032 Y N Start command with DCB specifying seek to cylinder 73
: : using head 0.  CC = 0703?
:
: 1 Go to step 061.
:
033 Y N Head 0 at cylinder 73?
:
034 : 1 Cylinder does not match previous seek.  Replace FDD
: : assembly (para 3.2).
:
035 Y N Start command with DCB specifying read data from
: : cylinder 73, sector 01.  CC = 0703?
:
: 1 Go to step 067.
:
036 Y N Start command with DCB selecting head 1.  CC = 0703?
:
: 1 Go to step 061.
:
037 Y N Start command with DCB specifying read data from
: : cylinder 73, sector 01.  CC = 0703?
:
: 1 Go to step 067.
:
038 Y N Start command with DCB specifying seek to cylinder 02
: : using head 0.  CC = 0703?
:
: 1 Go to step 061.
:
039 Y N Head 0 at cylinder 02?
:
040 : 1 Cylinder does not match previous seek.  Replace FDD
: : assembly (para 3.2).
:
041 Y N Start command with DCB specifying read data from
: : cylinder 02, sector 01.
:
: 1 Go to step 067.
:
:
:
4
A

```



```

A
4
:
054 Y N Start command with DCB selecting head 1. CC = 0703?
: :
: 1 Go to step 061.
:
055 Y N Start command with DCB specifying read data from
: : cylinder 03, sector 01. CC = 0703?
: :
: 1 Go to step 067.
:
056 Y N Start command with DCB specifying seek to cylinder 71
: : using head 0. CC = 0703?
: :
: 1 Go to step 061.
:
057 Y N Head 0 at cylinder 71?
: :
058 : 1 Cylinder does not match previous seek. Replace FDD
: : assembly (para 3.2).
:
059 Y N Start command with DCB specifying read data from
: : cylinder 71, sector 01. CC = 0703?
: :
: 1 Go to step 067.
:
060 Y N Start command with DCB selecting head 1. CC = 0703?
: :
061 : Y N Start cycle steal status command. CC = 0703?
: :
062 : : 1 Cycle steal status failed. Test aborted. Replace
: : attachment card. (1)
: :
063 : Y N Cycle steal status word 4 = XX00 and word 5 = 0000?
: :
064 : : 1 Branch to test 4620 (SAM 4620).
: :
065 : 1 Incorrect condition code returned for seek. Replace
: : attachment card. (1)
:
066 Y N Start command with DCB specifying read data from
: : cylinder 71, sector 01. CC = 0703?
: :
067 : Y N Start cycle steal status command. CC = 0703?
: :
068 : : 1 Cycle steal status failed. Test aborted. Replace
: : attachment card. (1)
: :
: :
: :
: :
6 6
A B

```

62947909

```

A B
5 5
: :
069 : Y N Cycle steal status word 4 = XX00 and word 5 = 0000?
: :
070 : : 1 Branch to test 4620 (SAM 4620).
: :
071 : Y N Cycle steal status word 1 = 1000?
: :
072 : : 1 Incorrect condition code returned for read data.
: : Replace attachment card. (1)
: :
073 : 1 Control-address marker encountered in read data
: operation. This occurs if diskette in FDD was used
: in a prior running of manual test 4611 (write/read
: address marker test). Run test 4610 (SAM 4610) to
: delete the control-address markers that test 4611 has
: written on diskette. Then rerun this auto-test.
:
074 : 1 Auto-tests completed successfully.

```

(1) Set switches on new attachment card for FDD device address and IPL assignment (Installing Attachment Card and Cabling, section 2).


```

A
3
:
032 Y N Start command with DCB selecting head 1. CC = 0703?
:
:
033 : 1 Incorrect condition code for head-reselection seek.
: Run auto-tests starting with test 4600 (SAM 4600).
:
:
034 Y N Start command with chained DCBs specifying write
: : format on cylinder 02 with words of 5555 in data
: : fields and then read-verify. CC = 0703?
:
:
: 1 Go to step 091.
:
035 Y N Start command with chained DCBs specifying read data
: : from cylinder 02. CC = 0703?
:
:
036 : 1 Incorrect condition code for read data. Run auto-
: test 4603 (SAM 4603) or if already run, replace
: attachment card. (1)
:
:
037 Y N Data words read = 5555?
:
:
038 : 1 Incorrect data read from formatted track. Replace
: attachment card (1) and I/O cable (2) one at a time.
:
:
039 Y N Start command with DCB specifying seek to cylinder 03
: : using head 0. CC = 0703?
:
:
040 : 1 Incorrect condition code for seek. Run auto-tests
: starting with test 4600 (SAM 4600).
:
:
041 Y N Start command with chained DCBs specifying write
: : format on cylinder 03 with words of 5555 in data
: : fields and then read-verify. CC = 0703?
:
:
: 1 Go to step 091.
:
042 Y N Start command with chained DCBs specifying read data
: : from cylinder 03. CC = 0703?
:
:
043 : 1 Incorrect condition code for read data. Run auto-
: test 4603 (SAM 4603) or if already run, replace
: attachment card. (1)
:
:
044 Y N Data words read = 5555?
:
:
:
:
:
:
:
:
:
:
5 5
A B WRITE SECTOR ID AND DATA TEST (CONTD) SAM 4610-4

```




```

A
5
:
058 Y N Data words read = 5555?
:
:
059 : 1 Incorrect data read from formatted track. Replace
: attachment card (1) and I/O cable (2) one at a time.
:
:
060 Y N Start command with DCB selecting head 1. CC = 0703?
:
:
061 : 1 Incorrect condition code for head-reselection seek.
: Run auto-tests starting with test 4600 (SAM 4600).
:
:
062 Y N Start command with chained DCBs specifying write
: : format on cylinder 74 with words of 5555 in data
: : fields and then read-verify. CC = 0703?
: :
: : 1 Go to step 091.
:
:
063 Y N Start command with chained DCBs specifying read data
: : from cylinder 74. CC = 0703?
: :
: :
064 : 1 Incorrect condition code for read data. Run auto-
: test 4603 (SAM 4603) or if already run, replace
: attachment card. (1)
:
:
065 Y N Data words read = 5555?
:
:
066 : 1 Incorrect data read from formatted track. Replace
: attachment card (1) and I/O cable (2) one at a time.
:
:
067 Y N Start command with DCB specifying seek to cylinder 75
: : using head 0. CC = 0703?
: :
: :
068 : 1 Incorrect condition code for seek. Run auto-tests
: starting with test 4600 (SAM 4600).
:
:
069 Y N Start command with chained DCBs specifying write
: : format on cylinder 75 with words of 5555 in data
: : fields and then read-verify. CC = 0703?
: :
: : 1 Go to step 091.
:
:
070 Y N Start command with chained DCBs specifying read data
: : from cylinder 75. CC = 0703?
: :
: :
: :
: :
: :
: :
: :
: :
7 7
A B WRITE SECTOR ID AND DATA TEST (CONTD) SAM 4610-6

```


A B
8 8
:
:
099 : 1 Incorrect data read from formatted track. Replace
: attachment card (1) and I/O cable (2) one at a time.
:
:
100 1 End of test. No error occurred.

-
- (1) Set switches on new attachment card for FDD device address and IPL assignment (Installing Attachment Card and Cabling, section 2).
 - (2) Access FDD (para 3.1) and route new I/O cable per section 2 of this manual if a standalone unit or per section 2 of MMD site information manual if a combination unit.



This FDD manual diagnostic test writes random data with data-address markers and control-address markers, has the attachment card read-verify what is written, and checks if the attachment card reacts correctly when the address markers are read back in a data read. Cylinders 01, 02, 03, 74, 75, and 76 are used in the test. On the BASIC diskette, these cylinders are allotted for scratch use (CE cylinders). After this test is completed, run test 4610 (SAM 4610) to delete the control-address markers that have been written on the diskette. Otherwise, later use of the diskette will cause error stoppage in auto-test 4603.

If the recalibration seek in step 004 or a write/read-verify fails, the test issues a start cycle steal command. If status indicates an improper FDD condition, an automatic branch to routine 4620 occurs to define the problem.

Use the instructions in para 3.6.1 or para 3.6.2, as applicable, to run the test.

NOTE

If the diskette in the FDD being tested is a CDC diskette (the BASIC diskette or a scratch diskette, the write-protect slot in the diskette jacket must be covered with opaque tape before this test is run.

CAUTION

If this test is run on the BASIC diskette, a malfunction may destroy program data. For a safeguard, do not run the test until the FDD auto-tests complete successfully.

001,002 Y N Wish to run this test and write on CE cylinders of
 : : diskette? If so, remove diskette, cover write-
 : : protect slot, and reinstall before answering.
 : : Enter 1 for yes, .0 for no.

003 : 1 No write commands were executed. Test 4611
 : terminated.

:
 2
 A

```

A
1
:
004 Y N Start command with DCB specifying recalibration
: : seek (head 0 to cylinder 00). CC = 0703 and
: : ISB = 00?
: :
005 : Y N Start cycle steal status command. CC = 0703
: : : and ISB = 00?
: : :
006 : : 1 Cycle steal status failed. Test aborted. Replace
: : attachment card. (1)
: :
007 : Y N Cycle steal status word 4 = XX00 and word 5 = 0000?
: : :
008 : : 1 Branch to test 4620 (SAM 4620).
: : :
009 : : 1 Incorrect condition code or interrupt status byte for
: : recalibration seek. Replace attachment card. (1)
: :
010 1 Delay for seek to end.
: :
011 Y N Start command with chained DCBs specifying seek to
: : cylinder 01 using head 0 and read sector ID.
: : CC = 0703, ISB = 00, and cylinder = 01?
: : :
012 : : 1 Incorrect condition code, interrupt status byte, or
: : cylinder for seek and read sector ID. Run auto-
: : test 4600 (SAM 4600).
: : :
013 Y N Start command with chained DCBs specifying write data
: : (random data) and data-address markers on cylinder 01
: : and then read-verify. CC = 0703 and ISB = 00?
: : :
: : 1 Go to step 091.
: :
014 Y N Start command with DCB specifying read data from
: : cylinder 01. CC = 0703 and ISB = 00?
: : :
015 : : 1 Incorrect condition code or interrupt status byte for
: : read data of fields with data-address markers.
: : Replace attachment card (1) and I/O cable (2) one at a
: : time.
: : :
016 Y N Start cycle steal status command. CC = 0703,
: : ISB = 00, and cycle steal status word 1 = 0000?
: : :
017 : : 1 Incorrect cycle steal status word 1. Replace attach-
: : ment card. (1)
: : :
: : :
: : :
3

```

A

A
2
:
018 Y N Start command with chained DCBs selecting head 1 and
: : specifying read sector ID. CC = 0703, ISB = 00, and
: : cylinder = 01?
:
019 : 1 Incorrect condition code, interrupt status byte, or
: : cylinder for seek and read sector ID. Run auto-
: : test 4600 (SAM 4600).
:
020 Y N Start command with chained DCBs specifying write data
: : (random data) and data-address markers on cylinder 01
: : and then read-verify. CC = 0703 and ISB = 00?
:
: 1 Go to step 091.
:
021 Y N Start command with DCB specifying read data from
: : cylinder 01. CC = 0703 and ISB = 00?
:
022 : 1 Incorrect condition code or interrupt status byte for
: : read data of fields with data-address markers.
: : Replace attachment card (1) and I/O cable (2) one at a
: : time.
:
023 Y N Start cycle steal status command. CC = 0703,
: : ISB = 00, and cycle steal status word 1 = 0000?
:
024 : 1 Incorrect cycle steal status word 1. Replace attach-
: : ment card. (1)
:
025 Y N Start command with chained DCBs specifying seek to
: : cylinder 02 using head 0 and read sector ID.
: : CC = 0703, ISB = 00, and cylinder = 02?
:
026 : 1 Incorrect condition code, interrupt status byte, or
: : cylinder for seek and read sector ID. Run auto-
: : test 4600 (SAM 4600).
:
027 Y N Start command with chained DCBs specifying write data
: : (random data) and control-address markers on cylin-
: : der 02 and then read-verify. CC = 0703 and ISB = 00?
:
: 1 Go to step 091.
:
028 Y N Start command with DCB specifying read data from
: : cylinder 02. CC = 0702 and ISB = 80?
:
029 : 1 Incorrect condition code or interrupt status byte for
: : read data of fields with control-address markers.
: : Replace attachment card (1) and I/O cable (2) one at a
: : time.

4

A

A
4
:
:
042 Y N Start command with DCB specifying read data from
: : cylinder 03. CC = 0703 and ISB = 00?
:
:
043 : 1 Incorrect condition code or interrupt status byte for
: read data of fields with data-address markers.
: Replace attachment card (1) and I/O cable (2) one at a
: time.
:
:
044 Y N Start cycle steal status command. CC = 0703,
: : ISB = 00, and cycle steal status word 1 = 0000?
:
:
045 : 1 Incorrect cycle steal status word 1. Replace attach-
: ment card. (1)
:
:
046 Y N Start command with chained DCBs selecting head 1 and
: : specifying read sector ID. CC = 0703, ISB = 00, and
: : cylinder = 03?
:
:
047 : 1 Incorrect condition code, interrupt status byte, or
: cylinder for seek and read sector ID. Run auto-
: test 4600 (SAM 4600).
:
:
048 Y N Start command with chained DCBs specifying write data
: : (random data) and data-address markers on cylinder 03
: : and then read-verify. CC = 0703 and ISB = 00?
:
:
: 1 Go to step 091.
:
:
049 Y N Start command with DCB specifying read data from
: : cylinder 03. CC = 0703 and ISB = 00?
:
:
050 : 1 Incorrect condition code or interrupt status byte for
: read data of fields with data-address markers.
: Replace attachment card (1) and I/O cable (2) one at a
: time.
:
:
051 Y N Start cycle steal status command. CC = 0703,
: : ISB = 00, and cycle steal status word 1 = 0000?
:
:
052 : 1 Incorrect cycle steal status word 1. Replace attach-
: ment card. (1)
:
:
053 Y N Start command with chained DCBs specifying seek to
: : cylinder 74 using head 0 and read sector ID.
: : CC = 0703, ISB = 00, and cylinder = 74?
:
:
054 : 1 Incorrect condition code, interrupt status byte, or
: cylinder for seek and read sector ID. Run auto-
: test 4600 (SAM 4600).
:
:
6

A

A
5

62947909

:
:
055 Y N Start command with chained DCBs specifying write data
: : (random data) and control-address markers on cylin-
: : der 74 and then read-verify. CC = 0703 and ISB = 00?
: :
: : 1 Go to step 091.
:
056 Y N Start command with DCB specifying read data from
: : cylinder 74. CC = 0702 and ISB = 80?
: :
057 : 1 Incorrect condition code or interrupt status byte for
: : read data of fields with control-address markers.
: : Replace attachment card (1) and I/O cable (2) one at a
: : time.
:
058 Y N Start cycle steal status command. CC = 0703,
: : ISB = 00, and cycle steal status word 1 = 1000?
: :
059 : 1 Incorrect cycle steal status word 1. Replace attach-
: : ment card. (1)
:
060 Y N Start command with chained DCBs selecting head 1 and
: : specifying read sector ID. CC = 0703, ISB = 00, and
: : cylinder = 74?
: :
061 : 1 Incorrect condition code, interrupt status byte, or
: : cylinder for seek and read sector ID. Run auto-
: : test 4600 (SAM 4600).
:
062 Y N Start command with chained DCBs specifying write data
: : (random data) and control-address markers on cylin-
: : der 74 and then read-verify. CC = 0703 and ISB = 00?
: :
: : 1 Go to step 091.
:
063 Y N Start command with DCB specifying read data from
: : cylinder 74. CC = 0702 and ISB = 80?
: :
064 : 1 Incorrect condition code or interrupt status byte for
: : read data of fields with control-address markers.
: : Replace attachment card (1) and I/O cable (2) one at a
: : time.
:
065 Y N Start cycle steal status command. CC = 0703,
: : ISB = 00, and cycle steal status word 1 = 1000?
: :
: :
: :
: :
: :
: :
7 7
A B WRITE/READ ADDRESS MARKER TEST (CONTD) SAM 4611-6

A
7
:
077 Y N Start command with DCB specifying read data from
: : cylinder 75. CC = 0703 and ISB = 00?
:
:
078 : 1 Incorrect condition code or interrupt status byte for
: read data of fields with data-address markers.
: Replace attachment card (1) and I/O cable (2) one at a
: time.
:
:
079 Y N Start cycle steal status command. CC = 0703,
: : ISB = 00, and cycle steal status word 1 = 0000?
:
:
080 : 1 Incorrect cycle steal status word 1. Replace attach-
: ment card. (1)
:
:
081 Y N Start command with chained DCBs specifying seek to
: : cylinder 76 using head 0 and read sector ID.
: : CC = 0703, ISB = 00, and cylinder = 76?
:
:
082 : 1 Incorrect condition code, interrupt status byte, or
: cylinder for seek and read sector ID. Run auto-
: test 4600 (SAM 4600).
:
:
083 Y N Start command with chained DCBs specifying write data
: : (random data) and control-address markers on cylin-
: : der 76 and then read-verify. CC = 0703 and ISB = 00?
:
:
: 1 Go to step 091.
:
:
084 Y N Start command with DCB specifying read data from
: : cylinder 76. CC = 0702 and ISB = 80?
:
:
085 : 1 Incorrect condition code or interrupt status byte for
: read data of fields with control-address markers.
: Replace attachment card (1) and I/O cable (2) one at a
: time.
:
:
086 Y N Start cycle steal status command. CC = 0703,
: : ISB = 00, and cycle steal status word 1 = 1000?
:
:
087 : 1 Incorrect cycle steal status word 1. Replace attach-
: ment card. (1)
:
:
088 Y N Start command with chained DCBs selecting head 1 and
: : specifying read sector ID. CC = 0703, ISB = 00, and
: : cylinder = 76?
:
:
089 : 1 Incorrect condition code, interrupt status byte, or
: cylinder for seek and read sector ID. Run auto-
: test 4600 (SAM 4600).
:
:
9

A

WRITE/READ ADDRESS MARKER TEST (CONTD)

SAM 4611-8

```

A
8
:
090 Y N Start command with chained DCBs specifying write data
: : (random data) and control-address markers on cylin-
: : der 76 and then read-verify. CC = 0703 and ISB = 00?
: :
091 : Y N Start cycle steal status command. CC = 0703 and
: : : ISB = 00?
: : :
092 : : 1 Cycle steal status failed. Test aborted. Replace
: : attachment card. (1)
: :
093 : Y N Cycle steal status word 4 = XX00 and word 5 = 0000?
: : :
094 : : 1 Branch to test 4620 (SAM 4620).
: :
095 : 1 Incorrect condition code or interrupt status byte for
: write data/read verify operation. Replace attachment
: card (1) and I/O cable (2) one at a time.
:
096 Y N Start command with DCB specifying read data from
: : cylinder 76. CC = 0702 and ISB = 80?
: :
097 : 1 Incorrect condition code or interrupt status byte for
: read data of fields with control-address markers.
: Replace attachment card (1) and I/O cable (2) one at a
: time.
:
098 Y N Start cycle steal status command. CC = 0703,
: : ISB = 00, and cycle steal status word 1 = 1000?
: :
099 : 1 Incorrect cycle steal status word 1. Replace attach-
: ment card. (1)
:
100 1 End of test. No error occurred.

```

(1) Set switches on new attachment card for FDD device address and IPL assignment (Installing Attachment Card and Cabling, section 2).

(2) Access FDD (para 3.1) and route new I/O cable per section 2 of this manual if a standalone unit or per section 2 of MMD site information manual if a combination unit.



This routine automatically executes when an improper condition is detected in the FDD auto-tests or in manual tests 4610 or 4611. If the previous test instructed that this routine be run, initiate routine manually by entering B4620. Sequentially, the routine:

- Displays (on assigned alternate console) the six cycle steal status words that were read from the attachment card during the previous test.
- Analyzes the FDD health parameters given in word 5 and if a failure is recorded, the routine stops and indicates the failure.
- If no failure is recorded in word 5, the routine continues and decodes the error-log byte (second byte) of word 4 and indicates the result. If necessary, an automatic branch to routine 4621 (SAM 4621) occurs to complete the decoding.

```

001 1 Display cycle steal status words on assigned alternate
    : console.
    :
002 Y N Mask word 5 with 8000. Bit 0 = 0?
    :
003 : 1 FDD not ready - door open, power not on, or diskette
    : speed 70 percent below normal. If FDD power is turned
    : on and door is closed, go to paper-only SAM 4672 (Not
    : Ready Status).
    :
004 Y N Mask word 5 with 2000. Bit 2 = 0?
    :
005 : 1 FDD I/O cable disconnected or open. Access FDD
    : (para 3.1) and check I/O cable connections at FDD PC
    : board and attachment card. If connections are OK,
    : replace I/O cable. (2)
    :
006 Y N Mask word 5 with 0200. Bit 6 = 0?
    :
007 : 1 +20 V from FDD power supply is low. Access FDD
    : (para 3.1) and check power cable connections at J7 on
    : power supply board and at attachment card. If connec-
    : tions are OK, go to paper-only SAM 4673 (Bad Power
    : Supply Voltages).
    :
008 Y N Mask word 5 with 0100. Bit 7 = 0?
    :
    :
    2 2
A B          CYCLE STEAL STATUS ANALYSIS ROUTINE      SAM 4620-1

```

```

A B
1 1
:
:
009 : 1 Attachment card +12-V power supply low. Replace
      : attachment card. (1)
      :
010 Y N Mask word 5 with 0800. Bit 4 = 0?
      :
011 : 1 Diskette speed too low. Access FDD (para 3.1) and
      : check that 104 to 127 V ac is present between brown
      : and blue (neutral) wires of B1P1 connector at right-
      : rear of FDD assembly. If voltage is OK, replace FDD
      : assembly (para 3.2); if voltage is bad, replace FDD
      : power supply (para 3.3).
      :
012 Y N Mask word 5 with 1000. Bit 3 = 0?
      :
013 : 1 Diskette speed too high. Replace FDD assembly
      : (para 3.2).
      :
014 Y N Mask word 5 with 0400. Bit 5 = 0?
      :
015 : 1 FDD write-fault latch stuck on. Replace FDD assembly
      : (para 3.2) and I/O cable (2) one at a time. After
      : replacement, run test 4610 (SAM 4610) to delete any
      : garbled or erased fields that may have been placed on
      : diskette by the malfunction. Otherwise, invalid read
      : errors of data or sector ID may occur in auto-tests
      : when verifying operation.
      :
016 Y N Mask word 5 with 0080. Bit 8 = 0?
      :
017 : 1 Attachment card reset latch stuck on. Replace attach-
      : ment card (1) and I/O cable (2) one at a time.
      :
018 Y N Mask word 5 with 0040. Bit 9 = 0?
      :
019 : 1 Attachment card test-mode latch stuck on. Replace
      : attachment card. (1)
      :
020 Y N Mask word 5 with 0020. Bit 10 = 0?
      :
021 : 1 Attachment card disk-initialize latch stuck on.
      : Replace attachment card. (1)
      :
022 Y N Mask word 5 with 0010. Bit 11 = 0?
      :
023 : 1 Attachment card write-fault reset latch stuck on.
      : Replace attachment card. (1)
      :
024 Y N Mask word 5 with 0002. Bit 14 = 0?
      :
      :
      :
3 3
A B CYCLE STEAL STATUS ANALYSIS ROUTINE (CONTD) SAM 4620-2

```



```

A B
3 3
: :
040 : 1 FDD write fault. Replace FDD assembly (para 3.2) and
: I/O cable (2) one at a time. After replacement, run
: test 4610 (SAM 4610) to delete any garbled or erased
: fields that may have been placed on diskette by the
: malfunction. Otherwise, invalid read errors of data
: or sector ID may occur in auto-tests when verifying
: operation.
:
041 Y N Error-log byte other than 0F?
: :
042 : 1 FDD seek error. Replace FDD assembly (para 3.2).
:
043 Y N Error-log byte other than 10?
: :
044 : 1 Sector ID field not found. Replace FDD assembly
: (para 3.2).
:
045 Y N Error-log byte other than 11?
: :
046 : 1 Data field not found. Replace FDD assembly
: (para 3.2).
:
047 Y N Error-log byte other than 12?
: :
048 : 1 Cyclic-redundancy-check error. Problem may be a bad
: diskette. Replace diskette and rerun previous test.
: If condition persists, replace FDD assembly (para 3.2).
:
049 Y N Error-log byte other than 13?
: :
050 : 1 Lost data in FDD controller chip on attachment card.
: Replace attachment card. (1) If malfunction occurred
: during write test 4610 or 4611, run test 4610
: (SAM 4610) after replacement. This deletes the
: garbled or erased fields that may have been placed on
: the diskette by the malfunction. Otherwise, invalid
: read errors of data or sector ID may occur in auto-
: tests when verifying operation.
:
051 Y N Error-log byte other than 1C?
: :
052 : 1 Command was received from processor during a malfunc-
: tion. Problem is identified in status word 5. Only
: bits 12 and 13 of word 5 have not been tested (FDD
: write-enable latch on attachment card either stuck set
: or clear following a write). Replace attachment card.
: (1) After replacement, run test 4610 (SAM 4610) to
: delete any garbled or erased fields that may have
: placed on diskette by the malfunction. Otherwise,
: invalid read errors of data or sector ID may occur in
: auto-tests when verifying operation.

```

5
A

A
4
:
053 Y N Error-log byte other than 1D?
:
054 : 1 DCB head byte differs with the head that is selected.
: Replace attachment card. (1)
:
055 Y N Error-log byte other than 1E?
:
056 : 1 Track register in FDD controller chip on attachment
: card did not load correctly. Replace attachment
: card. (1)
:
057 Y N Error-log byte other than 1F?
:
058 : 1 Attachment card disk-initialize latch failed to set
: for write-format operation. Replace attachment
: card. (1)
:
059 Y N Error-log byte other than 20?
:
060 : 1 Index detected before write-format operation completed
: track. Replace attachment card. (1) After replacement,
: run test 4610 (SAM 4610) to delete any garbled or
: erased fields that may have been placed on diskette by
: the malfunction. Otherwise, invalid read errors of
: data or sector ID may occur in auto-tests when veri-
: fying operation.
:
061 Y N Error-log byte other than 21?
:
062 : 1 Attachment card write-enable latch failed to set for
: write operation. Replace attachment card. (1)
:
063 Y N Error-log byte other than 22?
:
064 : 1 Attachment card write-enable latch failed to clear
: after write operation. Replace attachment card. (1)
: After replacement, run test 4610 (SAM 4610) to delete
: any garbled or erased fields that may have been
: placed on diskette by the malfunction. Otherwise,
: invalid read errors of data or sector ID may occur in
: auto-tests when verifying operation.
:
065 Y N Error-log byte other than 81?
:
066 : 1 Interface data check from Series/1 processor to
: attachment card. Replace attachment card. (1)
:
:
:
:
6

A

CYCLE STEAL STATUS ANALYSIS ROUTINE (CONTD)

SAM 4620-5

```

A
5
:
067 Y N Error-log byte other than 82?
:
:
068 : 1 Protect check for storage-access key given in DCB.
: Replace attachment card. (1)
:
:
069 Y N Error-log byte other than 83?
:
:
070 : 1 Invalid storage address thought to be given in DCB.
: Replace attachment card. (1)
:
:
071 Y N Error-log byte other than 84?
:
:
072 : 1 Storage data check. Data accessed from Series/1
: memory thought to be out of parity. Replace attach-
: ment card. (1) If condition persists, problem is in
: Series/1.
:
:
073 Y N Error-log byte other than 89?
:
:
074 : 1 Interface data check from attachment card to Series/1
: processor. Attachment card believes a parity error
: occurred on Series/1 I/O bus. Replace attachment
: card. (1) If condition persists, some other device
: attachment card is bad or problem is in Series/1.
:
:
075 Y N Error-log byte other than 23?
:
:
076 : 1 Last command was aborted by attachment card after
: 1.5-second timeout. Go to paper-only SAM 4672 (Not
: Ready Status).
:
:
077 1 Branch to routine 4621 (SAM 4621).

```

-
- (1) Set switches on new attachment card for FDD device address and IPL assignment (Attachment Card and I/O Cable Installation, section 2).
 - (2) Access FDD (para 3.1) and route new I/O cable per section 2 of this manual if a standalone unit or per section 2 of MMD site information manual if a combination unit.

A
 3
 :
 048 Y N Error-log byte other than 95?
 : :
 049 : 1 Odd storage address in DCB for start diagnostic 1
 : command. DCB decoded incorrectly. Replace attachment
 : card. (1)
 :
 050 Y N Error-log byte other than 96?
 : :
 051 : 1 Odd DCB address in IDCB for start diagnostic 2
 : command. IDCB decoded incorrectly. Replace attach-
 : ment card. (1)
 :
 052 Y N Error-log byte other than 98?
 : :
 053 : 1 Input flag bit set in start diagnostic 2 command. DCB
 : decoded incorrectly. Replace attachment card. (1)
 :
 054 Y N Error-log byte other than 99?
 : :
 055 : 1 Odd byte count in DCB for start diagnostic 2 command.
 : DCB decoded incorrectly. Replace attachment card. (1)
 :
 056 Y N Error-log byte other than 9A?
 : :
 057 : 1 Excessive byte count in DCB for start diagnostic 2
 : command. DCB decoded incorrectly. Replace attachment
 : card. (1)
 :
 058 Y N Error-log byte other than 9B?
 : :
 059 : 1 Odd storage address in DCB for start diagnostic 2
 : command. DCB decoded incorrectly. Replace attachment
 : card. (1)
 :
 060 Y N Error-log byte other than A3?
 : :
 061 : 1 Odd DCB address in IDCB for start cycle steal status
 : command. IDCB decoded incorrectly. Replace attach-
 : ment card. (1)
 :
 062 Y N Error-log byte other than A5?
 : :
 063 : 1 Input flag bit not set in start cycle steal status
 : command. DCB decoded incorrectly. Replace attachment
 : card. (1)
 :
 064 Y N Error-log byte other than A6?
 : :
 : :
 : :
 : :
 5 5
 A B

CONTINUATION OF CYCLE STEAL
 STATUS ANALYSIS (CONTD)

SAM 4621-4

A	B	
4	4	
:	:	
065	<u>1</u>	Odd byte count in DCB for start cycle steal status command. DCB decoded incorrectly. Replace attachment card. (1)
:	:	
066	Y N	Error-log byte other than A7?
:	:	
067	<u>1</u>	Excessive byte count in DCB for start cycle steal status command. DCB decoded incorrectly. Replace attachment card. (1)
:	:	
068	Y N	Error-log byte other than A8?
:	:	
069	<u>1</u>	Odd storage address in DCB for start cycle steal status command. DCB decoded incorrectly. Replace attachment card. (1)
:	:	
070	<u>1</u>	No error or failure reported in cycle steal status. Rerun previous test that was in process. If condition persists, replace attachment card. (1)

(1) Set switches on new attachment card for FDD device address and IPL assignment (Installing Attachment Card and Cabling, section 2).

(2) Access FDD (para 3.1) and route new I/O cable per section 2 of this manual if a standalone unit or per section 2 of MMD site information manual if a combination unit.

1 2 3 4 5 6 7 8 9 10

11 12 13 14 15 16 17 18 19 20



- 1 1 1 1 BONES-ON WND ... 00W 1210-3
- 009 : : : 2 Problem may be a bad diskette. Replace BASIC
: : : diskette and try to IPL again.
- 010 : : : 3 Replace attachment card (1) and try to IPL again.
- 011 : : : 4 Replace FDD assembly (para 3.2) and I/O cable (2)
: : : one at a time.
- 012 : : : 5 Problem is in Series/1.
- 013 : : : 1 Go to paper-only SAM 4671 (IPL Fault Isolation).
- 014 : 1 Open FDD door and turn off FDD and Series/1. Reseat
: : attachment card and check that primary/alternate
: : setting of IPL-selection switches on attachment card
: : match setting of IPL Source switch (refer to Install-
: : ing Attachment Card and Cabling, section 2, for
: : attachment card switch assignments). Try to IPL
: : again. If condition occurs again, replace attachment
: : card. (1)
- 015 : 2 Probable problem in Series/1 I/O bus or operator/
: programmer panel.
- 016 1 Check that red LED on attachment card is extinguished.
: If LED is lit, replace attachment card. (1)
- 017 2 If system contains another IPL device, open FDD door,
: turn off Series/1 and other IPL device, and disconnect
: that device attachment card from Series/1. Try to IPL
: again. If IPL is successful, other device either has
: same primary/alternate IPL assignment as FDD or attach-
: ment card for that device is bad.
- 018 3 Check that +5 \pm 0.5 V is present on Series/1 I/O bus
: (Installing Attachment Card and Cabling, section 2).
: If voltage is bad and cannot be adjusted, check
: voltage with attachment card removed. If voltage is
: OK with attachment card removed, replace attachment
: card (1); if voltage remains bad with attachment card
: removed, problem is in Series/1.
- 019 4 Probable problem in Series/1 processor or operator/
: programmer panel. If not already done, replace
: attachment card (1) to verify problem is in Series/1.

- A B
 1 1
 : :
 020 : 1 If spindle motor (top motor on FDD) is running, drive
 : : belt is off spindle. Reinstall or replace drive belt
 : : (para 3.4).
 : :
 021 : 2 Check that 104 to 127 V ac is present between brown and
 : : blue (neutral) wires of B1P1 connector at right-rear of
 : : FDD assembly. If voltage is bad, replace power supply
 : : (para 3.3).
 : :
 022 : 3 Replace FDD assembly (para 3.2).
 : :
 023 1 Check if circuit breaker on FDD power supply is tripped.
 : If so, leave breaker off and disconnect following
 : connectors:
 :
 : ● 3-pin B1P1 from right side of FDD assembly
 :
 : ● 7-pin B1P4 from FDD PC board
 :
 : ● 3-pin attachment power cable from J7 on power supply
 : board
 :
 : ● 2-pin LED power cable from J6 on FDD power supply
 : board

Identify short through following steps:

Steps	Replace if Breaker Trips
a. Turn breaker on.	FDD power supply (para 3.3).
b. Turn breaker off. Connect B1P1 and B1P4 connectors. Turn breaker on.	FDD assembly (para 3.2)
c. Turn breaker off. Connect LED power cable to J6. Turn breaker on.	On/Off-switch box (para 3.5)
d. Turn breaker off. Connect attachment power cable to J7. Turn breaker on.	Sequentially: attachment card (1), attachment power cable (2)

- 024 2 Check for +1.5 V between J6-1 and return J6-2 on FDD
 : power supply board. If voltage is present, replace
 : On/Off-switch box (para 3.5).

025 : : 3
 4 : : :

A

62947909 B

3

ILLUSTRATION PROVIDED BY THE MANUFACTURER

025 3 Press On/Off switch to Off and disconnect ac power cable
: from front of FDD power supply. Press On/Off switch to
: On and check that ac input (120 or 208/230 V ac) is
: present between black and white wires of power cable
: (white wire is neutral for 120 V ac). If voltage is
: not present, replace On/Off-switch box (para 3.5).

026 4 Check that following wires are secure in 12-pin B1P2
connector on right side of FDD power supply. If wires
are OK, replace power supply (para 3.3).

- o 120-V ac unit - brown circuit breaker wires in pins 4, 9, and 12; blue jumper wires in pin 1 to pin 11 and pin 11 to pin 6.

010

- 208-V ac unit - brown circuit breaker wires in pins 7 and 12; blue jumper wires in pin 1 to pin 11 and pin 3 to pin 6.

- 230-V ac unit - brown circuit breaker wires in pins 9 and 12; blue jumper wires in pin 4 to pin 6 and pin 1 to pin 11.

(1) Set switches on new attachment card for FDD device address and IPL assignment (Installing Attachment Card and Cabling, section 2).

(2) Route new I/O cable or attachment power cable per section 2 of this manual if a standalone unit or per section 2 of MMD site information manual if a combination unit.

A
1 V E
: S S

62947909
MOL KEYVA 207502 27W 1815-7

011 1 : Verify that the following items are OK. If not, correct
: and try to IPL again.

- 003 : A W
- Check connections of I/O cable at attachment card and FDD and connections of power cable at attachment card and FDD power supply. Also verify that all connectors on FDD PC board are secure.
 - Check that drive belt on left side of FDD has not slipped off spindle. If so, reinstall or replace drive belt (para 3.4).
 - Verify that switches 1 and 5 on FDD PC board are pressed down in ON position and that other switches are pressed to OFF.

012 2 Check following voltages. If any are bad, go to
: SAM 4673 (Bad Power Supply Voltages).

- +5 +0.25 V between J4-2 and return J4-3 on FDD PC board
- +24 +2.4 V between J4-4 and return J4-6 on FDD PC board
- +20 +2.4 V between return J7-2 and J7-1 and J7-3 on FDD power supply board
- 104 to 127 V ac between brown and blue (neutral) wires of B1Pl connector at right-rear of FDD assembly

013 3 Replace attachment card (1), FDD assembly (para 3.2),
I/O cable (2), and attachment power cable (2) one at
a time until IPL is successful.

(1) Set switches on new attachment card for FDD device address and IPL assignment (Installing Attachment Card and Cabling, section 2).

(2) Route new I/O cable or attachment power cable per section 2 of this manual if a standalone unit or per section 2 of MMD site information manual if a combination unit.

This paper-only SAM is to be used when instructed by a diagnostic test or when the diagnostics do not load or execute correctly. The SAM assumes that FDD power was turned on and door was closed when the diagnostics were in process.

Instructions: Access FDD (para 3.1).

001 Y N Turn on power. LED on front panel lights and spindle motor runs?

002 : 1 Circuit breaker on FDD power supply is tripped. Leave breaker off and disconnect following connectors:

- 3-pin B1P1 from right side of FDD assembly
- 7-pin B1P4 from FDD PC board
- 3-pin attachment power cable from J7 on power supply board
- 12-pin LED power cable from J6 on FDD power supply board

Identify short through following steps:

Steps	Replace if Breaker Trips
a. Turn breaker on.	FDD power supply (para 3.3)
b. Turn breaker off. Connect B1P1 and B1P4 connectors. Turn breaker on.	FDD assembly (para 3.2)
* c. Turn breaker off. Connect LED power cable to J6. Turn breaker on.	On/Off-switch box (para 3.5)
* d. Turn breaker off. Connect attachment power cable to J7. Turn breaker on.	Sequentially: attachment card (1), attachment power cable (2)

003 Y N Diskette rotates when door is closed?

2 2
A B NOT READY STATUS SAM 4672-1
03241300

A B

62947909

- 1 1
:
:
004 : 1 Drive belt has slipped off spindle. Reinstall or
: replace drive belt (para 3.4).
:
005 1 If diagnostics are being loaded from a different FDD
: than the one being tested, verify that the following
: items on test unit are OK. If not, correct and rerun
: diagnostic tests.
006 :
: • Check connections of I/O cable at attachment
: card and FDD. Also check that all connectors
: on FDD PC board are secure.
: • Verify that switches 1 and 5 on FDD PC board
: are pressed down in ON position and that other
: switches are pressed to OFF.
006 Y N Check following voltages. Are they OK?
:
: • +5 +0.25 V between J4-2 and return J4-3 on FDD
: PC board
:
: • +24 +2.4 V between J4-4 and return J4-6 on FDD
: PC board
:
: • +20 +2.4 V between return J7-2 and J7-1 and J7-3
: on FDD power supply board
:
: • 104 to 127 V ac between brown and blue (neutral)
: wires of B1P1 connector at right-rear of FDD
: assembly
:
007 : 1 Go to paper-only SAM 4673 (Bad Power Supply Voltages).
:
008 1 Replace FDD assembly (para 3.2) and rerun diagnostic
: tests. If same error stoppage occurs, replace attach-
: ment card (1), I/O cable (2), and attachment power
: cable (2) one at a time.

-
- (1) Set switches on new attachment card for FDD device address and IPL assignment (Installing Attachment Card and Cabling, section 2).
 - (2) Route new I/O cable or attachment power cable per section 2 of this manual if a standalone unit or per section 2 of MMD site information manual if a combination unit.

A B

1 1

010 : 3 Determine whether power supply or a load fault is causing low +24 V:

NOTE:

a. Turn power off and disconnect following cables:

NOTE: VERIFY IF A RESISTOR OR A DIODE IS SHORTED IN THE FOLLOWING LIST

(1) 7-pin B1P4 from J4 on FDD PC board

(2) 2-pin LED power cable from J6 on power supply board

(3) 3-pin attachment power cable from J7 on power supply board

b. Turn power on and remeasure for +24 \pm 2.4 V between pin 4 and return pin 6 of B1P4 connector. If voltage is still low, replace power supply (para 3.3).

011 : 4 Isolate load fault - turn power off and reconnect cables in following order until +24 V between B1P4-4 and B1P4-6 goes low. Turn power off while making connections.

Connect	Replace if +24 V Goes Low
Attachment power cable	Attachment card (1)
LED power cable	On/Off-switch box (para 3.5)
Not applicable	FDD assembly (para 3.2)

012 : 3 Determine whether power supply or a load fault is causing low +5 V:

a. Turn power off. Disconnect 7-pin B1P4 connector from J4 on FDD PC board and 2-pin LED power cable from J6 on power supply board.

b. Turn power on and remeasure for +5 \pm 0.25 V between pin 2 and return pin 3 of B1P4 connector. If voltage is still low, replace power supply (para 3.3).

3

A

A
2
:
4

013 4 Isolate load fault:

- a. Turn power off and reconnect LED power cable to J6 on power supply board.
- b. Turn power on and check if +5 V between B1P4-2 and B1P4-3 went low. If so, replace On/Off-switch box (para 3.5); if voltage is still OK, replace FDD assembly (para 3.2).

LED power cable	FDD assembly (para 3.2)
On/Off-switch box	On/Off-switch box (para 3.5)
Attachment card (1)	Attachment card (1)

connections:
 and B1P4-2 does not. Turn power off until power is removed
 cables in following order until +5V is present B1P4-2
 restore power fault - turn power off and reconnect.

assembly (para 3.3).
 for. If voltage is still low, replace power
 removed and if not return bit 2 of B1P4 connect.
 p. Turn power on and recheck for +5V +5.4 V

- (1) Set switches on new attachment card for FDD device address and IPL assignment (Installing Attachment Card and Cabling section 2) flow to on power assembly
- (2) Route new attachment power cable per section 2 of this manual if a standalone unit or per section 2 of MMD site information manual if a combination unit.

contains low +5V A:
 determine whether power assembly or a test fault is

FLORIDA 100

ALL INFORMATION CONTAINED HEREIN IS UNCLASSIFIED

NO/0 ON/OOL/ED /P/ER /M/D /L/YN/

NO FURTHER INFORMATION IS REQUIRED TO OBTAIN



COMMENT SHEET

MANUAL TITLE: 80210-10/80240 Flexible Disk Drive
Hardware Maintenance Manual (Site Information)

PUBLICATION NO.: 62947909

REVISION: B

NAME: _____

COMPANY: _____

STREET ADDRESS: _____

CITY: _____ **STATE:** _____ **ZIP CODE:** _____

This form is not intended to be used as an order blank. Control Data Corporation welcomes your evaluation of this manual. Please indicate any errors, suggested additions or deletions, or general comments below (please include page number references).

CUT ALONG LINE

AA3419 REV. 4/79 PRINTED IN U.S.A.

NO POSTAGE STAMP NECESSARY IF MAILED IN U.S.A.


FOLD ON DOTTED LINES AND STAPLE

STAPLE

STAPLE

FOLD

FOLD



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY MAIL
FIRST CLASS PERMIT NO. 8241 MINNEAPOLIS, MINN.

POSTAGE WILL BE PAID BY

CONTROL DATA CORPORATION

Publications and Graphics Division
2200 Berkshire Lane
Plymouth, MN 55441



CUT ALONG LINE

FOLD

FOLD



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY MAIL
FIRST CLASS PERMIT NO. 8241 MINNEAPOLIS, MINN.

POSTAGE WILL BE PAID BY
CONTROL DATA CORPORATION
Publications and Graphics Division
2500 Beckman Lane
Blymouth, MN 55441

NO POSTAGE

NECESSARY



**CORPORATE HEADQUARTERS, P.O. BOX 0, MINNEAPOLIS, MINNESOTA 55440
SALES OFFICES AND SERVICE CENTERS IN MAJOR CITIES THROUGHOUT THE WORLD**