




**CDC® 722-10/20 DISPLAY TERMINAL
CC628-A**



**HARDWARE MAINTENANCE MANUAL
(SITE INFORMATION)**

REVISION RECORD

REVISION	DESCRIPTION
A (10-01-80)	Manual released. Includes changes per ECO 14104, 14037, 14147, 14241, 14257, and 14262.
B (11-25-80)	Interim change to incorporate ECO 14353.
C (11-26-80)	Manual revised to incorporate ECO 14353 in its final form.
D (01-21-81)	Manual revised to incorporate procedure changes, to provide a switch setting record, and to update spare parts list per ECO's 14294, 14401, and 14431.
E (02-11-81)	Interim change to incorporate ECOs 14461, 14503, and 14530. Also adds appendix B.
F (04-07-81)	Manual revised to incorporate ECO 14530 in its final form and to make editorial and technical corrections.
G (05-07-81)	Interim change - manual revised to incorporate ECO 14675.
H (06-01-81)	Manual revised to incorporate ECO 14675 in its final form.
J (06-25-81)	Interim change - manual revised to incorporate ECO 14640.
K (07-06-81)	Interim change - manual revised to incorporate ECO 14753.
L (09-18-81)	Manual revised to incorporate ECO 14761 and finalize ECO's 14640 and 14753.

Publication No.

01989-2

62940003

REVISION LETTERS I, O, Q AND X ARE NOT USED

© 1980, 1981
by Control Data Corporation
Printed in the United States of America

Address comments concerning this manual to:

Control Data Corporation
Technical Publications Department
2401 North Fairview Avenue
St. Paul, Minnesota 55113

or use Comment Sheet in the back of this manual.

MANUAL TO EQUIPMENT LEVEL CORRELATION SHEET

This manual reflects the equipment configurations listed below.

EXPLANATION: Locate the equipment type and series number, as shown on the equipment FCO log, in the list below. Immediately to the right of the series number is an FCO number. If that number and all of the numbers underneath it match all of the numbers on the equipment FCO log, then this manual accurately reflects the equipment.

EQUIPMENT TYPE	SERIES	WITH FCO'S	COMMENTS
CC628-A	01	<div style="border: 1px solid black; display: inline-block; padding: 2px;">14353</div>	-- All units reworked to series 05 by ECO 14530
	02		
	03		
	04		
	05	-	ECO 14675 only (S/N 1016)
	06	-	ECO 14640 only (S/N 1550)
	07	14753	ECO 14753
	07	-	ECO 14671 only (S/N 2601)
08			

01987

000

0

0

0

0

0

LIST OF EFFECTIVE PAGES

New features, as well as changes, deletions, and additions to information in this manual are indicated by bars in the margins or by a dot near the page number if the entire page is affected. A bar by the page number indicates pagination rather than content has changed.

PAGE	REV	PAGE	REV	PAGE	REV
Cover	-	5A-1/5A-2	A		
Title Page	-	5A-3	F		
ii thru vi	L	5A-4/5A-5	A		
vii/viii	H	5B-1	A		
ix and x	F	5B-2	D		
xi/xii	D	5B-3	A		
1-1	G	5B-4/5B-5	D		
1-2	A	5B-6/5B-7	A		
1-3	F	5B-8/5B-9	D		
2-1	L	5B-10 thru 5B-12	K		
2-2	G	5B-13 thru 5B-16	E		
2-3	A	5B-17/5B-18	A		
2-4	K	6-1	A		
2-5	C	6-2 and 6-3	L		
2-6	K	A-1	K		
2-7 and 2-8	A	A-2	D		
2-9	H	B-1 thru B-4	H		
3-1 thru 3-4	A	Comment Sheet	L		
3-5	F	Mailer	-		
3-6	G	Back Cover	-		
3-7 thru 3-9	H				
4-1	A				
4-2	D				
5-1 thru 5-4	A				
5-5	K				
5-6	F				
5-7	E				
5-8	D				
5-9	G				
5-10/5-11	C				

02092-1A



PREFACE

This manual provides information to aid in the installation, checkout, and on-site maintenance of the CDC® 722-10/20 Display Terminal. It is assumed that the customer engineer has knowledge of basic terminal operations and use of common maintenance tools and test equipment.

Information is organized under the following section headings:

- Section 1 - General Description
- Section 2 - Operation
- Section 3 - Installation and Checkout
- Section 4 - Diagrams
- Section 5 - Maintenance
- Section 5A - SAM Listings
- Section 5B - Maintenance Procedures
- Section 6 - Parts Data
- Appendix A - Special Cables for Use with Terminal
- Appendix B - Generating Commands in Advanced/752 Mode

Other manuals providing reference and component level maintenance information on the terminal are listed as follows. All manuals may be ordered from:

Control Data Corporation
Literature and Distribution Services
308 North Dale Street
St. Paul, Minnesota 55103

<u>Title</u>	<u>Publication Number</u>
722-10/20 Display Terminal Reference Manual	62940001
722-10/20 Display Terminal Operators Guide/ Installation Instructions	62940002
722-10/20 Display Terminal Hardware Maintenance Manual (Support Information)	62940004

00

0

0

0

0

0

CONTENTS

1. GENERAL DESCRIPTION

Physical Description	1-1
Functional Description	1-2
Equipment Specifications	1-3

2. OPERATION

Operating Controls and Switches	2-1
Power On/Off Switch	2-2
Circuit Breaker (CB1)	2-2
Voltage Select Switch	2-2
Brightness Control	2-2
TEXT/NORMAL Switch	2-2
Open Connections	2-3
Shorted Connections	2-3
Control Switches	2-3
DATA RATE SELECT Switches	2-3
PAR EVEN/PAR ODD Switch	2-3
ROLL/PAGE Switch	2-4
FULL DUP/HALF DUP Switch	2-5
ON LINE/LOCAL Switch	2-5
MANUAL RELEASE Switch	2-5
Mode Select Switches	2-5
NORMAL/TRANSPARENT Switch	2-6
NORMAL/DATA ONLY Switch	2-6
PARITY ENABLE/PARITY DISABLE Switch	2-6
1 STOP BIT/2 STOP BITS Switch	2-7
NORMAL/AUTO LF Switch	2-7
DISABLE BELL/EOL BELL Switch	2-7
RTS CONSTANT/RTS SWITCHED Switch	2-8
DTR CONSTANT/DTR SWITCHED Switch	2-8
60 HZ REFRESH/50 HZ REFRESH Switch	2-8
Keyboard Functions	2-8
Keyboard Indicators	2-9

3. INSTALLATION AND CHECKOUT

Packaging	3-1
Installation	3-1
Installation Requirements	3-1
Installation Instructions	3-4
Checkout	3-8

4. DIAGRAMS

Interconnection Diagram, (Viking TTY Display Terminal 50/60 Hz)	4-2
--	-----

5. MAINTENANCE

General Maintenance Information 5-1
Suggested Emergency Maintenance Procedure 5-1
 Before Leaving For Customer Site 5-2
 Upon Arriving At Customer Site 5-2
Safety Precautions 5-3
Maintenance Tools and Materials 5-3
MOS Circuit-Handling Precautions 5-3
Maintenance Aids 5-4
Location of Major Assemblies 5-4
Internal Controls and Fuses 5-4
 Monitor PC Board 5-4
 Yoke Assembly 5-6
 Logic/Power Supply Board 5-6
Diagnostic and Corrective Maintenance 5-6
 Diagnostic Self-Test Routines 5-7
 Power-On Test 5-7
 System Level Test 5-7
 Transparent Mode Test 5-8
 Explanation of SAM Format 5-10
 Organization of SAMs and Procedures 5-11
 SAM CRT1 Power Fault Isolation 5A-1
 SAM CRT2 Monitor/Control Problems 5A-3
 SAM CRT3 Diagnostic Self-Test Errors 5A-5
 Procedure CRT1 - Power Application/Removal 5B-1
 Procedure CRT2 - Hood Removal/Replacement 5B-1
 Procedure CRT3 - Video Adjustments 5B-2
 Procedure CRT4 - Monitor PC Board Replacement 5B-4
 Procedure CRT5 - Yoke Replacement 5B-6
 Procedure CRT6 - High-Voltage Assembly
 Replacement 5B-7
 Procedure CRT7 - CRT Replacement 5B-8
 Procedure CRT8 - Logic/Power-Supply Board
 Replacement 5B-10
 Procedure CRT9 - Keyboard Assembly Replacement 5B-12
 Procedure CRT10 - BRIGHTNESS Control Checks/
 Replacement 5B-13
 Procedure CRT11 - Switch-Panel Assembly
 Replacement 5B-14
 Procedure CRT12 - Keyboard Switch Module
 Replacement 5B-15
 Procedure CRT13 - AC Short-Circuit Isolation 5B-17

6. PARTS DATA

Viking TTY Display Terminal SPL 6-2

APPENDIXES

A. SPECIAL CABLES FOR USE WITH TERMINAL A-1
B. GENERATING COMMANDS IN ADVANCED/752 MODE B-1

FIGURES

1. GENERAL DESCRIPTION

1-1	Display Terminal	1-1
1-2	Simplified Terminal Block Diagram	1-2

2. OPERATION

2-1	Location of Operating Controls and Switches . .	2-1
2-2	Front Panel Control Switches	2-4
2-3	Keyboard Indicators	2-9

3. INSTALLATION AND CHECKOUT

3-1	Display Terminal Packaging Instructions	3-2
3-2	Logic/Power Supply Module Packaging Instructions	3-3
3-3	Front-Panel Switch Setting Record	3-5
3-4	NORMAL/CURRENT LOOP Jumper Location	3-7
3-5	Cursor Home Position Jumper Location	3-7
3-6	I/O Connector Locations	3-8

5. MAINTENANCE

5-1	Location of Major Assemblies	5-5
5-2	ROM Character Display Example	5-9
5-3	Switch Panel Test Presentation Order	5-10
5-4	SAM Example	5-11
CRT1	Power On/Off Switch and Hood Mounting Screws . .	5B-1
CRT2	Monitor Adjustment Controls	5B-4
CRT3	Monitor PC Board Mounting Details	5B-5
CRT4	Yoke Assembly Details	5B-7
CRT5	CRT Replacement Details	5B-9
CRT6	Logic/Power Supply Board Mounting Details . .	5B-11
CRT7	Keyboard Assembly Mounting Details	5B-12
CRT8	BRIGHTNESS Control Mounting Details	5B-14
CRT9	Switch Panel Assembly Mounting Details	5B-15
CRT10	Keyboard Switch Module Mounting Details	5B-16

TABLES

1. GENERAL DESCRIPTION

1-1	Equipment Specifications	1-3
-----	------------------------------------	-----



This section provides a brief physical and functional description of the CC628-A Display Terminal including the related equipment specifications. Refer to the associated manuals listed in the preface for detailed information.

The terminal provides asynchronous character-by-character transmission in a manner consistent with teletypewriter conventions. Communication line coding is compatible with the CDC® 752 CRT Display Terminal and also can be set to operate in advanced (ADV) mode for extended control functions.

PHYSICAL DESCRIPTION

The display terminal, figure 1-1, is a remotely located micro-processor controlled input/output device. The terminal contains a 12-inch (diagonal measurement) crt and associated drive electronics, refresh memory, symbol generation and control logic, an alphanumeric keyboard, an asynchronous RS-232-C/CCITT V.24 voltage interface, and a 20-mA current-loop interface. The current loop interface RS232 selection requires internal adjustments requiring a field service engineer. The terminal may be ordered from the factory configured for either operating mode. Interface connectors are provided for external communication with a host processor and a receive-only printer.





Figure 1-1. Display Terminal

FUNCTIONAL DESCRIPTION

A simplified block diagram of the terminal is shown in figure 1-2. The keyboard provides for operator entry of alphanumeric characters and terminal function and control codes. All 128 ASCII X3.4 codes, plus 46 code sequences can be generated. The logic/power-supply module provides the internal timing and control for display raster generation, character generation, refresh memory functions, keyboard data encoding, and I/O interface functions. This module also contains the power supply, rectifiers, and regulators for the various internal dc voltages. The display module is a crt video display device that uses a raster scan technique to produce a noninterlaced horizontal scan of 300/360 lines at a vertical refresh rate of 60/50 Hz.



03901

Figure 1-2. Simplified Terminal Block Diagram

EQUIPMENT SPECIFICATIONS

The equipment specifications for the display terminal are listed in table 1-1.

TABLE 1-1. EQUIPMENT SPECIFICATIONS

CHARACTERISTIC	SPECIFICATION
Dimensions:	
Height	376 mm (14.8 in)
Width	429 mm (16.9 in)
Depth	533 mm (21 in)
Weight:	
Uncrated	16.78 kg (37 lb)
Crated	19.9 kg (44 lb)
Power Requirements: (Nominal)	120/220/240 V ac, 50/60 Hz, at 0.6 A (120 V) or 0.3 A (220/240 V), 70 W maximum
Temperature:	
Operating	10°C to 40°C (50°F to 104°F)
Nonoperating	-40°C to 60°C (-40°F to 140°F)
Change/h	8°C (18°F)
Relative Humidity:	
Operating	20% to 80%
Nonoperating	5% to 100%
Change/h	10%
Operating Altitude:	3000 m (9850 ft) maximum
Heat Dissipation (Air):	240 Btu/h (70 W) maximum, convection cooled
Display Format:	24 lines, 80 characters per line
Display Area: (Nominal)	216 mm (8.5 in) wide by 152 mm (6 in) high
Refresh Rate:	50 Hz or 60 Hz, switch selectable
Display Memory Size:	1920 characters
Transmission Speeds:	110, 150, 200, 300, 600, 1200, 1800, 2400, 4800, 9600, and 1 9200 baud; switch selectable



This section describes the operating controls and switches, keyboard functions, and keyboard indicators of the display terminal. Information on maintenance controls, and related adjustments is contained in section 5 under the specific adjustment procedure requiring their use. Internal control jumpers are described in section 3, Installation.

OPERATING CONTROLS AND SWITCHES

Figures 2-1 and 2-2 show the location of the various operating controls and switches. The following paragraphs describe their basic function. Refer to the terminal reference manual for a more detailed description (see preface for publication number).




Figure 2-1. Location of Operating Controls and Switches

POWER ON/OFF SWITCH

The power on/off switch controls the application of ac input power to the display terminal. Power is applied by pulling the switch lever forward (red-orange stripe on switch lever visible). Power is removed by pushing the switch lever in. Power application automatically initiates the self-test feature.

CIRCUIT BREAKER (CBI)

Circuit breaker (CBI) provides overload protection for the display terminal. The circuit breaker is thermally actuated and when tripped (circuit open) a red plunger is extended. The circuit breaker is reset by pressing the plunger in.

VOLTAGE SELECT SWITCH

The Voltage Select switch is used to select the appropriate tap of the power transformer for the ac voltage available at the site power outlet. The switch has three positions marked 120 V, 220 V, and 240 V. The 120-V position is for primary power between 104 and 128 V; the 220-V position for between 191 and 235 V; and the 240-V position for between 208 and 256 V. After a snap-in cover is removed, the switch can be set using a straight slot screwdriver while the terminal is tipped to one side. The factory setting is 120 V.

BRIGHTNESS CONTROL

The BRIGHTNESS control provides for video intensity adjustment to compensate for various ambient lighting conditions.

TEST/NORMAL SWITCH

The TEST/NORMAL switch, when positioned to the TEST position, connects the RS-232-C/CCITT V.24 interface signals together such that transmitted data is looped back as received data. With the terminal in online mode, this causes keyboard data to be transferred to the switch and returned via the receive circuits at the selected baud rate. Proper operation of the terminal in half duplex results in two characters being displayed for each alphanumeric character entered. Operation in full duplex results in a single character entry. No data transfers to the modem. Loop test is inoperative if current loop is selected.

The TEST position (switch positioned toward rear of terminal) of this switch alters the modem signal connections as follows:

Open Connector Pins

Send Data (pin 2)
Received Data (pin 3)
Request to Send (pin 4)

Clear to Send (pin 5)
Data Set Ready (pin 6)
Received Line Signal
Detector (pin 8)

Shorted Signal Lines

Send Data to Received Data
Request to Send to Clear to Send
Data Set Ready to Received Line Signal Detector to Data Terminal
Ready

Placing this switch to the NORM position (switch positioned toward front of terminal) restores the signal connections to their proper pins.

CONTROL SWITCHES

The various control switches of the display terminal are shown in figure 2-2. The control functions and operating characteristics established by these switches are as follows:

DATA RATE SELECT Switches

There are four DATA RATE SELECT switches used to select one of eleven different baud rates noted on the decal.

PAR EVEN/PAR ODD Switch

Placing this switch to the PAR EVEN position causes the display terminal to generate, and test for, even word parity. Positioning this switch to PAR ODD causes the display terminal to generate, and test for, odd word parity.

The function of this switch is altered when the PARITY ENABLE/PARITY DISABLE switch is in the PARITY DISABLE position (described under Mode Select Switches heading).




Figure 2-2. Front Panel Control Switches

ROLL/PAGE Switch

When this switch is in the ROLL position, the scroll feature is enabled. When this switch is in the PAGE position, the scroll feature is disabled. ADV mode operation changes the functions of this switch and the display terminal remains in scroll mode unless a scroll disable command is received.

The ROLL/PAGE switch is used to enable or disable the page print feature when the terminal is conditioned to ADV mode. Positioning the switch to PAGE enables the page print. The page print is disabled if the switch is positioned to ROLL.

FULL DUP/HALF DUP Switch

The FULL DUP/HALF DUP switch determines how keyboard input data is routed within the terminal during online operation. Modem operation is not affected.

- In the FULL DUP position, data is sent to the modem only.
- In the HALF DUP position, data is sent to both the modem and display memory. Data is displayed or acted upon in the same manner as if received from the modem.

ON LINE/LOCAL Switch

With the ON LINE/LOCAL switch in the LOCAL position, the terminal operates offline. This allows checking the operation of the terminal without communicating with the modem. The transmit circuits are disabled and keyboard data is displayed on the crt.

In the ON LINE position, keyboard data is transferred to the interface as keys are pressed. A 3-character internal buffer compensates for sporadic typing speeds in excess of the transmission line character rate.

MANUAL RELEASE Switch

The MANUAL RELEASE switch is a momentary action pushbutton switch. Pressing this switch reinitializes terminal operation and if TRANSPARENT mode is selected, initiates the transparent mode test routine. Screen data is unaffected unless the transparent mode test is initiated. A print operation is terminated if active and the keyboard is unlocked if previously locked.

MODE SELECT SWITCHES

The basic functions of the various mode select switches are described in the following paragraphs. Refer to figure 2-2 for switch locations.

NORMAL/TRANSPARENT Switch

When this switch is in the NORMAL position, all codes are stored, displayed, or acted upon as required for normal system operation.

When this switch is in the TRANSPARENT position, the terminal stores and displays all codes. No control code functions are performed other than storage and display of the code.

NORMAL/DATA ONLY Switch

When this switch is in the NORMAL position, the terminal inhibits transmitted data if either Data-Set-Ready or Clear-to-Send are off. Data-Set-Ready must be on in order to recognize received data. If RTS SWITCHED is enabled, the Received-Line-Signal-Detector must also be on in order to copy received data.

When this switch is in the DATA ONLY position, the terminal disregards the RS-232-C/CCITT V.24 modem control signals. Data-Terminal-Ready operates normally.

PARITY ENABLE/PARITY DISABLE Switch

In the PARITY ENABLE position, the terminal generates and tests for word parity as previously described under the PAR EVEN/PAR ODD switch functions.

Placing this switch in the PARITY DISABLE position disables the parity-checking logic and causes the terminal to transmit either a mark or space condition in the parity bit position of each transmitted word as determined by the position of the PAR EVEN/PAR ODD switch. Parity Even = Mark; Parity Odd = Space.

If parity is reselected, the terminal must be reinitialized by reapplying power or by pressing the MANUAL RELEASE switch.

1 STOP BIT/2 STOP BITS Switch

This switch selects the number of stop bits in the transmitted word. Received data requirements are not affected. If the stop bit selection is changed, the terminal must be reinitialized by reapplying power or by pressing the MANUAL RELEASE switch.

ADV/752 Switch

This switch determines what features are active and establishes the type of line communication coding to be used for external I/O transmission.

NORMAL/AUTO LF Switch

The normal or auto line-feed functions apply only to 752 mode operation. Operation in ADV mode does not require the auto line feed feature thereby allowing the switch to be used in a manner not related to carriage return/line-feed operations.

- 752 mode - In the NORMAL position, a carriage-return operation positions the cursor to the beginning of the current line. A line feed is not performed.

In the AUTO LF position, a line-feed operation and a carriage-return operation are performed during a carriage-return operation.

- ADV mode - In the NORMAL position, the first character position is equal to zero and progresses in binary fashion. When in the AUTO LF position, the cursor address is biased by 040g when sending or receiving X/Y positioning information and cursor position 0 is equal to 040g. Addressing is incremented in normal binary progression to 157g for the 80th column and 067g for the 24th line position.

DISABLE BELL/EOL BELL Switch

When this switch is in the EOL BELL position, cursor movement to the 73rd character position from the 72nd character or entry into the 24th line from the 23rd line causes the alarm to sound. In the DISABLE BELL position, the alarm is disabled.

RTS CONSTANT/RTS SWITCHED Switch

The RTS CONSTANT position of this switch causes the Request-to-Send signal to be on whenever DSR and DTR are on. If the RTS switch function is changed, the terminal must be reinitialized by pressing the MANUAL RELEASE switch or by reapplying power.

When the switch is in the RTS SWITCHED position, the RTS signal is activated as follows:

- Half Duplex - RTS turns on with the first keystroke and is switched off a minimum of 1 millisecond following transmission of a CR (015g), ETX (003g), EOT (004g), LF (012g), or if a break code is received, or if local mode is selected. Automatic response sequences cause RTS to be switched off 1 millisecond following the last word transferred.
- Full Duplex - RTS turns on during a power on application and is switched off when local mode is activated.

DTR CONSTANT/DTR SWITCHED Switch

The DTR CONSTANT position of this switch causes the DTR signal to be in the on condition. In the DTR SWITCHED position, the DTR signal is turned off when the terminal is in local mode. Received data is ignored if DTR is off. If the DTR switch function is changed, the terminal must be reinitialized by pressing the MANUAL RELEASE switch or by reapplying power.

60 HZ REFRESH/50 HZ REFRESH Switch

The refresh rate selection switch must be set at the rate of the primary power frequency. Selection of the improper refresh rate causes instability of the presentation on the crt. If the refresh rate is reselected, the terminal must be reinitialized by a power-on application.

KEYBOARD FUNCTIONS

The keyboard provides for operator input of alphanumeric data, control codes, and terminal functions. The keyboard operates in

four different levels of line coding. The levels are established as follows:


- First level - key only
- Second level - key and SHIFT
- Third level - key and CONTROL
- Fourth level - key, SHIFT, and CONTROL

Refer to the 722-10/20 Display Terminal Reference manual for line coding generated by the various levels (publication number is listed in the preface of this manual).

KEYBOARD INDICATORS

Two indicators are located on the keyboard as shown in figure 2-3. The LOCK (keyboard locked) indicator lights during a print operation and following each Request-to-Send until a Clear-to-Send is received. The keyboard locked condition can be cleared by pressing the MANUAL RELEASE switch or by reapplying power to the terminal.

The DSR indicator indicates the condition of the Data-Set-Ready signal from the modem.



03293-7

Figure 2-3. Keyboard Indicators



This section provides information on packaging, installation, and checkout of the display terminal.

PACKAGING

CAUTION

Observe MOS circuit handling precautions (described in section 5 of this manual) when packaging logic/power-supply module.

The display terminal is packaged for shipment as shown in figure 3-1. The I/O cable is shipped separately. If the display terminal is to be reshipped, it must be packaged as it was originally received from the factory. If the logic/power-supply module is to be returned for repair, use the materials specified in the packaging instructions of figure 3-2. Packaging materials may be obtained from:

Control Data Corporation
Corporate Traffic
8100 34th Avenue South
Minneapolis, MN 55440

INSTALLATION

The following paragraphs describe the installation requirements and installation instructions for the display terminal.


INSTALLATION REQUIREMENTS

Observe the following installation requirements:

- The primary power for the terminal must have adequate circuit overload protection devices to limit the maximum current flow to 20 A.

NOTES

1. USE PREFABRICATED SHIPPING MATERIALS (CDC P/N 41037500) FOR PACKAGING.
2. INTERLOCK FOAM BASE LEGS WITH END FRAMES.
3. PLACE END FRAMES WITH BASE LEGS ON DISPLAY TERMINAL.
4. PLACE DISPLAY TERMINAL WITH END FRAME CUSHIONING INTO EXTERIOR CONTAINER.
5. LOCK L BLOCKS IN POSITION.
6. SECURE POWER CABLE IN SLITS OF END FRAMES. (DO NOT LET PLUG DANGLE).
7. CLOSE AND SEAL EXTERIOR CONTAINER WITH 3-IN. REINFORCED BOX SEALING TAPE.




03352-1

Figure 3-1. Display Terminal Packaging Instructions

NOTES

1. USE PREFABRICATED SHIPPING CONTAINER AND ANTISTATIC BAG (CDC P/N 59126200) FOR PACKAGING.
2. PLACE LOGIC/POWER-SUPPLY MODULE IN ANTISTATIC BAG WITH MODULE HEAT SINK AT OPEN END OF BAG. SEAL BAG WITH TAPE.
3. PLACE BAG CONTAINING MODULE INTO CONTAINER WITH HEAT SINK FACING UP AND LOCATED AT HINGED END OF CONTAINER.
4. CLOSE CONTAINER AND SEAL WITH 3/4-in FILAMENT TAPE.



03351-1

Figure 3-2. Logic/Power Supply Module Packaging Instructions

- The installation site must be designed in such a manner as to allow easy access to the primary power circuit outlet by the operator.
- Check that enough cable slack is provided to allow moving the display terminal approximately 1 meter (3 feet) to permit servicing.
- Avoid direct sunlight on the display screen.
- Allow a 102-mm (4-in) minimum air space at top and sides of display terminal to provide adequate cooling.
- Avoid installing display terminal in areas of high electromagnetic interference.
- Avoid installing display terminal where particulate, liquid, and gaseous atmospheric contaminants exist, such as found in some process industries.
- I/O cable should be separated from electrical wiring (100 or 235 volts, 50 or 60 Hz) by a minimum of 50 mm (2 in). Unshielded, high-power, or high-energy wiring may require a larger separation. Cabling may be run in the same conduit as telephone lines.
- The customer is responsible for providing the I/O cable. Standard lengths and CDC part numbers are:

3.2 m (10.5 ft)	61409028
6.2 m (20.5 ft)	61409029
9.1 m (30 ft)	61409030
12.2 m (40 ft)	61409031
15.2 m (50 ft)	61409032

Special cables designed for use with the terminal are described in Appendix A.

If the I/O cable is not available with the system, have customer contact the CDC marketing representative.

- I/O cable runs, both horizontal and vertical, must be supported every 3.0 m (10 ft).

INSTALLATION INSTRUCTIONS

Install the display station per the following. Procedure numbers used in the steps refer to specific procedures contained in section 5B of this manual.

1. Unpackage display terminal (refer to figure 3-1) and move to desired location.
2. Inspect for any shipping damage.

- Tip terminal to one side and remove snap-in cover that is over Voltage Select switch. Verify that switch is set correctly for site input voltage.

<u>Switch Position</u>	<u>Voltage Range</u>
120 V	104 V ac to 128 V ac
220 V	191 V ac to 235 V ac
240 V	208 V ac to 256 V ac

- Set front panel switches as required by the operating system. The data site manager can assist in determining proper switch settings. (Refer to the Installation section of the Operator's Guide for typical switch selections.) Use figure 3-3 to plan the switch configuration and to provide a record for maintenance personnel. Keep a copy of the record with each terminal.

SWITCH NAME	DATA RATE SELECT												POSITION			
	110	150	200	300	600	1200	1800	2400	4800	9600	19200	19200	19200	19200		
DATA RATE (TOP) 1ST	<input type="checkbox"/>															
DATA RATE 2ND	<input type="checkbox"/>															
DATA RATE 3RD	<input type="checkbox"/>															
DATA RATE (BOTTOM) 4TH	<input type="checkbox"/>															
PAR EVEN - PAR ODD																
ROLL - PAGE																
FULL DUP - HALF DUP																
ON LINE - LOCAL																
MODE SELECT	POSITION															
	A =							B =								
NORMAL - XPARENT																
NORMAL - DATA ONLY																
PAR EN - PAR DIS																
1 STP BIT - 2 STP BIT																
ADVANCE - 752																
NORMAL - AUTO LF																
DIS BELL - EOL BELL																
RTS CONST - RTS SW																
DTR CONST - DTR SW																
60 HZ REFRESH - 50 HZ REFRESH																

Note: Place an X in the appropriate column to indicate switch selection.

Figure 3-3. Front-Panel Switch Setting Record

To set the data rate switches, refer to the decal on the inside of the operators access panel and note the alpha character associated with the desired data rate. Find the alpha character on the switch panel and set the switches as indicated by the white and black blocks below the alpha character. If a block is white, set the related switch to the left; if the block is black, set the related switch to the right.

For example, to select an 1800 baud data rate (alpha character G), set switches 1 and 4 to the right and switches 2 and 3 to the left.

If the data rate is reselected, reinitialize the terminal by powering it off and on, or by pressing the MANUAL RELEASE switch.

5. Position internal jumpers on logic/power supply and switch-panel boards as required for system operation. To change internal jumpers, remove hood (procedure CRT2) and refer to figures 3-4 and 3-5 for jumper locations. Use a small pair of needle-nose pliers to grasp jumper.


NOTE

Only the NORMAL/CURRENT LOOP and Cursor Home Position jumpers are subject to change during installation. Do not change any other jumpers. The functions established by these jumpers are as follows:

- NORMAL/CURRENT LOOP (on logic/power-supply board) - Factory jumpered to NORMAL position (two jumpers). This establishes an RS-232-C communication line interface. If a current-loop interface is desired, change both jumpers to CURRENT LOOP position (figure 3-4).
 - Cursor Home Position (on switch-panel board) - Factory jumpering causes cursor home position to be as determined by ROLL/PAGE switch setting. If first character position of first line is desired for home position regardless of scroll feature, change jumper to First Line Home Position (figure 3-5).
6. Connect modem I/O cable, and printer I/O cable if used, to rear connectors of terminal (figure 3-6). The printer must operate at the same data rate as the communications interface.
 7. Check that TEST/NORMAL switch is in NORMAL position.
 8. Check that terminal Power On/Off switch is pressed in (off) and plug ac power cord into site outlet.


NOTE

A CDC part number 15165426 power cord is required for 220-V/240-V, 50-Hz Schuko type site outlets.



03306-3

Figure 3-4. NORMAL/CURRENT LOOP Jumper Location



03900

Figure 3-5. Cursor Home Position Jumper Location




Figure 3-6. I/O Connector Locations

CHECKOUT

Checkout of the terminal is performed through use of the diagnostic self-test routines described in section 5 of this manual, and also through use of the Loop Test switch to check the external loopback capability. Procedure numbers used in the following steps refer to specific procedures contained in section 5B.

1. Apply power to display terminal (procedure CRT1).
2. Observe display screen for power-on test failures. Troubleshoot any test errors per SAM CRT3. If a terminal power-on problem occurs, refer to SAMs CRT1 and CRT2.
3. Execute transparent-mode test routines by placing NORMAL/TRANSPARENT switch to TRANSPARENT position, pressing MANUAL RELEASE switch, and placing LOOP TEST switch in TEST position.
4. Observe display screen for test failures. Troubleshoot any test errors per SAM CRT3.
5. Perform switch-panel test per prompts on display.

NOTE

Skip steps 6 through 9 if current loop is selected.

6. Place TEST/NORMAL switch to TEST position.
7. Press MANUAL RELEASE switch to exit from switch-panel routine and advance to keyboard routine.
8. Check operation of several alphanumeric keys and observe screen for correct display of characters. Each keystroke will produce multiple characters on screen. Data is transferred through the TEST/NORMAL switch at the selected baud rate.
9. Observe overall display quality. Slight variations in display geometry are acceptable. If video adjustments are required, refer to procedure CRT3.
10. Return NORMAL/TRANSPARENT switch to NORMAL position, and TEST/NORMAL switch to NORMAL position (towards keyboard).
11. Press MANUAL RELEASE switch to exit from self-test routines.
12. Place ON LINE/LOCAL switch to LOCAL position.
13. Check sound level of audio alarm by performing a CONTROL G function at keyboard. To adjust, remove hood (procedure CRT2) and adjust R7 on logic/power-supply board.
14. Return ON LINE/LOCAL switch to ON LINE position.
15. Place TEST/NORMAL switch to TEST position.
16. Place FULL DUP/HALF DUP switch to FULL DUP position.
17. Key in data. A single character should display for each keyboard input. Repeat for each alphanumeric key.
18. Return TEST/NORMAL switch to NORMAL position and check that FULL DUP/HALF DUP switch is in correct position as required for system operation.
19. To checkout an attached printer, do the following:
 - a. Place ADV/752 switch to ADV position.
 - b. Enter data from keyboard.
 - c. Press PRINT key. All data starting from beginning of current line should print out on printer. Refer to applicable printer maintenance manual for any printing problems.
20. Run any applicable system tests that may be specified by system level documentation.

00

0

0


0

0

0

This section contains only the interconnection diagram for the display terminal. Logic diagrams are contained in a separate support information manual (see preface for publication number).

SHEET REVISION STATUS				REVISION RECORD				
REV	CO	DESCRIPTION	DRFT	DATE	CHKD	APP		
00	5001.67	RELEASED CLASS B		2-8-80	WJG	APC		
01	51058	REVISED PER ECO	P.#	3-21-80	EE	APC		
02	51065	REVISED PER ECO	PH	3-28-80	EE	APC		
A	13471-74	RELEASED CLASS 'A'		4-9-80	EE	APC		
B	14104	REVISED PER ECO	WJA	6-26-80	EE	APC		
C	14241	REVISED PER ECO	WJA	9-2-80	WJG	APC		
D	14257	REVISED PER ECO	WJA	9-16-80	EE	APC		
E	14353	REVISED PER ECO	EE	12-2-80	EE	APC		



NOTE: ⚠ VOLTAGES MAY VARY +10% TO -15%.

REFERENCE DRAWING		TITLE	
FIRST USED ON		INTERCONNECTION DIAGRAM, (VIKING TTY DISPLAY TERMINAL 50/60HZ)	
DWN	Mary Dietz	1/31/80	
CHKD	APC	2/7/80	
ENGR	APC	2-8-80	
MFG	APC	2-13-80	
APPR	P.N.H.	3-27-80	
COMPONENTS, EXCEPT AS NOTED		CODE IDENT	DRAWING NO
TOLERANCE	VALUE	15920	62201048
RES		CROSS REF NO	
CAP		SHEET 1 OF 1	

This section provides information necessary to perform on-site maintenance on the terminal. The material presented assumes expertise in basic terminal maintenance techniques including use of common CE tools and equipment. The maintenance information covers checks, adjustments, removal, and replacement of the field-replaceable components as directed by the associated SAM (structured analysis method) listings for the terminal. Information is organized under the following major headings:

- General Maintenance Information
- Diagnostic and Corrective Maintenance

GENERAL MAINTENANCE INFORMATION

The following paragraphs provide information that the customer engineer should be familiar with before performing maintenance on the terminal. Topics discussed are:

- Suggested Emergency Maintenance Procedure
- Safety Precautions
- Maintenance Tools and Materials
- MOS Circuit-Handling Precautions
- Maintenance Aids
- Location of Major Assemblies
- Internal Controls

SUGGESTED EMERGENCY MAINTENANCE PROCEDURE

The following procedure provides suggested steps for the customer engineer (CE) to follow when responding to a customer request for maintenance on the terminal.

Before Leaving For Customer Site

Before leaving for the customer site, the CE should call the customer and talk to the person operating the terminal at the time the malfunction occurred, then:

1. Determine the following:
 - a. Type of symptoms terminal exhibited to indicate that a malfunction occurred.
 - b. Whether terminal is operating and what symptoms, if any, are present when an attempt is made to operate.
2. Decide course of action to take, for example:
 - a. Go to customer site and begin troubleshooting.
 - b. Deduce that terminal itself is probably not at fault and most likely cause of problem is either communication lines or a power reduction or loss. In either case, CE can notify responsible party (common carrier or customer) of problem.
 - c. Decide that an error in operating procedure rather than equipment failure is probably cause of malfunction, and notify customer of correct operating procedure.
3. If a site maintenance trip is required, CE should try to determine a probable cause for failure and gather necessary tools, manuals, and spare parts that may be needed.

Upon Arriving At Customer Site

Upon arriving at the customer site, the CE should locate the appropriate supervisory personnel and again talk to the terminal operator concerning the malfunction, then:

1. Visually inspect terminal to ensure that correct input/output and power cable connections exist.
2. Verify that a malfunction does exist, and then begin to troubleshoot terminal.

3. After source of malfunction is corrected, CE should:

- a. Run diagnostic self-test routines explained later in this section to ensure that terminal is operational.
- b. Demonstrate to customer that terminal is now operating properly within system.

SAFETY PRECAUTIONS

WARNING

Observe the following safety precautions at all times. Failure to do so may cause equipment damage and/or personal injury.

- Hazardous voltages exist in the terminal. Do not attempt repair unless qualified to do so.
- Exercise caution any time checks or adjustments are being made to terminal when power is applied.
- Always turn power off and disconnect ac power cord when removing/replacing components or cables.

MAINTENANCE TOOLS AND MATERIALS

The maintenance procedures require the use of common CE tools and test equipment. No special materials are required.

MOS CIRCUIT-HANDLING PRECAUTIONS

Special handling procedures are necessary for printed circuit cards containing MOS (metal-oxide semiconductor) integrated circuits. Observe the following precautions when handling the logic/power supply board:

- Turn power off before removing/installing or otherwise connecting/disconnecting any circuits.
- Ensure that any item that comes in contact with card is electrically grounded.

- Touch metal chassis frame to bleed off any accumulated static charge before handling card and continue to touch chassis while removing/installing card.
- Handle card only by a noncircuit portion. Connector pins and circuit paths must not be touched.
- Place card in a special conductive envelope whenever card is removed from chassis.

MAINTENANCE AIDS

There is no scheduled maintenance for the terminal. In the event of failure, the primary maintenance aids are the self-test routines and SAM troubleshooting listings. These aids are structured to isolate the failure to a field-replaceable component/assembly and to provide a procedure number reference to the applicable maintenance procedure to be used for correcting the malfunction. Refer to the Diagnostic and Corrective Maintenance heading for organization of this material.

LOCATION OF MAJOR ASSEMBLIES

Figure 5-1 shows the location of the major assemblies within the display terminal.


INTERNAL CONTROLS AND FUSES

Internal controls are located on the monitor pc board and on the yoke assembly for maintenance adjustments of the video display. An audio alarm potentiometer is located on the logic/power supply board. The following paragraphs describe the functions of these controls and identify the power supply circuits associated with the fuses contained on the logic/power supply board.

Monitor PC Board

The monitor pc board adjustment controls are:

- VIDEO-HORIZ PHASE control (R104) - adjusts centering of the video information within the raster.
- VERT SIZE control (R309) - adjusts vertical display height.



03890-1

Figure 5-1. Location of Major Assemblies

- HORIZ WIDTH coil (L102) - adjusts horizontal display width.
- FOCUS control (R415) - adjusts focus of displayed data.
- BRITE control (R412) - adjusts raster cutoff level.

Yoke Assembly

The yoke assembly adjustment controls are:

- Centering rings - adjusts centering of raster on crt.
- Trim magnets - adjusts for minimum distortion of displayed data.

Logic/Power Supply Board

The logic/power-supply board adjustment controls and fuses are:

- +15-V-Adjust potentiometer (R6) - this potentiometer is factory sealed. No alteration of the factory setting should be made during field maintenance.
- Audio Alarm potentiometer (R7) - adjusts sound level of audio transducer. Factory adjustment is for maximum sound level.
- Fuse F2 (4.0A Slow Blow) - provides overload protection for the 20 V ac transformer outputs feeding the +15 V power supply.
- Fuse F4 (1.5A Slow Blow) - provides overload protection for the 15.9 V ac transformer output feeding the -12 V power supply.
- Fuse F3 (1.5A Slow Blow) - provides overload protection for the 15.9 V ac transformer output feeding the +12 V power supply.
- Fuse F1 (4.0A Slow Blow) - provides overload protection for the 10.8 V ac transformer outputs feeding the +5 V power supply.

DIAGNOSTIC AND CORRECTIVE MAINTENANCE

The following paragraphs describe the diagnostic self-test routines, provide an explanation of the SAM format used for troubleshooting information, and describe the organization of the SAMs and related maintenance procedures.

DIAGNOSTIC SELF-TEST ROUTINES

The display terminal contains three internal self-test routines that test the basic operating capability of the logic circuits. The first test routine (power on) is initiated immediately following a power-on application. The second routine (system level) is initiated upon receipt of an Initiate Test command at the communications interface. The third routine (transparent mode) is initiated by manually pressing the front panel MANUAL RELEASE switch when the display terminal is in transparent mode.

Power-On Test

The power-on test is initiated immediately following a power-on application and consists of the following routines:

- Processor Routine - checks internal RAM and the processor. A message of CPU OK or CPU TEST FAIL is displayed on crt at test completion (assuming the failure mode does not prevent display).
- Program Memory Routine - determines if the internal program coding is as intended. Proper coding results in the message LRC B0 OK and LRC B1 OK being displayed. Improper coding causes display of a LRC B0 FAIL or LRC B1 FAIL message.
- Program Revision Routine - causes two numerals representing the program revision level to be displayed in the first line of the crt as follows: REV 1.1, REV 1.2, etc.
- Internal Loopback Routine - determines if a problem exists in the communication logic. The displayed messages resulting from this routine are INT LOOP OK or INT LOOP FAIL.
- Alarm Routine - the audible alarm is momentarily activated upon completion of the power-on test routines.

System Level Test

The system level test is initiated upon receipt of an Initiate Test command (036g, 026g) only when the terminal is in ADV mode. All of the routines of the power-on test are performed but are first preceded by a program memory test. The program

memory test consists of a write followed by a read to compare sliding alpha patterns shifted 256 times. Completion is indicated by a RAM TEST OK or RAM TEST FAIL message being displayed on the crt. Automatic responses are provided to the communication interface to indicate successful completion or failure of the test.


Transparent Mode Test

The transparent mode test is initiated by pressing the MANUAL RELEASE switch when the display terminal is in transparent mode. This test causes all of the routines described in the previous tests to be executed, plus the following routines. Continuation of the test routines following a RAM test failure is accomplished by pressing the MANUAL RELEASE switch again.

- The RAM test is modified to halt on error with the cursor positioned to the error position. Continuation of the test following a failure is accomplished by pressing the MANUAL RELEASE switch.

- ROM Character Generation Routine - four lines containing the following information are displayed (see figure 5-2):
 - 32 control codes
 - 64 alphanumeric and special characters
 - 32 lowercase and special characters
 - 32 line-drawing characters

- Switch Panel Routine - switch positions display on the crt as a series of 1 and 0 patterns; the order of presentation is shown in the attached figure (see figure 5-3). Operating the front-panel switches cause the character to be a 1 if the switch is positioned to the left. Exit from this test is accomplished by pressing the MANUAL RELEASE switch.



04031

Figure 5-3. Switch Panel Test Presentation Order

EXPLANATION OF SAM FORMAT


A SAM listing is a specialized format used to present troubleshooting information in a logical manner. Figure 5-4 illustrates the basic SAM format. Any applicable assumptions or advisory information is provided in the header information of the SAM.

To interpret a SAM, start at the top of the page and determine the response for the first question posed. Then follow the appropriate dashed line beneath the Y or N response. Answer the next question, etc. until the action numbers are reached. Perform the action(s) listed in that column in numerical order to correct the problem.

ORGANIZATION OF SAMs AND PROCEDURES

The SAMs and maintenance procedures are organized in two separate subsections of this manual as follows:

- SAM Listings (section 5A)
- Maintenance Procedures (section 5B)



03680

Figure 5-4. SAM Example



SAMS
SECTION 5A

00

0

0

0

00


SAM CRT1 POWER FAULT ISOLATION

This SAM assumes that ac power cord is plugged into site outlet and that voltage select switch is set correctly for site voltage available.

- | | | | |
|-----|----------|----------|---|
| 001 | Y | N | Does circuit breaker CB1 trip when power is applied? |
| 002 | Y | N | Are any fuses blown on logic/power supply board? |
| 003 | Y | N | Are any transformer secondary ac voltages missing at input connector J6/P6 of logic/power-supply board? Refer to interconnection diagram, section 4 of this manual for connector pins/ac voltages to be measured. |
| 004 | Y | N | Is +15 V low or missing at connector J8/P8 of logic/power-supply board? Pin 2 is +15 V and pin 3 is return. Do not use chassis for ground when measuring +15 V. |
| 005 | Y | N | Is +12 V low or missing? Measure at IC pins of A4 or A7. Pin 14 is +12 V, pin 7 is ground. (1) |
| 006 | Y | N | Is -12 V low or missing? Measure at IC pins of A4 or A7. Pin 1 is -12 V, pin 7 is ground. (1) |
| 007 | Y | N | Is +5 V low or missing? Note that three separate +5 V regulators are used for rows A, B, C, and D, E, and F, G. The regulator outputs can be checked at IC locations A06, D04, and G07. Pin 14 is +5 V, pin 1 is ground. (1) |
| 008 | | | <u>1</u> Internal voltages are OK. |
| 009 | <u>1</u> | <u>1</u> | <u>1</u> Replace logic/power-supply board (procedure CRT8). |
| 010 | <u>1</u> | | If +15 V is low or missing, disconnect monitor assembly, allow time to cool, and retry. If still low or missing, replace logic/power-supply board (procedure CRT8). If OK, isolate/replace monitor-assembly field-replaceable components. |
| | 2 | 2 | 2 |
| | A | B | C |

	A	B	C	
	1	1	1	
010			<u>1</u>	Replace transformer, or if all secondary voltages are missing, check ac input components for open circuit (refer to interconnection diagram in section 4 of this manual).
011	1			Reset circuit breaker and retry.
012		<u>1</u>		Replace logic/power supply board (procedure CRT8). Note that fuses provide secondary protection and if blown indicate a solid failure that cannot be repaired by fuse replacement.
013	<u>2</u>			Isolate electrical short (procedure CRT13).

(1) An outline drawing showing pin configuration of 14-pin ICs is as follows:



	A	B	C	D	E	
	2	2	2	2	2	
014					<u>1</u>	Go to SAM CRT3.
015	1	1	1	1		Check for loose internal cable connections.
016				2		Replace keyboard assembly (procedure CRT9).
017			5	<u>3</u>		Replace logic/power-supply board (procedure CRT8).
018			2			Check monitor pc board adjustments (procedure CRT3). Replace if unable to adjust correctly (procedure CRT4).
019			3			Check BRIGHTNESS control for open circuit (procedure CRT10). Replace if open.
020	2					Check for lit crt filament. If unlit, check for +15-V filament voltage at pin 3 (brown wire) of crt socket (use J8 pin 3 for ground side of voltmeter). If voltage is OK, replace crt (procedure CRT7). If voltage is missing, check +15-V supply. If supply voltage is OK, replace monitor pc board (procedure CRT4). If supply voltage is missing, replace logic/power-supply board (procedure CRT8).
021	<u>3</u>					Replace high-voltage assembly (procedure CRT6).
022		3				Replace yoke assembly (procedure CRT5).
023	2	4				Replace monitor pc board (procedure CRT4).

SAM CRT3 DIAGNOSTIC SELF-TEST ERRORS

This SAM is for isolating errors detected by the resident self-test diagnostic routines.

- N Y Is there a test FAIL message displayed?
- | 1 Replace logic/power-supply board (procedure CRT8).
 - | 2 Replace switch-panel assembly (procedure CRT11).
- N Y Is there a switch-panel test error?
- | 1 Check interconnecting cables.
 - | 2 Check for interference with switch mechanisms.
 - | 3 Replace switch-panel assembly.
 - | 4 Replace logic/power-supply board (procedure CRT8).
- N Y Is there a keyboard-test problem (incorrect or missing characters)?
- | 1 Check interconnecting cables.
 - | 2 Replace keyboard assembly (procedure CRT9).
 - | 3 Replace logic/power-supply board (procedure CRT8).
- 1 Self-test diagnostic checks are OK.

000

0

0

0

00

PROCEDURES
SECTION 5B

00

0

0

0

0

0

Procedure CRT1 - Power Application/Removal

This procedure assumes that the display terminal is plugged into the site ac outlet.

1. Apply power by pulling forward on power on/off switch lever (figure CRT1). A visible red-orange stripe on top of switch lever indicates power is on.
2. Remove power by pushing power on/off switch lever back in. Red-orange stripe on top of switch lever is not visible with power off.




Figure CRT1. Power On/Off Switch and Hood Mounting Screws

Procedure CRT2 - Hood Removal/Replacement

1. Slide display terminal forward on table until two front screws can be accessed.
2. Remove two mounting screws from bottom front of unit (figure CRT1).

3. Reposition display terminal on table and remove two screws from top rear of unit.
4. Lift hood off of display terminal.
5. Ensure bezel for keyboard is snapped into hood before replacing hood (keyboard bezel self-aligns to keyboard by two positioning pegs). CRT bezel should be installed after hood is in place.

Procedure CRT3 - Video Adjustments

Perform the following steps, as applicable, to adjust the monitor assembly for correct video display characteristics. Refer to figure CRT2 for control locations on monitor pc board.

WARNING

With power applied, high voltage is present at the high-voltage assembly and crt anode lead. Use caution when performing the following adjustments.

1. Turn terminal power on (procedure CRT1) and allow a 15 minute warm-up period before performing adjustments.
2. Remove hood (procedure CRT2).
3. Place TEST/NORMAL switch on the I/O connector to TEST position.
4. Adjust front-panel BRIGHTNESS control so that cursor is visible. If unable to view cursor, perform brightness adjustment (steps 12 through 14) before continuing.
5. Place NORMAL/TRANSPARENT switch to TRANSPARENT position.
6. Press MANUAL RELEASE switch to initiate self-test routines. When test stops on switch-panel routine, press MANUAL RELEASE switch again to advance to keyboard routine.
7. Press SHIFT and H keys to fill display screen with uppercase Hs.

Tilt Adjustment:

8. If video is tilted, do the following:
 - a. Loosen yoke clamp screw (figure CRT4) and rotate yoke to correct tilt.
 - b. Hold yoke in position and tighten yoke clamp screw. DO NOT OVERTIGHTEN.

Height/Width Adjustment:

9. Displayed pattern of Hs should be nominally 152 mm (6 in) high by 216 mm (8.5 in) wide. Adjust as follows:
 - a. Height - Adjust VERT SIZE control (R309).
 - b. Width - Adjust HORIZ WIDTH coil (L102).

Centering Adjustment:

10. Adjust yoke ring magnets to center raster within crt screen (figure CRT4). Note - adjust R412 to obtain visual raster.
11. Adjust VIDEO-HORIZ PHASE control (R104) to center video within raster.

Brightness Adjustment:

12. Turn front-panel BRIGHTNESS control fully counterclockwise (minimum intensity).
13. Adjust BRITE control (R412) for visual cutoff of raster.
14. Adjust BRIGHTNESS control to comfortable viewing level.

Focus Adjustment:

15. Adjust front-panel BRIGHTNESS control for desired intensity of displayed characters.

NOTE

Overly bright characters will appear out of focus and contribute to eyestrain.

16. Adjust FOCUS control (R415) for best overall focus.

Geometric Distortion Adjustment:

17. To correct for any barreling or pincushioning at top, bottom, or sides of displayed pattern, turn yoke trim magnets (figure CRT4) to minimize distortion.
18. When adjustments are complete, return terminal to normal operating conditions.




Figure CRT2. Monitor Adjustment Controls

Procedure CRT4 - Monitor PC Board Replacement

Perform the following steps to replace the monitor pc board. Refer to figure CRT3 for details.

1. Turn terminal power off (procedure CRT1) and unplug ac power cord from site outlet.
2. Remove hood (procedure CRT2).
3. Disconnect white/gray wire from aquadag grounding clip.
4. Disconnect connector socket from crt.

5. Disconnect two yoke connectors from monitor pc board.
6. Disconnect flyback connector from monitor pc board.
7. Disconnect board-edge connector from monitor pc board.
8. Compress four mounting tangs holding monitor pc board and lift pc board to remove.
9. Install replacement pc board per reverse of preceding steps. Refer to figure CRT4 for correct connection of yoke wires.
10. Perform video adjustments per procedure CRT3.




Figure CRT3. Monitor PC Board Mounting Details

Procedure CRT5 - Yoke Replacement

Refer to figure CRT4 and perform the following steps to replace the yoke assembly.

1. Turn terminal power off (procedure CRT1) and unplug ac power cord from site outlet.
2. Remove hood (procedure CRT2).

WARNING

Rough handling, nicks or scratches, or undue pressure on crt neck can cause crt to implode. Wear safety glasses and heavy gloves.

3. Remove connector socket from crt.
4. Disconnect two yoke connectors from monitor pc board.
5. Remove monitor pc board per procedure CRT4.
6. Loosen yoke clamp screw and carefully slide yoke assembly off of crt neck.
7. Slide replacement yoke assembly onto crt neck and position so that red and blue yoke wires are on the left and yellow and black wires are on the right of crt neck.

WARNING

Do not overtighten yoke clamp in following step.

8. Butt yoke assembly against rear of crt and tighten yoke clamp.
9. Reinstall monitor pc board.
10. Connect yoke wires to monitor pc board. Note that yellow and black wires connect to left of crt neck and red and blue wires connect to right of crt neck as viewed from the rear (figure CRT4).
11. Connect crt socket to crt and perform video adjustments per procedure CRT3.




Figure CRT4. Yoke Assembly Details

Procedure CRT6 - High-Voltage Assembly Replacement

Perform the following steps to replace the high-voltage assembly.

1. Turn terminal power off (procedure CRT1) and unplug ac power cord from site outlet.
2. Remove hood (procedure CRT2).

WARNING

CRT high voltage may be present at tube anode. Perform the following step to discharge crt.

3. Connect a wire to ground and then slide other end under anode cap to discharge high voltage from crt.

4. Squeeze anode cap and disconnect anode lead from crt.
5. Disconnect high-voltage-assembly connector from monitor pc board.
6. Remove two mounting screws from base of high-voltage assembly.
7. Install replacement high-voltage assembly and perform video adjustments per procedure CRT3.

Procedure CRT7 - CRT Replacement

To replace the crt, refer to figure CRT5, and perform the following steps.

1. Turn terminal power off (procedure CRT1) and unplug ac power cord from site outlet.
2. Remove hood (procedure CRT2).

WARNING

CRT high voltage may be present at tube anode. Perform the following step to discharge crt.

3. Connect a wire to ground and then slide other end under anode cap to discharge high voltage from crt.
4. Squeeze anode cap and disconnect anode lead from crt.
5. Remove monitor PC board (procedure CRT4).
6. Remove yoke assembly (procedure CRT5).


WARNING

Cathode-ray tubes contain a high vacuum and are subject to implosion if damaged. Such an implosion can propel flying glass causing personal injury. Do not nick or scratch glass or subject crt to any undue pressure during removal or installation. Wear safety glasses and heavy gloves.

6. Support neck of crt and remove four screws mounting crt to monitor chassis.
7. When installing replacement crt, aquadag grounding clip must be reinstalled in upper right corner of rear of crt.
8. Reinstall yoke assembly (procedure CRT5) and perform monitor adjustments per procedure CRT3.

NOTE

The procedure for replacing the glare shield is included in the Equipment Care section of the Operator's Guide. Use Scotchbrand No. 465 double-back adhesive tape or equivalent to install the glare shield.



03887

Figure CRT5. CRT Replacement Details

Procedure CRT8 - Logic/Power-Supply Board Replacement


To replace the logic/power-supply board, refer to figure CRT6 and perform the following:

1. Power off display terminal (procedure CRT1) and unplug ac power cord from site outlet.
2. Remove hood (procedure CRT2).
3. Remove snap-on switch panel.
4. Remove two monitor assembly hold-down screws and tilt monitor assembly to gain access to logic/power-supply board.
5. Disconnect monitor cable connector J8/P8 from logic/power-supply board.
6. Disconnect flat ribbon cable from keyboard assembly.

CAUTION

To prevent pc board damage, support corner of logic board by grasping firmly when removing/installing connector J6/P6.

7. Disconnect transformer cable connector J6/P6 from logic/power-supply board.
8. Disconnect printer and modem I/O cables and remove mounting screw from each I/O connector.
9. Remove two screws mounting logic/power-supply board to cabinet.
10. Disconnect switch-panel ribbon cable from connector J5/P5 of logic/power supply board.
11. Lift logic/power-supply board out of unit and install replacement per reverse of preceding steps. Ensure Keyboard Encoder Assembly is properly positioned.
12. Verify that replacement pc board has NORMAL/CURRENT LOOP jumper installed correctly. Refer to section 3 for jumper placement.
13. Return faulty logic/power-supply board for repair using packaging materials that spared assembly was shipped in. Refer to section 3 for packaging instructions.




03890-3

Figure CRT6. Logic/Power Supply Board Mounting Details

Procedure CRT9 - Keyboard Assembly Replacement

To replace the keyboard assembly, refer to figure CRT7 and perform the following:

1. Power off display terminal (procedure CRT1) and unplug ac power cord from site outlet.
2. Remove hood (procedure CRT2).
3. Disconnect flat ribbon cable from keyboard assembly.
4. Remove two screws mounting keyboard assembly to cabinet.
5. Install replacement keyboard assembly per reverse of preceding steps. Ensure that ground lead is reconnected to keyboard mounting screw.
6. Ensure keyboard encoder assembly is firmly inserted in socket.



03881-2

Figure CRT7. Keyboard Assembly Mounting Details

Procedure CRT10 - BRIGHTNESS Control Checks/Replacement

Perform the following to check and/or replace the front-panel BRIGHTNESS control. Refer to figure CRT8 for assembly details.

1. Power off display terminal (procedure CRT1) and unplug ac power cord from site outlet.
2. Remove hood (procedure CRT2).
3. Disconnect board-edge connector from monitor pc board and connector J8/P8 from logic/power-supply board.
4. To check control:
 - a. Determine resistance of potentiometer (stamped on case).
 - b. Check that total resistance value is present between outer lugs of potentiometer.
 - c. Connect meter leads between center lug and one outer lug of potentiometer. Rotate control shaft and observe resistance reading. Resistance value should change linearly as control shaft is rotated through its range.
 - d. Check for continuity of white, red, and black leads between lugs of BRIGHTNESS control and associated connector pins.
5. To replace control:
 - a. Cut cable tie holding BRIGHTNESS control cable to monitor-assembly chassis.
 - b. Remove snap-on switch-panel assembly by releasing top and raising assembly from frame.
 - c. Remove mounting nut from BRIGHTNESS control and remove control and cable from unit. Install replacement assembly per reverse of preceding steps.




Figure CRT8. BRIGHTNESS Control Mounting Details

Procedure CRT11 - Switch-Panel Assembly Replacement

To replace the switch-panel assembly, refer to figure CRT9 and perform the following:

1. Power off display terminal (procedure CRT1) and unplug ac power cord from site outlet.
2. Remove hood (procedure CRT2).
3. Remove snap-on switch-panel assembly by releasing top and raising panel assembly from frame.
4. Loosen keyboard-assembly mounting screws and tilt keyboard forward to disconnect J5/P5 from logic/power-supply board.

5. Install replacement switch-panel assembly per reverse of preceding steps.
6. Verify that all switches are set correctly for required system operation and ensure that Cursor Home Position jumper is in same position as original board (refer to section 3 for jumper placement information).





Figure CRT9. Switch Panel Assembly Mounting Details

Procedure CRT12 - Keyboard Switch Module Replacement

To replace keyboard switch modules, refer to figure CRT10 and perform the following:

1. Power off display terminal (procedure CRT1).

2. Remove keycap by prying it up.
3. Lift spring out of switch housing.
4. Pry switch housing loose from keyboard by pressing detent on each side of switch housing. It may be necessary to remove keycaps and springs from adjacent switch modules to provide sufficient clearance. Also note that pc board of keyboard assembly has retaining screws attached to some switch modules. Retaining screw must be removed from bottom of pc board before removing associated switch housing. If detents are not accessible from top, remove keyboard assembly (procedure CRT9) and separate pc board and keyswitch assembly. This is done by removing screws on underside of pc board. Then access faulty switch module from reverse of keyboard panel. Refer to procedure CRT9 for accessing pc board.
5. Install replacement switch module per reverse of preceding steps. Replacement switch module will have a blank keycap. Discard blank keycap and use existing one.



0388A

Figure CRT10. Keyboard Switch Module Mounting Details

Procedure CRT13-AC Short-Circuit Isolation

This procedure isolates short circuits causing CB1 to trip. Refer to the interconnection diagram (section 4) in conjunction with this procedure.

1. Turn terminal power off (procedure CRT1).
2. Remove hood (procedure CRT2).
3. Disconnect J8/P8 from logic/power-supply board.
4. Allow time for circuit breaker (CB1) to cool, then reset CB1 and power on display terminal. If CB1 no longer trips, replace monitor pc board (procedure CRT4). If CB1 still trips, continue with the following steps until fault is isolated.
5. Disconnect J6/P6 from logic/power-supply board.
6. Allow time for circuit breaker (CB1) to cool, then reset CB1 and power on display terminal. If circuit breaker no longer trips, replace logic/power supply board (procedure CRT8). If circuit breaker still trips, continue with the following steps until fault is isolated.
7. Unplug ac power cord from site outlet.
8. Remove keyboard assembly (procedure CRT9).
9. Remove logic/power-supply board (procedure CRT8).
10. Inspect ac wiring for electrical shorts.
11. Check transformer primary for shorts as follows:
 - a. Disconnect blue line-filter lead and white, blue, and orange transformer leads from Voltage Select switch.
 - b. Disconnect brown transformer primary lead from Power On/Off switch.
 - c. Use VOM to check for shorts between brown transformer lead and each of the remaining transformer primary leads (white, blue, and orange). Typical resistance readings are as follows:
 - Brown to white lead - 7 ohms
 - Brown to blue lead - 17 ohms
 - Brown to orange lead - 20 ohms

If shorted, replace transformer. Refer to schematic diagram in section 4 for color codes of transformer leads and connection information.

12. Check for shorted Voltage Select switch as follows:
 - With all leads disconnected from Voltage Select switch, check for shorts between each switch contact and ground. If shorted, replace Voltage Select switch.
13. Check for transformer secondary shorts between all pins of connector P6 and each pin to ground. If shorted, replace transformer.
14. Check for shorted power on/off switch by measuring between each switch contact and ground. If shorted replace power on/off switch.
15. The only remaining component that could cause CBl to trip is a faulty CBl itself. Therefore, replace CBl.

This section contains the spare parts list covering the field-replacable components and assemblies of the terminal. Note that the majority of items are warehouse spares and are not stocked on site. Refer to the support information manual for associated assembly drawings (see preface for publication number).

DWN	U. Glaser	1/80	CONTROL DATA CONTINUATION	TITLE	VIKING TTY DISPLAY TERMINAL	PREFIX SPL	DOCUMENT NO.	REV
CHKD	W. J. Glaser	2-1-80		FIRST USED ON	CC628A		66310609	K
ENG	M. P. Glaser	2-1-80		CODE IDENT	15920			SHEET 1 of 3
MFG	C. J. Glaser	2-1-80						
APPR	C. J. Glaser	2-25-80						

SHEET REVISION STATUS										REVISION RECORD				
3	2	1	REV	ECO	DESCRIPTION	DRFT	DATE	APP						
			00	00	00	50004-62				RELEASED CLASS B		1/1/80		
			00	01	01	51058	WJG 3-21-80	3/21/80	SPJ	F/N 16 WAS 96837905				
			A	A	A	13477-72		4-9-80		RELEASED CLASS A				
			B	B	B	14104	WJG	6-27-80		REVISED PER ECO				
			B	C	C	14241	WJG	9-15-80	SPJ	REVISED PER ECO				
			B	D	D	14262	WJG 9-16-80	9-17-80		REVISED PER ECO				
			E	D	E	14294	WJG 10-7-80	10-7-80	SPJ	F/N 23 WAS 61408439				
			E	F	F	14431	EE	11/4/80		F/N 13 WAS 51918969				
			E	G	G	14530	D.S.	3/11/81		CHG P/N 1, A				
			E	H	H	14675	WJG 5-19-81	5/21/81		F/N 1 WAS 90446277				
			E	J	J	14640	EE	7/13/81		F/N 17 WAS 61408810				
			K	K	K	14753	DS	8-27-81		CHANGE P/N 4, 26				

NOTES: 1. Under quantity required where REF is used, there is a quantity of one {} in each equipment, unless otherwise noted.

△ P/N 90446253 MAY BE USED INTERCHANGEABLY WITH P/N 90446308 IN THE FIELD.

DETACHED LISTS

A43180 REV. 8-71

PRINTED IN U.S.A.

CONTROL DATA			CODE IDENT	SHEET	S PL	DOCUMENT NO.	REV
			15920	2		66310609	1
FIND NO.	PART IDENTIFICATION	QUANTITY REQUIRED	UNIT OF MEAS	NOMENCLATURE OR DESCRIPTION	SPECIFICATIONS, NOTES, OR MATERIAL		
1	90446308	1	PC	CARD ASSY 9BTD MAIN LOGIC	△		
2	90446156	1	PC	CARD ASSY 9BSD SW PANEL			
3	66312052	1	PC	MONITOR CKT CARD			
4	51940700	1	PC	KEYBOARD			
5	66312532	REF	PC	SW MOD ASSY {CAP}	{86 PER KYBD}		
6	66312533	REF	PC	SW MOD ASSY, AA, LIGHTED	{CAP}		
7	66312050	REF	PC	CRT			
8	66312051	REF	PC	FLYBACK TRANSFORMER ASSY			
9	66312065	REF	PC	YOKE ASSY			
10	15165425	REF	PC	POWER CORD {60HZ}			
11	15165426	REF	PC	POWER CORD {50HZ}			
12	51918306	REF	PC	SLIDE SWITCH {POWER}			
13	61409074	REF	PC	VOLTAGE SELECT SWITCH ASSY			
14	61408878	REF	PC	LINE FILTER ASSY			
15	61408984	REF	PC	TRANSFORMER ASSY			
16	51782143	REF	PC	CIRCUIT BREAKER	SINGLE POLE		
17	61409138	REF	PC	CABLE ASSY CRT/BRIGHTNESS			
18	66312531	REF	PC	KEYCAP SET			
19	66312526	REF	PC	SPRING, STANDARD {2.5 oz}	{82 PER KYBD}		
20	66312527	REF	PC	SPRING, SPACE BAR {2.8 oz}			

A43181 REV. 8-71

PRINTED IN U.S.A.

CONTROL DATA			CODE IDENT 15920		SHEET 3		SPL	DOCUMENT NO. 66310609		REV. K						
FIND NO.	PART IDENTIFICATION	REF	QUANTITY REQUIRED										UNIT OF MEAS	NOMENCLATURE OR DESCRIPTION	SPECIFICATIONS, NOTES, OR MATERIAL	
21	71493086	REF												PC	DECAL, KEYBOARD	
22	71493107	REF												PC	DECAL, SWITCH PANEL	
23	71493222	REF												PC	BEZEL/DOOR ASSY	
24	71493056	REF												PC	MASK, SWITCH PANEL	
25	71493057	REF												PC	MASK, KEYBOARD	
26	66312534	REF												PC	KYBD Encoder Assy.	
27	51903800	REF												PC	INDICATOR, LED	{2 PER KYBD}
28	66312530	REF												PC	SPACE BAR MECHANISM	
29	66312525	REF												PC	SPRING, DUAL RETURN {1.2 oz}	{4 PER KYBD}
30	66312528	REF												PC	IC CS263 SENSE AMP	
31	15112800	REF												PC	IC MC840	
32	17183900	REF												PC	IC 7407	{2 PER KYBD}
33	50254300	REF												PC	IC 74123	

AA3181 REV. 8/71

PRINTED IN U.S.A.

000

0

0

0

000

This appendix identifies the various special I/O cables that can be used with the terminal. The interface application, cable configuration, and associated CDC part numbers are as follows:


<u>CURRENT LOOP INTERFACE</u>	
<u>12-CAVITY FEMALE CONNECTOR (AMP 86402-4)</u>	<u>25-PIN MALE CONNECTOR (RS-232)</u>
XDATA 1	9 REC+
TD 2	10 REC-
RD 11	18 TRANS+
RDATA 12	25 TRANS-
<u>Length</u>	<u>CDC Part Number</u>
30.4 m (100 ft)	61409000
152.0 m (500 ft)	61409001
304.8 m (1000 ft)	61409002

<u>CURRENT LOOP INTERFACE</u>	
<u>25-PIN FEMALE CONNECTOR (RS-232)</u>	<u>25-PIN MALE CONNECTOR (RS-232)</u>
+V 11	9 REC+
TD 2	10 REC-
RD 3	18 TRANS+
-12 V 18	25 TRANS-
<u>Length</u>	<u>CDC Part Number</u>
30.4 m (100 ft)	61408995
152.0 m (500 ft)	61408996
304.8 m (1000 ft)	61408997

RS-232 INTERFACE

12-CAVITY FEMALE
CONNECTOR
(AMP 86402-4)

25-PIN MALE
CONNECTOR
(RS-232)




<u>Length</u>	<u>CDC Part Number</u>
3.0 m (10 ft)	61408990
7.6 m (25 ft)	61408991
15.2 m (50 ft)	61408992

RS-232 INTERFACE

25-PIN FEMALE
CONNECTOR
(RS-232)

25-PIN MALE
CONNECTOR
(RS-232)



<u>Length</u>	<u>CDC Part Number</u>
3.0 m (10 ft)	61408985
7.6 m (25 ft)	61408986
15.2 m (50 ft)	61408987

TABLE B-1. GENERATING ASCII CONTROL CODES FOR
ADVANCE MODE COMMANDS

COMMAND	CODE MNEMONIC	KEY SEQUENCE	OCTAL CODE
Print Form	SOH	CONTROL and A	001
Page Print	DC1	CONTROL and Q	021
Print I/O	RS, F	CONTROL and +/=, then SHIFT and F	036, 106
Blind Printer	RS, DEL	CONTROL and +/=, then DEL	036, 177
Start Blink	SO	CONTROL and N	016
Start Underscore	DC4	CONTROL and T	024
Start Dim	FS	CONTROL and /Reverse Slash	034
Stop Blink	SI	CONTROL and O	017
End Underscore	NAK	CONTROL and U	025
End Dim	GS	CONTROL and]/[035
Enable Blink	ETX	CONTROL and C	003
Disable Blink	EOT	CONTROL and D	004
Roll Enable	DC2	CONTROL and R	022
Roll Disable	DC3	CONTROL and S	023
Set Scroll Field	RS, W	CONTROL and +/=, then SHIFT and W	036, 127
Field Scroll Up	RS, U	CONTROL and +/=, then SHIFT and U	036, 125
Field Scroll Down	RS, V	CONTROL and +/=, then SHIFT and V	036, 126
Tab	RS, EOT	CONTROL and +/=, then CONTROL and D	036, 004

TABLE B-1. GENERATING ASCII CONTROL CODES FOR
ADVANCE MODE COMMANDS (CONTD)

COMMAND	CODE MNEMONIC	KEY SEQUENCE	OCTAL CODE
Clear Field of: - All data	RS, P	CONTROL and +/=, then SHIFT and P	036, 120
- All data ex- cept low in- tensity areas	RS, @	CONTROL and +/=, then SHIFT and @/2	036, 100
- Only low in- tensity areas	RS, ?	CONTROL and +/=, then SHIFT and ?/Slash	036, 077
Delete Line	RS, Q	CONTROL and +/=, then SHIFT and Q	036, 121
Insert Line	RS, R	CONTROL and +/=, then SHIFT and R	036, 122
Line Drawing	RS, FS	CONTROL and +/=, then CONTROL and /Reverse Slash	036, 034
Basic Character	RS, GS	CONTROL and +/=, then CONTROL and]/[036, 035
Read Cursor Address	ENQ	CONTROL and E	005
Write Cursor Address	DLE	CONTROL and P	020
Initiate Test	RS, SYN	CONTROL and +/=, then CONTROL and V	036, 026
Read Status	RS, DC4	CONTROL and +/=, then CONTROL and T	036, 024
Read Parameter	RS, DC3	CONTROL and +/=, then CONTROL and S	036, 023
Read Data	RS, DLE	CONTROL and +/=, then CONTROL and P	036, 020
Read Attribute	RS, SO	CONTROL and +/=, then CONTROL and N	036, 016
Alarm	BEL	CONTROL and G	007
Add Delimiter	RS, ENQ	CONTROL and +/=, then CONTROL and E	036, 005

TABLE B-2. GENERATING ASCII CONTROL CODES FOR
752 MODE COMMANDS

COMMAND	CODE MNEEMONIC	KEY SEQUENCE	OCTAL CODE
Alarm	BEL	CONTROL and G	007
Reduced Intensity	SO	CONTROL and N	016
Blink	ETB	CONTROL and W	027
Stop Highlight	SI	CONTROL and O	017
X-Y Positioning	ESC, 1	ESC, then 1	033, 061
Backspace	BS	SHIFT and /4	010
Line Feed	LF	SHIFT and /2	012
Carriage Return	CR	CR or NEW LINE	015
Line Clear	SYN	CONTROL and V	026
Page Clear	CAN	SHIFT and EOP/EOL	030
Home	EM	SHIFT and HOME/5	031
Cursor Up	SUB	SHIFT and /8	032
*	NUL	CONTROL and @/2	000
*	SOH	CONTROL and A	001
*	STX	CONTROL and B	002
*	ETX	CONTROL and C	003
*	EOT	CONTROL and D	004
*	ENQ	CONTROL and E	005
*	ACK	CONTROL and F	006
*	HT	TAB	011
*	VT	CONTROL and K	013
*	FF	CONTROL and L	014
*	DLE	CONTROL and P	020
*	DC1	CONTROL and Q	021

TABLE B-2. GENERATING ASCII CONTROL CODES FOR
752 MODE COMMANDS (CONTD)

COMMAND	CODE MNEMONIC	KEY SEQUENCE	OCTAL CODE
*	DC2	CONTROL and R	022
*	DC3	CONTROL and S	023
*	DC4	CONTROL and T	024
*	NAK	SHIFT and /Q	025
*	ESC	ESC	033
*	FS	CONTROL and / Reverse Slash	034
*	GS	CONTROL and /	035
*	RS	CONTROL and +/=	036
*	US	CONTROL and _/-	037
*	DEL	DEL	177

*Only code transmission occurs.

COMMENT SHEET

MANUAL TITLE: CDC 722-10/20 Display Terminal CC628-A
Hardware Maintenance Manual (Site Information)

PUBLICATION NO.: 62940003

REVISION: L

NAME: _____

COMPANY: _____

STREET ADDRESS: _____

CITY: _____ STATE: _____ ZIP CODE: _____

This form is not intended to be used as an order blank. Control Data Corporation welcomes your evaluation of this manual. Please indicate any errors, suggested additions or deletions, or general comments below (please include page number references).

CUT ALONG LINE

03376 REV. 5/80 PRINTED IN U.S.A.

NO POSTAGE STAMP NECESSARY IF MAILED IN U.S.A.

FOLD ON DOTTED LINES AND STAPLE

STAPLE

STAPLE

FOLD


FOLD



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY MAIL
FIRST CLASS PERMIT NO. 8241 MINNEAPOLIS, MINN.

POSTAGE WILL BE PAID BY
CONTROL DATA CORPORATION
Technical Publications Department
2401 North Fairview Avenue
St. Paul, Minnesota 55113



CUT ALONG LINE

FOLD

FOLD

03377





CONTROL DATA CORPORATION