

TU58 DECtape II

User Guide

digital

TU58 DECtape II

User Guide

1st Edition, October 1978
2nd Edition, June 1981
3rd Edition, October 1982
4th Edition, December 1983

Copyright © 1978, 1981, 1982, 1983
by Digital Equipment Corporation

All Rights Reserved

The reproduction of this material, in part or whole, is strictly prohibited. For copy information, contact the Educational Services Department, Digital Equipment Corporation, Maynard, Massachusetts 01754.

The information in this document is subject to change without notice. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

Printed in U.S.A.

This equipment generates, uses, and may emit radio frequency. The equipment has been type tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC rules, which are designed to provide reasonable protection against such radio frequency interference. Operation of this equipment in a residential area may cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.

The following are trademarks of Digital Equipment Corporation, Maynard, Massachusetts.

DEC	DECnet	OMNIBUS
DECUS	DECsystem-10	OS/8
DIGITAL	DECSYSTEM-20	PDT
digital	DECwriter	RSTS
PDP	DIBOL	RSX
UNIBUS	EduSystem	VMS
DECtape	VAX	IAS
DECtape II	MASSBUS	VT

CONTENTS

CHAPTER 1 INTRODUCTION

1.1	Scope	1-1
1.2	General Description	1-1
1.3	Block Diagram	1-3
1.3.1	Drive Control	1-3
1.3.2	Processor	1-3
1.4	Specifications	1-4
1.4.1	Performance	1-4
1.4.2	Electrical	1-5
1.4.3	Mechanical	1-6
1.4.4	Environmental	1-6
1.5	Configurations	1-7
1.6	Hardware Documentation Ordering Information	1-9
1.7	Digital Repair Service	1-10

CHAPTER 2 OPERATION

2.1	TU58-DA, -CA Rackmount Controls and Indicators	2-1
2.1.1	Front Panel	2-1
2.1.2	Run Indicator	2-1
2.1.3	Application and Removal of Power	2-1
2.2	TU58-EA, -EB Controls and Indicators	2-2
2.2.1	Front Panel	2-2
2.2.2	Run Indicator	2-2
2.2.3	Application and Removal of Power	2-2
2.3	TU58-VA Controls and Indicators	2-2
2.3.1	Front Panel	2-2
2.3.2	Run Indicator	2-2
2.3.3	Application and Removal of Power	2-3
2.4	TU58 Components Controls and Indicators	2-3
2.4.1	Application and Removal of Power	2-3
2.5	Cartridge	2-3
2.5.1	Cartridge Loading	2-3
2.5.2	Cartridge Unloading	2-3
2.5.3	Keeping Track of Cartridges	2-3
2.5.4	Write Protect Tab	2-3
2.5.5	Cartridge Storage and Care	2-5
2.6	Maintenance	2-5
2.6.1	Head and Puck Cleaning	2-5
2.6.2	Operator Trouble Isolation	2-5
2.6.3	Cartridge Wear	2-5

CHAPTER 3 PROGRAMMING

3.1	General Principles	3-1
3.1.1	Block Number, Byte Count, and Drive Number	3-1
3.1.2	Special Handler Functions	3-1
3.2	Radial Serial Protocol (RSP) and Modified RSP (MRSP)	3-1
3.2.1	Packets	3-1
3.2.1.1	Packet Usage	3-2
3.2.2	Break and Initialization	3-3
3.2.3	Command Packets	3-3
3.2.3.1	Maintenance Mode	3-4
3.2.3.2	Special Address Mode	3-4
3.2.4	Data Packets	3-4
3.2.4.1	Radial Serial Protocol	3-4
3.2.4.2	Modified Radial Serial Protocol	3-4
3.2.5	End Packets	3-5
3.3	Instruction Set	3-6
3.4	PASCAL TU58 Handler Algorithm Definitions	3-11

CHAPTER 4 INSTALLATION

4.1	Introduction	4-1
4.2	Rack Installation (-DA Version)	4-1
4.2.1	Rackmount	4-1
4.2.2	Unpacking	4-1
4.2.3	Power Selection	4-1
4.2.4	Removing Bottom Plates for Controller Board Configuration	4-2
4.2.5	Rackmounting Procedure	4-2
4.3	Rack Installation (-CA Version)	4-7
4.3.1	Rackmount	4-7
4.3.2	Power Selection for the Rack Version	4-8
4.3.3	Removing Module from Chassis	4-10
4.3.4	Reinstalling the Module	4-10
4.4	Installation (-EA and -EB Versions)	4-12
4.4.1	Tabletop Installation	4-12
4.4.2	Solid Mounting Installation	4-12
4.5	Installation (-VA Version)	4-13
4.5.1	Tabletop Installation	4-13
4.5.2	Solid Mounting Installation	4-13
4.5.3	Mounting the TU58-VA to the SB11 (or BA11-VA)	4-13
4.6	Components	4-13
4.7	Interface Standards Selection and Setup	4-16
4.7.1	Selecting Interface Standards	4-17
4.7.2	Connecting Standards Jumpers	4-19
4.8	Operational Checkout	4-19
4.8.1	Checkout of Interface	4-19
4.8.2	Configuring Interface Modules	4-21
4.8.3	Checkout of Drive Command Function	4-31

CHAPTER 5 OPTIONS

5.1	Run Indicator	5-1
5.1.1	Installation	5-1
5.2	Boot Switch	5-2
5.2.1	General	5-2
5.2.2	Operation	5-2
5.2.3	Installation	5-2

APPENDIX A TU58/PDP-11 TOGGLE-IN BOOT

APPENDIX B RSP SEQUENCE

APPENDIX C SAMPLE DEVICE HANDLERS

APPENDIX D CARTRIDGE REPAIR

APPENDIX E FIELD REPLACEABLE UNIT SPARES LIST

FIGURES

1-1	Tape Cartridge Partially Inserted into Drive (Top View)	1-2
1-2	An Exchange in Radial Serial Protocol	1-3
1-3	TU58 Block Diagram	1-4
1-4	Block Locations on Tape	1-5
2-1	TU58-DA and -CA Rackmount Front Panel	2-1
2-2	TU58-EA, -EB, and -VA Front Panel	2-2
2-3	Cartridge Loading	2-4
2-4	Write Protect Tab	2-4
2-5	View Into Tape Drive Cartridge Slot	2-5
3-1	Read Command Packet Exchange	3-8
3-2	RSP Write Transaction	3-9
3-3	MRSP Write Transaction	3-10
4-1	TU58-DA Rear Panel	4-2
4-2	Installing Support Brackets	4-3
4-3	Installing Mounting Brackets	4-4
4-4	Front Vertical Rail U-Nut Retainers	4-4
4-5	Rackmounting the TU58-DA	4-5
4-6	Rear Vertical Support U-Nut Retainers	4-6
4-7	Fastening Support Bracket Extenders	4-6
4-8	Installing the Bezel	4-7
4-9	Bezel and Ball Stud	4-8
4-10	Rackmounting the TU58-CA	4-9
4-11	TU58-CA Rear Panel	4-10
4-12	Installing Cage and Retainer Bar	4-11
4-13	Mounting the TU58-EA and -EB	4-12
4-14	Mounting Choices for the TU58-VA	4-14
4-15	Interfacing the TU58-VA	4-14
4-16	Drive Outline Drawings	4-15
4-17	Board Outline Drawings	4-16
4-18	TU58 Drive Mounting Hardware	4-17
4-19	Data Rate and Cable Length for RS-423	4-19
4-20	Interface Selection Jumper Pin Locations	4-20

4-21	Factory Wiring	4-21
4-22	TU58 Wiring (9600 Baud)	4-21
4-23	DLV11-J Factory Configuration Summary	4-25
4-24	MXV11-A Jumper Locations	4-26
5-1	Installation of Run Indicator	5-1
D-1	Baseplate Screw Locations	D-1
D-2	Threading the Metal-Base Cartridge	D-2
D-3	Head Gate and Spring	D-3
D-4	Stretch the Belt with the Floating Roller	D-3
D-5	Threading the Plastic-Base Cartridge	D-4

TABLES

2-1	Operator Trouble Isolation	2-6
3-1	Command Packet Structure	3-3
3-2	Data Packets	3-5
3-3	End Packet	3-5
3-4	Instruction Set	3-7
4-1	TU58 Module Connections	4-18
4-2	MXV11-A Standard Factory Configuration	4-27

CHAPTER 1 INTRODUCTION

1.1 SCOPE

The TU58 DEctape II is a low-cost, mass-storage device that may be used in a wide variety of applications. This manual provides information that a user needs to install, interface, and operate the tape system. (For specific information about using the TU58 under DIGITAL operating systems, refer to the individual system manuals.)

Chapter 1 provides a general description of the TU58 and a list of its specifications, including electrical and mechanical requirements. The configurations section describes the available variations of the TU58.

Chapter 2 contains important information for daily operation and routine maintenance. It is the system operator's reference section.

Chapter 3 is a programming guide. It contains functional descriptions of the TU58 command set, illustrates command sequences, explains the details of the radial serial protocol (RSP) and the modified radial serial protocol (MRSP), lists system instruction codes and byte sequences, and includes a general purpose programming example for a TU58 device handler.

Chapter 4 describes instructions for jumper selection; mechanical, electrical, and interface installation; and operational checkout of the tape system.

Chapter 5 describes the optional features available in the TU58.

Appendix A lists a PDP-11 toggle-in bootstrap for the TU58.

Appendix B contains an RSP sequence to exercise a new cartridge.

Appendix C lists sample device handlers written in PDP-11 FORTRAN IV and PDP-11 MACRO-11 assembly language.

Appendix D covers cartridge repair procedures.

Appendix E lists the field replaceable units (FRUs) in the TU58.

1.2 GENERAL DESCRIPTION

The TU58 is a random-access, fixed-length-block, mass-storage tape system. It uses preformatted tape cartridges which store 262 kilobytes of data in 512-byte blocks. There are 256 blocks on each of two tracks. They may be accessed by a program in a fashion similar to that employed for data stored on disks or DEctape, using a new, high-level instruction set. A file-oriented structure is easily implemented in an operating system by setting aside several blocks on the tape to store a directory.

The TU58 is compact and mechanically simple. The tape cartridges are DIGITAL-preformatted, miniature, reel-to-reel packages containing 42.7 m (140 ft) of 3.81 mm (0.150 in) wide tape. A single puck drives the tape by engaging a roller which moves an elastomer drive belt in the cartridge. This belt loops around both tape spools and provides uniform tension and spill-free winding without mechanical linkages (Figure 1-1). The simple, single-point drive mechanism provides high reliability for the entire system.


The control and drive circuitry of the TU58 is located on a single circuit board. The controller uses a microprocessor (μP) to reduce the tape handling and communications management load on the host system.

The motor and tape head control, driver, and switching circuits that manage the two tape drives are on the printed circuit board with the μP . The controller supports one or two drives, but only one drive can operate at a time. The μP controls all activities of the TU58. Head and motor selection, speed and direction changes, etc. are managed by outputs from I/O ports on a peripheral integrated circuit (IC). The mechanical actions of the drives are supervised by the μP in order to improve system performance.

Operational amplifiers, comparators, and logic circuits perform amplification, signal switching and conditioning, proportional control, and logic steering functions in the controller. The tape is protected by motor current limiting and an anti-runaway timer.

The μP intelligence requires that requests from the host for data retrieval or storage contain only simple specifications about the transfer. The controller positions the tape and performs the transfer without supervision from the host.

The host and controller communicate in a format called either radial serial protocol (RSP), or modified radial serial protocol (MRSP). RSP uses two kinds of byte sequences called message packets. Both command and data packets have protocol information placed in specific locations in the byte sequence. This format is easily generated by the TU58, making host-peripheral interaction possible at a high level with low cost. Figure 1-2 illustrates a typical RSP exchange between a host computer and the TU58. See Chapter 3 for a full discussion of RSP implementation.



MA-2380

Figure 1-1 Tape Cartridge Partially Inserted into Drive (Top View)

When, owing to the data transfer rate selected, the buffer is unable to accept an entire transaction, modified serial protocol (MRSP) is utilized. MRSP is implemented by using the command packet switch byte. See Paragraph 3.2 for a more detailed description of MRSP implementation.

The serial host interface operates on full-duplex, asynchronous, 4-wire lines at jumper-selectable rates of 150 to 38.4K baud. Send and receive rates may be independently set with jumpers to operate in accordance with Electronic Industries Association (EIA) standards RS-422 or RS-423. When set to RS-423, the TU58 is also compatible with devices complying with RS-232-C.

1.3 BLOCK DIAGRAM

Figure 1-3 illustrates the structure of the TU58 system. The data path is along the top of the diagram, passing to the host through the processor at the right. The drive control is at the lower left, also closely associated with the processor through the I/O ports. The ports, memory, and universal asynchronous receiver-transmitter (UART) are connected to the processor by an 8-bit-wide data/address bus.

1.3.1 Drive Control

The cartridge drive motors are powered by servo-regulated speed and direction circuits. These are controlled by the processor, which monitors with tachometers and with signals from the tape. The heads are selected by processor-controlled switches and either feed the automatic-gain-controlled (AGC) read amplifier and decoder circuits or are driven by write currents encoded by the processor.

1.3.2 Processor

The processor consists of an 8085 processor supported by firmware in a 2-kilobyte, read only memory (ROM) and by scratchpad and data buffer memory in a 256-byte random access memory (RAM). The processor communicates with the drive control circuitry through a bidirectional I/O port. The UART exchanges data between the TU58 processor bus and the host computer via the serial line drivers and receivers.




Figure 1-2 An Exchange in Radial Serial Protocol




Figure 1-3 TU58 Block Diagram

1.4 SPECIFICATIONS

1.4.1 Performance

Capacity per cartridge

262,144 bytes, formatted in 512 blocks of 512 bytes each

Data transfer rate

Read/write on tape

41.7 μ s/data bit, 24 Kbits/s

Data buffer to interface

150 to 38.4 kbaud, jumper selected

Cartridge life

5000 minimum end-to-end-and-back tape passes

Data reliability

Soft data error rate

1 in 10^7 bits read (before self-correction)

Hard error rate

1 in 10^9 bits read (unrecoverable within 8 automatic retries)

Hard error rate with write-verify and system correction

2 in 10^{11} bits read/written

Error checking


Checksum with rotation

Average access time	9.3 seconds
Maximum access time	28 seconds
Read/write tape speed	76 cm/s (30 in/s)
Search tape speed	152 cm/s (60 in/s)
Bit density	315 bits/cm (800 bits/in)
Flux reversal density	945 fr/cm (2400 fr/in)
Recording method	Ratio encoding
Medium	DECtape II cartridge with 42.7 m (140 ft) of 3.81 mm (0.150 in) tape. Size: 6.1 × 8.1 × 1.3 cm (2.4 × 3.2 × 0.5 in). Order TU58-K.
Track format (Figure 1-4)	Two tracks, each containing 1024 individually numbered, firmware-interleaved "records." Firmware manipulates four records at each operation to form 512-byte blocks.
Drive	Single motor, head integrally cast into molded chassis.
Drives per controller	1 or 2 (only one may operate at a time)

1.4.2 Electrical

Power consumption	11 W typical, drive running
Board and 1 or 2 drives	+5 V ±5% at 0.75 A maximum
	+12 V + 10% - 5% at 1.2 A, peak
	0.6 A average running
	0.1 A idle

These voltages need not stabilize simultaneously upon power-on.



MA-2373

Figure 1-4 Block Locations on Tape

Rackmount	90 – 128 Vac, 180 – 256 Vac, 47 – 63 Hz, 35 W maximum
Serial interface standards	In accordance with RS-422 or RS-423; compatible with RS-232-C.
1.4.3 Mechanical	
Drive	8.1 H × 8.3 D × 10.6 W cm (3.2 × 3.3 × 4.1 in) with 19 cm (7.5 in) cable; 0.23 kg (0.5 lb)
Board	13.2 H × 26.5 D × 3.5 W cm (5.19 × 10.44 × 1.4 in); 0.24 kg (0.53 lb)
TU58-DA	Same rackspace as -CA. See -EA for chassis.
TU58-CA rackmount cabinet	13.2 H × 38.1 D × 48.3 W cm (5.19 × 15.0 × 19.0 in); 9 kg (20 lbs)
TU58-EA, -EB, -VA	9.2 H × 29.5 D × 33.7 W cm (3.6 × 11.6 × 13.3 in); with rubber feet, add 1.5 H cm (0.6 in)
Power connector to board	AMP 87159-6 with 87027-3 contacts DIGITAL PN 12-12202-09, 12-12203-00)
Power connector to rackmount	European IEC standard
Interface connector to board	AMP 87133-5 with 87124-1 locking clip contacts and 87179-1 index pin (PN 12-14268-02, 12-14267-00, 12-15418-00)

1.4.4 Environmental

When the TU58-AB or -BB is integrated in a host device such as a terminal, convection provides adequate cooling if the interior temperature is below 50° C (122° F) dry bulb, 26° C (79° F) wet bulb.

Maximum dissipation	
TU58-CA, -DA, -EA, -EB	120 Btu/hour
TU58-AB, -BB, -VA	34 Btu/hour
Temperature	
TU58 operating	15° C (59° F) to 42° C (108° F) ambient
TU58 nonoperating	–34° C (–30° F) to 60° C (140° F)
Maximum temperature difference between ambient and TU58 board	18° C (32.4° F)

Relative humidity, noncondensing

TU58 operating	
Maximum dew point	23° C (73.4° F)
Minimum dew point	2° C (36° F)
Relative humidity	10% to 90%
TU58 nonoperating	5% to 98%

CAUTION

If a cartridge has been exposed to either the maximum or minimum temperature extreme, the tape should be rewound one complete cycle before using. This is done to bring the tape to the proper tension.

1.5 CONFIGURATIONS

The TU58 is available in the following configurations with accompanying designations.

- TU58-CA** Rackmount, large chassis, two drives, serial interface controller board, power supply 115/230 V switch-selectable, detachable line cords and fuses for 115 V and 230 V, two cartridges, boot ROM for MR11-EA, User Guide, Field Maintenance Print Set (MP00747), two I/O cables (BC17A-18 and BC17B-18), diagnostic kit (ZJ287-RG).
- TU58-DA** Rackmount, tabletop chassis, two drives, serial interface controller board, power supply 115/230 V switch-selectable, detachable line cords and fuses for 115 V and 230 V, two cartridges, two I/O cables (BC17A-18 and BC17B-18), boot ROM for MR11-EA, accessory assembly hardware kit (70-16753-00), User Guide, Field Maintenance Print Sets (MP01014 and MP01063).
- TU58-EA** Tabletop, two drives, serial interface controller board, power supply 115/230 V switch-selectable, detachable line cord and fuse for 115 V, accessory assembly hardware kit (70-16753-00), User Guide, Field Maintenance Print Set (MP01014).
- TU58-EB** Tabletop, two drives, serial interface controller board, power supply 115/230 V switch-selectable, detachable line cords and fuses for 115 V and 230 V, two cartridges, two I/O cables (BC17A-18 and BC17B-18), boot ROM for MR11-EA, accessory assembly hardware kit (70-16753-00), User Guide, Field Maintenance Print Set (MP01014).
- TU58-VA** Tabletop, two drives, serial interface controller board, dc power cable (70-17569-1C), I/O cable (70-17568-1F), two cartridges, MXV11-A-2 boot ROM, User Guide, Configuration Guide, Field Maintenance Print Set (MP01013), accessory assembly hardware kit (70-16753-01).

Additional Supplies

NOTE

BC22D-10 replaces BC17A-18 and BC17B-18. The new cable has an improved shield connection to comply with FCC regulations.

- BC22D-10** Interface cable from TU58 to host.

BC17A-18	Interface cable from TU58 to DL-11 and DLV-11, 5.4 m (18 ft) (10-pin-to-40-pin connector).
BC17B-18	Interface cable from TU58 to DLV-11J and MXV-11, 5.4 m (18 ft) (10-pin-to-10-pin connector).
BC21B-05	Modem cable from TU58 to EIA connector, 1.5 m (5 ft) (10-pin-to-DB25-P male).
TU58-K	Preformatted tape cartridges, available singly or in packs of five.
TUC-01	Tape Drive Cleaning Kit.
TU58-DB	Rackmount installation kit for tabletop versions -EA, -EB, -VA.
TU58-EC	Accessory kit containing detachable line cord for 115 V, accessory assembly hardware kit (70-16753-00), User Guide, Field Maintenance Print Set (MP01014).
TU58-ED	Accessory kit containing detachable line cords for 115 V and 230 V and fuse for 230 V, two cartridges, two I/O cables (BC17A-18 and BC17B-18), boot ROM for MR11-EA, accessory assembly hardware kit (70-16753-00), User Guide, Field Maintenance Print Set (MP01014).
TU58-VB	Accessory kit containing dc power cable (70-17569-1C), I/O cable (70-177568-1F), two cartridges, MXV11-A2 boot ROM, User Guide, Configuration Guide, Field Maintenance Print Set (MP01013), accessory assembly hardware kit (70-16753-01).
17-00090-00	Line cord 250 V.
70-16753-00	Accessory assembly hardware kit with brackets for mounting TU58 tabletop versions to flat surface.
70-16753-01	Accessory assembly hardware kit with brackets for mounting TU58 tabletop versions below a flat surface.
23-126F3-0-0	Boot ROM for BDV11.
MXV11-A-2	Boot ROM for MXV11.
23-765A9-00	Boot ROM for MR11-EA.

1.6 HARDWARE DOCUMENTATION ORDERING INFORMATION

The following TU58 DECtape II Tape Subsystem hardware manuals can be purchased from DIGITAL's Accessory and Supplies Group.

Part No	Title
EK-0TU58-UG	TU58 DECtape II User Guide
EK-0TU58-PS	TU58 DECtape II Pocket Service Guide
EK-0TU58-TM	TU58 DECtape II Technical Manual (microfiche or paper)
EK-0TU58-IP	TU58 DECtape II Illustrated Parts Breakdown
MP00747	TU58-C Field Maintenance Print Set
MP01014-00	TU58-E Field Maintenance Print Set
MP01013-00	TU58-V Field Maintenance Print Set
MP01063	TU58-D Field Maintenance Print Set

ORDERING

You can order supplies and accessories from one of the following addresses, according to your location.

Continental USA

Call 800-258-1710, or mail order to:

Digital Equipment Corporation
P.O. Box CS2008
Nashua, NH 03061

New Hampshire

Call 603-884-6660, or mail order to:

Digital Equipment Corporation
P.O. Box CS2008
Nashua, NH 03061

Alaska or Hawaii

Call 408-734-4915, or mail order to:

Digital Equipment Corporation
632 Caribbean Drive
Sunnyvale, CA 94086

Canada

Call 800-267-6146, or mail order to:

Digital Equipment of Canada LTD.
P.O. Box 13000
Kanata, Ontario, Canada K2K 2A6
Att: A&SG Business Manager
Telex: 610-562-8732

1.7 DIGITAL REPAIR SERVICE

Digital Field Service offers a range of flexible service plans. Choose the one that is right for you.

ON SITE SERVICE offers the convenience of service at your site and insurance against unplanned repair bills. For a small monthly fee you receive personal service from our Service Specialists. Within a few hours the specialist is dispatched to your site with all the equipment and parts needed to give you fast and dependable maintenance.

BASIC SERVICE offers full coverage from 8 a.m. to 5 p.m., Monday through Friday. Options are available to extend your coverage to 12-, 16-, or 24-hour days, and to Saturdays, Sundays, and holidays.

DECservice offers a premium on-site service that guarantees extra-fast response and nonstop remedial maintenance. We don't leave until the problem is solved, which makes this service contract ideal for those who need uninterrupted operations.

Under Basic Service and DECservice all parts, materials, and labor are covered in full.

CARRY-IN SERVICE offers fast, personalized response and the ability to plan your maintenance costs for a smaller monthly fee than On-Site Service. When you bring your unit in to one of 160 Digital Servicenters worldwide, factory-trained personnel repair your unit within two days (usually 24 hours). This service is available on selected terminals and systems.

Digital Servicenters are open during normal business hours, Monday through Friday. Call one of the following numbers for the location of the office nearest you.

DECmailer offers expert repair at a per use charge. This service is for users who have the technical resources to troubleshoot, identify, and isolate the module causing the problem. You mail the faulty module to our Customer Returns Center where the module is repaired and mailed back to you within five days.

PER CALL SERVICE offers a maintenance program on a noncontractual, time-and-materials-cost basis. This service is available with either On-Site or Carry-In service. It is appropriate for customers who have the expertise to perform first-line maintenance, but may occasionally need in-depth support from Field Service.

Per Call Service is also offered as a supplementary program for Basic Service customers who need maintenance beyond their contracted coverage hours. There is no materials charge in this case.

On-Site Per Call Service is provided on a best effort basis, with a normal response time of two to three days. It is available 24 hours a day, seven days a week.

Carry-In Per Call Service is available during normal business hours, with a two to three day turnaround.

For more information on these Digital Service plans, prices, and special rates for volume customers, call one of the following numbers for the location of the Digital Field Service office nearest you.

Digital International Field Service Information Numbers

U.S.A.	1-(800)-554-3333	Denmark	430-1005
Canada	(800)-267-5251	Spain	91-7334370
United Kingdom	(0256)-57122	Finland	90-423332
Belgium	(02)-242-6790	Holland	(01820)-34144
West Germany	(089)-9591-6644	Switzerland	01-8105184
Italy	(02)-617-5381/2	Sweden	08-987350
Japan	(03)-989-7161	Norway	2-256422
France	1-6873152		

CHAPTER 2 OPERATION

2.1 TU58-DA, -CA RACKMOUNT CONTROLS AND INDICATORS

2.1.1 Front Panel

The front panel (Figure 2-1) has two slots for the tape cartridges and two tape motion indicators for the drives. In addition, the decorative bezel has a small compartment that can store up to four cartridges (six on the -CA) in their boxes.

2.1.2 Run Indicator

Each tape drive has an indicator that lights to show tape motion. Since data loss can occur if a cartridge is removed while the tape is being written, the cartridge should not be removed if the indicator is on.

2.1.3 Application and Removal of Power

The TU58-DA has a power switch on its backpanel, while the TU58-CA does not. If an outlet is available on a system power controller, the TU58 may be plugged into the controller. Otherwise, it does not need to be turned off. Its idling power consumption is less than 20 W.

When power is applied, the TU58 initializes itself, performs internal diagnostic tests, and then asks the host for an acknowledgement before it settles down to wait for instructions. See Paragraph 3.2.2 for a description of the required exchange.

If power is removed while a tape is being written, data may be lost. There are no other restrictions on power removal.




Figure 2-1 TU58-DA and -CA Rackmount Front Panel

2.2 TU58-EA, -EB CONTROLS AND INDICATORS

2.2.1 Front Panel

The front panel (Figure 2-2) has two slots for the tape cartridges and two tape motion indicators for the drives.

2.2.2 Run Indicator

Each tape drive has an indicator that lights to show tape motion in that drive.

2.2.3 Application and Removal of Power

The TU58-EA and -EB versions have power switches on their back panels. If an outlet is available on a system power controller, these versions may be plugged into the controller. Otherwise, they do not need to be turned off. Their idling power consumption is less than 20 W.

When power is applied, the TU58 initializes itself, performs internal diagnostic tests, and then asks the host for an acknowledgement before it settles down to wait for instructions. See Paragraph 3.2.2 for a description of the required exchange.

If power is removed while a tape is being written, data may be lost. There are no other restrictions on power removal.


2.3 TU58-VA CONTROLS AND INDICATORS

2.3.1 Front Panel

The front panel (Figure 2-2) has two slots for the tape cartridges and two tape motion indicators for the drives.

2.3.2 Run Indicator

Each tape drive has an indicator that lights to show tape motion in that drive.



MA-6643

Figure 2-2 TU58-EA, -EB, and -VA Front Panel

2.3.3 Application and Removal of Power

The TU58-VA requires +5 V and +12 V from the device to which it connects. See the electrical specifications in Paragraph 1.4.2 for power requirements of a controller board and two drives. The part number of dc power cable supplied with the TU58-VA is 70-17569-1C. See Chapter 4 for installation information.

When power is applied, the TU58 initializes itself, performs internal diagnostic tests, and then asks the host for an acknowledgement before it settles down to wait for instructions. See Paragraph 3.2.2 for a description of the required exchange.

If power is removed while a tape is being written, data may be lost. There are no other restrictions on power removal.

2.4 TU58 COMPONENTS CONTROLS AND INDICATORS

See Chapter 5 for installation and operation of optional features.

2.4.1 Application and Removal of Power

The TU58 may be supplied with power from a host system. It is ready for operation within one second of voltage stabilization. It does not need to be turned off when not in use; its idling power consumption is less than 5 W.

When power is applied, the TU58 initializes itself, performs internal diagnostic tests, and then asks the host for an acknowledgment before it settles down to wait for instructions. See Paragraph 3.2.2 for a description of the required exchange.

If power is removed while a tape is being written, data may be lost. There are no other restrictions on power removal.

2.5 CARTRIDGE

2.5.1 Cartridge Loading

The TU58 drive is designed to make correct loading easy. To load the cartridge, hold it label-up, line it up with the grooves in the chassis, and slide it in with a firm push. Figure 2-3 illustrates the fit of the cartridge into the drive chassis grooves.

2.5.2 Cartridge Unloading

Unloading the cartridge is as simple as loading. Just pull it straight out. It is best to wait for the tape to stop (run indicator turns off) before removing the cartridge. The mechanism cannot be damaged by removing the cartridge while the tape is moving, but if a write is in progress, data may be lost. An error message is sent to the host if a command is interrupted by removal of a cartridge. The cartridge may be left in the drive as long as needed.

2.5.3 Keeping Track of Cartridges

If the TU58 is used in a non-file-structured system, the cartridge does not have an identifying number or label recorded on the tape. If a cartridge is changed, the TU58 does not know that a different cartridge was loaded; the operator must keep track of the contents of various cartridges.

2.5.4 Write Protect Tab

Each tape cartridge has a movable tab which, when properly positioned, protects data on the tape from unintended write operations. When this write protect tab (Figure 2-4) is in the inner position (toward the drive roller), it locks out the write circuitry.

When the write protect tab is in the outer position, it closes a switch in the chassis and allows the controller to write when it is commanded. The operator should be sure that system or program tapes are backed up with copies before loading them into the TU58 with their write protect tabs set to record.




Figure 2-3 Cartridge Loading




Figure 2-4 Write Protect Tab

The write protect tab can be completely removed for long-term write protection. On the metal-base cartridge, use a fingernail under the protruding end to lift the protect tab. Replace it by dropping it into its slot and pressing on it until it snaps. On the plastic-base cartridge, pry up the tab from its back edge part way and then lift from the front. To replace it, drop it into its slot and press forward and down.

2.5.5 Cartridge Storage and Care

Store cartridges in their cases, away from dust, heat, and direct sunlight. Do not touch the tape; there is no safe way to clean the tape and permanent errors may result. Keep tools and other ferrous or magnetic objects away. If it is possible that a tape has been exposed to environmental extremes (as listed in the specifications), and if the software operating system permits, wind it all the way through with a Newtape (Paragraph 3.1.2) or equivalent command, or by requesting positionings to blocks at each end of the tape before attempting to store data on the cartridge.

2.6 MAINTENANCE

2.6.1 Head and Puck Cleaning

After the first 20 hours of break-in runtime on each drive, clean the head and motor puck with a long-handled cotton applicator moistened with DIGITAL cleaning fluid (from cleaning kit TUC-01), 95 percent isopropyl alcohol, fluorocarbon TF, 113 or equivalent (Figure 2-5). Push the puck around with the applicator to clean its entire surface. After the first cleaning, repeat the procedure after every 100 hours of runtime. Regular cleaning minimizes tape and head wear and prevents tape damage and data errors caused by contamination. This is the only regular maintenance required by the TU58.

2.6.2 Operator Trouble Isolation

Table 2-1 lists potential problems and possible corrective actions and comments. (Some items are not applicable to components.)

2.6.3 Cartridge Wear

Cartridge tape is expected to last for 5000 end-to-end-and-back passes. If a cartridge is at the end of its life, a read operation may require several retries to get the data in the presence of soft errors. A soft error is a temporary data loss which is usually caused by a speck of dirt or oxide on the tape or head surface. This speck lifts the tape away from the head and causes signal loss and consequent read errors. A few extra passes of the tape past the head may knock the speck away and allow error-free reading. If it happens often, the tape is probably old and shedding oxide and should be copied and discarded as soon as possible.




Figure 2-5 View Into Tape Drive Cartridge Slot

Table 2-1 Operator Trouble Isolation

Symptom	Action/Comments
TU58 does not respond to host	<ol style="list-style-type: none">1. Ensure that the TU58-CA, -DA, -EA, or -EB is plugged into a live ac socket (or proper dc source for -VA or components).2. Check that the voltage selection switch is properly set.3. Ensure that the fuse and power cord are intact and properly inserted.4. Check that the baud rates and interface standards are the same for both the TU58 and the host interface board (Paragraph 4.7).5. If possible, observe the self-test indicator on the controller board. Remove the bezel on the rackmount version. When power is applied, the indicator should light for a half second, go out for another half second, and then relight. This means the controller has passed its automatic self-test and is ready for operation. If the indicator remains off, there is some problem within the board or in the interface. Check that the interface cable is intact and properly inserted. If the serial interface is suspected and the standards are correct, try a new interface cable. An open wire in the line from the host prevents the indicator from coming on. Other causes require servicing.
TU58 does not write (reads okay)	<ol style="list-style-type: none">1. Check that the write protect tab is set correctly on the cartridge (Figure 2-4).2. The trouble may be in a drive. Try writing on the other drive. Any problem except the write protect tab setting requires service.
Read errors (some host operating systems may provide this or a similar message)	<ol style="list-style-type: none">1. Clean the head. Dirt and tape oxide buildup can cause errors.2. The tape may contain errors that were written onto it. If a tape is in poor condition or if data is not verified at write-time, errors may become a permanent part of the recording. A new cartridge with format problems will produce the same error message. Try another cartridge.3. Motor or head is reaching end of life. Replace drive.
TU58 sends motor-stopped error messages	This indicates that a malfunction has occurred in the data recovery section and the runaway timer has stopped the motor. The TU58 should not be commanded to move tape more than twice under these conditions without checking the cartridge. Make sure that the tape is not getting near the end where it might come free of the hub.

CHAPTER 3 PROGRAMMING

3.1 GENERAL PRINCIPLES

The TU58 is controlled by a microprocessor that frees the host computer from device-related operations, such as tape positioning and error retry. Only one high-level command to the microprocessor is necessary to initiate a complex operation. The host and TU58 communicate via strings of one or more bytes called packets. One brief packet can contain a message which completely describes a high-level command. The handshaking sequences between host and TU58 as well as packet format are defined by the radial serial protocol (RSP), or the modified radial serial protocol (MRSP), and were designed to be suitable for transmission by asynchronous interfaces.

3.1.1 Block Number, Byte Count, and Drive Number

The TU58 uses a drive number, block number, and byte count to write or read data. Figure 1-4 (Chapter 1) shows the locations of blocks on the tape. If all of the desired data is contained within a single 512-byte block, the byte count will be 512 or less. When the host asks for a particular block and a 512-or-less byte count, the TU58 positions the specified drive (unit) at that block and transfers the number of bytes specified. If the host asks for a block and also a byte count greater than that of the 512-byte boundary, the TU58 reads as many sequential blocks as are needed to fulfill the byte count. The same process applies to the write function. This means that the host software or an on-tape file directory need only store the number of the first block in a file and the file's byte count to read or write all the data without having to know the additional block numbers.

3.1.2 Special Handler Functions

Some device-related functions are not dealt with directly in the RSP, the MRSP, or in the TU58 firmware.

1. A short routine called Newtape (Appendix B) should be included in a TU58 handler to provide a complete wind-rewind for new or environmentally stressed tape cartridges. This procedure brings the tape to proper operating tension levels.
2. A TU58 handler should check the success code (byte 3 of the RSP or MRSP end message) for the presence of soft errors. This enables action to be taken before hard errors (permanent data losses) occur.

3.2 RADIAL SERIAL PROTOCOL (RSP) AND MODIFIED RSP (MRSP)

3.2.1 Packets

All communication between the host and the TU58 is accomplished via sequences of bytes called packets. There are two types of multi-byte packets: Control (Command) and Data. Either RSP or MRSP may be selected using the command packet switch byte. In addition, there are three single-byte packets used to manage protocol and control the state of the system: INIT, Continue, and XOFF.

Control (Command) – A Control packet is sent to the TU58 to initiate all operations. The packet contains a message completely describing the operation to be performed. In the case of a read or write operation, for example, the message includes the function to be performed, unit (drive) number, byte count and block number.

A special case of the Control packet, called an End packet, is sent from the TU58 to the host after completion of an operation or on an error. The End packet includes the status of the completed or aborted operation.

Data – The Data packet holds messages of between 1 and 128 bytes. This message is actually the data transferred from or to the TU58 during a read or write operation. For transmissions of larger than 128 bytes, the transfer is broken up and sent 128 bytes at a time.

INIT – This single-byte packet is sent to the TU58 to cause the power-up sequence. The TU58 returns Continue after completion, to indicate that the power-up sequence has occurred. When the TU58 makes a protocol error or receives an invalid command, it reinitializes and sends INIT continuously to the host. When the host recognizes INIT, it sends Break to the TU58 to restore the protocol.

Bootstrap – A flag byte saying Bootstrap (octal 10), followed by a byte containing a drive number, causes the TU58 to read block 0 of the selected drive. It returns the 512 bytes without radial serial packaging. This simplifies bootstrap operations. Bootstrap may be sent by the host instead of a second INIT as part of the initialization process described below.

Continue – Before the host sends a Data packet to the TU58, it must wait until the TU58 sends Continue. This permits the TU58 to control the rate that data packets are sent to it.

XON – An alternate term for Continue.

XOFF – Ordinarily, the TU58 does not have to wait between messages to the host. However, if the host is unable to receive all of a message from the peripheral at once, it may send XOFF. The TU58 stops transmitting immediately and waits until the host sends Continue to complete the transfer when it is ready. (Two characters may be sent by the UART to the host after the TU58 receives XOFF.)

3.2.1.1 Packet Usage – Position within the packet determines the meaning of each byte. All packets begin with a flag byte, which announces the type of packet to follow. Flag byte numeric assignments are as follows.

Packet Type	Flag Byte Value	
	Octal	Binary
Data	01	00001
Control (Command)	02	00010
INIT	04	00100
Bootstrap	10	01000
Continue	20	10000
XON	21	10001
XOFF	23	10011

(Bits 5 – 7 of the flag byte are reserved.)

Multiple-byte (Control and Data) packets also contain a byte count byte, message bytes, and two checksum bytes. The byte count byte is the number of message bytes in the packet. The two checksum bytes are a 16-bit checksum. The checksum is formed by summing successive byte-pairs taken as 16-bit words while adding any carry back into the sum (end-around carry). The flag and byte count bytes are included in the checksum. (See example in Appendix B.)

3.2.2 Break and Initialization

Break is a unique logic entity that can be interpreted by the TU58 and the host regardless of the state of the protocol. This is the logical equivalent of a bus init or a master reset. Break is transmitted when the serial line, which normally switches between two logic states called mark and space, is kept in the space condition for at least one character time. This causes the TU58's UART to set its framing error bit. The TU58 interprets the framing error as Break.

If communications break-down, due to any transient problem, the host may restore order by sending Break and INIT as outlined above. The faulty operations are cancelled, and the TU58 reinitializes itself, returns Continue, and waits for instructions.

With DIGITAL serial interfaces, the initialize sequence may be sent by the following sequence of operations. Set the Break bit in the transmit control status register, then send two null characters. When the transmit ready flag is set again, remove the Break bit. This times Break to be one character time long. The second character is discarded by the TU58 controller. Next, send two INIT characters. The first is discarded by the TU58. The TU58 responds to the second INIT by sending Continue. When Continue has been received, the initialize sequence is complete and any command packet may follow.

3.2.3 Command Packets

The command packet format is shown in Table 3-1. Bytes 0, 1, 12, and 13 are the message delivery bytes. Their definitions follow.

Table 3-1 Command Packet Structure

Byte	Byte Contents
0	Flag = 0000 0010(02g)
1	Message Byte Count = 0000 1010(12g)

2	Op Code
3	Modifier
4	Unit Number
5	Switches
6	Sequence Number – Low
7	Sequence Number – High
8	Byte Count – Low
9	Byte Count – High
10	Block Number – Low
11	Block Number – High

12	Checksum – Low
13	Checksum – High

0	Flag	This byte is set to 00000010 to indicate that the packet is a Command packet.
1	Message Byte Count	Number of bytes in the packet, excluding the four message delivery bytes. This is decimal 10 for all command packets.
12,13	Checksum	The 16-bit checksum of bytes 0 through 11. The checksum is formed by treating each pair of bytes as a word and summing words with end-around carry.

The remaining bytes are defined below.

2	Op Code	Operation being commanded. (See Table 3-4 and Paragraph 3.3 for definitions.)
3	Modifier	Permits variations of commands.
4	Unit Number	Selects drive 0 or 1.
5	Switches	Selects maintenance mode and specifies RSP or MRSP.
6,7	Sequence Number	Always zero for TU58.
8,9	Byte Count	Number of bytes to be transferred by a read or write command. Ignored by other commands.
10,11	Block Number	The block number to be used by commands requiring tape positioning.

3.2.3.1 Maintenance Mode – Setting bit 4 of the switches byte (byte 5) to 1 in a read command inhibits retries on data errors. Instead, the incorrect data is delivered to the host followed by an end packet. The success code in the end packet indicates a hard data error. Since data is transmitted in 128-byte packets, a multiple packet read progresses normally until a checksum mismatch occurs. Then the bad data packet is transmitted, followed by the end packet, and the operation terminates.

3.2.3.2 Special Address Mode – Setting the most significant bit of the modifier byte (byte 3) to 1 selects special address mode. In this mode all tape positioning operations are addressed by 128-byte records (0-2047) instead of 512-byte blocks (0-511). Zero-fill in a write operation only fills out to a 128-byte boundary in this mode. To translate between normal addressing and special addressing, multiply the normal address by 4. The result is the address of the first 128-byte record of the block. Add 1, 2, or 3 to get to the next three 128-byte records.

3.2.4 Data Packets

3.2.4.1 Radial Serial Protocol – A data transfer operation uses three or more message packets. The first packet is the command packet from host to the TU58. Next, the data is transferred in 128-byte packets in either direction (as required by read or write). After all data is transferred, the TU58 sends an end packet. If the TU58 encounters a failure before all data has been transferred, it sends the end packet as soon as the failure occurs.

The data packet is shown in Table 3-2. The flag byte is set to 001₈. The number of data bytes may be between 1 and 128 bytes. For data transfers larger than 128 bytes, the transaction is broken up and sent 128 bytes at a time. The host is assumed to have enough buffer capacity to accept the entire transaction, whereas the TU58 only has 128 bytes of buffer space. For write commands, the host must wait between message packets for the TU58 to send the Continue flag 020₈ before sending the next packet. Because the host has enough buffer space, the TU58 does not wait for a Continue flag between message packets when it sends back read data.

3.2.4.2 Modified Radial Serial Protocol – When the host does not have sufficient buffer space to accept entire transactions at the hardware selected data transfer rate, modified radial serial protocol (MRSP) may be specified using the command packet switch byte. Bit 3 of the switch byte is set to specify the MRSP. Bit 3 remains set until intentionally cleared or cleared during power up. A good practice is to set bit 3 in every MRSP command packet.

MRSP is identical to RSP except during transmission to the host. When a command packet specifies MRSP for the first time (that is, bit 3 of the switch byte was previously cleared or cleared during power up), the TU58 will send one data or end packet byte (whichever occurs first). The subsequent bytes, up to and including the last byte of the end packet, will not be transmitted until a Continue or an XON is received from the host. To prevent a protocol error from occurring, it is necessary to transmit Continue or XON before transmitting any command packets. If a protocol error is detected, continuous INITs are sent with the Continue handshake. If a bootstrap is being transmitted, however, no handshake is employed.

3.2.5 End Packets

The end packet is sent to the host by the TU58 after completion or termination of an operation or an error. End packets are sent using RSP or MRSP as specified by the last command packet. The end packet is shown in Table 3-3.

Table 3-2 Data Packets

Byte	Byte Contents
0	Flag = 0000 0001
1	Byte Count = M

2	First Data Byte
3	Data
.	.
.	.
.	.
M	Data
M + 1	Last Data Byte

M + 2	Checksum L
M + 3	Checksum H

Table 3-3 End Packet

Byte	Byte Contents
0	Flag = 0000 0010
1	Byte Count = 0000 1010

2	Op Code = 0100 0000
3	Success Code
4	Unit
5	Not Used
6	Sequence No. L
7	Sequence No. H
8	Actual Byte Count L
9	Actual Byte Count H
10	Summary Status L
11	Summary Status H

12	Checksum L
13	Checksum H

The definition of bytes 0, 1, 12, and 13 are the same as for the command packet. The remaining bytes are defined as follows.

Byte 2 Op Code – 0100 0000 for end packet

Byte 3	Success Code		
	Octal	Decimal	
	0	0	= Normal success
	1	1	= Success but with retries
	377	-1	= Failed self test
	376	-2	= Partial operation (end of medium)
	370	-8	= Bad unit number
	367	-9	= No cartridge
	365	-11	= Write protected
	357	-17	= Data check error
	340	-32	= Seek error (block not found)
	337	-33	= Motor stopped
	320	-48	= Bad op code
	311	-55	= Bad block number (>511)

Byte 4 Unit Number 0 or 1 for drive number.

Byte 5 Always 0.

Bytes 6,7 Sequence number – always 0 as in command packet.

Bytes 8,9 Actual byte count – number of bytes handled in transaction. In a good operation, this is the same as the data byte count in the command packet.

Bytes 10,11		Summary Status
Byte 10	Bit 0	} Reserved
	↓	
	Bit 7	
Byte 11	Bit 0	
	1	} Logic error
	2	
	3	
	4	
	5	Motion error
	6	Transfer error
	7	Special condition (errors)

3.3 INSTRUCTION SET

The operation performed by the TU58 when it receives a Control (command) packet is determined by the op code byte in the control packet message. Note that while any command can specify modified radial serial protocol with the switch byte, the response will not be MRSP if a boot operation is being performed. Instruction set op code byte assignments are listed in Table 3-4.

To allow for future development, certain op codes in the command set have been reserved. These commands have unpredictable results and should not be used. Op codes not listed in the command set are illegal and result in the return of an end packet with the “bad op code” success code.

Table 3-4 Instruction Set

Op Code Decimal	Op Code Octal	Instruction Set
0	0	NOP
1	1	INIT
2	2	Read
3	3	Write
4	4	(Reserved)
5	5	Position
6	6	(Reserved)
7	7	Diagnose
8	10	Get status
9	11	Set status
10	12	(Reserved)
11	13	(Reserved)

The following is a brief description and usage example of each.

OP CODE 0 NOP

This instruction causes the TU58 to return an end packet. There are no modifiers to NOP. The NOP packet is shown below.

BYTE

0	0000	0010	FLAG	
1	0000	1010	MESSAGE BYTE CNT	
2	0000	0000	OPCODE	
3	0000	0000	MODIFIER	
4	0000	000X	UNIT NUMBER (IGNORED)	
5	0000	0000	SWITCHES (NOT USED)	
6	0000	0000	SEQ NO. (NOT USED)	
7	0000	0000	SEQ NO. (NOT USED)	
8	0000	0000	BYTE COUNT L	NO DATA
9	0000	0000	BYTE COUNT H	INVOLVED
10	0000	0000	BLOCK NO. L	NO TAPE
11	0000	0000	BLOCK NO. H	POSITION
12	0000	001X	CHECKSUM L	
13	0000	1010	CHECKSUM H	

The TU58 returns the following end packet.

0	0000	0010	FLAG	
1	0000	1010	MESSAGE BYTE CNT	
2	0100	0000	OPCODE	
3	0000	0000	SUCCESS CODE	
4	0000	000X	UNIT (IGNORED)	
5	0000	0000	NOT USED	
6	0000	0000	SEQ. L	
7	0000	0000	SEQ. H	
8	0000	0000	ACTUAL BYTE CNT L	NO DATA
9	0000	0000	ACTUAL BYTE CNT H	INVOLVED
10	0000	0000	SUMMARY STATUS L	
11	XXXX	XXXX	SUMMARY STATUS H	
12	000X	XXXX	CHECKSUM L	
13	XXXX	XXXX	CHECKSUM H	

OP CODE 1 INIT

This instruction causes the TU58 controller to reset itself to a ready state. No tape positioning results from this operation. The command packet is the same as for NOP except for the op code and the resultant change to the low order checksum byte. The TU58 sends the same end packet as for NOP after reinitializing itself. There are no modifiers to INIT.

OP CODE 2 Read, and Read with Decreased Sensitivity

This instruction causes the TU58 to position the tape in the drive selected by Unit Number to the block designated by the block number bytes. It reads data starting at the designated block and continues reading until the byte count (command bytes 8 and 9) is satisfied. After data has been sent, the TU58 sends an end packet. Byte 3 indicates success, success with retries, or failure of the operation. In the event of failure, the end packet is sent at the time of failure without filling up the data count. The end packet is recognized by the host by the flag byte. The host sees a command flag (0000 0010) instead of a data flag (0000 0001).

There are two modifiers to the read command. Setting the least significant bit of byte 3 to 1 causes the TU58 to read the tape with decreased sensitivity in the read amplifier. This makes the read amplifier miss data if any weak spots are present. Thus, if the TU58 can read error-free in this mode, the data is healthy. The read transaction between TU58 and host is shown for 510 bytes (just under a full block) in Figure 3-1. Setting the most significant bit of byte 3 to 1 selects special address mode. See Paragraphs 3.2.3.1 and 3.2.3.2.




Figure 3-1 Read Command Packet Exchange

OP CODE 3 Write, and Write and Read Verify

This op code causes the TU58 to position the tape in the selected drive to the block specified by the number in bytes 10,11 of the command packet and write data from the first data packet into that block. It writes data from subsequent data packets into one or more blocks until the byte count called out in bytes 8, 9 of the command packet has been satisfied.

The controller automatically zero-fills any remaining bytes in a 512-byte tape block.

There are two modifiers permitted with the write command. Setting the least significant bit of byte 3 to 1 causes the TU58 to write all of the data and then back up and read the data just written with decreased sensitivity and test the checksum of each record. If all of the checksums are correct, the TU58 sends an end packet with the success code set to 0 (or 1 if retries were necessary to read the data). Failure to read correct data results in a success code of - 17 (357₈) to indicate a hard read error. Setting the most significant bit of byte 3 to 1 selects special address mode. See Paragraph 3.2.3.2.

The write operation has to cope with the fact that the TU58 only has 128 bytes of buffer space. It is necessary for the host to send a data packet and wait for the TU58 to write it before sending the next data packet. This is accomplished using the continue flag. The continue flag is a single byte response of 0001 0000 from TU58 to host. The RSP write transaction for both write and write/verify operations is shown in Figure 3-2. The MRSP write transaction for both write and write/verify operations is shown in Figure 3-3.





Figure 3-2 RSP Write Transaction



MA-10,493

Figure 3-3 MRSP Write Transaction

OP CODE 4 (Reserved)

OP CODE 5 Position

This command causes the TU58 to position tape on the selected drive to the block designated by bytes 10, 11. After reaching the selected block, it sends an end packet. See Paragraph 3.2.3.2.

OP CODE 6 (Reserved)

OP CODE 7 Diagnose

This command causes the TU58 to run its internal diagnostic program which tests the processor, ROM, and RAM. Upon completion, TU58 sends an end packet with appropriate success code (0 = Pass, -1 = Fail). Note that if the bootstrap hardware option is selected, boot information will be transmitted without handshaking even if the switch byte specifies MRSP.

OP CODE 8 Get Status

This command is treated as a NOP. The TU58 returns an end packet.

OP CODE 9 Set Status

This command is treated as a NOP because TU58 status cannot be set from the host. The TU58 returns an end packet.

OP CODE 10 (Reserved)

OP CODE 11 (Reserved)

3.4 PASCAL TU58 HANDLER ALGORITHM DEFINITIONS

The following collection of algorithms describes the basic functions required for using the TU58 in a system. These algorithms are written in a pseudo-Pascal language and are therefore only designed to illustrate the logic of operations involved in causing the TU58 to perform the intended function. Actual software for a particular host computer may be written using these algorithms along with the program examples found in Appendix C. The following is a list of the functions described.

1. **tudiagnose** – Constructs and sends the command packet causing the TU58 to execute its built-in, self-test diagnostic. Returns the TU58 end packet success code as the result.
2. **tuseek** – Constructs and sends the command packet which causes the TU58 to position the tape inserted in the specified drive to the specified block. Returns the success code obtained from the TU58 end packet as the result.
3. **turead** – Constructs and sends the command packet which causes the TU58 to read data from the tape in the specified drive into a buffer area. Returns the success code obtained from the TU58 end packet as the result.
4. **tuwrite** – Constructs and sends the command packet which causes the TU58 to write data from the buffer area specified to the specified TU58 tape unit. Returns the success code obtained from the TU58 end packet as the result.

In addition to the above specific functions, algorithms for supporting routines are also provided. These routines are shared by the TU58 function routines and are included for the sake of completeness.

Digital Equipment Corporation assumes no responsibility for the correctness of these algorithms, nor offers corrections should errors be present. These algorithms may be copied for use on any computer system by any suitable language implementation.

CONSTANTS (Defines some interesting and useful constants)

{ Define single byte packet flags }

data = 1;
control = 2;
init = 4;
continue = 16;
xoff = 19;

{ Define multi-byte packet opcodes }

read_opcode = 2;
write_opcode = 3;
position_opcode = 5;
diagnose_opcode = 7;
end_pack_opcode = 64;

{ Define initialization success codes }

success = 0;
failure = -127;

{ Define some useful subscript values }

command_flag = 0;
command_count = 1;
command_opcode = 2;
command_unit = 4;
data_count_low = 8;
data_count_high = 9;
command_block_low = 10;
command_block_high = 11;

{ Define length of command/data messages }

command_length = 10;
data_block = 128;

GLOBAL_VARIABLES (Indicate quantities used by all functions)

single_byte_packet : byte;

{ Note the variable length of the array defined below.
Its length is a function of the type of message to be
sent, i.e., N is the number of bytes contained in the
message }

multi_byte_packet : ARRAY[0..N+3] OF byte;

CALLING_PARAMETERS (Parameters defined by the calling routines)

unit_number, block_number : INTEGER; { Specified unit/block }
no_bytes : INTEGER; { Number of bytes in message }
buffer : ARRAY[1..no_bytes] OF byte; { Data/message space }

tudiagnose;

{ This routine runs the TU58 self-test diagnostic routine }

BEGIN

{ Construct and send the command packet
necessary to cause the TU58 controller
to execute its self-test diagnostic.
Return the value of the success code
contained in the TU58 end packet. }

IF initialize(diagnose_opcode)=success THEN BEGIN
 send_packet(packet, command_length+2);
 tudiagnose := get_end_packet
 END

ELSE
 tudiagnose := failure

END; { tudiagnose }

tuseek (unit_number, block_number);

{ Construct and send a command packet which indicates the
TU58 should position the specified unit to the specified
block. This routine returns the success code sent in
the TU58 end packet as its result. }

BEGIN

IF initialize(position_opcode)=success THEN BEGIN

{ Construct/send a command packet }

packet[command_unit] := unit_number;
packet[command_block_low] := low(block_number);
packet[command_block_high] := high(block_number);
send_packet(packet, command_length);

{ Conclude with an end packet }

tuseek := get_end_packet;
END;

ELSE
 tuseek := failure;

END; { tuseek }

turead (unit_number, block_number, buffer, no_bytes);

{ Construct and send the command packet required to read
'no_bytes' from the unit and block specified. Reads data
from the tape into a buffer space, returning the value of
the success code contained in the TU58 end packet. }

BEGIN

IF initialize(read_opcode)=success THEN BEGIN

{ Construct command packet; operators 'low', 'high'
return low byte, high byte respectively }

packet[command_unit] := unit_number;
packet[command_block_low] := low(block_number);
packet[command_block_high] := high(block_number);
send_packet(packet, command_length);

```

        { Get data output and stuff in buffer }
        IF get_data_packet(buffer)=success THEN
            turead := get_end_packet
        ELSE turead := failure
    END
    ELSE
        turead := failure
END; { turead }

tuwrite (unit_number, block_number, buffer, no_bytes);

{ Construct and send a command packet specifying the
unit and block for writing data. write the data from
the specified buffer area to the tape. Return the
success code obtained from the TU58 end packet as the
result.}

LOCAL_VARIABLES
    count, data_count : INTEGER;
BEGIN
    IF initialize(write_opcode)=success THEN BEGIN

        { Stuff parameters into command packet }
        packet[command_unit] := unit_number;
        packet[command_block_low] := low(block_number);
        packet[command_block_high] := high(block_number);
        send_packet(packet, command_length);

        { If continue is received, send data; 'get_byte'
'put_byte'are implementation-dependent function
calls }

        data_count := no_bytes

        WHILE get_byte=continue THEN DO BEGIN
            { Make blocks maximum of 128 bytes each }
            count := minimum(data_count, data_block);
            put_byte(count);
            send_packet(buffer[no_bytes-data_count+1],
                count);
            data_count := data_count - count
        END;

        { In any event, try for an end packet at end }

        tuwrite := get_end_packet
        END
    ELSE
        tuwrite := failure
END; { tuwrite }

initialize (op_code);

{ Initializes the TU58 by sending break characters on the
communication line, followed by the single byte packet
for INIT sent twice. The specified operation is then
transmitted to the TU58 as either a single byte packet
or the first (command) byte of a multi-byte packet. }

BEGIN
    { Set communication line control to BREAK }

```

```

set_break_bit;

{ Delay multiple character time to insure framing
  error }

wait(n_character_times);

{ Remove BREAK condition from line }

reset_break_bit;

{ Initialize command packet area }

packet[command_flag] := control;
packet[command_opcode] := op_code;

{ Send INIT flag to TU58 }

single_byte_packet := init;
put_byte(single_byte_packet);

IF get_byte=continue THEN initialize := success
ELSE initialize := failure;

END; { initialize }

send_packet (buffer, no_bytes);

{ Send information contained in 'buffer' to TU58 }

LOCAL_VARIABLES
  index, check_sum, check_word : INTEGER;

BEGIN
  { Must begin with checksum initialization }

  check_sum := 0;
  check_word := 0;

  { Check for even/odd bytes, performing checksum only
    if even; the operator 'odd' returns a Boolean value
    of TRUE if the argument is odd }

  FOR index := 1 TO no_bytes DO BEGIN
    IF odd(index) THEN
      check_word := buffer[index]
    ELSE BEGIN
      check_word := buffer[index]*256 + check_word;
      check_sum := check(check_sum, check_word)
    END;
    put_byte(buffer[index])
  END;

  IF odd(no_bytes) THEN
    check_sum := check(check_sum, check_word);

  { Now output checksum information; operators 'low',
    'high' return low byte, high byte respectively }

  put_byte(low(check_sum));
  put_byte(high(check_sum))

END; { send_packet }

```

```

get_data_packet (buffer);

{ Gets the data sent from the TU58 and stuffs it into
  'buffer' }

LOCAL_VARIABLES
  index, check_sum, data_count : INTEGER;

BEGIN
  { Initialize checksum variables }

  check_word := 0;
  check_sum := get_byte;

  { Look for valid data packet structure }

  IF (check_sum<>data) THEN get_data_packet := failure

  ELSE BEGIN
    { Get data packet from TU58, calculating
      checksum as the buffer is being filled }

    data_count := get_byte;
    check_sum := check_sum + data_count*256;

    FOR index := 1 TO data_count DO BEGIN
      buffer[index] := get_byte;
      IF odd(index) THEN
        check_word := buffer[index]
      ELSE BEGIN
        check_word := buffer[index]*256 + checkword;
        check_sum := check(check_sum, check_word)
      END
    END

    IF odd(data_count) THEN
      check_sum := check(check_sum, check_word);

    { Make sure packet was not in error }

    check_word := get_byte;
    check_word := check_word + get_byte*256;

    IF check_word<>check_sum THEN
      get_data_packet := failure
    ELSE get_data_packet := success
  END

END; { get_data_packet }

get_end_packet;
{ Gets an end packet from the TU58, returning success code
  as result }

LOCAL_VARIABLES
  index, check_sum, check_word : INTEGER;

BEGIN
  check_sum := get_byte;
  { Look for valid command packet structure }

  IF (check_sum<>command) OR (get_byte<>command_length)
    OR (get_byte<>end) THEN get_end_packet := failure

```

```

ELSE BEGIN
  { Get success code from command packet }

  get_end_packet := get_byte;

  { Now do the checksum calculation }

  check_sum := check(check_word, get_end_packet*256);
  FOR index := 1 TO 4 DO BEGIN
    check_word := get_byte;
    check_word := check_word + get_byte*256;
    check_sum := check(check_sum, check_word)
  END;

  { Make sure packet was not in error }

  check_word := get_byte;
  check_word := check_word + get_byte*256;
  IF check_word<>check_sum THEN
    get_end_packet := failure
  END
END; { get_end_packet }

check (arg1, arg2);

{ Computes the 16 bit checksum of arg1 and arg2, using end-
around carry technique of TU58 }

BEGIN
  { The function 'carry' returns a value of
  1 if the sum of the arguments results in
  a carry; a value of 0 is returned otherwise }

  check := arg1 + arg2 + carry(arg1,arg2)
END; { check }

{ End of algorithm definitions }

```

CHAPTER 4 INSTALLATION

4.1 INTRODUCTION

This chapter contains installation, configuration, and checkout procedures for all the versions of the TU58 DEctape II (-DA, -CA, -EA, -EB, -VA components).

4.2 RACK INSTALLATION (-DA Version)

4.2.1 Rackmount

The TU58-DA mounts in 13.2 cm (5.2 in) of standard 48.3 cm (19 in) width rack. It should be located so that the 2 m (6 ft) power cord can reach a power controller outlet box such as the DIGITAL 861 or any power outlet.

4.2.2 Unpacking

The TU58-DA shipping carton contains the following items for rackmounting.

- 1 TU58-EB
- 1 Bezel
- 2 Mounting brackets
- 2 Support brackets
- 2 Support bracket extenders
- 24 Phillips trusshead screws 10-32 \times 1/2 in
- 24 Internal lock washers
- 12 U-Nut retainers
- 6 Kep lock nuts 10-32 \times 3/8
- 1 Line cord (120 V)
- 2 Fuses (3/8 A and 3/4 A slow-blow)

4.2.3 Power Selection


Detachable line cords for 115 V and 230 V, and two fuses are supplied with the TU58-DA. The line cord receptacle meets European IEC standards. A switch on the back of the tape drive rear panel selects 115 V or 230 V (Figure 4-1).

1. Set the voltage switch to the correct value using a small screwdriver.

Switch Position	Voltage	Range
Left	115 V	90 – 128 Vrms
Right	230 V	180 – 256 Vrms

CAUTION

If the TU58 is plugged into a 230 V circuit while set for 115 V, it may be severely damaged.



MA-7630-83

Figure 4-1 TU58-DA Rear Panel

- From the two fuses provided, select and install the proper fuse in the fuse post. To open the fuse post, use a 3/16-inch blade type screwdriver. Press in the fuse post cap and turn it counterclockwise. To close the fuse post, use the screwdriver to press in the cap and turn it clockwise.

Voltage	Fuse
115 V	3/4 A slow-blow
230 V	3/8 A slow-blow

4.2.4 Removing Bottom Plates for Controller Board Configuration

The TU58 is shipped prewired for operation at 38.4K baud transmit and receive on RS-423. If a configuration change is necessary, the bottom plates must be removed in order to gain access to the controller board. Use the following procedure to remove the bottom plates. (See Paragraph 4.7 for configuration information.)

- Disconnect the power cord and interface cable from the rear panel of the TU58 (Figure 4-1).
- Place the TU58 upside-down on a flat working surface so the rear panel faces you.
- Remove the two Phillips head screws and lock washers from the front plate. Remove the front plate, exposing the two tape drives.
- Remove two Phillips head screws and lock washers from the bottom of the rear plate and one flat Phillips head screw from the rear panel at the left side of the interface cable connector. Remove the power supply assembly by lifting it out of the housing (with internal cables still attached) and placing it rightside-up next to the TU58.

4.2.5 Rackmounting Procedure

The following procedure enables one person to install the TU58-DA in the rack using a number 2 Phillips screwdriver.

- With the power cord and interface cable removed (Figure 4-1), carefully place the TU58-DA upside-down on a flat working surface so the front of the device is facing you.
- Remove the rubber feet if attached by removing the screws that hold them in place (Figure 4-1). Refer to Figure 4-2 and align the two support brackets on the bottom of the TU58-DA so they are flush with the left side. Fasten down the right side of each support bracket with two screws and two lock washers.




Figure 4-2 Installing Support Brackets

3. Fasten the mounting bracket to the left side of the TU58-DA with two screws and two lock washers so the ball stud faces forward (bend in bracket toward center of TU58-DA). Install the other mounting bracket in the same manner using two screws, two lock washers, and two lock nuts to secure it to the support brackets (Figure 4-3).
4. Attach four U-Nut retainers (two per side) to the front vertical rails (Figure 4-4). Refer to Figure 4-5 and position U-Nut retainers at the desired height for the TU58-DA.
5. Open the back of the rack. Attach four U-Nut retainers to the rear vertical rails (Figure 4-6).
6. If a non-DIGITAL rack is used, fasten the support bracket extenders to the rear vertical rails with four screws, four lock washers, and four lock nuts. Use two per side in the top and bottom holes (Figure 4-7).
7. Turn the TU58-DA rightside-up and while supporting it with one hand, place it into position in the rack.

NOTE

Be sure the mounting brackets are to the inside of the rear vertical rails.

8. Fasten the mounting brackets to the front vertical rails with four screws and four lock washers (two per side in the top and bottom holes).

CAUTION

Install the two bottom screws first to avoid bending the mounting ears.

9. For DIGITAL racks, fasten the mounting brackets to the rear vertical rails (Figure 4-6). For non-DIGITAL racks, fasten the mounting brackets to the support bracket extenders (Figure 4-7).
10. Attach the power cord and interface cable and connect to the appropriate device or receptacle. Close the back of the rack.
11. Install the bezel by pushing into place over the ball studs (Figure 4-8).




Figure 4-3 Installing Mounting Brackets




Figure 4-4 Front Vertical Rail U-Nut Retainers




Figure 4-5 Rackmounting the TU58-DA




Figure 4-6 Rear Vertical Support U-Nut Retainers





Figure 4-7 Fastening Support Bracket Extenders



MA-6466

Figure 4-8 Installing the Bezel

4.3 RACK INSTALLATION (-CA Version)

4.3.1 Rackmount

The TU58-CA rackmount unit mounts in 13.2 cm (5.2 in) of standard 48.3 cm (19 in) width rack. It should be located so that the 2 m (6 ft) power cord can reach a power controller outlet box such as the DIGITAL 861 or any power outlet.

To get to the mounting holes, remove the bezel (Figure 4-9) by gripping it at the top and bottom with both hands. Rotate it out from the bottom and lift it away. If the unit is installed in a recessed rack, the bezel may be removed by gripping it with both hands on the left edge with fingers or thumbs inside the storage well. Pull sharply out and swing the bezel away.

WARNING
Metal bezels are heavy!

If the rack requires them, install four U-Nut retainers at the holes spaced according to Figure 4-10. The TU58 is light enough for one person to install. Put the two bottom screws in first to avoid bending the mounting ears.




Figure 4-9 Bezel and Ball Stud

Four brackets and hardware are included with the TU58-CA to support the back end of the chassis in a rack. Use the two long brackets for DIGITAL cabinets. The short brackets are extenders for the long brackets used in non-DIGITAL cabinets. Attach the long brackets to the chassis with the existing power supply screws, and attach to the side rails of the rack with the supplied clipnuts and screws. Hardware is also provided to fasten the extender to the long bracket if required. The bend on the long bracket should point to the center of the rack while the bend on the extender should point to the outside of the rack.

4.3.2 Power Selection for the Rack Version

Line cords for 110 V and 220 V and two fuses are supplied with the TU58-CA. The chassis power receptacle meets European IEC standards. A switch on the back of the rackmount cabinet selects 110 V or 220 V (Figure 4-11).

1. Set the switch to the correct value using a small screwdriver.

CAUTION

If the unit is plugged into a 220 V circuit while set for 110 V, it may be severely damaged.

2. Install a fuse in the fuse post.

NOTE

A 3/8 Amp slow-blow fuse is required for 220 V, a 3/4 Amp slow-blow fuse for 110 V.

3. Insert the appropriate power cord into the receptacle. Do not plug it into an outlet until the installation is complete.




Figure 4-10 Rackmounting the TU58-CA




Figure 4-11 TU58-CA Rear Panel

4.3.3 Removing Module from Chassis

Refer to Figure 4-12 and perform the following steps.


1. Disconnect the power cord.
2. Remove the bezel.
3. Twist a coin or screwdriver in the gap between the retainer bar and the lip of the chassis. Lift the bar out of the chassis and set it aside.
4. Pull the cage toward you a few inches and turn it to the right. Slide the module out an inch or two and reach in at the back of the cage to remove the power and communication cables from the module connectors. Remove the cage entirely from the chassis and put it on a stable work surface.
5. Reach in again at the back of the cage and remove the drive cables from their connectors on the module.
6. Now slide the module out of the cage.

CAUTION

Be careful around the thin tachometer disk. It is easily bent (and its edge is sharp). If the disk gets bent without creasing, it might be straightened with pliers. Alignment is not critical, but it is better if the disk does not rub against the optical sensor block. If it cannot be aligned, or if it is creased, it must be replaced.

4.3.4 Reinstalling the Module

1. With the connector edge facing into the cage, slide the module partially into the cage along the card guides.
2. Install the drive cables onto their connectors. Note that the drive cables cross each other, with the left drive cable going to the right connector (as you look into the open end of the cage).



MA-5284

Figure 4-12 Installing Cage and Retainer Bar

3. Place the cage partially in the chassis and run the power and communication cables up to the module onto their connectors.
4. Slide the module all the way into the cage and set the cage into the hooking tabs stamped into the bottom of the chassis.
5. Align the retainer bar parallel to the floor of the chassis, with the spring on top. Engage the two slots with the vertical sheet metal of the cage at the middle of the cutaways. Press each end of the bar away and down, one at a time, so that the ends catch the lip of the chassis and the bar holds the cage in place in the chassis. The module should sit in the cage with its edge just clear of the retainer bar springs.
6. Replace the bezel and power cord.

4.4 INSTALLATION (-EA AND -EB VERSIONS)


The TU58-EA and -EB are tabletop units that require a minimum amount of space. Detachable line cords for 115 V and 230 V and two fuses are supplied with the TU58-EB; only the 115 V cord and fuse are supplied with the -EA. The cords are 6 ft long, enabling you to place the TU58 on a desk, tabletop, or a convenient location within reach of a power outlet. See Paragraph 4.2.3 for the correct power selection information and Paragraph 4.2.4 for controller board configuration.

4.4.1 Tabletop Installation

1. Disconnect the power cord and interface cable from the rear of the TU58 (Figure 4-1).
2. Place the TU58 upside-down on a flat working surface.
3. Install the four rubber feet using the four 1.3 cm (1/2 in) Phillips head screws to secure them to the bottom plates (Figure 4-13).
4. Turn the TU58 rightside-up and place it in the desired location.
5. Connect the power cord, interface cable, and cable shield wire to the rear panel.

4.4.2 Solid Mounting Installation

1. Perform steps 1 and 2 as above.
2. Install the four mounting brackets (bend facing the side of the TU58 housing) using the four 1.3 cm (1/2 in) Phillips head screws and lock washers to secure them to the bottom plates (Figure 4-13).
3. Turn the TU58 rightside-up and place it in the desired location.



MA-6471

Figure 4-13 Mounting the TU58-EA and -EB

4. Fasten the unit to the mounting surface using four screws through the holes of the mounting bracket bends.

NOTE

The four screws needed to secure the unit to the mounting surface are not supplied with the TU58.

5. Connect the power cord, interface cable, and cable shield wire to the rear panel.

4.5 INSTALLATION (-VA VERSION)

The TU58-VA is a tabletop unit that requires a minimum amount of space and can be placed in a convenient location within reach of a dc power source. (See Paragraph 1.4.2 for power requirements.) In addition, the TU58-VA can mount to the SB11 (or BA11-VA) if so desired.

NOTE

If reconfiguration is necessary, see Paragraph 4.2 before installing the TU58-VA.

4.5.1 Tabletop Installation

See Paragraph 4.4.1 for installation procedure.

4.5.2 Solid Mounting Installation


See Paragraph 4.4.2 for installation procedure.

4.5.3 Mounting the TU58-VA to the SB11 (or BA11-VA)

1. Attach the four rubber feet to the TU58-VA as described in Paragraph 4.4.1, steps 1 through 4. (If solid mounting is desired, order hardware kit PN 70-16753-00).
2. Place the SB11 (or BA11-VA) upside-down on a flat working surface.
3. Remove the rubber feet from the SB11 (or BA11-VA) if attached by removing the screws securing them to the bottom. Fasten the four brackets to the bottom (bend on the outside edge) using four screws and lock washers (Figure 4-14).
4. Position the SB11 (or BA11-VA) rightside-up over the TU58-VA so the mounting brackets line up with the holes on the side of the TU58-VA. Fasten to the TU58-VA using four screws and lock washers (Figure 4-14).
5. Referring to Figure 4-15, connect the interface cables and power cord to their respective locations.

4.6 COMPONENTS

Figures 4-16 and 4-17 provide the mounting dimensions for the circuit board and drive mechanism. The drive has a 19 cm (7.5 in) cable which plugs into the board connector with the wires coming out of the plug toward the center of the board. The plug is keyed to ensure proper orientation. The cartridge extends 1.60 cm (0.62 in) from the front of the drive. If the drive is recessed in a panel, clearance must be provided around the opening for fingers to grip the cartridge. Ideally, the cartridge slot in a front panel is somewhat larger than minimum, to allow easy insertion. The opening should be at least the dimensions of the cartridge, 1.3 cm (0.5 in) × 8.1 cm (3.2 in), located not more than 0.53 cm (0.17 in) above the bottom mounting surface (line A in Figure 4-16). The drive must be free to float on its mounting screws, so bezels or panels must not touch the drive.



MR-4333
MA-6641

Figure 4-14 Mounting Choices for the TU58-VA





Figure 4-15 Interfacing the TU58-VA



MA-2369

Figure 4-16 Drive Outline Drawings




Figure 4-17 Board Outline Drawings

The board should be mounted on a flat surface with 3 mm (4-40) hardware and 1 cm (3/8 in) standoffs. Both the board and the drive may be mounted at any angle. For mounting the drives to a surface above the drives, 1.80 cm (0.71 in) clearance is required; hole spacing is given in the outline drawings. For mounting the drives to a surface below the drives, an 8.18 cm (3.22 in) × 8.89 cm (3.50 in) chassis cutout is required, with the same mounting hole spacing.

CAUTION

The mounting surface for the drives must be flat within 0.64 cm (0.025 in).

Mounting hardware is included with each drive. There is a shoulder screw, spring, and flat washer for each of the four mounting holes. Figure 4-18 shows one assembly; in addition to the flatness specification for the mounting surface, there is a specification for the depth of the shoulder screw in the mounting surface. To prevent extra compression of the spring, the shoulder screw should meet the top of the mounting surface. Any tapering of the mounting hole must be limited so that at the screw's diameter of 0.419 cm (0.165 in) the edge of the shoulder is not more than 0.076 cm (0.030 in) below surface.

4.7 INTERFACE STANDARDS SELECTION AND SETUP

The TU58 is shipped with factory-installed jumpers for a transmission rate of 38.4K baud and the RS-423 unbalanced line interface. A variety of standards and rates may be selected by changing the jumpers on the controller board. Table 4-1 provides a list of all the pins on the board and their functions, including the wire-wrap (WW) pins, interface, and power connectors.




Figure 4-18 TU58 Drive Mounting Hardware

4.7.1 Selecting Interface Standards

The serial interface operates on full-duplex, asynchronous, 4-wire lines at rates from 150 baud to 38.4K baud. The transmit and receive rates may be independently set. Each 8-bit byte is transmitted with one start bit, one stop bit, and no parity. The line driver and receiver may be set to operate in accordance with EIA RS-422 balanced or RS-423 unbalanced signal standards. When set to RS-423, the TU58 is compatible with devices complying with RS-232-C.

The TU58 is shipped prewired for operation at 38.4K baud transmit and receive on RS-423. The maximum wire length that may be used at that data rate in an electrically quiet environment like an office is approximately 27 m (90 ft). The wire used with any installation should be no less than 24 AWG diameter.

Longer wire runs may be made if data rates are reduced. RS-422 is considerably more noise-immune than RS-423 and can be used over at least 1200 m (4000 ft) at any TU58 data rate. Figure 4-19, derived from the EIA standards, illustrates the variations in distance needed by RS-423 for different data rates. For more information, consult the standards for RS-422 and RS-423 published by the Electronic Industries Association.

Table 4-1 TU58 Module Connections

Wire-Wrap Pins

WW1	150 Baud	
WW2	300 Baud	
WW3	600 Baud	
WW4	1200 Baud	
WW5	2400 Baud	
WW6	4800 Baud	
WW7	9600 Baud	
WW8	19200 Baud	
WW9	38400 Baud	
WW10	UART Receive Clock Input	
WW11	UART Transmit Clock Input	
WW12	Auxiliary A (to interface connector pin 1)*	
WW13	Auxiliary B (to interface connector pin 10)*	
WW14	Factory Test Point	
WW15	Ground	} Connect together for auto-boot on power-up.
WW16	Boot	
WW17	RS-423 Driver	
WW18	RS-423 Common (Ground)	
WW19	Transmit Line+	
WW20	Transmit Line-	
WW21	RS-422 Driver+	
WW22	RS-422 Driver-	
WW23	} Receiver Series Resistor (Jump for RS-422)	
WW24		

Serial Interface Connector

J2-10	Auxiliary B	J2-5	Ground
J2-9	Ground	J2-4	Transmit Line-
J2-8	Receive Line+	J2-3	Transmit Line+
J2-7	Receive Line-	J2-2	Ground
J2-6	Key (no connection)	J2-1	Auxiliary A

Power Input Connector

J1-1	+12 V
J1-3	Ground
J1-5	+5 V
J1-6	Ground

Drive Cable

J3,4-1	Cart L	J3,4-9	LED
J3,4-2	No Connection	J3,4-10	Head Shield Ground
J3,4-3	Permit L	J3,4-11	Erase Return
J3,4-4	Signal Ground	J3,4-12	Erase 1
J3,4-5	Motor+	J3,4-13	Erase 0
J3,4-6	Motor-	J3,4-14	Head Return
J3,4-7	+12 V	J3,4-15	Head 0
J3,4-8	Tachometer	J3,4-16	Head 1

* For optional use, such as timing signals from baud clocks.




Figure 4-19 Data Rate and Cable Length for RS-423

4.7.2 Connecting Standards Jumpers

The jumper pins are standard 0.635 mm (0.025 in) wire-wrap posts which may be connected using 30 AWG wire and a hand tool. Other techniques that may be used include slip-on connectors, such as DIGITAL 915 patchcords, 917 daisy-chain, or soldering.

The baud rates may be set independently for transmission and reception, or both can operate together. Simply connect the pin with the desired baud value to either the XMIT or RCV pins or both. Figure 4-20 illustrates the pin locations, and Figure 4-21 the factory-wired configuration.

The interface standards may be selected by connecting sets of pins together. The connections are listed in abbreviated form in Figure 4-20. The group of pins 17 through 24 are the interface pins. The module is shipped prewired for RS-423 with pin 17 connected to pin 19, and pin 18 connected to pin 20. No other pins in the group are connected.

For RS-422, pin 21 should be tied to pin 19, pin 22 to pin 20, and pin 23 to pin 24. No other pins in the group are connected.

4.8 OPERATIONAL CHECKOUT

A confidence check of the operation of the newly installed TU58 may be performed through the console or keyboard console emulator of a host system without the use of an operating system device handler. The light on the TU58 board should be on, indicating a functional processor.

4.8.1 Checkout of Interface

To address the serial interface device registers with the console (consult the system manuals for address and codes), perform the following steps.

1. Set the transmit control status register to send Break to the TU58.
2. Remove the Break condition.
3. Transmit INIT: 04 (octal) to the TU58.
4. Transmit a second 04.
5. Examine the receive data buffer to find Continue: 20 (octal)





Figure 4-20 Interface Selection Jumper Pin Locations

DLV11-A (M7940)

Jumper	Setting	Value
A3	I	
A4	I	
A5	I	
A6	R	I76500 (address)
A7	I	
A8	R	
A9	I	
A10	R	
A11	R	
A12	R	
V3	I	
V4	I	
V5	I	300 (vector)
V6	R	
V7	R	
FR0	I	9600 (baud rate)
FR1	I	
FR2	I	
FR3	R	
NP	R	
2SB	I	
NB2	R	
NB1	R	
PEV	X	
FEH	R	
EIA	I	
CL1	X	
CL2	X	
CL3	X	
CL4	X	

DLV11-E (M80I7)

Jumper	Setting	Value
A3	R	
A4	R	
A5	R	
A6	I	
A7	R	I76500 (address)
A8	I	
A10	I	
A11	I	
A12	I	

DLV11-E (M8017) (Cont)

Jumper	Setting	Value
V3	R	
V4	R	
V5	R	300 (vector)
V6	I	
V7	I	
V8	R	
R0	I	
R1	R	
R2	R	
R3	R	9600 (baud rate)
T0	X	
T1	X	
T2	X	
T3	X	
BG	I	
P	R	
E	X	
1	R	
2	R	
PB	R	
C	I	
C1	I	
S	R	
S1	R	
H	R	
B	R	
-B	I	
-FD	I	
-FR	I	
RS	R	
FB	R	
M	R	
M1	R	

DLV11-F (M8028)

Jumper	Setting	Value
A3	R	
A4	R	
A5	R	
A6	I	
A7	R	176500 (address)
A8	I	
A9	R	
A10	I	
A11	I	
A12	I	

DLV11-F (M8028) (Cont)

Jumper	Setting	Value
V3	R	
V4	R	
V5	R	300 (vector)
V6	I	
V7	I	
V8	R	
R0	I	
R1	R	
R2	R	
R3	R	9600 (baud rate)
T0	X	
T1	X	
T2	X	
T3	X	
BG	I	
P	R	
<u>E</u>	X	
1	R	
2	R	
PB	R	
C	I	
C1	I	
S	R	
S1	R	
H	R	
<u>B</u>	R	
<u>B</u>	I	
1A	X	
2A	X	
3A	X	
4A	X	
5A	X	
1P	X	
2P	X	
3P	X	
4P	X	
EF	I	
M	R	
M1	R	
MT	R	

DLV11-J (M8043)

Use channel 0 of the factory-configured module for the TU58 interface. Change the baud rate for channel 0 from 9600 to 38400 by removing the jumper from O to N and connecting O to Z. Refer to Figure 4-23. Channel 0 is now compatible with the factory-configured TU58 with address 176500 and vector 300.




Figure 4-23 DLV11-J Factory Configuration Summary

MXV11-A (M8047)

Use channel 0 on factory-configured interface (address 176500 and vector 300). Refer to Figure 4-24 and Table 4-2




Figure 4-24 MXV11-A Jumper Locations

Table 4-2 MXV11-A Standard Factory Configuration

Function		Wire-Wrap From	Pins To	Level
RAM bank 0		J30	J31	L1
		J32	J33	L1
		J31	J32	L2
SLU CH0, address 177560		J23	J18	L1
		J24	J19	L1
SLU CH1, address 177560		J28	J10	L2
		J26	J15	L1
		J25	J14	L1
		J27	J13	L1
ROM bootstrap (TU58)		J37	J38	L1
		J21	J22	L1
		J34	J37	L2
		J33	J39	L2
		J29	J15	L2
SLU vectors	CH0(300)	J53	J57	L1
	CH1(60)	J54	J52	L1
		J56	J51	L1
		J54	J55	L2
SLU parameters (eight data bits, no parity bit, one stop bit)		J59	J61	L1
		J62	J64	L1
		J60	J63	L1
		J61	J62	L2
		J59	J66	L2
	J63	J65	L2	
Baud rates	CH0(38400)	J45	J50	L1
	CH1(9600)	J46	J48	L1
Bread generation (Half option)		J6	J7	L1
Crystal clock		J68	J67	L1

DL11-D (M7800 or M7800-YA)

Jumper	Setting	Value
A3	I	
A4	I	
A5	I	
A6	R	176500 (address)
A7	I	
A8	R	
A9	I	
A10	R	
V3	I	
V4	I	
V5	I	300 (vector)
V6	R	
V7	R	
V8	I	

Baud rate switches

Position 8 for 9600 baud receive and transmit with speed group 4 crystal (4608 MHz).

NP	R
2SB	I
EPS	X
NB2	R
N1	I
J1	I
N2	R
J3	R
J4	I
J5	I
J6	R
J7	R
J8	I
J9	R
J10	I
J11	R

DL11-E (M7800)

Jumper	Setting	Value
A3	I	
A4	I	
A5	I	
A6	R	176500 (address)
A7	I	
A8	R	
A9	I	
A10	R	
V3	I	
V4	I	
V5	I	300 (vector)
V6	R	
V7	R	
V8	I	

Baud rate switches:

Position 8 for 9600 baud receive and transmit with speed group 4 crystal (4608 MHz).

NP	R
2SB	I
EPS	X
NB1	R
NB2	R
N1	I
J1	I
J2	R
J3	R
J4	R
J5	I
J6	I
J7	I
J8	I
J9	R
J10	I
J11	R

DL11-W (M7856)

(address 176500, vector 300, speed 9600 baud)

Switch Pack	Switch Number	Position
1		Not used (Switch placement unspecified)
2	1	X
	2	X
	3	Off
	4	Off
	5	On
	6	Off
	7	On
	8	Off
3	1	On
	2	On
	3	Off
	4	Off
	5	On
	6-10	X
4	1	On
	2	X
	3	Off
	4	Off
	5	On
	6	Off
	7	Off
	8	X
	9	X
	10	Off
5	1	Off
	2	On
	3	Off
	4	On
	5	Off
	6	On
	7	On
	8	On
	9	On
	10	Off

4.8.3 Checkout of Drive Command Function

1. Insert a tape cartridge into drive 0 (left side). (The TU58 should have sent Continue (20g) already.)
2. Transmit the following string of octal numbers to the TU58. (Consult the programming chapter for an explanation of this format.)

2
12
2
0
0
0
0
0
0
200
200
0
204
212

The TU58 should wind to the beginning of the tape and read about half of the tape. If it does not work, see Table 2-1, under "TU58 does not respond to host."

CHAPTER 5 OPTIONS

5.1 RUN INDICATOR

Each tape drive may have an LED indicator which lights to show tape motion. Since data loss can occur if a cartridge is removed while the tape is being written, the cartridge should not be touched if the indicator is on.

5.1.1 Installation

The indicator (which may be any device capable of handling 30 mA with a forward voltage less than 1.8 V) is wired in series with the tachometer source indicator. Splice the run indicator into the wire from pin 7 of the drive connector. (Count from the end with the missing pin; that pin is number 2.) The anode should be on the board side of the wire (symbol arrow pointing away from pin 7, Figure 5-1). The indicator is available from DIGITAL (PN 11-10324), and wires with slip-on connectors are available to join the indicator to the tach (cable number 70-16526) and to extend the board connector end to the indicator at the front of the drive (cable number 70-16525).




Figure 5-1 Installation of Run Indicator

5.2 BOOT SWITCH

5.2.1 General

Special provision has been made for interfacing the TU58 to the LSI-11 ODT keyboard interpreter. The TU58 is placed at the system console address and vector, permitting it to "type" in a program using keyboard ODT. This means that a keyboard cannot be connected at the same time. This arrangement is useful in an unattended control system, where the TU58 can automatically load and start or reload and restart an unsupervised process controller or similar application. The Boot switch allows a manual reboot without powering down to cycle the automatic sequence.

NOTE

Boot mode does not work in any DIGITAL operating system environment.

5.2.2 Operation

When the boot switch is connected according to Paragraph 5.2.3, the TU58 operates in the following manner.

1. On power-up, the TU58 checks for the presence of the closed switch. It then delays one second and begins the boot procedure.
2. When the TU58 is in the idle state, it monitors the Boot switch. Any switch contact open-close sequence causes a one-second delay (to allow for contact settling or to allow the host processor to enter the halt mode), and then the TU58 begins the boot procedure.

The boot procedure positions the tape in drive 0 to block 0, sends Break to the host, and transfers ASCII characters from the tape to the host. A delay is inserted between characters to allow for the echo from the LSI-11. If the character sent is ASCII 0 - 7, this delay is one character time at 9600 baud. Any other character is interpreted as a control character, and time is allowed for 15 characters of echo. The TU58 exits the boot mode following the transfer of the terminating character ASCII G (147₈) and enters the idle state. Because of the timing requirement, only rates of 9600, 19.2, and 38.4K baud may be used with boot.

5.2.3 Installation

The boot pin on the board (WW16) may be connected to ground through a normally closed momentary action switch. Wires may be wire-wrapped, DIGITAL 915 patch-corded, or soldered to the pins. Placement of the switch and lead dress are not critical if adequate clearance is provided around moving parts of the drive and the heat sink and power resistors on the module.

The boot tape contents are formatted to appear to the LSI-11 as output from a console (keyboard) operating under the ODT keyboard interpreter.

APPENDIX A TU58/PDP-11 TOGGLE-IN BOOT

This boots drive 0 only.

1000/012701
1002/176500
1004/012702
1006/176504
1010/010100
1012/005212
1014/105712
1016/100376
1020/006300
1022/001005
1024/005012
1026/012700
1030/000004
1032/005761
1034/000002
1036/042700
1040/000020
1042/010062
1044/000002
1046/001362
1050/005003
1052/105711
1054/100376
1056/116123
1060/000002
1062/022703
1064/001000
1066/101371
1070/005007

APPENDIX C SAMPLE DEVICE HANDLERS

```

CCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCC
C
C      TTTTTT U      U 5555555 88888      C
C      T U      U 5      8      8      F O R T R A N      C
C      T U      U 5      8      8      S U P P O R T      C
C      T U      U 555555 88888      P A C K A G E      C
C      T U      U      5 8      8      C
C      T U      U      5 8      8      C
C      T      UUUUUUU 555555 88888      C
C
CCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCC

```

The following program listing contains a complete TU58 device handler package written entirely in PDP-11 FORTRAN IV. When used with the RT-11 FORTRAN IV compiler and object-time system, it can be built into ROM/PROM/EPROM based LSI-11 microcomputer applications.

The program implements four user-program callable entry points:

```

ierror = TUREAD( unit, block, buffer, bytecount )

      Read "bytecount" bytes from the TU58 drive specified by
      unit "unit" into the data area specified by "buffer",
      starting at random-access block "block" on the cartridge.

```

```

ierror = TUWRIT( unit, block, buffer, bytecount )

      Write "bytecount" bytes from the data area specified by
      "buffer" onto TU58 drive "unit", starting at the random-
      access block noted by "block".

```

```

ierror = TUSEEK( unit, block )

      Position the TU58 cartridge located in drive "unit" at
      the random-access block specified by "block".

```

```

ierror = TUDIAG( )

      Run the TU58 internal controller diagnostic function.

```

In all four cases, the functions return a standard set of error codes, as follows:

ierror value	meaning of error code
0	Normal success
1	Success, but retries were required
-1	TU58 failed self-test (TUDIAG)
-2	Partial operation (end-of-medium encountered)
-8	Invalid unit number was specified
-9	No cartridge is mounted in specified drive
-11	Specified cartridge is write-protected (TUWRIT)
-17	Data check error on cartridge

```

C          -32      Seek error (block not found)
C          -33      Motor stopped (TU58 hardware error)
C          -48      Invalid operation code (error in this program)
C          -55      Invalid record number (bad block number passed)
C          -127     Communications error between host and TU58
C
C          This software assumes that the TU58 controller is interfaced
C          through a DLV11, DLV11-J, DLV11-E, DLV11-F, or MXV11 interface
C          which has a receiver CSR address assignment of 176500(8).
C
C          The software operates the interface in a non-interrupt-driven
C          mode only for simplicity.
C
C          This program is neither licensed nor supported by Digital
C          Equipment Corporation, and may be copied or modified for use
C          on any computer system. Digital assumes no responsibility for
C          its reliability on any hardware, Digital-supplied or otherwise.
C
CCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCC
C
C          INTEGER FUNCTION Tudiag
C
C          Runs TU58 controller diagnostic function, returning success
C          code as function result.
C
C          IMPLICIT INTEGER (a-z)
COMMON /cmdpkt/ packet(6)
C
C          Initialize a command packet with the DIAGNOSE operation code.
C
C          Tudiag = Init(7)
C          IF (Tudiag.ne.0) GOTO 100
C
C          Now transmit the packet to the TU58 controller.
C
C          CALL Sndpkt(packet,12,0)
C
C          And ask for the results of the diagnostic in the end packet.
C
C          Tudiag = Getend(0)
100      RETURN
C          END

C
C          INTEGER FUNCTION Tuseek( unit, block )
C
C          Positions cartridge in "unit" to random-access block specified
C          by "block", returning the success code from the TU58 controller
C          as the function result.
C
C          IMPLICIT INTEGER (a-z)
COMMON /cmdpkt/ packet(6)
C
C          Initialize a command packet with the POSITION operation code
C
C          Tuseek = Init(5)
C          IF (Tuseek.ne.0) GOTO 100
C          packet(3) = unit
C          packet(6) = block
C
C          Transmit the command to the TU58 controller
C
C          CALL Sndpkt(packet,12,0)
C
C          And ask for the status of the operation from the end packet
C
C          Tuseek = Getend(0)
100      RETURN
C          END

```

```

C      INTEGER FUNCTION Turead( unit, block, buffer, bytcnt )
C
C      Reads "bytcnt" bytes from the TU58 drive selected by "unit"
C      into the data area specified by "buffer", starting at random-
C      access block "block" on the cartridge. Returns the success
C      code from the TU58 controller as the function result.
C
C      IMPLICIT INTEGER (a-z)
C      BYTE buffer(bytcnt), bword(2)
C      COMMON /cmdpkt/ packet(6)
C      EQUIVALENCE (iword,bword)
C
C      Build a READ command packet and send it to the TU58 controller
C
C      Turead = Init(2)
C      IF (Turead.ne.0) GOTO 500
C      packet(3) = unit
C      packet(5) = bytcnt
C      packet(6) = block
C      CALL Sndpkt(packet,12,0)
C      index = 1
C
C      Read the next data packet from the TU58
C
C      10      chksum = Getbyt()
C      IF (chksum.ne."001") GOTO 400 !Proceed to 400 if not data packet
C      datcnt = Getbyt()
C      chksum = chksum + datcnt*256
C      odd = 0
C      DO 100, i=1,datcnt
C      odd = .not.odd
C      IF (odd.eq.0) GOTO 50
C      bword(2) = 0
C      bword(1) = Getbyt()
C      buffer(index) = bword(1)
C      GOTO 100
C      50      bword(2) = Getbyt()
C      chksum = Check(chksum,iword)
C      buffer(index) = bword(2)
C      100     index = index + 1
C      IF (odd.ne.0) chksum = Check(chksum,iword)
C      bword(1) = Getbyt()
C      bword(2) = Getbyt()
C      IF (chksum.ne.iword) GOTO 500
C      GOTO 10
C
C      Found packet which is not data packet; try for end packet
C
C      400     Turead = Getend(chksum)
C      500     RETURN
C      END
C
C      INTEGER FUNCTION Twrit( unit, block, buffer, bytcnt )
C
C      Writes "bytcnt" bytes from data area specified by "buffer"
C      to TU58 drive "unit", starting at random-access block "block".
C      Returns success code from TU58 controller as function result.
C
C      IMPLICIT INTEGER (a-z)
C      BYTE buffer(bytcnt), bword(2)
C      COMMON /cmdpkt/ packet(6)
C      EQUIVALENCE (iword,bword)
C
C      Construct a WRITE command packet and transmit it to the TU58
C
C      Twrit = Init(3)
C      IF (Twrit.ne.0) GOTO 500
C      packet(3) = unit
C      packet(5) = bytcnt
C      packet(6) = block
C      CALL Sndpkt(packet,12,0)

```

```

C
datcnt = bytcnt
C
C Prepare to transmit a new data packet by checking for CONTINUE
C flag
C
10 chksum = Getbyt()
IF (chksum.ne."020) GOTO 400 !Proceed to 400 if not CONTINUE
CALL Putbyt("001) !Transmit data packet flag
count = Min0(datcnt,128) !Make packets maximum 128 bytes
CALL Putbyt(count) !Output byte count for packet
CALL Sndpkt(buffer(bytcnt-datcnt+1),count,count*256+"001)
datcnt = datcnt - count
GOTO 10
C
C Received flag was not a CONTINUE. Try for END packet.
C
C
400 Twrit = Getend(chksum)
C
500 RETURN
END

```

```

INTEGER FUNCTION Check( i, j )
C
C Computes 16-bit checksum of i and j, using end-around carry
C technique for TU58. Sum is returned as function value.
C
C IMPLICIT INTEGER (a-z)
C
C check = i + j
C
C If neither input operand has high-order bit set, no carry
C is possible
C
C IF ( (i.or.j).ge.0 ) GOTO 200
C
C If both inputs have high-order bit set, a carry is always
C generated
C
C IF ( (i.and.j).lt.0 ) GOTO 100
C
C If only one has high-order bit set, then a carry occurred
C only if the sum does not have its high-order bit set
C
C IF ( check.lt.0 ) GOTO 200
C
C Perform end-around carry if required
C
100 check = check + 1
200 RETURN
END

```

```

INTEGER FUNCTION Getbyt
C
C Gets next byte from the serial interface connecting the
C TU58 controller to the host machine.
C
C IMPLICIT INTEGER (a-z)
C
C wait for input character available (DONE flag set)
C
10 IF ( (Ipeek("176500).and."200).eq.0 ) GOTO 10
C
C Get character from data buffer and remove extraneous bits
C
Getbyt = Ipeek("176502).and.255
C
222 WRITE(6,222)GETBYT
FORMAT(' R',03)
RETURN
END

```

```

SUBROUTINE Putbyt( outbyt )
BYTE OUTBYT
C
C Writes a byte to the serial interface connecting the TU58
C controller to the host machine.
C
IMPLICIT INTEGER (a-z)
C
C Wait for output interface ready (DONE bit set)
C
C IF ( (Ipeek("176504).and."200).eq.0 ) GOTO 10
10
C Transmit character by moving it to data buffer register
C
CALL Ipoke("176506,outbyt)
C WRITE(6,222)OUTBYT
222 FORMAT(' T',03)
RETURN
END

INTEGER FUNCTION Init( opcode )
C
C Initializes TU58 controller for operations.
C Returns 0 if properly initialized, -127 otherwise.
C
IMPLICIT INTEGER (a-z)
COMMON /cmdpkt/ packet(6)
C
C Initialize command packet area with opcode specified
C
C
Init = 0
packet(1) = 10*256 + "002
packet(2) = opcode
packet(3) = 0
packet(4) = 0
packet(5) = 0
packet(6) = 0
C
C Loop to allow eight retries of entire initialization
C procedure
C
C DO 50, J=1,8
C
C Set BREAK bit in output serial interface (XCSR)
C
C CALL Ipoke("176504,"000001)
C
C Wait for BREAK to cause framing error in TU58 by
C transmitting eight NUL characters under it
C
C DO 10, I=1,8
10 CALL Putbyt("000)
C
C Remove BREAK condition on output interface
C
C CALL Ipoke("176504,"000000)
C
C Discard any (possibly erroneous) character in input buffer
C
C idummy = Ipeek("176502)
C
C Output two INIT commands to TU58 controller
C
C CALL Putbyt("004)
C CALL Putbyt("004)
C
C Wait for & check for CONTINUE flag in response
C
C IF ( Getbyt().eq."020 ) GOTO 100
50 CONTINUE
C

```

```

C      If no success after eight retries, report error
C
C      Init = -127
100    RETURN
      END

      SUBROUTINE Sndpkt(buffer,bytcnt,chkini)
C
C      Transmits a command or data packet to the TU58 controller,
C      sending "bytcnt" bytes from "buffer", followed by the updated
C      checksum. Checksum is initialized from the "chkini" argument.
C
      IMPLICIT INTEGER (a-z)
      BYTE buffer(bytcnt), bword(2)
      EQUIVALENCE (iword,bword)
C
      chksum = chkini
      odd = 0
C
C      Loop to transmit packet contents, one byte at a time
C
      DO 100, i=1,bytcnt
      odd = .not.odd
      IF (odd.eq.0) GOTO 50
C
C      If an odd-numbered byte, remember it for checksum calculation
C
      bword(2) = 0
      bword(1) = buffer(i)
      GOTO 100
C
C      Perform checksum calculation for each byte pair on even-
C      numbered byte
C
50     bword(2) = buffer(i)
      chksum = Check(chksum,iword)
C
C      In either case, output byte to interface
C
100    CALL Putbyt(buffer(i))
      IF (odd.ne.0) chksum = Check(chksum,iword)
C
C      Output computed checksum for packet
C
      iword = chksum
      CALL Putbyt(bword(1))
      CALL Putbyt(bword(2))
      RETURN
      END

      INTEGER FUNCTION Getend(chkini)
C
C      Reads an end packet from the TU58 controller, returning
C      as the function value the success code from the packet.
C
      IMPLICIT INTEGER (a-z)
      BYTE bword(2)
      EQUIVALENCE (iword,bword)
C
      chksum = chkini
C
C      If input checksum is not zero, first byte of packet has
C      already been read by the caller. It is the "chkini" value.
C
      IF (chksum.ne.0) GOTO 10
      chksum = Getbyt()
C
C      Check for valid END packet structure.
C
10     IF (chksum.ne."002") GOTO 500      !Must have flag = COMMAND
      IF (Getbyt().ne.10) GOTO 500      !Must have byte count = 10
      IF (Getbyt().ne."100") GOTO 500   !Must have opcode = END

```

```

C
C   If a valid packet is found, read success code byte and
C   store it
C
C   Getend = Getbyt()
C   chksum = Check(10*256+"102,Getend*256)
C
C   Read and discard remainder of packet, updating checksum
C
C   DO 100, i=1,4
C   bword(1) = Getbyt()
C   bword(2) = Getbyt()
100  chksum = Check(chksum,iword)
C
C   Read transmitted checksum and compare with computed value
C
C   bword(1) = Getbyt()
C   bword(2) = Getbyt()
C   IF (iword.eq.chksum) GOTO 600
C
C   Indicate checksum or transmission error
C
500  Getend = -127
600  RETURN
END

```

```

.TITLE TU58 NON-INTERRUPT DRIVEN TU58 HANDLER
.IDENT /0.1/

```

```

;+
; The following program listing contains a complete TU58 device
; handler package written in PDP-11 MACRO assembly language.
;
; The program implements four FORTRAN-callable entry points:
;
;   IERROR = TUREAD( UNIT, BLOCK, BUFFER, BYTECOUNT )
;
;   Read "BYTECOUNT" bytes from the TU58 drive specified by
;   unit "UNIT" into the data area specified by "BUFFER",
;   starting at random-access block "BLOCK" on the cartridge.
;
;   IERROR = TUWRIT( UNIT, BLOCK, BUFFER, BYTECOUNT )
;
;   Write "BYTECOUNT" bytes from the data area specified by
;   "BUFFER" onto TU58 drive "UNIT", starting at the random-access
;   block noted by "BLOCK".
;
;   IERROR = TUSEEK( UNIT, BLOCK )
;
;   Position the TU58 cartridge located in drive "UNIT" at the
;   random-access block specified by "BLOCK".
;
;   IERROR = TUDIAG( )
;
;   Run the TU58 internal controller diagnostic function.
;
; In all cases, the functions return a standard set of status
; codes, as follows:
;
;   IERROR VALUE           MEANING OF STATUS CODE
;
;       0                 Normal success
;       1                 Success, but retries were required
;      -1                 TU58 failed self-test (TUDIAG)
;      -2                 Partial operation (end-of-medium encountered)
;      -8                 Invalid unit number was specified
;      -9                 No cartridge is mounted in specified drive
;     -11                 Specified cartridge is write-protected (TUWRIT)
;     -17                 Data check error on cartridge
;     -32                 Seek error (block not found)
;     -33                 Motor stopped (TU58 hardware error)

```

```

;      -48      Invalid operation code (error in this program)
;      -55      Invalid record number (bad block number passed)
;      -127     Communications error between host and TU58
;
;

```

```

; This software assumes that the TU58 controller is interfaced
; through a DLV11, DLV11-J, DLV11-E, DLV11-F, or MXV11 interface
; which has a receiver CSR address assignment of 176500(8). These
; subroutines were written with a goal of readability: time and
; space performances are not optimal.
;

```

```

; This program is neither licensed nor supported by DIGITAL
; Equipment Corporation, and may be copied or modified for use
; on any computer system. Digital assumes no responsibility
; for its reliability on any hardware, Digital-supplied or
; otherwise.
;
;
;--

```

```

.SBTTL Symbol Definitions and Data Area

```

```

; Define packet flag byte codes
;

```

```

F.DATA  =      1      ; Data packet
F.CTRL  =      2      ; Control packet
F.INIT  =      4      ; INIT packet
F.CONT  =     20      ; CONTINUE packet
F.XOFF  =     23      ; XOFF packet

```

```

; Define Control packet op-codes
;

```

```

O.READ  =      2      ; perform read operation
O.WRIT  =      3      ; perform write operation
O.POS   =      5      ; perform seek operation
O.DIAG  =      7      ; perform self-test
O.END   =     100     ; packet is an End packet

```

```

; Define controller interface address assignment
;

```

```

DLRCSR  =     176500
DLRBUF  =     DLRCSR+2
DLXCSR  =     DLRCSR+4
DLXBUF  =     DLRCSR+6

```

```

; Macro to send a byte to TU58
;

```

```

.LAB:   .MACRO  PUTBYT  ARG, ?LAB
        TSTB   @#DLXCSR
        BPL    LAB
        MOVB   ARG, @#DLXBUF
        .ENDM  PUTBYT

```

```

; Macro to wait for a byte from TU58
; NOTE: If ARG is a register, the parity bit will be sign-extended
; into the high-byte of the register.
;

```

```

.LAB:   .MACRO  GETBYT  ARG, ?LAB
        TSTB   @#DLRCSR
        BPL    LAB
        MOVB   @#DLRBUF, ARG
        .ENDM  GETBYT

```

```

; Data area
;

```

```

.PSECT  USER$D  RW, D, LCL, REL, CON

```

```

; Area used to build Control packets
;

```

```

PACKET: .BYTE   F.CTRL, 10.      ; Control packet, length = 10.
        .WORD   0, 0, 0, 0, 0

```

```

; Word used to collect byte-pairs for 16-bit checksum calculation

```

```

;
WORD: .BLKW
; Pure (ROM-able) code follows
;
      .PSECT  USER$I  RW, I, LCL, REL, CON
      .SBTTL  TUREAD  Read Data From TU58

;+
; TUREAD
;
; Description:
;   See module heading
;
; Inputs:
;   R5 points to a five word standard FORTRAN argument block
;   0(R5) = 4
;   2(R5) = address of unit number byte
;   4(R5) = address of block number word
;   6(R5) = address of callers input buffer
;   8.(R5) = address of bytecount word
;
; Outputs:
;   R0 = 16-bit status code
;-

TUREAD::
CALL    INIT           ; initialize the TU58
TST     R0             ; if error occurred,
BNE     50$           ; return error to caller

; Build a Control packet
;
MOV     #0.READ, PACKET+2 ; operation is "READ"
MOV     @2(R5), PACKET+4  ; store unit number
MOV     @8.(R5), PACKET+8. ; store byte count
MOV     @4(R5), PACKET+10. ; store block number

; Send the Control packet to the TU58
;
MOV     #PACKET, R0      ; R0 points to packet
MOV     #12., R1        ; R1 = number of bytes to send
CLR     R2              ; R2 = initial checksum
CALL    SNDPKT         ; send the Control packet

; Receive zero or more Data packets from TU58, followed by an End packet.
;
Ss:    MOV     6(R5), R1 ; R1 = address of callers buffer
GETBYT R0             ; get flag byte from TU58
CMPB   R0, #F.DATA   ; if not a Data packet,
BNE     90$          ; check for End packet
GETBYT R2             ; get byte count from TU58
BIC    #*C<377>, R2  ; clear hi-byte
SWAB   R2            ; form initial checksum in R0
BIS    R2, R0        ; R0 = current checksum
SWAB   R2            ; restore byte count
CLR    R3            ; R3 is even/odd byte flip-flop

; Receive all characters in the Data packet, updating checksum as
; each pair of characters is received.
;
10$:   COM     R3      ; flip flag
BEQ    20$        ; branch if second character of pair
CLR    WORD     ; build character pair
GETBYT WORD      ; with next data character
MOVB   WORD, (R1)+ ; store data byte in callers buffer
BR     30$

20$:   GETBYT WORD+1 ; get second byte of pair
ADD    WORD, R0    ; update checksum
ADC    R0          ; with end-around carry
MOVB   WORD+1, (R1)+ ; store data byte in callers buffer

```

```

30$: SOB R2, 10$ ; loop until byte count is zero
      TST R3 ; if odd number of data bytes in
; packet,
;
      BEQ 40$
      ADD WORD, R0 ; finish checksum
      ADC R0

; Receive checksum from TU58 and compare to computed value
;
40$: GETBYT WORD ; get 16-bit checksum
      GETBYT WORD+1
      CMP WORD, R0 ; compare with computed checksum
      BEQ 5$ ; if the same, get next Data packet

; Checksum error. Return error code.
;
      MOV #-127., R0 ; set function value to error code
50$: RETURN ; and return to caller

; A packet was received from the TU58 that was not a Data packet.
; Check to see that it is an End packet.
;
90$: JMP GETEND ; check End packet and return to
; caller
;
      .SBTTL TUWRIT Send Data to TU58

;+
; TUWRIT
;
; Description:
; See module heading
;
; Inputs:
; R5 = address of a five word standard FORTRAN argument block
; 0(R5) = 4
; 2(R5) = address of unit number byte
; 4(R5) = address of block number word
; 6(R5) = address of output buffer
; 8.(R5) = address of bytecount word
;
; Outputs:
; R0 = 16-bit status code
;-

TUWRIT::
      CALL INIT ; initialize the TU58
      TST R0 ; if unsuccessful,
      BNE 99$ ; return to caller

; Build a Control packet to send to the TU58.
;
      MOVE #0.WRIT, PACKET+2 ; op-code is "WRITE"
      MOVR @2(R5), PACKET+4 ; set unit number
      MOV @8.(R5), PACKET+8. ; set byte count
      MOV @4(R5), PACKET+10. ; set block number

; Send the Control packet to the TU58.
;
      MOV #PACKET, R0 ; R0 = address of packet
      MOV #12., R1 ; R1 = number of bytes to send
      CLR R2 ; R2 = initial checksum
      CALL SNDPKT ; send the packet

      MOV @8.(R5), R3 ; R3 = number of bytes left to send
      MOV 6(R5), R5 ; R5 = address of callers data buffer

```

```

; Send one or more Data packets to the TU58.
;
10$:   GETBYT  R0           ; get a byte from TU58
      CMPB   R0, #F.CONT  ; if not CONTINUE,
      BNE   90$          ; check for End packet
      PUTBYT #F.DATA      ; send Data packet flag
      MOV   #128., R4     ; assume 128 or more bytes left
; to send
;
      CMP   R3, R4       ; if less than 128. bytes left
; to send,
;
      BHIS  20$          ;
      MOV   R3, R4       ; RESET R4 to actual number left
20$:   PUTBYT  R4         ; send byte count
      MOV   R5, R0       ; R0 = address of packet to send
      MOV   R4, R1       ; R1 = length of packet
      MOV   R4, R2
      SWAB  R2
      ADD  #F.DATA, R2   ; R2 = initial checksum
      CALL SNDPKT        ; send the packet to TU58
      SUB  R4, R3        ; update number of bytes left to send
      ADD  R4, R5        ; update data buffer pointer
      BR   10$          ; wait for acknowledgment from TU58

```

```

; A byte was received from the TU58 that was not a CONTINUE.
; See if the packet is an End packet.
;

```

```

90$:   CALL  GETEND
99$:   RETURN          ; return to caller

```

```

.SBTTL TUSEEK Position the TU58

```

```

;+
; TUSEEK
;
; Description:
;
; See module heading
;
; Inputs:
; R5 = address of three word standard FORTRAN argument block
; 0(R5) = 2
; 2(R5) = address of unit number byte
; 4(R5) = address of block number word
;
; Outputs:
; R0 = 16-bit status code
;-

```

```

TUSEEK::
      CALL  INIT          ; initialize the TU58
      TST  R0             ; if initialization failed,
      BNE  99$           ; return error to caller

```

```

; Build Control packet to send to TU58.
;

```

```

      MOVB  #0.POS, PACKET+2 ; set op-code
      MOVE  @2(R5), PACKET+4 ; set unit number
      MOV  @4(R5), PACKET+10. ; set block number

```

```

; Send the Control packet to the TU58.
;

```

```

      MOV  #PACKET, R0     ; R0 points to packet
      MOV  #12., R1       ; R2 = length of packet
      CLR  R2              ; R2 = initial checksum
      CALL SNDPKT        ; send the packet

```

```

; Get an End packet from the TU58 and return to caller.
;

```

```

      CLR  R0              ; indicate no byte pre-read
      CALL GETEND
99$:   RETURN          ; return to caller

```

.SBTTL TUDIAG Run TU58 Local Diagnostic

```

;+
; TUDIAG
;
; Description:
;   See module heading
;
; Inputs:
;   none
;
; Outputs:
;   R0 = 16-bit status code
;-

TUDIAG::
    CALL    INIT          ; initialize the TU58
    TST     R0            ; if initialization failed,
    BNE     99$          ; return error code to caller

; Build Control packet.
;
    MOVB    #0.DIAG, PACKET+2 ; set op-code

; Send the Control packet to the TU58.
;
    MOV     #PACKET, R0    ; R0 = address of packet
    MOV     #12., R1      ; R1 = length of packet
    CLR     R2             ; R2 = initial checksum
    CALL    SNDPKT        ; send the packet

; Receive an End packet and return status code to caller.
;
    CLR     R0             ; indicate no byte pre-read
    CALL    GETEND        ; get the End packet
99$:      RETURN          ; return to caller

```

.SBTTL INIT Initialize the TU58

```

;+
; INIT
;
; Description:
;   INIT is called by TUREAD, TUWRIT, TUSEEK, and TUDIAG
;   to initialize the TU58 to its power-up state.
;   This is done by causing a framing error in the TU58,
;   followed by sending two INIT packets to the TU58.
;   The TU58 should reply with a CONTINUE packet.
;
; Inputs:
;   none
;
; Outputs:
;   R0 = 16-bit status code
;-

INIT:
    CLR     R0             ; assume success
    MOV     #8., R1       ; retry eight times before failure

; Send BREAK.
;
10$:     MOV     #1, @DLXCSR ; start sending a break
        MOV     #8., R2     ; send nulls for 8 character times
20$:     PUTBYT #0
        SOB    R2, 20$
        CLR    @DLXCSR     ; stop sending the break
        TSTB   @DLRBUF     ; remove any extraneous input byte

```

```

; Send two INIT packets.
;
    PUTBYT  #F.INIT          ; send two INIT packets
    PUTRYT  #F.INIT

; See if TU58 sent a Continue packet
;
    GETBYT  R2              ; get a byte from TU58
    CMPB   R2, #F.CONT     ; if CONTINUE packet,
    BEQ    99$             ; return to caller
    SOB    R1, 10$        ; else retry

; Retry failed. Return error status to caller.
;
    MOV     #-127., R0
99$:      RETURN

.SBTTL   SNDPKT   Send a Packet to TU58

;+
; SNDPKT
;
; Description
;   SNDPKT is called by TUREAD, TUWRIT, TUSEEK, and TUDIAG to
;   send a multi-byte packet (either Control or Data) to the TU58.
;   SNDPKT will also compute the packets checksum and send the
;   checksum to the TU58.
;
; Inputs:
;   R0 = address of bytes to send
;   R1 = number of bytes to send
;   R2 = the initial checksum (non-zero if part of the packet has
;       already been sent)
;
; Outputs:
;   None
;-

SNDPKT:
    CLR     -(SP)          ; make odd/even byte flip-flop

; Send bytes to TU58. Update 16-bit checksum after each byte pair.
;
10$:     COM     (SP)          ; flip odd/even flag
        BEQ     20$          ; branch if second byte of pair
        CLR     WORD        ; set up byte pair word
        MOVB   (R0), WORD   ; with first byte of pair
        BR     30$

20$:     MOVB   (R0), WORD+1  ; store second byte of pair
        ADD    WORD, R2     ; update checksum
        ADC    R2          ; with end-around carry
30$:     PUTBYT (R0)+        ; send the data byte
        SOB    R1, 10$     ; loop until byte count is zero

        TST    (SP)+        ; if odd number of data bytes,
        BEQ    40$          ;
        ADD    WORD, R2     ; update computed checksum
        ADC    R2

40$:     PUTBYT R2          ; send 16-bit checksum
        SWAB   R2
        PUTBYT R2
        RETURN             ; return to caller

.SBTTL   GETEND   Check for End Packet

;+
; GETEND
;
; Description:
;   GETEND is called by TUREAD, TUWRIT, TUSEEK, and TUDIAG to accept
;   an End Control packet from the TU58. GETEND verifies that the

```

```

; received packet is indeed an End packet, and that the checksum
; word in the packet equals the computed checksum.
;
; Inputs:
; R0 = a byte already read by the caller or zero
;
; Outputs:
; R0 = 16-bit status code
;-

GETEND:
; If flag byte was not pre-read by caller, read it now.
;
    TSTB    R0                ; if not pre-read,
    BNE     10$              ;
    GETBYT  R0                ; read it
10$:
; Verify that the packet coming from the TU58 is indeed an End Control packet.
;
    CMPB    R0, #F.CTRL      ; check Control packet
    BNE     90$
    GETBYT  R0
    CMPB    R0, #10.         ; with length = 10.
    BNE     90$
    GETBYT  R0
    CMPB    R0, #O.END       ; and op-code = End
    BNE     90$
    GETBYT  R0                ; get success code
    BIC     #^C<377>, R0     ; clear hi-byte
    MOV     R0, R1           ; form 16-bit checksum in R1
    SWAB    R1               ; form 16-bit checksum
    ADD     #10.*256.+O.END+F.CTRL, R1
    ADC     R1                ; from bytes already received

; Receive and ignore rest of End packet, updating checksum.
;
    MOV     #4, R2
20$:   GETBYT  WORD
    GETBYT  WORD+1
    ADD     WORD, R1
    ADC     R1
    SOB    R2, 20$           ; loop four times to get 8. bytes

; Receive checksum transmitted from TU58 and compare with computed checksum.
;
    GETBYT  WORD
    GETBYT  WORD+1
    CMP     WORD, R1
    BEQ     100$

; Return error code for transmission error.
;
90$:   MOVB    #-127., R0
100$:  MOVB    R0, R0         ; return status as 16-bit value
    RETURN                    ; return to caller

.END

```

APPENDIX D CARTRIDGE REPAIR

D.1 INTRODUCTION

Under unusual circumstances of controller failure or cartridge mishandling, the tape might come free of the hub. The tape is not fastened to the hub but is held in place by the elastomer belt and by the tape's wrap around itself. The procedures for looping the tape back onto the hub are given here to help the user prevent the loss of important data. They are not a substitute for the customary precautions of proper handling and backup copying. Two procedures are given here. One is for the metal-base cartridge and the other is for the plastic-base cartridge.

These are moderately difficult procedures requiring the use of small tools. Minimum tools are a number 1 Phillips head screwdriver and a small probe (a straightened paper clip can be used). Tweezers are helpful.

NOTE

Keep magnetized tools away from the bulk of the tape and do not touch the tape surface except at the ends because fingerprints cause errors. (If staples or paper clips stick to a tool, it is magnetized.)

D.2 METAL-BASE CARTRIDGE

1. Open the cartridge by removing the four baseplate Phillips head screws (Figure D-1) and set it upright on the work surface with the cover still on.




Figure D-1 Baseplate Screw Locations

- Lift the cover off.

NOTE

To remove the head gate, swing it out to clear the tape before lifting it up. Its replacement is optional.

A spring is in the bottom of the gate. (Figure D-3).

- Thread the end of the tape around the tape guides (Figure D-2).





Figure D-2 Threading the Metal-Base Cartridge

- Moisten the end of the tape with water to get it to stick to the hub.
- With a small amount of slack at the free end, insert the end between the hub and belt and operate the drive roller with a finger to take up the tape. As soon as the tape is grabbed, keep some back tension on the tape. This keeps it feeding straight into the hub.
- Continue to wind. Watch for the loose ends as it comes around. If it separates from the hub, tuck it under the next turn of tape with the probe. (Back up if the end is too long.)
- Continue to wind a few more turns with the drive roller while applying tension to the tape.
- Hold the takeup hub and drive roller fixed, and rotate the supply hub to take up the slack.
- Continue winding the tape about 20 turns before reassembling.
- To reassemble the cartridge, reinstall the gate (if desired) by aligning the long and short ends of the spring with the long and short ends of the gate, as in Figure D-3.
- Drop the spring into the well in the gate. Holding the spring down with a thumbnail or probe, rotate the long end of the spring around to the slot that is at a right angle to the long dimension of the gate. Push the end of the spring into the slot; it should stay there by itself.
- Hold the gate halfway out so that the gate and the spring end do not touch the tape. Slowly press the gate down onto its pin on the cartridge baseplate. Reach in with the probe and press the spring down. It will clear its holding slot and snap into position, closing the gate.



MA-2358

Figure D-3 Head Gate and Spring

13. Carefully lower the cartridge cover into place and reinstall the screws.


D.3 PLASTIC-BASE CARTRIDGE

Open the plastic-base cartridge case by removing the four baseplate Phillips head screws (Figure D-1). Carefully remove the top.

D.3.1 Preparation for Threading

The four rollers and tape hubs in the plastic-base cartridge are held in their operating plane by the top and bottom of the case together. When the top is off, the various parts tend to creep out of position, and the elastomer belt can get folded under the hubs.

1. To organize the parts for threading, remove and discard the head gate and spring. Take the empty tape hub from the case and set it aside.
2. Remove the floating roller (Figure D-4).



MA-2356

Figure D-4 Stretch the Belt with the Floating Roller


3. Rearrange the elastomer belt around the drive roller and the supply hub.
4. Put the takeup hub on its pin.
5. Put the empty tape hub on its pin.
6. Using the top to hold the floating roller, belt and supply hub down, use a straightened paper clip or pencil to guide the elastomer belt around the hub. The hub should seat against the base with the belt around it.

D.3.2 Threading the Cartridge

1. Pull several centimeters (a few inches) of tape off the supply hub and through the tape guides (Figure D-5).

NOTE

Hold all parts down when moving them. Otherwise, the hubs will creep up the pins and cause the belt to slip. Then the procedure must be restarted at Paragraph D.3.1.



MA-2364

Figure D-5 Threading the Plastic-Base Cartridge

2. Moisten the end of the tape with water to get it to stick to the hub.
3. With a small amount of slack at the free end, insert the end between the hub and belt, and operate the floating roller to take up the tape.
4. As soon as the tape is grabbed, keep some back tension on the tape. This keeps the tape feeding straight into the hub.
5. Continue to wind. Watch for the loose end as it comes around. If it separates from the hub, tuck it under the next turn of tape with the paper clip. (Back up if the end is too long.)
6. Continue to wind a few more turns with the floating roller while applying tension to the tape.
7. Now hold the takeup hub, drive roller, and floating rollers fixed and rotate the supply hub to take up the slack.

D.3.3 Closing the Cartridge

Place the top back on the cartridge. Do not reinstall the head gate. The mirror window may need to be pressed in slightly to clear the bottom. Reinstall the four baseplate screws.

Now use a finger to operate the drive roller and wind the tape about 20 turns onto the takeup hub before inserting the cartridge into a drive.

NOTE

The only reason for performing this exercise is to copy the data from the injured tape as soon as possible. Discard the cartridge after copying.

APPENDIX E
FIELD REPLACEABLE UNIT SPARES LIST

Module	DIGITAL P/N	Option Name
Serial Controller Board	54-13489	TU58 - XB
Regulator Module	54-13609	
Drive	70-15510	TU58 - XA
Tachometer Encoder Wheel	74-20649	
Tape Cartridge	36-15809	TU58 - K

