
Microprogrammers' Reference, ECLIPSE MV/10000™ Computer



Microprogrammers' Reference, ECLIPSE MV/10000™ Computer

014-701003

Ordering No. 014-701003

© Data General Corporation, 1983
All Rights Reserved
Printed in the United States of America
Revision 00, May 1983

NOTICE

Data General Corporation (DGC) has prepared this document for use by DGC personnel, customers, and prospective customers. The information contained herein shall not be reproduced in whole or in part without DGC's prior written approval.

DGC reserves the right to make changes in specifications and other information contained in this document without prior notice, and the reader should in all cases consult DGC to determine whether any such changes have been made.

THE TERMS AND CONDITIONS GOVERNING THE SALE OF DGC HARDWARE PRODUCTS AND THE LICENSING OF DGC SOFTWARE CONSIST SOLELY OF THOSE SET FORTH IN THE WRITTEN CONTRACTS BETWEEN DGC AND ITS CUSTOMERS. NO REPRESENTATION OR OTHER AFFIRMATION OF FACT CONTAINED IN THIS DOCUMENT INCLUDING BUT NOT LIMITED TO STATEMENTS REGARDING CAPACITY, RESPONSE-TIME PERFORMANCE, SUITABILITY FOR USE OR PERFORMANCE OF PRODUCTS DESCRIBED HEREIN SHALL BE DEEMED TO BE A WARRANTY BY DGC FOR ANY PURPOSE, OR GIVE RISE TO ANY LIABILITY OF DGC WHATSOEVER.

IN NO EVENT SHALL DGC BE LIABLE FOR ANY INCIDENTAL, INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES WHATSOEVER (INCLUDING BUT NOT LIMITED TO LOST PROFITS) ARISING OUT OF OR RELATED TO THIS DOCUMENT OR THE INFORMATION CONTAINED IN IT, EVEN IF DGC HAS BEEN ADVISED, KNEW OR SHOULD HAVE KNOWN OF THE POSSIBILITY OF SUCH DAMAGES.

CEO, DASHER, DATAPREP, ECLIPSE, ENTERPRISE, INFOS, microNOVA, NOVA, PROXI, SUPERNOVA, ECLIPSE MV/4000, ECLIPSE MV/6000, ECLIPSE MV/8000, PRESENT, TRENDVIEW, and MANAP are U.S. registered trademarks of Data General Corporation.

AZ-TEXT, BusiPEN, BusiGEN, BusiTEXT, ECLIPSE MV/10000, DEFINE, DG/L, GENAP, GDC/1000, GW/4000, microECLIPSE, REV-UP, SLATE, SWAT, and XODIAC are U.S. trademarks of Data General Corporation.

Microprogrammers' Reference, ECLIPSE MV/10000 Computer 014-701003

Original Release - May 1983

Contents

Preface	p-1
Chapter 1 Introduction	1-1
Terminology	1-2 1-2
Chapter 2 MV/10000 Architecture and Operation	2-1
Clocks and Timing The Microsequencer Writable Control Store Microinstruction Register Microprogram Counters Microstack and Microstack Input Multiplexer Top of Stack Register RAM Address Multiplexer DSP Register, Crossbar Net, Dispatch Multiplexer AA Bus Flags SCP Control	2-2 2-2 2-3 2-3 2-4 2-5 2-5 2-6
Tests The Integer ALU Integer Register File Registers on the ID Bus Scratch Pad Transfer Register Hex Shifter ALU Carry-In Logic Commercial Test and Edit PROMs Bit Shifter Processor Status Register	2-7 2-8 2-10 2-11 2-12 2-13 2-14 2-15 2-16 2-17 2-18
The Floating-Point Unit FPU Buses	2-19 2-19 2-21 2-21 2-22 2-22 2-22

Floating-Point STATE Register	
Hex Shifter	 2-24
MAG Register	 2-24
Mantissa ALU	 2-26
Working Register	
Multiply Hardware	
X and Y Registers	
YSEL Counter	
Multiply ALU	
Divide Hardware	
Divide Guard Digit Register	
Divide Partial Remainder Register	
Sign and Exponent Logic	
Exponent Working Register	
Exponent ALU	
SA and SB Registers	
Sign Logic	
The Address Generator	
Buses	
Register File	
Register File Addressing	
AGB Bus Sources	
RFIN Multiplexer	
Address Generator ALU	 2-36
The Address Translation Unit	 2-36
Address Translation Cache	 2-37
Referenced/Modified RAM	
Validity RAM	
Logical Address Translation	
Page Table Addressing Logic	
Ring Protection	
Indirection Protection	
Read/Write/Execute Protection	
ATU State	
ATU Diagnostic Register	
ATU Dispatch	
The CPD Bus and Transfer Register	
Instruction Processor	
Interrupts	
I/O Protocols	 2-46
Chapter 3 Micro-order Format and Instruction Set	 . 3-
NAC-Next Address Control	
NAC:COP—Conditional OPcode	
NAC:TSEL —Test Selection	 . 3-6
Microsequencer Tests	
Address Translation Unit Tests	 . 3-9
Integer ALU Tests	 3-12
Floating-Point Tests	
NAC:UCOP—Unconditional OPcode	
NAC:DSR – Dispatch Address Source	
Address Generator Micro-orders	
	 1

AA and AB—The Register File Address Fields	3-24
AGB—The Address Generator Bus Field	3-28
AOP-Address Generator ALU Operation Field	3-29
AL-Address Generator Register Loading	3-29
Memory Control Micro-orders	3-30
MEMS – Memory Start	3-31
MEMC – Memory Complete	3-32
Bus Control Micro-orders	3-34
CPMS—CPM Bus Sources	3-34
CPDS—CPD Bus Sources	3-35
RAND—Random Micro-orders	3_39
RAND:GEN—General Random Micro-orders	3-40
RAND:GEN:REG0—General/ACSR/ACDR Micro-orders	
RAND:GEN:REG0—General/ACSK/ACDK Micro-orders	
RAND:GEN:REGI — Register Load Operations	
RAND:GEN:SPAD—Scratch Pad input Control	2.50
RAND:ATU —ATU Random Micro-orders	
RAND:ATU:ATU0—ATU Operations	
RAND:ATU:ATU1—Additional ATU Operations	
RAND:ATU:SPAD - Scratch Pad Input Control	3-59
RAND:FIX - Fixed-point Random Micro-orders	3-60
RAND:FIX:COVS—Carry, Overflow and Status	3-60
RAND:FIX:LOAD - Load Registers	3-63
RAND:FIX:SPAD Scratch Pad Input Control	3-63
RAND:FLT - Floating-Point Random Micro-orders	3-64
RAND:FLT:SGN — Floating-Point Sign	3-65
RAND:FLT:EXP—Floating-Point Exponent	3-66
RAND:FLT:SCNT—Shift Count Control	3-69
Integer ALU Micro-orders	
IA and IB—Integer Register File Addressing	3-71
ID – ID Bus Source Control	3-75
RS—ALU Input Multiplexer Control	3-77
IOP—ALU Control and Shift Magnitude	3-77
IY –IY Bus Source	
IL—Integer Register File Input	
Floating-Point ALU Micro-orders	
FR —FR Bus Source	3-86
FS –FS Bus Source	
FOP—Mantissa Operations	
FWR—Working Register Input	
FCW—Floating-Point Register Write Address	3-00
FL—Register File Load Specifier	3-90
FRG—Floating-Point Register Load Control	3 05
FX—Froating-Point Register Load Control	
FX—Excess-64 Control	3-77
Chapter 4 Microprogramming Examples	. 4-1
•	
Memory Accesses	. 4-2
IPOP—Crossing Macroinstruction Boundaries	. 4-4
Indirection Resolution	. 4-5
Dispatching	. 4-6

Chapter 5 MV/10000 Microcode Macroassembler	5-1
The Macroassembler	5-1
CPM Bus	
CPD Bus	
Memory Starts and Address Generator Operations	
Memory Completion	
ALU Operation Constructs	5-6
IY Bus	
ALU Test	
Loading SPAR	
Edit PROM	-10
ID Bus	
IR	
FPU Operations	
FD Bus	
FA and FB Buses	
$WR == \dots \dots$	
Sign and Exponent Control	
Shift Count	
Multiply Control	
FPU State	
Divide Control	
GEN Randoms	
ACSR (SRC Register Pointer) Randoms	
ACDR (DES Register Pointer) Randoms	
Flag Manipulation	
Skips	-17
Miscellaneous Randoms (NPDR and XTND)	
ATU Randoms	
FIX Randoms	
Next Address Sequence	
Conditional Address Generation	
Unconditional Address Generation	-19
Pseudo-unconditional Address Generation	
Test Definitions	
Examples	
Unassembled Example	-24
Assembled Examples	-26
Appendix A Page Faults	4-1
Appendix B CPD Bus Legal Path Analysis	B-1
Appendix C CPM Bus Legal Path Analysis	1
Transfer of the contract of th	_ 1
Appendix D ALU Source and Destination Paths [)_1
	,-1
Appendix E Page Zero Locations	R_1
FF	I

Apper	dix F Fault Codes				
Appei	dix G Exceptions				
Appei	Appendix H Scratch Pad Addresses H-1				
	Figures				
1-1	MV/10000 Subsystems				
2-1 2-2 2-3 2-4 2-5 2-6 2-7 2-8 2-9 2-10 2-11 2-12 2-13 2-14 2-15 2-16 2-17 2-18 2-19 2-20 2-21	MV/10000 System Clocks 2-1 Microinstruction Register 2-2 Program Counters and Microstack 2-4 The Crossbar Network and RA Multiplexer 2-6 Integer ALU 2-5 Integer ALU Register File 2-1 Registers on the ID Bus 2-1 Scratch Pad 2-1 The Transfer Register 2-1 The Integer ALU and Associated Logic 2-1 CARRY Bit and Carry-In Logic 2-1 The Floating-Point Unit 2-2 The MAG Register Sources 2-2 Multiply Data Paths 2-2 Divide Data Paths 2-2 Sign and Exponent Logic 2-3 The Address Generator 2-3 The Address Translation Unit 2-3 Page Table Addressing Logic 2-3 The Instruction Processor 2-4 I/O Command Formats 2-4				
3-1 3-2 3-3	The MV/10000 Microword				
A 1	Contaxt Blocks				

Tables

2-1	RAND Mode and CIB
2-2	Processor Status Register
2-3	Address Translation Unit State
2-4	ATU State Fault Codes
3-1	MV/10000 Microaddresses
3-2	Conditional Microorders in the OP Field
3-3	COM1 Tests
3-4	COM2 Tests
3-5	IOT Tests
3-6	Unconditional OP Microorders
3-7	Dispatch Address Source
3-8	RM Field Micro-orders
3-9	CNST Microorders for RAND MFS0 and MFS1
3-10	CNST Microorders for RAND AF46 and AF57
3-11	ATU Restored State
3-12	CP Mode Code
4-1	Microword Header Abbreviations

Preface

The *Microprogrammers' Reference, ECLIPSE MV/10000 Computer* describes the microcode for the ECLIPSE MV/10000TM computer.

Who Should Read This Manual?

This manual is intended as a reference for microprogrammers. It assumes some prior knowledge of the MV/10000 hardware and instruction set.

Manual Organization

The two major sections of this manual (Chapters 2 and 3) describe the MV/10000 hardware and MV/10000 micro-orders. The hardware descriptions are oriented towards microcode control. The micro-order descriptions are arranged by field. Chapter 4 presents examples of MV/10000 microprogram segments; these illustrate typical microcode operations. Chapter 5 describes the MV/10000 microcode macrolanguage and provides examples of microassembler input and output. Appendixes provide supplemental information and microprogramming aids.

Prerequisite Manuals

- ECLIPSE MV/10000 System Functional Characteristics (014-000724)
- Principles of Operation, 32-bit ECLIPSE Systems, Programmers Reference Series (014-000704)

Other Related Manuals

- µLink Microcode Linker Manual (093-400029)
- µASM Microassembler Manual (093-400030)
- SMI Microcode Simulator Manual (093-400031)

Contacting Data General

- To order any Data General manual, notify your sales representative and supply the manual title and order number.
- If you have software problems, please notify your local Data General systems engineer.
- · If you have hardware problems, please notify the Field Engineering Dispatch Center.

End of Preface

Chapter 1 Introduction

The ECLIPSE MV/10000TM computer implements the ECLIPSE MV instruction set. The MV/10000 CPU is microprogrammable. This manual describes the CPU microcode. In this chapter, we begin with a brief discussion of terminology and microprogramming. Then we describe each microcode-controlled subsystem in the MV/10000 CPU. We conclude by describing the CPU buses.

Terminology

Microprogramming terminology is similar to programming terminology. The following special terms are peculiar to microprogramming.

- Microcode Code written with microinstructions.
- Control store—The local memory, either RAM or ROM, that holds the microcode for a computer.
- Microinstruction—The contents of a location in control store. An MV/10000 microinstruction is 104 bits wide.
- Microassembler -A program that lets you use symbolic names when writing microcode.
- Microfield—A predefined segment of a microinstruction, usually associated with a particular control function.
- Micro-order—A possible value for a microfield. The number of micro-orders available for a microfield depends on the width of the field. In this text, we will usually refer to micro-orders by their microassembly names. For example, "FOP:SUB" means the SUB (subtract) micro-order in the FOP (floating-point operation) microfield.
- Microroutine—The set of microinstructions needed to carry out a complete operation, such as adding two numbers.
- Macroinstruction A machine-language instruction. A macroinstruction is implemented by one or more microinstructions.

Microprogramming

The MV/10000 machine-language instruction set is interpreted by microcode. In some computers, the machine language is "hard-wired." The signals that control various parts of the computer are generated by logic in the Central Processing Unit (CPU). This logic produces a different set of signals for each instruction the computer can execute. In the MV/10000 processor, microcode generates these same signals. Microcode has the advantage that, unlike hard-wired logic, it can be changed easily to accommodate changes to the instruction set.

Like the logic that preceded it, microcode controls the machine at a primitive level and uses the hardware to interpret machine—language instructions. Each macroinstruction is implemented by a microroutine residing in control store. This microroutine interprets an instruction much as a machine-language program might interpret a higher-level language.

MV/10000 microcode uses Writable Control Store (WCS), which means that microcode is stored in RAM and must be reloaded each time the machine is booted. (Some computers store their microcode in ROM, so that it is available even when the machine first starts up.) MV/10000 microcode is loaded by the System Control Processor (SCP).

MV/10000 Subsystems

The MV/10000 CPU has six separate subsystems: the Instruction Processor, the Microsequencer, the Address Generator, the Address Translation Unit, the Integer ALU, and the Floating-Point Unit. All of these are under microcode control. These subsystems are connected to the System Control Processor (which acts as a system console), the I/O Controller (which connects the MV/10000 processor to peripheral devices), and main memory. Figure 1-1 shows the MV/10000 subsystems.




Figure 1-1. MV/10000 Subsystems

The rest of this chapter briefly describes each microcode-controlled subsystem. Chapter 2 describes them in greater detail.

The Instruction Processor

The Instruction Processor (IP) decodes macroinstructions. Decoding an instruction means dividing it into component fields and producing a starting WCS address. The starting address points to the beginning of the microroutine that will execute (interpret) the instruction. The IP is pipelined: while one instruction is executing, several other instructions may be in various stages of decoding.

The IP contains the program counter, the instruction register, and the Instruction Cache (Icache). The Icache speeds up the fetching of instructions.

The Microsequencer

The microsequencer generates addresses into WCS. It determines which microinstruction will execute next. When microcode is being loaded, the microsequencer takes addresses from the SCP, along with the microroutines to be loaded.

The microsequencer contains the microprogram counter, the microstack, and the microaddress-generating logic. It can construct addresses from several different sources, depending on the needs of the microroutine. At the beginning of a microroutine that interprets a macroinstruction, the IP provides the microsequencer with a starting WCS address.

The Address Generator

The Address Generator (AG) constructs logical addresses for the MV/10000 processor. These addresses are 32-bit references to the 4-gigabyte, 8-segment ECLIPSE MV logical address

space. The AG provides addresses for the Address Translation Unit, which translates them into physical addresses for main memory.

The AG contains a register file, an ALU, and several individual registers. Decode logic in the AG, under microcode control, determines how an address is constructed.

The Address Translation Unit

The Address Translation Unit (ATU) changes logical addresses to physical addresses. Main memory uses a paging procedure that brings in logical pages from secondary memory only when they are needed. The ATU determines the physical location in main memory of the logical page addressed by the AG.

The ATU has an address translation cache, in which it stores recently used logical-to-physical translations. It also has special logic that lets it access page tables (which locate pages in main memory) very rapidly. In addition, the ATU has protection logic that checks memory references for validity.

The Integer ALU

The Integer ALU (IALU) adds and subtracts fixed-point numbers. It also shifts numbers, translates and validates commercial data, and performs logical operations.

The IALU contains a register file, a shifter, a scratchpad memory, and an ALU.

The Floating-Point Unit

The Floating-Point Unit (FPU) adds and subtracts floating-point numbers and multiplies and divides both floating- and fixed-point numbers. It can manipulate floating-point numbers up to 64 bits wide.

The FPU has separate exponent and mantissa sections. These share a 64-bit-wide register file; however, each section has its own ALU and logic. In addition, the FPU has sign logic to determine the sign for each result.

MV/10000 Buses

The following buses carry data within the MV/10000 CPU. They connect the various subsystems to other subsystems and to external devices:

- The CPM Bus is a 32-bit bus that carries data between the CPU and main memory. The AG, the IALU, and the FPU can all source and sink this bus.
- The CPD Bus is a 32-bit bus that carries data among the subsystems of the CPU and between the CPU and the I/O Controller. The CPD Bus connects to all the CPU subsystems except the FPU.
- The LA Bus carries 32-bit logical addresses between the AG and the ATU.
- The CPA Bus carries physical addresses from the ATU to main memory.

End of Chapter

Chapter 2 MV/10000 Architecture and Operation

This chapter describes elements of the MV/10000 processor, and explains how they are interconnected. Most of the descriptions are oriented towards a microprogrammer's point of view, with frequent references to specific micro-orders. Chapter 3 contains full descriptions of the micro-orders.

In this chapter, we examine the clocks and the microsequencer for the MV/10000 processor; then the Arithmetic Logic Units; and finally the addressing logic and instruction processor. We also look briefly at the protocols for I/O and memory references.

Clocks and Timing

The basic clock for the MV/10000 processor is SYS clock, which has a cycle of 70 nanoseconds. From SYS clock each board derives its own clock, typically called CP clock, which has a cycle of 140 nanoseconds. CP clock is the instruction-cycle clock for microinstructions. Thus, the basic system timing cycle is 140 nanoseconds.

The basic timing cycle can be extended by coding RAND: <GEN:REGO or ATU:ATU0>:XTND. This code extends the CP clock cycle by two SYS clock periods, so that CP clock takes 270 nanoseconds. Figure 1 shows the basic MV/10000 clocks.




Figure 2-1. MV/10000 System Clocks

The Microsequencer

The microsequencer determines the next microinstruction to be executed. The microsequencer contains part of the Writable Control Store, the microinstruction register, and the next address logic.

Writable Control Store

The MV/10000 Writable Control Store consists of 8K microwords divided into 1K pages. (The WCS address is 14 bits; however, only 13 are used at this time.) Each microword consists of 104 bits. WCS is divided so that 48 bits of each microword are on the microsequencer card and 56 bits are on the Address Generator (AG) card. The System Control Processor (SCP) loads microroutines into WCS when the system is booted.

Microinstruction Register

The microinstruction register is 104 bits wide, divided into 26 fields, 2 parity bits, and 4 unused bits. Figure 2-2 shows the microinstruction register. The fields in the microinstruction register are decoded to provide the control signals that operate the MV/10000 computer.




Figure 2-2. Microinstruction Register

Microprogram Counters

The MV/10000 processor has a microprogram counter (uPC) and an incremented microprogram counter (uPC+1). Both of these are available to microroutines. uPC+1 increments modulo 1024; that is, if uPC points to the upper boundary of a 1K page, uPC+1 addresses word zero in that page.

Both PCs are loaded whenever an address is sent to WCS. uPC+1 is automatically incremented when it is loaded. Figure 2-3 shows the two microprogram counters.

Microstack and Microstack Input Multiplexer

The microstack is a hardware stack that microroutines can use for calls and traps. It contains fifteen 16-bit words. The current value at the top of the stack is kept in the top of stack (TOS) register.

You can push either a 14-bit address or a 16-bit value from the CPD Bus onto the microstack. Inputs to the stack come through a multiplexer controlled by the NAC:COP or NAC:UCOP fields in the microword. The stack logic, controlled by these fields, determines whether the stack is pushed or popped. In addition, the stack control logic signals empty and IPOP. (IPOP occurs when a microinstruction pops an empty microstack; this operation dispatches to the microroutine for the next macroinstruction.) Figure 2-3 shows the microstack.

The NAC:COP and NAC:UCOP fields control the stack input multiplexer. This multiplexer can select one of the following to be pushed on the stack:

- the uPC+1
- the AA Bus (described below)
- the CPD Bus, bits 0-15 (inverted)

uPC+1 and AA are 14-bit addresses that the microcode can use to address WCS.

The most significant 16 bits of the CPD Bus can be pushed onto the stack also. This operation is used primarily to restore state.

In addition to uPC+1, AA, and CPD, the hardware can also push the current uPC and the current test result. It does this during a hardware TRAP; the uPC cannot be pushed under microcode control. To restore from a TRAP, the micro-order NAC:COP:CRST must be performed. This micro-order pops the test result from the stack and makes it the current test result. This result appears as TOS14 in the TOS register.




Figure 2-3. Program Counters and Microstack

Top of Stack Register

The top of stack (TOS) register holds the current value at the top of the microstack. (Figure 2-3 and Figure 2-4 show the TOS register.) This value can be sent as an address to WCS or it can be gated onto the CPD Bus. When the microstack is empty, the TOS register is disabled by the stack control logic. When the logic disables the TOS register, it enables a multiplexer (NTOS select) that supplies a new address. This multiplexer selects between the starting microaddress (STUAD), derived from the next macroinstruction, and CRA, an address the System Control Processor supplies. (Figure 2-4 shows the multiplexer.) The CRA is used for initial microcode loading and is not enabled in a running system.

RAM Address Multiplexer

The RAM Address (RA) multiplexer selects the control store address. (Figure 2-4 shows the RA multiplexer.) The multiplexer is controlled by the NAC:COP and NAC:UCOP fields, and selects among four possible addresses for the WCS:

- The TOS or STUAD address (described above)
- The address from the dispatch register and crossbar network
- · The AA Bus
- The incremented microprogram counter (uPC+1)

During a trap, this multiplexer forces an address to the appropriate trap routine.

DSP Register, Crossbar Net, Dispatch Multiplexer

The dispatch (DSP) register is used to form an address for WCS. The 8-bit register is loaded from CPD[24-31]-. The output of the dispatch register goes to a cross-bar network that provides three address formats. These are constructed from a combination of the AA Bus, two bits (ATD[0-1]) from the Address Translation Unit (ATU), and the dispatch register. The three formats are:

- AA[0-9],DSP[4-7]
- AA[0-5],DSP[0-7]
- AA[0-9],0,ATD[0-1],0

The dispatch multiplexer chooses among these addresses. The NAC:DSR field selects which of these addresses will go to the RA multiplexer. The DSR field is part of all microinstructions that specify a dispatch address.




Figure 2-4. The Crossbar Network and RA Multiplexer

AA Bus

The AA Bus is the main address bus in the microsequencer. It is fourteen bits wide, is sourced by the NAC:ADDRESS field of the microword and by uPC, and sources both the RA multiplexer and the crossbar network. The least significant ten bits of the AA Bus come from the NAC:ADDRESS field of the microword. The four most significant bits come from either NAC:ADDRESS or from the page bits [0-3] of the uPC, depending on the type of operation coded: unconditional or conditional, respectively.

Flags

The microsequencer card has eight flags that microcode can test. At IPOP time, the IP decode RAM sets flags 0-3, which refer specifically to the current macroinstruction.

- Flag 0 indicates the width of the data in the ALU and controls the word/sign extension on the IY Bus (see the ALU section). For FLAG0=0, the width is 16 bits; for FLAG0=1, the width is 32 bits.
- Flag 1 indicates the width of data on the Logical Address (LA) Bus. For narrow width addressing, the 15 least-significant bits and LA0 will be driven by the Address Generator. The ATU will supply the current ring bits, setting LA[1-3] equal to CRE[1-3]; bits LA[4-16] will be zero. For wide addressing, the Address Generator will drive all the bits on the LA Bus, unless the RAND:ATU:ATU1:AC micro-order is coded in the same cycle. For FLAG1=0, addressing is narrow; for FLAG1=1, addressing is wide.
- Flag 2 indicates operand precision (single or double) for operations of the floating-point unit. For FLAG2=0, operands are single precision; for FLAG2=1, operands are double precision.
- Flag 3 indicates the ALU test width. Test widths from the ALU can be either 32 bits or 16 bits. For FLAG3=0, width is 16 bits; for FLAG3=1, width is 32 bits.

The remaining 4 flags are set to zero at IPOP time; these flags are defined only by their use in the microprogram. All eight flags can be manipulated by the microprogram. The CPDS:USS micro-order gates the flags onto CPD[16-23]- as part of the microsequencer state.

SCP Control

The microcode in WCS is loaded from the System Control Processor. When the system is booted, the SCP scans in microroutines. Only after microcode is loaded is control turned over to the microsequencer.

Tests

The microsequencer can perform actions conditional on the outcome of various tests. There are 64 tests that can be specified by the NAC:TSEL field. These tests fall into four categories:

- Microsequencer tests, including microstack empty and flag tests.
- · ATU tests
- · Integer ALU tests
- Floating-Point tests

In addition, the TSEL polarity bit can invert the test result, thus altering its interpretation. The test result determines which action is performed by a micro-order in the NAC:COP field.

The Integer ALU

The Integer ALU (IALU) performs arithmetic and logic operations on 16-bit and 32-bit integers. It consists of a register file, an ALU, a hex shifter, a bit shifter, a scratch-pad file, and miscellaneous additional logic. Figure 2-5 shows the integer ALU.

Narrow and Wide Operations

The Integer ALU can perform either 16-bit or 32-bit arithmetic. Width is determined by FLAG0 (for bus widths) and FLAG3 (for test widths). The Instruction Processor automatically sets these flags when it is decoding a macroinstruction.

When FLAG0=1, the IY Bus in the ALU is effectively a 32-bit bus. When FLAG0=0, the IY Bus is effectively a 16-bit bus. Values that are sourced onto the bus when FLAG0=0 will go into the least-significant 16 bits (IY[16-31]). For FLAG0=0, data from the ALU and bit shifter will be sign-extended if written to the IALU's or Address Generator's register files, or to the Scratch Pad (SPAD); other destinations will be one-filled in their most-significant bits. Data from the hex-shifter always contains zeros in the most-significant bits, regardless of destination.

When FLAG3=1, Integer ALU tests apply to 32-bit quantities; when FLAG3=0, the tests apply to 16-bit quantities. The exact effect of this on any given test is explained in Chapter 3 under the individual test explanations.




Figure 2-5. Integer ALU

Integer Register File

The Integer ALU general register file consists of sixteen 32-bit registers with two separately addressable output ports and a single input port. The register file input is through a multiplexer that selects either the CPM Bus or the IY Bus. The output from the register file is to the A Bus and the ID Bus. Figure 2-6 shows the register file.

By convention, registers in the file are assigned particular meanings as follows:

Register	Meaning	
0	Programmer-visible Accumulator 0 (must contain same value as AG reg. 0 at IPOP)	
1	Programmer-visible Accumulator 1 (must contain same value as AG reg. 1 at IPOP)	
2	Programmer-visible Accumulator 2 (must contain the same value as AG reg. 2 at IPOP)	
3	Programmer-visible Accumulator 3 (must contain the same value as AG reg. 3 at IPOP)	
4	Wide frame pointer	
5	Wide stack limit	
6	Wide stack base	
7	Constant (-1)	
8	Microprogram general register	
9	Microprogram general register	
10	Microprogram general register	
11	Microprogram general register	
12	Microprogram general register	
13	Microprogram general register	
14	Register addressed by ACSR	
15	Register addressed by ACDR	




Figure 2-6. Integer ALU Register File

The IA and IB fields of the microinstruction supply addresses for the A and B output ports. The following table shows the relationship between values in the IA and IB fields and the registers addressed:

IA or IB	Register Addressed
=<D	The field directly addresses the register file.
=E	The Accumulator Source Register (ACSR) addresses the register file.
=F	The Accumulator Destination Register (ACDR) addresses the register file.

The IB address field supplies addresses for the input port of the integer register file. The CPM Bus and the IY Bus source the register file through a multiplexer. This multiplexer is controlled by the IL field of the microinstruction.

Registers on the ID Bus

Figure 2-7 shows the registers that source the ID Bus. Data from these registers can go to either input of the ALU or to the Processor Status Register. The ACDR and ACSR registers can both source and sink the bus. The B output port of the Integer ALU Register File (ALU BREG) is another source, described above. The Scratch Pad (SPAD) can also source the ID Bus; it is described in the section "Scratch Pad," below. PDR is a 32-bit register that transfers data between the CPD and ID Bus. It is described in "CPD Bus Register—PDR," below.




Figure 2-7. Registers on the ID Bus

ACSR and ACDR Registers

The Accumulator Source and Destination Registers (ACSR and ACDR) are 4-bit registers that address the integer register file. They generally contain the values from the ACS and ACD fields of a macroinstruction. The registers can be incremented, decremented, or loaded. The RAND:GEN:REG0 field controls these registers.

CON and SPAR registers

The constant (CON) and Scratch Pad Address Register (SPAR) are 8-bit registers that address locations in the scratch pad (see below). CON contains the value in the CNST field of the microinstruction. SPAR can be loaded from the IY Bus or from CON. In addition, SPAR can be loaded with a hardware-generated address that indexes into bit masks kept in the first thirty-two scratch-pad locations. Besides addressing the scratch pad, both CON and SPAR can source the ID Bus.

Scratch Pad

The scratch pad (SPAD) consists of 256 thirty-two-bit registers. It stores temporary values and constants used in various microcode routines. Appendix H lists the scratch pad constants. Figure 2-8 shows the scratch pad and its addressing logic.




Figure 2-8. Scratch Pad

Data is written into the scratch pad from the IY Bus or the CPM Bus; the scratch pad sources data to the ID Bus. The scratch pad can be addressed by the CNST field of the microinstruction or by the scratch pad address register (SPAR). Micro-orders in the RAND:GEN:REGO, SPAD, and ID fields control the scratch pad.

Special logic generates the scratch pad address for the WSKBO and WSKBZ instructions. The address is constructed from the macro instruction register and loaded into SPAR as follows:

The table of bit masks for WSKBO and WSKBZ resides in the first thirty-two scratch pad locations. The constructed address indexes into the scratch pad for the proper mask.

Transfer Register

The transfer register (TREG) moves data from the CPM Bus to the CPD Bus. Figure 2-9 shows the position of the TREG.




Figure 2-9. The Transfer Register

TREG is controlled by the LT micro-order, which can be used in the RAND FIX:LOAD, ATU:ATU1, or GEN:REG1 fields, and the CPDS:TRG micro-order.

Hex Shifter

The hex shifter can shift left, shift right, or rotate 32 bits in 4-bit increments. A shifted number is zero filled. In addition, the hex shifter can sign-extend words and bytes, and can zero- extend words. Figure 2-10 shows the hex shifter. The size of the shift is controlled by the IOP field of the microword, and so, generally, you cannot use the ALU and the shifter simultaneously.




Figure 2-10. The Integer ALU and Associated Logic

ALU

The ALU performs the arithmetic and logical functions for the integer ALU section of the CPU. Figure 2-10 shows the ALU and its relationship to other logic. The inputs to the ALU are through the R-in and S-in multiplexers, which can take data from the A and ID buses. They are controlled by the RS field of the microinstruction. The R input can also take data from the CPD Bus. In addition the ALU has a carry-in bit for arithmetic functions. The output of the ALU goes through the bit shifter to the IY Bus.

The IOP field controls the R and S inputs and the polarity of the carry-in input to the ALU. The ALU can perform the following functions:

- · R AND S
- R OR S
- · R AND S'

- · R XOR S
- \cdot R' + S + CIB'
- \cdot R + S + CIB'
- \cdot R' + S + CIB
- $\cdot R + S + CIB$

Note that the IOP field also specifies the hex-shifter count when HL0, HR0, or HRT is coded in the IY field.

Carry-In Logic

The carry-in logic for the ALU determines the value of the carry-in base (CIB). The CIB is normally a zero. As can be seen in the preceding section, the arithmetic operations allow selection of either polarity for the CIB. The fixed-point mode randoms also allow the CARRY bit to be selected as the CIB. This facilitates multiword arithmetic operations. Figure 2-11 shows the carry-in logic.




Figure 2-11. CARRY Bit and Carry-In Logic

The CIB can be either the CARRY register or zero, depending on the RAND mode. Table 2-1 shows the CIB that goes with each RAND mode.

 RAND Mode
 CIB

 GEN
 0

 ATU
 0

 FIX (XC)
 CARRY

 FIX (XZ)
 0

Table 2-1, RAND Mode and CIB

The polarity of the CIB is controlled by the IOP field. See "ALU," above, for the possible CIB polarities.

The CARRY bit may be set as follows:

FLT

- 1) One -CARRY is set to one.
- 2) Zero—CARRY is set to zero.
- 3) CRY0/CRY16—CARRY is set to the carry-out from the ALU; depending on whether the operation is wide (FLAG3=1) or narrow (FLAG3=0), the carry-out will be for a 32-bit result (CRY0) or a 16-bit result (CRY16).
- 4) R Bus—CARRY is set to bit 0 or bit 16 of the R Bus (the output of the R-input multiplexer—see Figure 2-10) depending on whether the operation is wide or narrow (FLAG3=1 or 0).
- 5) ALC carry—CARRY is set according to an ALC macroinstruction. The carry is dependent on IR[10-11], which specify the carry operation; on IR[5-7], which specify the macroinstruction function; and IR[8-9], which specify the shift function and its effect on the carry.

The CARRY register is controlled by the RAND: <XC XZ>:COVS field of the microinstruction.

Commercial Test and Edit PROMs

The test and edit PROMs test the validity of the least-significant byte on the A Bus as commercial data. The PROMs are enabled by the TSEL:COM1 and TSEL:COM2 micro-orders. The test is specified by a code in the CNST field; the test result may be used by the microsequencer like any other test result. In addition, the PROMs translate commercial data to BCD, which is sourced to the IY Bus and may be accessed by the IY:EDT micro-order.

The same PROMs also generate the IOT test functions. The TSEL:IOT micro-order enables these functions. Micro-orders in the CNST field specify the tests.

Bit Shifter

The bit shifter can pass 32-bit or 16-bit data, swap the two least-significant bytes of data, or shift the output of the ALU to the IY Bus one bit right or left for 32-bit or 16-bit data. The bit shifter is shown in Figure 2-10. The shift can be either zero or one filled, depending on the micro-order in the IY field. In addition, if RAND:<XC XZ>:COVS:ALC is coded, the input bit to the shift will be forced to the ALC carry, which is determined from the macroinstruction (see "Carry-in Logic," above). For narrow operations (FLAG0=0), the most-significant sixteen bits on the IY Bus are not used. They are filled with ones, except when the result goes to the Address Generator, SPAD, or the register file. In these cases, the 16-bit result (IY[16-31]) is sign extended into [0-15] by the input multiplexers of those destinations.

Processor Status Register

The Processor Status Register (PSR) contains information about the state of the MV/10000 processor. Table 2-2 shows the bits in the PSR.

Bit	Name	Description
0	оук	Overflow mask
1	OVR	Fixed-point overflow indicator
2	IRES	Interrupt resume
3	IXCT	The interrupted instruction was Executed via XCT or PBX.
4-15	_	Reserved

Table 2-2. Processor Status Register

The overflow mask indicates whether an overflow trap may occur; when OVK is zero, the trap is disabled. The overflow indicator tells whether a fixed-point overflow has occurred. Note that unless both OVR and OVK are set, overflow faults cannot happen.

The RAND:COVS field controls the OVK and OVR status bits. If a micro-order is coded to update OVR (from the current ALU computation) during an IPOP cycle, and the result produces an overflow error, a microtrap is always generated. The trap microcode examines the OVK bit to determine whether the fault should also be serviced at the macro level.

The IRES bit is used by the interrupt routines for resumable instructions. During an interrupt, resumable instructions save state on the user stack, and must restore it when the interrupt is over. When an instruction is interrupted, IRES is set. The microroutine for a resumable instruction must test IRES before it begins to execute. From IRES, it determines whether it has just started or is being resumed.

If the instruction can resume at more than one place, assign a number to each entry and use that number to determine the proper entry point. To protect the system, do not push a microaddress onto the user stack.

The IXCT bit is used by interrupt routines. It indicates that the executing instruction was inserted into the I-stream by the CPU. The instruction was originally in an accumulator and was executed as a result of an XCT or PBX instruction.

The PSR is controlled by the RAND: <XZ or XC>:COVS field.

CPD Bus Register—PDR

PDR is a 32-bit register that transfers data between the CPD Bus and ID Bus. In addition, it can act as a counter. It can be read using the ID:PD micro-order.

The least-significant eight bits of PDR may be used as a counter. The micro-order TSEL:CNT4 and TSEL:CNT8 will increment the eight-bit counter. CNT4 tests for the four least-significant bits equal to zero; CNT8 tests for all eight bits equal to zero. The count should not be tested until two cycles after the counter has been loaded with its initial value.

Normally, PDR is loaded every time the CPD Bus is active (i.e., whenever the CPDS field is not coded with N). However, loading is suppressed during an LAT routine, a Cache Block Crossing routine, or when the micro-orders RAND:ATU:ATU0:NPDR or RAND:GEN:REG0:NPDR are coded. Loading of PDR is also suppressed when a page fault occurs, up until the time that the ATU state is read.

The Floating-Point Unit

The Floating-Point Unit (FPU) performs all floating-point arithmetic as well as doing integer multiply and divide. The FPU is synchronous with other MV/10000 units. Figure 2-12 shows the floating-point unit.




Figure 2-12. The Floating-Point Unit

FPU Buses

FPU internal buses are 72 bits wide. Bits 0-7 form the sign and exponent of the floating-point number and generally go to the sign and exponent sections of the FPU. Bits 8-71 are manipulated by the mantissa section of the FPU. Bits 64-71 are guard bits; they ensure sufficient bits for rounding during all operations. For single-precision arithmetic (FLAG2=0), only the most-significant bits on a bus are used. The effects of this are noted for the individual buses.

The FA Bus is sourced by the A output of the floating-point register file and by the Floating-Point STATE Register and the floating-point STATUS register. The bus sources the R input of the mantissa ALU, the X register of the multiply logic, the STATE register, and the R input of the exponent and sign logic. Bits 32-71 are zero for single-precision operations (FLAG2=0) and bits 64-71 are zero for double-precision operations (FLAG2=1).

The FB Bus is sourced by the B output of the register file. The bus sources the S input of the Mantissa ALU, the Y register of the multiply logic, and the S input of the exponent and sign logic. When the FB Bus sources the ALU, bits 32-71 of the S input are zero for single-precision operations (FLAG2=0) and bits 64-71 are zero for double-precision operations (FLAG2=1).

The *FD Bus* is sourced by the mantissa ALU (bits 8-71) and the exponent ALU (bits 1-7). It can source the working register and the floating-point register file.

The FR Bus is sourced by the Divide Partial Remainder register, the multiply ALU, the FA Bus, the Divide Guard Digit register, and the round logic. It sources the working register and the R input of the mantissa ALU.

The FS Bus is sourced by the hex shifter and the FB Bus. It sources the DGD register, the working register, and the S input of the mantissa ALU. Bits 40-71 are zero for single-precision operations (FLAG2=0); bits 64-71 are zero for double precision operations (FLAG2=1) when the FB Bus is the source.

When the working register is the source, bits 40-71 are zero for single-precision operations (FLAG2=0). When the FB Bus is the source, bits 32-71 are zero for single-precision operations and bits 64-71 are zero for double-precision operations.

It is also possible to provide zeros on bits 8-71 of the FS bus for use in passing data on the FR Bus through the ALU.

The M Bus sources the FR Bus and is sourced by the multiplier ALU.

Mantissa Logic

The mantissa logic of the FPU performs arithmetic on the mantissas of floating-point numbers and does division and multiplication on integers.

General Logic

Much of the mantissa logic is used by more than one arithmetic algorithm. This includes such things as the register file, various FPU state registers, and the hex shifter.

Floating-Point Register File

The floating-point register file is a 16-word by 64-bit file that holds the operands for floating-point operations and for integer multiply and divide. The register file has two output ports, A and B, which are addressed by the IA and IB fields of the microword. The single input port is addressed by the FCW field.

The A output port sources the FA Bus while the B port sources the FB Bus.

Floating-Point Status Register

The Floating-Point Status Register (FPSR) contains bits that specify floating-point overflow, underflow, divide by zero, or mantissa overflow. Any of these conditions is a floating-point error, but they are handled differently in microcode. The UNF and OVF bits cause a microtrap to a handler when they are updated by FRG:UFS. The DVZ and MOF bits must be set by microcode, which must explicitly test for the presence of the related error conditions. The need for these tests occurs infrequently.

Additional bits perform other functions. The following table describes the bits in the FPSR:

Bits	Name	Description
0	ANY	The value of the logical OR of FPSR[1-4].
1	OVF	An exponent overflow occurred during processing of a floating-point number; the result is correct except that the exponent is 128 too small. This will cause a microtrap when the FPSR is updated by FRG:UFS.
2	UNF	An exponent underflow occurred during processing of a floating-point number; the result is correct except that the exponent is 128 too large. This will cause a microtrap when the FPSR is updated by FRG:UFS.
3	DVZ	Microcode detected a zero divisor during a divide. DVZ is a floating-point error that is detected by microcode, which is responsible for jumping to an error handler.
4	MOF	Microcode detected a mantissa overflow during the FSCAL, FFAS, FFMD or WFFAD instruction. MOF is a floating-point error that is detected by microcode. Microcode is responsible for jumping to an error handler.
5	MOF	This bit indicates mantissa overflow (MOF). While processing a FSCAL instruction, the FPU shifted the mantissa left. During a FFAS, FFMD, or WFFAD instruction, the result contained more than 15 bits for single-word results or 31 bits for double-word results. MOF is a floating-point error that is detected by microcode, which is responsible for jumping to an error handler.

Bits	Name	Description	
	TE	If this bit is set (=1), a 1 in any of the FPSR bits 1-4 will result in a floating-point macro trap. Microcode tests for this trap and jumps to the appropriate handler.	
6	Z	The result of the last floating-point operation was true zero.	
7	N	The result of the last floating-point operation was negative.	
8	RND	If this bit is set $(=1)$, then unbiased rounding is used for floating-point operations. If this bit is not set $(=0)$, then truncation is used for floating-point operations.	
9	RES	Microcode sets this bit to indicate that an interrupt has occurred during execution of resumable code.	
10-11	-	Reserved for future use. Must be zero.	
12-15	FPMOD	Floating-point ID code. Hardwired to 0111.	

Floating-Point STATE Register

The floating-point STATE register contains various bits that are necessary to restore the Floating-Point Unit after its state has been altered. The following fields are included in the state register:

Bits	Mnemonic	Description
0	SA	Sign register for A operand
1	SB	Sign register for B operand
2	A.EQ.B	Result from a compare operation. The A operand equals the B operand.
3	A.LT.B	Result from a compare operation. The A operand is less than the B operand in magnitude.
4	SWAP	This bit causes the A and B addresses for the register file to be exchanged. It is used after a compare operation to force the larger operand onto the FA Bus. This bit has no effect on write addressing.
5	X.GT.15	Result from a compare operation. The absolute exponent difference exceeds 15.
6	^XEWR	The most significant bit of the exponent working register (EWR). This bit is an inverted extension bit.
7	^ER0	The second most significant bit of the exponent R Bus. This will be the EWR0 if RAND:FLT:EXP:N is coded.
8-11	YSEL[0-3]	The contents of the byte-selection counter (see below).
12-15	^MAG[0-3]	The contents of the hex-shifter magnitude register (see below).

Hex Shifter

The hex shifter can shift the output of the working register (WR) either left or right by up to 8 bytes in four-bit increments. The shifter sources the FS Bus through a multiplexer controlled by the FS field of the microword. Micro-orders in this field also designate whether the shift is left or right. When the shifter is the FS Bus source, the magnitude of the shift is determined by the MAG portion of the floating-point STATE register.

MAG Register

The MAG register controls the hex shifter and provides a value that can be arithmetically manipulated by the exponent ALU. MAG is part of the floating-point STATE register (bits 12-15). The MAG register is controlled by the RAND:FLT:SCNT field. Figure 2-13 shows the MAG register.




Figure 2-13. The MAG Register Sources

The MAG register is sourced by the following:

- A) The Leading Zero Detector (LZD)—The LZD determines the number of leading hexadecimal zeros in the mantissa and places the result in MAG. MAG can then be used to left-shift the mantissa and to adjust the exponent in order to normalize the number. Note that on the first cycle the LZD gives a result for only the first two hexadecimal digits in the mantissa. If the first three digits are zero, the full result must be used on the next cycle to provide the correct value for MAG. If the first two hexadecimal digits are not both zero, then all leading zeros have been detected and the initial result is correct. Hardware resolves the correct MAG value, invisibly to microcode, except that RAND:FLT:SCNT:LZD must be coded twice (see Chapter 3).
- B) The value of bits 4-7 of the EF Bus (the output of the exponent ALU).
- C) The absolute value of the difference between two exponents.
- D) The value of bits 12-15 of the FA Bus.
- E) The IY field—The value in the IY field of the microword can source the MAG register.
- F) First Nibble Zero logic—If the first nibble of the mantissa is 0, MAG is set to -1; otherwise, MAG is set to 0.
- G) Divide Prescale logic—MAG is set to 1 if there was a carry-out from the mantissa; otherwise, MAG is set to 0.

Mantissa ALU

The mantissa ALU is used for all floating-point operations, as well as integer multiplication and division. It adds and subtracts mantissas after they have been aligned. During multiplication, it sums the partial products produced by the multiply ALU. During division, it calculates the quotient by adding or subtracting the divisor from the partial remainder.

Working Register

The working register holds the quotient in divide operations and the partial product in multiply operations. For addition and subtraction prescaling, it holds the smaller of the two operands. It also holds the unnormalized result of all operations that use rounding and normalization. The FR Bus, FS Bus, and FDI Bus can all source the working register. During division, the working register performs 1-bit left shifts and gets its least-significant bit from the Q-bit. The Q-bit is an extension to the mantissa ALU and is derived from the mantissa carry, the ALU operation, and the most significant bit of the ALU output. The hex shifter can left-shift or right-shift the output of the working register.

Multiply Hardware

FPU multiplication uses the multiply ALU, the mantissa ALU, the X and Y registers, and the working register. The operands are placed in the X and Y registers. The X register is multiplied by a single byte of the Y register; that byte is selected by the YSEL counter. Each multiplication by the multiply ALU produces a partial product that is added to the accumulated partial product in the working register. Figure 2-14 shows the mantissa hardware used in multiplication.




Figure 2-14. Multiply Data Paths

X and Y Registers

The X and Y registers hold the multiplicand and the multiplier, respectively, for integer and mantissa multiplication. The Y register outputs a single byte at a time, selected by the YSEL counter.

YSEL Counter

The YSEL counter is a 4-bit counter that designates which byte of the Y (multiplier) register forms the current partial product. This counter is controlled by the FRG field of the microword, and loaded from the IY field. Note that YSEL is part of the floating-point STATE register (bits 8-11).

Multiply ALU

The multiply ALU multiplies the 56-bit X register by 8 bits of the Y register. This operation forms a 64-bit partial product. Partial products are accumulated in the working register to form the final product.

Divide Hardware

FPU division uses the mantissa ALU, the Divide Partial Remainder (DPR) register, the working register, and the Divide Guard Digit (DGD) register. The DGD register preserves the guard digits of the prescaled dividend when that value must be temporarily written back to the register file (which has no guard-digit storage).

The floating-point ALU implements a nonrestoring division algorithm. The hardware performs the following functions:

- The working register shifts in the quotient one bit at a time.
- The DPR register stores the remainder, left shifted by one bit.
- The mantissa ALU adds or subtracts the divisor from the remainder.
- The register file stores the divisor. During division, the FCW and IB fields must address the divisor in order for the register outputs to be stable. Register file port B sources the divisor to the S side of the mantissa ALU.

Figure 2-15 shows the divide data paths in the FPU. Note that two division cycles are performed for each microinstruction cycle.




Figure 2-15. Divide Data Paths

Divide Guard Digit Register

The Divide Guard Digit (DGD) register holds the least-significant 8 bits of the dividend at the beginning of a divide operation. The most-significant bits are in a register in the register file. The DGD register and the A port of the register file together source the entire dividend onto the FR Bus. The divisor is subtracted from the dividend during the initial division cycle, and the result is loaded into the Divide Partial Remainder (DPR) register.

Divide Partial Remainder Register

The Divide Partial Remainder (DPR[8-71]) register holds the intermediate dividend during a divide operation. The DPR is sourced by the mantissa ALU and sources the R side of that ALU. When a value is passed through the DPR, it is left-shifted by one bit and the least-significant digit is zero filled.

Sign and Exponent Logic

The sign and exponent logic determines the signs of the results of arithmetic operations and computes the exponents of floating-point numbers. Figure 2-16 shows the sign and exponent logic.




Figure 2-16. Sign and Exponent Logic

The operands for any operation are available on the FA and FB Buses, which also source the sign registers (SA and SB). The sign logic uses the values in these registers to determine the sign of the result. The RAND:FLT:SGN field of the microword controls the sign logic.

Exponents in MV/10000 floating-point numbers are in excess-64 form. If exponents are added or subtracted, as in multiply or divide, the excess-64 form must be restored by subtracting or adding 64 to the result. These operations are performed by the RAND:FLT:EXP micro-orders A64 and S64 in conjunction with the FX:X64 micro-order.

Exponent Working Register

The Exponent Working Register (EWR) provides temporary storage for exponent values. The EWR is one of the possible inputs to the exponent ALU; the MAG register can be added to or subtracted from the EWR.

Exponent ALU

The exponent ALU manipulates the exponents of floating-point numbers. The R side of the ALU accepts input from either the EWR or the FA Bus; the inputs to the S side can be the FB Bus, the MAG register, or zero. The exponent ALU can add its inputs or subtract its S input from its R input. Output from the ALU is to the FD Bus and the EWR. An exponent value can be stored in the EWR for use in a future cycle. In addition to the R and S inputs, the ALU can add 1 to the exponent to correct for a carry-out (MOF) from the mantissa that is adjusted by a right shift.

SA and SB Registers

The SA and SB registers are single-bit registers that hold the signs of the current operands. They are sourced by the most-significant bits of the FA and FB Buses. In turn, they source the sign logic.

Sign Logic

The sign logic determines the sign of the result of an FPU operation. The RAND:FLT:SGN field determines how the sign is computed.

The Address Generator

The Address Generator (AG) provides logical addresses, which can then be transformed into physical addresses by the Address Translation Unit (ATU). The AG input comes from either the IP via the DISP bus, or from main memory via the CPM bus. The AG can source data to the CPM bus, the CPD bus, the LA bus, and the DISP bus. Figure 2-17 shows the Address Generator.




Figure 2-17. The Address Generator

Buses

The DISP bus is a 32-bit, bidirectional bus that carries data between the Instruction Processor (IP) and the AG. The IP ALU sources the DISP bus, while both the IPPC register and the ICP register take data off the bus. The IP normally drives the DISP bus. It uses the bus to provide instruction displacements (either addressing offsets or immediate data) to the AG. If an address calculation is specified as PC relative, the IP will add the PC to the address offset before sending it to the AG. The AG ALU can source the DISP bus with the AY bus during branches so the IP can update the IPPC and ICP registers.

The Logical Address (LA) bus carries logical addresses from the AG to the Address Translation Unit (ATU). FLAG1 determines the width of the LA bus. If FLAG1=0, the LA bus is narrow and the AG drives the 15 least-significant bits and LA0; the Address Translation Unit will supply the current ring bits (LA[1-3]) from CRE[1-3]. If FLAG1=1, the

LA bus is wide and the AG drives all the bits on the LA bus, except when RAND:ATU:ATU1:AC is coded.

The LA bus is sourced by the AG ALU via the AY bus. Two separate drivers can drive AY[0-31] or AGB[31],AY[0-30] onto the LA bus. Unless overridden by the RAND:ATU:ATU0 micro-orders BYTE and WORD, the type of memory start determines which bits go onto the bus: word and double word addresses use AY[0-31]; byte addresses use AGB[31],AY[0-30].

The AY bus is a 32-bit, internal AG bus. It is sourced by the AG ALU and transfers data to:

- A) the last Logical Address (LA) register,
- B) the Logical Address (LA) bus,
- C) the IP DISP bus,
- D) the AG register file (through the RFIN multiplexer), and
- E) the CPM bus.

The Address Generator Bus (AGB) is a 32-bit, internal AG bus that drives the B input to the AG ALU. The AGB is sourced by:

- A) the Displacement (DISP) register,
- B) the B output port of the AG register file,
- C) the last LA register, and
- D) the 8-bit constant register (with sign fill).

Register File

The AG register file has sixteen 32-bit registers, a single input port, and two output ports. The output ports, A and B, are separately addressable. The A output goes to the A input of the AG ALU and also drives the CPD bus; the B output goes to the AGB bus. Input to the register file is through a multiplexer that selects either the AY bus or the CPM bus.

By convention, registers in the file are assigned particular meanings as follows:

Register	Meaning
0	Identical to macroprogram accumulator 0 at IPOP (must contain same value as ALU reg. 0 at IPOP)
1	Identical to macroprogram accumulator 1 at IPOP (must contain same value as ALU reg. 1 at IPOP)
2	Identical to macroprogram accumulator 2 at IPOP (must contain the same value as ALU reg. 2 at IPOP)
3	Identical to macroprogram accumulator 3 at IPOP (must contain the same value as ALU reg. 3 at IPOP)
4	Wide stack pointer
5	Constant (=1)
6	Constant (=2)
7	Reserved register for Long Address Translation (LAT)
8	Microprogram general register
9	Microprogram general register
10	Microprogram general register
11	Microprogram general register
12	Microprogram general register
13	Microprogram general register
14	Register addressed by ACSR
15	Register addressed by ACDR

Register File Addressing

The register file addressing logic controls the selection of particular registers within the file. The logic produces separate addresses for the A and B output ports; the B address is also the address for the input port. The addresses for the register file can be supplied from fields in the microword, fields in the macroword, or registers in the integer ALU.

When the AG is not performing effective address (EFA) calculations, the AA (CSAA[0-3]) and AB (CSAB[0-3]) fields of the microword determine which registers will be addressed. For AA or AB from 0 to D, the value in the field directly specifies the register in the file. For AA or AB equal to E, the register is specified by the ACSR register (SRC[0-3]) of the integer ALU; for AA or AB equal to F, the file address is specified by the ACDR register (DES[0-3]) of the integer ALU.

When the AG is performing EFA calculations, the A output port addressing and the ALU operation are controlled by the index bits from the macroinstruction:

A-Port Address	Address Mode and Operation
00	Absolute macroaddressing—The A port is not used for EFA calculations.
01	PC relative addressing—The A port is not used for EFA calculations.
10	AC2 relative addressing—The A port reads AC2, which is added to the displacement from the AGB bus.
11	AC3 relative addressing—The A port reads AC3, which is added to the displacement from the AGB bus.

AGB Bus Sources

The AGB bus sources the B input of the AG ALU. The bus itself has four sources. The AGB field of the microword selects a particular source. The sources are:

- · the register file,
- · the IP displacement register,
- the constant register with sign extension, and
- the last Logical Address (LA) register.

The register file is discussed above.

The *IP displacement* register is sourced by DISP[0-31]. DISP[0-31] is the output of the IP ALU. Usually, the displacement register contains the displacement portion of the next macroinstruction from the Instruction Processor.

The constant register is loaded from the CONSTANT field of the microinstruction. The register is loaded on every microinstruction, but when the field is being used for a floating-point instruction, the bits in the register may be meaningless.

The last logical address register holds the address used for the most recent memory start. Its input comes from the AY bus. It is loaded automatically on memory starts, except for Long Address Translations (LATs) or Cache Block Crossings. LATs occur when the ATU does not have an encached translation for the logical address from the AG. Thus, on return

from an LAT routine, the last logical address register holds the address of the original memory request. Cache block crossings (CBXs) occur when a double word access is performed for a memory address that ends in (octal) 7 (i.e., the eighth and last word in a block).

RFIN Multiplexer

The Register File In (RFIN) multiplexer selects the source of the data that is read into the AG register file. This data can come from the AY bus or the CPM bus. The multiplexer is controlled by the AL field of the microword.

Address Generator ALU

The Address Generator (AG) ALU is 32 bits wide, with A and B inputs and a carry-in. Its A input comes from the register file and its B input comes from the AGB bus. Its output goes to the AY bus. The ALU is controlled by the AOP field of the microword. The following functions are available:

- $\cdot A + B$
- B A
- · Pass the B input through unchanged
- Try to perform an Effective Address (EFA) calculation. If the index bits in the macroinstruction are 00 or 01, the ALU passes the B input (sourced by the displacement register). If the index bits are 10 or 11, the ALU performs A + B, where A is sourced by AG2 or AG3, respectively, and B is sourced by the displacement register.

The Address Translation Unit

The Address Translation Unit (ATU) changes logical addresses from the Address Generator into physical addresses that reference main memory. Because the logical address space is much larger than the physical address space, it is necessary for the ATU to map any logical address into a smaller physical address. Figure 2-18 shows the various parts of the ATU.




Figure 2-18. The Address Translation Unit

Address mapping is done on a page (2K-byte) basis. Software maintains page tables in physical memory that specify the current mapping of all logical pages. Parts of those tables are also kept in a cache in the ATU. If a mapping is encached, then the ATU can immediately translate a logical address to a physical address. Otherwise, microcode must go to main memory and examine the page tables to determine the correct physical address and to load the cache with a new value.

The ATU also maintains the Segment Base Registers (SBRs). The SBRs registers point to the page tables in main memory. They also contain certain status bits for a segment.

Besides addressing, the ATU also takes care of protection by checking each address for ring maximization, indirection depth, and read/write/execute access. In addition, it maintains the modified/referenced RAM, which keeps track of the current status of physical pages in memory.

Address Translation Cache

The Address Translation Cache (see Figure 2-18) contains 1024 translations of logical to physical addresses. It is addressed by the Logical Address (LA) bus. The cache outputs a 14-bit physical page address. The page address is concatenated with the 10-bit page offset to form a full physical address on the CPU Physical Address (CPA) bus. The physical address goes to the memory system. Microcode can load, flush, and read the cache.

Referenced/Modified RAM

The referenced/modified RAM contains bits for each physical page that indicate whether that particular page has been referenced (read or written) or modified (written). This information is used by the operating system to determine which pages need to be swapped out to secondary memory (i.e., disk) and whether a page can be overwritten.

The referenced and modified bits are part of the ATU state. This state can be read by using the CPDS:ATS micro-order. The referenced and modified bits can be written by the RAND:ATU:ATU0:WRRM micro-order. In addition, referenced bits can be read and reset by the RAND:ATU:ATU0:RSRF micro-order. The specific use of the RSRF micro-order is described in Chapter 3.

Validity RAM

The ATU validity RAM indicates the current state of the address translation cache. There are 1K bits in the RAM: one bit for each translation. Whenever an LAT loads a valid address translation into the cache, the appropriate validity bit is set. The RAND:ATU:ATU0:PRGA resets all the bits in the RAM. If the validity bit for a particular translation is not set, then an LAT routine is necessary to produce the proper logical-to-physical address translation.

Logical Address Translation

If the logical address presented to the ATU is encached, then the ATU can simply place a physical address on the CPA bus and the memory reference can continue. However, if the logical address is not encached, then the ATU causes a Long Address Translation (LAT) trap to occur. The micromachine goes into LAT mode and executes an LAT routine.

The LAT routine aborts the main memory start and inhibits any pending start, constructs the new logical to physical address translation by going to page tables in memory, and then restarts memory the same way that it was started before the LAT routine began. The new translation is stored in the ATU cache.

Page Table Addressing Logic

The ATU has logic that expedites page table addressing. The micro-order RAND:ATU:ATU0:RSBR automatically constructs an address from the current address in the Logical Address Register (LAR). The logic addresses the appropriate SBR (determined by bits 1-3 of the LAR) and concatenates it to bits 4-12 or 13-21 of the LAR. Which set of bits is chosen depends on the level bit (bit 1) of the SBR: for one-level page table addressing, the logic chooses bits 13-21; for two-level addressing, bits 4-12. This address is gated to the CPA bus for an immediate memory reference. Figure 2-19 shows the page table addressing logic.




Figure 2-19. Page Table Addressing Logic

Ring Protection

The ATU maintains two registers for keeping track of protection rings. These are the Current Ring of Execution (CRE) register and the Effective Source Register (ESR). The CRE register is set to the ring in which the presently running program resides. The ESR register is used in indirection chains; it represents the ring for the last memory reference.

At macroinstruction boundaries, ESR is set to CRE. During an indirection chain, the protection logic checks the newly started address against the ESR. All memory references must be outward from the ring of execution. On valid memory references, the ESR is reset to the new address; this process continues until the end of the indirection chain or until it reaches an indirection depth of fifteen.

Indirection Protection

The defer counter keeps track of indirection depth. The counter is set to zero at the beginning of a macroinstruction; the only exception occurs when there was an EFA started at IPOP during the previous macroinstruction. The counter will be incremented each time an indirection is resolved. (Incrementing occurs when the RAND:ATU:ATU1:DF micro-order is coded and the test for ending the indirection chain is false.)

The defer counter will allow fifteen levels of indirection for all the indirection resolution required by a macroinstruction. For instance, if an instruction takes a stack fault and must resolve a pointer, that resolution is added to the defer count. At fifteen levels of indirection, a protection trap occurs if the ATU is on; if the ATU is off, there is no protection.

If more than one indirection resolution occurs in a macroinstruction, microcode must reset ESR to CRE at the beginning of each such resolution. This is done with the following steps:

- 1) Code RAND:ATU:ATU1:AC, which sets the logical address ring bits to CRE, and
- 2) Code RAND:ATU:ATU0:LCRE, which loads both CRE and ESR from the logical address ring bits.

Read/Write/Execute Protection

The ATU contains a read/write/execute RAM. This RAM is loaded from bits 2-4 of a PTE and reflects the current protection status of pages with translations in the address translation cache. The bits are written whenever a new address translation is produced. These bits can cause a memory protection error if microcode attempts to access a page illegally.

ATU State

The Address Translation Unit (ATU) has 32 bits of state. Table 2-3 explains these bits.

Table 2-3. Address Translation Unit State

Bits	Name	Description
0	^RESTART	Indicates whether the instruction can be restarted after a page fault.
1-3	ESR[1-3]	The Effective Source Ring
4-6	^FLT CODE[0-2]	The fault code for a hardware protection trap.
7	^ASMPND	A cache-block crossing, read double-word assembly is pending.
16	^MEMSTARTED	A memory start is still pending.
17	^SXCT STRT	An XCT start is pending.
18	^IPST STRT	Indicates whether the last non-LAT start was an Instruction Processor start (IPST).
19	^ICAT STRT	Indicates whether the last non-LAT start was an Instruction Cache Address Translation (ICAT).
20	^CPWRITE@	Indicates whether the last non-LAT start was a write.
21-23	^CPMODE@[0-2]	The mode bits for the last non-LAT start.
24	^CBXRTIN	Indicates whether the last non-LAT start was during a Cache Block Crossing.
25	^AT:SET LAT	Indicates whether the processor is in the LAT state.
26	MOD	The modify bit of the page addressed the preceding cycle.

Table 2-3. Address Translation Unit State (Continued)

Bits	Name	Description
27	REF	The reference bit of the page addressed the preceding cycle.
28-31	REF[0-3]	The four reference bits for the quad page addressed the preceding cycle.

These state bits can be sourced to the CPD bus with the CPDS:ATS micro-order. The ESR and ^CPMODE bits can be restored from the LA and CPD buses with the RAND:ATU:ATU0:LATS micro-order. The ^CPMODE bits are explained under the LATS micro-order in Chapter 3. Table 2-4 shows the meanings of values in the FLTCODE field.

Table 2-4. ATU State Fault Codes

Code	Meaning
0	Read protection fault
1	Write protection fault
2	Execute protection fault
4	Inward reference
5	Defer protection (more than 15 indirect references)

ATU Diagnostic Register

The ATU Diagnostic Register is a 24-bit register that can hold either the current value on the CPA bus or various internal state bits of the CPU. These bits can be sourced (inverted) on the CPD Bus with the CPDS:ATD micro-order. The register captures data whenever a CPU memory start is coded (including IP starts). If RAND:ATU:ATU0:XTND is coded, then CPA[8-31] sources the register; if XTND is not coded, the register will hold the following bits:

Bits	Signal	Description
8-9	_	Reserved
10	^BP:CPRT	The read transfer signal on the backplane.
11	^BP:CPWT	The write transfer signal on the backplane.
12	^PERMITRD	The read-enable bit in the read/write/execute RAM for the page addressed by the current logical address.

Bits	Signal	Description
13	^PERMITWR	The write-enable bit in the read/write/execute RAM for the page addressed by the current logical address.
14	^PERMITXEQ	The execute-enable bit in the read/write/execute RAM for the page addressed by the current logical address.
15	NEWXLAT	LOAD STATUS bit for translation cache, protection, and validity RAM.
16	FRC LAT	The Force Logical Address Translation bit in the of the CBUS register R1 (bit 5). This bit lets the SCP force LAT after every memory reference from microcode. This bit is valid only when the ATU is on and it is not in a LAT routine.
17	^GDXLATA	The output of the address-translation cache comparator that compares LA[4-11] with TAGLA[4-11].
18	^GDXLATB	The output of the address-translation cache comparator that compares LA[12-14] to TAGLA[12-14]. If FRC LAT is set, this output will always be zero.
19	VLDSETSEL	The set-selector bit for the validity RAM. When this bit equals 1, it designates set A; when 0, set B.
20	^VALID TAG	The output of the validity RAM designated by VLDSETSEL. The RAM is addressed by the current logical address or by the purge counter.
21-31	TAGLA[4-14]	The output of the tag store for the address translation cache.

ATU Dispatch

The ATU can produce a two-bit code that goes to the microsequencer and can be used as part of a dispatched microaddress. This type of dispatching is used in Long Address Translation (LAT). The code provides a quick means to branch on the differences between one-level and two-level page tables and between memory start types. The NAC:DSR:A micro-order implements dispatching.

Micro-orders in the RAND:ATU:ATU0 field distinguish the various types of memory start. The possible meanings of the dispatch code, as generated by the ATU, are as follows:

Code	Meaning
00	Start memory for the second Page Table Entry (PTE). This means that the first memory start for the first PTE has already been performed using an RBSR micro-order. This second memory start must use a LPTA micro-order during the memory start in order to correctly address the second PTE.
01	Start memory using an IPST micro-order, i.e., an IP start caused the original LAT routine, and memory must be restarted in the same manner.
10	Start memory using an ICAT miro-order, i.e., an instruction cache translation caused the original LAT routine, and memory must be restarted in the same manner.
11	Start memory using an OPTA micro-order. OPTA means that the final address has been formed and is sourced to the CPA bus for this memory start.

Note: Within an LAT routine, IPST and ICAT have the meaning of OPTA in addition to their regular meanings. When a routine is simply examining PTEs, any of the last three dispatch codes means that the final translation has been encountered.

The CPD Bus and Transfer Register

The ATU cannot take data directly off the CP Memory (CPM) bus. To get information from memory (e.g., a PTE during an LAT), data is passed through the transfer registers (TREG) of the integer ALU. See the integer ALU section for the details of this register.

Instruction Processor

The Instruction Processor (IP) decodes macroinstructions from the instruction stream. It provides starting microaddresses to the WCS for the microroutines that implement the instructions. The IP decode process is pipelined, so that at any given time as many as four different instructions may be in various stages of decoding. The IP has an instruction cache that contains the currently executing instructions. It also maintains the macroinstruction program counter (IPPC). Figure 2-20 shows the IP.




Figure 2-20. The Instruction Processor

When the IP executes instructions sequentially, PCX (which is derived from PCN and the instruction length) points to the executing instruction, PCN points to instruction to be executed next, and IPPC points to the instruction after that. When the next instruction is out of sequence, e.g., because of a JMP, microcode loads a new location into the IPPC register. PCX always points to the currently executing macroinstruction.

Microcode can examine PCX and PCN using micro-orders in the CPDS field. In addition, it can examine the next instruction location whether it comes from PCN or IPPC.

Displacement fields from macroinstructions can go to the Address Generator over the DISP bus.

Instruction Processor State

IP state consists of the following registers:

- The Instruction Processor Program Counter (IPPC)
- The Next Program Counter (PCN)

- The LPCX[0-1] register, which contains the length of the currently executing instruction
- · The ION flag, which is the interrupt mask bit
- The XCTFLG, which indicates whether the current macroinstruction resulted from an XCT

The CPDS:IPS micro-order sources IP state onto the CPD bus as follows:

CPD Bits	IP State Bits	Description
30-31	LPCX[0-1]	Length of currently executing instruction
29	ION	Master interrupt mask bit
28	XCTFLG	Bit indicating that the current macroinstruction was the result of an XCT instruction

Interrupts

Interrupts are handled by the IP. Interrupts are normally taken between macroinstructions as a result of the IP forcing the starting microaddress (STUAD) to the beginning of the interrupt routine.

If an instruction takes longer to execute than the specified interrupt latency (12 microseconds), microcode must acknowledge interrupts within that instruction. By convention, microcode tests for interrupts within 64 instruction cycles if an instruction requires more than 80 cycles to execute. We classify interruptable instructions as "restartable" or "resumable."

A restartable instruction can safely back out of the current operation or can leave the accumulators in such a state the instruction can procede with its operation. These instructions manage interrupts by either backing out or updating the accumulators, pointing the IPPC at themselves, and performing an IPOP. At IPOP the IP forces the STUAD to the interrupt routine. On returning from the interrupt, execution starts again at the interrupted instruction. A wide character move (WCMV) is an example of a restartable instruction. Because the data in the accumulators is updated with each byte moved, the instruction can be restarted at any point.

A resumable instruction cannot back out of the current operation and requires more state than the accumulators. In this case, state is pushed on the user's stack in the same ring as the interrupted instruction (to maintain system integrity, a microaddress may not be pushed on the user's stack). PSR2 is set, which indicates that an instruction must be resumed, IPPC is pointed at the instruction itself, and an IPOP is performed. When the instruction reexecutes, it must check PSR2 to discover whether it must begin fresh or continue from where it left off.

I/O Protocols

The MV/10000 CPU communicates with the I/O Controller (IOC) (and therefore all peripherals) via the CPD bus. The IOC uses the least-significant 16 bits of the bus to transmit and receive data. TREG is the only valid CPD source for communication with the IOC. Bits 14-15 are command bits that tell the IOC what the CPU expects it to do. These bits are coded as follows:

CPD[14-15]	Explanation of Command
00	Clear (No op)
01	Instruction: the data on CPD[16-31] is interpreted as a command. See below for commands.
10	Input: the data on CPD[16-31] is irrelevant.
11	Output: the data on CPD[16-31] goes to the IOC.

There are two separate instruction formats: one for programmed I/O and one for nonprogrammed I/O. These formats are shown in Figure 2-21.




Figure 2-21. I/O Command Formats

The first bit in the command specifies programmed or non-programmed I/O. The remaining fields have the following meanings:

- Port—The IOC port address. Port 7 is the broadcast port. Port 0 and 1 are supported.
- R—Reserved.

- OPcode The programmed I/O command: NIO, DIA, DOA, etc.
- f—The control bits for Busy/Done flags. These are S, C, P for non-SKP instructions, and BZ, BN, DZ, DN for SKP instructions.
- Device Code The code for a device on the I/O bus.
- Register—The address of a register in the port. This is the register that will be read from or written to.

The following sequence transfers data to and from the IOC:

- 1) Issue an instruction (01) command.
- 2) Issue either an input (10) command or an output (11) command.
- 3) Wait two cycles and then test I/O Busy (TSEL:IOB).
- 4) Wait for I/O Busy to clear, and, if Step 2 was input, read the input data from the CPD bus.
- 5) Issue a clear (00) command to prepare for next instruction.

End of Chapter

Chapter 3 Micro-order Format and Instruction Set

This chapter describes the micro-orders in the MV/10000 microword. The microword contains 104 bits, including spare and parity bits (see Figure 3-1).




Figure 3-1. The MV/10000 Microword

The microword is divided according to its control functions. Each subsystem in the MV/10000 processor has its own microword fields; in addition, the RAND field contains micro-orders that control several different subsystems.

Each micro-order is described separately in this chapter. Each description begins with a descriptive title, followed by the microassembler mnemonic and the value (in hexadecimal) for that micro-order. For example:

Sample micro-order

SAMP

00

Description of micro-order.

NAC-Next Address Control

The Next Address Control (NAC) field controls logic on the microsequencer board. The NAC field has two separate formats, depending on whether the microinstruction is conditional or unconditional. Figure 3-2 shows the NAC subfields.




Figure 3-2. The NAC Field

The NAC field controls:

- stack operation and address selection,
- · test selection, and
- · dispatching.

Note that a micro-order contains either a COP and TSEL field or a UCOP field. All micro-orders beginning '111' are unconditional. (This escape is automatically coded by the microassembler whenever a UCOP micro-order is specified.)

Addresses

Microsequencer addresses can come from:

- 1) the incremented microprogram counter (uPC+1),
- 2) the top-of-stack (TOS) register,
- 3) the AA Bus, or
- 4) the dispatch register.

The incremented microprogram counter value is the address immediately following the current one with wrap-around on 1K pages. The top-of-stack register value is an address that was previously pushed onto the stack by an NAC:COP or NAC:UCOP micro-order.

The AA Bus is sourced differently depending on whether a micro-order is conditional or unconditional. For conditional micro-orders, the least significant ten bits come from the NAC:ADDRESS field and the most significant bits are equal to the current page; thus conditional micro-orders cannot address beyond the current page boundaries. For unconditional micro-orders, all fourteen bits on the AA Bus come from the NAC:ADDRESS field; thus unconditional micro-orders can address all of WCS.

Addresses from the dispatch register maintain the same distinction between conditional and unconditional. Like the AA Bus addresses, conditional dispatched addresses take the current page number for the four most significant bits. However, the AA Bus supplies only the most-significant address bits for micro-orders that use dispatching. The least-significant bits are provided from the dispatch register or the Address Translation Unit (ATU). Table 3-1 shows the possible address forms for MV/10000 microcode.

Table 3-1. MV/10000 Microaddresses

Symbol	Description
uPC+1	The 14-bit address from the incremented microprogram counter.
TOS	The address that is currently at the top of the microstack.
AA	The 14-bit address from the microinstruction. [unconditional, undispatched]
PA	The current page number concatenated to the 10-bit page offset in the microinstruction (NAC[10-19]). [conditional, undispatched]
ADA	The address from the dispatch multiplexer that is based on the NAC:ADDRESS field. [unconditional, dispatched]
PDA	The address from the dispatch multiplexer that is based on the NAC:ADDRESS field concatenated to the current page number. [conditional, dispatched]

Stack Control and Address Selection

The stack control and address selection logic is controlled by the COP and UCOP subfields of the NAC field. This logic includes:

- the AA selector logic, which determines the source of the AA Bus;
- the microaddress selector logic, which determines the source of the WCS address;
- the microstack source selector logic, which determines what will be pushed onto the microstack; and
- the microstack control logic, which determines whether the stack will be pushed or popped.

NAC:COP—Conditional OPcode

The COP field controls conditional actions by the microsequencer, i.e., those actions that depend on the outcome of a test. The micro-order specifies the next address and the stack operation for both the true and the false test results. The particular test is specified in the NAC:TSEL field. Table 3-2 summarizes COP field micro-orders. (In the table .+1 means uPC+1.)

Table 3-2. Conditional Microorders in the OP Field

Mnemonic	Value	True		True False	alse	Description
		uPC	uStack	uPC	uStack	
СЈМР	0	PA	-	.+1	-	Conditional jump
CJSR	1	PA	PSH .+1	.+1	-	Jump and save return
CDSP	2	PDA	-	.+1	-	Conditional dispatch
CABT	3	PA	POP	.+1	POP	Cond jump, abort TOS
CRTN	4	TOS	POP	PA	-	Conditional return
тwв	5	TOS	POP	PA	POP	Two-way branch
CRST	6	TOS	POP	PA	_	Conditional restore
_	7	_	_	-	_	Escape to unconditionals

Conditional Jump

CJMP

0

If the test is true, CJMP transfers control to the address specified in NAC:ADDRESS. This address must be within the current page; CJMP's 10-bit address field cannot address more than a page at a time. If the test is false, CJMP goes to uPC+1. CJMP has no effect on the microstack.

Jump and Save Return

CJSR

1

CJSR is identical to CJMP, except that if the test is true, uPC+1 is pushed onto the microstack. At some later point, control can be returned by popping the stack.

Conditional Dispatch

CDSP

2

If the test is true, CDSP forms an address using the dispatch register or bits from the ATU. If the test is false, control transfers to the following instruction. Note that CDSP requires the use of a DSR micro-order to further specify the dispatching.

Conditional Jump, Abort TOS

CABT

3

If the test is true, CABT transfers control to the address specified in the NAC:ADDRESS field. If the test is false, control transfers to the following instruction. In this regard, CABT is identical to CJMP. However, CABT has the additional effect that regardless of the test outcome, the microstack is popped.

Conditional Return

CRTN

4

If the test is true, CRTN transfers control to the address at the top of the stack and pops the microstack. If it is false, control transfers to the address in the NAC:ADDRESS field and the microstack is unchanged.

Two-way Branch

TWB

5

If the test is true, TWB transfers control to the address at the top of the microstack. If it is false, control transfers to the address in the NAC:ADDRESS field. Regardless of the test result, TWB pops the microstack.

Conditional Restore

CRST

6

If the test is true, CRST:

- A) transfers control to the address at the top of the microstack,
- B) pops the microstack, and
- C) forces the test condition for the next microcycle to come from the restored microstack (TOS14).

If the test is false, control transfers to the address in the NAC:ADDRESS field and the microstack is unchanged.

Note that CRST is the only micro-order that restores the test condition; it is used primarily by trap routines.

NAC:TSEL-Test Selection

The test select (TSEL) field selects tests for COP micro-orders. There are a total of 64 tests. Unless otherwise noted, the test result applies to the test condition in the preceding microcycle.

The polarity bit controls the value of the test return: if the polarity is changed from the value in the table, the meaning of the test is reversed. For instance, if the polarity bit for

NAC:TSEL-Test Selection

IOB is changed from 1 to 0, the meaning becomes "I/O not busy."

Note: The microassembler automatically changes the polarity bit if a mnemonic is preceded by "N," e.g., "NIOB." Also, the assembler recognizes FALSE as having the meaning NTRUE.

Microsequencer Tests

The following tests apply particularly to the microsequencer.

True

TRUE

Polarity=0 Value=0

The outcome of the TRUE test is always true, forcing the action specified in the COP field. Coding FALSE will reverse the polarity bit and force the false choice.

CPD31 Equals 1

CPD31

Polarity=1 Value=1

CPD31 tests the value of the least significant bit on the CPD Bus. If the bit is 1, the test is true; if 0, false.

Microstack Empty

USMT

Polarity=1 Value=2

USMT is true if there is no more data in the microstack; if values remain to be popped, the test is false.

Interrupt Pending

INTR

Polarity=1 Value=3

INTR is true if there is an unserviced interrupt waiting and the interrupt on flag (ION) is set to 1.

IO Busy

IOB

Polarity=1 Value=4

IOB is true if the I/O Controller (IOC) is busy, i.e., if it cannot receive or source data at this time. See the section "I/O Protocols" in Chapter 2.

IP Started

IPST

Polarity=0 Value=5

This test is true if, during the current macroinstruction, a RAND:ATU:ATU0:IPST micro-order has been issued. This means that a new value has been loaded into IPPC.

SCP Command Valid

CIRV

Polarity=1 Value=5

CIRV is true if the CIR register on the SCP has valid data; i.e., an SCP request is ready.

Macroinstruction Executed

XCTF

Polarity=0 Value=6

XCTF is true if an *Execute* microinstruction sequence inserted the current macroinstruction in the instruction stream (rather than the instruction coming from memory). Note that both XCT and PBX instructions perform *Execute* sequences.

Perform Rounding

RND

Polarity = 0 Value = 7

RND is true if bit 8 of the Floating Point Status Register (FPSR) is 1. FPSR8 specifies whether rounding or truncation takes place in floating-point arithmetic. FPSR8=1 indicates unbiased rounding; FPSR8=0 indicates truncation.

Flag Tests

FLG[0-7]

Polarity=0 Value=[8-F]

The FLG# tests are true if the appropriate flag is 1, and false if the flag is 0. The "Flags" section of Chapter 2 explains the meanings of the individual flags.

Address Translation Unit Tests

The following tests are used by the Address Translation Unit (ATU).

Test Most Significant Bit

INDR

Polarity = 1 Value = 10

This micro-order tests the most-significant bit in the data coming from memory. If a double-word memory start was initiated in MEMS, then it tests CPM0; if a single-word memory start was initiated, it tests CPM16. The test is true if the tested bit is 1.

This test is used to examine the indirection bit in data brought from main memory.

Current Ring Equal to Zero

RNG0

Polarity=1 Value=11

This micro-order tests to see if the Current Ring of Execution (CRE) is zero, i.e., if the program is currently in the operating system segment. The test is true if CRE = 0.

Check for Inward Reference

RMAX

Polarity=1 Value=12

Checks the current reference to see whether it is less than the Current Ring of Execution (CRE) or the Effective Source Ring (ESR). If the micro-order RAND:ATU:ATU1:DF (the defer micro-order) was coded with the last memory start, then the processor is in an indirection chain, and the test uses the ESR. Otherwise, the test uses the CRE.

Note that memory need not be started for this test: simply sourcing the address to the LA Bus is sufficient. If memory is started, then the memory protection mechanism is also armed.

Ring Less Than Effective Source Ring

LESR

Polarity=0 Value=13

Checks to see whether the ring bits for the current logical address are less than the Effective Source Ring (ESR). The test is true for LA[1-3] < ESR[1-3].

Ring Greater Than Current Ring of Execution

GCRE

Polarity = 0 Value = 14

Checks to see whether the ring bits for the current logical address are greater than the Current Ring of Execution (CRE). The test is true for LA[1-3] > CRE[1-3].

Ring Equal to Current Ring of Execution

ECRE

Polarity=0 Value=15

Checks to see whether the ring bits of the current logical address are equal to the Current Ring of Execution (CRE). The test is true for LA[1-3] = CRE[1-3].

Ring Less Than Current Ring of Execution

LCRE

Polarity=0 Value=16

Checks to see whether the ring bits of the current logical address are less than the Current Ring of Execution (CRE). The test is true for LA[1-3] < CRE[1-3].

Detect Cache Block Boundary

CBLK

Polarity=1 Value=17

Checks to see whether the current logical address is on the upper boundary of a cache block in main memory. Cache blocks contain eight 16-bit words; the least-significant three bits in a logical address determine a word's location in the block. This micro-order detects whether the least-significant three bits are all ones. The test is true if LA[29-31] = 7.

Address Translation Unit On

ATON

Polarity=0 Value=18

This test is true if the Address Translation Unit is on this cycle.

Address Translation Unit Purging

PRGB

Polarity=0 Value=19

This test is true if the Address Translation Unit is currently purging its translation cache.

Check for Valid Page Table Entry

VPTE

Polarity=1 Value=1A

This micro-order checks the two most-significant bits on the CPM Bus. If the last memory start was with RAND:ATU:ATU0:<RSBR or LPTA> these bits will be the "valid" and "resident" bits of a Page Table Entry. This test is true if CPM[0-1]=3.

Check for Valid Segment Base Register

VSBR

Polarity=1 Value=1B

This micro-order checks the "valid" and "length" bits of Segment Base Register (SBR). If the length bit is zero (1-level page table), then bits 4-12 of the current logical address should be zero. This test is true if:

SBR0=1 AND (SBR1=1 OR (SBR1=0 AND LAR[4-12]=0))

Check Valid Bit

VLD

Polarity=1 Value=1C

Depending the coding of RAND:ATU:ATU0, this micro-order examines the valid bit for a Segment Base Register or a Page Table Entry (PTE).

If RAND:ATU:ATU0:RSBR was coded last cycle, then this test is true if SBR0=1.

If RAND:ATU:ATU0:<OPTA or LPTA> is coded, then this test is true if CPD0=1. (Presumably, CPD0 is the valid bit for a PTE that was addressed by RSBR or LPTA in a previous microinstruction.)

Macroinstruction Decoded

IVLD

Polarity=0 Value=1D

IVLD is true if the Instruction Processor has a macroinstruction decoded. If an instruction is decoded, then IPOP can proceed.

I/O Allowed

IOEN

Polarity=0 Value=1E

This test is true if I/O is allowed in the current ring.

PC Relative Addressing

IXPC

Polarity=0 Value=1E

This test is true if the index bits of the macroinstruction indicate PC relative addressing (=01). This test is valid only during the first cycle of a macroinstruction.

Integer ALU Tests

The following tests apply to functions in the integer ALU.

Test Bit 28 on the Y Bus

Y28

Polarity=0 Value=28

This test is true if bit Y28 is one, and false if it is zero.

Test Bit 29 on the Y Bus

Y29

Polarity=0 Value=29

This test is true if bit Y29 is one, and false if it is zero.

Test Bit 30 on the Y Bus

Y30

Polarity=0 Value=2A

This test is true if bit Y30 is one, and false if it is zero.

Test Bit 31 on the Y Bus

Y31

Polarity=0 Value=2B

This test is true if bit Y31 is one, and false if it is zero.

Test Bit 31 on the D Bus

D31

Polarity=1 Value=2C

This test is true if bit D31 is one, and false if it is zero.

Test the Sign Bit on the D Bus

DSGN

Polarity=0 Value=2D

This test is true if the D Bus sign bit is 1. FLG3 determines which bit is the sign bit: if FLG3=0, D16 is the sign bit; if FLG3=1, D0 is the sign bit.

Compare the Source and Destination Addresses

COMP

Polarity=0 Value=2E

This test is true if the ACSR and ACDR point to the same register in the integer register file.

Test the Resumable Instruction Bit

IRES

Polarity=0 Value=2F

The Processor Status Register (PSR) bit 2 indicates whether a resumable instruction has been interrupted. All resumable instructions must test this bit when they begin execution. If it is set, they must restore state from the user stack.

Commercial Data Validity Test 1

COM1

Polarity=0 Value=30

The COM1 test validates commercial data. A PROM tests the least-significant byte on the A Bus of the integer ALU section, i.e., the data must be available at the A output port of the integer register file. The test to be performed is specified in the CNST field. Table 3-3 describes the tests. The inputs are those octal values that will cause COM1 = true.

Table 3-3. COM1 Tests

Mnemonic	Value	Description
VCB	0	Validate Character Byte Inputs: 040 101-132 141-172
VSB	1	Validate Sign Byte Inputs: 053 055
VSL	2	Validate Sign Low (Low nibble in byte) Inputs: 014 015 017
vcs	3	Validate Commercial Sign Byte Inputs: 015 055 175 112-122

Commercial Data Validity Test and Translation

COM₂

Polarity=0 Value=31

The COM2 test validates commercial data. A PROM tests the least-significant byte on the A Bus of the integer ALU section, i.e., data must be available at the A output port of the integer register file. The test to be performed is specified in the CNST field. Table 3-4 describes the tests. The inputs are those octal values that will cause COM2 = true. The outputs are the hexadecimal values that the inputs are translated into. The micro-order IY:EDT makes the outputs available on the IY Bus.

Table 3-4. COM2 Tests

Mnemonic	Value	Description
VSO	4	Validate Sign Overpunch and Translate Data Inputs: 040 053 055 060-071 101-111 112-122 173 175 Outputs: 0 0 0 0-9 1-9 1-9 0 0
VDB	5	Validate Digit Byte Inputs: 040 060-071 Outputs: 0 0-9
VDL	6	Validate Low Digit (Low nibble in byte) Inputs: 000-011 Outputs: 0-9
VDH	7	Validate High Digit (High nibble in byte) Inputs: 000-011 Outputs: 0-9

I/O Tests

TOI

Polarity=0 Value=32

The IOT micro-order is used for I/O skips and for decoding NOVA I/O instructions. The test is specified in the CNST field. The data to be tested must be on the A Bus of the integer ALU, i.e., it must be available at the A output port of the integer register file. Table 3-5 shows the CNST field micro-orders that specify the tests.

Table 3-5. IOT Tests

Mnemonic	Value	Description
CPUD	О	CPU Device Code: A[24-31] = xx11 1111
SKPT	1	Skip test: $A[28-31] = 000x$ or $011x$ or $10x0$ or $11x1$
IONF	2	ION Flag change: A[24-25] = 10 or 01

Test the Least-Significant ALU Bit

F31

Polarity = 0 Value = 33

This test is true if F31, the ALU output's least-significant bit, equals 1.

Carry from Least-Significant 4 Bits

CRY28

Polarity=0 Value=34

This test is true if the carry-out from bits 28-31 of the ALU equals 1.

Test the Sign on the R Bus

RSGN

Polarity=0 Value=35

The test is true if the R Bus sign bit equals 1. For FLAG3=1, the sign bit is R0; for FLAG3=0, the sign bit is R16.

Test the Most-Significant Bit on the Y Bus

Y0

Polarity=0 Value=37

This test is true if IY[0] equals 1. For narrow operations from the bit shifter, this test is always true.

Test 8-bit PDR Counter

CNT8

Polarity=1 Value=38

Test and increment the CPD Bus register (PDR) in the integer ALU. This test is true if PDR[24-31] is all ones. Note that, for this micro-order, PDR is considered an 8-bit counter. After testing, the counter is incremented by one. (This micro-order is functionally equivalent to incrementing the counter and testing for 0.)

Test 4-bit PDR Counter

CNT4

Polarity=1 Value=39

Test and increment the CPD Bus register (PDR) in the integer ALU. This test is true if PDR[28-31] is all ones. Note that, for this micro-order, PDR is considered a 4-bit counter. After testing, the counter is incremented by one. Note that CNT4 increments the entire eight-bit counter. (This micro-order is equivalent to incrementing the counter and testing PDR[28-31] for 0.)

Carry

CRY

Polarity=0 Value=3A

Test the carry-out from the ALU. For wide tests (FLAG3=1), this test is true if CRY0=1; for narrow tests (FLAG3=0), if CRY16=1.

Test the ALU Sign Bit

FSGN

Polarity=0 Value=3B

This test is true if the ALU output's sign bit equals one (i.e., if the value is negative). For wide tests (FLAG3=1), the sign bit is F0; for narrow tests (FLAG3=0), the sign bit is F16.

Overflow

OVF

Polarity=0 Value=3C

This test is true if there is overflow from an ALU operation. For wide tests (FLAG3=1), the overflow is from a 32-bit result; for narrow tests (FLAG3=0), from a 16-bit result.

Test for ALU Result Equal to Zero

FZR

Polarity=1 Value=3D

This test is true if the F Bus (the ALU output) equals zero. For wide tests (FLAG3=1), the test is for 32 bits (F[0-31]); for narrow tests (FLAG3=0), 16 bits (F[16-31]).

Signed Greater Than or Equal

SGE

Polarity=1 Value=3E

This test is true if the signed value on the S input is greater than or equal to the signed value on the R input. For this test to work correctly, on the previous cycle you must subtract (IOP:CSR) the quantities you wish to compare.

For wide tests (FLAG3=1), SGE tests all 32 bits; for narrow tests (FLAG3=0), SGE tests only the least-significant 16 bits.

CARRY Equal to One

CRRY

Polarity=1 Value=3F

Test for CARRY equal to one this cycle.

Floating-Point Tests

Floating-point tests in the TSEL field compare the magnitudes of two numbers or check for mantissa or exponent carry-out. A compare test is based on the compare status bits in the STATE register. These bits are set by the RAND:FLT:SCNT:CMP micro-order. The signed magnitude tests are based on the values in SA and SB. In order for the comparison tests to work, the CMP micro-order must be executed and, if necessary, RAND:FLT:SGN:LAB must be executed at least two cycles before the microinstruction containing the test.

A Equals B, Unsigned

UAEB

Polarity=0 Value=27

This test is true if the absolute values of the numbers on the FA and FB buses were equal when CMP was executed.

A Less Than B, Unsigned

UALB

Polarity=0 Value=26

This test is true if the absolute value of the number on the FA Bus was less than the absolute value of the number on the FB Bus when CMP was executed.

A Greater Than B, Unsigned

UAGB

Polarity=0 Value=25

This test is true if the absolute value of the number on the FA Bus was greater than the absolute value of the number on the FB Bus when CMP was executed.

A Equals B, Signed

SAEB

Polarity=1 Value=24

This test is true if the signed value of the number on the FA Bus was equal to the signed value of the number on the FB Bus.

A Less Than B, Signed

SALB

Polarity=0 Value=23

This test is true if the signed value of the number on the FA Bus was less than the signed value of the number on the FB Bus.

A Greater Than B, Signed

SAGB

Polarity=0 Value=22

This test is true if the signed value of the number on the FA Bus was greater than the signed value of the number on the FB Bus.

Mantissa Carry-out

FCRY

Polarity=0 Value=21

This test is true if there was a carry-out from the mantissa ALU.

Exponent Carry-out

ECRY

Polarity=0 Value=20

This test is true if there was a carry-out from the exponent ALU.

NAC:UCOP-Unconditional OPcode

The UCOP field controls unconditional actions by the microsequencer, i.e., actions that occur without regard to any test condition. Table 3-6 summarizes the micro-orders in the UCOP field.

Table 3-6. Unconditional OP Microorders

Mnemonic	Value	uPC	uStack	Description
LEAP	0	AA	_	14-bit jump
LSR	1	AA	PSH .+1	Leap and save return
DSPA	2	ADA	_	14-bit dispatch
DSPR	3	ADA	PSH .+1	Dispatch and save return
LPOP	4	AA	POP	Leap and pop TOS
PUSH	5	.+1	PSH AA	Push a 14-bit address
PCPD	6	AA	PSH CPD	Push stack state from CPD bus
TPSH	7	TOS	PSH AA	Go to TOS and push address

The NAC:ADDRESS field for UCOP micro-orders is 14 bits long, so that these micro-orders can address all of WCS.

Fourteen-bit Jump

LEAP

0

LEAP transfers control to NAC:ADDRESS.

Fourteen-bit Jump and Save

LSR

1

LSR pushes the uPC+1 onto the microstack and transfers control to NAC:ADDRESS.

Fourteen-bit Dispatch

DSPA

2

DSPA constructs an address using bits from the dispatch register or the ATU. The DSR field must be coded with DSPA to specify how the address is constructed.

Fourteen-bit Dispatch and Save Return

DSPR

3

DSPR constructs an address using bits from the dispatch register or the ATU. In addition, it pushes uPC+1 onto the stack for a future return. The DSR field must be coded with DSPA to specify how the address is constructed.

Jump and Pop the Microstack

LPOP

4

LPOP transfers control to NAC:ADDRESS and pops the microstack. Note that the current top of stack (TOS) value is lost.

Push a Fourteen-bit Address

PUSH

5

PUSH transfers control to the following instruction (uPC+1) and pushes NAC:ADDRESS onto the microstack.

Push State from CPD

PCPD

6

PCPD transfers control to NAC:ADDRESS and pushes the most significant bits from the CPD Bus (CPD[0-15]-) onto the microstack. This micro-order can be used to store state that can be recovered at some later time by popping the stack.

Go to TOS and Push a Fourteen-bit Address

TPSH

7

TPSH transfers control to the address at the top of the microstack and pushes NAC:ADDRESS onto the microstack.

NAC:DSR-Dispatch Address Source

The DSR portion of the NAC field controls the cross-bar network and the dispatch multiplexer. It is used by microinstructions that specify dispatch addressing, specifically, the NAC field micro-orders COP:CDSP, UCOP:DSPA, and UCOP:DSPR.

Table 3-7. Dispatch Address Source

Mnemonic	Value	Description
Α	0	ATU dispatch: AA[0-9],0,ATD[0-1],0
F	1	Four-bit dispatch: AA[0-9],DSP[4-7]
E	3	Eight-bit dispatch: AA[0-5],DSP[0-7]

The dispatch register is loaded from the CPD Bus. Using the dispatch register, the microprogram can branch on the basis of some external value (e.g., a value from a macroinstruction or from an I/O controller). The cross-bar network can also construct an address with two bits supplied by the Address Translation Unit.

ATU Dispatch

Α

0

The A micro-order constructs an address using the most significant ten bits from the AA Bus and two bits supplied by the ATU over the ATD Bus. The resulting address is:

$$AA[0-9], 0, ATD[0-1], 0$$

ATU addresses are used to direct page-table searches for the Long Address Translation (LAT) routine.

Four-bit Dispatch

F

1

The F micro-order constructs an address with the ten most significant bits from the AA Bus and the four least significant bits from the dispatch register. The resulting address is:

$$AA[0-9],DSP[4-7]$$

You can use the four-bit dispatch for such things as quick access to a table (with the AA address as the table base and DSP as an index).

Eight-bit Dispatch

E

3

The E micro-order is similar to F, except that it uses eight bits from the dispatch register and only six bits from the AA Bus. The resulting address is

$$AA[0-5],DSP[0-7]$$

The additional bits allow dispatching to a greater range of addresses (e.g., for larger tables).

Address Generator Micro-orders

The Address Generator portion of the microword contains the following fields:

- AA—specifies the A output of the register file.
- AB—specifies the B output of the register file and also the input register for the register file.
- AGB-specifies the sources for the AGB Bus.
- · AOP-specifies the operation for the AG ALU.
- AL-specifies the source for loading the register file.

AA and AB-The Register File Address Fields

The AA and AB fields designate the sources for the register file's A and B output ports. In addition, the AB field designates the input register. The following micro-orders can appear in both the AA and AB fields.

Macroinstruction Accumulator 0

AG0

0

This micro-order specifies the first register in the register file. At IPOP, this register must contain the same value as Accumulator 0 in the Integer ALU register file.

Macroinstruction Accumulator 1

AG1

1

This micro-order specifies the second register in the register file. At IPOP, this register must contain the same value as Accumulator 1 in the Integer ALU register file.

Macroinstruction Accumulator 2

AG2

2

This micro-order specifies the third register in the register file. At IPOP, this register must contain the same value as Accumulator 2 in the Integer ALU register file.

Macroinstruction Accumulator 3

AG3

3

This micro-order specifies the fourth register in the register file. At IPOP, this register must contain the same value as Accumulator 3 in the Integer ALU register file.

Wide Stack Pointer

SP

4

The wide stack pointer for the current ring (page-zero-location 12_{16}) is copied into this register. By convention, these copies are not always identical. The register contains the valid copy.

Constant 1

ONE

5

This register always contains a 1. The microprogrammer can use it to increment or decrement values.

Constant 2

TWO

6

This register always contains a 2. The microprogrammer can use it to increment or decrement a value by 2. For instance, the 2 can be used to increment the wide stack pointer for WPSH.

Reserved Register for Long Address Translation

LAT

7

This register is used by the LAT routine, and must not be used for general microprogramming.

General Register 0

AR0

8

The microprogrammer may use this register for general purposes. It has no assigned meaning.

General Register 1

AR1

9

The microprogrammer may use this register for general purposes. It has no assigned meaning.

General Register 2

AR2

A

The microprogrammer may use this register for general purposes. It has no assigned meaning.

General Register 3

AR3

В

The microprogrammer may use this register for general purposes. It has no assigned meaning.

General Register 4

AR4

 \mathbf{C}

The microprogrammer may use this register for general purposes. It has no assigned meaning.

General Register 5

AR5

D

The microprogrammer may use this register for general purposes. It has no assigned meaning.

Register Addressed by ACSR

SRC

 \mathbf{E}

This micro-order takes the address for the AG register file from the Accumulator Source (ACSR) address register of the integer ALU. Thus, for this micro-order, the AG register will correspond to the ACSR register. For example, if the ACSR register holds 1, it addresses macroaccumulator 1 and the macroaccumulator's copy in register 1 of the AG register file.

Register Addressed by ACDR

DES

F

This micro-order takes the address for the AG register file from the Accumulator Destination (ACDR) address register of the integer ALU. Thus, for this micro-order, the AG register will correspond to the ACDR register. For example, if the ACDR register holds 1, it addresses macroaccumulator 1 and the macroaccumulator's copy in register 1 of the AG register file.

AGB-The Address Generator Bus Field

The AGB field controls the sources to the B input of the AG ALU. The following micro-orders are used in this field:

Displacement Register

D

0

The Instruction Processor (IP) Displacement Register is chosen as the source for the AGB Bus. The IP controls the loading of this register from the DISP Bus. Microcode should use this register only to perform EFA calculations; its contents are indeterminant to a microprogram. The D micro-order must always be used in the AGB field at IPOP.

Register File B Port

В

1

The B output port of the AG register file sources the AGB Bus. The B port address comes from the AB field of the microinstruction.

Constant Register

 \mathbf{C}

2

The constant register sources the AGB Bus. This register is loaded from the CONSTANT field of the microinstruction. Note that if the CONSTANT field is being used for floating-point operations, the value in the constant register may be meaningless.

Last Logical Address Register

L

3

The last Logical Address (LA) register sources the AGB Bus. The last LA register is loaded only on memory starts, except during LAT or Cache Block Crossings (CBXs). CBXs are performed by incrementing the last LA register to access the second half of the double word.

AOP-Address Generator ALU Operation Field

The AOP field controls the actions of the AG ALU. The ALU is used for address calculations. The following micro-orders are available for this field:

B minus A
SUB
0
Subtra

Subtract the A input to the AG ALU from the B input. This operation has a carry-in of 1 (2's complement subtraction).

A plus B

ADD

1

Add the A input of the AG ALU to the B input. This operation has no carry-in.

Pass AGB Bus

PSB

2

Pass the B input (the AGB Bus) through the AG ALU unchanged. The A input is ignored.

Effective Address Calculation

EFA

3

Try to perform the next Effective Address (EFA) calculation. Note that this micro-order uses the index bits of the next macroinstruction to calculate the A-port address for the AG register file and to determine the AG ALU function. Therefore, the microprogrammer cannot use the AA field in an IPOP cycle. This micro-order must be coded during IPOP.

AL-Address Generator Register Loading

The AL field of the microinstruction determines which source is used when the AG register file is loaded. Note that the address for this file is always the B address, specified in the AB field. The following micro-orders can be coded in the AL field:

No Load

N

Do not load the AG register file on this microinstruction.

Load from CPM

M

Load the AG register file from the CPM Bus.

Load from AY

Y

Load the AG register file from the AY Bus.

Load on True

C

3

Load the AG register file from the CPM Bus if the test coded on this cycle is true.

Memory Control Micro-orders

The memory control portion of the microword contains the following fields:

- MEMS-starts a main memory reference.
- MEMC-completes a main memory reference.

MEMS—Memory Start

The following micro-orders start memory prior to a transfer of data to or from the CPU. The Address Generator forms the reference addresses during the same microinstruction as the memory start. The type of start determines how the logical address is formed:

	Start Type	Address Formation
	Word or double word	LA[0-31] = AGB[0],AY[1-31]
	Byte	LA[0-31] = AY[31],AY[0-30]
If FLAG1=0 (n	arrow addressing), then LA	L[1-3] = CRE[1-3] and $LA[4-16]$ are zeroed.
No Operation		
N		
0		
No operatio	n takes place.	
Read a Word		
RW		
1		
Start a men	nory cycle to read a word.	
Read a Double	Word	
RD		
2		
Start a mer	mory cycle to read a double	word.
Read a Byte		
RB		
3		
Start a mei	mory cycle to read a byte.	

Machine State Determined Start

S@

4

Start memory according to the information from the current macroinstruction (read/write, byte/word/double word, and indirection). In a LAT routine, start memory according to the last non-LAT memory start. S@ must be coded during IPOP.

Write a Word

 $\mathbf{W}\mathbf{W}$

5

Start a memory cycle to write or read/modify a word.

Write a Double Word

WD

6

Start a memory cycle to write or read/modify a double word.

Write a Byte

WB

7

Start a memory cycle to write or read/modify a byte. For byte writes, only the integer ALU buses IA and IY correctly align themselves for the cache. Other sources must be aligned by microcode: for even addresses, CPM[16-23]; for odd addresses CPM[24-31]. The cache looks at only the specified bits on the CPM Bus.

MEMC—Memory Complete

MEMC micro-orders complete memory transfers that were started by micro-orders in the MEMS field.

No Operation N 0 No operation takes place. Read or Read/Modify Complete R 1 Complete a read operation started on a previous cycle by a micro-order in the MEMS field. An R complete checks read protection. You perform a read/modify operation by coding a write start followed by a read complete. Memory will remain started until you code a write complete. Write Complete W 2 Complete a write operation started on a previous cycle by a micro-order in the MEMS field. If possible, avoid coding W in the same microinstruction with a read memory start, because memory will cause a delay in the microinstruction cycle. Never code W with a read start during IPOP. Execute Complete X 2 Complete a read-word memory start (MEMS:RW) to the Instruction Processor (IP). Execute protection will be checked if the start was accompanied RAND:ATU:ATU0:<IPST or ICAT> micro-orders. Abort Α

Abort a memory start. An abort always inhibits protection, except for indirection depth. Coding A enables the ATU diagnostic register. This is described in Chapter 2 under "ATU Diagnostic Register."

3

Bus Control Micro-orders

The Bus Control portion of the microword contains the following fields:

- CPMS—specifies the source for the CPM Bus.
- CPDS—specifies the source for the CPD Bus.

CPMS-CPM Bus Sources

The CPMS field controls the sources of the CPM Bus.

No Op N 0 The CPM Bus is not driven. Main Memory MM1 Main memory (the system cache) drives the CPM Bus. See the MEMS and MEMC micro-order fields. Address Generator AG 2 The AY Bus of the Address Generator drives the CPM Bus. ALU IY Bus IY 3

The IY Bus of the integer ALU drives the CPM Bus. The IY Bus carries data from the ALU, the hex shifter, and the edit RAMs.

CPMS-CPM Bus Sources

ALU A Bus

IA

4

The A Bus of the integer ALU drives the CPM Bus. The A Bus is the A output of the integer ALU register file.

Most-Significant Floating-Point Word

HF

5

The most-significant bits from the floating-point register file (FA[0-31]) source the CPM Bus.

Least-Significant Floating-Point Word

LF

6

The least-significant bits from the floating-point register file (FA[32-63]) source the CPM Bus.

CPDS—**CPD Bus Sources**

The CPD Bus is the major bus connecting the various boards of the MV/10000 CPU. Most data that is internal to the CPU travels over this bus, and the I/O controller is connected to this bus.

The PDR register is loaded whenever the CPD Bus is sourced (i.e., any micro-order other than N). The only exceptions to this are during a LAT routine and when RAND:ATU:ATU0:NPDR is coded.

Note: Sources designated as "slow" cannot be used for arithmetic or during IPOP. These sources start and stop driving the CPD Bus later than normal sources. A normal source should not be coded in a cycle immediately following a slow source. If this were done, the normal source signals would be garbled by the signals from the slow source.

No Op

N

0

No source drives the CPD Bus. The bus contains zeros and the PDR register is not loaded.

ALU IY Bus

IY

1

The IY Bus of the integer ALU drives the CPD Bus.

Transfer Register

TRG

2

The transfer register (TREG) in the integer ALU sources the CPD Bus. TREG is loaded from the CPM Bus. TREG drives the CPD Bus fast enough so that it can source the integer ALU. The result from the ALU can be driven to the Address Generator on the CPM Bus during the same microinstruction cycle.

Microsequencer State

USS

3

USS causes the microsequencer to drive its state onto the CPD Bus. This state consists of the current top of the stack (16 bits), the flags (8 bits), and the dispatch register (8 bits), as follows:

- TOS[0-15] goes to CPD[0-15]-
- FLG[0-7] goes to CPD[16-23]-
- DSP[0-7] goes to CPD[24-31]-

The top of stack data and the flags are read from CPD with their true values and written back to the bus in inverted form. The dispatch register bits are read inverted and written true. For state save and restore, data should be inverted before writing it to memory.

Next Sequential PC

PCN

4

The value on the CPD Bus is the currently executing PC plus the length of the currently executing macroinstruction. This micro-order only makes setup to the PDR register.

Executing PC

PCX

5

The value on the CPD Bus is the currently executing PC. This micro-order only makes setup to the PDR register.

Next PC

PC .

6

The value on the CPD Bus is the next PC. This value will be identical to PCN if there is no IPST; otherwise, the value will be the IPST value (see RAND:ATU:ATU0:IPST). This micro-order only makes setup to the PDR register.

Instruction Processor State

IPS

7

The Instruction Processor (IP) state sources the CPD Bus, as follows.

CPD Bits	IP State Bits	Description
28	XCTFLG	Bit indicating that the current macroinstruction was the result of an XCT instruction
29	ION	Master interrupt mask bit
30-31	^LPCX[0-1]	Length of currently executing instruction

This is a slow source.

I/O Controller Data Register

IOC

8

The data register from the I/O controller sources the CPD Bus. This micro-order transfers data from peripherals and the I/O controller directly to the CPU. This is a slow source. See the I/O Protocols section of Chapter 2.

ATU Diagnostic Register

ATD

9

The ATU diagnostic register sources the CPD Bus. See the ATU Diagnostic Register section of Chapter 2. This is a slow source.

Logical Address Register

LAR

Α

The Logical Address Register (LAR) sources the CPD Bus. LAR drives the bus fast enough so that it can source the integer ALU. The result from the ALU can drive the CPM Bus to the Address Generator during the same microinstruction cycle.

ATU State

ATS

В

The value on the CPD Bus is the Address Translation Unit (ATU) State. See the ATU state section of Chapter 2 and RAND:ATU:ATU0:LATS. This is a slow source.

SCP Instruction Register

CIR

 \mathbf{C}

The System Control Processor's instruction register sources the CPD Bus. This is a slow source.

CPDS-CPD Bus Sources

SCP Data Register

CDR

D

The System Control Processor's data register sources the CPD Bus. This is a slow source.

Address Generator

AGA

E

The Address Generator's register-file A-port sources the CPD Bus. This micro-order cannot be used during IPOP.

Zero

ZER

F

Zeros are driven onto the CPD Bus. Unlike N, this micro-order loads PDR.

RAND-Random Micro-orders

The RAND field contains general micro-orders, as well as additional micro-orders for the IALU, the FPU, and the ATU. Micro-orders in the RAND field occur in four possible modes. The mode is specified by the first subfield (RM) in the RAND field. Table 3-8 shows the micro-orders in the RM field:

Table 3-8. RM Field Micro-orders

Mnemonic	Value	RAND Mode
GN	0	General (GEN)
AT	1	Address Translation Unit (ATU)
XC	2 CIB=0	Fixed-point (FIX), Carry-In Base is CARRY
XZ	2 CIB=1	Fixed-point (FIX), Carry-In Base is zero
FL	3	Floating point (FLT)

Note that FIX mode is invoked by either the XC or XZ micro-orders. These micro-orders also set the CIB field.

Each RAND mode has a corresponding set of subfields. The formats for each mode are shown in Figure 3-3.




Figure 3-3. RAND Mode Formats

RAND:GEN - General Random Micro-orders

The RAND:GEN portion of the microword contains the following fields:

- * *REG0*—specifies general and ACS and ACD operations.
- * *REG1*—specifies register control operations.
- * SPAD—specifies scratch pad operations.

RAND:GEN:REG0—General/ACSR/ACDR Micro-orders

The RAND:GEN:REG0 field has micro-orders for general operations and for control of the ACSR and ACDR registers. The ACSR and ACDR micro-orders must be coded at least one cycle before the registers are used for addressing.

No Operation

N

0

No operation is performed.

```
Write Console Data
CDW
1
   This micro-order gates the least-significant sixteen bits of the CPD Bus to the System
Control Processor: CPD[16-31] goes to CDR[0-15].
Increment ACSR
INCS
   INCS increments ACSR[2-3] by one. Note that ACSR[0-1] are unchanged.
Decrement ACSR
DECS
5
   DECS decrements ACSR[2-3] by 1. Note that ACSR[0-1] are unchanged.
Load ACSR
LDAS
6
   The Accumulator Source Register is loaded from the ID Bus (ID[28-31]).
Force ACSR
FRCS
7
   The Accumulator Source Register is set to 'E' (hexadecimal).
```

```
Increment ACDR
INCD
8
   INCD increments ACDR[2-3] by one. Note that ACDR[0-1] are unchanged.
Decrement ACDR
DECD
9
    DECD decrements ACDR[2-3] by one. Note that ACDR[0-1] are unchanged.
Load ACDR
LDAD
Α
   The Accumulator Destination Register is loaded from ID[24-27].
Force ACDR
FRCD
В
    The Accumulator Destination Register is set to 'F' (hexadecimal).
Force CARRY Bit
FCY
\mathbf{C}
   This micro-order forces the CARRY bit onto the CPM Bus when the A output of the
integer register file sources that bus. CARRY goes to CPM0 if FLAG1=1; to CPM16 if
FLAG1=0.
```

Enable Wide Skips

WSKP

D

This micro-order enables wide (32-bit) skips. The skip itself is dependent on test conditions coded in the CNST field. The tests are coded in the same way as those in the TSEL field. Note that they can be wide or narrow, depending on FLAG3. WSKP and the test conditions can be coded only at IPOP and cannot be coded with a memory complete. The table below lists the test conditions.

Mnemonic	Value	Description
CRY	0	Test the carry-out from the integer ALU (CRY0 or CR16 for FLAG3 = 1 or 0). The test is true if CRY# = 1.
NCRY	1	Test the carry-out from the integer ALU (CRY0 or CR16 for FLAG3 = 1 or 0). The test is true if CRY# = 0.
SGE	2	Compare the signed S input to the signed R input (bits 0-31 or 16-31 for FLAG3 = 1 or 0). The test is true for S >= R. For this test to work you must perform a subtract on the previous cycle.
NSGE	3	Compare the signed S input to the signed R input (bits 0-31 or 16-31 for FLAG3 = 1 or 0). The test is true for S < R. For this test to work you must perform a subtract on the previous cycle.
FZR	4	The test is true if the integer ALU output (F) equals zero (F[0-31] or F[16-31] for FLAG3 = 1 or 0).
NFZR	5	The test is true if the integer ALU output (F) does not equal zero (F[0-31] or F[16-31] for FLAG3 = 1 or 0).

Load ACSR and ACDR

LDSD

E

ACDR[0-3] are loaded from ID[24-27] and ACDS[0-3] are loaded from ID[28-31].

Force ACSR and ACDR

FRSD

F

The ACSR is set to 'E' (hexadecimal) and the ACDR is set to 'F' (hexadecimal).

Modify Flag Set 0

MFS0

10

MFS0 can modify flags 0, 1, 2, and 3, according to the coding in the CNST field.

Modify Flag Set 1

MFS1

11

MFS1 can modify flags 4, 5, 6, and 7, according to the coding in the CNST field.

CNST Field with MFS0 and MFS1


For the REG0 micro-orders MFS0 and MFS1, two bits in the CNST field specify what is to be done to each flag. Table 3-9 shows how these two bits are coded.

Table 3-9. CNST Microorders for RAND MFS0 and MFS1

Mnemonic	Value	Description
N	0	No operation to flag
S	1	Set flag to 1
С	2	Clear flag to 0
Т	3	Toggle flag

For these micro-orders, the microassembler codes four micro-orders in the CNST field, rather than one. For example, to set flags 0-3 to 1,0,1,0, you would code:

The assembler would code the micro-order MFS0 in RAND:GEN:REG0, and the micro-orders S,C,S,C in the CNST field:



MFLG0, MFLG1, MFLG2 and MFLG3 are two-bit subfields of CNST that correspond to the flags of the specified set.

Accumulate Test Results into Flags 4 and 6

AF46

12

AF46 puts test results into Flag 4 and Flag 6. Before the results are stored, they can be manipulated by codes in the CNST field.

Accumulate Test Results into Flags 5 and 7

AF57

13

AF57 puts test results into Flag 5 and Flag 7. Before the results are stored, they can be manipulated by codes in the CNST field.

CNST Field with Micro-orders AF46 and AF57


For the REG0 micro-orders AF46 and AF57, two 3-bit sections of the CNST field are used, one for each flag to be manipulated. Table 1 shows how these bits are coded.

Table 3-10. CNST Microorders for RAND AF46 and AF57

Mnemonic	Value	Description
N	0	No operation to flag
X	1	XOR test to flag
S	2	Set flag to 1
Α	3	AND test to flag
С	4	Clear flag to 0
0	5	OR test to flag
T	6	Toggle flag
L	7	Load test into flag

For these micro-orders the microassembler codes two micro-orders in the CNST field, rather than one. For example, to load a test result into flag 4 and invert flag 6 if the test result is 1, you would code:

The assembler would code the micro-order L in the AFLG0 subfield of CNST and X in the AFLG1 subfield.



Load Flags From CPD

LFLG

14

LFLG loads the flags from CPD[16-23] (inverted). This micro-order does not load PDR.

Skip on False Test

SKFT

15

Skip over the next word in the instruction stream if the test selected this cycle is false. The microroutine must IPOP the next cycle in order for the skip to operate properly.

Even Parity

EPAR

16

Select even parity for WCS next cycle.

Load SPAR from Constant Register

SPCN

17

Designate CON[0-7], which contains the value in the CNST field of the micro-order, for loading SPAR.

Load Least Significant SPAR bits from IY Bus

SPY4

18

Designate the IY Bus for loading SPAR. SPAR[4-7] come from IY[28-31]; SPAR[0-3] remain unchanged.

SPCN and SPY4-SPAD Micro-orders

The scratch pad address register (SPAR) is one possible address source for the scratch pad. By default, SPAR is loaded from IY[24-31]; however, the SPCN and SPY4 micro-orders override this source. Note that these orders only select the input to SPAR; the micro-order RAND:<GEN,ATU,FIX>:SPAD:LS must be coded at the same time in order to load SPAR. These orders must not be coded at IPOP. For WSKBO and WSKBZ, the hardware generates an address that indexes the proper bit mask in the scratch pad (see Appendix H).

No Load PDR

NPDR

1E

Normally, the PDR is loaded whenever the CPD Bus is active. This micro-order prevents that loading.

Extended Clock
XTND
1F
This micro-order extends the microinstruction cycle for an additional cycle.
RAND:GEN:REG1—Register Load Operations
No Op
N
0
No operation takes place.
Append CRE
AC
1
Append the Current Ring of Execution (CRE) bits to the logical address. CRE[1-3] goes to LA[1-3].
Load the Dispatch Register
LD
2
LD loads the dispatch register from CPD[24-31]. The register must be loaded at least one microcycle before it is used.
Load Transfer Register
LT
3
Load the transfer register (TREG) from the CPM Bus: CPM[0-31] go to TREG[0-31].

RAND:GEN:SPAD-Scratch Pad Input Control

3

The SPAD field RAND micro-orders control the scratch pad, and the micro-orders in the field have the same meaning for the GEN, ATU, and FIX modes. The scratch pad is read when it is enabled onto the ID Bus by the micro-orders ID:SS and ID:SC. The scratch pad is loaded from the IY Bus or the CPM Bus, as selected by the IL field. It cannot be read and written on the same cycle.

No Operation N 0 The scratch pad is not written to in this cycle; however, it may be read. SPAR Addresses SPAD WS 1 Load data into the scratch pad from the IY or CPM Bus, as selected by the IL field. The scratch pad address register (SPAR) addresses the scratch pad. CON Addresses SPAD WC 2 Load data into the scratch pad from the IY or CPM Bus, as selected by the IL field. The CON register (which contains the value in the CNST field) addresses the scratch pad. Load SPAR LS

Load data into the scratch pad address register (SPAR). The default input for SPAR is IY[24-31]. Other inputs are possible using micro-orders in the RAND:GEN:REG0 field.

RAND:ATU - ATU Random Micro-orders

Micro-orders in the RAND:ATU field are the principal micro-orders for the Address Translation Unit. The RAND:ATU portion of the microword contains the following fields:

- ATU0—specifies ATU operations.
- ATU1—specifies ATU operations.
- SPAD—specifies scratch pad operations.

RAND:ATU:ATU0-ATU Operations

No Op

N

0

No operation takes place.

Load the CRE and ESR Registers

LCRE

4

The Current Ring of Execution (CRE) register and the Effective Source Register (ESR) are loaded from the logical address bus: LA[1-3] goes to CRE[1-3] and ESR[1-3].

Start Memory in Mode 0

CM0

5

This micro-order is used for certain types of main memory references: cache-block-crossing reads, cache flushes, and XCT instructions. All of these references deal directly with the system cache and its functioning.

Cache Block Crossing

The MV/10000 main memory system is organized into blocks of four 32-bit double words. When a double-word (32-bit) read crosses a block boundary in the cache, there must be two separate memory reads—one for each 16-bit word in the reference. To code this memory start, use RAND:ATU:ATU0:CM0 along with MEMS:RW. The cache will assemble the two words into a double word and source it to the CPM Bus when the memory complete is coded. Note that no special memory start is necessary for cache-block-crossing writes.

Cache Flush

Normally, the system cache sends data back to main memory only when it is necessary to overwrite a block in the cache. However, it is possible to force the cache to write a block back to main memory arbitrarily. This ability is used for main memory diagnosis: you can move data out of a single main memory block, store it temporarily, and move it back to main memory without accessing any other blocks.

To move data this way, you must code a MEMS:RD micro-order along with CM0, and provide a block address, i.e., one that ends in three zeros. The addressed block will be read out from the cache and subsequently written back to main memory. In the fourth cycle following the memory start, you must code a MEMC:R micro-order; no other MEMC micro-orders are allowed.

XCT

In order to implement the XCT instruction, the opcode to be executed is sent to the Instruction Processor (IP) via the system cache. The following sequence of operations is used for XCT:

- 1) Code MEMS:WW and ATU:ATU0:CM0 in the same microinstruction.
- 2) Source the opcode onto the CPM Bus (from an accumulator in the integer ALU) and at the same time code a memory abort (MEMC:A).
- 3) Wait four cycles and IPOP.

Restore ATU State

LATS

6

This micro-order restores the state for the Address Translation Unit. The Effective Source Ring (ESR) register and the last memory start register (^CPWRITE@, ^CPMODE@[0-2]) are restored from the Logical Address Bus (LA[1-3] and LA[20-23]). Table 3-11 shows the ATU state that is restored.

Table 3-11. ATU Restored State

Bits	Name	Description
1-3	ESR[1-3]	The Effective Source Ring
20	^CPWRITE@	Indicates that the last non-LAT start was a write.
21-23	^CPMODE@[0-2]	The mode bits for the last non-LAT start.

The following table shows the possible values for the CPMODE state field:

Table 3-12. CP Mode Code

Code	Meaning	
0	Word reference (16 bits)	
1	Low byte reference	
2	Double word reference (32 bits)	
3	High byte reference	
4	Assemble	
5	Send execute data	
6	Flush cache block	
7	No operation	

Write SBR

WSBR

7

This micro-order writes the SBR addressed by bits 1-3 of the LA Bus from the CPD Bus (inverted).

Address Page Table Entry with SBR

RSBR

8

This micro-order gates the address of a page table entry (PTE) onto the CPU Physical Address (CPA) Bus. The PTE address is formed from the address portion of the Segment Base Register (SBR) addressed by LAR[1-3] and either LAR[4-12],0 or LAR[13-21],0; the least significant bit of the PTE address is always zero because PTEs are aligned on 32-bit boundaries.

The number of page-table levels determines the specific bits from the LA Bus. Hardware makes this determination from bit 1 of the SBR and automatically inserts the correct bits into the PTE address.

For a one-level page table, the memory reference with this micro-order returns the physical page address corresponding to the current logical page address. The OPTA micro-order can combine the physical page address with the word-in-page offset (LA[22-31]) to produce a correct memory reference.

For a two-level page table reference, the memory returns the address of the second page table, and you must use the LPTA micro-order to get the physical page address.

Low-Order Page Table Addresses Memory

LPTA

9

This micro-order is used to address the second page table after the address from the first page table has been returned. The physical page address of the first page table is returned on CPD, and is combined with bits 13-21 of the Logical Address Register (LAR). The combination of CPD[18-31],LAR[13-21],0, is sourced to the CPA Bus for a memory reference. The memory returns the physical page address that corresponds to the logical page address. The OPTA micro-order combines this page address with the word-in-page offset (LA[22-31]) to form a physical address.

Load the Logical Address Register and Physical Page Address Register

LLAR

Α

This micro-order loads the Logical Address Register (LAR) from the logical address Bus and PPAR[8-21] from CPA[8-21]

Load the Modified/Referenced RAM

WRRM

В

This micro-order sends data from CPD[26-27] to the modified and referenced bits addressed by the CPA Bus. CPD26 goes to the mod bit and CPD27 to the reference bit. The bits are addressed by the page address that the ATU gates onto the CPA Bus (CPA[8-21]). This address can be generated by either the address translation cache or the page table entry logic.

Read And Reset Reference Bits

RSRF

D

This RSRF micro-order will read and reset to zero the reference bits for eight pages simultaneously. The following prodedure must be followed to use this micro-order correctly:

1) Place the address for the first page in the eight-page block into the Physical Page Address Register (PPAR). This address must end in three zeros. The address is usually loaded by turning off the ATU, sourcing the physical address onto the LA Bus, and coding the ATU random LLAR.

- 2) Code RSRF. This sources the reference bits to the CPD Bus. Note that the bits will be ORed with any other data on the CPD Bus. The only possible destination for the reference bits is the PDR register in the integer ALU; there is not enough set-up time for any other registers on the CPD Bus.
- 3) Get the reference bits from the PDR[24-31]. Bit 24 is the reference bit for the page whose address ends in three zeros. The ATU is now on. ATU0:AOFF must be coded if the ATU should not be on.

Purge the Address Translation Cache

PRGA

E

This micro-order resets all the bits in the validity RAM for the address translation cache. In effect, it returns the cache to an empty state.

Page Table Addresses Memory

OPTA

F

This micro-order takes a page address from a Page Table Entry (PTE) and uses it to address a memory location. The page address itself comes from memory as a result of an RSBR or LPTA micro-order. The full address for memory is assembled from the PTE page address and the logical address's page offset. The page address is sourced to the ATU on the CPD Bus; the logical address is available on the LA Bus. The bits are sourced to the CPA Bus as follows:

$$CPA[8-31] = CPD[18-31], LABUF[22-31]$$

If the test condition in this microinstruction is true, then the ATU cache is also loaded. The cache will contain the physical address on CPA in the location pointed to by the logical address on the LA Bus. Thus, the next time this particular logical address is presented to the ATU, it will hit in the cache and avoid LAT.

Load Instruction Processor State

LIPS

10

This micro-order loads the Instruction Processor (IP) state and has the same effect as IPST on the ATU. The IP state consists of the following registers:

- The Program Counter (PC);
- The Next Program Counter (PCN);

- The LPCX[0-1] register, which contains the length of the currently executing instruction; and
- The XCTFLG, which indicates whether the current macroinstruction resulted from an XCT instruction.

In order to restore state to the IP:

1) Source the value for PCN to the Address Generator's AY Bus and code RAND:ATU:AT0:IPST.

Note: No memory start should be coded while restoring IP state.

2) Source the value for the PC to the Address Generator's AY Bus and source XCTFLG on CPD28 and ^LPCX on CPD[30-31]. Code RAND:ATU:AT0:LIPS. (ION is not restored by this operation—see ION and IOFF.) If no memory start is coded, the random IPFL should be used to ensure that the IP is flushed and a good translation is provided.

Disable Interrupts

DISI

12

This micro-order disables interrupts for one macroinstruction.

Note: Do not code IPOP with this instruction.

Turn ION On

ION

13

This micro-order turns on the ION bit (part of the Instruction Processor state). This enables interrupts. This micro-order disables interrupts for one instruction cycle if ION changes state. NOTE: Do not code IPOP with this instruction.

Turn ION Off

IOFF

14

This micro-order turns off the ION bit (part of the Instruction Processor state). This action disables interrupts.

Note: Do not code IPOP with this instruction.

Instruction Cache Translation

ICAT

16

This micro-order loads the physical page register of the Instruction Processor (IP) with a physical address generated by the ATU. The IP uses the ATU to translate addresses, which the IP then uses to fetch instructions. Specifically, the following takes place:

$$PHY[8-21] = CPA[8-21]$$

Instruction Processor Start

IPST

17

This micro-order loads the Instruction Processor Program Counter (IPPC) and flushes the IP pipeline. The IPPC is loaded with the Current Ring of Execution (CRE) and the value on the AY Bus of the Address Generator. CRE also sources the Logical Address (LA) Bus:

IPPC =
$$CRE[1-3]$$
, $AY[4-31]$
 $LA[1-3]$ = $CRE[1-3]$

At the same time, the physical page register is loaded with a physical address created by the ATU, as follows:

$$PHY[8-21] = CPA[8-21]$$

Send I/O Command or Data

SIO

18

This micro-order enables a command or data to the I/O controller. The command or data must be on the CPD Bus, and must follow the I/O protocols discussed in Chapter 2.

Force Byte Addressing

BYTE

1**A**

This micro-order forces byte addressing of main memory, regardless of what kind of memory start was initiated. Note: the LA register is not valid after this random.

Force Word Addressing

WORD

1B

This micro-order forces word addressing of main memory, regardless of what kind of memory start was initiated.

Turn On Address Translation Unit

AON

1C

This micro-order turns on the Address Translation Unit, so that logical addresses are converted into physical addresses before they go to main memory.

Turn Off Address Translation Unit

AOFF

1D

This micro-order turns off the Address Translation Unit. Effectively, all addresses are treated as physical addresses; there is no logical to physical translation.

Don't Load the PDR Register

NPDR

1E

This micro-order inhibits loading of the PDR register. Normally, the PDR is loaded every time the CPD Bus is used. NPDR allows the contents of PDR to remain unchanged regardless of CPD use.

Extend the CP Clock

XTND

1F

This micro-oorder extends the CP clock, which is normally 140 nanoseconds, by two SYS clock cycles to 270 nanoseconds. This micro-order also determines which of two sets of information is captured by the ATU diagnostic register. (See the MEMC:A micro-order, earlier in this chapter.)

RAND:ATU:ATU1-Additional ATU Operations

No Op

N

0

No operation takes place.

Append CRE

AC

1

This micro-order appends the current CRE to the most significant bits of the current logical address as follows:

$$LA[1-3] = CRE[1-3]$$

Increment DEFER Counter

DF

2

This micro-order increments the DEFER counter and, if the test this cycle is false, replaces the current ESR with bits 1-3 of the new logical address. In effect, this micro-order descends one more level in an indirection chain. If the defer counter goes beyond 15, it causes a trap.

When DF is coded, an inward reference is determined by comparing the started address's ring field to the ESR (not the CRE).

Load TREG

LT

3

This micro-order loads the transfer register (TREG) between the CPM and CPD buses from the CPM Bus. Later, TREG can source the CPD Bus.

RAND:ATU:SPAD-Scratch Pad Input Control

The SPAD field RAND micro-orders control the scratch pad, and the micro-orders in the field have the same meaning for the GEN, ATU, and FIX modes. The scratch pad is read when it is enabled onto the ID Bus by the micro-orders ID:SS and ID:SC. The scratch pad is loaded from the IY Bus or the CPM Bus, as selected by the IL field. It cannot be read and written on the same cycle.

No Operation

N

0

The scratch pad is not written to on this cycle; however, it may be read.

SPAR Addresses SPAD

WS

1

Load data into the scratch pad from the IY or CPM Bus, as selected by the IL field. The scratch pad address register (SPAR) addresses the scratch pad.

CON Addresses SPAD

WC

2

Load data into the scratch pad from the IY or CPM Bus, as selected by the IL field. The CON register (which contains the value in the CNST field) addresses the scratch pad.

Load SPAR

LS

3

This micro-order loads data into the scratch pad address register (SPAR). The default input for SPAR is IY[24-31]. Other inputs are possible using micro-orders in the RAND:GEN:REG0 field.

RAND:FIX-Fixed-point Random Micro-orders

The RAND:FIX portion of the microword contains the following fields:

- CIB—specifies the carry-in base. This field is set by the same micro-order that sets the RAND:FIX mode (XC or XZ). See the explanation at the beginning of the RAND section of this chapter and under "Carry-In Logic" in Chapter 2.
- · COVS—controls the CARRY bit as well as OVR and OVK bits.
- · LOAD-controls the loading of register and narrow or wide conditions in the IALU.
- SPAD—specifies scratch pad operations.

RAND:FIX:COVS - Carry, Overflow and Status

COVS field micro-orders load and set the Processor Status Register (PSR) and manipulate the CARRY register.

No Operation

N

0

No operation is performed.

Clear OVR

COVR

1

This micro-order resets PSR1 (OVR) to 0. (Once set, PSR1 remains 1 until COVR resets it.)

Clear OVK **COVK** 2 This micro-order resets PSR0 (OVK) to 0. Set OVK **SOVK** 3 Set PSR0 (OVK) to 1. Load the PSR LPSR 4 Load the Processor Status Register from the ID Bus: ID[0-3] goes to PSR[0-3]. Load Overflow and Carry LOVC 5 Set PSR1 (OVR) and CARRY from the results of the current ALU operation. For narrow operations (FLG3=0), OVR=OVR16 and CARRY=CRY16. For wide operations (FLG3=1), OVR=OVR0 and CARRY=CRY0. LOVC will cause an overflow trap if OVR=1 and OVK=1. An overflow trap will reset OVK to zero. Load CARRY **LCRY**

Load the CARRY register from carry-out of the integer ALU. For narrow operations

(FLG3=0), CARRY=CRY16; for wide operations (FLG3=1), CARRY=CRY0.

6

Clear CARRY **CLRC** 7 Reset the CARRY register to 0. Load CARRY from R Bus **LDCY** 8 Load the CARRY register from the R Bus. For narrow operations, CARRY=R16; for wide operations, CARRY = R0. Enable ALC Functions **ALC** 9 This micro-order enables the ALC skip and no-load logic and determines the ALC carry from bits 10 and 11 of the macroinstruction. The effect of this micro-order on the CARRY register depends on micro-orders in the IY field. For IY:BR1 and IY:BL1, ALC uses ALC carry as the shift input, and loads CARRY with the shift out. For other micro-orders in the IY field, CARRY is loaded with ALC carry.

Set the CARRY Register

SETC

Α

Set the CARRY register to 1.

RAND:FIX:LOAD-Load Registers

The LOAD field inhibits loading of the register file, forces narrow operations in the ALU, and loads the transfer register.

No Op

No operation takes place.

Absolute Value

AV

Prevent the loading of negative values into the register file. If the FSGN test is true, then the value is not loaded into the register file.

Force Narrow Operations

NA

2

The IALU will operate on 16-bit values only, i.e., FLAG3=0.

Load Transfer Register

LT

3

Load the transfer register (TREG) from the CPM Bus: CPM[0-31] go to TREG[0-31].

RAND:FIX:SPAD-Scratch Pad Input Control

The SPAD field RAND micro-orders control the scratch pad, and the micro-orders in the field have the same meaning for the GEN, ATU, and FIX modes. The scratch pad is read when it is enabled onto the ID Bus by the micro-orders ID:SS and ID:SC. The scratch pad is loaded from the IY Bus or the CPM Bus, as selected by the IL field. It cannot be read and written on the same cycle.

No Operation

N

0

The scratch pad is not written to on this cycle; however, it may be read.

SPAR Addresses SPAD

WS

1

Load data into the scratch pad from the IY or CPM Bus, as selected by the IL field. The scratch pad address register (SPAR) addresses the scratch pad.

CON Addresses SPAD

WC

2

Load data into the scratch pad from the IY or CPM Bus, as selected by the IL field. The CON register (which contains the value in the CNST field) addresses the scratch pad.

Load SPAR

LS

3

Load data into the scratch pad address register (SPAR). The default input for SPAR is IY[24-31]. Other inputs are possible using micro-orders in the RAND:GEN:REG0 field.

RAND:FLT-Floating-Point Random Micro-orders

The RAND:FLT portion of the microword contains the following fields:

- SGN—controls the floating-point sign logic.
- EXP—controls the floating-point exponent logic.
- · SCNT-specifies operations that control the hex-shifter shift count.

RAND:FLT:SGN -Floating-Point Sign

The floating-point sign is the value sourced to FD0.

No-op

SA

0

The sign is taken directly from the SA register. No operations are performed on it.

Sign Equal FA0

MOV

1

The sign is equal to FA0 (bit zero of the FA Bus).

Sign Equal FA0-

NEG

2

The sign is equal to the inverse of FA0.

Truncate and Invert

TRI

3

Truncate the bottom guard digit of the FS Bus if the Floating-Point Status Register round bit (FPSR8) is equal to zero. The bottom guard digit is FS[68-71] if FLAG2=1 or FS[23-39] if FLAG2=0. Load the SA register from FA0 and the SB register from FB0. The value loaded into SA is inverted if the SWAP bit in the floating-point state register is set. The FPSR must be set at least two cycles before this micro-order is executed.

This random is used during signed mantissa subtraction to determine the correct sign of the result.

Sign Equals 0

ZER

4

The new sign will be 0 (positive number).

Sign Equals SA EXOR SB

XOR

5

The sign equals SA XOR SB. This means that if the signs are the same, the sign will be positive (0), and if they are different, the sign will be negative (1). Thus this micro-order produces the correct sign for the multiplication or division of floating-point numbers.

Load SA and SB

LAB

6

The SA register is set to FA0 and the SB register to FB0. The previous value of SA becomes the new sign.

Truncate

TRN

7

Truncate the bottom guard digit of the FS Bus if the Floating-Point Status Register round bit (FPSR8) is equal to zero. The bottom guard digit is FS[68-71] if FLAG2=1 or FS[23-39] if FLAG2=0. Load the SA register from FA0 and the SB register from FB0. The FPSR must be set at least two cycles before this micro-order is executed. This random is used during signed mantissa addition to determine the correct sign of the result.

RAND:FLT:EXP—Floating-Point Exponent

The EXP field controls the exponent logic for floating-point numbers. The exponent is the value that is sourced to FD[1-7].

The micro-orders ACW, ACA, and ACN use the mantissa overflow (MOF). This is not the same as the MOF bit in the FPSR, which is a flag for macroinstructions. Mantissa overflow can be corrected by shifting the mantissa right by one hex digit between the mantissa ALU and the FD Bus; this shifts the overflow digit back into the mantissa proper, so that the most significant digit of the mantissa is 0001. The exponent is adjusted for this shift by adding in the MOF.

No-op

N

0

The exponent is the unaltered value in the Exponent Working Register (EWR).

Subtract 64

S64

0

The exponent is the value in the EWR, minus 64. In order for this micro-order to work you must code it in conjunction with FX:X64. The MV/10000 processor uses excess-64 notation internally. This micro-order is used to correct exponent addition:

$$(A+64) + (B+64) - 64 = (A+B) + 64$$

where A and B are the true exponent values.

Load FA

LAX

1

The exponent is the value from the FA Bus that is sourced to the Exponent ALU. This value is equal to 0,0,FA[1-7].

Subtract Normalize

SNM

2

The exponent is set to the value of the EWR minus MAG[0-3].

Subtract

SUB

3

The exponent is the value from the FA Bus minus the value from the FB Bus. This micro-order is normally used for a floating-point divide operation.

Correct EWR

ACW

4

Add the MOF to the exponent.

Add 64

A64

4

The exponent is the value in the EWR plus 64. In order for this micro-order to work, you must code it in conjunction with FX:X64. This micro-order is used to correct exponent subtraction:

$$(A+64) - (B+64) + 64 = (A-B) + 64$$

where A and B are the true exponent values.

Correct FA

ACA

5

Add the MOF to the FA source.

Correct and Normalize

ACN

6

The exponent is the exponent working register, plus MAG, plus the MOF. This micro-order normalizes floating-point numbers after an arithmetic operation. MAG is set to minus the number of leading hexadecimal zeros in the mantissa by using the SCNT:LZD random, and the exponent is added to the value in MAG. At the same time, the mantissa should be left-shifted in four-bit shifts to remove the zeros. The result is a number with the smallest possible exponent and no leading zeros in the mantissa (if the result is not zero). NOTE: MAG will be a negative value, which will produce the proper left shift in the hex shifter.

Add

ADD

7

Add the FA and FB sources. This micro-order is used for a floating-point multiply operation. After the mantissas are multiplied, the result can be normalized.

RAND:FLT:SCNT-Shift Count Control

The SCNT field controls the MAG register and, therefore, determines the size of the shift of the hex shifter. SCNT also sets the SWAP bit in the STATE register, which reverses the A and B outputs of the register file.

All of the micro-orders below except N, RST, and CMP will set the SWAP and X.GT.15 bits to 0. (Note that IPOP also clears these bits.) The CMP and RST micro-orders change the compare bits (STATE[2-3]).

Note that MAG must be loaded at least one cycle before the shift uses it.

No Load MAG

N

0

MAG and the swap bit are not loaded.

Restore STATE

RST

1

Load MAG[0-3], SWAP, X.GT.15, and the compare bits from the FA Bus.

Compare

CMP

2

Perform a prescale compare operation on the operands in preparation for signed mantissa addition or subtraction. If FA < FB, set the SWAP bit. If 'R' is coded in the FWR field, FR as the source for the working register when FA < FB; select FS when FA >= FB. For CMP to work correctly, a subtract operation must be coded on both the exponents and mantissas of FA and FB. This micro-order loads MAG with the absolute value of the exponent difference, which is used in the next cycle to prescale (right shift) the operand loaded in the working register.

Load Constant

LCN

3

Load a constant into MAG[0-3] from the IY field. The following constants are defined for the IY field when LCN is used:

R0 to R15 These are the appropriate values for right shifts from 0

to 15 hex digits. (1-15)

LO to L15 These are the appropriate values for left shifts from 0

to 15 hex digits. (0,15-1)

These values in the IY field do *not* specify the direction of the shift. (The shift direction is specified by the FS field when the shift is desired.) The use of left and right magnitudes in the IY field is strictly for the convenience of the programmer. These codes are provided because the magnitude of the shift in the proper direction is not a straightforward mapping.

First Nibble Zero

FNZ

4

Set MAG to -1 if the first nibble of the mantissa is zero; otherwise, set MAG to 0. This micro-order is used for multiply normalization. Note that no mantissa overflow (MOF) is possible for a multiply operation.

Divide Prescale

DVP

5

Set MAG to 1 if there is a carry-out from the mantissa; otherwise, set MAG to 0.

Load Exponent Fbus

LEF

6

Load MAG[0-3] from EF[4-7] (the output of the Exponent ALU).

Leading Zero Detection

LZD

7

Detect leading zeros and mantissa overflow (MOF). If MOF occurs, the output of the mantissa ALU is shifted right by four bits. Do not code FOP:TAD while using the LZD random to detect leading zeros.

Because of timing, leading zero detection is done for a maximum of two hex digits during the cycle when the LZD random is coded. This value will be wrong if there are more than two leading zeros; however, if LZD is coded again for the cycle when the value is used, then the correct value will be calculated. Coding any other SCNT micro-orders except N and LZD after the LZD random will cancel any later correction attempt.

Integer ALU Micro-orders

The Integer ALU portion of the microword contains the following fields:

- IA—specifies the A output of the integer register file.
- IB—specifies the B output of the integer register file.
- *ID*—specifies the source for the ID Bus.
- RS—specifies the input sources for the ALU.
- IOP—controls the operation of the ALU.
- IY—specifies the source for the IY Bus.
- *IL*—controls the loading of the register file.

IA and IB—Integer Register File Addressing

The IA and IB fields control the addressing for the integer register file. Note that, when floating-point numbers are being manipulated, these same fields control the addressing for the floating-point register file. Each micro-order specifies a particular register. The following micro-orders can be used in the IA and IB fields:

Macroinstruction Accumulator 0

AC₀

0

This is the programmer-visible Accumulator 0. Assembly code can access it. At IPOP, this register must contain the same value as Accumulator 0 in the AG register file.

Macroinstruction Accumulator 1

AC1

1

This is the programmer-visible Accumulator 1. Assembly code can access it. At IPOP, this register must contain the same value as Accumulator 1 in the AG register file.

Macroinstruction Accumulator 2

AC2

2

This is the programmer-visible Accumulator 2. Assembly code can access it. At IPOP, this register must contain the same value as Accumulator 2 in the AG register file.

Macroinstruction Accumulator 3

AC3

3

This is the programmer-visible Accumulator 3. Assembly code can access it. At IPOP, this register must contain the same value as Accumulator 3 in the AG register file.

Wide Frame Pointer

FP

4

Register 4 contains a copy of the Wide Frame Pointer, which is stored at page 0, address 10_{16} . By convention, these copies are not always the same. The register contains the valid copy.

Wide Stack Limit

SL

5

Register 5 contains a copy of the Wide Stack Limit for the current ring, which is stored at page 0, 14_{16} . By convention, these copies are always identical.

Wide Stack Base SB 6 Register 6 contains a copy of the Wide Stack Base for the current ring, which is stored at page 0, 16₁₆. By convention, these copies are always identical. Minus One M1 7 Register 7 contains a constant -1 (all ones). General Register 0 GR0 8 This is a general register for use by the microprogrammer. It has no assigned meaning. General Register 1 GR1 9 This is a general register for use by the microprogrammer. It has no assigned meaning. General Register 2 GR2 Α This is a general register for use by the microprogrammer. It has no assigned meaning.

General Register 3 GR3 В This is a general register for use by the microprogrammer. It has no assigned meaning. General Register 4 GR4 C This is a general register for use by the microprogrammer. It has no assigned meaning. General Register 5 GR5 D This is a general register for use by the microprogrammer. It has no assigned meaning. Register Addressed by ACSR SRC E This micro-order takes the address for the register file from the Accumulator Source Register (ACSR). Register Addressed by ACDR DES F This micro-order takes the address for the register file from the Accumulator Destination Register (ACDR).

ID--ID Bus Source Control

SPAD Addressed by SPAR

SS

0

The scratch pad outputs to the ID Bus. The scratch pad address register (SPAR) addresses the scratch pad.

SPAD Addressed by CON

SC

1

The scratch pad outputs to the ID Bus. The CON register (which contains the value from the CNST field of the micro-order) addresses the scratch pad.

SPAR, ACD, and ACS to ID Bus

MS

2

The SPAR, ACD, and ACS registers source the ID Bus in the following manner:

$$ID[0-15] = -0-$$
; $ID[16-31] = SPAR[0-7], ACD[0-3], ACS[0-3]$

ACS to ID Bus

AS

3

The ACS register sources the ID Bus in the following manner:

```
ID[0-27] = 0 ; ID[28-31] = ACS[0-3]
```

Constant Register to ID Bus CN4 The constant register (CON) sources the ID Bus in the following manner: ID[0-23] = 0 ; ID[24-31] = CON[0-7]CPD Bus Register-PDR to ID Bus PD 5 The PDR sources the ID Bus. This register is used to transfer data off the CPD Bus. Additionally, it can be used as a counter. (See TSEL: <CNT4 CNT8>.) B Port to ID Bus BR 6 The B output port of the integer ALU register file sources the ID Bus. Zero ZR 7

The ID Bus is forced to zero.

RS-ALU Input Multiplexer Control

The RS field controls the inputs to the ALU.

ID Bus and A Port

DA

0

The ID Bus is the input to the R side of the ALU; the A port of the register file is the input to the S side.

A Port and ID Bus

AD

1

The A port of the register file is the input to the R side of the ALU; the ID Bus is the input to the S side.

CPD Bus and A Port

CA

2

The CPD Bus is the input to the R side of the ALU; the A port of the register file is the input to the S side.

CPD Bus and ID Bus

CD

3

The CPD Bus is the input to the R side of the ALU; the ID Bus is the input to the S side.

IOP-ALU Control and Shift Magnitude

The IOP field has two separate functions: it controls the ALU and it determines the magnitude of the hex shift specified by the IY field. The codes for the hex shift will be found with the appropriate micro-orders in the IY field. The ALU control micro-orders determine combinations of the R and S inputs of the ALU and also control the Carry-In Base (CIB) polarity.

```
Logical AND
 AND
 0
     The logical AND of the R and S inputs to the integer ALU.
 Logical OR
 OR
 1
    The logical OR of the R and S inputs to the integer ALU.
Logical AND with Complement
ANC
2
    The logical AND of the R input and the complement of the S input.
Exclusive OR
XOR
3
    The exclusive OR of the R and S inputs to the integer ALU.
Addition with Complement
CSR
   The addition of the complemented R input to the S input with the CIB complemented (this
is a twos complement subtract if CIB is zero):
               R' + S + CIB'
```

Addition with Complemented Carry-in

CAD

5

The addition of the R and S inputs with the CIB complemented:

$$R + S + CIB'$$

Addition with Complement

SMR

6

The addition of the complemented R input to the S input with the uncomplemented CIB:

$$R' + S + CIB$$

Addition

ADD

7

The addition of the R and S inputs with the uncomplemented CIB:

$$R + S + CIB$$

IY -- IY Bus Source

The IY field specifies the source for the IY Bus. As a result, it also controls the hex and bit shifters, as well as certain ALU output functions. The IY Bus can be wide (32 bits) or narrow (16 bits), depending on FLAGO. The effect of this is explained for each micro-order.

Append PSR

PSR

0

The Processor State Register (PSR) sources the most-significant bits of the Y Bus: Y[0-31] comes from PSR[0-3],F[4-31].

For narrow operations (FLAG0=0), the source data is sign extended if it goes to the address generator, SPAD, or the integer register file; for other destinations, the most-significant sixteen bits are one filled.

Pass the F Bus to the Y Bus

PASS

1

The current value of F (ALU output) passes unchanged to the Y Bus: F[0-31] goes to Y[0-31].

For narrow operations (FLAG0=0), the source data is sign extended if it goes to the address generator, SPAD, or the integer register file; for other destinations, the most-significant sixteen bits are one filled.

Edited Commercial Data

EDT

2

The edited translation of the least-significant byte on the A Bus goes to the Y Bus: Y[0-31] comes from (F[0-27],TRANS(A[24-31]=28-31)). This micro-order must be used with the TSEL:COM2 micro-order and the CNST field.

For narrow operations (FLAG0=0), the source data is sign extended if it goes to the address generator, SPAD, or the integer register file; for other destinations, the most-significant sixteen bits are one filled.

Swap Bytes

BSW

3

Interchange the two least significant bytes from the ALU output: Y[0-31] comes from F[0-15], F[24-31], F[16-23].

For narrow operations (FLAG0=0), the source data is sign extended if it goes to the address generator, SPAD, or the integer register file; for other destinations, the most-significant sixteen bits are one filled.

Bit Shift Left—One Filled

BL1

4

Shift the ALU output (F) left one bit. Shift in a one, unless RAND:<XC XZ>:COVS:ALC is coded. In that case, the least-significant bit will be the ALC carry, and the CARRY register will be loaded with the shifted-out bit.

For narrow operations (FLAG0=0), the bit-shifter output is sign extended if it goes to the address generator, SPAD, or the integer register file; for other destinations, the most-significant sixteen bits are one filled.

Bit Shift Left—Zero Filled

BL₀

5

Shift the ALU output (F) left one bit. Shift in a zero, unless RAND: <XC XZ>:COVS:ALC is coded. In that case, the least-significant bit will be the ALC carry, and the CARRY register will be loaded with the shifted-out bit.

For narrow operations (FLAG0=0), the output of the bit shifter is sign extended if it goes to the address generator, SPAD, or the integer register file; for other destinations, the most-significant sixteen bits are one filled.

Bit Shift Right—One Filled

BR1

6

Shift the ALU output (F) right one bit. Shift in a one, unless RAND:<XC XZ>:COVS:ALC is coded. In that case, the most-significant bit will be the ALC carry, and the CARRY register will be loaded with the shifted-out bit.

For narrow operations (FLAG0=0), the bit-shifter output is sign extended if it goes to the address generator, SPAD, or the integer register file; for other destinations, the most-significant sixteen bits are one filled.

Bit Shift Right—Zero Filled

BR0

7

Shift the ALU output (F) right one bit. Shift in a one, unless RAND:<XC XZ>:COVS:ALC is coded. In that case, the most-significant bit will be the ALC carry, and the CARRY register will be loaded with the shifted-out bit.

For narrow operations (FLAG0=0), the shifter output is sign extended if it goes to the address generator, SPAD, or the integer register file; for other destinations, the most-significant sixteen bits are one filled.

Hex Shift Right-Zero Filled

HR0

8

The hex shifter shifts the data selected by ALU-input multiplexer R to the right in 4-bit increments and shifts zeros in from the left. The IOP field determines the magnitude of the shift. The IOP codes for a right shift are:

Mnemonic	Value	Description
R1	0	Hex shift right 1.
R2	1	Hex shift right 2.
R3	2	Hex shift right 3.
R4	3	Hex shift right 4.
R5	4	Hex shift right 5.
R6	5	Hex shift right 6.
R7	6	Hex shift right 7.
@R	7	Hex shift right (ACSR[1-3]+1). ACSR = X111 gives a result of zero.

 $FLAG0=0 \rightarrow zero extended$

Hex Shift Left—Zero Filled

HL0

9

The hex shifter shifts the data selected by ALU-input multiplexer R to the left in 4-bit increments and shifts zeros in from the right. The IOP field determines the magnitude of the shift. The IOP codes for a left shift are:

Mnemonic	Value	Description
@L	0	Hex shift left by ACSR[1-3]; ACSR = X000 gives a result of zero.
L1	1	Hex shift left 1.
L2	2	Hex shift left 2.
L3	3	Hex shift left 3.
L4	4	Hex shift left 4.
L5	5	Hex shift left 5.
L6	6	Hex shift left 6.
L7	7	Hex shift left 7.

 $FLAG0=0 \rightarrow zero extended$

Hex Rotate Right

HRT

Α

The hex shifter rotates the data selected by ALU input multiplexer R to the right in 4-bit increments. The IOP field determines the magnitude of the shift. The IOP codes for rotation are:

Mnemonic	Value	Description
R1	0	Hex rotate right 1.
R2	1	Hex rotate right 2.
R3	2	Hex rotate right 3.
R4	3	Hex rotate right 4.

Mnemonic	Value	Description
R5	4	Hex rotate right 5.
R6	5	Hex rotate right 6.
R7	6	Hex rotate right 7.
@R	7	Hex rotate right (ACSR[1-3]+1). ACSR = X111 gives a result of zero.

 $FLAG0=0 \rightarrow zero extended$

Byte Sign Extension

BSX

В

Extend the sign bit of the least-significant byte on the R Bus: R24 is repeated 24 times, so that Y[0-31] comes from 24 < R24 > R[24-31].

Word Zero Extension

WZX

 \mathbf{C}

The most-significant word on the Y Bus is zero filled; the least-significant word comes from the least-significant word of the R Bus. Y[0-31] equals 16 < 0 >, R[16-31].

Word Sign Extension

WSX

E

Extend the sign bit of the least-significant word on the R Bus. Y[0-31] equals 16 < R16 > R[16-31].

IL -Integer Register File Input

The IL field controls the input multiplexer for the integer register file and the scratch pad. It also enables loading of the register file. The input port address is the same as the B output port address, i.e., the IB field specifies it.

No Operation N 0 This micro-order disables the multiplexer. Note that this micro-order is identical to NM. Different mnemonics are provided for the convenience of the microcoder, to indicate differences in intention. Select CPM Data NM 0 The multiplexer selects the CPM Bus, but the register file is not loaded. This micro-order allows the loading of CPM data into the scratch pad. Select IY Data NY 1 The multiplexer selects the IY Bus, but the register file is not loaded. This micro-order allows the loading of IY data into the scratch pad. Select and Load CPM Data M 2 The multiplexer selects the CPM Bus and loads the data into the register addressed by IB. Select and Load IY Data Y 3

The multiplexer selects the IY Bus and loads the data into the register addressed by IB.

Floating-Point ALU Micro-orders

The Floating-point Unit portion of the microword contains the following fields:

- * FR—specifies the source of the FR Bus.
- * FS—specifies the source of the FS Bus.
- * FOP—controls the floating-point ALU operations.
- FWR—specifies the input to the working register.
- FCW—specifies the write address for the FPU register file.
- * FL—specifies the input to the FPU register file.
- FRG—controls the loading of FPU registers.
- * FX—controls the excess-64 exponent correction.

The FR, FS, FOP and FWR fields are also used as the system-wide CNST field. Therefore, use of the floating point unit generally prohibits use of the constant field and vice-versa.

FR -FR Bus Source

The FR Bus drives the R input of the mantissa ALU and can source the working register. The FR field determines the source for the FR Bus.

FA Bus

FA

0

FA[8-71] is the source for the FR Bus. You can use this micro-order to move values from the register file to the ALU.

Multiplier Partial Product

MP

1

The multiply ALU M[8-71] sources the FR Bus. This micro-order brings partial products to the mantissa ALU, where they are added into the partial sum during multiplication.

Round Bit

RB

2

The rounding logic calculates the rounding bit: either 31 or 63 (FLAG2=0 or 1). This bit represents either a truncation of the final result or an unbiased rounding, depending on whether FPSR8 is set. The bit is driven onto the FR Bus and may be added to the working register; the result is a correctly rounded mantissa. If the first four bits of the mantissa are zero, the FDI Bus is zeroed (true zero). The round bit is usually added to the result during the normalization cycle.

Divide Partial Remainder

DR

3

The DPR register (DPR[8-71]) sources the FR Bus. Note that passing data through the DPR register produces a 1-bit left shift. This shift is used during the division algorithm to move the current partial remainder into position for the next subtraction.

During a divide operation, both FCW and IB must be coded with the register that contains the divisor.

FS-FS Bus Source

The FS Bus sources the S input of the mantissa ALU. It can also source the working register. The sources to the FS Bus are controlled by the FS field. Because the FS Bus is the only output for the hex shifter, the FS field also includes the coding that determines whether the hex shifter shifts right or left. Note that the size of the shift is determined by MAG[0-3], which in turn has been determined by the RAND:FLT:SCNT field. FS[40-72] is zeroed for single-precision operations.

FB Bus

FB

0

The FB Bus sources the FS Bus. The FB Bus is the output bus for the B port of the register file.

Zero

ZR

1

The FS Bus is zeroed; no data is driven onto the bus at this time.

Right Shift

RS

2

The output of the working register to the FS Bus is shifted right. The value in MAG represents the number of hexadecimal digits shifted.

Left Shift

LS

3

The output of the working register to the FS Bus is shifted left. The value in MAG represents the number of hexadecimal digits shifted.

FOP - Mantissa Operations

The FOP field controls the operations of the mantissa ALU. The inputs to the ALU are the FR and FS buses. The output goes to the FF Bus.

Except during division, the mantissa ALU adds and subtracts unsigned numbers. A negative mantissa result is meaningful only for comparison purposes. During floating-point addition or subtraction, a prescale operation is performed to ensure that the smaller operand is on the FR Bus and the result of mantissa subtraction is meaningful.

The FF Bus sources the FD Bus either directly or right shifted by four bits.

Conditional Add

ADD

0

Add the values on FR and FS together if SA is equal to SB (i.e., if the signs are the same); otherwise, subtract FS from FR. A prescale operation must be performed on the FR operand to obtain a meaningful result. See the FLT:SCNT:CMP random description earlier in this chapter for details.

Conditional Subtract

SUB

1

Subtract FS from FR if SA is equal to SB (i.e., if the signs are the same); otherwise, add them. A prescale operation must be performed on the FR operand to obtain a meaningful result. See the FLT:SCNT:CMP random description for details.

Unconditional Add

TAD

2

Add FR to FS regardless of the signs of the numbers.

Unconditional Subtract

TSB

3

Subtract FS from FR regardless of the signs of the numbers. TSB is coded for prescale compare and divide operations. During divide operations, TSB will cause the ALU either to add or subtract, depending on the sign of the partial remainder from the previous operation.

FWR —Working Register Input

The FWR field controls the input multiplexer for the working register. Note that loading of the working register is controlled by micro-orders in the FRG field; FWR only selects the source to be loaded.

FS Bus

S

0

Select the FS Bus to source the working register.

FR Bus

R

1

Select the FR Bus to source the working register.

This micro-order can be overridden if the CMP micro-order is coded in the RAND:FLT:SCNT field. In this case, if the value on FR is greater than or equal to the value on FS (FR \geq = FS), then FS is the source for the working register.

Left Shift

Q

2

Shift the data from the working register left one bit. Put the value of the Q bit, from a divide operation, into the least-significant bit of the working register. (For single-precision, the least-significant bit is 39; for double-precision, 71.) The Q bit is derived from a subtraction or addition operation that produced a partial remainder. After a series of subtractions or additions, the bits that have been shifted into the working register will be the quotient from the complete divide operation.

During division cycles, TBS is coded in the FOP field. The division hardware will perform an addition or subtraction based upon the value of the partial remainder from the previous operation.

FD Bus

D

3

Select the FD Bus to source the working register.

FCW-Floating-Point Register Write Address

The FCW field specifies the write address for the floating-point register file. (The read addresses for the register file are specified by the IA and IB fields, the same as for the integer register file.) The input to the register file is the FDI Bus, and the FCW field specifies which register the data from the FDI Bus will go into.

The floating-point accumulators and general registers correspond in their addresses to the integer accumulators. This is useful for operations, such as integer division and multiplication, that use both the integer and floating-point ALUs.

The mnemonics listed below can also be used in the IA and IB fields when those fields are used to address the output ports of the floating-point register file.

```
FP Accumulator 0
FP0
0
   FP0 addresses floating-point accumulator (FPAC) 0. This is the macroprogram accumulator.
FP Accumulator 1
FP1
1
    FP1 addresses floating-point accumulator (FPAC) 1. This is the macroprogram accumulator.
FP Accumulator 2
FP2
2
    FP2 addresses floating-point accumulator (FPAC) 2. This is the macroprogram accumulator.
FP Accumulator 3
FP3
3
    FP3 addresses floating-point accumulator (FPAC) 3. This is the macroprogram accumulator.
 Integer Halving Constant
 IHC
 4
     IHC addresses a register that always contains a constant: EXP=14, Mantissa=.5. This
```

the addresses a register that always contains a constant: EXP=14, Manussa-.3. This constant is used for conversion from floating point to fixed point and for halving. (Note that the exponent is in excess-64 form, i.e., the actual decimal value stored is 78.)

Constant Zero **ZER** 5 ZER addresses a register that contains a constant zero. Constant Maximum Number MAX 6 MAX addresses a register that contains the largest power of 10, minus 1, that will fit in a Floating-Point General Register 6 FG6 7 FG6 addresses a general register the microprogrammer may use for any purpose. There is no restriction on this register such as there is on the FPAC registers. Floating-Point General Register 0 FG0 8 FG0 addresses a general register that the microprogrammer may use for any purpose. There is no restriction on this register such as there is on the FPAC registers. FG0 is the only general-purpose register that is saved in a context block when a page fault occurs. Use FG0 for memory to FPAC operations (e.g., FAMS). Floating-Point General Register 1

FG1

9

FG1 addresses a general register that the microprogrammer may use for any purpose. There is no restriction on this register such as there is on the FPAC registers.

Floating-Point General Register 2

FG2

Α

FG2 addresses a general register that the microprogrammer may use for any purpose. There is no restriction on this register such as there is on the FPAC registers.

Floating-Point General Register 3

FG3

В

FG3 addresses a general register that the microprogrammer may use for any purpose. There is no restriction on this register such as there is on the FPAC registers.

Floating-Point General Register 4

FG4

 \mathbf{C}

FG4 addresses a general register that the microprogrammer may use for any purpose. There is no restriction on this register such as there is on the FPAC registers.

Floating-Point General Register 5

FG5

D

FG5 addresses a general register the microprogrammer may use for any purpose. There is no restriction on this register such as there is on the FPAC registers.

Accumulator Source

SRC

Ε

When SRC is coded, the Accumulator Source Register (ACSR) addresses the floating-point register file.

Accumulator Destination

DES

F

When DES is coded, the Accumulator Destination Register (ACDR) addresses the floating-point register file.

FL-Register File Load Specifier

The FL field determines the source for the register specified in the FCW field. MV/10000 system buses are 32 bits wide, but the floating-point register file is 64 bits wide. Double-precision data must be loaded from the system in two 32-bit segments (most-significant followed by least-significant).

If the double-precision flag is not set (flag2=0), FDI[32-63] is forced to zero. Single-precision numbers use only the most significant half of a location in the register file.

No Load

N

0

No value is written to the register file. However, data is taken from the CPM Bus and driven onto the FDI Bus. CPM[0-31] goes to FDI[0-31] and FDI[32-63].

Load Lower Half

ML

1

ML loads the least-significant 32 bits of a location in the floating-point register file. CPM[0-31] are sourced onto FDI[32-63] and FDI[0-31], and the least significant portion of the register file (bits 32-63) is loaded from the FDI Bus.

Load Upper Half

MH

2

MH loads all 64 bits of a location in the floating-point register file. CPM[0-31] source these bits. For double-precision numbers (FLAG2=1), CPM[0-31] are sourced on FDI [0-31] and FDI [32-63]; for single-precision numbers (FLAG2=0), CPM[0-31] are sourced on FDI [0-31], while FDI[32-63] are set to zero. All 64 bits of the register file are loaded from the FDI Bus.

FL-Register File Load Specifier

Note that the most significant half of double precision data must always be loaded first, because MH destroys the least significant bits.

Load From FD

D

3

D sources FD[0-63] onto all 64 bits of the FDI Bus and loads all 64 bits of a location in the floating-point register file from the FDI Bus. If the FR field is coded with RB (i.e., a rounding operation is being performed), the FDI Bus will be forced to zero if the top 4 bits and carry-out of the mantissa ALU are zero.

FRG -Floating-Point Register Load Control

FRG controls the loading of various floating-point registers.

No Operation

N

0

N produces no effect.

Update FPSR

UFS

1

The Z, N, OVF, and UNF bits of the FPSR are updated. Z and N are set to the current values from the FDI Bus; OVF and UNF are ORed with the current values from the exponent ALU, so that the values in FPSR represent an accumulated value since the last time the bits were cleared.

Care must be taken if only the Z and N flags are to be updated. To avoid causing invalid floating point faults, pass a valid exponent through the exponent ALU if a valid floating point calculation has not been performed.

Read LO

RLO

4

RLO reads LOW[0-63] to M[8-71]. The LOW register is part of the multiply ALU hardware, and its contents are calculated as follows (where X is the X register and MY is the byte selected by YSEL). This micro-order is primarily for diagnostic visibility.

```
MY * X[24-31] => LOW[0-7] (These bits are indeterminate.)

MY * X[8-15] => LOW[8-23]

MY * X[24-31] => LOW[24-39]

MY * X[40-47] => LOW[40-55]

0 => LOW[56-63]
```

Load Guard Digits

LGD

5

Load the Divide Guard Digit (DGD) register. This register holds the least-significant digits of the dividend before it is transferred to the DPR register. During division setup, the prescaled dividend is transferred from the working register to the register file, so that it may be transferred to the FS Bus. The DGD register prevents loss of guard digits during this transfer.

Partial Multiply and Load Working Register

LWM

6

Step the multiply pipe;

- 1) Add the data in the HI and LO registers and source the result on the M Bus.
- 2) Multiply the x register by the byte in the Y register selected by YSEL.
- 3) Load intermediate result in the HI and LO registers.
- 4) Decrement YSEL.
- 5) Load the working register.

Normally, the multiply pipe will be stepped for each byte of the multiplier in Y. LWM must be invoked one cycle before the first partial product is added into the working register. To accumulate partial products, M should source the FR Bus, the working register should be right shifted one byte and sourced on the FS Bus, the mantissa ALU should perform addition, and the FD Bus should source the working register input bus.

Load Working Register

LWR

7

LWR loads the working register at the end of the cycle (i.e., after a value has been calculated by the Mantissa ALU).

Load Y

LY

8

Load the Y register and the YSEL counter. LY loads a new value in Y and restarts the multiplication process, while maintaining the old value in X. The YSEL counter is loaded with the value from the IY field. YSEL=0 points to the high byte of the Y register.

Load XY

LXY

9

LXY loads the X and Y multiplier registers and the YSEL count. This is the initial setup command for a multiply operation. The X and Y registers hold the multiplicand and multiplier, respectively. The YSEL counter, which is loaded from the IY field (inverted), specifies which byte of the multiplier will be used for the next partial product. YSEL=0 points to the high byte of the Y register.

Source FPSR

SFS

Α

SFS sources the Floating-Point Status Register to the FA Bus, bits 0-15. SFS disables the output to FA from the register file.

Source STATE

SST

В

SST sources the floating-point STATE register to the FA Bus, bits 0-15. SST disables the A output of the register file.

Load FPSR

LFS

 \mathbf{C}

LFS loads the Floating-Point Status Register (FPSR) from the FDI Bus, bits 0-15.

Load STATE

LST

D

LST loads the floating-point STATE register from bits 0-15 of the FA Bus.

Initial Divide

IDV

E

IDV is the micro-order that begins a division procedure. At this point the Divide Guard Digit register should contain the least-significant bits of the dividend, while the most-significant bits should be in a location in the register file. IDV sources DGD onto the FR Bus bits 32-39 or 64-72 (FLAG2=0 or 1). Which bits are used depends on the precision flag (FLAG2=1, double precision; FLAG2=0, single precision). At the same time, the FR Bus should be sourced by the general register file for the most-significant bits. The FS Bus should be sourced with the divisor from the register file (address must be in IB and FCW fields) and the mantissa ALU should perform subtraction (FOP:TSB). At the end of the cycle, the DPR is loaded with the initial partial remainder.

Double Load

LWD

F

LWD loads the DPR and WR twice per cycle.

FX-Excess-64 Control

The FX field is used in conjunction with the RAND:FLT:EXP:<S64 and A64> micro-orders. These micro-orders correct excess-64 exponents after exponent addition or subtraction.

No Operation

0

N

No operation is performed. This micro-order should be used with the RAND:FLT:EXP:<N and ACW> micro-orders.

Excess-64 Conversion

X64

1

This micro-order sources 64 to the S input of the exponent ALU. That value can then be added to or subtracted from the Exponent Working Register. Adding and subtracting 64 corrects exponents after addition or subtraction.

End of Chapter

Chapter 4 **Microprogramming Examples**

This chapter gives examples of MV/10000 microcode. The microinstructions are presented as they are printed by the microassembler. The microfields are presented in the same order as in Chapters 2 and 3, except that the microassembler reverses the FL and FCW fields. Some microfield names have been abbreviated in the microword headers; the micro-orders for each field are those given in Chapter 3. Note that the "LABEL" field is a pseudo field for the microassembler. Table 4-1 lists the abbreviations found in the microword headers.

Table 4-1. Microword Header Abbreviations

Abbreviation	Field Name
OP	COP or UCOP
D	DSR
AG	AGB
ST	MEMS
СМ	MEMC
СРМ	CPMS
CPD	CPDS
RO	REGO or ATUO or COVS or SGN
R1	REG1 or ATU1 or LOAD or EXP
R2	SPAD or SCNT
w	FW

For illustration purposes, we have left many of the microcode fields blank. In a genuine microroutine, many of these fields would of course be used. For instance, in the examples of memory accesses, you would have to specify a source and destination for the CPM Bus.

Memory Accesses

Because synchronization between the memory and the CPU is automatic, you need not consider timing in memory accesses. You may start memory (MEMS micro-order) in one microinstruction and complete memory (MEMC micro-order) in any following microinstruction. (A memory complete need not follow the start immediately, so long as there is no other intervening memory start. However, you should not leave a memory start pending for long, as this blocks I/O traffic.) The examples below show typical sequences.

Read Operation

In the example below, the double-word (32-bit) read operation is started with the RD micro-order. This operation is completed on the next microinstruction with the R micro-order. Note that the CPM Bus is sourced by main memory (MM), as it will be for any read operation.

Although the example above is for a double-word read, the same sequence would apply to single-word or byte reads.

Write Operation

In the following example, the word write (16-bit) operation is started with the WW micro-order and completed with the W micro-order.

Read and Modify Operation

A read and modify operation requires no special memory start or complete. It begins with a write start, followed by a read complete. The read complete will not release memory, which remains started until a write complete is coded.

In the following example, the first microinstruction starts memory for a word write. The second has a read complete. The third instruction actually completes the start with a write. This sequence is used when you want to read information and write it back, possibly modified, to the same location.

Execute Completion

Microcode reads instructions for the IP by starting memory with a read word and a RAND:ATU:ATU0:IPST or RAND:ATU:ATU0:ICAT instruction. The reference is then completed with a MEMC:X micro-order. If there is any other combination of micro-orders, the ATU will not check execute protection.

In the following example, RW is coded in the same microinstruction with IPST. The reference is completed in the next instruction with an X.

Overlapped Write Operation

In this example, the WD micro-order starts a double-word write operation. This operation completes during the next microinstruction with the W micro-order. As the first write completes, a second is started. The third microinstruction completes the second start. For the first write, the most-significant bits of a register in the FPU source the CPM Bus; for the second write, the least-significant bits are the source.

Overlapped Read and Write

The following sequence shows a series of reads overlapped with a series of writes.

LABEL:	OP	TSEL	ADDRESS	D	AA	AB	AG	AOP	AL	ST	CM	CPM	CPD	RM	R0	Rl	R2	IA	IB	ID	RS	IOP	IY	IL	FR	FS	FOP	W	FCW	FL	FRG
RD1:				-						RW																		-			
DD2+				-						RW	R																	-			
MD1.				-						WW	R																	-			
MD2 ·				_						WW	W																	-			
WKZ:											W																	-			

The following sequence shows a series of writes overlapped with a series of reads. This sequence is not illegal, but should be avoided. When a read start is coded in the same instruction with a write complete, it causes memory to extend the microinstruction cycle.

Illegal Sequences

The following examples show illegal sequences of microinstructions. No memory start can occur before the previous memory start is completed.

In the first sequence, RW starts memory in the first microinstruction. However, the N in the MEMC [CM] field does not release memory. Therefore, the RW is illegal, because it tries to start memory before it has been released.

LABEL:	OP	TSEL	ADDRESS	D	AA	AB	AG	AOP	AL	ST	CM	CPM	CPD	RM	R0	Rl	R2	IA	IB	ID	RS	IOP	IY	ΙL	FR	FS	FOP	W	FCW	FL :	FRG
RD2:				-						RW	N																				
RDCOMPLT1	:			_							R																				
RDCOMPLT2	:			-							R																				

In the second example, the sequence begins with a WW memory start. However, in the next microinstruction, a read complete is coded. This is a read/modify sequence (see above). Memory is not released by the R micro-order, and, therefore, the WW coded in the same microinstruction is illegal.

IPOP - Crossing Macroinstruction Boundaries

The IPOP procedure connects one macroinstruction routine to another. The object of IPOP is to get the IP to provide a starting microaddress based on its decoding of the next macroinstruction, and to properly set up the parameters for that instruction. IPOP is performed by coding a NAC:COP micro-order that pops an empty stack and specifies the Top of Stack (TOS) as the next address. At the same time, the microinstruction tries to perform an effective address calculation (EFA) for the next macroinstruction. (Of course, the next macroinstruction may not require an EFA, in which case the effort is wasted. However, no instruction cycles are lost, and if an EFA is needed, the calculations are already under way before the next microroutine starts.)

The following microinstruction implements IPOP. (For this to work, the stack must be empty.)

```
LABEL: OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG
```

- A) CRTN—When its condition is true, this micro-order has a next address of TOS and pops the microstack. The microstack must be empty.
- B) TRUE—This forces CRTN to pop and take TOS as the next address. If a normal test is used, e.g., an ALU test, the false path of the microprogram must code an abort for the memory start.
- C) D—This micro-order designates the displacement register as the source of the AGB Bus. The Address Generator will therefore try to construct a logical address from the displacement field of the next macroinstruction.
- D) EFA—This micro-order causes the Address Generator to do an EFA calculation, based on the decoded macroinstruction from the IP, and using the displacement from that instruction.
- E) S@-This micro-order, in conjunction with the EFA micro-order, attempts a memory start based on the IP decode information from the next macroinstruction. The IP also

determines whether an actual memory start takes place, i.e., the S@ micro-order may not start memory.

Indirection Resolution

The following microroutine illustrates indirection resolution. The routine is called from a microinstruction that starts memory for a word write (WW). The address for the write is in AR1 in the AG. If the indirection bit is set in the address, the instruction does a jump to the indirecton resolution subroutine.

An important general rule for calling microroutines is that a memory abort should be coded following the return from a subroutine which attempted an EFA calculation (a bogus memory start will be pending as a result).

Calling Microinstruction

```
LABEL: OF TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG

Start a write to the address in AR1.

Do a conditional jump to the indirection subroutine (IRES). The indirection bit determines whether the jump occurs.

The next microinstruction must complete the write.
```

Called Routine

The subroutine that does the indirection chaining aborts the original write reference, and begins a read instead. The RAND:ATU:ATU1:DF micro-order is coded, which ensures that indirection will not exceed 15 levels.

Dispatching

The microsequencer can construct addresses using the dispatch register (see Chapter 2). The following example demonstrates dispatching in a microroutine with the implementation of an actual macroinstruction: WCOB (Wide Count Bits). WCOB counts the bits that are set in the source (ACS) accumulator and adds that count to the value in the destination (ACD) accumulator. The microroutine that implements WCOB uses a dispatch table to determine the number of 1-bits in each nibble of the source accumulator.

Dispatch Table

The dispatch table has one test instruction and fifteen nearly identical table entries. Each table entry performs a new dispatch based on the beginning of the table: WCOBTAB. Which table entry is executed depends on the DSP register, which holds the value of the current least-significant nibble in the PDR register. The CNST value equals the number of 1 bits in that nibble. For example, if the nibble is 0111, it dispatches to the seventh table entry; the CNST field for that entry contains 3_{10} . The CNST value is added into the value in the destination accumulator each time a table entry is executed.

```
LABEL:
                            OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG
                    ;This microinstruction begins the table and is also the test to see whether the routine is complete. Whenever the nibble ;being tested is 0, the table entries dispatch to location 0 in the table. The TSEL:FRZ micro-order tests whether the ;remaining bits in the PDR register are equal to zero. This test was set up by the Ml micro-order in the previous ;microinstruction. If non-zero bits remain, control goes back to WCOBl, which dispatches into the table again. If no bit;remain, the routine is done and this microinstruction IPOPs.
                                                                            WCOBTAB: CRTN FZR
                                                     WCOB1
  ;Each microinstruction in the table is identical to WCOB1, except for the CNST field, which holds a value equal to the ;number of l's in the current nibble.
                                                                             F DES DES C ADD Y -- -- AG
F DES DES C ADD Y -- -- AG
F DES DES C ADD Y -- -- AG
F DES DES C ADD Y -- -- AG
F DES DES C ADD Y -- -- AG
F DES DES C ADD Y -- -- AG
F DES DES C ADD Y -- -- AG
F DES DES C ADD Y -- -- AG
F DES DES C ADD Y -- -- AG
F DES DES C ADD Y -- -- AG
F DES DES C ADD Y -- -- AG
F DES DES C ADD Y -- -- AG
F DES DES C ADD Y -- -- AG
F DES DES C ADD Y -- -- AG
F DES DES C ADD Y -- -- AG
F DES DES C ADD Y -- -- AG
F DES DES C ADD Y -- -- AG
F DES DES C ADD Y -- -- AG
F DES DES C ADD Y -- -- AG
F DES DES C ADD Y -- -- AG
F DES DES C ADD Y -- -- AG
F DES DES C ADD Y -- -- AG
                                                                                                                                                                                                         --- M1
--- M1
--- M1
                                                                                                                                                                                                                               DES PD DA R1
DES PD DA R1
DES PD DA R1
DES PD DA R1
              ---- DSPA ----- WCOBTAB
DSPA ----- WCOBTAB
----- DSPA ----- WCOBTAB
----- DSPA ----- WCOBTAB
                                                                                                                                                                          GN ---- LD
GN ---- LD
GN ---- LD
                                                                                                                                                                                                                                                                                         001 --- --- --- --- ---
                                                                                                                                                                                                                                                                                          001 --- --- - ---
                                                                                                                                                                        GN ---- LD
                                                                                                                                                                 IY
                                                                                                                                                                                                         --- M1
--- M1
--- M1
                                                                                                                                                                                                                                          PD DA R1
PD DA R1
PD DA R1
                                                                                                                                                                                                                                                                                         ----- DSPA ---- WCOBTAB
DSPA ---- WCOBTAB ---- DSPA ---- WCOBTAB ---- DSPA ---- WCOBTAB ---- DSPA ---- WCOBTAB
                                                                                                                                                                                                                                DES
                                                                                                                                                                                                         --- M1
--- M1
--- M1
--- M1
                                                                                                                                                                IY
IY
IY
IY
                                                                                                                                                                                                                               DES PD DA RI
DES PD DA RI
DES PD DA RI
DES PD DA RI
                                                                                                                                                                                                                                                                                         001 --- --- --- ---
002 --- --- --- ---
002 --- --- --- ---
HR0
                                                                                                                                                                                                                              DES PD DA RI HRO
                                                                                                                                                                                                                                                                                        002 --- -- -- -- --- --- 003 --- -- -- --- 004 --- -- -- --- ---
```

End of Chapter

Chapter 5 MV/10000 Microcode Macroassembler

The first section of this chapter outlines the macroassembler constructs. The second section provides examples of assembled microprogram segments.

The Macroassembler

The macroassembler makes your job easier by letting you code at a higher level than individual micro-orders. We use the following syntax conventions to describe the macroassembler:

Symbol	Name	Meaning
[]	Square brackets	Enclose optional elements.
< >	Angle brackets	Enclose non-terminal elements.
=	Equals	Precedes a data destination.
==	Double equals	Precedes a data source.
	Ellipsis	Indicates repeatable element.
{ }	Braces	Indicate a choice of the enclosed elements. When several elements are listed on successive lines, this also indicates a choice among the elements.
::=	definition	"Is defined as"
	Вох	Encloses micro-order equivalents of macroassembler constructs. The micro-order codings are always presented immediately following the terminal construct from which they result.

Each macroassembler command consists of one or more constructs and produces a single microinstruction. A macroassembler command has the following syntax:

<macroassembler_construct>,...;

Comments have a percent sign (%) at the beginning of the line, or are enclosed in /* . . . */. The second type of comment delimiter can be nested to any level.

CPM Bus

```
CPM [ = <CPM_dest> ]... == <CPM_src>
 <CPM_dest> ::=
MEM_WRITE
                                MEMC:W
EXECUTE_DATA
                                MEMC: A
FPSR
                                FRG:LFS
FP_LOW ( <FPU_reg> )
                                FL:ML, FCW
FP_HIGH ( <FPU_reg> )
                               FL:MH, FCW
ALU ( <ALU_reg> )
                               IL:M, IB
TREG
                                {GEN:REG1,ATU:ATU1}:LT
SPAD ( <literal> )
                                IL: {NM M}, SPAD: WC, CNST
SPAD ( SPAR )
                               IL:{NM M},SPAD:WS
AG ( <AG_reg> )
                               AL:M, AB
AG_IF_TRUE ( <AG_reg> )
                               AL:C, AB
<CPM_src> ::=
ALU ( <ALU_req> )
                               CPMS:IA, IA
CARRY_IN_ALU ( <ALU_reg> )
                               CPMS:IA,IA,GEN:REG0:FCY
                               CPMS:IY
ΑY
                               CPMS:AY
MEM_READ
                               CPMS:MM, MEMC:R
FP_HIGH ( <FPU_reg> )
                               CPMS:HF, IA
FP_LOW ( <FPU_reg> )
                               CPMS:LF, IA
FPSR
                               CPMS:HF, FRG:SFS
FP_STATE
                               CPMS:HF, FRG:SST
ALL_ONES
                               CPMS:N
```

Notes:

<FPU_reg> is a mnemonic specifying one of 16 FPU registers (see "Floating-Point ALU Micro-orders" in Chapter 3).

<ALU_reg> is a mnemonic specifying one of 16 ALU registers (see "Integer ALU Micro-orders" in Chapter 3).

In SPAD (teral>), the literal is a mnemonic that specifies the scratch pad address.

CPD Bus

The two CPD Bus constructs are CPD and PDR. The CPD construct implies PDR should not be loaded; i.e., the macroassembler codes {GEN:REG0 ATU:ATU0}:NPDR. The only exception to this is CPD==ZERO. The PDR construct does not code NPDR. In addition, the PDR construct can manipulate the reference bits. The only other difference between the two constructs is that CPD == ZERO codes CPDS:N and PDR == ZERO codes CPDS:ZER.

IO_CONTROLLER
MICRO_STACK_INVERTED
CONSOLE_DATA
CASE_DATA
REF_MOD_BITS
SBR_INVERTED
TRANSLATION_CACHE
IP_STATE

ATU: ATU0: SIO
NAC: PCPD
GEN: REG0: CDW
GEN: REG1: LD
ATU: ATU0: WRRM
ATU: ATU0: WSBR
ATU: ATU0: OPTA
ATU: ATU0: LIPS

<CPD_src> ::=

CPDS:TRG TREG CPDS:LAR LAR CPDS: IPS IP_STATE CPDS:ATS ATU_STATE CPDS:USS* SEQUENCER_STATE CPDS:IOC IO_DATA CPDS:CDR CONSOLE_DATA CPDS:CIR CONSOLE_INSTRUCTION CPDS:PC CPDS:PCX PC_OF_EXECUTION CPDS:PCN RETURN_PC CPDS:IY CPDS:ATD ATU_DIAGNOSTICS CPDS: {ZER, N} ZERO CPDS:AGA, AA AG (<AG_reg>)

Notes:

* SEQUENCER_STATE sources MICRO_STACK and FLAGS in true sense, and CASE_DATA in inverted sense.

<AG_reg> is a mnemonic specifying one of 16 AG registers (see "Address Generator Micro-orders" in Chapter 3).

Memory Starts and Address Generator Operations

```
START <AG-op> [<adr_opt>] [ FOR ] <ref_type>
<AG_op> ::=
AY [ = <AG_dest> ]... == <AG_src>
<AG__dest> ::=
CRE
               ATU: ATU0: LCRE
RESTORE_PC
               ATU: ATU0: LIPS
LAR
               ATU:ATU0:LLAR
PC
               ATU: ATU0: IPST
ATU_STATE
               ATU:ATU0:LATS
<CPM_dest>
               See "CPM Bus," above.
<AG_src> ::=
PASS ( <AGB_src> )
<AGB_src> {+ -} A(<AG_reg>)
<AGB_src> ::=
CNST ( <literal> )
                        AGB:C, CNST:<literal>
LAST_LA
                        AGB:L
B ( <AG_reg> )
                        AGB:B, AB:<AG_reg>
```

Note:

In CNST(<literal>), the literal is a hex number (00-FF).

<AG_reg> is a mnemonic specifying one of 16 AG registers (see "Address Generator Micro-orders" in Chapter 3).

Memory Starts and Address Generator Operations

```
<adr_opt> ::=
[ <byte/word> ] [ IN_CURRENT_RING {ATU,GEN}:REG1:AC

<byte/word> ::=
WITH_BYTE_ADDRESSING ATU:ATU0:BYTE
WITH_WORD_ADDRESSING ATU:ATU0:WORD
```

<ref_type> ::=

WIDE_JUMP
NARROW_JUMP
IP_TRANSLATION
READ_DOUBLE
READ_WORD
READ_BYTE
WRITE_DOUBLE
WRITE_WORD
WRITE_BYTE
PER_IP_DECODE
PREVIOUS_REFERENCE
OBJECT_REFERENCE
DBL_WORD_ASSEMBLY
CACHE_BLOCK_FLUSH

ATU:ATU0:IPST, MEMS:RD
ATU:ATU0:IPST, MEMS:RW
ATU:ATU0:ICAT, MEMS:RW
MEMS:RD
MEMS:RW
MEMS:RB
MEMS:WD
MEMS:WB
MEMS:WB
MEMS:S@
ATU:ATU0:OPTA, MEMS:S@
ATU:ATU0:CM0, MEMS:RW
ATU:ATU0:CM0, MEMS:RD

START_EXECUTE

ATU:ATU0:CM0, MEMS:WW, AA:0, AB:0, AGB:B, AOP:SUB

ATTEMPT_NEXT_EFA

AGB:D, AOP:EFA, MEMS:S@

```
START_READ_FOR <PTE_level>

<PTE_level> ::=

FIRST_PAGE_TABLE_ENTRY ATIL:
```

FIRST_PAGE_TABLE_ENTRY
SECOND_PAGE_TABLE_ENTRY

ATU:ATU0:RSBR, MEMS:RD ATU:ATU0:LPTA, MEMS:RD

Memory Completion

ABORT_MEMORY
READ_MEMORY*
COMPLETE_JUMP
COMPLETE_FLUSH
COMPLETE_TRANSLATE**

MEMC:A MEMC:R MEMC:X MEMC:R MEMC:X

Notes:

Normal reads and writes are handled by <CPM_dest>.

ALU Operation Constructs

IY Bus

```
TY [ = <alu_dest>]... == <alu_src>

<alu_dest> ::=

SPAR
SPAR_TABLE_OFFSET

GEN:SPAD:LS
GEN:REG0:SPY4, SPAD:LS
```

SPAR_TABLE_OFFSET
ABS_VALUE(<ALU_reg>)
PDR
CASE_DATA
<CPM_dest>

CPDS:IY
CPDS:IY, GEN:REG1:LD*
See "CPM Bus," above.

FIX:LOAD:AV

*Note:

CASE_DATA will load PDR unless NO_LOAD_PDR is coded.

<ALU_reg> is a mnemonic specifying one of 16 ALU registers (see "Integer ALU Micro-orders" in Chapter 3).

^{*} READ_MEMORY does NOT source CPM.

^{**} COMPLETE_TRANSLATE is for completion of ICATs.

```
<alu src> ::=
<alu_op>
<alu_IY_op> ( <alu_op> )
<hex_shift_op> ( <shft_mag>, <IR_src> )
<extnd_op> ( <IR_src> )
TRANSLATION_OF <ALU_reg> FOR <edit_type> IN_BOTTOM_NIBBLE_OF <alu_op>
Note:
<ALU_reg> is a mnemonic specifying one of 16 ALU registers (see "Integer ALU
Micro-orders" in Chapter 3).
<alu_op> ::= <IS_src> <iop> <IR_src>
<IS_src> ::= A ( <ALU_reg> )
             <ID_src>
<ID_src> ::=
                        ID:BR
B ( <ALU_reg> )
SPAD ( teral> )
                        ID:SC
SPAD ( SPAR )
                        ID:SS
CNST ( <literal> )
                        ID:CN
                        ID:PD
PDR
SRC_POINTER
                        ID:AS
MICROSTATE
                        ID:MS
                        ID:ZR
ZERO
```

Notes:

In SPAD (teral>), the literal is a mnemonic that specifies the scratch pad address.

In CNST (teral>), the literal is a hex number (00-FF).

<ALU_reg> is a mnemonic specifying one of 16 ALU registers (see "Integer ALU Micro-orders" in Chapter 3).

```
<iop> ::=
                IOP:ADD
+1 +
                IOP:CAD,
                          'Add with carry in'
                IOP:CSR
-1 -
                IOP:SMR,
                          'Subtract without carry'
AND
                IOP: AND
XOR
                IOP:XOR
OR
                IOP:OR
NOT_AND
                IOP: ANC, 'AND complement in
                                reverse direction'
<IR_src> ::=
<IS_src>
                        See "ALU Test"
CPD_ZERO
                        RS:{CA, CD}, CPDS:N
AG( <AG_reg> )
                        RS:{CA, CD}, CPDS:AGA*
LAR
                        RS:{CA, CD}, CPDS:LAR*
TREG
                        RS: {CA, CD}, CPDS:TRG*
CPD
                        RS:{CA, CD}
PC_OF_EXECUTION
                        RS:{CA, CD}, CPDS:PCX**
RETURN_PC
                        RS:{CA, CD}, CPDS:PCN**
PC
                        RS:{CA, CD}, CPDS:PC**
Notes:
* AG, LAR, and TREG will cause PDR to load unless NO_LOAD_PDR is coded. CPD_ZERO will
 not load PDR.
** {ATU, GEN}: XTND is coded.
<AG_reg> is a mnemonic specifying one of 16 AG registers (see "Address Generator
Micro-orders" in Chapter 3).
<alu_IY_op> ::=
BIT_SHIFT_RIGHT
                                IY:BR0
BIT_SHIFT_RIGHT_WITH_1
                                IY:BR1
```

IY:BL0

IY:BL1

IY:BSW

IY:PSR

BIT_SHIFT_LEFT

APPEND_PSR_TO

BYTE_SWAP

BIT_SHIFT_LEFT_WITH_1

<hex_shift_op> ::=

HEX_SHIFT_RIGHT HEX_SHIFT_LEFT HEX_ROTATE_RIGHT IY:HR0 IY:HL0 IY:HRT

<shift_mag> ::=

{R1, R2, R3, R4, R5, R6, R7, R0, L1, L2, L3, L4, L5, L6, L7, L0}

<IR_src> ::= See "<alu_src>," above.

<extnd_op> ::=

WORD_SWAP WORD_SIGN_EXTEND WORD_ZERO_EXTEND BYTE_SIGN_EXTEND IY:HRT, IOP:R4
IY:WSX

IY:WSX
IY:WZX
IY:BSX

<edit_type> ::=

SIGN_OVERPUNCH_BYTE DIGIT LOW_NIBBLE_DIGIT HIGH_NIBBLE_DIGIT CNST:VSO CNST:VDB CNST:VDL

CNST: VDH

ALU Test

This construct allows use of the ALU without sourcing the result to the IY Bus:

ALU_TEST == <alu_op>

<alu_op> ::= See "<alu_src>," above.

Loading SPAR

This construct loads SPAR with an address from the constant field:

SPAR == <literal>

```
GEN:REGO:SPCN, GEN:SPAD:LS, CNST:<literal>
```

Note:

teral> is a hex number (00-FF).

Edit PROM

This construct specifies an edit PROM test generation only (See CNST: Commercial Translation):

TEST <ALU_reg> FOR TEST

cprom_test> ::=

CNST:VSO
CNST:VDB
CNST:VDL
CNST:VDH
CNST:VCB
CNST:VSB
CNST:VSL
CNST:CSB
CNST:CSB
CNST:CPUD
CNST:SKPT
CNST:IONF

Note:

<a href="<a href="<a

ID Bus

This construct is for use of the ID Bus (when not required by an <alu_op>) and for loading the PSR:

IR

This construct specifies an IR (R Bus) source for the IR_SIGN test:

```
IR == <IR_src>
<IR_src> ::= See "<alu_src>," above.
```

FPU Operations

FD Bus

```
<FR_src> ::=
```

```
ROUND_BIT
A( <FPU_reg> ) [ WITH_DGD ]
SELECTED_A( <FPU_reg>, <FPU_reg> )
DPR
MULTIPLIER
```

FR:RB FR:FA,IA,[FRG:IDV] FR:FA,IA,IB FR:DR FR:MP

<fop> ::=

```
+ FOP:TAD
- FOP:TSB
@+ FOP:ADD
@- FOP:SUB
```

<FS_src> ::=

ZERO
B(<FPU_reg>)
PRESCALED_WR
WR_RIGHT
NORMALIZED_WR
WR_LEFT

FS:ZR FS:FB,IB FS:RS FS:RS FS:LS FS:LS

Note:

<FPU_reg> is a mnemonic specifying one of 16 FPU registers (see "Floating-Point ALU Micro-orders" in Chapter 3).

FA and FB Buses

These constructs source FA and FB from the register file without sourcing on FR and FS:

- 1. $FA == A(\langle FPU_reg \rangle)$ (IA)
- 2. $FB == B(\langle FPU_reg \rangle)$ (IB)
- 3. FPU_B_SELECT_DURING_SECOND_HALF == B(< FP_reg>) (FCW) (This construct selects FB data during division cycles.)

Note:

<FPU_reg> is a mnemonic specifying one of 16 FPU registers (see "Floating-Point ALU Micro-orders" in Chapter 3).

FA and FB Buses

WR = =

```
PRESCALE_OPERAND
QUOTIENT
A ( <FPU_reg> )
B ( <FPU_reg> )
ZERO

FWR:R, RM:FL, FLT:SCNT:CMP
FWR:Q, FRG:LWD
FWR:R, FR:FA, IA
FWR:S, FS:FB, IB
FWR:S, FS:ZER
```

Notes:

Loading WR from FD is specified with the FD = WR == construct defined for <FPU_op>'s.

<FPU_reg> is a mnemonic specifying one of 16 FPU registers (see "Floating-Point ALU Micro-orders" in Chapter 3).

Sign and Exponent Control

SIGN ==

A_SIGN FA0 NEG_FA0 ZERO A_XOR_B	FLT:SGN:{SA LAB TRN TRI} FLT:SGN:MOV FLT:SGN:NEG FLT:SGN:ZER FLT:SGN:XOR	

LOAD_SIGNS

```
FLT:SGN:{LAB TRN TRI}
```

EXPONENT ==

EWR	FLT:EXP:N
EWK	LDI.EVL.N
FA	FLT:EXP:LAX
EWR-64	FLT:EXP:S64,FX:X64
EWR+64	FLT:EXP:A64,FX:X64
EWR-MAG	FLT:EXP:SNM
FA-FB	FLT:EXP:SUB
EWR+MOF	FLT:EXP:ACW
FA+MOF	FLT:EXP:ACA
EWR+MAG+MOF	FLT:EXP:ACN
FA+FB	FLT:EXP:ADD

Shift Count

SHIFT_MAG ==

EXPONENT
PRESCALE_COMPARE
FIRST_NIBBLE_ZERO_DETECT
LEADING_ZERO_DETECT
DIVIDE_PRESCALE_DETECT
CNST (<literal>)

FLT:SCNT:LEF
FLT:SCNT:CMP
FLT:SCNT:FNZ
FLT:SCNT:LZD
FLT:SCNT:DVP
FLT:SCNT:LCN, IY:<literal>

Note:

teral> is a hex number (0-F). Use a positive value for a right shift, or a twos
complement value for a left shift. For example: E= right-shift 14 digits, or left-shift 2 digits.
Use the symbols R0 through R15 and L0 through L15 to specify the literal.

ALLOW_SHIFT_MAG_CORRECTION

FLT:SCNT:LZD

ENABLE_MOF_CORRECTION

FLT:SCNT:LZD

Multiply Control

```
X == A(\langle FPU\_reg \rangle), Y == B(\langle FPU\_reg \rangle), Y\_SELECT == \{0 \text{ to } 7\}
```

FRG:LXY, FR:FA, IA, FS:FB, IB, IY:<Y_select>

 $Y == B(\langle FPU_reg \rangle), Y_SELECT == \{0 \text{ to } 7\}$

FRG:LY, FS:FB, IB, IY:<Y_select>

Notes:

<Y_select> is a hex number (0-7) specifying one of eight bytes of the Y operand. Y_SELECT = 0 gives the most significant byte of Y.

Multiply Control

The above two constructs must be coded in the order shown.

<FPU_reg> is a mnemonic specifying one of 16 FPU registers (see "Floating-Point ALU Micro-orders" in Chapter 3).

STEP_MULTIPLY_PIPE

FRG:LWM

FPU State

UPDATE_FPSR

FRG:UFS

RESTORE_STATE_WITH A(<FPU_reg>)

FRG:LST, IA, FLT:SCNT:RST

Note:

<FPU_reg> is a mnemonic specifying one of 16 FPU registers (see "Floating-Point ALU Micro-orders" in Chapter 3).

Divide Control

DGD == FS_GUARD_DIGITS

FRG:LGD

GEN Randoms

ACSR (SRC Register Pointer) Randoms

INCREMENT_SRC_POINTER
DECREMENT_SRC_POINTER
POINT_SRC_TO_E

POINT_SRC_TO <register>

GEN:REG0:INCS GEN:REG0:DECS

GEN:REG0:{FRCS,FRSD}

GEN:REG0:{LDAS,LDSD},ID:CN,CNST:<reg>

Note:

<register> is a mnemonic specifying one of 16 registers.

ACDR (DES Register Pointer) Randoms

```
INCREMENT_DES_POINTER
DECREMENT_DES_POINTER
POINT_DES_TO_F
POINT_DES_TO <register>
GEN:REG0:INCD
GEN:REG0:DECD
GEN:REG0:{FRCD,FRSD}
GEN:REG0:{LDAD,LDSD},ID:CN,CNST:<reg>
```

Notes:

See the ALU (ID =) construct earlier in this chapter for loading SRC and DES from the ID Bus.

<register> is a hex number (0-F) or register mnemonic specifying one of 16 registers.

Flag Manipulation

These macros use the CNST field to specify flag manipulation.

```
<flg_tmod> ::=
```

N SET CLEAR TOGGLE AND OR XOR	AFLG:N AFLG:S AFLG:C AFLG:T AFLG:A AFLG:O AFLG:X
LOAD	AFLG:L

MODIFY_FLAGS_57_WITH_TEST (<flg_tmod>, <flg_tmod>)

GEN:REG0:AF57

Skips

SKIP ON <skp_condition>

<skp_condition> ::=

```
FIX:COVS:ALC
ALC_RESULT
                    GEN:REG0:SKFT
FALSE_TEST
                    GEN:REGO:WSKP, CNST:CRY
ALU_CRY=1
                    GEN:REG0:WSKP, CNST:NCRY
ALU_CRY=0
IS>≕IR
                    GEN:REG0:WSKP, CNST:CRY
                    GEN:REGO:WSKP, CNST:NCRY
IS<IR
SIGNED_IS>=IR
                    GEN:REGO:WSKP, CNST:SGE
                    GEN:REGO:WSKP, CNST:NSGE
SIGNED_IS<IR
                    GEN:REGO:WSKP, CNST:FZR
ALU≕0
                    GEN:REGO:WSKP, CNST:NFZR
ALU<>0
```

Miscellaneous Randoms (NPDR and XTND)

```
NO_LOAD_PDR {GEN:REG0,ATU:ATU0}:NPDR
```

EXTEND_MICRO_CYCLE {GEN:REG0, ATU:ATU0}:XTND

ATU Randoms

TURN_ATU_ON
TURN_ATU_OFF
SET_IFLUSH
RESET_8_REF_BITS*
ENABLE_INTERRUPTS
DISABLE_INTERRUPTS
DISABLE_INTERRUPTS_ONE_INSTRUCTION**
RESET_ESR
PURGE_THE_ATU_CACHE
DEFER_ON_FALSE_TEST
CPA ==OBJECT_PAGE_TABLE_ADDRESS
CPA ==LOW_ORDER_PAGE_TABLE_ADDRESS

ATU:ATU0:{AON, RSRF}
ATU:ATU0:AOFF
ATU:ATU0:IPFL
ATU:ATU0:RSRF
ATU:ATU0:ION
ATU:ATU0:IOFF
ATU:ATU0:DISI
ATU:ATU0:PRGA
ATU:ATU1:DF
ATU:ATU1:DF
ATU:ATU0:OPTA
ATU:ATU0:LPTA

Note:

- * This random forces data on top of CPD < 24-31 >.
- ** Do not code during IPOP.

FIX Randoms

CARRY_IN_IS_CARRY
CARRY == SIGN_OF(<IR_src>)
CARRY == ZERO
CARRY == ONE
CARRY == ALU_CRY
CARRY == ALC_CRY
CLEAR_OVR
UPDATE_OVR
CLEAR_OVK
SET_OVK
USE_16_BIT_TESTS

```
XC random mode: RM:FIX, CIB:C
FIX:COVS:LDCY
FIX:COVS:CLRC
FIX:COVS:SETC
FIX:COVS:{LCRY, LOVC}
FIX:COVS:ALC
FIX:COVS:COVR
FIX:COVS:LOVC
FIX:COVS:COVK
SET_OVK
FIX:LOAD:NA
```

<IR_src> ::= See "<alu_src>," above.

Next Address Sequence

Conditional Address Generation

```
<page_address>[
                             NAC: {CJMP CABT}
IF [NOT] <test-cond> GOTO
     POP_MICRO_STACK
                       NAC: CABT
                                  <page_address>
IF [NOT] <test_cond> <cnac_op>
<cnac_op> ::=
                                NAC:CJSR
CALL
                                NAC:CDSP,DSR:E
CASE_8_INTO
                                NAC:CDSP,DSR:F
CASE_4_INTO
                                NAC:CDSP,DSR:A
CASE_ATU_INTO
                                NAC: CRTN
RETURN_ELSE_GOTO
RETURN_ELSE_POP_AND_GOTO
                                NAC: TWB
                                NAC: CRST
RESTORE_ELSE_GOTO
```

Note:

for a listing of <test_cond>, see "Test Definitions", below.

Unconditional Address Generation

```
<unac_op> <full_address>
<unac_op> ::=
                           NAC:LEAP
GOTO
                           NAC:LSR
CALL
                           NAC:DSPA,DSR:E
CASE_8_INTO
                           NAC:DSPA,DSR:F
CASE_4_INTO
                           NAC:DSPA,DSR:A
CASE_ATU_INTO
                           NAC:DSPR,DSR:E
CALL_CASE_8_INTO
                           NAC:DSPR,DSR:F
CALL_CASE_4_INTO
                           NAC:DSPR,DSR:A
CALL_CASE_ATU_INTO
POP_AND_GOTO
                           NAC:LPOP
                           NAC: PUSH
PUSH
                           NAC: PCPD
PUSH_CPD_AND_GOTO
GOTO_TOS_AND_PUSH
                           NAC: TPSH
```

Note:

<full_address> is a symbolic address.

Pseudo-unconditional Address Generation

RETURN POP_MICRO_STACK RESTORE RESTORE_WITH_EVEN_PARITY

NAC:CRTN,TSEL:TRUE NAC:CABT,TSEL:FALSE NAC:CRST,TSEL:TRUE NAC:CRST,TSEL:TRUE, GEN:REG0:EPAR

Test Definitions

Microsequencer Tests

<u>Macro</u>	<u>TSEL Micro-order</u>
TRUE	TRUE
FALSE	NTRUE
CPD<31>=1 CPD<31>=0 MICRO_STACK_EMPTY INTERRUPT_PENDING IO_BUSY INSTRUCTION_READY	CPD31 NCPD31 USMT INTR IOB IVLD
XCTED_INSTRUCTION ROUNDING	XCTF RND
FLAG0=1	FLG0
FLAG0=0	NFLG0
FLAG1=1	FLG1
FLAG1=0	NFLG1
FLAG2=1	FLG2
FLAG2=0	NFLG2
FLAG3=1	FLG3
FLAG3=0	NFLG3
FLAG4=1	FLG4
FLAG4=0	NFLG4
FLAG5=1	FLG5
FLAG5=0	NFLG5
FLAG6=1	FLG6
FLAG6=0	NFLG6
FLAG7=1	FLG7
FLAG7=0	NFLG7

ALU Test Conditions

Macro	TSEL Micro-order
IY<28>=1	Y28
IY<28>=0	NY28
IY<29>=1	Y29
IY<29>=0	NY29
IY<30>=1	Y30
IY<30>=0	NY30
IY<31>=1	Y31
IY<31>=0	NY31
ID<31>=1	D31
ID<31>=0	ND31
ID_SIGN=1	DSGN
ID_SIGN=0	NDSGN
SRC=DES	COMP
SRC<>DES	NCOMP
INTERRUPT_RESUME	IRES
SIGN_OVERPUNCH_BYTE	COM2
DIGIT	COM2
LOW_NIBBLE_DIGIT	COM2
HIGH_NIBBLE_DIGIT	COM2
CHARACTER	COM1
SIGN LOW_NIBBLE_SIGN COMMERCIAL_SIGN	COM1 COM1
CPU_DEVICE	IOT
IO_SKIP	IOT
ION_FLAG_CHANGE	IOT
ALU<31>=1	F31
ALU<31>=0	NF31
ALU_NIBBLE_CRY=1	CRY28
ALU_NIBBLE_CRY=0	NCRY28
IR_SIGN=1	RSGN
IR_SIGN=0	NRSGN
IY<0>=1	У0
IY<0>=0	NY0
BYTE_COUNT+1=0	CNT8
BYTE_COUNT+1<>0	NCNT8
HEX_COUNT+1=0	CNT4
HEX_COUNT+1<>0	NCNT4
ALU_CRY=1	CRY
ALU_CRY=0	NCRY

The next seven tests assume that a twos-complement subtract has been performed on unsigned numbers during the previous cycle.

IS>=IR	CRY
IS <ir< td=""><td>NCRY</td></ir<>	NCRY
ALU_SIGN=1	FSGN
ALU_SIGN=0	NFSGN
OVERFLOW	OVF
ALU=0	FZR
ALU<>0	NFZR

The next four tests assume that a twos-complement subtract has been performed on signed numbers during the previous cycle.

SIGNED_IS>=IR	SGE
SIGNED_IS <ir< td=""><td>NSGE</td></ir<>	NSGE
CARRY=1	CRRY
CARRY=0	NCRRY

ATU Test Conditions

Macro	TSEL Micro-order
INDIRECT	INDR
RING=0	RNG0
RING<>0	NRNG0
INWARD_REFERENCE	RMAX
LA <esr< td=""><td>LESR</td></esr<>	LESR
LA>=ESR	NLESR
LA>CRE LA<=CRE LA=CRE LA<>CRE	GCRE NGCRE ECRE NECRE
LA <cre< td=""><td>LCRE</td></cre<>	LCRE
LA>=CRE	NLCRE
ATU_ON	ATON
ATU_OFF	NATON
CACHE_BLOCK_X ATU_PURGING VALID_PTE VALID_SBR	CBLK PRGB VPTE VSBR

Test Definitions

VALIDITY_BIT=1	ATD
VALIDITY_BIT=0	\mathtt{NVLD}
PC_REL_INDEX	IXPC

FPU Test Conditions

Macro	TSEL Micro-order
FR=FS	UAEB
FR<>FS	NUAEB
FR <fs< td=""><td>UALB</td></fs<>	UALB
FR>=FS	NUALB
SIGNED_FR=FS	SAEB
SIGNED_FR<>FS	NSAEB
SIGNED_FR>FS	SAGB
SIGNED_FR<=FS	NSAGB
SIGNED_FR <fs< td=""><td>SALB</td></fs<>	SALB
SIGNED_FR>=FS	NSALB
MANTISSA_CRY=1	FCRY
MANTISSA_CRY=0	NFCRY
EXPONENT_CRY=1 EXPONENT_CRY=0	ECRY NECRY
FF8=1	FF8
FF8=0	NFF8

Examples

This section contains an example of unassembled MV/10000 microcode macros and a number of examples of assembled microcode.

Unassembled Example

This example shows the unassembled instructions that produce a dispatch table. This is the same table that was used as an example in Chapter 4. The dispatch table will also appear among the assembled examples.

```
BIT INSTRUCTION DISPATCH TABLES
       WCOBTAB - Used by WCOB, COB
       % Dispatch table is based on the number of bits set (which is
       % added to DES).
       % AG: CPM <- DES <- DES + CONST; Load DSP REG;
       % ALU: CPD <- PDR <- RSHIFT(PDR); DES <- CPM
       % F bus <- PDR AND M1 for FZR test
       % Location 0 of dispatch table checks for completion of instruction
WCOBTAB: ATTEMPT_NEXT_EFA, IF ALU=0 RETURN_ELSE_GOTO WCOB1;
       AY = AG(DES) = ALU(DES) == CNST(01) + A(DES)
              IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),
                     ALU_TEST == A(M1) AND PDR,
                             CASE_4_INTO WCOBTAB;
       AY = AG(DES) = ALU(DES) == CNST(01) + A(DES)
              IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),
                     ALU_TEST == A(M1) AND PDR,
                             CASE_4_INTO WCOBTAB;
       AY = AG(DES) = ALU(DES) == CNST(02) + A(DES)
              IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),
                     ALU_TEST == A(M1) AND PDR,
                             CASE_4_INTO WCOBTAB;
       AY = AG(DES) = ALU(DES) == CNST(01) + A(DES),
              IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),
                     ALU\_TEST == A(M1) AND PDR,
                             CASE_4_INTO WCOBTAB;
       AY = AG(DES) = ALU(DES) == CNST(02) + A(DES),
              IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),
                     ALU_TEST == A(M1) AND PDR,
                             CASE_4_INTO WCOBTAB;
       AY = AG(DES) = ALU(DES) == CNST(02) + A(DES),
              IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),
                     ALU_TEST == A(M1) AND PDR,
                             CASE_4_INTO WCOBTAB;
```

```
AY = AG(DES) = ALU(DES) == CNST(03) + A(DES),
        IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),
                ALU_TEST == A(M1) AND PDR,
                        CASE_4_INTO WCOBTAB;
AY = AG(DES) = ALU(DES) == CNST(01) + A(DES),
        IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),
                ALU_TEST == A(M1) AND PDR,
                        CASE_4_INTO WCOBTAB;
AY = AG(DES) = ALU(DES) == CNST(02) + A(DES),
        IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),
                ALU_TEST == A(M1) AND PDR,
                        CASE_4_INTO WCOBTAB;
AY = AG(DES) = ALU(DES) == CNST(02) + A(DES),
        IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),
                ALU_TEST == A(M1) AND PDR,
                        CASE_4_INTO WCOBTAB;
AY = AG(DES) = ALU(DES) == CNST(03) + A(DES),
        IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),
                ALU_TEST == A(M1) AND PDR,
                        CASE_4_INTO WCOBTAB;
AY = AG(DES) = ALU(DES) == CNST(02) + A(DES),
        IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),
                ALU_TEST == A(M1) AND PDR,
                        CASE_4_INTO WCOBTAB;
AY = AG(DES) = ALU(DES) == CNST(03) + A(DES)
        IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),
                ALU_TEST == A(M1) AND PDR,
                        CASE_4_INTO WCOBTAB;
AY = AG(DES) = ALU(DES) == CNST(03) + A(DES),
        IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),
                ALU_TEST == A(M1) AND PDR,
                        CASE_4_INTO WCOBTAB;
AY = AG(DES) = ALU(DES) == CNST(04) + A(DES),
        IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),
                ALU\_TEST == A(M1) AND PDR,
                        CASE_4_INTO WCOBTAB;
```

Assembled Examples

The following examples show typical MV/10000 microcode in assembled form. The assembler commands precede the assembled microword in each case.

```
Proprietary information of Data General Corporation
    55B .EJECT;
56B .FT 1 "TABLES
                                Source File
                                                               Cvcle 1
                                                                             18-AUG-82 15:24:34 RGG"
   /*------
    64B*
65B
66B
    67B
                 ***********************
    69B
70B
71B
72B
                                 BIT INSTRUCTION DISPATCH TABLES
   73B
74B
75B
76B
77B
78B
79B
80B
                        WCOBTAB - Used by WCOB, COB
                % Dispatch table is based on the number of bits set (which is added to DES).
% AG: CPM <- DES <- DES + CONST; Load DSP REG;
% ALU: CPD <- PDR <- RSHIFT(PDR); DES <- CPM
% F bus <- PDR AND M1 for FZR test
 --DFVs:
         addr is WCOB1 (003B)
86B
--0001--
               DSPA
--DFVs:
91B
--0002--
         addr is WCOBTAB (0000)
         AY = AG(DES) = ALU(DES) == CNST(01) + A(DES),

IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),

ALU_TEST == A(M1) AND PDR,

CASE_4_INTO WCOSTAB;

OP TSEL ADDRESS D AA AB AG AGO AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X DSPA WCOSTAB F DES DES C ADD Y AG IY GN LD M1 DES PD DA AND HR0 M 01

R1
   93B
94B
95B
--DFVs: addr is WCOBTAB (0000)
96B
--0003-- AY = AG(DES) = A
               AY = AG(DES) = ALU(DES) == CNST(02) + A(DES),

IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),

ALU_TEST == A(M1) AND PDR,
   99B
                              SAMPLES
               Instruction Set Microcode Rev Source File Cycl
TABLES
```

```
Proprietary information of Data General Corporation
    12B
    13B*
14B*
15B*
                        External definitions for Widgeon microcode samples.
                       Some of the samples reference routines that, for the sake of brevity, are not worth including in the samples. The number of such references in the collection will be kept to a minimum.
    16B*
    17B*
18B*
    19B*
    20B*
    21B* +--
    22B
23B
                                    NSTK_OVERFLOW, WSTK_OVERFLOW,
          .EXTERNAL
    24B
                                    PROTECTION_FAULT,
PRIVILEGE_PROTECTION,
RESTARTABLE_INTERRUPT;
    25B
    28B
    29B
          .RADIX 16;
   SAMPLES
                           Instruction Set Microcode
                                                                         Rev 1
                                                                                                09-DEC-82 10:47:39 RGG
             00.10.00
                                                       0002 - 01
   UASM
```

```
Proprietary information of Data General Corporation
     30B .EJECT;
31B .FT 1 "SAMPLES
                                                                                                                                          18-AUG-82 15:24:34 RGG"
                                                                                                                 Cycle 1
                                                         Source File
     32B
33B
             ;
     3 4B
3 5B*
3 6B*
                             Widgeon Microcode Samples
      37B*
                             This collection of sample microcode is taken directly from Widgeon sources. Each selection is, as far as practical, the code for an entire macro instruction. Selections are presented in order of increasing complexity.
      38B*
     39B*
40B*
41B*
      42R*
      43B*
44B
45B
      45B*
     47B*
48B*
49B*
50B*
                             A note regarding style:
                             Having been drawn from the sources, the samples display a variety of documentation and coding styles. These variations are preserved mainly to minimize the task of compiling the samples.
      51B*
     52B*
53B*
     54B*
                                                                                                                09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
SAMPLES Instruction Source File UASM 00.10.00
                              Instruction Set Microcode
                                                                                      Rev
                                                                                      Cycle 1
                                                         0003 - 01
```

```
Proprietary information of Data General Corporation
     55B .EJECT;
56B .FT 1 "TABLES
                                                                                       Cycle 1
                                                                                                           18-AUG-82 15:24:34 RGG*
     58B
59B
                       Dispatch table for WCOB instruction, which appears in
                       an example below.
     62B*
     63B*
     65B
66B
                                              BIT INSTRUCTION DISPATCH TABLES
                                  WCOBTAB - Used by WCOB, COB
                       79B
    83B
84B % Location 0 of dispatch table checks for completion of instruction
--0000--WCOBTAB: ATTEMPT_NEXT_EFA, IF ALU=0 RETURN_ELSE_GOTO WCOBL;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CRTN FZR WCOB1 D EFA S8
--DFVs:
              addr is WCOB1 (003B)
                     -0001--
    88B
                                                                                                       R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X LD M1 DES PD DA AND HRO M 01
              DSPA
--DFVs:
91B
--0002-
              addr is WCOBTAB (0000)
             AY = AG(DES) = ALU(DES) == CNST(O1) + A(DES),
IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),
ALU_TEST == A(M1) AND PDR,
CASE_4_INTO WCOBTAB;

OP TSEL ADDRESS D AA AB AG AGD AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X DSPA WCOBTAB F DES DES C ADD Y AG IY GN LD M1 DES PD DA AND HRO M 01
R1
    93B
94B
--DFVs:
96B
--0003--
              addr is WCOBTAB (0000)
                      AY = AG(DES) = ALU(DES) == CNST(02) + A(DES),

IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),

ALU_TEST == A(M1) AND PDR,
    99B
SAMPLES Instruction Set Microcode Rev 1
TABLES Source File Cycle 1
UASM 00.10.00 0004 - 01
                                                                                       09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
```

```
Proprietary information of Data General Corporation
        Rl R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X LD M1 DES PD DA AND HR0 M 02 R1
        addr is WCOBTAB (0000)
  101B
        --0004--
        addr is WCOBTAB (0000)
106B
--0005--
        AY = AG(DES) = ALU(DES) == CNST(02) + A(DES),
IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),
ALU_TEST == A(M1) AND PDR,
CASE_4_INTO WCOBTAB;

OF TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X DSPA WCOBTAB F DES C ADD Y AG IY GN LD M1 DES PD DA AND HR0 M 02
R1
 110B
--DFVs:
111B
112B
--0006--
114B
115B
        addr is WCOBTAB (0000)
        116B
--DFVs:
117B
        addr is WCOBTAB (0000)
        -0007-
 119B
120B
--DFVs:
122B
--0008--
        addr is WCOBTAB (0000)
        124B
--DFVs:
127B
--0009--
        addr is WCOBTAB (0000)
             AY = AG(DES) = ALU(DES) == CNST(02) + A(DES),

IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),

ALU_TEST == A(M1) AND PDR,
SAMPLES Instruction Set Microcode Rev 1
TABLES Source File Cycle 1
UASM 00:10:00 0005 - 01
                                                      09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
```

```
Proprietary information of Data General Corporation
                     CASE_4_INTO WCOBTAB;

OP TSEL ADDRESS D AA AB AG AOF AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X DSPA WCOBTAB F DES C ADD Y AG IY GN LD M1 DES PD DA AND HR0 M 02
                     addr is WCOBTAB (0000)
                    --00004--
--DFVs: addr is WCOBTAB (0000)
                    -000B--
 --DFVs: addr is WCOBTAB (0000)
   142B
-000C--
                    144B
--DFVs:
147B
--000D--
                     addr is WCOBTAB (0000)
                    149B
150B
  -DFVs: addr is WCOBTAB (0000)
                    152B
--000E--
--DFVs: addr is WCOBTAB (0000)
157B
--000F--- AY = AG(DES) = AL
                   AY = AG(DES) = ALU(DES) == CNST(04) + A(DES),

IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),

ALU_TEST == A(M1) AND PDR,

        SAMPLES
        Instruction Set Microcode
        Rev 1
        09-DEC-82
        10:47:39 RGG
        RGG

        TABLES TABLES UASM
        Source File 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00 00:00
```

```
Proprietary information of Data General Corporation

161B

CASE_4_INTO WCOBTAB;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X DSPA WCOBTAB F DES DES C ADD Y AG IY GN LD M1 DES PD DA AND HRO M 04

--DFVs: addr is WCOBTAB (0000)

SAMPLES Instruction Set Microcode Rev 1 09-DEC-82 10:47:39 RGG
TABLES Source File Cycle 1 18-AUG-82 15:24:34 RGG
UASM 00.10.00 0007 - 01
```

```
Proprietary information of Data General Corporation
   162B .EJECT;
163B .FT 1 "MEM
                                                                                                                                       18-AUG-82 15:24:34 RGG"
                                                       Source File
                                                                                                              Cycle l
             ;
    166B
    167B*
                             Memory references for the next macro instruction can be started by the IP from decode information. In these two examples, the completion of an IP initiated memory reference is shown. The completion is generic, i.e. read or write. The start instigated by the IP specified the exact type of transfer to perform.
    168B*
169B*
170B*
    171B*
    174B*
                             Also shown here is the attempt of the next EFA on behalf of the next executing macro instruction. This attempt must be made in the last micro cycle of every macro instruction The combination of the attempt and popping an empty micro stack constitutes a macro instruction pop (IPOP).
    175B*
    176B*
177B*
    178B*
    179B*
    181B*
    182B
    183B
   184B
185B
                             186B
    187B
                                 Perform load or store of AC pointed to by DES. IPOP.
    188B
189B
 --0010--LWLDA:
--0010--LWLDA:

--0010--LWLDA:

--0010--LNLDA:

--0010--ELDA:

--0010--LDA:
                             CPM = AG(DES) = ALU(DES) == MEM_READ, ATTEMPT_NEXT_EFA, RETURN;
TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2 IA IB IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
TRUE DES D EFA M S0 R MM
                 OP
CRTN
--DFVs:
196B
--0011--LWSTA:
--0011--XWSTA:
--0011--LNSTA:
--0011--XNSTA:
--0011--ESTA:
--0011--STA:
OP
                             CPM = MEM_WRITE == ALU(DES), ATTEMPT_NEXT_EFA, RETURN;
TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
TRUE D EFA S W IA DESA
                  CRTN
   -DFVs:
203B
204B
205B
                              % Jump Instructions: WBR, LJMP, XJMP, EJMP %
    206B
207B
                              % Complete IPST. Go to IP_ALT WAIT. %*******
    208B
    209B
    210B
                                                                                                               09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
SAMPLES
                             Instruction Set Microcode
                                                                                    Rev
 MEM
                             Source File
                                                                                   Cycle 1
            00.10.00
                                                               0008 - 01
```

```
Proprietary information of Data General Corporation
--0012--LJMP:
--0012--XJMP:
--0012--EJMP:
                 COMPLETE_JUMP, GOTO WAIT;
TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X WAIT
--0012--JMP:
--DFVs:
          addr is WAIT (OFFF)
  216B
217B
218B
  219B
                  § Jump Subroutine Instructions: <L X E >JSR
                  % Read PCN (Return PC) into PDR; Complete IPST.
  220B
221B
222B
223B
                  % Move PDR to AC3, AG3; and IPOP.
223B
224B
225B
226B
--0013--LJSR:
--0013--XJSR:
--0013--EJSR:
--0013--EU-
--0013--JSR:
          SR: COMPLETE_JUMP, PDR == RETURN_PC;
OP TSEL ADDRESS DAA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CJMP FALSE W PCN
--DFVs:
231B
--0014--
          233B
                                                                                                                    IL FR FS FOP W FCW FL FRG X
                                                                                          M1 AC3 PD AD AND PASS Y
--DFVs:
  •
                                                                    09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
SAMPLES
                  Instruction Set Microcode
                                                   Rev 1
Cycle 1
         Source File
00.10.00 0009 - 01
HASM
```

```
Proprietary information of Data General Corporation
   Cycle 1 18-AUG-82 15:24:34 RGG"
                      Some Nova ALC instructions illustrate the use of the ALU for simple arithmetic. The shift operation is used along with the ALC opcode to provide the decode address. Carry, no-load and skip options are accelerated with hardware.
    243B* |
244B* |
245B* +---
    246B
247B
248B
249B
250B
                       % NOVA Arithmetic and Logical Instructions
    251B
252B
                                                                   l cycle no skip
2 cycles skip, no EFA required
    253B
                       %
Perform ALU operation; then Pass, Shift, or Swap; Write result to AG
% and ALU AC pointed to by DES. Enable ALC skip and IPOP.
%********
    254B
  254B
255B
256B
257B
-0015--ADD:
             DD: IY = AG(DES) = ALU(DES) == B(DES) + A(SRC),

CARRY == ALC_CRY, SKIP_ON ALC_RESULT,

ATTEMPT_NEXT_EFA, RETURN;

OP TSEL ADDRESS DAA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X

CRTN TRUE DES D EFA M S@ IY XZ ALC SRC DES BR AD ADD PASS Y
   259B
 --DFVs:
261B
--0016--INC:
              NC: IY = AG(DES) = ALU(DES) == ZERO +1+ A(SRC),
CARRY == ALC_CRY, SKIP_ON ALC_RESULT,
ATTEMPT_NEXT_EFA, RETURN;
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CRIN TRUE DES D EFA M S0 IY XZ ALC SRC DES ZR AD CAD PASS Y
   263B
264B
SAMPLES
09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
```

```
Proprietary information of Data General Corporation
    270B .EJECT;
271B .FT 1 "IMMEDIATE
                                                                                                                        18-AUG-82 15:24:34 RGG"
                                                Source File
                                                                                                 Cycle 1
   272B ;
   A Load Effective Address instruction is nothing more than an aborted memory reference. The final contents of the Logical Address Register are loaded, via the CPD bus and ALU, into the required registers.
    278B*
279B*
    280B*
                         The architecture specifies that the effective address is checked for a ring crossing error. This check will not be performed by hardware because the memory operation used to generate the address is aborted. A micro test is used to check validity.
    281B*
   282B*
283B*
284B*
285B*
    286B*
287B*
                         This example also shows the use of a conditional IPOP. A memory abort operation is recommended following the failure of a conditional IPOP.
    288B*
289B*
    290B*
    292B
   293B
   294B
                          Load Effective Address: LEF, ELEF, XLEF, LLEF

Load LAR into the AG and ALU DES registers. Abort Memory. If RMAX is
   295B
296B
   297B
                          % violated, then go to the RMAX Protection routine, else IPOP.
% Load the RMAX fault code into GRO and faulting address into
% ARS and go to the Protection routine.
%
   298B
   299B
300B
    301B
    302B
--0018--LLEF:
--0018--XLEF:
--0018--ELEF:
                          IY = AG(DES) = ALU(DES) == SPAD(BITO) NOT_AND LAR,
                EP: IY = AG(DES) = ALU(DES) == SPAD(BITU) NOT_AND LAK,

EXTEND_MICRO_CYCLE,

ATTEMPT_NEXT_EFA, ABORT_MEMORY,

IF NOT INWARD_REFERENCE RETURN_ELSE_GOTO RMAX_PROTECTION;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X

CRIN NRMAX RMAX_PRO DES D EFA M S@ A IY LAR GN XTND DES SC CD ANC PASS Y BITO
   307B
308B
   309B
 --DFVs: addr is RMAX_PROTECTION (0019) const is BITO (0000)
Instruction Set Microcode
                                                                                                  09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
             Source File 00.10.00
                                             0011 - 01
 IMMEDIATE
UASM
```

```
Proprietary information of Data General Corporation
    317B
    318B*
                       Instructions which load immediate data from the instruction stream use an approach similar to the LEF instructions. In their case, the immediate data has been loaded into the LAR by the IP as specified by decode information, but no memory reference has been initiated.
    319B* |
320B* |
    321B*
    322B*
323B*
    324B*
    325B*
    326B
327B
328B
            % Long Add Immediates: <W N >ADDI
% DES + (Displacement) -> DES (Displacement is in LAR)
% The W and N types load overflow into OVR and CRY<0 16> into CARRY.
    329B
    330B
331B
    331B % 332B %******
   -001A--ADDI: IY = ALU(DES) = AG(DES) == B(DES) + LAR, ATTEMPT_NEXT_EFA, RETURN;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X

CRTN TRUE DES D EFA M SØ IY LAR DES BR CD ADD PASS Y
--DFVs:
335B
341B
342B
            TE Source File Cycle 1 09-DEC-82 10:47:39 RGG 00:10:00 0012 - 01
 IMMEDIATE
```

```
Proprietary information of Data General Corporation
        343B /*
344B* |
345B* |
346B* |
                                       A short immediate field is derived from the source accumulator bit field of the macro instruction. Actual values are 0 through 3, but implied values are 1 through 4. The following instructions read an operand from a memory location, subtract the implied immediate data from it, and store the result back in the same memory location.
          349B*
          350B*
          351B*
          3 5 3 B
         354B
         355B &******
                           % Short Subtract Immediate from Memory: <L X><W N >SBI
        --DFVs:
                                  addr is XLSBI (001E)
 --001D--XNSBI:
--001D--XNSBI:
--001D--LNSBI: CPM = ALU(GR0) == MEM_READ,
370B
371B
OP
LEAP

OP
LEAP
    -DFVs: addr is XLSBI (001E)
                        -XLSBI: IY = MEM_WRITE == A(GR0) -1- SRC_POINTER,
CARRY == ALU_CRY, UPDATE_OVR,
ATTEMPT_NEXT_EFA, RETURN;
OP TSEL ADDRESS DAA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CRTN TRUE

D EFA S@ W IY XZ LOVC GR0 AS DA SMR FASS
  --001E-
 --DFVs:
          •
        ٠
  SAMPLES
                           Instruction Set Microcode Rev 1
TE Source File Cycle 1
00.10.00 0013 - 01
                                                                                                                                                                                               09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
  IMMEDIATE
```

```
Proprietary information of Data General Corporation
   376B .EJECT;
377B .FT 1 "BYTE
                                                                                                                             Cycle 1 18-AUG-82 15:24:34 RGG"
                                                             Source File
    380B
    381B*
                                These selections from the byte microcode show the use of a conditional subroutine call, a memory start using the address generator, and a memory abort. A copy of the PC of execution + 1 is moved to the address generator by first loading PCX into PDR, and then subtracting -1 from it and loading the result in the AG register file via the CPM bus.
    382B*
383B*
    384B*
    385B*
               388B*
     389B*
    390B
391B
392B
     393B
     394B
     395B
396B
                                EFA calculations for a Byte address cannot be completely performed by the hardware. The PC relative index case cannot be performed since the Displacement is a byte address and the PC is a word address. The AG converts the byte displacement and performs the other indexing.
     397B
     398B
     399B
400B
     401B
     402B
     403B
404B
405B
                                                            Subroutines to perform READ/WRITE PC Relative Byte Addresses
     406B
     407B
408B
409B
                                                PC Relative Addressing must be handled separately since the IP cannot align a Byte displacement.
     410B
                                % Abort the previous start and move the PC of the instruction
plus 1 (PC of the DISP) to the AG (ARO).
Form the PC relative address by adding the Displacement (LAST_LA)
to the PC (ARO) and start for the Byte Read/Write. Word
addressing must be forced since the addresses have already
been aligned to word addresses. Return to the caller.
     411B
412B
413B
     414B
     419B
     001F--READ_PC_BYTE:
                     OP TSEL ADDRESS DAA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X CJMP FALSE ARO M A IY M1 PD AD CSR PASS
 --DFVs:
422B
--0020--
                              START AY == LAST_LA + A(ARO) WITH_WORD_ADDRESSING FOR READ_BYTE,
RETURN;
TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
TRUE ARO L ADD RB AT WORD
     424B
 --DFVs:
425B
                                                                                                                              09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
            ES Instruction Set Microcode Rev 1
Source File Cycle 1
00.10.00 0014 - 01
 SAMPLES
```

```
Proprietary information of Data General Corporation
--DFVs:
429B
--0022--
    --DFVs:
 -0023--WLDB:
--U023--WIDB: START AY == PASS(B(SRC)) FOR READ_BYTE, GOTO LDA;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X

LEAP LDA SRC B PSB RB
addr is LDA (0010)
-DFVs:
460B
461B
   Instruction Set Microcode Rev
Source File Cvole
SAMPLES
               Rev 1
Cycle 1
                          09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
```

```
Proprietary information of Data General Corporation
  462B .EJECT;
463B .FT 1 "XCT
                                                                Cycle 1 18-AUG-82 15:24:34 RGG"
                                Source File
  The code for the XCT instruction address SPAD with a constant, uses the flags to control sequencing and does a word zero extend with the hex shifter.
  471B*
  474B
475B
  476B*
477B*
478B*
                         XCT Execute an AC's contents
             DES contains the opcode to be executed
  480B*
  4818* +----
  482B
483B %
                Enter here for ordinary XCT. If restarting or resuming, XCTed opcode must still be in DES. Bit 0 of double word saved in SPAD is cleared to indicate to interrupt handlers that saving XCT opcode on wide stack is not required. Start execute.
 484B %
485B %
486B %
487B
--DFVs: addr is & (0027)
          ID == SPAD(XCTOP), IF NOT XCTED_INSTRUCTION GOTO NORMAL_XCT;
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X CJMP NXCTF NORMAL_X
--DFVs:
492B
493B
494B
495B
         addr is NORMAL_XCT (0029) const is XCTOP (00C3)
            % If XCT was executed by a PBX, then the XCT should set Bit0 of
% XCTOP since it was virtually executed by the PBX.
          IF ID_SIGN=1 GOTO EXECUTE_PBX;
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X CJMP DSGN EXECUTE_
--DFVs: addr is EXECUTE_PBX (002D)
500B
501B %
502B
                Send instruction to the IP via the Cache.
```

```
Proprietary information of Data General Corporation
            MODIFY_FLAGS_4567( CLEAR, N, N, N ),
GOTO XCT_WAIT1;
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO RL R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
LEAP XCT_WAIT A IA GN MFS1 DES
 --DFVs: addr is XCT_WAIT1 (002B)
   506B
507B %
                    Wait 4 cycles before IPOPing.
   T N N N
 --DFVs: addr is XCT_WAIT1 (002B)
   511B
511B
--002C--XCT_WAIT2: MODIFY_FLAGS_4567( TOGGLE, N, N, N ), ATTEMPT_NEXT_EFA,
513B
IF FLAG4=1 RETURN_ELSE_GOTO XCT_WAIT2;
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CRTN FLG4 XCT_WAIT D EFA S0 GN MFS1
T N N N
  -DFVs: addr is XCT_WAIT2 (002C)
514B
515B
516B
517B % Enter here from PB)
518B % placed in DES. Mus
519B % interrupt handlers
520B % Push address for re
                     Enter here from PBX or BKPT after PBX detected. Opcode was placed in DES. Must set bit 0 before saving in SPAD to tell interrupt handlers to save opcode on wide stack. Start execute Push address for return from WAIT.
   521B
  521B
-002D--EXECUTE_PBX:
523B IY = ALU(GR5) == SPAD(BIT0) OR A(DES), START_EXECUTE;
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CJMP FALSE AGO AGO B SUB WW AT CMO DES GR5 SC AD OR PASS Y BITO
  -DFVs: const is BIT0 (0000)
   524B
525B %
                     Save executed opcode in SPAD. Send instruction to IP.
            --DFVs: const is XCTOP (00C3)
           MODIFY_FLAGS_4567( SET, N, N, N ), GOTO XCT_WAIT1;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X

LEAP XCT_WAIT S N N N
--DFVs: addr is XCT_WAIT1 (002B)
        S Instruction Set Microcode Rev 1
Source File Cycle 1
SAMPLES
                                                                                09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
```

```
Proprietary information of Data General Corporation
  531B .EJECT;
532B .FT 1 "BIT
533B ;
534B
  18-AUG-82 15:24:34 RGG"
                      This selection from the bit microcode provides varied examples of the use of the ALU hardware. Also, this code does a read-modify-write memory operation. Note the start for a write, and the subsequent read and write
   539B*
   540B*
541B*
542B*
                       completions.
                      The subroutine WBITW is used to resolve indirection chains. It requires three cycles per defer level because the word pointer of the bit address is indirectable, while the final bit address is formed by adding the bit offset to the resolved word pointer.
   543B*
   544B*
545B*
546B*
   547B*
                       resolved word pointer.
   549B*
549B*
550B
551B
   552B
   5 5 3 B
5 5 4 B
5 5 5 B
                               WSZBO - Wide Skip on Zero Bit and set bit to One
   556B
557B
558B
559B
                              5 cycles minimum
+ 3 cycles for each level of indirection
                      % Skip if SRC=DES, ARO <- RSHIFT(DES), D bus <- SRC
   560B
  560B IV = AG(ARO) == HEX_SHIFT_RIGHT(R1, A(DES)),
563B SPAR == BIT16,
             FAR = 51116,

IF SRC=DES GOTO WSZBOBIT;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X CJMP COMP WSZBOBIT ARO M IY GN SPCN LS DES SRC BR AD HRO BIT16

R1
   564B
--DFVs: addr is WSZBOBIT (0035) const is BIT16 (0010)
  565B
566B
567B
-0031-
                       % Call WBITW if indirect, LA(WW) <- SRC+ARO, GR1 <- DES AND OF
             START AY == B(AR0) + A(SRC) FOR WRITE_WORD,
IY = SPAR_TABLE_OFFSET == B(M1) AND A(DES),
IF ID_SIGN=1 CALL WBITW;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CJSR DSGN WBITW SRC AR0 B ADD WW GN SPY4 LS DES M1 BR AD AND PASS
   569B
  570B
--DFVs: addr is WBITW (0036)
  --DFVs:
SAMPLES
                                            Cycle 1
BIT
                       Source File
BIT 00.10.00
```

```
Proprietary information of Data General Corporation
    577B
                     % Set WORD(BIT#)=1, Note, an unmodified copy exists in GRO for testing.
             --0033--
   -DFVs:
   580B
581B
                     % Macro skip if WORD(BIT#)=0 (GR0 * SPAD(SPAR)=0), else IPOP
    582B
                     ATTEMPT_NEXT_EFA,
IY == A(GR0) AND TREG,
SKIP_ON ALU=0,
   -0034-
   584B
585B
586B
                     RETURN;
             RETURN;
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CRIN TRUE D EPA S@ TRG GN WSKP GRO CA AND PASS
   587B
588B
                     % LA(RW) <- ARO, append CRE, GR1 <- DES AND OF
   589B
-0035-
           WSZBOBIT: START AY == PASS(B(ARO)) IN_CURRENT_RING FOR WRITE_WORD,
IY = SPAR_TABLE_OFFSET == B(M1) AND A(DES),
GOTO WSZBONRM;
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
LEAP WSZBONRM ARO B PSB WW GN SPY4 AC LS DES M1 BR AD AND PASS
   591B
   592B
 --DFVs:
             addr is WSZBONRM (0032)
   593B
594B
595B
                     596B
597B
598B
599B
                     % WBITW - RESOLVES WIDE BIT INDIRECTION (MEMORY WRITE)
   600B
    601B
                     % Used by WBTO, WBTZ, WSZBO
                     % AR1 <- SRC (First time only), LA(RD) <- AR1, Abort assumed WW
% Use defer random to be sure indirection does not exceed 15 levels.</pre>
   604B
   605B
   0036--WBITW: START AY = AG(AR1) == CNST(0) + A(SRC) FOR READ_DOUBLE,

607B ABORT_MEMORY,

608B DEFER_ON_FALSE_TEST,
            ABORT_MEMORY,
DEFER_ON_FALSE_TEST,
GOTO WBITW2;
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
LEAP WBITW2 SRC AR1 C ADD Y RD A AT DF 00
   609B
--DFVs:
610B
611B
           addr is WBITW2 (0038)
                    % Continue resolving indirection, LA(RD) <- AR1% Abort WW
612B
--0037--WBITW1: START AY == PASS(B(AR1)) FOR READ_DOUBLE,
614B ABORT_MEMORY,
Instruction Set Microcode Rev 1 Source File UASM 00.10.00 0019 - 01
                                                                             09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
```

```
Proprietary information of Data General Corporation
            DEFER_ON_FALSE_TEST;
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X CJMP FALSE AR1 B PSB RD A AT DF
  615B
--DFVs:
616B
                    % AR1 <- CPM
-0038--WBITW2: CPM = AG(AR1) == MEM_READ;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X

CJMP FALSE AR1 M R MM
--DFVs:
  620B
  621B
622B
                    % Return if no indirection, LA(WW) <- AR1+AR0
                  START AY == B(AR0) + A(AR1) FOR WRITE_WORD,
IF NOT INDIRECT RETURN FIRE COME.
 -0039--
            IF NOT INDIRECT RETURN_ELSE_GOTO WBITWI;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO Rl R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X CRIN NINDR WBITWI ARI ARO B ADD WW
  624B
--DFVs:
           addr is WBITW1 (0037)
  625B
626B
   •
SAMPLES Instruction Set Microcode Rev 1 09-DEC-82 10:47:39 RGG BIT Cycle 1 18-AUG-82 15:24:34 RGG UASM 00.10.00 0020 - 01
```

```
Proprietary information of Data General Corporation
   628B* |
629B* |
                       Wide Count Bits uses a dispatch table to accelerate counting the number of bits in an accumulator which are set.
   630B* I
   631B*
632B*
633B*
   634B
635B
                      %
%
%
%
%
%
Used by COB
%
3 cycles minimum (all zeroes)
18 cycles maximum
%
%
Times:
%
2 cycles setup
% + 2 cycles if nybble = 00 Repeat until remaining
% or 1 cycle if nybble <> 00 result = 0 (by shifting)
   638B
   639B
   640B
641B
642B
   643B
644B
   6 45B
6 46B
6 4/B
   648B
   649B
650B
651B
                      % AG: CPD<- SRC, Load DSP REG, ALU: PDR <- CPD
   652B
             COB: PDR = CASE_DATA == AG(SRC);
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CJMP FALSE SRC AGA GN LD
  -003A--WCOB:
--DFVs:
654B
655B
656B
                       % AG: CPM <- DES <- DES + CONST, Load DSP REG
% ALU: CPD <- PDR <- RSHIFT(PDR), DES <- CPM
% F bus <- PDR AND M1 for FZR test
% Continue dispatching.
 --DFVs: addr is WCOBTAB (0000) 664B
SAMPLES Instruction Set Microcode Rev 1 Source File O021 - 01 Cycle 1 UASM 00.10.00
                                                                                09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
```

```
Proprietary information of Data General Corporation
   665B .EJECT;
666B .FT 1 "STACK
                                                                                                             Cycle 1
                                                                                                                                      18-AUG-82 15:24:34 RGG"
                                                      Source File
    667B
    668B
669B /*-
670B* |
671B* |
                            These two examples are corresponding narrow and wide stack operations. The narrow stack operation must first read the stack parameters from memory. The wide stack parameters for the current ring are in dedicated ALU and AG
    672B*
673B*
674B*
    675B*
                             register file locations.
    676B*
677B*
678B*
                             In order to read its stack parameters, the narrow stack
                            operation starts memory using an address generated from the constant field. Because the Logical Address bus is forced to narrow conditions wiring the narrow stack instruction, bits 1-3 of the address are forced to the value of CRE.
    679B*
    680B*
    681B*
682B*
683B*
                             Both samples illustrate the use of the SRC and DES pointers to address a range of accumulators in a loop. \,
    684B*
    686B*
687B*
    688B
   688B
689B
690B
691B*
692B*
                            Push Multiple Accumulators
   693B*
694B*
695B*
                            PSH
                                       acs,acd
    696B*
697B
                 SH: START AY == PASS (CNST(NSP)) FOR READ_WORD;
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CJMP FALSE C PSB RW NSP
               const is NSP (0020)
   700B
700B
701B
703D--
                             %NSP-->ARO
                 CPM = AG(ARO) == MEM_READ,
START AY == PASS (CNST(NSL)) FOR READ_WORD;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X CJMP FALSE ARO C FSB M RW R MM

NSL

NSL
--DFVs: const is NSL (0022)
704B
705B %NSL-->GRI
                         %NSL-->GR1
   706B
-003E--
708B
709B
                 CPM = ALU(GR1) == MEM_READ,
START AY = AG(AR0) == B(AR0) + A(ONE) FOR WRITE_WORD,
DECREMENT_DES_POINTER, IF SRC<>DES CALL PSHL;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CJSR NCOMP PSHL ONE AR0 B ADD Y WW R MM GN DECD GR1 R2 IA IB ID RS IOP IY M

W
--DFVs: addr is PSHL (0041) 710B
                                                                                                             09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
SAMPLES
                             Instruction Set Microcode Rev 1
                                                     Cycle 1
STACK Source File UASM 00.10.00
```

```
Proprietary information of Data General Corporation
              %NSL-TOP OF STACK-->TEST
  712B
addr is NSTK_OVERFLOW (0000 *EXT*)
--DFVs:
 719B
720B
721B
             %DONE? ARO+1-->ARO,LAR,WW SRC-->CPM [ACS]+1-->[ACS]
 --DFVs:
        addr is PSHL (0041)
  727B %****
  728B % Wide Push Accumulators: WPSH 729B %
  729B
730B
731B
732B
      Start a write for the push.

Write the Accumlator to the new TOS, and start a write for the next one.

Generate a test for overflow: SL - SP. Increment the SRC pointer and compare it to the DBS pointer for termination of the loop.

Update the SP from PDR and abort the pending write. IPOP if no overflow occurred, else service the overflow.
736B %*****
--0042--WPSH: START AY = AG(SP) == CNST(2) + A(SP) FOR WRITE_DOUBLE;
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CJMP FALSE SP SP C ADD Y WD 02
--DFVs:
738B
--DFVs: addr is WPSH_LOOP (0043)
744B
--0044--WPSHT: IY = AG(SP) == PDR AND A(M1), ABORT_MEMORY, ATTEMPT_NEXT_EFA,
              Instruction Set Microcode Rev 1
Source File Cycle 1
                                                     09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
SAMPLES
STACK Source File UASM 00.10.00
```

```
Proprietary information of Data General Corporation
    747B .EJECT;
748B .FT 1 "PRIV
    747B .F
748B .F
749B ;
750B
751B /*
752B* |
753B* |
                                                                                                                    Cycle 1
                                                         Source File
                              Privileged instructions are those which can be executed only while the PC is in ring 0. Microcode for these
                              only while the PC is in ring 0. Microcode for these instructions must confirm this by testing for CRE = 0.
    754B*
755B*
    756B*
757B*
758B*
                              This code restarts the IP at the next instruction to be executed. Specifying WIDE_JUMP will result in a double word being fetched for the IP start, while specifying NARROW_JUMP (or simply JUMP) will cause a single word to fetched. This is not to be confused with the width of the address bus. Rather, these will result in a wide or narrow defer chain being resolved should indirection be specified.
    759B*
     760B*
     762B*
    763B*
    764B*
765B*
    766B
767B
    768B
    769B*
770B*
                                                   PURGE THE ATU: PATU
    771B*
    772B*
    773B*
774B*
    775B
-0045--PATU:
                  % Take a Privilege Protection Fault if not in Ring 0.

IF RING<>0 GOTO PRIVILEGE_PROTECTION;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X CJMP NRNG0 PRIVILEG
  -DFVs:
               addr is PRIVILEGE_PROTECTION (0003 *EXT*)
    780B
781B
                                     % Make sure a clean set of Validity bits are availble... % also set CRE bits to zero for LSBRA \,
783B
--0046--PATUW: IF ATU_PURGING GOTO PATUW, PDR == PC,
785B AY = CRE == B(AR3) - A(AR3);
OP TSEL ADDRESS D AA AB AG AGP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CJMP PRGB PATUW AR3 AR3 B SUB PC AT LCRE
--DFVs:
786B
787B
                  addr is PATUW (0046)
                  * ... then swap in the clean Validity bits.

PURCE_THE_ATU_CACHE, IY = AG(ARO) == A(M1) AND PDR;

OP TSEL ADDRESS DA AB AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X CJMP FALSE ARO M IY AT PRGA M1 PD DA AND PASS
--0047--
  -DFVs:
   789B
790B
                                      % Restart the IP since Logical memory has been changed.
SAMPLES
                              Instruction Set Microcode Rev 1
Source File Cycle 1
0025 - 01
                                                                                                                   09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
PRIV
UASM 00.10.00
```

```
Proprietary information of Data General Corporation

--0048-- START AY = PC == PASS (B(ARO)) FOR WIDE_JUMP, GOTO JMP;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X

--DFVs: addr is JMP (0012)

•
•
•
•
•
SAMPLES Instruction Set Microcode Rev 1 09-DEC-82 10:47:39 RGG
PRIV Source File Cycle 1 18-AUG-82 15:24:34 RGG
```

```
Proprietary information of Data General Corporation
  LFLDS fpac,[@]displacement[,index]
XFLDS fpac,[@]displacement[,index]
FLDS fpac,[@]displacement[,index]
  822B* |
823B* |
824B* |
825B* +---
                 Requires 1 cycle.
  826B
827B %
                     Read a double word from memory and place it in the high order half of the destination FPAC. Update the FPSR. Return.
  828B %
829B %
830B
  -0049--LFLDS:
--0049--XFLDS:
--0049--FLDS:
834B
             835B
                                                                 S@R MM FL
                                                                                               LAX DES
                                                                                                                                                                DES MH UFS
 -DFVs:
836B
  839B* |
839B* |
840B* |
841B* |
842B* |
843B* |
844B* |
                    Load Floating Point Double
                    LFLDD fpac,[@]displacement[,index]
KFLDD fpac,[@]displacement[,index]
fpac,[@]displacement[,index]
  849B
850B %
851B %
                     Read a double word from memory and place it in the high order half of the destination FPAC. Update the FPSR. Start memory for a read of the next double word.
  852B %
--004A--LFLDD:
--004A--XFLDD:
--004A--FLDD:
            FLDD:
CPM = FP_HIGH(DES) == MEM_READ,
EXPONENT == FA, FA == A(DES), UPDATE_FPSR,
START AY == LAST_LA + A(TWO) FOR READ_DOUBLE;
OP TSEL ADDRESS D AA AB AG AGOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CJMP FALSE TWO L ADD RD R MM FL
  857B
                                                                                                 LAX DES
--DFVs:
  859B
860B %
861B %
862B
                     Read a double word from memory and place it in the low order half of the destination \ensuremath{\mathsf{FPAC}} .
--004B--
                     CPM = FP_LOW(DES) == MEM_READ, FD == A(DES) + ZERO,
                    Instruction Set Microcode Rev 1 09-DEC-82 10:47:39 RGG Source File Cycle 1 18-AUG-82 15:24:34 RGG 0 0028 - 01
SAMPLES
FLPT UASM 00.10.00
```

```
Proprietary information of Data General Corporation

864B

ATTEMPT_NEXT_EFA, RETURN;
OP TSEL ADDRESS DAA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X CRTN TRUE

DES
FA 2R TAD DES ML

--DFVS:
865B
866B

SAMPLES Instruction Set Microcode Rev 1 · 09-DEC-82 10:47:39 RGG
FLPT Source File Cycle 1 18-AUG-82 15:24:34 RGG
UASM 00.10.00 0029 - 01
```

```
Proprietary information of Data General Corporation
     867B /*-----
868B* |
869B* | Store Floating Point Single
870B* |
                                        LFSTS fpac,[@]displacement[,index]
KFSTS fpac,[@]displacement[,index]
fpac,[@]displacement[,index]
     871B*
      872B*
     873B*
874B*
875B*
                                      Cycles: 1
      876B*
      877B* +----
     878B
879B
880B
                                         Get a double word from the high order half of the
     880B %
881B %
                                        destination FPAC and write it to memory.
      882B
--DFVs:
     886B
887B
     Store Floating Point Double
     892B*
                                        LFSTD
                                                         fpac,[@]displacement[,index]
      893B*
                                                              fpac,[@]displacement[,index]
fpac,[@]displacement[,index]
     894B*
895B*
896B*
                                        FSTD
                                        Cvcles: 2
      897B*
     898B*
899B
900B
                                        Read a double word from the high order half of the destination \ensuremath{\mathsf{FPAC}} and write it to memory. Start memory for a write of the next double word.
     901B %
901B %
902B %
903B %
904B
--004D--LFSTD:
--004D--XFSTD:
                        FSID:
STD: CPM = MEM_WRITE == FP_HIGH(DES),
STD: CPM = FP_H
--004D--FSTD:
                                                                                                                                                                                                                DES
   -DFVs:
     909B
910B %
                                        Write the low order half of the destination FPAC to memory.
     911B
                                         CPM = MEM_WRITE == FP_LOW(DES), ATTEMPT_NEXT_EFA, RETURN;
TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
TRUE D EFA S0 W LF
                        OP TSEL
CRTN TRUE
                                                                                                                                                                                                              DES
 --DFVs:
                                        Instruction Set Microcode Rev 1 09-DEC-82 10:47:39 RGG Source File Cycle 1 18-AUG-82 15:24:34 RGG
SAMPLES
            Source File
 FI.PT
```

```
Proprietary information of Data General Corporation

913B
914B

•
•
•
•
•
•
SAMPLES Instruction Set Microcode Rev 1 09-DEC-82 10:47:39 RGG
FLPT Source File Cycle 1 18-AUG-82 15:24:34 RGG
UASM 00.10.00 0031 - 01
```

```
Proprietary information of Data General Corporation
    915B /*-
    916B* |
917B* |
918B* |
919B* |
                           Add Single (Memory to FPAC)
                          LFAMS fpac,[@]displacement[,index]
XFAMS fpac,[@]displacement[,index]
FAMS fpac,[@]displacement[,index]
    920B*
921B*
922B*
923B*
924B*
                          Cycles: 4
    925B*
926B
927B
928B
    929B
930B
931B
932B
                            Read a double word from memory and place it in the high order half of a temporary register. Place the number of the temporary register in the source register pointer. Go to code which executes floating point add.
9328 %
933B
--004F--LFAMS:
--004F--XFAMS:
--004F--FAMS:
                           CPM = FP_HIGH(FGO) == MEM_READ, POINT_SRC_TO FGO, GOTO FAS;
TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X FAS R MM GN LDAS CN
                                                                                                                                                                                                     FG0 FG0 MH
 --DFVs: addr is FAS (0052)
    937B
938B
939B
    940B* |
941B* |
942B* |
943B* |
944B* |
946B* |
947B* |
                            Add Double (Memory to FPAC) (Long Displacement)
                           LFAMD fpac,[@]displacement[,index]
fpac,[@]displacement[,index]
fpac,[@]displacement[,index]
                        Cycles: 5
   948B*
949B*
950B
951B
952B
953B
                           Read a double word from memory and place it in the high order half of a temporary register. Start a memory read for the next double word. Place the number of the temporary register in the source register pointer.
    951B %
952B %
953B %
954B %
955B
--DFVs:
961B
962B %
963B %
964B %
                           Read a double word from memory and place it in the low order half of the temporary register. Go to code which executes floating point add.

Instruction Set Microcode Rev 1 09-DEC-82 10:47:39 RGG Source File Cycle 1 18-AUG-82 15:24:34 RGG 0 0032 - 01
SAMPLES
FLPT Source File UASM 00.10.00
```

```
Proprietary information of Data General Corporation
                   CPM = FP_LOW(FGO) == MEM_READ, GOTO FAD;
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
LEAP R MM
--0051--
--DFVs: addr is FAD (0052)
    970B* |
971B* |
                              Add Single (FPAC to FPAC)
    972B* |
973B* |
                            FAS facs, facd
    974B*
975B*
                            Cycles: 3
    976B* |
977B* +----
    978B
979B
    980B*
    981B*
982B*
                                Add Double (FPAC to FPAC)
                            FAD facs, facd
    983B*
    984B*
    985B* | Cycles: 3
986B* |
987B* +-----
    988B
                                Compare source and destination mantissas and load signs. Compare exponents and load the shift magnitude register with the difference. If the exponents are equal, the working register is loaded with the smaller mantissa. If the exponents are not equal, the working register is loaded with the mantissa corresponding to the smaller exponent. The swap bit is set if the source mantissa is loaded into the working register.
    989B %
990B %
991B %
992B %
    AD:
AS: FD == A(SRC) - B(DES), LOAD_SIGNS,
EXPONENT == FA-FB, WR == PRESCALE_OPERAND;
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CJMP FALSE
FL
    996B
--0052--FAD:
--0052--FAS:
999B
                                                                                                                                                                                                                         FA FB TSB R
                                                                                                                                            LAB SUB CMP SRC DES
 --DFVs:
1000B
1001B %
                                 Add with signs the right shifted mantissa in the working register to the mantissa selected by the swap bit. Place the result in the working register. Add mantissa overflow bit to the exponent selected by the swap bit. Form the guard digits and load the signs as selected by the swap bit. Detect leading zeroes in the result and load the shift magnitude register.
  1003B
1004B
  1005B
  1005B 4
1006B 4
1007B
--0053--
                    FD = WR == SELECTED_A (SRC,DES) @+ PRESCALED_WR TRUNCATED_IF_NOT_ROUNDING,

EXPONENT == FA+MOF, LOAD_SIGNS, SHIFT_MAG == LEADING_ZERO_DETECT;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X

CJMP FALSE

FL THE TRUNCATED_IF_NOT_ROUNDING,

EXPONENT == FA+MOF, LOAD_SIGNS, SHIFT_MAG == LEADING_ZERO_DETECT;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X

CJMP FALSE
  1009B
                                                                                                                                                                                                                                                                     LWR
                                                                                                                                                                                                                          FA RS ADD D
                                                                                                                                            TRN ACA LZD SRC DES
              Instruction Set Microcode Source File
 --DFVs:
SAMPLES
                                                                                               Rev
                                                                                                                              09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
                                                           0033 - 01
FLPT
UASM
```

```
Proprietary information of Data General Corporation
                                    Add left shifted result in working register and round bit and allow correction for mantissa overflow. Select sign in A register. Adjust the exponent for normalization and mantissa overflow. Store result in destination PPAC. Update the
   1012B %
1013B %
1014B %
1015B %
                                    FPSR.
                      RND: FD = FPU(DES) == ROUND_BIT + NORMALIZED_WR,
ENABLE_MOF_CORRECTION, ALLOW_SHIFT_MAG_CORRECTION,
SIGN == A_SIGN,
EXPONENT == EWR+MAG+MOF, UPDATE_FPSR, ATTEMPT_NEXT_EFA, RETURN;
OP TSEL ADDRESS DAA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CRIN TRUE

OR TSEL ADDRESS DAA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CRIN TRUE

SA ACN LZD

RB LS TAD DES D UFS
   1016B
     -0054--FRND:
   1020B
    -DFVs:
   1021B
1022B
1023B
   1025B
SAMPLES
                                                                                                                                 09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
                                   Instruction Set Microcode Rev 1
FLPT
            Source File Cycle 1 00.10.00 0034 - 01
```

```
Proprietary information of Data General Corporation
  1026B .EJECT;
1027B .FT 1 "WLMP
                                                                                                   Cycle 1 18-AUG-82 15:24:34 RGG"
                                                  Source File
             ;
   1028B
  1029B
  1030B
1031B*
1032B*
                           The code for the load map instruction illustrates the communication protocal with the IO controller. Note all IO commands are piped through TREG. This is the only CPD source which will make timing to the IOC.
   1033B*
   1034B*
                           Although WMLP is a wide instruction, decode information starts the instruction as though it were narrow. This is to handle a peculiarity of the instruction in a convenient fashion (i.e. incrementing and sign extending the map slot counter in the first cycle). The ALU is placed in the wide mode at the end of the first cycle.
   1037B*
   1038B*
   1039B*
   1041B*
   1042B*
  1042B*
1043B*
1044B*
1045B
1046B
1047B
1048B*
1048B*
                         Wide Load Map
  1050B*
  1051B*
                        WLMP
                         FLAGO must be cleared by decode.
   1054B*
  10558* +----
  1056B
--0055--WLMP:
                         Pre-increment and sign extend map slot counter to enter loop. Put ALU data paths in wide mode. Take privilege protection fault if not in ring 0.
  1059B
  1060B
  1061B
1061B
1062B
1063B
               IY = TREG == ZERO +1+ A(AC1),

MODIFY_FLAGS_0123 (SET,N,N,N),

IF RING<>0 GOTO PRIVILEGE_PROTECTION;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X CJMP NRNG0 PRIVILEG IY GN MFSO LT AC1 ZR AD CAD PASS
  1064B
 1065B
                                                                                                                                                                                 S N N N
--DFVs:
             addr is PRIVILEGE_PROTECTION (0003 *EXT*)
 1066B
1067B %
                          Decrement map slot counter. Check for interrupt BEFORE loading first
  1068B %
 1069B
--0056--
               IY = ALU(AC1) = AG(AG1) == A(M1) + TREG,

IF INTERRUPT_PENDING GOTO WLMP_INT;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X CJMP INTR WLMP_INT AGI M IY TRG M1 AC1 CA ADD PASS Y
 1071B
--DFVs: addr is WLMP_INT (0063) 1072B
 1073B
--0057--WLMP_LOOP:
1075B
SAMPLES
             Instruction Set Microcode
                                                                                                      09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
                                                                             Rev
                          Source File Cycle 1
WLMP
UASM 00.10.00
```

```
Proprietary information of Data General Corporation
                       Isolate the map slot number from ACO and convert to an IOC register number by shifting left. Start read for the first double word to load in the map. If map slot counter is zero, there is nothing left to do.
1076B %
             IY = ALU(GR0) == BIT_SHIFT_LEFT (SPAD(WASHM17) NOT_AND A(ACO)),
START AY == PASS (B(AC2)) FOR READ_DOUBLE,
IF ALU=0 GOTO WLMP_DONE;
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CJMP FZR WLMP_DON AG2 B PSB RD AC CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
 1080B
 1081B
 1082B
1083B
             addr is WLMP_DONE (0064) const is WASHM17 (0031)
1084B
1085B %
                        There are still more map slots to load. Read the map data.
                        CPM = ALU(GR2) == MEM_READ;
TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X R MM
              CJMP FALSE
--DFVs:
1088B
1089B %
                       Isolate high half of map data.
1090B
--0059--
                        IY = ALU(GR1) == HEX_SHIFT_RIGHT (R4,A(GR2));
TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X FALSE

R4

R4

R4
               CJMP FALSE
--DFVs:
1092B
1093B %
                       Form command to load high half of current map slot.
              1094B
--DFVs:
1096B
1097B %
1098B %
            const is IOCMD1 (0079)
                        Send load command.
Form data for high half of current map slot.
 1098B
--005B-
1101B
               PDR = IO_CONTROLLER == TREG,
IY = TREG == SPAD(IOCMD) OR A(GR1);
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CJMP FALSE IY TRG AT SIO LT GR1 SC AD OR PASS IOCMD
 --DFVs:
1102B
1103B %
1104B %
            const is IOCMD (0078)
                        Send data for high half of map slot. Increment address part of command to write low half of map slot.
 1105B
--005C-
1107B
                        PDR = IO_CONTROLLER == TREG,
IY = ALU(GR0) == ZERO +1+ A(GR0);
TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
TRG AT SIO GR0 GR0 ZR AD CAD PASS Y
               CJMP FALSE
--DFVs:
  1108B
  1109B %
          % Move command to load low half of current map slot to TREG.
S Instruction Set Microcode Rev 1 09-DEC-82 10:47:39 RGG
Source File Cycle 1 18-AUG-82 15:24:34 RGG
SAMPLES
WLMP
UASM
```

```
Proprietary information of Data General Corporation
           1110B %
                                                                           Wait until IO is finished.
           --DFVs: addr is WLMP_HI_WAIT (005D)
1114B
1115B % IO is done. Incremen
1116B % words). Send clear ct
                                                                          IO is done. Increment map data pointer (by 2 since they are double words). Send clear command.
                                              --DFVs:
1120B
1121B %
1122B %
                                                                          Form data for low half of map slot. Send command to load low half of current map slot.
                                           IY = TREG == SPAD(IOCMD) OR A(GR2),
PDR = IO_CONTROLLER == TREG;
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CJMP FALSE IY TRG AT SIO LT GR2 SC AD OR PASS IOCMD
           -005F--
        1125B
      --DFVs: const is IOCMD (0078)
       1126B
1127B %
1128B %
1129B
                                                                         Send data for low half of current map slot. Increment map slot number. % \left( 1\right) =\left( 1\right) \left( 
                                           -0060--
   --DFVs:
1132B
1133B %
                                                             Wait here until IO is finished.
      1134B
        -0061--WLMP_LO_WAIT: IF IO_BUSY GOTO WLMP_LO_WAIT;
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CJMP IOB WLMP_LO_
  --DFVs: addr is WLMP_LO_WAIT (0061)
    1136B
1137B %
1138B %
                                                                      \ensuremath{\mathsf{IO}} is done. Send clear command and decrement slot counter. Loop if an interrupt is not pending.
      1139B
                                         CPD = IO_CONTROLLER == ZERO,
IY = ALU(AC1) = AG(AG1) == A(M1) + B(AC1),
IF NOT INTERRUPT_PENDING GOTO WLMF_LOOP;
OP TSEL ADDRESS D AA AB AG AGP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CJMP NINTR WLMF_LOO AG1 M IY N AT SIO M1 AC1 BR DA ADD PASS Y
     1141B
1142B
--DFVs: addr is WLMP_LOOP (0057)
1143B
SAMPLES Instruction Set Mi
SAMPLES Instruction Set Microcode Rev 1 WLMP Source File Cycle 1 UASM 00.10.00 0037 - 01
                                                                                                                                                                                                                                                                           09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
```

```
Proprietary information of Data General Corporation
 1144B
--0063--WLMP_INT:
1146B
1147B % II
1148B % PI
1149B
                        Interrupt is pending. Correct the map slot counter, load PCX into
                        PDR, and honor the interrupt.
              IY = ALU(AC1) = AG(AG1) == B(AC1) - A(M1),
PDR == PC_OF_EXECUTION, GOTO RESTARTABLE_INTERRUPT;
OP TSEL ADDRESS D AA AB AG AGP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
LEAP RESTARTA AG1 M IY PCX M1 AC1 BR AD CSR PASS Y
   1151B
  --DFVs: addr is RESTARTABLE_INTERRUPT (0004 *EXT*)
  1152B
1153B
--0064--WLMP_DONE:
1155B
                        Normal termination of WLMP instruction. Abort the pending read and IPOP. \,
  1156B %
1157B %
1158B
               ABORT_MEMORY, ATTEMPT_NEXT_EFA, RETURN;
OP TSEL ADDRESS DAA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CRTN TRUE D EFA S@ A
   1159B
 --DFVs:
             Instruction Set Microcode Rev 1 09-DEC-82 10:47:39 RGG Source File Cycle 1 18-AUG-82 15:24:34 RGG 0.10.00
SAMPLES
WLMP
UASM 00.10.00
```

```
Proprietary information of Data General Corporation

1160B .EJECT;
1161B .FT 1 "IP_ALT Source File Cycle 1 18-AUG-82 15:24:34 RGG"
1161B .FT 1 "IP_ALT Source File Cycle 1 18-AUG-82 15:24:34 RGG"
1162B ;
1163B .LOC OFFF; % WAIT
1165B % WAIT for the IP
1167B % Abort any outstanding memory starts and try to IPOP to
1161B % Abort any outstanding memory starts and try to IPOP to
1161B % Abort any outstanding memory starts and try to IPOP to
1161B % Abort any outstanding memory starts and try to IPOP to
1161B % Abort any outstanding memory starts and try to IPOP to
1161B % Abort any outstanding memory starts and try to IPOP to
1161B % Abort any outstanding memory starts and try to IPOP to
1161B % Abort any outstanding memory starts and try to IPOP to
1161B % Abort any outstanding memory starts and try to IPOP to
1161B % Abort any outstanding memory starts and try to IPOP to
1161B % Abort any outstanding memory starts and try to IPOP to
1162B % Abort any outstanding memory starts and try to IPOP to
1162B % Abort any outstanding memory starts and try to IPOP to
1172B % ABORT MEMORY, ATTEMPT NEXT_EFA, RETURN;
0P TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
0P TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
0P TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
0P TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
0P TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
0P TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
0P TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
0P TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
0P TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS
```

SYMBOL	QUALIFIER	TYPE	VALUE	
&	.GLOBAL.	PARSE	0003	
+	AOP1	CONST	0001	
•	ALU_OP	CONST	0007	
	FP_OP	CONST	0002	
+1+	ALU_OP	CONST	0002	
	AOP1	CONST	0000	
	ALU_OP	CONST	0004	
	FP_OP	CONST	0003	
-1	ALU_OP	CONST	0006	
.BEGIN	.COMMAND.	COMMAND	0000	
.EJECT	.COMMAND.	COMMAND	0000	
.END	.COMMAND.	COMMAND	0000	
.EXTERNAL	. COMMAND.	COMMAND	0000	
•FT	.COMMAND.	COMMAND	0000	
• HD	. COMMAND.	COMMAND	0000	
• LOC	.COMMAND.	COMMAND	0000	
.RADIX	.COMMAND.	COMMAND	0000	
.TITLE	.COMMAND.	COMMAND	0000	
=	AG_DEST	PARSE	003A	
	CPM_DEST	PARSE	0050	
	CPD_DEST	PARSE	0067	
	ALU_DEST	PARSE	00F8	
	FPU_DEST	PARSE	0132	
TE 20	AG_DEST	CONST	0000	
	CPM_DEST	CONST	0000	
	CPD_DEST	CONST	0000	
	ALU_DEST	CONST	0000	
	EQUAL	CONST	0000	
	ID_DEST_	CONST	0000	
2 .	FPU_DEST	CONST	0000	
@+	FP_OP	CONST	0000	
A	AGA	PARSE	003F	
	IS	PARSE	00F9	
	IR	PARSE	0111	
	FR_SRC FA_SRC	PARSE PARSE	0135 0144	
ABORT_MEMORY	.GLOBAL.	PARSE	0040	
AC0	IAB	CONST	0000	
AC1	IAB	CONST	0001	
AC2	IAB	CONST	0002	
AC3	IAB	CONST	0003	
ADD	.GLOBAL.	LABEL	0015	
ADDI	.GLOBAL.	LABEL	001A	
AG	AG_DEST	PARSE	002E	
	CPM_DEST	PARSE	0049	
	PDR_SRC	PARSE	0069	
	ALU_DEST	PARSE	00F1	
	IR	PARSE	0119	
AG0	AAB	CONST	0000	
AG1	AAB	CONST	0001	
AG2	AAB	CONST	0002	
AG3	AAB	CONST	0003	
ALC_CRY	CRY_RAND	CONST	0009	
ALC_RESULT	TSKIP	PARSE	00CE	
ALLOW_SHIFT_MAG_C		PARSE	013F	
ALU	AG_DEST	PARSE	002B	
	CPM_DEST	PARSE	0 0 46	
	CPM_SRC	PARSE	0055	
	ALU_DEST	PARSE	00EB	
UASM 00.10.00	*** Symbol Table ***			

```
VALUE
  SYMBOL
                                                                                                                                                                       QUALIFIER
                                                                                                                                                                                                                                                                                                                                            TYPE
                                                                                                                                                                      TEST
                                                                                                                                                                                                                                                                                                                                           CONST
CONST
SET
PARSE
CONST
CONST
CONST
CONST
PARSE
CONST
PARSE
                                                                                                                                                                                                                                                                                                                                                                                               007D
  ALU=0
                                                                                                                                                                     TEST
TSKIP
CRY_RAND
.GLOBAL.
ALU_OP
AAB
AAB
AAB
AAB
.GLOBAL.
TEST
.GLOBAL.
AG_OP
SGNR
AGB_SRC
                                                                                                                                                                                                                                                                                                                                                                                               0004
0015
0122
0000
0008
0009
ALU_CRY
ALU_TEST
AND
ARO
AR1
AR3
AR5
                                                                                                                                                                                                                                                                                                                                                                                               000D
0026
0019
0028
0029
0017
003E
00FA
0112
0129
0138
00010
00105
0001
  ATTEMPT_NEXT_EFA
ATU_PURGING
AY
                                                                                                                                                                                                                                                                                                                                            PARSE
PARSE
SET
PARSE
PARSE
PARSE
PARSE
PARSE
   A_SIGN
B
                                                                                                                                                                      SGNR
AGB_SRC
IS
IR
ID_SRC
FS_SRC
.GLOBAL.
.GLOBAL.
 BIT0
BIT16
BIT_SHIFT_LEFT
CALL
CARRY
CASE_4_INTO
CASE_DATA
                                                                                                                                                                                                                                                                                                                                            PARSE
LABEL
LABEL
PARSE
CONST
PARSE
PARSE
PARSE
CONST
                                                                                                                                                                       IS
CONDITIONAL
                                                                                                                                                                      GLOBAL.
GLOBAL.
CPD_DEST
ALU_DEST
MF
AGB_SRC
                                                                                                                                                                                                                                                                                                                                                                                               000E
0062
00E9
0002
003C
00FE
0042
005C
011C
  CLEAR
CNST
                                                                                                                                                                                                                                                                                                                                             PARSE
PARSE
PARSE
                                                                                                                                                                      IS
.GLOBAL.
.GLOBAL.
IR
   COMPLETE_JUMP
CPD
                                                                                                                                                                                                                                                                                                                                           PARSE
PARSE
PARSE
PARSE
PARSE
PARSE
CONST
CONST
LABEL
                                                                                                                                                                                                                                                                                                                                                                                               011D
0045
0039
0071
  CPD_ZERO
CPU_ABANG
CPM
CRE
DECREMENT_DES_POINTER
DEFER_ON_FALSE_TEST
                                                                                                                                                                           GLOBAL.
                                                                                                                                                                      .GLOBAL.
AG_DEST
GLOBAL..GLOBAL.
AAB
IAB
FABC
.GLOBAL..GLOBAL.
.GLOBAL..GLOBAL.
.GLOBAL..GLOBAL..GLOBAL..GLOBAL..GLOBAL..GLOBAL..GLOBAL..GLOBAL..GLOBAL..GLOBAL..GLOBAL..GLOBAL..GLOBAL..GENPR
                                                                                                                                                                                                                                                                                                                                                                                               00DB
000F
000F
                                                                                                                                                                                                                                                                                                                                                                                               000F
000F
0012
0013
0010
0024
0018
0140
0011
   EJMP
EJSR
ELDA
ELDB
    ELEF
  ELEF
ENABLE_MOF_CORRECTION
ESTA
EWR+MAG+MOF
EXECUTE
EXECUTE_DATA
EXECUTE_PBX
EXPONENT
EXTEND_MICRO_CYCLE
FA
                                                                                                                                                                     GLOBAL.
EXPR
GLOBAL.
CPM_DEST
GLOBAL.
GLOBAL.
GLOBAL.
GLOBAL.
GLOBAL.
EXPR
EXPR
EXPR
EXPR
EXPR
CAUBAL
SUBBAL
GLOBAL
GLOBAL
OGLOBAL
                                                                                                                                                                                                                                                                                                                                                                                               0026
0027
002D
0154
00D1
013A
0001
0005
                                                                                                                                                                                                                                                                                                                                              LABEL
PARSE
LABEL
                                                                                                                                                                                                                                                                                                                                             PARSE
PARSE
PARSE
CONST
CONST
  FA+MOF
FA-FB
FAD
                                                                                                                                                                                                                                                                                                                                              CONST
    UASM
                                           00.10.00
```

```
SYMBOL
                                                                                                                                      QUALIFIER
                                                                                                                                                                                                                                                                          TYPE
                                                                                                                                                                                                                                                                                                               VALUE
                                                                                                                                       .GLOBAL.
    FAMD
                                                                                                                                                                                                                                                                          LABEL
                                                                                                                                                                                                                                                                                                                0050
                                                                                                                                    .GLOBAL.
.GLOBAL.
.GLOBAL.
.GLOBAL.
FABC
ALL_REGSS
TEST
TEST
.GLOBAL.
MEM_STR
.FPU_DEST
CPM_DEST
CPM_DEST
CPM_DEST
CPM_BSC
CPM_DEST
CPM_BSC
GLOBAL.
.GLOBAL.
.GLOBAL.
.GLOBAL.
.GLOBAL.
    FAMS
FAS
FD
FG0
                                                                                                                                                                                                                                                                        LABEL
LABEL
PARSE
CONST
PARSE
CONST
LABEL
LABEL
PARSE
PARSE
PARSE
PARSE
PARSE
                                                                                                                                                                                                                                                                                                               FLAG4=0
FLAG4=1
FLDD
   FLDS
  FOR
FPU
FP_HIGH
  FP_LOW
   FRND
                                                                                                                                  LABEL
LABEL
LABEL
  FSTD
FSTS
GOTO
                                                                                                                                                                                                                                                                        SET
PARSE
  GR0
GR1
GR2
GR5
HEX_SHIFT_RIGHT
                                                                                                                                                                                                                                                                       CONST
CONST
CONST
PARSE
PARSE
CONST
PARSE
CONST
CONST
CONST
PARSE
LABEL
LABEL
LABEL
   ID
ID_SIGN=1
ID_SIGN=1
IF
INC
INCREMENT_SRC_POINTER
INDIRECT
INTERRUPT_PENDING
INWARD_REFERENCE
IN_CURRENT_RING
IOCMD
IOCMDI
IO_BUSY
IO_CONTROLLER
IS>=IR
IY
JMP
JSR
LAR
LAST_LA
                                                                                                                                                                                                                                                                                                               006C
0050
0043
                                                                                                                                                                                                                                                                                                               0052
001C
0078
0079
                                                                                                                                    TEST
MEM_STR
.GLOBAL.
.GLOBAL.
TEST
CPD_DEST
TEST
.GLOBAL.
.GLOBAL.
.GLOBAL.
                                                                                                                                                                                                                                                                       CONST
PARSE
CONST
PARSE
LABEL
LABEL
PARSE
PARSE
LABEL
CONST
LABEL
LABEL
LABEL
LABEL
LABEL
LABEL
                                                                                                                                                                                                                                                                                                               0044
005F
003A
00E7
0012
0013
011A
003D
0010
0023
0007
                                                                                                                                    IR
AGB_SRC
.GLOBAL.
.GLOBAL.
MAG_OP
LAR
LAST_LA
LDA
LDB
LEADING_ZERO_DETECT
LEF
LFAMB
LFAMB
LFLDB
LFLDB
LFLDB
LFLDB
LFCMB
                                                                                                                                     .GLOBAL.
.GLOBAL.
                                                                                                                                                                                                                                                                                                               0050
004F
004A
0049
                                                                                                                                     GLOBAL.
GLOBAL.
GLOBAL.
GLOBAL.
GLOBAL.
                                                                                                                                                                                                                                                                       LABEL
LABEL
LABEL
LABEL
LFEDS
LFSTD
LFSTS
LJMP
LJSR
LLDB
                                                                                                                                                                                                                                                                                                              0049
004D
004C
0012
0013
0024
                                                                                                                                                                                                                                                                       LABEL
LABEL
LABEL
                                                                                                                       .GLOBAL.
.GLOBAL.
*** Symbol Table ***
0003 - 02
                                                                                                                                                                                                                                                                        LABEL
                                                                                                                                                                                                                                                                                                               0018
UASM
                                00.10.00
```

```
SYMBOL
                                                                                                                  QUALIFIER
                                                                                                                                                                                                                                    TYPE
                                                                                                                                                                                                                                                                  VALUE
                                                                                                                   .GLOBAL.
                                                                                                                                                                                                                                    LABEL
LNLDA
LNSBI
LNSTA
LOAD_SIGNS
                                                                                                                                                                                                                                                                    0010
001D
0011
0153
0010
001C
0011
0007
0053
004E
00F6
                                                                                                                                                                                                                                    LABEL
LABEL
PARSE
                                                                                                                 GLOBAL.
GLOBAL.
GLOBAL.
GLOBAL.
GLOBAL.
GLOBAL.
IAB
GLOBAL.
IAB
ALU_DEST
GLOBAL.
GLOBAL.
GLOBAL.
GLOBAL.
GLOBAL.
TEST
GLOBAL.
ALU_OP
GLOBAL.
ALU_OP
GLOBAL.
 LWLDA
LWSBI
LWSTA
                                                                                                                                                                                                                                    LABEL
LABEL
                                                                                                                                                                                                                                    LABEL
CONST
PARSE
PARSE
M1
MEM_READ
MEM_WRITE
                                                                                                                                                                                                                                    PARSE
  MODIFY_FLAGS_0123
MODIFY_FLAGS_4567
                                                                                                                                                                                                                                   PARSE
PARSE
CONST
                                                                                                                                                                                                                                                                     00C8
00C9
0000
001B
  NADDI
NORMALIZED_WR
NORMAL_XCT
                                                                                                                                                                                                                                    LABEL
                                                                                                                                                                                                                                    CONST
LABEL
PARSE
LABEL
                                                                                                                                                                                                                                                                     0003
0029
0002
0040
  NOT
NOTST
NOT_AND
NSL
NSP
                                                                                                                                                                                                                                    CONST
CONST
CONST
                                                                                                                                                                                                                                                                     0002
0022
0020
                                                                                                                .GLOBAL.
.AAB
ALU_OP
AGB_SRC
.GLOBAL.
                                                                                                                                                                                                                                                                    0000
0005
0001
003B
0045
0046
 NSTK_OVERFLOW
ONE
                                                                                                                                                                                                                                    XTRNL
                                                                                                                                                                                                                                    CONST
CONST
PARSE
 OR
PASS
PATU
PATUW
PC
                                                                                                                                                                                                                                    LABEL
                                                                                                                  .GLOBAL.
AG_DEST
PDR_SRC
PDR_SRC
                                                                                                                                                                                                                                    LABEL
                                                                                                                                                                                                                                   PARSE
CONST
CONST
                                                                                                                                                                                                                                                                    002A
0006
0005
PC_OF_EXECUTION
PC_REL_INDEX
PDR
                                                                                                                                                                                                                                  CONST
CONST
PARSE
PARSE
PARSE
PARSE
                                                                                                                                                                                                                                                                     0005
005F
005B
00EA
00FB
0113
                                                                                                                  TEST
.GLOBAL.
ALU_DEST
IS
                                                                                                                  IR
POINT_SRC_TO
PRESCALED_WR
PRESCALE_OPERAND
PRIVILEGE_PROTECTION
PROTECTION_FAULT
PRT_RMX
PSH
DEVI
                                                                                                                  .GLOBAL.
FS_SRC
WR_SEL
                                                                                                                                                                                                                                   PARSE
CONST
PARSE
XTRNL
                                                                                                                                                                                                                                                                     006F
0002
014C
0003
                                                                                                                   .GLOBAL.
.GLOBAL.
.GLOBAL.
                                                                                                                                                                                                                                    XTRNL
CONST
LABEL
                                                                                                                                                                                                                                                                     0002
0004
003C
                                                                                                                GLOBAL.
GLOBAL.
GLOBAL.
GLOBAL.
GLOBAL.
RSHIFT
RSHIFT
MEM_STR
GLOBAL.
MEM_STR
GLOBAL.
GLOBAL.
GLOBAL.
CONDITIONAL
FDR_SRC
                                                                                                                                                                                                                                  LABEL
LABEL
PARSE
CONST
 PSHL
PSHM
PURGE_THE_ATU_CACHE
                                                                                                                                                                                                                                                                     0041
003F
00DA
0000
0003
0003
0002
001F
0001
PURGE_THE_ATU_CACHE
R1
R4
READ_BYTE
READ_DOUBLE
READ_PC_BYTE
READ_WORD
RESTARTABLE_INTERRUPT
RETURN
RETURN_ELSE_GOTO
PETURN_ELSE_GOTO
                                                                                                                                                                                                                                   CONST
CONST
LABEL
CONST
                                                                                                                                                                                                                                  XTRNL
PARSE
CONST
CONST
                                                                                                                                                                                                                                                                     0004
0007
0004
0004
0011
RETURN_PC
RING<>0
RMAX_PROTECTION
ROUND_BIT
                                                                                                                   PDR_SRC
                                                                                                                  FDK_SRC
TEST
.GLOBAL.
FR_SRC
* Symbol Table ***
0004 - 02
UASM
                           00.10.00
```

```
SYMBOL
                                                               QUALIFIER
                                                                                                                            TYPE
                                                                                                                                             VALUE
 SELECTED_A
                                                               FR_SRC
                                                                                                                            PARSE
                                                                                                                                               0134
                                                                                                                                               0001
013D
0152
                                                                                                                            CONST
 SET
 SHIFT_MAG
                                                               .GLOBAL.
                                                               .GLOBAL.
                                                                                                                            PARSE
 SKIP_ON
                                                               .GLOBAL.
                                                                                                                            PARSE
                                                                                                                                               0000
                                                                                                                            CONST
                                                                                                                                               0005
 SL
SP
                                                               TAR
 SPAD
                                                              ALU_DEST
                                                                                                                            PARSE
                                                                                                                                               00EC
0100
                                                               IS
                                                               ID_SRC
                                                                                                                            PARSE
PARSE
PARSE
                                                                                                                                               012A
00CF
0101
                                                              .GLOBAL.
R_SPAD
 SPAR
                                                              ALU_DEST
AAB
IAB
FABC
                                                                                                                            PARSE
CONST
CONST
 SPAR_TABLE_OFFSET
                                                                                                                                               OOEF
                                                                                                                            CONST
                                                                                                                                               000E
                                                                                                                                              006E
002E
0115
0011
 SRC<>DES
                                                              TEST
                                                                                                                            CONST
 SRC=DES
SRC_POINTER
STA
START
                                                              TEST
IR
.GLOBAL.
                                                                                                                            CONST
                                                                                                                            LABEL
PARSE
                                                               GLOBAL.
                                                                                                                                               0019
                                                              .GLOBAL.
.GLOBAL.
MF
CPM_DEST
                                                                                                                            PARSE
LABEL
CONST
                                                                                                                                              0019
0025
0017
0003
 START EXECUTE
 SUBL
TOGGLE
TREG
                                                                                                                                              0048
0002
00F0
011B
                                                                                                                            PARSE
                                                                                                                            CONST
PARSE
PARSE
                                                              PDR SRC
                                                              ALU_DEST
IR
.GLOBAL.
 TRUNCATED_IF_NOT_ROUNDING
                                                                                                                            PARSE
                                                                                                                                              0139
                                                                                                                            CONST
PARSE
PARSE
                                                                                                                                              0006
0148
00E3
001B
                                                              AAB
 UPDATE FPSR
                                                               .GLOBAL.
 UPDATE_OVR
WADDI
WAIT
                                                               .GLOBAL.
                                                                                                                            LABEL
                                                               .GLOBAL .
                                                                                                                            LABEL
LABEL
LABEL
                                                                                                                                              0FFF
0031
0036
0037
                                                              .GLOBAL.
.GLOBAL.
 WASHM17
 WBITW
WBITW1
                                                                                                                            LABEL
                                                              GLOBAL.
GLOBAL.
GLOBAL.
GLOBAL.
GLOBAL.
                                                                                                                           LABEL
LABEL
LABEL
                                                                                                                                              0038
0012
003A
 WBITW2
 WBR
WBR
WCOB1
WCOBTAB
WIDE_JUMP
WITH_WORD_ADDRESSING
WLDB
WLMP_DONE
                                                                                                                            LABEL
                                                                                                                                              003B
                                                                                                                           LABEL
PARSE
PARSE
I.ABEL
                                                                                                                                              0000
001F
001B
0023
0055
                                                              MEM_STR
MEM_STR
.GLOBAL.
.GLOBAL.
                                                                                                                            LABEL
                                                                                                                           LABEL
LABEL
LABEL
                                                                                                                                              0064
005D
0063
                                                               .GLOBAL.
WLMP_HI_WAIT
WLMP_INT
WLMP_LOOP
WLMP_LO_WAIT
                                                               .GLOBAL.
                                                                                                                           LABEL
LABEL
LABEL
PARSE
                                                               .GLOBAL.
                                                                                                                                              0057
                                                                                                                                              0061
001B
010E
                                                              .GLOBAL.
WNADT
                                                               .GLOBAL.
WORD_ZERO_EXTEND
WPSH
WPSHT
                                                              IS
.GLOBAL.
                                                                                                                           LABEL
LABEL
LABEL
                                                                                                                                              0042
0044
0043
0131
014B
                                                             .GLOBAL.
FPU_DEST
.GLOBAL.
MEM_STR
WPSH_LOOP
WR
                                                                                                                            PARSE
                                                                                                                           PARSE
WRITE_BYTE
                                                                                                                           CONST
                                                                                                                                              0007
                                                               Symbol Table ***
0005 - 02
UASM
              00.10.00
```

```
SYMBOL
                                                                       OUALIFIER
                                                                                                                                            TYPE
                                                                                                                                                                VALUE
 WRITE_DOUBLE
WRITE_PC_BYTE
WRITE_WORD
WSTK_OVERFLOW
WSZ BO
WSZ BO
WSZ BONRM
VCT
                                                                      MEM_STR
                                                                                                                                                                 0006
                                                                                                                                             CONST
                                                                        GLOBAL.
                                                                                                                                             LABEL
                                                                                                                                                                 0005
0001
0030
0035
0032
                                                                                                                                            CONST
XTRNL
LABEL
LABEL
                                                                       MEM STR
                                                                       .GLOBAL.
                                                                       .GLOBAL.
                                                                                                                                            LABEL
LABEL
CONST
LABEL
WSZBONRM
XCT
XCTED_INSTRUCTION
XCTOP
XCT_WAIT1
XCT_WAIT2
                                                                                                                                                                 0026
0006
00C3
002B
                                                                        .GLOBAL
                                                                       .GLOBAL.
                                                                                                                                            LABEL
                                                                                                                                                                 002C
0050
004F
004A
0049
                                                                                                                                            LABEL
LABEL
LABEL
LABEL
                                                                       .GLOBAL.
 XFAMD
XFAMS
XFLDD
XFLDS
                                                                       .GLOBAL.
.GLOBAL.
                                                                       - GLOBAL -
                                                                                                                                            LABEL
                                                                       .GLOBAL.
.GLOBAL.
.GLOBAL.
                                                                                                                                                                 004D
004C
0012
                                                                                                                                            LABEL
LABEL
 XFSTD
 XFSTD
XFSTS
XJMP
XJSR
XLDB
                                                                                                                                            LABEL
                                                                                                                                                                 0013
0024
0018
                                                                       .GLOBAL .
                                                                                                                                            LABEL
                                                                                                                                            LABEL
LABEL
LABEL
LABEL
                                                                       . GLOBAL
 XLEF
XLSBI
XNLDA
                                                                       .GLOBAL.
                                                                                                                                                                 001E
0010
                                                                       .GLOBAL.
                                                                                                                                            LABEL
LABEL
LABEL
 XNSBI
                                                                       .GLOBAL.
                                                                                                                                                                 0010
                                                                       .GLOBAL.
.GLOBAL.
                                                                                                                                                                 0011
0010
001C
0011
 XNSTA
 XWLDA
XWSBI
                                                                                                                                            LABEL
 XWSTA
ZERO
                                                                       .GLOBAL.
                                                                                                                                            LABEL.
                                                                                                                                           CONST
PARSE
PARSE
CONST
                                                                      PDR SRC
                                                                                                                                                                 000F
006A
                                                                      CPD_SRC
                                                                                                                                                                 00FF
0001
                                                                      IS
FS_SRC
                                                               *** Symbol Table ***
0006 - 02
                 00.10.00
UASM
```

MBOL	REFERENCES					
&:.GLOBAL.	489-01					112.01
+:AOP1	87-01	92-01	97-01	102-01	107-01	113-01 143-01
	118-01	123-01	128-01	133-01 423-01	138-01 430-01	568-01
	148-01	153-01	158-01		723-01	737-01
	606-01	623-01	660-01	708-01	1118-01	/3/-01
	742-01	858-01	908-01	959-01	1141-01	
+:ALU_OP	258-01	334-01	338-01	1070-01	1141-01	
+:FP_OP	863-01	1017-01	1107 01	1131-01		
+1+:ALU_OP	262-01	1063-01	1107-01	1131-01		
-: AOP1	785-01	401 01	428-01	714-01	741-01	1150-01
-:ALU_OP	266-01	421-01	420-01	714-01	741 01	1130 01
-: FP_OP	998-01					
-1-:ALU_OP	373-01					
.BEGIN: .COMMAND.	4-01	30-01	55-01	162-01	234-01	270-01
.EJECT:.COMMAND.	1-01 376-01	462-01	531-01	665-01	747-01	792-01
	1026-01	1160-01	331-01	003 01		
END COMMAND	1174-01	1100-01				
.END:.COMMAND.	23-01					
.EXTERNAL:.COMMAND.	8-01	31-01	56-01	163-01	235-01	271-01
.FT:.COMMAND.	377-01	463-01	532-01	666-01	748-01	793-01
	1027-01	1161-01				
.HD:.COMMAND.	5-01	6-01				
.LOC: .COMMAND.	1164-01	1164-01				
.RADIX:.COMMAND.	7-01	29-01	7-01	29-01		
.TITLE: .COMMAND.	2-01					
=: AG_DEST	87-01	87-01	92-01	92-01	97-01	97-01
NG_DDD1	102-01	102-01	107-01	107-01	113-01	113-01
	118-01	118-01	123-01	123-01	128-01	128-01
	133-01	133-01	138-01	138-01	143-01	143-01
	148-01	148-01	153-01	153-01	158-01	158-01
	606-01	660-01	660-01	708-01	723-01	737-01
	742-01	785-01	791-01	1118-01	1118-01	260.01
=: CPM_DEST	195-01	195-01	202-01	314-01	365-01	369-01
	459-01	459-01	503-01	528-01	575-01	619-01
	702-01	707-01	713-01	722-01	740-01	833-01
	856-01	863-01	885-01	907-01	912-01	936-01
	958-01	966-01	1087-01	1112-01	1125-01	1130-01
=:CPD_DEST	653-01	1100-01	1106-01	1119-01	1125-01	1130-01
	1140-01	00.01	93-01	93-01	98-01	98-01
=:ALU_DEST	88-01	88-01	108-01	108-01	114-01	114-01
	103-01 119-01	103-01 119-01	124-01	124-01	129-01	129-01
	134-01	134-01	139-01	139-01	144-01	144-01
	149-01	149-01	154-01	154-01	159-01	159-01
	232-01	232-01	258-01	258-01	262-01	262-01
	266-01	266-01	306-01	306-01	313-01	334-01
	334-01	338-01	338-01	373-01	421-01	428-01
	499-01	523-01	527-01	561-01	569-01	574-01
	579-01	591-01	661-01	717-01	745-01	788-01
	1063-01	1070-01	1070-01	1081-01	1091-01	1095-01
	1095-01	1101-01	1107-01	1124-01	1131-01	1131-01
	1141-01	1141-01	1150-01	1150-01		
=:FPU_DEST	1008-01	1017-01				
==:AG_DEST	87-01	92-01	97-01	102-01	107-01	113-01
	118-01	123-01	128-01	133-01	138-01	143-01
	148-01	153-01	158-01	366-01	370-01	423-01
	430-01	442-01	568-01	590-01	606-01	613-01
	623-01	660-01	698-01	703-01	708-01	715-01
	***	Symbol Cro	ss Referer	nce ***		
M 00.10.00			- 03			

SYMBOL	REFERENCE						
	7 23-01	737-01	742-01	785-01	791-01	858-01	-01
	908-01	959-01	1082-01	1118-01			
==:CPM_DEST	195-01	202-01	314-01	365-01	369-01	459-01	
	503-01	528-01	575-01	619-01	702-01	707-01	
	713-01	722-01	740-01	833-01	856-01	863-01	
	885-01 1087-01	907-01 1112-01	912-01	936-01	958-01	966-01	-01
==:CPD DEST	230-01	457-01	653-01	713-01	740-01	784-01	-01
·CID_BUBI	1100-01	1106-01	1119-01	1125-01	1130-01	1140-01	
	1151-01	1100 01	1113 01	1125 01	1130 01	1140 01	01
==:ALU_DEST	88-01	93-01	98-01	103-01	108-01	114-01	-01
	119-01	124-01	129-01	134-01	139-01	144-01	
	149-01	154-01	159-01	232-01	258-01	262-01	-01
	266-01	306-01	313-01	334-01	338-01	373-01	-01
	421-01	428-01	499-01	523-01	527-01	561-01	-01
	569-01	574-01	579-CL	584-01	591-01	661-01	
	717-01	745-01	788-01	1063-01	1070-01	1081-01	
	1091-01	1095-01	1101-01	1107-01	1124-01	1131-01	-01
==: EQUAL	1141-01	1150-01	00.01	304.03	300 03		
: EQUAL	89-01 120-01	94-01 125-03	99-01 130-01	104-01 135-01	109-01	115-01	
	150-01	155-01	160-01	259-01	140-01 263-01	145-01 267-01	
	339-01	374-01	563-01	662-01	714-01	741-01	
	834-01	834-01	857-01	857-01	999-01	999-01	
	1009-01	1009-01	1019-01	1020-01	333 01	333 01	0.1
==:ID_DEST	491-01	562-01					
==:FPU_DEST	863-01	998-01	1008-01	1017-01			
@+:FP_OP	1008-01						
A:AGA	87-01	92-01	97-01	102-01	107-01	113-01	
	118-01	123-01	128-01	133-01	138-01	143-01	
	148-01	153-01	158-01	423-01	430-01	568-01	
	606-01	623-01	660-01	708-01	723-01	737-01	
A:IS	742-01	785-01	858-01	908-01	959-01	1118-01	
W:12	89-01 120-01	94-01 125-01	99-01 130-01	104-01	109-01	115-01	
	150-01	155-01	160-01	135-01 338-01	140-01 373-01	145-01 579-01	
	584-01	662-01	788-01	1070-01	1141-01	3/9-01	01
A:IR	232-01	258-01	262-01	266-01	421-01	428-01	0.1
*****	499-01	523-01	527-01	561-01	569-01	574-01	01
	591-01	745-01	1063-01	1081-01	1091-01	1095-01	
	1101-01	1107-01	1124-01	1131-01	1150-01		
A:FR_SRC	863-01	998-01					
A:FA_SRC	834-01	857-01					
ABORT_MEMORY: .GLOB		308-01	312-01	421-01	428-01	607-01	01
100 715	614-01	745-01	1159-01	1171-01			
ACO: IAB	1081-01	1131-01	1131-01				
AC1:IAB	1063-01	1070-01	1141-01	1141-01	1150-01	1150-01	01
AC2:IAB AC3:IAB	1118-01						
ADD: GLOBAL.	232-01						
ADDI: GLOBAL.	258*01 334*01						
AG:AG_DEST	87-01	92-01	97-01	102-01	107-01	113-01	0.1
	118-01	123-01	128-01	133-01	138-01	143-01	
	148-01	153-01	158-01	606-01	660-01	708-01	
	723-01	737-01	742-01	1118-01	000 01	700 01	01
AG:CPM_DEST	195-01	314-01	459-01	619-01	702-01		
AG:PDR_SRC	653-01	713-01	740-01				
AG:ALU_DEST	232-01	258-01	262-01	266-01	306-01	334-01	
	338-01	421-01	428-01	561-01	745-01	788-01	01
UASM 00.10.00	*** (Symbol Cros	ss Referenc	e ***			
		0002	_ 03				

SYMBOL	REFERENCE	s					
	1070-01	1131-01	1141-01	1150-01			
AG: IR	741-01						
AGO: AAB	1131-01	1141 01	1150-01				
AG1:AAB	1070-01	1141-01 1118-01	1118-01				
AG2: AAB	1082-01 232-01	1110-01	1110-01				
AG3:AAB	CRY_RAND 259-01	263-01	267-01				
	ULT:TSKIP 259-01	263-01	267-01				
	HIFT_MAG_CORRECTION: . (1018-01				
ALU:AG_I		92-01	97-01	102-01	107-01	113-01	
	118-01	123-01	128-01	133-01	138-01	143-01	
	148-01	153-01	158-01	660-01	1118-01		
ALU:CPM_	DEST 195-01	365-01	369-01	459-01	707-01	1087-01	
ALU:CPM_		314-01	503-01	528-01	713-01	722-01	
	740-01	1112-01			206 01	212 01	
ALU:ALU_		258-01	262-01	266-01	306-01	313-01	
	334-01	338-01	523-01	574-01	1070-01 1141-01	1081-01 1150-01	
**** 0	1091-01	1095-01	1107-01	1131-01	1141-01	1120-01	
ALU=0:TI		1083-01					
ALU=0:TS	CRY_RAND 339-01	374-01					
	F:.GLOBAL. 89-01	94-01	99-01	104-01	109-01	115-01	
ALO_IDD	120-01	125-01	130-01	135-01	140-01	145-01	
	150-01	155-01	160-01	662-01	714-01	741-01	
AND:ALU_		94-01	99-01	104-01	109-01	115-01	
	120-01	125-01	130-01	135-01	140-01	145-01	
	150-01	155-01	160-01	232-01	569-01	574-01	
	584-01	591-01	662-01	745-01	788-01		
AR0:AAB	421-01	423-01	428-01	430-01	561-01	568-01	
	590-01	623-01	702-01	708-01	708-01	713-01	
	723-01	723-01	788-01	791-01 623-01			
AR1:AAB	606-01 785-01	613-01 785-01	619-01	623-01			
AR3:AAB AR5:AAB	314-01	763-01					
	NEXT_EFA:.GLOBAL.	85-01	195-01	202-01	233-01	260-01	
milibrii i	264-01	268-01	308-01	334-01	340-01	375-01	
	459-01	512-01	583-01	717-01	745-01	835-01	
	864-01	885-01	912-01	1020-01	1159-01	1171-01	
ATU_PURG	GING:TEST 784-01						
AY: GLO	BAL. 87-01	92-01	97-01	102-01	107-01	113-01	
	118-01	123-01	128-01	133-01	138-01	143-01	
	148-01	153-01	158-01	660-01	785-01	1118-01	
AY:AG_O	P 366-01	370-01	423-01	430-01	442-01	568-01 703-01	
	590-01 708-01	606-01 715-01	613-01 723-01	623-01 737-01	698-01 742-01	703-01	
	858-01	908-01	959-01	1082-01	142 01	7 71 01	
A SIGN:		200-01	939-01	1002 01			
B:AGB_S		568-01	590-01	613-01	623-01	708-01	
D. RGD_5.	723-01	785-01	791-01	1082-01	1118-01		
B:IS	258-01	266-01	334-01	569-01	591-01	714-01	
2.10	741-01	1150-01					
B:IR	1141-01						
B:ID_SR							
B:FS_SR							
BIT0: .G		523-01					
BIT16:		1001 03					
	FT_LEFT:IS 266-01	1081-01	709-01				
	NDITIONAL 457-01 GLOBAL 259-01	570-01 263-01	709-01 267-01	339-01	374-01		
CARRY:		Symbol Cros			2/4-01		
UASM	00.10.00	0003	- 03				
JASH	55.25.00						

SYMBOL	REFERENCES					
CASE_4_INTO:.GLOBAL.		90-01	95-01	100-01	105-01	110-01
	116-01	121-01	126-01	131-01	136-01	141-01
	146-01	151-01	156-01	161-01	663-01	
CASE_DATA:CPD_DEST	653-01					
CASE_DATA:ALU_DEST	88-01	93-01	98-01	103-01	108-01	114-01
	119-01	124-01	129-01	134-01 661-01	139-01	144-01
0. B.B. WB	149-01	154-01	159-01	991-01		
CLEAR:MF	504-01 87-01	92-01	97-01	102-01	107-01	113-01
CNST:AGB_SRC	118-01	123-01	128-01	133-01	138-01	143-01
	148-01	153-01	158-01	606-01	660-01	698-01
	703-01	715-01	737-01	742-01		
CNST:IS	313-01					
COMPLETE_JUMP: . GLOBA	L.	215-01	230-01			
CPD:.GLOBAL.	1140-01					
CPD:IR	714-01					
CPD_ZERO:IR	313-01	717-01	224 02	265 01	260.01	450.01
CPM:.GLOBAL.	195-01	202-01	314-01 575-01	365-01 619-01	369-01 702-01	459-01 707-01
	503-01 713-01	528-01 722-01	740-01	833-01	856-01	863-01
	885-01	907-01	912-01	936-01	958-01	966-01
	1087-01	1112-01	J12 01	330 01	330 01	300 0
CRE:AG_DEST	785-01	1111				
DECREMENT_DES_POINTS			709-01			
DEFER_ON_FALSE_TEST:		608-01	615-01			
DES:AAB	87-01	87-01	92-01	92-01	97-01	97-01
	102-01	102-01	107-01	107-01	113-01	113-01
	118-01	118-01	123-01	123-01	128-01	128-01 143-01
	133-01	133-01	138-01	138-01 153-01	143-01 158-01	158-01
	148-01	148-01 258-01	153-01 262-01	266-01	306-01	334-01
	195-01 338-01	459-01	660-01	660-01	300-01	334-01
DES: IAB	87-01	92-01	97-01	102-01	107-01	113-01
DES: IAB	118-01	123-01	128-01	133-01	138-01	143-01
	148-01	153-01	158-01	195-01	202-01	258-01
	258-01	262-01	266-01	266-01	306-01	314-01
	334-01	334-01	338-01	338-01	459-01	499-01
	503-01	523-01	561-01	569-01	591-01	660-01
DES:FABC	833-01	834-01	856-01	857-01	863-01	863-01
	885-01	907-01	912-01	998-01	1008-01	1017-01
EJMP: GLOBAL.	214*01					
EJSR:.GLOBAL. ELDA:.GLOBAL.	229*01 194*01					
ELDA: GLOBAL.	457 * 01					
ELEF: GLOBAL.	305*01					
ENABLE_MOF_CORRECTION			1018-01			
ESTA: GLOBAL.	201*01		· · · · · · · · · · · · · · · · · · ·			
EWR+MAG+MOF: EXPR	1020-01					
EXECUTE:.GLOBAL.	488*01					
EXECUTE_DATA: CPM_DES		503-01	528-01			
EXECUTE_PBX:.GLOBAL.		522*01	496-01		1000 07	
EXPONENT: .GLOBAL.	834-01	857-01	999-01	1009-01	1020-01	
EXTEND_MICRO_CYCLE:		307-01				
FA:.GLOBAL.	834-01	857-01 857-01				
FA:EXPR	834-01 1009-01	92/-01				
FA+MOF:EXPR FA-FB:EXPR	999-01					
FAD: GLOBAL.	997*01	966-01				
FAMD: GLOBAL.	958*01	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,				
		ymbol Cro	ss Referen	ce ***		
UASM 00.10.00			- 03			

SYMBOL	REFERENCE	-				
FAMS: GLOBAL.	936*01	026 01				
FAS:.GLOBAL. FD:.GLOBAL.	998*01 863-01	936-01 998-01	1008-01	1017-01		
FG0:FABC	936-01	958-01	966-01	101/-01		
FG0:ALL_REGSS	936-01	960-01	300 01			
FLAG4=0:TEST	510-01	300 01				
FLAG4=1:TEST	513-01					
FLDD: . GLOBAL .	856*01					
FLDS: .GLOBAL.	833*01					
FOR:MEM_STR	366-01	370-01	423-01	430-01	442-01	568-01
	590-01	606-01	613-01	623-01	698-01	703-01
	708-01 858-01	715-01 908-01	723-01 959-01	737-01 1082-01	742-01	791-01
FPU:FPU_DEST	1017-01	908-01	959-01	1002-01		
FP_HIGH: CPM_DEST	833-01	856-01	936-01	958-01		
FP_HIGH: CPM_SRC	885-01	907-01	330 01	330 01		
FP_LOW:CPM_DEST	863-01	966-01				
FP_LOW:CPM_SRC	912-01					
FRND: .GLOBAL.	1017*01					
FSTD:.GLOBAL.	907*01					
FSTS:.GLOBAL.	885*01			554.03	7.42 03	770 01
GOTO: CONDITIONAL	491-01	496-01	510-01	564-01	743-01 1113-01	779-01 1135-01
	784-01 1142-01	1065-01	1071-01	1083-01	1113-01	1135-01
GOTO:.GLOBAL.	215-01	314-01	367-01	371-01	442-01	489-01
	505-01	530-01	592-01	609-01	791-01	936-01
	966-01	1151-01				
GR0:IAB	313-01	365-01	369-01	373-01	574-01	579-01
	584-01	1081-01	1095-01	1095-01	1107-01	1107-01
CD1 - TAD	1112-01	734 03	1001 01	1101 01		
GR1:IAB GR2:IAB	707-01 1087-01	714-01 1091-01	1091-01 1124-01	1101-01		
GR5:IAB	523-01	527-01	528-01			
HEX_SHIFT_RIGHT: IS	88-01	93-01	98-01	103-01	108-01	114-01
	119-01	124-01	129-01	134-01	139-01	144-01
	149-01	154-01	159-01	561-01	661-01	1091-01
ID:.GLOBAL.	491-01	562-01				
ID_SIGN=1:TEST	496-01	570-01				
<pre>IF:.GLOBAL.</pre>	85-01	309-01	457-01	491-01	496-01	510-01
	513-01	564-01	570-01 746-01	624-01 779-01	709-01 784-01	718-01 1065-01
	724-01 1071-01	743-01 1083-01	1113-01	1135-01	1142-01	1002-01
INC: GLOBAL.	262*01	1003-01	1115 01	1133-01	1142 01	
INCREMENT_SRC_POINT			724-01	743-01		
INDIRECT: TEST	624-01					
INTERRUPT_PENDING:		1071-01	1142-01			
INWARD_REFERENCE: T		309-01				
IN_CURRENT_RING:ME		590-01				
IOCMD: GLOBAL.	1101-01	1124-01				
IOCMD1:.GLOBAL. IO_BUSY:TEST	1095-01 1113-01	1135-01				
IO_CONTROLLER:CPD_I		1100-01	1106-01	1119-01	1125-01	1130-01
10_0011110222111012_	1140-01	1100 01	1100 01			
IS>=IR:TEST	718-01	746-01				
IY: .GLOBAL .	88-01	93~01	98-01	103-01	108-01	114-01
	119-01	124-01	129-01	134-01	139-01	144-01
	149-01	154-01	159-01	232-01	258-01	262-01
	266-01	306-01	313-01	334-01	338-01	373-01
	421-01	428-01	499-01	523-01	527-01	561-01
UASM 00.10.00	**	Symbol Cro	ss Reference - 03	e •••		

	YMBOL	REFERENC	ES					
_		569-01	574-01	579-01	584-01	591-01	661-01	
		717-01		788-01	1063-01	1070-01	1081-01	
		1091-01	1095-01	1101-01	1107-01	1124-01	1131-01	
		1141-01						
J	MP:.GLOBAL.	215*01	791-01					
J	SR:.GLOBAL.	230*01						
	AR:IR	306-01		338-01				
I	AST_LA:AGB_SRC	366-01		423-01	430-01	858-01	908-01	
		959-01						
	DA: GLOBAL.	195*01						
	DB:.GLOBAL.	442*01						
	EADING_ZERO_DETECT		1009-01					
	EF:.GLOBAL.	306*01						
	FAMD: GLOBAL.	956*01						
	FAMS: GLOBAL.	934*01 854*01						
	FLDD: GLOBAL.	831*01						
	FLDS:.GLOBAL. FSTD:.GLOBAL.	905*01						
	FSTS:.GLOBAL.	883*01						
	JMP: GLOBAL.	212*01						
	JSR: GLOBAL.	227*01						
	LDB: GLOBAL.	455*01						
	LEF: GLOBAL.	303*01						
	NLDA:.GLOBAL.	192*01						
	NSBI: GLOBAL.	369*01						
	NSTA: .GLOBAL.	199*01						
	OAD_SIGNS:.GLOBAL.	998-01	1009-01					
L	WLDA: .GLOBAL.	190 * 01						
L	WSBI:.GLOBAL.	365*01						
L	WSTA:.GLOBAL.	197*01						
M	l:IAB	89-01	94-01	99-01	104-01	109-01	115-01	
		120-01	125-01	130-01	135-01	140-01	145-01	
		150-01	155-01	160-01	232-01	421-01	428-01	
		569-01	574-01	591-01	662-01	745-01	788-01	
.,	DE DEAD ONE ONG	1070-01	1141-01	1150-01	459-01	575-01	619-01	
M	EM_READ:CPM_SRC	195-01 702-01	365-01 707-01	369-01 833-01	856-01	863-01	936-01	
		958-01	966-01	1087-01	920-01	903-01	930-01	
м	EM_WRITE:CPM_DEST	202-01	713-01	722-01	740-01	885-01	907-01	
rı	BH_#KIIB:CFR_DESI	912-01	713-01	722-01	740-01	003-01	307-01	
м	EM_WRITE:ALU_DEST	373-01	579-01	717-01				
	ODIFY_FLAGS_0123:.0		1064-01	.1, 01				
	ODIFY_FLAGS_4567:.		504-01	509-01	512-01	530-01		
	:MF	504-01	504-01	504-01	509-01	509-01	509-01	
••		512-01	512-01	512-01	530-01	530-01	530-01	
		1064-01	1064-01	1064-01	-	-		
N	ADDI:.GLOBAL.	338*01						
N	ORMALIZED_WR:FS_SRO		1017-01					
N	ORMAL_XCT:.GLOBAL.	498*01	491-01			*		
	OT:TEST	309-01	491-01	624-01	1142-01			
	OTST: GLOBAL.	717*01						
	OT_AND:ALU_OP	306-01	1081-01					
	SL:.GLOBAL.	703-01						
	SP:.GLOBAL.	698-01	715-01					
	STK_OVERFLOW:.GLOBA		23*01	718-01				
	NE:AAB	708-01	723-01	507 01	570 03	717 0	1005 01	
0	R:ALU_OP	313-01	523-01	527-01	579-01	717-01	1095-01	
_		1101-01	1124-01	440 01	F00 03	633.03	600.01	
P.	ASS:AGB_SRC	366-01	370-01	442-01	590-01	613-01	698-01	
U.		⊼ ≒ ≒	Symbol Cross	s kererence	. ×××			

SYMBOL	REFERENCES	3					
			701 01	1002 01			
	703-01 776*01	715-01	791-01	1082-01			
PATU: GLOBAL.	784*01	784-01					
PATUW: GLOBAL.	791-01	784-01					
PC:AG_DEST	784-01						
PC:PDR_SRC PC_OF_EXECUTION:PDI		457-01	1151-01				
	457-01	437 01	1131 01				
PC_REL_INDEX:TEST	230-01	457-01	653-01	713-01	740-01	784-01	
PDR:.GLOBAL.	1100-01	1106-01	1119-01	1125-01	1130-01	1151-01	
PDR:ALU_DEST	88-01	93-01	98-01	103-01	108-01	114-01	
PDR:ALO_DESI	119-01	124-01	129-01	134-01	139-01	144-01	
	149-01	154-01	159-01				
PDR:IS	232-01	421-01	428-01	717-01	745-01		
PDR:IR	88-01	89-01	93-01	94-01	98-01	99-01	
	103-01	104-01	108-01	109-01	114-01	115-01	
	119-01	120-01	124-01	125-01	129-01	130-01	
	134-01	135-01	139-01	140-01	144-01	145-01	
	149-01	150-01	154-01	155-01	159-01	160-01	
	661-01	662-01	788-01				
POINT_SRC_TO:.GLOB		936-01	960-01				
PRESCALED_WR:FS_SR							
PRESCALE_OPERAND:W		999-01		1065 03			
PRIVILEGE_PROTECTI	ON: GLOBAL.	26*01	779-01	1065-01			
PROTECTION_FAULT:.		25*01	314-01				
PRT_RMX:.GLOBAL.	313-01						
PSH: GLOBAL.	698*01	709-01	724-01				
PSHL: GLOBAL.	722*01 713*01	709-01	724-01				
PSHM: GLOBAL.		788-01					
PURGE_THE_ATU_CACH Rl:RSHIFT	88-01	93-01	98-01	103-01	108-01	114-01	
KI;KSHIFI	119-01	124-01	129-01	134-01	139-01	144-01	
	149-01	154-01	159-01	561-01	661-01		
R4:RSHIFT	1091-01	10. 01					
READ_BYTE:MEM_STR	423-01	442-01					
READ_DOUBLE: MEM_ST		613-01	858-01	959-01	1082-01		
READ_PC_BYTE: .GLOB		420*01	457-01				
READ_WORD:MEM_STR	698-01	703-01					
RESTARTABLE_INTERR	UPT: .GLOBAL	•	27*01	1151-01			
RETURN: . GLOBAL .	195-01	202-01	233-01	260-01	264-01	268-01	
	334-01	340-01	375-01	424-01	431-01	459-01	
	586-01	835-01	864-01	885-01	912-01	1020-01	
DEMUNDS DE ON GOMO	1159-01	1171-01	309-01	513-01	624-01	718-01	
RETURN_ELSE_GOTO: C	724-01	85-01 746-01	203-01	212-01	024-01	710 01	
RETURN_PC:PDR_SRC	230-01	/40-01					
RETURN_PC:PDR_SRC RING<>0:TEST	779-01	1065-01					
RMAX_PROTECTION:.G		311*01	309-01				
ROUND_BIT:FR_SRC	1017-01	311 01	302 31				
SELECTED_A:FR_SRC	1008-01						
SET:MF	530-01	1064-01					
SHIFT_MAG:.GLOBAL.	1009-01						
SIGN: GLOBAL.	1019-01						
SKIP_ON: .GLOBAL .	259-01	263-01	267-01	585-01			
SL: IAB	741-01					- 40 03	
SP:AAB	737-01	737-01	740-01	741-01	742-01	742-01	
	745-01						
SPAD:ALU_DEST -	499-01	527-01		1001 61	1005 01	1101 01	
SPAD: IS	306-01	523-01	574-01	1081-01	1095-01	1101-01	
	1124-01		- 5-5	+++			
	***	Symbol Cros	s Referer - 03	ice ***			
UASM 00.10.00							

SYMBOL	REFERENCE						
SPAD:ID_SRC	491-01						
SPAR: GLOBAL.	563-01						
SPAR:R_SPAD	574-01						
SPAR_TABLE_OFFSET:A		569-01	591-01				
SRC:AAB SRC:IAB	442-01 258-01	568-01 262-01	606-01 266-01	653-01 562-01	713-01	722 01	
SKC: IAB	740-01	262-01	200-01	362-01	/13-01	722-01	
SRC:FABC	998-01	1008-01					
SRC<>DES:TEST	709-01	743-01					
SRC=DES:TEST	564-01	724-01					
SRC_POINTER: IR	373-01						
STA: GLOBAL.	202*01						
START: GLOBAL.	366-01	370-01	423-01	430-01	442-01	568-01	
	590-01	606-01	613-01	623-01	698-01	703-01	
	708-01	715-01	723-01	737-01	742-01	791-01	
CONTROL OF OR	858-01	908-01	959-31	1082-01			
START_EXECUTE:.GLOB SUBL:.GLOBAL.	AL. 266*01	499-01	523-01				
TOGGLE:MF	509-01	512-01					
TREG: CPM_DEST	575-01	1112-01					
TREG: PDR_SRC	1100-01	1106-01	1125-01	1130-01			
TREG:ALU_DEST	1063-01	1095-01	1101-01	1124-01			
TREG: IR	579-01	584-01	1070-01				
TRUNCATED_IF_NOT_RO	UNDING:.GL	OBAL.	1008-01				
TWO:AAB	858-01	908-01	959-01	1118-01			
UPDATE_FPSR:.GLOBAL		834-01	857-01	1020-01			
UPDATE_OVR: GLOBAL.	339-01	374-01					
WADDI: GLOBAL.	336*01						
WAIT:.GLOBAL. WASHM17:.GLOBAL.	1171*01	215-01					
WBITW: GLOBAL.	1081-01 606*01	570-01					
WBITW1:.GLOBAL.	613*01	624-01					
WBITW2:.GLOBAL.	619*01	609-01					
WBR:.GLOBAL.	211*01						
WCOB: .GLOBAL.	653*01						
WCOB1:.GLOBAL.	660*01	85-01					
WCOBTAB: .GLOBAL .	85*01	90-01	95-01	100-01	105-01	110-01	
	116-01 146-01	121-01 151-01	126-01	131-01	136-01	141-01	
WIDE_JUMP:MEM_STR	791-01	121-01	156-01	161-01	663-01		
WITH_WORD_ADDRESSING		423-01	430-01				
WLDB: .GLOBAL.	441 * 01	425 01	430-01				
WLMP:.GLOBAL.	1057*01						
WLMP_DONE:.GLOBAL.	1154*01	1083-01					
WLMP_HI_WAIT:.GLOBAI		1112*01	1113-01				
WLMP_INT:.GLOBAL.	1145*01	1071-01					
WLMP_LOOP:.GLOBAL.	1074*01	1142-01					
WLMP_LO_WAIT:.GLOBAL		1135*01	1135-01				
WNADI:.GLOBAL.	337*01						
WORD_ZERO_EXTEND: IS WPSH: .GLOBAL .	499-01 737*01						
WPSHT:.GLOBAL.	745*01						
WPSH_LOOP: GLOBAL.	739*01	743-01					
WR:FPU_DEST	1008-01	/ #3-0I					
WR: GLOBAL.	999-01						
WRITE_BYTE:MEM_STR	430-01						
WRITE_DOUBLE:MEM_STR	l	366-01	737-01	742-01	908-01		
WRITE_PC_BYTE:.GLOBA	L.	427 * 01					
WRITE_WORD:MEM_STR	370-01	568-01	590-01	623-01	708-01	715-01	
	***	Symbol Cross	n	***			

```
REFERENCES
       SYMBOL
                                                                                                                                                                                                           723-01
                                                                                                                                                                                                                                                                                                               24*01
                                                                                                                                                                                                                                                                                                                                                                                                746-01
     WSTK_OVERFLOW:.GLOBAL.
WSZBO:.GLOBAL.
WSZBOBIT:.GLOBAL.
WSZBONRM:.GLOBAL.
                                                                                                                                                                                                           561*01
590*01
574*01
489*01
                                                                                                                                                                                                                                                                                                         564-01
WSZBOBIT:.GLOBAL. 5
WSZBONRM:.GLOBAL. 5
XCT:.GLOBAL. 4
XCTED_INSTRUCTION:TEST
XCTOP:.GLOBAL. 5
XCT_WAIT1:.GLOBAL. 5
XFAMD:.GLOBAL. 9
XFAMD:.GLOBAL. 9
XFAMD:.GLOBAL. 8
XFIDD:.GLOBAL. 8
XFIDD:.GLOBAL. 8
XFIDS:.GLOBAL. 8
XFIDS:.GLOBAL. 8
XFSTS:.GLOBAL. 9
XFSTS:.GLOBAL. 2
XLSST:.GLOBAL. 2
XLSST:.GLOBAL. 2
XLSB:.GLOBAL. 2
XLSB:.GLOBAL. 2
XLSB:.GLOBAL. 3
XNSBI:.GLOBAL. 1
XWSDA.GLOBAL. 1
XWSDA.G
                                                                                                                                                                                                                                                                                                         592-01
                                                                                                                                                                                                                                                                                                         491-01
                                                                                                                                                                                                             491-01
509*01
512*01
957*01
935*01
855*01
855*01
832*01
906*01
228*01
228*01
193*01
193*01
193*01
191*01
194*01
                                                                                                                                                                                                                                                                                                         499-01
505-01
513-01
                                                                                                                                                                                                                                                                                                                                                                                                      527-01
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          530-01
                                                                                                                                                                                                                                                                                                                                                                                                      510-01
                                                                                                                                                                                                                                                                                                           367-01
                                                                                                                                                                                                                                                                                                                                                                                 371-01
                                                                                                                                                                                                           1119-01
                                                                                                                                                                                                           1140-01
262-01
                                                                                                                                                                                                                                                                                                             527-01 1063-01 1107-01 1131-01
               ZERO:FS_SRC
                                                                                                                                                                                                                    863-01
                                                                                                                                                                                                                                                 *** Symbol Cross Reference ***
0009 - 03
                                                                                      00.10.00
               UASM
```

```
.EJECT; .TITLE "Widgeon Microcode: SAMPLES Code Group"
 2A
3A
4B
5B
6B
7B
8B
9B
10B
11B
      **BEGIN;
-HD 1 "Proprietary information of Data General Corporation";
-HD 2 "";
      RADIX 16;
FT 2 "SAMPLES
                                                                                   09-DEC-82 10:47:39 RGG"
                                                                Rev 1
                                Instruction Set Microcode
 •
                                                     Rev 1
                                                                      09-DEC-82 10:47:39 RGG
                 Instruction Set Microcode
SAMPLES
                                        0001 - 01
       00.10.00
UASM
```

```
Proprietary information of Data General Corporation
    12B /*----
    13B*
14B*
15B*
16B*
                       External definitions for Widgeon microcode samples.
                      Some of the samples reference routines that, for the sake of brevity, are not worth including in the samples. The number of such references in the collection will be kept to a minimum.
    18B*
19B*
20B*
     21B* +
                                   NSTK_OVERFLOW,
WSTK_OVERFLOW,
PROTECTION_FAULT,
PRIVILEGE_PROTECTION,
RESTARTABLE_INTERRUPT;
          .EXTERNAL
    24B
     25B
     28B
           .RADIX 16;
    2 9B
      0
                                                                                             09-DEC-82 10:47:39 RGG
                                                                       Rev 1
                            Instruction Set Microcode
     SAMPLES
                                                       0002 - 01
                00.10.00
     UASM
```

```
Proprietary information of Data General Corporation
    30B .EJECT;
                                                    Source File
                                                                                                         Cycle 1
                                                                                                                                    18-AUG-82 15:24:34 RGG"
     32B
33B
     3 4B
3 5B*
3 6B*
                            Widgeon Microcode Samples
     37B*
                      This collection of sample microcode is taken directly from Widgeon sources. Each selection is, as far as practical, the code for an entire macro instruction. Selections are presented in order of increasing complexity.
     38B*
     39B*
40B*
41B*
     42B*
     43B*
     44B
45B
     46B*
     47B*
48B*
49B*
                         A note regarding style:
                      Having been drawn from the sources, the samples display
a variety of documentation and coding styles. These
variations are preserved mainly to minimize the task of
compiling the samples.
     50B*
     51B*
     54B*
                Instruction Set Microcode Rev 1 09-DEC-82 10:47:39 RGG Source File Cycle 1 18-AUG-82 15:24:34 RGG 00:10:00 0003 - 01
    SAMPLES
    SAMPLES
```

```
Proprietary information of Data General Corporation
      55B .EJECT;
56B .FT 1 "TABLES
                                           Source File
                                                                                     Cvcle 1
                                                                                                         18-AUG-82 15:24:34 RGG"
            /*-----
      5 9B
      60B*
      60B* |
61B* |
               Dispatch table for WCOB instruction, which appears in an example below.
     62B*
63B*
64B*
                       $ **********************
     68B
                                             BIT INSTRUCTION DISPATCH TABLES
     73B
74B
75B
76B
77B
78B
79B
80B
                                 WCOBTAB - Used by WCOB, COB
                       % Dispatch table is based on the number of bits set (which is added to DES).
% AG: CPM <- DES <- DES + CONST; Load DSP REG;
% ALU: CPD <- PDR <- RSHIFT(PDR); DES <- CPM
% F bus <- PDR AND M1 for FZR test
     81B
 --DFVs: addr is WCOB1 (003B)
             AY = AG(DES) = ALU(DES) == CNST(01) + A(DES),
IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),
ALU_TEST == A(M1) AND PDR,
CASE_4_INTO WCOBTAB;

OP TSEL ADDRESS DAA AB AG AGP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X DSPA WCOBTAB F DES DES C ADD Y AG IY GN LD M1 DES PD DA AND HR0 M 01
R1
     86 B
--0001--
88B
89B
90B
--DFVs: addr is WCOBTAB (0000)
             AY = AG(DES) = ALU(DES) == CNST(01) + A(DES),
IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT(R1, PDR),
ALU_TEST == A(M1) AND PDR,
CASE_4_INTO WCOBTAB;

OP TSEL ADDRESS D AA AG AOP AL ST CM CPM CPM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X DSPA WCOBTAB F DES DES C ADD Y AG IY GN LD R1 DES PD DA AND HR0 M 01
R1
91B
--0002--
    93B
94B
    95B
--DFVs: addr is WCOBTAB (0000)
96B
--0003--
                     AY = AG(DES) = ALU(DES) == CNST(02) + A(DES),

IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),

ALU_TEST == A(M1) AND PDR,
SAMPLES Instruction Set Microcode Rev 1 09-DEC-82 10:47:39 RGG TABLES Source File Cycle 1 18-AUG-82 15:24:34 RGG
TABLES Source File Cycle 1
UASM 00.10.00 0004 - 01
```

```
Proprietary information of Data General Corporation
           OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X DSPA WCOBTAB F DES C ADD Y AG IY GN LD M1 DES PD DA AND HRO M 02
            addr is WCOBTAB (0000)
--DFVs:
101B
--0004--
           AY = AG (DES) = ALU(DES) == CNST(01) + A(DES),
IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),
ALU_TEST == A(M1) AND PDR,
CASE_4_INTO WCOBTAB;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X DSPA
WCOBTAB F DES DES C ADD Y AG IY GN LD M1 DES PD DA AND HR0 M 01
R1
R1
  103B'
104B
  105B
            addr is WCOBTAB (0000)
--DFVs:
106B
--0005--
            108B
  109B
--DFVs:
111B
112B
            addr is WCOBTAB (0000)
           --0006-
  116B
--DFVs:
117B
--0007--
           --DFVs:
122B
            addr is WCOBTAB (0000)
            AY = AG(DES) = ALU(DES) == CNST(01) + A(DES),
IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),
ALU_TEST == A(M1) AND PDR,
CASE_4_INTO WCOBTAB;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X DSPA WCOBTAB F DES DES C ADD Y AG IY GN LD M1 DES PD DA AND HR0 M 01
R1
--0008--
124B
125B
--DFVs:
127B
--0009--
129B
           addr is WCOBTAB (0000)
                   AY = AG(DES) = ALU(DES) == CNST(02) + A(DES),

IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),

ALU_TEST == A(M1) AND PDR,
                   Instruction Set Microcode Rev 1 Source File 0 0005 - 01
                                                                            09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
SAMPLES
TABLES UASM 00.10.00
```

```
Proprietary information of Data General Corporation
                                OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPN CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X DSPA WCOBTAB F DES DES C ADD Y AG IY GN LD M1 DES PD DA AND HRO M 02
        131B
  --DFVs: addr is WCOBTAB (0000)
                             AY = AG(DES) = ALU(DES) == CNST(02) + A(DES),

IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),

ALU_TEST == A(M1) AND PDR,

CASE_4_INTO WCOSTAB;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X DSPA

WCOSTAB F DES DES C ADD Y AG IY GN LD M1 DES PD DA AND HR0 M 02

R1
        134B
135B
        136B
  --DFVs: addr is WCOBTAB (0000)
       137B
-000B--
                              AY = AG(DES) = ALU(DES) == CNST(03) + A(DES),
IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),
ALU_TEST == A(M1) AND PDR,
CASE_4_INTO WCODTAB;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
DSPA WCOBTAB F DES DES C ADD Y AG IY GN LD M1 DES PD DA AND HR0 R1
R1
R1
        139B
  --DFVs: addr is WCOBTAB (0000)
142B
--000C-- AY = AG(DES) = A
                             AY = AG(DES) = ALU(DES) == CNST(02) + A(DES),

IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),

ALU_TEST == A(M1) AND PDR,

CASE_4_INTO WCOSTAB;

OP TSEL ADDRESS D AA : A AOP AL ST CM CPM CPM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X DSPA WCOSTAB F DES DES C ADD Y AG IY GN LD M1 DES PD DA AND HR0 M 02

R1
       144B
145B
        146B
     -DFVs: addr is WCOBTAB (0000)
  147B
--000D--
                             AY = AG(DES) = ALU(DES) == CNST(03) + A(DES),

IY = PDR = CASE_DATA == HEX_SHIFT_RIGHT( R1, PDR),

ALU_TEST == A(M1) AND PDR,

CASE_4_INTO WCOBTAB;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X DSPA

WCOBTAB F DES DES C ADD Y AG IY GN LD M1 DES PD DA AND HR0 M 03

R1
       149B
150B
151B
     -DFVs: addr is WCOBTAB (0000)
152B
-000E-- AY = AG(DES) = A
                            154B
155B
156B
   --DFVs: addr is WCOBTAB (0000)
TABLES | Instruction Set Microcode | Rev | 1 | 09-DEC-82 | 10:47:39 | RGG | Cycle | 1 | 18-AUG-82 | 15:24:34 | RGG | RGG
```

```
Proprietary information of Data General Corporation
   162B .EJECT;
163B .FT 1 "MEM
                                                                                                        Cycle 1 18-AUG-82 15:24:34 RGG"
                                                     Source File
    164B
    165B
                            Memory references for the next macro instruction can be started by the IP from decode information. In these two examples, the completion of an IP initiated memory reference is shown. The completion is generic, i.e. read or write. The start instigated by the IP specified the
    168B*
    169B*
    170B*
171B*
    172B*
173B*
                            exact type of transfer to perform.
    174B*
175B*
176B*
                           Also shown here is the attempt of the next EFA on behalf of the next executing macro instruction. This attempt must be made in the last micro cycle of every macro instruction The combination of the attempt and popping an empty micro stack constitutes a macro instruction pop (IPOP).
    177B*
    178B*
    181B*
    182B
    183B
                            185B
    1.86B
                             -

% Perform load or store of AC pointed to by DES. IPOP.
    188B
    189B
   -0010--LWLDA •
--0010--LWLDA:

--0010--LNLDA:

--0010--XNLDA:

--0010--ELDA:
--0010--LDA:
--0010--LDA:
OP
                           CPM = AG(DES) = ALU(DES) == MEM_READ, ATTEMPT_NEXT_EFA, RETURN;
TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
TRUE DES D EFA M S0 R MM
                 CRTN TRUE
--DFVs:

196B

--0011--LWSTA:

--0011--XWSTA:

--0011--XNSTA:

--0011--ESTA:

--0011--STA:
                 DIA:
TA: CPM = MEM_WRITE == ALU(DES), ATTEMPT_NEXT_EFA, RETURN;
OP TSEL ADDRESS DAA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CRTN TRUE D EFA S@ W IA DES
--0011--STA:
OP
--DFVs:
   203B
204B
205B
                            Jump Instructions: WBR, LJMP, XJMP, EJMP
    206B
    207B
    208B
                              Complete IPST. Go to IP_ALT WAIT.
    209B
210B
   -0012--WBR:
                                                                                               09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
         LES Instruction Set Microcode Rev 1
Source File Cycle 1
00.10.00 0008 - 01
SAMPLES
```

```
Proprietary information of Data General Corporation
--0012--IJMP:
--0012--LJMP:
--0012--EJMP:
--0012--JMP:
OP
                    COMPLETE_JUMP, GOTO WAIT;
TSEL ADDRESS DAA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X WAIT
            LEAP
--DFVs: addr is WAIT (OFFF)
  217B
  218B
                     Jump Subroutine Instructions: <L X E >JSR
Read PCN (Return PC) into PDR; Complete IPST.
  219B
220B
  221B
  222B
   223B
                     % Move PDR to AC3, AG3; and IPOP.
  224B
225B
  226 B
--0013--LJSR:
--0013--XJSR:
--0013--EJSR:
             SR: COMPLETE_JUMP, PDR == RETURN_PC;
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CJMP FALSE W PCN
--0013--JSR:
--DFVs:
231B
                 IY = AG(AG3) = ALU(AC3) == PDR AND A(M1),
ATTEMPT_NEXT_EFA, RETURN;
TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO RL R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
TRUE AG3 D EFA M S@ IY M1 AC3 PD AD AND PASS Y
--0014--
             CRTN TRUE
--DFVs:
  •
  •
                                                                                  09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
SAMPLES
                     Instruction Set Microcode
                                                             Rev
                     Source File Cycle 1
```

```
Proprietary information of Data General Corporation
   234B .EJECT;
235B .FT 1 "ALC
236B;
237B
238B /*----
                                                                                  Cycle 1
                                                                                                   18-AUG-82 15:24:34 RGG"
    239B*
   240B* |
241B* |
242B* |
243B* |
                    Some Nova ALC instructions illustrate the use of the ALU for simple arithmetic. The shift operation is used along with the ALC opcode to provide the decode address. Carry, no-load and skip options are accelerated with hardware.
   244B*
245B*
   246B
247B
248B
249B
250B
251B
                      %*******
% NOVA Arithmetic and Logical Instructions
                                                       l cycle no skip
2 cycles skip, no EFA required
                      % EXECUTION TIME: 1 cycle no skip
% 2 cycles skip, no EFA required
%
% Perform ALU operation; then Pass, Shift, or Swap; Write result to AG
% and ALU AC pointed to by DES. Enable ALC skip and IPOP.
%********
    252B
   253B
254B
255B
 --DFVs:
--PFVS:
265B
--0017--SUBL: IY = AG(DES) = ALU(DES) == BIT_SHIFT_LEFT( B(DES) - A(SRC) ),
267B
268B

OP
TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2
CRTN TRUE

OP
TRUE

DES D EFA M S@ IY XZ ALC

SRC DES BR AD CSR BLO Y
--DFVs:
269B
                     Instruction Set Microcode Rev 1
Source File Cycle 1
SAMPLES
                                                                                 09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
ALC Source File UASM 00.10.00
```

```
Proprietary information of Data General Corporation
   270B .EJECT;
271B .FT 1 "IMMEDIATE
                                         Source File
                                                                                       Cycle 1 18-AUG-82 15:24:34 RGG"
   273B
274B
   275B* |
276B* |
                       A Load Effective Address instruction is nothing more
    277B*
                       than an aborted memory reference. The final contents of
the Logical Address Register are loaded, via the CPD bus
   278B*
   279B*
                       and ALU, into the required registers.
   280B*
281B*
                       The architecture specifies that the effective address is checked for a ring crossing error. This check will not be performed by hardware because the memory operation used to generate the address is aborted. A micro test is used to check validity.
   282B*
   283B*
   286B*
                       287B*
   290B*
   291B* +----
   292B
293B
294B
                       295B
                       % Load Effective Address: LEF, ELEF, XLEF, LLEF
                       296B
297B
298B
299B
   300B
   301B
302B
--0018--LLEF:
--0018--XLEF:
--0018--ELEF:
             LEF:

EF: IY = AG(DES) = ALU(DES) == SPAD(BITO) NOT_AND LAR,

EXTEND_MICRO_CYCLE,

ATTEMPT_NEXT_EFA, ABORT_MEMORY,

IF NOT INWARD_REFERENCE RETURN_ELSE_GOTO RMAX_PROTECTION;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X CRTN NRMAX RMAX_PRO DES D EFA M S@ A IY LAR GN XTND DES SC CD ANC PASS Y BITO
   307B
308B
   309B
--DFVs: addr is RMAX_PROTECTION (0019) const is BITO (0000)
  310B
-0019--
           RMAX_PROTECTION:
                       ABORT MEMORY.
   312B
313B
             ABORT_MEMORY,
IY = ALU(GRO) == CNST(PRT_RMX) OR CPD_ZERO,
CPM = AG(ARS) == ALU(DES), GOTO PROTECTION_FAULT;
OP TSL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL PR FS FOP W FCW FL FRG X
LEAP PROTECTI ARS M A IA N DES GRO CN CD OR PASS Y PRT_RMX
--DFVs:
315B
316B
            addr is PROTECTION_FAULT (0002 *EXT*) const is PRT_RMX (0004)
SAMPLES
                                                                                       09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
                       Instruction Set Microcode
                                                                 Rev l
Cycle l
IMMEDIATE
UASM 00
                       Source File
                                         0011 - 01
           00-10-00
```

```
Proprietary information of Data General Corporation
      318B* |
319B* |
                                 Instructions which load immediate data from the instruction stream use an approach similar to the LEF instructions. In their case, the immediate data has been loaded into the LAR by the IP as specified by decode information, but no memory reference has been initiated.
      320B* I
      321B* |
322B* |
323B* |
       324B*
       328B
      329B % Long Add Immediates: <W N > ADDI
330B % DES + (Displacement) -> DES
                                   DES + (Displacement) -> DES (Displacement is in LAR)
The W and N types load overflow into OVR and CRY<0 16> into CARRY.
      332B %**
      333B
 --001A--ADDI: IY = ALU(DES) = AG(DES) == B(DES) + LAR, ATTEMPT_NEXT_EFA, RETURN;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X

CRTN TRUE DES D EFA M SQ IY LAR DES BR CD ADD PASS Y
--DFVs:
335B
--O01B--WADDI: % For the 32-bit Immediate
--O01B--WADDI: % For the 16-bit Immediate
--O01B--WADDI: IY = ALUCES) = AG(DES) = LAR,
339B
CARRY == ALUCRY, UPDATE_OVR,
340B
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CRTN TRUE
DES D EPA M S@ IY LAR XZ LOVC
DES DES CA ADD PASS Y
                   Instruction Set Microcode Rev 1
Source File Cycle 1
00.10.00 0012 - 01
                                                                                                                                  09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
  SAMPLES.
  IMMEDIATE
UASM 0
```

```
Proprietary information of Data General Corporation
         344B* |
345B* |
                                              A short immediate field is derived from the source accumulator bit field of the macro instruction. Actual values are 0 through 3, but implied values are 1 through 4. The following instructions read an operand from a memory location, subtract the implied immediate data from it, and store the result back in the same memory location.
          348B*
          349B*
          3452B*
         353B
         356B % Short Subtract Immediate from Memory: <L X><W N >SBI 357B %
                                      MEM - ([ACS] + 1) -> MEM
         358B %
        360B % Read Memory operand into ALU (GRO). Start same address to write back.
361B % Go to XLSBI to complete the operation and perform the write.
362B %***********
--DFVS: addr is XLSBI (001E)
--001D--XNSBI:
--001D--LNSBI:
--001D-
 --DFVs: addr is XLSBI (001E) 372B
--DFVs:
                           TE Source File Cycle 1
00.10.00 0013 - 01
                                                                                                                                                                                                               09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
  IMMEDIATE
```

```
Proprietary information of Data General Corporation
               .EJECT;
.FT 1 "BYTE
                                                                                                                                                                   18-AUG-82 15:24:34 RGG"
                                                                    Source File
                                                                                                                                      Cycle 1
    378B
379B
     3808
    381B* |
382B* |
                                   These selections from the byte microcode show the use of a conditional subroutine call, a memory start using the address generator, and a memory abort. A copy of the PC of execution + 1 is moved to the address generator by first loading PCX into PDR, and then subtracting -1 from it and loading the result in the AG register file via the CPM bus.
     383B*
     384B*
     385B*
     386B*
387B*
     388B*
    389B*
390B
391B
392B
               £***********************
     393B
394B
395B
                                                                                       Instructions
                                                              Byte EFA
     396B
397B
                                   EFA calculations for a Byte address cannot be completely performed
by the hardware. The PC relative index case cannot be performed
since the Displacement is a byte address and the PC is a word address.
The AG converts the byte displacement and performs the other indexing.
     400B
     401B
     402B
     403B
404B
     405B
                                                    Subroutines to perform
READ/WRITE PC Relative Byte Addresses
PC Relative Addressing must be handled separately since the IP cannot align a Byte displacement.
     406B
407B
     408B
     409B
                                   PC Relative Addressing must be handled separately since the IP cannot align a Byte displacement.

Abort the previous start and move the PC of the instruction plus 1 (PC of the DISP) to the AG (ARO).

Form the PC relative address by adding the Displacement (LAST_LA) to the PC (ARO) and start for the Byte Read/Write. Word addressing must be forced since the addresses have already been aligned to word addresses. Return to the caller.
     410B
411B
412B
     413B
     414B
415B
416B
     418B
419B
001F-
421B
                 -READ_PC_BYTE:
IY = AG(ARO) == PDR - A(M1), ABORT_MEMORY;
OP TSEL ADDRESS DAA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X
CJMP FALSE ARO M A IY M1 PD AD CSR PASS
--DFVs:
422B
--0020--
                                   START AY == LAST_LA + A(ARO) WITH_WORD_ADDRESSING FOR READ_BYTE,
                      RETURN;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X

CRTN TRUE ARO L ADD RB AT WORD
     424B
--DFVs:
425B
SAMPLES
                                   Instruction Set Microcode Rev 1
Source File Cycle 1
                                                                                                                                      09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
                  00.10.00
```

```
Proprietary information of Data General Corporation
 426B
--0021--WRITE_PC_BYTE:
428B IY = AG(AR0) == FDR - A(M1), ABORT_MEMORY;
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X CJMP FALSE ARO M A IY M1 PD AD CSR PASS
--DFVs:
429B
--0022--
             START AY == LAST_LA + A(ARO) WITH_WORD_ADDRESSING FOR WRITE_BYTE,

RETURN;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X

CRTN TRUE ARO L ADD WB AT WORD
--DFVs:
432B
433B
434B
$********
435B
436B
437B
$ Start
438B
$ F
   --UC23--WLDD:
--0023--LDB: START AY == PASS(B(SRC)) FOR READ_BYTE, GOTO LDA;
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X LEAP LDA SRC B PSB RB
 --DFVs: addr is LDA (0010)
  -DFVS: addr is
443B
444B
444B
445B
8*******
446B
8
1447B
8
                   Indexed Load/Store Byte: LLDB, XLDB, ELDB
   454B
--0024--LLDB:
--0024--LLDB:
--0024--XLDB:
--0024--ELDB: PDR == PC_OF_EXECUTION, IF PC_REL_INDEX CALL READ_PC_BYTE;
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X CJSR IXPC READ_PC_ PCX
--DFVs: addr is READ_PC_BYTE (001F)
458B
--0025-- CPM = AG(DES) = ALU(DE
            --DFVs:
460B
461B
SAMPLES
                    Instruction Set Microcode
Source File
0 0015 - 01
                                                                             09-DEC-82 10:47:39 RGG
18-AUG-82 15:24:34 RGG
BYTE
UASM 00.10.00
```

```
Proprietary information of Data General Corporation
  462B .EJECT;
463B .FT 1 "XCT Sour
464B ;
465B 465B /*-----
                                                                                             Cycle 1 18-AUG-82 15:24:34 RGG"
                                               Source File
   46678 | The code for the XCT instruction address SPAD with a 4698* | constant, uses the flags to control sequencing and does 4708* | a word zero extend with the hex shifter.
   473B
474B
475B
                                     XCT Execute an AC's contents
   478B* |
   479B* |
                    DES contains the opcode to be executed
   482B
                        Enter here for ordinary XCT. If restarting or resuming, XCTed opcode must still be in DES. Bit 0 of double word saved in SPAD is cleared to indicate to interrupt handlers that saving XCT opcode on wide stack is not required. Start execute.
   483B %
   487B
4878
--0026--EXECUTE:
--0026--EXECUTE:
--0026--EXECUTE:
--0026--EXECUTE:
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X LEAP
--DFVs: addr is & (0027)
               ID == SPAD(XCTOP), IF NOT XCTED_INSTRUCTION GOTO NORMAL_XCT;
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X CJMP NXCTF NORMAL_X
490B
--0027--
               addr is NORMAL_XCT (0029) const is XCTOP (00C3)
--DFVs:
   492B
493B
494B
495B
                  % If XCT was executed by a PBX, then the XCT should set Bit0 of
% XCTOP since it was virtually executed by the PBX.
               IF ID_SIGN=1 GOTO EXECUTE_PBX;
OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM R0 R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X CJMP DSGN EXECUTE_
 --0028--
--DFVs: addr is EXECUTE_PBX (002D)
-0029-NORMAL_XCT:

499B IY = SPAD( XCTOP ) == WORD_ZERO_EXTEND (A (DES)), START_EXECUTE;

OP TSEL ADDRESS D AA AB AG AOP AL ST CM CPM CPD RM RO R1 R2 IA IB ID RS IOP IY IL FR FS FOP W FCW FL FRG X CJMP FALSE AG0 AG0 B SUB WW AT CM0 WC DES AD WZX NY XCTOP
  -DFVs: const is XCTOP (00C3)
500B
501B % Send instruction to the IP via the Cache.
   502B
                         CPM = EXECUTE_DATA == ALU(DES),

Instruction Set Microcode Rev 1 09-DEC-82 10:47:39 RGG

Source File Cycle 1 18-AUG-82 15:24:34 RGG

0 0016 - 01
 --002A--
SAMPLES
XCT
UASM 00.10.00
```

End of Chapter

Appendix A Page Faults

Page faults occur during Logical Address Translation (LAT). There are two possible causes for page faults:

- A referenced page is not in physical memory. This is indicated by the page table entry RESIDENT bit (bit 1) being 0.
- A referenced page requires a two-level page table when only a one-level page table has been defined. This is indicated when a Segment Base Register (SBR) LENGTH bit (bit 1) is 0, but the logical address bits 4-12 are not zero.

Page Table Entry:

0	1	2 4	5	12	13		31
V	R	ACC		RESERVED	PHYSICAL	ADDRESS	

Segment Base Register:

0	1	2	3	4	31
V	L	LEF	1/0	PHYSICAL ADDRES	5

The LAT trap microcode must determine that the referenced address is nonresident, and then transfer control to the page-fault microcode.

The purpose of the page fault is to pass control to the operating system. The operating system may then bring the nonresident page into physical memory. Before the operating system receives control, microcode pushes a context block to preserve the current state of the hardware.

There are four types of context blocks, only two of which are now implemented. The type of block depends on the instruction executing when the page fault occurred. The following list shows the page-fault types.

- 1) Simple
- 2) Resumable
- 3) Floating Point (not implemented)
- 4) Decimal (not implemented)

Microcode pushes a *simple* context block when the macroinstruction will be restarted after its referenced page is brought into physical memory. A macroinstruction is restartable if the current microcycle is the first cycle of an instruction (i.e., one cycle after an IPOP) or inside an EFA. Restart may also be forced by setting SPAD location PF_RESTART to a nonzero value. An example of an instruction that can only restart is LDA. LDA references memory only during its first cycle.

Microcode pushes a *resumable* context block when a macroinstruction will resume with the microinstruction that was executing when the LAT trap occurred. Because most of the machine-visible state must be saved, a resumable context block is longer than a simple context block. Most instructions that reference memory (except for EFA references) are resumable.

Figure A-1 shows the context blocks.




Figure A-1. Context Blocks

After the context block is pushed, a fault code is returned in AC1:

Code	Meaning		
0	Multiple ERCC fault		
1	Page table depth fault		
2	Page table page fault		
4	Normal object reference		

Note: The multiple ERCC fault is currently a nonrecoverable condition.

End of Appendix

Appendix B CPD Bus Legal Path Analysis

The following figure illustrates legal combinations of sources and destinations for the CPD Bus.

Typical Destinations

	· yprodi				
CPD Source	Into ALU*	PDR DSP CDW ATS/REF ATS/MOD	uSTK IPS ATS/ST	FLAGS**	IOC
TREG USS ZER/N LAR ATD	Type 1	Yes	Yes	Yes	Yes
CIR CDR ATS/STS***	Type 2	Yes	Yes	Yes	Yes
AGA	Type 3	Yes	Yes	Yes	Yes
IOC IPS	Type 4	Yes	Yes	Yes	Yes
ATS/REF*** ATS/MOD*** PCN	Type 5	Yes	Yes	No	No
PCX PC	. , , , ,	Yes	Yes	No	No

^{*} See the ALU path table (Appendix D) for these setups.

^{**} FLAGS can be placed in the uSTK category, if they are guaranteed not to be tested next cycle.

^{***} The ATS source contains two different types of data: ATS/STS is the ATU Status bits and ATS/(REF MOD) is the Reference and Modify bits.

Appendix C CPM Bus Legal Path Analysis

The following figure illustrates legal combinations of sources and destinations for the CPM Bus.

	Typical Destinations			
CPM Source	SPAD	ALU AG FPU CACHE	FPSR	TREG
ALU IY	*	*	*	*
ALU IA	Yes	Yes	Yes	Yes
FPU	Yes	Yes	Yes	Yes
FPSR	Yes	Yes	Yes	Yes
FP STATE	Yes	Yes	Yes	Yes
ALL_ONES	Yes	Yes	Yes	Yes
AG	Yes	Yes	Yes	Yes
MEMORY	Yes	Yes	Yes	Yes

^{*} See ALU path analysis (Appendix D).

End of Appendix

Appendix D **ALU Source and Destination Paths**

The following table illustrates legal sources and destinations for the integer ALU. Sources are classified as follows:

Туре	Sources
1	All ID Bus sources (except SPAD), ALU Register File, TREG, LAR, ZER/N, USS, ATD
2	CIR, CDR, ATS (Except REF and MOD bits)
3	AGA
4	IOC, SPAD, IPS
5	Any PC type, ATS (REF and MOD bits)*

Destinations

Sources	AG RF FP RF FPSR uSTK IPS	SPAD ATS1	Cache	PDR TREG DSP CDW ATS2	ALU Spar
Arithmetics or Hex Shifts					
	Yes	Yes	Yes	Yes	Yes
Type 1 (LAR)		No	No	No	Yes
Type 2 (CIR)	No				
Type 3 (AG)	No	No	No	No	Yes
Type 4 (SPAD)	No	No	No	No	Yes
Logical					
Type 1 (LAR)					
Type 2 (CIR)	Yes	Yes	Yes	Yes	Yes
Type 3 (AG)	Yes	Yes	Yes	Yes	Yes
Type 4 (SPAD)	No	Yes	Yes	Yes	Yes
,	No	No	Yes	Yes	Yes
EDIT Translate AREG only	Yes	Yes	Yes	Yes	Yes

^{*} Types 5 and 6 will not make any destination except PDR class CPD destinations without an EXTEND.

Note: All types will make any desired destination, using any desired operation, if they are extended. Note that SPAD cannot be read and written in the same cycle under any circumstances.

Appendix E Page Zero Locations

By convention, an MV machine has a set of reserved storage locations in page 0 of segment 0 that are used by fault routines. This appendix lists the definitions for those locations.

```
.RADIX 16;
         PAGE ZERO LOCATION DEFINITIONS
   The size of the pointer and whether it is indirectable is indicated
        by a 16, 32, 16I, or 32I at the end of the comment.
+_____ */
.DEFINE INTR_LEV = 00; % Current Level of Interrupt processing (A count DEFINE INTR_HDLR = 01; % Interrupt Handler address - 16I
.DEFINE INTR_RTN = 02; % Interrupt Return address - 32
.DEFINE SYC_HDLR = 02; % System Call Handler address - 16I (if ATU off)
.DEFINE INTR_LEV
                           = 00; % Current Level of Interrupt processing (A count)
                           = 04; % Vector Stack Pointer - 16
= 06; % Vector Stack Limit - 16
= 07; % Vector Stack Fault Handler address - 16I
.DEFINE VSP
.DEFINE VSL
.DEFINE VSF
                      = 08; % Breakpoint Handler address - 32I
= 0A; % Wide XOP Table base address - 32
.DEFINE BKP_HDLR
.DEFINE WXOP_TBL
.DEFINE WSF
                           = OC; % Wide Stack Fault Handler address - 16I
.DEFINE WSF = 0C; % Wide Stack Fault Handler address - 16I
.DEFINE UIT_HDLR = 0D; % Unimplemented Instruction Handler address - 16
.DEFINE WFP = 10; % Wide Stack Frame Pointer - 32
.DEFINE WSP = 12; % Wide Stack Pointer - 32
.DEFINE WSL = 14; % Wide Stack Limit - 32
.DEFINE WSL
                           = 16; % Wide Stack Base - 32
.DEFINE WSB
                         = 18; % Page Fault Handler address - 32I
.DEFINE PGF_HDLR
                           = 1A; % Context Block Area Pointer - 32I
.DEFINE CNTX_BLK
.DEFINE GATE_TBL
                           = 1C; % Gate Array base address - 32
.DEFINE PRT_HDLR
                           = 1E; % Protection Fault Handler address - 16I
.DEFINE FIX_HDLR
                           = 1F; % Fix Point Fault Handler address - 16I
                            = 20; % Narrow Stack Pointer - 16
.DEFINE NSP
.DEFINE NFP
                           = 21; % Narrow Frame Pointer - 16
                            = 22; % Narrow Stack Limit - 16
.DEFINE NSL
                            = 23; % Narrow Stack Fault Handler address - 16I
.DEFINE NSF
.DEFINE NXOP_TBL
                           = 24; % Narrow XOP Table base address - 16
                      = 25; % Floating Point Fault Handler address - 16I
= 26; % Commercial Fault Handler address - 16I
= 27; % Diagnostic From Policy
.DEFINE FLT_HDLR
.DEFINE COM_HDLR
.DEFINE DERR HDLR
                           = 27; % Diagnostic Error Fault handler address - 16I
/* ----- */
```

Appendix F Fault Codes

This appendix lists the MV/10000 fault codes. These codes should be placed in macroaccumulator 1 after a fault occurs.

```
.RADIX 16;
%*****
% DEFINITION OF FAULT CODES
         Protection Faults:
.DEFINE PRT_RD = 00; % Read
                        = 01; % Write
= 02; % Execute
= 03; % Validity of SBR or PTE
.DEFINE PRT_WR
.DEFINE PRT_EX
.DEFINE PRT_VLD
                       = 04; % Inward Memory Reference (Ring Maximization)
= 05; % Defer level exceeded
= 06; % Illegal Gate
.DEFINE PRT_RMX
.DEFINE PRT_DFR
.DEFINE PRT_GATE
                        = 07; % Outward Call
.DEFINE PRT_CALL
                       = 08; % Inward Return
= 09; % Privileged Instruction
.DEFINE PRT_RTN
.DEFINE PRT_PRV
                        = 0A; % IO Protection
.DEFINE PRT_IO
.DEFINE PRT_CB
.DEFINE PRT_IMI
                        = 0B; % Invalid Context Block type
= 0C; % Invalid microinterrupt return block
        Page Faults:
.DEFINE PAG_PTD .DEFINE PAG_PTE
                         = 01; % Page Table Depth exceeded
                          = 02; % Nonresident Page Table
.DEFINE PAG_REF
                          = 04; % Nonresident Reference (object) page
         Wide Stack Faults:
                         = 00; % Any overflow except for WMSP, wide saves, or CALL
.DEFINE STK_OVE
                          = 01; % Underflow or overflow caused by WMSP, wide saves
.DEFINE STK_ABT
                        = 02; % Too many arguments on a CALL
= 03; % Underflow
= 04; % Overflow while pushing return block for
.DEFINE STK_ARG
.DEFINE STK_UNF
.DEFINE STK_FOV
                                   % fault or interrupt
%*****
%********
         Messages to the SCP:
.DEFINE SCP_HALT = 00; % The machine has entered the HALT loop
.DEFINE SCP_IPRT
                         = 01; % Infinite Protection Fault loop detected
= 02; % Infinite Page Fault loop detected
.DEFINE SCP_IPGF
                         = 03; % Load Control Store request
.DEFINE SCP_LCS
.DEFINE SCP_IORST
.DEFINE SCP_INTR
                        = 04; % An IORST is being performed
= 05; % A trap to the SCP has occured
%*****
```

End of Appendix

Appendix G **Exceptions**

```
.RADIX 16;
%******
    Definition of TRAP addresses:
.DEFINE TRAP_PROT = 04; % Protection DEFINE TRAP_LAT = 0C; % Long Address
                                      % Long Address Translation
                                    % Read Cache Block Crossing
.DEFINE TRAP CBXR
                          = 14;
                           = 1C;
                                     % Write Cache Block Crossing
.DEFINE TRAP_CBXW
                         = 24;
= 2C;
= 34;
= 3C;
.DEFINE TRAP_FXERR
                                    % Fix Point Error (Overflow)
                                    % Floating Point Error
% Unused
% System Console Processer
.DEFINE TRAP_FLERR
.DEFINE TRAP_UNUSED
.DEFINE TRAP_SCP
%******
%******
        Definition of IP Alternate Addresses:
DEFINE IP_WAIT = 0FFF; % Wait for IP

DEFINE IP_USKP = 0FFE; % Microcode-form

DEFINE IP_HLT = 0FFC; % Halt

DEFINE IP_IFLUSH = 0FFA; % IP Pipeline
                                      % Microcode-forced Skip
% Halt
                           .DEFINE IP_INTRT
.DEFINE IP_@JMP
                           = 0FF4; % Indirect Jump Reference
                           = 0FF2; % Indirect Memory Reference
.DEFINE IP_@MRF
                           = 0FF0; % ICache Translation
.DEFINE IP_ICAT
%******
```

End of Appendix

Appendix H Scratch Pad Addresses

The scratch pad in the integer ALU contains reserved locations that are used as save areas or to hold constants used by microroutines. This appendix lists the SPAD reserved locations.

```
.FT 3 SCRATCH PAD;
SCRATCH PAD ADDRESSES
.RADIX 10;
.WORD 32;
.WIDTH 4;
.LENGTH 256;
.DESTINATION SCRATCH_PAD;
.SFIELD spadcontenth (0-15);
.SFIELD spadcontent1(16-31);
.DFIELD (spadcontenth), (spadcontent1);
.LIST SAME, 16;
.RADIX 16;
% Used in BTZ,BTO,SNB,SZBO,SZB
% LOCed to hardware address mux for WSKBO, WSKBZ
BIT0: 8000 0000;
BIT1:
      4000 0000;
     2000 0000;
BIT2:
      1000
BIT3:
            0000;
BIT4:
       0800
            0000;
      0400
BIT5:
            0000;
      0200
            0000;
BIT6:
      0100
            0000;
BIT7:
BIT8:
      0080 0000;
       0040
            0000;
BIT9:
       0020
BIT10:
            0000;
BIT11:
       0010
            0000;
       8000
            0000;
BIT12:
BIT13:
       0004
            0000;
BIT14:
       0002
            0000;
BIT15:
       0001
            0000;
       0000
BIT16:
            8000;
       0000
            4000;
BIT17:
BIT18:
       0000
            2000;
BIT19:
       0000
            1000;
BIT20:
       0000 0800;
BIT21:
       0000 0400;
       0000 0200;
BIT22:
BIT23:
       0000
            0100;
       0000
            0080;
BIT24:
       0000 0040;
BIT25:
```

```
BIT26:
         0000 0020;
BIT27:
         0000 0010;
BIT28:
       0000 0008;
BIT29:
         0000 0004;
         0000 0002;
0000 0001;
BIT30:
BIT31:
% Table of mask constants for WASH
WASHM0: 08000 0000;
WASHM1: 0C000 0000;
BRNGMSK:
                % Byte ring mask
WASHM2: 0E000 0000;
WASHM3: 0F000 0000;
WASHM4:
        0F800
                0000;
WASHM5:
         0FC00
                0000;
WASHM6:
        0FE00
                0000;
WASHM7: OFF00
                0000;
WASHM8: 0FF80
                0000;
WASHM9: 0FFC0 0000;
WASHM10: OFFE0 0000;
WASHM11: 0FFF0 0000;
WASHM12: OFFF8
                0000;
WASHM13: OFFFC
                0000;
WASHM14: OFFFE 0000;
WDMSK:
WASHM15: OFFFF 0000;
WASHM16: OFFFF 08000;
WASHM17: OFFFF 0C000;
WASHM18: OFFFF OE000;
WASHM19: OFFFF OF000;
WASHM20: OFFFF OF800;
WASHM21: OFFFF OFC00;
WASHM22: OFFFF OFE00;
WASHM23: OFFFF OFF00;
WASHM24: OFFFF OFF80;
WASHM25: OFFFF OFFCO;
WASHM26: OFFFF OFFEO;
WASHM27: OFFFF OFFFO;
WASHM28: OFFFF OFFF8;
WASHM29: OFFFF OFFFC;
WASHM30: OFFFF OFFFE;
WASHM31: OFFFF OFFFF;
```

```
/* This group of elements is location-locked so that it will not be loaded
    and verified by SCP/OS. If the size or location of this group must
    be changed, the MAKE_WIDGEON macro must be changed.
         Save locations for console primitives.
         Must be aligned for SPAD table offset computations.
                        % Save area for ALU register file.
AC0SV:
         0000 0000;
         0000 0000;
AC1SV:
         0000 0000;
AC2SV:
         0000 0000;
AC3SV:
         0000 0000;
FPSV:
         0000 0000;
SLSV:
         0000 0000;
SBSV:
        OFFFF OFFFF;
M1SV:
         0000 0000;
GR0SV:
         0000 0000;
GR1SV:
         0000 0000;
GR2SV:
         0000 0000;
GR3SV:
GR4SV:
         0000 0000;
         0000 0000;
GR5SV:
         0000 0000;
GR6SV:
         0000 0000;
GR7SV:
                         % Save area for AG register file.
         0000 0000;
AG0SV:
         0000 0000;
AG1SV:
         0000 0000;
AG2SV:
         0000 0000;
AG3SV:
SPSV:
         0000 0000;
         0000 0001;
ONESV:
         0000 0002;
TWOSV:
LATSV:
         0000 0000;
         0000 0000;
AR0SV:
AR1SV:
         0000 0000;
         0000 0000;
AR2SV:
         0000 0000;
AR3SV:
         0000 0000;
AR4SV:
         0000 0000;
AR5SV:
         0000 0000;
AR6SV:
         0000 0000;
AR7SV:
                         % Shadow copies of SBRs. Needed for SCP examine SBR
         0000 0000;
SBR0CP:
SBR1CP:
         0000 0000;
                         % primitive.
SBR2CP:
         0000 0000;
         0000 0000;
SBR3CP:
         0000 0000;
SBR4CP:
         0000 0000;
SBR5CP:
         0000 0000;
SBR6CP:
         0000 0000;
SBR7CP:
         0000 0000;
                         % PDR
PDRSV:
TRGSV:
         0000 0000;
                        % TREG
                         % Last LA
         0000 0000;
LLASV:
                                                          USEQ STATE
         0000 0000;
                         % Flags and dispatch register
FLDSV:
                                                          ALU STATE
                         % SPAR and DES/SRC pointers
         0000 0000;
SDSSV:
                                                          ATU STATE
                         % MemStart, RefMod, Faultcode
         0000 0000;
ATUSV:
                         % Reserved for IP State word
         0000 0000;
IPSSV:
                         % Reserved for PC of executing instruction
         0000 0000;
PCXSV:
        Do not change these SCP save locations without fixing
                                                                    */
                     the MAKE_WIDGEON macro.
```

```
%******
     Constants
%************
% Table of constants for I/O
          0001 0000:
SNIO:
SDIA:
          0001
                0100;
SDOA:
          0001
                0200;
SDIB:
          0001
                0300;
          0001
SDOB:
                0400:
SDIC:
          0001
                0500;
SDOC:
          0001
                0600;
SSKP:
          0001
                0700;
IOCMD:
          0003
                0000; % I/O Transfer Command Constant used by DIX and DOX
IOCMD1: 0001
                8000; % I/O Transfer Command Constant for CIO (Type 1)
DESMSK: 0000 3000; % Used by PIO to mask the DES field
PORT_MSK:0000 7000; % Used by PIO to mask the Port field
HI9:
          0000 9000; % Mask used by the interrupt code for Type 1
IO_OP:
          0000 6000; % Used by PIO to construct a NOVA I/O opcode
XVCT_OP:OFFFF 0C709; % XVCT's opcode used by interrupt code
INTA_OP: 0001
                733F; % Interrupt Acknowledge Opcode used by XVCT
DMSKO_OP:0001
DMSKO_OP:0001 743F; % Device Mask Out Opcode used by XVCT PMSKO_OP:0001 0FFC1; % Port Mask Out Opcode for use by XVCT
         0000 1000; % I/O Time Out Count
RNGMSK: 07000 0000; % Ring bit Mask
M12:
        OFFFF OFFF4; % CONSTANT -12
CHAR:
         2020 2020; % A Double Word of Spaces
EXPM:
         7F00
                0000; % Mask for floating-point exponent
EXP4:
         4400
               0000; % Floating-point exponent of value 4
         4800 0000; % Floating point exponent of value 8\,
EXP8:
M280:
         0000 0280; % Mask for ATU State word in WDPOP
M680:
         0000 0680; % Mask for ATU State word in WDPOP
         0300 0000; % Mask for Z and N FPSR bits
ZNBIT:
UOBIT:
         6000
               0000; % Mask for UNF and OVF FPSR bits
         3000 0000; % Mask for UNF and DVZ FPSR bits 5000 0000; % Mask for OVF and DVZ FPSR bits
UDBIT:
ODBIT:
% The following constants are used to convert floating-point
% integers in the range 0 to 10**16-1 into a fraction for
% conversion to decimal format. If the correct factor is used,
% subsequent multiplications by 10 will yield at the most
% one leading zero.
STITM1: 4019
               9999;
                         % 1/10
         9999 9999;
STITM2:
        3F28 0F5C2;
                         % 1/10**2
         8F5C 28F6:
STITM3:
         3E41 8937;
                         % 1/10**3
         4BC6 0A7F0;
STITM4:
        3D68 0DB8B;
                         % 1/10**4
        0AC71 0CB3;
STITM6: 3C10 0C6F7;
                         % 1/10**6
        0A0B5 0ED8D;
STITM7: 3B1A 0D7F2:
                         % 1/10**7
         9ABC 0AF48;
STITM8: 3A2A 0F31D;
                         % 1/10**8
        0C461
              1874;
STITM9: 3944 0B82F;
                         % 1/10**9
        0A09B 5A53;
STITM10: 386D 0F37F;
                         % 1/10**10
         675E 0F6EB;
STITM12: 3711
               9799;
                         % 1/10**12
         812D. 0EA11;
STITM13: 361C 25C2;
                         % 1/10**13
         6849
               7682;
STITM14: 352D 0937;
                         % 1/10**14
         0D42 5736:
STITM15: 3448 OEBE;
                        % 1/10**15
         7B9D 5857;
```

```
% LOC'ed so constants can be added without moving the Scratch locations
.LOC 0C0;
%***************
    Scratch Locations and Register Extensions
%**************
DEFAULT_PORT:
        0000 0000; % Port number to be used for NOVA I/O Opcodes
PORT_NUM:0000 0000; % Port number to be used by the DIX/DOX routines
                   % It is always reset to DEFAULT_PORT upon completion.
        0000 0000; % PC of last floating point instruction with an error.
FPPC:
        0000 0000; % Op code of the last XCT'ed instruction
XCTOP:
PROTST: 0000 0000; % Used to detect protection faults within prot. faults
AC_UPDATE: 0000 0000; % Used by prot. faults
TREGSAVE: 0000 0000; % Temporary register used during the LAT routine
% Reserved for Page Fault Context Save
                      % Flag to force instruction restart if Page Faulted.
PF_RESTART: 0 0000;
                      % Page Fault Lock set to detect Recursive faults.
              0000;
PF_FLAG: 0000
                      % Reason for Page Fault
PF_CODE: 0000
              0000;
                      % Type of context block to be pushed
PF_TYPE: 0000
              0000;
                      % Single Register: TREG, PDR, and LAR
              0000;
PF_TREG: 0000
PF_PDR: 0000
              0000;
PF_LAR:
        0000
              0000;
                      % Microsequencer State word: Fault uPC, FLAGs, and DSP
PF_MSEQ: 0000
              0000;
                      % ALU state word: SPAR, ACDR, ACSR
PF_ALU: 0000
              0000;
                      % IP state word: Length and other state.
PF IP:
        0000
              0000;
                      % ATU state word: Start type and other state.
PF ATU:
        0000
             0000;
                      % AG Reg File variables:
              0000;
        0000
PF_AG0:
        0000
              0000;
PF_AG1:
PF_AG2:
        0000
              0000;
              0000;
PF AG3:
        0000
              0000;
        0000
PF_AR0:
PF_AR1:
        0000
              0000;
        0000
              0000;
PF AR2:
              0000;
        0000
PF_AR3:
        0000
              0000;
PF_AR4:
PF_AR5:
         0000
              0000;
                      % Mapped by SRC = E
PF AR6:
        0000
              0000;
        0000
              0000;
                      % Mapped by DES = F
PF_AR7:
                      % Holds GRO to allow calculations on the ALU
        0000 0000;
PF GRO:
OFC;
% Locked to last four locations for SCP
         0000 MODEL_NUM;
MODEL:
              MINOR_REV;
MNREV:
         0000
         0000
              MAJOR_REV;
MJREV:
                      % Memory size placed here by the SCP
         0000
              000F;
MEMSZ:
```

End of Appendix

Index

Note: Page numbers in bold type (e.g., 1-5) indicate definitions of terms or other key information.

AA Bus 2-3, 2-6 ACDR register 2-12	CPD Bus 1-4, 2-3, 2-43, B-1 CPD Bus register 2-19
ACSR register 2-12	CPM Bus 1-4, C-1
Address Generator 1-3, 2-31	Crossbar network 2-5
ALU 2-36	
buses 2-32	DISP Bus 2-32
micro-orders 3-24	Dispatch multiplexer 2-5
Address Generator bus 2-33	Dispatch register 2-5
Address Generator Bus, sources 2-35	Divide guard digit register 2-29
Address Generator register file 2-33	Divide hardware 2-28
addressing 2-34	Divide Partial Remainder register 2-29
Address Translation Cache 2-37	DPR, see Divide Partial Remainder register
Address Translation Unit 1-4, 2-36	211, 000
diagnostic register 2-41	Exception definitions G-1
dispatch 2-42	Excess-64 conversion 3-99
state 2-40	Exponent ALU 2-31
tests 3-9	Exponent logic 2-30
AG, see Address Generator	Exponent working register 2-30
AGB, see Address Generator Bus	
ALU, IALU 2-15	FA Bus 2-21
ATU	Fault codes F-1
see Address Translation Unit	FB Bus 2-21
AY bus 2-33	Flags 2-6
	Floating-point ALU micro-orders 3-86
Bit shifter 2-18	Floating-point divide hardware 2-28
Bus control micro-orders 3-34	Floating-point multiply hardware 2-26
	Floating-point register file 2-22
CARRY 2-16	Floating-point STATE register 2-24
Carry-in base 2-16	Floating-Point Status Register 2-22
Carry-in logic 2-16	Floating-point tests 3-18
CIB, see Carry-in base	Floating-Point Unit 1-4, 2-19
Clocks and Timing 2-1	buses 2-21
Commercial edit PROMs 2-17	multiply hardware 2-26
Commercial test PROMs 2-17	FPSR, see Floating-Point Status Register
Commercial tests 2-17	FPU
CON register 2-12	see Floating-Point Unit
Context block A-2	FR Bus 2-21
Control store 1-1	FS Bus 2-21
CPA Bus 1-4	

Hex shifter	Microfields
FPU 2-24	AA 3-24
IALU 2-14	AB 3-24
	AGB 3-28
I/O protocols 2-46	AL 3-29
IALU	AOP 3-29
see Integer ALU	CPDS 3-35
ID Bus 2-11	CPMS 3-34
Indirection protection 2-39	FCW 3-90
Instruction Processor 1-3, 2-43	FL 3-92
state 2-44	FOP 3-88
Integer ALU 1-4, 2-8, D-1	FR 3-86
tests 3-12	FRG 3-95
width of operations 2-8	FS 3-87
Integer ALU micro-orders 3-71	FWR 3-89
Integer register file 2-10	IA 3-71
Interrupts 2-45	IB 3-71
IP	ID 3-75
see Instruction Processor	IL 3-84
	IOP 3-77
LA Bus 1-4	IY 3-79
LA bus 2-32	MEMC 3-32
LAT, see Logical Address Translation	MEMS 3-31
Leading Zero Detector 2-25	NAC 3-2
Logical Address Translation 2-38, A-1	NAC:COP 3-4
LZD, see Leading Zero Detector	NAC:DSR 3-23
	NAC:TSEL 3-6
M Bus 2-21	NAC:UCOP 3-20
Macroassembler	RAND:ATU:ATU0 3-50
ALU operation constructs 5-6	RAND:ATU:ATU1 3-58
CPD Bus constructs 5-3	RAND:ATU:SPAD 3-59
CPM Bus constructs 5-2	RAND:FIX:COVS 3-60
FA and FB Bus constructs 5-12	RAND:FIX:LOAD 3-63
flag constructs 5-16	RAND:FIX:SPAD 3-63
FPU operation constructs 5-11	RAND:FLT:EXP 3-66
ID Bus constructs 5-11	RAND:FLT:SCNT 3-69
memory completion constructs 5-6	RAND:FLT:SGN 3-65
memory start constructs 5-4	RAND:GEN:REG0 3-40
syntax 5-1	RAND:GEN:REG1 3-48
Macroinstruction 1-1	RAND:GEN:SPAD 3-49
MAG register 2-24	RS 3-77
Mantissa ALU 2-26	Microinstruction 1-1
Mantissa logic 2-21	Microinstruction register 2-2
Memory control micro-orders 3-30	Wheromstruction register 2-2
Micro-order 1-1	
Microassembler 1-1	
Microcode 1-1	
Microfield 1-1	

Migropudara	CDW A 44
Microorders 0 3-99	CDW 3-41
A 3-23, 3-33	CIR 3-38
A 3-23, 3-33 A64 3-68	CIRV 3-8
AC 3-48, 3-58	CJMP 3-5
AC0 3-71	CJSR 3-5
AC0 3-71 AC1 3-72	CLRC 3-61
AC1 3-72 AC2 3-72	CM0 3-50
AC2 3-72 AC3 3-72	CMP 3-69
ACA 3-68	CN 3-76
ACA 3-08 ACN 3-68	CNT4 3-17
ACN 3-68 ACW 3-68	CNT8 3-17
ACW 3-08 AD 3-77	COM1 3-14
	COM2 3-15
ADD 3-29, 3-69, 3-79, 3-88 AF46 3-45	COMP 3-14
AF57 3-45	COVK 3-60
	COVR 3-60
AG 3-34	CPD31 3-7
AG0 3-24	CRRY 3-18
AG1 3-25	CRST 3-6
AG2 3-25	CRTN 3-6
AG3 3-25	CRY 3-17
AGA 3-39	CRY28 3-16
ALC 3-62	CSR 3-78
ANC 3-78	D 3-28, 3-90, 3-95
AND 3-78	D31 3-13
AOFF 3-57	DA 3-77
AON 3-57	DECD 3-42
AR0 3-26	DECS 3-41
AR1 3-26	DES 3-27, 3-74, 3-94
AR2 3-26	DF 3-58
AR3 3-27	DISI 3-55
AR4 3-27	DR 3-87
AR5 3-27	DSGN 3-13
AS 3-75	DSPA 3-21
ATD 3-38	DSPR 3-22
ATON 3-11	DVP 3-70
ATS 3-38	E 3-24
AV 3-63	ECRE 3-10
B 3-28	ECRY 3-20
BL0 3-81	EDT 3-80
BL1 3-81	EFA 3-29
BR 3-76	EPAR 3-47
BR0 3-82	F 3-23
BR1 3-81	F31 3-16
BSW 3-80	FA 3-86
BSX 3-84	FB 3-87
BYTE 3-56	FCRY 3-20
C 3-28, 3-30	FCY 3-42
CA 3-77	FG0 3-92
CABT 3-5	FG1 3-92
CAD 3-79	FG2 3-93
CBLK 3-10	FG3 3-93
CD 3-77	FG4 3-93
CDR 3-39	FG5 3-93
CDSP 3-5	FG6 3-92

NC 1	
Microorders, cont.	LDAS 3-41
FLG[0-7] 3-9	LDCY 3-62
FNZ 3-70	LDSD 3-44
FP 3-72	LEAP 3-21
FP0 3-91	LEF 3-70
FP1 3-91	LESR 3-10
FP2 3-91	LF 3-35
FP3 3-91	LFLG 3-46
FRCD 3-42	LFS 3-98
FRCS 3-41	LGD 3-96
FRSD 3-44	LIPS 3-54
FSGN 3-17	
FZR 3-18	LLAR 3-53
GCRE 3-10	LOVC 3-61
GR0 3-73	LPOP 3-22
	LPSR 3-61
GR1 3-73	LPTA 3-53
GR2 3-73	LS 3-49, 3-59, 3-64, 3-88
GR3 3-74	LSR 3-21
GR4 3-74	LST 3-98
GR5 3-74	LT 3-48, 3-58, 3-63
HF 3-35	LWD 3-98
HL0 3-83	LWM 3-96
HR0 3-82	LWR 3-97
HRT 3-83	LXY 3-97
IA 3-35	LY 3-97
ICAT 3-56	LZD 3-71
IDV 3-98	
IHC 3-91	M 3-30, 3-85
INCD 3-42	M1 3-73
INCS 3-41	MAX 3-92
INDR 3-9	MFS0 3-44
	MFS1 3-44
INTR 3-7	MH 3-94
IOB 3-8	ML 3-94
IOC 3-38	MM 3-34
IOEN 3-12	MOV 3-65
IOFF 3-55	MP 3-86
ION 3-55	MS 3-75
IOT 3-15	N 3-30, 3-31, 3-33, 3-34, 3-36, 3-40, 3-48, 3-49,
IPS 3-37	3-50, 3-58, 3-59, 3-60, 3-63, 3-64, 3-67,
IPST 3-8, 3-56	3-69, 3-85, 3-94, 3-95
IRES 3-14	NA 3-63
IVLD 3-12	NEG 3-65
IXPC 3-12	NM 3-85
IY 3-34, 3-36	NPDR 3-47, 3-57
L 3-28	
LAB 3-66	NY 3-85
LAR 3-38	ONE 3-25
LAT 3-26	OPTA 3-54
LATS 3-51	OR 3-78
LAX 3-67	OVF 3-18
LCN 3-70	PASS 3-80
	PC 3-37
LCRE 3-10, 3-50	PCN 3-37
LCRY 3-61	PCPD 3-22
LD 3-48	PCX 3-37
LDAD 3-42	PD 3-76

Microorders, cont.	UAEB 3-19	Index-5
PRGA 3-54	UAGB 3-19	
PRGB 3-11	UALB 3-19	
PSB 3-29	UFS 3-95	
PSR 3-79	USMT 3-7	
PUSH 3-22	USS 3-36	
Q 3-90	VLD 3-11	
R 3-33, 3-90	VPTE 3-11	
RB 3-31, 3-87	VSBR 3-11	
RD 3-31	W 3-33	
RLO 3-96	WB 3-32	
RMAX 3-9	WC 3-49, 3-59, 3-64	
RND 3-8	WD 3-32	
RNG0 3-9	WORD 3-57	
RS 3-88	WRRM 3-53	
RSBR 3-52	WS 3-49, 3-59, 3-64	
RSGN 3-16	WSBR 3-52	
RSRF 3-53	WSKP 3-43	
RST 3-69	WSX 3-84	
RS1 3-09 RW 3-31	WW 3-32	
S 3-89	WZX 3-84	
S 3-89 S64 3-67	X 3-33	
S@ 3-32	X64 3-99	
SA 3-65	XCTF 3-8	
SAEB 3-19	XOR 3-66, 3-78	
SAGB 3-19 SAGB 3-20	XTND 3-48, 3-57	
SALB 3-19	Y 3-30, 3-85	
	Y0 3-16	
SAMP 3-2	Y28 3-12	
SB 3-73	Y29 3-13	
SC 3-75	Y30 3-13	
SETC 3-62 SFS 3-97	Y31 3-13	
SGE 3-18	ZER 3-39, 3-66, 3-92	
SIO 3-56	ZR 3-76, 3-88	
SKFT 3-46	Microprogram counters 2-3	
SL 3-72	Microprogramming 1-2	
SMR 3-79	examples 4-1	
SNM 3-67	Microroutine 1-1	
SOVK 3-61	Microsequencer 1-3, 2-2	
SP 3-25	micro-orders 3-2	
SPCN 3-47	tests 2-7, 3-7	
SPY4 3-47	Microstack 2-3	
SRC 3-27, 3-74, 3-93	Microstack Input Multiplexer 2	-3
SS 3-75	Microword format 3-1	
SST 3-97	Multiply ALU 2-28	
SUB 3-29, 3-67, 3-89	Multiply hardware 2-26	
TAD 3-89	MV/10000 computer 1-1	
TPSH 3-22	architecture 2-1	
TRG 3-36	buses 1-4	
TRI 3-65	operation 2-1	
TRN 3-66	subsystems 1-2	
TRUE 3-7		
TSB 3-89		
TWB 3-6		
TWO 3-26		
1110 520		

NAC, see Next Address Control Narrow and wide operations 2-8 Next Address Control 3-2

Page fault A-1
Page table addressing logic 2-38
Page zero locations E-1
PDR, see CPD Bus register
Processor Status Register 2-18
PSR, see Processor Status Register

RA multiplexer, see RAM Address multiplexer
RAM Address multiplexer 2-5
Random micro-orders 3-39
Read/write/execute protection 2-40
Referenced/modified RAM 2-38
Register file
 AG 2-33
 floating-point 2-22
 IALU 2-10
Register File In multiplexer 2-36
RFIN multiplexer, see Register File In multiplexer
Ring protection 2-39

SA and SB registers 2-31
SCP
see System Control Processor
Scratch pad 2-12, H-1
Sign logic 2-30, 2-31
SPAD, see Scratch pad
SPAR register 2-12
Starting microaddress 2-5
STUAD, see Starting microaddress
System Control Processor 1-2, 2-7

Terminology 1-1
Tests 2-7
Address Translation'Unit 3-9
floating-point 3-18
integer ALU 3-12
microsequencer 3-7
Top of stack register 2-4, 2-5
TOS, see Top of stack register
Transfer register 2-13

Validity RAM 2-38

WCS see Writable Control Store Working register 2-26 Writable Control Store 1-2, 2-2

X and Y registers 2-27

YSEL counter 2-28



Comment Form

Please help us improve our future Title:_ publications by answering the questions below. Document No. . Use the space provided for your comments. Yes No O You (can, cannot) find things easily. Other: Is this manual easy to read? O Language (is, is not) appropriate. O Technical terms (are, are not) defined as needed. \bigcirc Learning to use the equipment O To instruct a class. In what ways do you find this manual useful? O Other: O As a reference \bigcirc As an introduction to the product O Visuals (are, are not) well designed. Do the illustrations help you? O Labels and captions (are, are not) clear. O Other: Does the manual tell you all you need to know? What additional information would you like? Is the information accurate? (If not please specify with page number and paragraph.)

FOLD

TAPE

FOLD TAPE

FOLD FOLD



BUSINESS REPLY MAIL


FIRST CLASS PERMIT NO. 26

SOUTHBORO, MA. 01772

Postage will be paid by addressee:



ATTN: Technical Publications 62 Alexander Drive Research Triangle Park, NC 27709 NO POSTAGE NECESSARY IF MAILED IN THE





TD	
1 1 2	

TIPS ORDER FORM Technical Information & Publications Service

BILL T	O:							
COMPA	NY NAME							
ADDRE	ESS		ADDRESS					
CITY								
STATE		ZIP	STATE	ZIP				
ATTN:			ATTN:					
	T			UNIT	LINE	TOTAL		
QTY	MODEL#	DESC	CRIPTION	PRICE	DISC	PRICE		
				<u> </u>				
						_		
(Addit	ional items c	an be included on second order for	orm) [Minimum order is \$50.00]	то	TAL			
			Tax Exempt #	Sales Tax				
			or Sales Tax (if applicable)	Shipping				
				TO	TAL			
						_ 		
	—— M	IETHOD OF PAYMENT —						
		oney order enclosed	☐ DGC will select best way (U.P.S or Postal)					
	For orders I	ess than \$100.00	□ Other:					
	Charge my	□ Visa □ MasterCard	☐ U.P.S. Blue Label					
	Acc't No	Expiration Date	☐ Air Freight ☐ Other					
	D	rder Number:						
		NOTE: ORDERS LESS THAN \$100,	INCLUDE \$5.00 FOR SHIPPING AND HA	INDLING.				
-		1 41-1 1	Phone E		extension			
Person	n to contact a	bout this order	I none		Atcholon			
					•			
Mail Orders to: Data General Corporation Attn: Educational Services/TIPS F019 4400 Computer Drive Westboro, MA 01580 Tel. (617) 366-8911 ext. 4032			Buyer's Authorized Signature			Date		
			(agrees to terms & conditions on reverse side	e)				
			Title					
			DGC Sales Representative (If Known)		Ra	dge#		
			DGC Sales Representative (II Known)		Da	uge "		

educational

DATA GENERAL CORPORATION TECHNICAL INFORMATION AND PUBLICATIONS SERVICE TERMS AND CONDITIONS

Data General Corporation ("DGC") provides its Technical Information and Publications Service (TIPS) solely in accordance with the following terms and conditions and more specifically to the Customer signing the Educational Services TIPS Order Form shown on the reverse hereof which is accepted by DGC.

1. PRICES

Prices for DGC publications will be as stated in the Educational Services Literature Catalog in effect at the time DGC accepts Buyer's order or as specified on an authorized DGC quotation in force at the time of receipt by DGC of the Order Form shown on the reverse hereof. Prices are exclusive of all excise, sales, use or similar taxes and, therefore are subject to an increase equal in amount to any tax DGC may be required to collect or pay on the sale, license or delivery of the materials provided hereunder.

2. PAYMENT

Terms are net cash on or prior to delivery except where satisfactory open account credit is established, in which case terms are net thirty (30) days from date of invoice.

3. SHIPMENT

Shipment will be made F.O.B. Point of Origin. DGC normally ships either by UPS or U.S. Mail or other appropriate method depending upon weight, unless Customer designates a specific method and/or carrier on the Order Form. In any case, DGC assumes no liability with regard to loss, damage or delay during shipment.

4. TERM

Upon execution by Buyer and acceptance by DGC, this agreement shall continue to remain in effect until terminated by either party upon thirty (30) days prior written notice. It is the intent of the parties to leave this Agreement in effect so that all subsequent orders for DGC publications will be governed by the terms and conditions of this Agreement.

5. CUSTOMER CERTIFICATION

Customer hereby certifies that it is the owner or lessee of the DGC equipment and/or licensee/sub-licensee of the software which is the subject matter of the publication(s) ordered hereunder.

6. DATA AND PROPRIETARY RIGHTS

Portions of the publications and materials supplied under this Agreement are proprietary and will be so marked. Customer shall abide by such markings. DGC retains for itself exclusively all proprietary rights (including manufacturing rights) in and to all designs, engineering details and other data pertaining to the products described in such publication. Licensed software materials are provided pursuant to the terms and conditions of the Program License Agreement (PLA) between the Customer and DGC and such PLA is made a part of and incorporated into this Agreement by reference. A copyright notice on any data by itself does not constitute or evidence a publication or public disclosure.

7. DISCLAIMER OF WARRANTY

DGC MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, WARRANTIES OF MERCHANT-ABILITY AND FITNESS FOR PARTICULAR PURPOSE ON ANY OF THE PUBLICATIONS SUPPLIED HEREUNDER.

8. LIMITATIONS OF LIABILITY

IN NO EVENT SHALL DGC BE LIABLE FOR (I) ANY COSTS, DAMAGES OR EXPENSES ARISING OUT OF OR IN CONNECTION WITH ANY CLAIM BY ANY PERSON THAT USE OF THE PUBLICATION OF INFORMATION CONTAINED THEREIN INFRINGES ANY COPYRIGHT OR TRADE SECRET RIGHT OR (II) ANY INCIDENTIAL, SPECIAL, DIRECT OR CONSEQUENTIAL DAMAGES WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOSS OF DATA, PROGRAMS OR LOST PROFITS.

9. GENERAL

A valid contract binding upon DGC will come into being only at the time of DGC's acceptance of the referenced Educational Services Order Form. Such contract is governed by the laws of the Commonwealth of Massachusetts. Such contract is not assignable. These terms and conditions constitute the entire agreement between the parties with respect to the subject matter hereof and supersedes all prior oral or written communications, agreements and understandings. These terms and conditions shall prevail notwithstanding any different, conflicting or additional terms and conditions which may appear on any order submitted by Customer.

DISCOUNT SCHEDULES

DISCOUNTS APPLY TO MAIL ORDERS ONLY.

LINE ITEM DISCOUNT

5-14 manuals of the same part number - 20% 15 or more manuals of the same part number - 30%

◆DataGeneral

TIPS ORDERING PROCEDURE:

Technical literature may be ordered through the Customer Education Service's Technical Information and Publications Service (TIPS).

- 1. Turn to the TIPS Order Form.
- 2. Fill in the requested information. If you need more space to list the items you are ordering, use an additional form. Transfer the subtotal from any additional sheet to the space marked "subtotal" on the form.
- 3. Do not forget to include your MAIL ORDER ONLY discount. (See discount schedules on the back of the TIPS Order Form.)
- 4. Total your order. (MINIMUM ORDER/CHARGE after discounts of \$50.00.)
 - If your order totals less than 100.00, enclose a certified check or money order for the total (include sales tax, or your tax exempt number, if applicable) plus \$5.00 for shipping and handling.
- 5. Please indicate on the Order Form if you have any special shipping requirements. Unless specified, orders are normally shipped U.P.S.
- 6. Read carefully the terms and conditions of the TIPS program on the reverse side of the Order Form.
- 7. Sign on the line provided on the form and enclose with payment. Mail to:

TIPS
Educational Services – M.S. F019
Data General Corporation
4400 Computer Drive
Westboro, MA 01580

8. We'll take care of the rest!



NG DOTTED LINE

1-DataGeneral USEPS GPOUP

Installation Membership Form

Name Position		Date		
Company, Organization or	School			
Address	City	State	Zip	
Telephone: Area Code	No	Ext		
1. Account Category	☐ OEM ☐ End User ☐ System House ☐ Government	5. Mode of Operation	□ Batch (Central)□ Batch (Via RJE)□ On-Line Interactive	
2. Hardware M/600 MV/Series ECLIPSE Commercial ECLIPSE Scientific ECLIPSE Array Processors CS Series NOVA®4 Family Other NOVAs microNOVA® Family		6. Communication	 □ HASP □ X.25 □ HASP II □ SAM □ RJE80 □ CAM □ RCX 70 □ XODIACTM □ RSTCP □ DG/SNA □ 4025 □ 3270 □ Other Specify	
MPT Family Other(Specify) 3. Software	□ AOS □ RDOS	7. Application Description	0	
The second secon	□ AOS/VS □ DOS □ AOS/RT32 □ RTOS □ MP/OS □ Other □ MP/AOS Specify	8. Purchase	From whom was your machine(purchased? Data General Corp. Other	
4. Languages	□ ALGOL □ BASIC □ DG/L □ Assembler □ COBOL □ FORTRAN 77 □ Interactive □ FORTRAN 5 COBOL □ RPG II	9. Users Group	Are you interested in joining a special interest or regional Data General Users Group?	

FOLD

FOLD

TAPE

TAPE

FOLD

FOLD




BUSINESS REPLY MAIL

FIRST CLASS PERMIT NO. 26 SOUTHBORO, MA. 01772

Postage will be paid by addressee:



ATTN: Users Group Coordinator (C-228) 4400 Computer Drive Westboro, MA 01581 NO POSTAGE NECESSARY IF MAILED IN THE UNITED STATES



◆DataGeneral users GFOUP Installation Membership Form

Name Position		Date		
Company, Organization or School				
Address City	State	State Zip		
Telephone: Area Code No	Ext			
1. Account	5. Mode of Operation	□ Batch (Central)□ Batch (Via RJE)□ On-Line Interactive		
2. Hardware M/600 MV/Series ECLIPSE® Commercial ECLIPSE Scientific ECLIPSE Array Processors CS Series NOVA®4 Family Other NOVA® microNOVA® Family	6. Communication	☐ HASP ☐ X.25 ☐ HASP II ☐ SAM ☐ RJE80 ☐ CAM ☐ RCX 70 ☐ XODIAC™ ☐ RSTCP ☐ DG/SNA ☐ 4025 ☐ 3270 ☐ Other Specify		
MPT Family Other (Specify)	7. Application Description	0		
AOS	8. Purchase	From whom was your machine(s) purchased? Data General Corp. Other		
4. Languages	9. Users Group	Are you interested in joining a special interest or regional Data General Users Group?		

FOLD

FOLD

TAPE

TAPE

FOLD

FOLD



BUSINESS REPLY MAIL

FIRST CLASS

PERMIT NO. 26 SOUTHBORO, MA. 01772

Postage will be paid by addressee:



ATTN: Users Group Coordinator (C-228) 4400 Computer Drive Westboro, MA 01581

NO POSTAGE NECESSARY IF MAILED IN THE **UNITED STATES**

