

**DSD 890**  
**User Guide**  
Model DSD-890

**ADVANCE COPY**

Copyright © 1983

All rights reserved. No part of this  
book may be reproduced in any form or  
by any means without prior written  
permission of Data Systems Design, Inc.

Printed in USA.

---

WARRANTY

---

Data Systems Design products are warranted against defects in materials and workmanship. For DSD products sold in the U.S.A., this warranty applies for ninety (90) days from date of shipment.\* DSD will, at its option, either repair or replace either equipment or components which prove to be defective during the warranty period. This warranty includes labor, parts, and surface travel costs of system modules or components. Freight charges for other than surface travel or for complete systems returned for repair are not included in this warranty. Equipment returned to DSD for repair must be shipped freight prepaid and accompanied by a Material Return Authorization number issued by DSD Customer Service. Repairs necessitated by shipping damage, misuse of the equipment, or by hardware, software, or interfacing not provided by DSD are not covered by this warranty.

No other warranty is expressed or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. DSD shall not be liable for consequential damages and/or loss of data.



---

## PREFACE

---

This guide provides user information for the Data Systems Design (DSD) 890, Winchester and Tape Storage System, and contains the following information:

- Chapter 1: Brief description and features
- Chapter 2: Specifications and operational requirements
- Chapter 3: Physical and functional descriptions
- Chapter 4: Unpacking instructions, controls and indicators, installation instructions, and acceptance tests
- Chapter 5: Operating instructions
- Chapter 6: User maintenance
- Chapter 7: Field troubleshooting and service information
- Appendix A: GEMEXR Software User Guide
- Appendix B: DSDBR Software User Guide
- Appendix C: TSEXR Software User Guide
- Appendix D: RLEXR Software User Guide
- Appendix E: Bootstrap Program Listing

The material in this manual is subject to change without notice. The manufacturer assumes no responsibility for any errors, which may appear in this manual.

Please note that DEC, LSI-11 (Q-Bus), RL02, TS-11, RT, RSX, and RSTS are registered trademarks of Digital Equipment Corporation. TSX and TSX+ are trademarks of S & H Computer Systems, Inc. Unix is a trademark of Bell Laboratories.

## SAFETY

Operating and maintenance personnel must always observe sound safety practices. Do not replace components, or attempt repairs to this equipment with the power turned on. Under certain conditions, dangerous voltage potentials may exist when the power switch is in the off position, because of charges retained on capacitors. To avoid injury, always remove power before attempting repair procedures.

Data Systems Design, Inc. will accept no responsibility for injury or damage sustained as a result of operation or maintenance of this equipment with the covers removed and the power applied.

## WARNING

This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.

## CAUTION

Do not operate system until you have:

- Released the lock on the Winchester drive (spindle lock).
- Rotated the head lock actuator to RUN position.

Both locks are secured in a locked position before shipment from the factory. See Chapter 4 for detailed procedures covering installation and checkout of equipment.

## IMPORTANT

We recommend using tape cartridges that have been certified for 6400 bpi. Using non-certified tape cartridges may result in unrecoverable loss of data.

## Table of Contents

1.	INTRODUCTION .....	1-1
1.1	General Information .....	1-1
1.2	System Overview .....	1-1
1.3	Features .....	1-2
2.	SPECIFICATIONS .....	2-1
2.1	General Information .....	2-1
2.2	System Modules .....	2-1
2.3	Recording Characteristics .....	2-3
2.4	Cable and Connector Requirements .....	2-5
3.	SYSTEM DESCRIPTION .....	3-1
3.1	General Information .....	3-1
3.2	Introduction .....	3-1
3.3	Functional Description .....	3-4
3.3.1	Disk Drive Emulation .....	3-6
3.3.2	Non-Interleaved Data Transfer .....	3-8
3.3.3	Error Detection and Correction .....	3-10
3.3.4	Disk Flaw Management .....	3-11
3.3.5	Tape Drive Emulation .....	3-12
3.3.6	Tape Cartridge Storage Capacity .....	3-12
4.	INSTALLATION .....	4-1
4.1	General Information .....	4-1
4.2	Unpacking and Inspection .....	4-1
4.3	Controls and Indicators .....	4-2
4.3.1	Status Panel .....	4-2
4.3.2	Operator Panel .....	4-4
4.4	Power Requirements .....	4-6
4.5	Mechanical Preparations .....	4-6
4.6	Installation .....	4-8
4.6.1	Cabinet Installation .....	4-9
4.6.2	Cabling .....	4-10
4.6.3	Configuring Controller Board .....	4-14
4.6.3.1	Bootstrapping Options .....	4-17
4.6.3.2	Device Options .....	4-21
4.6.3.3	Interrupt Priority Options .....	4-21
4.6.3.4	DMA Request Monitor Option .....	4-23
4.6.3.5	Error Correction Option .....	4-26
4.6.4	Mounting Controller .....	4-26
4.6.5	System Power-Up .....	4-29
4.6.6	Acceptance Testing .....	4-29
4.6.6.1	Testing With RLEXR .....	4-30
4.6.6.2	Testing With TSEXr .....	4-30


4.6.7	Installing Software Programs .....	4-31
4.6.7.1	Transfer Using Floppy .....	4-31
4.6.7.2	Transfer Using RL02 .....	4-33
4.6.7.3	Transfer Using TSV05 .....	4-34
5.	OPERATING INSTRUCTIONS .....	5-1
5.1	General Information .....	5-1
5.2	Introduction .....	5-1
5.3	Applying Power .....	5-1
5.4	Loading the Cartridge .....	5-2
5.5	Unloading the Cartridge .....	5-4
5.6	Bootstrapping .....	5-4
5.7	Backup and Restore Operations .....	5-5
5.7.1	Creating Backups .....	5-6
5.7.2	Restoring Disk Data .....	5-7
6.	USER MAINTENANCE .....	6-1
6.1	General Information .....	6-1
6.2	Proper Ventilation .....	6-1
6.3	Cleaning the Cabinet .....	6-1
6.4	Quick Troubleshooting Chart .....	6-2
7.	FIELD TROUBLESHOOTING AND REPAIRS .....	7-1
7.1	General Information .....	7-1
7.2	Maintenance Philosophy .....	7-1
7.3	Preventive Maintenance .....	7-2
7.4	Winchester Disk Formatting .....	7-2
7.5	Bad-Track Map Updating .....	7-4
7.6	Diagnostic Tools .....	7-5
7.6.1	Power-On Confidence Tests .....	7-5
7.6.1.1	Winchester POCs .....	7-5
7.6.1.2	Tape Drive POCs .....	7-6
7.6.1.3	POCs Results .....	7-6
7.6.2	HyperDiagnostics .....	7-6
7.6.2.1	Controls and Indicators .....	7-7
7.6.2.2	Description .....	7-7
7.6.2.3	Operation .....	7-12
7.7	Troubleshooting .....	7-12
7.8	Replacement Procedures .....	7-33
7.8.1	Preparation .....	7-33
7.8.2	Replacing Modules .....	7-34
7.9	Maintenance Assistance .....	7-37
APPENDIX A:	GEMEXR UTILITY PROGRAM.....	A-1
APPENDIX B:	DSDBR UTILITY PROGRAM.....	B-1
APPENDIX C:	TSEXr UTILITY PROGRAM.....	C-1
APPENDIX D:	RLEXr USER GUIDE.....	D-1
APPENDIX E:	BOOTSTRAP PROGRAM LISTING.....	E-1

## List of Figures

Figure 2-1. System Modules .....	2-2
Figure 3-1. DSD 8240 Controller Board .....	3-3
Figure 3-2. Controller Architecture .....	3-5
Figure 3-3. DSD Winchester/RL02 Emulation .....	3-7
Figure 3-4. Two-Port RAM Buffer Data Transfer .....	3-9
Figure 4-1. Status Panel .....	4-3
Figure 4-2. Operator Panel .....	4-5
Figure 4-3. Winchester Spindle and Head Lock .....	4-7
Figure 4-4. Front Bezel Removal .....	4-11
Figure 4-5. Cabinet and Board Cabling .....	4-13
Figure 4-6. DSD 8240 Jumpers .....	4-15
Figure 4-7. Bootstrapping Options .....	4-20
Figure 4-8. Device Options .....	4-22
Figure 4-9. Interrupt Priority Options .....	4-24
Figure 4-10. DMA Request Monitor Option .....	4-25
Figure 4-11. Error Correction Option .....	4-27
Figure 4-12. Common LSI-11 Backplanes .....	4-28
Figure 4-13. Transferring Software Using Floppy .....	4-32
Figure 4-14. Transferring Software Using RL02 .....	4-35
Figure 4-15. Transferring Software Using TSV05/TS11 ...	4-37
Figure 5-1. Magnetic Tape Cartridge .....	5-3
Figure 5-2. Inserting the Cartridge .....	5-3
Figure 6-1. Fuse Location .....	6-4
Figure 7-1. Tape Drive Cleaning .....	7-3
Figure 7-2. HyperDiagnostics Controls and Indicators ..	7-8
Figure 7-3. HyperDiagnostics Procedure .....	7-13
Figure 7-4. Main Troubleshooting Path .....	7-15
Figure 7-5. POC Failure .....	7-16
Figure 7-6. Bootstrapping Failure .....	7-17
Figure 7-7. Power Distribution Diagram .....	7-35
Figure 7-8. Cabinet Exploded View .....	7-36

## List of Tables

Table 2-1. System Modules .....	2-1
Table 2-2. System Specifications .....	2-3
Table 2-3. Cabinet Specifications .....	2-4
Table 2-4. Interface Specifications .....	2-4
Table 3-1. Block Size vs Tape Storage Capacity .....	3-13
Table 4-1. Status Panel--Indicators .....	4-2
Table 4-2. Operator Panel--Controls and Indicators ....	4-4
Table 4-3. DSD 8240 Jumpers .....	4-16
Table 5-1. Bootstrap Device Selection .....	5-5
Table 6-1. Quick Troubleshooting Chart .....	6-3
Table 7-1. HyperDiagnostics Tests .....	7-7
Table 7-2. HyperDiagnostics Error Codes .....	7-18
Table 7-3. Software Diagnostic Procedures .....	7-21
Table 7-4. POC Error Codes .....	7-26
Table 7-5. Bootstrap Error Codes .....	7-29
Table 7-6. Error Code Summary .....	7-30



DSD 890 Winchester and Tape Storage System

TP 565/84

---

## 1 INTRODUCTION

---

### 1.1. General Information

This chapter briefly describes the DSD 890 Winchester and Tape Storage System and outlines its features. Refer to Chapter 3 for a more comprehensive description.

### 1.2. System Overview

The DSD 890 is a mass storage system consisting of a main cabinet and an intelligent bus interface board. The system is fully compatible with DEC computers using LSI-11 bus configurations and provides, in a rack-mount package, many value-added features not found in comparable DEC equipment. For example, the cabinet contains:

- An eight-inch Winchester (sealed bubble) disk drive. This drive replaces three DEC RL02 cartridge disk volumes, storing up to 31.2 Mbytes of formatted data.
- A start/stop Tape drive that uses 1/4-inch tape cartridges. This drive stores up to 16.25 Mbytes of formatted data on each cartridge and emulates DEC TS11/TSV05-class subsystems. The DSD Tape drive can be used to obtain backup copies of Winchester disk data, restore the data, or load diagnostic programs distributed by DSD.

In addition, the cabinet contains its own power supply, a built-in bootstrapping program, and cooling fan. Switches and LEDs are conveniently located on the front panel to permit:

- individual write-protection of each of the three Winchester volumes.
- control over Tape cartridge load/unload operations.
- rapid access to comprehensive HyperDiagnostics - a DSD proprietary built-in diagnostic program.

The cabinet is interfaced with DEC LSI-11 computers via the DSD 8240 Controller board. This quad-wide board is hardware compatible with all DEC LSI-11 bus (Q-Bus) back-planes. The board is, both, a bus interface for the storage cabinet and an intelligent controller that emulates DEC RL02, and TS11/TSV05 auxiliary storage subsystems, allowing the user to fully utilize operating systems and application software distributed by DEC.

This board contains a high-speed direct memory access (DMA) microcontroller and three gate arrays that provide non-interleaved disk operations, transparent error correction, and optimum system throughput.

### 1.3. Features

The following list compiles features of the DSD 890 System:

#### Winchester Drive

- Emulates three DEC RL02 disk pack subsystems.
- Provides three 10.4-Mbyte storage volumes.
- Contains built-in bootstrapping PROM.
- Supports 22-bit addressing modes.
- Provides HyperDiagnostics via Operator panel.

#### Tape Drive

- Emulates one DEC TS-11/TSV05 (1/2-inch) tape subsystem.
- Provides up to 16.25 Mbytes of back-up storage on each cartridge.
- Supports 22-bit addressing modes.
- Provides HyperDiagnostics via Operator panel.
- Boots diagnostic software from supplied cartridge.

## Controller Interface Board

- Fully emulates DEC peripheral controllers.
- Provides software compatibility with DEC LSI-11 (Q-Bus) computers.
- Provides compatibility with RT, RSX, TSX, TSX+, RSTS, and UNIX operating systems.
- Uses one of two user-selectable methods for transferring disk sector data: Two-way interleaving method afford flexibility, while non-interleaving method results in increased data throughput rate
- Supports simultaneous disk and tape operations with maximum throughput and minimum degradation of either operation.
- Corrects Winchester drive error bursts up to 11 bits long using error correction coding (ECC) techniques.
- Detects Tape drive random errors using a 16-bit cyclic redundancy coding (CRC) technique.
- Supports DSD diagnostic software for testing storage devices and media.
- Supports DSD software utilities for managing Winchester media, for making backup copies of Winchester volumes on cartridge, and for restoring cartridge data to Winchester volumes.
- Uses state-of-the-art semiconductor technology on single quad-wide controller board.
- Provides increased reliability and serviceability, at reduced cost.
- Complies with LSI-11 bus bandwidth requirements.
- Provides automatic error retry for Winchester disk data.
- Provides access, via computer console, to DEC on-line debugging techniques (ODT).

[^]



---

## 2 SPECIFICATIONS

---

### 2.1. General Information

This chapter outlines specifications and operational requirements for the DSD 890 Winchester and Tape Storage System. Specifications include storage capacities, recording characteristics, and data transfer rates. Also provided is a listing of major components and the system physical dimensions.

Requirements include interface cabling, connectors, and power requirements. Environmental limitations are also stated.

### 2.2. System Modules


The DSD 890 System modules are listed in Table 2-1 and illustrated in Figure 2-1.

Table 2-1. System Modules

---

Module	Part Number
System Cabinet	
Chassis	700267-01
Display Control Board	808945-01
Winchester Disk Drive (60 Hz) or,	900482-01
Winchester Disk Drive (50 Hz)	900482-02
Tape Drive	900473-01
Fan Assembly	900112-01
Power Supply, Linear (100 Watts)	500014
Diagnostic Control Board	808940-01
Computer Interface	
Controller Interface (8240) Board	808240-01
Interface Cable Shipping Kit	900476-01

---



TP 321/83

Figure 2-1. System Modules

### 2.3. Recording Characteristics

The Winchester drive records data using the modified frequency modulation (MFM) technique. The magnetic tape cartridge drive uses the group code recording (GCR) technique. Product specifications are listed in Tables 2-2 through 2-4.

Table 2-2. System Specifications

<b>GENERAL</b>	<b>WINCHESTER DRIVE</b>	<b>TAPE DRIVE</b>
Emulates Modifications to Operating System Software Formatted Capacity	Three RL02s None 10.4 Mbytes/RL02 image 31.2 Mbytes total	TS-11 None 16.25 Mbytes (450 ft. cartridge, 16 Kbyte blocks)
<b>DATA ORGANIZATION</b>  Recording technique Bytes/disk sector Bytes/tape block Error detection  Flaw management  Recording density Track density Number of read/write heads Number of tracks	MFM 256 — Header CRC Data ECC, Transparent Correction Spare track assignment is user transparent 6600 bpi 345 tpi 8 512	GCR — 512-16K CRC  —  6400 bpi — 1 4 (Serpentine)
<b>SPEEDS</b>  Disk seek time (including head setting) Average Maximum Track-to-track Disk head switching time Disk average latency Disk start-up time Tape speed  Tape rewind time Data transfer time Non-interleaved Kbyte/s 2-way interleaved Kbyte/s  Data transfer length Time to read or write RL02 image (10.4 Mbytes)	65 ms 100 ms 15 ms 20 ms 10 ms 30 sec.   WITHIN A      WITHIN A      ACROSS SECTOR        CYLINDER     ENTIRE DISK 542.5        396.8        352.7 542.5        198.4        186.7  5.1 Kwords maximum 25.5 seconds	— — — — — — 30 ips (read/write) 70 ips (rewind) 3 minutes max.   256 to 8 Kwords 8.95 minutes
<b>ERROR RATES (W/O ECC)</b>  Soft read errors Hard read errors Seek Errors	1 per 10 <sup>10</sup> bits read 1 per 10 <sup>12</sup> bits read 1 per 10 <sup>6</sup> seeks	1 per 10 <sup>10</sup> bits read 1 per 10 <sup>11</sup> bits read —

Table 2-3. Cabinet Specifications

<b>CHASSIS OPERATING VOLTAGE AND POWER REQUIREMENTS</b>		
<b>POWER LINE FREQUENCY</b>		
The DSD 890 is available in two versions for use on either 50Hz or 60 Hz AC power. Order DSD 890-A for use of 60 ± 0.5Hz Service Order DSD 890-B for use on 50 ± 0.5Hz Service		
<b>VOLTAGE RANGES</b>		
The DSD 890 has four operator selectable AC voltage ranges to cover world wide power distribution conditions. These AC voltage ranges are as follows: 100VAC ± 10% An AC voltage range is selected 120VAC ± 10% by setting the range selector 220VAC ± 10% switch on the AC power input 240VAC ± 10% receptacle on the rear of the chassis NOTE: The DSD 890-A (60Hz) will be shipped set for use on 120VAC ± 10% The DSD 890-B (50Hz) will be shipped set for use on 220VAC ± 10%		
<b>POWER REQUIREMENTS</b>		
Average power consumed 300 watts Maximum starting surge power 500 watts, 5 seconds maximum		
<b>ENVIRONMENTAL SPECIFICATIONS</b>		
	<b>OPERATING</b>	<b>NON-OPERATING</b>
Temperature	10°C to 40°C	- 40°C to 66°C
Relative Humidity, Maximum Wet Bulb	20% to 80% (non-condensing)	
Altitude	10,000 feet maximum	30,000 feet
<b>CHASSIS DIMENSIONS</b>		
Overall Dimensions	5.25 in. h x 17.6 in. w x 21.0 in. d (13.34 cm. h x 44.7 cm. w x 53.34 cm. d)	
Shipping Carton	10.5 in. h x 24.0 in. w x 33.5 in. d (26.7 cm. h x 61.0 cm. w x 85.1 cm. d)	
<b>WEIGHTS</b>		
MODEL	SYSTEM WEIGHT	SHIPPING WEIGHT
DSD 890	53 lbs ( 24 Kg)	65 lbs ( 29.5 Kg)

Table 2-4. Interface Specifications

<b>LSI-11 INTERFACE</b>	<b>WINCHESTER DRIVE</b>	<b>TAPE DRIVE</b>
Backplane Requirement	One quad-wide Q-Bus slot in any Q-Bus backplane	
Device Address		
Standard	17774400	17772520
Alternate	17774420	17772530
Interrupt Address		
Standard	160	224
Alternate	150	170
Bootstrap Address		
Standard	17773000	
Alternate	17771000	
<b>POWER REQUIREMENTS</b>	5 VDC (5.5 A) 12 VDC (0.1 A)	

#### 2.4. Cable and Connector Requirements

The DSD 890 System is furnished with all internal cables installed and configured for proper operation. The DSD 8240 controller interface board is installed at the backplane of the host computer and connected to the system cabinet by three cable assemblies:

- (a) A 50-pin Winchester control cable
- (b) A 20-pin Winchester data cable
- (c) A 40-pin Tape cable

[^]



---

## 3 SYSTEM DESCRIPTION

---

### 3.1. General Information

This chapter describes the DSD 890 System. Emphasis is given to the DSD 8240 board, which provides computer interfacing and control of all data storage and retrieval operations.

### 3.2. Introduction

The DSD 890 is a mass storage system that consists of a Winchester drive, a Tape drive, and a DSD 8240 Controller board.

Designed to support the DEC LSI-11 computer product line, the DSD 890 System emulates interface software of DEC RL02 and TS11/TSV05 subsystems.

The LSI-11 (Q-Bus) bus uses 44 lines. These lines are used by the central processing unit (CPU), main memory, and input/output (I/O) devices to communicate with each other.

Most lines are bidirectional and use terminations for maintaining a high (negated) transistor-transistor-logic (TTL) level. Devices are connected to these lines via high impedance bus receivers and open collector drivers. A device can assert a line when its driver places a low TTL logic level on the line.

All devices on the bus communicate with each other in an asynchronous mode. For bus transactions between devices to occur, one device must become master and the other become slave. Some devices, such as main memory are always slave.

A device, such as disk or tape, can become master by asserting a DMA-request signal to request the data section of the bus. The CPU is responsible for arbitrating simultaneous requests and granting the bus to the device with highest priority.

Once master, the device can use various methods to perform the data transfer transaction. DMA is the method used by the DSD 890 System.

This method is most useful when using mass storage devices that move large blocks of data to and from main memory. DMA causes the least intervention from the CPU and it is consequently the most efficient data transfer method.

During DMA, the storage device needs to know the starting address in memory, the starting address in the storage device, the length of the transfer, and the type of operation. DMA starts after the CPU grants bus mastership to the highest priority DMA device requesting the bus.

The DSD 890 contains an intelligent interface controller that uses a microcontroller and three semi-custom designed gate array integrated circuits (IC) for emulating DEC software while providing full compatibility (see Figure 3-1).

The microcontroller, a Signetics 8X305, is a high-speed processing device, which performs and controls all the intelligent functions of the storage system.

The microcontroller receives commands from the LSI-11 computer intended for the specific peripheral devices. These commands are coded into a form compatible with the DSD storage devices and transmitted to them.

Similarly, the microcontroller receives data from the storage devices and codes the data into a format compatible with the LSI-11 operating software.

Gate arrays are large scale integrated (LSI) circuits fabricated by a process, which provides designers with circuits semi-customized to their application. Using gate arrays results in a more efficient and cost-effective product.

The DSD 890 uses three gate array devices to provide several product enhancements. Use of these devices allow the following value-added features:

- Non-Interleaved Disk Operation: Increased data transfer rate, across the entire disk, to 352.7 Kbytes per second - about 12 percent faster than a single RL02 subsystem.
- Transparent Error Correction: Detection of error bursts 22 bits long and correction of 11 bits. These functions are performed transparently.
- Optimum System Throughput: DMA is used to obtain greatest computer throughput without sacrificing compatibility.




Figure 3-1. DSD 8240 Controller Board

The Winchester is a Quantum Q2040 eight-inch Winchester disk drive. The Tape is a Kennedy 6455 1/4-inch start/stop cartridge tape drive.

The Winchester drive stores a maximum of 31.2 Mbytes of formatted data. The data transfer rate within a sector, within a cylinder, or across the entire disk varies with the method used for transferring data (i.e., non-interleaving or two-way interleaving). Refer to Chapter 2, Specifications for more details.

The Tape has four tracks arranged in a serpentine configuration. Data is recorded serially, and reading/writing takes place in both directions with an automatic head switch at the end of the tape. The data transfer rate is 24 Kbytes per second.

Because of recording overhead, the Tape storage capacity is directly related to the block size used in the recording format. The storage capacity ranges from 3.56 Mbytes to 16.25 Mbytes.


### 3.3. Functional Description

The DSD 8240 Controller consists of a 8X305 microcontroller connected to a high-speed internal data bus, three gate arrays, a disk read/write controller chip, and tape interface logic with first-in-first-out (FIFO) buffers. (See Figure 3-2.)

The 8X305 is a bipolar microcontroller with a cycle time of 200 ns. The 8X305 serves as internal bus master and controls all on-board intelligent functions; for example:

- Monitors and controls Winchester drive, tape drive, and interfacing operations.
- Performs the storage device emulation function.
- Provides read, write, and data transfer functions.

The gate arrays consist of an error correction chip in a 22-pin package, a two-port RAM controller chip, and a Q-Bus DMA chip; the latter two are in 64-pin grid-array packages.



TP 317/83

Figure 3-2. Controller Architecture

The disk read/write controller, tape interface logic, two-port RAM controller, and Q-Bus DMA controller act as internal bus slaves. Disk data is synchronized by a phase-locked loop, under control of the read/write controller.

During device operation, the 8X305 produces a status for each device and stores it in RAM. As disk and tape operations proceed, the 8X305 updates and stores various bits of information.

Any read of the I/O registers by the computer software interrupts the 8X305 and causes it to place, within ten microseconds, the selected register data on the Bus. This high speed is required to avoid an abort of the operation by the LSI-11 watchdog timer.

The use of intelligence in the DSD 8240 Controller allows a single quad-wide board to emulate two different storage devices, and to provide additional features such as non-interleaved data transfer, transparent error detection and correction, disk flaw management, and on-board diagnostics.

### 3.3.1. Disk Drive Emulation


The DSD Controller emulates three 10.4-Mbyte RL02 drives using an eight-inch Winchester drive.

The RL02 disk drive has two read/write heads, one on each side of a single disk-platter. Each side of the platter has 512 concentric tracks. Each track contains forty 256-byte sectors.

The DSD Winchester drive has eight read/write heads, one on each side of four platters. Each side of a platter has 512 tracks. Each track contains thirty-one 256-byte sectors.

Because of the physical differences between the two drives, the Controller needs to convert track, head, and sector addresses of the RL02 drives to a form compatible with the Winchester drive.

To emulate the drives, the Controller maps the RL02s vertically as three concentric, three-dimensional cylinders, instead of assigning each Winchester platter a different RL02. (See Figure 3-3.)



ABSEC = ABSOLUTE SECTOR ADDRESS

TP 318/83

Figure 3-3. DSD Winchester/RL02 Emulation

The following paragraphs describe the conversion process used by the Controller:


- (1) The absolute sector number (ABSEC) is determined. RL02 disk addresses are re-defined to consist of a cylinder number (CY), a head number (HD), and a sector number (SEC). Head numbers range from 0 to 1; sector numbers from 0 to 39. The firmware in the microcontroller uses the following formula:
  - $ABSEC = SEC + (40 \times HD) + (80 \times CY)$
- (2) Corrections are made. An offset is added to identify the RL02 being accessed and a correction for flaws is made based on a flaw translation table stored on track 0 of the Winchester drive.
- (3) The sector number is calculated. The result obtained above is divided by a constant (248), yielding the Winchester drive cylinder number and a remainder. This remainder is divided by another constant (31), yielding the Winchester drive head number and another remainder. This second remainder is the Winchester sector number. This number is added to another constant, which identifies the RL02 volume being addressed.
- (4) A read or write operation is done. Using the information obtained in the last step, the firmware commands the Winchester drive to position its head over the proper track and read or write.

Using a similar process, responses from the Winchester are converted into the format expected by the LSI-11 operating system. Data is transferred between drive and main memory by DMA.

### 3.3.2. Non-Interleaved Data Transfer

The Controller is capable of transferring Winchester disk data at an optimum rate by using non-interleaved data transfer techniques; that is, reading or writing a full track of data during one disk revolution.

Non-interleaved data transfer requires a complex data buffering scheme. The DSD Controller uses a 1-Kbyte RAM buffer in a two-port configuration. (See Figure 3-4.)



TP 319/83

Figure 3-4. Two-Port RAM Buffer Data Transfer

The control logic for the two-port RAM resides in a semi-custom gate array, which uses 1700 gates to do the equivalent function of 30 TTL devices.

The two-port buffer configuration allows Winchester sector data to be read into one port, while data from the previous sector is transferred to main memory. Figure 3-4 shows the details of the data transfer operation as follows:

- (1) When buffer A is filled with data from the first Winchester sector, the two-port RAM controller switches to buffer B and begins to fill it with data from the second Winchester sector.
- (2) As buffer B is being filled, the contents of buffer A are transferred to main memory.
- (3) When buffer B is filled, the cycle is repeated and data moves continuously, at high speed, between disk drive and main memory.

If the CPU data bus is being used by other high data rate DMA devices, the high data rate transfer obtained by non-interleaved operations may not be desirable. In such cases, the disk can be formatted for interleaved operations and the Controller set to slow down memory accesses for preventing I/O bus overloads.

### 3.3.3. Error Detection and Correction

A major DSD 8240 Controller feature is detecting and correcting disk errors transparently; that is, in a way not perceived by the operating system.

The Controller contains a proprietary, complementary-MOS (CMOS) gate array that uses 540 silicon gates to provide error detection and correction.

The Controller implements these functions as follows:

- (1) The 256-byte data record in a Winchester sector is converted to a binary polynomial of degree equal to the bits in the record.
- (2) This polynomial is divided by a second constant polynomial stored within the error detection and correction chip. The remainder of this division is a 32-bit error correction code (ECC).

- (3) The ECC is concatenated (appended) to the disk sector data each time a Winchester sector is written. When a sector is read, data and ECC are shifted through the chip. If no error is present, the remainder in the chip is equal to zero.
- (4) If an error is present, the residual remaining in the chip generates an error indication. This indication is used by the 8X305 microcontroller to generate an error pattern and to identify the location of the bit or bits in error.
- (5) Once the error location is identified, the 8X305 microcontroller attempts to reread the data record several times before applying error correction.
- (6) If the error pattern persists, the 8X305 microcontroller corrects the data in its data buffer before loading it into the host CPU memory, thus providing transparent error detection and correction of error burst up to 11 bits long.

#### 3.3.4. Disk Flaw Management

Winchester disk drives contain permanent hard errors known as flaws. A list of these flaws is provided by the manufacturer with each drive. This list is used by DSD to produce a "bad-track map" table. Several copies of this table are then recorded in track 0 of the disk drive.

When power is applied, the DSD 8240 Controller reads the Winchester drive bad-track map table and stores it in scratch pad RAM.

After converting an RL02 disk address to a Winchester disk address, the 8X305 microcontroller accesses the bad-track map table from memory and compares its entries to the desired Winchester disk address. The microcontroller then makes the necessary corrections to ensure that complete tracks are flagged as defective and are not used.

The corrections made during flaw management are transparent to the host operating system. Also, since RL02 emulation does not use all the available Winchester tracks, there are enough spare tracks to compensate for many flaws.

### 3.3.5. Tape Drive Emulation

The DSD 8240 Controller emulates a DEC TS-11 or TSV05 magnetic tape system using a start/stop Tape drive.

The TS-11/TSV05 tape drives use standard 1/2-inch, nine-track magnetic tape. The drives read and write at 25 inches per second, with a data transfer rate of 40 Kbytes per second.

The DSD Tape drive uses a smaller 1/4-inch, start/stop magnetic tape cartridge. Data is recorded serially at a transfer rate of 24 Kbytes per second.

The 8X305 microcontroller receives LSI-11 commands intended for the DEC drive. These commands are converted into a form compatible with the Tape drive and are transmitted to it. Similarly, the 8X305 converts Tape drive data into the format expected by the computer.

### 3.3.6. Tape Cartridge Storage Capacity

The DSD 890 Tape drive records data at 6.4 Kbits per inch (800 bytes per inch), using four serial tracks arranged in a serpentine configuration to avoid rewinding at the end of each track. The length of the tape in the cartridge is 450 feet (5400 inches).

The unformatted capacity of a tape cartridge is computed by using the following formula:

- Storage Capacity = Bytes/inch x Tracks x Length; in our case this is: 800 x 4 x 5400 = 17.28 Mbytes

In the Tape drive, data is recorded in blocks with an inter-block gap (IBG) of 1.2 inches. The data format on the tape for a single data block consists of the IBG, an 80-bit preamble, a 5-bit sync mark, the data pattern, a 5-bit end mark, a 16-bit CRC, and an 80-bit post-amble.

The formatted data (except data pattern) and the IBG are considered recording overhead. In our case, 186 bits (0.029) plus 1.2 inches of IBG for a total of 1.229 inches of overhead.

Consequently, the drive storage capacity is directly related to the block size of the recording format. This relationship is shown in Table 3-1. Note that a 2-Kbyte or larger block size is needed for backing up an entire RL02 disk image (10.4 Mbytes).

Table 3-1. Block Size vs Tape Storage Capacity

---

BLOCK SIZE (Bytes)	STORAGE CAPACITY (Mbytes)
256	3.56
512	5.91
1K	8.80
2K	11.65
4K	13.91
8K	15.40
16K	16.25

---

[^]



---

## 4 INSTALLATION

---

### 4.1. General Information

This chapter provides instructions for installing your 890 System, including acceptance test procedures.

The DSD 890 System is fully tested before shipping. Unless there is physical damage from shipment, it can be installed and made operational in a short period of time without any special procedures other than those recommended here.

### 4.2. Unpacking and Inspection

When your DSD 890 System arrives, inspect the shipping container immediately for evidence of mishandling during transit. If the container is damaged, request the presence of the carrier's agent before opening it.

Compare the packing list attached to the shipping container against your purchase order to verify the shipment is correct.

Ensure that all items are unpacked and none accidentally discarded with the packing material. Note that the DSD 8240 Controller board is packaged in the shipping container separately.

Carefully unpack the shipping container and inspect each item for external damage such as broken controls and connectors, dented corners, bent panels, scratches, or loose components.

If damage is evident, notify DSD Customer Service Department immediately.

Retain the shipping container and packing material for examination in the settlement of claims, or for future use.

### 4.3. Controls and Indicators

The controls and indicators are located on the front bezel of the system cabinet and consist of a Status display panel and an Operator panel.

The only control not accessible from the front bezel is the POWER ON/OFF switch, which is a rocker arm switch located at the rear of the cabinet.

#### 4.3.1. Status Panel


The Status panel is located on the upper right side of the front bezel and becomes visible when the system cabinet is powered-up.

The Status panel shows the status of the Winchester and the Tape drives. It also provides system power on/off and fault indications.

The Status panel indicators are shown in Figure 4-1 and their functions described in Table 4-1.

Table 4-1. Status Panel - Indicators

Indicator	Function
POWER	● Lights to show cabinet is powered-up
WIN ACTIVE	● Lights to show Winchester drive is active
WIN WP	● Lights when any WIN VOLUME WRITE PROTECT switch is ON
FAULT	● Lights to show system fault (see Chapter 7 for details)
TAPE ACTIVE	● Lights to show Tape drive is active
UNLOAD	● Lights to show tape cartridge is at unload point and safe to remove from Tape drive



TP 326/83

Figure 4-1. Status Panel

### 4.3.2. Operator Panel

The Operator panel is located on the front bezel lower right side behind a hinged door. This door is opened by applying fingertip pressure near the bottom.


The Operator panel allows the operator to control Winchester write-protect functions, tape load/unload operations, and to start HyperDiagnostics (see Caution below). It also provides diagnostic error code information.

The Operator panel controls and indicators are shown in Figure 4-2 and their functions described in Table 4-2.

Table 4-2. Operator Panel - Controls and Indicators

Control/Indicator	Function
WIN VOLUME WRITE PROTECT (0 - 2) Switches	<ul style="list-style-type: none"><li>● Each, when set (ON), write-protects corresponding drive volume and lights WIN WP indicator. (See Chapter 7 for other functions.)</li></ul>
TAPE LOAD/UNLOAD Switch	<ul style="list-style-type: none"><li>● Setting to LOAD moves cartridge to load point.</li><li>● Setting to UNLOAD moves cartridge to unload point, lights UNLOAD indicator, and allows safe cartridge removal.</li></ul>
TEST Pushbutton (momentary-action)	<ul style="list-style-type: none"><li>● Used for starting HyperDiagnostics. (See Caution below.)</li></ul>
STATUS Indicator	<ul style="list-style-type: none"><li>● Displays zero when system is off-line.</li><li>● Blanks when system is on-line. (For other functions, see Chapter 7)</li></ul>

**CAUTION:** Some HyperDiagnostics (tests) will destroy Winchester and Tape data. Unless you are completely familiar with this feature, do not press the panel TEST pushbutton. Refer to Chapter 7 for instructions.



TP 327/83

Figure 4-2. Operator Panel

#### 4.4. Power Requirements

The DSD 890 System is available in configurations for nominal line voltages of 120 or 240 Vac. The line frequency must be within 0.5 Hz of the required frequency (50 Hz or 60 Hz).

The system voltage and frequency configurations can be field-modified; however, the process requires that mechanical, as well as electrical, adjustments be made.

Should you need to modify the system, contact DSD Customer Service for assistance.


#### 4.5. Mechanical Preparations

The system Winchester drive is shipped with locked spindle and head mechanisms. These mechanisms must be unlocked before installation to avoid damage to the drive motor. Refer to Figure 4-3 and follow these instructions:

- (1) Remove spindle-lock access panel in bottom cover.
- (2) Loosen 11/32" hex nut on spindle-lock.
- (3) Rotate locking clip away from pulley.
- (4) Tighten 11/32" hex nut.
- (5) Replace spindle-lock access panel.
- (6) Unlock head lock by rotating actuator lock counterclockwise to RUN (about 1/2-turn). DO NOT FORCE. The Winchester drive is ready for operation. (See Caution below.)

---

**CAUTION:** Never ship the system cabinet or the Winchester drive assembly with the spindle and head mechanisms unlocked. Failure to observe this precaution will result in costly damage and void the Warranty. See Chapter 7 for instructions



TP 332/83

Figure 4-3. Winchester Spindle and Head Lock

## 4.6. Installation

### FCC Compliance Testing

The DSD 890 System has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC rules. The following is a brief description of the test:

- An DSD 8240 controller interface board was mounted inside a DEC MICRO/PDP-11 computer card-cage.
- A DSD 890 cabinet was placed, on a table top, alongside the DEC computer.
- Three shielded ribbon cables were used to connect the DSD 890 cabinet and the DSD 8240 board. These cables were grounded to both, the DEC computer and the DSD 890 chassis.
- Several operational tests were performed using a DEC VT-102 terminal as the system console.

Under the above conditions, it was found that no special enclosures were needed as long as the three cables were shielded and properly grounded. A complete test report is available on request.

Please note that the DSD 890 System is designed for integration into a larger computer system. The final responsibility for compliance with FCC regulations rests with the system integrator. The need for shielded cables in other applications, such as when the DSD 890 System is rack-mounted, can be determined only by proper testing of the final computer system configuration.

---

\* A shielded cable-kit, including necessary hardware, to terminate cable shields to a DEC MICRO/PDP-11 computer is available from DSD. Contact your nearest DSD Sales Representative for price and availability.

## Installation Overview

Before installing the DSD 890 System, refer to DEC CPU documentation and power down the LSI-11 computer (see Caution below). The equipment installation consists of:

- cabinet installation
- cabling
- reconfiguring Controller (if necessary)
- mounting Controller
- powering computer
- acceptance testing
- installing operating systems

### 4.6.1. Cabinet Installation

Because of the interconnecting cable length, the system cabinet must be installed within ten feet of the DSD 8240 Controller board. If the computer operator anticipates frequent tape changes, it may be convenient to locate the cabinet next to the computer console terminal.

The cabinet may be mounted in a standard 19-inch rack, or placed on a table top. The rack installation hardware is included in the shipping carton.

When mounting the cabinet, ensure that there is enough space behind the cabinet fan to permit unrestricted air flow. The temperature of the air entering the cabinet should not exceed 104 degrees F (40 degrees C).

To mount the 890 cabinet in the standard 19-inch instrumentation rack, proceed as follows:

- (1) If you purchased chassis slides mounting kit, complete kit instructions and return to this procedure. If not, go to next step and remove front bezel.

---

**CAUTION:** Ensure that line power is off. Do not restore or apply power to either the computer or the DSD 890 System until instructed.

- (2) With both hands, apply fingertip pressure at bottom of bezel. Simultaneously, pull bezel-top away from cabinet with thumbs. Bezel will detach as illustrated in Figure 4-4.
- (3) Gently, insert cabinet into rack. Sudden movements may damage Winchester disk drive.
- (4) Install cabinet retaining screws.
- (5) Re-install bezel by locating guide pins and firmly pressing until retaining mechanism engages. The system cabinet is installed.


#### 4.6.2. Cabling

The DSD 890 cabinet has three connectors at the rear of the unit. These connectors are protected by two cable clamps. One cable clamp covers the Winchester control connector. The other, longer, cable clamp covers the Winchester data connector and the Tape connector. The DSD 8240 controller interface is a quad-wide printed circuit board, labeled P/N 808240-01.

The system cabinet is interconnected with the DSD 8240 board via three flat ribbon cables shielded to prevent radio-frequency (RF) emissions. Three 10-foot shielded cables are provided with your equipment. If you desire to make your own cables, please read the FCC Compliance Testing statement under Section 4.6, Installation.

The following procedure assumes that you are using the cables provided with your equipment. Refer to Figure 4-5 and:

- (1) Remove protective cable clamps from cabinet connectors and set aside.
- (2) Set controller board on flat surface, component side up, as shown in the figure.
- (3) Obtain 20-pin Winchester data cable. Note the cable has a black jacket that covers its shield. On one connector end, the jacket is notched on both sides. This end plugs into the cabinet.
- (4) Inspect cable connector on notched end and observe a triangular marking etched on one side. This marking identifies pin 1.
- (5) Go to rear of cabinet and locate DATA INPUT rear panel connector. Notice marking identifying pin 1.



TP 323/83

Figure 4-4. Front Bezel Removal

- (6) Plug Winchester data cable into DATA INPUT. Ensure that pin 1 of cable matches pin 1 of connector.
- (7) Plug loose end of cable into 8240-J1. Ensure that pin 1 of cable matches J1-1 as shown in figure.
- (8) Obtain 50-pin Winchester control cable. As before, identify end that connects to cabinet (the end with the black jacket notched on both sides). Also, identify pin 1.
- (9) Plug cable into WINCHESTER INPUT. Ensure that pins 1 of cable and connector match.
- (10) Plug other end of cable into 8240-J3 as shown in figure.
- (11) Obtain 40-pin Tape cable. As before identify end that connects to cabinet. Also identify pin 1.
- (12) At rear of cabinet, plug one end of cable into TAPE INPUT. Ensure that pins 1 of cable and connector match.
- (13) Plug other end of cable into 8240-J4.
- (14) Compare cabling just done with the figure. If no errors are found continue this procedure and install the cable clamps.
- (15) Note from the detail in Figure 4-5 that the cable clamps are notched on one face. The notched face indicates the bottom part of the clamps.
- (16) Install the bottom (longer) clamp first. Ensure the clamp makes good mechanical contact with the exposed shielded parts of both cables. Tighten both captive screws of the clamp.
- (17) Set a multimeter to a low ohms scale and measure between chassis ground and the exposed cable shields to ensure good electrical continuity.
- (18) Install the top clamp. As before, ensure good mechanical as well as good electrical contact is made between chassis ground and the exposed cable shield.

Ensure that all three cable shields are grounded to the CPU chassis. If you have any questions, contact DSD Customer Service Department.



### 4.6.3. Configuring Controller Board

The DSD 8240 Controller is configured with jumpers. These jumpers are installed between pairs of pins at various locations on the printed circuit board. It is important that the board is properly configured before it is used with a computer system.


The jumpers on the DSD 8240 Controller board are grouped in five classes:

- (1) Bootstrapping Options. This group provides jumpers to enable or disable the built-in boot program (W16 and W17), select boot address (W10) and boot mode (W31), and control line-time clock (LTC) interrupts (W8 and W9).
- (2) Device Options. The jumpers in this group enable or disable the disk (W15) and select disk address and interrupt vectors (W11). There are also jumpers to enable or disable the tape (W12 and W13), select tape address and interrupt vectors (W18), select tape drive emulation mode (W32), and enable or disable tape drive POCs (W33).
- (3) Interrupt Priority Options. The jumpers in this group select the disk and/or tape interrupt priority level (W20 and W21).
- (4) DMA Request Monitor Option. Two jumpers in this group (W6 and W7) enable or disable the option.
- (5) Error Correction Option. One jumper (W25) enables or disables the option.

Figure 4-6 shows the location of the Controller jumpers. Table 4-3 is a reference chart that lists all jumpers, including those used for testing the board at the manufacturing facility.

The factory configuration is based on the most common applications used by customers. If this "standard" configuration satisfies you, skip the rest of this section, go to the next section, and mount the board.

If you need to reconfigure the board, read the rest of this section and use the flowcharts in Figures 4-7 through 4-11. Each figure is preceded by pertinent information.



TP 310/83

Figure 4-6. DSD 8240 Jumpers

Table 4-3. DSD 8240 Jumpers

Jumper	Shipped	Option Class	Function (As Shipped)
W1	Installed	N/A	Factory use
W2	Installed	N/A	Factory use
W3	Installed	Boot	LTC Disabled
W4	Installed	N/A	Factory use
W5	Installed	N/A	Factory use
W6	Removed	DMA Request	Monitor Disabled
W7	Installed	DMA Request	Monitor Disabled
W8	Removed	Boot	LTC Disabled
W9	Installed	Boot	LTC Disabled
W10	Removed	Boot	Boot: Normal Address
W11	Removed	Device	Disk: Normal Address
W12	Removed	Device	Tape Enabled
W13	Installed	Device	Tape Enabled
W14	Removed	Device	Disk Enabled
W15	Installed	Device	Disk Enabled
W16	Installed	Boot	Boot Enabled
W17	Removed	Boot	Boot Enabled
W18	Removed	Device	Tape: Normal Address

Table 4-3. DSD 8240 Jumpers (Cont)

Jumper	Shipped	Option Class	Function (As Shipped)
W21	Removed	Int. Priority	At Level Five
W19	(Not used on this board)		
W20	Installed	Int. Priority	At Level Five
W22	Removed	N/A	Factory use
W23	Removed	N/A	Factory use
W24	Removed	N/A	Factory use
W25	Removed	Error Correction	Enabled
W26	(Not used on this board)		
W27	Installed	N/A	Factory use
W28	Removed	N/A	Factory use
W29	Removed	N/A	Factory use
W30	Installed	N/A	Factory use
W31	Removed	Boot	CM Boot Disabled
W32	Removed	Device	TSV05 Emulation
W33	Removed	Device	Tape POCs Enabled
W34	Installed	N/A	Factory use

#### 4.6.3.1. Bootstrapping Options

LSI-11 computers use a "bootstrapping" technique for loading software programs. This technique consists of loading a primary set of instructions into main memory that, when executed, enables the CPU to load a secondary and, slightly longer, set.

The secondary set or bootstrap loader, as it is also known, enables the CPU to load complete operating systems and application programs.

The primary boot is contained in the DSD 890 diagnostic control board. This board contains a program in PROM, which initializes system memory, including parity. It also checks the Controller, Winchester drive, and permits bootstrap loading (second boot) from any Winchester volume, the Tape drive, or a RX02-compatible floppy - such as DS-100/105 subsystems.

This primary boot is enabled or disabled with two jumpers. The program can be selected from starting address 17773000 (DEC normal) or 17771000 (DEC alternate). One jumper selects this address.

Most DEC LSI-11 CPU modules are configured in one of two power-up modes. Some modules may be configured in as many as four power-up modes. Because of these variations, You should consult your DEC documentation for specific details about the CPU module that you are using. As an example, LSI-11/23 modules can be configured to power-up in modes 1 and 2. The DSD 8240 Controller will behave differently depending on the selected power-up mode.

In mode 1, the CPU enters console ODT without attempting to boot. At that point, the user must manually initiate the primary boot by typing the address of the boot device. That is, 17773000 or 17771000 for the DSD Winchester boot PROM, or the address of some other device boot PROM in the system.

In mode 2, power applied to the module causes the CPU to internally generate a bootstrap starting address (17773000) and begin to execute instructions found at that address.

The DSD 8240 Controller provides two secondary boot modes: conversational and non-conversational. The conversational mode prompts the user, via console, to select a device for the secondary boot.

In non-conversational mode, there are, again, differences based on the selected power-up mode. To use the LSI-11/23 example once more:

- In mode 1, the secondary boot device can be selected, via console ODT, by typing the device starting address.
- In mode 2, the secondary boot will be obtained from volume 0 of the Winchester drive.

One frequent problem with DEC CPUs is completing the boot operation while the line-time clock (LTC) is running. This is because some systems use a continuously-running LTC, not enabled by operating software. In such systems, an LTC interrupt may occur during booting - before proper interrupt-handling software is loaded into main memory.

If you are using a StacPac Processor module (DS-400), you will not experience any of these problems. If you are using other "Processor" modules you can also prevent these problems by properly using the functions provided by your DSD 8240 Controller.

The following example assumes you are using a LSI-11/23-PLUS (DEC KDF11-BA) CPU. This illustrates system-dependent considerations that must be taken into account. Refer to DEC documentation for other CPU boards.

The DEC LSI-11/23-PLUS board includes a bootstrap PROM. This PROM tests memory and allows bootstrap loading from several devices. The confidence checks provided by the PROM are oriented towards the CPU and serial communications link.

If your computer CPU is an LSI-11/23-PLUS, you have a choice of using the Winchester boot or the CPU boot. However, you must be aware of the following:

- (a) The LSI-11/23-Plus boot PROM and LTC are enabled by a single jumper (J5) on the board. The DEC CPU responds to LTC address: 1777546.
- (b) The DSD 8240 Controller contains circuitry to temporarily disable LTC interrupts (clamping Q-Bus signal BEVENT L low), until enabled by interrupt-handling software (i.e., a write to location 1777546 with bit 6 set).

Consequently, if you desire to use the DEC KDF11-BA boot, you must:

- Disable the DSD Controller boot and LTC functions.

Conversely, if you desire to use the DSD 8240 boot, you must:

- Disable the DEC KDF11-BA boot/LTC functions (by grounding J5) and enable these functions on the Controller board.

Consult DEC documentation and use Figure 4-7 to determine the bootstrapping configuration required by your DSD Controller board.




Figure 4-7. Bootstrapping Options

#### 4.6.3.2. Device Options

The DSD 8240 controller supports the Winchester drive and the Tape drive. Either device may be independently enabled or disabled. Standard and alternate device addresses and interrupt vectors are provided for each device.

Most applications require using the standard (DEC standard) device addresses. The alternate addresses may be required if the system contains two DSD 8240 Controllers, or if a DEC RL02 subsystem is also connected to the computer system.

The Winchester disk must be temporarily disabled when copying an operating system from a RL02 onto cartridge tape. This procedure is explained in Section 4.6.7. The disk drive is disabled by moving a jumper from location W15 to location W14.

The Tape must be temporarily disabled when copying an operating system from a TSV05/TS11 onto a Winchester volume. This procedure is explained in Section 4.6.7. The Tape drive is disabled by moving a jumper from location W13 to location W12. In addition, the Tape interface POCs must be disabled by installing a jumper in location W33.

The Tape Drive emulates DEC TS11 and TSV05 magnetic tape systems. Jumpers are provided on the Controller board to select either function. In general, TSV05 emulation should be selected in computer systems using 22-bit addressing modes.

Use Figure 4-8 and select configuration required by your Controller board.

#### 4.6.3.3. Interrupt Priority Options

DEC LSI-11/23 and LSI-11/23-PLUS CPUs provide a multiple-level interrupt scheme, which is fully supported by the DSD 8240 Controller. This scheme permits peripheral devices to have interrupt priorities, which are position-independent, that is, independent of the backplane position occupied by their controllers.




Figure 4-8. Device Options

TP 520/83

Priority levels may be set anywhere from level four (lowest) to level seven (highest). DEC normally configures RL02 controllers to operate at level five. This priority level will also work for older LSI-11 processors using level four only.

In the DSD 8240, the disk and tape sections operate at the same interrupt-priority level. The Controller firmware arbitrates disk and tape interrupts to ensure no conflicts.

Use Figure 4-9 to configure your Controller board. We recommend using interrupt-priority level five (5).

#### 4.6.3.4. DMA Request Monitor Option

The DSD 8240 Controller transfers data between the storage drives and main memory using DMA. When slower DMA controllers are used with the DSD 8240, the slower controllers may experience "data late" conditions. A tape controller with a small (one- or two-byte buffer) is an example of such a controller.

To reduce data lates, the DSD 8240 can be jumpered to monitor the Q-Bus DMA Request line (BDRMR L). DMA transfers are monitored in blocks of four words. If during a DMA operation another controller requests the bus, the DSD 8240 temporarily relinquishes the bus and delays the transfer.

Generally, the DMA Request Monitor function does not interfere with non-interleaving disk operations, unless a second controller is using the full bus bandwidth - the spectrum of data transfer speeds acceptable by the bus.

In such heavily loaded systems, Winchester disk performance may be degraded if the Controller cannot complete transfers of disk sectors during one disk revolution. In this case, it is preferable to format the Winchester for two-way interleaving. This procedure is explained in Appendix A (GEMEXR User Guide).

Use Figure 4-10 to configure your Controller, according to your needs. If you want the Controller to process DMA data transfers at the fastest possible rate, disable the DMA Request Monitor option.

Also, if your system is equipped with a DSD 8836 Controller (DSD 880 Subsystems), it may be desirable to disable the option on both controllers.




Figure 4-9. Interrupt Priority Options

TP 521/83




Figure 4-10. DMA Request Monitor Option TP 522/83

#### 4.6.3.5. Error Correction Option

One important function of the DSD 8240 Controller is transparent error correction for the Winchester disk drive. The Controller can detect and correct data field errors recorded on the disk. The errors can be as long as eleven bits.

Disk errors detected during an initial read operation are not immediately corrected. The Controller reports the error to the operating system as a "data CRC error. On sensing the error, the software logs the error to create a history file and re-tries the operation.

The Controller reads the data field again. This time, if the error is correctable, the Controller does the correction without informing the software.

Since DEC does not provide the error detection and correction function, a jumper on the Controller board disables it. This simple operation is shown in Figure 4-11.

#### 4.6.4. Mounting Controller

The Controller board can be inserted into an LSI-11 computer card-cage or into a StacPac Processor module. The board makes electrical connections with the backplane via contact fingers on four edge connectors.

Figure 4-12 shows three common LSI-11 backplane versions. Refer to your DEC manual for other configurations. If using a Processor module, refer to the Technical Reference manual provided with that unit.

When installing the board, ensure that no opened or unused slots are left in the priority chain between the CPU and the board. It may be necessary to re-arrange dual-wide cards, such as memory boards or serial line units to meet this requirement. To install the board, proceed as follows:






Figure 4-11. Error Correction Option

TP 523/83




### DEC Backplane H9270



View is from Module Side of Connectors

### DEC Backplane H9273-A



### DEC Backplane DDVII-8

TP 312/83

Figure 4-12. Common LSI-11 Backplanes

- (1) At computer, insert board into selected card cage slot.
- (2) Ensure board is properly seated on backplane connectors.
- (3) Dress subsystem cables to reduce cable stress and allow proper ventilation. The Controller board is properly installed.

#### 4.6.5. System Power-Up

Your system is equipped with a three-prong power cord. The power-up procedure is quite simple:

- (1) AT the rear of the cabinet, ensure the POWER ON/OFF switch is off.
- (2) Locate the three-prong power receptacle. Note the window above it and ensure that it reads the correct ac voltage value.
- (3) Connect the female end of the power cord in the receptacle.
- (4) Plug the male end of the cord into a three-prong ac power outlet. Ensure that your outlet is properly grounded. If using an adapter, ground the adapter with a pigtail.
- (5) Restore power to the LSI-11 computer.
- (6) Turn the POWER ON/OFF switch on and wait a few seconds for the system to complete the POCs. If no failures are detected (FAULT LED off), go to the next section and do the acceptance tests. If the FAULT LED stays on, refer to Chapter 7 for instructions.

#### 4.6.6. Acceptance Testing

The DSD 890 acceptance testing consists of running programs stored in the RL/TS Distribution tape cartridge. These programs are also distributed on diskettes (floppy disks).

The programs used for acceptance testing are RLEXR (Winchester exerciser) and TSEXER (tape exerciser). These programs exercise the RL02 and TS11/TSV05 emulation capabilities of the system, and check the Winchester and magnetic tape media.

A user guide for each program is provided in Appendices C and D. Condensed versions are provided in the next two subsections. Do the tests in the sequence provided.

#### 4.6.6.1. Testing With RLEXR

The RLEXR program may destroy any data stored on the Winchester disk volumes, excluding format information. The RLEXR test program is controlled from the system console.

- (1) Write-protect RL/TS Distribution tape cartridge and insert it into drive.
- (2) Boot from cartridge to load tape monitor (TMON) program.
- (3) Select RLEXR from displayed menu.
- (4) Use SHort Acceptance test to verify all three emulated RL02 volumes. Allow test to run at least two hours or until errors are reported.
- (5) If no errors are reported, continue with Tape tests provided in next subsection. If errors are reported, go to Chapter 7 for troubleshooting instructions.

#### 4.6.6.2. Testing With TSEXr

The TSEXr program verifies the write-capability of the drive. Therefore, unless you proceed with caution, any data stored on the cartridge may be destroyed. The TSEXr test program is controlled from the system console.

- (1) Write-protect RL/TS Distribution tape cartridge and insert it into drive.
- (2) Boot from cartridge to load tape monitor (TMON) program.
- (3) Select TSEXr from displayed menu.
- (4) Remove Distribution cartridge from Tape drive and insert write-enabled, blank cartridge, in its place. Ensure cartridge reaches "load" point before beginning tests.
- (5) Use ACCEPT command to test basic Tape drive read/write functions. A few recoverable errors (TCC4 or TCC5) may occur during normal operations. A function reject error (TCC3) may occur if cartridge is improperly installed, write-protected, or if testing began at wrong tape point.

- (6) If excessive errors occur, clean Tape drive head (see Chapter 7) and repeat tests. If after cleaning head, errors persist, refer to Chapter 7 for troubleshooting instructions.


#### 4.6.7. Installing Software Programs

The Winchester drive records data in a soft-sectored format. The drive is preformatted at the factory and ready to use. In most cases, the operating system and application software packages can be transferred from a system device such as an RX02-compatible floppy device, a DEC RL02 disk subsystem, or a DEC TSV05 tape system. The next three subsections provide examples on how these operations can be done with each device.


##### 4.6.7.1. Transfer Using Floppy

If your computer system is equipped with a RX02-compatible floppy drive, such as the StacPac DS-100 or DS105 subsystem, you can transfer the software to the Winchester, and then to the Tape with the Backup and Restore utility program (DSDBR) stored on the RL/TS Distribution cartridge. Refer to Figure 4-13 and:

- (1) Boot from floppy device.
- (2) Using your operating system utilities, copy all system files, command files, and disk handler to one Winchester volume.
- (3) Insert RL/TS Distribution cartridge into Tape drive.
- (4) Using DSDBR, make backup copy of Winchester volume on cartridge tape. Write-protect cartridge and save for future use. A complete user guide for DSDBR is provided in Appendix B. Simplified versions of Backup and Restore procedures are provided in Chapter 5.



1. Use Operating System "Copy" Utility



2. Insert RL/TS Distribution Cartridge and  
3. Use DSDBR Utility to Copy to Tape

TP 527/83

Figure 4-13. Transferring Software Using Floppy

#### 4.6.7.2. Transfer Using RL02

If you have a DEC RL02 device and DEC RLV11/RLV12 controller available, you can transfer software from the RL02 device to the Tape drive cartridge, and then to the Winchester. Several methods can be used, however; since the RL02 address may be identical to the Winchester drive address some care is required. Refer to Figure 4-14 and:

- (1) Disconnect power from processor rack, install DEC RLV11/RLV12 controller and RL02 device at DEC standard address (17774400/160).
- (2) Remove DSD 8240 Controller from card cage.
- (3) Disable Winchester disk by removing Jumper W15 and installing it in location W14. The Winchester primary boot can still be used.
- (4) Mount DSD Controller board and reapply system power.
- (5) Insert RL/TS Distribution cartridge into Tape drive.
- (6) Boot from Tape drive and load DSDBR.
- (7) Remove RL/TS Distribution cartridge from Tape drive.
- (8) Insert write-enabled blank cartridge into Tape drive.
- (9) Using DSDBR commands, copy RL02 volume to tape cartridge.
- (10) Remove recorded cartridge from Tape drive.
- (11) Power off processor rack, remove DEC controller, and RL02 device.
- (12) Remove DSD 8240 Controller from card cage.
- (13) Enable Winchester disk by removing Jumper W14 and installing it in location W15.
- (14) Mount DSD Controller board and re-apply system power.
- (15) Insert RL/TS Distribution cartridge into Tape drive.
- (16) Boot from Tape drive and load DSDBR.
- (17) Remove RL/TS Distribution cartridge from Tape Drive.
- (18) Insert recorded cartridge into Tape Drive.

- (19) Using DSDBR, restore contents of tape cartridge to Winchester volume.
- (20) Remove recorded cartridge from Tape drive, write-protect it, and save for future use.

If one DEC RL02 device is permanently installed in the system, the above procedure is slightly different. Instead of disabling the Winchester disk, you can assign the RL02 the normal address and interrupt vector (17774400/160) and the DSD Winchester the alternate address and interrupt vector (17774420/150).


If multiple DEC RL02 devices are permanently installed, you must use the first procedure. That is, you must disable the DSD Winchester drive, during the RL02-to-Tape transfer.

#### 4.6.7.3. Transfer Using TSV05


If your system is equipped with a DEC TSV05 or DEC TS11 tape system and the operating system is configured (sysgened) for multiple tape controllers, you can copy software from the DEC tape to the DSD Winchester using copy utility commands.

If the operating system is not sysgened for multiple tape controllers, refer to Figure 4-15 and:


- (1) Power off processor rack.
- (2) Remove DSD 8240 Controller from card cage.
- (3) Disable tape by removing Jumper W13 and installing it in location W12. Also, install a jumper in location W33 to disable Tape drive POCs.
- (4) Mount DSD Controller board and re-apply system power.
- (5) Boot from DEC TSV05/TS11 device.
- (6) Using utility commands, copy DEC tape to Winchester volume
- (7) Power off processor rack.
- (8) Remove DSD 8240 Controller from card cage.




RL/TS Distribution Cartridge in Drive  
 1. Load DSDBR in Memory



Blank Cartridge in Drive  
 2. Use DSDBR to Copy to Tape



RL/TS Distribution Cartridge in Drive  
 3. Load DSDBR in Memory






Recorded Cartridge in Drive  
 4. Use DSDBR to Restore to Winchester

TP 528 83

Figure 4-14. Transferring Software Using RL02

- (9) Enable DSD Tape Drive by removing Jumper W12 and installing it in location W13. Also, enable Tape Drive POCs by removing Jumper W33.
- (10) Set Tape base address to 175520 by removing jumper W18.
- (11) Remove DEC TSV05/TS11 device and controller from system.
- (12) Mount DSD Controller board and re-apply system power.
- (13) Insert RL/TS Distribution cartridge into Tape drive.
- (14) Boot from Tape drive and load DSDBR.
- (15) Remove RL/TS Distribution cartridge from Tape drive.
- (16) Insert write-enabled cartridge into Tape drive.
- (17) Using DSDBR, back up contents of Winchester volume to cartridge.
- (18) Remove recorded cartridge, write-protect it, and save it for future use.

[^]



TP 529/83

Figure 4-15. Transferring Software Using TSV05/TS11



---

## 5 OPERATING INSTRUCTIONS

---

### 5.1. General Information

This chapter provides instructions for the most frequent system operations. The DSD 890 controls and indicators were described in Chapter 4. If necessary, refer to that chapter.

### 5.2. Introduction

Your system consists of mechanical drives, printed circuit (PC) boards, and interconnecting cables. The mechanical drives are normally inactive unless an operation is requested from the system console, the Operator panel, or the operating system software.

To extend the life of your system, we recommend that you leave it turned-on most of the time. As a safety measure, it is always a good practice to remove power from equipment which remains unattended for long periods of time.

### 5.3. Applying Power

The system cabinet is powered by turning the rear power switch to ON. The Controller board receives power from the processor backplane.

When the cabinet and Controller board are powered-up, the Controller automatically does a series of power-on confidence (POC) tests. These POCs are fully described in Chapter 7.

During the POCs, the Tape ACTIVE and WIN ACTIVE LEDs on the Status panels light. At the end of these brief tests, both LEDs go off, and test results are displayed:

- If no failures are found, the STATUS LED displays zero.
- If failures are detected, the FAULT LED is lighted and STATUS displays a two-number error code. Since only one digit is available, the LED flashes one number, blanks

for a short time, flashes a second number, and blanks for a longer time. For example, to display number 41, the LED flashes number four, blanks for a brief time, flashes number one, blanks for a longer time, and repeats the sequence.

If, during the POCs, failures are detected, contact your technical personnel for advice. Troubleshooting instructions are provided in Chapter 7.0.

#### 5.4. Loading the Cartridge


The cartridge used with your system has a file protect indicator on the upper left hand corner (see Figure 5-1). The file protect indicator can be turned with a screwdriver to either of two positions.

When the indicator points to SAFE, it prevents the Tape drive from overwriting data on the tape. This is desired when loading DSD programs from cartridge tape.

When the indicator points away from SAFE, the drive can do read/write operations with the tape. This is necessary for data storage and retrieval operations.


To load the tape cartridge into the drive, proceed as follows:

- (1) Open the Operator panel door.
- (2) Ensure the LOAD/UNLOAD switch on the panel is set to LOAD.
- (3) Insert the tape cartridge into the slot provided in the front panel (see Figure 5-2).
- (4) Wait while the drive rewinds the cartridge to the load point. Observe the TAPE ACTIVE indicator is on. Wait for the indicator to go off.
- (5) When the TAPE ACTIVE indicator goes off, the Tape drive is ready to use.



TP 315/83

Figure 5-1. Magnetic Tape Cartridge



TP 328/83

Figure 5-2. Inserting the Cartridge

## 5.5. Unloading the Cartridge

Before a cartridge is removed from the drive, it is a good practice to rewind the tape to the unload point. This simple precaution will ensure that recorded data is protected from dust or other foreign matter and that the tape in the cartridge is smoothly wound for its next use. Follow these instructions:

- (1) Observe the UNLOAD indicator on the Status panel. If the indicator is off, proceed with Step 2. If the indicator is on, go directly to Step 5.
- (2) Open the Operator panel door and set the LOAD/UNLOAD switch to UNLOAD.
- (3) Wait for the system to complete any tape operations and begin to rewind the cartridge. During the rewind operation, the TAPE ACTIVE indicator lights.
- (4) Wait for the TAPE ACTIVE indicator to go off. When it goes off, the UNLOAD indicator lights. (See Caution below.)
- (5) Remove the tape cartridge from the drive.

## 5.6. Bootstrapping

To function, computers need to load at least part of an operating system into main memory. These memories are temporary storage locations, which are erased every time the main processing (CPU) rack is turned off.

If your computer system has been turned off or otherwise lost power, you will need to reload the operating system.

Before you reload the operating system, you will need to load a program, which will enable you to do so. The method of loading this enabling program is known as bootstrapping or booting, for short.

---

CAUTION: Before removing cartridge, ensure TAPE ACTIVE is off and UNLOAD is on to prevent unrecoverable loss of data.

The boot method depends on how your computer is set up to power-up. It also depends on how the Controller board was configured during installation. The most common power-up conditions are outlined below:

- The computer will automatically boot from volume 0 of the Winchester drive.
- The computer will prompt you to select a booting device, by displaying a list of available devices.
- The computer will display a special prompt (@). At this point, you can type one of the addresses shown in Table 5-1. Refer to Chapter 4 for more details, or ask your installer what address to use.

Table 5-1. Bootstrap Device Selection

To Select:	Type Address:
Winchester Volume 0	771000 or 773000
Winchester Volume 1	771002 or 773002
Winchester Volume 2	771004 or 773004
(Reserved)	771006 or 773006
Tape Cartridge	771010 or 773010
Floppy at 777170	771012 or 773012
Floppy at 777150	771014 or 773014
(Reserved)	771016 or 773016

NOTE: After entering the address, press G (for GO!).

## 5.7. Backup and Restore Operations

The cartridge tape is an excellent medium on which to store Winchester backup files for later use in restoring lost disk data. There are three methods available for doing backup and restore operations:

- (a) Since the Tape drive emulates the DEC TS-11/TSV05 storage system, it is simple to obtain tape copies from disk by using DEC operating system commands. For example, to copy a filename and extension such as "DATA.SAV" under the RT11 operating system, the user enters:
- COPY DL0:DATA.SAV MS0:
- (b) Under DEC RSX-11M or similar operating systems, higher-level backup and restore utilities, such as BRU and DSC, are supported. These utilities are supported by the DSD 8240 Controller. Consult your DEC documentation for operating information.
- (c) Full disk image backup and restore operations are supported by the DSD backup and restore (DSDBR) program. This program is stored in the RL/TS Distribution cartridge supplied with your equipment. Complete instructions for DSDBR are given in Appendix B. Simplified backup and restore procedures are provided in the next two subsections. See Note below.

### 5.7.1. Creating Backups

Your Tape drive can be used to make backup copies of all files stored on any of the three Winchester volumes. The backup frequency will be determined by the needs of your organization. Because the operation is somewhat time-consuming, we suggest that backups be done at the end of the working day or before an extended work break. The operation is done from the system console.

- (1) Write protect the RL/TS Distribution cartridge and insert it into the tape drive.
- (2) Boot from the tape to load the tape monitor (TMON) program.
- (3) Select DSDBR from the displayed menu.
- (4) Remove the distribution cartridge from the drive.
- (5) Insert a write-enabled blank cartridge into the drive.

---

NOTE: The DSDBR program is RT-11 compatible. It may be copied to the system disk and used as an RT-11 utility.

- (6) Select the Winchester volume to be copied. You can backup up to one complete Winchester volume (10 Mbytes) on each cartridge.
- (7) After the operation is completed, remove the cartridge from the drive, write protect it, and save it for future use.

### 5.7.2. Restoring Disk Data

Your Tape drive can be used to restore data from a backup cartridge to any of the three Winchester volumes. As backups, restoring disk data is time-consuming and should be done during times when the drives are not constantly needed. The operation is done from the system console.

- (1) Insert the RL/TS Distribution cartridge into the tape drive.
- (2) Boot from the tape, to load the tape monitor (TMON) program.
- (3) Select DSDBR from the displayed menu.
- (4) Remove the distribution cartridge from the drive.
- (5) Insert a write-protected backup data cartridge into the drive.
- (6) Select the Winchester volume to be restored. You can restore up to one complete Winchester volume (10 Mbytes) from each cartridge.
- (7) After the operation is completed, remove the cartridge from the drive.

[^]



---

## 6 USER MAINTENANCE

---

### 6.1. General Information

This chapter provides maintenance instructions for the daily user of the system. No technical training is needed for using this information, however; observe all suggested precautions to avoid equipment damage, personal injury, or both.

### 6.2. Proper Ventilation

Your equipment is kept at an ideal operating temperature by vents located at the rear of the modules. The circulating air is propelled by an internal fan. It is important that the cabinet have enough rear space - not less than three inches - for free air flow.

Should the system become hot, turn the power off and inspect the area surrounding the cabinet for obstructing objects. Turn the power on again. If the problem recurs, turn the power off and contact your technical manager or DSD Customer Service for further instructions.

### 6.3. Cleaning the Cabinet

The cabinet is not waterproof; consequently care should be used when cleaning its surface. Follow these instructions:

- Dust each module surface frequently to keep display panels clean.
- Turn the power off. Pour a small amount of non-abrasive mild detergent solution (such as Windex or equivalent) on a lint-free soft cloth (see Caution below).

---

**CAUTION:** Cleaners containing solvents or abrasive substances can damage the cabinet surface.

- Apply the damp cloth, or paper towel, to the module surface and rub gently until it appears clean. Allow it to dry; reapply, if necessary.

#### 6.4. Quick Troubleshooting Chart

Generally, field equipment problems are due to minor oversights easily correctable by a few simple steps. Table 6-1 contains a chart for aiding the user with these types of problems.

When using the chart, first look under the "Trouble Indication" column and find the signs given by your equipment most closely approximating the chart.

Second, look under the "Possible Cause" column. Examine your equipment to see if the cause of your trouble is in the chart.

Before attempting any corrective action (for example, replacing a blown fuse) turn the cabinet power off and unplug the power cord. Do not attempt repairs that require removing the cabinet covers.

Field maintenance instructions are provided in Chapter 7. That chapter requires technical experience or training.

If unable to correct the problem, contact the technical manager of your organization, your equipment supplier, or DSD Customer Service for further instructions.

Table 6-1. Quick Troubleshooting Chart

Indication	Possible Cause
Equipment "dead"	<ul style="list-style-type: none"> <li>● Power cord unplugged</li> </ul>
Equipment "dead"	<ul style="list-style-type: none"> <li>● Blown fuse (See Figure 6-1)</li> </ul>
* Equipment "dead"	<ul style="list-style-type: none"> <li>● Defective power supply</li> </ul>
FLT light always on	<ul style="list-style-type: none"> <li>● Loose Winchester/Tape drive cable connections</li> </ul>
No Tape drive action	<ul style="list-style-type: none"> <li>● Loose Tape drive cable at rear connector, or at backplane</li> </ul>
No Tape drive action	<ul style="list-style-type: none"> <li>● Defective Tape drive</li> </ul>
No Winchester drive action	<ul style="list-style-type: none"> <li>● Loose Winchester cable at rear connector</li> </ul>
No Winchester drive action	<ul style="list-style-type: none"> <li>● Defective Winchester drive</li> </ul>
Winchester drive action, but no read/write functions	<ul style="list-style-type: none"> <li>● Loose Winchester data cable rear connection</li> </ul>
Winchester drive action, but no read/write functions	<ul style="list-style-type: none"> <li>● Defective Winchester circuits</li> </ul>

[^]




Figure 6-1. Fuse Location

TP 585/84

---

## 7 FIELD TROUBLESHOOTING AND REPAIRS

---

### 7.1. General Information

This chapter covers the following topics:

- Preventive maintenance
- Winchester media management information
- Diagnostic tools
- Troubleshooting using flowcharts
- Repair and replacement information

Your equipment passed rigorous factory tests to ensure long periods of trouble-free service. However, if you suspect a malfunction, follow the instructions provided in this chapter. Observe all suggested precautions to avoid equipment damage, personal injury, or both.

### 7.2. Maintenance Philosophy

Maintenance of the DSD 890 System is an easy task because the equipment was designed with the user in mind. The product maintenance philosophy can be summarized as follows:

- **Preventive Maintenance:** The equipment requires a minimum number of preventive routines.
- **Troubleshooting:** Several diagnostic tools are either built into the equipment or loaded from DSD software media. These tools permit rapid diagnosis of persistent malfunctions and help detect intermittent drives and media problems.
- A telephone hot-line, staffed by fully trained DSD technicians, provides diagnostic help with difficult problems.

- A Rapid Module Exchange policy allows the user to receive a replacement unit shortly after the faulty one is identified.

### 7.3. Preventive Maintenance

Trouble preventing routines are limited to periodic cleaning of the Tape drive head and capstan rubber wheel. The cleaning frequency is proportional to the amount of use. Refer to Figure 7-1 and follow these instructions:


- (1) Turn the DSD 890 cabinet power off.
- (2) Visually check the drive for oxide or dirt accumulation on read/write head and capstan rubber wheel.
- (3) Use a vacuum cleaner to remove accumulation of dust. Do not allow suction tip of vacuum cleaner to touch read/write head. DO NOT ALLOW METAL PARTS OF VACUUM CLEANER NEAR READ/WRITE HEAD.
- (4) Dip a cotton swab in a commercial (90%) solution of isopropyl alcohol. Do not use common isopropyl (rubbing or denatured) alcohols found in drug stores. Allow a few seconds for excess solvent to evaporate. (See Caution below.)
- (5) Gently clean head and capstan rubber wheel with cotton portion of cotton swab. Do not allow wooden portion to touch head. Repeat if necessary until head and wheel are clean. Allow solution to evaporate before using drive.

### 7.4. Winchester Disk Formatting

Data is stored on the Winchester disk in a soft-sectored format. (i.e., a sector position is identified by a header followed by a 256-byte data field). During normal operations, data fields are frequently updated; data headers are not. Formatting is the process of recording headers on the disk.

---

CAUTION: Do not use excess solution and be extremely careful not to allow solution to penetrate the ball bearings of the capstan motor; it will destroy their lubrication.



CAUTION:  
Remove power prior to cleaning.  
Do not use acetone or lacquer  
thinners, aerosol sprays, or  
rubbing alcohol.

TP 398/83

Figure 7-1. Tape Drive Cleaning

The Winchester drive is pre-formatted. Generally, it is not necessary to reformat the disk unless the GEMEXR or RLEXR programs show a "header not found" error. The GEMEXR program can be used to reformat the disk; it provides two basic commands:

- **FORMAT Command.** The entire disk or any consecutive tracks may be formatted. As a default, the entire disk is formatted except cylinder zero, which contains the bad-track map. If cylinder zero is re-formatted, the bad-track map must be re-created.
- **RLFMT Command.** An individual RL02 logical volume may be formatted using this command.

Formatting destroys data stored on the disk. Also, after a formatting operation, it is necessary to restore DEC-compatible RL02 bad sector files at the end of each RL02 logical volume. These operations can be done with the RLBAD command.

#### 7.5. Bad-Track Map Updating

Except for cylinder zero, Winchester manufacturers cannot guarantee the disk media as flaw-free. Consequently, a mechanism must be developed by manufacturers of mass storage systems to deal with flaws.

In the DSD System, a bad-track map is recorded on cylinder zero of the disk before shipment. The map is a list of tracks containing known flaws.

When the system is powered up, the list is read and translated by the controller, which then avoids the bad-tracks.

The specific bad-track map list for your system is provided on a card inside an envelope. This envelope is located inside the Winchester module, in a compartment, right in front of the Winchester drive. We recommend that you return the list to the compartment after each use.

The BADTRK command (GEMEXR) can recreate the bad-track map or add additional tracks. Whenever the bad-track map list is altered, note the necessary corrections on the card.

The bad-track map must be initialized whenever cylinder zero of the Winchester drive is reformatted. Refer to Appendix A, GEMEXR User Guide, for operating instructions.

## 7.6. Diagnostic Tools

The DSD 890 System provides four distinct types of diagnostic tools:

- Power-On Confidence (POC) Tests: Brief but complete self-checks are automatically initiated at power-up. These tests thoroughly check for faults and provide a general and effective evaluation of the equipment.
- Bootstrapping Sequence: If the Controller boot is selected, its sequence can be used to isolate malfunctions. The bootstrapping program is listed in Appendix E.
- HyperDiagnostics - a DSD proprietary internal program - can be used to further diagnose problems.
- Comprehensive software programs - distributed on cartridge tape or diskette - exercises disk and tape drives/media to help isolate intermittent or random problems. These programs can also be used for acceptance testing of new modules and for verifying repairs.

### 7.6.1. Power-On Confidence Tests

The firmware enabling the POCs reside in the Controller. The tests consist of two categories: Winchester and Tape drive POCs.

#### 7.6.1.1. Winchester POCs

The functions of the Winchester POCs are listed below:

- Read on-board jumpers and front panel switches
- Reset the disk drive
- Test the controller scratch RAM and buffer RAM
- Test internal controller logic
- Perform a READ/ECC test on the drive data simulator located in the Diagnostic Control board.
- Read the disk bad-track map file and validate its contents

- Initialize all I/O registers and scratch RAM contents

#### 7.6.1.2. Tape Drive POCs

The functions of the Tape Drive POCs are listed below.

- Check tape timer
- Initialize interface, drive, and registers
- Verify drive interrogation protocols

#### 7.6.1.3. POCs Results

While the POCs are running, the Tape and Winchester ACTIVE LEDs light. At completion, both LEDs go off and:

- For no failures, STATUS displays zero.
- For failures, FAULT lights and STATUS displays a two-number code.

A list of codes is provided in the Troubleshooting section. The codes are in octal (0 through 7). Also, codes having identical numbers are not used (for example, 66, 77, etc.)

---

NOTE:

---

Since STATUS has one digit, the two-number code is implemented by flashing the most significant digit, the least significant digit, and then blanking the display for one second. This cycle is repeated until ended with TEST.

---

#### 7.6.2. HyperDiagnostics

This section identifies the controls and indicators used with HyperDiagnostics, outlines the test sequence, and describes the tests.

### 7.6.2.1. Controls and Indicators

The DSD 890 System provides a series of tests known as Hyper-Diagnostics. These tests are controlled from the Operator panel (see Figure 7-2):

---

#### CAUTION:

---

Tests one, four, and five destroy data contained on the device under test. Winchester formatting and bad-track information, however, is preserved.

---

Table 7-1. HyperDiagnostics Tests

---


Number	WP0	WP1	WP2	Test	Minutes/Cycle
0	OFF	OFF	OFF	Re-enter Wait Mode	--
1	OFF	OFF	ON	Disk Write/Read	7.5
2	OFF	ON	OFF	Display Firmware Version	--
3	OFF	ON	ON	Disk Read-Only	2.0
4	ON	OFF	OFF	Tape Write/Read	10.0
5	ON	OFF	ON	Tape and Disk Write/Read	10.0
6	ON	ON	OFF	Re-enter Wait Mode	--
7	ON	ON	ON	Display Last Error Code	--

---

### 7.6.2.2. Description

After a CPU power-up or after a bus initialization, the system enters a "wait" mode. In this mode, STATUS displays a steady zero.

In wait, either CPU or user can gain system control. If the host issues a command, STATUS "blanks" (goes dark) and the system enters emulation mode, disabling TEST.



TP 547/83

---

**Control/Indicator**

**Function**

---

STATUS LED	<ul style="list-style-type: none"> <li>● Lights when system is ready to enter HyperDiagnostics.</li> <li>● Displays test number and test results.</li> </ul>
TEST Pushbutton:	<ul style="list-style-type: none"> <li>● Initiates or cancels any test.</li> </ul>
WP0 through WP2 Switches	<ul style="list-style-type: none"> <li>● Operate as three-digit binary switch.</li> <li>● Select up to eight (0 through 7) decimal numbers. For example, when all are ON (up), number "seven" is selected. See Table 7-1.</li> </ul>

---

Figure 7-2. HyperDiagnostics Controls and Indicators

To select a test, the user sets the write-protect switches to the test number combination and presses TEST. STATUS counts down from nine to zero, and displays the test number. The test can be canceled by pressing TEST, or confirmed by setting the switches down and pressing TEST.

Once started, a test runs until canceled with TEST or until an error is found. If canceled, the system re-enters the wait mode.

If an error is found, FAULT lights and STATUS displays an error code. Error codes are listed in the Troubleshooting section (Section 7.7).

The eight possible combinations of the write-protect switches, during test selection, are listed below.

ZERO:

This is not a test. It allows the user to re-enter the wait mode.

ONE:

This is a disk write/read test. It writes, checks, and reads a test pattern, which contains a sector address, an incrementing data (pass) byte, and an incrementing pattern. This test takes 7.5 minutes for a complete pass.

Test one begins at cylinder 0, head 6 and continues to cylinder 777, head 7 (octal). At that time a POC is done and the test repeats. If an error is found, the bad-track map file is checked to verify if the error occurred on a mapped track. This type of error is ignored. If the error did not occur on a mapped track, the sequence is retried before displaying a fatal error code.

---

CAUTION:

---

During test one, data stored on the disk is destroyed. Bad-track information, mapped on heads 0 through 5 of cylinder 4 are untouched.

---

TWO:

This combination displays the system firmware version code.

THREE:

This is a disk read-only test. It operates on the same sector range as test one. Test three checks for headers-not-found and ECC errors. Error correction is suppressed during retries to avoid masking media defects. Disk data is not affected by this test. This test takes 2 minutes for a complete pass.

FOUR:

This is a tape write/read test. It verifies tape function by performing the sequence below. This test takes 10 minutes for a complete pass.

- (1) Issues tape rewind command and verifies cartridge is at beginning of tape (BOT)
- (2) Switches drive to track two, writes one record, and rewinds
- (3) Writes incrementing data pattern on track zero. Each record is between 4000 bytes and 4255 bytes - depending on record number
- (4) Writes one record in track one
- (5) Switches to track three, writes one record, and one file mark
- (6) Reads all tracks and verifies data pattern previously written
- (7) Verifies space record, forward and backwards, over file mark
- (8) Verifies skip file mark, forwards and backwards, over file mark

During test four, a maximum of nine re-tries per record are allowed for correctable tape errors. For non-correctable errors, one re-try per pass is attempted.

---

**CAUTION:**

---

During test four, all data stored on the tape is destroyed.

---

**FIVE:**

This is both a tape and a disk write/read test. It does, simultaneously, the same checks as one and four. The displayed error code, if any, is assigned to the first device detecting an unrecoverable error. This test takes 10 minutes for a complete pass.

---

**CAUTION:**

---

During test five, data stored on both devices is destroyed. Winchester formatting and bad-track information remains untouched.

---

**SIX:**

This is not a test. This combination, when confirmed, allows the user to re-enter the wait mode.

**SEVEN:**

This is not a test. This combination displays the contents of an error-save location that contains the last system error code. This location is cleared only at Controller power-up and it is retained across bus initializations.

If no error code occurred since the last power-up, a flashing zero is displayed. Some RT-11 systems may display code 23 (invalid word count). This is a normal code stored during the computer bootstrapping operation. Operating systems may cause other software-related error codes.

### 7.6.2.3. Operation

The Hyperdiagnostics sequence of operation is shown in Figure 7-3. This procedure exemplifies the most significant steps.

- (1) Apply subsystem power and observe STATUS. It should display zero. If not, halt CPU and operate Reset (Restart) switch.
- (2) Select test number from Table 7-1.
- (3) Set write-protect switches to test number.
- (4) Press TEST and observe STATUS. It counts down from 9 to 0 and then displays test number.
- (5) Reset switches to OFF and press TEST to confirm. While test is running, STATUS displays test number.
- (6) Wait for test to complete desired number of test cycles.
- (7) If test fails, FAULT lights and STATUS displays error code.
- (8) To end test, press TEST. The system returns to wait mode, ready for next test.

### 7.7. Troubleshooting

This section provides a methodic diagnostic technique for troubleshooting your equipment. Before using this technique perform the following preliminary checks:

- Observe the Status panel to verify that the cabinet is on. If not, ensure the power switch is on, and the fuse is not blown.
- Observe the front panel for obvious mistakes. For example, trying to write a write-protected disk volume or cartridge tape.
- Check system ventilation.
- Ensure that all cables between the cabinet and the Controller board are properly mated.




Figure 7-3. HyperDiagnostics Procedure

TP 444/83

After the routine checks are completed, proceed to Figure 7-4. This figure contains a main flowchart that will lead you to other figures or tables.

While troubleshooting, it is essential to follow the exact sequence provided by the flowcharts - correct interpretation of each test depends on the results obtained from previous ones.

The complete set of troubleshooting figures and tables is listed below:

- Figure 7-4. Main Troubleshooting Path.
- Figure 7-5. POC Failure
- Figure 7-6. Bootstrapping Failure.
- Table 7-2. HyperDiagnostics Error Codes.
- Table 7-3. Software Diagnostic Procedures.
- Table 7-4. POC Error Codes.
- Table 7-5. Bootstrap Error Codes.

In addition, Table 7-6 provides a summary of all codes that can be displayed by the STATUS LED.

Figure 7-4. Main Troubleshooting Path.

Figure 7-5. POC Failure

Figure 7-6. Bootstrapping Failure.





Figure 7-4. Main Troubleshooting Path.



TP 526/83

Figure 7-5. POC Failure




Figure 7-6. Bootstrapping Failure.

Table 7-2 HyperDiagnostics Error Codes

ERROR CODE	MEANING	PROBABLE CAUSE
01	Disk Drive Home Error. No track 0, and/or seek complete, and/or drive ready.	1. Head lock not removed during installation. 2. Faulty Winchester drive.
06	Timeout waiting for seek complete from disk during seek operation.	1. Head lock not removed during installation. 2. Faulty Winchester drive.
07	Desired disk header not found during read/write, or write check operation.	1. Winchester disk needs reformatting. See note 2. 2. Faulty 8240 controller. 3. Faulty Winchester disk drive.
10	Disk write protect violation.	1. Attempt to write while disk volume was write protected. Check the write protect switches.
14	Disk header CRC error detected during header search; rest of header appeared correct.	1. Winchester disk needs reformatting. See note 2. 2. Faulty 8240 controller. 3. Faulty Winchester disk drive.
15	Disk seek error. * Head selection error, or head on wrong cylinder.	1. Faulty Winchester disk drive. 2. Faulty 8240 controller.
17	Unable to find disk data field address mark during read or write check operation.	1. Corrupted data field, can usually be corrected by rewriting the data. See note 2. 2. Faulty 8240 controller. 3. Faulty Winchester disk drive.
20	Disk data field ECC error. Note: Error correction is not attempted during POC or HyperDiagnostics.	1. Corrupted data field, can usually be corrected by rewriting the data. See note 2. 2. Faulty 8240 controller 3. Faulty Winchester disk drive.

Table 7-2 HyperDiagnostics Error Codes (continued)

ERROR CODE	MEANING	PROBABLE CAUSE
21	Write fault error reported by disk drive during write operation.	1. Faulty 8240 controller. 2. Faulty Winchester disk drive.
24	Disk read/write controller failure.	1. Faulty 8240 controller.
30	Data compare error during disk write check operation.	1. Faulty 8240 controller. 2. Faulty Winchester disk drive.
31	Invalid disk bad-track map.	1. Rewrite bad-track map using GENEXR diagnostic program. 2. Faulty 8240 controller. 3. Faulty Winchester disk drive.
36	Disk drive not ready.	1. Head lock not removed during installation. 2. Faulty Winchester disk drive.
41	Disk timer failure.	1. Faulty 8240 controller.
45	Invalid data field ID byte found in disk data field during read or write check operation.	1. Corrupted or missing data field, can usually be corrected by rewriting the data. See note 2. 2. Faulty 8240 controller.
90	Tape data read did not match data written during HyperDiagnostics.	1. Faulty tape drive. 2. Faulty 8240 controller.
91	Tape timer failure.	1. Faulty 8240 controller.
92	Tape write file mark failure during HyperDiagnostics.	1. Faulty tape drive. 2. Faulty 8240 controller.
93	No tape cartridge or can't find BOT during rewind operation.	1. No tape installed. 2. Faulty tape drive.
94	Tape space record or file mark error (forward or backward) during HyperDiagnostics.	1. Faulty tape drive. 2. Faulty 8240 controller.

Table 7-2 HyperDiagnostics Error Code (continued)

ERROR CODE	MEANING	PROBABLE CAUSE
95	Unable to detect tape FIFO data overflow.	1. Faulty 8240 controller
96	Tape read/write error during HyperDiagnostics.	1. Tape cartridge write protected. 2. Worn-out tape cartridge. 3. Dirty tape head. 4. Faulty tape drive.
97	Tape interface test failure.	1. No power to tape drive. 2. Tape cable incorrectly installed. 3. Faulty tape drive. 4. Tape cartridge removed during initialization.

- Notes:
1. The probable cause portion of this table applies only to error codes reported during HyperDiagnostics. Probable causes are listed in decreasing order of probability.
  2. In case of recurring disk errors, use the GEMEXR diagnostic program to locate the flaw and add to the bad-track map.
  3. CAUTION: HyperDiagnostics may overwrite data stored on the disk and/or tape.

Table 7-3 Software Diagnostic Procedures

FAULT SYMPTOM	STEP	DIAGNOSTIC AND CORRECTIVE ACTION
Procedure A.	1.	Load RLEXR Diagnostic Program.
Any disk subsystem problem suspected. This procedure is also used for acceptance testing.	2.	Use the short acceptance test to verify all three emulated RL-02 volumes. Test should be allowed to run at least two hours, or until errors are reported.
CAUTION: this procedure will destroy data stored on the disk.	3.	Go to Procedure B. If read/write errors, header CRC errors, data compare errors, write check errors, or header not found errors are being reported. These errors indicate problems reading or writing disk data.
	4.	The 8240 controller is the most likely cause of failure if no bus response errors, no interrupt errors, time out errors or ac power low errors are being reported.

Table 7-3 Software Diagnostic Procedures (continued)

FAULT SYMPTOM	STEP	DIAGNOSTIC AND CORRECTIVE ACTION
Procedure B.	1.	Load GEMEXR Diagnostic Program.
HyperDiagnostics, operational software or RLEXR diagnostic report disk write or read errors.	2.	Use BADTRK command and PRINT subcommand to list contents of bad-track map. Compare to form inside DS-330 module.
CAUTION: this procedure will destroy data stored on the disk.		If there are differences, or if the message INVALID BAD TRACK MAP is reported, rewrite the bad-track map using CREATE subcommand under BADTRK. Note: It is important that the map on the disk match the form in the drive module.
	3.	Use VERIFY command and WRTREAD subcommand to test disk over all heads and cylinders 1 through 777 for at least ten passes.
	4.	Carefully examine any errors reported during the WRTREAD tests, noting especially whether errors seem to repeat for given cylinder and head numbers, or are randomly scattered over the disk surface.
		If header not found errors are being reported, cylinders 1 through 777 should be reformatted. Then rerun the WRTREAD test.

Table 7-3 Software Diagnostic Procedures (continued)

FAULT SYMPTOM	STEP	DIAGNOSTIC AND CORRECTIVE ACTION
		<p>IF data CRC errors, or header not found errors are being found on a few tracks and tend to repeat from pass to pass, assume that a flaw has developed on the disk surface. Use the INCLUDE subcommand under BADTRK to add the flaw to the Bad Track Map. VERY IMPORTANT-- also add the new bad tracks to the record inside the drive module.</p> <p>If many random errors are being reported which do not seem associated with particular tracks:</p> <ol style="list-style-type: none"> <li>1. Most likely cause is disk drive.</li> <li>2. Next most likely cause is 8240 controller.</li> </ol>
<p>Procedure C</p> <p>Any problem suspected with the Tape Subsystem.</p> <p>CAUTION: this procedure will destroy data recorded on the tape cartridge. Use a scratch tape.</p>	<ol style="list-style-type: none"> <li>1.</li> <li>2.</li> <li>3.</li> <li>4.</li> </ol>	<p>First run the tests in Procedure A.</p> <p>Note: The following steps will destroy any data recorded on the tape. If it is important to save data, first try to copy tape to an unused area of the disk, using the normal operating system.</p> <p>Load TSEX R Diagnostic Program.</p> <p>Install scratch tape in the tape drive.</p>

Table 7-3 Software and Diagnostic procedures (continued)

FAULT SYMPTOM	STEP	DIAGNOSTIC AND CORRECTIVE ACTION
	5.	<p>Use ACCEPT command to test basic tape read and write functions. This test does not check the entire tape (see Procedure D).</p> <p>A few recoverable errors (TCC4 or TCC5) will not usually cause problems in normal use. If many recoverable errors are reported, clean the tape head and repeat the test. If errors persist, the tape cartridge should be replaced. If errors still persist, the tape drive should be replaced.</p> <p>If function reject (TCC3) errors occur, check that tape cartridge is properly installed, is at the load point, and is not write protected.</p> <p>If repeated unrecoverable (TCC6) or fatal (TCC7) errors, most likely cause is tape drive. Next most likely cause is 8240 Controller.</p> <p>If tape bus parity errors are being reported, most likely cause is 40-pin tape cable. Next most likely cause is 8240 controller or tape drive.</p>

Table 7-3 Software Diagnostic Procedures (continued)

FAULT SYMPTOM	STEP	DIAGNOSTIC AND CORRECTIVE ACTION
<p>Procedure D.</p> <p>Problems suspected with a specific tape cartridge.</p> <p>CAUTION: this procedure will destroy data recorded on the tape cartridge.</p>	<ol style="list-style-type: none"> <li>1.</li> <li>2.</li> <li>3.</li> <li>4.</li> <li>5.</li> <li>6.</li> </ol>	<p>Note: The following steps will destroy any data recorded on the tape. If it is important to save data, first try to copy tape to an unused area of the disk, using the normal operating system.</p> <p>Load TSEXR Diagnostic Program.</p> <p>Install tape to be tested in the tape drive.</p> <p>Use ACCEPT command to test basic tape read and write functions. This test does not check the entire tape. Go to step 6 if any errors are reported.</p> <p>Use the MEDIA command to test the tape cartridge.</p> <p>Carefully examine any errors reported during steps 4 or 5.</p> <p>A few recoverable errors (TCC4 or TCC5) will not usually cause problems in normal use. If many recoverable errors are reported, clean the tape head and repeat the test. If errors persist, the tape cartridge should be replaced.</p> <p>If function reject (TCC3) errors occur, check that tape cartridge is properly installed, is at the lead point, and is not write protected.</p> <p>If unrecoverable errors (TCC6) occur, the tape cartridge should be replaced.</p>

Table 7-4 POC Error Codes

ERROR CODE	MEANING	PROBABLE CAUSE (POC TESTS)
01	Disk drive home error. No track 0, and/or seek complete, and/or drive ready.	<ol style="list-style-type: none"> <li>1. Head lock not removed during installation</li> <li>2. Faulty Winchester drive.</li> </ol>
06	Timeout waiting for seek complete from disk during seek operation.	<ol style="list-style-type: none"> <li>1. Head lock not removed during installation.</li> <li>2. Faulty Winchester drive.</li> </ol>
07	Desired disk header not found during read, write or write check operation.	<ol style="list-style-type: none"> <li>1. Winchester disk needs re-formatting. See note 2.</li> <li>2. Faulty Winchester disk drive.</li> <li>3. Faulty 8240 controller.</li> </ol>
14	Disk header CRC error detected during header search; rest of header appeared correct.	<ol style="list-style-type: none"> <li>1. Winchester disk needs re-formatting. See note 2.</li> <li>2. Faulty Winchester disk drive.</li> <li>3. Faulty 8240 controller.</li> </ol>
15	Disk seek error. Head Selection error or head on wrong cylinder.	<ol style="list-style-type: none"> <li>1. Faulty Winchester disk drive.</li> <li>2. Faulty 8240 controller.</li> </ol>
17	Unable to find disk data field address mark during read or write check operation.	<ol style="list-style-type: none"> <li>1. Cylinder 0 of Winchester disk needs re-formatting; bad-track map must be re-written. See note 2.</li> <li>2. Faulty Winchester disk drive.</li> <li>3. Faulty 8240 controller.</li> </ol>
20	Disk data field ECC error.	<ol style="list-style-type: none"> <li>1. Cylinder 0 of Winchester disk needs re-formatting; bad-track map must be re-written. See note 2.</li> <li>2. Faulty Winchester disk drive</li> <li>3. Faulty 8240 controller.</li> </ol>
21	Write fault error reported by disk drive during write operation.	<ol style="list-style-type: none"> <li>1. Faulty 8240 controller.</li> <li>2. Faulty Winchester disk drive.</li> </ol>
24	Disk read/write controller failure.	<ol style="list-style-type: none"> <li>1. Faulty 8240 controller.</li> </ol>

Table 7-4 POC Error Codes (continued)

ERROR CODES	MEANING	PROBABLE CAUSE (POC TESTS)
30	Data compare error during disk write check operation.	1. Faulty 8240 controller. 2. Faulty Winchester disk drive.
31	Invalid disk bad-track map.	1. Rewrite bad-track map using GEMEXR diagnostic program. 2. Faulty 8240 controller. 3. Faulty Winchester disk drive.
36	Disk drive not ready.	1. Head lock not removed during installation. 2. Faulty Winchester disk drive.
41	Disk timer failure.	1. Faulty 8240 controller.
45	Invalid data field ID byte found in disk data field during read or write check operation.	1. Cylinder 0 of Winchester disk needs re-formatting; bad-track map must be re-written. See note 2. 2. Faulty Winchester drive. 3. Faulty 8240 controller.
50	Scratch RAM failure during POC.	1. Faulty 8240 controller.
51	Buffer RAM failure during POC.	1. Faulty 8240 controller.
52	QBC gate array failure during POC.	1. Faulty 8240 controller.
53	Error reading drive data simulator during POC.	1. 20-pin Winchester data cable problem. 2. Faulty 8240 controller. 3. Faulty adapter board.
54	ECC circuitry failure during POC.	1. Faulty 8240 controller. 2. Faulty adapter board.
91	Tape timer failure.	1. Faulty 8240 controller.

Table 7-4 POC Error Codes (continued)

ERROR CODE	MEANING	PROBABLE CAUSE(POC TESTS ONLY)
95	Unable to detect tape FIFO data overflow.	1. Faulty 8240 controller.
97	Tape interface test failure.	1. No power to tape drive. 2. Tape cable incorrectly installed. 3. Faulty tape drive. 4. Tape cartridge removed during initialization.

- Notes:
1. The probable cause portion of this table applies only to error codes reported during the power-on confidence (POC) tests, which run when power is first applied to the 8240 controller. Probable causes are listed in decreasing order of probability.
  2. POC tests operate only on Cylinder 0 of the Winchester disk. Errors on this cylinder require reformatting Cylinder 0 and rewriting the bad-track map, using the GEMEXR program.

Table 7-5            Bootstrap Error Codes

BOOT ERROR CODE IN R0	MEANING	PROBABLE CAUSE
000001	Memory test error. Address is in register R3.	1. Faulty system memory.
000002	No response from designated disk I/O register. Address is in register R3.	1. 8240 incorrectly jumpered. 2. Faulty 8240 controller.
000003	No response from designated tape I/O register. Address is in register R3.	1. 8240 incorrectly jumpered. 2. Faulty 8240 controller.
000004	No response from designated floppy I/O register. Address is in register R3.	1. Floppy controller not present or incorrectly jumpered.
000005	Winchester disk read/write test error.	1. Faulty Winchester disk drive. 2. Faulty 8240 controller.
000006	Error reading boot block from designated boot device.	1. Boot device (Winchester, tape, or floppy) is faulty. 2. Faulty drive. 3. Faulty 8240 controller.
000007	Invalid boot block read from designated boot device.	1. No boot on volume.

- Notes:
1. Probable causes are listed in decreasing order of probability.
  2. These codes appear in CPU register R0 after a bootstrap error halt.

Table 7-6 Error Code Summary

ERROR CODE	MEANING
00	No error.
01	Disk drive home error. No track 0 and/or seek complete, and/or drive ready during home operation.
02	Non-existent logical drive (DL3) selected by software.
06	Timeout waiting for seek complete from disk during seek operation.
07	Desired disk header not found during read, write, or write check operation.
10	Disk write protect violation.
14	Disk header CRC error detected during header search; rest of header appeared correct.
15	Disk seek error. Head selection error or head on wrong cylinder.
17	Unable to find disk data field address mark during read or write check operation.
20	Disk data field ECC error.
21	Write fault error reported by disk drive during write operation.
23	Invalid disk word count specified by software.
24	Disk read/write controller failure.
25	Invalid format keyword issued by software during format operation.
26	Data late condition during disk format operation.
27	GAP 4 timeout failure during disk format operation.
30	Data compare error during disk write check operation.

Table 7-6 Error Code Summary (continued)

ERROR CODE	MEANING
31	Invalid bad-track map. Read check sum or keyword error.
35	Non-existent memory found during disk or tape DMA.
36	Disk drive not ready.
40	Bootstrap (drive data simulator) read error.
41	Disk timer failure.
43	Invalid disk RLDAR value loaded by software.
45	Invalid ID byte found in disk data field during read or write check operation.
50	Scratch RAM failure during POC.
51	Buffer RAM failure during POC.
52	QBC gate-array failure during POC.
53	Error reading drive data simulator during POC.
54	ECC circuitry failure during POC.
80	Tape termination code 0 (normal)
81	Tape termination code 1 (attention)
82	Tape termination code 2 (status alert)
83	Tape termination code 3 (function reject)
84	Tape termination code 4 (recoverable error)
85	Tape termination code 5 (recoverable error)
86	Tape termination code 6 (non-recoverable error)
87	Tape termination code 7 (fatal error)

Table 7-6 Error Code Summary (continued)

ERROR CODE	MEANING
90	Tape data read did not match data written during HyperDiagnostics.
91	Tape timer failure.
92	Tape write file mark failure during HyperDiagnostics.
93	No tape cartridge or can't find BOT during rewind operation.
94	Tape space record or file mark error (forward or backward) during HyperDiagnostics.
95	Unable to detect tape FIFO data overflow during HyperDiagnostics.
96	Tape read/write error during HyperDiagnostics.
97	Tape interface test failure.

**Note:** This table gives a summary of all error and status codes which may be displayed on the HyperDiagnostic panel status display.

## 7.8. Replacement Procedures

The following modules (or boards) can be replaced by the field technician after obtaining DSD Customer Service approval:

- Controller Interface (8240) Board
- Winchester Drive Module
- Magnetic Tape Drive Module
- Power Supply Module
- Fan Module
- Diagnostic Control Board
- Display Control Board

Before replacing a module follow the instructions provided in the next subsection, then go to the actual replacement procedures.

### 7.8.1. Preparation

Before replacing any of the modules previously listed, follow these instructions:


- (1) Remove power from system cabinet and controller interface board and disconnect system cables. If the 8240 board is at fault, return it to the factory as instructed by Customer Service. If the faulty module is inside the cabinet, proceed with the next step.
- (2) Snap off front bezel and remove rack retaining screws.
- (3) Gently, remove cabinet from rack. Abrupt movements may damage the Winchester drive assembly. Set cabinet on side.
- (4) Lock head mechanism by rotating actuator lock (clockwise) to LOCK.
- (5) Remove spindle lock access panel.
- (6) Loosen 11/32" hex nut on spindle locking clip and position clip over pulley. Ensure that pulley is locked and tighten nut.

- (7) Replace spindle lock access panel.
- (8) Set cabinet in a normal upright position and remove top cover.
- (9) Reapply power to the cabinet.
- (10) Refer to power distribution diagram shown in Figure 7-7 and use a digital multimeter to ensure suspected module is receiving proper DC voltage levels. If not, remove power and check internal cabling for electrical continuity.
- (11) If voltage levels are correct, remove power from cabinet and refer to next subsection.

#### 7.8.2. Replacing Modules


When replacing any module or internal board follow these steps:

- (1) Complete preparation instructions previously provided.
- (2) Inside cabinet, disconnect ac, dc, and other internal cables.
- (3) Refer to Figure 7-8 and identify screws holding faulty unit.
- (4) Remove retaining screws and faulty unit.
- (5) Remove replacement unit from box and re-install.
- (6) Carefully pack faulty unit using material shipped with replacement unit. INCLUDE RETURN AUTHORIZATION NUMBER ON BOX.
- (7) Refer to Chapter 4, Installation. Beginning with "Mechanical Preparations", follow installation procedures provided in that chapter until you have completed "Acceptance Tests".



TP 330/83

Figure 7-7. Power Distribution Diagram



TP 539/83

Figure 7-8. Cabinet Exploded View

## 7.9. Maintenance Assistance

Data Systems Design maintains a fully staffed Customer Service Department. If at any time during inspection, installation, or operation of the equipment you encounter a problem, contact your nearest DSD Customer Service office.

Our trained staff can help you diagnose the cause of failure, and if necessary, rush replacement parts to you. Any time you need to return a product to the factory, please contact Customer Service for a Material return Authorization Number.

Customer Service offices in the United States are listed below. For service outside the U.S.A., contact your local distributor.

---

Western Region Service  
2241 Lundy Avenue  
San Jose, CA 95131  
(408) 946-5800  
TWX: 910-338-0249

Central Region  
Sales and Service  
5050 Quorum Drive  
Suite 339  
Dallas, TX 75240  
(214) 980-4884

North Central Region  
Sales and Service  
2311 West 22nd St.  
Suite 110  
Oakbrook, Il 60521  
(312) 920-0444

Eastern Region  
Sales and Service  
51 Morgan Drive  
Norwood, MA 02062  
(617) 769-7620  
TWX: 710-336-0120

---

[^]



---

## APPENDIX A: GEMEXR UTILITY PROGRAM

---

### 1.1. INTRODUCTION

All DSD subsystems are shipped with a tape cartridge containing an interactive program called GEMEXR. This manual explains the operation of this comprehensive media management utility program, and assumes that the user is familiar with DSD subsystem operations and technology.

GEMEXR is a general media management utility program designed for the DSD Winchester disk drive. Routines are provided for format initialization, media flaw management, and for verification of media integrity. GEMEXR runs as a standalone program, with bootstrap.

### 1.2. PROGRAM LOADING

GEMEXR requires a standard console device, an LSI-11 computer, and at least 24K words of memory. Loading GEMEXR can be accomplished either from an RT-11 compatible operating system, or from the monitor provided on the DSD distribution media. To run GEMEXR from an RT-11 system, issue the command:

```
RU <DEV:>GEMEXR <CR>
```

On a system running other operating systems, the distribution media (tape cartridge) must be bootstrapped into memory. When the program is in memory, the following will appear on the screen:

```
DSD TAPE MONITOR V3A
```

```
TMON>
```

to run the GEMEXR program, type:

```
R GEMEXR <CR>
```

When GEMEXR is in memory, the program title and main command menu will be displayed on the console device. If more than one RL compatible device is in the system configuration, the user will be prompted to select one device for GEMEXR functions. GEMEXR uses direct access mode so only DSD devices can be selected.

### 1.3. PROGRAM EXIT

There is one command and two control keys that may be used to exit GEMEXR, and these are detailed in Tables 1 and 2. At the main command level, issuing a "QUIT" command will cause an exit from GEMEXR. During program execution; a "CTRL-C" will terminate the program and exit from GEMEXR, a "CTRL-R" will also stop the execution of a command, but will return to the command menu within GEMEXR.

### 1.4. PROGRAM COMMANDS

Table 1, GEMEXR Commands, lists all the main commands and sub-commands available with the program. GEMEXR also recognizes various control inputs, and these are listed in Table 2.

Table 1. GEMEXR Commands.

Commands	Description
QUIT	Exit from GEMEXR
FORMAT	Formats DSD Winchester disk
RLFMT	Formats individual RL volumes
BADTRK	Flaw management for Winchester disk. A DSD bad track file is required on Winchester for proper operation.
Sub-Commands:	
EXIT	Exit from badtrack routines
CREATE	Allows creation of bad track file on the Winchester. This command should be issued each time cylinder zero of the Winchester is formatted or otherwise written. If the Winchester has bad tracks, as indicated by the factory bad sector list, answer "Y" to the prompt "INSERT BAD TRACKS [Y/N]:", and enter the bad tracks. A carriage return <CR> alone on any input line, ends the input. If there is an error in the bad track input, answer "Y" to the prompt, "EDIT BAD TRACK FILE [Y/N]:". Every time a new DSD bad track file is written to the disk, The RL Bad Sectors file is automatically written.

**EDIT** Allows modification of the existing bad track file. Tracks may be added or deleted and the bad track list printed during the editing session. ANY CHANGES TO THE BAD TRACK FILE WILL CAUSE THE LOSS OF INFORMATION ON DISK SUBSEQUENT TO TRACK CHANGE.

**INCLUDE** Takes the list of tracks flagged as bad from verification tests performed in the current GEMEXR session, and permanently adds them to the DSD bad track file. To examine this list, issue the "STAT" sub-command in the "VERIFY" command menu.

**PRINT** Prints the DSD bad track file to the console device.

**XFORM** Transforms emulated RL disk addresses to an actual Winchester cylinder, head, and sector

**RLBAD** Writes DEC compatible RL bad sectors file to each RL volume. Since internal DSD bad track mapping presents an apparent flaw free drive to the operating system, this file will have no bad sector entries but it MUST be present.

**VERIFY** verifies integrity of the Winchester media.

**Sub-commands:** NOTE: All verify sub-commands allow the selection of a range of tracks and a number of passes, after the sub-command is issued.

**EXIT** Returns to main menu.

**WRITE** Writes a pattern to all tracks within the selected range.

**READ** Reads all tracks within the selected range and compares with the desired pattern. A "WRITE" command MUST have been previously issued.

**WRTREAD** Does a "WRITE" followed by a "READ" over the selected range.

**SCAN** Reads every track in the selected range to verify header information.

ACCEPT	Performs a "WRTREAD" followed by a "SCAN".
STAT	Reports the status of verification tests. Prints the number of reads, writes, and errors, followed by list of tracks (if any) flagged as bad by verification tests.
DUMP	Dumps contents of individual Winchester sectors to the console. User selects either word, or byte dump, and the absolute starting cylinder, head, and sector. The prompt, "EXIT DUMP? [Y/N]" appears after each sector is displayed. An affirmative answer will return to the VERIFY menu, otherwise the next sequential sector will be displayed.
CHAR	Sets certain program operation characteristics. An affirmative answer to the prompt "SKIP BAD TRACKS [Y/N]:", allows the following tests to ignore tracks already in the DSD bad track file.
CONFIG	Displays the status of the control panel switches and certain 8240 controller jumpers.
H	The H (help) command lists program version number, device addresses, interrupt vectors, and command menu. Also lists current value of parameters set up in the "CHAR" command.

---

Table 2. Control Key Functions.

---

Input	Description
CTRL-C	Stops execution and returns to monitor.
CTRL-R	Asks "ABORT OPERATION [Y/N]:". Answer "Y" to quit current operation and return to GEMEXR command

menu.

CTRL-B Puts program in debug mode. Additional device status is displayed and execution pauses are inserted to aid in debugging. Exit debug mode by re-entering "CTRL-B". Recommended for factory use only.

CTRL-D Lists Winchester device registers.

<LF> Displays current Winchester cylinder and head.

### 1.5. ERROR MESSAGES

Table 3 contains a list of the error messages reported by the GEMEXR program and a brief description of each. If an error is detected by the program, it will attempt to complete the current operation. If successful, the program will wait until the operation is complete to print the error information. If the error is considered fatal, the operation will terminate and the error information will be displayed immediately. The error information contains the error message (see Table 3) followed by the current cylinder, current head, and the starting (first) sector for the operation.

Table 3. GEMEXR Error Messages.

#### Error Messages:

##### Spin Error:

Indicates that drive was not up to speed during current operation.

##### Seek Time Out Error:

A seek time out did not occur in 200 milliseconds.

##### Write Data Error:

Data read from disk did not compare to that originally written.

##### Operation Incomplete:

Current command could not be completed by the controller.

**Data CRC Error:**

A CRC error was detected during a data transfer.

**Header CRC Error:**

CRC error detected in header that otherwise appeared correct.

**Header Not Found:**

Correct header could not be found after approximately 550 milliseconds.

**Non-Existant Memory:**

During a DMA transfer, the memory location addressed did not respond within 10 microseconds.

**Parity Error:**

Memory parity error detected during attempt to read a memory location. Current operation is aborted.

**Extended Mode Entry Error:**

Command issued with other than a DSD device specified.

**Status Error:**

Indicates an error was detected that did not fit into the parameters for other error messages. Drive is in an unknown state. This is a default error condition, and will not normally be seen.

---

---

## APPENDIX B: DSDBR UTILITY PROGRAM

---

### 1.1. INTRODUCTION

All DSD subsystems are shipped with a tape cartridge containing an interactive program called DSDBR. This manual explains the operation of this backup and restore utility program, and assumes that the user is familiar with subsystem operations and technology.

The DSD backup and restore utility program allows backup of a 10 Mbyte RL volume to TS cartridge, and restoration of an RL volume from TS cartridge.

Data transfers are image transfers and are written to tape in 5120 byte blocks. Automatic error correction is attempted when a correctable tape write or read error is detected, and the number of retries necessary to recover the record is reported to the display. A large number of correctable tape errors indicates a possible defective tape.

### 1.2. PROGRAM LOADING

DSDBR requires a standard console device, an LSI-11 computer, and at least 24K words of memory. Loading DSDBR can be accomplished either from an RT-11 compatible operating system, or from the monitor provided on the DSD distribution media. To run DSDBR from an RT-11 system, issue the command:

```
RU <DEV:>DSDBR <CR>
```

On a system running other operating systems, the distribution media (tape cartridge) must be bootstrapped into memory. When the program is in memory, the following will appear on the screen:

```
DSD TAPE MONITOR V3A
```

```
TMON>
```

to run the DSDBR program, type:

```
R DSDBR <CR>
```

After DSDBR is loaded into memory, the program title and main command menu will be displayed on the console device. If there is more than one RL or TS compatible device in the system configuration, the user will be prompted to select one device for DSDBR functions.

Remove the distribution tape cartridge, to prevent accidental loss of the monitor program. If a backup function is desired, load a blank, write enabled cartridge. If a restore function is desired, load a previously recorded Winchester disk image prior to issuing a restore command.

### 1.3. PROGRAM EXIT

There is one command and two control key inputs that may be used to exit from the DSDBR program. These are detailed in Tables 1 and 2. At the main command level, issuing a "QUIT" command will cause an exit from DSDBR. During execution of a command; a "CTRL-C" will terminate the function and exit from DSDBR, and a "CTRL-R" will also halt the execution of a command, but will return to command menu.

### 1.4. PROGRAM COMMANDS

Table 1 lists all the commands available in the DSDBR utility program, and Table 2 lists the control functions used with DSDBR.

Table 1. DSDBR Commands.

Command	Description
H	The H (help) command lists program version, current device configuration, and main command menu.
BACKUP	Rewinds tape, asks which unit is to be backed up, and begins backup.
VERIFY	After backup, checks and verifies the tape image with original disk data.
RESTORE	Rewinds tape, asks which unit is to be restored, and begins restoration.
BACKV	Performs "BACKUP" followed by "VERIFY".
RESTV	Performs "RESTORE" followed by "VERIFY".

TEST	Continuously runs "BACKUP" and "VERIFY".
QUIT	Exit backup/restore utility program.

---

Table 2. Control Key Functions.

---

Input	Function
CTRL-B	Puts program in debug mode. Additional device status is displayed, and execution pauses are inserted to aid in debugging. Exit debug mode by re-entering "CTRL-B". Recommended for factory use only.
CTRL-C	Abort program and return to monitor.
CTRL-D	Show current tape and disk control registers.
CTRL-R	Interrupts execution of a command and asks if the user wishes to abort operation. If answer is yes ("Y"), the current operation is aborted and program continues at command menu.
<LF>	Displays current operation name, and current disk position.

---

### 1.5. ERROR MESSAGES

During the execution of backup or restore functions errors may develop that will be reported by the system. The reported errors will be the same ones reported for the Winchester drive as listed in the GEMEXR program manual, or for the Tape drive as listed in the TSEXR program manual. These error listings are reproduced here in Table 3, Winchester Error Messages and Table 4, Tape Error Messages.

Table 3 contains a list of error messages related to the Winchester drive system, and a brief description of each. If an error is detected by the program, it will attempt to complete the current operation. If successful, the program will wait until the operation is completed before displaying the error information. If the error is considered fatal, the operation will terminate and the error information will be displayed immediately. The error information contains the error message, followed by the current cylinder, current head, and the first sector where the operation began.

Table 3. Winchester Drive Error Messages.

---

**Error Messages:****Spin Error:**

Indicates that drive was not up to speed during current operation.

**Seek Time Out Error:**

A seek time out did not occur in 200 milliseconds.

**Write Data Error:**

Data read from disk did not compare to that originally written.

**Operation Incomplete:**

Current command could not be completed by the controller.

**Data CRC Error:**

A CRC error was detected during a data transfer.

**Header CRC Error:**

CRC error detected in header that otherwise appeared normal.

**Header Not Found:**

Correct header could not be found after approximately 550 milliseconds.

**Non-Existant Memory:**

During a DMA transfer, the memory location addressed did not respond within 10 microseconds.

**Parity Error:**

Memory parity error detected during attempt to read a memory location. Current operation was aborted.

**Extended Mode Error:**

Command issued with other than a DSD device specified.

**Status Error:**

Indicates an error was detected that did not fit into the parameters for other error messages. Drive is in an unknown state. This a default error condition, and will not normally be seen.

---

The tape drive system error messages are divided into three general areas. First, are the termination class codes (TCC), second are the fatal class codes (FCC), and finally there are the error messages related to memory. Table 4 lists these error messages and gives a brief description of each.

Table 4. Tape System Error Messages.

---

**Termination Class Codes:**

- TCC0: Undefined special condition. The special condition bit was set in the tape system status register (TSSR), but no other error condition was detected.
- TCC1: Attention condition. Status change has occurred on the transport (off-line, on-line).
- TCC2: Tape status alert. Change in tape status has occurred [tape mark (TMK), end of tape (EOT), record length short (RLS), or record length long (RL)].
- TCC3: Function reject. Command was not executed due to a fault condition [off-line (OFL), volume check (VCK), beginning of tape (BOT), write lock error (WLE), illegal command (ILC), or illegal address (ILA)].
- TCC4: Recoverable error. A recoverable error has occurred, and retries are attempted unless inhibited.
- TCC5: Recoverable error. Same as TCC4.
- TCC6: Unrecoverable error. Tape position has been lost. Recovery is not possible.
- TCC7: Fatal subsystem error. Subsystem is incapable of reliably executing command. Refer to fatal class codes that follow.

**Fatal Class Codes:**

FCC0: Capstan runaway.  
FCC1: Main CROM parity error.  
FCC2: I/O silo parity error.  
FCC3: AC power fail detected.

**Other Error Messages:****Q-Bus Parity Error:**

Memory parity error detected during data transfer.

**Tape Bus Parity Error:**

Parity error detected on the bus between controller and tape drive.

**Register Modification Refused:**

TSDB has been loaded with a command pointer before subsystem ready (SSR).

**Non-Existant Memory:**

Host processor memory does not respond to a read or write operation.

**Need Buffer Address:**

A command was issued before a valid buffer address was sent to transport by a set characteristics command.

---

## APPENDIX C: TSEXR UTILITY PROGRAM

---

### 1.1. INTRODUCTION

All DSD subsystems are shipped with a tape cartridge containing an interactive diagnostic program called TSEXR. This manual explains the operation of this comprehensive tape exerciser program, and assumes that the user is familiar with DSD subsystem operation and technology.

The TSEXR program tests the basic functions and the data reliability of the DSD cartridge tape drive. In addition, the program will execute a sequence of user selected commands. TSEXR runs as a standalone program, with bootstrap.

### 1.2. PROGRAM LOADING

TSEXR requires a standard console device, an LSI-11 computer, and at least 24K words of memory. Loading TSEXR can be accomplished either from an RT-11 compatible operating system, or from the monitor provided on the DSD distribution media. To run TSEXR from an RT-11 system, issue the command:

```
RU <DEV:>TSEXR <CR>
```

On a system running other operating systems, the distribution media (tape cartridge) must be bootstrapped into memory. When the program is in memory, the following message will be displayed:

```
DSD TAPE MONITOR V3A
```

```
TMON>
```

to run the TSEXR program, type:

```
R TSEXR <CR>
```

After TSEXR is loaded into memory, the program title and main command menu will be displayed on the console device. At this time, remove the distribution cartridge tape, and replace it with a blank, write enabled tape cartridge.

If there is more than one TS compatible device in the system configuration, the user will be prompted to select one device for TSEXR functions.

### 1.3. PROGRAM EXIT

There is one command and two control key functions that may be used to exit TSEXR, and these are detailed in Tables 1 and 2. At the main command level, a "QUIT" command will cause an exit from the TSEXR program. During command execution; a "CTRL-C" will halt the program and exit to the monitor, and a "CTRL-R" also stops the program, but will return to the command menu within TSEXR.

### 1.4. PROGRAM COMMANDS

Table 1, TSEXR Command Structure, defines the commands and lists the sequence of tests performed by the commands. TSEXR also recognizes certain control inputs, and these are listed in Table 2.

Table 1. TSEXR Command Structure.

Command	Description
QUIT	Exit from TSEXR.
H	The "H" (help) command lists commands and configuration. Also lists current value of parameters set up in the CHAR command.
EXER	Performs a list of tape commands designed to exercise the transport section of the DSD tape drive. The list of commands may be discarded by the user, and a new sequence of commands entered by answering 'Y' to the prompt, "MODIFY DEFAULT SEQUENCE [Y/N]". If this is done, the first command in the new sequence should be an "SCH" (set characteristics) command. All valid command mnemonics are listed below, and the user input is terminated by an "END" command. When an opcode mnemonic is entered, the user is prompted for a "count". This is the BYTE/RECORD/FILE count in the command packet. The prompt "repetitions" refers to the number of times the command is to be executed. For example, to read four records of 2000 bytes each, respond to the prompts as follows: tape cmd: RDF

```
count (1): 2000
repetitions (1): 4
```

```
or to rewind the tape:
tape cmd: RWD
count (1): <CR>
repetitions (1): <CR>
```

Note that this routine is an exerciser designed to test the physical transport mechanism, and that no data checking is performed.

Valid Commands:

Mnemonic	Definition
DRI	Drive Initialization
RDF	Read Forward
RDR	Read Reverse
WRT	Write Data
SRF	Skip Records Forward
SRR	Skip Records Reverse
RNR	Read Next Reverse
RNF	Read Next Forward
RPF	Read Previous Forward
RWD	Rewind
MBR	Message Buffer Release
WTM	Write Tape Mark
SFF	Skip Files Forward
SFR	Skip Files Reverse
GES	Get Status
ERS	Erase
UNL	Unload
CLN	Clean
SCH	Set Characteristics
END	End Sequence

**FUNCT** Verifies all functions of the DSD tape drive by performing the following sequence:

1. Set characteristics
2. Get tape status
3. Rewind tape
4. Rewind tape at BOT
5. Write 4 records forward
6. Rewind
7. Read 4 records forward and verify
8. Write tape mark
9. Write 3 records forward
10. Skip 1 record reverse
11. Erase 10 times

12. Write record forward
13. Write tape mark
14. Write tape mark reverse
15. Skip 2 files reverse
16. Skip 2 files forward
17. Repeat steps 15 and 16
18. Rewind
19. Skip 1 file forward
20. Skip 1 record reverse
21. Skip 1 record forward
22. Read and verify record
23. Skip 2 records reverse
24. Read reverse and verify
25. Rewind
26. Skip record forward
27. Read reverse and verify
28. Read next reverse and verify
29. Read forward and verify
30. Skip record forward
31. Read previous forward and verify
32. Read previous reverse and verify
33. Rewind
34. Write 2 records forward
35. Write 1 record reverse
36. Read previous forward and verify
37. Issue clean command
38. Rewind
39. Skip 2 files forward
40. Write 3 even length records forward
41. Write 4 odd length records forward
42. Set swap bytes flag in command word
43. Write 3 even length records forward
44. Write 4 odd length records forward
45. Reset swap bytes flag in command word
46. Read 2 records reverse and verify
47. Set swap bytes flag in command word
48. Read 4 records reverse and verify
49. Reset swap bytes flag in command word
50. Read 4 records forward and verify
51. Rewind.

Note. A "Y" response to the prompt, "PAUSE BEFORE EACH COMMAND [Y/N]", will cause execution to be interrupted prior to each tape command. Enter <CR> when asked "CMD --- ABORT [Y/N]" to continue the command sequence.

ACCEPT            Performs 2 passes of EXER and 2 passes of FUNCT commands.

MEDIA            Tape cartridge media tests.

## Subcommands:

SEQWRT	Writes sequential pattern to entire tape.
SEQRD	Reads tape pattern from tape and compares each record to the pattern expected from "SEQWRT".
SEQWRD	Does a "SEQWRT" followed by a "SEQRD".
RANWRT	Writes records of varying length to entire tape.
RANRD	Reads tape pattern from tape and compares each record to the pattern expected from "RANWRT".
RANWRD	Does a "RANWRT" followed by a "RANRD".
COR	Tests the tape performance at the track switch areas.
CHAR	Allows selection of the following program execution parameters:
Prompt	Meaning
Reset tape stats	Sets number of reads, writes, and errors to zero.
Enable interrupts	Enables interrupts on all tape operations.
Ignore RFC errors?	If set, the program does not issue an error message when BYTE/RECORD/FILE count is other than what was expected.
Disable error recovery?	If error recovery is disabled, no retries are attempted.
Enable extended error reporting?	Enables additional error reporting.
Number base?	Allows specification of number base for all input/output.
The default number base is octal. All the other prompts are worded so that the default value is NO.	
STAT	Shows the state of the status register, command packet, and message packet. Also shows number of reads, writes, retries, and errors.

Table 2. Control Input Functions.

Input	Function
CTRL-B	Puts program in debug mode. Additional device status is displayed and execution pauses are inserted to aid in debugging. Exit debug mode by re-entering "CTRL-B". Recommended for factory use only.
CTRL-C	Stops execution and returns to monitor.
CTRL-D	Lists TS command packet values.
CTRL-R	Asks, "ABORT OPERATION [Y/N]". Type "Y" to quit current operation and return to the command menu within TSEX. R.
<LF>	Lists number of reads, writes, errors and retries.

### 1.5. ERROR MESSAGES

The TSEX. R error messages are divided into three general areas. First, are the termination class codes (TCC), second are the fatal class codes (FCC) associated with TCC7, y there are the error messages related to memory. Table 3, TSEX. R Error Messages, lists these error messages and a short description of each.

Table 3. TSEX. R Error Messages.

#### Termination Class Codes (TCC):

- TCC0: Undefined special condition. The special condition bit was set in the tape system status register (TSSR) but no other error condition was detected.
- TCC1: Attention condition. Status change has occurred on the transport (off-line, on-line).
- TCC2: Tape status alert. Change in tape status has occurred [tape mark (TMK), end of tape (EOT), record length short (RLS), or record length long (RL)].
- TCC3: Function reject. Command was not executed due to a fault condition [off-line (OFL), volume check (VCK),

beginning of tape (BOT), write lock error (WLE), illegal command (ILC), or illegal address (ILA)].

- TCC4: Recoverable error. A recoverable error has occurred, and retries are attempted unless inhibited.
- TCC5: Recoverable error. Same as TCC4.
- TCC6: Unrecoverable error. Tape position has been lost. Recovery is not possible.
- TCC7: Fatal subsystem error. Subsystem is incapable of reliably executing commands. Refer to Fatal Class Codes below.

#### Fatal Class Codes (FCC):

- FCC0: Capstan runaway.
- FCC1: Main CROM parity error.
- FCC2: I/O Silo parity error.
- FCC3: AC power fail detected.

#### Other Error Messages:

##### Q-Bus Parity Error:

Memory parity error detected during data transfer

##### Tape Bus Parity Error:

Parity error detected on the bus between the controller and the tape drive.

##### Register Modification Refused:

TSDB has been loaded with a command pointer before subsystem ready (SSR).

**Nonexistent Memory:**

Host processor memory does not respond to a read or write operation.

**Need Buffer Address:**

A command was issued before a valid buffer address was sent to transport by a set characteristics command.

---

## APPENDIX D: RLEXR USER GUIDE

---

### 1.1. INTRODUCTION

All DSD systems having an LSI-11 or PDP-11 interface board are shipped with a diskette or tape cartridge containing an interactive diagnostic program called RLEXR. This manual explains the operation of this comprehensive set of tests and utility programs. The manual assumes the user is familiar with DSD 880 and/or DSD 890 (StacPac) operations and technology.

The information contained in this manual is generally the same for both the DSD 880, a Winchester/Floppy system, and the DSD 890, a Winchester/Tape drive system. Where procedures or instructions differ, separate information will be provided for both systems. The user of this manual may then ignore those small portions not applicable to his system.

RLEXR is designed to test and verify all functions of the DSD 880 and DSD 890 Winchester drive subsystems in normal and extended modes (if applicable). It runs as a standalone program (with bootstrap) and is capable of handling multiple drives and systems. Both display console and hard copy terminals with full X-On, X-Off output control are supported. To facilitate unattended operation, all terminal output is retained in a circular text buffer that is configured to use all available memory. This buffer may be displayed or reset at any time by use of a single command. Test commands fully exercise system functions while detecting and reporting any faults or bad disk areas. The acceptance tests provide total reliability testing and are suitable for both system burn-in/exercise and quality control checks.

### 1.2. PROGRAM LOADING

RLEXR requires a standard console device, an LSI-11 or PDP-11 computer, and at least 16K words of memory. Loading RLEXR can be accomplished by two methods. One method is to bootstrap the diagnostic diskette or tape cartridge. This loads RLEXR into memory automatically. The other method requires an RT-11 compatible directory and file structure. The files on the diagnostic diskette or tape cartridge can be accessed using standard RT-11 procedures. RLEXR can be run from an RT-11 system by typing:

```
RU <DEV:> RLEXR <CR>
```

On a system running other operating systems (e.g., RSX-11M, IAS, RSTS, etc.), the distribution diskette or tape cartridge must be bootstrapped into memory. Once the program has been bootstrapped into memory, the following appears on the screen:

For DSD 880:

DSD DIAGNOSTIC MONITOR V3A

DSDMON>

to run RLEXR program, type:

R RLEXR <CR>

For DSD 890:

DSD TAPE MONITOR V2A

TMON>

to run RLEXR program, type:

R RLEXR <CR>

When the RLEXR diagnostic program has been loaded into memory, the diagnostic diskette or tape cartridge should be removed to prevent inadvertent damage to the files. After RLEXR is loaded into memory, a brief description is displayed on the terminal that includes a memory map and preliminary usage instructions. The memory map indicates the ranges of address space which responds with SSYNC or BRPLY when accessed by the host computer. The following example shows the text initially output.

After you have run RLEXR by typing:

R RLEXR <CR>

Text similar to the following example will be displayed:

```
(000000 - 157776)
(171000 - 171776)
(172300 - 172316)
(172340 - 172356)
(172516 - 172516)
(173000 - 173776)
(174400 - 174406)
(177150 - 177152)
(177170 - 177172)
```

(177560 - 177566)  
 (177572 - 177616)  
 (177640 - 177656)  
 (177776)

Remove the distribution diskette or tape cartridge.

Type: A to do an acceptance test. This will do a short acceptance test followed by a full acceptance test.

Type: H for a list of valid commands.

CTRL-C Returns to command prompt.

CTRL-R Aborts function and returns to command prompt.

All numeric inputs/outputs are in octal.

Enter device type (0 - 3) or 'CR' for list.

Type: 'CR'

TYPE	DEVICE
0	880X/8
1	880X/20
2	880X/30
3	890

Enter device type (0 - 3) or 'CR' for list.

Make choice and enter.

Another memory map similar to the following example is printed:

DSD RLEXR V7A

(000000 - 157776)  
 (171000 - 171776)  
 (172300 - 172316)  
 (172340 - 172356)  
 (172516 - 172516)  
 (173000 - 173776)  
 (174400 - 174406)  
 (177150 - 177152)  
 (177170 - 177172)  
 (177560 - 177566)  
 (177572 - 177616)  
 (177640 - 177656)  
 (177776)

Full or partial testing (F,P)?

This option is asking whether to run the diagnostic over the entire disk, or only part of the disk. Partial testing preserves tracks 00 through 10 so that testing can be performed without wiping out the diagnostic programs.

Make choice and enter.

Set class switch to 0 (DSD 880 systems only)  
Push button and enter a character.

This means set the switch marked CLASS on the HyperDiagnostic panel to 0 and depress the EXECUTE pushbutton. Type any character on the keyboard to signal the program to proceed. This step does not appear on 890 systems.

Enable halt on error (Y/N) ?

A yes answer means that the program will halt on the first error encountered. A no answer means the program will store all error messages in a circular buffer. These messages can be recovered using the DUMP C command.

Make choice and enter.

# COMMAND:

### 1.3. PROGRAM EXIT

If RLEXR was loaded via the RT-11 operating system, DSDMON, or TMON, direct return to the monitor may be possible. A CTRL-C input will cause RLEXR to output, EXIT TO RT-11?. A yes response will cause the return to RT-11 monitor. Exit to the monitor may not function if:

1. There is insufficient memory available.
2. The system device is not located at 177170.
3. The system device is not available.

If direct monitor exit is not possible, the operating system must be rebooted.

#### 1.4. PROGRAM COMMANDS

The valid responses to the command prompt are listed in Table 1 and are grouped by class of command. Only the characters enclosed in parenthesis need to be typed. The parenthesis should NOT be typed. When the typed string is recognized, the terminal bell will sound, at which time the <CR> should be entered. The program will fill in the remaining characters and then proceed to execute the function.

RLEXR also recognizes various control character inputs. Table 2 lists the control inputs and the associated action taken. This input can be performed at any time, even while a test is in progress.

Table 1. RLEXR Commands.

<u>Command</u>	<u>Description</u>
<b>Comprehensive Tests:</b>	
● (A)cceptance	General Exerciser
● (SH)ort acceptance	Short Exerciser
<b>Individual Tests:</b>	
● (INTE)rface test	Interface test
● (INTR) test	Interrupt test
● (SC)an	Scan
● (SEE)k range	Seek
● (E)xtended mode test	Extended mode test
● (SEQ W)/r test	Sequential write/read test
NOTE	
The following three tests require a sequential write pass.	
● (SEQ R)ead	Sequential read test
● (RANDOM R/)w	Random read/write test
● (RANDOM RE)ad	Random read test
<b>Program Control Utilities:</b>	
● (SET D)evice	Set device
● (SET U)nit	Display selected units
● (SET T)rack	Set track
● (SET I)nterrupt status	Set interrupt status
● (SET M)ode	Set mode
<b>Program Status:</b>	
● (H)elp	Provides list of commands

- (M)ap address                   Memory and device map
- (ST)atus                        Display status information
- (SA)ve status                   Save status
- (RES)et status                  Clear status
- (DUMP C)ir buffer               Display content of circular  
buffer
- (REC)over status                Retrieve status

## Data Utilities:

- (RD) without header            Read without header
- (DUMP S)ector                   Display disk sectors

Table 2. Control Inputs.

<u>Input</u>	<u>Meaning</u>	<u>Notes</u>
CTRL-R	Aborts current test, restarts at command	
CTRL-S	Freeze terminal output until another character is typed	
CTRL-O	Throws away all output until another character is typed	
CTRL-P	Throws away all output, except errors, until another character is typed	
CTRL-Q	Causes output to resume	1
<LF>	Types current track and sector status	2
CTRL-C	Asks, EXIT TO RT-11?. If RT-11 monitor is available, type Y to exit. If RT-11 monitor not available, action is similar to CTRL-R. If in ODT, may return control to program	3
CTRL-D	Causes control transfer to ODT	3,4
CTRL-T	Causes control transfer to ODT with stack trace	3,4
RUB or DEL	Deletes previous character in input string	

## NOTES

1. Actually, any character input will perform this function.

2. This command always functions; however, for some tests, the track and sector information should be disregarded (such as, fill/empty test).
3. Exit to monitor and control transfer to debug may not function if there is not enough memory or if booted from a device other than a 177170.
4. Control transfer from ODT back to RLEXR is accomplished by CTRL-C. If this does not work, the program may be restarted by XXXX;G, where XXXX is the appropriate restart address.

Full testing will set the lower track limit to 0. Partial testing will set it to 10 (octal). Partial testing is recommended if diagnostics or other files are already on the RL. If system file RT-11 is on the RL, the lower track limit should be set much higher. The default upper track limits are:

<u>Type</u>	<u>Device</u>	<u>Limit</u>
0	880X/8-normal mode	376
0	880X/8-extended mode	576
1	880X/20	776
2	880X/30	776
3	890	776

Selection of the next higher tracks (377, 577, 777) may result in the bad block map being destroyed. The bad block map may be rewritten by using the WINEXR (880) or GEMEXR (890) utility programs. The set mode command may only be executed by the 880X/8 (type 0) device to change modes from normal to extended mode, or from extended mode to normal mode.

RLEXR then prints the name and version number of the program, DSD RLEXR V7A. RLEXR then prints <CRLF># when starting, and then attempts an initialize sequence. When the initialize instruction is successfully completed, the program prints the prompt word, # COMMAND:. This prompt allows the operator to input a command. A list of all the available commands may be obtained by typing H<CR> (Help command).

RLEXR has several restart addresses that can be used to restart the program if necessary. They are:

1104 - Normal start/restart address

1110 - Start address for monitor call

1114 - Start at command prompt without performing an initialize sequence on the device

1100 - Return address from ODT after CTRL-D dispatch

### 1.5. PROGRAM INPUT/OUTPUT

All data input and output (except status counters) are in octal format, unless otherwise specified.

The DEL or RUB key may be used during input to remove the previously input character. On some output devices, the cursor will be backspaced one position for each deletion. On others, a / will be output, followed by the characters being deleted. Normal input may be resumed at any time.

The program fully supports X-On, X-Off protocol, (CTRL-S, CTRL-O, and CTRL-Q) to enable output to be suspended and restarted.

Disk data is accessed via a combined address of unit, side, track, and sector values. Various commands are provided to specify the limits of the address components to be used by the tests. Default values are preset following the initial program load.

Input is typically terminated by a <CR> or <SP>. Validation input (Y/N)?, typically does not require termination.

### 1.6. STATUS AND ERROR DISPLAYS

RLEXR types out error and status information under a wide variety of circumstances. All printouts to the console terminal are sent to a circular buffer in memory as well. The buffer size is determined by available memory. The circular buffer is useful if a hard copy console terminal is not being used, and the error printouts are longer than can be displayed on the CRT screen. The display output buffer function (DUMP C) is used to examine messages in the circular buffer.

#### Status Variables Displayed:

The status variables that might appear on the console terminal are explained below:

DEV XXX        Is printed only when running multiple controllers. XXX are the six octal digits of the CS address for the system whose error/status data is being displayed.

UN U            U represents the logical drive unit number for which the error/status data is being displayed.

TRACK=TK        Track address at time of error/status printout.

SECTOR=SC      Sector address at time of error/status printout.

SIDE 1          Indicates the status or error relates to side one (first or second side of disk).

RLCS=XY        Shows content of the command and status register.

#BAD=XX        Indicates number of status errors detected.

#RD/WRT=XX     Indicates number of read/write operations performed error free.

B-TRACK=XX     Indicates number of bad tracks detected.

B-DATA=XX      Number of data errors where a byte or word of data did not compare with the value the program was expecting. This is different from the CRC error, which would be counted as bad status. There can be up to 128 data errors in one sector.

#### Error Messages and Meanings:

##### 1 \*No Bus Response\*

ADDRESS

17XXXX

This indicates no SSYN acknowledge to memory access within 200 milliseconds (interface test only).

##### 2 \*Status Error\*

RLCS    RLBA    RLDA    RLMP    STAT

XXXX    XXXX    XXXX    XXXX    XXXX

This indicates fault or error during operation indicated in RLCS. Parameters in address registers and status should give exact nature of error (all tests).

## 3 \*No Interrupt\*

RLCS	RLBA	RLDA	RLMP	STAT
XXXX	XXXX	XXXX	XXXX	XXXX

An expected interrupt did not occur after completion of the function in RLCS (interrupt test).

## 4 \*Read/Write Error\*

ADDR	READ	EXPECTED
17XXXX	XXXX	XXXX

## 5 \*Bus Reset Error\*

ADDR	READ	EXPECTED
17XXXX	XXXX	XXXX

A bus reset instruction did not clear all expected bits in a specific register at address indicated (interface test).

## 6 \*Time Out Error\*

RLCS  
XXXX

Indicates that a function was not completed within the required time.

## 7 \*Header CRC Error\*

DEVICE	UNIT	SECTOR	SIDE	TRACK	EXPECT	CALC
17XXXX	XXXX	XXXX	XXXX	XXXX	XXXX	XXXX

The CRC calculated by software did not compare to that written by hardware during a format operation (scan test).

## 8 \*Non Consecutive Header Error\*

DEVICE	UNIT	PREV	PRES	SIDE	TRACK
17XXXX	XXXX	XXXX	XXXX	XXXX	XXXX

Sector header information for two adjacent sectors was incorrect (scan test).

## 9 \*Data Compare Error\*

DEVICE	UNIT	SIDE	TRACK	SECTOR	EXPECT	READ	WD #
17XXXX	XXXX	XXXX	XXXX	XXXX	XXXX	XXXX	XXXX

During a sequential or random read, data read did not match that expected (written). Multiple errors may indicate a bad sector or track. Refer to WINEXR (880) or GEMEXR (890) utility programs for rewriting the bad track map.

## 10 \*Bad Track Detected\*

DEVICE	UNIT	SIDE	TRACK
17XXXX	XXXX	XXXX	XXXX

Results from multiple data compare errors on the same track.

## 11 \*Write Protect Error\*

DEVICE	UNIT
17XXXX	XXXX

Drive was write protected during a write operation (sequential or random write tests).

## 12 \*Drive Select Error\*

RLCS	RLBA	RLDA	RLMP	STATUS
XXXX	XXXX	XXXX	XXXX	XXXX

A nonexistent drive unit was selected (all tests).

## 13 \*Spin Error\*

DEV	UNIT	RLCS
17XXXX	XXXX	XXXX

Indicates drive not up to speed during operation in RLCS (all tests).

## 14 \*Nonexistant Memory\*

DEV	UNIT	RLCS	RLBA
17XXXX	XXXX	XXXX	XXXX

## 15 \*Seek Time Out\*

DEV	UNIT	RLCS
17XXXX	XXXX	XXXX

A seek operation did not complete in 200 milliseconds (all tests).

## 16 \*Write Check Error\*

RLCS	RLBA	RLDA	RLMP	STATUS
XXXX	XXXX	XXXX	XXXX	XXXX

Data read from disk did not compare to that originally written. Usually indicates a bad block or track (sequential read/write test).

## 17 \*Header Not Found\*

DEV	UNIT	HEAD	TRACK	SECTOR
17XXXX	XXXX	XXXX	XXXX	XXXX

Seek to sector and track in RLDA could not be completed in 200 milliseconds due to invalid or nonexistant disk address (all tests).

## 18 \*Header CRC Error\*

```
DEV      UNIT  RLCS  RLDA
17XXXX  XXXX  XXXX  XXXX
```

A CRC error was detected on the header field (scan test).

## 19 \*Data CRC Error\*

```
DEV      UNIT  RLCS  RLBA  RLDA
17XXXX  XXXX  XXXX  XXXX  XXXX
```

A CRC error was detected during a data transfer (scan, sequential write/read, and random write/read tests).

## 20 \*AC Power Low\*

```
RLCS
```

```
XXXX
```

AC voltage is below normal, or interface cable is not connected (all tests).

## Examples of Error Output:

The following are examples of the RLEXR diagnostic program outputs to the console under varying circumstances:

Example 1: Operator requests status of currently selected drive during a test by typing, <LF>.

```
DRIVE #0  SIDE 0  AT TRACK 155  SECTOR 0  # BAD=0
# RD/WRT=0  B-TRACK=0  B-DATA=0
```

Example 2: Operator requests status of both drives using the status command.

```
UNIT#0  #BAD=0  #RD/WRT=0  B-TRACK=0  B-DATA=0
UNIT#1  #BAD=0  #RD/WRT=0  B-TRACK=0  B-DATA=0
```

Example 3: Disk was write protected.

\*Write Protect Error\*

DEVICE UNIT

174400 1

Example 4: Bad block found during read/write test.

\*Data Compare Error\*

DEVICE	UNIT	SIDE	TRACK	SECTOR	EXPECT	READ
174400	1	1	207	31	14761	14561

WD #

2

## 1.7. DETAILED DESCRIPTION OF COMMANDS

### Comprehensive Tests:

- (A)CCEPTANCE

This test does one pass of a short acceptance test on the first seven tracks and then resets the limit variables back to the default values. It then induces an automatic CTRL-P to inhibit all but error printout, and initiates the longer test. This test will run until terminated by a CTRL-R.

Example:           # COMMAND: A<CR>  
                   SCRATCH DISKS INSTALLED? (Y/N)? Y  
                   TEST NOW STARTING  
                   SCAN CRC CHECKED WRITING READING  
                   INTERRUPTS ENABLED  
                   WRITING READING

- (SH)ORT ACCEPTANCE

This interactive program changes the track range used by the acceptance so that only the first seven tracks of each selected drive are tested. This test will run until halted by a CTRL-R.

## Individual Tests:

- (INTE)RFACE TEST

Checks for response of all interface registers and issues a response error if a bus time out occurs. All read/write bits in each register are verified to be individually set and cleared without affecting other bits. A no-op or a maintenance-op code is checked along with bus reset.

- (INTR) INTERRUPT TEST

All RL op codes (except write) are executed with interrupts enabled. If an interrupt does not occur, and interrupt error message will appear. This test runs until terminated by a CTRL-R.

- (SCAN)

The scan test reads all sectors on all selected drives sequentially, and checks for CRC errors. No direct data checking takes place in this test. only status is checked. After all units are scanned once, the command prompt is displayed on the console.

- (SEEK) RANGE

The seek test function is a versatile drive test that performs all possible seeks within the operator specified track and seek length boundaries. Thus, it is a worst case test of the drive stepper motor and head setting. Status information will be continuously displayed during execution of the test indicating the seek length currently being used (x) and direction of seek (^ = outward). A ! will be printed at the conclusion of each pass. This test will run until terminated by a CTRL-R.

```
Example:      # COMMAND:  SEE<CR>
              SEEK LENGTH (1):  3  THROUGH (40):  7
              COVERING TRACKS -(0):  10  THROUGH (776):  40
```

- (SEQ W)/R TEST

The sequential write/read test writes pseudo-random data sequentially on all selected tracks. The test then reads and checks all the data. The message "WRITING" is displayed on the console terminal when the test starts writing the data. The message "READING" is displayed when the test starts reading the data. This test continues until the operator enters a CTRL-R.

- (E)XTENDED MODE TEST

checks implied seek capability of controller during large inter-track data transfers. This test will not execute if the 880X/8 device (type 0) has been selected, and if the extended mode was selected.

NOTE

The following three tests require a sequential write pass be done first in order to initialize the pseudo-random data. If this is not done, data compare errors are reported.

- (SEQ R)EAD

This test reads all the data on all selected drives sequentially and compares the data pattern against what was written. The program types, "READING" at the beginning of each pass. Test is halted by entering a CTRL-R.

- (RANDOM R)/W

This test selects a random sector of a selected drive, then reads or writes it. It checks data when appropriate. The test will continue until terminated by a CTRL-R.

- (RANDOM RE)AD

This test reads randomly selected sectors. Data is checked after each read. Test continues until halted by a CTRL-R.

Program Control Utilities:

- (SET M)ODE

This test may be executed only on an 880X/8 device. The test allows selection of normal or extended mode of opera-

tion. Extended mode will allow access of tracks 0 through 576 (octal) and is selected in normal mode, class 1. Normal mode (normal switch, class 0) allows access to tracks 0 through 376 (octal). After setting class select switch to 0 or 1, depress EXECUTE pushbutton before typing a character. After typing a character, it prompts, "ENABLE HALT ON ERROR? If an error occurs, the error message will be printed and followed by \*HR\*. This allows the LED to continue flashing the current error.

● (SET U)NIT

This command will cause the console terminal to display the currently selected drives that are to be accessed by test functions. Refer to the set device command for procedure to change the selected drive units.

● (SET T)RACK

This command allows the operator to specify the lower and upper track limits for all other tests. The default lower track limit is 0. The default upper track limits are as follows:

Type	Device	Limit
0	880X/8 - normal mode	376
0	880X/8 - extended mode	576
1	880X/20	776
2	880X/30	776
3	890	776

If the last physical track is selected (377, 577, or 777), the bad block map might be destroyed and would have to be rewritten (Refer to WINEXR (880) or GEMEXR (890) User Guides for procedures). A warning message will be output if this happens. Nothing will be destroyed until testing begins. The command prompt is issued after the entry of valid new limits. The lower limit must not exceed the upper limit.

● (SET I)NTERRUPT STATUS

This command enables the operator to test the disk system with interrupts enabled or disabled. If interrupts are enabled, the program ensures that an interrupt occurs when appropriate. This test is also used in the acceptance tests to set interrupts enabled or disabled. A <CR> response is no answer.

```
Example:      # COMMAND:  SET 1<CR>
              CURRENTLY INTERRUPTS ARE DISABLED (D)
              ENABLE INTERRUPTS (Y/N)?
```

- (SET D)EVICE

This function facilitates testing controllers that are not configured at the standard device input/output address and interrupt vector. It also enables the test program to simultaneously exercise multiple controllers. The function protocol asks you for device address, interrupt vector, and flag word. If a space is typed, the program steps past that field, leaving it intact. Return to the command prompt is by input of a <CR> in response to RLCS@0:. The flag word is organized as follows:

```
15-14-13-12-11-10-09-08  07  06  05  04  03  02-01-00
                        US3 US2 US1 US0
```

When set to a 1, the bit labelled

```
US3 indicates this device contains a drive unit 3
US2 indicates this device contains a drive unit 2
US1 indicates this device contains a drive unit 1
US0 indicates this device contains a drive unit 0
```

US0, US1, US2, and US3 do an implicit set unit function when set.

```
Example:      # COMMAND:  SET D<CR>
              SET THE DEVICE FLAGS FOR EACH SYSTEM AS FOLLOWS
              10: ENABLE UNIT 0 ON CURRENT DEVICE
              20: ENABLE UNIT 1 ON CURRENT DEVICE
              40: ENABLE UNIT 2 ON CURRENT DEVICE
              RLCS @ 174400:  INT @ 160 INTVEC=160  FLAGS: 70
              RLCS @ 0:
```

#### Program Status Commands:

- (H)ELP

This command causes all valid command responses to be displayed on the console terminal. The command prompt is typed when this function is complete.

- (M)AP ADDRESS

The map address command causes a memory and device address map of the system to be displayed on the console terminal. This is the same map displayed when the RLEXR program is first loaded. In addition, the interrupt vector address associated with each disk interface is displayed. The command prompt is printed when this function is complete.

- (ST)ATUS

The status command causes all the current status information including hardware errors, data errors, and pass counts to be displayed on the console terminal. Displaying status information does not reset the status counts. The command prompt is printed when this function is complete.

Example:           # COMMAND: ST<CR>  
                  UNIT #0 #BAD=3 #RD/WRT=2049 B-DATA=0  
                  B-TRACK=0  
                  # COMMAND:

- (RES)ET STATUS

This command first displays all the available status counts. Next, the display will ask whether all status counts need resetting. A yes answer will cause all of the error, pass, etc., counts to be reset to zero. The command prompt is output when this function is complete.

- (SA)VE STATUS

This command causes all the status counts associated with a particular drive to be written on track 0, sector 1 of the respective Winchester RL unit. This function is used by the acceptance test so that it can survive a loss of main memory without a loss of cumulative error data. The command prompt is displayed when this function is complete.

- (REC)OVER STATUS

This command performs the opposite function performed by the save status command. The stored data is recovered from the Winchester and transferred back to the status/counter variables in memory. The command prompt is displayed when the function is completed.

- (DUMP C)IR BUFFER

This command is used to display the output buffer associated with all console terminal outputs. This function is useful on systems where the console terminal is a CRT. Messages previously output can be re-examined on the display. The buffer can be cleared after it is displayed by this command.

#### Data Utilities Commands:

- (DUMP S)ECTOR

This command enables the operator to cause an octal, or ASCII dump, at a specified sector, to the console terminal. The function prompts for unit, cylinder, sector, side, ASCII or octal format, and exit from this function.

```
Example:      # COMMAND:  DUMP S<CR>
              ALL PARAMETERS ARE IN OCTAL
              UNIT (0,2)?  2<CR>
              CYLINDER (0, 776)?  23<CR>
              SECTOR (0, 47)?  5<CR>
              SIDE (0,1)?  1<CR>
              DUMP IN ASCII OR OCTAL FORMAT (A, 0)?  0<CR>
              .....
              EXIT (Y/N)?  Y
```

- (RD)WITHOUT HEADER

This command performs the same function as the dump sector command.

APPENDIX E  
BOOTSTRAP PROGRAM LISTING



DSD 890 BOOTSTRAP PROGRAM      MACRO M1113 25-MAR-83 14:34  
TABLE OF CONTENTS

2-	50	BOOTSTRAP DEFINITIONS
3-	112	22 BIT MEMORY TEST
4-	227	WINCHESTER READ WRITE TEST
5-	327	WINCHESTER BOOT SECTION
6-	371	TAPE BOOT SECTION
7-	419	FLOPPY BOOT SECTION
8-	485	I/O SUPPORT SECTION

DSD 890 BOOTSTRAP PROGRAM      MACRO M1113 25-MAR-83 14:34 PAGE 1

```

1          .TITLE DSD 890 BOOTSTRAP PROGRAM
2
3          , BOOTSTRAP FOR DSD 890 WINCHESTER / TAPE CONTROLLER.
4          , BOOTS FROM RL VOLUMES, SINGLE OR DOUBLE DENSITY FLOPPY OR TAPE.
5
6          , BOOT PROCEDURE:
7
8          , 1. SIZES, TESTS AND INITIALIZES MEMORY OVER THE FULL 22-BIT RANGE,
9          ,   AVOIDING THE BOOT AREA AND I/O PAGE.
10         , 2. CHECKS THAT THE 8240 CONTROLLER REGISTERS RESPOND WITH REASONABLE DATA.
11         , 3. PERFORM DIRECT ACCESS MODE READ WRITE TEST ON CYLINDER ZERO HEAD TWO.
12         , 4. IF PROMPTING IS ENABLED (BY JUMPER ON CONTROLLER BOARD) AND BOOT ADDRESS
13         ,   BITS 0 - 7 ARE ZERO, THEN PROMPT AND ACCEPT USER INPUT TO DETERMINE BOOT
14         ,   DEVICE. OTHERWISE, DECODE BOOT DEVICE FROM CONFIGURATION WORD.
15         , 5. READ IN BOOT BLOCK FROM SELECTED DEVICE AND TRANSFERS CONTROL TO LOCN 0.
16
17         , ABNORMAL TERMINATION ERROR CODES - LOCATED IN REGISTER 0 AFTER SYSTEM HALT.
18         ,   R1 CONTAINS BOOTSTRAP PROGRAM REVISION LEVEL AND R2 HAS CONTROLLER
19         ,   MICROCODE REVISION LEVEL.
20
21         , 1. MEMORY TEST ERROR -
22         ,   OFFSET ADDRESS OF OFFENDING ADDRESS IN R3. PAGE
23         ,   (IF APPLICABLE) IS IN APR 6.
24         , 2. WINCHESTER Q-BUS REGISTER ERROR -
25         ,   NO RESPONSE FROM DESIGNATED WINCHESTER REGISTER. REGISTER
26         ,   ADDRESS IN R3.
27         , 3. TAPE Q-BUS REGISTER ERROR -
28         ,   NO RESPONSE FROM DESIGNATED TAPE REGISTER. REGISTER ADDRESS IN R3.
29         , 4. FLOPPY Q-BUS REGISTER ERROR-
30         ,   NO RESPONSE FROM DESIGNATED FLOPPY REGISTER. REGISTER ADDRESS IN R3.
31         , 5. WINCHESTER READ/WRITE TEST ERROR -
32         ,   DEVICE ADDRESS IN R3.
33         , 6. BOOT READ ERROR -
34         ,   ERROR READING BOOT BLOCK. DEVICE ADDRESS IN R3.
35         , 7. INVALID BOOT BLOCK -
36         ,   BLOCK READ INTO MEMORY NOT A VALID BOOT BLOCK.
37
38         , BOOT ADDRESSES -
39
40         , 77X000      WINCHESTER VOLUME 0 (DL0)
41         , 77X002      WINCHESTER VOLUME 1 (DL1)
42         , 77X004      WINCHESTER VOLUME 2 (DL2)
43         , 77X006      RESERVED
44         , 77X010      TAPE
45         , 77X012      FLOPPY AT 777170
46         , 77X014      FLOPPY AT 777150
47         , 77X016      RESERVED
48

```

DSD 890 BOOTSTRAP PROGRAM      MACRO M1113 25-MAR-83 14:34 PAGE 2  
 BOOTSTRAP DEFINITIONS

```

50      .SBTTL BOOTSTRAP DEFINITIONS
51      ;
52      ; RLO1 / RLO2 COMPATIBLE HARDWARE DEFS.
53      ;
54      000002 .RLBA= 2           ; BUS ADDRESS OFFSET
55      000004 .RLDA= 4           ; DISK ADDRESS OFFSET
56      000006 .RLMP= 6           ; MULTI PURPOSE OFFSET
57      000010 .RLBAE=10         ; BUS ADDRESS EXTENSION OFFSET
58      000012 .RLCS2=12         ; CS2 OFFSET
59      ;
60      ; I/O REGISTER ADDRESSES
61      ;
62      177560 TKS = 177560       ; KEYBOARD STATUS
63      177562 TKB = 177562       ; KEYBOARD DATA
64      177564 TPS = 177564       ; OUTPUT STATUS
65      177566 TPB = 177566       ; OUTPUT DATA
66      ;
67      ; MEMORY MANAGEMENT UNIT ADDRESSES
68      ;
69      177572 MMUSRO = 177572    ; MMU STATUS REGISTER 0
70      172516 MMUSR3 = 172516    ; MMU STATUS REGISTER 3
71      172300 KPDR0 = 172300    ; KERNAL PAGE DESCRIPTOR 0
72      172340 KPAR0 = 172340    ; KERNAL PAGE ADDRESS REGISTER 0
73      172354 KPAR6 = 172354    ; KERNAL PAGE ADDRESS REGISTER 6
74      ;
75      ; REGISTER USAGE IN CONFIGURATION AND MEMORY TEST SECTION
76      ;
77      000003 MMU= %3           ; R3   BOOLEAN MMU FLAG. ZERO = NOT PRESENT
78      000005 CFW= %5           ; R5   CONFIGURATION WORD
79      ;
80      ; COMMAND CODES
81      ;
82      000002 WCK = 2           ; WRITE CHECK
83      000004 GES = 4           ; GET STATUS
84      000006 SEEK = 6          ; SEEK
85      000010 RDH = 10          ; READ HEADER
86      000012 WRT = 12          ; WRITE DATA
87      000014 RD = 14           ; READ DATA
88      ;
89      ; CONFIGURATION CONSTANTS
90      ;
91      000400 WADJMP = 400       ; WINCHESTER ADDRESS JUMPER
92      001000 TADJMP = 1000     ; TAPE ADDRESS JUMPER
93      010000 TINJMP = 10000    ; TAPE INSTALLED JUMPER
94      020000 PROMPT = 20000    ; PROMPTING ENABLED
95      003002 MTBEG = 3002      ; START OF MEMORY TO TEST
96      000000 BTREV = 0         ; BOOT PROGRAM REVISION #
97      111000 EMENTER = 111000  ; CODE TO ENTER EXTENDED MODE
98      101000 EMOKAY = 101000   ; CS2 RESPONSE TO EMENTER
99      020000 RWADD = 20000     ; DISK ADDRESS FOR R/W TEST
100     ;
101     ; ABNORMAL TERMINATION CODES. LOCATED IN R0 AFTER SYSTEM HALT
102     ;
103     000001 MTE = 1           ; MEMORY TEST ERROR - OFFSET OF MEM LOCN (INTO APR 6) IN R1
104     000002 WGE = 2           ; WINCHESTER Q-BUS REGISTER ERROR - DEVICE ADDR IN R1
105     000003 TGE = 3           ; TAPE Q-BUS REGISTER ERROR - "
106     000004 FGE = 4           ; FLOPPY Q-BUS REGISTER ERROR - "

```

DSD 890 BOOTSTRAP PROGRAM      MACRO M1113 25-MAR-83 14:34 PAGE 2-1  
 BOOTSTRAP DEFINITIONS

```

107     000005 WRW = 5           ; WINCHESTER R/W TEST ERROR - "
108     000006 BRE = 6           ; BOOT READ ERROR - "
109     000007 IBB = 7           ; INVALID BOOT BLOCK - "
110

```

DSD 890 BOOTSTRAP PROGRAM  
22 BIT MEMORY TEST

MACRO M1113 25-MAR-83 14:34 PAGE 3

```

112          .SBTTL 22 BIT MEMORY TEST
113 000000          CSECT
114          ;
115          ;
116          ;
117 000000 013705 START: MOV    @#3000,CFW    ; GET CONFIG WORD. KEEP IN R5
          003000
118 000004 011706          MOV    (PC), SP    ; SET STACK TO 12700
119 000006 012700          MOV    #340, R0    ; LOCK OUT LINE TIME CLOCK
          000340
120 000012 106400          MTPS   R0        ; BY SETTING PRIORITY TO 7
121 000014 004467          JSR    R4, MEMCHK  ; R4 POINTS TO TRAP ROUTINE
          000010
122          ;
123          ; TRAP PROCESSOR FOR NXM TIMEOUT
124          ; SETS CARRY AND RETURNS ON NON-EXISTANT MEMORY TRAP
125          ;
126 000020          TRAP4:
127 000020 052766          BIS    #1, 2(SP)    ; SET CARRY BIT ON TRAP TO 4
          000001
          000002
128 000026 000002          RTI
129          ;
130          ; MEMORY TEST SECTION
131          ;
132 000030 012701 MEMCHK: MOV    #4, R1        ; SET LOW MEM POINTER
          000004
133 000034 010421          MOV    R4, (R1)+    ; LOAD TRAP VECTOR
134 000036 010021          MOV    R0, (R1)+    ; LOAD PSW = 340
135 000040 030527          BIT    CFW, #PROMPT  ; IS PROMPTING ENABLED ?
          020000
136 000044 001414          BEQ    MTINIT    ; IF NOT GOTO MEM TEST INIT
137 000046 004167          JSR    R1, PRINT    ; LOAD R1 WITH POINTER TO "TESTING MEMORY"
          001702
138          .NLIST BIN
139 000052 TSTMSG: .ASCIZ <15><12>/TESTING MEMORY /<15><12>
140          .EVEN
141          .LIST BIN
142 000076 012704 MTINIT: MOV    #MTBEG, R4    ; R4 POINTS TO LOCN TO BE TESTED
          003002
143 000102 005003          CLR    MMU        ; INITIALIZE MMU FLAG TO FALSE
144 000104 012737          MOV    #0, @#MMUSRO ; DISABLE MEMORY MANAGEMENT UNIT
          000000
          177572
145 000112 103446          BCS    MEMTST    ; IF NO MMU PRESENT START TEST
146 000114 005203          INC    MMU        ; SET MMU FLAG TO TRUE
147 000116 012700          MOV    #10, R0    ; USE R0 TO COUNT MMU RESISTERS
          000010
148 000122 012701          MOV    #KPDRO, R1  ; START WITH KERNAL PDR 0
          172300
149 000126 012721 10*: MOV    #77406, (R1)+  ; INIT PDR = 4K WDS, UPWARD EXP., R/W
          077406
150 000132 077003          SOB    R0, 10*   ; LOOP UNTIL DONE
151 000134 012702          MOV    #7, R2    ; REINITIALIZE COUNTER (DON'T INCLUDE IO PAGE)
          000007
152 000140 012701          MOV    #KPARO, R1 ; SET POINTER TO APRS
          172340

```

DSD 890 BOOTSTRAP PROGRAM  
22 BIT MEMORY TEST

MACRO M1113 25-MAR-83 14:34 PAGE 3-1

```

153 000144 010021 20$: MOV    R0, (R1)+      ; APR = BASE ADDRESS (START R0 = 0)
154 000146 062700      ADD    #200, R0        ; INCREMENT BY 128 BLOCKS (4K WORDS)
                        000200
155 000152 077204      SOB    R2, 20$        ; LOOP UNTIL DONE
156 000154 012711      MOV    #177600, (R1)  ; APR 7 = I/O PAGE
                        177600
157 000160 005237      INC    @#MMUSRO      ; ENABLE MMU
                        177572
158 000164 005037      CLR    @#0           ; CLEAR LOCATION 0 TO SEE IF MEM > 18 BITS
                        000000
159 000170 012702      MOV    #KPAR6, R2    ; USE R2 AS POINTER TO KERNAL APR 6
                        172354
160 000174 012712      MOV    #10000, (R2)  ; SET AT BEGINNING OF 19 BIT MEM SPACE
                        010000
161 000200 005237      INC    @#140000     ; INCREMENT LOCN
                        140000
162 000204 103406      BCS    30$          ; IF NXM BRA
163 000206 005737      TST    @#0          ; SEE IF LOCN 0 CHANGED
                        000000
164 000212 001003      BNE    30$          ; IF SO IMPLIES SHADOWING
165 000214 012737      MOV    #20,@#MMUSR3 ; ENABLE 22-BIT ADDR
                        000020
                        172516
166 000222 052704 30$:  BIS    #140000, R4    ; INITIALIZE TO APR 6
                        140000
167 000226 005012      CLR    (R2)         ; START WITH APR 6 = 0
168 000230      MEMTST:
169 000230 000241 10$:  CLC
170 000232 010414      MOV    R4, (R4)     ; (ADDR) = ADDR
171 000234 103427      BCS    MEMEND       ; CARRY MEANS TRAP 4
172 000236 020414      CMP    R4, (R4)     ; CHECK IF SAME AS WRITTEN
173 000240 001016      BNE    MTERR        ; IF NOT MEM TEST ERROR ROUTINE
174 000242 005114      COM    (R4)         ; COMPLEMENT MEMORY LOCATION
175 000244 060414      ADD    R4, (R4)     ; CHECK (SHOULD = 177777)
176 000246 005224      INC    (R4)+        ; MAKE = 0 AND GOTO NEXT LOCN
177 000250 001012      BNE    MTERR        ; BRANCH IF ERROR
178 000252 005703      TST    MMU          ; IS MMU PRESENT
179 000254 001765      BEQ    10$          ; IF NOT KEEP LOOPING
180 000256 020427      CMP    R4, #160000 ; END OF 4K BANK?
                        160000
181 000262 001362      BNE    10$          ; LOOP IF NOT
182 000264 062712      ADD    #200, (R2)   ; BUMP APR CONTENTS
                        000200
183 000270 012704      MOV    #140000, R4  ; START AGAIN WITH OFFSET 0 INTO APR6
                        140000
184 000274 000755      BR    10$           ; BRANCH FOREVER (TRAP 4 EXITS)
185 000276 012700 MTERR: MOV    #MTE, R0      ; MEMORY TEST ERROR CODE
                        000001
186 000302 010401      MOV    R4, R1       ; OFFSET OF ERROR LOCATION
187 000304 000167      JMP    BOOTERR
                        001070
188 000310 000000 TOPOFF: .WORD 0
189 000312 000000 TOPAPR: .WORD 0
190 000314 010467 MEMEND: MOV   R4, TOPOFF ; HOLDS TOP OF MEMORY OFFSET
                        177770
191 000320 011267      MOV    (R2), TOPAPR ; HOLDS TOP OF MEMORY APR
                        177766

```

DSD 890 BOOTSTRAP PROGRAM  
22 BIT MEMORY TEST

MACRO M1113 25-MAR-83 14:34 PAGE 3-2

```

192 000324 005037      CLR      @MMUSRO      ; DISABLE MMU
      177572
193
194      ; CHECK THAT ALL 890 REGISTERS RESPOND CORRECTLY
195      ;
196 000330 005000 REGCHK: CLR      RO      ; USE AS PTR FOR STD CONFIG STORAGE
197 000332 012701      MOV      #174420,R1   ; LOAD ALT ADDR
      174420
198 000336 032705      BIT      #WADJMP,CFW   ; RCSR SELECT = STD ?
      000400
199 000342 001402      BEQ      1$      ; IF NOT STANDARD
200 000344 012701      MOV      #174400,R1   ; LOAD STD ADDR
      174400
201 000350 010120 1$    MOV      R1,(R0)+   ; SAV SELECTED RL @ LOCN 0
202 000352 005721      TST      (R1)+      ; RLCSR
203 000354 103561      BCS      WERR      ; BRANCH IF NO RESPONSE
204 000356 012702      MOV      #-1,R2      ; R2 HAS ALL 1'S
      177777
205 000362 010211      MOV      R2,(R1)    ; RLBA SHOULD RESPONDS WITH ALL 1'S
206 000364 020221      CMP      R2,(R1)+   ;
207 000366 001154      BNE      WERR      ; BRANCH IF NOT EQ.
208 000370 010211      MOV      R2,(R1)    ; SAME WITH RLDA
209 000372 020221      CMP      R2,(R1)+
210 000374 001151      BNE      WERR
211 000376 005721      TST      (R1)+      ; SKIP RLMPR
212 000400 010211      MOV      R2,(R1)    ; ALL ONES TO BAE
213 000402 022711      CMP      #77,(R1)   ; SHOULD ONLY RESPOND WITH BITS 0-5
      000077
214 000406 001144      BNE      WERR
215 000410 005021      CLR      (R1)+      ; RESET BAE
216 000412 012711      MOV      #EMENTER,(R1) ; WRITE EMENTER CODE TO RLCS2
      111000
217 000416 012711      MOV      #111333,(R1) ; SECOND WORD OF EMENTER
      111333
218 000422 011100      MOV      (R1),RO    ; COPY OF RLCS2
219 000424 001535      BEQ      WERR      ; SHOULD BE NON ZERO
220 000426 105000      CLR      RO
221 000430 000300      SWAB    RO          ; MICROCODE REV LEVEL TO LOW BYTE
222 000432 010037      MOV      RO,@#10    ; SAVE AT LOCATION 10
      000010
223 000436 162701      SUB      #12,R1     ; RESET R1 TO RLCS
      000012
224 000442 010100      MOV      R1,RO
225 000444 062700      ADD      #6,RO      ; RO HAS ADDRESS OF ACTIVE RLMPR
      000006

```

DSD 890 BOOTSTRAP PROGRAM      MACRO M1113 25-MAR-83 14:34 PAGE 4  
 WINCHESTER READ WRITE TEST

```

227          .SBTTL WINCHESTER READ WRITE TEST
228          ;
229          ;
230          000001 LCS = %1;
231 000450    RWTST:
232          ; INCLUDE CODE TO SKIP RW TEST IF ALL UNITS WRITE PROTECT
233 000450    030527    BIT      CFW,#170      ; IS DRIVE WRITE PROTECTED
                000170
234 000454    001523    BEQ      TSCHK        ; IF SO SKIP READ/WRITE TEST
235 000456    012761    MOV      #EMENTER,.RLCS2(LCS) ; RE ENTER EXTENDED MODE
                111000
                000012
236 000464    012761    MOV      #111333,.RLCS2(LCS) ;
                111333
                000012
237 000472    005046    CLR      -(SP)        ; SECTOR FOR RW TEST
238 000474    012761    MOV      #RWADD,.RLDA(LCS)
                020000
                000004
239 000502    012703    MOV      #SEEK,R3      ; SET UP SEEK COMMAND
                000006
240 000506    004767    JSR      PC,RLEX      ; ISSUE SEEK COMMAND
                000162
241 000512    005723    TST      (R3)+        ; TURN INTO READ HEADER COMMAND
242 000514    004767    JSR      PC,RLEX      ; ISSUE READ HEADER COMMAND
                000154
243 000520    021027    CMP      (R0),#RWADD    ; SEEK SUCCESSFUL ?
                020000
244 000524    001075    BNE      WERR        ; BRANCH IF NOT
245 000526    005061    CLR      .RLBAE(LCS) ; START AT SECTOR 0
                000010
246 000532    012703    AGN:  MOV      #RD,R3      ; READ DATA COMMAND
                000014
247 000536    004767    JSR      PC,RLEX      ; READ ONE SECTOR TO BUFFER
                000132
248 000542    011661    MOV      (SP),.RLBAE(LCS) ; SECTOR TO CHECK
                000010
249 000546    012703    MOV      #WCK,R3      ; WRITE CHK
                000002
250 000552    004767    JSR      PC,RLEX      ;
                000116
251 000556    005711    TST      (LCS)        ; TEST FOR WRITE CHK ERROR
252 000560    100435    BMI      RTRY        ; BRANCH IF ERROR
253 000562    012703    MOV      #200,R3     ; USE R3 AS COUNTER FOR COMPLEMENT
                000200
254 000566    010446    MOV      R4,-(SP)     ; PUSH R4
255 000570    012704    MOV      #MTBEG,R4   ; POINTER TO BUFFER
                003002
256 000574    005124    10*:  CDM      (R4)+    ; INVERT WORD
257 000576    077302    SOB      R3,10*      ; DO WHOLE BUFFER
258 000600    012604    MOV      (SP)+,R4    ; RESTORE R4
259 000602    012703    MOV      #WCK,R3     ; ANOTHER WRITE CHECK
                000002
260 000606    004767    JSR      PC,RLEX      ; EXECUTE
                000062
261 000612    005711    TST      (LCS)        ; EXPECT ERROR THIS TIME
262 000614    100017    BPL      RTRY        ; RETRY IF NOT AN ERROR

```

DSD 890 BOOTSTRAP PROGRAM  
WINCHESTER READ WRITE TEST

MACRO M1113 25-MAR-83 14:34 PAGE 4-1

```

263 000616 012703      MOV      #WRT,R3      ; WRITE DATA COMMAND
                000012
264 000622 004767      JSR      PC,RLEX     ; EXECUTE
                000046
265 000626 005711      TST      (LCS)       ; WRITE DATA ERROR ?
266 000630 100411      BMI      RTRY        ; TRY AGAIN IF SO
267 000632 012703      MOV      #WCK,R3     ; DO ANOTHER WRITE CHK
                000002
268 000636 004767      JSR      PC,RLEX     ;
                000032
269 000642 005711      TST      (LCS)       ; ERROR ?
270 000644 100403      BMI      RTRY        ; THEN TRY AGAIN
271 000646 005061      CLR      .RLCS2(LCS) ; EXIT EXTENDED MODE
                000012
272 000652 000424      BR      TSCHK        ; OK NOW CHECK TS REGISTERS
273 000654 062716      RTRY:   ADD      #400,(SP) ; BUMP SECTOR
                000400
274 000660 031627      BIT      (SP),#4000  ; CHECK IF REPEATED 7 TIMES
                004000
275 000664 011661      MOV      (SP),.RLBAE(LCS)
                000010
276 000670 001413      BEQ      WERR        ;
277 000672 000717      BR      AGN          ; IF NOT REPEAT
278 000674 012761      RLEX:   MOV      #MTBEG,RLBA(LCS); USE 3002 AS BUFFER
                003002
                000002
279 000702 012761      MOV      #-200,.RLMP(LCS) ; ONE SECTOR WORD COUNT
                177600
                000006
280 000710 010311      MOV      R3,(LCS)    ; ISSUE COMMAND
281 000712 105711      RLWT:   TSTB      (LCS) ; WAIT FOR DONE
282 000714 100376      BPL      RLWT
283 000716 000207      RTS      PC          ; RETURN
284 000720 005037      WERR:   CLR      @#0 ; ZERO @ LOCN 0 MEANS NO WINCH
                000000
285 000724 012700      TSCHK:  MOV      #2,R0
                000002
286 000730 005010      CLR      (R0)        ; ZERO @ LOCN 2 MEANS NO TAPE
287 000732 032705      BIT      #TINJMP,CFW ; IS TAPE INSTALLED ?
                010000
288 000736 001013      BNE      DECODE      ; BRANCH IF NOT
289 000740 012701      MOV      #172530,R1 ; LOAD ALT ADDR
                172530
290 000744 032705      BIT      #TADJMP,CFW ; TSSR SELECT = STD ?
                001000
291 000750 001402      BEQ      3#         ; IF NOT BRANCH
292 000752 012701      MOV      #172520,R1 ; LOAD STD ADDR
                172520
293 000756 010120      3#:    MOV      R1,(R0)+ ; SAV STD TAPE
294 000760 005721      TST      (R1)+      ; CHECK FOR RESPONSE
295 000762 005711      TST      (R1)       ; " "
296 000764 103572      BCS      TGERR      ; BRANCH IF NO RESPONSE
297
                ;
298                ; DECODE CONFIGURATION WORD
299                ;
300 000766 010500      DECODE: MOV      CFW,R0 ; MAKE A COPY
301 000770 042700      BIC      #177770,R0 ; MASK UNIT & TAPE BITS

```

DSD 890 BOOTSTRAP PROGRAM  
WINCHESTER READ WRITE TEST

MACRO M1113 25-MAR-83 14:34 PAGE 4-2

```

177770
302 000774 001073      BNE      10%           ; JUMP IF NOT BASE ADDRESS
303 000776 032705      BIT       #PROMPT,CFW ; IF IT IS SEE IF PROMPTING ENABLED
                        020000
304 001002 001470      BEG      10%           ; BRANCH IF NOT
305 001004 004167      5%:   JSR      R1,PRINT ; LOAD R1 WITH POINTER TO PROMPT MSG
                        000744

306                                .NLIST BIN
307 001010                                .ASCII <15><12>/BOOT DEV/<15><12>
308 001024                                .ASCII <40>/ (0=DLO, 1=DL1, 2=DL2, 3=TAPE, 4=FLP 177170, 5=FLP 177150)/
309 001116                                .ASCIIZ <15><12>/?/
310                                .EVEN
311                                .LIST BIN
312 001122 004767      JSR      PC,GETCHR ; GET ANSWER
                        000550
313 001126 022700      CMP      #15,R0 ; IS IT A CARRIAGE RETURN
                        000015
314 001132 001003      BNE      7%           ; BRANCH IF NOT
315 001134 005000      CLR      R0 ; DEFAULT IS DLO
316 001136 000167      JMP      BOOTRL ; GO BOOT IT
                        000032
317 001142 162700      7%:   SUB      #'0,R0 ; MAKE INTO NUMBER
                        000060
318 001146 020027      CMP      R0,#5 ; MAKE SURE VALID ENTRY
                        000005
319 001152 003314      BGT      5%           ; TRY AGAIN IF NOT
320 001154 020027      CMP      R0,#2 ; IT IS WINCHESTER ?
                        000002
321 001160 003405      BLE      BOOTRL ; IF SO GO TO DISPATCH
322 001162 005200      INC      R0 ; IF NOT INC TO OFFSET FOR RESERVED WINCH 3
323 001164 022700      10%:  CMP      #4,R0 ; IS IT TAPE ?
                        000004
324 001170 001513      BEG      BOOTTS ; BRANCH IF SO
325 001172 003542      BLE      BOOTRX

```

DSD 890 BOOTSTRAP PROGRAM            MACRO M1113 25-MAR-83 14:34 PAGE 5  
 WINCHESTER BOOT SECTION

```

327                            SBTTL WINCHESTER BOOT SECTION
328
329                            LCS = %1
330                            ; DISK BOOT, DETERMINE RLCSR BASE ADDRESS
331 001174 013701 BOOTRL: MOV        @#0,LCS            ; STD DISK ADDR AT LOCN 0
                             000000
332 001200 005701                            TST        LCS            ; IF ZERO MEANS WINCH R/W ERROR
333 001202 001460                            BEQ        RWERR        ; DON'T ALLOW BOOT FROM WINCH
334 001204 105711                            2*: TSTB        (LCS)            ; CHECK CONTROLLER READY
335 001206 103464                            BCS        WGERR        ; HANG IF NO BUS RESPONSE TO DEVICE
336 001210 100375                            BPL        2$            ; ELSE WAIT FOR CONTROLLER RDY
337 001212 012761                            MOV        #3, .RLDA(LCS) ; DO RESET CONTROLLER ON GET STATUS
                             000003
                             000004
338 001220 010003                            MOV        R0,R3
339 001222 000303                            SWAB        R3
340 001224 052703                            BIS        #4,R3
                             000004
341 001230 010311                            MOV        R3,(LCS)        ; LCS - LOAD GET STATUS FUNCTION
342 001232 105711                            3*: TSTB        (LCS)            ; WAIT FOR CONTROLLER READY
343 001234 100376                            BPL        3$
344 001236 012761                            MOV        #177601,.RLDA(LCS) ; SET MAXIMAL LENGTH SEEK OUTWARDS
                             177601
                             000004
345 001244 012703                            MOV        #6*400, R3        ; SEEK COMMAND
                             003000
346 001250 050003                            BIS        R0, R3            ; WITH UNIT BITS
347 001252 000303                            SWAB        R3            ; BACK TO UN UN CR IE DF DF FN FN FN GO
348 001254 010311                            MOV        R3,(LCS)        ; LOAD RL01 SEEK COMMAND
349 001256 105711                            4*: TSTB        (LCS)            ; LCS - WAIT FOR CONTROLLER READY
350 001260 100376                            BPL        4$
351 001262 012761                            MOV        #-400,.RLMP(R1) ; RLWC - SET WORDCOUNT FOR 1 BLOCK
                             177400
                             000006
352 001270 005061                            CLR        .RLDA(R1)        ; LOAD A ZERO INTO DISK ADDRESS REG
                             000004
353 001274 005061                            CLR        .RLBA(R1)        ; LOAD A ZERO INTO BUS ADDRESS REG
                             000002
354 001300 062703                            ADD        #6, R3            ; MAKE SEEK INTO A READ COMMAND
                             000006
355 001304 010311                            MOV        R3,(LCS)        ; ISSUE READ FUNCTION
356 001306 105711                            5*: TSTB        (LCS)            ; CONTROLLER READY?
357 001310 100376                            BPL        5$
358 001312 005711                            TST        (LCS)            ; ERROR?
359 001314 100003                            BPL        CHKNOP
360 001316 012700                            MOV        #BRE,R0        ; BOOT READ ERROR CODE
                             000006
361 001322 000426                            BR        BOOTERR
362 001324                            CHKNOP:
363 001324 023727                            CMP        @#0,#240        ; IS FIRST WORD NO-OP
                             000000
                             000240
364 001332 001403                            BEQ        1$            ; BRANCH IF SO
365 001334 012700                            MOV        #IBB,R0        ; INVALID BOOT BLOCK CODE
                             000007
366 001340 000417                            BR        BOOTERR        ; BRANCH TO COMMON ERROR ROUTINE
367 001342 005007                            1*: CLR        PC            ; DISPATCH TO LOC 0.

```

DSD 890 BOOTSTRAP PROGRAM      MACRO M1113 25-MAR-83 14:34 PAGE 5-1  
 WINCHESTER BOOT SECTION

```

368                   ;
369                   ; ERROR HANDLER
370                   ;
371 001344 012700 RWERR: MOV   #WRW,R0           ; WINCHESTER READ WRITE ERROR
                  000005
372 001350 000413           BR    BOOTERR
373 001352 012700 TGERR: MOV   #TGE,R0           ; TAPE REGISTER ERROR
                  000003
374 001356 000410           BR    BOOTERR
375 001360 012700 WGERR: MOV   #WGE,R0           ; WINCHESTER REGISTER ERROR
                  000002
376 001364 000405           BR    BOOTERR
377 001366 012700 FGERR: MOV   #FGE,R0           ; FLOPPY REGISTER ERROR
                  000004
378 001372 000402           BR    BOOTERR
379 001374 012700 BRERR: MOV   #BRE,R0           ; BOOT READ ERROR
                  000006

380                   ;
381                   ; COMMON BOOT ERROR HALT
382                   ;
383 001400           BOOTERR:
384 001400 010103           MOV   R1,R3           ; PARM IN R3
385 001402 012701           MOV   #BTREV,R1       ; BOOT PROG REVISION
                  000000
386 001406 013702           MOV   @#10,R2       ; PROM REV
                  000010
387 001412 105002           CLRB  R2           ; PUT IN LOW ORDER BITS
388 001414 000302           SWAB  R2
389 001416 000000           HALT           ; AND STOP

```

DSD 890 BOOTSTRAP PROGRAM      MACRO M1113 25-MAR-83 14:34 PAGE 6  
 TAPE BOOT SECTION

```

391                   ; SBTTL TAPE BOOT SECTION
392                   ;
393                   ; TAPE BOOT SECTION
394                   ;
395                   ; SETUP R1 TO TSSR ADDRESS
396 001420 013701 BOOTTS: MOV   @#2,R1           ; LOCN 2 HOLDS SELECTED TAPE
                  000002
397 001424 005701           TST   R1           ; CHECK IF R1 = 0
398 001426 001751           BEG   TGERR       ; IF SO NO TAPE
399 001430 000401           BR    10$       ; NEXT WORD MUST BE AT FIXED OFFSET
400 001432 046523           .WORD  46523       ; DEVICE "MS" ID BACKWARDS
401
402 001434 062701 10$:   ADD   #2,R1           ; R1=TSDB+2
                  000002
403 001440 010102 BTRTRY: MOV   R1,R2           ; R2 = TSSR
404 001442 005000           CLR   R0
405 001444 105711 1$:   TSTB  (R1)       ; WAIT FOR SSR
406 001446 100376           BPL   1$
407 001450 010704           MOV   PC,R4       ; OFFSET = "SM" + 20
408
409 001452 010103           MOV   R1,R3       ; R3=TSSR
410 001454 062703           ADD   #1,R3       ; BOOT REQUIRES WRITE TO BASE + 3 (172523)
                  000001
411 001460 112713           MOVB  #200,(R3)   ; TSV05 IMPLIED BOOT
                  000200
412 001464 005242           INC   -(R2)       ; WRITE INTO TSDB
413 001466 105711 2$:   TSTB  (R1)       ; WAIT FOR SSR
414 001470 100376           BPL   2$
415 001472 005711           TST   (R1)       ; TEST FOR ERROR
416 001474 100761           BMI   BTRTRY   ; RETRY IF SC
417 001476 005007           CLR   PC           ; JUMP TO ZERO

```

DSD 890 BOOTSTRAP PROGRAM      MACRO M1113 25-MAR-83 14:34 PAGE 7  
 FLOPPY BOOT SECTION

```

419          .SBTTL FLOPPY BOOT SECTION
420          ;
421          ; FLOPPY BOOT SECTION
422          ;
423          ; BOOT THE DEVICE IN R1. REGISTERS USED AS INDICATED BELOW
424          000001 XCS=  %1      ; R1   POINTER TO RXCS
425          000002 XDB=  %2      ; R2   POINTER TO RXDB
426          ; R3   READ COMMAND VALUE WITH DENSITY BIT
427          000004 LDP=  %4      ; R4   LOAD POINTER
428          000005 SCT=  %5      ; R5   CURRENT SECTOR # (1, 3, 5, 7)
429          ; (SP) WORD COUNT FOR CURRENT DENSITY
430
431 001500 012701 BOOTRX: MOV    #177170,XCS    ; STD FLPY ADDRESS
432          177170
433 001504 020027          CMP    R0,#6        ; WAS ALTERNATE SPECIFIED ?
434          000006
435 001510 001002          BNE    1$          ; BRANCH IF NOT
436 001512 012701          MOV    #177150,XCS    ; LOAD ALTERNATE ADDRESS
437          177150
438 001516 012703 1$:     MOV    #7,R3
439          000007
440 001522 005004          CLR    LDP          ; INIT LOAD ADDRESS POINTER
441 001524 012746          MOV    #100, -(SP)    ; SET LOW DENSITY WORDCOUNT
442          000100
443 001530 012705          MOV    #1, SCT      ; INIT SECTOR TO READ
444          000001
445 001534 005000          CLR    R0          ; ONLY UNIT 0 ALLOWED FOR FLPY
446 001536 004767 RDLP:  CALL   WTFLAG        ; WAIT FOR DONE FLAG SET?
447          000124
448 001542 010102          MOV    XCS, XDB    ; COPY RXCS POINTER
449 001544 010322          MOV    R3, (XDB)+  ; LOAD READ COMMAND AND BUMP XDB TO RXDB
450 001546 105711 1$:     TSTB   (XCS)        ; WAIT FOR TRREQ
451 001550 103706          BCS   FGERR      ; BRANCH TO ERROR IF NO RESPONSE
452 001552 100375          BPL   1$
453 001554 010512          MOV    SCT, (XDB)  ; LOAD SECTOR
454 001556 105711 2$:     TSTB   (XCS)
455 001560 100376          BPL   2$
456 001562 012712          MOV    #1, (XDB)  ; LOAD TRACK
457          000001
458 001566 004767          CALL   WTFLAG        ; WAIT FOR DONE
459          000074
460 001572 005711          TST    (XCS)      ; KLUDGE SINCE DEC RX02 SETS ERROR
461          ; BEFORE IT SETS DONE
462 001574 100010          BPL   EMPBUF      ; EMPTY IF NO ERROR
463 001576 032712          BIT    #20, (XDB) ; IS ERROR A DENSITY ERROR?
464          000020
465 001602 001674          BEQ   BRERR      ; NO- FLOPPY READ ERROR
466 001604 052703          BIS   #400, R3   ; SET COMMAND TO DOUBLE DENSITY
467          000400
468 001610 012716          MOV    #200, (SP) ; SET TO D. D. WORD COUNT
469          000200
470 001614 000750          BR    RDLP      ; AND TRY READING AGAIN
471          459
472 001616 010346 EMPBUF: MOV   R3, -(SP) ; GET COMMAND COPY
473 001620 042716          BIC   #4, (SP)   ; MAKE INTO AN EMPTY BUFFER COMMAND
474          000004
475 001624 012611          MOV    (SP)+, (XCS) ; AND EXECUTE

```

DSD 890 BOOTSTRAP PROGRAM  
FLOPPY BOOT SECTION

MACRO M1113 25-MAR-83 14:34 PAGE 7-1

```

463 001626 105711 1*: TSTB (XCS) ; WAIT FOR FIRST TRREQ
464 001630 100376 BPL 1*
465 001632 011612 MOV (SP), (XDB) ; LOAD THE WORD COUNT
466 001634 105711 2*: TSTB (XCS)
467 001636 100376 BPL 2*
468 001640 010412 MOV LDP, (XDB) ; AND XFER ADDRESS
469 001642 004767 CALL WTFLAG ; WAIT FOR DONE OR TRREQ
000020
470 001646 061604 ADD (SP), LDP ; BUMP LOAD ADDRESS FOR NEXT SECT
471 001650 061604 ADD (SP), LDP ; ADD ACTUAL BYTE COUNT
472 001652 122525 CMPB (SCT)+, (SCT)+ ; BUMP SECTOR # BY 2
473 001654 020427 CMP LDP, #1000 ; FINISHED LOADING?
001000
474 001660 002726 BLT RDLP ; READ NEXT SECTOR
475
476 001662 000167 JMP CHKNOP ; CHECK LOC 0 = NOP AND DISPATCH
177436
477
478
479 ; WAIT FOR FLOPPY FLAGS, DONE, ERROR, TRREQ
480
481 001666 032711 WTFLAG BIT #240, (XCS) ; WAIT FOR DONE OR TRREQ
000240
482 001672 001775 BEQ WTFLAG ; CAN'T TEST RX02 ERROR HERE
483 001674 000207 RETURN

```

DSD 890 BOOTSTRAP PROGRAM      MACRO M1113 25-MAR-83 14:34 PAGE 8  
I/O SUPPORT SECTION

```

485      .SBTTL I/O SUPPORT SECTION
486      ;
487      ; I/O SUPPORT SECTION
488      ;
489      ; GETCHR - RETURNS CHAR VALUE IN RO, LSTCHR
490      ; CLEARS PARITY BIT
491
492 001676 105737 GETCHR: TSTB  @#TKS
      177560
493 001702 100375      BPL  GETCHR
494 001704 113700      MOVB  @#TKB, RO
      177562
495 001710 042700      BIC  #^C177, RO
      177600

496      ;
497      ; FALL THROUGH TO OUTCHR TO ECHO INPUT
498      ;
499      ; OUTCHR PRINTS CHAR IN RO
500      ;
501 001714 105737 OUTCHR: TSTB  @#TPS
      177564
502 001720 100375      BPL  OUTCHR
503 001722 110037      MOVB  RO, @#TPB
      177566
504 001726 105737      TSTB  @#TKS          ; CHAR READY?
      177560
505 001732 100007      BPL  10$
506 001734 113746 4$:  MOVB  @#TKB, -(SP)
      177562
507 001740 042716      BIC  #^C177, (SP)      ; STRIP PARITY
      177600
508 001744 122627      CMPB  (SP)+, #'S-100 ; CTRL S? REQUIRED FOR HIGH SPEED TERMINALS
      000023
509 001750 001771      BEQ  4$
510 001752 000207 10$: RTS  PC
511      ;
512      ; PRINT STRING POINTED AT BY R1 (TERMINATED BY 0 BYTE)
513      ;
514 001754      PRINT:
515 001754 112100 10$:  MOVB  (R1)+, RO          ; TO RO FOR OUTCHR
516 001756 105700      TSTB  RO          ; AT END OF STRING ?
517 001760 001403      BEQ  20$          ; EXIT IF YES
518 001762 004767      JSR  PC, OUTCHR      ; OUTPUT (RO)
      177726
519 001766 000772      BR  10$          ; LOOP
520 001770 000201 20$: RTS  R1
521 001772      BOTLST: .
522      000001      .END

```

DSD 890 BOOTSTRAP PROGRAM      MACRO M1113 25-MAR-83 14:34 PAGE 8-1  
 SYMBOL TABLE

AGN	000532R	MEMEND	000314R	TKB	= 177562
BOOTER	001400R	MEMTST	000230R	TKS	= 177560
BOOTRL	001174R	MMU	=%000003	TOPAPR	000312R
BOOTRX	001500R	MMUSRO	= 177572	TOPOFF	000310R
BOOTTS	001420R	MMUSR3	= 172516	TPB	= 177566
BOTLST	001772RG	MTBEG	= 003002	TPS	= 177564
BRE	= 000006	MTE	= 000001	TGE	= 000003
BRERR	001374R	MTERR	000276R	TGERR	001352R
BTREV	= 000000	MTINIT	000076R	TRAP4	000020R
BTRTRY	001440R	OUTCHR	001714R	TSCHK	000724R
CFW	=%000005	PRINT	001754R	TSTMSG	000052R
CHKNOP	001324R	PROMPT	= 020000	WADJMP	= 000400
DECODE	000766R	RD	= 000014	WCK	= 000002
EMENTE	= 111000	RDH	= 000010	WERR	000720R
EMOKAY	= 101000	RDLP	001536R	WGE	= 000002
EMPBUF	001616R	REGCHK	000330R	WGERR	001360R
FGE	= 000004	RLEX	000674R	WRT	= 000012
FGERR	001366R	RLWT	000712R	WRW	= 000005
GES	= 000004	RTRY	000654R	WTFLAG	001666R
GETCHR	001676R	RWADD	= 020000	XCS	=%000001
IBB	= 000007	RWERR	001344R	XDB	=%000002
KPAR0	= 172340	RTST	000450R	.RLBA	= 000002
KPAR6	= 172354	SCT	=%000005	.RLBAE	= 000010
KPDRO	= 172300	SEEK	= 000006	.RLCS2	= 000012
LCS	=%000001	START	000000R	.RLDA	= 000004
LDP	=%000004	TADJMP	= 001000	.RLMP	= 000006
MEMCHK	000030R	TINJMP	= 010000		

. ABS. 000000      000  
           001772      001  
 ERRORS DETECTED. 0

VIRTUAL MEMORY USED. 848 WORDS ( 4 PAGES)  
 DYNAMIC MEMORY. 2822 WORDS ( 10 PAGES)  
 ELAPSED TIME: 00.00.23  
 BB90X2, BB90X2/LI: TTM/-SP=BB90X2

SPECIAL SUPPLEMENT  
For  
LSI-11/73 Compatibility

1.0 SCOPE

This special supplement affects the DSD 890 User Guide only when used with the LSI-11/73 computer.

The DSD 890 System utilizes the 8240 controller, and release three of the micro-code permits use of the system with the LSI-11/73. The information contained in this supplement is intended to facilitate system use with this computer device.

The material is arranged into change pages that can be slipped into the manual in place of the standard cited pages.

2.0 ACTION

Replace the manual pages with the change pages attached to this supplement only if your intended use of your system is with the LSI-11/73 CPU. No action is required if used with other compatible computer devices.



November 21, 1984

## 80B240-03 RELEASE NOTE

The purpose of this note is to document the known problems and work-around solutions with the 80B240-03 controller being shipped with your system.

1. TSX and TSX-Plus will hang when exiting the TSX monitor to RT-11. The work-around solution is to re-boot the system.
2. In RSX-11M-Plus, Shadow Mode Recording is not supported when one unit is powered-down.
3. In all operating systems, operating in Power-up Mode 0 (battery backup) is not supported.

Problems resolved on the 80B240-03 controller from the 80B240-02 controller are:

1. All 11/73-compatible problems with RSX-11M and RSX-11M-Plus appear to be resolved as long as RSX-11M has had Autopatch C or greater applied and in RSX-11M-Plus as long as Autopatch D or greater has been applied. BRU, BRU64K, and IOX all function properly.
2. A time-out has been added for initializing brand new tapes under RSTS/E.
3. Due to DEC modifications to the latest 11/73 processor, a problem has been corrected where the bootstrap hangs when booting.



## Table of Contents

1.	INTRODUCTION .....	1-1
1.1	General Information .....	1-1
1.2	System Overview .....	1-1
1.3	Features .....	1-2
2.	SPECIFICATIONS .....	2-1
2.1	General Information .....	2-1
2.2	System Modules .....	2-1
2.3	Recording Characteristics .....	2-3
2.4	Cable and Connector Requirements .....	2-5
3.	SYSTEM DESCRIPTION .....	3-1
3.1	General Information .....	3-1
3.2	Introduction .....	3-1
3.3	Functional Description .....	3-4
3.3.1	Disk Drive Emulation .....	3-6
3.3.2	Non-Interleaved Data Transfer .....	3-8
3.3.3	Error Detection and Correction .....	3-10
3.3.4	Disk Flaw Management .....	3-11
3.3.5	Tape Drive Emulation .....	3-12
3.3.6	Tape Cartridge Storage Capacity .....	3-12
4.	INSTALLATION .....	4-1
4.1	General Information .....	4-1
4.2	Unpacking and Inspection .....	4-1
4.3	Controls and Indicators .....	4-2
4.3.1	Status Panel .....	4-2
4.3.2	Operator Panel .....	4-4
4.4	Power Requirements .....	4-6
4.5	Mechanical Preparations .....	4-6
4.6	Installation .....	4-8
4.6.1	Cabinet Installation .....	4-9
4.6.2	Cabling .....	4-10
4.6.3	Configuring Controller Board .....	4-14
4.6.3.1	Bootstrapping Options .....	4-17
4.6.3.2	Device Options .....	4-21
4.6.3.3	Interrupt Priority Options .....	4-21
4.6.3.4	DMA Request Monitor Option .....	4-23
4.6.3.5	Error Correction Option .....	4-26
4.6.3.6	CPU Option .....	4-26
4.6.4	Mounting Controller .....	4-26
4.6.5	System Power-Up .....	4-29
4.6.6	Acceptance Testing .....	4-29
4.6.6.1	Testing With RLEXR .....	4-30
4.6.6.2	Testing With TSEXr .....	4-30

4.6.7	Installing Software Programs .....	4-31
4.6.7.1	Transfer Using Floppy .....	4-31
4.6.7.2	Transfer Using RL02 .....	4-33
4.6.7.3	Transfer Using TSV05 .....	4-34
5.	OPERATING INSTRUCTIONS .....	5-1
5.1	General Information .....	5-1
5.2	Introduction .....	5-1
5.3	Applying Power .....	5-1
5.4	Loading the Cartridge .....	5-2
5.5	Unloading the Cartridge .....	5-4
5.6	Bootstrapping .....	5-4
5.7	Backup and Restore Operations .....	5-5
5.7.1	Creating Backups .....	5-6
5.7.2	Restoring Disk Data .....	5-7
6.	USER MAINTENANCE .....	6-1
6.1	General Information .....	6-1
6.2	Proper Ventilation .....	6-1
6.3	Cleaning the Cabinet .....	6-1
6.4	Quick Troubleshooting Chart .....	6-2
7.	FIELD TROUBLESHOOTING AND REPAIRS .....	7-1
7.1	General Information .....	7-1
7.2	Maintenance Philosophy .....	7-1
7.3	Preventive Maintenance .....	7-2
7.4	Winchester Disk Formatting .....	7-2
7.5	Bad-Track Map Updating .....	7-4
7.6	Diagnostic Tools .....	7-5
7.6.1	Power-On Confidence Tests .....	7-5
7.6.1.1	Winchester POCs .....	7-5
7.6.1.2	Tape Drive POCs .....	7-6
7.6.1.3	POCs Results .....	7-6
7.6.2	HyperDiagnostics .....	7-6
7.6.2.1	Controls and Indicators .....	7-7
7.6.2.2	Description .....	7-7
7.6.2.3	Operation .....	7-12
7.7	Troubleshooting .....	7-12
7.8	Replacement Procedures .....	7-33
7.8.1	Preparation .....	7-33
7.8.2	Replacing Modules .....	7-34
7.9	Maintenance Assistance .....	7-37
APPENDIX A:	GEMEXR UTILITY PROGRAM.....	A-1
APPENDIX B:	DSDBR UTILITY PROGRAM.....	B-1
APPENDIX C:	TSEXr UTILITY PROGRAM.....	C-1
APPENDIX D:	RLEXr USER GUIDE.....	D-1
APPENDIX E:	BOOTSTRAP PROGRAM LISTING.....	E-1




Figure 4-5. Cabinet and Board Cabling

### 4.6.3. Configuring Controller Board

The D8240 controller is configured with jumpers. These jumpers are installed between pairs of pins at various locations on the printed circuit board. It is important that the board is properly configured before it is used with a computer system.

The jumpers on the D8240 controller board are grouped in six classes:

- (1) Bootstrapping Options. This group provides jumpers to enable or disable the built-in boot program (W16 and W17), select boot address (W10) and boot mode (W31), and control line-time clock (LTC) interrupts (W8 and W9).
- (2) Device Options. The jumpers in this group enable or disable the disk (W15) and select disk address and interrupt vectors (W11). There are also jumpers to enable or disable the tape (W12 and W13), select tape address and interrupt vectors (W18), select tape drive emulation mode (W32), and enable or disable tape drive POCs (W33).
- (3) Interrupt Priority Options. The jumpers in this group select the disk and/or tape interrupt priority level (W20 and W21).
- (4) DMA Request Monitor Option. Two jumpers in this group (W6 and W7) enable or disable the option.
- (5) Error Correction Option. One jumper (W25) enables or disables the option.
- (6) CPU Option. One jumper (W24) changes this option.

Figure 4-6 shows the location of the controller jumpers. Table 4-3 is a reference chart that lists all jumpers, including those used for testing the board at the manufacturing facility.

The factory configuration is based on the most common applications used by customers. If this "standard" configuration satisfies you, skip the rest of this section, go to the next section, and mount the board.

If you need to reconfigure the board, read the rest of this section and use flowcharts Figures 4-7 through 4-11 and Figure 4-11A. Each figure is preceded by pertinent information.

Table 4-3. D8240 Jumpers (Cont)

Jumper	Shipped	Option Class	Function (As Shipped)
W21	Removed	Int. Priority	At Level Five
W19	(Not used on this board)		
W20	Installed	Int. Priority	At Level Five
W22	Removed	N/A	Factory use
W23	Removed	N/A	Factory use
W24	Removed	CPU	11/2, 11/23, 11/23+ CPU
W25	Removed	Error Correction	Enabled
W26	(Not used on this board)		
W27	Installed	N/A	Factory use
W28	Removed	N/A	Factory use
W29	Removed	N/A	Factory use
W30	Installed	N/A	Factory use
W31	Removed	Boot	CM Boot Disabled
W32	Removed	Device	TSV05 Emulation
W33	Removed	Device	Tape POCs Enabled
W34	Installed	N/A	Factory use

#### 4.6.3.1. Bootstrapping Options

LSI-11 computers use a "bootstrapping" technique for loading software programs. This technique consists of loading a primary set of instructions into main memory that, when executed, enables the CPU to load a secondary and, slightly longer, set.

The secondary set or bootstrap loader, as it is also known, enables the CPU to load complete operating systems and application programs.

The primary boot is contained in the DSD 890 diagnostic control board. This board contains a program in PROM, which initializes system memory, including parity. It also checks the Controller, Winchester drive, and permits bootstrap loading (second boot) from any Winchester volume, the Tape drive, or a RX02-compatible floppy - such as DS-100/105 subsystems.

This primary boot is enabled or disabled with two jumpers. The program can be selected from starting address 17773000 (DEC normal) or 17771000 (DEC alternate). One jumper selects this address.

Most DEC LSI-11 CPU modules are configured in one of two power-up modes. Some modules may be configured in as many as four power-up modes. Because of these variations, You should consult your DEC documentation for specific details about the CPU module that you are using. As an example, LSI-11/23 modules can be configured to power-up in modes 1 and 2. The DSD 8240 Controller will behave differently depending on the selected power-up mode.

In mode 1, the CPU enters console ODT without attempting to boot. At that point, the user must manually initiate the primary boot by typing the address of the boot device. That is, 17773000 or 17771000 for the DSD Winchester boot PROM, or the address of some other device boot PROM in the system.

In mode 2, power applied to the module causes the CPU to internally generate a bootstrap starting address (17773000) and begin to execute instructions found at that address.

The DSD 8240 Controller provides two secondary boot modes: conversational and non-conversational. The conversational mode prompts the user, via console, to select a device for the secondary boot.

In non-conversational mode, there are, again, differences based on the selected power-up mode. To use the LSI-11/23 example once more:

- In mode 1, the secondary boot device can be selected, via console ODT, by typing the device starting address.
- In mode 2, the secondary boot will be obtained from volume 0 of the Winchester drive.




Figure 4-11. Error Correction Option

TP 52383








Figure 4-11A. CPU Option




### DEC Backplane H9270



View is from Module Side of Connectors

### DEC Backplane H9273-A



### DEC Backplane DDV11-8

TP 312/83

Figure 4-12. Common LSI-11 Backplanes