


HP 12792B

8-Channel Asynchronous Multiplexer Subsystem

Configuration Guide

For HP 1000 M/E/F-Series Computers



HP 12792B
8-Channel Asynchronous
Multiplexer Subsystem

Configuration Guide



PRINTING HISTORY

The Printing History below identifies the Edition of this Manual and any Updates that are included. Periodically, Update packages are distributed which contain replacement pages to be merged into the manual, including an updated copy of this Printing History page. Also, the update may contain write-in instructions.

Each reprinting of this manual will incorporate all past Updates, however, no new information will be added. Thus, the reprinted copy will be identical in content to prior printings of the same edition with its user-inserted update information. New editions of this manual will contain new information, as well as all Updates.

To determine what software manual edition and update is compatible with your current software revision code, refer to the appropriate Software Numbering Catalog, Software Product Catalog, or Diagnostic Configurator Manual.

First Edition Jan 1983

NOTICE

The information contained in this document is subject to change without notice.

HEWLETT-PACKARD MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance or use of this material.

Hewlett-Packard assumes no responsibility for the use or reliability of its software on equipment that is not furnished by Hewlett-Packard.

This document contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced or translated to another program language without the prior written consent of Hewlett-Packard Company.

Table of Contents

Chapter 1 Overview

Chapter 2 System Planning

Software Modules	2-1
Device Drivers	2-2
Supported Devices	2-3
Interface Support Definition	2-3
Interface Driver With/without User Written Device Driver	2-5
Interface Driver With DDV05	2-5
Interface Driver With DDV12	2-5
Other HP Subsystems	2-5
Modems	2-6

Chapter 3 System Generation

General Considerations	3-1
Initialization Phase	3-2
Program Input Phase	3-2
Parameter Input Phase	3-3
Table Generation Phase	3-3
Equipment Table Entries	3-3
Device Reference Table Entries	3-4
Interrupt Table Entries	3-6
Partition Definition Phase System Available Memory	3-7

Chapter 4 Initialization

Using The Default Device Driver	4-1
Enabling A DDV12 Device	4-2
Enabling A DDV05 Device	4-2
Example	4-3

Chapter 5 Troubleshooting

Appendix A Partial Sample System Generation

Index

Chapter 1 Overview

The purpose of this Configuration Guide is to give the System Manager specific instructions for generating the HP 12792B Multiplexer (MUX) into an RTE-IVB or RTE-6/VM system. Also included are instructions on initializing the devices attached to the multiplexer and on troubleshooting if problems arise upon installation.

For more detailed information on the operation of the HP 12792B Multiplexer, the reader is referred to the HP 12792B 8-Channel Asynchronous Multiplexer Users Manual, part no. 5955-8867 and the 12792B 8-Channel Asynchronous Multiplexer Subsystem Installation and Reference Manual, part no. 12792-90020.

Chapter 2

System Planning

Software Modules

Software modules provided with the HP 12792B multiplexer are listed in Table 2-1 along with their approximate sizes.

Table 2-1. Software Modules for 12792B.

Module	Approx size (decimal bytes)	Description
%DVM00	3000	Interface card driver
%PVM00	150	Pre-driver
%DDV05	500	26XX terminal screen mode device driver
%DDV12	320	2631/2635/7310 printer device driver
%%DVTB	6	Device driver address table

%DVM00 and %PVM00 are always used in every system generation. %%DVTB is always used but if the user writes an additional device driver \$DVTB must be modified. %DDV05 and %DDV12 are used according to the needs of the user and the devices attached to the multiplexer interface. For more information on the tasks of these modules, refer to Chapter 4 of the 12792B users manual, part no. 5955-8867, covering Device Driver Writing.

Device Drivers

One of the features of the HP 12792B is its device driver capability. Users can write device drivers for RS-232-C or RS-423-A devices attached to the multiplexer to take care of special control required by the device. Device drivers are simply subroutines of the interface driver and use the interface driver to communicate with the CPU and devices. When writing device drivers, the user need only be concerned with adding the required character sequences to user data to control the devices.

HP supplies two device drivers with the 12792B product DDV05 (26XX terminal screen mode device driver) and DDV12 (2631/2635/7310 printer device driver). These device drivers, along with the interface driver (DVM00), the pre-driver (PWMOO) and \$DVTB can be relocated in a two page driver partition. Users adding their own device drivers may find that all of the software won't fit into a two page driver partition. There are several alternatives besides using a three page driver partition (which decreases maximum size of a user partition). Refer to Chapter 4 of the multiplexer users manual covering Device Driver Writing for the alternative locations of these modules.

The interface driver (DVM00) uses the device driver address table (\$DVTB) to find the appropriate device driver when the device driver is selected with a control 33B request. The device drivers are selected by numbers which are determined by the device driver's position in the device driver address table. Each device driver to be used with the interface driver must have an entry in the device driver address table. Thus, users writing their own device drivers must modify \$DVTB. \$DVTB need not be modified if only the HP-supplied device drivers or a subset thereof are used.

If one of the HP-supplied device drivers is not relocated (e.g., DDV05 is to be used for terminals but DDV12 is not) and it is to be selected by the HP-supplied device driver address table \$DVTB, an undefined external will result at system generation time. This will be the name of the device driver not used (e.g., DDV12).

The undefined external can be ignored, or it can be eliminated by recoding \$DVTB specifically for the applicable device drivers. (Refer Chapter 4 of the users manual for instructions on recoding \$DVTB.)

\$DVTB, revision 2226 and later, contains an entry for device driver DDV63. DDV63 is supplied with MRJE subsystem software. The device driver address table includes DDV63 for the convenience of MRJE users.

Supported Devices

This section describes the extent of Hewlett-Packard's support for terminals and devices not specifically called out as supported by the HP 12792B Multiplexer Subsystem. Hewlett-Packard's responsibility extends only to insuring that the HP 12792B performs according to the following specifications when correctly installed and commanded to perform according to the instructions in the HP 12792B documentation supplied to the user.

Interface Support Definition

Electrical: The HP 12792B provides connection for two twisted pair data lines per channel. One pair provides send data, the other provides receive data. Two of the wires may be connected together to form a signal common. The electrical specifications of the data lines are RS-423-A, which is backwards compatible with RS-232-C.

Line Speeds: The 12792B will transmit and receive data simultaneously on any combination of channels at the following baud rates, provided that the aggregate throughput of 76800 baud (total for all 8 channels) is not exceeded.

SUPPORTED BAUD RATES

50	150	2400
75	300	4800
110	1200	9600
134.5	1800	19200

In addition, the rate at which the interface driver/card can process read and write requests (including device driver read and write requests) may not exceed 128 requests per second. This request rate may be reduced by other system activity.

User data reproduction: The character size may be specified at 5, 6, 7, or 8 bits per character not including an optional parity bit. On transmit, the user data will be processed byte by byte passing the 5, 6, 7, or 8 least significant bits in each byte to the character depending on character size. A parity bit will be added by the interface if parity is enabled. On receive, the user data from each character will be passed to the user's buffer into the 5, 6, 7, or 8 least significant bits of each byte, with the unused bits defined as follows:

Receive 8 bits/char:

bits 0 - 7: data
parity bit: always stripped

Receive 7 bits/char:

bits 0 - 6:	data
bit 7:	always zero (parity bit is always stripped)

Receive 6 bits/char:

bits 0 - 5:	data
bit 6:	parity bit or, if no parity defined, is always 1
bit 7:	always 0

Receive 5 bits/char:

bits 0 - 4:	data
bit 5:	parity bit or, if no parity defined, is always 1
bit 6:	always 1
bit 7:	always 0

Character Insertion/Deletion: To support the broadest range of devices the HP 12792B may be configured to completely pass all user data in both directions. Character handshakes required by devices may be inserted or deleted from the user data with a user-written device driver. Devices using hardware handshaking between the multiplexer card and the device are not supported. XON/XOFF protocol and transmit handshaking controlled by the device (rather than the interface) are not supported.

Additionally, the interface driver/card has the capability to perform the following character-oriented functions when configured by control requests:

TRANSMIT: Send ENQ (ASCII 5) and wait 5 seconds for an ACK (ASCII 6) response after every 80 characters.

Add a CR LF after each record or, if the last character is an underscore, delete the underscore and don't add CR LF.

RECEIVE: End transfer on, and strip one or more of the following: CR, RS, EOT and DC2. Or, end transfer on count and strip nothing.

On BS, strip the BS and delete the last character entered.

On DEL, strip the DEL and delete all characters previously entered in the record, restarting the record.

Echo all characters received and, on CR or DEL, echo CR LF.

Interface Driver With/Without User Written Device Driver

The HP 12792B Multiplexer Subsystem will support any RS-232-C or RS-423-A asynchronous bit-serial character-mode device whose interface characteristics are compatible with the Electrical, Line Speed, and User Data Reproduction sections of the preceding Interface Support Definition. The user may be required to write a device driver for the device in order to obtain this support.

Interface Driver With DDV05

The HP-supplied device driver DDV05 supports character and block mode operation with the following HP terminals:

2621A/P	2640B
2645A	2647A
2648A	2649B/C/G
2626A	

DDV05 provides no support for EQT subchannels. This includes cartridge tape units, printers, etc.. A separate LU is required for a serial line printer, in which case it may be connected directly to the MUX via either DDV12 or a user-written device driver.

Interface Driver With DDV12

The HP-supplied DDV12 device driver supports write-only with optional lineprinter-like column one carriage control on the following HP devices:

2631A/B
2635A/B
7310

For more information on HP-supplied device drivers, refer to Appendix B of the multiplexer users manual.

Other HP Subsystems

Support of non-HP terminals and devices by the HP 12792B Multiplexer Subsystem does not imply support of the devices by other HP systems or subsystems communicating with these devices through the HP 12792B. Consult the specific subsystem documentation for devices supported by that subsystem.

Modems

The MUX will passively support asynchronous, full duplex modems. Passive support means the MUX does not recognize or supply any modem control or status lines. The RS-232-C connectors on the HP 12828A have modem "clear to send" connected back to "request to send" and "carrier detect" wired back to "data terminal ready." ("Data set ready" is pulled to +12v through a 1k ohm resistor for those terminals that require it.) Use of the HP 12828A or connectors similar to these allow the passive support of modems. The user should be aware that "line loss" or other "modem not ready" problems cannot be detected by the MUX or user software through the MUX.

When using modems be aware that if the modem line (with auto answer) is disconnected, no provision is available to detect the condition. If the user was logged on under an RTE-IVB or RTE-6/VM session and the line is disconnected before the user logs off, anyone dialing in to that port will be re-connected to the session in progress at the time of the previous disconnect.

If the user wishes to have full modem capability, the HP 37214A Systems Modem subsystem should be used in place of the 12828A Multiplexer Panel. The system modem subsystem consists of the HP 37214A Card Cage having 8-slots to hold a modem controller card and seven optional cards as follows: the HP 37213A Modem Card, the HP External Modem Card (37215A), and the HP 37216A Terminal Interface Card. The modem card is compatible with Bell 212 and 103 modems. If your configuration will be communicating via telephone lines, the modem controller card (supplied with the 37214A) must always be plugged into port 7, and one modem card for each telephone line must be inserted into any of the other slots. Thus, it is possible to have up to seven modem lines (since one slot is taken by the modem controller card).

If the user supplied modems are to be used, they can be connected to the MUX either through the external modem cards or through terminal interface cards in the systems modem panel if terminal connections are desired.

Any combination of modem cards, external modem cards, or terminal interface cards (up to seven) can be included. If only terminal interface cards are installed, port 7 can also be used for a terminal interface card so that all eight ports contain terminal interface cards. However, if one or more modem cards (including the external modem card) is used, then the modem controller card must be inserted into port 7. Refer to the Systems Modem Installation Operating and Service Manual, part no. 37214-90000 for more information.

Chapter 3

System Generation

The following paragraphs outline the recommended procedure for generating the HP 12792B Multiplexer into an RTE Operating System. Examples of input at each of the relevant phases is shown. An example listing of the relevant generation phases is shown in Appendix A.

General Considerations

The generation of the HP 12792B multiplexer driver software into RTE is very similar to that of other terminal drivers. Each multiplexer card may be assigned up to eight EQTs (one EQT per port). Each EQT to be used with this driver is assigned to an interface card at generation time by the select code designated when EQTs are specified. Any EQT associated with a particular interface card can be used for any port on that card, but EQTs cannot be moved from one card to another after generation.

The size of an extent assigned to an EQT is determined by adding the size required by the interface driver (17 words) to the largest of the extents required by any device drivers attached to that EQT. The HP-supplied device drivers both require four word extents, so when using only HP-supplied software the extent size would be $17 + 4 = 21$ words.

A Device Reference Table (DRT) entry must be generated for each logical unit (LU) to be used. A different LU number must be assigned to each individual terminal or device.

On system boot-up, the WELCOM file should contain control requests needed to initialize the ports. It is at this time that the association between LU (and its EQT), and physical port (device) is made. The WELCOM file contents are covered in Chapter 4 (Initialization).

In the following examples the step numbers referred to in each phase refer to the steps in Section 2 of the RTE-IVB or RTE-6/VM On-Line Generator Reference Manual (part nos. 92068-90007 and 92084-90010, respectively).

Initialization Phase

Since the HP 12792B multiplexer driver is not privileged (as opposed to the HP 12920B multiplexer product), nothing related to the MUX needs to be done in this phase.

Program Input Phase

Step 16C (refer to the applicable On-Line Generator Reference Manual) specifies the modules to be relocated by their relocatable file names with optional security code and disc cartridge specification. Relocate %DVM00, %PVM00, %\$DVTB, and all HP- and User-supplied device drivers to be included. Refer to Figure 3-1 which shows the HP-supplied software to be relocated.

- 16c) Enter the RELOCATE commands (with optional MAP, LINKS IN, and DISPLAY commands)

REL	, %DVM00	_____	_____	_____	(REL [(name)],filename [:sc [: cartridge label]])
REL	, %PVM00	_____	_____	_____	(RT4GN responds with a — after each user input)
REL	, %DDV05	_____	_____	_____	
REL	, %DDV12	_____	_____	_____	
REL	, %\$DVTB	_____	_____	_____	

Figure 3-1. Relocating HP-Supplied Software.

Parameter Input Phase

In step 17 the user is required to change the program type of module PWM00 to 13. This forces PWM00 to reside in Table Area II. Refer to Figure 3-2.

Parameter Input Phase	(modify type, priority, and execution interval, or the ENT (entry record of any of the programs specified during the Program Input Phase)
(17) PARAMETERS	(output by generator at start of Parameter Input Phase)
-	(generator prompt)
PWM00,13	(name, Type [,priority [,execution interval]])
-	
-	(terminate your final entry with a /E)
-	

Figure 3-2. Changing PWM00 Parameter.

Table Generation Phase

Equipment Table Entries

In step 19, the user specifies the EQT entries for the multiplexer. All EQTs associated with devices on one interface card use that card's select code number. Each EQT may specify buffering (B), and should have an EQT extent as described at the beginning of this chapter (17 + largest extent required by device drivers). When using only HP-supplied device drivers, the extent will be 21. A timeout value may optionally be specified. Do not specify DMA usage ("D" option). Refer to Figure 3-3. Note that EQTs shown here are contiguous, but they need not be. Also, "SC" refers to the code of the multiplexer card.

(19) EQUIPMENT TABLE ENTRY

EQT XX?

SC, DVMØØ, B, X=21, T=32767, _____, _____, _____
(oct. select code,
driver [B] [D]
[S] [M] [T = tttt]
[X = xxx])

EQT XX+1?

SC, DVMØØ, B, X=21, T=32767, _____, _____, _____
(do not specify SDA
for system disc
driver)

EQT XX+2?

SC, DVMØØ, B, X=21, T=32767, _____, _____, _____
(terminate your
final entry with a /E)

EQT XX+3?

SC, DVMØØ, B, X=21, T=32767, _____, _____, _____

EQT XX+4?

SC, DVMØØ, B, X=21, T=32767, _____, _____, _____

EQT XX+5?

SC, DVMØØ, B, X=21, T=32767, _____, _____, _____

EQT XX+6?

SC, DVMØØ, B, X=21, T=32767, _____, _____, _____

EQT XX+7?

SC, DVMØØ, B, X=21, T=32767, _____, _____, _____

Figure 3-3. Equipment Table Entries

Device Reference Table Entries

Step 20 specifies the Device Reference Table (DRT) entries for the MUX. There should be one entry for each port utilized by a terminal or device.

Each entry in the DRT is the EQT number of the equipment table entry for a port. The DRT entries are in LU number order. The terminal on that port will be referred to by the LU number of the current DRT entry.

No support is provided for EQT subchannels in the HP-supplied device drivers or interface drivers (these drivers will ignore any subchannel specification although for compatibility with future products it should be set to zero). This includes cartridge tape units, printers, etc.. Users may write their own device drivers which will use EQT subchannels. Refer to Chapter 4 of the multiplexer users manual (part no. 5955-8867) covering Device Driver Writing.

Refer to Figure 3-4 for the format of DRT entries, where XX refers to the EQT number and YY refers to the LU number. Note that these entries are sequential, but need not be.

20	DEVICE REFERENCE TABLE
YY = EQT # ?	<u>XX</u> , _____
YY+1 = EQT # ?	<u>XX+1</u> , _____
YY+2 = EQT # ?	<u>XX+2</u> , _____
YY+3 = EQT # ?	<u>XX+3</u> , _____
YY+4 = EQT # ?	<u>XX+4</u> , _____
YY+5 = EQT # ?	<u>XX+5</u> , _____
YY+6 = EQT # ?	<u>XX+6</u> , _____
YY+7 = EQT # ?	<u>XX+7</u> , _____

Figure 3-4. DRT Entries For The MUX.

Interrupt Table Entries

Step 21 specifies the interrupt table entries for the HP 12792B Multiplexer. One entry is required for each interface card generated into the system. On systems using up to eight terminals, on the MUX, users will want to specify:

SC, PRG, PRMPT

to enable scheduling of PRMPT on unsolicited interrupts. Unsolicited interrupts are caused by striking a key on a terminal which does not have a read request pending on it. If a user-written program is to be scheduled upon receipt of an unsolicited interrupt, include that program's name in place of PRMPT. Note that the program specified is used for all channels on that card unless overridden on-line via a user request. If unsolicited interrupts are to be ignored, use:

sc, EQT, eqt#

where sc is the select code of the card and eqt# is the number of any one of the EQT's specified for that card. This will still allow communication with each port's EQT the only effect it has is to ignore unsolicited interrupts. This can be overridden via an on-line request.

Refer to your operating system's On-Line Generator Reference Manual for more details. Figure 3-5 shows the entry used when devices are connected to the MUX.

Figure 3-5. Interrupt Table Entries.

Partition Definition Phase — System Available Memory

Step 33 allows the system manager to increase the size of System Available Memory (SAM) by moving the starting page of the first user partition to a higher location in memory.

The system manager should keep in mind that since terminals on the MUX may be buffered, SAM will be required for programs to communicate with terminals. If there is not enough SAM, programs communicating with terminals may be suspended waiting for System Available Memory.

Chapter 4

Initialization

Initialization of the HP 12792B Multiplexer Subsystem is typically performed at boot-up in the WELCOM file by a sequence of control requests. Three requests are performed on each port:

```
control 30B: Set port ID  
control 33B: Configure driver responses, if needed  
control 20B: Enable schedule, if needed  
              (schedule a program on  
              unsolicited interrupts)
```

These control functions must be given in the above order, and are defined in detail in the multiplexer users manual part no. 5955-8867.

The HP 12792B multiplexer interface card contains two baud rate generators. When employing the HP 12828A Multiplexer Panel with the standard cable, baud rate generator 0 (BRG0) is wired to port 0, and baud rate generator 1 (BRG1) is wired to ports 1-7. Typically, the printer port is port 0 (running at, say, 2400 baud) while the other seven ports are terminals running at 9600 baud. Note that these two baud rate generators can be split in other ways (2 or 3 or 4 ports on one baud rate generator and the rest on the other). Refer to the HP 12792B Multiplexer Subsystem Installation and Reference Manual for more information.

It is important to remember that devices must be configured to agree with the values specified in the control 30B request in the WELCOM file. For example, for a HP 7310 line printer, the switches on the back of it should be set for the baud rate and parity option at which it is to be used. All other switches should be in their normal positions.

Using the Default Device Driver

All ports must be associated with a device driver. For devices which do not require request processing beyond what the interface driver performs, a defaultdevice driver is included as part of the interface driver. Upon being sent a request by the interface driver, the default device driver simply passes the request back to the interface driver without performing any processing on the request.

The default device driver is selected by specifying device driver number one when issuing a control 33B request.

Enabling a DDV12 Device

The following could be used to initialize a line printer attached to port 0:

```
:CN,lu,30B,142310B      * Port 0, 2400 baud, ENQ/ACK enabled, no parity,  
                         1 stop bit, BRG 0, 8 bits char.  
  
:CN,lu,33B,2            * Attach device driver number 2, DDV12 (in the  
                         HP-supplied $DVTB, DDV12 is device driver  
                         number 2).  
  
:CN,lu,21B              * Disable schedule (see below).
```

The last request (control 21B, disable schedule) is included so that the device driver is entered before any user request is given. This gives the driver a chance to set the port's driver type to 12B in case a user inquires driver type before any other request is given. Any reasonable control request may be given 21B was chosen since it also ensures that extraneous noise will not cause program scheduling.

Note that a control 20B is not used for a line printer since there will be no read requests or unsolicited interrupts from the printer.

As with all devices, when using an HP 7310line printer, an HP 2631 terminal, or an HP 2635 terminal, be sure the switches are set for whatever baud rate and parity option is to be used. These must agree with the values specified using the control 30B request in the WELCOM file.

Enabling a DDV05 Device

The control requests that could be used to initialize a terminal port are shown below. Typically these are running off of baud rate generator one (BRG1).

```
:CN,lu,30B,152334B      * Port 4, 9600 baud, ENQ/ACK enabled, no parity,  
                         1 stop bit, BRG 1, 8 bits per character.  
  
:CN,lu,33B,3            * Attach device driver 3, DDV05 (in the  
                         HP-supplied $DVTB, DDV05 is device driver 3).  
  
:CN,lu,20B              * Enable scheduling (schedule program on unsolicited interrupt).
```

Be sure that the terminal strapping configuration switches agree with the commands given in the control request. Refer to the appropriate terminal/device instruction manual.

Example

The following is a sample part of a WELCOM file which initializes each port to 9600 baud, no parity, one stop bit, ENQ/ACK handshake enabled, attaches device driver 3 (the 26XX screen mode terminal device driver), and puts the port in type-ahead mode with cancel on break. Port 7 on the second card is configured for an HP 7310 line printer (device driver 2). Note that the default (hardwired) baud rate configuration is used (port 0 uses baud rate generator 0, ports 1-7 use baud rate generator 1). With the HP 12828A Multiplexer Panel, port 0 uses BRG0 and ports 1-7 use BRG1 unless the user modifies the hood connector.

```
/*
 * SET PORT ID'S ON CARD 1
 */
:CN,19,30B,142330B
:CN,20,30B,152331B
:CN,21,30B,152332B
:CN,22,30B,152333B
:CN,23,30B,152334B
:CN,24,30B,152335B
:CN,25,30B,152336B
:CN,26,30B,152337B
/*
 * SET PORT ID'S ON CARD 2
 */
:CN,27,30B,142330B
:CN,28,30B,152331B
:CN,29,30B,152332B
:CN,30,30B,152333B
:CN,31,30B,152334B
:CN,32,30B,152335B
:CN,33,30B,152336B
:CN,34,30B,152337B
/*
 * CONFIGURE DRIVER RESPONSES ON ALL PORTS
 */
:CN,19,33B,23003B
:CN,20,33B,23003B
.
.
```

```
        .
etc
        .
        .
        .
:CN, 33, 33B, 23003B
:CN, 34, 33B, 2
:*
:*
:ENABLE SCHEDULING ON ALL PORTS
:*
:CN, 19, 20B
:CN, 20, 20B
        .
        .
        .
etc
        .
        .
        .
:CN, 33, 20B
:CN, 34, 21B
```

Chapter 5

Troubleshooting

When your system has been generated, booted up, and the multiplexer terminals are initialized according to the instructions in the preceding sections of this manual, your multiplexer terminals should respond to pressing of any key in a manner similar to that of any DVR05 or DVR00 terminal. If a multiplexer terminal fails to respond properly, the following checklist may help to correct the problem.

- o Verify that the baud rate of the terminal matches the baud rate expected by the software.
- o Verify that the Baud Rate Generator specified for each port during initialization agrees with the BRG strapped for that port on the edge connector.
- o If one port is not working, verify that the baud rate for the BRG on the port has not been changed. This could have happened by changing the baud rate of another port using the same BRG.
- o Check that the terminal strap switches are set according to the terminal instruction manual.
- o Verify that the cables are connected properly according to the HP 12792B Multiplexer Subsystem Installation and Reference Manual and the terminal and/or modem instruction manual.
- o Verify that the MUX board is in the appropriate select code.
- o Verify that PWM00 was set to type 13 in the parameter input phase of the system generation.
- o Check power-up echo. The card "comes up" in a state where it echoes everything that comes in and sends CR LF on CR. Rubout echoes CR LF. The default (power-up) baud rates are 2400 baud for BRG0 and 9600 baud for BRG1. If the terminal is attached to port 0, set the baud rate to 2400 and check to see if it echoes (set terminals connected to BRG1 to 9600 baud). This verifies that the card, terminal, and cable are operating. If this doesn't work, try the other seven terminals to determine if it is the cable or terminal.
- o Run the on-line or off-line diagnostics. Refer to the HP 12792B Multiplexer Subsystem Installation and Reference Manual for a detailed explanation.

Appendix A

Partial Sample System Generation

Below is listed some relevant sections of a system generation listing which includes the HP 12792B Multiplexer. Some irrelevant portions have been omitted due to space considerations.

RTE-6/VM GENERATOR MODEL 92084A 1:56 PM, 19 NOV., 1982

ECHO?
YES * ECHO ON

OUTPUT FILE NAMR?
MXENSY::50::3500 * 800819

.

.

.

PRIV. INT. SELECT CODE?
0 * NO PRIV. INT.

MEM. RES. ACCESS TABLE AREA II?
YES * MR ACCESS TA II

RT MEMORY LOCK?
YES * RT MEMORY LOCK

BG MEMORY LOCK?
YES * BG MEMORY LOCK

SWAP DELAY?
50 * SWAP DELAY

MEM SIZE?
96 * MEM SIZE

BOOT FILE NAMR?
0 * NO BOOT FILE

PROG INPUT PHASE:

-
MAP GLOBALS, MODULES, LINKS

-
LINKS IN CURRENT

.
. .
*
-
REL, %DVM00 * MUX DRIVER
-
REL, %PVM00 * MUX PRE-DRIVER
-
REL, %DDV05 * 26XX DEVICE DRIVER
-
REL, %DDV12 * DEVICE DRIVER FOR 7310 LINE PRINTER
-
REL, %\$DVTB * DEVICE DRIVER ADDRESS TABLE
-
*
-
*
-
. . .

PARAMETERS

-
D.RTR, 3, 1
-
WHz AT, 3, 51
-
PRMPT, 1, 10
-
R\$PN\$, 1, 10
-
MEM, 1, 9000
-

.
. .

AUTOR, 1, 1

-
PVM00, 13
-
/E

CHANGE ENTS?

-

.MW, RP, 105777
-
.MBT, RP, 105765
-
.LBT, RP, 105763
-

.

.

.

IFIX, RP, 105100
-
FLOAT, RP, 105120
-
/E

TABLE AREA I <<PAGE 00001>>:

EQUIPMENT TABLE ENTRY

EQT 01?

.

.

.

EQT 06?

13, DVM00, B, X=21 * EQT 6 - MUX PORT

EQT 07?

13, DVM00, B, X=21 * EQT 7 - MUX PORT

EQT 08?

13, DVM00, B, X=21 * EQT 8 - MUX PORT

EQT 09?

13, DVM00, B, X=21 * EQT 9 - MUX PORT

EQT 10?

13, DVM00, B, X=21 * EQT 10 - MUX PORT

EQT 11?

13, DVM00, B, X=21 * EQT 11 - MUX PORT

EQT 12?

13, DVM00, B, X=21 * EQT 12 - MUX PORT

EQT 13?

13, DVM00, B, X=21

* EQT 13 - MUX PORT

EQT 14?
/E

DEVICE REFERENCE TABLE

001 = EQT #?
2,0 * LU 1 - CONSOLE
.
. .
012 = EQT #?
6 * LU 12 - MUX PORT
013 = EQT #?
7 * LU 13 - MUX PORT
014 = EQT #?
8 * LU 14 - MUX PORT
015 = EQT #?
9 * LU 15 - MUX PORT
016 = EQT #?
10 * LU 16 - MUX PORT
017 = EQT #?
11 * LU 17 - MUX PORT
018 = EQT #?
12 * LU 18 - MUX PORT
019 = EQT #?
13 * LU 19 - MUX PORT
020 = EQT #?
/E

INTERRUPT TABLE

-	4, ENT, \$POWR	* POWER FAIL
-		
	.	
	.	
	.	
	13, PRG, PRMPT	* MUX
-		
	.	
	.	
	.	
	17, PRG, PRMPT	* D VR 05
-		
/E		

TABLE AREA I MODULES

\$\$TB1(0099)03011 03152 92084-1X481 REV. 2121 810613
*\$ERAB 03021
*\$PVCN 03023
*\$EXEC 03013
*\$XLUEX 03016
*\$LIBR 03025
*\$LIBX 03032
*\$PVST 03024

.

.

.

DRIVR PART 00002
CHANGE DRIVR PART?
2 * CHANGE DP SIZE

DP 01 <<PAGE 00005>>:

.

.

.

.

.

.

SUBSYSTEM GLOBAL AREA <<PAGE 00007>>:

.

.

.

TABLE AREA II <<PAGE 00010>>:

OF I/O CLASSES?
40 * # OF I/O CLASSES

OF LU MAPPINGS?
5 * # OF LU MAPPINGS

OF RESOURCE NUMBERS?
30 * # OF RESOURCE NUMBERS

BUFFER LIMITS (LOW, HIGH)?
100,400 * BUFFER LIMITS

0024 LONG ID SEGMENTS USED
OF BLANK LONG ID SEGMENTS?
50 * # OF BLANK ID SEGMENTS

0012 SHORT ID SEGMENTS USED
OF BLANK SHORT ID SEGMENTS?
41 * # OF BLANK SHORT ID SEGMENTS

0000 ID EXTENSIONS USED
OF BLANK ID EXTENSIONS?
5 * # OF BLANK ID EXTENSIONS

MAXIMUM # OF PARTITIONS?
20 * MAX NUMBER OF PARTITIONS

TABLE AREA II MODULES

\$\$TB2(0099)33547 33653 92084-1X482 REV. 2121 810519

*\$MATA 33547
*\$MCHN 33550
*\$MBGP 33551
*\$MRTP 33552
*\$DLTH 33553
*\$DVPT 33554
*\$TIME 33555
*\$BATM 33560

*\$DLP 33562
*\$PLP 33563
*\$SSCT 33602
*\$STRK 33601
*\$ENDS 33564
*\$MPFT 33567
*\$BGR 33570
*\$RTFR 33571
*\$IDEX 33572
*\$MRMP 33573
*\$MPS2 33575
*\$EMRP 33607
*\$MPSA 33574
*\$SDA 33576
*\$SDT2 33577
*\$CMST 33600
*\$COML 33603
*\$CFR 33604
*\$MNP 33605
*\$DVMP 33606
*\$RLB 33610
*\$RLN 33611
*\$SBTB 33612
*\$OTAT 33565
*\$OPRI 33566
*\$SPCR 33620
*\$ELTB 33621
*\$PNTI 33631
*\$MAXI 33632
*\$SALI 33633
*\$SRTI 33634
*\$CES 33652
*\$LMES 33637
*\$SMEM 33635
BP LINKAGE 01420

PVM00(0099)33654 33765 12792-16001 REV. 2032 800605 V. 03
*PM00 33654
BP LINKAGE 01420

\$SUB2(0099)33766 33766 92084-1X052 REV. 2226 820302

S Y S T E M <<PAGE 00013>>:

\$C R61(0099)33767 33766 92084-12024 REV. 2226 820504
BP LINKAGE 00100

DISP6(0099)33770 41521 92084-1X471 REV. 2121 811218
*\$RENT 34617
*\$BRED 41222
*\$ZZZ 41322

.

.

.

*\$NPGQ 70004
*\$GDPG 72565
*\$SAVE 65335
BP LINKAGE 01322

PARTITION DRIVERS

DP 02 <<PAGE 00030>>:

DVA05(0099)12102 15164 92084-16607 REV. CODE 2121 811020
*IA05 12102
*CA05 12200
BP LINKAGE 01367

DP 03 <<PAGE 00032>>:

DVM00(0099)12056 14566 12792-16002 REV. 2301 821007 V. 38
*IM00 12117
*CM00 12255
BP LINKAGE 01357
\$DVTB 14636 14640 12792-16005 REV. 2226 820413 V. 06
*\$DVTB 14636
BP LINKAGE 01356
DDV05 14641 15174 12792-16003 REV. 2301 820630 V. 04
*DDV05 14654
BP LINKAGE 01356
DDV12 15175 15430 12792-16004 REV. 2140 810821 V. 09
*DDV12 15206
BP LINKAGE 01356

DP 04 <<PAGE 00034>>:

.

.

.

Index

%\$DVTB module size, 2-1
enabling a device on, 4-2
module size, 2-1
%DDV05 support of, 2-5
%DDV12 enabling a device on, 4-2
module size, 2-1
support of, 2-5
%DVM00 module size, 2-1
%PVM00 module size, 2-1

B

Baud rates supported, 2-3

C

Character
insertion/deletion, 2-4
insertion/deletion interface support definition, 2-4

D

DDV05 enabling a device on, 4-2
module size, 2-1
support of, 2-5
DDV12 enabling a device on, 4-2
module size, 2-1
support of, 2-5
Default
device driver, 4-1
device driver specifying, 4-1
Device
characteristics, 2-4
characteristics hardware handshaking, 2-4
drivers general description, 2-2
reference table, 3-4
reference table system generation, 3-4

E

EQT
extent size, 3-1, 3-3
extent size specifying at system generation, 3-1, 3-3

Equipment

table entries, 3-3
table entries system generation, 3-3

G**Generation of system**

device reference table, 3-4
EQT extent size, 3-1
equipment table entries, 3-3
general considerations, 3-1
initialization phase, 3-2
interrupt table, 3-6
parameter input phase, 3-3
program input phase, 3-2
SAM considerations, 3-7
table generation phase, 3-3

H**Hardware handshaking, 2-4****I****Initialization of devices**

example, 4-3
in WELCOM file, 4-1

Initialization phase

system generation, 3-2

Interface driver

support of, 2-5
support with DDV05, 2-5
support with DDV12, 2-5

Interface support definition

character insertion/deletion, 2-4
electrical, 2-3
line speeds, 2-3
user data reproduction, 2-3

Interrupt table

table system generation, 3-6

M**Modems**

support of, 2-6

Modules

approximate size, 2-1
provided with 12792B product, 2-1

P

Parameter input phase
 system generation, 3-3
Parity bit
 bit description of interface processing, 2-3
Power-up echo
 and troubleshooting, 5-1
Program input phase
 system generation, 3-2

S

SAM considerations during system generation, 3-7
Size of 12792B software modules, 2-1
Software modules
 approximate sizes, 2-1
 provided with 12792B product, 2-1

Support definitions
 electrical, 2-3
 line speeds, 2-3
 user data reproduction, 2-3
Supported
 baud rates, 2-3
 devices, 2-3
System generation
 device reference table, 3-4
 EQT extent size, 3-1
 equipment table entries, 3-3
 general considerations, 3-1
 initialization phase, 3-2
 interrupt table, 3-6
 parameter input phase, 3-3
 program input phase, 3-2
 SAM considerations, 3-7
 table generation phase, 3-3

T

Table
 generation phase, 3-3
 generation phase system generation, 3-3
Terminals supported, 2-5
Transmit handshaking, 2-4
Troubleshooting, 5-1

U

Undefined externals
when using HP-supplied \$DVTB, 2-2
User data processing on interface, 2-3
User data reproduction
interface support definition, 2-3

W

WELCOM file
example, 4-3
requests performed in, 4-1

X

XON/XOFF protocol, 2-4

READER COMMENT SHEET

12792B MULTIPLEXER SUBSYSTEM Configuration Guide

5955-8868

January 1983

**Update No. _____
(If Applicable)**

We welcome your evaluation of this manual. Your comments and suggestions help us improve our publications.
Please use additional pages if necessary.

FROM:

Name _____

Company _____

Address _____


Phone No. _____ **Ext.** _____

FOLD

FOLD



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

A series of twelve thick horizontal black bars, used for postal sorting, positioned below the FIM bar.

BUSINESS REPLY MAIL

FIRST CLASS PERMIT NO. 141 CUPERTINO, CA.

— POSTAGE WILL BE PAID BY —

Hewlett-Packard Company
Data Systems Division
11000 Wolfe Road
Cupertino, California 95014
ATTN: Technical Publications

FOLD

FOLD

SALES & SUPPORT OFFICES

Arranged alphabetically by country

1



Product Line Sales / Support Key

Key Product Line
A Analytical
CM Components
C Computer Systems Sales only
CH Computer Systems Hardware Sales and Services
CS Computer Systems Software Sales and Services
E Electronic Instruments & Measurement Systems
M Medical Products
MP Medical Products Primary SRO
MS Medical Products Secondary SRO
P Personal Computation Products
 · Sales only for specific product line
 ** Support only for specific product line

IMPORTANT: These symbols designate general product line capability. They do not insure sales or support availability for all products within a line, at all locations. Contact your local sales office for information regarding locations where HP support is available for specific products.

HP distributors are printed in italics.

HEADQUARTERS OFFICES

If there is no sales office listed for your area, contact one of these headquarters offices.

NORTH/CENTRAL AFRICA

Hewlett-Packard S.A.
 7, Rue du Bois-du-Lan
CH-1217 MEYRIN 2, Switzerland
 Tel: (022) 83 12 12
 Telex: 27835 hpse
 Cable: HEWPACKSA Geneve

ASIA

Hewlett-Packard Asia Ltd.
 6th Floor, Sun Hung Kai Centre
 30 Harbour Rd.
 G.P.O. Box 795
HONG KONG
 Tel: 5-832 3211
After Jan. 1, 1984
 47th Floor, China Resources Bldg.
 26 Harbour Rd., Wanchai
HONG KONG
 Telex: 66678 HEWPA HX
 Cable: HEWPACK HONG KONG

CANADA

Hewlett-Packard (Canada) Ltd.
 6877 Goreway Drive
MISSISSAUGA, Ontario L4V 1M8
 Tel: (416) 678-9430
 Telex: 610-492-4246

EASTERN EUROPE

Hewlett-Packard Ges.m.b.h.
 Lieblgasse 1
 P.O.Box 72
 A-1222 VIENNA, Austria
 Tel: (222) 2365110
 Telex: 1 3 4425 HEPA A

NORTHERN EUROPE

Hewlett-Packard S.A.
 Uilenstede 475
 P.O.Box 999
NL-1180 AZ AMSTELVEEN
 The Netherlands
 Tel: 20 437771

SOUTH EAST EUROPE

Hewlett-Packard S.A.
 7, Rue du Bois-du-Lan
CH-1217 MEYRIN 2, Switzerland
 Tel: (022) 83 12 12
 Telex: 27835 hpse
 Cable: HEWPACKSA Geneve

OTHER EUROPE

Hewlett-Packard S.A.
 P.O. Box
 150, Rte du Nant-D'Avril
CH-1217 MEYRIN 2, Switzerland
 Tel: (022) 83 8111
 Telex: 22486 hpsa
 Cable: HEWPACKSA Geneve

MEDITERRANEAN AND MIDDLE EAST

Hewlett-Packard S.A.
 Mediterranean and Middle East
 Operations
 Atrina Centre
 32 Kifissias Ave.
 Paradissos-Amarousion, ATHENS
 Greece
 Tel: 682 88 11
 Telex: 21-6588 HPAT GR
 Cable: HEWPACKSA Athens

EASTERN USA

Hewlett-Packard Co.
 4 Choke Cherry Road
ROCKVILLE, MD 20850
 Tel: (301) 258-2000

MIDWESTERN USA

Hewlett-Packard Co.
 5201 Tollview Drive
ROLLING MEADOWS, IL 60008
 Tel: (312) 255-9800

SOUTHERN USA

Hewlett-Packard Co.
 2000 South Park Place
 P.O. Box 105005
ATLANTA, GA 30348
 Tel: (404) 955-1500

WESTERN USA

Hewlett-Packard Co.
 3939 Lankershim Blvd.
 P.O. Box 3919
LOS ANGELES, CA 91604
 Tel: (213) 506-3700

OTHER INTERNATIONAL AREAS

Hewlett-Packard Co.
 Intercontinental Headquarters
 3495 Deer Creek Road
PALO ALTO, CA 94304
 Tel: (415) 857-1501
 Telex: 034-8300
 Cable: HEWPACK

ANGOLA

Telecra
Empresa Técnica de Equipamentos
R. Barbosa Rodrigues, 41-I DT.
Caixa Postal 6487
LUANDA
Tel: 355 15,355 16
E,P

ARGENTINA

Hewlett-Packard Argentina S.A.
 Avenida Santa Fe 2035
Martinez 1640 BUENOS AIRES
 Tel: 798-5735, 792-1293
 Telex: 17595 BIONAR
 Cable: HEWPACKARG
 A,E,CH,CS,P
Biotron S.A.C.I.M. e I.
Av Paseo Colon 221, Piso 9
1399 BUENOS AIRES
Tel: 30-4846, 30-1851
Telex: 17595 BIONAR
M

AUSTRALIA

Adelaide, South Australia Office

Hewlett-Packard Australia Ltd.
 153 Greenhill Road
PARKSIDE, S.A. 5063
 Tel: 272-5911
 Telex: 82536
 Cable: HEWPARD Adelaide
 A*,CH,CM,,E,MS,P

Brisbane, Queensland Office

Hewlett-Packard Australia Ltd.
 10 Payne Road
THE GAP, Queensland 4061
 Tel: 30-4133
 Telex: 42133
 Cable: HEWPARD Brisbane
 A,CH,CM,E,M,P

Canberra, Australia Capital Territory Office

Hewlett-Packard Australia Ltd.
 121 Wollongong Street
FYSHWICK, A.C.T. 2609
 Tel: 80 4244
 Telex: 62650
 Cable: HEWPARD Canberra
 CH,CM,E,P

Melbourne, Victoria Office

Hewlett-Packard Australia Ltd.
 31-41 Joseph Street
BLACKBURN, Victoria 3130
 Tel: 895-2895

Telex: 31-024
 Cable: HEWPARD Melbourne
 A,CH,CM,OS,E,MS,P

Perth, Western Australia Office

Hewlett-Packard Australia Ltd.
 261 Stirling Highway
CLAREMONT, W.A. 6010
 Tel: 383-2188
 Telex: 93859
 Cable: HEWPARD Perth
 A,CH,CM,E,MS,P

Sydney, New South Wales Office

Hewlett-Packard Australia Ltd.
 17-23 Talavera Road
 P.O. Box 308
NORTH RYDE, N.S.W. 2113
 Tel: 887-1611
 Telex: 21561
 Cable: HEWPARD Sydney
 A,CH,CM,CS,E,MS,P

AUSTRIA

Hewlett-Packard Ges.m.b.h.
 Grottenhofstrasse 94
A-8052 GRAZ
 Tel: (0316) 291 5 66
 Telex: 32375
 CH,E
 Hewlett-Packard Ges.m.b.h.
 Lieblgasse 1
 P.O. Box 72
A-1222 VIENNA
 Tel: (0222) 23 65 11-0
 Telex: 134425 HEPA A
 A,CH,CM,CS,E,MS,P

BAHRAIN

Green Salon
 P.O. Box 557
 Manama
BAHRAIN
 Tel: 255503-255950
 Telex: 84419
 P

Wael Pharmacy

P.O. Box 648

BAHRAIN
 Tel: 256123
 Telex: 8550 WAEL BN
 E,C,M

BELGIUM

Hewlett-Packard Belgium S.A./N.V.
 Blvd de la Woluwe, 100
 Woluwedal
B-1200 BRUSSELS
 Tel: (02) 762-32-00
 Telex: 23-494 palaben bru
 A,CH,CM,CS,E,MP,P

BRAZIL

Hewlett-Packard do Brasil I.e.C. Ltda.
 Alameda Rio Negro, 750
 Alphaville
06400 BARUERI SP
 Tel: (011) 421.1311
 Telex: (011) 33872 HPBR-BR
 Cable: HEWPACK Sao Paulo
 A,CH,CM,CS,E,M,P
 Hewlett-Packard do Brasil I.e.C. Ltda.
 Avenida Epitacio Pessoa, 4664
22471 RIO DE JANEIRO-RJ
 Tel: (021) 286.0237
 Telex: 021-21905 HPBR-BR
 Cable: HEWPACK Rio de Janeiro
 A,CH,CM,E,MS,P*

ANAMED I.C.E.I. Ltda.

Rua Bage, 103
04012 SAO PAULO
 Tel: (011) 570-5726
 Telex: 021-21905 HPBR-BR
 M



SALES & SUPPORT OFFICES

Arranged alphabetically by country

CANADA

Alberta

Hewlett-Packard (Canada) Ltd.
3030 3rd Avenue N.E.
CALGARY, Alberta T2A 6T7
Tel: (403) 235-3100
A,CH,CM,E*,MS,P*

Hewlett-Packard (Canada) Ltd.
11120A-178th Street
EDMONTON, Alberta T5S 1P2
Tel: (403) 486-6666
A,CH,CM,CS,E,MS,P

British Columbia

Hewlett-Packard (Canada) Ltd.
10691 Shellbridge Way

RICHMOND,
British Columbia V6X 2W7
Tel: (604) 270-2277
Telex: 610-922-5059
A,CH,CM,CS,E*,MS,P*

Manitoba

Hewlett-Packard (Canada) Ltd.
380-550 Century Street
WINNIPEG, Manitoba R3H 0Y1
Tel: (204) 786-6701
A,CH,CM,E,MS,P*

Nova Scotia

Hewlett-Packard (Canada) Ltd.
P.O. Box 931
900 Windmill Road
DARTMOUTH, Nova Scotia B2Y 3Z6
Tel: (902) 469-7820
CH,CM,CS,E*,MS,P*

Ontario

Hewlett-Packard (Canada) Ltd.
3325 N. Service Rd., Unit 6
BURLINGTON, Ontario P3A 2A3
Tel: (416) 335-8644
CS,M*

Hewlett-Packard (Canada) Ltd.
552 Newbold Street
LONDON, Ontario N6E 2S5
Tel: (519) 686-9181
A,CH,CM,E*,MS,P*

Hewlett-Packard (Canada) Ltd.
6877 Goreway Drive
MISSISSAUGA, Ontario L4V 1M8
Tel: (416) 678-9430
A,CH,CM,CS,E,MP,P

Hewlett-Packard (Canada) Ltd.
2670 Queensview Dr.
OTTAWA, Ontario K2B 8K1
Tel: (613) 820-6483
A,CH,CM,CS,E*,MS,P*

Hewlett-Packard (Canada) Ltd.
220 Yorkland Blvd., Unit #11
WILLOWDALE, Ontario M2J 1R5
Tel: (416) 499-9333
CH

Quebec

Hewlett-Packard (Canada) Ltd.
17500 South Service Road
Trans-Canada Highway
KIRKLAND, Quebec H9J 2M5
Tel: (514) 697-4232
A,CH,CM,CS,E,MP,P*

Hewlett-Packard (Canada) Ltd.
Les Galeries du Vallon
2323 Du Versant Nord
STE. FOY, Quebec G1N 4C2
Tel: (418) 687-4570
CH

CHILE

Jorge Calcagni y Cia. Ltda.
Av. Italia 634 Santiago
Casilla 16475
SANTIAGO 9
Tel: 222-0222
Telex: Public Booth 440001
A,CM,E,M
Olympia (Chile) Ltda.
Av. Rodrigo de Araya 1045
Casilla 256-V
SANTIAGO 21
Tel: (02) 22 55 044
Telex: 240-565 OLYMP CL
Cable: Olympiachile Santiagochile
CH,CS,P

CHINA, People's Republic of

China Hewlett-Packard Rep. Office

P.O. Box 418
1A Lane 2, Luchang St.
Beiwei Rd., Xuanwu District
BEIJING
Tel: 33-1947, 33-7426
Telex: 22601 CTSHP CN
Cable: 1920
A,CH,CM,CS,E,P

COLOMBIA

Instrumentación
H. A. Langebaek & Kier S.A.
Carrera 4A No. 52A-26
Apartado Aereo 6287
BOGOTA 1, D.E.
Tel: 212-1466
Telex: 44400 INST CO
Cable: AARIS Bogota
CM,E,M
Casa Humboldt Ltda.
Carrera 14, No. 98-60
Apartado Aereo 51283
BOGOTA 1, D.E.
Tel: 256-1686
Telex: 45403 CCAL CO.
A

COSTA RICA

Cientifica Costarricense S.A.
Avenida 2, Calle 5
San Pedro de Montes de Oca
Apartado, 10159
SAN JOSE
Tel: 24-38-20, 24-08-19
Telex: 2367 GALGUR CR
CM,E,M

CYPRUS

Telerexa Ltd.
P.O. Box 4809
14C Stassinos Avenue
NICOSIA
Tel: 62698
Telex: 2894 LEVIDO CY
E,M,P

DENMARK

Hewlett-Packard A/S
Datavej 52
DK-3460 BIRKEROD
Tel: (02) 81-66-40
Telex: 37409 hpas dk
A,CH,CM,CS,E,MS,P
Hewlett-Packard A/S
Rolighedsvej 32
DK-8240 RISSKOV, Aarhus
Tel: (06) 17-60-00
Telex: 37409 hpas dk
CH,E

DOMINICAN REPUBLIC

Microprog S.A.
Juan Tomás Mejía y Cotes No. 60
Arroyo Hondo
SANTO DOMINGO
Tel: 565-6268
Telex: 4510 ARENTA DR (RCA) P

ECUADOR

CYEDE Cia. Ltda.
Avenida Eloy Alfaro 1749
Casilla 6423 CCI
QUITO
Tel: 450-975, 243-052
Telex: 2548 CYEDE ED
CM,E,P

Hospitalar S.A.

Robles 625
Casilla 3590
QUITO
Tel: 545-250, 545-122
Telex: 2485 HOSPTL ED
Cable: HOSPITALAR-Quito
M

EGYPT

International Engineering Associates
24 Hussein Hegazi Street
Kasr-el-Aini
CAIRO
Tel: 23829, 21641
Telex: IEA UN 93830
CH,CS,E,M
EGYPOR
P.O.Box 2558
42 El Zahraa Street
CAIRO, Egypt
Tel: 65 00 21
Telex: 93 337
P

EL SALVADOR

IPESA de El Salvador S.A.
29 Avenida Norte 1216
SAN SALVADOR
Tel: 26-6858, 26-6868
Telex: 20539 IPESASAL
A,CH,CM,CS,E,P

FINLAND

Hewlett-Packard Oy
Revontuletie 7
PL 24
SF-02101 ESPOO 10
Tel: (90) 4550211
Telex: 121563 hewpa sf
CH,CM,CS,P
Hewlett-Packard Oy
(Olarinluoma 7)
PL 24
02101 ESPOO 10
Tel: (90) 4521022
A,E,MS

Hewlett-Packard Oy
Aatoksenkatv 10-C
SF-40720-72 JYVASKYLA
Tel: (941) 216318
CH
Hewlett-Packard Oy
Kainuntie 1-C
SF-90140-14 OULU
Tel: (981) 338785
CH

FRANCE

Hewlett-Packard France
Z.I. Mercurie B
Rue Berthelot
F-13763 Les Milles Cedex
AIX-EN-PROVENCE

Tel: 16 (42) 59-41-02
Telex: 410770F
A,CH,E,MS,P*

Hewlett-Packard France
64, rue Marchand Saillant

F-61000 ALENCON
Tel: 16 (33) 29 04 42
CH,M

Hewlett-Packard France
13, Place Napoleon III

F-29000 BREST
Tel: 16 (98) 03-38-35

Hewlett-Packard France
Chemin des Mouilles
Boite Postale 162
F-69130 ECULLY Cedex (Lyon)
Tel: 16 (78) 833-81-25
Telex: 310617F
A,CH,CS,E,MP

Hewlett-Packard France
Tour Lorraine
Boulevard de France

F-91035 EVRY Cedex

Tel: 16 6 077-96-60
Telex: 692315F
E

Hewlett-Packard France
Parc d'Activite du Bois Briard
Ave. du Lac
F-91040 EVRY Cedex
Tel: 16 6 077-8383
Telex: 692315F
E

Hewlett-Packard France
5, avenue Raymond Chanas
F-38320 EYBENS (Grenoble)
Tel: 16 (76) 25-81-41
Telex: 980124 HF GRENOB EYBE
CH

Hewlett-Packard France
Centre d'Affaire Paris-Nord
Bâtiment Ampère 5 étage
Rue de la Commune de Paris
Boite Postale 300
F-93153 LE BLANC MESNIL

Tel: 16 (1) 865-44-52
Telex: 211032F
CH,CS,E,MS

Hewlett-Packard France
Parc d'Activités Cadera
Quartier Jean Mermoz
Avenue du Président JF Kennedy
F-33700 MERIGNAC (Bordeaux)
Tel: 16 (56) 34-00-84
Telex: 550105F
CH,E,MS

Hewlett-Packard France
Immeuble "Les 3 B"
Nouveau Chemin de la Garde
ZAC de Bois Briand
F-44085 NANTES Cedex
Tel: 16 (40) 50-32-22
CH**

SALES & SUPPORT OFFICES

Arranged alphabetically by country

3



FRANCE (Cont'd)

Hewlett-Packard France
125, rue du Faubourg Bannier
F-45000 ORLEANS
Tel: 16 (38) 68 01 63

Hewlett-Packard France
Zone Industrielle de Courtabœuf
Avenue des Tropiques
F-91947 Les Ulis Cedex ORSAY
Tel: (6) 907-78-25

Telex: 600048F
A,CH,CM,CS,E,MP,P

Hewlett-Packard France
Paris Porte-Maillot
15, Avenue de L'Amiral Bruix
F-75782 PARIS CEDEX 16
Tel: 16 (1) 502-12-20
Telex: 613663F
CH,MS,P

Hewlett-Packard France
124, Boulevard Tourasse
F-64000 PAU
Tel: 16 (59) 80 38 02

Hewlett-Packard France
2 Allée de la Bourgogne
F-35100 RENNES
Tel: 16 (99) 51-42-44

Telex: 740912F
CH,CM,E,MS,P*

Hewlett-Packard France
98 Avenue de Bretagne
F-76100 ROUEN
Tel: 16 (35) 63-57-66
CH**,CS

Hewlett-Packard France
4 Rue Thomas Mann
Boite Postale 56
F-67033 STRASBOURG Cedex
Tel: 16 (88) 28-56-46
Telex: 890141F
CH,E,MS,P*

Hewlett-Packard France
Le Périgole
20, Chemin du Pigeonnier de la
Cépière
F-31083 TOULOUSE Cedex
Tel: 16 (61) 40-11-12
Telex: 531639F
A,CH,CS,E,P*

Hewlett-Packard France
9, rue Baudin
F-26000 VALENCE
Tel: 16 (75) 42 76 16

Hewlett-Packard France
Carolor
ZAC de Bois Briand
F-57640 VIGY (Metz)
Tel: 16 (8) 771 20 22
CH

Hewlett-Packard France
Immeuble Péricentre
F-59658 VILLENEUVE D'ASCQ Cedex
Tel: 16 (20) 91-41-25
Telex: 160124F
CH,E,MS,P*

GERMAN FEDERAL REPUBLIC

Hewlett-Packard GmbH
Geschäftsstelle
Keithstrasse 2-4
D-1000 BERLIN 30
Tel: (030) 24-90-86
Telex: 018 3405 hpbln d
A,CH,E,M,P

Hewlett-Packard GmbH
Geschäftsstelle
Herrenberger Strasse 130
D-7030 BOBLINGEN
Tel: (7031) 14-0

Telex:
A,CH,CM,CS,E,MP,P
Hewlett-Packard GmbH
Geschäftsstelle
Emanuel-Leutze-Strasse 1
D-4000 DUSSELDORF
Tel: (0211) 5971-1

Telex: 085/86 533 hpdd d
A,CH,CS,E,MS,P
Hewlett-Packard GmbH
Geschäftsstelle
Schleefstr. 28a
D-4600 DORTMUND-Aplerbeck
Tel: (0231) 45001

Hewlett-Packard GmbH
Vertriebszentrale Frankfurt
Berner Strasse 117
Postfach 560 140
D-6000 FRANKFURT 56
Tel: (0611) 50-04-1

Telex: 04 13249 hpffm d
A,CH,CM,CS,E,MP,P

Hewlett-Packard GmbH
Geschäftsstelle
Aussenstelle Bad Homburg
Louisenstrasse 115
D-6380 BAD HOMBURG

Tel: (06172) 109-0
Hewlett-Packard GmbH
Geschäftsstelle
Kapstadttring 5
D-2000 HAMBURG 60
Tel: (040) 63804-1

Telex: 021 63 032 phhh d
A,CH,CS,E,MS,P

Hewlett-Packard GmbH
Geschäftsstelle
Heidering 37-39
D-3000 HANNOVER 61
Tel: (0511) 5706-0

Telex: 092 3259
A,CH,CM,E,MS,P

Hewlett-Packard GmbH
Geschäftsstelle
Rossauer Weg 2-4
D-6800 MANNHEIM
Tel: (0621) 70050

Telex: 0462105
A,C,E

Hewlett-Packard GmbH
Geschäftsstelle
Messerschmittstrasse 7
D-7910 NEU ULM
Tel: 0731-70241

Telex: 07 12816 HP ULM-D
A,C,E*

Hewlett-Packard GmbH
Geschäftsstelle
Ehhericherstr. 13
D-8500 NÜRNBERG 10
Tel: (0911) 5205-0

Telex: 0623 860
CH,CM,E,MS,P

Hewlett-Packard GmbH
Geschäftsstelle
Eschenstrasse 5
D-8028 TAUFSKIRCHEN
Tel: (089) 6117-1

Telex: 0524985
A,CH,CM,E,MS,P

GREAT BRITAIN

See United Kingdom

GREECE
Kostas Karaynnis S.A.
8 Omirou Street
ATHENS 133
Tel: 32 30 303, 32 37 371
Telex: 215962 RKAR GR
A,CH,CM,CS,E,M,P
PLAISIO S.A.
G. Gerardos
24 Stournara Street
ATHENS
Tel: 36-11-160
Telex: 221871 P

GUATEMALA

IPESA
Avenida Reforma 3-48, Zona 9
GUATEMALA CITY
Tel: 316627, 314786
Telex: 4192 TELTRO GU
A,CH,CM,CS,E,M,P

HONG KONG

Hewlett-Packard Hong Kong, Ltd.
G.P.O. Box 795
5th Floor, Sun Hung Kai Centre
30 Harbour Road
HONG KONG
Tel: 5-832311
Telex: 66678 HEWPA HX
Cable: HEWPACK HONG KONG
E,CH,CS,P

CET Ltd.
1402 Tung Wah Mansion
199-203 Hennessy Rd.
Wanchia, HONG KONG
Tel: 5-729376
Telex: 85148 CET HX

CM
Schmidt & Co. (Hong Kong) Ltd.
Wing On Centre, 28th Floor
Connaught Road, C.

HONG KONG
Tel: 5-455644
Telex: 74766 SCHMX HX

A,M
ICELAND
Elding Trading Company Inc.
Hafnarvöli-Tryggvagotu
P.O. Box 895
IS-REYKJAVIK
Tel: 1-58-20, 1-63-03
M

INDIA
Computer products are sold through
Blue Star Ltd. All computer repairs and
maintenance service is done through
Computer Maintenance Corp.
Blue Star Ltd.
Sabri Complex II Floor
24 Residency Rd.
BANGALORE 560 025
Tel: 55660
Telex: 0845-430
Cable: BLUESTAR
A,CH*,CM,CS*,E

Blue Star Ltd.
T.C. 7/603 Poornima
Maruthankuzhi
TRIVANDRUM 695 013
Tel: 65799
Telex: 0884-259

Cable: BLUESTAR
E

Computer Maintenance Corporation
Ltd.

115, Sarojini Devi Road
SECUNDERABAD 500 003

Tel: 310-184, 345-774

Telex: 031-2960 CH**

Blue Star Ltd.

Band Box House
Prabhadevi
BOMBAY 400 025
Tel: 422-3101
Telex: 011-3751

Cable: BLUESTAR
A,M

Blue Star Ltd.
Sahas

414/2 Vir Savarkar Marg
Prabhadevi

BOMBAY 400 025
Tel: 422-6155
Telex: 011-4093

Cable: FROSTBLUE
A,CH*,CM,CS*,E,M

Blue Star Ltd.
Kalyan, 19 Vishwas Colony
Alkapuri, **BORODA**, 390 005

Tel: 65235

Cable: BLUE STAR

A
Blue Star Ltd.
7 Hare Street
CALCUTTA 700 001
Tel: 12-01-31

Telex: 021-7655
Cable: BLUESTAR
A,M

Blue Star Ltd.
133 Kodambakkam High Road
MADRAS 600 034
Tel: 82057

Telex: 041-379
Cable: BLUESTAR
A,M

Blue Star Ltd.
Bhandari House, 7th/8th Floors
91 Nehru Place

NEW DELHI 110 024
Tel: 682547

Telex: 031-2463
Cable: BLUESTAR
A,CH*,CM,CS*,E,M

Blue Star Ltd.
15/16:C Wellesley Rd.
PUNE 411 011
Tel: 22775

Cable: BLUE STAR
A

Blue Star Ltd.
2-2-47/1108 Bolarum Rd.
SECUNDERABAD 500 003

Tel: 72057

Telex: 0155-459
Cable: BLUEFROST
A,E

Blue Star Ltd.
T.C. 7/603 Poornima
Maruthankuzhi
TRIVANDRUM 695 013

Tel: 65799

Telex: 0884-259

Cable: BLUESTAR

E

Computer Maintenance Corporation
Ltd.

115, Sarojini Devi Road

SECUNDERABAD 500 003

Tel: 310-184, 345-774

Telex: 031-2960

CH**



SALES & SUPPORT OFFICES

Arranged alphabetically by country

INDONESIA

BERCA Indonesia P.T.
P.O.Box 496/Jkt.

Jl. Abdul Muis 62

JAKARTA

Tel: 21-373009

Telex: 46748 BERSAL IA

Cable: BERSAL JAKARTA

P

BERCA Indonesia P.T.

P.O.Box 2497/Jkt.

Antara Bldg., 17th Floor

Jl. Medan Merdeka Selatan 17

JAKARTA-PUSAT

Tel: 21-344-181

Telex: BERSAL IA

A,CS,E,M

BERCA Indonesia P.T.

P.O. Box 174/SBY.

Jl. Kutei No. 11

SURABAYA

Tel: 68172

Telex: 31146 BERSAL SB

Cable: BERSAL-SURABAYA

A*,E,M,P

IRAQ

Hewlett-Packard Trading S.A.

Service Operation

Al Mansoor City 9B/3/7

BAGHDAD

Tel: 551-49-73

Telex: 212-455 HEPAIRAQ IK

CH,CS

IRELAND

Hewlett-Packard Ireland Ltd.

82/83 Lower Leeson Street

DUBLIN 2

Tel: 0001 608800

Telex: 30439

A,CH,CM,CS,E,M,P

Cardiac Services Ltd.

Kilmore Road

Artane

DUBLIN 5

Tel: (01) 351820

Telex: 30439

M

ISRAEL

Eldan Electronic Instrument Ltd.

P.O.Box 1270

JERUSALEM 91000

16, Ohaliav St.

JERUSALEM 94467

Tel: 553 221, 553 242

Telex: 25231 AB/PAKRD IL

A

Electronics Engineering Division

Motorola Israel Ltd.

16 Kremenetski Street

P.O. Box 25016

TEL-AVIV 67899

Tel: 3 88 388

Telex: 33569 Motil IL

Cable: BASTEL Tel-Aviv

A,CH,CM,CS,E,M,P

ITALY

Hewlett-Packard Italiana S.p.A

Traversa 99C

Via Giulio Petroni, 19

I-70124 BARI

Tel: (080) 41-07-44

M

Hewlett-Packard Italiana S.p.A.

Via Martin Luther King, 38/III

I-40132 BOLOGNA

Tel: (051) 402394

Telex: 511630

CH,E,MS

Hewlett-Packard Italiana S.p.A.

Via Principe Nicola 43G/C

I-95126 CATANIA

Tel: (095) 37-10-87

Telex: 970291

C,P

Hewlett-Packard Italiana S.p.A.

Via G. Di Vittorio 9

I-20063 CERNUSCO SUL NAVIGLIO

(Milano)

Tel: (02) 923691

Telex: 334632

A,CH,CM,CS,E,MP,P

Hewlett-Packard Italiana S.p.A.

Via C. Colombo 49

I-20090 TREZZANO SUL NAVIGLIO

(Milano)

Tel: (02) 4459041

Telex: 322116

C,M

Hewlett-Packard Italiana S.p.A.

Via Nuova San Rocco a

Capodimonte, 62/A

I-80131 NAPOLI

Tel: (081) 7413544

Telex: 710698

A,CH,E

Hewlett-Packard Italiana S.p.A.

Viale G. Modugno 33

I-16156 GENOVA PEGLI

Tel: (010) 68-37-07

Telex: 215238

E,C

Hewlett-Packard Italiana S.p.A.

Via Pelizzzo 15

I-35128 PADOVA

Tel: (049) 664888

Telex: 430315

A,CH,E,MS

Hewlett-Packard Italiana S.p.A.

Viale C. Pavese 340

I-00144 ROMA EUR

Tel: (06) 54831

Telex: 610514

A,CH,CM,CS,E,MS,P*

Hewlett-Packard Italiana S.p.A.

Via di Casellina 57/C

I-50018 SCANDICCI-FIRENZE

Tel: (055) 753863

Hewlett-Packard Italiana S.p.A.

Corso Svizzera, 185

I-10144 TORINO

Tel: (011) 74 4044

Telex: 221079

CH,E

JAPAN

Yokogawa-Hewlett-Packard Ltd.

152-1, Onna

ATSUGI, Kanagawa, 243

Tel: (0462) 28-0451

CM,C*,E

Yokogawa-Hewlett-Packard Ltd.

Meiji-Seimeji Bldg. 6F

3-1 Hon Chiba-Cho

CHIBA, 280

Tel: 472 25 7701

E,CH,CS

Yokogawa-Hewlett-Packard Ltd.

Yasuda-Seimeji Hiroshima Bldg.

6-11, Hon-dori, Naka-ku

HIROSHIMA, 730

Tel: 82-241-0611

Yokogawa-Hewlett-Packard Ltd.

Towa Building

2-3, Kaigan-dori, 2 Chome Chuo-ku

KOBE, 650

Tel: (078) 392-4791

C,E

Yokogawa-Hewlett-Packard Ltd.

Kumagaya Asahi 82 Bldg

3-4 Tsukuba

KUMAGAYA, Saitama 360

Tel: (0485) 24-6563

CH,CM,E

Yokogawa-Hewlett-Packard Ltd.

Asahi Shinbun Daiichi Seimeji Bldg.

4-7, Hanabata-cho

KUMAMOTO, 860

Tel: (0963) 54-7311

CH,E

Yokogawa-Hewlett-Packard Ltd.

Shin-Kyoto Center Bldg.

614, Higashi-Shiokoji-cho

Karasuma-Nishiiru

Shiokoji-dori, Shimogyo-ku

KYOTO, 600

Tel: 075-343-0921

CH,E

Yokogawa-Hewlett-Packard Ltd.

Mito Mitsui Bldg

4-73, Sanno-maru, 1 Chome

MITO, Ibaraki 310

Tel: (0292) 25-7470

CH,CM,E

Yokogawa-Hewlett-Packard Ltd.

Sumitomo Seimeji 14-9 Bldg.

Meieki-Minami, 2 Chome

Nakamura-ku

NAGOYA, 450

Tel: (052) 571-5171

CH,CM,CS,E,MS

Yokogawa-Hewlett-Packard Ltd.

Chuo Bldg.,

4-20 Nishinakajima, 5 Chome

Yodogawa-ku

OSAKA, 532

Tel: (06) 304-6021

Telex: YHPOSA 523-3624

A,CH,CM,CS,E,MP,P*

Yokogawa-Hewlett-Packard Ltd.

27-15, Yabe, 1 Chome

SAGAMIHARA Kanagawa, 229

Tel: 0427 59-1311

Yokogawa-Hewlett-Packard Ltd.

Daiichi Seimeji Bldg.

7-1, Nishi Shinjuku, 2 Chome

Shinjuku-ku, TOKYO 160

Tel: 03-348-4611

CH,E

Yokogawa-Hewlett-Packard Ltd.

29-21 Takanodai-Higashi, 3 Chome

Suginami-ku TOKYO 168

Tel: (03) 331-611

Telex: 232-2024 YHPTOK

A,CH,CM,CS,E,MP,P*

Yokogawa-Hewlett-Packard Ltd.

Daiichi Asano Building

2-8, Odori, 5 Chome

UTSUNOMIYA, Tochigi 320

Tel: (0286) 25-7155

CH,CS,E

Yokogawa-Hewlett-Packard Ltd.

Yasuda Seimeji Nishiguchi Bldg.

30-4 Tsuruya-cho, 3 Chome

YOKOHAMA 221

Tel: (045) 312-1252

CH,CM,E

JORDAN

Mouasher Cousins Company

P.O. Box 1387

AMMAN

Tel: 24907, 39907

Telex: 21456 SABCO JO

CH,E,M,P

KENYA

ADCOM Ltd., Inc., Kenya

P.O.Box 30070

NAIROBI

Tel: 331955

Telex: 22639

E,M

KOREA

Samsung Electronics HP Division

12 Fl. Kinam Bldg.

San 75-31, Yeoksam-Dong

Kangnam-Ku

Yeongdong P.O. Box 72

SEOUL

Tel: 555-7555, 555-5447

Telex: K27364 SAMSAN

A,CH,CM,CS,E,M,P

KUWAIT

Al-Khalidiya Trading & Contracting

P.O. Box 830 Safat

KUWAIT

Tel: 42-4910, 41-1726

Telex: 22481 Areeg kt

CH,E,M

Photo & Cine Equipment

P

SALES & SUPPORT OFFICES

Arranged alphabetically by country

5



MAYLAYSIA (Cont'd)

Protel Engineering
P.O.Box 1917
Lot 6624, Section 64
23/4 Pending Road
Kuching, SARAWAK
Tel: 36299
Telex: MA 70904 PROMAL
Cable: PROTELENG
A,E,M

MALTA

Philip Toledo Ltd.
Notabile Rd.
MRIEHEL
Tel: 447 47, 455 66
Telex: Media MW 649
E,P

MEXICO

Hewlett-Packard Mexicana, S.A. de C.V.
Av. Periferico Sur No. 6501
Tepepan, Xochimilco
16020 MEXICO D.F.
Tel: 6-76-46-00
Telex: 17-74-507 HEWPACK MEX
A,CH,CS,E,MS,P
Hewlett-Packard Mexicana, S.A. de C.V.
Ave. Colonia del Valle 409
Col. del Valle
Municipio de Garza Garcia
MONTERREY, Nuevo Leon
Tel: 78 42 41
Telex: 038 410
CH
ECISA
José Vasconcelos No. 218
Col. Condesa Deleg. Cuauhtémoc
MEXICO D.F. 06140
Tel: 553-1206
Telex: 17-72755 ECE ME
M

MOROCCO

Dolbeau
81 rue Karatchi
CASABLANCA
Tel: 3041-82, 3068-38
Telex: 23051, 22822
E
Gerep
2 rue d'Agadir
Boite Postale 156
CASABLANCA
Tel: 272093, 272095
Telex: 23 739
P

NETHERLANDS

Hewlett-Packard Nederland B.V.
Van Heuven Goedhartlaan 121
NL 1181KK AMSTELVEEN
P.O. Box 667
NL 1180 AR AMSTELVEEN
Tel: (020) 47-20-21
Telex: 13 216 HEPA NL
A,CH,CM,CS,E,MP,P
Hewlett-Packard Nederland B.V.
Bongerd 2
NL 2906VK CAPELLE A/D IJSSEL
P.O. Box 41
NL 2900AA CAPELLE A/D IJSSEL
Tel: (10) 51-64-44
Telex: 21261 HEPAC NL
A,CH,CS,E

Hewlett-Packard Nederland B.V.
Pastoor Petersstraat 134-136
NL 5612 LV EINDHOVEN
P.O. Box 2342
NL 5600 CH EINDHOVEN
Tel: (040) 326911
Telex: 51484 hepac nl
A,CH*,E,M

NEW ZEALAND

Hewlett-Packard (N.Z.) Ltd.
5 Owens Road
P.O. Box 26-189
Epsom, AUCKLAND
Tel: 687-159
Cable: HEWPACK Auckland
CH,CM,E,P*

Hewlett-Packard (N.Z.) Ltd.

4-12 Cruckshank Street
Kilbirnie, WELLINGTON 3
P.O. Box 9443
Courtenay Place, WELLINGTON 3
Tel: 877-199
Cable: HEWPACK Wellington
CH,CM,E,P

Northrop Instruments & Systems Ltd.
369 Khyber Pass Road

P.O. Box 8602
AUCKLAND
Tel: 794-091
Telex: 60605
A,M

Northrop Instruments & Systems Ltd.
110 Mandeville St.

P.O. Box 8388

CHRISTCHURCH
Tel: 486-928
Telex: 4203
A,M

Northrop Instruments & Systems Ltd.

Sturdee House
85-87 Ghuznee Street
P.O. Box 2406

WELLINGTON

Tel: 850-091

Telex: NZ 3380

A,M

NORTHERN IRELAND

See United Kingdom

NORWAY

Hewlett-Packard Norge A/S
Folke Bernadottes vei 50
P.O. Box 3558
N-5033 FYLLINGSDALEN (Bergen)

Tel: 0047/51 55 40

Telex: 16621 hpnas n

CH,CS,E,MS

Hewlett-Packard Norge A/S

Österndalen 16-18

P.O. Box 34

N-1345 ÖSTERÅS

Tel: 0047/2/17 11 80

Telex: 16621 hpnas n

A,CH,CM,CS,E,M,P

OMAN

Khimjil Ramdas

P.O. Box 19

MUSCAT

Tel: 722225, 745601

Telex: 3289 BROKER MB MUSCAT

P

Suhail & Saud Bahwan

P.O.Box 169

MUSCAT

Tel: 734 201-3

Telex: 3274 BAHWAN MB

PAKISTAN

Mushko & Company Ltd.
1-B, Street 43
Sector F-8/1
ISLAMABAD
Tel: 51071
Cable: FEMUS Rawalpindi
A,E,M

Mushko & Company Ltd.
Osman Chambers
Abdullah Haroon Road
KARACHI 0302
Tel: 524131, 524132
Telex: 2894 MUSKO PK
Cable: COOPERATOR Karachi
A,E,M,P*

PANAMA

Electrónico Balboa, S.A.
Calle Samuel Lewis, Ed. Alta
Apartado 4929
PANAMA 5
Tel: 63-6613, 63-6748
Telex: 3483 ELECTRON PG
A,CM,E,M,P

PERU

Cía Electro Médica S.A.
Los Flamencos 145, San Isidro
Casilla 1030
LIMA 1
Tel: 41-4325, 41-3703
Telex: Pub. Booth 25306
CM,E,M,P

PHILIPPINES

The Online Advanced Systems Corporation
Rico House, Amorsolo Cor. Herrera Street
Legaspi Village, Makati
P.O. Box 1510
Metro MANILA
Tel: 85-35-81, 85-34-91, 85-32-21
Telex: 3274 ONLINE
A,CH,CS,E,M

Electronic Specialists and Proponents Inc.

690-B Epifanio de los Santos Avenue
Cubao, QUEZON CITY
P.O. Box 2649 Manila
Tel: 98-96-81, 98-96-82, 98-96-83
Telex: 40018, 42000 ITT GLOBE
MACKAY BOOTH
P

PORTUGAL

Mundinter
Intercambio Mundial de Comércio S.A.R.L.
P.O. Box 2761
Av. Antonio Augusto de Aguiar 138
P-LISBON
Tel: (19) 53-21-31, 53-21-37
Telex: 16691 munter p
M

Soquimica

Av. da Liberdade, 220-2

1298 LISBOA Codex

Tel: 56 21 81/2/3

Telex: 13316 SABASA

P

Telectra-Empresa Técnica de Equipamentos Eléctricos S.A.R.L.
Rua Rodrigo da Fonseca 103
P.O. Box 2531
P-LISBON 1
Tel: (19) 68-60-72
Telex: 12598
CH,CS,E,P

PUERTO RICO

Hewlett-Packard Puerto Rico
Ave. Muñoz Rivera #101
Esq. Calle Ochoa
HATO REY, Puerto Rico 00918
Tel: (809) 754-7800
Hewlett-Packard Puerto Rico
Calle 272 Edificio 203
Urb. Country Club
RIO PIEDRAS, Puerto Rico
P.O. Box 4407
CAROLINA, Puerto Rico 00628
Tel: (809) 762-7255
A,CH,CS

QATAR

Computearbia
P.O. Box 2750
DOHA
Tel: 883555
Telex: 4806 CHPARB
P

Eastern Technical Services
P.O.Box 4747

DOHA
Tel: 329 993
Telex: 4 156 EASTEC DH
Nasser Trading & Contracting
P.O.Box 1563
DOHA
Tel: 22170, 23539
Telex: 4439 NASSER DH
M

SAUDI ARABIA

Modern Electronic Establishment
Hewlett-Packard Division
P.O. Box 22015
Thuobah
AL-KHOBAR
Tel: 895-1760, 895-1764
Telex: 671 106 HPMEEK SJ
Cable: ELECTRA AL-KHOBAR
CH,CS,E,M

Modern Electronic Establishment
Hewlett-Packard Division
P.O. Box 1228
Redec Plaza, 6th Floor
JEDDAH
Tel: 644 38 48
Telex: 4027 12 FARNAS SJ
Cable: ELECTRA JEDDAH
CH,CS,E,M

Modern Electronic Establishment
Hewlett-Packard Division
P.O.Box 22015
RIYADH
Tel: 491-97 15, 491-63 87
Telex: 202049 MEERYD SJ
CH,CS,E,M

Abdul Ghani El Ajou
P.O. Box 78
RIYADH
Tel: 40 41 717
Telex: 200 932 EL AJOU
P

SCOTLAND

See United Kingdom

SINGAPORE

Hewlett-Packard Singapore (Sales) Pte. Ltd.
#08-00 Inchcape House
450-2 Alexandra Road
P.O. Box 58 Alexandra Rd. Post Office
SINGAPORE, 9115
Tel: 631788
Telex: HPSGS0 RS 34209
Cable: HEWPACK, Singapore
A,CH,CS,E,MS,P



SALES & SUPPORT OFFICES

Arranged alphabetically by country

SINGAPORE (Cont'd)

Dynamar International Ltd.
Unit 05-11 Block 6
Kolam Ayer Industrial Estate
SINGAPORE 1334
Tel: 747-6188
Telex: RS 26283
CM

SOUTH AFRICA

Hewlett-Packard So Africa (Pty.) Ltd.
P.O. Box 120
Howard Place **CAPE PROVINCE 7450**
Pine Park Center, Forest Drive,
Pinelands
CAPE PROVINCE 7405
Tel: 53-7954
Telex: 57-20006
A,CH,CM,E,MS,P
Hewlett-Packard So Africa (Pty.) Ltd.
P.O. Box 37099
92 Overport Drive
DURBAN 4067
Tel: 28-4178, 28-4179, 28-4110
Telex: 6-22954
CH,CM

Hewlett-Packard So Africa (Pty.) Ltd.
6 Linton Arcade
511 Cape Road

Linton Grange

PORT ELIZABETH 6000

Tel: 041-302148
CH

Hewlett-Packard So Africa (Pty.) Ltd.
P.O.Box 33345

GLENSTANIA 0010 TRANSVAAL

1st Floor East
Constantia Park Ridge Shopping
Centre
Constantia Park
PRETORIA
Tel: 982043
Telex: 32163
CH,E

Hewlett-Packard So Africa (Pty.) Ltd.
Private Bag Wendywood
SANDTON 2144
Tel: 802-5111, 802-5125
Telex: 4-20877
Cable: HEWPACK Johannesburg
A,CH,CM,CS,E,MS,P

SPAIN

Hewlett-Packard Española S.A.

Calle Entenza, 321
E-BARCELONA 29
Tel: 322.24.51, 321.73.54
Telex: 52603 hpbee
A,CH,CS,E,MS,P

Hewlett-Packard Española S.A.

Calle San Vicente S/No
Edificio Albia II
E-BILBAO 1
Tel: 423.83.06
A,CH,E,MS

Hewlett-Packard Española S.A.
Ctra. de la Coruña, Km. 16, 400

Las Rozas

E-MADRID

Tel: (1) 637.00.11

CH,CS,M

Hewlett-Packard Española S.A.

Avda. S. Francisco Javier, S/no
Planta 10. Edificio Sevilla 2,
E-SEVILLA 5
Tel: 64.44.54
Telex: 72933
A,CS,MS,P

Hewlett-Packard Española S.A.
Calle Ramon Gordillo, 1 (Entlo.3)
E-VALENCIA 10
Tel: 361-1354
CH,P

SWEDEN

Hewlett-Packard Sverige AB
Sunnanvagen 14K
S-22226 LUND
Tel: (046) 13-69-79
Telex: (854) 17886 (via Spånga
office)
CH

Hewlett-Packard Sverige AB
Östra Tullgatan 3
S-21128 Malmö
Tel: (040) 70270
Telex: (854) 17886 (via Spånga
office)

Hewlett-Packard Sverige AB
Västra Vintergatan 9
S-70344 ÖREBRO
Tel: (19) 10-48-80
Telex: (854) 17886 (via Spånga
office)

Hewlett-Packard Sverige AB
Skalholtsgränd 9, Kista
Box 19
S-16393 SPÅNGA

Tel: (08) 750-2000
Telex: (854) 17886
Telefax: (08) 7527781
A,CH,CM,CS,E,MS,P

Hewlett-Packard Sverige AB
Frötallegatan 30
S-42132 VÄSTRA-FRÖLUNDA
Tel: (031) 49-09-50
Telex: (854) 17886 (via Spånga
office)

CH,E,P
SWITZERLAND
Hewlett-Packard (Schweiz) AG
Clarastrasse 12
CH-4058 BASEL
Tel: (61) 33-59-20
A

Hewlett-Packard (Schweiz) AG
7, rue du Bois-du-Lan
Case Postale 365
CH-1217 MEYRIN 2
Tel: (0041) 22-83-11-11
Telex: 27333 HPAG CH

CH,CM,CS
Hewlett-Packard (Schweiz) AG
Allmend 2
CH-8967 WIDEN
Tel: (0041) 57 31 21 11
Telex: 53933 hpag ch

Cable: HPAG CH

A,CH,CM,CS,E,MS,P
SYRIA
General Electronic Inc.

Nuri Basha Ahnaf Ebn Kays Street
P.O. Box 5781
DAMASCUS
Tel: 33-24-87
Telex: 411 215
Cable: ELECTROBOR DAMASCUS

E

Middle East Electronics
P.O.Box 2308
Abu Rummaneh
DAMASCUS
Tel: 33 4 5 92
Telex: 411 304
M

TAIWAN

Hewlett-Packard Far East Ltd.
Kaohsiung Office
2/F 68-2, Chung Cheng 3rd Road
KAOHHSIUNG
Tel: (07) 241-2318
CH,CS,E

Hewlett-Packard Far East Ltd.
Taiwan Branch
8th Floor
337 Fu Hsing North Road
TAIPEI
Tel: (02) 712-0404
Telex: 24439 HEWPACK

Cable:HEWPACK Taipei
A,CH,CM,CS,E,M,P
Ing Lih Trading Co.
3rd Floor, 7 Jen-Ai Road, Sec. 2
TAIPEI 100
Tel: (02) 3948191
Cable: INGLIH TAIPEI

A

THAILAND

Unimesa
30 Patpong Ave., Suriwong
BANGKOK 5
Tel: 235-5727

Telex: 84439 Simonco TH
Cable: UNIMESA Bangkok
A,CH,CS,E,M

Bangkok Business Equipment Ltd.
5/5-6 Dejo Road
BANGKOK
Tel: 234-8670, 234-8671
Telex: 87669-BEQUIPT TH
Cable: BUSIQUIPT Bangkok

P

TRINIDAD & TOBAGO

Caribbean Telecoms Ltd.
50/A Jerningham Avenue
P.O. Box 732
PORT-OF-SPAIN
Tel: 62-44213, 62-44214
Telex: 235,272 HUGCO WG

CM,E,M,P

TUNISIA

Tunisie Electronique
31 Avenue de la Liberte
TUNIS

Tel: 280-144
E,P

Corema
1 ter. Av. de Carthage
TUNIS

Tel: 253-821
Telex: 12319 CABAM TN
M

TURKEY

Teknrim Company Ltd.
Iran Caddesi No. 7
Kavaklıdere, **ANKARA**
Tel: 275800
Telex: 42155 TKNM TR

E

E.M.A.
Medina Eldem Sokak No.4 1/6
Yuksel Caddesi
ANKARA
Tel: 175 622
Telex: 42 591
M

UNITED ARAB EMIRATES

Emitac Ltd.

P.O. Box 2711
ABU DHABI
Tel: 82 04 19-20
Cable: EMITAC ABUDHABI

Emitac Ltd.
P.O. Box 1641
SHARJAH
Tel: 591 181
Telex: 68 136 Emitac Sh
CH,CS,E,M,P

UNITED KINGDOM

GREAT BRITAIN

Hewlett-Packard Ltd.

Trafalgar House
Navigation Road
ALTRINCHAM
Cheshire WA14 1NU
Tel: 061 928 6422
Telex: 668068
A,CH,CS,E,M,MS,P
Hewlett-Packard Ltd.
Elstree House, Elstree Way
BOREHAMWOOD, Herts WD6 1SG
Tel: 01 207 5000
Telex: 8952716
E,CH,CS,P

Hewlett-Packard Ltd.
Oakfield House, Oakfield Grove
Clifton **BRISTOL**, Avon BS8 2BN
Tel: 0272 736806
Telex: 444302
CH,CS,E,P

Hewlett-Packard Ltd.

Bridewell House
Bridewell Place
LONDON EC4V 6BS
Tel: 01 583 6565
Telex: 298163
CH,CS,P
Hewlett-Packard Ltd.
Fourier House
257-263 High Street
LONDON COLNEY
Herts. AL2 1HA, St. Albans
Tel: 0727 24400
Telex: 1-8952716
CH,CS

Hewlett-Packard Ltd.

Pontefract Road
NORMANTON, West Yorkshire WF6 1RN
Tel: 0924 895566
Telex: 557355
CH,CS,P

Hewlett-Packard Ltd.

The Quadrangle
106-118 Station Road
REDHILL, Surrey RH1 1PS
Tel: 0737 68655
Telex: 947234
CH,CS,E,P

SALES & SUPPORT OFFICES

Arranged alphabetically by country

7



GREAT BRITAIN (Cont'd)

Hewlett-Packard Ltd.
Avon House
435 Stratford Road
Shirley, SOLIHULL, West Midlands
B90 4BL
Tel: 021 745 8800
Telex: 339105
CH,CS,E,P
Hewlett-Packard Ltd.
West End House
41 High Street, West End
SOUTHAMPTON
Hampshire SO3 3DQ
Tel: 04218 6767
Telex: 477138
CH,CS,P
Hewlett-Packard Ltd.
Eskdale Rd.
Winnersh, **WOKINGHAM**
Berkshire RG11 5DZ
Tel: 0734 696622
Telex: 848884
E
Hewlett-Packard Ltd.
King Street Lane
Winnersh, **WOKINGHAM**
Berkshire RG11 5AR
Tel: 0734 784774
Telex: 847178
A,CH,CS,E,M,MP,P
Hewlett-Packard Ltd.
Nine Mile Ride
Easthampstead, **WOKINGHAM**
Berkshire, 3RG11 3LL
Tel: 0344 773100
Telex: 848805
CH,CS,E,P

IRELAND

NORTHERN IRELAND
Hewlett-Packard Ltd.
Cardiac Services Building
95A Finaghy Road South
BELFAST BT10 0BY
Tel: 0232 625-566
Telex: 747626
CH,CS

SCOTLAND

Hewlett-Packard Ltd.
SOUTH QUEENFERRY
West Lothian, EH30 9TG
Tel: 031 331 1188
Telex: 72682
CH,CM,CS,E,MP,P

UNITED STATES

Alabama
Hewlett-Packard Co.
700 Century Park South, Suite 128
BIRMINGHAM, AL 35226
Tel: (205) 822-6802
A,CH,M
Hewlett-Packard Co.
420 Wynn Drive
HUNTSVILLE, AL 35805
P.O. Box 7700
HUNTSVILLE, AL 35807
Tel: (205) 830-2000
CH,CM,CS,E,M*

Arizona

Hewlett-Packard Co.
8080 Pointe Parkway West
PHOENIX, AZ 85044
Tel: (602) 273-8000
A,CH,CM,CS,E,MS

Hewlett-Packard Co.
2424 East Aragon Road
TUCSON, AZ 85706
Tel: (602) 889-4631
CH,E,MS**
California
Hewlett-Packard Co.
99 South Hill Dr.
BRISBANE, CA 94005
Tel: (415) 330-2500
CH,CS
Hewlett-Packard Co.
P.O. Box 7830 (93747)
5060 E. Clinton Avenue, Suite 102
FRESNO, CA 93727
Tel: (209) 252-9652
CH,CS,MS
Hewlett-Packard Co.
P.O. Box 4230
1430 East Orangethorpe
FULLERTON, CA 92631
Tel: (714) 870-1000
CH,CM,CS,E,MP
Hewlett-Packard Co.
320 S. Kellogg, Suite B
GOLETA, CA 93117
Tel: (805) 967-3405
CH
Hewlett-Packard Co.
5400 W. Rosecrans Boulevard
LAWNDALE, CA 90260
P.O. Box 92105
LOS ANGELES, CA 90009
Tel: (213) 970-7500
Telex: 910-325-6608
CH,CM,CS,MP
Hewlett-Packard Co.
3155 Porter Oaks Drive
PALO ALTO, CA 94304
Tel: (415) 857-8000
CH,CS,E
Hewlett-Packard Co.
4244 So. Market Court, Suite A
P.O. Box 15976
SACRAMENTO, CA 95852
Tel: (916) 929-7222
A*,CH,CS,E,MS
Hewlett-Packard Co.
9606 Aero Drive
P.O. Box 23333
SAN DIEGO, CA 92139
Tel: (619) 279-3200
CH,CM,CS,E,MP
Hewlett-Packard Co.
2305 Camino Ramon "C"
SAN RAMON, CA 94583
Tel: (415) 838-5900
CH,CS
Hewlett-Packard Co.
3005 Scott Boulevard
SANTA CLARA, CA 95050
Tel: (408) 988-7000
Telex: 910-338-0586
A,CH,CM,CS,E,MP
Hewlett-Packard Co.
5703 Corsa Avenue
WESTLAKE VILLAGE, CA 91362
Tel: (213) 706-6800
E*,CH*,CS*

Colorado
Hewlett-Packard Co.
24 Inverness Place, East
ENGLEWOOD, CO 80112
Tel: (303) 649-5000
A,CH,CM,CS,E,MS

Connecticut

Hewlett-Packard Co.
47 Barnes Industrial Road South
P.O. Box 5007
WALLINGFORD, CT 06492
Tel: (203) 265-7801
A,CH,CM,CS,E,MS

Florida

Hewlett-Packard Co.
2901 N.W. 62nd Street
P.O. Box 24210
FORT LAUDERDALE, FL 33307
Tel: (305) 973-2600
CH,CS,E,MP

Hewlett-Packard Co.

6177 Lake Ellenor Drive
P.O. Box 13910
ORLANDO, FL 32859
Tel: (305) 859-2900
A,CH,CM,CS,E,MS

Hewlett-Packard Co.

5750B N. Hoover Blvd., Suite 123
P.O. Box 15200

TAMPA, FL 33614

Tel: (813) 884-3282

A*,CH,CM,CS,E*,M*

Georgia

Hewlett-Packard Co.
2000 South Park Place
P.O. Box 105005
ATLANTA, GA 30348
Tel: (404) 955-1500
Telex: 810-766-4890
A,CH,CM,CS,E,MP

Hawaii

Hewlett-Packard Co.
Kawaiahao Plaza, Suite 190
567 South King Street
HONOLULU, HI 96813
Tel: (808) 526-1555
A,CH,E,MS

Illinois

Hewlett-Packard Co.
304 Eldorado Road
P.O. Box 1607
BLOOMINGTON, IL 61701
Tel: (309) 662-9411
CH,MS**

Hewlett-Packard Co.

1100 31st Street, Suite 100
DOWNS GROVE, IL 60515
Tel: (312) 960-5760
CH,CS

Hewlett-Packard Co.

5201 Tollview Drive
ROLLING MEADOWS, IL 60008
Tel: (312) 255-9800
Telex: 910-687-1066
A,CH,CM,CS,E,MP

Indiana

Hewlett-Packard Co.
7301 No. Shadeland Avenue
P.O. Box 50807
INDIANAPOLIS, IN 46250
Tel: (317) 842-1000
A,CH,CM,CS,E,MS

Iowa

Hewlett-Packard Co.
1776 22nd Street, Suite 1
WEST DES MOINES, IA 50265
Tel: (515) 224-1435
CH,MS**

Kansas

Hewlett-Packard Co.
7804 East Funston Road, #203
WICHITA, KS 67207
Tel: (316) 684-8491
CH

Kentucky

Hewlett-Packard Co.
10300 Linn Station Road, #100
LOUISVILLE, KY 40223
Tel: (502) 426-0100
A,CH,CS,MS

Louisiana

Hewlett-Packard Co.
160 James Drive East
ST. ROSE, LA 70087
P.O. Box 1449
KENNER, LA 70063
Tel: (504) 467-4100
A,CH,CS,E,MS

Maryland

Hewlett-Packard Co.
3701 Koppers Street
BALTIMORE, MD 21227
Tel: (301) 644-5800
Telex: 710-862-1943
A,CH,CM,CS,E,MS

Massachusetts

Hewlett-Packard Co.
1775 Minuteman Road
ANDOVER, MA 01810
Tel: (617) 682-1500
A,C,CH,CS,CM,E,MP,P*

Hewlett-Packard Co.
32 Hartwell Avenue
LEXINGTON, MA 02173
Tel: (617) 861-8960
CH,CS,E

Michigan

Hewlett-Packard Co.
4326 Cascade Road S.E.
GRAND RAPIDS, MI 49506
Tel: (616) 957-1970
CH,CS,MS

Hewlett-Packard Co.
1771 W. Big Beaver Road
TROY, MI 48084
Tel: (313) 643-6474
CH,CS

Minnesota

Hewlett-Packard Co.
2025 W. Larpenteur Ave.
ST. PAUL, MN 55113
Tel: (612) 644-1100
A,CH,CM,CS,E,MP

Missouri

Hewlett-Packard Co.
11131 Colorado Avenue
KANSAS CITY, MO 64137
Tel: (816) 763-8000
A,CH,CM,CS,E,MS

Wisconsin

Hewlett-Packard Co.
13001 Hollenberg Drive

BRIDGETON, MO 63044

Tel: (314) 344-5100
A,CH,CS,E,MP



SALES & SUPPORT OFFICES

Arranged alphabetically by country

UNITED STATES (Cont'd)

Nebraska

Hewlett-Packard
10824 Old Mill Rd., Suite 3
OMAHA, NE 68154
Tel: (402) 334-1813
CM,MS

New Jersey

Hewlett-Packard Co.
120 W. Century Road
PARAMUS, NJ 07652
Tel: (201) 265-5000
A,CH,CM,CS,E,MP
Hewlett-Packard Co.
60 New England Av. West
PISCATAWAY, NJ 08854
Tel: (201) 981-1199
A,CH,CM,CS,E

New Mexico

Hewlett-Packard Co.
11300 Lomas Blvd., N.E.
P.O. Box 11634
ALBUQUERQUE, NM 87112
Tel: (505) 292-1330
CH,CS,E,MS

New York

Hewlett-Packard Co.
5 Computer Drive South
ALBANY, NY 12205
Tel: (518) 458-1550
A,CH,E,MS
Hewlett-Packard Co.
9600 Main Street
P.O. Box AC
CLARENCE, NY 14031
Tel: (716) 759-8621
CH

Hewlett-Packard Co.
200 Cross Keys Office Park
FAIRPORT, NY 14450
Tel: (716) 223-9950
CH,CM,CS,E,MS

Hewlett-Packard Co.
7641 Henry Clay Blvd.

LIVERPOOL, NY 13088
Tel: (315) 451-1820
A,CH,CM,E,MS

Hewlett-Packard Co.
No. 1 Pennsylvania Plaza
55th Floor
34th Street & 8th Avenue
MANHATTAN NY 10119
Tel: (212) 971-0800
CH,CS,E*,M*

Hewlett-Packard Co.
250 Westchester Avenue
WHITE PLAINS, NY 10604
Tel: (914) 684-6100
CM,CH,CS,E

Hewlett-Packard Co.
3 Crossways Park West
WOODBURY, NY 11797
Tel: (516) 921-0300
A,CH,CM,CS,E,MS

North Carolina

Hewlett-Packard Co.
5605 Roanoke Way
P.O. Box 26500
GREENSBORO, NC 27420
Tel: (919) 852-1800
A,CH,CM,CS,E,MS

Ohio

Hewlett-Packard Co.
9920 Carver Road
CINCINNATI, OH 45242
Tel: (513) 891-9870
CH,CS,MS

Hewlett-Packard Co.
16500 Sprague Road
CLEVELAND, OH 44130
Tel: (216) 243-7300
A,CH,CM,CS,E,MS

Hewlett-Packard Co.
962 Crupper Ave.
COLUMBUS, OH 43229
Tel: (614) 436-1041
Eff. Nov. 25, 1983
675 Brookside Blvd.
WESTERVILLE, OH 43081
CH,CM,CS,E*

Hewlett-Packard Co.
330 Progress Rd.
DAYTON, OH 45449
Tel: (513) 859-8202
A,CH,CM,E*,MS

Oklahoma
Hewlett-Packard Co.
304 N. Meridian, Suite A
P.O. Box 75609
OKLAHOMA CITY, OK 73147
Tel: (405) 946-9499
A*,CH,E*,MS

Hewlett-Packard Co.
3840 S. 103rd E. Avenue, #100
P.O. Box 35747
TULSA, OK 74153
Tel: (918) 665-3300
A**,CH,CS,M*

Oregon
Hewlett-Packard Co.
9255 S. W. Pioneer Court
P.O. Box 328
WILSONVILLE, OR 97070
Tel: (503) 682-8000
A,CH,CS,E,MS

Pennsylvania
Hewlett-Packard Co.
111 Zeta Drive
PITTSBURGH, PA 15238
Tel: (412) 782-0400
A,CH,CS,E,MP

Hewlett-Packard Co.
2750 Monroe Boulevard
P.O. Box 713
VALLEY FORGE, PA 19482
Tel: (215) 666-9000
A,CH,CM,E,M

South Carolina
Hewlett-Packard Co.
Brookside Park, Suite 122
1 Harbison Way
P.O. Box 21708
COLUMBIA, SC 29221
Tel: (803) 732-0400
CH,E,MS

Hewlett-Packard Co.
Koger Executive Center
Chesterfield Bldg., Suite 124
GREENVILLE, SC 29615
Tel: (803) 297-4120

Tennessee
Hewlett-Packard Co.
224 Peters Road, Suite 102
P.O. Box 22490
KNOXVILLE, TN 37922
Tel: (615) 691-2371
A*,CH,MS

Hewlett-Packard Co.
3070 Directors Row
MEMPHIS, TN 38131
Tel: (901) 346-8370
A,CH,MS

Texas
Hewlett-Packard Co.
4171 North Mesa
Suite C-110
EL PASO, TX 79902
Tel: (915) 533-3555
CH,E*,MS**

Hewlett-Packard Co.
10535 Harwin Drive
P.O. Box 42816
HOUSTON, TX 77042
Tel: (713) 776-6400
A,CH,CM,CS,E,MP
Hewlett-Packard Co.
930 E. Campbell Rd.
P.O. Box 1270
RICHARDSON, TX 75080
Tel: (214) 231-6101
A,CH,CM,CS,E,MP

Hewlett-Packard Co.
1020 Central Parkway South
P.O. Box 32993
SAN ANTONIO, TX 78216
Tel: (512) 494-9336
CH,CS,E,MS

Utah
Hewlett-Packard Co.
3530 W. 2100 South
SALT LAKE CITY, UT 84119
Tel: (801) 974-1700
A,CH,CS,E,MS

Virginia
Hewlett-Packard Co.
4305 Cox Road
GLEN ALLEN, VA 23060
P.O. Box 9669
RICHMOND, VA 23228
Tel: (804) 747-7750
A,CH,CS,E,MS

Washington
Hewlett-Packard Co.
15815 S.E. 37th Street
BELLEVUE, WA 98006
Tel: (206) 643-4000
A,CH,CM,CS,E,MP
Hewlett-Packard Co.
Suite A
708 North Argonne Road
SPOKANE, WA 99212
Tel: (509) 922-7000
CH,CS

West Virginia
Hewlett-Packard Co.
4604 MacCorkle Ave.
P.O. Box 4297
CHARLESTON, WV 25304
Tel: (304) 925-0492
A,MS

Wisconsin
Hewlett-Packard Co.
150 S. Sunny Slope Road
BROOKFIELD, WI 53005
Tel: (414) 784-8800
A,CH,CS,E*,MP

URUGUAY

Pablo Ferrando S.A.C. e.I.
Avenida Italia 2877
Casilla de Correo 370
MONTEVIDEO
Tel: 80-2586
Telex: Public Booth 901
A,CM,E,M

VENEZUELA

Hewlett-Packard de Venezuela C.A.
3RA Transversal Los Ruices Norte
Edificio Segre 1, 2 & 3
Apartado 50933
CARACAS 1071
Tel: 239-4133
Telex: 251046 HEWPACK
A,CH,CS,E,MS,P
Hewlett-Packard de Venezuela C.A.
Calle-72-Entre 3H y 3Y, No. 3H-40
Edificio Ada-Evelyn, Local B
Apartado 2646
4001, MARACAIBO, Estado Zulia
Tel: (061) 80.304
C,E*

Hewlett-Packard de Venezuela C.A.
Calle Vargas Rondon
Edificio Seguros Carabobo, Piso 10
VALENCIA
Tel: (041) 51 385
CH,CS,P
Bioelectronica Medica C.A.
Calle Buen Pastor
Edif. Cota Mil-Piso 2 y Semi Solano 1
Boleita Norte
Apartado 50710 **CARACAS 1050A**
Tel: 239 84 41
Telex: 26518

ZIMBABWE

Field Technical Sales
45 Kelvin Road, North
P.B. 3458
SALISBURY
Tel: 705 231
Telex: 4-122 RH
C,E,M,P

July 1983 5952-6900
Indicates main office

HP distributors are printed in italics.



MANUAL PART NO. 5955-8868
Printed in U.S.A. January 1983
E0183

HEWLETT-PACKARD COMPANY
Data Systems Division
11000 Wolfe Road
Cupertino, California 95014