

GA33-1525-4  
File No. 4300-01

**Systems**

**Operator's Library:  
IBM 4321/4331 Processors  
Operating Procedures  
and Problem  
Determination Guide**

**IBM**

## Federal Communications Commission (FCC) Statement

**Warning: This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instruction manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.**

### Fifth Edition, October 1982

This is a major revision of GA33-1525-3 which is now obsolete. The information contained in this manual is subject to change from time to time. Any such changes will be reported in subsequent revisions or Technical Newsletters.

Changes are continually made to the information herein; before using this publication in connection with the operation of IBM systems, consult the latest *IBM System/370 and 4300 Processors Bibliography*, GC20-0001, for the editions that are applicable and current.

Any reference to an IBM program product in this document is not intended to state or imply that only IBM's program product may be used. Any functionally equivalent program may be used instead.

It is possible that this material may contain reference to, or information about, IBM products (machines and programs), programming, or services that are not announced in your country. Such references or information must not be construed to mean that IBM intends to announce such IBM products, programming, or services in your country.

Publications are not stocked at the addresses given below; requests for copies of IBM publications should be made to your IBM representative or to the IBM branch office serving your locality.

A form for reader's comments is provided at the back of this publication. If the form has been removed, comments may be addressed to:

International Business Machines Corporation  
Department 812B  
1133 Westchester Avenue  
White Plains, New York 10604

or to:

IBM Laboratories  
Dept. 3179, Product Publications  
Schoenaicher Strasse 220  
D-7030 Boeblingen, Federal Republic of Germany

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation whatever.

You may, of course, continue to use the information you supply.

## Preface

This manual is for use when operating the IBM 4321 or 4331 Processor. You are assumed to have a knowledge of *Introduction to IBM Data Processing Systems*, GC20-1684, and some experience in operating a similar computing system. The information in this manual is organized in the following way:

- Chapter 1 contains emergency and first aid procedures.
- Chapter 2 tells you about parts of the IBM 4321 or 4331 Processor which are used to communicate with, and control the system. The chapter describes the operator console and related facilities.
- Chapter 3 explains some routine operations on the IBM 4321 or 4331 Processor.
- Chapter 4 contains problem determination procedures.
- Chapter 5 contains reference information.
- Chapter 6 of the manual contains a glossary.



# Contents

<b>Chapter 1. Emergency Procedures</b> .....	<b>1-1</b>
Electric Shock .....	1-1
Artificial Respiration .....	1-1
Fire .....	1-1
<b>Chapter 2. Communicating with the System</b> .....	<b>2-1</b>
Operator Console .....	2-2
Display Screen of 3278-2A Console .....	2-2
Display Screen of 3279-2C Color Console .....	2-3
Screen Layout .....	2-3
Control Panel .....	2-4
Control Panel Lights .....	2-4
Control Panel Keys .....	2-5
Console Keyboard .....	2-6
Alphameric Keys .....	2-6
Cursor .....	2-6
Cursor Keys .....	2-7
Tabulator Keys, Backspace Key, Space Bar .....	2-7
Function Keys .....	2-8
Keyboard Lock and Keyboard Inhibition .....	2-11
Machine Status Display .....	2-13
Line 21 Display .....	2-14
Line 22 Display .....	2-16
Line 23 Display .....	2-17
Line 25 Display .....	2-18
System Diskette .....	2-20
Customer Set Up (CSU) for Displays and Printers .....	2-21
Disconnecting .....	2-22
Problem Determination .....	2-22
<b>Chapter 3. Procedures</b> .....	<b>3-1</b>
Loading the Control Diskette .....	3-2
Switching Power On .....	3-3
Switching Power Off .....	3-4
Loading the Microcode (IML) .....	3-5
Initial Program Load (IPL) .....	3-6
Mode Selection .....	3-7
Errors Made During Mode Selection .....	3-9
Fast Mode Selection .....	3-10
Address Compare .....	3-12
Check Control .....	3-15
Display/Alter .....	3-17
Control Registers .....	3-19
Current PSW (Program Status Word) .....	3-20
Floating Point Registers .....	3-22
General Registers .....	3-23
Storage Key .....	3-24
Main Storage .....	3-25
Main Storage Size .....	3-27
Capacity Counts .....	3-28
Main Storage Real .....	3-29
Main Storage Virtual .....	3-30
Page Description .....	3-32
Communication Lines .....	3-33
Start / Stop Lines .....	3-33
Synchronous Data Link Control (SDLC) Lines .....	3-36
Binary Synchronous Communication (BSC) Lines .....	3-39
Temporary Configuration Change .....	3-40
Instruction Step .....	3-44
Interval Timer .....	3-45
Machine Save .....	3-46
Program Load .....	3-47
Clear Reset .....	3-50
Reset I-Step .....	3-51
Program Reset .....	3-52

Restart	3-53
Store Status	3-54
TOD Enable	3-55
Native Displays and Printers	3-56
Configuration Rules and Limitations	3-58
Native User Diskette	3-59
Diskette Device Address	3-61
<b>Chapter 4. Problem Determination</b>	<b>4-1</b>
Procedure	4-1
Sense Byte Table	4-24
<b>Chapter 5. Reference Information</b>	<b>5-1</b>
Restart Procedures for the IBM 5424 Multi-Function Card Unit (MFCU)	5-1
Restart Information Field	5-1
Operator Restart Instructions	5-2
Procedure	5-2
00 Device not Ready	5-2
10 Read Check	5-3
12 Read Check and Print Check	5-3
20 Punch Check	5-3
21 Punch Check and Read Check	5-3
22 Punch Check and Print Check	5-4
23 Punch Check, Read Check and Print Check	5-4
30 Print Check	5-5
40 Hopper Check	5-5
42 Hopper Check and Print Check	5-5
50 Feed Check	5-5
51 Feed Check and Hopper Check	5-6
54 Feed Check and Punch Check	5-6
55 Feed Check, Hopper Check and Punch Check	5-7
60 Error on Recovery	5-7
Manual Calling on Integrated Modem WT Switched Line with Auto Answer	5-8
Connection Sequence	5-8
Disconnection Sequence	5-8
3340 String Switch	5-9
Conversion Binary to Hexadecimal to Decimal	5-10
Katakana Feature	5-11
Data Keys	5-11
Shift Keys	5-11
Messages	5-11
CA Configuration Charts	5-12
Line Address 30	5-13
Line Address 31	5-14
Line Address 32	5-15
Line Address 33	5-16
Line Address 34	5-17
Line Address 35	5-18
Line Address 36	5-19
Line Address 37	5-20
<b>Appendix A.</b>	<b>A-1</b>
Display Unit IBM 3279-2C Testing and Adjustment	A-1
Test Procedure	A-2
Color Convergence Procedure	A-5
Changing the Battery	A-8
<b>Glossary</b>	<b>X-1</b>
<b>Index</b>	<b>X-3</b>

## Chapter 1. Emergency Procedures

If people are endangered, or if equipment could be damaged, disconnect power to the system by pressing the relevant EMERGENCY POWER-OFF switch in the computer room.

### Electric Shock

1. If the casualty is still in contact with the electrical supply:
  - a. Disconnect the electrical supply, or
  - b. Remove the casualty from contact with the electrical supply by pulling at his *dry* clothing. Do not move the casualty unless it is necessary.
2. If the casualty has stopped breathing, apply mouth-to-mouth resuscitation *immediately* (see artificial respiration below).
3. Call for help.

### Artificial Respiration

1. Clear throat of water, food or foreign matter.
2. Tilt head back to open air passage.
3. Lift jaw up to keep tongue out of air passage.
4. Pinch nostrils to prevent air leakage when you blow.
5. Take a deep breath. Seal your mouth around casualty's mouth, blow until you see chest rise.
6. Remove your lips and allow lungs to empty.
7. Listen for snoring and gurglings, signs of throat obstruction.
8. Repeat mouth to mouth breathing 10 to 20 times a minute. Continue rescue breathing until casualty breathes unaided.

### Fire

*Do not use water to fight a fire in electrical equipment. Use only a fire extinguisher approved for this purpose, for example one that contains carbon dioxide (CO<sub>2</sub>). Follow the instructions on the extinguisher and call for help.*



## **Chapter 2. Communicating with the System**

This section describes the parts of the IBM 4321 or 4331 Processor that you, as an operator, will use in your work.

## Operator Console


The operator console is a device used to control the IBM 4321 or 4331 Processor.

It consists of:

- *Display Screen*
  - to provide information from the system, in the form of messages and displays. The information that you enter into the system also appears on the screen. A permanent display of the status of the IBM 4321 or 4331 Processor is shown in the lower part of the screen.
- *Console Keyboard*
  - for entering commands and data into the system.
- *Control Panel*
  - with lights and buttons for functions that cannot conveniently be handled by the keyboard and display screen.


The operator console may be a 3278-2A (one-color display) or a 3279-2C (four-color display). The console does not provide printed output. The optional 3287 Model 2 printer may be used to supply printouts of messages.

### *Display Screen of 3278-2A Console*



For a description of the lights and switches shown above, see *IBM 3270 Information Display System Operator's Guide, GA27-2890*.


## Display Screen of 3279-2C Color Console



For a description of the lights and switches shown above, see *IBM 3270 Information Display System, 3279 Color Display Station, Operator's Guide, GA33-3057*.

### Screen Layout

The display screen displays numeric characters, alphabetic characters and special symbols. It is equipped with an audible alarm that alerts you to messages requiring your attention. During operation the security keylock must be in the "on" position. The format of the screen is shown below.



**A System Area:**


The system area of the screen displays messages from the operating system. It is also used when the operator communicates with the system.

**B Machine Status Area:**

This area displays information about the status of the IBM 4321 or 4331 Processor.

**Control Panel**

On the control panel are the following lights and keys that allow you to check and control basic machine functions.



**Control Panel Lights**

**Basic Check:**

The red BASIC CHECK light indicates a failure in the processor. There is a danger of data being destroyed. Save the status of the machine and call the service representative. The BASIC CHECK light is also on when the power-service mode switch is in "service" position. The power-service mode switch is located in the IBM 4321 or 4331 processor and can be operated only by service personnel.

**System:**

The green SYSTEM light is on when instructions are being processed or when I/O operations are in process.

**Wait:**

The amber WAIT light is on when the wait bit in the current PSW is set. This means that the processor is idle, that is, not processing instructions or handling I/O operations. The setting of the wait state is controlled by the operating system. Usually the processor awaits the completion of data transfer from an I/O device. The processor leaves the wait state upon an interruption.

***Power in Process:***

The POWER IN PROCESS light indicates that a power-on, or power-off sequence is in progress.

***Power Complete:***

The green POWER COMPLETE light comes on when the power-on sequence is completed.

**Control Panel Keys**

***IML:***

Pressing this key while power is on starts the IML (initial microcode load) sequence.

***Lamp Test:***

The LAMP TEST key tests the control panel lights and the lights of the IBM 5424 Multifunction Card Unit (if installed). When this key is pressed, the check lights on the panel turn on. The lights go out when the key is released.


***Power Off:***

The POWER OFF key starts the power-off sequence. If during this sequence a power failure is detected, a reference code is displayed and the power-off sequence is halted, however, power is not turned off. Note the reference code for the service representative's use and press POWER OFF a second time to complete the power-off sequence.

The power-off sequence can also be initiated by operating the POWER-ON/OFF toggle switch located at the righthand side of the IBM 4321 or 4331 Processors. Note: The power-off sequence clears the contents of all storages. Power off is complete after 5 - 7 seconds.

## Console Keyboard

At the console keyboard you enter commands and data into the system. The keyboard has the following layout:



 Only active when ALT key is pressed at the same time

 Typamatic key

The keyboard has three types of keys:

- Alphameric keys
- Cursor and tabulator keys, backspace key, and space bar
- Function keys

The keys and their functions are described on the following pages.

### Alphameric Keys

The alphameric keys are used to enter messages and data, and to call up displays. These keys are typamatic, that is, they repeat their function as long as they are held down. The second character on some alphameric keys can only be used in conjunction with the SHIFT or the ALT key (see "Function Keys"). The position of the alphameric keys on the keyboard is shown above.

### Cursor

The cursor is a light-marker on the screen that indicates where the next character to be entered will appear.

- When a character is entered, it appears just above the cursor.
- The cursor is automatically positioned ready for the next entry.
- You can position the cursor manually by means of the five cursor keys. To prevent interference with internal operations, these keys can be locked. For example, during IML, or when the cross indicator (see "Machine Status Display," line 25) is on the screen, you cannot free these keys. The system


returns them to your control when the internal operation is completed.

- The five cursor keys are typamatic, which means you can “run” the cursor by holding the key down. When the cursor reaches the edge of the screen, it returns (or wraps around) to the opposite edge of the screen and continues moving in the same direction as long as the key is held down.
- To alter data displayed on the screen, position the cursor under the data to be changed, type in the new data, and press ENTER.
- The cursor can be moved by the space bar and the backspace key.

## Cursor Keys

The cursor can be moved in the following ways:

### *Cursor to New Line:*



The cursor moves to the first unprotected character position (\*) in the next lower line, traversing all protected lines before finally returning to the first line with an unprotected character position.

### *Cursor Up:*



The cursor moves upward in the same character column. Finally it returns to the bottom of the screen and repeats the same path upwards.

### *Cursor Down:*



The cursor moves downward in the same character column. Finally it returns to the top of the screen and repeats the same path downwards.

### *Cursor to Left:*



The cursor moves right to left and line by line upwards. Finally it returns to the bottom right-hand corner of the screen and repeats the same path. The backspace key performs the same function as the cursor-to left key.

### *Cursor to Right:*



The cursor moves left to right and line by line downward. Finally it returns to the top left hand corner of the screen and repeats the same path.

## Tabulator Keys, Backspace Key, Space Bar


These keys cause the cursor to move in the following ways:

### *Tabulator:*



The cursor moves right to the first unprotected character position. If held down, it traverses all first character positions of unprotected fields in a left-to-right, top-to-bottom direction. Finally it returns to the leftmost character position of the topmost unprotected field.


### ***Back Tabulator:***



The current position of the cursor affects the operation of the back tabulator key. When the cursor is in an input field at a location other than the first character position, the back tabulator key repositions it to the first character position in the field. When the cursor is in a protected field, or at the first character position of the input field, the back tabulator key repositions it to the first character position of the first input to the left of the present field.

Using this key together with the ALT key repositions the cursor to the home position, that is to the first unprotected position on the total display.

### ***Backspace:***



The cursor moves right to left and line by line upward. Finally it returns to the bottom right-hand corner of the screen and repeats the same path. The cursor-to-left key performs the same function as the backspace key.

### ***Space Bar:***

The cursor moves to the right and inserts a blank character.

## **Function Keys**

### ***Mode SEL/DIAG:***



Pressing MODE SEL causes the mode selection display to appear on the screen. This display lists the available operating modes. These modes, and how to use them, are described in Chapter 3.

Mode selection can be requested at any time; it does not affect the state of the machine other than breaking into a chain of messages that is about to be written onto the screen. The display on the screen when MODE SEL is pressed is automatically stored by the system and can be recalled later. Do not, however, keep this display, nor any other manual operations display, on the screen any longer than necessary as, during this time, the system can neither use the screen nor record errors.

The DIAG (diagnostic) function of this key is for service personnel only. For operation of this key during a color convergence test, see Note following description of CHG DPLY.

### ***CNCL:***



CNCL (cancel) is used to stop operations that have been started but not completed (the ENTER key has not been pressed). The operation is terminated according to the mode that the screen was in when data entry started:

- If the screen was under control of the system, and if the command set is 3270, the message or reply is deleted. If the command set is 1052, the message or reply is marked with an asterisk.
- If the screen was in manual operations mode, the display is deleted, control returns to the system and the last full picture that was displayed before manual operations began is restored to the screen. For operation of this key during

a color convergence test, see Note following description of CHG DPLY.

### **CHG DPLY:**



The CHG DPLY (change display) key causes the screen display to change from the system message buffer to the manual operations buffer, and vice versa. During system operation, the screen and keyboard are made available to the operating system. During manual operation the screen and keyboard (except START, STOP and INTR) are made available for manual operation.

### **Note on Color Convergence:**

When a color convergence test is running on another terminal attached to your 4321 or 4331, you will get an abnormal response to pressing MODE SEL/DIAG, CNCL, or CHG DPLY. Instead of the expected result, the message MODE SEL CANCELS CONV comes up. If you press MODE SEL while this message is on the screen, MAN OP is displayed and manual operations can be carried out. Note, however, that the color convergence test on the other terminal is terminated. If you press DIAG, CNCL or CHG DPLY, the message CONVERGENCE ON PORT nn is displayed but there is no further action.

### **INTR/Line Disc:**



The INTR (interrupt) key is used to request an external interruption.

The LINE DISC (line disconnect) function of this key is for service personnel only.

### **Erase Input:**



Pressing the ERASE INPUT key erases all input fields on the screen. The cursor moves to the first character location available for entering data.

### **Erase EOF / SP M/O:**



Pressing the ERASE EOF (Erase End of Field) key erases character positions in the input field in which the cursor is located. All character positions from the cursor location to the end of the field or line are erased. The cursor does not move. The SP M/O function of this key is for service personnel only.

### **REQ / Comm REQ:**



The function of the REQ (request) key depends upon the command set being used:

- When the 1052 command set is being used, the keyboard is normally locked. It is freed when the system executes a read inquiry command which is invoked by pressing the REQ key.
- When the 3270 command set is being used, the REQ key requests an Attention Interrupt.

The COMM REQ (communication request) function of this key is for service personnel only.

### ***Copy:***



Pressing the COPY key during manual operations (MAN) produces a printed copy of the screen contents (all lines except line 25). The copy is printed by the 3287 console printer (if attached) on the port with the lowest address.

**Note:** Programmed operations on the 3287 terminal printer have priority over the COPY key function. This means that the COPY key has no effect when the print buffer contains data that has not yet been printed. The COPY key becomes effective as soon as data in the print buffer has been printed. If there is a dead-lock (such as, the print program hangs, or a similar error), the power switch on the printer should be turned off and on again. This action resets the entire print buffer and enables the COPY key function.

### ***Shift:***



There is a SHIFT key on each side of the keyboard. Both SHIFT keys serve the same purpose. Pressing a SHIFT key causes:

- The upper character of a key with two characters to be entered.
- The upper case of an alphabetic character to be entered.

The shift symbol is displayed in line 25 when this key is depressed. In TEST mode the symbol is not displayed.

### ***Lock:***



Press the LOCK key to shift and lock the keyboard in upper case. To release the shift lock, press one of the SHIFT keys. The shift symbol is displayed in shift lock mode.

### ***Reset:***



Press RESET to free the keyboard when it is locked. When the WAIT indicator is shown (because some action was initiated), the Reset key will cancel this action. See also Problem Determination Guide located in the keyboard.

### ***Start:***



Press START to start the processor. Instructions are processed in two modes:

- Instruction step mode - one instruction is processed each time START is pressed (See "Instruction Step" in Chapter 3.)
- Continuous processing, for example when START is pressed after a normal pause in system operation.

***Stop:***



Press STOP to stop program execution. The system stops when processing of the current instruction and any I/O operation in progress is completed and after waiting interrupts have been serviced.

***Insert Mode:***



Use this key before you insert characters into existing information displayed on the screen. Thereafter, characters can be inserted into already existing text whereby all characters to the right of the insert mark are automatically shifted as additional characters are typed in. This allows for entering characters without retyping the entire text. Press RESET, ENTER, or any program function (PF) key.

***Delete:***



This key is used to delete characters from displays without leaving a blank. Zeros are inserted into the end of the field.

***ALT:***



Use ALT when the alternative function of keys with functions on keyface is required. Hold down ALT and press the appropriate function key.

***Enter:***



When you press ENTER, the data that you have typed into the display is accepted by the system. Until you press ENTER, the data can be changed.

**Keyboard Lock and Keyboard Inhibition**

The status of the keyboard depends mainly on the mode of operation.

- 3270 Mode

In 3270 mode the keyboard is normally free to type in data until the operator initiates a system operation, which inhibits the keyboard, that is, the keyboard does not accept any further input until the initiated operation is completed. The keyboard is also inhibited when data entry into a protected field is attempted. The reason for inhibition is shown on line 25. The reset key is used to reset the inhibition.

- 1052 Mode


In 1052 mode, the keyboard is normally locked and it must be unlocked by a read inquiry command which is usually issued by the operating system when the REQ key is operated. In locked state, the cursor is displayed in the upper lefthand corner. Operating the RESET key does not change the locked state. The read inquiry command displays the cursor in line 19 position 2, sounds the audible alarm, and PROCEED is displayed. Any inhibit state of the keyboard is displayed on line 25. Inhibition due to errors (such as writing into a protected field) may be reset by the RESET key. However, when a system action has been initiated (e.g. the REQ key has been pressed) and the wait indicator is on, the RESET key resets not only the keyboard but also cancels

the requested action. The following system keys are never locked or inhibited:

- STOP
- INTR
- MODE SEL
- DIAG

## Machine Status Display

The last five lines on the display screen show the status of the system. Some indicators in the display remain constant, and some change during processing, but the machine status is always on the screen (*except* during maintenance displays). The machine status area is a protected area. Its layout is shown below, followed by a table explaining each status indicator.



Line 21	MAN (TEST) (LOAD) ( 1MB) (370 )TIMER: (OFF) SYSDSK COMP DATA:XXXXADDR:XXXXXX (CHECKSTOP) (bbbb) (SAVE) ( 2MB) (VSE) (ON ) DISK bbbb (IPL-ERROR) (bbbb) ( 4MB) ( 8MB) (16MB) (REAL)						
Line 22	RATE:I-STEP CHK-CTL:HARD TOD:(SEC)ADDR-COMP:(STOP)TYPE:(ANYREF)(R-ADDR:)XXXXXX (ENBL) (SYNC) (I/OREF) (ADDR:) (D-STOR) (I-CNTR)						
Line 23	(SP MESSAGES) (CA/ILT STATUS, REF, CODE) (LOG PENDING) (TIMEOUT ADDR: , REF, CODE) (I/O ERR. ADDR: , REF, CODE XXXXXXXX) (LOOP MSG)						
Line 24	RESERVED FOR SERVICE PERSONNEL						
Line 25	1 - 6	9 - 15	16 - 19	30 - 37	39 - 41	44	58 - 64
	IA TEST	     		3270 1052 MAN OP 力+	NUM 		  

## Line 21 Display

### *MAN:*

The system has been stopped by:

- Pressing STOP
- Manual operations (for example, Instruction Step or Address Compare).

MAN does not appear under the following conditions:

1. When the system is running.
2. When the system is in wait state (unless STOP is pressed).
3. When the system is in CHECK STOP state. After a maintenance display, MAN does not have the same status as before the display.

### *Check Stop:*

A check-stop has occurred.

The next instruction address can be seen by displaying the PSW. After a maintenance display, CHECK STOP does not show the same status as before the display.

**Note:** Enter "P" (Program Reset) before carrying out manual operations.

### *IPL Error:*

A valid PSW cannot be loaded (for example, when the load device is not ready, or an invalid address was specified).

If an IPL number is displayed, go to the IPL malfunction flowchart for details.

### *Test:*

TEST appears when:

- Instruction step mode is set
- Address Compare mode is set
- Check control mode other than "normal" is set
- An in-line test is running

TEST does not appear for program initiated test such as online tests (OLTs) or the stand alone executive program (OLTSEP), or program event recording. It is also off during log operations.

***Load:***

An IPL Load operation has been started.

LOAD remains on the screen until a valid PSW has been loaded.

***Save:***

Machine SAVE has been completed successfully.

***1MB, 2MB, 4MB, 8MB, 16MB, REAL:***

Gives the size of addressable storage when IML is performed in VSE mode.

Storage size appears only for VSE mode after Power On, Reset, or Reset Clear.

***Timer: Off/On:***

The interval timer (AT LOCATION 80) is enabled (ON) or disabled (OFF).

***SYSDSK:***

The system diskette requires attention.

***Disk:***

The diskette drive requires attention.

***COMP:***

The processor has stopped because "Address Compare" mode is on and the matching address has been found.

***Data:***

Shows the half-word stored at the storage location indicated by ADDR.

After a maintenance display, ADDR and DATA do not show the same status as before the display.

***ADDR:***

Shows storage address of the next instruction to be executed.

## Line 22 Display

### ***Rate: I-Step:***

Instruction step mode is set.

### ***CHK-CTL: Hard:***

Check control mode is set.

### ***TOD: SEC/ENBL:***

The time of day clock is secure/enabled. Secure indicates that the TOD clock cannot be altered by the SET CLOCK instruction. Enable means that the TOD clock can be altered.

### ***Addr-Comp: STOP, SYNC:***

Indicates the type of action to be performed when the address match occurs.

### ***Type: ANY REF, I/O REF, D-STOR, I-CNTR:***

Indicates the type of storage reference for which address comparison is performed.

### ***R-ADDR:***

### ***ADDR:***

Indicates the address that is compared with all storage references of the type indicated under TYPE.

ADDR appears if the processor is in ECPS:DOS/VS mode. R-ADDR (real address) appears if the processor is in System/370 compatibility mode.

## Line 23 Display

### *SP Messages:*

#### *LOG Pending:*

Messages to service personnel. Appears when customer manual operations are performed and a log is pending.

Can be any message to service personnel originating in the processor hardware.

#### *CA/ILT.*

Shows the status of the communications adapter. Reserved for service personnel.

#### *Status, REF Code:*

Shows status and reference code of current diagnostic program. This information is for service personnel. The reference code may also be caused by an I/O error or interface error.

The reference code remains on the screen only if checkstop occurs. If the system recovers successfully, the reference code disappears. It can be displayed again by pressing the CHG/DPLY key.

#### *Timeout Addr: , Ref. Code*

Indicates the address of a device that did not respond in time. If the address field points to a tape device, a tape reel with empty (new or erased) tape may have been mounted.

#### *I/O Err. Addr: , Ref.Code XXXXXXXX*

Indicates the address of a device in error, possibly a disk track error. Use alternate track assignment.

The four bytes of reference code have the following meaning:

Byte	3340/44	231X
1	Cylinder	Cylinder
2	Head addr.	Track addr.
3	Emulated dev.	Reserved
4	Reserved	Reserved

#### *Loop Msg*

Indicates that a loop message which requires your attention has been recorded. See *Operator's Library IBM 4331 Processor Multiuse Communications Loop Operating Procedures*, GA33-1538.

## Line 25 Display

### *Test:*

“TEST” mode is used for in-line tests.


If you should enter this mode by mistake, keep the ALT key pressed down and press COPY to return to normal mode.

### *Insert Indicator:*

The operator console is in insert mode.

This indicator turns on when you press INSERT. Press RESET or ENTER, or any of the PF keys to turn it off.

### *Wrong Place Indicator:*



The keyboard is locked (except for the RESET key).

An attempt has been made to enter, insert, or delete a character when the cursor was in a protected field on the screen. Press RESET to unlock the keyboard.

### *Wait Indicator:*



The system has locked the keyboard because a function key such as CNCL, REQ, or PF1-24 has been pressed but the corresponding program interruption has not yet occurred.

Before the interruption occurs you can still unlock the keyboard by pressing RESET.

### *Shift Indicator:*



The SHIFT key is depressed.

Release the SHIFT key, or reset the SHIFT LOCK to terminate the function.

### *Online Indicator:*



The operator console is ready and connected to the system under A rules as defined by the 3270 system.

The indicator stays on as long as the screen is online.

### *Minus Symbol:*



The symbol keyed in is not available.

Press RESET to restore the keyboard.

### *Minus Function:*



Requested function is not available.

Press RESET to restore the keyboard.

**Security Key:**



When this symbol is displayed no operator input can be accepted.

**Too Much Data:**



An attempt has been made to enter too much information into a field. Press RESET to unlock the keyboard.

**What?:**



The previous input was not accepted.

Because of uncertainty about what was accepted, the screen contents should be checked before the operation is repeated.

**3270:**

3270 is displayed when the console works in 3270 operation mode.

**1052:**

1052 is displayed when the console works in /360 system 1052 emulation mode.

**MAN OP:**

MAN OP is displayed when the console works in manual operation mode. MAN OP is the only mode in which the console test can be started.

**Katakana:**



When this symbol is displayed, Katakana mode has been set by pressing a shift key on the keyboard of a 4321/4331 which has the Katakana language option.

**Printer Not Working:**



The 1052 slave printer is not functioning (unplugged, out of paper, or has failed during printing).

**Note:** Does not come up for print operations requested by pressing the COPY key.

Resets with Power-On-Reset of the attached printer.

**Printing:**



Appears as long as the printer is printing. Does not come up for print operations requested by pressing the COPY key.

## System Diskette

The system diskette provides services for control, testing, error diagnosis and logging. There are two diskettes:

- Control Diskette
- Diagnostic Diskette

both containing information vital to the functioning of the system. To safeguard this information, avoid the following:


- Rough handling of the diskette.
- Handwriting on the diskette (do not write on the diskette cover with the diskette inside it).
- Pressure on any part of the diskette.
- Strong, direct sunlight on the diskette.
- Attempts to clean the diskette in any way.
- Exposing the diskette to magnetic fields (Keep it away from metal objects).
- Touching exposed surfaces of the diskette.

Inform the service representative if the diskette is damaged in any way.


Under normal conditions the system diskette remains in the drive unit and need not be handled.

## Customer Set Up (CSU) for Displays and Printers


The IBM 4321 or 4331 Processor has a customer access area to enable the customer to connect CSU equipment such as display units, matrix printers, and line printers. The customer access area is located at the bottom left-hand side of the processor opposite the system diskette.



Connector for the coaxial cable must be a Bendix 3022-3 or equivalent.



Switch power off. Run the cable under the bracket and plug the connector into the appropriate receptacle as shown.



When you have connected the device, you have to provide the system with information on this connection. The procedure "Native Displays and Printers" in Chapter 3 of this manual tells you how to do this.

### ***Disconnecting***

To disconnect CSU equipment, switch power off and pull out the Bendix or equivalent connector.

### ***Problem Determination***

If physical installation and the procedure "Native Displays and Printers" have been carried out, and the line printer does not operate, check if "intervention required" is indicated. The indication "intervention required" varies from one operating system to the other.

The following conditions cause "intervention required" to be indicated when the line printer is in the ready state:

- Open coax cable
- Line printer not logically connected

CAUSE	ACTION
<p>Open coax cable (the CPU interface light at both line printers is off)</p> <p>Line printer not logically connected</p>	<p>Switch power off. Connect the coax cable to the defined port, or repair the coax cable</p> <p>For 3262: Press the Test key.</p> <p>For 3289: Press the Reset switch.</p> <p>Or, for both line printers: Invoke "Program Reset", or re-IML.</p>

If this action is unsuccessful, call the service representative.



## **Chapter 3. Procedures**

**This section describes manual operations on the IBM 4321 or 4331 Processor.  
The information is divided into procedures.**


## Loading the Control Diskette

For machines without the "diskette drive" feature, the control diskette is located in the drive unit accessible from the table top of the IBM 4321 or 4331 Processor. Any handling of the control diskette is not required except by the service representative. The control diskette must never be removed, nor must the sliding door be opened while the system is in operation.

For machines with the "diskette drive" feature, the control diskette is under the covers of the IBM 4321 or 4331 Processor, while the drive unit accessible from the table top is available for I/O operations.

Before loading the diskette, check that it is undamaged. Do not use a damaged diskette until a service representative has inspected it.

1. Depress the latch of the sliding door and open the sliding door at the table top. This automatically opens the mounting plate of the diskette.
2. Grasp the diskette by the white label and remove it from its envelope.
3. Lower the diskette carefully into position behind the mounting plate until it comes to rest on the locating surfaces.




4. Close the sliding door fully. This will close the mounting plate automatically. The centering cone must slide freely into the center of the diskette. If not, check that the diskette is seated against the locating surfaces and that it is undamaged.
5. Store the empty diskette envelope where it will not become damaged or dirty.
6. If a diskette has been exposed to temperatures outside the machine's environmental range, allow five minutes before use.
7. When receiving diskettes, check for carton and diskette damage.

## Switching Power On

Before switching power on, ensure that no person is exposed to risk and that all equipment covers are shut. Also ensure that power switch on the display console is in the "on" position and the Normal/Test switch is set to "Normal." If the Normal/Test switch is in the "Test" position the console is not available for the program and forces a "wait" condition.

Press the power-on toggle switch at the righthand side of the 4331 Processor. Above this power-on switch is a red power-active lamp that comes on about one second after the switch has been pressed. At this time the POWER IN PROCESS lamp on the control panel also comes on.

The 4321 or 4331 Processor does not distribute AC primary power to the attached I/O devices. Each type-numbered unit has its own power-on switch and its own power-cord. In most cases power must be turned on at each unit individually (except when the power interface feature is installed, in which case the connected units power-up together with the processor). On some units, such as the 3310 disk drives or the 8809 tape drives, the optional power interface cannot be installed. You must turn on power at the power switches of these units.



## Switching Power Off


The system power must always be switched off at the processor before power is switched off at the I/O devices. The reason for this sequence is that some devices (3310, 3340, 3370) maintain error and usage counters, which would be lost if power were switched off at these devices first.

The following procedure ensures that all error and usage counters are saved on the system diskette before power is switched off.

1. Ensure that all jobs have been completed.
2. Wait until the Wait light on the console comes on.
3. Press STOP on the control panel and wait until the MAN indicator (manual mode) appears on the screen.
4. Press the Power Off key on the control panel. The processor will save all counters before it starts the power-down cycle.
5. Switch the power off at the I/O devices.

## Loading the Microcode (IML)


The microcode controls processor operations and must be loaded into control storage before any other program can be loaded. All microcode is contained on the system diskette and is loaded when you switch POWER ON or press the IML key on the control panel.



*Note:* Do not press any keyboard keys at the console while IML is in progress.

## Initial Program Load (IPL)

The initial program load (IPL) procedure causes the operating system to be loaded. The IPL procedure can also be used for loading stand-alone programs.



## Mode Selection

There are two modes of operation for the 4321 or 4331 Processor:

1. System operation mode, in which instructions and I/O operations are executed under program control.
2. Manual operation mode.

Mode selection enables you to stop or suspend the system operation mode and enter the manual operation mode.


The manual operations described in this section allow you to display and change certain control information and data. These operations are listed below and the associated operating procedures are given on the following pages. Column 1 in the list gives the names of the manual operations; column 2 shows the selector character used to call up the display. Columns 3 and 4 show the manual operations that apply to 370 and VSE.

Col.1	Col.2	Col.3	Col.4
Manual Operation	Selector Char.	VSE	370
Address Compare	A	X	X
Check Control	K	X	X
Display/Alter	D	X	X
Capacity Counts	S	X	-
Control Registers	C	X	X
Current PSW	P	X	X
Floating Point Regs	F	X	X
General Registers	G	X	X
Storage Key	K	-	X
Main Storage	V	X	-
Main Storage Real	M	-	X
Main Storage Virtual	V	-	X
Page Description	D	X	-
Page Down	+	X	X
Page Up	-	X	X
Main Storage Size	S	-	X
Communication Lines	E	X	X
Instruction Step	I	X	X
Interval Timer	J	X	X
Machine Save	S	X	-
Native Displays and Printers	M	X	X
Program Load	L	X	X
Restart	R	X	X
Clear Reset	C	X	X
Reset Instruction Step	N	X	X
Program Reset	P	X	X
Store Status	S	-	X
TOD Enable	Y	X	X
User Diskette Control	G	X	X
Diskette Device Address	H	X	X
Loop Adapter	F	X	X
	(see Note)		

To call up a display, first press MOD SEL. This brings the "mode selection" display to the screen. Listed in this display are the manual operations available in the IBM 4331 Processor, and next to each is a selector character.

**Note:** The loop adapter display is not described in this manual. See *Operator's Library IBM 4331 Processor Multiuse Communications Loop Operating Procedures*, GA33-1538.

Here is an example of the mode selection display:



Type the selector character for the desired operation into the “mode selection” display after the word SELECTION at the bottom of the screen and press ENTER.

For the manual operations listed on the left of the screen, entry is now complete. The mode is operational.

For the manual operations listed on the right of the screen, the above procedure calls up a separate display in which additional selection characters may be entered. The following pages describe how to use these displays.

### ***Errors Made During Mode Selection***

When you have pressed ENTER, the system checks your entries and displays the following messages if it detects an error:

**Invalid Character:** the first character entered is not one of the selector characters shown in the display. The “MODE SELECTION” display remains on the screen and the cursor indicates the error. To complete selection enter the correct selector character.

**Incomplete Entry:** No character was entered, or the input was incomplete. To correct the error, enter the complete specification.

## Fast Mode Selection

“Fast Mode Selection” enables you to type in all specifications for a mode at once without going through the selection procedure picture by picture.

1. Press MODE SEL. The “mode selection” display will appear.
2. Type in the mode selector character (col. 1 in list).
3. Type in your mode specifications (one character from each group in col. 2 plus an address if required).
4. Press ENTER.

A quick-reference list of the specifications is given below.

**Note:** Do not insert blanks or commas between characters.


MODE	MODE SPECIFICATION CHARACTERS	
	Col.1	Column 2
Add- ress Comp- are	A	1. N=Normal S=Stop Y=Sync 2. A=Any C=Instruction Count D=Data Store I=I/O Data 3. Storage Address=Six-digit hexadecimal number
		Example: AS15FA0 Tells the system to compare address 005FA0 to the addresses used during I/O data transfer, and to stop when a match occurs.
Check Con- trol	K	N=Normal S=Hard stop
		Example: KS Tells the system to enter the check stop state when a machine or channel check occurs.
Commun. Lines	E	Allows to change the values of certain options for communication lines.
Inter- val Timer	J	N=On F=Off
		Example: JN Tells the system to turn on the interval timer.

MODE		MODE SPECIFICATION CHARACTERS
	Col.1	Column 2
Dis- play/ Alter	D	<p>1. G=General Registers  C=Control Registers  P=Current PSW  F=Floating Point Registers  *D=Page description (VSE mode only)  *K=Storage Key (370 mode only)  S=Capacity Counts (VSE mode only)  S=Main Storage Size (370 mode only)  *V=Main Storage  *M=Main Storage Real (370 mode only)  *V=Main Storage Virtual (370 mode)</p> <p>*Plus six-digit hexadecimal storage address.</p>
		Example: DV0019FA
Pro- gram Load	L	<p>1. 0-5=Channel  2. 0-F=Control Unit  3. 0-F=Device  4. P=Reset Program  C=Reset Clear  5. V=VSE Mode  3=370 Mode  6. M=Maximum Storage Size  R=Storage equals real storage size  1,2,4,8=Megabytes of storage  7. Y=1052 Mode  N=No 1052 support  8. 1-8=Functional Adapter Buffers  0-8=Emulator Buffers  9. R=3211 Emulation  S=2314 Emulation  10. Six-digit hexadecimal address for host for emulated device.  11. Y=Log  N=No log</p>
		Example: "L09CP" Tells the system to load from device 09C with program (P) reset.

## Address Compare

The “address compare” display allows you to stop the machine when a reference to a specific main storage location is made during system operation. This feature is useful, for example, in finding and diagnosing system errors. Address Compare stops are possible on real addresses only.

For virtual addresses in System /370 Mode, use the Display/Alter Main Storage Virtual (DV) option (see “Main Storage Virtual” in this chapter) to display the corresponding real address and work with that address.



To select and set “address compare”:

1. Press MODE SEL to call up the “mode selection display” and enter an A after the word SELECTION at the bottom of the screen.

2. Press ENTER.

3. Enter one of the following three codes under FUNCTION:

- N (Normal) The address compare mode is turned off and normal processing continues.
- S (Stop) The machine stops when the address has been found (see “Compare Type,” step 4 below, for the search conditions).
- Y For maintenance purposes only. A synchronization pulse is issued when the address match occurs. The machine does not stop.

4. Enter one of the following four codes under COMPARE TYPE:
  - A (Any) The search address given in column 3 is compared with all addresses used in any references to storage.
  - C (Instr Count) The search address is compared only with addresses used for fetching instructions.
  - D (Data Store) The search address is compared only with addresses used to store data.
  - I (I/O Data) The search address is compared only with addresses used in transferring data between main storage and I/O devices.
5. Enter the search address under STORAGE ADDRESS. This can be up to six hexadecimal characters. If you enter less than six digits, the processor supplies the appropriate number of leading zeros to make a six-digit number.

All addresses can be compared, including those where the processor stores updated information. If, for example, you select address 80 (where the interval timer is stored) a match occurs each time the interval timer is updated, and the processor then stops.

**Error Messages:**

**Invalid Character** is displayed if you enter either an incorrect selector character or a non-hexadecimal character as address.

**Invalid Address** appears if you specify an address that is outside main storage size.

**Incomplete Entry** is displayed, and the cursor is set below the next character if, during fast selection, you specify incomplete specifications.

6. Press ENTER. The “address compare” display disappears from the screen, and your specifications are displayed in line 22 of the Machine Status Area as a reminder that address compare mode is set.
7. The processor stops after completion of the instruction that was in progress when the address match occurred. The effect is the same as if the Stop key had been pressed. When the Start key is subsequently pressed, processing continues with the next sequential instruction.

*With instruction count mode* set as address compare criterion, the processor stops always upon completion of the instruction that caused the address match.

When the location of a branch instruction is the address compare target, the stop occurs upon completion of the branch instruction, that is, after the branch is taken. When the Start key is subsequently pressed, operations resume at the next sequential instruction if no branch was taken, or at the branch address if the branch was taken.


**Note:** When the location of the instruction that immediately follows the branch instruction is the address compare target, then two stops are provided for the seven most commonly used branch instructions. The first stop occurs after the branch is taken (provided the instruction does branch). The second stop occurs at the actual address compare target, that is, at the instruction that would have been executed next if no branch had occurred. The stop occurs at the completion of that instruction.

The following branch instructions have two stops:

BAL, BALR, BCR, BXH, BXLE, BCT, BCTR

## Check Control

The “check control” mode allows you to preset the system’s response to machine checks. The current check control mode is shown in line 22 of the machine status area.



To select “check control” mode:

1. Type K into the “mode selection” display after the word SELECTION.
2. Press ENTER. The screen picture changes to the “check control” display (see example above).
3. Enter one of the following selector characters into the display:

**N** (Normal) This code causes the previously selected check control mode to be turned off.

**S** (Hardstop) This code causes the machine to enter the “checkstop” state as soon as possible after the detection of a machine-check or channel-check condition. A machine-check interruption is any machine error that would cause a machine check interruption in normal mode. A channel check is any machine error that would cause an I/O interruption indicating Channel Control Check, Interface Control Check or Channel Data Check in normal mode.

(Note that a check-stop requires a program or clear reset to recover).

**Error Message:**

**Invalid Character indicates a selector character other than "N" or "S."**

## Display/Alter

“Display/Alter” mode allows you to display and/or alter values in the processor. The values that you can display and alter are listed as options shown in the example below. The procedure following it explains how to use the display.

* DISPLAY/ALTER*	VSE Mode
G GENERAL REGISTERS	
C CONTROL REGISTERS	
P CURRENT PSW	
F FLOATING POINT REGISTERS	
D PAGE DESCRIPTION	
S CAPACITY COUNTS	
V MAIN STORAGE	
	370 Mode
G GENERAL REGISTERS	
C CONTROL REGISTERS	
P CURRENT PSW	
F FLOATING POINT REGISTERS	
K STORAGE KEY	
S MAIN STORAGE SIZE	
V MAIN STORAGE VIRTUAL	
M MAIN STORAGE REAL	
*MAIN STORAGE DISPLAY*	
+ PAGE UP	
- PAGE DOWN	
SELECTION:	ADDRESS:

To select “Display/Alter”:

1. Type D after the word SELECTION.
2. Press ENTER.

The program stops and the “Display/Alter” menu appears on the screen.

To call up a specific option:

1. Type the selector character for the option into the display after the word SELECTION, for example G for the general registers.
2. Press ENTER.

The display for the selected option appears on the right of the screen while the “alter/display” menu remains on the left. Data is displayed in two fields:

### Data Field

The current data in the displayed facility appears on the screen in the data field.

## **Alter Field**

New data entered from the keyboard appears in the alter field, which is one line below the data field (and appears blank prior to any data insertion).

To change data in a selected option:

1. Position the cursor in the alter field and under the character to be changed, that is, one line below the character displayed.
2. Type in the new character. It will appear underneath the current character which continues to be displayed.
3. Press ENTER. The new character moves up from the alter field into the display field and replaces the old character. At the same time it is stored in the system.

**Note:** Selecting any of the options causes the processor to stop. For this reason START must be pressed to resume operations, regardless of whether any alterations have been made or not. The displayed facility remains on the screen until the Cancel (CNL) key (or Change Display Key) is pressed.

## **Error Messages:**

**Invalid Character** indicates an invalid selector, hexadecimal or binary character.

**Incomplete Entry** appears and the cursor is set below the next character to be specified if, during fast selection, you entered incomplete specifications.

**Invalid Address** indicates an address that exceeds the storage size of your machine.

**Check Stop.** If a CHECK STOP occurs and the selected function was not reset it may be caused by a PSW loop. You can recognize a PSW loop only by two symptoms which are "lack of activity with SYS indicator on ..." and "the stop key does not work." In this case perform PROGRAM RESET and check the PSWs.

## Control Registers

The “Control Registers” display allows you to examine and change the contents of the control registers.

* DISPLAY/ALTER*	*CONTROL REGISTERS*			
G GENERAL REGISTERS	0	1	2	3
C CONTROL REGISTERS	0 DDD DDDD	DDDD DDDD	DDDD DDDD	DDDD DDDD
P CURRENT PSW	4	5	6	7
F FLOATING POINT REGISTERS	DDDD DDDD	DDDD DDDD	DDDD DDDD	DDDD DDDD
D PAGE DESCRIPTION				
S CAPACITY COUNTS				
V MAIN STORAGE	8	9	A	B
	DDDD DDDD	DDDD DDDD	DDDD DDDD	DDDD DDDD
*MAIN STORAGE DISPLAY*	C	D	E	F
	DDDD DDDD	DDDD DDDD	DDDD DDDD	DDDD DDDD
+ PAGE UP				
- PAGE DOWN				
SELECTION: C ADDRESS:				

The display above appears in VSE mode. To select the “Control Registers” display:


1. Type C next to SELECTION in the “Display /Alter” display.
2. Press ENTER.

All 16 control registers appear in the display. Their contents are represented as eight hexadecimal characters in the display field (“D” in the example above). Below each display field is the corresponding alter field, which is blank unless data is being altered.

To direct the cursor to a register, type the register number (O-F) after ADDRESS and press ENTER. The cursor will appear below the leftmost (alter) character position in the specified register.

## Current PSW (Program Status Word)

This display allows you to change the contents of the current PSW.



**Note:** Above is a “Current PSW” display as it appears when the system is in 370/BC mode. The ILC (instruction length code) appears only for a system in BC mode. In EC mode the ILC is in a fixed storage location. To select the “Current PSW” display:

1. Type P after the word SELECTION in the display.
2. Press ENTER.

When you press ENTER, the machine stops and the PSW is displayed in binary notation, except for the instruction address, which appears in hexadecimal notation.

The logical meaning of the data that appears in the “current PSW” display depends on whether your machine is in VSE or 370 mode, and also on whether it is in Basic Control (BC) or Extended Control (EC) mode. The control mode currently in effect for your machine, 370 or VSE, is shown in line 21 of the machine status area, and the EC or BC mode is distinguished by the E-bit in the PSW being one for EC mode, 0 for BC mode.

The contents of each bit position in the PSW are represented as binary 1 or 0 (“B” in the example above). Below each display field is the corresponding alter field, which is blank unless data is being altered.

With the exception of the system mask (SYST. MASK), the contents of the current PSW may be altered in any binary (or hex for the instruction address) combination. The allowed combinations for the system mask are as follows:

BBBB BBBB	
xxxx xxxx	VSE BC Mode
xxxx xxxx	370 BC Mode
0x00 00xx	VSE EC Mode
0x00 0xxx	370 EC Mode

where "X" may be 0 or 1.


Any other combination results in the error message "Invalid Syst. Mask."

If logical errors are made while altering the current PSW, the errors are accepted and loaded with the PSW. The following is a logical error:

- When in BC mode the address exceeds the storage size, INVALID ADDR LOADED appears; but the address is still loaded into the PSW. If the program uses an invalid address, the message PSW ADR ERROR appears on line 21.

## Floating Point Registers

This display enables you to examine the contents of the floating point registers.



The picture above appears in VSE mode.

To select the "Floating Point Registers" display:

1. Type in F after the word SELECTION.
2. Press ENTER.


The four floating point registers appear in the display. In the example given above, each X represents a hexadecimal digit. Beneath each display field is the corresponding alter field, which is blank unless data is being altered.

To direct the cursor to the first half of a register, type the register number (0, 2, 4, 6) next to ADDRESS and press ENTER. To select the second half of the register, specify 1, 3, 5 or 7. The cursor will appear below the first (alter) character position in the specified fullword.

The procedure for altering is described under "General Registers."

## General Registers

This display causes all 16 General Registers to be displayed.



This picture is shown in VSE mode.

To select the "General Registers" display:

1. Type G into the "Display/Alter" display next to SELECTION.
2. Press ENTER.

To direct the cursor to a register, type the register number (0-F) next to ADDRESS and press ENTER. The cursor will appear below the first (alter) character position in the specified register.


The contents of each register in the display are represented as eight hexadecimal characters in the display field (X in the example above). Below each display field is the corresponding alter field, which is blank unless data is being altered.

After an alteration, START must be pressed to resume operation.

**Note:** You may keep the "General Registers" display on the screen for diagnostic purposes during processing. If you then press STOP, processing stops and the current contents of the general registers are displayed.

## Storage Key

The "Storage Key" display enables you to determine the protection key of any given main storage address. An example of this display is given below. (This display is operational only in 370 mode).




To select the "Storage Key" display:

1. Type K into the "Display/Alter" display next to SELECTION.
2. Type in the main storage address in hexadecimal notation. Leading zeros are provided by the processor.
3. Press ENTER.

Note that the address is in hexadecimal notation and the key is in binary notation. The reference (R), the change (C) and the fetch (F) protection bits are shown in binary notation.

## Main Storage

The “Main Storage” display enables you to show a block of 32 halfwords of main storage on the screen.



This picture is shown in VSE mode.

To select the “Main Storage” display:

1. Type V into the “Display/Alter” display next to SELECTION.
2. Type in the main storage address in hexadecimal. The leading zeros are supplied by the system.
3. Press ENTER.

The Y characters in the example display represent in hexadecimal notation the main storage address without its low order digit. Each X represents a hexadecimal digit. The low-order digit of the address is shown above the left-most byte of each halfword (0,2,4,6,8,A,C,E). To display another part of storage, enter V and the new address next to SELECTION.

The block of storage displayed on the screen may be in one of the following three states:

- Addressable (Processor addressable)
- Connected (Channel only addressable)
- Disconnected (not addressable)

The status is shown in the message area on the screen. If a block is disconnected,

the data area on the screen is blank.

The PAGE function displayed on the screen above SELECTION enables you to display the adjacent storage section, that is, the next 64 bytes in either descending or ascending order of address. To get the next higher section press the “+” key, to get the next lower section press the “-” key.


Another possibility to scroll pages is:

PAGE UP - Hold the ALT key down and press PAGE ↑

PAGE DOWN - Hold the ALT key down and press PAGE ↓

## Main Storage Size

The “Main Storage Size” display enables you to display the size of the physical storage which is actually available for Operating System and Application Program residence (370 mode only).



To select the “Main Storage Size” display:


1. Type S into the “Display/Alter” display after the word SELECTION.
2. Press ENTER.

The main storage size is displayed as six hexadecimal characters.

**Note:** The main storage size can only be displayed, not altered.

## Capacity Counts

This display allows you to display the capacity counts and the physical storage size actually available to the operating system and application program residence (in VSE mode only).



To select the "Capacity Counts" display:


1. Type S into the "Display/Alter" display next to SELECTION
2. Press ENTER.

The capacity counts are displayed as four hexadecimal characters, the machine storage size as six hexadecimal characters.

**Note:** Capacity counts and available storage can only be displayed, not altered.

## Main Storage Real

This display allows you to display a block of 32 halfwords of real main storage (in 370 mode only).



To select the "Main Storage Real" display:

1. Type M into the "Display/Alter" display next to SELECTION.
2. Type in the main storage address in hexadecimal notation. The leading zeros are supplied by the system.
3. Press ENTER. The system stops and the "Main Storage Real" display appears on the screen.


The Y characters in this display represent, in hexadecimal notation, the real main storage address without its low order digit. Each X represents a hexadecimal digit. The low-order digit of the address is shown above the left-most byte of each halfword.

The PAGE function displayed on the screen above SELECTION enables you to display the adjacent part of real storage by moving the display address backwards or forwards by 64 bytes.

PAGE UP - Hold the ALT key down and press PAGE   
PAGE DOWN - Hold the ALT key down and press PAGE 

## Main Storage Virtual

This display enables you to show a block of 32 halfwords of virtual storage on the screen (in 370 mode only).



To select the "Main Storage Virtual" display:

1. Type V into the "Display/Alter" display next to SELECTION.
2. Type in the virtual main storage address in hexadecimal notation. The leading zeros are supplied by the system.
3. Press ENTER.

The Y characters in this display represent in hexadecimal notation the virtual main storage address without its low-order digit. Each X represents a hexadecimal digit. The low-order hexadecimal digit of the address is shown above the left-most byte of each halfword (0,2,4,6,8,A,C and E). The R characters represent, in hexadecimal notation, the translation of the virtual address which you entered to get this display.

The PAGE function displayed on the screen above SELECTION allows you to display an adjacent part of virtual storage by moving the display address backward or forward 64 bytes:

PAGE UP - Hold the ALT key down and press PAGE  $\uparrow$   
PAGE DOWN - Hold the ALT key down and press PAGE  $\downarrow$

display does not appear:

**Outside Page Table:** The specified address is outside the page table.

**Outside Segment Table:** The specified address is outside the segment table.

**Page or Segment Entry Invalid:** The specified address is not in physical storage.


**Specification Exception:** Specification error: Zeros are missing from the prescribed bit positions in the specified page or segment entry.

**Addressing Exception:** The page or segment entry address is outside processor storage.

**Address not Translatable:** The system is in BC mode.

## Page Description

The "Page Description" display enables you to display and, in some cases, alter selected data in page frames in main storage (in VSE mode only).



To select this display:

1. Type D into the "Display/Alter" display next to SELECTION.
2. Type in the main storage address in hexadecimal notation. The leading zeros are provided by the processor.
3. Press ENTER.

The following data in the page description can be altered:

- Storage key
- Programmable bits
- Fetch protection (F) bit
- Reference (R) bit
- Change (C) bit

The following data is displayed but cannot be altered:


- Frame index
- Address
- Addressable state bit (A) (processor addressable)
- Connected state bit (C) (channel only addressable)
- Disconnected state bit (D) (not addressable)

## Communication Lines

Communication lines are permanently configured at installation time (see Chapter 5 "Reference Information, Configuration Chart for Communications Adapter"). The "Communication Lines" display allows you to temporarily change some operating parameters of your communication lines so as to improve the operation or to achieve compatibility with the terminal at the other end. Among the items that can be changed are the transmission speed, the way in which the modem answers, the line code used, and others explained in the following text. The changes are temporary because they are automatically reset to the values chosen at system installation time upon the next IML or any type of system reset.

### Start / Stop Lines

This display allows you to change the values of certain options for the telecommunication lines under S/S line protocol.



To select the display:

1. Type E into the "MODE SELECTION" display after SELECTION.
2. Press ENTER.

The display appears, showing the configuration for the telecommunication line. The top portion of the display explains how to select the various items, how to get the next line, etc. Underneath, the currently selected line is specified in the following terms:

1. Line address
2. Line control procedure:
  - S/S (Start/Stop) IBM Terminal Control 1
3. Type of clock:
  - BM (Business Machine) clock
  - Mod (External Modem) clock
4. Type of interface:
  - EIA I/F - EIA/CCITT V24 interface
  - INT MODEM - integrated modem

The remaining lines on the screen contain items for which usually two options are offered. To change these values, proceed as follows:

1. Press the PF1 key to move the large arrow in the left margin of the screen to point at the item you wish to change. You must hold down the ALT key and then press the numeric key 1 (this activates the PF1 function.)
2. Press the PF2 key to move the small arrow pointing at one of the options (in the right-hand columns) to the required value. If the small arrow is missing, the associated parameter is not relevant to this configuration. Some combinations of parameter values are invalid. If such a combination is selected, a warning message is given and the change is rejected.
3. When you have finished updating the options for the line presently displayed, press the PF4 key and the display for the next line will appear. A message appears if the equipment corresponding to the next line is not installed. If the present display was for the last line, the display for the first line appears again.
4. When all updating is finished, press ENTER. If you intend to finish the procedure without changing anything, press PF3.

Changes in the displayed configuration are required only when your installation uses switched lines where you may have communications with various different types of terminals and you may have to adjust your equipment to the needs of the remote terminal. The following describes the start/stop line parameters and when they are required.

*Unit Exception Suppress* must be set to yes when the remote station is a 2741 or equivalent. The 2741 sends a circle-C character as the only ending character it "knows" and this would always cause a unit exception which breaks a command chain unless suppressed as recommended.

*Read Interrupt* should be set to "yes" when the program (in your system) is to be authorized to issue a break command to the remote station to stop this station's transmission. If read interrupt is set to "no," a break command is rejected. The issuing of a break command is possible only on duplex facilities (4-wire line or duplex modem on 2-wire line).

*Write Interrupt* should be set to “yes” if you want to authorize the remote station to stop your line’s transmission. By setting “yes,” your line will accept the break signal from the remote station. This requires duplex facilities (same as for read interrupt).


*Select Standby* should be set to “yes” when your leased or privately owned line is damaged and you are forced to change to a switched line to sustain communication. The standby can be used only when the modem has the switched network backup capability.

*Answer Tone* should be set to 2025 Hz if the modem of the remote station is a WE 202 (Western Electric) type modem. This selection sets the integrated modem in the 4331 to provide the answer tone which the WE 202 requires. Select 2100 Hz in all other cases, or if the modem of the other station is unknown.

**Note:** The answer tone selection appears in the display only when your line is equipped with the integrated modem, otherwise the bottom line of the display is omitted.

## Synchronous Data Link Control (SDLC) Lines

This display allows you to change the values of certain options for the telecommunication lines under SDLC control.



To select the display:

1. Type E into the "MODE SELECTION" display next to SELECTION.
2. Press ENTER.

The display appears containing the configuration for the telecommunication line. The top portion of the display explains how to select the various items, how to get the next line, etc. Underneath, the currently selected line is specified in the following terms:

1. Line address
2. Line protocol:
  - SDLC (Synchronous Data Link Control)
3. Type of clock:
  - BM (Business Machine) clock
  - Mod (External Modem) clock

#### 4. Type of interface:

- EIA I/F - EIA/CCITT interface
- V35 I/F - CCITT high speed interface
- DDS I/F - DDS interface
- LOC ATT - local attachment
- INT MODEM - integrated modem
- X21 I/F - X21 LL interface

The remaining lines on the screen contain items for which usually two options are offered. To change these values, proceed as follows:

1. Press the PF1 key to move the large arrow in the left margin of the screen to point at the item you wish to change. Hold down the ALT key, then press the numeric key 1 (this activates the PF1 function).
2. Press the PF2 key to move the small arrow pointing at one of the options (in the right-hand columns) to the required value. If the small arrow is missing, the associated parameter is not relevant to this configuration. Some combinations of parameter values are invalid. If such a combination is selected, a warning message is given and the change is rejected.
3. When you have finished updating the options for the line presently displayed, press the PF4 key and the display for the next line will appear. A message appears if the equipment corresponding to the next line is not installed. If the present display was for the last line the display for the first line appears again.
4. When all updating is finished, press ENTER. When you intend to finish the procedure without changing anything press PF3.

The following describes the SDLC line parameters and when they are required.

*Select Standby* allows you to select the switched network backup facility of your modem (provided the modem is so equipped). By selecting yes, the modem uses a switched line instead of the normally used leased or privately owned line. Select yes when the normally used line is damaged.

*Data Signaling Rate Selector* allows you to set the modem to the higher or lower of two clocking speeds if the modem is properly equipped. Normally the higher speed is set. However, if the number of error incidents and therefore the number of recovery or retransmission actions becomes excessive, you should select the lower speed. With a lower speed a "noisy" line can still be used. You may also have to change the speed (the signaling rate) to adjust to the speed of a remote station.

*NRZI* allows you to change from the normal non-return-to-zero inverted (NRZI) method of encoding digital signals to a method where the signal is not inverted when successive zero bits appear.

Some modems are sensitive to certain steady bit patterns and may thus require either NRZI or not-NRZI to function properly (check the modem manufacturers information for the applicable mode). Crypto-units which encipher/decipher data may likewise require one or the other mode. Because SDLC-transmission is bit-oriented, bit synchronization is important. Therefore, if too many errors occur, check that the mode is correct.

*Answer Tone* should be set to 2025 Hz if the modem of the remote station is a WE 202 (Western Electric) type modem. This selection sets the integrated modem in the 4331 to provide the answer tone which the WE 202 requires. Select 2100 Hz in all other cases, or when the modem of the other station is unknown.


**Note:** The answer tone selection appears in the display only when your line is equipped with the integrated modem, otherwise the bottom line of the display is omitted.

## Binary Synchronous Communication (BSC) Lines

This display allows you to change the values of certain options for the telecommunication lines under BSC control.

To select the display:


1. Type E into the "MODE SELECTION" display next to SELECTION.
2. Press ENTER.
3. The following display will appear on the screen:



This display allows you to directly select either the temporary configuration change facility or the display for changing the tributary station addresses for all BSC lines.

Type "A" for the Temporary Configuration Change or "B" for the Tributary Station Address and press ENTER. The associated displays will appear on the screen.

## Temporary Configuration Change



The display appears containing the configuration for the telecommunication line. The top portion of the display explains how to select the various items, how to get the next line, etc. Underneath, the currently selected line is specified in the following terms:

1. Line address

2. Line protocol:

BSC (Binary Synchronous Communication)

3. Type of clock:

BM (Business Machine) clock  
Mod (External Modem) clock

4. Type of interface:

EIA I/F - EIA/CCITT interface  
V35 I/F - CCITT high speed interface  
DDS I/F - DDS interface  
LOC ATT - local attachment  
INT MODEM - integrated modem  
X21 I/F - X21 leased line interface

The remaining lines on the screen contain items for which usually two options are offered. To change these values, proceed as follows:

1. Press the PF1 key to move the large arrow in the left margin of the screen to point at the item you wish to change. Actually you must hold down the ALT key then press the numeric key 1 (this activates the PF1 function).
2. Press the PF2 key to move the small arrow pointing at one of the options (in the right-hand columns) to the required value. If the small arrow is missing, the associated parameter is not relevant to this configuration. Some combinations of parameter values are invalid. If such a combination is selected, a warning message is given and the change is rejected.
3. When you have finished updating the options for the line presently displayed, press the PF4 key and the display for the next line will appear. A message appears if the equipment corresponding to the next line is not installed. If the present display was for the last line the display for the first line appears again.
4. When all updating is finished, press ENTER. When you intend to finish the procedure without changing anything press PF3.

The following describes the BSC parameters and when they are required:

*Select Standby* allows you to select the switched network backup facility of your modem (provided the modem is so equipped). By selecting yes, the modem uses a switched line instead of the normally used leased or privately owned line. Select yes when the normally used line is damaged.


*Data Signal Rate Selector* allows you to set the modem to the higher or lower of two clocking speeds if the modem is properly equipped. Normally the higher speed is set. However, if the number of error incidents and therefore the number of recovery or retransmission actions becomes excessive, you should select the lower speed. With a lower speed a "noisy" line can still be used. You may also have to change the speed (the signaling rate) to adjust to the speed for a remote station. (high speed = 1200 BPS, low speed = 600 BPS).

*Data Code.* ASCII code should be selected whenever the remote station requires this type of line code, otherwise EBCDIC should be used. Ask the system programmer when in doubt or ask the operator at the remote location.

*EIB Mode* allows you to specify that an error index byte (EIB) is to be set into storage adjacent to each ITB, ETB, and ETX character that is received. The intermediate text block (ITB), end of text block (ETB), and end of text (ETX) character are inserted into the message by the remote station to divide the transmission into smaller portions. In this way EIB mode reduces the amount of code that is to be retransmitted for recovery because only the text up to the last index byte must be sent again (ask the system programmer for details as to when to use EIB mode).

#### ***Tributary Station Address:***

The tributary station addresses appear only if your installation includes BSC lines and you have entered B in the CA-Customer Manual Ops display. This selection brings the following display to the screen:



The display lists all lines that use BSC protocol but only those lines. This explains why the addresses do not necessarily appear in sequence (in our example, line 31 is followed by line 35 because lines 32, 33, 34 are Non-BSC or do not exist).

The display is required only when your communication lines are part of a multi-point network and participate as tributary stations. Tributary stations can be selected or polled from a master (remote) station. For this reason they must be "known" by an address and this address is normally assigned once at installation time.

Every line has two tributary station addresses which may (but need not) both be used. The idea is to give a group of lines a group address, for example address 40. If address 40 is given to four lines, these four lines could simultaneously receive data from the master station (when addressed by their group address). The display contains the group address 40 as default value for each line. You may leave these addresses or change them, as you like. Besides such a group address, each line can get an individual tributary station address, for example 41, 42, 43, etc, and will then be separately addressable. The place to enter such addresses is blank in the display, but marked XX in our example for clarity.

You may enter the first address (leftmost two digits) as group address and the next two digits (marked XX) may represent the individual station address, or vice versa. The addresses are accepted in either position. If you enter only one address (either left or right) for a line, that address is automatically assumed to apply to both address slots. For example, if you keep the default address 40, the individual address is also 40 (even though the space marked XX is blank in the display).

Address bit 2 (counting from left to right) is used to distinguish between polling and selection of the station. If you use the default address 40, the station is polled with address 40, and selected with address 60.

In 3270-type addressing, the addresses for polling and selection do not always follow this rule. The exceptions for 3270 addresses 1 and 16 may be handled by the 4321 or 4331 by specifying two station addresses: C141 (character "A") for address 1, and 50DO (character "@") for address 16.

The cursor is located underneath the first line's left address. You may enter the addresses in sequence (the cursor moves along) or you may pick a specific address via the cursor movement keys.

**Note:** Only specific codes are valid as tributary station addresses and the display accepts only valid codes. You may either assign the address by trial and error or go by the following rules:

1. Do not use any of the following control characters: SOH (Hex 01), STX (Hex 02), ETX (Hex 03), EOT (Hex 37), ETB (Hex 26), ENQ (Hex 2D), DLE (Hex 10), NAK (Hex 3D), SYN (Hex 32), or ITB (Hex 1F). The Hex codes listed here are EBCDIC. For ASCII, see the /370 reference card.
2. If the line code is ASCII (which is a 7-bit code) no value higher than hex 7F can be used (that is, bit 0 in the byte must be 0).
3. Bit number 2 in the byte must not be 1. This rules out all addresses that begin with 2, 3, 5, 6, A or F. This rule ensures that bit 2 can be used to distinguish polling and selection during addressing.

When you have typed in all addresses, you may either press the PF3 key to exit without changing anything or the ENTER key to put the change to work.

After ENTER key depression you will first see the message "update in process" and after a while this message changes to "update done." As of this instant, the changes are recorded on the system diskette and the changes are in effect for any program. No IML is required.

To return to the operating system, press CANCEL or PF3.

## ***Instruction Step***

Instruction step mode allows you to direct the processor to execute only one instruction with each depression of the START key. The changes in data that occur for each instruction executed are shown on the screen so that you can follow them. This mode is set from the mode selection display.

To select instruction step mode:

1. Type I into the "Mode Selection" display next to SELECTION.
2. Press ENTER.


Line 22 of the machine status area indicates when instruction step mode is in effect.

Instruction step mode remains in effect even if other modes are subsequently selected, such as "Display/Alter" mode.

To terminate "Instruction Step" mode see "Reset I-step."

## *Interval Timer*

This display enables you to start or stop the interval timer. The state of the interval timer is shown in line 21 of the machine status area.



To select the "Interval Timer" display:

1. Type J into the mode selection display next to SELECTION.
2. Press ENTER.

Type one of the following into the display next to SELECTION:

- N - Turn timer on.
- F - Turn timer off.

The interval timer is started automatically at IML time.

## ***Machine Save***

The “Machine Save” operation enables you to make a record of the current state of the processor (VSE mode only). A save operation is especially recommended prior to loading any dump programs or other diagnostic means that use internal facilities (such as registers). The save operation preserves the processor state as it was when the error occurred.

To specify machine save:

1. Type S into the “Mode Selection” display next to SELECTION.
2. Press ENTER.


When machine save is specified, the following actions occur in the system:

- The processor stops.
- The contents of page 0, that is, the 2048 bytes at addresses 0 to 2047, and all registers and timers are saved in internal storage.

When a save operation has been completed successfully, the save indicator in the machine status area is turned on. A reset, IPL or power off during “machine save” terminates the operation.

## Program Load

The "Program Load" display enables you to load the operating system and the application programs to be run on your installation. This operation is usually known as "initial program load" (IPL). The display appears automatically when IML has been completed successfully.



```
*PROGRAM LOAD*

CHANNEL          CONTROL UNIT      DEVICE          P PROGRAM
 0-6             0-F             0-F            C CLEAR
* *             * *             * *            * *
- -             - -             - -            - -

MACHINE MODE    VSE STORAGE SIZE  1052 MODE      NUMBER OF
V VSE          2=2MB C=12MB  P=PRINT        3340 BUFFERS
3 370         4=4MB M=16MB  N=NO PRINT     1-8
              8=8MB R=REAL    F=OFF

* *             * *             * *            * *
- -             - -             - -            - -

NUMBER OF       EMULATED DEVICE   FIRST HOST      EMULATION
EMU BUFFERS    R 2311           ADDRESS        ONLY MODE
0-8            S 2314           IN HEX         Y YES
              T 3330
              U 3340
* *             * *             * *            * *
- -             - -             - -            - -
```

**Note:** The following legends appear on the screen only when the corresponding compatibility features are installed:

- 1052 MODE
- NUMBER OF 3340 BUFFERS
- NUMBER OF EMU BUFFERS
- EMULATED DEVICE
- FIRST HOST ADDRESS
- EMULATION ONLY MODE

To select the "program load" display:

1. Type L into the "mode selection" display after SELECTION.
2. Press ENTER.

The program load display appears on the screen, showing the specification entered for the previous load operation. If you wish to repeat this specification, press ENTER and proceed. If you wish to perform a different load operation, specify as follows:

1. Enter the address of the device from which you want to load your programs in the CHANNEL, CONTROL UNIT, and DEVICE fields.

2. Type in either P or C under the program reset field:
  - P PROGRAM specifies an initial program reset and clears the following controls to zero with valid parity: PSW, iU timer, clock comparator and control registers.
  - C CLEAR causes a clear reset (see the "Clear Reset" procedure) and must be specified when STORAGE SIZE, NUMBER OF BUFFERS, EMULATED DEVICE or FIRST HOST ADDRESS are changed or this is the first load operation after power-on.
3. Specify under MACHINE MODE in which mode the system is to run: V for VSE mode, or 3 for 370 mode.
4. If you select VSE mode, specify under STORAGE SIZE the size of storage required. The entries "2," "4," "8," "C" provide 2, 4, 8 or 12 megabytes of storage. You may also specify "M," which gives you the maximum storage size (16 megabytes), or "R," which means that the (virtual) processor storage equals the machine storage size of the model you are using.
5. If the console is to operate in 1052 Printer/Keyboard mode, the operator must define whether this mode should include the 3287 terminal printer or not. If no printer is installed or if the printer is required for other than console message printing, "N" for no should be entered. The 1052 mode will then use the screen as the only means for message output. If the 3287 terminal printer is to be used for console message printing, "P" for print should be entered. This causes the 3287 on the lowest port to do the job of 1052 printing. The address of this 3287 is now no longer available for software or local-copy operations. If you attempt local copying, the message "Printer Not Working" will appear at the requesting station, although the printer will work in 1052 mode. If "F" for off or a blank is entered, the console operates in 3270 operation mode. 1052 mode is required for operating systems which do not support the display mode of the operator console.
6. If the 3340 direct attachment is installed, it is always operational and one buffer is automatically allocated by the system. You can specify further buffers to a maximum of eight.
7. Zero to 8 buffers may be specified under EMU if the disk compatibility feature is installed (at least one buffer must be specified for the feature to become operational). If zero is specified, the feature is not activated and no storage is occupied by microcode.
8. If you have made the disk compatibility feature operational (by specifying EMU buffers), select one of the devices listed under EMULATED DEVICE.
9. If the disk compatibility feature has been activated, specify the address (three hexadecimal characters) of the device that is host to the first emulated volume under FIRST HOST ADDRESS.
10. If you load an operating system that does not support the host device (does not "know" the 3310 or 3370), EMULATION-ONLY MODE = YES must be specified. "YES" indicates to the compatibility feature that it has to perform the error logging for the host device.

If you load an operating system that supports the host disk ("knows" the 3310 or 3370), such as VSE, EMULATION-ONLY MODE = NO must be specified. The operating system will then log host errors even if the host bears nothing but emulated disks, and no host application runs.

**Note:** After entering (or changing) specifications for the disk compatibility feature perform a "Clear Reset."

When you have typed in the load data, press ENTER to start the initial program load process. At this instant the "LOAD" indicator appears and remains on until a valid PSW is loaded, at which time the entire load display disappears.

If the IPL process is unsuccessful, the IPL display and the LOAD indicator remain on the screen and the message "IPL ERROR" appears.

A reference code is displayed for service personnel.

The most common IPL errors are:

- Load device not ready
- Some other device besides the load device was made ready (should be the load device alone)
- Wrong address: for example, the address of the line printer was entered as load address.

If you make an error while entering program load specifications the following messages are displayed on the screen:

**Invalid Character** is displayed when an incorrect selector character has been entered.

**Invalid Address** is displayed if an invalid "channel," "control unit," "device," or "host device" address is specified.

**Incomplete Entry** appears on the screen if no character was entered or if in case of fast selection, the set of characters keyed in is incomplete.

**Invalid Reset, Select \*C\*** appears on the screen and the cursor is set below the reset specification, if one of the specifications "storage size," "number of buffers," "emulated device," "host device" or "emulation-only mode" are changed and program reset (character "P") is specified. This occurs also if P is specified for the first load operation after power-on.

**Invalid Host Device Address** appears on the screen and the cursor is set below the host device address specification, if one of the possible host device addresses is used, but that address was not assigned at system installation time (or has been deleted).

**No Console Printer Configured** appears on the screen when 1052 emulation mode with console printer is selected ("P") and no 3287 console printer was assigned to any of the port addresses at installation time (or was deleted). See "Native Displays and Printers" for additional information.

## **Clear Reset**

The "Clear Reset" operation enables you to reset the entire system and clears the storage. This operation is initiated from the mode selection display.

To set "Clear Reset":

1. Type C into the "Mode Selection" display.
2. Press ENTER.

When "Clear Reset" is entered, the current operation (if any), is halted. Any pending interruption conditions or machine checks are cleared, and the CPU stops. The following system resources also stop:

- All channels including their control units and attached devices
- All adapters including attached devices

The RESERVE status of 3340s or 3370s is reset. The physical switch on the 3340 or 3370 is set to NEUTRAL if it was occupied by the 4321 or 4331 Processor.

"Clear Reset" resets the channels and the CPU and initializes the control registers. It also clears to zero the values of the following:

- Main storage
- Current PSW
- CPU timer
- Clock comparator
- General registers
- Floating point registers
- Keys in main storage
- Page description
- All error counters and usage counters in directly-attached disk drives.

The TOD clock is not altered and its parity remains unchanged. The mode selection display remains on the screen and, when processor reset has been completed, RESET COMPLETE appears.

## ***Reset I-Step***

“Reset I-Step” has no display. It is performed from the “Mode Selection” display.

To set “Reset I-Step”:

1. Type **N** into the “Mode Selection” display after **SELECTION**.
2. Press **ENTER**.

When “Reset I-Step” has been set, the instruction step indicator in line 22 of the machine status area is turned off and the screen is returned to the operating system. To continue processing, press **START**.

## ***Program Reset***

The "Program Reset" operation enables you to reset certain system resources without resetting storage and vital control parameters in registers. The operation is performed from the mode selection display.

To specify "Program Reset":

1. Type P into the "mode selection" display next to SELECTION.
2. Press ENTER.

When "Program Reset" is entered, execution of the current instruction (if any) is halted, any pending interruption conditions are cleared, and the CPU stops.

The following system resources also stop:

- All channels including control units and attached devices
- All adapters including attached devices

The RESERVE status of 3340s or 3370s is reset. The physical switch on the 3340 or 3370 is set to NEUTRAL if it was occupied by the 4321 or 4331 Processor.

**Program Reset** resets the channels and the CPU, but it does not affect the values of the following:

- Current PSW
- CPU timer
- Clock comparator
- General registers
- Floating point registers
- Control registers
- Main storage
- Keys in main storage
- Page description

**Reset Complete** appears on the screen when processor reset has been completed.

Program reset should not be used indiscriminately because it leaves the registers and the storage loaded with values from previous activities and this may not be suited for a restart.

Only program reset should be used prior to loading a stand-alone dump program.

## ***Restart***

The "Restart" operation is used to restart processing from a logical point defined by the operating system. This operation is specified from the mode selection display.

To specify "Restart":

1. Type R into the "Mode Selection" display next to the word SELECTION.
2. Press ENTER.

When "Restart" has been entered, the system takes control of the screen. If the machine is in the stopped state when "Restart" is entered, processing starts immediately with the program restart PSW (a fixed location in storage). If the machine is in the operating state, the restart PSW gets control when the current instruction has been executed and after all interruption conditions for which the CPU is enabled have been handled.

A "Restart" is successful only when an operating system is used that takes advantage of the restart PSW or prepares a restart PSW for the explicit purpose of restarting the system at a meaningful point.

## ***Store Status***

The "Store Status" mode enables you to make a record of the current status of certain system resources. "Store Status" is recommended prior to loading a standalone dump program because it saves the contents of the general registers before they are being used by the standalone dump program. The "Store Status" operation is initiated from the mode selection display. (370 mode only.)

"Store Status" applies only to a machine in 370 mode. If an error occurs during the operation, the processor enters the check-stop state.

To specify "Store Status":

1. Type S into the "Mode Selection" display next to SELECTION.
2. Press ENTER.

The "Store Status" operation stops the processor, then causes the following to be stored in fixed locations in main storage:

- CPU timer
- Clock comparator
- Current PSW
- Floating point register
- Control registers
- General registers

When ENTER is pressed, the mode selection display remains on the screen and the message STATUS STORED appears. The system goes into the stopped state.

## ***TOD Enable***

This operation allows you to determine the instant when the time of day (TOD) clock is set. "TOD Enable" is performed from the mode selection display. To set "TOD Enable":

1. Type Y into the "Mode Selection" display after SELECTION.
2. Press ENTER at the exact instant at which you wish to set (synchronize) the clock. This may be, for example, the moment when the hands of the clock jump to the full hour.

The time-of-day clock is always in the "secure" state which means that the program cannot set the clock. This secure state is only briefly removed when you press the ENTER key, and the program will set the clock at this instant (with a previously prepared value).

The status of the TOD clock is indicated in line 22 of the machine status area. The TOD enters secure state automatically after "TOD Enable."


## Native Displays and Printers

This display allows you to specify what types of devices are connected to the display/printer adapter, how these devices are equipped, and which addresses are assigned to them. The display allows you to delete devices from your configuration without physically disconnecting them, and it allows you to change device addresses or assign new devices. You can also change the keyboard type and language specification of the attached terminals.

To select "Native Displays and Printers":

1. Type MM into the "Mode Selection" display next to SELECTION. (By typing a single M you get a picture which offers ROCF subselection. ROCF procedures are described in Operator's Library *IBM 4331 Processor Remote Operator Console Facility, GA33-1545.*)
2. Press ENTER.

The following frame is displayed. Ports 8-15 are available only if the optional feature (display/printer adapter expansion) is installed.



The following display and printer devices can be attached by using addresses X'009' through X'01F':

- |                         |                       |
|-------------------------|-----------------------|
| • 3278-2A               | Display Console       |
| • 3279-2C               | Color Display Console |
| • 3278-2                | Display Station       |
| • 3279-2A               | Color Display Station |
| • 3287 -1, 2, 1C, or 2C | Matrix Printer        |
| • 3289-4                | Printer               |
| • 3262-1 or 11          | Printer               |

- 3230-2 Terminal Printer
- 3268-2 Printer

The fourth line of the display shows, following the heading “translate tables (T),” the keyboard layouts for the terminals to be attached and the associated national language. Two different layouts may have been ordered: the mandatory typewriter layout and either the data entry 1 or data entry 2 type layout (these are key-punch-like keyboards). Each keyboard type may have its own language associated or both may have the same. It is also possible that only one type of keyboard (the typewriter) was ordered for all terminals but two different languages.

Whatever the choice may have been, the mandatory typewriter layout with its associated language is denoted as “1” and the other keyboard type and its associated language (if any) is denoted as “2” in the display. For example:

**TRANSLATE TABLES (T):**

TYPEWRITER (FRENCH) = 1  
DATA ENTRY 2 (U.S. ENGLISH) = 2

This makes it easy for you to define the language and keyboard combination of a terminal which you want to connect because you only need to enter a 1 or a 2 (as applicable) in the “T” column of the terminal field. The terminal field consists of four columns which define (from left to right) the port number, the device type, the device address, and the keyboard/language combination, as follows:

**PORT DEVICE ADR T**

The number entered under “port” defines into which receptacle the device’s coax cable will be plugged. The cable receptacles are numbered sequentially from 0 to 15. The system expects to find the operator console at port 0, that is, it routes the operating system messages automatically to the device connected to port 0 (using the device address associated with port 0). The number entered under device specifies whether the terminal is a display or a matrix printer or a line printer (e.g. 3278-2, 3262, etc.). The device address (ADR) defines the number under which the program can address this device, and the T column defines the keyboard/language combination (when applicable).

**Note:** For terminal printers, only the language portion of the keyboard/language combination is meaningful and effective when a 1 or a 2 is entered. For line printers (e.g. 3289-4 or 3262) no language need be specified because line printers receive their language character set via the “load USCB operation” (operating system). For line printers, the X may remain in the T column.

The display shows the current configuration, and you may enter your changes underneath. In order to logically *attach* a device, position the cursor under the alter field (identified by “....”) of the corresponding port and key-in the applicable device type number.

In order to logically *detach* a device from the system, type “X” into any position of the alter field of the corresponding DEVICE display field. When you then press the ENTER key, Xs appear in the DEVICE display field and automatically in the corresponding translate language (T) and device address (ADR) fields.

Pressing ENTER after you have made the necessary changes causes the new con-

figuration to be written onto the system disk.

After changing the configuration, IML must be performed. If you have merely swapped two line-printer ports, you can bypass IML by operating the Reset switch (3289-4) or the Test key (3262).

### Configuration Rules and Limitations

- A device (except line printers) may be configured (logically attached) even if it is not physically attached. If such a device is addressed during system operation, "intervention required" is presented, and nothing else happens.
- Port 0 is always reserved for the operator console.
- A maximum of two system printers (3289 and/or 3262) may be attached in any combination.
- The Copy key addresses the matrix printer with the lowest port number.
- Ports 8-15 can be used only if the optional feature (display/printer adapter expansion) is installed.

### Specification Errors/Messages

The following messages may appear on the screen:

**Invalid Device Name:** Appears if an invalid DEVICE name has been specified, that is, if you enter device type numbers other than those shown in the top of the display, following the heading "ATTACH DEVICES:."  
Also appears if you try to detach the operator console by entering X-characters for port 0.

**Invalid Keyboard Language:** Appears if a character other than "1" or "2" has been entered for TRANSLATE LANGUAGE.

**Duplicate Device Address:** Appears if the same DEVICE ADDRESS has been entered twice.

**Duplicate Diskette Address:** Appears if one of the duplicate addresses is a diskette device address (the native user diskette address is also in the range X'009' to X'01F').

**Invalid Configuration:** Appears if the "Configuration Rules and Limitations" (listed above) have been violated.  
Port 0 allows 3278 or 3279. If you specify for port 0 a device name valid for ports 1 to 15 only, the message appears.

**Only 8 Ports Effective:** Appears if entries are made against any of ports 8-15 when the optional feature (display/printer adapter expansion) is not installed.

**Configuration Update Complete:** Appears when the system has finished processing of the configuration update specified by the operator.

## *Native User Diskette*

When the diskette drive requires your attention, line 21 of the machine status area shows either the legend DISK, or (if, at the same time, the system diskette also requires attention) SYSDSK.

When you then invoke the mode selection display onto the screen and enter selector character "G" against "Selection," the screen picture changes to the "Native User Diskette" display.

The "Native User Diskette" display shows the status, and allows you to control, the direct attached diskette drive. The DEVICE STATUS displayed may be:

STARTED  
NOT READY  
LOAD NEXT DISKETTE  
DEFECTIVE DISKETTE

STARTED indicates that the diskette device can accept commands from the source program. NOT READY indicates that a command was issued either to a stopped drive or to a started drive without diskette or with open cover. It can also indicate a hardware malfunction such as a torn drive belt, a defective index pulse sensor, or a wrong type of diskette.

**Note:** The READY and NOT READY indications do not immediately reflect any manual interference; they show the state of the diskette I/O as it was when the device was last addressed. For example, when the device is ready and you remove the diskette, the status will still show READY until the device is addressed. Only then will the indication change to NOT READY. LOAD NEXT DISKETTE indicates that a new diskette is required.

DEFECTIVE DISKETTE indicates that machine-internal error recovery failed and that, to recover, the diskette has to be replaced or the service representative to be called.

ERROR CODE is a two-digit code. For detailed information, refer to *IBM 4321/4331 Processor Functional Characteristics and Processor Complex Configurator*, GA33-1526.


"N" for START  
"S" for STOP  
"R" for RESET

The operation specified is executed when you press the ENTER key.

**START** This operation is rarely required because the action of loading a diskette and closing the cover makes the device automatically ready. Alternatively, only the cover need be opened and then closed. The START command allows you to make the diskette ready from the operator console, provided a diskette is mounted.

**STOP** This command halts the device at the completion of the current operation and makes the device not ready. You should stop the device prior to removing the diskette to make sure that you do not disturb any operation in progress.

**RESET** This command performs the start function as described above, and the device is conditioned to move the access mechanism to its home position the next time a command is received.



The following message is displayed when an invalid character is entered:

**Invalid Character**


## Diskette Device Address

The "Diskette Device Address" display permits changing the device address of the diskette I/O.

To select "Diskette Device Address":

1. Type "H" into the mode selection display next to "SELECTION"
2. Press ENTER

The display appears, showing the current device address.



The address, which must be within the range of X'009' through X'01F', must be entered into the alter field (\*...\*) of the address display field. When ENTER is pressed, the new (valid) address replaces the old address.

**Note:** The diskette drive may be configured even if it is not physically attached. If it is addressed during system operation, "intervention required" is presented.

### Specification Errors/Messages:

**Invalid Device Address:** Appears if an invalid device address has been specified.

**Duplicate Device Address:** Appears if the same address has already been specified for one of the native displays or printers.

**Configuration Update Complete:** Appears when the system has finished processing of the configuration update specified by the operator.




## Chapter 4. Problem Determination


### Procedure

1. Check if your problem is listed on the following page.
2. If your problem is *not* listed, go to Entry 1, page 4-3.
3. If your problem *is* listed, go to the Entry shown.


Always note down a problem and the steps you take to solve it. Report the details if necessary to the service representative. The report helps the service center to give you good service.

PROBLEM	GO TO	
	ENTRY	PAGE
After pressing Power On the POWER COMPLETE light does not come on.	1	4 - 3
Power drops during normal operation.	1	4 - 3
"PROGRAM LOAD" display is not displayed after IML.	2	4 - 3
Error during IPL after IML was successfully performed.	3	4 - 4
Operating system message displayed.	4	4 - 4
"CHECKSTOP" displayed on Line 21.	5	4 - 6
System stops with BASIC CHECK light on.	6	4 - 6
SYSTEM light and WAIT lighth on.	7	4 - 6
SYSTEM light on.	9	4 - 6
WAIT light on.	8	4 - 6
Any teleprocessing malfunction.	10	4 - 21
Any loop feature malfunction.	11	4 - 7
Any Reference Code displayed on Line 23.	12	4 - 17
DISK or SYSDISK displayed on Line 21.	13	4 - 20








**B** From previous page




No


LINE 25	1 - 6	9 - 15	16 - 19	30 - 37	39 - 41	44	58 - 64
IA TEST	X	X	X ? +	3270	NUM	^	X
	X -5			1052			X
	X c-f		Canadian	HANDP			X
	X !		French				X
	X !		Symbols				X
	X						X





No





**C** Continue on next page.











IPL malfunction

From page 4-4

If this is not the first IPL since power on, you get the program load display by:  
• Pressing MODE SEL  
• Keying in L  
• Pressing ENTER  
The specifications from the last IPL appear in the display. A description of entries into IPL display is given under "Program Load Display" in Chapter 3 of this manual.

Check that IPL device is powered on.

Check that IPL device is ready.

Only the IPL device should be ready, all other I/O devices are only powered on.

Check for correct IPL device address on the PROGRAM LOAD screen.

First IPL since power on

No

If the specifications are to remain the same; if not, key in new specifications and press ENTER.


Press ENTER


Yes


Key in specifications. Press ENTER


LOAD appears in line 21 from the moment ENTER is pressed, until a valid PSW is loaded.


G Continue on next page.
































From page  
4 – 18

IBM MAINTENANCE AND SERVICE PROGRAM SELECTION

LV: CA UNIT CHECK LOG DISPLAY PAGE:

LINE	SENSE	CMD	CHECK	TIME	LAST ENTRY	CONFIG		
NBR	BYTE 2		COUNT	MO/	DY/	HR/	MI	BYTE 2-3
32	06	00	002	00	00	00	00	18 20
33	06	00	001	00	00	00	00	18 20
33:	E3	0C	001	00	00	00	00	18 20

LAST ERASE DATE: FIRST LOG: LAST LOG:  
 LOG COUNT: LAST REF. CODE: 89FFFF01 33E30C00

PRESS ENTER FOR NEXT LOG

SELECTION: 2C TIMER: DATA: ADDR:  
TOD: SEC

Compare SENSE BYTE 2 value  
in table on page 4 – 24.

Example: 06 Table  
06 A

- Action A**  
 The reason is a wrong  
 or defective program.
- Correct program
  - Change configuration
  - Provide correct configuration.

## Sense Byte Table

Sense Byte 2					
04	A	28	None	96	None
05	A	29	C	A0	None
06	A	2A	C	A1	None
07	A	2C	C	A2	A
08	A	2D	C	A3	A
09	A	2E	C		
0A	A	30	A	C0	A B
0B	A	31	C	C1	A
0C	A	60	None	C2	C
0D	A	61	A	C4	C
0E	A	62	None	C5	C
0F	A	63	None	C6	C A
10	A	64	None	C7	A
11	A	70	C		
12	A	71	C	E2	C
13	A	72	None	E3	B
14	A	73	None	E4	C
15	A	74	None	E5	B C
16	A	75	None	E6	C
17	A	76	None	E7	C
18	A	80	C	E8	C
19	A	82	A	E9	C
		84	C	EA	A B C
20	C	85	B	EB	A
21	C	86	C	EC	C
22	C	90	C	ED	C
23	C	91	A	F0	B C
24	C	92	None	F1	B C
25	C	93	C	F2	A
26	C	95	A	F3	A
27	C				

### Action A

The reason is a wrong or defective program.

- Correct program.
- Change configuration.
- Provide correct configuration by new installation.

### Action B

The reason is an operator handling error.

- Check local and remote modems for matching strapping options.
- Check with remote operator what handling is required at both ends and restart in correct sequence.

### **Action C**

The reason is an unpowered modem or auto call unit.

- Power modem or auto call unit up.
- For stand alone modems and auto call units follow the appropriate modem check out procedure.



## Chapter 5. Reference Information

### Restart Procedures for the IBM 5424 Multi-Function Card Unit (MFCU)

There are no separate operating procedures for the 5424 MFCU Attachment. Operating procedures for the 5424 MFCU are contained in:

System/370 5424 Multifunction Card Unit Programmer's Reference and Operator's Guide, GA21-9167.

There are a number of restart procedures for the 5424 which are given as operator codes and are issued at the end of operator messages. These codes and restart procedures are explained in the following pages.

The restart code (RS) numbers are:

- 00 Not ready
- 10 Read check
- 12 Read check and print check
- 20 Punch check
- 21 Punch check and read check
- 22 Punch check and print check
- 23 Punch check, read check and print check
- 30 Print check
- 40 Hopper check
- 42 Hopper check and print check
- 50 Feed check
- 51 Feed check and hopper check
- 54 Feed check and punch check
- 55 Feed check, hopper check and punch check
- 60 Error on recovery

When the second digit is a number other than 0, two or more checks have occurred at once.

#### ***Restart Information Field***

For the IBM 5424 (MFCU) the error messages provided by the operating system are extended by the "Restart Information Field." This field is present only when a permanent error that requires operator action has occurred.

There are four formats, each depending on the type of check.

Feed check format:

RS =   H  S  N =

Read equipment check format:

RS =   H  C =

Punch equipment check format:

RS =   H  S

All other check formats:

RS =   H

Legend:

Indicates a number

**RS:** Indicates the beginning of the restart information field.

**H:** Indicates the hopper field. The number given is that of the affected hopper.

**S:** Indicates the stacker field. The number given is that of the affected stacker.

**N:** Indicates the number of cards involved in the feed check.

**C:** Indicates the column field. The number given is that of the affected column(s) where the first read check occurred.

After pressing NPRO, the cards in the primary feed path enter stacker 1, and the cards in the secondary feed path enter stacker 4. Normally stackers 1 and 2 are used for the primary feed path, and stackers 3 and 4 for the secondary feed path.

## ***Operator Restart Instructions***

### **Procedure**

#### **00 Device not Ready**

Reasons for not-ready can be:

- Specified feed not ready
- Hopper empty
- Stacker full
- Chip box full or out
- Cover open
- Stop key pressed

1. Determine the cause of the not-ready message by inspecting the indicators on the MFCU operator panel, then correct the condition.
2. Press the MFCU start key to continue the job. If the specified feed is not ready, press the MFCU stop key, then the start key.

### **10 Read Check**

1. Press MFCU stop key.
2. Lift the cards in the hopper indicated by the error message and press the NPRO key. One card is fed into stacker 1. If the NPRO key does not work, remove the card manually.
3. Ensure that this card was placed in the hopper correctly, and was not off-punched, or damaged. If the card is off-punched or damaged, re-punch card. Place the card ahead of the deck in the specified hopper.
4. Press MFCU start key to continue the job.

### **12 Read Check and Print Check**

1. Press MFCU stop key.
2. Mark the last card in each stacker that is being used for output. If in doubt, mark the last card in every stacker.
3. Lift the cards in the hopper indicated by the error message and press the NPRO key. One card is fed into stacker 1. If the NPRO key does not work, remove the card manually.
4. Ensure that this card was placed in the hopper correctly, and was not incorrectly punched or damaged. If the card is off-punched or damaged, re-punch card. Place the card ahead of the deck in the specified hopper.
5. Press MFCU start key to continue the job.
6. Upon completion of the run, identify the output files with "print check." The cards to be checked for print errors are the marked cards and the two cards immediately preceding each marked card.

### **20 Punch Check**

1. Press MFCU stop key.
2. Remove the last card from the stacker indicated in the error message, mark the card and return it to the stacker.
3. Lift the cards in the hopper indicated by the error message and press the NPRO key. One card is fed into stacker 1. If the NPRO key does not work, remove the card.
4. Place this card under the other cards of the hopper indicated in the error message.
5. If blank cards are being punched, press MFCU start key to continue the job.
6. If pre-punched cards are being punched, place an additional blank card under all cards in the hopper indicated in the error message.
7. Press MFCU start key to continue the job.
8. When job is completed, punch and verify the prepunched information from the marked card into the card immediately following it. Discard the marked card or save it for the CE.

### **21 Punch Check and Read Check**

1. Press MFCU stop key.
2. Remove the last card from the stacker indicated by the error message, mark the card and return it to the stacker.
3. Lift the cards in the hopper indicated in the error message and press the

- NPRO key. One card is fed into stacker 1. If the NPRO key does not work, remove the card.
4. Ensure that this card was placed in the hopper correctly, and was not off-punched, or damaged. If card is off-punched or damaged, re-punch card. Place the card ahead of deck in specified hopper.
  5. Place an additional blank card under all cards in the hopper indicated by the error message.
  6. Press MFCU start key to continue the job.
  7. When the job is completed, punch and verify the pre-punched information from the marked card into the card immediately following it. Discard the marked card or save it for the CE.

## **22 Punch Check and Print Check**

1. Press MFCU stop key.
2. Mark the last card in each stacker being used for output. If in doubt, mark the last card in every stacker. The marked card(s) or each immediately preceding card may be misprinted.
3. Remove the last card from the stacker indicated in the error message, mark the card and return it to the stacker.
4. Lift the cards in the hopper indicated in the error message and press the NPRO key. One card is fed into stacker 1. If the NPRO key does not work, remove the card manually.
5. Place this card under the other cards of the hopper indicated in the error message.
6. If blank cards are being punched, press MFCU start key to continue the job.
7. If pre-punched cards are being punched, place an additional blank card under all cards in the hopper indicated in the error message.
8. Press MFCU start key to continue the job.
9. When the job is completed, punch and verify the pre-punched information from the marked card into the card immediately following it. Discard the marked card or save it for the CE.

## **23 Punch Check, Read Check and Print Check**

1. Press MFCU stop key.
2. Mark the last card in each stacker that is being used for output. If in doubt, mark the last card in every stacker. The marked card(s) or each immediately preceding card may be misprinted.
3. Remove the last card from the stacker indicated in the error message, mark the card, and return it to the stacker.
4. Lift the cards in the hopper indicated by the error message and press the NPRO key. One card is fed into stacker 1. If the NPRO key does not work, remove the card manually.
5. Ensure that this card was placed in the hopper correctly, and was not off-punched, or damaged. If the card is off-punched or damaged, re-punch card. Place card ahead of deck in the specified hopper.

6. Place an additional blank card under each card in the hopper indicated by the error message.
7. Press MFCU start key to continue the job.
8. When the job is completed, punch and verify the pre-punched information from the marked card into the card immediately following it. Discard the marked card or save it for the CE.

### 30 Print Check

1. Press MFCU stop key.
2. Mark the last card in each stacker that is being used for output. If in doubt, mark the last card in every stacker.
3. Press MFCU start key to continue the job.
4. Upon completion of the run, identify the output files with "print check." The cards to check for print errors are the marked cards and the two cards immediately preceding each marked card.

### 40 Hopper Check

1. Straighten and place cards correctly in the specified hopper.
2. Press MFCU start key to continue job.

### 42 Hopper Check and Print Check

1. Press MFCU stop key.
2. Mark the last card in each stacker that is being used for output. If in doubt, mark the last card in every stacker.
3. Straighten or place cards correctly in the specified hopper.
4. Press MFCU start key to continue the job.
5. Upon completion of the run, identify the output files with "print check." The cards to check for print errors are the marked cards and the card immediately preceding each marked card.

### 50 Feed Check

1. Open MFCU top cover.
2. If the error message indicates a secondary feed check, remove the card from the primary (upper) wait station and place it under the cards (if any) in the primary hopper. This prevents the unnoticed run-out of this primary card when you attempt to clear the secondary path later in this procedure. If the error message indicates a primary feed check, remove the card from the secondary (lower) wait station and place it under the cards (if any) in the secondary hopper.
3. Remove all remaining cards from the card feed path starting at the area between the hopper and wait station and progressing through the punch and print stations. Keep cards face down and in sequence.
4. Check the number of cards removed with the card number displayed in the error message. If equal go to step 6.
5. If the number of cards removed is smaller than the message indicates, remove the number of missing cards from the stacker indicated in the error message and place them on the bottom of the stack of cards removed in step 3.
6. Place removed cards under the cards (if any) in the indicated hopper and close the MFCU cover.
7. Lift cards in the primary hopper and press the NPRO key to turn off error indicator on MFCU panel. If error indicator does not turn off, raise the cards in the secondary hopper and press the NPRO key. If only the secondary path

was in use, press the NPRO key twice, because the automatic path selection goes to the primary path first; pressing the NPRO key only once merely results in resetting an error in the primary path. If the NPRO key does not work, check that the card path is clear, because a wrongly positioned card can inhibit the NPRO key.

8. Press MFCU start key to continue the job.

### **51 Feed Check and Hopper Check**

1. Open MFCU top cover.
2. If the error message indicates a secondary feed check, remove the card from the primary (upper) wait station and place it under the cards (if any) in the primary hopper. If the error message indicates a primary feed check, remove the card from the secondary (lower) wait station and place it under the cards (if any) in the secondary hopper.
3. Remove all remaining cards from the card feed path starting at the area between the hopper and wait station and progressing through the punch and print station. Keep cards face down and in order.
4. Remove the card that has not been ejected from the hopper. This card is either completely or partly located in the hopper.
5. Check the number of cards removed with the card number displayed in the error message. If equal go to step 6.
6. If the number of cards removed is smaller than the message indicates, remove the number of missing cards from the stacker indicated by the error message and place them on the bottom of the stack of cards removed in step 3.
7. Place removed cards under the cards (if any) in the indicated hopper and close MFCU cover.
8. Lift cards in the primary hopper and press the NPRO key to turn off the error indicator on MFCU panel. If the error indicator does not turn off, raise the cards in the secondary hopper and press the NPRO key. If the NPRO key does not work, check that the card path is clear, because a wrongly positioned card can inhibit the NPRO key.
9. Press MFCU start key to continue the job.

### **54 Feed Check and Punch Check**

1. Open MFCU top cover.
2. If the error message indicates a secondary feed check, remove the card from the primary (upper) wait station and place it under the cards (if any) in the primary hopper. If the error message indicates a primary feed check, remove the card from the secondary (lower) wait station and place it under the cards (if any) in the secondary hopper.
3. Remove all remaining cards from the card feed path starting at the area between the hopper and wait station and progressing through the punch and print stations. Keep cards face down and in order. If there is a card in the punch station or corner station, replace it with a blank card or a pre-punched card as required.
4. Check the number of cards removed with the card number displayed in the error message. If equal go to step 6.
5. If the number of cards removed is smaller than the message indicates, remove the missing cards from the stacker indicated by the error message and place them on the bottom of the stack of cards removed in step 3.
6. Place the removed cards under the cards (if any) in the indicated hopper and close MFCU cover.
7. Lift cards in the primary hopper and press the NPRO key to turn off the error

indicator on MFCU panel. If the error indicator does not turn off, raise cards in the secondary hopper and press the NPRO key. If the NPRO key does not work, check that the card path is clear, because a wrongly positioned card can inhibit the NPRO key.

8. Press MFCU start key to continue the job.

### **55 Feed Check, Hopper Check and Punch Check**

1. Open MFCU top cover.
2. If the error message indicates a secondary feed check, remove the card from the primary (upper) wait station and place it under the cards (if any) in the primary hopper. If the error message indicates a primary feed check, remove the card from the secondary (lower) wait station and place it under the cards (if any) in the secondary hopper.
3. Remove all remaining cards from the card feed path starting at the area between the hopper and wait station and progressing through the punch and print station. Keep cards face down and in order. If there is a card in the punch station or corner station, replace it with a blank card or a pre-punched card as required.
4. Remove the card that has not been ejected from the hopper. The card is either completely or partly located in the hopper.
5. Check the number of cards removed with the card number displayed in the error message. If equal go to step 6.
6. If the number of cards removed is smaller than the message indicates, remove the number of missing cards from the stacker indicated in the error message and place them on the bottom of the stack of cards removed in step 3.
7. Place removed cards under the cards (if any) in the indicated hopper and close MFCU cover.
8. Lift the cards in the primary hopper and press the NPRO key to turn off the error indicator on MFCU panel. If the error indicator does not turn off, raise the cards in the secondary hopper and press the NPRO key. If the NPRO key does not work, check that the card path is clear, because a wrongly positioned card can inhibit the NPRO key.
9. Press MFCU start key to continue job.

### **60 Error on Recovery**

To recover, when an error condition occurs during a restart procedure, re-establish the condition that existed when the restart procedure was started, and then repeat the restart procedure.

## Manual Calling on Integrated Modem WT Switched Line with Auto Answer

### *Connection Sequence*

#### *If the line is the calling side:*

1. Disable the line (if not done before (see Note 1)).
2. Lift the handset and dial the number of the station to be called.
3. Ensure that the called station is in data mode. Switching to data mode is done by the operator (if manual answering station) or automatically after completing the answer tone (if auto answering station, see Note 2).
4. Enable the line immediately (see Notes 3 and 4).
5. Replace the handset.

**Note 1:** Manual dialing from the enabled line is not possible.

**Note 2:** In certain countries, the answer tone is not used for mode switching. In this case, consult the TP specialist.

**Note 3:** If the line is enabled during receiving the answer tone, the result may be unpredictable.

**Note 4:** Don't make noise after the called station enters data mode and before the line is enabled. Otherwise, it will be recognized as receive data at the called station.

#### *If the line is the called side:*

Enable the line before or during being called (but never lift the handset) (see Notes 1 and 2).

**Note 1:** If the handset is lifted before or during being called the result may be unpredictable.

**Note 2:** For use of the handset for telephone conversation disable the line first.

### *Disconnection Sequence*

In either case where the line is the calling side or the called side, disable the line, if not done by the software automatically (see Note).

**Note:** Otherwise, the telephone charge continues to accumulate (if the calling station) or the line stays busy and cannot accept any other calls (if the called station).

## 3340 String Switch

Since the 3340 string switch is not program-controlled, switching must be done by the operator.

The 3340 string must always be assigned (switched) to one processor at a time. To switch from processor A (a 4331, for example) to processor B (a System/370 Model 138, for example), follow these instructions:

1. Wait until all disk jobs are finished or flip the 3340 start/stop switch to "Stop."
2. Flip the interface A switch on the 3340 controller from "enable" to "disable."
3. Switch power off at the 3340 controller.
4. Flip the interface B switch on the 3340 controller from "disable" to "enable."
5. Switch power on at the 3340 controller and check that the 3340 start/stop switch is at "Start."
6. Processor B is now ready to process jobs on the switched 3340/3344s.

To reverse the string switch assignment, proceed as follows:

1. Wait until all disk jobs are finished or flip the 3340 start/stop switch to "stop."
2. Flip interface B switch to "disable."
3. Switch power off at the 3340 controller.
4. Flip the interface A switch to "enable" and check that the 3340 start/stop switch is at "start."
5. Switch power on at the 3340 controller.
6. Processor A is now ready to process jobs on the switched 3340/3344s.

## Conversion Binary to Hexadecimal to Decimal

Binary	Hex	Decimal				
		$16^4$	$16^3$	$16^2$	$16^1$	$16^0$
0001	1	65,536	4,096	256	16	1
0010	2	131,072	8,192	512	32	2
0011	3	196,608	12,288	768	48	3
0100	4	262,144	16,384	1,024	64	4
0101	5	327,680	20,480	1,280	80	5
0110	6	393,216	24,576	1,536	96	6
0111	7	458,752	28,672	1,792	112	7
1000	8	524,288	32,768	2,048	128	8
1001	9	589,824	36,864	2,204	144	9
1010	A	655,360	40,960	2,560	160	10
1011	B	720,896	45,056	2,816	176	11
1100	C	786,432	49,152	3,072	192	12
1101	D	851,968	53,248	3,328	208	13
1110	E	917,504	57,344	3,584	224	14
1111	F	983,040	61,440	3,840	240	15

To convert a binary number (see the table above), proceed as follows:

1. Separate the binary number by spacing it into groups of four bits each, starting from the right. If necessary, add leading zeros for leftmost group. Thus:

Binary 110110110 = 0001 1011 0110.

2. Using the first two columns of the table, convert each group of four binary bits into hexadecimal (hex). Thus:

Binary 0001 1011 0110 = Hex 1B6.

3. Working from the right, relate bits of the hex number to the associated decimal column. Thus:

6 relates to  $16^0$  column, B relates to  $16^1$  column and 1 relates to  $16^2$  column.

Using bits in the hex column as reference, find the associated decimal part and add decimal parts to get the decimal total. Thus:

Hex 6	=	( $16^0$ column)	decimal	6
Hex B	=	( $16^1$ column)	decimal	176
Hex 1	=	( $16^2$ column)	decimal	256
				===
			decimal	438 = Hex 1B6
				= Binary 110110110

## Katakana Feature

When the Katakana feature is installed your console has a special keyboard marked with Katakana characters. There are 48 data keys and four shift keys.

### Data Keys

On the top of each data key up to four characters (Katakana as well as regular alphanumerics and symbols) are shown. Thus each data key allows you to enter up to four characters, one or two of which may be blanks.

### Shift Keys

There are four shift keys (see column 2 of Table). The shift keys set the keyboard for selecting characters. Before entering data, press the appropriate shift key for either upper left, lower left, upper right, or lower right characters. Once selected, a shift stays in force until (1) another shift key or (2) the MODE SEL DIAG key is pressed. Pressing this key sets alphameric mode.

You can see which shift has been pressed by looking at the status indicator on line 25 of the screen (see column 4 of Table).

### Messages

When the Katakana feature is installed, messages from the operating system may be displayed in Katakana but other messages (for example, maintenance displays) appear in English.

SHIFT	SYMBOL ON SHIFT KEY	MODE SET	STATUS INDICATOR (LINE 25)	NOTES
Upper left	英記号	Alpha symbol	3270↑ or MAN OP↑	—
Lower left	英数	Alpha-meric	3270 or MAN OP	After IPL the console has 3270 status and alphameric mode.
Upper right	カナ記号	Katakana symbol	カナ↑	Console has 3270 status. To switch to MAN OP status (with alphameric mode) press Mode SEL DIAG.
Lower right	カナ	Katakana	カナ	

For an illustration of the Katakana keyboard, see *IBM 3270 Information Display System Character Set Reference*, GA27-2837.

## CA Configuration Charts

These charts are provided for reference. They show the options that can be entered by the service representative when the CA is permanently configured at installation time.



**Line Address 31**

```

Hardware
Configuration
Byte 2 and 3 ..... Line Control Procedure
                        ( )S/S   ( )BSC   ( )SDLC
Clocking                ( )Modem   ( )Business Machine
Adapter Type            ( )EIA      ( )LOCAL ( )38LS ( )DDS ( )X.21
Link Type                1 ( )Switched ( )Leased ( )Leased Switched Backup
If Leased                ( )2 Wire  ( )4 Wire ( )RPQ installed# .....
Line Speed for BSC/SDLC ( )BPS

Common
Line Connection          ( )Point   ( )Multipoint
                        to Point
Duplex                   ( )Half    ( )Full
Perm Request to Send    ( )Yes   ( )No
Wrap Test Selection     ( )Modem ( )CA 1/F
Auto/Manual Answer      ( )Auto   ( )Manual
Select Standby          ( )Yes    ( )No
Modem Answer Tone (Hz)  ( )2025  ( )2100
Auto Call Adapter       ( )Yes   ( )No
If yes: ACU Interface   ( )1     ( )2

Synchronous (Common)
New Sync                 ( )Yes   ( )No
Data Signal Rate Select ( )Low    ( )High
High Speed Operation    ( )Yes   ( )No
Modem Procedure         ( )CDSTL ( )DTR

Synchronous (BSC)
EIB Mode                 ( )Yes   ( )No
Data Code                ( )ASCII ( )EBCDIC

Synchronous (SDLC)
NRZI                     ( )Yes   ( )No

Asynchronous (S/S)
Read Interrupt           ( )Yes   ( )No
Write Interrupt          ( )Yes   ( )No
Unit Except Suppress     ( )Yes   ( )No
Delay Select (CHAR)      ( )0     ( )1     ( )2
Line Speed(BPS) ( )2400* ( )1200  ( )600   ( )300   ( )134.5 ( )110 ( )75
Stop Bit(s)*            ( )One   ( )Two
CR as LN CTRL CHAR*     ( )Yes   ( )No
    
```

Remote Terminal(s)

Poll Addr	Remote Selection Addr.	Terminal Type	Remote Modem Type	Local Modem Type	Customer Office Phone NBR	Remote Phone NBR (Switched)	Local Phone NBR (Switched)

**Line Address 32**

```

Hardware
Configuration
Byte 2 and 3 ..... Line Control Procedure
                        ( )S/S   ( )BSC   ( )SDLC
Clocking                ( )Modem   ( )Business Machine
Adapter Type            ( )EIA     ( )LOCAL ( )38LS ( )DDS ( )X.21
Link Type               ( )Switched ( )Leased ( )Leased Switched Backup
If Leased               ( )2 Wire  ( )4 Wire ( )RPQ installed#.....
Line Speed for BSC/SDLC ( )BPS

Common
Line Connection        ( )Point   ( )Multipoint
                        to Point
Duplex                 ( )Half   ( )Full
Perm Request to Send  ( )Yes   ( )No
Wrap Test Selection    ( )Modem ( )CA I/F
Auto/Manual Answer     ( )Auto  ( )Manual
Select Standby        ( )Yes   ( )No
Modem Answer Tone (Hz) ( )2025 ( )2100
Auto Call Adapter     ( )Yes   ( )No
If yes: ACU Interface ( )1     ( )2

Synchronous (Common)
New Sync              ( )Yes   ( )No
Data Signal Rate Select ( )Low   ( )High
High Speed Operation  ( )Yes   ( )No
Modem Procedure       ( )CDSTL ( )DTR

Synchronous (BSC)
EIB Mode              ( )Yes   ( )No
Data Code             ( )ASCII ( )EBCDIC

Synchronous (SDLC)
NRZI                  ( )Yes   ( )No

Asynchronous (S/S)
Read Interrupt        ( )Yes   ( )No
Write Interrupt       ( )Yes   ( )No
Unit Except Suppress  ( )Yes   ( )No
Delay Select (CHAR)   ( )0     ( )1     ( )2
Line Speed(BPS) ( )2400* ( )1200 ( )600 ( )300 ( )134.5 ( )110 ( )75
Stop Bit(s)*         ( )One   ( )Two
CR as LN CTRL CHAR*  ( )Yes   ( )No

* RPQ 750276 (TTC2) only
    
```

**Remote Terminal(s)**

Poll Addr	Remote Selection Addr.	Terminal Type	Remote Modem Type	Local Modem Type	Customer Office Phone NBR	Remote Phone NBR (Switched)	Local Phone NBR (Switched)

**Line Address 33**

```

Hardware
Configuration
Byte 2 and 3 ..... Line Control Procedure
                        ( )S/S  ( )BSC  ( )SDLC
Clocking                ( )Modem ( )Business Machine
Adapter Type           ( )EIA    ( )LOCAL ( )38LS ( )DDS ( )X.21
Link Type              ( )Switched ( )Leased ( )Leased Switched Backup
If Leased              ( )2 Wire ( )4 Wire ( )RPQ installed#.....
Line Speed for BSC/SDLC ( )BPS

Common
Line Connection        ( )Point ( )Multipoint
                       to Point
Duplex                 ( )Half  ( )Full
Perm Request to Send  ( )Yes  ( )No
Wrap Test Selection   ( )Modem ( )CA I/F
Auto/Manual Answer    ( )Auto  ( )Manual
Select Standby        ( )Yes  ( )No
Modem Answer Tone (Hz) ( )2025 ( )2100
Auto Call Adapter     ( )Yes  ( )No
If yes: ACU Interface ( )1    ( )2

Synchronous (Common)
New Sync              ( )Yes  ( )No
Data Signal Rate Select ( )Low  ( )High
High Speed Operation  ( )Yes  ( )No
Modem Procedure       ( )CDSTL ( )DTR

Synchronous (BSC)
EIB Mode              ( )Yes  ( )No
Data Code             ( )ASCII ( )EBCDIC

Synchronous (SDLC)
NRZI                  ( )Yes  ( )No

Asynchronous (S/S)
Read Interrupt        ( )Yes  ( )No
Write Interrupt       ( )Yes  ( )No
Unit Except Suppress  ( )Yes  ( )No
Delay Select (CHAR)   ( )0    ( )1    ( )2
Line Speed(BPS) ( )2400* ( )1200 ( )600 ( )300 ( )134.5 ( )110 ( )75
Stop Bit(s)*         ( )One  ( )Two
CR as LN CTRL CHAR*  ( )Yes  ( )No
    
```

**Remote Terminal(s)**

Poll Addr	Remote Selection Addr	Terminal Type	Remote Modem Type	Local Modem Type	Customer Office Phone NBR	Remote Phone NBR (Switched)	Local Phone NBR (Switched)

**Line Address 34**

```

Hardware
Configuration
Byte 2 and 3 ..... Line Control Procedure
                        ( )S/S  ( )BSC  ( )SDLC
Clocking                ( )Modem  ( )Business Machine
Adapter Type            ( )EIA      ( )LOCAL ( )38LS  ( )DDS ( )X.21
Link Type                ( )Switched ( )Leased ( )Leased Switched Backup
If Leased                ( )2 Wire  ( )4 Wire ( )RPQ installed#.....
Line Speed for BSC/SDLC ( )BPS

Common
Line Connection          ( )Point  ( )Multipoint
                        to Point
Duplex                   ( )Half   ( )Full
Perm Request to Send    ( )Yes   ( )No
Wrap Test Selection     ( )Modem ( )CA I/F
Auto/Manual Answer      ( )Auto  ( )Manual
Select Standby          ( )Yes   ( )No
Modem Answer Tone (Hz)  ( )2025 ( )2100
Auto Call Adapter       ( )Yes   ( )No
If yes: ACU Interface   ( )1     ( )2

Synchronous (Common)
New Sync                 ( )Yes   ( )No
Data Signal Rate Select ( )Low   ( )High
High Speed Operation     ( )Yes   ( )No
Modem Procedure          ( )CDSTL ( )DTR

Synchronous (BSC)
EIB Mode                 ( )Yes   ( )No
Data Code                 ( )ASCII ( )EBCDIC

Synchronous (SDLC)
NRZI                      ( )Yes   ( )No

Asynchronous (S/S)
Read Interrupt           ( )Yes   ( )No
Write Interrupt          ( )Yes   ( )No
Unit Except Suppress     ( )Yes   ( )No
Delay Select (CHAR)      ( )0     ( )1     ( )2
Line Speed(BPS) ( )2400* ( )1200  ( )600   ( )300   ( )134.5 ( )110 ( )75
Stop Bit(s)*            ( )One   ( )Two
CR as LN CTRL CHAR*     ( )Yes   ( )No

* RPQ 7S0276 (TTC2) only
    
```

**Remote Terminal(s)**

Port Addr	Remote Selection Addr.	Terminal Type	Remote Modem Type	Local Modem Type	Customer Office Phone NBR	Remote Phone NBR (Switched)	Local Phone NBR (Switched)



**Line Address 36**

```

Hardware
Configuration
  Byte 2 and 3 .....          Line Control Procedure
                                ( )S/S   ( )BSC   ( )SDLC
Clocking                        ( )Modem  ( )Business Machine
Adapter Type                    ( )EIA    ( )LOCAL ( )38LS ( )DDS ( )X.21
Link Type                       ( )Switched ( )Leased ( )Leased Switched Backup
If Leased                       ( )2 Wire ( )4 Wire ( )RPQ installed#.....
Line Speed for BSC/SDLC (      )BPS

Common
Line Connection                 ( )Point   ( )Multipoint
                                to Point
Duplex                         ( )Half   ( )Full
Perm Request to Send          ( )Yes   ( )No
Wrap Test Selection           ( )Modem ( )CA I/F
Auto/Manual Answer            ( )Auto  ( )Manual
Select Standby                 ( )Yes   ( )No
Modem Answer Tone (Hz)        ( )2025 ( )2100
Auto Call Adapter              ( )Yes   ( )No
If yes: ACU Interface         ( )1     ( )2

Synchronous (Common)
New Sync                       ( )Yes   ( )No
Data Signal Rate Select        ( )Low   ( )High
High Speed Operation           ( )Yes   ( )No
Modem Procedure                 ( )CDSTL ( )DTR

Synchronous (BSC)
EIB Mode                       ( )Yes   ( )No
Data Code                       ( )ASCII ( )EBCDIC

Synchronous (SDLC)
NRZI                            ( )Yes   ( )No

Asynchronous (S/S)
Read Interrupt                  ( )Yes   ( )No
Write Interrupt                 ( )Yes   ( )No
Unit Except Suppress            ( )Yes   ( )No
Delay Select (CHAR)             ( )0     ( )1     ( )2
Line Speed(BPS) ( )2400* ( )1200 ( )600 ( )300 ( )134.5 ( )110 ( )75
Stop Bit(s)*                    ( )One   ( )Two
CR as LN CTRL CHAR*            ( )Yes   ( )No

          * RPQ 7S0276 (TTC2) only
  
```

**Remote Terminal(s)**

Poll Addr	Remote Selection Addr.	Terminal Type	Remote Modem Type	Local Modem Type	Customer Office Phone NBR	Remote Phone NBR (Switched)	Local Phone NBR (Switched)

**Line Address 37**

```

Hardware
Configuration
Byte 2 and 3 .....          Line Control Procedure
                               ( )S/S   ( )BSC   ( )SDLC
Clocking                       ( )Modem ( )Business Machine
Adapter Type                   ( )EIA   ( )LOCAL ( )38LS ( )DDS ( )X.21
Link Type                      ( )Switched ( )Leased ( )Leased Switched Backup
If Leased                     ( )2 Wire ( )4 Wire ( )RPQ installed#.....
Line Speed for BSC/SDLC (    )BPS

Common
Line Connection                ( )Point ( )Multipoint
                               to Point
Duplex                        ( )Half ( )Full
Perm Request to Send         ( )Yes ( )No
Wrap Test Selection          ( )Modem ( )CA I/F
Auto/Manual Answer           ( )Auto ( )Manual
Select Standby               ( )Yes ( )No
Modem Answer Tone (Hz)       ( )2025 ( )2100
Auto Call Adapter            ( )Yes ( )No
If yes: ACU Interface        ( )1 ( )2

Synchronous (Common)
New Sync                      ( )Yes ( )No
Data Signal Rate Select      ( )Low ( )High
High Speed Operation         ( )Yes ( )No
Modem Procedure              ( )CDSTL ( )DTR

Synchronous (BSC)
EIB Mode                     ( )Yes ( )No
Data Code                    ( )ASCII ( )EBCDIC

Synchronous (SDLC)
NRZI                          ( )Yes ( )No

Asynchronous (S/S)
Read Interrupt               ( )Yes ( )No
Write Interrupt              ( )Yes ( )No
Unit Except Suppress        ( )Yes ( )No
Delay Select (CHAR)         ( )0 ( )1 ( )2
Line Speed(BPS) ( )2400* ( )1200 ( )600 ( )300 ( )134.5 ( )110 ( )75
Stopbit(s)*                 ( )One ( )Two
CR as LN CTRL CHAR*        ( )Yes ( )No
    
```

**Remote Terminal(s)**

Poll Addr	Remot. Selection Addr.	Terminal Type	Remote Modem Type	Local Modem Type	Customer Office Phone NBR	Remote Phone NBR (Switched)	Local Phone NBR (Switched)

## **Appendix A.**

### **Display Unit IBM 3279-2C Testing and Adjustment**

## Test Procedure

Before executing the procedure described below (Figure A-1) the IBM 3279-2C must have passed the "stand-alone tests" described in the operator's booklet provided with the IBM 3279-2C.




Figure A-1 (Part 1 of 3). 3279-2C Test Procedure




Figure A-1 (Part 2 of 3). 3279-2C Test Procedure




Figure A-1 (Part 3 of 3). 3279-2C Test Procedure

## Color Convergence Procedure

This procedure (Figure A-2) describes how to optimize the settings of the primary colors (red, green and blue) displayed to produce a pure compound color. For example, white contains all three primary colors. If convergence is wrong, you can see traces of each color at the edges of a white character.

If the color convergence procedure is just performed with another 3279, the message CONVERGENCE ON PORT NN is displayed.

**Note:** Before doing color convergence, check the date on the battery located in the access area at the back of the 3279-2C. (The first two numbers represent the month, the second two the year). If the battery is more than 3 years old, change it according to the procedure in this chapter.




Figure A-2 (Part 1 of 3). 3279-2C  
Color Convergence Procedure




Figure A-2 (Part 2 of 3). 3279-2C Color Convergence Procedure




Figure A-2 (Part 3 of 3). 3279-2C Color Convergence Procedure

## Changing the Battery

A battery in the access area at the back of the 3279-2C provides power to the color convergence storage when the display is switched off. If the color convergence has to be adjusted, or if machine check indicator followed by 228 or 229 is displayed on line 25 each time you switch on the display console, change the battery.

**Note:** Each battery is marked with a date-code; the first two numbers show the month, the second two show the year; if a battery is more than 18 months old, do not use it.

Replacement batteries are available from IBM through your IBM marketing representative. Order only sufficient batteries for your immediate needs; batteries can be expected to provide 3 years of normal operation, and those more than 18 months old must not be used as replacements.

The display console should be switched on while the battery is being replaced, if it is switched off the full convergence procedure will be required.

To change the battery:

1. With the 3279-2C switched on open the cover of the access area at the back of the 3279-2C.
2. Unplug the connector from the old battery and remove the battery.

**Note:** Return the old battery to IBM for disposal.

3. Place the new battery in the holder and replace the connector.
4. Close the cover of the access area.
5. Check operation with the new battery:
  - a. Observe the displayed characters and, if necessary, perform the Convergence Procedure described in this chapter.
  - b. Switch power off and wait for approximately five minutes.
  - c. Switch power on; the color convergence should be satisfactory. If the convergence is wrong, unplug the new battery and plug it in again to make sure that the connection is good; then perform the Convergence Procedure. (If the symptom persists, record the problem.)

# Glossary

This glossary contains technical terms associated with this publication. A wider and more general range of terms is contained in IBM Data Processing Glossary, GC20-1699.

IBM is grateful to the American National Standards Institute (ANSI) for permission to reprint its definitions from the American National Standard Vocabulary for Information Processing (Copyright 1970 by American National Standards Institute, Incorporated), which was prepared by Subcommittee X3.5 on Terminology and Glossary of American National Standards Committee X3. These definitions are indicated by an asterisk.

**address translation.** The process of changing the address of an item of data or an instruction from its virtual address to its machine storage address. See also dynamic address translation.

**basic control (BC) Mode.** A mode in which the features of a System/360 computing system and some System/370 features, such as new machine instructions, are operational on a System/370 computing system or a 4300 processor. See also extended control (EC) mode.

**CCITT.** Consultative Committee on International Telegraphy and Telephony.

**control registers.** A set of registers used for operating system control of relocation, priority interruption, program event recording, error recovery, and masking operations.

**control storage.** An area in a subprocessor where the microcode is stored.

**cursor.** A movable marker on a video display used to indicate the position of the next character to be entered on the screen.

**DDS.** DATA-PHONE Digital Service. DATA-PHONE is both a service mark and a trademark of AT&T and the Bell System.

**\*dump.** To copy the contents of all or part of a storage, usually from an internal storage into an external storage.

**dynamic address translation.**

1. The change of a virtual storage address to a machine storage address during execution of an instruction.

See also address translation.

2. A hardware feature that performs the translation.

**EIA.** Electronic Industries Association

**enter.** Refers in this manual to the placing of information into the system by specifying commands, data or addresses at the keyboard, and then pressing the ENTER key. See also "Key In."

**extended control (EC) mode.** A mode in which all the features of a System/370 computing system or a 4300 processor in 370 mode, including dynamic address translation, are operational. See also basic control (BC) mode.

**hexadecimal.** A number system that uses the equivalent of a decimal number 16 as a base.

**initial microcode load.** The procedure that causes the microcode to be loaded into control storage. Abbreviated to IML.

**\*initial program load.** The procedure that causes the initial part of an operating system or other program to be loaded such that the program can then proceed under its own control. Abbreviated to IPL. In the 4321/4331s this procedure is known as "program load."

**\*initialize.** To set counters, switches and addresses to zero or other starting values at the beginning of, or at the prescribed points in, a computer routine.

**integrated adapter (or attachment).** A device which allows I/O devices to be attached to the system without a standard input/output interface.

**\*interrupt.** To stop a process in such a way that it can be resumed.

**key in.** Refers to the typing of characters by means of the alphameric keys at the keyboard. It does not include pressing the ENTER key. See also "Enter."

**machine storage.** The storage where data and instructions actually reside when they are accessed by the processor and channel programs (called real storage in System/370).

**main storage.** All program addressable storage from which instructions may be executed and from which data can be loaded directly into registers. Most machine storage is used as main storage.

**microinstruction.** A basic or elementary machine instruction. Each program, each channel routine, and so on, consists of sequences of microinstructions.

**\*modem.** (Modulator-DEModulator.) A device that modulates and demodulates signals transmitted over data communication facilities.

**multipoint network.** A line or circuit that interconnects several stations in a data communications system.

**native attachment.** A part of some machines that allows I/O devices to be attached to the processor directly instead of via channel and control unit. (Also called integrated attachment and integrated adapter).

**\*online.** Pertaining to equipment or devices under continual control of the processor.

**\*operating system.** Software that controls the execution of computer programs and provides scheduling, debugging, input/output control, accounting, compilation, storage assignment, data management, and related services.

**processor.** A device which fetches instructions from main storage, processes them, and returns the results to main storage. It also analyzes I/O instructions and handles input/output operations and I/O interruptions.

**program load.** See "initial program load."

**program status word.** A doubleword in the processor storage used to control the order in which instructions are executed, and to hold and indicate the status of the computing system in relation to a particular program. Abbreviated to PSW.

**real address.** The address of a location in real storage.

**real storage.** The storage of a computing system where data and instructions in machine storage are made addressable to the processor and channel programs.

**service processor.** A subprocessor which loads microcode, initializes the system, monitors and logs errors, and handles the manual control operations of the system.

**stand-alone program.** An independent program that does not require an operating system.

**teleprocessing.** The processing of data that is received from or sent to remote locations by way of telecommunication lines.

**tributary station.** In a centralized multipoint data communications system, this is a station, other than the control station, that can communicate only with the control station when polled or selected by the control stations.

**typamatic key.** A key that repeats its function as long as it is held down.

**virtual address.** An address which refers to virtual storage and must, therefore, be translated into a machine storage address when it is used.

**virtual storage.** Addressable space that appears to the user as main storage, from which instructions and data are mapped into machine storage. The size of virtual storage is limited by the addressing scheme of the computing system rather than by the actual size of machine storage.

# Index

## A

accent plus what indicator 2-19  
ADDR indicator 2-15, 2-16  
ADDR-COMP: STOP, SYNC indicator 2-16  
address compare display 3-12  
    errors 3-13  
        incomplete entry 3-13  
        invalid address 3-13  
        invalid character 3-13  
alphameric keys 2-6  
ALT key 2-11  
artificial respiration, casualty procedure 1-1

## B

backspace key 2-7  
basic check light 2-4  
binary synchronous communication (BSC) lines 3-39

## C

CA configuration charts 5-12  
CA sense byte table 4-24  
CA trouble 4-22  
CA/ILT indicator 2-17  
capacity counts display 3-28  
check control display 3-15  
    errors 3-16  
        invalid character 3-16  
CHECK STOP indicator 2-14  
CHG DPLY key 2-9  
CHK-CTL: HARD indicator 2-16  
clear reset display 3-50  
CNCL key 2-8  
color convergence procedure, 3279-2C A-5  
communicating with the system 2-1  
communication lines 3-33, 3-36  
    binary synchronous communication (BSC) lines 3-39  
    start / stop lines 3-33  
    synchronous data link control (SDLC) lines 3-36  
    temporary configuration change 3-40  
    tributary station address(es) for BSC lines 3-42  
COMP indicator 2-15  
configuration charts, CA 5-12  
console keyboard 2-6  
    alphameric keys 2-6  
    backspace key 2-7  
    cursor key 2-7  
    space bar 2-7  
    tabulator key 2-7  
control panel 2-4  
    keys 2-5  
control registers 3-19  
conversion binary to hexadecimal to decimal 5-10  
COPY key 2-10  
current PSW display 3-20  
cursor key 2-7  
customer set up for displays and printers 2-21  
    problem determination 2-22

## D

DATA indicator 2-15  
delete key 2-11  
device not ready, 5424 5-2  
DISK indicator 2-15  
diskette 2-20  
    control 2-20  
    diagnostic 2-20  
    system 2-20  
diskette device address display 3-61  
    errors and messages 3-61  
        configuration update complete 3-61  
        duplicate device address 3-61  
        invalid device address 3-61  
diskette trouble 4-21  
display screen, operator console 2-4  
    machine status area 2-4  
    system area 2-4  
display/alter display 3-17  
    errors 3-18  
        check stop 3-18  
        incomplete entry 3-18  
        invalid address 3-18  
        invalid character 3-18  
displays and printers, customers set up 2-21  
divider line on screen 4-8

## E

electric shock, casualty procedure 1-1  
emergency procedures 1-1  
EMU buffers 3-47  
ENTER key 2-11  
ERASE EOF / SP M/O key 2-9  
Erase Input key 2-9  
error on recovery, 5424 5-7

## F

fast mode selection 3-10  
feed check and hopper check, 5424 5-6  
feed check and punch check, 5424 5-6  
feed check, hopper check and punch check, 5424 5-7  
feed check, 5424 5-5  
fire fighting 1-1  
floating point registers 3-22  
function keys 2-8  
    ALT key 2-11  
    CHG DPLY key 2-9  
    CNCL key 2-8  
    COPY key 2-10  
    delete key 2-11  
    ENTER key 2-11  
    ERASE EOF / SP M/O key 2-9  
    Erase Input key 2-9  
    insert mode key 2-11  
    INTR/LINE DISC key 2-9  
    lock key 2-10  
    MOD SEL/DIAG key 2-8  
    REQ / COMM REQ key 2-9  
    RESET key 2-10  
    shift key 2-10

START key 2-10  
STOP key 2-11

## G

general registers 3-23  
glossary X-1

## H

hopper check and print check, 5424 5-5  
hopper check, 5424 5-5

## I

I/O device trouble 4-16  
I/O ERR. ADDR: REF.CODE indicator 2-17  
IML 3-5  
IML key 2-5  
IML trouble 4-10  
indicators 2-14  
    ADDR 2-15, 2-16  
    ADDR-COMP: STOP, SYNC 2-16  
    CA/ILT 2-17  
    CHECK STOP 2-14  
    CHK-CTL: HARD 2-16  
    COMP 2-15  
    DATA 2-15  
    DISK 2-15  
    I/O ERR. ADDR: REF.CODE 2-17  
    insert 2-18  
    IPL ERROR 2-14  
    Katakana 2-19  
    LOAD 2-15  
    LOG PENDING 2-17  
    Loop Msg 2-17  
    MAN 2-14  
    MAN OP 2-19  
    minus function 2-18  
    minus symbol 2-18  
    online 2-18  
    printer not working 2-19  
    printing 2-20  
    R-ADDR 2-16  
    RATE: I-STEP 2-16  
    SAVE 2-15  
    security key 2-19  
    shift 2-18  
    SP messages 2-17  
    STATUS, REF CODE 2-17  
    SYDSK 2-15  
    TEST 2-14, 2-18  
    TIMEOUT ADDR: REF. CODE 2-17  
    TIMER OFF/ON 2-15  
    TOD: SEC/ENBL 2-16  
    TYPE: ANY REF, I/O REF, D-STOR, I-CNTR 2-16  
    wait 2-18  
    what? 2-19  
    wrong place 2-18  
    1MB, 2MB, 4MB, 8MB, 16MB, REAL 2-15  
    1052 2-19  
    3270 2-19  
initial program load (IPL) 3-6

insert indicator 2-18  
insert mode key 2-11  
instruction step display 3-44  
interval timer display 3-45  
INTR/LINE DISC key 2-9  
IPL 3-6, 3-47  
IPL ERROR indicator 2-14  
IPL trouble 4-11

## K

Katakana feature 5-11  
Katakana indicator 2-19  
keyboard Inhibition 2-11  
keyboard lock 2-11  
keyboard/display trouble 4-17  
keyboard, console 2-6

## L

LAMP TEST key 2-5  
line 21 display 2-14  
line 22 display 2-16  
line 23 display 2-17  
line 25 display 2-18  
LOAD indicator 2-15  
loading the control diskette 3-2  
loading the microcode (IML) 3-5  
lock key 2-10  
LOG PENDING indicator 2-17  
Loop Msg indicator 2-17  
loop trouble 4-7

## M

machine save display 3-46  
machine status display 2-13  
main storage display 3-25  
main storage real display 3-29  
main storage size display 3-27  
main storage virtual display 3-30  
    errors 3-30  
        address not translatable 3-31  
        addressing exception 3-31  
        outside page table 3-30  
        outside segment table 3-31  
        page or segment entry invalid 3-31  
        specification exception 3-31  
MAN indicator 2-14  
MAN OP indicator 2-19  
manual calling on integrated modem WT switched line 5-8  
manual operation mode 3-7  
manual operations 3-1  
message analysis 4-15  
message or status on screen 4-8  
minus function indicator 2-18  
minus symbol indicator 2-18  
MOD SEL/DIAG key 2-8  
mode selection 3-7  
    errors 3-9  
        incomplete entry 3-9  
        invalid character 3-9  
modes of operation 3-7

## N

- native displays and printers 3-56
  - configuration rules 3-58
  - errors 3-58
    - configuration update complete 3-58
    - duplicate device address 3-58
    - duplicate diskette address 3-58
    - invalid configuration 3-58
    - invalid device name 3-58
    - invalid keyboard language 3-58
    - only 8 ports effective 3-58
- native user diskette 3-59
  - errors 3-60
    - invalid character 3-60

## O

- online indicator 2-18
- operator console 2-2
  - console keyboard 2-2
  - control panel 2-2, 2-4
    - control panel lights 2-4
  - display screen 2-2

## P

- page description display 3-32
- permanent configuration, CA 5-12
- POWER COMPLETE light 2-5
- POWER IN PROCESS light 2-5
- power off 3-4
- POWER OFF key 2-5
- power on 3-3
- power trouble 4-8
- print check, 5424 5-5
- printer not working indicator 2-19
- printing indicator 2-20
- problem determination, system 4-1
  - entry table 4-2
  - procedure 4-1
  - troubleshooting charts 4-3
- procedures, operator console 3-1
  - address compare 3-12
  - capacity counts 3-28
  - check control 3-15
  - clear reset 3-50
  - communication lines 3-33
  - control registers 3-19
  - current PSW 3-20
  - diskette device address 3-61
  - display/alter 3-17
  - fast mode selection 3-10
  - floating point registers 3-22
  - general registers 3-23
  - IML 3-5
  - initial program load (IPL) 3-6
  - instruction step 3-44
  - interval timer 3-45
  - IPL 3-6, 3-47
  - loading the control diskette 3-2
  - loading the microcode (IML) 3-5
  - machine save 3-46
  - main storage 3-25
  - main storage real 3-29
  - main storage size 3-27
  - main storage virtual 3-30

- mode selection 3-7
- native displays and printers 3-56
- native user diskette 3-59
- page description 3-32
- power off 3-4
- power on 3-3
- program load 3-47
- program reset 3-52
- reset I-Step 3-51
- restart 3-53
- start / stop lines 3-33
- storage address compare 3-12
- storage key 3-24
- store status 3-54
- switching power off 3-4
- switching power on 3-3
- TOD enable 3-55
- program load 3-47
  - errors 3-49
    - incomplete entry 3-49
    - invalid address 3-49
    - invalid character 3-49
    - invalid host device address 3-49
    - invalid reset, select 3-49
    - no console printer configured 3-49
- program reset display 3-52
- punch check and print check, 5424 5-4
- punch check and read check, 5424 5-3
- punch check, read check and print check, 5424 5-4
- punch check, 5424 5-3

## R

- R-ADDR indicator 2-16
- RATE: I-STEP indicator 2-16
- read check and print check, 5424 5-3
- read check, 5424 5-3
- reference code displayed 4-8
- reference information 5-1
- REQ / COMM REQ key 2-9
- reset I-Step 3-51
- RESET key 2-10
- restart 3-53
- restart procedure, 5424 5-1
- ROCF selection 3-56

## S

- save indicator 2-15
- security key indicator 2-19
- sense byte table, CA 4-24
- shift indicator 2-18
- shift key 2-10
- SP messages indicator 2-17
- space bar 2-7
- start / stop lines 3-33
- START key 2-10
- status display, machine 2-13
- STATUS, REF CODE indicator 2-17
- STOP key 2-11
- storage address compare display 3-12
- storage key display 3-24
- store status display 3-54
- string switch, 3340 5-9
- switching power off 3-4
- switching power on 3-3

synchronous data link control (SDLC) lines 3-36  
SYSDSK indicator 2-15  
system diskette 2-20  
SYSTEM light 2-4  
SYSTEM light on 4-14  
system operation mode 3-7

## T

tabulator key 2-7  
teleprocessing trouble 4-22  
temporary configuration change, CA 3-40  
TEST indicator 2-14, 2-18  
TIMEOUT ADDR: REF. CODE indicator 2-17  
TIMER OFF/ON indicator 2-15  
TOD enable 3-55  
TOD: SEC/ENBL indicator 2-16  
tributary station address(es) for BSC lines 3-42  
troubleshooting charts 4-3  
    CA trouble 4-22  
    diskette trouble 4-21  
    divider line on screen 4-8  
    I/O device trouble 4-16  
    IPL trouble 4-12  
    keyboard/display trouble 4-17  
    loop trouble 4-7  
    message analysis 4-15  
    message or status on screen 4-8  
    power trouble 4-8  
    reference code displayed 4-8  
    SYSTEM light on 4-14  
    teleprocessing trouble 4-22  
    WAIT light on 4-14  
TYPE: ANY REF, I/O REF, D-STOR, I-CNTR indicator 2-16

## W

wait indicator 2-18  
WAIT light 2-4  
WAIT light on 4-14  
what? indicator 2-19  
wrong place indicator 2-18

## 1

1MB, 2MB, 4MB, 8MB, 16MB, REAL indicator 2-15  
1052 indicator 2-19  
1052 mode 3-47

## 3

3270 indicator 2-19  
3278-2A console 2-2  
    display screen of 3278-2A console 2-2  
        a/A switch 2-2  
        audible alarm 2-2  
        brightness control 2-2  
        contrast control 2-2  
        normal/test switch 2-2  
        on/off switch 2-2  
        red lights 2-2  
        security keylock 2-2  
3279-2C color console 2-3  
    battery change A-8  
    color convergence procedure 2-3  
    display screen of 3279-2A color console 2-3  
        audible alarm volume control 2-3  
        base color switch 2-3  
        brightness control 2-3  
        display ready light 2-3  
        dual case/mono case switch 2-3  
        normal/test switch 2-3  
        power on light 2-3  
        power on/off switch 2-3  
        security keylock 2-3  
        test light 2-3  
    test procedure A-2  
3340 buffers 3-47  
3340 string switch 5-9

Operator's Library: IBM 4321/4331 Processors  
Operating Procedures and Problem Determination Guide  
Order No. GA33-1525-4

This manual is part of a library that serves as a reference source for system analysts, programmers, and operators of IBM systems. This form may be used to communicate your views about this publication. They will be sent to the author's department for whatever review and action, if any, is deemed appropriate. Comments may be written in your own language; use of English is not required.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation whatever. You may, of course, continue to use the information you supply.

*Note: Copies of IBM publications are not stocked at the location to which this form is addressed. Please direct any requests for copies of publications, or for assistance in using your IBM system, to your IBM representative or to the IBM branch office serving your locality.*

Possible topics for comment are:

Clarity Accuracy Completeness Organization Coding Retrieval Legibility

If you wish a reply, give your name and mailing address:

---

---

---

What is your occupation? \_\_\_\_\_

Number of latest Newsletter associated with this publication: \_\_\_\_\_

Thank you for your cooperation. No postage stamp is necessary if mailed in the U.S.A.  
(Elsewhere, an IBM office or representative will be happy to forward your comments or you may mail directly to the address in the Edition Notice on the back of the title page.)

IBM CORPORATION, ARMONK, N.Y. 10504

Reader's Comment Form


Cut or Fold Along Line

(FHE NO. 4300-U1) Printed in U.S.A. GA33-1525-4

Fold and tape

Please Do Not Staple

Fold and tape



NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES

**BUSINESS REPLY MAIL**  
FIRST CLASS PERMIT NO. 40 ARMONK, N.Y.



POSTAGE WILL BE PAID BY ADDRESSEE:

International Business Machines Corporation  
Department 812 B  
1133 Westchester Avenue  
White Plains, New York 10604

Fold and tape

Please Do Not Staple

Fold and tape

