

# MODEL 8/16 E PROCESSOR

## TEST PART 1

**Consists of:**

Program Description	06-211M95A15
16-Bit Program Listing	06-211M96A13
Bootstrap Object Tape	06-211M17



B06-211R00A15

July, 1977

## MODEL 8/16E PROCESSOR TEST PART 1

1.	MODEL 8/16E PROCESSOR TEST PART 1	06-211R00
1.1	Related Documents	
	Test Program Listing	06-211R00M96A13
	Test Program Tape	06-211R00M17
1.2	Test Programs to be Run Prior to Running this Test	
	Model 8/16E Memory Test	06-221
1.3	Other Applicable Test Programs	
	Common Teletype Basic Confidence Test	06-004
	Common Current Loop Interface	06-184
	Common Carousel Test	06-183
	Common CRT Test	06-146
	Series 16 Floating Point Test	06-205

### 2. PURPOSE OF TEST

This program exhaustively tests the Model 9/16 Processor. All the logic and arithmetic instructions are tested. The Floating Point instructions are not tested (refer to Test 06-205).

### 3. MINIMUM HARDWARE REQUIRED

#### 3.1 Processor

Model 8/16E Processor  
10KB of Memory

#### 3.2 Console Device

Teletype  
CRT  
Carousel 15, 30, 35 or 300

#### 3.3 Paper Tape Reader

Teletype, High Speed Paper Tape Reader, or Carousel 35

#### 4. REQUIREMENTS OF MACHINE UNDER TEST

Location IO contains X'02' for the Console address. If the Console address is different, this location must be changed. (See Appendix 1 for appropriate setup.)

#### 5. LOADING PROCEDURES

##### 5.1 Test Tape Format

The test tape 06-211R00A13 is in absolute, non-zoned object type (M17) with a front end bootloader. This test occupies approximately 9KB of Memory.

##### 5.2 Normal Loading Procedure

Manually enter the X'50' sequence as shown below into memory:

<u>Location</u>	<u>Contents</u>
X'30'	X'0000'
X'32'	X'0000'
X'34'	X'0000'
X'36'	X'0050'
X'50'	X'D500'
X'52'	X'00CF'
X'54'	X'4300'
X'56'	X'0080'
For TTY or Carousel 35	X'78'
HSPTR	X'78'
HSPTR/P	X'78'
	X'0294'
	X'0399'
	X'1399'

Place the program tape in the paper tape reader. Execute at address X'30'.

When the Processor halts, observe the Display Panel. If zero is shown loading is complete; otherwise repeat the loading procedure.

##### 5.3 Multi-Media Diagnostic Loading Procedure

To load this program from the INTERDATA Multi-Media Diagnostic System, refer to Publication Number 06-176A15.

##### 5.4 Program Execution

After the requirements of the Machine Under Test are met and the loading of PART 1 is complete, execute at X'100' and observe that the following title is output:

Model 8/16E PROCESSOR TEST PART 1 06-211R00  
CPU  
\*

## 6. OPERATING PROCEDURES

### 6.1 Normal Testing

After loading is complete, and the proper Processor number has been entered (see Appendix 2), the following is printed:

Enter Ø or 1

If the Processor under test has 16KB or less memory, enter a zero. If the Processor has more than 16KB of memory, enter a one. The test then executes the appropriate subtests a total of 10 times or until an error has been encountered. (See Appendix 4 for meaning of errors.)

### 6.2 Optional Testing

All the printouts can be inhibited by turning the Console OFF or OFF-Line (DU=1). When this is done, a count is made of the total number of times the entire test is repeated. This is stored in memory location TOTAL and is also continuously copied into the Display Panel 2. If an error is detected, a count is made of the total number of errors at memory location TOTERR.

When the Console is turned On-Line, the test is repeated until TOTAL equals NTIMES. The test is terminated and the following characters are printed:

NO ERROR  
NNNN RRRR

where

NNNN = Contents of TOTAL,  
RRRR = Contents of TOTERR.

If any errors are detected while the Console is turned OFF and no errors detected after it was turned ON, the following is printed:

NNNN RRRR

where

N and R have the same meaning as above.

If any errors are detected after turning the Console ON, the following characters are printed and the test is terminated:

ERROR XXXX  
NNNN RRRR

where

XXXX = The last error detected,  
NNNN = Contents of TOTAL,  
RRRR = Contents of TOTERR.

When the Console is turned OFF, the test is aborted if, (1) a spurious interrupt is detected (e.g., an illegal instruction). In this case, the error, which is 1NFl through 1NF9 (N = subtest number in which the error occurred), is copied into the Display Panel and the Processor is halted by loading a PSW of X'8000'. When the EXECUTE switch is depressed and the Console Device is turned ON, the error message is printed; the test is also aborted if TOTERR equals X'FFFF'. In this case, X'FFFF' is copied into the Display Panel and the Processor is halted by loading a PSW of X'8000'. When the EXECUTE switch is depressed and the Console Device is turned ON, characters FFFF ERRORS are printed and the test is terminated.

## 7. ERROR PROCEDURES

In case of an error, further action depends on the type of error (see Appendix 4 for a description of each error number).

Case 1 - the program detects an error; the error number in Display 2 is the same as the error number printed on the Console. The error number dictionary in Appendix 4 should be referred to pinpoint the error.

Case 2 - If a spurious interrupt is detected, the error number is copied into the Display Panel 2 and the Processor is halted by loading a PSW of X'8000'. The error number has the form X'1TFN' where T equals the test number which was executing at the time of the error; N defines the spurious interrupt. See the error numbers in Appendix 4. When the EXECUTE switch is depressed, the error number is printed.

Case 3 - If an error is detected in a test which checks arithmetic operations, refer to Appendix 4. In Tests 8 and 11 which check the Fixed Point Arithmetic instructions, after printing the error number certain registers are also printed.

Case 4 - If a SET MAP instruction error occurs, refer to Appendix 4. Error numbers 1C01 to 1C04 refer to the first part of the test. Error numbers 1C05 to 1C08 refer to the second part of the test. Further diagnosis can be performed by observing which part of the test the error occurred in (see the listing). Then executing the section (see the listing) of the test to find the exact PSW bits which caused the SET MAP instruction to fail.

### 7.1 Examples

#### ERROR 1604

If this message is printed, it indicates that Test 6 detected an error. The error number is 04. Refer to the Error Number Table in Appendix 4. It indicates that instruction SLHA or SRHA failed.

To isolate the problem further, the program can be run in single steps starting at the beginning of the test. The program may also be executed, starting at a location where the test for the failed instruction begins. Thus, Test 6 can be started after it has

tested for errors 1601 through 1603 and begins to test for error 1604. In this case, the symbolic location is T6F.

#### ERROR 19F2

This indicates that Test 9 detected an error. Error number F2 indicates that an illegal instruction interrupt was detected. To determine at what location this occurred, the program must be executed in single step mode starting at Test 9.

#### ERROR 1B0C

If the following messages is printed:

```
0000 0000 FFFF 0000 0000 0000 0000 1000 1000 7777 0000
```

it indicates that Test 11 detected an error. The error number is 0C. Refer to the Error Printout Description in Appendix 4. It states that error 1B0C refers to incorrect fixed point division. The printed values of the contents of some registers can be interpreted using the information given in the Error Printout Description as shown below:


0000 0000	FFFF	0000 0000	0000 0000	1000	1000
Dividend	Divisor	actual values	expected values	PSW	PSW
= 0	= -1	of remainder	of remainder	after	before
		and quotient	and quotient	division	division
7777		0000			
actual divide		expected divide			
fault interrupt		fault interrupt			
flag		flag			

The above interpretation of the printed information indicates: When 0 was divided by -1, the obtained values of the remainder and quotient were zero (which are identical to expected values), the PSW remained unchanged (PSW should not change), and a divide fault interrupt was taken (indicated by non-zero actual divide fault flag) when it was not expected (indicated by zero expected divide fault interrupt flag). So an error in divide fault interrupt logic has been detected.

For further diagnosis of the problem, the program can be run in single step starting from the instruction which sets the error number to X'C' (in this case DLOOP2+4).

#### 8. RESTART PROCEDURES

The starting address for PART 1 is X'100'. However, the program can be restarted without selecting the Processor number through the Console by starting the program at ENTRY2 (see listing). To restart the program without selecting the Processor number and the zero or one (for the memory size) through the console, start the program at ENTRY3 (see listing).




APPENDIX 1  
USER DEVICE DEFINITION

The halfword labeled IO (see listing) has the default value for Teletype as an Input/Output Console Device. If the console is different, it must be changed as follows:

		0	15
IO	CONSOLE DEVICE IDENT.		


Console Device Identifier	Explanation
X'0101'	CRT on PASLA/PALM Interface strapped for FDX at highest baud.
X'0202'	TTY, Carousel 15,30,35 on TTY Interface or GDT/CRT on Current Loop Interface.
X'0404'	Carousel 300 on PASLA/PALM Interface strapped for FDX at highest baud rate.

Location CONADR should be equal to the address of the Console Device except if connected through a PALM/PASLA Interface. In that case, location PASADR should equal the receive/send addresses.



APPENDIX 2  
CPU SELECTION


MODEL UNDER TEST	REQUIRED INPUT (CPU) PART 1
8/16E BASIC	8A
8/16E BASIC with Multiply/Divide	8B
8/16E BASIC Single Precision Floating Point	8C
8/16E BASIC Single/Double Pre- cision Floating Point	8D



### APPENDIX 3

The following table indicates the test number where each particular instruction is tested.

Test Number	Instruction
Test 1	LPSW,BTC,BFC,BTFS,BTBS,BFFS
Test 2	LH,CLHR,CLHI,LHI,CLH,LIS,LHR,LCS
Test 3	STH,LM,STM
Test 4	XHR,XHI,XH;OHR,OHI,OH;NHR,NHI,NH
Test 5	BAL,BXLE,BXH,BR,BTCR,BFCR,BALR
Test 6	EPSR,SLLS,SRLS,SLHL,SRHL,SLHA,SRHA,THI
Test 7	LB,STB,CLB,LBR,STBR,EXBR
Test 8	AH,AHR,AHI,AHM,AIS,ACH,ACHI,SH,SHR,SHI,SIS, SCH,SCHI
Test 9	Simulate interrupt and illegal instruction interrupt
Test 10	SLL,SRL,SLA,SRA,RLL,RRL
Test 11	MH,MHR,MHU,MHUR,DH,DHR
Test 12	SETMR,SETM,LPS,LPSR



APPENDIX 4  
ERROR MESSAGES

Test No.	Error No.	Type of Failure, Instructions Failed
1	1101 1102 1103 1104 1105	LPSW BTC, BFC (COND. CODE = 0000) BTC, BFC (COND. CODE = 1111) BFFS, BFBS (UNCONDITIONAL) BTFS, BFFS, BTBS, BFBS
2	1201	LH, CLHR, CLHI, LHI, CLH, LIS, LHR, LCS
3	1301 1302 1303	STH LM STM
4	1401 1402 1403	XHR, XHI, XH OHR, OHI, OH NHR, NHI, NH
5	1501 1502 1503	BAL BXLE, BXH BTCR, BFCR, BR
6	1601 1602 1603 1604 1605	ESPR SLLS, SRSL SLHL, SRHL SLHA, SRHA THI
7	1701	LB, STB, CLB, LBR, STBR, EXBR

For Test 8, after printing the error number, some of the pertinent register values are also printed as shown below:

AAAA (i)	BBBB (ii)	CCCC (iii)	DDDD	....Max. 10 halfwords printed
-------------	--------------	---------------	------	----------------------------------

The table below describes the meaning of different operand values.

For error numbers 1801, M and N are 2 arbitrary numbers whose values are between -2<sup>15</sup> and 2<sup>15</sup>-1. C is 1 if there is an input carry to the least significant bit.

## APPENDIX 4 (Continued)

If there is no carry, the value of C is 0.

TEST NUMBER	ERROR NUMBER	TYPE OF FAILURE	VALUES PRINTED TO AID IN DIAGNOSIS
8	1801	M+(-M) does not equal zero. AIS,AHM	(i) M (ii) -M (iii) M+(-M) (calculated value)
	1802	M+(R4)-(R4) does not equal M. AHR,SHR	(i) M (ii) M+(R4) (iii) M+(R4)-(R4) (calculated value)
	1803	M+X'789A'-X'789A' does not equal M. AHI, SHI	(i) M (ii) M+X'789A' (iii) M+X'789A'-X'789A' (calculated value)
	1804	(M+M+C)+(M-N-C) is not equal to 2*M. AH, SIS, ACH, SH	(i) M (ii) N (iii) C (iv) M+N+C (v) M-N-C (vi) Calculate value of (M=N=C)+(M-N-C) (vii) expected value of (M+N+C) + (M-N-C)
	1805	(M+N+C)=(M-N-C)-C is not equal to 2N+C	(i) M (ii) N (iii) C (iv) M+N+C (v) M-N-C (vi) calculated value of (M+N+C)-(M-N-C) (vii) expected value of (M+N+C)-(M-N-C)-C

Error numbers from 1806 through 181D refer to improper setting of the condition code as a result of addition or subtraction operation. The actual and expected values of condition codes are printed in each case.

## APPENDIX 4 (Continued)

TEST NUMBER	ERROR NUMBER	TYPE OF FAILURE, INSTRUCTIONS FAILED	VALUES PRINTED TO AID IN DIAGNOSIS
8	1806	0 + 0 did not set condition code correctly	(i) Actual Condition Code (ii) Expected condition Code
	1807	0 - 0 SHR	"
	1808	X'7FFE'-X'7FFE' SHI	"
	1809	X'FFFF'-X'FFFF' SH	"
	180A	X'8001'+X'7FFE' AH	"
	180B	X'8002'-X'0001' SIS	"
	180C	X'7FFE'+1 AIS	"
	180D	X'7FFF'-X'7FFE' SHI	"
	180E	X'FFFF'-X'FFFE' SH	"
	180F	X'7FFE'+X'7FFF' AH	"
	1810	X'8001'-X'7FFF' SHI	"
	1811	X'0001'+X'FFFF' AHR	"
	1812	X'7FFF'+X'8001' AHI	"
	1813	X'FFFF'+X'FFFE' AHR	"

APPENDIX 4 (Continued)

TEST NUMBER	ERROR NUMBER	TYPE OF FAILURE, INSTRUCTIONS FAILED	VALUES PRINTED TO AID IN DIAGNOSIS
8	1814	0 - 1 SIS	(i) Actual condition code  (ii) Expected condition code
	1815	X'FFFE'-X'FFFF' SHI	"
	1816	X'7FFE'-X'7FFF' SH	"
	1817	X'FFFF'+2 AIS	"
	1818	0-X'FFFF' SHI	"
	1819	X'7FFE'-X'FFFF' SH	"
	181A	X'8002'+X'7FFF'	"
	181B	X'7FFF'-X'FFFF' SH	"
	181C	2-X'8001' SHI	"
	181D	X'8001'+X'FFFF' AHI	"

APPENDIX 4 (Continued)

Error numbers 181E and 181F refer to incorrect operation of instruction ACH, ACHR, SCH, SCHR, when they are used for multi-precision addition and subtraction. Expected value is indicated below and the program prints the actual incorrect value (triple precision) in 3 halfwords:

TEST NUMBER	ERROR NUMBER	TYPE OF FAILURE AND EXPECTED VALUE
8	181E	2221 + 2*1111 + 3*1111 + ....+ FFFF*1111 does not equal 0888 7777 8000 ACH ACHR
	181F	0888 7777 8000 -1111 -2*1111 -3*1111.... -FFFF*1111 does not equal zero SCH, SCHR

APPENDIX 4 (Continued)

Errors 1820 through 1833 refer to incorrect condition codes set up after the fixed point compare operation. The actual condition code and the expected condition codes are printed as two halfwords.

TEST NUMBER	ERROR NUMBER	TYPE OF FAILURE, INSTRUCTIONS FAILED
8	1820 1821 1822 1823 1824 1825 1826 1827 1828 1829 182A 182B 182C 182D 182E 182F 1830 1831 1832 1833	0:0, CLHR 2:2, CLH X'7FFF':X'7FFF', CLHI X'8002':X'8001', CHR X'FFFE':X'FFFE', CH X'FFFF':X'FFFF', CHI X'8002':2, CLHR X'7FFF':X'7FFFF', CLH X'8002':X'8001', CLHI 2:0, CHR X'FFFF':X'FFFE', CH 0:X'8001', CHI X'8001':2, CLH X'FFFE'-X'FFFF', CLHR 0:1, CLHI 0:1, CHI X'8001':X'8002', CH X'FFFF':0, CHR X'7FFE':X'FFFF', CLH X'7FFF':X'FFFE', CLHI
9	1901 1902 1903 1904 1905 1906	External I/O Interrupt Detected. Incorrect Service Pointer used by SINT to generate interrupt. SINT used Immediate Interrupt Service when not specified by PSW. SINT generated no interrupt. PSW swap not OK after SINT. The illegal instruction at location ILLEGGL was executed and it did not generate an interrupt. When the illegal instruction interrupt is generated, the locations X'30' through X'34' were not set up correctly.
10	1A01 1A02 1A03 1A04	Zero shift set incorrect condition code SRL or SLL instruction failed SLA or SRA instruction failed RLL or RRL instruction failed

## APPENDIX 4 (Continued)

Test 11 prints twelve different error numbers (1B01 to 1B0D). The error numbers 1B01 to 1B0A refer to improper fixed point multiplication. If any of these errors are detected, the following information is printed:

ERROR NNNN  
AAAA BBBB A'A'A'A' B'B'B'B' RRRR RRRR R'R'R'R' R'R'R'R' PPPP P'P'P'P'

where

NNNN	Error Number
AAAA	First Operand
BBBB	Second Operand
A'A'A'A'	Negative of the first operand
B'B'B'B'	Negative of the second operand
RRRR RRRR	Double length actual result
R'R'R'R' R'R'R'R'	Double length expected result
PPPP	PSW after multiplication
P'P'P'P'	PSW before multiplication

The error numbers 1B0C and 1B0D refer to incorrect division. If any error in the fixed point divide operation is detected, the following is printed:

ERROR NN  
AAAA AAAA BBBB RRRR QQQQ R'R'R'R' Q'Q'Q'Q' PPPP P'P'P'P' FFFF F'F'F'F'

where

NNNN	Error Number
AAAA AAAA	First operand (double length dividend)
BBBB	Second operand (Divisor)
RRR	Actual remainder
QQQQ	Actual Quotient
R'R'R'R'	Expected remainder
Q'Q'Q'Q'	Expected quotient
PPPP	PSW after division
P'P'P'P'	PSW before division
FFFF	Actual divide fault flag (non-zero if divide fault interrupt was taken, zero otherwise).
F'F'F'F'	Expected Divide fault flag (non-zero if divide fault interrupt is expected, otherwise zero).

## APPENDIX 4 (Continued)

TEST NUMBER	ERROR NUMBER	TYPE OF FAILURE, INSTRUCTION FAILED
11	1B01	A*B does not equal the expected value, MH.
	1B02	B*A is not equal to the expected value of the product, MH.
	1B03	(-A)*(-B) is not equal to the expected product, MHR
	1B04	(-B)*(-A) is not equal to the expected value, MHR.
	1B05	A*(-B) does not equal the expected result, MHR.
	1B06	(-B)*A does not equal the expected result, MH.
	1B07	B*(-A) is not equal to the expected value of the product, MHR.
	1B08	(-A)*(B) is not equal to the expected value of the product.
	1B09	Unsigned product of A and B does not equal the expected value, MHU.
	1B0A	Unsigned product of B and A is not equal to the expected value of the unsigned product, MHUR.
	1B0C	A/B did not produce the expected values of the remainder and the quotient, DHR.
	1B0D	A/B did not produce the expected remainder and quotient values.
12	1C01	First operand not correct (RR format), SETMR
	1C02	PSW is incorrect (RX format), SETM
	1C03	First operand not correct (RR format), SETMR
	1C04	PSW is incorrect (RX format), SETM
	1C05	First operand not correct (RR format), SETMR

APPENDIX 4 (Continued)

TEST NUMBER	ERROR NUMBER	TYPE OF FAILURE, INSTRUCTION FAILED
	1C06	PSW is incorrect (RX format), SETM
	1C07	First operand not correct (RR format), SETMR
	1C08	PSW is incorrect (RX format), SETM
	1C09	R <sub>2</sub> field was destroyed during execution of a SET MAP instruction
	1C0A	LPS instruction failed to load correct PSW
	1C0B	LPSR instruction failed to load correct PSW
	1C0C	R <sub>1</sub> field was destroyed after LPS instruction
	1C0D	R <sub>1</sub> field was destroyed after LPSR instruction

## APPENDIX 4 (Continued)

### Other Errors

Error No.	Type of Failure
1NF1	Floating Point Arithmetic Fault Interrupt is detected.
1NF2	Illegal Instruction Interrupt is detected.
1NF3	Machine Malfunction Interrupt is detected.
1NF4	External Interrupt is detected.
1NF5	Fixed Point Divide Fault Interrupt is detected.
1NF6	Channel I/O Termination Interrupt is detected.
1NF7	Termination Queue Overflow Interrupt is detected.
1NF8	SVC is performed from an incorrect location (one of X'9C' through X'13A')
1NF9	Incorrect Service Pointer used (one of X'D0' through X'2CE')

### NOTE

N - test number from 1 through X'C'.

PROG= PT211 ASSEMBLED BY CAL 03-066R05-00 (32-BIT)

```

1      CROSS
2      WIDTH 120
3      TARGT 16
4      PT211  PROG MODEL 8/16E PROCESSOR TEST PART 1 06-211M96R00A13
5      *
6      *      COPYRIGHT INTERDATA, INC (MAY 77)
7      *
8      *
9      *      THIS PROGRAM IS DESIGNED TO TEST MODEL 8/16E PROCESSORS
10     *
11     *
12     *
13     *
0000 0000    14 R0    EQU 0
0000 0001    15 R1    EQU 1
0000 0002    16 R2    EQU 2
0000 0003    17 R3    EQU 3
0000 0004    18 R4    EQU 4
0000 0005    19 R5    EQU 5
0000 0006    20 R6    EQU 6
0000 0007    21 R7    EQU 7
0000 0008    22 R8    EQU 8
0000 0009    23 R9    EQU 9
0000 000A    24 R10   EQU 10
0000 000B    25 R11   EQU 11
0000 000C    26 R12   EQU 12
0000 000D    27 R13   EQU 13
0000 000E    28 R14   EQU 14
0000 000F    29 R15   EQU 15
0000 5302    30 SETM   EQU X'5302'
0000 1308    31 SETMR  EQU X'1308'
0000 7302    32 LPS    EQU X'7302'
0000 3308    33 LPSR   EQU X'3308'
34     *
0000R      35 ORG    X'80'
36     *
0080 2421    37 LIS    R2,1
0082 2303    38 BS     BOOT
0084 0110    39 DC     Z(PSWAVE)
0086 2344    40 DC     Z(REGSAV)
0088 4020 0022 41 BOOT   STH   R2,X'22'
008C C810 0100 42 LHI   R1,X'100'
0090 C830 2344 43 LHI   R3,LNZB
0094 C860 0000 44 MN    LHI   R6,0
0098 D340 0078 45 LB    R4,X'78'
009C DE40 0079 46 OC    R4,X'79'
00A0 9D45    47 LEADER SSR   R4,R5
00A2 2091    48 BTBS  9,1
00A4 9B45    49 RDR   R4,R5
00A6 0855    50 LOAR  R5,R5
00A8 2254    51 BZS   LEADER
00AA D251 0000 52 LOAD  STB   R5,0(R1)
00AE D351 0000 53 LB    R5,0(R1)

```

PT100010  
PT100020  
PT100030  
PT100040  
PT100050  
P PT100060  
PT100070  
PT100080  
PT100090  
PT100100  
PT100110  
PT100120  
PT100130  
PT100140  
PT100150  
PT100160  
PT100170  
PT100180  
PT100190  
PT100200  
PT100210  
PT100220  
PT100230  
PT100240  
PT100250  
PT100260  
PT100270  
PT100280  
PT100290  
PT1U0300  
PT100310  
PT100320  
PT100330  
PT100340  
PT100350  
PT100360  
PT100370  
PT100380  
PT100390  
PT100400  
PT100410  
PT100420  
PT100430  
PT100440  
PT100450  
PT100460  
PT100470  
PT100480  
PT100490  
PT100500  
PT100510  
PT100520  
PT100530

0082	0765	54	XAR	R6,R5	PT100540	
0084	9481	55	EXBR	R8,R1	PT100550	
0086	9828	56	WHR	R2,R8	PT100560	
0088	9045	57	SSR	R4,R5	PT100570	
008A	2091	58	BTBS	9,1	PT100580	
008C	9B45	59	RDR	R4,R5	PT100590	
008E	C110 00AA	60	BXLE	R1,LOAD	PT100600	
00C2	9496	61	EXBR	R8,R6	PT100610	
00C4	9828	62	WHR	R2,R8	PT100620	
00C6	2478	63	LDWT	LIS R7,8	PT100630	
00C8	917C	64		SLLS R7,12	PT100640	
00CA	9557	65		EPSR R5,R7	PT100650	
00CC	2203	66		BS LDWT	PT100660	
00CE		67		ORG X'100'	PT100670	
0100	4300 0112	68	ORIGIN1 B	ENTRY1	PT100680	
*****						PT100690
0104	0202	70	IO DCX	0202 IO INDICATOR	PT100700	
0106	0101	71	CRT DCX	0101 CRT VALUE	PT100710	
0108	0404	72	CAR DCX	0404 CAROUSEL VALUE	PT100720	
010A	0202	73	CONADR DCX	0202 CONSOLE ADDRESS	PT100730	
010C	1011	74	PASADR DCX	1011 PASLA ADDRESS REC/SND DEFAULT 1011	PT100740	
010E	000A	75	NTIMES DC	10	PT100750	
0110	0000	76	PSWAVE DC	0	PT100760	
		77	*		PT100770	
		78	*		PT100780	
		79	*	SET UP FOR SPURIOUS INTERRUPTS	PT100790	
		80	*		PT100800	
0112	C800 0000	81	ENTRY1 LHI	R0,0	PT100810	
0116	4000 002C	82	M5001 STH	R0,X'2C'	PT100820	
011A	4000 0034	83	STH	R0,X'34'	PT100830	
011E	4000 003C	84	STH	R0,X'3C'	PT100840	
0122	4000 0044	85	STH	R0,X'44'	PT100850	
0126	4000 004C	86	STH	R0,X'4C'	PT100860	
012A	4000 0086	87	STH	R0,X'86'	PT100870	
012E	4000 0090	88	M5002 STH	R0,X'90'	PT100880	
		89	*		PT100890	
0132	C800 2346	90	LHI	R0,LNZB+2	PT100900	
0136	4000 0022	91	STH	R0,X'22'	PT100910	
013A	C800 212E	92	LHI	R0,FLPTNT	PT100920	
013E	4000 002E	93	STH	R0,X'2E'	PT100930	
0142	C800 2132	94	LHI	R0,ILGINT	PT100940	
0146	4000 0036	95	STH	R0,X'36'	PT100950	
014A	C800 2136	96	LHI	R0,MALFTN	PT100960	
014E	4000 003E	97	STH	R0,X'3E'	PT100970	
0152	C800 213A	98	LHI	R0,EXTINT	PT100980	
0156	4000 0046	99	STH	R0,X'46'	PT100990	
015A	C800 2140	100	LHI	R0,DVDFLT	PT101000	
015E	4000 004E	101	STH	R0,X'4E'	PT101010	
0162	C800 22CC	102	LHI	R0,TABLE	PT101020	
0166	4000 0080	103	STH	R0,X'80'	PT101030	
016A	C800 2144	104	LHI	R0,CHANIO	PT101040	
016E	4000 0088	105	STH	R0,X'88'	PT101050	
0172	C800 2148	106	LHI	R0,QVRFL0	PT101060	
0176	4000 0092	107	STH	R0,X'92'	PT101070	
		108	*		PT101080	

		109 * SET UP INPUT OUTPUT DEVICES	PT101090	
		110 *	PT101100	
017A	C800 F800	111 LHI R0,X'F800'	PT101110	
017E	4000 22F0	112 STH R0,FIRSTCMD	PT101120	
0182	D300 0104	113 IOTEST LB R0,IO	PT101130	
0186	C500 0004	114 CLHI R0,4	PT101140	
018A	4230 0196	115 BNE CRTIO	PT101150	
018E	C800 F000	116 LHI R0,X'F000'	PT101160	
0192	4000 22F0	117 STH R0,FIRSTCMD	PT101170	
0196	D300 0104	118 CRTIO LB R0,IO	PT101180	
019A	C500 0002	119 CLHI R0,2	PT101190	
019E	4330 01C0	120 BE TTYIO	PT101200	
01A2	D310 22E8	121 LB R1,CRTOUT+1	PT101210	
01A6	D210 22E7	122 STB R1,INCMND	PT101220	
01AA	D310 0100	123 LB R1,PASADR+1	PT101230	
01AE	D320 22EA	124 LB R2,CRTOUT	PT101240	
01B2	DE10 22F0	125 OC R1,FIRSTCMD	PT101250	
01B6	2531	126 LCS R3,1	PT101260	
01B8	4030 22EE	127 STH R3,CRTFLG	PT101270	
01BC	4300 01D8	128 B I02	PT101280	
	0000 01C0	129 TTYIO EQU *	PT101290	
01C0	C810 00A4	130 LHI R1,X'A4'	PT101300	
01C4	D210 22E7	131 STB R1,INCMND	PT101310	
01C8	C810 0000	132 LHI R1,0	PT101320	
01CC	4010 22EE	133 STH R1,CRTFLG	PT101330	
01D0	D310 010A	134 LB R1,CONADR	PT101340	
01D4	D320 22EC	135 LB R2,CONOUT	PT101350	
	0000 01D8	136 I02 EQU *	PT101360	
01D8	D210 22E6	137 STB R1,OUTDEV	PT101370	
01DC	D220 22E8	138 STB R2,OUTCMD	PT101380	
01E0	D320 22E6	139 LB R2,OUTDEV	PT101390	
01E4	DE20 22E8	140 OC R2,OUTCMD	PT101400	
01E8	9D23	141 SSR R2,R3	PT101410	
01EA	4210 02AA	142 BTC 1,ENTRY2	PT101420	
01EE	C430 00FC	143 NHI R3,X'FC'	PT101430	
01F2	C530 000C	144 CLHI R3,X'0C'	PT101440	
01F6	4330 02AA	145 BE ENTRY2	PT101450	
01FA	9D23	146 PRTTLE SSR R2,R3	PT101460	
01FC	4240 02AA	147 BTC 4,ENTRY2	PT101470	
0200	4280 01FA	148 BTC 8,PRTTLE	PT101480	
0204	4840 22E2	149 LH R4,CPUFLAG	PT101490	
0208	C540 0001	150 CLHI R4,X'1'	PT101500	
020C	4330 0216	151 BE PRTCPU1	PT101510	
0210	C840 2306	152 LHI R4,TITLE1	PT101520	
0214	2303	153 BS PRTCPU	PT101530	
0216	C840 2334	154 PRTCPU1 LHI R4,TITLE2	PT101540	
021A	D304 0000	155 PRTCPU LB R0,0(R4)	PRINT CPU *	PT101550
021E	41E0 211A	156 BAL R14,WRITE1	PT101560	
0222	2641	157 AIS R4,1	PT101570	
0224	C540 2344	158 CLHI R4,TITEND	PT101580	
0228	2037	159 BNES PRTCPU	PT101590	
022A	2441	160 LIS R4,1	PT101600	
022C	4040 22E2	161 STH R4,CPUFLAG	PT101610	
	0000 0230	162 PRTCP EQU *	PT101620	
0230	4800 22EE	163 LH R0,CRTFLG	PT101630	

0234	2339	164	BZS	RD	PT101640
0236	D320 010C	165	LB	R2,PASADR	PT101650
023A	DE20 22E7	166	OC	R2,INCMND	PT101660
023E	9023	167	SSR	R2,R3	PT101670
0240	2281	168	BFBS	8,1	PT101680
0242	4300 024A	169	B	RDCPU1	PT101690
	0000 0246	170	RD	EQU *	PT101700
0246	DE20 22E7	171	OC	R2,INCMND	PT101710
024A	9023	172	RDCPU1	SSR R2,R3	PT101720
024C	2081	173	BTBS	8,1	PT101730
024E	9B20	174	RDR	R2,R0	PT101740
0250	C400 007F	175	NHI	R0,X'7F'	PT101750
0254	9D23	176	RDCPU2	SSR R2,R3	PT101760
0256	4280 0254	177	BTC	8,RDCPU2	PT101770
025A	9B21	178	RDR	R2,R1	PT101780
025C	C410 007F	179	NHI	R1,X'7F'	PT101790
0260	9108	180	SLLS	R0,8	PT101800
0262	0601	181	OHR	R0,R1	PT101810
0264	C500 3841	182	CLHI	R0,C'8A'	PT101820
0268	4330 0296	183	BE	MOD5	PT101830
026C	C500 3842	184	CLHI	R0,C'8B'	PT101840
0270	4330 0296	185	BE	MOD5	PT101850
0274	C500 3843	186	CLHI	R0,C'8C'	PT101860
0278	4330 0296	187	BE	MOD5	PT101870
027C	C500 3844	188	CLHI	R0,C'8D'	PT101880
0280	4330 0296	189	BE	MOD5	PT101890
0284	C800 003F	190	CPUERR	LHI R0,C'7'	PT101900
0288	41E0 211A	191	BAL	R14,WRITE1	PT101910
028C	0744	192	XHR	R4,R4	PT101920
028E	4040 22E2	193	STH	R4,CPUFLAG	PT101930
0292	4300 01FA	194	B	PRITLE	PT101940
0296	4000 22E0	195	MOD5	STH R0,CPUNO	PT101950
029A	C800 000D	196	MOD	LHI R0,X'D'	PT101960
029E	41E0 211A	197	BAL	R14,WRITE1	PT101970
02A2	C800 000A	198	LHI	R0,X'A'	PT101980
02A6	41E0 211A	199	BAL	R14,WRITE1	PT101990
	0000 02AA	200	*		PT102000
02AA	07EE	201	ENTRY2	EQU *	PT102010
02AC	C840 1F40	202	WMEM	XHR R14,R14	PT102020
02B0	C850 1F55	203		LHI R4,MESMEM1	PT102030
02B4	D320 22E6	204		LHI R5,MESMEM2	PT102040
02B8	DE20 22E8	205		LB R2,OUTDEV	PT102050
02BC	9023	206		OC R2,OUTCMD	PT102060
02BE	2081	207		SSR R2,R3	PT102070
02C0	9624	208		BTBS 8,1	PT102080
02C2	4800 22EE	209		WBR R2,R4	PT102090
02C6	2308	210		LH R0,CRTFLG	PT102100
02C8	D320 010C	211		BZS WMEM1	PT102110
02CC	DE20 22E7	212		LB R2,PASADR	PT102120
02D0	9023	213		OC R2,INCMND	PT102130
02D2	2281	214		SSR R2,R3	PT102140
02D4	2303	215		BFBS 8,1	PT102150
02D6	DE20 22E7	216		BS WMEM2	PT102160
02DA	9023	217	WMEM1	OC R2,INCMND	PT102170
		218	WMEM2	SSR R2,R3	PT102180

MESSAGE ROUTINE FOR TEST 12 ONLY  
BEGINNING ADDRESS OF MESSAGE  
ENDING ADDRESS OF MESSAGE

WRITE COMMAND

WRITE MESSAGE

02DC	2081	219	BTBS	8,1		PT102190	
02DE	9B2E	220	RDR	R2,R14	READ IN 0 OR 1	PT102200	
02E0	C4E0 007F	221	NHI	R14,X'7F'		PT102210	
02E4	C5E0 0030	222	CLHI	R14,X'30'		PT102220	
02E8	2335	223	BES	WMEM3		PT102230	
02EA	C5E0 0031	224	CLHI	R14,X'31'		PT102240	
02EE	4230 02AA	225	BNE	WMEM		PT102250	
02F2	C4E0 000F	226	WMEM3	NHI R14,X'F'		PT102260	
02F6	40E0 1F56	227	STH	R14, MEMST0	STORE FLAG IN STORAGE AREA	PT102270	
		228 *				PT102280	
	0000 02FA	229	ENTRY4	EQU *		PT102290	
02FA	C800 0000	230	LHI	R0,0		PT102300	
02FE	4000 22DE	231	STH	R0,TTYOFF		PT102310	
0302	4000 22DA	232	STH	R0,TOTAL		PT102320	
0306	4000 22DC	233	STH	R0,TOTERR		PT102330	
	0000 030A	234	ENTRY3	EQU *		PT102340	
030A	C800 0001	235	LHI	R0,X'1'		PT102350	
030E	DE00 22E5	236	OC	R0,NORM		PT102360	
	0000 0312	237	ENT3A	EQU *		PT102370	
0312	D320 22E6	238	LB	R2,OUTDEV		PT102380	
0316	9D25	239	SSR	R2,R5		PT102390	
0318	4210 032C	240	BTC	1,ENT3B		PT102400	
031C	C450 00FC	241	NHI	R5,X'FC'		PT102410	
0320	C550 000C	242	CLHI	R5,X'0C'		PT102420	
0324	4330 032C	243	BE	ENT3B		PT102430	
0328	4300 0334	244	B	TEST1		PT102440	
	0000 032C	245	ENT3B	EQU *		PT102450	
032C	C850 0001	246	LHI	R5,X'1'		PT102460	
0330	4050 22DE	247	STH	R5,TTYOFF		PT102470	
		248	*****				PT102480
		249	*				PT102490
		250	*	TEST1 CHECKS THE INSTRUCTIONS			PT102500
		251	*				PT102510
		252	*	LPSW, BTC,BFC,BTFS,BTBS,BFFS			PT102520
		253	*				PT102530
0334	C800 0508	254	TEST1	LHI	R0,TEST2		PT102540
0338	4000 22F4	255	STH	R0,NXTST		PT102550	
033C	C800 3131	256	LHI	R0,C'11'		PT102560	
0340	4000 22B8	257	STH	R0,TESTNO		PT102570	
0344	C800 0111	258	LHI	R0,X'0111'		PT102580	
0348	4000 22F2	259	STH	R0,ERRIND		PT102590	
	0000 034C	260	LPSW	EQU *		PT102600	
034C	C200 0350	261	LPSW	T1		PT102610	
0350	0000	262	T1	DC 0,T1A		PT102620	
0352	0358						
0354	4300 2182	263	T1AA	B ERROR		PT102630	
0358	4300 0364	264	T1A	B T1B		PT102640	
035C	4300 036C	265	T1A2	B T1C		PT102650	
0360	4300 2182	266	T1ERR1	B ERROR		PT102660	
0364	4300 035C	267	T1B	B T1A2		PT102670	
0368	4300 2182	268	B	ERROR		PT102680	
	0000 036C	269	BTC	EQU *		PT102690	
036C	4210 0380	270	T1C	BTC 1,T1ERR2	COND. CODE = 0000 , SO	PT102700	
0370	4220 0380	271	BTC	2,T1ERR2	ERR. IF BRANCH ON TRUE	PT102710	
0374	4240 0380	272	BTC	4,T1ERR2		PT102720	

0378	4280 0380	273	BTC	8,T1ERR2		PT102730
	0000 037C	274	BFC	EQU *		PT102740
037C	4310 038C	275	BFC	1,T1D1	COND. CODE = 0000	PT102750
0380	C800 0211	276	T1ERR2	LHI R0,X'0211'	ERROR 1102	PT102760
0384	4000 22F2	277	STH	R0,ERRIND		PT102770
0388	4300 2182	278	B	ERROR		PT102780
038C	4320 0394	279	T1D1	BFC 2,T1D2		PT102790
0390	4300 0380	280	B	T1ERR2		PT102A00
0394	4340 039C	281	T1D2	BFC 4,T1D3		PT102A10
0398	4300 0380	282	B	T1ERR2		PT102A20
039C	4300 03A4	283	T1D3	BFC 8,T1D4		PT102A30
03A0	4300 0380	284	B	T1ERR2		PT102A40
03A4	C200 03A8	285	T1D4	LPSW T1D8		PT102A50
03A8	000F	286	T1D8	DC 15,T1D9		PT102A60
03AA	03AC					
03AC	4310 03D8	287	T1D9	BFC 1,T1ERR3	COND CODE = 1111 , SO	PT102A70
0380	4320 03D8	288	BFC	2,T1ERR3	ERR. IF BRANCH ON ZERO	PT102A80
0384	4340 03D8	289	BFC	4,T1ERR3		PT102A90
0388	4380 03D8	290	BFC	8,T1ERR3		PT102900
03BC	4210 03C4	291	BTC	1,T1E1	COND. CODE = 1111 , SO	PT102910
03C0	4300 03D8	292	B	T1ERR3	ERR. IF BRANCH NOT TAKEN	PT102920
03C4	4220 03CC	293	T1E1	BTC 2,T1E2		PT102930
03C8	4300 03D8	294	B	T1ERR3		PT102940
03CC	4240 03D4	295	T1E2	BTC 4,T1E3		PT102950
03D0	4300 03D8	296	B	T1ERR3		PT102960
03D4	4280 03E4	297	T1E3	BTC 8,T1E4		PT102970
03D8	C800 0311	298	T1ERR3	LHI R0,X'0311'	ERROR 1103	PT102980
03DC	4000 22F2	299	STH	R0,ERRIND		PT102990
03E0	4300 2182	300	B	ERROR		PT103000
	0000 03E4	301	BFFS	EQU *		PT103010
03E4	2301	302	T1E4	BFFS 0,1	BS +1	PT103020
03E6	2302	303	BFFS	0,2	BS+2	PT103030
03E8	2302	304	BFFS	0,2		PT103040
03EA	2303	305	BFFS	0,3		PT103050
03EC	4300 0486	306	B	T1ERR4		PT103060
03F0	2303	307	BFFS	0,3	BS+3	PT103070
03F2	4300 0486	308	B	T1ERR4		PT103080
03F6	2307	309	BFFS	0,7	BS+7 1	PT103090
03F8	4300 0486	310	B	T1ERR4		PT103100
03FC	2306	311	BFFS	0,6	BS+6 3	PT103110
03FE	4300 0486	312	B	T1ERR4		PT103120
0402	2306	313	BFFS	0,6	BS+6	PT103130
0404	2204	314	BFBs	0,4	BS-4 2	PT103140
0406	2302	315	BFFS	0,2	BS+2	PT103150
0408	2203	316	BFBs	0,3	BS-3 4	PT103160
040A	4300 0486	317	B	T1ERR4		PT103170
	318 *					PT103180
040E	230F	319	T1F	BFFS 0,15	BS+15 1	PT103190
0410	2302	320	BFFS	0,2		PT103200
0412	2303	321	BFFS	0,3	BS+3	PT103210
0414	2302	322	BFFS	0,2		PT103220
0416	230E	323	BFFS	0,14	BS+14 3	PT103230
0418	2302	324	BFFS	0,2		PT103240
041A	230D	325	BFFS	0,13	BS+13 5	PT103250
041C	2302	326	BFFS	0,2		PT103260

## MODEL 8/16E PROCESSOR TEST PART 1 06-211M96R00A13

PAGE 7 09:54:45 11/04/78

041E	230C	327	BFFS	0.12	BS+12	7	PT103270	
0420	2302	328	BFFS	0.2			PT103280	
0422	230B	329	BFFS	0.11	BS+11	9	PT103290	
0424	2302	330	BFFS	0.2			PT103300	
0426	230A	331	BFFS	0.10	BS+10	11	PT103310	
0428	2303	332	BFFS	0.3			PT103320	
042A	2309	333	BFFS	0.9	BS+9	13 TO T1F2	PT103330	
042C	220B	334	BFBS	0.11	BS-11	2	PT103340	
042E	4300 0486	335	B	T1ERR4			PT103350	
0432	220C	336	BFBS	0.12	BS-12	4	PT103360	
0434	22U8	337	BFBS	0.11	BS-11	6	PT103370	
0436	22U4	338	BFBS	0.10	BS-10	8	PT103380	
0438	22U9	339	BFBS	0.9	BS-9	10	PT103390	
043A	22U8	340	BFBS	0.8	BS-8	12	PT103400	
		341 *					PT103410	
043C	2308	342	T1F2	BFFS	0.8	BS+8	1	PT103420
043E	2302	343	BFFS	0.2			PT103430	
0440	2307	344	BFFS	0.7	BS+7	3	PT103440	
0442	2302	345	BFFS	0.2			PT103450	
0444	2306	346	BFFS	0.6	BS+6	5	PT103460	
0446	23U2	347	BFFS	0.2			PT103470	
0448	2305	348	BFFS	0.5	BS+5	7	PT103480	
044A	2306	349	BFFS	0.6			PT103490	
044C	2206	350	BFBS	0.6	BS-6	2	PT103500	
044E	2205	351	BFBS	0.5	BS-5	4	PT103510	
0450	2204	352	BFBS	0.4	BS-4	6	PT103520	
0452	2304	353	BFFS	0.4	BS+4	8	PT103530	
0454	2301	354	BFFS	0.1	BS+1		PT103540	
0456	4300 0486	355	B	T1ERR4			PT103550	
		356 *					PT103560	
045A	230F	357	BS	T1F3			PT103570	
045C	2302	358	BFFS	0.2			PT103580	
045E	2307	359	BFFS	0.7	9	BS+7	PT103590	
0460	2302	360	BFFS	0.2			PT103600	
0462	230F	361	BFFS	0.15	6	BS+15	PT103610	
0464	2302	362	BFBS	0.2			PT103620	
0466	2204	363	BFBS	0.4	8	BS-4	PT103630	
0468	2304	364	BFFS	0.4			PT103640	
046A	230D	365	BFFS	0.13			PT103650	
046C	230C	366	BS	T1F4			PT103660	
046E	2308	367	BFFS	0.8	4	BS+8	PT103670	
0470	2302	368	BFFS	0.2			PT103680	
0472	22U2	369	BFBS	0.2	3	BS-3	PT103690	
0474	2303	370	BFFS	0.3			PT103700	
0476	2202	371	BFBS	0.2	2	BS-2	PT103710	
0478	2201	372	T1F3	BFBS	0.1	1	BS-1	
047A	2306	373	BS	T1ERR4			PT103730	
047C	2305	374	BS	T1ERR4			PT103740	
047E	220E	375	BFBS	0.14	5	BS-14	PT103750	
0480	220D	376	BFBS	0.13	7	BS-13	PT103760	
0482	23U2	377	BS	T1ERR4			PT103770	
0484	2309	378	T1F4	BS	T1G2		PT103780	
0486	C800 0411	379	T1ERR4	LHI	R0,X'0411'	ERROR 1104	PT103790	
048A	4000 22F2	380	STH	R0,ERRIND			PT103800	
048E	4300 2182	381	B	ERROR			PT103810	

		382 *			PT103820
		383 *	COND CODE = 1111		PT103830
		384 *			PT103840
	0000 0492	385 BTFS	EQU *		PT103850
0492	2144	386 T1G	BTFS 3,4	3	PT103860
0494	2302	387	BFFS 0,2		PT103870
0496	2154	388 T1G2	BTFS 5,4	1	PT103880
0498	2302	389	BFFS 0,2		PT103890
049A	218A	390	BTFS 8,10	4	PT103900
049C	2302	391	BFFS 0,2		PT103910
	0000 049E	392 BTBS	EQU *		PT103920
049E	2056	393	BTBS 5,6	2	PT103930
04A0	2302	394	BFFS 0,2		PT103940
04A2	2144	395	BTFS 7,4	6	PT103950
04A4	2302	396	BFFS 0,2		PT103960
04A6	2117	397	BTFS 1,7	8	PT103970
04A8	2302	398	BFFS 0,2		PT103980
04AA	2092	399	BTBS 9,2	7	PT103990
04AC	2302	400	BFFS 0,2		PT104000
04AE	2046	401	BTBS 4,6	5	PT104010
04B0	4300 04F8	402	B T1ERR5		PT104020
04B4	2315	403	BFFS 1,5		PT104030
04B6	2344	404	BFFS 4,4		PT104040
04B8	2393	405	BFFS 9,3		PT104050
04BA	2372	406	BFFS 7,2		PT104060
04BC	2303	407	BFFS 0,3		PT104070
04BE	4300 04F8	408	B T1ERR5		PT104080
		409 *			PT104090
04C2	C200 04C6	410	LPSW T1H		PT104100
04C6	0000	411	T1H DC 0,T1H1		PT104110
04C8	04D0				
04CA	2304	412	BS T1H1+2		PT104120
04CC	2344	413	BFFS 3,4	3	PT104130
04CE	2302	414	BFFS 0,2		PT104140
04D0	2354	415	T1H1 BFFS 5,4	1	PT104150
04D2	2302	416	BFFS 0,2		PT104160
04D4	238A	417	BFFS 8,10	4	PT104170
04D6	2302	418	BFFS 0,2		PT104180
04D8	2256	419	BFBS 5,6	2	PT104190
04DA	2302	420	BFFS 0,2		PT104200
04DC	2374	421	BFFS 7,4	6	PT104210
04DE	2302	422	BFFS 0,2		PT104220
04E0	2317	423	BFFS 1,7	8	PT104230
04E2	2302	424	BFFS 0,2		PT104240
04E4	2292	425	BFBS 9,2	7	PT104250
04E6	2302	426	BFFS 0,2		PT104260
04E8	2246	427	BFBS 4,6	5	PT104270
04EA	4300 04F8	428	B T1ERR5		PT104280
		429 *			PT104290
04EE	2115	430	BTFS 1,5		PT104300
04F0	2144	431	BTFS 4,4		PT104310
04F2	2193	432	BTFS 9,3		PT104320
04F4	2172	433	BTFS 7,2		PT104330
04F6	2307	434	BFFS 0,7		PT104340
04F8	C800 0511	435	T1ERR5 LHI R0,X'0511'	ERROR 1105	PT104350

04FC	4000 22F2	436	STH R0,ERRIND	PT104360	
0500	4300 2182	437	B ERROR	PT104370	
0504	4300 0508	438	T1END B TEST2	PT104380	
		439	*****	PT104390	
		440	*	PT104400	
		441	* TEST 2 CHECKS THE INSTRUCTIONS	PT104410	
		442	*	PT104420	
		443	* LH, CLHR, CLHI, LHI, CLH, LIS, LHR, LCS	PT104430	
		444	*	PT104440	
		445	* MEMORY LOCATIONS USED ARE	PT104450	
		446	*	PT104460	
		447	* ZERO 0	PT104470	
		448	* ONE X'FFFF'	PT104480	
		449	* FIVE X'5555'	PT104490	
		450	* TEN X'AAAA'	PT104500	
		451	*	PT104510	
	0508	C800 0622	452	TEST2 LHI R0,TEST3	PT104520
	050C	4000 22F4	453	STH R0,NXTST	PT104530
	0510	C800 0112	454	LHI R0,X'0112'	PT104540
	0514	4000 22F2	455	STH R0,ERRIND	PT104550
	0518	C800 3132	456	LHI R0,X'3132'	PT104560
	051C	4000 22B8	457	STH R0,TESTNO	PT104570
	0520	C200 0524	458	LPSW T2	PT104580
	0524	7C00	459	T2 DC X'7C00',T2A	PT104590
	0526	0528	460	*	PT104600
	0528	2400	461	T2A LIS R0,0	PT104610
	052A	213C	462	BNZS T2R1	PT104620
		0000 052C	463	LHR EQU *	PT104630
	052C	0810	464	LHR R1,R0	PT104640
	052E	213A	465	BNZS T2R1	PT104650
	0530	0821	466	LHR R2,R1	PT104660
	0532	0832	467	LHR R3,R2	PT104670
	0534	0843	468	LHR R4,R3	PT104680
	0536	0504	469	CLHR R0,R4	PT104690
	0538	2135	470	BNES T2R1	PT104700
	053A	0853	471	LHR R5,R3	PT104710
	053C	0865	472	LHR R6,R5	PT104720
	053E	0536	473	CLHR R3,R6	PT104730
	0540	2332	474	BES T2B	PT104740
	0542	230E	475	T2R1 BS T2R2	PT104750
		0000 0544	476	LH EQU *	PT104760
	0544	4870 22F6	477	T2B LH R7,ZERO	PT104770
	0548	C570 0000	478	CLHI R7,0	PT104780
	054C	2139	479	BNES T2R2	PT104790
	054E	4530 22F6	480	CLH R3,ZERO	PT104800
	0552	2136	481	BNES T2R2	PT104810
	0554	48A0 2302	482	LH R10,TEN	PT104820
	0558	C5A0 AAAA	483	CLHI R10,X'AAAA'	PT104830
	055C	2332	484	BES T2C	PT104840
	055E	230D	485	T2R2 BS T2R3	PT104850
	0560	C5A0 AAA9	486	T2C CLHI R10,X'AAA9'	PT104860
	0564	218A	487	BLS T2R3	PT104870
	0566	2339	488	BES T2R3	PT104880
	0568	45A0 22FA	489	CLH R10,ONE	PT104890

056C	2386	490	BNLS	T2R3	PT104900
056E	2385	491	BNCS	T2R3	PT104910
0570	4850 22FE	492	LH	R5,FIVE	PT104920
	0000 0574	493	CLHR	EQU *	PT104930
0574	055A	494	CLHR	R5,R10	PT104940
0576	2182	495	BLS	T2D	PT104950
0578	2300	496	T2R3	BS	PT104960
057A	0553	497	T2D	CLHR	PT104970
057C	2188	498		R5,R3	PT104980
057E	233A	499	BLS	T2R4	PT104990
0580	C8F0 5555	500	BES	T2R4	PT105000
0584	055F	501	LHI	R15,X'5555'	PT105010
0586	2136	502	CLHR	R5,R15	PT105020
0588	0505	503	BNES	T2R4	PT105030
058A	2384	504	CLHR	R0,R5	PT105040
	0000 058C	505	BNLS	T2R4	
058C	4550 22FE	506	CLH	EQU *	PT105050
0590	2332	507	CLH	R5,FIVE	PT105060
0592	230E	508	BES	T2E	PT105070
0594	4540 22F6	509	T2R4	BS	PT105080
0598	2138	510	T2E	CLH	PT105090
059A	45A0 22FE	511		R4,ZERO	PT105100
059E	2188	512	BNES	T2R5	PT105110
05A0	2337	513	BES	T2R5	PT105120
05A2	C5A0 AAAB	514	CLHI	R10,X'AAAB'	PT105130
05A6	2384	515	BNLS	T2R5	PT105140
	0000 05A8	516	CLHI	EQU *	PT105150
05A8	C540 0003	517	CLHI	R4,3	PT105160
05AC	2183	518	BLS	T2F	PT105170
05AE	4300 2182	519	T2R5	B	PT105180
05B2	48F0 22FA	520	T2F	ERROR	PT105190
05B6	C5F0 FFFF	521	LH	R15,ONE	PT105200
05BA	213B	522	CLHI	R15,X'FFFF'	PT105210
05BC	48A0 22FE	523	BNES	T2R6	PT105220
05C0	05A5	524	LH	R10,FIVE	PT105230
05C2	2137	525	CLHR	R10,R5	PT105240
05C4	4850 2302	526	BNES	T2R6	PT105250
	0000 05C8	527	LH	R5,TEN	PT105260
05C8	C8A0 AAAA	528	EQU	EQU *	PT105270
05CC	055A	529	LHI	R10,X'AAAA'	PT105280
05CE	2302	530	CLHR	R5,R10	PT105290
05D0	230D	531	BES	T2G	PT105300
	0000 05D2	532	T2R6	BS	PT105310
05D2	2477	533	LIS	T2R7	PT105320
05D4	C570 0007	534	EQU	EQU *	PT105330
05D8	2139	535	T26	LIS	PT105340
05DA	2488	536	CLHI	R7,7	PT105350
05DC	24D0	537	BNES	R7,7	PT105360
05DE	C580 0008	538	T2R7	CLHI	PT105370
05E2	2154	539	LIS	R8,8	PT105380
05E4	C5D0 000D	540	BNES	R13,13	PT105390
05E8	2333	541	CLHI	T2R7	PT105400
05EA	4300 060C	542	BES	R8,8	PT105410
	0000 05EE	543	T2R7	BNES	PT105420
05EE	25E1	544	LCS	EQU *	PT105430
			LCS	R14,1	PT105440
				R14=FFFF	

05F0	2233	545	BZS	T2R7	PT105450		
05F2	2024	546	BPS	T2R7	PT105460		
05F4	05EF	547	CLHR	R14,R15	PT105470		
05F6	2138	548	BNES	T2R8	PT105480		
05F8	258B	549	LCS	R11,11	PT105490		
05FA	2129	550	BPS	T2R8	PT105500		
05FC	25CC	551	LCS	R12,12	PT105510		
05FE	2127	552	BPS	T2R8	PT105520		
0600	C5H0 FFF5	553	CLHI	R11,X'FFF5'	PT105530		
0604	2134	554	BNES	T2R8	PT105540		
0606	C5C0 FFF4	555	CLHI	R12,X'FFF4'	PT105550		
060A	2333	556	BES	T2END	PT105560		
060C	4300 2182	557	T2R8	B	ERROR	1201	PT105570
0610	4300 0622	558	T2END	B	TEST3	PT105580	
0614	0000	559	DC	0	PT105590		
0616	0000	560	T2WRD0	DC	0	PT105600	
0618	0000	561	DC	0	PT105610		
061A	0000	562	T2WRD1	DC	0	PT105620	
061C	0000	563	DC	0	PT105630		
061E	0000	564	T2WRD2	DC	0	PT105640	
0620	0000	565	DC	0	PT105650		
		566	*****			PT105660	
		567	*	PT105670			
		568	*	TEST 3 CHECKS THE INSTRUCTIONS	PT105680		
		569	*	PT105690			
		570	*	STH , LM AND STM	PT105700		
		571	*	PT105710			
		572	*	T3BUF0 = 16 HW'S OF ZEROS	PT105720		
		573	*	PT105730			
		574	*	T3BUF2 = 16 HW'S OF DATA 0,1,2,.....,14,15	PT105740		
		575	*	PT105750			
		576	*	T3BUF1 = T3BUF2 + 14, (STARTS AT HW = 7)	PT105760		
		577	*	PT105770			
		578	*	T3BUF3 = 16 HW'S OF STORAGE AREA	PT105780		
		579	*	PT105790			
0622	C800 07BC	580	TEST3	LHI R0,TEST4	PT105800		
0626	4000 22F4	581	STH	R0,NXTST	PT105810		
062A	C800 0113	582	LHI	R0,X'0113'	PT105820		
062E	4000 22F2	583	STH	R0,ERRIND	ERRIND = 0113	PT105830	
0632	C800 3133	584	LHI	R0,X'3133'	PT105840		
0636	4000 22B8	585	STH	R0,TESTNO	PT105850		
		586	*	PT105860			
063A	2501	587	LCS	R0,1	RO=FFFF	PT105870	
063C	2512	588	LCS	R1,2	PT105880		
063E	2523	589	LCS	R2,3	PT105890		
	0000 0640	590	STH	PT105900			
0640	4000 0616	591	STH	R0,T2WRD0	T2WRD0 = R0 = FFFF	PT105910	
0644	4010 061A	592	STH	R1,T2WRD1	T2WRD1 = R1 = FFFE	PT105920	
0648	4020 061E	593	STH	R2,T2WRD2	T2WRD2 = R2 = FFFD	PT105930	
064C	4310 2182	594	BNM	ERROR	PT105940		
0650	4860 0616	595	LH	R6,T2WRD0	PT105950		
0654	4870 061A	596	LH	R7,T2WRD1	PT105960		
0658	4880 061E	597	LH	R8,T2WRD2	PT105970		
065C	0506	598	CLHR	R0,R6	PT105980		
065E	4230 2182	599	BNE	ERROR	PT105990		

0662	0528	600	CLHR	R2,R8	PT106000
0664	4230 2182	601	BNE	ERROR	PT106010
0668	C800 0213	602	LHI	R0,X'213'	PT106020
066C	4000 22F2	603	STH	R0,ERRIND	PT106030
	0000 0670	604	LM	EQU *	PT106040
0670	D100 0752	605	T3B	LM R0,T3BUF0	ZERO INTO ALL REG. R0 THRU R15 PT106050
0674	08U0	606	LHR	R0,R0	PT106060
0676	2135	607	BNZS	T3R1	PT106070
0678	050F	608	CLHR	R0,R15	PT106080
067A	2133	609	BNES	T3R1	PT106090
067C	0507	610	CLHR	R0,R7	PT106100
067E	2332	611	BES	T3C	PT106110
0680	230D	612	T3R1	BS T3R2	PT106120
0682	D170 0782	613	T3C	LM R7,T3BUF1	REG7=7,....,REG15=15 PT106130
0686	0800	614	LHR	R0,R0	R0 THRU R6 MUST BE UNCHANGED PT106140
0688	2139	615	BNZS	T3R2	PT106150
068A	0866	616	LHR	R6,R6	PT106160
068C	2137	617	BNZS	T3R2	PT106170
068E	C570 0007	618	CLHI	R7,7	PT106180
0692	2134	619	BNES	T3R2	PT106190
0694	C580 0008	620	CLHI	R8,8	PT106200
0698	2332	621	BES	T3D	PT106210
069A	230F	622	T3R2	BS T3R3	PT106220
069C	C5F0 000F	623	T3D	CLHI R15+15	PT106230
06A0	213C	624	BNES	T3R3	PT106240
06A2	C5E0 000E	625	CLHI	R14+14	PT106250
06A6	2139	626	BNES	T3R3	PT106260
06A8	2544	627	LCS	R4,4	R4=FFFF PT106270
06AA	2555	628	LCS	R5,5	R5=FFFB PT106280
06AC	2565	629	LCS	R6,5	R6=FFFB PT106290
06AE	D150 0752	630	LM	R5,T3BUF0	ALL REG. R5 THRU R15 = 0 PT106300
06B2	C540 FFFC	631	CLHI	R4,X'FFFFC'	PT106310
06B6	2332	632	BES	T3E	PT106320
06B8	2300	633	T3R3	BS T3R4	PT106330
06BA	0800	634	T3E	LHR R0,R0	PT106340
06BC	2138	635	BNZS	T3R4	PT106350
06BE	0505	636	CLHR	R0,R5	PT106360
06C0	2139	637	BNES	T3R4	PT106370
06C2	0506	638	CLHR	R0,R6	PT106380
06C4	2137	639	BNES	T3R4	PT106390
06C6	050F	640	CLHR	R0,R15	PT106400
06C8	2135	641	BNES	T3R4	PT106410
06CA	050E	642	CLHR	R0,R14	PT106420
06CC	2133	643	BNES	T3R4	PT106430
06CE	0509	644	CLHR	R0,R9	PT106440
06D0	2333	645	BES	T3F	PT106450
06D2	4300 2182	646	T3R4	B ERROR	ERROR 1302 PT106460
06D6	C800 0313	647	T3F	LHI R0,X'313'	PT106470
06DA	4000 22F2	648	STH	R0,ERRIND	PT106480
06DE	2466	649	LIS	R6,6	PT106490
06E0	D1U6 U76E	650	LM	R0,T3BUF2-6(R6)	270 REG 0=0 REG 1=1 ETC PT106500
	0000 06E4	651	STM	EQU *	PT106510
06E4	D008 078E	652	STM	R0,T3BUF3-8(R8)	PT106520
06E8	4800 0796	653	LH	R0,T3BUF3	PT106530
06EC	2130	654	BNZS	T3R5	PT106540

MODEL 8/16E PROCESSOR TEST PART 1 06-211M96R00A13 PAGE 13 09:54:45 11/04/78

06EE	4800 0798	655	LH	R0,T3BUF3+2	1	PT106550
06F2	0501	656	CLHR	R0,R1		PT106560
06F4	2139	657	BNES	T3R5		PT106570
06F6	4800 079A	658	LH	R0,T3BUF3+4	2	PT106580
06FA	0502	659	CLHR	R0,R2		PT106590
06FC	2135	660	BNES	T3R5		PT106600
06FE	4800 07B4	661	LH	R0,T3BUF3+30	15	PT106610
0702	050F	662	CLHR	R0,R15		PT106620
0704	2332	663	BES	T3G		PT106630
0706	230D	664	T3R5	BS		PT106640
0708	4800 07B2	665	T3G	LH	14	PT106650
070C	050E	666	CLHR	R0,K14		PT106660
070E	2139	667	BNES	T3R6		PT106670
0710	4800 07A8	668	LH	R0,T3BUF3+18		PT106680
0714	0590	669	CLHR	R9,R0		PT106690
0716	2135	670	BNES	T3R6		PT106700
0718	4800 07A0	671	LH	R0,T3BUF3+10	5	PT106710
071C	0505	672	CLHR	R0,R5		PT106720
071E	2333	673	BES	T3H		PT106730
0720	4300 2182	674	T3R6	B	ERROR	PT106740
0724	D100 0752	675	T3H	LM	R0,T3BUF0	PT106750
0728	D000 0796	676	STM	R0,T3BUF3	T3BUF3 = 0	PT106760
072C	4800 0796	677	LH	R0,T3BUF3	0	PT106770
0730	213E	678	BNZS	T3R7		PT106780
0732	4800 0798	679	LH	R0,T3BUF3+2	1	PT106790
0736	213B	680	BNZS	T3R7		PT106800
0738	4800 07B4	681	LH	R0,T3BUF3+30	15	PT106810
073C	2138	682	BNZS	T3R7		PT106820
073E	4800 07A4	683	LH	R0,T3BUF3+14	7	PT106830
0742	2145	684	BNZS	T3R7		PT106840
0744	4800 07AA	685	LH	R0,T3BUF3+20	10	PT106850
0748	4330 07B8	686	BZ	T3END		PT106860
074C	4300 2182	687	T3R7	B	ERROR	PT106870
0750	FFFF	688	DC	X'FFFF'	ERROR 1303	PT106880
0752	0000	689	T3BUF0	DC	0	PT106890
0754	0000	690	DC	0	1	PT106900
0756	0000	691	DC	0	2	PT106910
0758	0000	692	DC	0	3	PT106920
075A	0000	693	DC	0	4	PT106930
075C	0000	694	DC	0	5	PT106940
075E	0000	695	DC	0	6	PT106950
0760	0000	696	DC	0	7	PT106960
0762	0000	697	DC	0	8	PT106970
0764	0000	698	DC	0	9	PT106980
0766	0000	699	DC	0	10	PT106990
0768	0000	700	DC	0	11	PT107000
076A	0000	701	DC	0	12	PT107010
076C	0000	702	DC	0	13	PT107020
076E	0000	703	DC	0	14	PT107030
0770	0000	704	DC	0	15	PT107040
0772	FFFF	705	DC	X'FFFF'		PT107050
0774	0000	706	T3BUF2	DC	0	PT107060
0776	0001	707	DC	1		PT107070
0778	0002	708	DC	2		PT107080
077A	0003	709	DC	3		PT107090

077C	0004	710	DC	4	PT107100
077E	0005	711	DC	5	PT107110
0780	0046	712	DC	6	PT107120
0782	0007	713	T3BUF1	DC 7	PT107130
0784	0008	714	DC	8	PT107140
0786	0009	715	DC	9	PT107150
0788	000A	716	DC	10	PT107160
078A	000B	717	DC	11	PT107170
078C	000C	718	DC	12	PT107180
078E	000D	719	DC	13	PT107190
0790	000E	720	DC	14	PT107200
0792	000F	721	DC	15	PT107210
0794	FFFF	722	DC	X'FFFF'	PT107220
0796	0000	723	T3BUF3	DC 0	PT107230
0798	0000	724	DC	0	PT107240
079A	0000	725	DC	0	PT107250
079C	0000	726	DC	0	PT107260
079E	0000	727	DC	0	PT107270
07A0	0000	728	DC	0	PT107280
07A2	0000	729	DC	0	PT107290
07A4	0000	730	DC	0	PT107300
07A6	0000	731	DC	0	PT107310
07A8	0000	732	DC	0	PT107320
07AA	0000	733	DC	0	PT107330
07AC	0000	734	DC	0	PT107340
07AE	0000	735	DC	0	PT107350
07B0	0000	736	DC	0	PT107360
07B2	0000	737	DC	0	PT107370
07B4	0000	738	DC	0	PT107380
07B6	0000	739	DC	0	PT107390
07B8	4300 07BC	740	T3END	B TEST4	PT107400
		741	*****		
		742	*		PT107410
		743	*	TEST 4 CHECKS THE LOGIC INSTRUCTIONS	PT107420
		744	*		PT107430
		745	*	XHR , XHI + XH : OHR , OHI , OH : NHR , NHI , NH	PT107440
		746	*		PT107450
07BC	C800 09BA	747	TEST4	LHI R0,TEST5	PT107460
07C0	4000 22F4	748		STH R0,NXTST	PT107470
07C4	C800 0114	749		LHI R0,X'0114'	PT107480
07C8	4000 22F2	750		STH R0,ERRIND	PT107490
07CC	C800 3134	751		LHI R0,X'3134'	PT107500
07D0	4000 22B8	752		STH R0,TESTNO	PT107510
		753	*		PT107520
07D4	D100 0752	754		LM R0,T3BUFO	PT107530
07D8	4850 22FE	755		LH R5,FIVE	PT107540
07DC	48A0 2302	756		LH R10*TEN	PT107550
07E0	25F1	757		LCS R15+1	PT107560
	0000 07E2	758	XHR	EQU *	PT107570
07E2	0705	759		XHR R0,R5	PT107580
07E4	2350	760		BZS T4R1	PT107590
07E6	21CC	761		BTFS 12,12	PT107600
07E8	05UF	762		CLHR R0,R15	PT107610
07EA	238A	763		BNLS T4R1	PT107620
07EC	070A	764		XHR R0,R10	PT107630
				R0=FFFF	PT107640

07EE	2338	765	BZS	T4R1		PT107650	
07F0	21C7	766	BTFS	12,7		PT107660	
07F2	054F	767	CLHR	R0,R15		PT107670	
07F4	2145	768	BNES	T4R1		PT107680	
07F6	0703	769	XHR	R0,R3	RO=FFFF,R3=0	PT107690	
07F8	2343	770	BZS	T4R1		PT107700	
07FA	050F	771	CLHR	R0,R15	RO = FFFF	PT107710	
07FC	2333	772	BES	T4B		PT107720	
07FE	4300 2182	773	T4R1	B	ERROR	PT107730	
0802	070A	774	T4B	XHR	R0,R10	RO = 5555	PT107740
0804	2233	775	BZS	T4R1		PT107750	
0806	20C4	776	BTBS	12,4		PT107760	
0808	0505	777	CLHR	R0,R5		PT107770	
080A	2036	778	BNES	T4R1		PT107780	
080C	0705	779	XHR	R0,R5		PT107790	
080E	2038	780	BNZS	T4R1		PT107800	
0810	0800	781	LHR	R0,R0	RO = 0	PT107810	
0812	203A	782	BNZS	T4R1		PT107820	
0814	C700 5555	783	XHI	R0,X'5555'	RO = 5555	PT107830	
0818	223D	784	BZS	T4R1		PT107840	
081A	20CE	785	BTBS	12,14		PT107850	
081C	0505	786	CLHR	R0,R5		PT107860	
081E	213D	787	BNES	T4R2		PT107870	
	0000 0820	788	XHI	EQU *		PT107880	
0820	C700 AAAA	789	XHI	R0,X'AAAA'	RO = FFFF	PT107890	
0824	233A	790	BZS	T4R2		PT107900	
0826	21C9	791	BTFS	12,9		PT107910	
0828	050F	792	CLHR	R0,R15		PT107920	
082A	2157	793	BNES	T4R2		PT107930	
082C	C700 0000	794	XHI	R0,0	RO = FFFF	PT107940	
0830	2334	795	BZS	T4R2		PT107950	
0832	21C3	796	BTFS	12,3		PT107960	
0834	050F	797	CLHR	R0,R15		PT107970	
0836	2333	798	BES	T4D		PT107980	
0838	4300 2182	799	T4R2	B	ERROR	PT107990	
083C	C700 5555	800	T4D	XHI	R0,X'5555'	RO = AAAA	PT108000
0840	2234	801	BZS	T4R2		PT108010	
0842	050A	802	CLHR	R0,R10		PT108020	
0844	2036	803	BNES	T4R2		PT108030	
0846	C700 AAAA	804	XHI	R0,X'AAAA'	RO = 0	PT108040	
084A	2039	805	BNZS	T4R2		PT108050	
084C	0840	806	LHR	R0,R0		PT108060	
084E	2038	807	BNZS	T4R2		PT108070	
	0000 0850	808	XH	EQU *		PT108080	
0850	4700 22FE	809	XH	R0,FIVE	RO = 5555	PT108090	
0854	223E	810	BZS	T4R2		PT108100	
0856	0505	811	CLHR	R0,R5		PT108110	
0858	213B	812	BNES	T4R3		PT108120	
085A	4700 2302	813	XH	R0,TEN	RO = FFFF	PT108130	
085E	2338	814	BZS	T4R3		PT108140	
0860	054F	815	CLHR	R0,K15		PT108150	
0862	2146	816	BNES	T4R3		PT108160	
0864	4700 22F6	817	XH	R0,ZERO	RO = FFFF	PT108170	
0868	2333	818	BZS	T4R3		PT108180	
086A	050F	819	CLHR	R0,R15		PT108190	

086C	2333	820	BES	T4E		PT108200
086E	4300 2182	821	T4R3	B	ERROR	PT108210
		822	*			PT108220
0872	C870 0214	823	T4E	LHI	R7,X'214'	PT108230
0876	4070 22F2	824		STH	R7,ERRIND	PT108240
		825	*			PT108250
087A	4700 2302	826		XH	R0,TEN	PT108260
087E	2238	827		BZS	T4R3	PT108270
0880	0505	828		CLHR	R0,R5	PT108280
0882	203A	829		BNES	T4R3	PT108290
0884	4700 22FE	830		XH	R0,FIVE	PT108300
0888	203D	831		BNZS	T4R3	PT108310
088A	0800	832		LHR	R0,R0	PT108320
088C	203F	833		BNZS	T4R3	PT108330
		834	*			PT108340
		835	*	THE REG. HAVE THE VALUES:		PT108350
		836	*			PT108360
		837	*	R0=0,R5=5555,R10=AAAA,R15=FFFF		PT108370
		838	*			PT108380
		839	*	ALL OTHERS=0		PT108390
		840	*			PT108400
088E	087F	841	LHR	R7,R15	R7=R15=FFFF	PT108410
	0000 0890	842	OHR	EQU	*	PT108420
0890	0640	843		OHR	R4,R0	PT108430
0892	213F	844		BNZS	T4R4	PT108440
0894	0540	845		CLHR	R4,RU	PT108450
0896	213D	846		BNES	T4R4	PT108460
	0000 0898	847	OHI	EQU	*	PT108470
0898	C640 0000	848		OHI	R4,0	PT108480
089C	213A	849		BNZS	T4R4	PT108490
089E	0540	850		CLHR	R4,R0	PT108500
08A0	2138	851		BNES	T4R4	PT108510
	0000 08A2	852	OH	EQU	*	PT108520
08A2	4640 22F6	853		OH	R4,ZERO	PT108530
08A6	2135	854		BNZS	T4R4	PT108540
08A8	C540 0000	855		CLHI	R4,R0	PT108550
08AC	4330 08B4	856		BE	T4G	PT108560
08B0	4300 2182	857	T4R4	B	ERROR	PT108570
08B4	0674	858	T4G	OHR	R7,R4	PT108580
08B6	2233	859		BZS	T4R4	PT108590
08B8	20C4	860		BTBS	12,4	PT108600
08BA	057F	861		CLHR	R7,R15	PT108610
08BC	2036	862		BNES	T4R4	PT108620
08BE	0540	863		CLHR	R4,RU	PT108630
08C0	2038	864		BNES	T4R4	PT108640
08C2	C670 0000	865		OHI	R7,0	PT108650
08C6	223B	866		BZS	T4R4	PT108660
08C8	057F	867		CLHR	R7,R15	PT108670
08CA	209D	868		BNES	T4R4	PT108680
08CC	4670 22F6	869		OH	R7,ZERO	PT108690
08D0	233E	870		BZS	T4R5	PT108700
08D2	21CC	871		BTFS	12,12	PT108710
08D4	057F	872		CLHR	R7,R15	PT108720
08D6	213B	873		BNES	T4R5	PT108730
08D8	0647	874		OHR	R4,R7	PT108740

08DA	2339	875	BZS	T4R5	PT108750	
08DC	21C7	876	BTFS	12,7	PT108760	
08DE	054F	877	CLHR	R4,R15	PT108770	
08E0	2136	878	BNES	T4R5	PT108780	
08E2	2135	879	BNES	T4R5	PT108790	
08E4	057F	880	CLHR	R7,R15	PT108800	
08E6	C600 FFFF	881	OHI	R0,X'FFFF'	PT108810	
08EA	2133	882	BNZS	T4H	PT108820	
08EC	4300 2182	883	T4R5	B	ERROR	PT108830
08F0	050F	884	T4H	CLHR	R0,R15	PT108840
08F2	2033	885	BNES	T4R5	PT108850	
08F4	4680 22FA	886	OH	R8,ONE	PT108860	
08F8	2236	887	BZS	T4R5	PT108870	
08FA	20C6	888	BTBS	12,6	PT108880	
08FC	058F	889	CLHR	R8,R15	PT108890	
08FE	064F	890	OHR	R4,R15	PT108900	
0900	223A	891	BZS	T4R5	PT108910	
0902	20C9	892	BTBS	12,9	PT108920	
0904	C600 0000	893	OHI	R0,0	PT108930	
0908	2338	894	BZS	T4R6	PT108940	
090A	050F	895	CLHR	R0,R15	PT108950	
090C	2136	896	BNES	T4R6	PT108960	
090E	4680 22FA	897	OH	R8,ONE	PT108970	
0912	2333	898	BZS	T4R6	PT108980	
0914	058F	899	CLHR	R8,R15	PT108990	
0916	2333	900	BES	T4J	PT109000	
0918	4300 2182	901	T4R6	B	ERROR	PT109010
		902	*			PT109020
		903	*	THE REG. HAVE THE VALUES:		PT109030
		904	*			PT109040
		905	*	RO=R4=R8=FFFF		PT109050
		906	*			PT109060
		907	*	R5=5555,R10=AAAA,R15=FFFF		PT109070
		908	*			PT109080
		909	*	ALL OTHERS=0		PT109090
		910	*			PT109100
		911	T4J	LHI	R0,X'314'	PT109110
		912		STH	R0,ERRIND	PT109120
		913	*		ERRIND = 0314	PT109130
		914		LIS	R0,0	PT109140
		915		LIS	R9,0	PT109150
		916	NHR	EQU	*	PT109160
		917		NHR	R9,R0	PT109170
		918		BNZS	T4R7	PT109180
		919		LHR	R9,R9	PT109190
		920		BNZS	T4R7	PT109200
		921		CLHR	R9,R0	PT109210
		922		BNZS	T4R7	PT109220
		923	NH	EQU	*	PT109230
		924		NH	R9,ZERO	PT109240
		925		BNZS	T4R7	PT109250
		926		CLHR	R9,RU	PT109260
		927		BNES	T4R7	PT109270
		928	NHI	EQU	*	PT109280
		929		NHI	R9,0	PT109290

0942	2133	930	BNZS	T4R7		PT109300	
0944	0590	931	CLHR	R9,RU	R9=0000	PT109310	
0946	2333	932	BES	T4K		PT109320	
0948	4300 2182	933	T4R7	B	ERROR	PT109330	
094C	0478	934	T4K	NHR	R9,R8	PT109340	
094E	2033	935	BNZS	T4R7		PT109350	
0950	058F	936	CLHR	R8,R15	R8=R15=FFFF?	PT109360	
0952	2035	937	BNES	T4R7		PT109370	
0954	0590	938	CLHR	R9,RU	R9=R0=0?	PT109380	
0956	2037	939	BNES	T4R7		PT109390	
0958	C490 FFFF	940	NHI	R9,X'FFFF'	R9=0	PT109400	
095C	203A	941	BNZS	T4R7		PT109410	
095E	0590	942	CLHR	R9,RU	R9=R0=0?	PT109420	
0960	203C	943	BNES	T4R7		PT109430	
0962	4490 22FA	944	NH	R9,ONE	R9=0,ONE=FFFF	PT109440	
0966	203F	945	BNZS	T4R7		PT109450	
0968	0590	946	CLHR	R9,R0		PT109460	
096A	0448	947	NHR	R4,R8	R4=FFFF,R8=FFFF	PT109470	
096C	233A	948	BZS	T4R8		PT109480	
096E	21C9	949	BTFS	12,9		PT109490	
0970	054F	950	CLHR	R4,R15	R4=R15=FFFF?	PT109500	
0972	2137	951	BNES	T4R8		PT109510	
0974	058F	952	CLHR	R8,R15	R8=R15=FFFF?	PT109520	
0976	C440 FFFF	953	NHI	R4,X'FFFF'		PT109530	
097A	2333	954	BZS	T4R8		PT109540	
097C	054F	955	CLHR	R4,R15	R4=R15=FFFF?	PT109550	
097E	2333	956	BES	T4L		PT109560	
0980	4300 2182	957	T4R8	B	ERROR	PT109570	
0984	4440 22FA	958	T4L	NH	R4,ONE	PT109580	
0988	2234	959	BZS	T4R8		PT109590	
098A	20C5	960	BTBS	12,5		PT109600	
098C	054F	961	CLHR	R4,R15	R4=R15=FFFF?	PT109610	
098E	2037	962	BNES	T4R8		PT109620	
0990	0440	963	NHR	R4,R0	R4=FFFF,R0=0 R4=R0=0	PT109630	
0992	2039	964	BNZS	T4R8		PT109640	
0994	0844	965	LHR	R4,R4		PT109650	
0996	203B	966	BNZS	T4R8		PT109660	
0998	0540	967	CLHR	R4,R0		PT109670	
099A	213C	968	BNES	T4R9		PT109680	
099C	C480 0000	969	NHI	R8,0	R8=FFFF R8=0	PT109690	
09A0	2139	970	BNZS	T4R9		PT109700	
09A2	0580	971	CLHR	R8,RU	R8=R0=0?	PT109710	
09A4	2137	972	BNES	T4R9		PT109720	
09A6	087F	973	LHR	R7,R15	R7=R15=FFFF	PT109730	
09A8	4470 22F6	974	NH	R7,ZERO	R7=FFFF,ZERO=0 R7=0	PT109740	
09AC	2133	975	BNZS	T4R9		PT109750	
09AE	0570	976	CLHR	R7,K0		PT109760	
09B0	2333	977	BES	T4END		PT109770	
09B2	4300 2182	978	T4R9	B	ERROR	PT109780	
09B6	4300 09BA	979	T4END	B	TEST5	PT109790	
		980	*****				PT109800
		981	*			PT109810	
		982	*	TEST 5 TESTS THE INSTRUCTIONS		PT109820	
		983	*			PT109830	
		984	*			PT109840	

		985	*	BAL , BXLE , BXH , BR , BTCR,BFCR , BALR	PT109850
		986	*		PT109860
		987	*	(ERR1, ERR2,3,4      ERR5,6,7)	PT109870
		988	*		PT109880
09BA	C800 0B14	989	TEST5	LHI R0,TEST6	PT109A90
09BE	4000 22F4	990		STH R0,NXTST	PT109900
09C2	C800 0115	991		LHI R0,X'0115'	PT109910
09C6	4000 22F2	992		STH R0,ERRIND	PT109920
09CA	C800 3135	993		LHI R0,X'3135'	PT109930
09CE	4000 22B8	994		STH R0,TESTNO	PT109940
		995	*		PT109950
	0000 09D2	996	BAL	EQU *	PT109960
09D2	4100 09D8	997		BAL R0,T5A2	PT109970
09D6	230C	998	T5A1	BS T5ERR1	PT109980
09D8	C810 09D6	999	T5A2	LHI R1,T5A1	PT109990
09DC	0501	1000		CLHR R0,R1	PT110000
09DE	2138	1001		BNES T5ERR1	PT110010
09E0	4130 09E6	1002		BAL R3,T5B2	PT110020
09E4	2305	1003	T5B1	BS T5ERR1	PT110030
09E6	C820 09E4	1004	T5B2	LHI R2,T5B1	PT110040
09EA	0523	1005		CLHR R2,K3	PT110050
09EC	2333	1006		BES T5C	PT110060
09EE	4300 2182	1007	T5ERR1	B ERROR	PT110070
09F2	C800 0A18	1008	T5C	LHI R0,T5D2	PT110080
09F6	2440	1009		LIS R4,0	PT110090
09F8	2451	1010		LIS R5,1	PT110100
09FA	2468	1011		LIS R6,8	PT110110
09FC	C540 0009	1012	T5D	CLHI R4,9	PT110120
0A00	233A	1013		BES T5ERR2	PT110130
	0000 0A02	1014	BXLE	EQU *	PT110140
0A02	C140 09FC	1015		BXLE R4,T5D	PT110150
0A06	C540 0009	1016		CLHI R4,9	PT110160
0A0A	2135	1017		BNES T5ERR2	PT110170
0A0C	C560 0008	1018		CLHI R6,8	PT110180
0A10	2132	1019		BNES T5ERR2	PT110190
0A12	230D	1020		BS T5D3	PT110200
0A14	4300 0A6E	1021	T5ERR2	B T5ERR4	PT110210
0A18	4300 0A7E	1022	T5D2	B T5E1	PT110220
0A1C	4300 0A86	1023	T5E2	B T5F	PT110230
0A20	2411	1024		LIS R1,1	PT110240
0A22	2448	1025	T5F2	LIS R0,8	PT110250
0A24	4300 0A92	1026		B T5G	PT110260
0A28	4300 0AFE	1027	T5Q	B T5Q2	PT110270
0A2C	C870 9684	1028	T5D3	LHI R7,X'9684'	PT110280
0A30	2482	1029		LIS R8,2	PT110290
0A32	C890 F436	1030		LHI R9,X'F436'	PT110300
0A36	C570 F437	1031	T5D4	CLHI R7,X'F437'	PT110310
0A3A	2389	1032		BNLS T5ERR3	PT110320
0A3C	C170 0A36	1033		BXLE R7,T5D4	PT110330
0A40	C570 F438	1034		CLHI R7,X'F438'	PT110340
0A44	2134	1035		BNES T5ERR3	PT110350
0A46	C590 F436	1036		CLHI R9,X'F436'	PT110360
0A4A	2353	1037		BES T5D5	PT110370
0A4C	4300 0A6E	1038	T5ERR3	B T5ERR4	PT110380
0A50	C840 7328	1039	T5D5	LHI R4,X'7328'	PT110390

0A54	2452	1040	LIS	R5,2	PT110400
0A56	C860 9648	1041	LHI	R6,X'9648'	PT110410
0A5A	C540 9649	1042	T5B3	CLHI R4,X'9649'	PT110420
0A5E	2388	1043	BNLS	T5ERR4	PT110430
	0000 0A60	1044	BXH	EQU *	PT110440
0A60	C040 0A66	1045	BXH	R4,T5B4	PT110450
0A64	2205	1046	BS	T5B3	PT110460
0A66	C540 964A	1047	T5B4	CLHI R4,X'964A'	PT110470
0A6A	2182	1048	BLS	T5ERR4	PT110480
0A6C	2307	1049	BS	T5E	PT110490
0A6E	C800 0215	1050	T5ERR4	LHI R0,X'0215'	PT110500
0A72	4000 22F2	1051	STH	R0,ERRIND	PT110510
0A76	4300 2182	1052	B	ERROR	PT110520
	0000 0A7A	1053	BR	EQU *	PT110530
0A7A	0300	1054	T5E	BR R0	PT110540
0A7C	230A	1055	BS	T5R5	PT110550
0A7E	C860 0A1C	1056	T5E1	LHI R6,T5E2	PT110560
0A82	0306	1057	BR	R6	PT110570
0A84	2306	1058	BS	T5R5	PT110580
0A86	2400	1059	T5F	LIS R0,0	PT110590
0A88	2410	1060	LIS	R1,0	PT110600
0A8A	C850 0A22	1061	LHI	R5,T5F2	PT110610
0A8E	0305	1062	BR	R5	PT110620
0A90	2308	1063	T5R5	BS T5ERR5	PT110630
0A92	C500 0008	1064	T5G	CLHI R0,8	PT110640
0A96	2138	1065	BNES	T5ERR5	PT110650
0A98	0811	1066	LHR	R1,R1	PT110660
0A9A	2136	1067	BNZS	T5ERR5	PT110670
0A9C	4300 0AC0	1068	B	T5K1	PT110680
0AA0	4300 0AD2	1069	T5H1	B T5K2	PT110690
0AA4	2301	1070	T5H2	BS T5ERR5	PT110700
0AA6	4300 0B04	1071	T5ERR5	B T5ERR7	PT110710
0AAA	4300 0AE2	1072	T5H3	B T5K3	PT110720
0AAE	2204	1073	T5H4	BS T5ERR5	PT110730
0AB0	C820 0AEA	1074	T5J1	LHI R2,T5L	PT110740
0AB4	0512	1075	CLHR	R1,R2	PT110750
0AB6	2038	1076	BNES	T5ERR5	PT110760
0AB8	C830 0AEC	1077	LHI	R3,T5M	PT110770
0ABC	0143	1078	BALR	R4,R3	PT110780
0ABE	220C	1079	T5J3	BS T5ERR5	PT110790
	1080	*			PT110800
0AC0	C800 0AA0	1081	T5K1	LHI R0,T5H1	PT110810
0AC4	C830 0AA4	1082	LHI	R5,T5H2	PT110820
0AC8	2418	1083	LIS	R1,8	PT110830
0ACA	0511	1084	CLHR	R1,R1	PT110840
	0000 0ACC	1085	BFCR	EQU *	PT110850
0ACC	0330	1086	BFCR	3,R0	PT110860
0ACE	4300 0A6E	1087	B	T5ERR4	PT110870
	0000 0AD2	1088	BTCR	EQU *	PT110880
0AD2	0235	1089	T5K2	BTCR 3,R5	PT110890
0AD4	C840 0AAA	1090	LHI	R4,T5H3	PT110900
0AD8	C860 0AAE	1091	LHI	R6,T5H4	PT110910
0ADC	0516	1092	CLHR	R1,R6	PT110920
0ADE	0284	1093	BTCR	8,R4	PT110930
0AE0	230A	1094	BS	T5ERR6	PT110940

0AE2	0386	1095	T5K3	BFCR	8,R6	ERR. IF BRANCH	PT110950	
		1096	*				PT110960	
0AE4	C890 0AB0	1097	LHI	R9,T5J1			PT110970	
0AE8	0119	1098	BALR	R1,R9	(12) TO T5J1 + R1 = (T5L)		PT110980	
0AEA	2305	1099	T5L	BS	T5ERR6		PT110990	
0AEC	C880 0ABE	1100	T5M	LHI	R8,T5J3		PT111000	
0AF0	0548	1101	CLHR	R4,R8			PT111010	
0AF2	2332	1102	BES	T5P			PT111020	
0AF4	2308	1103	T5ERR6	BS	T5ERR7	ERROR 1503	PT111030	
0AF6	C870 0A28	1104	T5P	LHI	R7,T5Q	R7 = ADD. OF T5Q	PT111040	
	0000 0AFA	1105	BALR	EQU	*		PT111050	
0AFA	0177	1106	BALR	R7,R7			PT111060	
0AFC	2304	1107	T5R7	BS	T5ERR7		PT111070	
0AFE	C570 0AFC	1108	T5Q2	CLHI	R7,T5R7	IS R7 = ADD. OF T5R7	PT111080	
0B02	2337	1109	BES	T5END			PT111090	
0B04	C800 0315	1110	T5ERR7	LHI	R0,X'0315'	ERROR 1503	PT111100	
0B08	4000 22F2	1111	STH	R0,ERRIND			PT111110	
0B0C	4340 2182	1112	B	ERROR			PT111120	
0B10	4300 0B14	1113	T5END	B	TEST6		PT111130	
		1114	*****					PT111140
		1115	*				PT111150	
		1116	*	TEST 6 CHECKS THE INSTRUCTIONS			PT111160	
		1117	*				PT111170	
		1118	*	EPSR	+ SLLS , SRLS , SLHL , SRHL		PT111180	
		1119	*				PT111190	
		1120	*	(T6R1 , T6R2,T6R3,T6R4 , T6R5,T6R6 )			PT111200	
		1121	*				PT111210	
		1122	*				PT111220	
		1123	*	SLHA	+ SRHA , THI		PT111230	
		1124	*				PT111240	
		1125	*	(T6R7,T6R8,T6R9 , T6RA )			PT111250	
		1126	*				PT111260	
0B14	C800 0D5C	1127	TEST6	LHI	R0,TEST7		PT111270	
0B18	4000 22F4	1128	STH	R0,NXTST			PT111280	
0B1C	C800 3136	1129	LHI	R0,C'16'			PT111290	
0B20	4000 2288	1130	STH	R0,TESTNO			PT111300	
0B24	C800 0116	1131	LHI	R0,X'0116'			PT111310	
0B28	4000 22F2	1132	STH	R0,ERRIND	ERRIND = 0116		PT111320	
		1133	*				PT111330	
0B2C	2400	1134	LIS	R0,0			PT111340	
	0000 0B2E	1135	EPSR	EQU	*		PT111350	
0B2E	9510	1136	EPSR	R1,R0			PT111360	
0B30	2511	1137	LCS	R1,1			PT111370	
0B32	2400	1138	LIS	R0,0			PT111380	
0B34	9510	1139	EPSR	R1,R0	PSW INTO R1 , R0 INTO PSW		PT111390	
0B36	213B	1140	BNZS	T6R1			PT111400	
0B38	0800	1141	LHR	R0,R0			PT111410	
0B3A	2139	1142	BNZS	T6R1			PT111420	
0B3C	0510	1143	CLHR	R1,R0			PT111430	
0B3E	2137	1144	BNES	T6R1			PT111440	
0B40	2511	1145	LCS	R1,1			PT111450	
0B42	2400	1146	LIS	R0,0	COND. CODE = 0 , R0 = 0		PT111460	
0B44	9511	1147	EPSR	R1,R1	R1 = PSW = 0 ?		PT111470	
0B46	2133	1148	BNZS	T6R1			PT111480	
0B48	0510	1149	CLHR	R1,R0			PT111490	

084A	2333	1150	BES	T6A1		PT111500
084C	4300 2182	1151	T6R1	B	ERROR	PT111510
0850	C810 7C0F	1152	T6A1	LHI	R1,X'7C0F'	PT111520
0854	9501	1153		EPSR	R0,R1	PT111530
0856	2440	1154		LIS	R4,U	PT111540
0858	9540	1155		EPSR	R4,R0	PT111550
085A	C540 7C00	1156	M5004	CLHI	R4,X'7C00'	PT111560
085E	2039	1157		BNES	T6R1	PT111570
0860	9511	1158		EPSR	R1,R1	PT111580
0862	203B	1159		BNZS	T6R1	PT111590
0864	0811	1160		LHR	R1,R1	PT111600
0866	203D	1161		BNZS	T6R1	PT111610
0868	2402	1162	T6B	LIS	R0,2	PT111620
086A	D200 22F2	1163		STB	R0,ERRIND	PT111630
		1164	*			PT111640
086E	C840 D28B	1165		LHI	R6,X'D28B'	PT111650
0872	C870 DD4B	1166		LHI	R7,X'DD4B'	PT111660
	0000 0B76	1167	SLLS	EQU	*	PT111670
0876	9170	1168		SLLS	R7,0	PT111680
0878	218C	1169		BCS	T6R2	PT111690
	0000 0B7A	1170	SRLS	EQU	*	PT111700
087A	9070	1171		SRLS	R7,0	PT111710
087C	212A	1172		BPS	T6R2	PT111720
	0000 0B7E	1173	SLHL	EQU	*	PT111730
087E	CD70 0000	1174		SLHL	R7,0	PT111740
0882	2187	1175		BCS	T6R2	PT111750
	0000 0B84	1176	SRHL	EQU	*	PT111760
0884	CC70 0000	1177		SRHL	R7,0	PT111770
0888	2124	1178		BPS	T6R2	PT111780
088A	CF60 0000	1179		SLHA	R6,U	PT111790
088E	2383	1180		BNCS	T6B2	PT111800
0890	4300 2182	1181	T6R2	B	ERROR	PT111810
	0000 0B94	1182	SRHA	EQU	*	PT111820
0894	CE60 0000	1183	T6B2	SRHA	R6,0	PT111830
0898	2024	1184		BPS	T6R2	PT111840
089A	C560 D28B	1185		CLHI	R6,X'D28B'	PT111850
089E	2037	1186		BNES	T6R2	PT111860
08A0	C570 DD4B	1187		CLHI	R7,X'DD4B'	PT111870
08A4	203A	1188		BNES	T6R2	PT111880
08A6	9161	1189		SLLS	R6,1	PT111890
08A8	228C	1190		BNCS	T6R2	PT111900
08AA	C560 A576	1191	T6B4	CLHI	R6,X'A576'	PT111910
08AE	213D	1192		BNES	T6R3	PT111920
08B0	9162	1193		SLLS	R6,2	PT111930
08B2	218B	1194		BCS	T6R3	PT111940
08B4	C560 9508	1195		CLHI	R6,X'9508'	PT111950
08B8	2138	1196		BNES	T6R4	PT111960
08BA	9164	1197		SLLS	R6,4	PT111970
08BC	2386	1198		BNCS	T6R3	PT111980
08BE	C560 5D80	1199		CLHI	R6,X'5D80'	PT111990
08C2	2133	1200		BNES	T6R3	PT112000
08C4	9168	1201		SLLS	R6,8	PT112010
08C6	2183	1202		BCS	T6B6	PT112020
08C8	4300 2182	1203	T6R3	B	ERROR	PT112030
08CC	C560 8000	1204	T6B6	CLHI	R6,X'8000'	PT112040

0800	2034	1205	BNES T6R3		PT112050
0802	C570 DD4B	1206	CLHI R7,X'DD4B'	R7 MUST BE UNCHANGED	PT112060
0806	2037	1207	BNES T6R3		PT112070
0808	C840 2369	1208 T6C	LHI R4,X'2369'		PT112080
080C	9041	1209	SRLS R4,1	SHIFT RIGHT SHORT 1	PT112090
080E	2288	1210	BNCS T6R3		PT112100
08E0	C540 11B4	1211	CLHI R4,X'11B4'		PT112110
08E4	2190	1212	BNES T6R4		PT112120
08E6	9042	1213	SRLS R4,2	SHIFT RIGHT SHORT 2	PT112130
08E8	2188	1214	BCS T6R4		PT112140
08EA	C540 0460	1215	CLHI R4,X'460'		PT112150
08EE	2138	1216	BNES T6R4		PT112160
08F0	9044	1217	SRLS R4,4	SHIFT RIGHT SHORT 4	PT112170
0BF2	2386	1218	BNCS T6R4		PT112180
0BF4	C540 0046	1219	CLHI R4,X'46'		PT112190
0BF8	2133	1220	BNES T6R4		PT112200
0BFA	9048	1221	SRLS R4,8	SHIFT RIGHT SHORT 8	PT112210
0BFC	2333	1222	BZS T6C3		PT112220
0BFE	4300 2182	1223 T6R4	B ERROR	ERROR 1602	PT112230
0C02	0844	1224 T6C3	LHR R4,R4		PT112240
0C04	2033	1225	BNZS T6R4		PT112250
0C06	2403	1226 T6D	LIS R0,3		PT112260
0C08	D200 22F2	1227	STB R0,ERRIND	ERRIND = 0316	PT112270
0C0C	C840 D288	1228	LHI R4,X'D288'		PT112280
0C10	CD40 0001	1229	SLHL R4,1	SHIFT LEFT HW 1	PT112290
0C14	238E	1230	BNCS T6R5		PT112300
0C16	C540 A576	1231	CLHI R4,X'A576'		PT112310
0C1A	2138	1232	BNES T6R5		PT112320
0C1C	CD40 0002	1233	SLHL R4,2	SHIFT LEFT HW 2	PT112330
0C20	2188	1234	BCS T6R5		PT112340
0C22	C540 95D8	1235	CLHI R4,X'95D8'		PT112350
0C26	2135	1236	BNES T6R5		PT112360
0C28	2474	1237	LIS R7,4		PT112370
0C2A	CD47 0000	1238	SLHL R4,U(R7)		PT112380
0C2E	2183	1239	BCS T6D2		PT112390
0C30	4300 2182	1240 T6R5	B ERROR	ERROR 1603	PT112400
0C34	C540 5D80	1241 T6D2	CLHI R4,X'5D80'		PT112410
0C38	2034	1242	BNES T6R5		PT112420
0C3A	CD40 0008	1243	SLHL R4,8	SHIFT LEFT HW 8	PT112430
0C3E	2287	1244	BNCS T6R5		PT112440
0C40	C540 8000	1245	CLHI R4,X'8000'		PT112450
0C44	203A	1246	BNES T6R5		PT112460
0C46	C860 2369	1247 T6E	LHI R6,X'2369'		PT112470
0C4A	CC60 0001	1248	SRHL R6,1	SHIFT RIGHT HW 1	PT112480
0C4E	238D	1249	BNCS T6R6		PT112490
0C50	C560 11B4	1250	CLHI R6,X'11B4'		PT112500
0C54	213A	1251	BNES T6R6		PT112510
0C56	CC60 0002	1252	SRHL R6,2	SHIFT RIGHT HW 2	PT112520
0C5A	2187	1253	BCS T6R6		PT112530
0C5C	C560 0460	1254	CLHI R6,X'460'		PT112540
0C60	2194	1255	BNES T6R6		PT112550
0C62	CC60 0004	1256	SRHL R6,4	SHIFT RIGHT HW 4	PT112560
0C66	2183	1257	BCS T6E2		PT112570
0C68	4300 2182	1258 T6R6	B ERROR	ERROR 1603	PT112580
0C6C	C560 0046	1259 T6E2	CLHI R6,X'46'		PT112590

0C70	2034	1260	BNES	T6R6	PT112600
0C72	2478	1261	LIS	R7,8	PT112610
0C74	CC67 0000	1262	SRHL	R6,0(R7)	PT112620
0C78	2038	1263	BNZS	T6R6	PT112630
0C7A	0866	1264	LHR	R6,R6	PT112640
0C7C	203A	1265	BNZS	T6R6	PT112650
0C7E	2404	1266 T6F	LIS	R0,4	PT112660
0C80	D2U0 22F2	1267	STB	R0,ERRIND	PT112670
0C84	C860 496C	1268	LHI	R6,X'496C'	PT112680
0C88	CF60 0001	1269	SLHA	R6,1	PT112690
0C8C	238E	1270	BNCS	T6R7	PT112700
0C8E	C560 12D8	1271	CLHI	R6,X'12D8'	PT112710
0C92	2198	1272	BNES	T6R7	PT112720
0C94	CF60 0002	1273	SLHA	R6,2	PT112730
0C98	2188	1274	BCS	T6R7	PT112740
0C9A	C560 4860	1275	CLHI	R6,X'4860'	PT112750
0C9E	2135	1276	BNES	T6R7	PT112760
0CA0	9161	1277	SLLS	R6,1	PT112770
0CA2	CF60 0004	1278	SLHA	R6,4	PT112780
0CA6	2383	1279	BNCS	T6F3	PT112790
0CA8	4300 2182	1280 T6R7	B	ERROR	PT112800
0CAC	C560 EC00	1281 T6F3	CLHI	R6,X'EC00'	PT112810
0CB0	2034	1282	BNES	T6R7	PT112820
0CB2	C860 ECAA	1283	LHI	R6,X'ECAA'	PT112830
0CB6	CF60 0008	1284	SLHA	R6,8	PT112840
0CBA	2289	1285	BNCS	T6R7	PT112850
0CBC	C560 AA00	1286	CLHI	R6,X'AA00'	PT112860
0CCC	203C	1287	BNES	T6R7	PT112870
0CC2	C870 6729	1288 T6G	LHI	R7,X'6729'	PT112880
0CC6	CE70 0001	1289	SRHA	R7,1	PT112890
0CCA	238C	1290	BNCS	T6R8	PT112900
0CCC	232B	1291	BNPS	T6R8	PT112910
0CCE	C570 3394	1292	CLHI	R7,X'3394'	PT112920
0CD2	2138	1293	BNES	T6R8	PT112930
0CD4	CE70 0002	1294	SRHA	R7,2	PT112940
0CD8	2185	1295	BCS	T6R8	PT112950
0CDA	2324	1296	BNPS	T6R8	PT112960
0CDC	C570 0CE5	1297	CLHI	R7,X'CE5'	PT112970
0CE0	2333	1298	BES	T6G4	PT112980
0CE2	4300 2182	1299 T6R8	B	ERROR	PT112990
0CE6	C860 948A	1300 T6G4	LHI	R6,X'948A'	PT113000
0CEA	CE60 0004	1301	SRHA	R6,4	PT113010
0CEE	2286	1302	BNCS	T6R8	PT113020
0CF0	2027	1303	BPS	T6R8	PT113030
0CF2	C560 F948	1304	CLHI	R6,X'F948'	PT113040
0CF6	203A	1305	BNES	T6R8	PT113050
0CF8	CE60 0008	1306	SRHA	R6,8	PT113060
0CFc	2185	1307	BCS	T6R9	PT113070
0CFE	2124	1308 T6G8	BPS	T6R9	PT113080
0D00	C560 FFF9	1309	CLHI	R6,X'FFF9'	PT113090
0D04	2333	1310	BES	T6H	PT113100
0D06	4300 2182	1311 T6R9	B	ERROR	PT113110
0D0A	2405	1312 T6H	LIS	R0,5	PT113120
0D0C	D2U0 22F2	1313	STB	R0,ERRIND	PT113130
0D10	24U0	1314	LIS	R0,0	PT113140

0012	C300 0000	1315	THI R0,0	PT113150
0016	2139	1316	BNZS T6RA	PT113160
0018	0800	1317	LHR R0,R0	PT113170
001A	2137	1318	BNZS T6RA	PT113180
001C	2437	1319	LIS R3,7	PT113190
001E	C330 5555	1320	THI R3,X'5555'	PT113200
0022	2323	1321	BNPS T6RA	PT113210
0024	4310 0D2C	1322	BFC 1,T6H3	PT113220
0028	4300 2182	1323	T6RA B ERROR	PT113230
002C	C530 0007	1324	T6H3 CLHI R3,7	PT113240
0D30	2034	1325	BNES T6RA	PT113250
0032	2035	1326	BNES T6RA	PT113260
0D34	C880 8000	1327	LHI R8,X'8000'	PT113270
	0000 0D38	1328	THI EQU *	PT113280
0D38	C380 AAAA	1329	THI R8,X'AAAA'	PT113290
0D3C	4330 0D54	1330	BFC 3,T6GA	PT113300
0D40	9181	1331	SLLS R8,1	PT113310
0D42	2139	1332	BNZS T6GA	PT113320
0D44	C8A0 AAAA	1333	LHI R10,X'AAAA'	PT113330
0D48	C3A0 0000	1334	THI R10,0	PT113340
0D4C	2134	1335	BNZS T6GA	PT113350
0D4E	45A0 2302	1336	CLH R10,TEN	PT113360
0D52	2331	1337	BES T6GA	PT113370
	0000 0D54	1338	T6GA EQU *	PT113380
0D54	4300 0D58	1339	B T6END	PT113390
0D58	4300 0D5C	1340	T6END B TEST7	PT113400
		1341	*****	PT113410
		1342	*	PT113420
		1343	*	PT113430
		1344	*	PT113440
		1345	*	PT113450
		1346	*	PT113460
0D5C	C800 0E8A	1347	TEST7 LHI R0,TEST8	PT113470
0D60	4000 22F4	1348	STH R0,NXTST	PT113480
0D64	C800 0117	1349	LHI R0,X'0117'	PT113490
0D68	4000 22F2	1350	STH R0,ERRIND	PT113500
0D6C	C800 3137	1351	LHI R0,X'3137'	PT113510
0D70	4000 22B8	1352	STH R0,TESTNO	PT113520
		1353	*	PT113530
0D74	2501	1354	LCS R0,1	PT113540
0D76	4000 0616	1355	STH R0,T2WRD0	PT113550
0D7A	4000 061A	1356	STH R0,T2WRD1	PT113560
0D7E	4000 061E	1357	STH R0,T2WRD2	PT113570
0D82	0810	1358	LHR R1,R0	PT113580
0D84	0850	1359	LHR R5,R0	PT113590
0D86	08A0	1360	LHR R10,R0	PT113600
	0000 0D88	1361	LB EQU *	PT113610
0D88	D310 22FA	1362	LB R1,ONE	PT113620
0D8C	D350 22FE	1363	LB R5,FIVE	PT113630
0D90	D3A0 2302	1364	LB R10,TEN	PT113640
0D94	C510 0UFF	1365	CLHI R1,X'FF'	PT113650
0D98	21D0	1366	BNES T7R1	PT113660
0D9A	C550 0055	1367	CLHI R5,X'55'	PT113670
0D9E	213A	1368	BNES T7R1	PT113680
0DA0	C5A0 00AA	1369	CLHI R10,X'AA'	PT113690

TEST 7 CHECKS THE BYTE HANDLING INSTRUCTIONS

LB, STB, CLB, LBR, STBR, EXBR

ERRIND = 0117

T2WRD0 = FFFF  
T2WRD1 = FFFF  
T2WRD2 = FFFF  
R1 = R0 = FFFF  
R5 = R0 = FFFF  
R10 = R0 = FFFF

CHECK BYTES LOADED INTO  
R1  
R5  
R10

0DA4	2137	1370	BNES	T7R1	R10	PT113700
0DA6	D410 22FB	1371	CLB	R1,ONE+1	TEST CLB INSTRUCTION USING	PT113710
0DAA	2134	1372	BNES	T7R1	R1	PT113720
	0000 0DAC	1373	CLB	EQU *		PT113730
0DAC	D450 22FF	1374	CLB	R5,FIVE+1		PT113740
0DB0	2333	1375	BES	T7B	R5	PT113750
0DB2	4300 2182	1376	T7R1	B ERROR	ERROR 1701	PT113760
0DB6	D4A0 2302	1377	T7B	CLB R10,TEN	R10	PT113770
0DBA	2034	1378	BNES	T7R1		PT113780
0DBC	C870 0123	1379	LHI	R7,X'0123'	R7 = 0123	PT113790
0DC0	C880 4567	1380	LHI	R8,X'4567'	R8 = 4567	PT113800
0DC4	C890 89AB	1381	LHI	R9,X'89AB'	R9 = 89AB	PT113810
	0000 0DC8	1382	STB	EQU *		PT113820
0DC8	D270 0617	1383	STB	R7,T2WRD0+1	T2WRD0 = FF23	PT113830
0DCC	D280 061B	1384	STB	R8,T2WRD1+1	T2WRD1 = FF67	PT113840
0DD0	D290 061E	1385	STB	R9,T2WRD2	T2WRD2 = 89FF	PT113850
0DD4	4310 0E02	1386	BNM	T7R2		PT113860
0DD8	4800 0616	1387	LH	R0,T2WRD0	R0 = FF23	PT113870
0DDC	4810 061A	1388	LH	R1,T2WRD1	R1 = FF67	PT113880
0DE0	4820 061E	1389	LH	R2,T2WRD2	R8 = ABFF	PT113890
0DE4	C500 FF23	1390	CLHI	R0,X'FF23'		PT113900
0DE8	2130	1391	BNES	T7R2		PT113910
0DEA	C510 FF67	1392	CLHI	R1,X'FF67'		PT113920
0DEE	213A	1393	BNES	T7R2		PT113930
0DF0	C520 ABFF	1394	CLHI	R2,X'ABFF'		PT113940
0DF4	2197	1395	BNES	T7R2		PT113950
0DF6	D470 0617	1396	CLB	R7,T2WRD0+1	R7 = 0123, T2WRD0 = FF23	PT113960
0DFA	2134	1397	BNES	T7R2		PT113970
0DFC	D480 061B	1398	CLB	R8,T2WRD1+1	R8=4567, T2WRD1=FF67	PT113980
0E00	2333	1399	BES	T7C		PT113990
0E02	4300 2182	1400	T7R2	B ERROR	ERROR 1701	PT114000
0E06	D490 061E	1401	T7C	CLB R9,T2WRD2	R9=89AB, T2WRD2=ABFF	PT114010
0E0A	2034	1402	BNES	T7R2		PT114020
0E0C	D400 061A	1403	CLB	R0,T2WRD1	R0=FF238T2WRD1=FF67	PT114030
0E10	2237	1404	BES	T7R2		PT114040
0E12	D470 22F8	1405	CLB	R7,ZERO+2	R7=0123, ZERO=0000	PT114050
0E16	223A	1406	BES	T7R2		PT114060
0E18	24B0	1407	LIS	R11,0		PT114070
0E1A	D4B0 22FA	1408	CLB	R11,ONE		PT114080
0E1E	223E	1409	BES	T7R2		PT114090
		1410	*			PT114100
0E20	25B1	1411	LCS	R11,1	R11 = FFFF	PT114110
0E22	25C2	1412	LCS	R12,2	R12 = FFFE	PT114120
0E24	25D3	1413	LCS	R13,3	R13=FFFD	PT114130
	0000 0E26	1414	STBR	EQU *		PT114140
0E26	927B	1415	STBR	R7,R11		PT114150
0E28	928C	1416	STBR	R8,R12		PT114160
0E2A	929D	1417	STBR	R9,R13		PT114170
0E2C	C5B0 FF23	1418	CLHI	R11,X'FF23'		PT114180
0E30	213E	1419	BNES	T7R3		PT114190
0E32	C5C0 FF67	1420	CLHI	R12,X'FF67'		PT114200
0E36	213B	1421	BNES	T7R3		PT114210
0E38	C5D0 FFAB	1422	CLHI	R13,X'FFAB'		PT114220
0E3C	2138	1423	BNES	T7R3		PT114230
	0000 0E3E	1424	LBR	EQU *		PT114240

OE3E	93B1	1425	LBR	R11,R1	R1=FF678 R11=FF23	PT114250
OE40	93C0	1426	LBR	R12,R0	R0=FF23, R12=FF67	PT114260
OE42	93D2	1427	LBR	R13,R2	R2=ABFF, R13=FFAB	PT114270
OE44	2134	1428	BNZS	T7R3		PT114280
OE46	C5B0 0067	1429	CLHI	R11,X'0067'		PT114290
OE4A	2333	1430	BES	T7E		PT114300
OE4C	4300 2182	1431	T7R3	B	ERROR	PT114310
OE50	C5C0 0023	1432	T7E	CLHI	R12,X'0023'	PT114320
OE54	2034	1433	BNES	T7R3		PT114330
OE56	C5D0 00FF	1434	CLHI	R13,X'00FF'		PT114340
OE5A	2037	1435	BNES	T7R3		PT114350
		1436	*			PT114360
	0000 0E5C	1437	EXBR	EQU *		PT114370
OE5C	9478	1438	EXBR	R7,R8	R7=0123, R8=4567	PT114380
		1439	*		R7 = 6745 , R8 = 4567	PT114390
OE5E	C5F0 6745	1440	CLHI	R7,X'6745'		PT114400
OE62	203B	1441	BNES	T7R3		PT114410
OE64	C5B0 4567	1442	CLHI	R8,X'4567'		PT114420
OE68	203E	1443	BNES	T7R3		PT114430
OE6A	9489	1444	EXBR	R8,K9	R8 = AB89 , R9 = 89AB	PT114440
OE6C	213B	1445	BNES	T7R4		PT114450
OE6E	C5B0 AB89	1446	CLHI	R8,X'AB89'		PT114460
OE72	9499	1447	EXBR	R9,R9	R9 = AB89	PT114470
OE74	9488	1448	EXBR	R8,R8	R8 = 89AB	PT114480
OE76	C5B0 89AB	1449	CLHI	R8,X'89AB'		PT114490
OE7A	2134	1450	BNES	T7R4		PT114500
OE7C	C5B0 AB89	1451	CLHI	R9,X'AB89'		PT114510
OE80	2333	1452	BES	T7END		PT114520
OE82	4300 2182	1453	T7R4	B	ERROR	PT114530
OE86	4300 0E8A	1454	T7END	B	TEST8	PT114540
		1455	*****			
		1456	*			PT114550
		1457	*	TEST8 CHECKS THE INSTRUCTIONS		PT114560
		1458	*			PT114570
		1459	*	AH , AHR , AHI , AHM , AIS , ACH , ACHI		PT114580
		1460	*			PT114590
		1461	*	SH , SHR , SHI , SIS , SCH , SCHI		PT114600
		1462	*			PT114610
		1463	*			PT114620
		1464	*	TEST8 CHECKS THE FIXED POINT ADD,SUBTRACT,AND COMPARE INSTRUCTIONS		PT114630
		1465	*			PT114640
		1466	*			PT114650
	0000 000F	1467	TOT	EQU 15		PT114660
		1468	*			PT114670
OE8A	C800 12C4	1469	TEST8	LHI R0,TEST9		PT114680
OE8E	4000 22F4	1470	STH	R0,NXTST		PT114690
OE92	C800 0118	1471	LHI	R0,X'0118'		PT114700
OE96	4000 22F2	1472	STH	R0,ERRIND		PT114710
OE9A	C800 3138	1473	LHI	R0,C'18'		PT114720
OE9E	4000 22B8	1474	STH	R0,TESTNO		PT114730
OEAA	24F1	1475	LIS	TOT+1	SET ERROR NUMBER=1	PT114740
OE44	2445	1476	LIS	R4,S	SET INDEX OFFSET=5	PT114750
OE46	0700	1477	XHR	R0,R0	CARRY IN=0	PT114760
OE48	0711	1478	XHR	R1,R1	INITIAL M=0	PT114770
OEAA	0722	1479	XHR	R2,R2	INITIAL N=0	PT114780
						PT114790

0EAC	C8A0 0101	1480	LHI	R10,X'0101'	INCREMENT=X'0101'	PT114800
0EB0	4180 0EE2	1481	BAL	R8,TEST85	CHECK FOR ALL COMBINATIONS OF M AND N	PT114810
0EB4	2408	1482	LIS	R0,8	CARRYIN=1	PT114820
0EB6	C810 0040	1483	LHI	R1,X'0040'	INITIAL M	PT114830
0EBA	C820 00C0	1484	LHI	R2,X'00C0'	INITIAL N	PT114840
0E8E	4180 0EE2	1485	BAL	R8,TEST85	CHECK FOR ALL COMBINATION OF M AND N	PT114850
0EC2	0700	1486	XHR	R0,R0	CARRY IN=0	PT114860
0EC4	0711	1487	XHR	R1,R1	INITIAL M=0	PT114870
0EC6	0722	1488	XHR	R2,R2	INITIAL N=0	PT114880
0EC8	C8A0 1010	1489	LHI	R10,X'1010'	INCREMENT=X'1010'	PT114890
0ECC	4180 0EE2	1490	BAL	R8,TEST85	CHECK FOR ALL COMBINATIONS OF M AND N	PT114900
0ED0	2408	1491	LIS	R0,8	CARRY IN = 1	PT114910
0ED2	C810 0404	1492	LHI	R1,X'0404'	INITIAL M	PT114920
0ED6	C820 0C0C	1493	LHI	R2,X'0C0C'	INITIAL N	PT114930
0EDA	4180 0EE2	1494	BAL	R8,TEST85	CHECK FOR ALL COMBINATIONS OF M AND N	PT114940
0EDE	4300 0F04	1495	B	OTEST	GO TO NEXT PART OF TEST	PT114950
0EE2	4010 12C2	1496	TEST85	STH R1,INITM	SAVE INITIAL M	PT114960
0EE6	24CF	1497	LIS	R12,15	COUNTER 1	PT114970
0EE8	24EF	1498	LIS	R14,15	COUNTER 2	PT114980
0EEA	4190 11B8	1499	LOOP85	BAL R9,TEST83	INCREMENT M	PT114990
0EEE	0A1A	1500	AHR	R1,R10	DECREMENT COUNTER 1	PT115000
0EF0	27C1	1501	SIS	R12,1	LOOP IF COUNT IS NONNEGATIVE	PT115010
0EF2	2214	1502	BNMS	LOOP85	INITIALIZE M	PT115020
0EF4	4810 12C2	1503	LH	R1,INITM	INITIALIZE COUNTER 1	PT115030
0EF8	24CF	1504	LIS	R12,15	INCREMENT N	PT115040
0EFA	0A2A	1505	AHR	R2,R10	DECREMENT COUNTER 2	PT115050
0EFC	27E1	1506	SIS	R14,1	LOOP IF COUNT IS NON-NEGATIVE	PT115060
0EFE	4310 0EEA	1507	BNM	LOOP85	EXPECTED CC=0	PT115070
0F02	0308	1508	BR	R8	(R0)=0	PT115080
0F04	07CC	1509	OTEST	XHR R12,R12	(R3)=X'7FFE'	PT115090
0F06	0700	1510	XHR	R0,R0	(R8)=X'FFFF'	PT115100
0F08	4830 12A6	1511	LH	R3,CD3	SET ERROR NUMBER=6	PT115110
0F0C	4880 12B0	1512	LH	R8,CD8	PT115120	
0F10	24F6	1513	LIS	TOT,6	PT115130	
0F12	2600	1514	AIS	R0,0	PT115140	
0F14	4190 11A6	1515	BAL	R9,TESTCC	PT115150	
0F18	0800	1516	*	ERROR NUMBER=7	PT115160	
0F1A	4190 11A6	1517	SHR	R0,R0	PT115170	
0F1E	C830 7FFE	1518	BAL	R9,TESTCC	PT115180	
0F22	4190 11A6	1519	*	ERROR NUMBER=8	PT115190	
0F26	4880 12B0	1520	SHI	R3,X'7FFE'	PT115200	
0F2A	4190 11A6	1521	BAL	R9,TESTCC	PT115210	
0F2E	24C1	1522	*	ERROR NUMBER=9	PT115220	
0F30	4850 12AA	1523	SH	R8,CD8	PT115230	
0F34	4860 12AC	1524	BAL	R9,TESTCC	PT115240	
0000	0F38	1525	*	ERROR NUMBER=X'A'	PT115250	
0F38	4A50 12A6	1526	LIS	R12,1	EXPECTED CC=1	PT115260
0F3C	4190 11A6	1527	LH	R5,CD5	(R5)=X'8001'	PT115270
0F40	2761	1528	LH	R6,CD6	(R6)=X'8002'	PT115280
0F42	4190 11A6	1529	AH	EQU *	PT115290	
		1530	AH	R5,CD3	'8001'+7FFE'	PT115300
		1531	BAL	R9,TESTCC	PT115310	
		1532	SIS	R6,1	PT115320	
		1533	BAL	R9,TESTCC	PT115330	
		1534	*	ERROR NUMBER=X'C'	PT115340	

0F46	24L2	1535	LIS	R12,2	EXPECTED CC=2	PT115350
0F48	4830 12A6	1536	LH	R3,C03	(R3)='7FFE'	PT115360
0F4C	4840 12A8	1537	LH	R4,C04	(R4)='7FFF'	PT115370
0F50	4880 12B0	1538	LH	R8,C08	(R8)='FFFF'	PT115380
0F54	2631	1539	AIS	R3,1	'7FFE'+1='7FFF'	PT115390
0F56	4190 11A6	1540	BAL	R9,TESTCC		PT115400
	0000 0F5A	1541	SHI	EQU *		PT115410
0F5A	CB40 7FFE	1542	SHI	R4,X'7FFE'	'7FFF'-'7FFE'	PT115420
0F5E	4190 11A6	1543	BAL	R9,TESTCC		PT115430
	0000 0F62	1544	*	ERROR NUMBER=x'E'		PT115440
0F62	4880 12AE	1545	SH	EQU *		PT115450
0F66	4190 11A6	1546	SH	R8,C07	'FFFF'-'FFFE'	PT115460
0F6A	C8C0 0005	1547	BAL	R9,TESTCC		PT115470
0F6E	4840 12A8	1548	LHI	R12,5	EXPECTED CC=5	PT115480
0F72	4A40 12A6	1549	LH	R4,C04	(R4)='7FFF'	PT115490
0F76	4190 11A6	1550	AH	R4,C03	'7FFE'+ '7FFF'	PT115500
	0000 0F62	1551	BAL	R9,TESTCC		PT115510
0F7A	24C6	1552	*	ERROR NUMBER=x'10'		PT115520
0F7C	4850 12AA	1553	LIS	R12,6	EXPECTED CC=6	PT115530
0F80	CB50 7FFF	1554	LH	R5,C05	(R5)='8001'	PT115540
0F84	4190 11A6	1555	SHI	R5,X'7FFF'	'8001'-'7FFF'	PT115550
0F88	24C8	1556	BAL	R9,TESTCC		PT115560
0F8A	4810 12A2	1557	LIS	R12,8	EXPECTED CC=8	PT115570
0F8E	4840 12A8	1558	LH	R1,C01	(R1)=1	PT115580
0F92	4880 12B0	1559	LH	R4,C04	(R4)=X'7FFF'	PT115590
	0000 0F96	1560	LH	R8,C08	(R8)='FFFF'	PT115600
0F96	CA40 8001	1561	AHI	EQU *		PT115610
0F9A	4190 11A6	1562	AHI	R4,X'8001'		PT115620
	0000 0F9E	1563	BAL	R9,TESTCC		PT115630
0F9E	0A18	1564	AHR	EQU *		PT115640
0FA0	4190 11A6	1565	AHR	R1,R8	X'0001' + X'FFFF'	PT115650
0FA4	24C9	1566	BAL	R9,TESTCC		PT115660
0FA6	4850 12A6	1567	LIS	R12,9	EXPECTED CC=9	PT115670
0FAA	4870 12AE	1568	LH	R3,C03	(R3)=X'7FFE'	PT115680
0FAE	4880 12B0	1569	LH	R7,C07	(R7)=X'FFFE'	PT115690
0FB2	0A87	1570	LH	R8,C08	(R8)=X'FFFF'	PT115700
0FB4	4190 11A6	1571	AHR	R8,R7	'FFFF'+ 'FFFE'	PT115710
	0000 0FB8	1572	BAL	R9,TESTCC		PT115720
0FB8	2701	1573	*	ERROR NUMBER=x'14'		PT115730
	0FB8	1574	SIS	EQU *		PT115740
0FB8	4190 11A6	1575	SIS	R0,1	0-1	PT115750
0FBE	CB70 FFFF	1576	BAL	R9,TESTCC		PT115760
0FC2	4190 11A6	1577	SHI	R7,X'FFFF'	'FFFE'-'FFFF'	PT115770
0FC6	4830 12A8	1578	BAL	R9,TESTCC		PT115780
0FCA	4190 11A6	1579	SH	R3,C04	'7FFE'-'7FFF'	PT115790
0FCE	24CA	1580	BAL	R9,TESTCC		PT115800
0FD0	0700	1581	LIS	R12,X'A'	EXPECTED CC= 'A'	PT115810
0FD2	4830 12A6	1582	XHR	R0,R0	(R0)=0	PT115820
0FD6	4860 12AC	1583	LH	R3,C03	(R3)=X'7FFE'	PT115830
0FDA	4880 12B0	1584	LH	R6,C06	(R6)='8002'	PT115840
	0000 0FDE	1585	LH	R8,C08	(R8)='FFFF'	PT115850
0FDE	2682	1586	AIS	EQU *		PT115860
0FEO	4190 11A6	1587	AIS	R8,2	'FFFF'+2	PT115870
	0000 0FDE	1588	BAL	R9,TESTCC		PT115880
0FEO	4190 11A6	1589	*	ERROR NUMBER=x'18'		PT115890

0FE4	CB00 FFFF	1590	SHI R0,X'FFFF'	0-'FFFF'	PT115900
0FE8	4190 11A6	1591	BAL R9,TESTCC	'7FFE'-'FFFF'	PT115910
0FEC	4B30 12B0	1592	SH R3,C08	'7FFE'-'FFFF'	PT115920
0FF0	4190 11A6	1593	BAL R9,TESTCC	'8002' + '7FFF' = '0001'	PT115930
0FF4	CA60 7FFF	1594	AHI R6,X'7FFF'	'8002' + '7FFF' = '0001'	PT115940
0FF8	4190 11A6	1595	BAL R9,TESTCC	'7FFF'-'FFFF'	PT115950
0FC	24CD	1596	LIS R12,X'0'	EXPECTED CC='0'	PT115960
0FFE	4840 12A8	1597	LH R4,C04	(R4)='7FFF'	PT115970
1002	4820 12A4	1598	LH R2,C02	(R2)=2	PT115980
1006	4840 12AE	1599	SH R4,C07	'7FFF'-'FFFF'	PT115990
100A	4190 11A6	1600	BAL R9,TESTCC		PT116000
		1601 *	ERROR NUMBER=X'1C'		PT116010
100E	CB20 8001	1602	SHI R2,X'8001'	2-'8001'	PT116020
1012	4190 11A6	1603	BAL R9,TESTCC		PT116030
		1604 *	ERROR NUMBER=X'1D'		PT116040
1016	C8C0 000E	1605	LHI R12,X'E'	EXPECTED CC = 'E'	PT116050
101A	4850 12AA	1606	LH R5,C05	(R5)='8001'	PT116060
101E	CA50 FFFE	1607	AHI R5,X'FFFE'	'8001'+'FFFE'	PT116070
1022	4190 11A6	1608	BAL R9,TESTCC		PT116080
		1609 *	ERROR NUMBER=X'1E'		PT116090
		1610 *	MULTIPLE PRECISION ADD	SUBTRACT CHECK	PT116100
1026	0700	1611	XHR R0,R0	(R0) = 0 FIRST WORD OF RESULT	PT116110
1028	0711	1612	XHR R1,R1	(R1) = 0 SECOND WORD OF RESULT	PT116120
102A	0722	1613	XHR R2,R2	(R2) = 0 THIRD WORD OF RESULT	PT116130
102C	0733	1614	XHR R3,R3	(R3) = 0 FIRST WORD OF INCREMENT	PT116140
102E	0744	1615	XHR R4,R4	(R4) = 0 SECOND WORD OF ENCREMENT	PT116150
1030	C850 1110	1616	LHI R5,X'1110'	(R5) = '1110' MSB OF FINAL VALUE OF IN	PT116160
1034	C860 EEEF	1617	LHI R6,X'EEEF'	(R6) = 'EEEF' LSB OF FINAL VALUE OF INC	PT116170
1038	C870 0888	1618	LHI R7,X'0888'	FIRST WORD OF EXPECTED RESULT	PT116180
103C	C880 7777	1619	LHI R8,X'7777'	SECOND WORD OF EXPECTED RESULT	PT116190
1040	C890 8000	1620	LHI R9,X'8000'	THIRD WORD OF EXPECTED RESULT	PT116200
1044	4A40 12B4	1621	LOOP1 AH R4,ININC2	INCREMENT THE INCREMENT BY '00001111	PT116210
	0000 1048	1622	ACH	EQU *	PT116220
1048	4E90 12B2	1623	ACH R3,ININC1		PT116230
104C	0A24	1624	AHR R2,R4	ADD THE INCREMENT TO TRIPLE	PT116240
104E	0E13	1625	ACHR R1,R3	PRECISION RESULT	PT116250
1050	4E00 22F6	1626	ACH R0,ZERO		PT116260
1054	08D5	1627	LHR R13,R5		PT116270
1056	08E6	1628	LHR R14,R6		PT116280
1058	08E4	1629	SHR R14,R4		PT116290
105A	4230 1044	1630	BNZ LOOP1		PT116300
	0000 105E	1631	SHR EQU *		PT116310
105E	0BD3	1632	SHR R13,R3		PT116320
1060	4230 1044	1633	BNZ LOOP1		PT116330
1064	0592	1634	CLHR R9,R2	COMPARE TRIPLE	PT116340
1066	4230 127C	1635	BNE ERR13	PRECISION CALCULATED	PT116350
106A	0581	1636	CLHR R8,R1	AND EXPECTED	PT116360
106C	4230 127C	1637	BNE ERR13		PT116370
1070	0570	1638	CLHR R7,R0	RESULTS	PT116380
1072	4230 127C	1639	BNE ERR13		PT116390
1076	26F1	1640	AIS TOT+1	INCR. ERROR NUMBER BY 1	PT116400
		1641 *	ERROR NUMBER=X'1F'		PT116410
1078	0B24	1642	LOOP2 SHR R2,R4	SUBTRACT THE DECREMENT FROM	PT116420
107A	0F13	1643	SCHR R1,R3	TRIPLE PRECISION RESULT	PT116430
	0000 107C	1644	SCH EQU *		PT116440

107C	4F00 22F6	1645	SCH	R0,ZERO		PT116450
1080	4B40 1284	1646	SH	R4,ININC2	DECR. THE DECREMENT BY '00001111'	PT116460
1084	4F30 1282	1647	SCH	R3,ININC1		PT116470
1088	0844	1648	LHR	R4,R4		PT116480
108A	4230 1078	1649	BNZ	LOOP2		PT116490
108E	0833	1650	LHR	R3,R3		PT116500
1090	4230 1078	1651	BNZ	LOOP2		PT116510
1094	0822	1652	LHR	R2,R2		PT116520
1096	4230 127C	1653	BNZ	ERR13		PT116530
109A	0811	1654	LHR	R1,R1		PT116540
109C	4230 127C	1655	BNZ	ERR13		PT116550
10A0	0800	1656	LHR	R0,R0		PT116560
10A2	4230 127C	1657	BNZ	ERR13		PT116570
		1658 *	FIXED POINT	COMPARE CHECK		PT116580
10A6	26F1	1659	AIS	TOT,1	ERROR NUMBER=X'20'	PT116590
10A8	2475	1660	LIS	R7,5	SET INDEX OFFSET=5	PT116600
10AA	4800 22F6	1661	LH	R0,ZERO	(R0)= 0	PT116610
10AE	4810 12A2	1662	LH	R1,CD1	(R1) = 1	PT116620
10B2	4820 12A8	1663	LH	R2,CD4	(R2) = '7FFF'	PT116630
10B6	4830 12AA	1664	LH	R3,CD5	(R3) = '8001'	PT116640
10BA	4840 12AE	1665	LH	R4,CD7	(R4) = 'FFFE'	PT116650
10BE	4850 12B0	1666	LH	R5,CD8	(R5) = 'FFFF'	PT116660
10C2	08C0	1667	LHR	R12,R0	EXPECTED CC = 0	PT116670
10C4	0500	1668	CLHR	R0,R0		PT116680
10C6	4190 11A6	1669	BAL	R9,TESTCC		PT116690
10CA	4517 1290	1670	CLH	R1,CD1-5(R7)		PT116700
10CE	4190 11A6	1671	BAL	R9,TESTCC		PT116710
		1672 *	ERROR NUMBER=X'22'			PT116720
10D2	C520 7FFF	1673	CLHI	R2,X'7FFF'		PT116730
10D6	4190 11A6	1674	BAL	R9,TESTCC		PT116740
10DA	0933	1675	CHR	R3,R3		PT116750
10DC	4190 11A6	1676	BAL	R9,TESTCC		PT116760
		1677 *	ERROR NUMBER=X'24'			PT116770
10E0	4940 12AE	1678	CH	R4,CD7		PT116780
10E4	4190 11A6	1679	BAL	R9,TESTCC		PT116790
10E8	C950 FFFF	1680	CHI	R5,X'FFFF'		PT116800
10EC	4190 11A6	1681	BAL	R9,TESTCC		PT116810
		1682 *	ERROR NUMBER=X'26'			PT116820
10F0	24C1	1683	LIS	R12,1	EXPECTED CC=1	PT116830
10F2	4810 12AC	1684	LH	R1,CD6	(R1) ='8002'	PT116840
10F6	4820 12A2	1685	LH	R2,CD1	(R2) = '0001'	PT116850
10FA	0512	1686	CLHR	R1,R2		PT116860
10FC	4190 11A6	1687	BAL	R9,TESTCC		PT116870
1100	C8C0 0002	1688	LHI	R12,2	EXPECTED CC=2	PT116880
1104	4810 12A8	1689	LH	R1,CD4	(R1)='7FFF'	PT116890
1108	4510 12A6	1690	CLH	R1,CD3	COMPARE WITH '7FFE'	PT116900
110C	4190 11A6	1691	BAL	R9,TESTCC	CHECK CC	PT116910
		1692 *	ERROR NUMBER X'28'			PT116920
1110	4810 12AC	1693	LH	R1,CD6	(R1)='8002'	PT116930
1114	C510 8001	1694	CLHI	R1,X'8001'		PT116940
1118	4190 11A6	1695	BAL	R9,TESTCC		PT116950
111C	4820 12B0	1696	LH	R2,CD8	(R2)= X'FFFF'	PT116960
1120	4800 22F6	1697	LH	R0,ZERO	(R0) = 0	PT116970
1124	4810 12A2	1698	LH	R1,CD1	(R1)=1	PT116980
1128	0910	1699	CHR	R1,R0		PT116990

112A	4190 11A6	1700	BAL R9,TESTCC		PT117000
		1701 *	ERROR NUMBER=X'2A'		PT117010
112E	4927 12A9	1702	CH R2,CD7-5(R7)	COMPARE 'FFFF' AND 'FFFE'	PT117020
1132	4190 11A6	1703	BAL R9,TESTCC		PT117030
1136	C900 8001	1704	CHI R0,X'8001'	COMPARE 0 AND '8001'	PT117040
113A	4190 11A6	1705	BAL R9,TESTCC		PT117050
		1706 *	ERROR NUMBER=X'2C'		PT117060
113E	24C6	1707	LIS R12,6	EXPECTED CC=6	PT117070
1140	4810 12AA	1708	LH R1,CD5	(R1) = '8001'	PT117080
1144	4510 12A4	1709	CLH R1,CD2	COMPARE '8001' AND '0002'	PT117090
1148	4190 11A6	1710	BAL R9,TESTCC		PT117100
114C	24C9	1711	LIS R12,9	EXPECTED CC=9	PT117110
114E	4800 22F6	1712	LH R0,ZERO	(R0)=0	PT117120
1152	4810 12AE	1713	LH R1,CD7	(R1)='FFFF'	PT117130
1156	4820 12B0	1714	LH R2,CD8	(R2)='FFFF'	PT117140
115A	4830 12AA	1715	LH R3,CD5	(R3)='8001'	PT117150
115E	0512	1716	CLHR R1,R2		PT117160
1160	4190 11A6	1717	BAL R9,TESTCC		PT117170
		1718 *	ERROR NUMBER=X'2E'	COMPARE 0 AND 1	PT117180
1164	C500 0001	1719	CLHI R0,1		PT117190
1168	4190 11A6	1720	BAL R9,TESTCC		PT117200
116C	C900 0001	1721	CHI R0,1		PT117210
1170	4190 11A6	1722	BAL R9,TESTCC		PT117220
		1723 *	ERROR NUMBER=X'30'		PT117230
1174	4930 12AC	1724	CH R3,CD6	COMPARE '8001' AND '8002'	PT117240
1178	4190 11A6	1725	BAL R9,TESTCC		PT117250
117C	0920	1726	CHR R2,R0	COMPARE 'FFFF' AND 0	PT117260
117E	4190 11A6	1727	BAL R9,TESTCC		PT117270
		1728 *	ERROR NUMBER=X'32'		PT117280
1182	C8C0 000A	1729	LHI R12,X'A'	EXPECTED CC=X'A'	PT117290
1186	4810 12A6	1730	LH R1,CD3	(R1) = '7FFE'	PT117300
118A	4820 12A8	1731	LH R2,CD4	(R2) = '7FFF'	PT117310
118E	4510 12B0	1732	CLH R1,CD8	COMPARE '7FFE' AND 'FFFF'	PT117320
1192	4190 11A6	1733	BAL R9,TESTCC		PT117330
1196	C8C0 000D	1734	LHI R12,X'D'	EXPECTED CC=X'D'	PT117340
119A	C520 FFFE	1735	CLHI R2,X'FFFE'	COMPARE '7FFF' AND 'FFFF'	PT117350
119E	4190 11A6	1736	BAL R9,TESTCC		PT117360
		1737 *	ERROR NUMBER=X'34'		PT117370
11A2	4300 12C4	1738 T8END	B TEST9		PT117380
		1739 *	SUBROUTINES USED IN TEST8		PT117390
11A6	95EE	1740 TESTCC	EPSR R14,R14	OBTAIN CC FROM CURRENT PSW	PT117400
11A8	C4E0 000F	1741	NHI R14,X'F'		PT117410
11AC	05EC	1742	CLHR R14,R12		PT117420
11AE	4230 1288	1743	BNE ERR14		PT117430
11B2	26F1	1744	AIS TOT.1		PT117440
11B4	4309 0000	1745	B 0(R9)	RETURN	PT117450
		1746 *	RO CONTAINS 1 IF CARRY-IN IS 1		PT117460
		1747 *	RO CONTAINS 0 IF CARRY-IN IS ZERO		PT117470
		1748 *	R1 AND R2 CONTAINS VALUES OF M AND N		PT117480
	0000 11B8	1749 AHM	EQU *		PT117490
11B8	24F1	1750 TEST83	LIS TOT.1	SET ERROR NUMBER=1	PT117500
11B8	4010 12B8	1751	STH R1,PLUSM	STORE M	PT117510
11B8	4020 12BA	1752	STH R2,PLUSN	STORE N	PT117520
11C2	0831	1753	LHR R3,R1	M	PT117530
11C4	C730 FFFF	1754	XHI R3,X'FFFF'		PT117540

11C8	2631	1755	AIS	R3,1	GET - M	PT117550
11CA	4030 1286	1756	STH	R3,MINUSM	STORE-M	PT117560
11CE	6114 1281	1757	AHM	R1,MINUSM-5(R4)	M+(-M)=0	PT117570
11D2	4200 0000	1758	NOP			PT117580
11D6	4850 1286	1759	LH	R5,MINUSM	GET M+(-M)	PT117590
11DA	4230 1258	1760	BNZ	ERR11		PT117600
11DE	24F2	1761	LIS	TOT,2	SET ERROR NUMBER=2	PT117610
11E0	0831	1762	LHR	R3,R1	M	PT117620
11E2	0A34	1763	AHR	R3,R4	M+(R4)=M+5	PT117630
11E4	0853	1764	LHR	R5,R3		PT117640
11E6	0854	1765	SHR	R5,R4	M+(R4)-(R4)=M?	PT117650
11E8	0551	1766	CLHR	R5,R1		PT117660
11EA	4230 1258	1767	BNE	ERR11		PT117670
11EE	24F3	1768	LIS	TOT,3	SET ERROR NUMBER =3	PT117680
11F0	0831	1769	LHR	R3,R1	M	PT117690
11F2	CA30 789A	1770	AHI	R3,X'789A'	M+X'789A'	PT117700
11F6	0853	1771	LHR	R5,R3		PT117710
11F8	CB50 789A	1772	SHI	R5,X'789A'		PT117720
11FC	0551	1773	CLHR	R5,R1		PT117730
11FE	4230 1258	1774	BNE	ERR11		PT117740
1202	24F4	1775	LIS	TOT,4	SET ERROR NUMBER=4	PT117750
1204	0851	1776	LHR	R5,R1	M	PT117760
1206	95D0	1777	EPSR	R13,R0	SET CARRY FLAG IF CARRY IN	PT117770
1208	4E54 1285	1778	ACH	R5,PLUSN-5(R4)	M+N+C	PT117780
120C	4050 12BC	1779	STH	R5,MPNPC	STORE M+N+C	PT117790
1210	4850 1288	1780	LH	R5,PLUSM	M	PT117800
1214	0800	1781	LHR	R0,R0	EXAMINE CARRY IN	PT117810
1216	4330 121C	1782	BZ	NCRY1	IF NO CARRY IN GOTO NCRY1	PT117820
121A	2751	1783	SIS	R5,1		PT117830
121C	4B54 1285	1784	NCRY1	SH	R5,PLUSN-5(R4)	PT117840
1220	40D0 128E	1785	STH	R5,MMNMC	STORE M-N-C	PT117850
1224	4A54 1287	1786	AH	R5,MPNPC-5(R4)	GET (M+N+C)+(M-N-C)=2M	PT117860
1228	0871	1787	LHR	R7,R1	M	PT117870
122A	CD70 0001	1788	SLHL	R7,1	GET 2*M	PT117880
122E	0557	1789	CLHR	R5,R7	IF (M+N+C)+(M-N-C) IS NOT=2*M	PT117890
1230	4230 1264	1790	BNE	ERR12	BRANCH TO ERR1	PT117900
1234	24F5	1791	LIS	TOT,5	SET ERROR NUMBER=5	PT117910
1236	4850 12BC	1792	LH	R5,MPNPC	M+N+C	PT117920
123A	95D0	1793	EPSR	R13,R0		PT117930
123C	4F54 1289	1794	SCH	R5,MMNMC-5(R4)	(M+N+C)-(M-N-C)-C =2N+C	PT117940
1240	4870 12BA	1795	LH	R7,PLUSN	N	PT117950
1244	CD70 0001	1796	SLHL	R7,1	2*N	PT117960
1248	0800	1797	LHR	R0,R0	EXAMINE IF CARRY IN HAS	PT117970
124A	4330 1250	1798	BZ	NOCRY	BEEN SPECIFIED	PT117980
124E	2671	1799	AIS	R7,1	2*N+C	PT117990
1250	0557	1800	NCRY	CLHR	IF (M+N+C)-(M-N-C)-C	PT118000
1252	42D0 1264	1801	BNE	ERR12	IS NOT=2*N+C,BRANCH TO ERR1	PT118010
1256	0309	1802	BR	R9	RETURN	PT118020
1258	2443	1803	ERR11	LIS	THREE VALUES FOR PRINT OUT	PT118030
125A	0875	1804	LHR	R7,R5	ACTUAL RESULT	PT118040
125C	0853	1805	LHR	R6,R3	-M OR M+(R4)OR M+X'789A'	PT118050
125E	0851	1806	LHR	R5,R1	VALUE OF M	PT118060
1260	43D0 1292	1807	B	ERR1		PT118070
1264	2447	1808	ERR12	LIS	SEVEN VALUES ARE TO BE PRINTED	PT118080
1266	0845	1809	LHR	R10+R5	ACTUAL RESULT	PT118090

1268	0887	1810	LHR	R11,R7	EXPECTED RESULT	PT118100
126A	0851	1811	LHR	R5,R1	M	PT118110
126C	0862	1812	LHR	R6,R2	N	PT118120
126E	0870	1813	LHR	R7,R0	CARRY IN	PT118130
1270	4880 12BC	1814	LH	R8,MPNPC	M+N+C	PT118140
1274	4890 12BE	1815	LH	R9,MMNMC	M-N-C	PT118150
1278	4300 1292	1816	B	ERR1		PT118160
127C	2443	1817	ERR13	LIS R4,3	THREE VALUES TO BE PRINTED	PT118170
127E	0850	1818	LHR	R5,R0	ACTUAL	PT118180
1280	0861	1819	LHR	R6,R1	TRIPAL PRECISION	PT118190
1282	0872	1820	LHR	R7,R2	RESULT	PT118200
1284	4300 1292	1821	B	ERR1		PT118210
1288	2442	1822	ERR14	LIS R4,2	TWO VALUES TO BE PRINTED	PT118220
128A	085E	1823	LHR	R5,R14	ACTUAL CONDITION CODE	PT118230
128C	086C	1824	LHR	R6,R12	EXPECTED CONDITION CODE	PT118240
128E	4300 1292	1825	B	ERR1		PT118250
1292	C800 0018	1826	ERR1	LHI R0,X'0018'		PT118260
1296	91F8	1827	SLLS	TOT,8		PT118270
1298	060F	1828	OHR	R0,TOT		PT118280
129A	4000 22F2	1829	STH	R0,ERRIND		PT118290
129E	4300 2182	1830	B	ERROR		PT118300
		1831	*	DATA OF TEST 8		PT118310
12A2	00U1	1832	CD1	DC 1		PT118320
12A4	0002	1833	CD2	DC 2		PT118330
12A6	7FFE	1834	CD3	DC X'7FFE'		PT118340
12A8	7FFF	1835	CD4	DC X'7FFF'		PT118350
12AA	8001	1836	CD5	DC X'8001'		PT118360
12AC	8002	1837	CD6	DC X'8002'		PT118370
12AE	FFFE	1838	CD7	DC X'FFFE'		PT118380
12B0	FFFF	1839	CD8	DC X'FFFF'		PT118390
12B2	0000	1840	ININC1	DC 0		PT118400
12B4	1111	1841	ININC2	DC X'1111'		PT118410
12B6		1842	MINUSM	DS 2		PT118420
12B8		1843	PLUSM	DS 2		PT118430
12BA		1844	PLUSN	DS 2		PT118440
12BC		1845	MPNPC	DS 2		PT118450
12BE		1846	MMNMC	DS 2		PT118460
12C0		1847	MMMNMC	DS 2		PT118470
12C2		1848	INITM	DS 2		PT118480
		1849	*			PT118490
		1850	*	*****		PT118500
		1851	*			PT118510
		1852	*	TEST 9 CHECKS THE INSTRUCTIONS		PT118520
		1853	*			PT118530
		1854	*	SINT AND ILLG. INSTR. INTRPR.		PT118540
		1855	*			PT118550
		1856	*	T90INT=ADD. FOR INTERRUPT		PT118560
		1857	*			PT118570
		1858	*	T90SNT=ADD. SIMULATE INTERRUPT		PT118580
		1859	*			PT118590
		1860	*	OLDPSW=ADD. OF INSTR. AFTER T90SNT		PT118600
		1861	*			PT118610
		1862	*	T90DEV=DEV. NO. 0 THRU 255 OF THE INTRPT. DEV.		PT118620
		1863	*			PT118630
		1864	TEST9	LHI R0,TEST10		PT118640

12C8	4000 22F4	1865	STH	R0,NXTST	PT118650
12CC	C800 0119	1866	LHI	R0,X'0119'	PT118660
12D0	4000 22F2	1867	STH	R0,ERRIND	PT118670
12D4	C800 3139	1868	LHI	R0,C'19'	PT118680
12D8	4000 22B8	1869	STH	R0,TESTNO	PT118690
		1870 *			PT118700
12DC	2410	1871	LIS	R1,0	PT118710
12DE	C840 00FE	1872	LHI	R4,X'FE'	PT118720
12E2	C830 1322	1873	LHI	R3,T90R2	PT118730
12E6	4034 0000	1874	T90A9	STH R3,0(R4)	PT118740
12EA	2742	1875	SIS	R4,2	PT118750
12EC	C540 00D0	1876	CLHI	R4,X'D0'	PT118760
12F0	2035	1877	BNES	T90A9	PT118770
12F2	C830 2182	1878	T90A2	LHI R3,ERROR	PT118780
12F6	4030 0046	1879	STH	R3,X'46'	PT118790
12FA	4010 0044	1880	STH	R1,X'44'	PT118800
12FE	4010 0040	1881	STH	R1,X'40'	PT118810
1302	4010 0042	1882	STH	R1,X'42'	PT118820
1306	4010 1394	1883	STH	R1,T90DEV	PT118830
130A	4010 1322	1884	STH	R1,T90R2	PT118840
130E	4010 1324	1885	STH	R1,T90R2+2	PT118850
1312	4010 1326	1886	STH	R1,T90R2+4	PT118860
1316	C830 1336	1887	LHI	R3,T90INT	PT118870
131A	4030 00D0	1888	STH	R3,X'D0'	PT118880
131E	4300 138A	1889	B	T90SNT	PT118890
1322	0000	1890	T90R2	DC 0	PT118900
1324	0000	1891	DC	0	PT118910
1326	0000	1892	DC	0	PT118920
1328	C800 0219	1893	T90R2B	LHI R0,X'0219'	PT118930
132C	4000 22F2	1894	STH	R0,ERRIND	PT118940
1330	4300 2182	1895	B	ERROR	PT118950
		1896 *			PT118960
1334	0000	1897	DC	0	PT118970
1336	0000	1898	T90INT	DC 0	PT118980
1338	0000	1899	DC	0	PT118990
133A	0000	1900	DC	0	PT119000
133C	2400	1901	LIS	R0,0	PT119010
133E	4830 1336	1902	LH	R3,T90INT	PT119020
1342	C540 4000	1903	CLHI	R3,X'4000'	PT119030
1346	215A	1904	BNES	T90R4	PT119040
1348	C830 1396	1905	LHI	R3,OLDPSW	PT119050
134C	4530 1338	1906	CLH	R3,T90INT+2	PT119060
1350	2135	1907	BNES	T90R4	PT119070
1352	9530	1908	EPSR	R3,R0	PT119080
1354	C430 FFF0	1909	NHI	R3,X'FFF0'	PT119090
1358	2335	1910	BZS	T90D	PT119100
135A	C800 0419	1911	T90R4	LHI R0,X'0419'	PT119110
135E	4300 139A	1912	B	T90R34	PT119120
		1913 *			PT119130
		1914 *		NO ERROR DETECTED	PT119140
		1915 *			PT119150
1362	4000 1336	1916	T90D	STH R0,T90INT	PT119160
1366	4000 1338	1917	STH	R0,T90INT+2	PT119170
136A	C830 1322	1918	LHI	R3,T90R2	PT119180
136E	4034 0000	1919	STH	R3,0(R4)	PT119190
				RESET OLD PSW STORAGE LOC.	
				LOAD ERROR ADD. AT	
				DEV. NO. JUST TESTED	

1372	2611	1920	AIS	R1,1		PT119200	
1374	C510 0018	1921	CLHI	R1,X'18'		PT119210	
1378	4330 13A2	1922	BE	T90E		PT119220	
137C	2642	1923	AIS	R4,2	SERVICE POINTER FOR NEXT DEV.	PT119230	
137E	C830 1336	1924	LHI	R3,T90INT	STORE INTERRUPT ADDRESS	PT119240	
1382	4034 0000	1925	STH	R3,0(R4)		PT119250	
1386	4010 1394	1926	STH	R1,T90DEV		PT119260	
138A	C200 138E	1927	T90SNT	LPSW	**4	PT119270	
138E	4000	1928	DC	X'4000*,**2		PT119280	
1390	1392	1929	SINT	EQU	*	PT119290	
1392	E200	1930	DC	X'E200'	SINT INSTR. CODE	PT119300	
1394	0000	1931	T90DEV	DC	0	DEV. NO.	PT119310
	0000 1396	1932	OLDPSW	EQU	*	PT119320	
1396	C800 0319	1933	T90R3	LHI	R0,X'0319'	ERROR 1903	PT119330
139A	4000 22F2	1934	T90R34	STH	R0,ERRIND	PT119340	
139E	4300 2182	1935	B	ERROR	ERROR 1903 OR 1904	PT119350	
		1936	*			PT119360	
		1937	*	TEST ILLEGAL INSTRUCTION INTERRUPT FOR INSTRUCTIONS		PT119370	
		1938	*			PT119380	
		1939	*	10 THRU 1F , 30 THRU 3F , 50 THRU 5F , 70 THRU 7F		PT119390	
		1940	*			PT119400	
		1941	*	80 THRU 8F , A0 THRU AF , B0 THRU BF , F0 THRU FF		PT119410	
		1942	*			PT119420	
		1943	*	ILLEGAL = ADD. OF THE ILLEGAL INSTRUCTION		PT119430	
		1944	*			PT119440	
		1945	*	ILGINT = ILLG. INSTR. INTRPT. ADDRESS		PT119450	
		1946	*			PT119460	
13A2	4800 22E0	1947	T90E	LH	R0,CPUNO	PT119470	
13A6	C840 1478	1948	LHI	R4,T908A		PT119480	
13AA	C500 3841	1949	CLHI	R0,C'8A'		PT119490	
13AE	4330 13CA	1950	BE	T906		PT119500	
13B2	C840 147E	1951	LHI	R4,T908B		PT119510	
13B6	C500 3842	1952	CLHI	R0,C'8B'		PT119520	
13BA	2338	1953	BES	T906		PT119530	
13BC	C840 148F	1954	LHI	R4,T908C		PT119540	
13C0	C500 3843	1955	CLHI	R0,C'8C'		PT119550	
13C4	2333	1956	BES	T906		PT119560	
13C6	C840 14A0	1957	LHI	R4,T908D		PT119570	
13CA	24A0	1958	T906	LIS	R10,0	PT119580	
13CC	2460	1959	LIS	R6,0		PT119590	
13CE	24B0	1960	LIS	R11,0		PT119600	
13D0	2400	1961	T90H	LIS	R0,0	PT119610	
13D2	4000 0034	1962	STH	R0,X'34'	NEW PSW , ILLG. INSTR.	PT119620	
13D6	C800 1450	1963	LHI	R0,T90ILG		PT119630	
13DA	4000 0036	1964	STH	R0,X'36'		PT119640	
13DE	2501	1965	LCS	R0,1		PT119650	
13E0	4000 0030	1966	STH	R0,X'30'		PT119660	
13E4	4000 0032	1967	STH	R0,X'32'		PT119670	
13E8	08AA	1968	LHR	R10,R10		PT119680	
13EA	4230 1404	1969	BNZ	T90K	IF R10 = 1 , TEST ODD ILLG. INST.	PT119690	
13EE	D314 0000	1970	LB	R1,0(R4)	OTHERWISE GET NEXT ILLG. INSTR.	PT119700	
13F2	0811	1971	LHR	R1,R1		PT119710	
13F4	2135	1972	BNZS	T90J		PT119720	
13F6	24A1	1973	LIS	R10,1	R1 = 0	PT119730	

13F8	C840 14B8	1974	LHI	R4,T90000	PT119740
13FC	23U2	1975	BS	T90JJ	PT119750
13FE	2641	1976	T90J	AIS R4,1	PT119760
1400	4300 1426	1977	T90JJ	B T90L	PT119770
1404	0888	1978	T90K	LHR R11,R11	PT119780
1406	2338	1979	BZS	T90KK	PT119790
1408	2480	1980	LIS	R11,0	PT119800
140A	2641	1981	AIS	R4,1	PT119810
140C	C540 14BE	1982	CLHI	R4,T90LST+1	PT119820
1410	4330 14BE	1983	BE	T90Z	PT119830
1414	2460	1984	LIS	R6,0	PT119840
1416	D314 0000	1985	T90KK	LB R1,0(R4) R11 = 0	PT119850
141A	8A16	1986	T90P1	AHR R1,R6	PT119860
141C	2661	1987	AIS	R6,1	PT119870
141E	C560 0010	1988	CLHI	R6,16	PT119880
1422	2132	1989	BNES	T90L	PT119A90
1424	24B1	1990	LIS	R11,1	PT119900
		1991	*		PT119910
		1992	*	R1 = ILLEGAL INSTRUCTION	PT119920
		1993	*		PT119930
1426	D210 1446	1994	T90L	STB R1,ILLEG'L	PT119940
142A	4800 1446	1995	LH	R0,ILLEG'L	PT119950
142E	C500 1300	1996	CLHI	R0,X'1300'	PT119960
1432	4330 1300	1997	BE	T90H	PT119970
1436	C500 5300	1998	CLHI	R0,X'5300'	PT119980
143A	4330 1300	1999	BE	T90H	PT119990
143E	C200 1442	2000	LPSW	T90M	PT120000
1442	7C05	2001	T90M	DC X'7C05',ILLEG'L	PT120010
1444	1446				
1446	0000	2002	ILLEG'L	DC 0 ILLEGAL INSTRUCTION	PT120020
1448	C800 0519	2003	T90R7	LHI R0,X'0519' ERRIND = 0519	PT120030
144C	43U0 1470	2004	B	T90R78 ERROR 1905	PT120040
		2005	*		PT120050
1450	4800 0030	2006	T90ILG	LH R0,X'30'	PT120060
1454	C5V0 7C05	2007	M5006	CLHI R0,X'7C05'	PT120070
1458	4230 146C	2008	BNE	T90R8	PT120080
145C	C830 1446	2009	LHI	R3,ILLEG'L	PT120090
1460	4530 0032	2010	CLH	R3,X'32'	PT120100
1464	2134	2011	BNES	T90R8	PT120110
1466	9533	2012	EPSR	R3,R3	PT120120
1468	4330 1300	2013	BZ	T90H	PT120130
146C	C800 0619	2014	T90R8	LHI R0,X'0619' ERRIND = 0619	PT120140
1470	4000 22F2	2015	T90R78	STH R0,ERRIND	PT120150
1474	4300 2182	2016	B	ERROR 1905 OR 1906	PT120160
		2017	*		PT120170
1478	0C	2018	T908A	DB X'0C' MHR	PT120180
1479	0D	2019	DB	X'0D' DHR	PT120190
147A	4C	2020	DB	X'4C' MH	PT120200
147B	4D	2021	DB	X'4D' DH	PT120210
147C	9C	2022	DB	X'9C' MHUR	PT120220
147D	DC	2023	DB	X'DC' MHU	PT120230
		2024	*		PT120240
147E	28	2025	T908B	DB X'28' LER	PT120250
147F	29	2026	DB	X'29' CER	PT120260
1480	2A	2027	DB	X'2A' AER	PT120270

1481	2B	2028	DB	X'2B'	SER	PT120280
1482	2C	2029	DB	X'2C'	MER	PT120290
1483	2D	2030	DB	X'2D'	DER	PT120300
1484	60	2031	DB	X'60'	STE	PT120310
1485	68	2032	DB	X'68'	LE	PT120320
1486	69	2033	DB	X'69'	CE	PT120330
1487	6A	2034	DB	X'6A'	AE	PT120340
1488	6B	2035	DB	X'6B'	SE	PT120350
1489	6C	2036	DB	X'6C'	ME	PT120360
148A	6D	2037	DB	X'6D'	DE	PT120370
148B	2E	2038	DB	X'2E'	FXR	PT120380
148C	2F	2039	DB	X'2F'	FLR	PT120390
148D	71	2040	DB	X'71'	STME	PT120400
148E	72	2041	DB	X'72'	LME	PT120410
148F	38	2042	DB	X'38'	LDR	PT120420
1490	39	2043	DB	X'39'	CDR	PT120430
1491	3A	2044	DB	X'3A'	ADR	PT120440
1492	3B	2045	DB	X'3B'	SOR	PT120450
1493	3C	2046	DB	X'3C'	MOR	PT120460
1494	3D	2047	DB	X'3D'	DDR	PT120470
1495	3E	2048	DB	X'3E'	FXDR	PT120480
1496	3F	2049	DB	X'3F'	FLDR	PT120490
1497	70	2050	DB	X'70'	STD	PT120500
1498	78	2051	DB	X'78'	LO	PT120510
1499	79	2052	DB	X'79'	CO	PT120520
149A	7A	2053	DB	X'7A'	AD	PT120530
149B	7B	2054	DB	X'7B'	SD	PT120540
149C	7C	2055	DB	X'7C'	MD	PT120550
149D	7D	2056	DB	X'7D'	DD	PT120560
149E	7E	2057	DB	X'7E'	STMD	PT120570
149F	7F	2058	DB	X'7F'	LMD	PT120580
0000 14A0		2059	T908D	EQU *		PT120590
14A0	30	2060	DB	X'30'		PT120600
14A1	31	2061	DB	X'31'		PT120610
14A2	32	2062	DB	X'32'		PT120620
14A3	34	2063	DB	X'34'		PT120630
14A4	35	2064	DB	X'35'		PT120640
14A5	36	2065	DB	X'36'		PT120650
14A6	37	2066	DB	X'37'		PT120660
14A7	74	2067	DB	X'74'		PT120670
14A8	75	2068	DB	X'75'		PT120680
14A9	76	2069	DB	X'76'		PT120690
14AA	77	2070	DB	X'77'		PT120700
14AB	62	2071	DB	X'62'		PT120710
14AC	63	2072	DB	X'63'		PT120720
14AD	6E	2073	DB	X'6E'		PT120730
14AE	6F	2074	DB	X'6F'		PT120740
14AF	E0	2075	DB	X'E0'		PT120750
14B0	E3	2076	DB	X'E3'		PT120760
14B1	E4	2077	DB	X'E4'		PT120770
14B2	E5	2078	DB	X'E5'		PT120780
14B3	E6	2079	DB	X'E6'		PT120790
14B4	E7	2080	DB	X'E7'		PT120800
14B5	E8	2081	DB	X'E8'		PT120810
14B6	E9	2082	DB	X'E9'		PT120820

14B7 00	2083	DB	X'00'	PT120830	
14B8 10	2084	T90000	DB X'10'	PT120840	
14B9 50	2085	DB	X'50'	PT120850	
14BA 80	2086	DB	X'80'	PT120860	
14BB A0	2087	DB	X'A0'	PT120870	
14BC B0	2088	DB	X'B0'	PT120880	
14BD F0	2089	T90LST	DB X'F0'	PT120890	
14BE	2090	DB	*	PT120900	
	2091	*		PT120910	
14BE C800 213A	2092	T90Z	LHI R0,EXTINT	PT120920	
14C2 4000 0046	2093	STH	R0,X'46'	RESTORE EXTINT ERROR ADRS.	PT120930
14C6 C800 2132	2094	LHI	R0,ILGINT	PT120940	
14CA 4000 0036	2095	STH	R0,X'36'	RESTORE ILGINT ERROR ADRS.	PT120950
14CE 4300 14D2	2096	T9END	B TEST10	PT120960	
	2097	*****	*****	PT120970	
	2098	*		PT120980	
	2099	*	TEST 10 CHECKS THE INSTRUCTIONS	PT120990	
	2100	*		PT121000	
	2101	*	SLL , SRL , SLA , SRA , RLL , RRL	PT121010	
	2102	*		PT121020	
14D2 C200 14D6	2103	TEST10	LPSW T10	PT121030	
14D6 7C00	2104	T10	DC X'7C00',T10A	PT121040	
14D8 14DA					
14DA C800 17F0	2105	T10A	LHI R0,TEST11	PT121050	
14DE 4000 22F4	2106	STH	R0,NXTST	PT121060	
14E2 C800 011A	2107	LHI	R0,X'011A'	PT121070	
14E6 4000 22F2	2108	STH	R0,ERRIND	ERRIND = 011A	PT121080
14EA C800 3142	2109	LHI	R0,X'3142'	PT121090	
14EE 4000 22B8	2110	STH	R0,TESTNO	PT121100	
	2111	*		PT121110	
14F2 2440	2112	LIS	R4,0	PT121120	
14F4 2450	2113	LIS	R5,0	PT121130	
0000 14F6	2114	SLL	EQU *	THIS SECTION CHECKS THE SL,SRL,	
14F6 ED40 0000	2115	SLL	R4,0	SRA,SLA INSTRUCTIONS FOR ZERO SHIFT	
14FA 213A	2116	BNZS	T10R1	COND. CODE = 0 ?	PT121150
0000 14FC	2117	SRL	EQU *	PT121160	
14FC EC40 0000	2118	SRL	R4,0	PT121170	
1500 2137	2119	BNZS	T10R1	PT121180	
0000 1502	2120	SLA	EQU *	PT121190	
1502 EF40 0000	2121	SLA	R4,0	PT121200	
1506 2134	2122	BNZS	T10R1	PT121210	
0000 1508	2123	SRA	EQU *	PT121220	
1508 EE40 0000	2124	SRA	R4,0	PT121230	
150C 2333	2125	BZS	T10B1	PT121240	
150E 4300 2182	2126	T10R1	B ERROR	PT121250	
1512 C840 0101	2127	T10B1	LHI R4,X'0101'	ERROR 1A01	PT121260
1516 2450	2128	LIS	R5,0	PT121270	
1518 ED40 0000	2129	SLL	R4,0	PT121280	
151C 22<7	2130	BFBS	2,T10R1	CHECK G FLAG FOR SLL	PT121290
151E EC40 0000	2131	SRL	R4,0	PT121300	
1522 222A	2132	BFBS	2,T10R1	CHECK G FLAG FOR SLA	PT121310
1524 EF40 0000	2133	SLA	R4,0	PT121320	
1528 2324	2134	BFFS	2,T10R2A	CHECK G FLAG FOR SRA	PT121330
152A EE40 0000	2135	SRA	R4,0	PT121340	
152E 2123	2136	BTFS	2,T10B	CHECK G FLAG FOR SRA	PT121350
				PT121360	

1530	4300 2182	2137	T10R2A	B	ERROR		PT121370
1534	C840 D2BB	2138	T10B	LHI	R4,X'D2BB'	R4=1101,0011,1111,1111	PT121380
1538	C850 2D55	2139		LHI	R5,X'2D55'	R5=0010,1101,0101,0101	PT121390
153C	ED40 0000	2140		SLL	R4,0	ZERO SHIFT	PT121400
1540	2088	2141		BCS	T10R2A	CHECK C FLAG FOR SLL	PT121410
1542	2219	2142		BNMS	T10R2A	CHECK L FLAG FOR SLL	PT121420
1544	EC40 0000	2143		SRL	R4,0		PT121430
1548	204C	2144		BCS	T10R2A	CHECK C FLAG FOR SRL	PT121440
154A	231F	2145		BNMS	T10R2	CHECK L FLAG FOR SRL	PT121450
154C	EF40 0000	2146		SLA	R4,0		PT121460
1550	218C	2147		BCS	T10R2	CHECK C FLAG FOR SLA	PT121470
1552	2318	2148		BNMS	T10R2	CHECK L FLAG FOR SLA	PT121480
1554	EE40 0000	2149		SRA	R4,0		PT121490
1558	2188	2150		BCS	T10R2	CHECK C FLAG FOR SRA	PT121500
155A	2317	2151		BNMS	T10R2	CHECK L FLAG FOR SRA	PT121510
		2152	*				PT121520
155C	C540 D2BB	2153		CLHI	R4,X'D2BB'	CHECK FOR SHIFTS OF ZERO ONLY	PT121530
1560	2134	2154		BNES	T10R2		PT121540
1562	C550 2D55	2155		CLHI	R5,X'2D55'		PT121550
1566	2327	2156		BES	T10D		PT121560
1568	4300 2182	2157	T10R2	B	ERROR	ERROR 1A01	PT121570
156C	C800 021A	2158		LHI	R0,X'021A'		PT121580
1570	4000 22F2	2159	T10R2B	STH	R0,ERRIND	ERRIND 021A	PT121590
		2160	*				PT121600
	0040 1574	2161	T10D	EQU	*		PT121610
1574	ED40 0001	2162		SLL	R4,1	SHIFT LEFT 1	PT121620
1578	2284	2163		BNCS	T10R2B		PT121630
157A	C540 A576	2164		CLHI	R4,X'A576'		PT121640
157E	2037	2165		BNES	T10R2B		PT121650
1580	C550 5AAA	2166		CLHI	R5,X'5AAA'		PT121660
1584	213D	2167		BNES	T10R3		PT121670
1586	ED40 0002	2168		SLL	R4,2	SHIFT LEFT 2	PT121680
158A	218A	2169		BCS	T10R3		PT121690
158C	C540 95D9	2170		CLHI	R4,X'95D9'		PT121700
1590	2137	2171		BNES	T10R3		PT121710
1592	C550 6AA8	2172		CLHI	R5,X'6AA8'		PT121720
1596	2134	2173		BNES	T10R3		PT121730
1598	ED40 0004	2174		SLL	R4,4	SHIFT LEFT 4	PT121740
159C	2183	2175		BCS	T10E		PT121750
159E	4300 2182	2176	T10R3	B	ERROR	ERROR 1A02	PT121760
15A2	C540 5D96	2177	T10E	CLHI	R4,X'5D96'		PT121770
15A6	2034	2178		BNES	T10R3		PT121780
15A8	C550 AA80	2179		CLHI	R5,X'AA80'		PT121790
15AC	2037	2180		BNES	T10R3		PT121800
15AE	ED40 0008	2181		SLL	R4,8	SHIFT LEFT 8	PT121810
15B2	228A	2182		BNCS	T10R3		PT121820
15B4	C540 96AA	2183		CLHI	R4,X'96AA'		PT121830
15B8	2030	2184		BNES	T10R3		PT121840
15BA	C550 8000	2185		CLHI	R5,X'8000'		PT121850
15BE	213B	2186		BNES	T10R4		PT121860
15C0	C850 67A5	2187		LHI	R5,X'67A5'		PT121870
15C4	ED40 0010	2188		SLL	R4,16	SHIFT LEFT 16	PT121880
15C8	2186	2189		BCS	T10R4		PT121890
15CA	C540 67A5	2190		CLHI	R4,X'67A5'		PT121890
15CE	2193	2191		BNES	T10R4		PT121910

1500	0855	2192	LHR	R5,R5	PT121920
1502	2333	2193	BZS	T10F	PT121930
1504	4300 2182	2194 T10R4	B	ERROR	PT121940
1508	C840 AAB4	2195 T10F	LHI	R4,X'AAB4'	PT121950
150C	C850 2D55	2196	LHI	R5,X'2D55'	PT121960
15E0	EC40 0001	2197	SRL	R4,1	PT121970
15E4	238A	2198	BNCS	T10R5	PT121980
15E6	C540 555A	2199	CLHI	R4,X'555A'	PT121990
15EA	2157	2200	BNES	T10R5	PT122000
15EC	C550 16AA	2201	CLHI	R5,X'16AA'	PT122010
15F0	2134	2202	BNES	T10R5	PT122020
15F2	EC40 0002	2203	SRL	R4,2	PT122030
15F6	2183	2204	BCS	T10G	PT122040
15F8	4300 2182	2205 T10R5	B	ERROR	PT122050
15FC	C540 1556	2206 T10G	CLHI	R4,X'1556'	PT122060
1600	2034	2207	BNES	T10R5	PT122070
1602	C550 85AA	2208	CLHI	R5,X'85AA'	PT122080
1606	2037	2209	BNES	T10R5	PT122090
1608	EC40 0004	2210	SRL	R4,4	PT122100
160C	228A	2211	BNCS	T10R5	PT122110
160E	C540 0155	2212 T10H	CLHI	R4,X'0155'	PT122120
1612	2130	2213	BNES	T10R6	PT122130
1614	C550 685A	2214	CLHI	R5,X'685A'	PT122140
1618	213A	2215	BNES	T10R6	PT122150
161A	EC40 0008	2216	SRL	R4,8	PT122160
161E	2187	2217	BCS	T10K6	PT122170
1620	C540 0001	2218	CLHI	R4,1	PT122180
1624	2134	2219	BNES	T10R6	PT122190
1626	C550 5568	2220	CLHI	R5,X'5568'	PT122200
162A	2333	2221	BES	T10H2	PT122210
162C	4300 2182	2222 T10R6	B	ERROR	PT122220
1630	C840 AA95	2223 T10H2	LHI	R4,X'AA95'	PT122230
1634	EC40 0010	2224	SRL	R4,16	PT122240
1638	2086	2225	BCS	T10R6	PT122250
163A	C550 AA95	2226	CLHI	R5,X'AA95'	PT122260
163E	2039	2227	BNES	T10R6	PT122270
1640	0844	2228	LHR	R4,R4	PT122280
1642	203B	2229	BNZS	T10R6	PT122290
1644	C840 031A	2230 T10J	LHI	R0,X'31A'	PT122300
1648	4000 22F2	2231	STH	R0,ERRIND	PT122310
164C	C860 496C	2232	LHI	R6,X'496C'	PT122320
1650	C870 B5E3	2233	LHI	R7,X'B5E3'	PT122330
1654	EF60 0001	2234	SLA	R6,1	PT122340
1658	238D	2235	BNCS	T10R7	PT122350
165A	C560 12D9	2236	CLHI	R6,X'12D9'	PT122360
165E	213A	2237	BNES	T10R7	PT122370
1660	C570 6BC6	2238	CLHI	R7,X'6BC6'	PT122380
1664	2137	2239	BNES	T10R7	PT122390
1666	EF60 0002	2240	SLA	R6,2	PT122400
166A	2184	2241	BCS	T10R7	PT122410
166C	C560 4B65	2242	CLHI	R6,X'4B65'	PT122420
1670	2333	2243	BES	T10K	PT122430
1672	4300 2182	2244 T10R7	B	ERROR	PT122440
1676	C570 AF18	2245 T10K	CLHI	R7,X'AF18'	PT122450
167A	2034	2246	BNES	T10R7	PT122460

167C	9161	2247	SLLS	R6,1	R6 =96CA	PT122470
167E	EF60 0004	2248	SLA	R6,4	SHIFT LEFT ARITH. 4	PT122480
1682	2088	2249	BCS	T10R7		PT122490
1684	C560 ECAA	2250	CLHI	R6,X'ECAA'		PT122500
1688	203B	2251	BNES	T10R7		PT122510
168A	C570 F180	2252	CLHI	R7,X'F180'		PT122520
168E	204E	2253	BNES	T10R7		PT122530
1690	2488	2254	LIS	R8,8		PT122540
1692	EF68 0000	2255	SLA	R6,0(R8)		PT122550
1696	238C	2256	BNCS	T10R8		PT122560
1698	C560 AAF1	2257	CLHI	R6,X'AAF1'		PT122570
169C	2139	2258	BNES	T10R8		PT122580
169E	C570 8000	2259	CLHI	R7,X'8000'		PT122590
16A2	2136	2260	BNES	T10R8		PT122600
16A4	C870 550E	2261	LHI	R7,X'550E'		PT122610
16A8	EF60 0010	2262	SLA	R6,16	SHIFT LEFT ARITH. 16	PT122620
16AC	2383	2263	BNCS	T10K2		PT122630
16AE	4300 2182	2264	T10R8	B	ERROR	PT122640
16B2	C560 D50E	2265	T10K2	CLHI	R6,X'D50E'	PT122650
16B6	2034	2266	BNES	T10R8		PT122660
16B8	0877	2267	LHR	R7,R7		PT122670
16BA	2036	2268	BNZS	T10R8		PT122680
		2269	*			PT122690
		2270	*	SRA		PT122700
		2271	*			PT122710
16BC	C860 4576	2272	T10L	LHI	R6,X'4576'	PT122720
16C0	C870 6729	2273	LHI	R7,X'6729'		PT122730
16C4	EE60 0001	2274	SRA	R6,1	SHIFT RIGHT ARITH. 1	PT122740
16C8	228D	2275	BNCS	T10R8		PT122750
16CA	222E	2276	BNPS	T10R8		PT122760
16CC	C560 2280	2277	CLHI	R6,X'2280'		PT122770
16D0	213F	2278	BNES	T10R9		PT122780
16D2	C570 3394	2279	CLHI	R7,X'3394'		PT122790
16D6	213C	2280	BNES	T10R9		PT122800
16D8	2482	2281	LIS	R8,2		PT122810
16DA	EE68 0000	2282	SRA	R6,0(R8)		PT122820
16DE	2188	2283	BCS	T10R9		PT122830
16E0	2327	2284	BNPS	T10R9		PT122840
16E2	C560 08AE	2285	CLHI	R6,X'08AE'		PT122850
16E6	2134	2286	BNES	T10R9		PT122860
16E8	C5'0 CCE5	2287	CLHI	R7,X'CCE5'		PT122870
16EC	2333	2288	BES	T10L3		PT122880
16EE	4300 2182	2289	T10R9	B	ERROR	PT122890
16F2	C860 AB0F	2290	T10L3	LHI	R6,X'AB0F'	PT122890
16F6	C870 148A	2291	LHI	R7,X'148A'		PT1228910
16FA	EE60 0004	2292	SRA	R6,4	SHIFT RIGHT ARITH. 4	PT1228920
16FE	2288	2293	BNCS	T10R9		PT1228930
1700	2029	2294	BPS	T10R9		PT1228940
1702	C560 FA80	2295	CLHI	R6,X'FA80'		PT1228950
1706	204C	2296	BNES	T10R9		PT1228960
1708	C570 F148	2297	CLHI	R7,X'F148'		PT1228970
170C	213B	2298	BNES	T10R95		PT1228980
170E	EE60 0008	2299	SRA	R6,8	SHIFT RIGHT ARITH. 8	PT1228990
1712	2168	2300	BCS	T10R95		PT123000
1714	2127	2301	BPS	T10R95		PT123010

1716	C560 FFFA	2302	CLHI	R6,X"FFFA"	PT123020	
171A	2134	2303	BNES	T10R95	PT123030	
171C	C570 B0F1	2304	CLHI	R7,X"B0F1"	PT123040	
1720	2333	2305	BES	T10L5	PT123050	
1722	4300 2182	2306	T10R95	B ERROR	PT123060	
1726	C860 730E	2307	T10L5	LHI R6,X"730E"	PT123070	
172A	EE60 0010	2308	SRA	R6,16	PT123080	
172E	2286	2309	BNCS	T10R95	PT123090	
1730	2227	2310	BNPS	T10R95	PT123100	
1732	C570 730E	2311	CLHI	R7,X"730E"	PT123110	
1736	203A	2312	BNES	T10R95	PT123120	
1738	0866	2313	LHR	R6,R6	PT123130	
173A	203C	2314	BNZS	T10R95	PT123140	
173C	C800 041A	2315	T10P	LHI R0,X"41A"	PT123150	
1740	4040 22F2	2316	STH	R0,ERRIND	PT123160	
1744	C840 8F70	2317	LHI	R4,X"8F70"	PT123170	
1748	0864	2318	LHR	R6,R4	PT123180	
174A	C850 E6A0	2319	LHI	R5,X"E6A0"	PT123190	
174E	0875	2320	LHR	R7,R5	PT123200	
	0000 1750	2321	RLL	EQU *	PT123210	
1750	EB60 0000	2322	RLL	R6,0	PT123220	
1754	212E	2323	BPS	T10RA	RESULT IS +VE	PT123230
	0000 1756	2324	RRR	EQU *	PT123240	
1756	EA60 0000	2325	RRL	R6,0	PT123250	
175A	212B	2326	BPS	T10RA	PT123260	
175C	0546	2327	CLHR	R4,R6	PT123270	
175E	2139	2328	BNES	T10RA	PT123280	
1760	0557	2329	CLHR	R5,R7	PT123290	
1762	2137	2330	BNES	T10RA	PT123300	
1764	EB60 0001	2331	RLL	R6,1	ROTATE LEFT 1	PT123310
1768	2324	2332	BNPS	T10RA	PT123320	
176A	C560 1EE1	2333	CLHI	R6,X"1EE1"	PT123330	
176E	2333	2334	BES	T10P2	PT123340	
1770	4300 2182	2335	T10RA	B ERROR	PT123350	
1774	C570 CD41	2336	T10P2	CLHI R7,X"CD41"	PT123360	
1778	2034	2337	BNES	T10RA	PT123370	
177A	EA60 0001	2338	RRL	R6,1	ROTATE RIGHT 1	PT123380
177E	2027	2339	BPS	T10RA	PT123390	
1780	0546	2340	CLHR	R4,R6	PT123400	
1782	2039	2341	BNES	T10RA	PT123410	
1784	0557	2342	CLHR	R5,R7	PT123420	
1786	2038	2343	BNES	T10RA	PT123430	
1788	EB60 0002	2344	RLL	R6,2	ROTATE LEFT 2	PT123440
178C	232E	2345	BNPS	T10RB	PT123450	
178E	C560 3DC3	2346	CLHI	R6,X"3DC3"	PT123460	
1792	214B	2347	BNES	T10RB	PT123470	
1794	C570 9A82	2348	CLHI	R7,X"9A82"	PT123480	
1798	2138	2349	BNES	T10RB	PT123490	
179A	EA60 0002	2350	RRL	R6,2	ROTATE RIGHT 2	PT123500
179E	2125	2351	BPS	T10RB	PT123510	
17A0	0546	2352	CLHR	R4,R6	PT123520	
17A2	2133	2353	BNES	T10RB	PT123530	
17A4	0557	2354	CLHR	R5,R7	PT123540	
17A6	2333	2355	BES	T10P4	PT123550	
17A8	4300 2182	2356	T10RB	B ERROR	PT123560	

17AC	EB60 0004	2357	T10P4	RLL	R6,4	ROTATE LEFT 4	PT123570				
17B0	2024	2358		BPS	T10RB		PT123580				
17B2	EB60 0008	2359		RLL	R6,8	ROTATE LEFT 8	PT123590				
17B6	2227	2360		BNPS	T10RB		PT123600				
17B8	EA60 0004	2361		RRL	R6,4	ROTATE RIGHT 4	PT123610				
17Bc	222A	2362		BNPS	T10RB		PT123620				
17BE	EA60 0008	2363		RRL	R6,8	ROTATE RIGHT 8	PT123630				
17C2	202D	2364		BPS	T10RB		PT123640				
17C4	0546	2365		CLHR	R4,R6		PT123650				
17C6	213E	2366		BNES	T10RC		PT123660				
17C8	0557	2367		CLHR	R5,R7		PT123670				
17CA	213C	2368		BNES	T10RC		PT123680				
17CC	EB60 0010	2369		RLL	R6,16	ROTATE LEFT 16	PT123690				
17D0	2129	2370		BPS	T10RC		PT123700				
17D2	2188	2371		BCS	T10RC		PT123710				
17D4	0547	2372		CLHR	R4,R7		PT123720				
17D6	2136	2373		BNES	T10RC		PT123730				
17D8	0556	2374		CLHR	R5,R6		PT123740				
17DA	2134	2375		BNES	T10RC		PT123750				
17DC	EA60 0010	2376		RRL	R6,16	ROTATE RIGHT 16	PT123760				
17E0	2323	2377		BNPS	T10PB		PT123770				
17E2	4300 2182	2378	T10RC	B	ERROR	ERROR 1A04	PT123780				
17E6	0546	2379	T10P8	CLHR	R4,R6		PT123790				
17E8	2033	2380		BNES	T10RC		PT123800				
17EA	0557	2381		CLHR	R5,R7		PT123810				
17EC	2035	2382		BNES	T10RC		PT123820				
		2383	*				PT123830				
17EE	2301	2384	T10END	BS	TEST11		PT123840				
		2385	*****					PT123850			
		2386	*				PT123860				
		2387	*	TEST11 CHECKS THE INSTRUCTIONS			PT123870				
		2388	*				PT123880				
		2389	*	MH	,	MHR	,	MHU	,	MHUR	PT123890
		2390	*				PT123900				
		2391	*	DH	,	DHR	PT123910				
		2392	*				PT123920				
		2393	*	TEST11 TESTS THE MULTIPLY AND DIVIDE INSTRUCTIONS			PT123930				
		2394	*				PT123940				
	0000 0000	2395	POINT	EQU	13		PT123950				
		2396	*				PT123960				
17F0	C800 1B66	2397	TEST11	LHI	R0,TEST12		PT123970				
17F4	4000 22F4	2398		STH	R0,NXTST		PT123980				
17F8	C800 011B	2399		LHI	R0,X'011B'		PT123990				
17FC	4000 22F2	2400		STH	R0,ERRIND		PT124000				
1800	C800 3142	2401		LHI	R0,C'18'		PT124010				
1804	4000 2288	2402		STH	R0,TESTNO		PT124020				
1808	4800 22E0	2403		LH	R0,CPUNO		PT124030				
180C	C500 3841	2404		CLHI	R0,C'8A'		PT124040				
1810	4330 1866	2405		BE	TEST12		PT124050				
		2406	*				PT124060				
1814	24F1	2407		LIS	TOT,1	SET ERROR NUMBER=1	PT124070				
1816	C800 1A3C	2408	MCHK2	LHI	POINT,MUD1		PT124080				
181A	2478	2409		LIS	R7,8		PT124090				
181C	4830 0000	2410	MLOOP1	LH	R3,0(POINT)	FETCH A	PT124100				
1820	4840 0002	2411		LH	R4,2(POINT)	FETCH B	PT124110				

1824	4850 22F6	2412	LH	R5,ZERO	PT124120
1828	4860 22F6	2413	LH	R6,ZERO	PT124130
182C	0B53	2414	SHR	R5,R3	PT124140
182E	0B64	2415	SHR	R6,R4	PT124150
1830	488D 0004	2416	LH	R8,4(POINT)	PT124160
1834	489D 0006	2417	LH	R9,6(POINT)	PT124170
1838	0813	2418	LHR	R1,R3	PT124180
183A	95LC	2419	EPSR	R12,R12	PT124190
	0000 183C	2420	MH	EQU *	PT124200
183C	4C0D 0002	2421	MH	R0,2(POINT)	PT124210
1840	41A0 1980	2422	BAL	R10,TESTC4	PT124220
1844	24F2	2423	LIS	TOT,2	PT124230
1846	0814	2424	LHR	R1,R4	PT124240
1848	95CC	2425	EPSR	R12,R12	PT124250
184A	4C0D 0000	2426	MH	R0,0(POINT)	PT124260
184E	41A0 1980	2427	BAL	R10,TESTC4	PT124270
1852	24F3	2428	LIS	TOT,3	PT124280
1854	0722	2429	XHR	R2,R2	PT124290
1856	4020 185E	2430	STH	R2,SFLAG	PT124300
185A	C550 8000	2431	CLHI	R5,X'8000'	PT124310
185E	4230 1872	2432	BNE	SCONT1	PT124320
1862	C560 8000	2433	CLHI	R6,X'8000'	PT124330
1866	4330 1872	2434	BE	SCONT1	PT124340
186A	C820 7777	2435	LHI	R2,X'7777'	PT124350
186E	4020 185E	2436	STH	R2,SFLAG	PT124360
1872	0815	2437	SCONT1	LHR R1,R5	PT124370
1874	95CC	2438	EPSR	R12,R12	PT124380
1876	0C06	2439	MHR	R0,R6	PT124390
1878	41A0 1A12	2440	BAL	R10,SCHECK	PT124400
187C	41A0 1980	2441	BAL	R10,TESTC4	PT124410
1880	24F4	2442	LIS	TOT,4	PT124420
1882	0816	2443	LHR	R1,R6	PT124430
1884	95CC	2444	EPSR	R12,R12	PT124440
1886	0C05	2445	MHR	R0,R5	PT124450
1888	41A0 1A12	2446	BAL	R10,SCHECK	PT124460
188C	41A0 1980	2447	BAL	R10,TESTC4	PT124470
1890	24F5	2448	LIS	TOT,5	PT124480
1892	0788	2449	XHR	R8,R8	PT124490
1894	0799	2450	XHR	R9,R9	PT124500
1896	4B9D 0006	2451	SH	R9,6(POINT)	PT124510
189A	4F8D 0004	2452	SCH	R8,4(POINT)	PT124520
189E	0722	2453	XHR	R2,R2	PT124530
18A0	4020 185E	2454	STH	R2,SFLAG	PT124540
18A4	C560 8000	2455	CLHI	R6,X'8000'	PT124550
18A8	4230 1884	2456	BNE	SCONT2	PT124560
18AC	C820 7777	2457	LHI	R2,X'7777'	PT124570
18B0	4020 185E	2458	STH	R2,SFLAG	PT124580
18B4	0813	2459	SCONT2	LHR R1,R3	PT124590
18B6	95CC	2460	EPSR	R12,R12	PT124600
18B8	0C06	2461	MHR	R0,R6	PT124610
18BA	41A0 1A12	2462	BAL	R10,SCHECK	PT124620
18BE	41A0 1980	2463	BAL	R10,TESTC4	PT124630
18C2	24F6	2464	LIS	TOT,6	PT124640
18C4	0816	2465	LHR	R1,R6	PT124650
18C6	95CC	2466	EPSR	R12,R12	PT124660

18C8	4C0D 0000	2467	MH	R0,0(POINT)	(-B)*A	PT124670
18CC	41A0 1A12	2468	BAL	R10,SCHECK		PT124680
18D0	41A0 1980	2469	BAL	R10,TESTC4		PT124690
18D4	24F7	2470	LIS	TOT,7	SET ERROR NUMBER=7	PT124700
18D6	0722	2471	XHR	R2,R2		PT124710
18D8	4020 185E	2472	STH	R2,SFLAG	RESET SFLAG	PT124720
18DC	C550 8000	2473	CLHI	R5,X'8000'		PT124730
18E0	4230 18EC	2474	BNE	SCONT3		PT124740
18E4	C820 7777	2475	LHI	R2,X'7777'		PT124750
18E8	4020 1B5E	2476	STH	R2,SFLAG	SET SFLAG	PT124760
18EC	0814	2477	LHR	R1,R4	B	PT124770
18EE	95CC	2478	EPSR	R12,R12		PT124780
	0000 18F0	2479	MHR	EQU *		PT124790
18F0	UC05	2480	MHR	R0,R5	B*(-A)	PT124800
18F2	41A0 1A12	2481	BAL	R10,SCHECK		PT124810
18F6	41A0 1980	2482	BAL	R10,TESTC4		PT124820
18FA	24F8	2483	LIS	TOT,8	SET ERROR NUMBER=8	PT124830
18FC	0815	2484	LHR	R1,R5	-A	PT124840
18FE	95CC	2485	EPSR	R12,R12		PT124850
1900	4C0D 0002	2486	MH	R0,2(POINT)	(-A)*B	PT124860
1904	41A0 1A12	2487	BAL	R10,SCHECK		PT124870
1908	41A0 1980	2488	BAL	R10,TESTC4		PT124880
190C	24F9	2489	LIS	TOT,9	SET ERROR NUMBER=9	PT124890
190E	488D 0008	2490	LH	R8,8(POINT)	EXPECTED DOUBLE LENGTH VALUE	PT124900
1912	489D 000A	2491	LH	R9,10(POINT)	OF UNSIGNED PRODUCT OF A AND B	PT124910
1916	0813	2492	LHR	R1,R3	A	PT124920
1918	95CC	2493	EPSR	R12,R12		PT124930
	0000 191A	2494	MHU	EQU *		PT124940
191A	DC0D 0002	2495	MHU	R0,2(POINT)	A*B UNSIGNED	PT124950
191E	41A0 1980	2496	BAL	R10,TESTC4		PT124960
1922	24FA	2497	LIS	TOT,10	SET ERROR NUMBER=X'A'	PT124970
1924	0814	2498	LHR	R1,R4	B	PT124980
1926	95LC	2499	EPSR	R12,R12		PT124990
	0000 1928	2500	MHUR	EQU *		PT125000
1928	9C03	2501	MHUR	R0,R3	B*A UNSIGNED	PT125010
192A	41A0 1980	2502	BAL	R10,TESTC4		PT125020
192E	24F1	2503	LIS	TOT,1		PT125030
1930	260C	2504	AIS	POINT,12		PT125040
1932	2771	2505	SIS	R7,1		PT125050
1934	4230 181C	2506	BNZ	ML0OP1		PT125060
	0000 0007	2507	*			PT125070
	2508	POINTR	EQU	7		PT125080
	2509	*				PT125090
1938	0722	2510	DVDCHK	XHR R2,R2		PT125100
193A	4020 004C	2511	STH	R2,X'4C'		PT125110
193E	C830 19FE	2512	LHI	R3,DEFAULT		PT125120
1942	4030 004E	2513	STH	R3,X'4E'		PT125130
1946	C820 1000	2514	LHI	R2,X'1000'	ENABLE DIVIDE FAULT INTERRUPT	PT125140
194A	9532	2515	EPSR	R3,R2		PT125150
194C	C870 1A9C	2516	LHI	POINTR,DIVD2		PT125160
1950	242F	2517	LIS	R2,15		PT125170
1952	D1A7 0000	2518	DL0OP2	LM R10,0(POINTR)		PT125180
1956	243C	2519	LIS	R3,12	SET ERROR NUMBER=X'C'	PT125190
1958	080A	2520	LHR	R0,R10	DOUBLE LENGTH	PT125200
195A	081B	2521	LHR	R1,R11	DIVIDEND	PT125210

195C	9588	2522	EPSR	R8,R8	SAVE PSW	PT125220
	0000 195E	2523	DHR	EQU *		PT125230
195E	0D0C	2524	DHR	R0,R12	DIVIDEND/DIVISOR	PT125240
1960	4190 1996	2525	BAL	R9,TESTC5		PT125250
1964	243D	2526	LIS	R3,13	SET ERROR NUMBER=X'D'	PT125260
1966	080A	2527	LHR	R0,R10	DOUBLE LENGTH	PT125270
1968	081B	2528	LHR	R1,R11	DIVIDEND	PT125280
196A	9588	2529	EPSR	R8,R8	SAVE PSW	PT125290
	0000 196C	2530	DH	EQU *		PT125300
196C	4D07 0004	2531	DH	R0,4(POINTR)	DIVIDEND/DIVISOR	PT125310
1970	4190 1996	2532	BAL	R9,TESTC5		PT125320
1974	267C	2533	AIS	POINTR,12	INCREMENT POINTER BY 12	PT125330
1976	2721	2534	SIS	R2,1	DECREMENT COUNT	PT125340
1978	4310 1952	2535	BNM	DLOOP2		PT125350
197C	4300 1866	2536	T11END	B	TEST12	PT125360
		2537	*	SUBROUTINES OF T11		PT125370
1980	95EE	2538	TESTC4	EPSR R14,R14	GET PSW	PT125380
1982	05CE	2539	CLHR	R12,R14		PT125390
1984	4230 198A	2540	BNE	ERR21		PT125400
1988	0580	2541	CLHR	R8,R0		PT125410
198A	4230 198A	2542	BNE	ERR21		PT125420
198E	0591	2543	CLHR	R9,R1		PT125430
1990	4230 198A	2544	BNE	ERR21		PT125440
1994	030A	2545	BR	R10		PT125450
1996	9566	2546	TESTC5	EPSR R6,R6	GET PSW	PT125460
1998	0568	2547	CLHR	R6,R8		PT125470
199A	4230 19D6	2548	BNE	ERROR1		PT125480
199E	05UD	2549	CLHR	R0,R13		PT125490
19A0	4230 19D6	2550	BNE	ERROR1		PT125500
19A4	051E	2551	CLHR	R1,R14		PT125510
19A6	4230 19D6	2552	BNE	ERROR1		PT125520
19AA	45F0 185C	2553	CLH	R15,IDLFLAG		PT125530
19AE	4230 19D6	2554	BNE	ERROR1		PT125540
19B2	0766	2555	XHR	R6,R6		PT125550
19B4	4060 185C	2556	STH	R6,IDLFLAG		PT125560
19B8	0309	2557	BR	R9		PT125570
19BA	08DE	2558	ERR21	LHR R13,R14	PSW AFTER MULTIPLICATION	PT125580
19BC	08EC	2559	LHR	R14,R12	PSW BEFORE MULTIPLICATION	PT125590
19BE	0888	2560	LHR	R11,R8	CALCULATED	PT125600
19C0	08C9	2561	LHR	R12,R9	RESULT	PT125610
19C2	0890	2562	LHR	R9,R0	EXPECTED	PT125620
19C4	08A1	2563	LHR	R10,R1	RESULT	PT125630
19C6	0875	2564	LHR	R7,R5	NEGATIVE OF THE FIRST OPERAND	PT125640
19C8	0886	2565	LHR	R8,R6	NEGATIVE OF THE SECOND OPERAND	PT125650
19CA	0853	2566	LHR	R5,R3	THE FIRST OPERAND	PT125660
19CC	0864	2567	LHR	R6,R4	THE SECOND OPERAND	PT125670
19CE	244A	2568	LIS	R4,10	TEN VALUES ARE TO BE PRINTED	PT125680
19D0	083F	2569	LHR	R3,TOT		PT125690
19D2	4300 19EE	2570	B	ERR2		PT125700
19D6	244B	2571	ERROR1	LIS R4,11	ELEVEN HALF WORDS ARE TO BE PRINTED	PT125710
19D8	085A	2572	LHR	R5,R10	MSB OF THE DIVIDEND	PT125720
19DA	087C	2573	LHR	R7,R12	DIVISOR	PT125730
19DC	0891	2574	LHR	R9,R1	ACTUAL VALUE OF QUOTIENT	PT125740
19DE	08AD	2575	LHR	R10,R13	EXPECTED VALUE OF REMAINDER	PT125750
19E0	08C6	2576	LHR	R12,R6	PSW AFTER DIVISION	PT125760

19E2	08D8	2577	LHR	R13,R8	PSW BEFORE DIVISION	PT125770
19E4	0880	2578	LHR	R8,R0	ACTUAL VALUE OF THE REMAINDER	PT125780
19E6	086B	2579	LHR	R6,R11	LSB OF THE DIVIDEND	PT125790
19E8	088E	2580	LHR	R11,R14	EXPECTED QUOTIENT VALUE	PT125800
19EA	48E0 1B5C	2581	LH	R14, IDFLAG	ACTUAL DIVIDE FAULT FLAG	PT125810
19EE	C800 001B	2582	ERR2	LHI R0,X'001B'		PT125A20
19F2	9138	2583	SLLS	R3,R8		PT125A30
19F4	0603	2584	OHR	R0,R3		PT125A40
19F6	4000 22F2	2585	STH	R0,ERRIND		PT125850
19FA	4300 2182	2586	B	ERROR		PT125860
19FE	4060 1B60	2587	DEFAULT	STH R6,TEMPF		PT125870
1A02	C860 7777	2588	LHI	R6,X'7777'		PT125A80
1A06	4060 1B5C	2589	STH	R6, IDFLAG	SET DIVIDE FAULT INT. FLAG	PT125A90
1A0A	4860 1B60	2590	LH	R6,TEMPF	RESTORE R6	PT125900
1A0E	C200 0048	2591	LPSW	X'48'	LOAD NEW PSW & LOC FROM '48'	PT125910
1A12	95E2	2592	SCHECK	EPSR R2,R2	SAVE PSW	PT125920
1A14	48E0 1B5E	2593	LH	R14,SFLAG	EXAMINE SFLAG	PT125930
1A18	2338	2594	BZS	NCHANG	IF RESET, DO NOT MODIFY	PT125940
1A1A	C700 FFFF	2595	XHI	R0,X'FFFF'	COMPLEMENT	PT125950
1A1E	C710 FFFF	2596	XHI	R1,X'FFFF'	THE RESULT	PT125960
1A22	2611	2597	AIS	R1,1		PT125970
1A24	4E00 22F6	2598	ACH	R0,ZERO		PT125980
1A28	95E2	2599	NCHANG	EPSR R14,R2	RESTORE PSW	PT125990
1A2A	030A	2600	BR	R10		PT126000
1A2C	0000	2601	*	DATA OF TEST11		PT126010
1A2E	0001	2602	MUD2	DC 0,1,X'FFFF'		PT126020
1A30	FFFF					
1A32	7FFF	2603	DC	X'7FFF',X'8001'		PT126030
1A34	8001					
1A36	8000	2604	DC	X'8000',X'7777'		PT126040
1A38	7777					
1A3A	79DE	2605	DC	X'79DE'		PT126050
1A3C	0000	2606	MUD1	DC 0	A	PT126060
1A3E	0000	2607	DC	0	B	PT126070
1A40	0000	2608	DC	0,0	A*B	PT126080
1A42	0000					
1A44	0000	2609	DC	0,0	A*B UNSIGNED	PT126090
1A46	0000					
1A48	0000	2610	DC	0	A	PT126100
1A4A	FFFF	2611	DC	X'FFFF'	B	PT126110
1A4C	0000	2612	DC	0,0	A*B	PT126120
1A4E	0000					
1A50	0000	2613	DC	0,0	A*B UNSIGNED	PT126130
1A52	0000					
1A54	7FFF	2614	DC	X'7FFF',0		PT126140
1A56	0000					
1A58	0000	2615	DC	0,0		PT126150
1A5A	0000					
1A5C	0000	2616	DC	0,0		PT126160
1A5E	0000					
1A60	1111	2617	DC	X'1111'	A	PT126170
1A62	1111	2618	DC	X'1111'	B	PT126180
1A64	0123	2619	DC	X'0123',X'4321'	A*B	PT126190
1A66	4321					

MODEL 8/16E PROCESSOR TEST PART 1 06-211M96R00A13 PAGE 49 09:54:45 11/04/78

1A68	0123	2620	DC	X'0123', X'4321'	A*B UNSIGNED	PT126200
1A6A	4321					
1A6C	1111	2621	DC	X'1111'	A	PT126210
1A6E	FFFF	2622	DC	X'FFFF'	B	PT126220
1A70	FFFF	2623	DC	X'FFFF', X'EEEF'	A*B	PT126230
1A72	EEEF					
1A74	1110	2624	DC	X'1110', X'EEEF'	A*B UNSIGNED	PT126240
1A76	EEEF					
1A78	FFFF	2625	DC	X'FFFF'	A	PT126250
1A7A	FFFF	2626	DC	X'FFFF'	B	PT126260
1A7C	0000	2627	DC	0,1	A*B	PT126270
1A7E	0001					
1A80	FFFE	2628	DC	X'FFFE', X'0001'	A*B UNSIGNED	PT126280
1A82	0001					
1A84	8000	2629	DC	X'8000', X'FFFF'		PT126290
1A86	FFFF					
1A88	0000	2630	DC	0, X'8000'		PT126300
1A8A	8000					
1A8C	7FFF	2631	DC	X'7FFF', X'8000'		PT126310
1A8E	8000					
1A90	8000	2632	DC	X'8000', X'8000'		PT126320
1A92	8000					
1A94	4000	2633	DC	X'4000', 0		PT126330
1A96	0000					
1A98	4000	2634	DC	X'4000', 0		PT126340
1A9A	0000					
1A9C	0000	2635 DIVD2	DC	0, 0, 0		PT126350
1A9E	0000					
1AA0	0000					
1AA2	0000	2636	DC	0, 0, X'7777'		PT126360
1AA4	0000					
1AA6	7777					
1AA8	0000	2637	DC	0, 1, 0		PT126370
1AAA	0001					
1AAC	0000					
1AAE	0000	2638	DC	0, 1, X'7777'		PT126380
1AB0	0001					
1AB2	7777					
1AB4	FFFF	2639	DC	X'FFFF', X'FFFF'		PT126390
1AB6	FFFF					
1AB8	0000	2640	DC	0, X'FFFF', X'FFFF'		PT126400
1ABA	FFFF					
1ABC	FFFF					
1ABE	7777	2641	DC	X'7777'		PT126410
1AC0	0000	2642	DC	0, 0, X'7FFF'		PT126420
1AC2	0000					
1AC4	7FFF					
1AC6	0000	2643	DC	0, 0, 0		PT126430
1AC8	0000					
1ACA	0000					
1ACC	0000	2644	DC	0, 0, X'FFFF'		PT126440
1ACE	0000					
1ADD	FFFF					
1AD2	0000	2645	DC	0, 0, 0		PT126450
1AD4	0000					

## MODEL 8/16E PROCESSOR TEST PART 1 06-211M96R00A13

PAGE 50 09:54:45 11/04/78

1AD6	0000						
1AD8	0000	2646	DC	0,0,X'8000'			PT126460
1ADA	0000						
1ADC	8000						
1ADE	0000	2647	DC	0,0,0			PT126470
1AE0	0000						
1AE2	0000						
1AE4	3FFF	2648	DC	X'3FFF',X'8000'			PT126480
1AE6	8000						
1AE8	7FFF	2649	DC	X'7FFF',X'3FFF'			PT126490
1AEA	3FFF						
1AEC	8000	2650	DC	X'8000',X'7777'			PT126500
1AEE	7777						
1AF0	C000	2651	DC	X'C000',X'8000'			PT126510
1AF2	8000						
1AF4	8001	2652	DC	X'8001',X'C000'			PT126520
1AF6	C000						
1AF8	8000	2653	DC	X'8000',X'7777'			PT126530
1AFA	7777						
1AFC	3FFF	2654	DC	X'3FFF',X'7FFF'			PT126540
1AFE	7FFF						
1B00	7FFF	2655	DC	X'7FFF',X'7FFE'			PT126550
1B02	7FFE						
1B04	7FFF	2656	DC	X'7FFF',0			PT126560
1B06	0000						
1B08	C000	2657	DC	X'C000',X'8001'			PT126570
1B0A	8001						
1B0C	8001	2658	DC	X'8001',X'8002'			PT126580
1B0E	8002						
1B10	7FFF	2659	DC	X'7FFF',0			PT126590
1B12	0000						
1B14	3FFF	2660	DC	X'3FFF',X'FFFE'			PT126600
1B16	FFFE						
1B18	8001	2661	DC	X'8001',X'7FFE'			PT126610
1B1A	7FFE						
1B1C	8000	2662	DC	X'8000',0			PT126620
1B1E	0000						
1B20	C000	2663	DC	X'C000',X'0002'			PT126630
1B22	0002						
1B24	7FFF	2664	DC	X'7FFF',X'8002'			PT126640
1B26	8002						
1B28	8000	2665	DC	X'8000',0			PT126650
1B2A	0000						
1B2C	3FFF	2666	DC	X'3FFF',X'FFFF'			PT126660
1B2E	FFFF						
1B30	8001	2667	DC	X'8001',X'3FFF'			PT126670
1B32	3FFF						
1B34	FFFF	2668	DC	X'FFFF',X'7777'			PT126680
1B36	7777						
1B38	C000	2669	DC	X'C000',X'0001'			PT126690
1B3A	0001						
1B3C	7FFF	2670	DC	X'7FFF',X'C000'			PT126700
1B3E	C000						
1B40	0001	2671	DC	X'0001',X'7777'			PT126710
1B42	7777						

1B44 0000	2672	DC 0,1,X'FFFF'	PT126720	
1B46 0001				
1B48 FFFF				
1B4A 0000	2673	DC 0,X'FFFF',0	PT126730	
1B4C FFFF				
1B4E 0000				
1B50 FFFF	2674	DC X'FFFF',X'FFFC'	PT126740	
1B52 FFFC				
1B54 0002	2675	DC X'0002',0	PT126750	
1B56 0000				
1B58 FFCE	2676	DC X'FFFE',0	PT126760	
1B5A 0000				
1B5C 0000	2677	IDFLAG DC 0	PT126770	
1B5E 0000	2678	SFLAG DC 0	PT126780	
1B60 0000	2679	TEMPF DS 2	PT126790	
1B62 0000	2680	NUMBER DC 0,X'7FFF'	PT126800	
1B64 7FFF				
	2681	*****	PT126810	
	2682	*	PT126820	
	2683	* TEST 12	PT126830	
	2684	*	PT126840	
	2685	* THIS TEST CHECKS SET MAP AND LOAD PROGRAM STATUS INSTRUCTIONS.	PT126850	
	2686	* THE FIRST PART OF THE TEST CHECKS SETMR AND SETM.	PT126860	
	2687	* THE SECOND PART OF THE TEST CHECKS LPS AND LPSR.	PT126870	
	2688	*	PT126880	
	2689	*****	PT126890	
	2690	*	PT126900	
	2691	* THE COMMENTS BELOW REFER TO BITS 8-11.	PT126910	
	2692	* THESE BITS ARE FROM THE SECOND OPERAND (R2).	PT126920	
	2693	*	PT126930	
1B66 C8E0 1CBE	2694	TEST12 LHI R14,STOSETM	STORAGE AREA FOR RX FORMAT INSTR.	PT126940
1B6A C8F0 0334	2695	LHI R15,TEST1		PT126950
1B6E 40F0 22F4	2696	STH R15,NXTST		PT126960
1B72 C800 3143	2697	LHI R0,C'1C'		PT126970
1B76 4000 22B8	2698	STH R0,TESTNO		PT126980
1B7A C850 7C00	2699	LHI R5,X'7C00'	ARBITRARY PSW FOR SWITCHING	PT126990
1B7E 07AA	2700	XHR R10,R10	FLAG DECIDES TO EXEC. SETMR OR SETM	PT127000
1B80 0799	2701	XHR R9,R9	DOCOMP ROUTINE FLAG	PT127010
1B82 C800 001C	2702	LHI R0,X'001C'		PT127020
1B86 4000 22F2	2703	STH R0,ERRIND		PT127030
1B8A 4300 1B80	2704	B SET01		PT127040
1B8E C5A0 0001	2705	SET0 CLHI R10,1	CHECK FLAG	PT127050
1B92 2184	2706	BLS SER0	IF FLAG IS ZERO EXECUTE SETMR	PT127060
1B94 2339	2707	BES SER	IF FLAG IS NOT ZERO EXECUTE SETMR	PT127070
1B96 4300 1CC0	2708	B CHANST	BRANCH TO CHECK FOR LARGER MEMORY	PT127080
1B9A 1312	2709	SER0 SETMR R1,R2		PT127090
1B9C 4520 1F3C	2710	CLH R2,RTWIFI	CHECK R2 FIELD TO SEE IF INTACT	PT127100
1BA0 4230 1F34	2711	BNE SETERC		PT127110
1BA4 030B	2712	BR R11		PT127120
1BA6 4020 1CBE	2713	SER STH R2,STOSETM	STORE R2 FIELD IN STORAGE LOCATION	PT127130
1BA8 531E 0000	2714	SETM R1,0(R14)	R14 CONTAINS ADDRESS OF STOSETM	PT127140
1BAE 030B	2715	BR R11		PT127150
	2716	*		PT127160
	2717	* BITS 8-11 IN THIS SECTION ARE FROM 0000 TO 0110		PT127170
	2718	*		PT127180

1880 0744	2719	SET01	XHR	R4,R4	R4 IS CHECK AGAINST R2 (PSW)	PT127190
1882 0766	2720		XHR	R6,R6	R6 IS PSW COUNTER	PT127200
1884 0722	2721		XHR	R2,R2	R2 IS LOCATION FOR NEW PSW'S	PT127210
1886 9552	2722		EPSR	R5,R2	SWITCH TO NEW PSW	PT127220
1888 4020 1F3C	2723		STH	R2,RTWOFI		PT127230
188C 0755	2724		XHR	R5,R5		PT127240
18BE C810 F0F0	2725		LHI	R1,X'F0F0'	R1 TO BE COMPARE TO	PT127250
18C2 0831	2726		LHR	R3,R1	CONSTANT VALUE OF R3	PT127260
18C4 C880 0060	2727		LHI	R8,X'0060'	R8 IS UPPER LIMIT FOR COUNTER	PT127270
18C8 C880 1BD4	2728		LHI	R11,SET0A		PT127280
18CC C8D0 1C2E	2729		LHI	R13,SETR		PT127290
18D0 4300 1B8E	2730		R	SET0		PT127300
	2731	*				PT127310
	2732	*				PT127320
	2733	*	THIS SECTION TESTS THE ABOVE SET UPS FOR SETMR AND SETM			
18D4 0513	2734	SET0A	CLHR	R1,R3	COMPARE R1 TO EXPECTED VALUE (R3)	PT127340
18D6 4230 1C98	2735		BNE	SETERA		PT127350
18D8 9525	2736		EPSR	R2,R5	EXCHANGE PSW TO TEST IT	PT127360
18DC 0524	2737		CLHR	R2,R4	COMPARE R2(PSW) TO EXPECTED PSW(R4)	PT127370
18DE 4230 1CAE	2738		BNE	SETERB		PT127380
18E2 C5A0 0001	2739		CLHI	R10,1	CHECK IF SETM OR SETMR EXECUTED	PT127390
18E6 2137	2740		BNES	SET0A2	IF R10=1, R2 FIELD WAS CHECKED	PT127400
18E8 4820 1CAE	2741		LH	R2,STOSETM	LOAD R2 FIELD INTO R2 FOR CHECK	PT127410
18EC 4520 1F3C	2742		CLH	R2,RTWOFI	CHECK IF R2 FIELD IS STILL INTACT	PT127420
18F0 4230 1F34	2743		BNE	SETERC		PT127430
1BF4 0568	2744	SET0A2	CLHR	R6,R8	CHECK IF ALL PSW'S HAVE BEEN TESTED	PT127440
1BF6 4330 1C12	2745		BE	CHFI		PT127450
1BFA CA60 0010	2746		AHI	R6,X'10'	INCREMENT PSW COUNTER	PT127460
1BFE 0826	2747	SET0A1	LHR	R2,R6	LOAD NEW PSW INTO R2	PT127470
1C00 C420 00F0	2748		NHI	R2,X'00F0'	AND OFF UNNECESSARY BITS	PT127480
1C04 C620 4C00	2749		OHI	R2,X'4C00'	OR IN CHECK BITS	PT127490
1C08 4020 1F3C	2750		STH	R2,RTWOFI	STORE IN R2 FIELD CHECK AREA	PT127500
1C0C 0846	2751		LHR	R4,R6		PT127510
1C0E 4300 1B8E	2752		R	SET0	BRANCH TO EXECUTE TEST INSTRUCTION	PT127520
	2753	*				PT127530
1C12 C560 7E60	2754	CHFI	CLHI	R6,X'7E60'	COMPARE COUNTER (R6) TO FINAL PSW	PT127540
1C16 033D	2755		BER	R13		PT127550
1C18 C460 FF00	2756		NHI	R6,X'FF00'	REMOVE EXTRANEOUS BITS	PT127560
1C1C CA60 0200	2757		AHI	R6,X'0200'	INCREMENT FOR NEW PSW	PT127570
1C20 0886	2758		LHR	R8,R6		PT127580
1C22 CA80 0060	2759		AHI	R8,X'60'	ADJUST R8 TO FINAL PSW	PT127590
1C26 9556	2760		EPSR	R5,R6	SWITCH TO NEW PSW	PT127600
1C28 0856	2761		LHR	R5,R6	R5 TO BE NEW PSW AT COMPAR. ROUTINE	PT127610
1C2A 4300 1BFE	2762		R	SET0A1		PT127620
	2763	*				PT127630
	2764	*	BIT 8-11 IN THIS SECTION ARE EQUAL TO 1111 ONLY			
	2765	*				PT127640
1C2E C810 F0F0	2766	SETB	LHI	R1,X'F0F0'	LOAD R1 WITH CONSTANT	PT127660
1C32 0831	2767		LHR	R3,R1	R3 TO BE CHECK AGAINST R1	PT127670
1C34 C880 1C4A	2768		LHI	R11,SET0B		PT127680
1C38 0755	2769		XHR	R5,R5	R5 TO BE COUNTER	PT127690
1C3A 9525	2770		EPSR	R2,R5	SWITCH TO NEW PSW	PT127700
1C3C C820 00F0	2771		LHI	R2,X'00F0'	SET UP R2 FIELD	PT127710
1C40 4020 1F3C	2772		STH	R2,RTWOFI	STORE IN R2 FIELD CHECK AREA	PT127720
1C44 0842	2773		LHR	R4,R2	R4 TO BE CHECK AGAINST R2	PT127730

1C46	4300 1B8E	2774	B	SET0	PT127740
1C4A	0513	2775 *			PT127750
1C4C	4230 1C98	2776	SET08	CLHR R1,R3	PT127760
1C50	9525	2777	BNE	SETERA	PT127770
1C52	0524	2778	EPSR	R2,R5	PT127780
1C54	4230 1CAE	2779	CLHR	R2,R4	PT127790
1C58	C5A0 0001	2780	BNE	SETERB	PT127800
1C5C	4230 1C6C	2781	CLHI	R10,1	PT127810
1C60	4820 1CBE	2782	BNE	SET08.2	PT127820
1C64	4520 1F3C	2783	LH	R2,STOSETM	PT127830
1C68	4230 1F34	2784	CLH	R2,RTWOFI	PT127840
1C6C	C550 7E00	2785	BNE	SETERC	PT127850
1C70	4330 1C8E	2786	SET08.2	CLHI R5,X'7E00'	PT127860
1C74	CA50 0200	2787	BE	SET08.1	PT127870
1C78	0825	2788	AHI	R5,X'200'	PT127880
1C7A	C620 4CF0	2789	LHR	R2,R5	PT127890
1C7E	4020 1F3C	2790	OHI	R2,X'4CF0'	PT127900
1C82	0845	2791	STH	R2,RTWOFI	PT127910
1C84	C640 00F0	2792	LHR	R4,R5	PT127920
1C88	9565	2793	OHI	R4,X'00F0'	PT127930
1C8A	4300 1B8E	2794	EPSR	R6,R5	PT127940
1C8E	C8B0 1BD4	2795	B	SET0	PT127950
1C92	26A1	2796	SET08.1	LHI R11+SET0A	PT127960
1C94	4300 1B80	2797	AIS	R10,1	PT127970
		2798	B	SET01	PT127980
		2799 *			PT127990
1C98	08AA	2800	SETERA	LHR R10,R10	PT128000
1C9A	2134	2801	BNZS	SETERA1	PT128010
1C9C	C800 011C	2802	LHI	R0,X'011C'	PT128020
1CA0	2303	2803	BS	SETERR	PT128030
1CA2	C800 021C	2804	SETERA1	LHI R0,X'021C'	PT128040
1CA6	4000 22F2	2805	SETERR	STH R0,ERRIND	PT128050
1CAA	4300 2182	2806	B	ERROR	PT128060
1CAE	08AA	2807	SETERB	LHR R10,R10	PT128070
1CB0	2134	2808	BNZS	SETERB1	PT128080
1CB2	C800 031C	2809	LHI	R0,X'031C'	PT128090
1CB6	2208	2810	BS	SETERR	PT128100
1CB8	C800 041C	2811	SETERB1	LHI R0,X'041C'	PT128110
1CBC	220B	2812	BS	SETERR	PT128120
		2813 *			PT128130
1CBE	0000	2814	STOSETM	DC 0	PT128140
		2815 *			PT128150
1CC0	48E0 1F56	2816	CHANST	LH R14, MEMSTO	PT128160
1CC4	C5E0 0001	2817	CLHI	R14,X'1'	PT128170
1CC8	4230 1F58	2818	BNE	CHLPS	PT128180
1CCC	0799	2819	XHR	R9,R9	PT128190
1CCE	C8C0 1F5E	2820	LHI	R12,CHLPS1	PT128200
1CD2	C850 7C00	2821	LHI	R5,X'7C00'	PT128210
1CD6	9545	2822	EPSR	R4,R5	PT128220
1CD8	C8U0 1CF4	2823	LHI	R13,SET00	PT128230
1CDC	D3FD 0000	2824	CHBYT	LB R15,0(R13)	PT128240
1CE0	D2FD 8000	2825	STB	R15,X'8000*(R13)	PT128250
1CE4	05DC	2826	CLHR	R13,R12	PT128260
1CE6	2334	2827	BES	SWLPS	PT128270
1CE8	26D1	2828	AIS	R13,1	PT128280

1CEA	4300 1CDC	2829	B	CHBYT	PT128290
		2830	*		PT128300
1CEE	C820 7C90	2831	SWLPS	LHI R2,X'7C90'	PT128310
1CF2	9502	2832	SWL1	EPSR R5,R2	PT128320
1CF4	07AA	2833	SET00	XHR R10,R10	PT128330
1CF6	C8E0 1F3E	2834		LHI R14,STOSETMB	PT128340
1CFA	4300 1D1E	2835		B SET1	PT128350
1CFE	C5A0 0001	2836	SET001	CLHI R10,1	PT128360
1D02	2184	2837		BLS SEROB	PT128370
1D04	2338	2838		BES SERB	PT128380
1D06	4300 1F58	2839		B CHLPS	PT128390
1D0A	1312	2840	SEROB	SETMR R1,R2	PT128400
1D0C	052F	2841		CLHR R2,R15	PT128410
1D0E	4230 1F34	2842		BNE SETERC	PT128420
1D12	030B	2843		BR R11	PT128430
1D14	4020 1F3E	2844	SERB	STH R2,STOSETMB	PT128440
1D18	531E 0000	2845		SETM R1,0(R14)	PT128450
1D1C	03UB	2846		BR R11	PT128460
		2847	*		PT128470
		2848	*	BITS 8-11 IN THIS SECTION ARE FROM 1000 TO 1110, R1 IS POSITIVE	PT128480
		2849	*		PT128490
1D1E	C820 0080	2850	SET1	LHI R2,X'0080'	PT128500
1D22	0862	2851		LHR R6,R2	PT128510
1D24	9552	2852		EPSR R5,R2	PT128520
1D26	C620 4C00	2853		OHI R2,X'4C00'	PT128530
1D2A	08F2	2854		LHR R15,R2	PT128540
1D2C	0755	2855		XHR R5,R5	PT128550
1D2E	C880 00E0	2856		LHI R8,X'00E0'	PT128560
1D32	C830 8000	2857		LHI R3,X'8000'	PT128570
1D36	0799	2858		XHR R9,R9	PT128580
1D38	0744	2859		XHR R4,R4	PT128590
1D3A	0711	2860		XHR R1,R1	PT128600
1D3C	C8B0 1D6E	2861		LHI R11,SET0AB	PT128610
1D40	C8D0 1D48	2862		LHI R13,SETAB	PT128620
1D44	4300 1CFE	2863		B SET001	PT128630
		2864	*		PT128640
		2865	*		PT128650
		2866	*	BITS 8-11 IN THIS SECTION ARE FROM 1000 TO 1110, R1 IS NEGATIVE	PT128660
		2867	*		PT128670
1D48	C820 0080	2868	SETAB	LHI R2,X'0080'	PT128680
1D4C	0862	2869		LHR R6,R2	PT128690
1D4E	C810 F0F0	2870		LHI R1,X'F0F0'	PT128700
1D52	0831	2871		LHR R3,R1	PT128710
1D54	0744	2872		XHR R4,R4	PT128720
1D56	C880 00E0	2873		LHI R8,X'00E0'	PT128730
1D5A	9552	2874		EPSR R5,R2	PT128740
1D5C	C620 4C00	2875		OHI R2,X'4C00'	PT128750
1D60	08F2	2876		LHR R15,R2	PT128760
1D62	0755	2877		XHR R5,R5	PT128770
1D64	2491	2878		LIS R9,1	PT128780
1D66	C8D0 1E32	2879		LHI R13,DOCOMP	PT128790
1D6A	4300 1CFE	2880		B SET001	PT128800
		2881	*		PT128810
1D6E	0513	2882	SET0AB	CLHR R1,R3	PT128820
1D70	4230 1F08	2883		BNE SETERAB	PT128830

1D74	9525	2884	EPSR	R2,R5	GET THE PSW INTO R2	PT128840
1D76	0524	2885	CLHR	R2,R4	COMPARE R2(PSW) TO EXPECTED PSW(R4)	PT128850
1D78	4230 1F24	2886	BNE	SETERBB		PT128860
1D7C	C5A0 0001	2887	CLHI	R10+1	COMPARE R10 TO CHECK IF	PT128870
1D80	4230 1D8E	2888	BNE	SET0A.1	SETMR R0 SETM TO BE CHECKED	PT128880
1D84	4820 9F3E	2889	LH	R2,STOSETMB+X*8000*	LOAD FROM R2 FIELD SAVE AREA	PT128890
1D88	052F	2890	CLHR	R2,R15	CHECK IF R2 FIELD IS STILL INTACT	PT128890
1D8A	4230 1F34	2891	BNE	SETERC	BRANCH TO ERROR 1C09 IF NOT INTACT	PT1288910
1D8E	0568	2892	SET0A.1	CLHR	CHECK FOR FINAL PSW	PT1288920
1D90	4330 10CC	2893	BE	CHF1		PT1288930
1D94	CA60 0010	2894	AHI	R6,X*10*	INCREMENT COUNTER	PT1288940
1D98	C590 0001	2895	CLHI	R9,1	CHECK THE FLAG	PT1288950
1D9C	2134	2896	BNES	RNO		PT1288960
1D9E	CA40 0010	2897	AHI	R4,X*10*	INCREMENT R4 (EXPECTED PSW)	PT1288970
1DA2	230A	2898	BS	RN1		PT1288980
1DA4	0711	2899	RNO	XHR	RESET R1	PT1288990
1DA6	0826	2900	LHR	R1,R1	LOAD INCREMENTED PSW INTO R2	PT1289000
1DA8	9552	2901	EPSR	R2,R6	SWITCH TO NEW PSW	PT1289010
1DAA	0755	2902	XHR	R5,R5	RESET R5 TO CONTROL MEMORY	PT1289020
1DAC	C620 4C00	2903	OHI	R2,X*4C00*	OR IN CHECK BITS	PT1289030
1DB0	08F2	2904	LHR	R15,R2	SAVE R2 IN R15 FOR CHECK	PT1289040
1DB2	4300 1CFE	2905	B	SET001		PT1289050
1DB6	0826	2906	RN1	LHR	LOAD NEW PSW	PT1289060
1DB8	C420 FF80	2907	NHI	R2,X'FF80'	AND IN NECESSARY BITS	PT1289070
1DBC	9552	2908	EPSR	R5,R2	SWITCH TO NEW PSW	PT1289080
1DBE	0826	2909	LHR	R2,R6	SET UP R2 FIELD	PT1289090
1DC0	0755	2910	XHR	R5,R5	RESET R5, TO CONTROL MEMORY	PT1289100
1DC2	C620 4C00	2911	OHI	R2,X*4C00*	OR IN CHECK BITS	PT1289110
1DC6	08F2	2912	LHR	R15,R2	SAVE R2 FIELD IN R15	PT1289120
1DC8	4300 1CFE	2913	B	SET001		PT1289130
		2914	*		CHECK FOR CHOICE OF PSW INCRE. ROUT.	PT1289140
1DCC	C590 0001	2915	CHF1	CLHI	R9,1	PT1289150
1DD0	4230 1E04	2916	BNE	CHF3		PT1289160
1DD4	C560 7EE0	2917	CLHI	R6,X*7EE0*	COMPARE COUNTER (R6) TO FINAL PSW	PT1289170
1DD8	4330 1E32	2918	BE	DOCOMP		PT1289180
1DDC	C460 FF00	2919	NHI	R6,X'FF00'	REMOVE EXTRANEOUS BITS	PT1289190
1DE0	CA60 0200	2920	AHI	R6,X'200'	INCREMENT COUNTER	PT1289200
1DE4	0755	2921	XHR	R5,R5	RESET R5, TO BE NEW PSW	PT1289210
1DE6	C660 0080	2922	OHI	R6,X'0080'	SET R6 TO BE NEXT PSW	PT1289220
1DEA	9576	2923	EPSR	R7,R6	SWITCH TO NEW PSW	PT1289230
1DEC	0846	2924	LHR	R4,R6	R4 TO CHECK AGAINST NEW PSW	PT1289240
1DEE	C440 FF7F	2925	NHI	R4,X'FF7F'	SET UP R4 FOR PSW	PT1289250
1DF2	0826	2926	LHR	R2,R6	SET UP F2 FIELD	PT1289260
1DF4	C620 4C00	2927	OHI	R2,X*4C00*	OR IN CHECK BITS	PT1289270
1DF8	08F2	2928	LHR	R15,R2	STORE R2 FIELD IN R15	PT1289280
1DFA	0886	2929	LHR	R8,R6	R8 TO BE LIMIT FOR BITS 8-12 OF PSW	PT1289290
1DFC	C680 00E0	2930	OHI	R8,X'00E0'	INCREMENT R8 TO UPPER LIMIT FOR PSW	PT1289300
1E00	4300 1CFE	2931	B	SET001		PT1289310
1E04	C560 7EE0	2932	CHF3	CLHI	COPARE R6 TO CHECK FOR LAST	PT1289320
1E08	4330 1D48	2933	BE	SETAB	PSW (TOTAL PSW)	PT1289330
1E0C	C460 FF00	2934	NHI	R6,X'FF00'	REMOVE EXTRANEOUS BITS	PT1289340
1E10	CA60 0200	2935	AHI	R6,X'200'	INCREMENT FOR NEXT PSW	PT1289350
1E14	0755	2936	XHR	R5,R5		PT1289360
1E16	0846	2937	LHR	R4,R6	R4 TO BE CHECK AGAINST NEW PSW	PT1289370
1E18	C660 0080	2938	OHI	R6,X'0080'	OR IN CHECK BIT FOR NEW PSW	PT1289380

1E1C	9576	2939	EPSR	R7,R6	SWITCH TO NEW PSW	PT129390	
1E1E	0826	2940	LHR	R2,R6	SET UP R2 FIELD	PT129400	
1E20	C620 4C00	2941	OHI	R2,X'4C00'	OR IN CHECK BITS	PT129410	
1E24	08F2	2942	LHR	R15,R2	STORE R2 FIELD IN R15	PT129420	
1E26	0886	2943	LHR	R8,R6	SET UP R8 TO BE COUNTER	PT129430	
1E28	C680 00E0	2944	OHI	R8,X'00E0'	OF BITS 8-12 OF NEW PSW	PT129440	
1E2C	0711	2945	XHR	R1,R1	RESET R1 FIELD	PT129450	
1E2E	4300 1CFE	2946	B	SET001		PT129460	
		2947 *				PT129470	
		2948 *			* BITS 8-11 IN THIS SECTION ARE EQUAL TO 0111 ONLY	PT129480	
		2949 *				PT129490	
1E32	2410	2950	DOCOMP	LIS	R1,0	RESET R1	PT129500
1E34	C830 8000	2951	LHI	R3,X'8000'	R3 IS CHECK AGAINST R1	PT129510	
1E38	C820 00F0	2952	LHI	R2,X'00F0'	SET UP NEW PSW	PT129520	
1E3C	9552	2953	EPSR	R5,R2	SWITCH TO NEW PSW	PT129530	
1E3E	C850 7C00	2954	LHI	R5,X'7C00'	R5 TO BE PSW BEFORE COMPARISON	PT129540	
1E42	C420 0070	2955	NHI	R2,X'0070'	AND OFF PROPER BITS	PT129550	
1E46	C620 4C00	2956	OHI	R2,X'4C00'	OR IN CHECK BITS	PT129560	
1E4A	08F2	2957	LHR	R15,R2	STORE R2 FIELD IN R15	PT129570	
1E4C	24B0	2958	LIS	R6,0	R6 IS COUNTER FOR ENTIRE PSW	PT129580	
1E4E	2440	2959	LIS	R4,0	R4 IS CHECK AGAINST R2 (PSW)	PT129590	
1E50	24C0	2960	LIS	R12,0	INCREMENT FLAG	PT129600	
1E52	C880 1E5A	2961	LHI	R11,SET01B		PT129610	
1E56	4300 1CFE	2962	B	SET001		PT129620	
		2963 *				PT129630	
1E5A	0543	2964	SET01B	CLHR	R1,R3	COMPARE R1 TO EXPECTED VALUE (R3)	PT129640
1E5C	4230 1F08	2965	BNE	SETERAB		PT129650	
1E60	9525	2966	EPSR	R2,R5	GET PSW	PT129660	
1E62	0524	2967	CLHR	R2,R4	COMPARE R2(PSW) TO EXPECTED PSW(R4)	PT129670	
1E64	4230 1F24	2968	BNE	SETERBB		PT129680	
1E68	C5A0 0001	2969	CLHI	R10,1	IF SETMR INSTRUCTION THEN R2 FIELD	PT129690	
1E6C	2136	2970	BNES	SET0A.2	HAS ALREADY BEEN CHECKED	PT129700	
1E6E	4820 1F3E	2971	LH	R2,STOSETMB	LOAD R2 FIELD INTO R2	PT129710	
1E72	052F	2972	CLHR	R2,R15	CHECK R2 FILED TO SEE IF INTACT	PT129720	
1E74	4230 1F34	2973	BNE	SETERC		PT129730	
1E78	C5C0 0001	2974	SET0A.2	CLHI	R12,X'1'	COMPARE DOCOMP FLAG (R12)	PT129740
1E7C	42B0 1E88	2975	BL	CH		PT129750	
1E80	4330 1ED2	2976	BE	CH12		PT129760	
1E84	4300 1EFC	2977	8	CH13		PT129770	
1E88	C540 7E00	2978	CH	CLHI	R4,X'7E00'		PT129780
1E8C	4330 1EB2	2979	BE	CH11		PT129790	
1E90	CA60 0200	2980	AHI	R6,X'200'	INCREMENT FOR NEXT PSW	PT129800	
1E94	0826	2981	LHR	R2,R6	SET UP R2 FIELD	PT129810	
1E96	C620 00F0	2982	OHI	R2,X'00F0'	OR IN PROPER PSW BITS	PT129820	
1E9A	9552	2983	EPSR	R5,R2	SWITCH TO NEW PSW	PT129830	
1E9C	C420 FF70	2984	NHI	R2,X'FF70'	AND OFF PROPER BITS FOR R2 FIELD	PT129840	
1EA0	C850 7C00	2985	LHI	R5,X'7C00'	R5 TO BE NEW PSW BEFORE COMPARISON	PT129850	
1EA4	C620 4C00	2986	OHI	R2,X'4C00'	OR IN CHECK BITS	PT129860	
1EA8	08F2	2987	LHR	R15,R2	STORE R2 FIELD IN R15	PT129870	
1EAA	0846	2988	LHR	R4,R6	R4 TO BE CHECK AGAINST NEW PSW	PT129880	
1EAC	2410	2989	LIS	R1,0	SET UP R1 FIELD	PT129890	
1EAE	4300 1CFE	2990	B	SET001		PT129900	
		2991 *				PT129910	
1EB2	0733	2992	CH11	XHR	R3,R3	R3 TO BE CHECK AGAINST R1 FIELD	PT129920
1EB4	26C1	2993	AIS	R12,1		PT129930	

1EB6	C820 00F0	2994	LHI	R2,X'00F0'	SET UP FOR NEW PSW	PT129940	
1EBA	9552	2995	EPSR	R5,R2		PT129950	
1EBC	C850 7C00	2996	LHI	R5,X'7C00'	R5 TO BE NEW PSW BEFORE COMPARISON	PT129960	
1EC0	C420 0070	2997	NHI	R2,X'0070'	AND IN PROPER BITS INTO R2 FIELD	PT129970	
1EC4	08F2	2998	LHR	R15,R2	STORE R5 FIELD IN R15	PT129980	
1EC6	2460	2999	LIS	R6,0		PT129990	
1EC8	C810 8000	3000	LHI	R1,X'8000'	SET UP R1 FIELD	PT130000	
1ECC	2440	3001	LIS	R4,0	R4 IS CHECK AGAINST NEW PSW	PT130010	
1ECE	4300 1CFE	3002	B	SET001		PT130020	
		3003 *				PT130030	
1ED2	C560 7E00	3004	CH12	CLHI	R6,X'7E00'	PT130040	
1ED6	4330 1EFC	3005	BE	CH13		PT130050	
1E0A	CA60 0200	3006	AHI	R6,X'200'	INCREMENT COUNTER FOR TOTAL PSW	PT130060	
1EDE	0826	3007	LHR	R2,R6	SET UP R2 FIELD	PT130070	
1EE0	C620 00F0	3008	OHI	R2,X'00F0'	OR IN CHECK BITS FOR PSW	PT130080	
1EE4	9552	3009	EPSR	R5,R2	SWITCH TO NEW PSW	PT130090	
1EE6	C420 FF70	3010	NHI	R2,X'FF70'	AND OFF EXTRANEOUS BITS	PT130100	
1EEA	0755	3011	XHR	R5,R5	RESET R5, TO BE PSW AT COMPAR. ROUT.	PT130110	
1EEC	C620 4C00	3012	OHI	R2,X'4C00'	OR IN CHECK BITS	PT130120	
1EF0	08F2	3013	LHR	R15,R2	STORE R2 FIELD IN R15	PT130130	
1EF2	0846	3014	LHR	R4,R6	R4 TO CHECK NEW PSW	PT130140	
1EF4	C810 8000	3015	LHI	R1,X'8000'	SET UP R211 FIELD	PT130150	
1EF8	4300 1CFE	3016	B	SET001		PT130160	
1EFC	07CC	3017	CH13	XHR	R12,R12	PT130170	
1EFE	26A1	3018	AIS	R10,1	INCREMENT TEST INSTRU. FORMAT FLAG	PT130180	
1F00	C800 1D6E	3019	LHI	R11,SET0AB		PT130190	
1F04	4300 101E	3020	B	SET1		PT130200	
		3021 *				PT130210	
1F08	08AA	3022	SETERA8	LHR	R10,R10	PT130220	
1F0A	2134	3023	BNZS	SETERA18	IF FLAG NOT ZERO THEN SETM ERROR	PT130230	
1F0C	C800 051C	3024	LHI	R0,X'051C'	ERROR 1C05	PT130240	
1F10	2303	3025	BS	SETERRB		PT130250	
1F12	C800 061C	3026	SETERA1B	LHI	R0,X'061C'	PT130260	
1F16	C820 7C00	3027	SETERRB	LHI	R2,X'7C00'	PT130270	
1F1A	9552	3028	EPSR	R5,R2		PT130280	
1F1C	4000 22F2	3029	STH	R0,ERRIND		PT130290	
1F20	4300 2182	3030	B	ERROR		PT130300	
1F24	08AA	3031	SETERBB	LHR	R10,R10	PT130310	
1F26	2134	3032	BNZS	SETERB18	IF FLAG NOT ZERO THEN SETM ERROR	PT130320	
1F28	C800 071C	3033	LHI	R0,X'071C'	ERROR 1C07	PT130330	
1F2C	220B	3034	BS	SETERRB		PT130340	
1F2E	C800 081C	3035	SETERB1B	LHI	R0,X'081C'	PT130350	
1F32	22UE	3036	BS	SETERRB		PT130360	
1F34	C800 091C	3037	SETERC	LHI	R0,X'091C'	PT130370	
1F38	4300 1F16	3038	B	SETERRB		PT130380	
		3039 *				PT130390	
1F3C	0000	3040	RTWOFI	DC	0	PT130400	
1F3E	0000	3041	STOSETMB	DC	0	STORAGE AREA FOR SETM INSTRU.	PT130410
		3042 *				PT130420	
1F40	000A	3043	MESMEM1	DC	X'00A'	MESSAGE TO CHECK FOR GREATER	PT130430
1F42	FFFF	3044		DC	X'FFFF'	THAN 32K OF MEMORY	PT130440
1F44	454E 5445 5220 3020	3045		DC	C'ENTER 0 OR 1'	ENTER A ZERO FOR 32K OR	PT130450
1F4C	4F92 2031						
1F50	FFFF	3046		DC	X'FFFF'	LESS OF MEMORY	PT130460
1F52	000A	3047		DC	X'00A'	ENTER A ONE FOR 64K	PT130470

1F54 FFFF 0000 1F55	3048 DC X'FFFF' 3049 MESMEM2 EQU **-1 3050 * 3051 MEMSTO DCX 0 3052 * 3053 ***** 3054 * 3055 * THIS PART OF THE TEST CHECKS THE LPS AND LPSR INSTRUCTIONS. 3056 *	OR MORE OF MEMORY STORAGE AREA FOR MEMORY FLAG ***** THIS PART OF THE TEST CHECKS THE LPS AND LPSR INSTRUCTIONS.	PT130480 PT130490 PT130500 PT130510 PT130520 PT130530 PT130540 PT130550 PT130560 PT130570 PT130580 PT130590 PT130600 PT130610 PT130620 PT130630 PT130640 PT130650 PT130660 PT130670 PT130680 PT130690 PT130700 PT130710 PT130720 PT130730 PT130740 PT130750 PT130760 PT130770 PT130780 PT130790 PT130800 PT130810 PT130820 PT130830 PT130840 PT130850 PT130860 PT130870 PT130880 PT130890 PT130900 PT130910 PT130920 PT130930 PT130940 PT130950 PT130960 PT130970 PT130980
1F58 C850 7C00 1F5C 9525 1F5E C840 F0F0 1F62 C840 5C00 1F66 4040 1FC8 1F6A C830 1FC8 1F6E C200 1F72 1F72 3C10 1F74 1F76 1F76 7303 0000 ** F008 ** 1F7A 9515 1F7C C500 F0F0 1F80 4230 1FB8 1F84 0514 1F86 4230 1FAA 1F8A 0834 1F8C C200 1F90 1F90 3C10 1F92 1F94 1F94 3303 ** F008 ** 1F96 9515 1F98 C500 F0F0 1F9C 4230 1FC2 1FA0 0514 1FA2 4230 1FB6 1FA6 4300 1FCA 1FAA C800 0A1C 1FAE 4070 22F2 1FB2 4300 1CA6 1FB6 C800 0B1C 1FBA 2206 1FBC C800 0C1C 1FC0 2209 1FC2 C800 0D1C 1FC6 220C 1FC8 0000	3057 CHLPS LHI R5,X'7C00' 3058 EPSR R2,R5 3059 CHLPS1 LHI R0,X'F0F0' 3060 LHI R4,X'5C00' 3061 STH R4,MEMFLAG 3062 LHI R3,MEMFLAG 3063 LPSW LS 3064 LS DC X'3C10',LS1 3065 LS1 LPS O(R3) 3066 EPSR R1,R5 3067 CLHI R0,X'F0F0' 3068 BNE LERR2 3069 CLR R1,R4 3070 BNE LERR 3071 * 3072 LHR R3,R4 3073 LPSW LS2 3074 LS2 DC X'3C10',LS3 3075 LS3 LPSR R3 3076 EPSR R1,R5 3077 CLHI R0,X'F0F0' 3078 BNE LERR3 3079 CLR R1,R4 3080 BNE LERR1 3081 B TSTEND 3082 * 3083 LERR LHI R0,X'0A1C' 3084 SETERR1 STH R7,ERRIND 3085 B SETERR 3086 LERR1 LHI R0,X'0B1C' 3087 BS SETERR1 3088 LERR2 LHI R0,X'0C1C' 3089 BS SETERR1 3090 LERR3 LHI R0,X'0D1C' 3091 BS SETERR1 3092 * 3093 MEMFLAG DC X'0000' 3094 * 3095 ***** 3096 * 3097 * ALL THE TESTS IN PART 1 ARE DONE 3098 *	CHANGE PSW TO INSURE CORRECT MEMORY MODULE SET R1 FIELD EQUAL TO A CONSTANT R4 IS CHECK AGAINST R1 (NEW PSW) STORE NEW PSW IN MEMFLAG LOAD ADDR. OF TEST PSW LOAD A PSW CHANGE PSW WITH TEST INSTRUCTION GET PSW CHECK R1 FIELD IF NOT EQUAL BRANCH TO ERROR CHECK FOR CORRECT PSW IF NOT CORRECT BRANCH TO ERROR LOAD TEST PSW INTO R3 LOAD A PSW CHANGE PSW WITH TEST INSTRUCTION GET PSW CHECK R1 FIELD IF NOT EQUAL BRANCH TO ERROR CHECK FOR CORRECT PSW (R1) IF NOT CORRECT BRANCH TO ERROR1 ERROR 1C0A ERROR 1C0B ERROR 1C0C ERROR 1C0D STORAGE AREA FOR MEMORY FLAG ***** ALL THE TESTS IN PART 1 ARE DONE	

1FCA	4800 22DA	3099	TSTEND	LH	R0,TOTAL	PT130990
1FCE	2601	3100		AIS	R0,1	PT131000
1FD0	4000 22DA	3101		STH	R0,TOTAL	PT131010
1FD4	2431	3102		LIS	R3,1	PT131020
1FD6	DE <sup>30</sup> 22E5	3103		OC	R3,NORM	PT131030
1FDA	9400	3104		EXBR	R0,R0	PT131040
1FDC	9830	3105		WHR	R3,R0	PT131050
1FDE	9400	3106		EXBR	R0,R0	PT131060
1FE0	C500 FFFF	3107		CLHI	R0,X'FFFF'	PT131070
1FE4	4230 200C	3108		BNE	NOTFF	PT131080
1FE8	D320 22E6	3109	AGTRY	LB	R2,OUTDEV	PT131090
1FEC	9025	3110		SSR	R2,R5	PT131100
1FEE	4210 1FE8	3111		BTC	1,AGTRY	PT131110
1FF2	4240 1FE8	3112		BTC	4,AGTRY	PT131120
1FF6	C450 00FC	3113		NHI	R5,X'FC'	PT131130
1FFA	C550 000C	3114		CLHI	R5,X'0C'	PT131140
1FFE	223B	3115		BES	AGTRY	PT131150
2000	41F0 2076	3116		BAL	R15,TIM	PT131160
2004	4100 2088	3117		BAL	R13,PRTTOT	PT131170
2008	4300 0112	3118		B	ENTRY1	PT131180
	0000 200C	3119	NOTFF	EQU	*	PT131190
	200C D320 22E6	3120		LB	R2,OUTDEV	PT131200
2010	9025	3121		SSR	R2,R5	PT131210
2012	4210 2024	3122		BTC	1,DONE0	PT131220
2016	4240 2024	3123		BTC	4,DONE0	PT131230
201A	C450 00FC	3124		NHI	R5,X'FC'	PT131240
201E	C550 000C	3125		CLHI	R5,X'0C'	PT131250
2022	2136	3126		BNES	DONE	PT131260
2024	2451	3127	DONE0	LIS	R5,1	PT131270
2026	4050 22DE	3128		STH	R5,TTYOFF	PT131280
202A	4300 0334	3129		B	TEST1	PT131290
	0000 202E	3130	DONE	EQU	*	PT131300
202E	4500 010E	3131		CLH	R0,NTIMES	PT131310
2032	4250 030A	3132		BL	ENTRY3	PT131320
2036	4800 22DE	3133		LH	R0,TTYOFF	PT131330
203A	2353	3134		BZS	DONE11	PT131340
203C	41F0 2076	3135		BAL	R15,TIM	PT131350
	0000 2040	3136	DONE11	EQU	*	PT131360
2040	4840 22DC	3137		LH	R0,TOTERR	PT131370
2044	213F	3138		BNZS	DONE3	PT131380
2046	2440	3139		LIS	R4,0	PT131390
2048	C850 22C9	3140		LHI	R5,NOERRB	PT131400
204C	DE20 22E8	3141		OC	R2,OUTCMD	PT131410
2050	9023	3142	DONE12	SSR	R2,R3	PT131420
2052	2081	3143		BTBS	8,1	PT131430
2054	DA24 22BC	3144	DONE2	WD	R2,NOERRA(R4)	PT131440
2058	C554 22BC	3145		CLHI	R5,NOERRA(R4)	PT131450
205C	2353	3146		BES	DONE3	PT131460
205E	2641	3147		AIS	R4,1	PT131470
2060	2208	3148		BS	DONE12	PT131480
	0000 2062	3149	DONE3	EQU	*	PT131490
2062	4840 22DE	3150		LH	R0,TTYOFF	PT131500
2066	4300 0112	3151		BZ	ENTRY1	PT131510
206A	41F0 2076	3152		BAL	R15,TIM	PT131520
206E	4100 2088	3153		BAL	R13,PRTTOT	PT131530

TOTAL INTO CONSOLE IND.

R5 = TTY STATUS

TTYOFF = 1 AND

2072	4300 20E2	3154	TOWT	B	WT000F	PT131540
	0000 2076	3155	TIM	EQU	*	PT131550
2076	C800 FFFF	3156	LHI	R0,X'FFFF'		PT131560
207A	2701	3157	TIME	SIS	R0,1	PT131570
207C	2031	3158	BNZS	TIME		PT131580
207E	C800 FFFF	3159	LHI	R0,X'FFFF'		PT131590
2082	2701	3160	TIME2	SIS	R0,1	PT131600
2084	2031	3161	BNZS	TIME2		PT131610
2086	030F	3162	BR	R15		PT131620
2088	C800 00FF	3163	PRTTOT	LHI	R0,X'FF'	PT131630
208C	41E0 211A	3164	BAL	R14,WRITE1		PT131640
2090	41E0 211A	3165	BAL	R14,WRITE1		PT131650
2094	41E0 211A	3166	BAL	R14,WRITE1		PT131660
2098	240D	3167	LIS	R0,13		PT131670
209A	41E0 211A	3168	BAL	R14,WRITE1		PT131680
209E	C800 00FF	3169	LHI	R0,X'FF'		PT131690
20A2	41E0 211A	3170	BAL	R14,WRITE1		PT131700
20A6	240A	3171	LIS	R0,10		PT131710
20A8	41E0 211A	3172	BAL	R14,WRITE1		PT131720
20AC	48F0 220A	3173	LH	R15 TOTAL	PRINT TOTAL	PT131730
20B0	41C0 20EA	3174	BAL	R12,PRNTRF		PT131740
20B4	C800 0020	3175	LHI	R0,X'20'		PT131750
20B8	41E0 211A	3176	BAL	R14,WRITE1		PT131760
20BC	41E0 211A	3177	BAL	R14,WRITE1		PT131770
20C0	41E0 211A	3178	BAL	R14,WRITE1		PT131780
20C4	41E0 211A	3179	BAL	R14,WRITE1		PT131790
20C8	48F0 220C	3180	LH	R15 TOTERR	PRINT TOTERR	PT131800
20CC	41C0 20EA	3181	BAL	R12,PRNTRF		PT131810
2000	240D	3182	LIS	R0,13		PT131820
20D2	41E0 211A	3183	BAL	R14,WRITE1		PT131830
20D6	41E0 211A	3184	BAL	R14,WRITE1		PT131840
20DA	240A	3185	LIS	R0,10		PT131850
20DC	41E0 211A	3186	BAL	R14,WRITE1		PT131860
20E0	030D	3187	BR	R13		PT131870
	0000 20E2	3188	WT000F	EQU	*	PT131880
20E2	4300 0112	3189	B	ENTRY1	NO OP THIS BRANCH TO BYPASS	PT131890
20E6	4300 030A	3190	B	ENTRY3	INITIAL SET UP	PT131900
		3191	*			PT131910
		3192	*	PRINT THE CONTENTS OF REG. 15 IN HEX.		PT131920
		3193	*			PT131930
		3194	*	EXIT ON R12		PT131940
		3195	*			PT131950
20EA	080F	3196	PRNTRF	LHR	R0,R15	PT131960
20EC	900C	3197	SRLS	R0,12		PT131970
20EE	41E0 210A	3198	BAL	R14,PRNTR0		PT131980
20F2	080F	3199	LHR	R0,R15		PT131990
20F4	9008	3200	SRLS	R0,8		PT132000
20F6	41E0 210A	3201	BAL	R14,PRNTR0		PT132010
20FA	080F	3202	LHR	R0,R15		PT132020
20FC	9004	3203	SRLS	R0,4		PT132030
20FE	41E0 210A	3204	BAL	R14,PRNTR0		PT132040
2102	080F	3205	LHR	R0,R15		PT132050
2104	41E0 210A	3206	BAL	R14,PRNTR0		PT132060
2108	030C	3207	BR	R12		PT132070
210A	C400 000F	3208	PRNTR0	NHI	R0,15	PT132080

210E	CA00 0030	3209	AHI	R0,X'30'	PT132090	
2112	C500 003A	3210	CLHI	R0,X'3A'	PT132100	
2116	2182	3211	BLS	WRITE1	PT132110	
2118	2607	3212	AIS	R0,7	PT132120	
211A	0320 22E6	3213	WRITE1	LB R2,OUTDEV	PT132130	
211E	DE20 22E8	3214	OC	R2,OUTCMD	PT132140	
2122	9023	3215	WRIT	SSR R2,R3	PT132150	
2124	021E	3216	BTCR	1,R14	PT132160	
2126	4280 2122	3217	BTC	8,WRIT	PT132170	
212A	9A20	3218	WDR	R2,R0	PT132180	
212C	030E	3219	BR	R14	PT132190	
		3220	*		PT132200	
		3221	*****	*****	PT132210	
		3222	*		PT132220	
		3223	*	AN INTERRUPT IS DETECTED	PT132230	
		3224	*		PT132240	
212E	24F1	3225	FLPTNT	LIS R15,1	FLPT ARITH. FAULT INTRPT.	PT132250
2130	2309	3226	BS	ERRF	PT132260	
2132	24F2	3227	ILGINT	LIS R15,2	ILL. INSTR. INTRPT.	PT132270
2134	2307	3228	BS	ERRF	PT132280	
2136	24F3	3229	MALFTN	LIS R15,3	MACH. MALFTN. INTRPT.	PT132290
2138	2305	3230	BS	ERRF	PT132300	
213A	24F4	3231	EXTINT	LIS R15,4	EXTERNAL INTERRUPT	PT132310
213C	9FAB	3232	AIR	R10,R11	PT132320	
213E	2302	3233	BS	ERRF	PT132330	
2140	24F5	3234	DVDFLT	LIS R15,5	FIXD. PT. DIV. FAULT INTRPT	PT132340
2142	2309	3235	ERRF	BS ERRORF	PT132350	
2144	24F6	3236	CHANIO	LIS R15,6	CHAN. I/O TERM. INTRPT.	PT132360
2146	2307	3237	BS	ERRORF	PT132370	
2148	24F7	3238	QVRFLO	LIS R15,7	QUEUE OVERFLO INTRPT.	PT132380
214A	2305	3239	BS	ERRORF	PT132390	
214C	24F8	3240	SVCERR	LIS R15,8	PT132400	
214E	2303	3241	BS	ERRORF	PT132410	
2150	0000	3242	DEVERR	DC 0	PT132420	
2152	24F9	3243	LIS	R15,9	PT132430	
2154	C6F0 00F0	3244	ERRORF	OHI R15,X'F0'	PT132440	
2158	D2F0 22F2	3245	STB	R15,ERRIND	PT132450	
215C	C800 0046	3246	LHI	R13,X'46'	PT132460	
2160	91D8	3247	SLIS	R13,8	PT132470	
2162	C4F0 000F	3248	NHI	R15,X'000F'	PT132480	
2166	C6F0 0030	3249	OHI	R15,X'30'	PT132490	
216A	06FD	3250	OHR	R15,R13	PT132500	
216C	40F0 22BA	3251	STH	R15,ERRNO	PT132510	
2170	2431	3252	LIS	R3,1	PT132520	
2172	D830 22F2	3253	WH	R3,ERRIND	PT132530	
2176	C200 217A	3254	LPSW	WAITF	PT132540	
217A	8000	3255	WAITF	DC X'8000',ERFSS	PT132550	
217C	217E	3256	*		PT132560	
217E	4300 21C6	3257	ERFSS	B ERROF	PT132570	
		3258	*		PT132580	
		3259	*	NXTST = RETURN ADD. IF TTY IS TURNED OFF	PT132590	
		3260	*		PT132600	
		3261	*	R14 = PSW WHEN THE ERROR OCCURED	PT132610	
		3262	*		PT132620	

		3263 *	ERRINO = ERROR NO. INTO IND.	PT132630	
		3264 *		PT132640	
		3265 *	TESTNO = 31NN , NN = TEST NO. 1 THRU E	PT132650	
		3266 *		PT132660	
	0000 2182	3267 ERROR	EQU *	PT132670	
2182	D000 2344	3268 ERRA	STM R0,REGSAV	SAVE REGISTERS	PT132680
2186	95EE	3269 EFSR	R14,R14	STORE CURRENT PSW	PT132690
2188	2431	3270 LIS	R3,1	R3 = 1 = CONSOLE ADDRESS	PT132700
218A	D890 22F2	3271 WH	R3,ERRIND	ERRNO. INTO CONSOLE IND.	PT132710
218E	D3U0 22F2	3272 ERRA6	LB R0,ERRIND	CONVERT ERRIND INTO	PT132720
2192	C850 0030	3273 LHI	R5,X'30'		PT132730
2196	C500 0010	3274 CLHI	R0,16	TWO BYTES TO PRINT	PT132740
219A	2383	3275 BNLS	ERRB		PT132750
219C	0805	3276 LHR	R0,R5		PT132760
219E	2307	3277 BS	ERRB2		PT132770
21A0	9004	3278 ERRB	SRLS R0,4		PT132780
21A2	0A05	3279 AHR	R0,R5		PT132790
21A4	C500 003A	3280 CLHI	R0,X'3A'		PT132800
21A8	2182	3281 BLS	ERRB2		PT132810
21AA	2607	3282 AIS	R0,7		PT132820
		3283 *			PT132830
		3284 *	ERRNO = 2 BYTES TO PRINT		PT132840
		3285 *			PT132850
21AC	D200 22BA	3286 ERRB2	STB R0,ERRNO		PT132860
21B0	D300 22F2	3287 LB	R0,ERRIND		PT132870
21B4	C400 000F	3288 ERRB4	NHI R0,15		PT132880
21B8	0A05	3289 AHR	R0,R5		PT132890
21BA	C500 003A	3290 CLHI	R0,X'3A'		PT132900
21BE	2182	3291 BLS	ERRB6		PT132910
21C0	2607	3292 AIS	R0,7		PT132920
21C2	D200 22BB	3293 ERRB6	STB R0,ERRNO+1		PT132930
	0000 21C6	3294 ERROF	EQU *		PT132940
21C6	4800 22DC	3295 LH	R0,TOTERR	COUNT TOTAL ERRORS	PT132950
21CA	2601	3296 AIS	R0,1		PT132960
21CC	4000 22DC	3297 STH	R0,TOTERR		PT132970
21D0	C500 FFFF	3298 CLHI	R0,X'FFFF'	IF TOTERR = FFFF	PT132980
21D4	4330 21FE	3299 BE	WTFFFF		PT132990
21D8	D320 22E6	3300 LB	R2,OUTDEV		PT133000
21DC	9D23	3301 SSR	R2,R3		PT133010
21DE	4250 21F0	3302 BTC	S,NEXT		PT133020
21E2	C430 00FC	3303 NHI	R3,X'FC'		PT133030
21E6	C530 000C	3304 CLHI	R3,X'0C'		PT133040
21EA	2343	3305 BES	NEXT		PT133050
21EC	4300 2232	3306 B	PRTRR		PT133060
21F0	4800 22F4	3307 NEXT	LH R0,NXTST	IF TTY IS OFF GO TO NEXT TEST	PT133070
21F4	C500 0334	3308 CLHI	R0,TEST1		PT133080
21F8	4390 1FCA	3309 BE	TSTEND		PT133090
21FC	0300	3310 BR	R0	CONTINUE THE NEXT TEST	PT133100
21FE	2431	3311 WTFFFF	LIS R3,1	FFFF INTO CO-S-LE &ND.	PT133110
2200	9830	3312 WHR	R3,R0		PT133120
2202	C200 2206	3313 LPSW	WAITFF		PT133130
2206	8000	3314 WAITFF	DC X'8000',CONT	WAIT UNTIL EXE IS DEPRESSED	PT133140
2208	220A				
220A	D320 22E6	3315 CONT	LB R2,OUTDEV		PT133150
220E	DE20 22E8	3316 OC	R2,OUTCMD		PT133160

2212	9D25	3317	SSR	R2,R5	PT133170	
2214	4210 21FE	3318	BTC	1,WTFFFF	PT133180	
2218	C450 00FC	3319	NHI	R5,X'FC'	PT133190	
221C	C550 000C	3320	CLHI	R5,X'0C'	PT133200	
2220	4330 21FE	3321	BE	WTFFFF	PT133210	
2224	C840 229C	3322	LHI	R4,FFFF	PT133220	
2228	C850 22AD	3323	LHI	R5,FFFFRR	PT133230	
222C	9624	3324	WBR	R2,R4	PT133240	
222E	4300 20E2	3325	B	WT000F	PT133250	
2232	C840 22AE	3326	PRTERR		PT133260	
2236	D320 22E6	3327	LB	R2,OUTDEV	PT133270	
223A	DE20 22E8	3328	OC	R2,OUTCMD	PT133280	
		3329	*		PT133290	
	0040 223E	3330	PRTTR	EQU *	PT133300	
		3331	*		PT133310	
223E	D320 22E6	3332	LB	R2,OUTDEV	PT133320	
2242	DE20 22E8	3333	OC	R2,OUTCMD	PT133330	
2246	9D23	3334	PRTBSY	SSR R2,R3	PT133340	
2248	2081	3335	BTBS	8,1	PT133350	
224A	DA24 0000	3336	WD	R2,0(R4)	PT133360	
224E	2641	3337	AIS	R4,1	PT133370	
2250	C540 22BE	3338	CLHI	R4,ERRNO+4	PT133380	
2254	203B	3339	BNES	PRTTR	PT133390	
2256	48D0 22BA	3340	LH	R13,ERRNO	PT133400	
225A	C4D0 4600	3341	NHI	R13,X'4600'	PT133410	
225E	C5D0 4600	3342	CLHI	R13,X'4600'	PT133420	
2262	4330 2296	3343	BE	PRTEND	PT133430	
2266	D300 22B9	3344	LB	R0,TESTNO+1	PT133440	
226A	C500 0038	3345	CLHI	R0,C'B'	PT133450	
226E	2335	3346	BES	TST812	PT133460	
2270	C500 0042	3347	CLHI	R0,C'B'	IF IT IS NOT TEST11	PT133470
2274	4230 2296	3348	BNE	PRTEND	BRANCH TO PRTEND	PT133480
2278	C870 234C	3349	TST812	LHI R7,REGSAV+8	GET THE POINTER TO REG SAVE AREA	PT133490
227C	4887 0000	3350	LH	R8,0(R7)	NUMBER OF REGISTERS TO BE PRINTED	PT133500
2280	26/2	3351	LOOPXX	AIS R7,2	INCREMENT THE POINTER	PT133510
2282	48F7 0000	3352	LH	R15,0(R7)	GET THE REGISTER CONTENTS	PT133520
2286	41C0 20EA	3353	BAL	R12,PRNTRF	PRINT THE CONTENTS	PT133530
228A	C800 0020	3354	LHI	R0,X'20'	PT133540	
228E	41E0 211A	3355	BAL	R14,WRITE1	PT133550	
2292	2781	3356	SIS	R8,1	PT133560	
2294	203A	3357	BNZS	LOOPXX	IF NOT DONE GO TO LOOPXX	PT133570
2296	2404	3358	PRTEND	LIS R0,4	PT133580	
2298	4300 2062	3359	B	DONE3	PT133590	
		3360	*		PT133600	
229C	0D0A	3361	FFFF	DC X'D0A'	PT133610	
229E	4646 4646 2045 5252	3362	DC	C'FFFF ERRORS'	PT133620	
22A6	4F52 5320					
22AA	0D0A	3363	DC	X'D0A'	PT133630	
22AC	FFFF	3364	DCX	FFFF	PT133640	
	0000 22AD	3365	FFFFRR	EQU **-1	PT133650	
22AE	0D0A	3366	PRTERR	DC X'D0A'	PT133660	
22B0	4552 524F 5220	3367	DC	C'ERROR '	PT133670	
22B6	2000	3368	DC	X'2000'	PT133680	
22B8	3130	3369	TESTNO	DC X'3130'	PT133690	
22BA	3030	3370	ERRNO	DC X'3030'	PT133700	

22BC	000A	3371	NOERRA	DC	X'D0A'	PT133710
22BE	4E4F 2045 5252 4F52	3372		DC	C'NO ERROR'	PT133720
22C6	0DVA	3373		DC	X'D0A'	PT133730
22C8	FFFF	3374		DCX	FFFF	PT133740
	0000 22C9	3375	NOERRB	EQU	*-1	PT133750
		3376	*			PT133760
		3377	*			PT133770
		3378	*****		*****	PT133780
		3379	*			PT133790
		3380	*		DATA CONSTANTS	PT133800
		3381	*			PT133810
		3382	*****		*****	PT133820
		3383	*			PT133830
22CA	0000	3384		DC	0	PT133840
22CC	0000	3385	TABLE	DC	0	PT133850
22CE	0000	3386		DC	0	PT133860
22D0	0000	3387		DC	0	PT133870
22D2	0000	3388		DC	0	PT133880
22D4	0000	3389		DC	0	PT133890
22D6	0040	3390		DC	0	PT133900
22D8	0000	3391	TEMP	DC	0	PT133910
22DA	0040	3392	TOTAL	DC	0	PT133920
22DC	00U0	3393	TOTERR	DC	0	PT133930
22DE	0000	3394	TTYOFF	DC	0	PT133940
22E0	0000	3395	CPUNO	DC	0	PT133950
22E2	0000	3396	CPUFLAG	DCX	0	PT133960
22E4	00	3397	M7DSWT	DB	0	PT133970
22E5	80	3398	NORM	DB	X'80'	PT133980
		3399	*			PT133990
		3400	*****		*****	PT134000
		3401	*			PT134010
22E6	02	3402	OUTDEV	DB	2	OUTDEV = 2 = TTY ADDRESS
22E7	A4	3403	INCMND	DB	X'A4'	READ COMMAND FOR TTY
22E8	A8	3404	OUTCMD	DB	X'A8'	PT134030
22EA	ABB9	3405	CRTOUT	DCX	ABB9	PT134040
22EC	C8E4	3406	CONOUT	DCX	C8E4	PT134050
22EE	0000	3407	CRTFLG	DCX	0	PT134060
22F0	UUVO	3408	FIRSTCMD	DCX	0	PT134070
22F2		3409		DB	*	PT134080
22F2	00U0	3410	ERRIND	DC	0	PT134090
22F4	00U0	3411	NXTST	DC	0	PT134100
		3412	*			PT134110
		3413	ZERO	DC	0	PT134120
22F8	0000	3414		DC	0	PT134130
22FA	FFFF	3415	ONE	DC	X'FFFF'	PT134140
22FC	0000	3416		DC	0	PT134150
22FE	5555	3417	FIVE	DC	X'5555'	PT134160
2300	U000	3418		DC	0	PT134170
2302	AAAA	3419	TEN	DC	X'AAAA'	PT134180
2304	UUUV	3420		DC	0	PT134190
		3421	*			PT134200
2306	00	3422	TITLE1	DB	13	CR
2307	0A	3423		DB	10	LF
2308	404F 4445 4C20 382F	3424		DC	C'MODEL 8/16E PROCESSOR TEST PART 1 06-211R00'	PT134220
2310	3196 4520 5052 4F43					PT134230
						PT134240

2318	4553	534F	5220	5445					
2320	5354	2050	4152	5420					
2328	3120	2030	3620	3231					
2330	3152	3030							
2334	FFFF		3425	TITLE2	DCX	FFFF			PT134250
2336	000A		3426		DCX	000A			PT134260
2338	FF1F		3427		DCX	FFFF			PT134270
233A	4350	5520	3428		DC	C'CPU'			PT134280
233E	000A		3429		DCX	000A			PT134290
2340	2A		3430		DB	C'*'	*		PT134300
2342	FFFF		3431		DCX	FFFF			PT134310
	0000	2344	3432	TITEND	EQU	*			PT134320
	0000	2344	3433	LNZB	EQU	*			PT134330
2344			3434	REGSAV	DS	32			PT134340
			3435	*	CHKSUM				PT134350
			3436	*	(THE FOLLOWING CODE IS NOT PART OF THE TEST.)				PT134360
			3437	*					PT134370
			3438	*					PT134380
2364	2400		3439	\$CHKSUM	LIS	R0,0	PUNCH M17 TAPE WITH CHECKSUM		PT134390
2366	9510		3440		EPSR	R1,R0	SELECT REG. SET 0		PT134400
			3441	*					PT134410
2368	C810	0100	3442		LDAI	R1,ORIGIN1	START		PT134420
236C	2421		3443		LIS	R2,1	INCREMENT		PT134430
236E	C830	2344	3444		LDAI	R3,LNZB	FINAL		PT134440
2372	2440		3445		LIS	R4,0	CHECKSUM BYTE		PT134450
2374	D351	0000	3446	\$GEN	LB	R5,0(R1)			PT134460
2378	0745		3447		XAR	R4,R5			PT134470
237A	C110	2374	3448		BXLE	R1,\$GEN			PT134480
237E	D240	0097	3449		STB	R4,MN+3	CHECKSUM BYTE TO BOOT LOADER		PT134490
			3450	*					PT134500
2382	C810	0080	3451	\$TAPE	LHI	R1,X'0080'			PT134510
2386	9E21		3452		OCR	R2,R1	DISPLAY : NORMAL MODE		PT134520
2388	9444		3453		EXBR	R4,R4			PT134530
238A	9824		3454		WHR	R2,R4	CHECKSUM BYTE TO D1		PT134540
238C	9411		3455		EXBR	R1,R1			PT134550
238E	9501		3456		EPSR	R0,R1	HALT PROCESSOR.		PT134560
2390	D360	007A	3458	\$PUNCH	LB	R6,X'7A'	GET BOUTDV (PUNCH) ADDRESS.		PT134580
2394	DE60	007B	3459		OC	R6,X'7B'	START TAPE PUNCH		PT134590
2398	9D60		3460		SSR	R6,R0			PT134600
239A	2081		3461		BTBS	8,1			PT134610
239C	41F0	23DE	3462		BAL	R15,\$TAPL	PUNCH LEADER		PT134620
23A0	9411		3463		EXBR	R1,R1	(R1) = X'0080'		PT134630
23A2	C850	00CF	3464		LHI	R3,X'CF'			PT134640
23A6	DA61	0000	3465	\$PNCH1	WD	R6,0(R1)	PUNCH BOOT LOADER		PT134650
23AA	9D60		3466		SSR	R6,R0			PT134660
23AC	2081		3467		BTBS	8,1			PT134670
23AE	C110	23A6	3468		BXLE	R1,\$PNCH1			PT134680
23B2	41F0	23E4	3469		BAL	R15,\$TAPL1	PUNCH ONE-FOLD GAP.		PT134690
			3470	*					PT134700
23B6	D340	0097	3471		LB	R4,MN+3	GET CHECKSUM BYTE		PT134710
23BA	C810	0100	3472		LDAI	R1,ORIGIN1	(NORMALLY X'A00')		PT134720
23BE	C850	2344	3473		LDAI	R3,LNZB			PT134730
23C2	D351	0000	3474	\$PNCH2	LB	R5,0(R1)	PUNCH PROGRAM		PT134740

23C6 0745	3475	XAR R4,R5	PT134750	
23C8 9A65	3476	WDR R6,R5	PT134760	
23CA 9401	3477	EXBR R0,R1	PT134770	
23CC 9840	3478	WHR R2,R0	PT134780	
23CE 9D60	3479	SSR R6,R0	PT134790	
23D0 2081	3480	BTBS 8,1	PT134800	
23D2 C110 23C2	3481	BXLE R1,\$PNCH2	PT134810	
23D6 41F0 23DE	3482	BAL R15+\$TAPL	PT134820	
23DA 4300 2382	3483	B \$TAPE	PT134830	
		DATA ADDRESS TO DISPLAY.		
		PUNCH TRAILER.		
		DISPLAY CHECKSUM, HALT PROCESSOR.		
23DE C800 0100	3485 \$TAPL	LHI R0,256	TO PUNCH BLANK LEADER	PT134850
23E2 2303	3486 BS	\$TAPLP		PT134860
23E4 C800 0055	3487 \$TAPL1	LHI R0,85	TO PUNCH 1-FOLD GAP	PT134870
23E8 2701	3488 \$TAPLP	SIS R0,1		PT134880
23EA 032F	3489 BNPR	R15	RETURN	PT134890
23EC 2430	3490 LIS	R3,0		PT134900
23EE 9A63	3491 WDR	R6,R3	PUNCH BLANK FRAME	PT134910
23F0 9D68	3492 SSK	R6,R8		PT134920
23F2 2081	3493 BTBS	8,1		PT134930
23F4 2206	3494 BS	\$TAPLP	CONTINUE.	PT134940
23F6	3495 *			PT134950
	3496 END			PT134960

ASSEMBLED BY CAL 03-066R05-00 (32-BIT)

START OPTIONS: \*NONE\*

2 CAL ERRORS PREVIOUS ERROR ON PAGE 58  
NO CAL WARNINGS  
2 PASSES

\$CHKSUM	0000	2364	3439*			
\$GEN	0000	2374	3446*	3448		
\$PNCH1	0000	23A6	3465*	3468		
\$PNCH2	0000	23C2	3474*	3481		
\$PUNCH	0000	2390	3458*			
\$TAPE	0000	2382	3451*	3483		
\$TAPL	0000	23DE	3462	3482	3485*	
\$TAPL1	0000	23E4	3469	3487*		
\$TAPLP	0000	23E8	3486	3488*	3494	
ABSTUP	0000	23F6				
ACH	0000	1048	1622*			
ADC	0000	0002				
AGTRY	0000	1FE8	3109*	3111	3112	3115
AH	0000	0F38	1529*			
AHI	0000	0F96	1561*			
AHM	0000	11B8	1749*			
AHR	0000	0F9E	1564*			
AIS	0000	0FDE	1586*			
BAL	0000	09D2	996*			
BALR	0000	0AFA	1105*			
BFC	0000	037C	274*			
BFCR	0000	0ACC	1085*			
BFFS	0000	03E4	301*			
BOOT	0000	0088	38	41*		
BR	0000	0A7A	1053*			
BTBS	0000	049E	392*			
BTC	0000	036C	269*			
BTCR	0000	0AD2	1088*			
BTFS	0000	0492	385*			
BXH	0000	0A60	1044*			
BXLE	0000	0A02	1014*			
CAR	0000	0108	72*			
CD1	0000	12A2	1558	1662	1670	1685
CD2	0000	12A4	1598	1709	1833*	
CD3	0000	12A6	1511	1530	1536	1550
CD4	0000	12A8	1537	1549	1559	1579
CD5	0000	12AA	1527	1554	1606	1664
CD6	0000	12AC	1528	1584	1684	1693
CD7	0000	12AE	1546	1569	1599	1665
CD8	0000	12B0	1512	1523	1538	1560
CH	0000	1E88	2975	2978*		
CH11	0000	1EB2	2979	2992*		
CH12	0000	1ED2	2976	3004*		
CH13	0000	1EFC	2977	3005	3017*	
CHANIO	0000	2144	104	3236*		
CHANST	0000	1CC0	2708	2816*		
CHBYT	0000	1CDC	2824*	2829		

CHF1	0000 10CC	2893	2915*					
CHF3	0000 1E04	2916	2932*					
CHFI	0000 1C12	2745	2754*					
CHLPS	0000 1F58	2818	2839	3057*				
CHLPS1	0000 1F5E	2820	3059*					
CLB	0000 00AC	1373*						
CLH	0000 058C	505*						
CLHI	0000 05A8	516*						
CLHR	0000 0574	493*						
CONADR	0000 010A	73*	134					
CONOUT	0000 22EC	135	3406*					
CONT	0000 220A	3314	3315*					
CPUERR	0000 0284	190*						
CPUFLAG	0000 22E2	149	161	193	3396*			
CPUUNO	0000 22E0	195	1947	2403	3395*			
CRT	0000 0106	71*						
CRTFLG	0000 22EE	127	133	163	210	3407*		
CRTIO	0000 0196	115	118*					
CRTOUT	0000 22EA	121	124		3405*			
DEVERR	0000 2150	3242*						
DFAULT	0000 19FE	2512	2587*					
DH	0000 196C	2530*						
DHR	0000 195E	2523*						
DIVD2	0000 1A9C	2516	2635*					
DLOOP2	0000 1952	2518*	2535					
DOCOMP	0000 1E32	2879	2918	2950*				
DONE	0000 202E	3126	3130*					
DONE0	0000 2024	3122	3123	3127*				
DONE11	0000 2040	3134	3136*					
DONE12	0000 2050	3142*	3148					
DONE2	0000 2054	3144*						
DONE3	0000 2062	3138	3146	3149*	3359			
DVDCHK	0000 1938	2510*						
DVDFLT	0000 2140	100	3234*					
ENT3A	0000 0312	237*						
ENT3B	0000 032C	240	243	245*				
ENTRY1	0000 0112	68	81*	3118	3151	3189		
ENTRY2	0000 02AA	142	145	147	201*			
ENTRY3	0000 030A	234*	3132	3190				
ENTRY4	0000 02FA	229*						
EPSR	0000 082E	1135*						
ERFSS	0000 217E	3255	3257*					
ERR1	0000 1292	1807	1816	1821	1825	1826*		
ERR11	0000 1258	1760	1767	1774	1803*			
ERR12	0000 1264	1790	1801	1808*				
ERR13	0000 127C	1635	1637	1639	1653	1655	1657	1817*
ERR14	0000 1288	1743	1822*					
ERR2	0000 19EE	2570	2582*					
ERR21	0000 198A	2540	2542	2544	2558*			
ERRA	0000 2182	3268*						
ERRA6	0000 218E	3272*						
ERRB	0000 21A0	3275	3278*					
ERRB2	0000 21AC	3277	3281	3286*				
ERRB4	0000 21B4	3288*						
ERRB6	0000 21C2	3291	3293*					

MODEL 8/16E PROCESSOR TEST PART 1 06-211M96R00A13 PAGE 69 09:54:45 11/04/78

MODEL 8/16E PROCESSOR TEST PART 1 06-211M95R00A13

PAGE 70 09:54:45 11/04/78

MODEL 8/16E PROCESSOR TEST PART 1 06-211M96B00A13

PAGE : 71 09:54:45 11/04/78

## MODEL 8/16E PROCESSOR TEST PART 1 06-211M96R00A13

PAGE 72 09:54:45 11/04/78

		3287	3288	3289	3290	3292	3293	3295	3296	3297	3298	3307	3308	341~
		3312	3344	3345	3347	3354	3358	3439	3440	3456	3460	3466	3477	3478
		3479	3485	3487	3488									
R1	0000 0001	15*	42	52	53	55	60	121	122	123	125	130	131	132
		133	134	137	178	179	181	464	466	588	592	656	999	1000
		1024	1060	1066	1066	1075	1083	1084	1084	1092	1098	1136	1137	1139
		1143	1145	1147	1147	1149	1152	1153	1158	1158	1160	1160	1358	1362
		1365	1371	1388	1392	1425	1478	1478	1483	1487	1487	1492	1496	1500
		1503	1558	1565	1612	1612	1625	1636	1643	1654	1654	1662	1670	1684
		1686	1689	1690	1693	1694	1698	1699	1708	1709	1713	1716	1730	1732
		1751	1753	1757	1762	1766	1769	1773	1776	1787	1806	1811	1819	1871
		1880	1881	1882	1883	1884	1885	1886	1920	1921	1926	1970	1971	1971
		1985	1986	1994	2418	2424	2437	2443	2459	2465	2477	2484	2492	2498
		2521	2528	2543	2551	2563	2574	2596	2597	2709	2714	2725	2726	2734
		2766	2767	2776	2840	2845	2860	2860	2870	2871	2882	2899	2899	2945
		2945	2950	2964	2989	3000	3015	3066	3069	3076	3079	3440	3442	3446
		3448	3451	3452	3455	3455	3456	3463	3463	3465	3468	3472	3474	3477
		3481												
R10	0000 000A	24*	482	483	486	489	494	511	514	523	524	528	529	756
		764	774	802	1333	1334	1336	1360	1364	1369	1377	1480	1489	1500
		1505	1809	1958	1968	1968	1973	2422	2427	2440	2441	2446	2447	2462
		2463	2468	2469	2481	2482	2487	2488	2496	2502	2518	2520	2527	2545
		2563	2572	2575	2600	2700	2700	2705	2739	2781	2797	2800	2800	2807
		2807	2833	2833	2836	2887	2969	3018	3022	3022	3031	3031	3232	
R11	0000 000B	25*	549	553	1407	1408	1411	1415	1418	1425	1429	1810	1960	1978
		1978	1980	1990	2521	2528	2560	2579	2580	2712	2715	2728	2768	2794
		2843	2846	2861	2961	3019	3232							
R12	0000 000C	26*	551	555	1412	1416	1420	1426	1432	1497	1501	1504	1509	1509
		1526	1535	1548	1553	1557	1567	1581	1596	1605	1667	1683	1688	1707
		1711	1729	1734	1742	1824	2419	2419	2425	2425	2438	2438	2444	2444
		2460	2460	2466	2466	2478	2478	2485	2485	2493	2493	2499	2499	2524
		2539	2559	2561	2573	2576	2820	2826	2960	2974	2993	3017	3017	3174
		3181	3207	3353										
R13	0000 000D	27*	537	540	1413	1417	1422	1427	1434	1627	1632	1777	1793	2549
		2558	2575	2577	2729	2755	2823	2824	2825	2826	2828	2862	2879	3117
		3153	3187	3246	3247	3250	3340	3341	3342					
R14	0000 000E	28*	156	191	197	199	202	202	220	221	222	224	226	227
		544	547	625	642	666	1498	1506	1628	1629	1740	1740	1741	1742
		1823	2538	2538	2539	2551	2558	2559	2580	2581	2593	2599	2694	2714
		2816	2817	2834	2845	3164	3165	3166	3168	3170	3172	3176	3177	3178
		3179	3183	3184	3186	3198	3201	3204	3206	3216	3219	3269	3269	3355
R15	0000 000F	29*	500	501	520	521	547	608	623	640	662	757	762	767
		771	792	797	815	819	841	861	867	872	877	880	884	889
		890	895	899	936	950	952	955	961	973	2553	2695	2696	2824
		2825	2841	2854	2876	2890	2904	2912	2928	2942	2957	2972	2987	2998
		3013	3116	3135	3152	3162	3173	3180	3196	3199	3202	3205	3225	3227
		3229	3231	3234	3236	3238	3240	3243	3244	3245	3248	3249	3250	3251
		3352	3462	3469	3482	3489								
R2	0000 0002	16*	37	41	56	62	124	135	138	139	140	141	146	165
		166	167	171	172	174	176	178	205	206	207	209	212	213
		214	217	218	220	238	239	466	467	589	593	600	659	1004
		1005	1074	1075	1389	1394	1427	1479	1479	1484	1488	1488	1493	1505
		1598	1602	1613	1613	1624	1634	1642	1652	1652	1663	1673	1685	1686
		1696	1702	1714	1716	1726	1731	1735	1752	1812	1820	2429	2429	2430
		2435	2436	2453	2453	2454	2457	2458	2471	2471	2472	2475	2476	2510

## MODEL 8/16E PROCESSOR TEST PART 1 06-211M96R00A13 PAGE 73 09:54:45 11/04/78

		2510	2511	2514	2515	2517	2534	2592	2592	2599	2709	2710	2713	2721
		2721	2722	2723	2736	2737	2741	2742	2747	2748	2749	2750	2770	2771
		2772	2773	2778	2779	2783	2784	2789	2790	2791	2831	2832	2840	2841
		2844	2850	2851	2852	2853	2854	2868	2869	2874	2875	2876	2884	2885
		2889	2890	2900	2901	2903	2904	2906	2907	2908	2909	2911	2912	2926
		2927	2928	2940	2941	2942	2952	2953	2955	2956	2957	2966	2967	2971
		2972	2981	2982	2983	2984	2986	2987	2994	2995	2997	2998	3007	3008
		3009	3010	3012	3013	3027	3028	3058	3109	3110	3120	3121	3141	3142
		3144	3213	3214	3215	3218	3300	3301	3315	3316	3317	3324	3327	3328
	R3	0000 0003	3332	3333	3334	3336	3443	3452	3454	3478				
		17*	43	126	127	141	143	144	146	167	172	176	207	214
		218	467	468	471	473	480	497	769	1002	1005	1077	1078	1319
		1320	1324	1511	1520	1536	1539	1568	1579	1583	1592	1614	1614	1623
		1625	1632	1643	1647	1650	1650	1664	1675	1675	1715	1724	1753	1754
		1755	1756	1'62	1763	1764	1769	1770	1771	1805	1873	1874	1878	1879
		1887	1888	1902	1903	1905	1906	1908	1909	1918	1919	1924	1925	2009
		2010	2012	2012	2410	2414	2418	2459	2492	2501	2512	2513	2515	2519
		2526	2566	2569	2583	2584	2726	2734	2767	2776	2857	2871	2882	2951
		2964	2992	2992	3062	3072	3102	3103	3105	3142	3215	3252	3253	3270
	R4	0000 0004	3271	3301	3303	3304	3311	3312	3334	3444	3464	3473	3490	3491
		18*	45	46	47	49	57	59	149	150	152	154	155	157
		158	160	161	192	192	193	203	209	468	469	509	517	627
		631	843	845	848	850	853	855	858	863	874	877	890	947
		950	953	955	958	961	963	965	965	967	1009	1012	1015	1016
		1039	1042	1045	1047	1078	1090	1093	1101	1154	1155	1156	1208	1209
		1211	1213	1215	1217	1219	1221	1224	1224	1228	1229	1231	1233	1235
		1238	1241	1243	1245	1476	1537	1542	1549	1550	1559	1562	1597	1599
		1615	1615	1621	1624	1629	1642	1646	1648	1648	1665	1678	1757	1763
		1765	1776	1784	1786	1794	1803	1808	1817	1822	1872	1874	1875	1876
		1919	1923	1925	1948	1951	1954	1957	1970	1974	1976	1981	1982	1985
		2112	2115	2118	2121	2124	2127	2129	2131	2133	2135	2138	2140	2143
		2146	2149	2153	2162	2164	2168	2170	2174	2177	2181	2183	2188	2190
		2195	2197	2199	2203	2206	2210	2212	2216	2218	2223	2224	2228	2228
		2317	2318	2327	2340	2352	2365	2372	2379	2411	2415	2424	2477	2498
		2567	2568	2571	2719	2719	2737	2751	2773	2779	2792	2793	2822	2859
		2859	2872	2872	2885	2897	2924	2925	2937	2959	2967	2978	2988	3001
		3014	3060	3061	3069	3072	3079	3139	3144	3145	3147	3322	3324	3326
	R5	0000 0005	3336	3337	3338	3445	3447	3449	3453	3453	3454	3471	3475	
		19*	47	49	50	50	52	53	54	57	59	65	204	239
		241	242	246	247	471	472	492	494	497	501	503	506	524
		526	529	628	630	636	672	755	759	777	779	786	811	828
		1010	1040	1061	1062	1082	1089	1359	1363	1367	1374	1527	1530	1554
		1555	1606	1607	1616	1627	1666	1680	1759	1764	1765	1766	1771	1772
		1773	1776	1778	1779	1780	1783	1784	1785	1786	1789	1792	1794	1800
		1804	1806	1809	1811	1818	1823	2113	2128	2139	2155	2166	2172	2179
		2185	2187	2192	2192	2196	2201	2208	2214	2220	2226	2319	2320	2329
		2342	2354	2367	2374	2381	2412	2414	2431	2437	2445	2473	2480	2484
		2564	2566	2572	2699	2722	2724	2724	2736	2760	2761	2769	2769	2770
		2778	2786	2788	2789	2792	2794	2821	2822	2832	2852	2855	2855	2874
		2877	2877	2884	2901	2902	2902	2910	2910	2921	2921	2936	2936	
		2953	2954	2966	2983	2985	2995	2996	3009	3011	3011	3028	3057	3058
		3066	3076	3110	3113	3114	3121	3124	3125	3127	3128	3140	3145	3273
		3276	3279	3289	3317	3319	3320	3323	3446	3447	3474	3475	3476	
	R6	0000 0006	20*	44	54	61	472	473	595	598	616	616	629	638
		650	1011	1018	1041	1056	1057	1091	1092	1095	1165	1179	1183	1185

MODEL 8/16E PROCESSOR TEST PART 1 06-211M96R00A13 PAGE 74 09:54:45 11/04/78

MODEL 8/16E PROCESSOR TEST PART 1 06-211M96R00A13 PAGE 75 09:54:45 11/04/78

SWLPS	0000 1CEE	2827	2831*
T1	0000 0350	261	262*
T10	0000 14D6	2103	2104*
T10A	0000 14DA	2104	2105*
T10B	0000 1534	2136	2138*
T10B1	0000 1512	2125	2127*
T10D	0000 1574	2156	2161*
T10E	0000 15A2	2175	2177*
T10END	0000 17EE	2384*	
T10F	0000 15D8	2193	2195*
T10G	0000 15FC	2204	2206*
T10H	0000 160E	2212*	
T10H2	0000 1630	2221	2223*
T10J	0000 1644	2230*	
T10K	0000 1676	2243	2245*
T10K2	0000 16B2	2263	2265*
T10L	0000 16BC	2272*	
T10L3	0000 16F2	2288	2290*
T10L5	0000 1726	2305	2307*
T10P	0000 173C	2315*	
T10P2	0000 1774	2334	2336*
T10P4	0000 17AC	2355	2357*
T10P8	0000 17E6	2377	2379*
T10R1	0000 150E	2116	2119    2122    2126*    2130    2132
T10R2	0000 1568	2145	2147    2148    2150    2151    2154    2157*
T10R2A	0000 1530	2134	2137*    2141    2142    2144
T10R2B	0000 1570	2159*	2163    2165
T10R3	0000 159E	2167	2169    2171    2173    2176*    2178
T10R4	0000 15D4	2186	2189    2191    2194*
T10R5	0000 15F8	2198	2200    2202    2205*
T10R6	0000 162C	2213	2215    2217    2219    2222*
T10R7	0000 1672	2235	2237    2239    2241    2244*
T10R8	0000 16AE	2256	2258    2260    2264*
T10R9	0000 16EE	2278	2280    2283    2284
T10R95	0000 1722	2298	2300    2301    2303    2306*
T10RA	0000 1770	2323	2326    2328    2330    2332    2335*
T10RB	0000 17A8	2345	2347    2349    2351    2353    2356*
T10RC	0000 17E2	2366	2368    2370    2371    2373    2375    2378*
T11END	0000 197C	2536*	
T1A	0000 0358	262	264*
T1A2	0000 035C	265*	267
T1AA	0000 0354	263*	
T1B	0000 0364	264	267*
T1C	0000 036C	265	270*
T1D1	0000 038C	275	279*
T1D2	0000 0394	279	281*
T1D3	0000 039C	281	283*
T1D4	0000 03A4	283	285*
T1D8	0000 03A8	285	286*
T1D9	0000 03AC	286	287*
T1E1	0000 03C4	291	293*
T1E2	0000 03CC	293	295*
T1E3	0000 03D4	295	297*
T1E4	0000 03E4	297	302*
T1END	0000 0504	438*	

MODEL 8/16E PROCESSOR TEST PART 1 06-211M96800A13

PAGE 77 09:54:45 11/04/78

MODEL 8/16F PROCESSOR TEST PART 1 06-211M96B00A13

PAGE 78 09:54:45 11/04/78



MODEL 8/16E PROCESSOR TEST PART 1 06-211M96R00A13 PAGE 80 09:54:45 11/04/78

T90INT	0000 1336	1887	1898*	1902	1906	1916	1917	1924						
T90J	0000 13FE	1972	1976*											
T90JJ	0000 1400	1975	1977*											
T90K	0000 1404	1969	1978*											
T90KK	0000 1416	1979	1985*											
T90L	0000 1426	1977	1989	1994*										
T90LST	0000 1480	1982	2089*											
T90M	0000 1442	2000	2001*											
T90000	0000 14B8	1974	2084*											
T90P1	0000 141A	1986*												
T90R2	0000 1322	1873	1884	1885	1886	1890*	1918							
T90R28	0000 1328	1893*												
T90R3	0000 1396	1933*												
T90R34	0000 139A	1912	1934*											
T90R4	0000 135A	1904	1907	1911*										
T90R7	0000 1448	2005*												
T90R78	0000 1470	2004	2015*											
T90R8	0000 146C	2008	2011	2014*										
T90SNT	0000 138A	1889	1927*											
T90Z	0000 14BE	1983	2092*											
T9END	0000 14CE	2096*												
TABLE	0000 22CC	102	3385*											
TEMP	0000 22D8	3391*												
TEMPF	0000 1B60	2587	2590	2679*										
TEN	0000 2302	482	526	756	813	826	1336	1364	1377	3419*				
TEST1	0000 0334	244	254*	2695	3129	3308								
TEST10	0000 14D2	1864	2096	2103*										
TEST11	0000 17F0	2105	2384	2397*										
TEST12	0000 1B66	2397	2405	2536	2694*									
TEST2	0000 0508	254	438	452*										
TEST3	0000 0622	452	558	580*										
TEST4	0000 07BC	580	740	747*										
TEST5	0000 098A	747	979	989*										
TEST6	0000 0B14	989	1113	1127*										
TEST7	0000 0D5C	1127	1340	1347*										
TEST8	0000 0E8A	1347	1454	1469*										
TEST83	0000 11B8	1499	1750*											
TEST85	0000 0EE2	1481	1485	1490	1494	1496*								
TEST9	0000 12C4	1469	1738	1864*										
TESTC4	0000 1980	2422	2427	2441	2447	2463	2469	2482	2488	2496	2502	2538*		
TESTC5	0000 1996	2525	2532	2546*										
TESTCC	0000 11A6	1515	1518	1521	1524	1531	1533	1540	1543	1547	1551	1556	1563	1566
		1572	1576	1578	1580	1588	1591	1593	1595	1600	1603	1608	1669	1671
		1674	1676	1679	1681	1687	1691	1695	1700	1703	1705	1710	1717	1720
		1722	1725	1727	1733	1736	1740*							
TESTNO	0000 22B8	257	457	585	752	994	1130	1352	1474	1869	2110	2402	2698	3344
		3369*												
THI	0000 0D38	1328*												
TIM	0000 2076	3116	3135	3152	3155*									
TIME	0000 207A	3157*	3158											
TIME2	0000 2082	3160*	3161											
TITEND	0000 2344	158	3432*											
TITLE1	0000 2306	152	3422*											
TITLE2	0000 2334	154	3425*											
TOT	0000 000F	1467*	1475	1513	1640	1659	1744	1750	1761	1768	1775	1791	1827	1828



