

**Basic Four® Model 2500  
Fixed Disc Drive  
Service Manual**

**BFISD 8006**



*Basic Four  
Information Systems®*

**AD: The drives seems to be from  
Century Data, at least one drive i  
have is a T80 (Trident)  
Documentation for these drives is  
available on Bitsavers.**

The information contained herein is proprietary to and considered a trade secret of Management Assistance Inc.

All rights reserved. No part of this publication may be reproduced, recorded or stored in a retrieval system, or transmitted, in any form or by any means, whether electronic, mechanical, photographic, or otherwise, without prior written permission of the Basic Four Information Systems Division of Management Assistance Inc.

All Rights Reserved

***BFISD 8006***

Copyright © 1979 by Basic Four Corporation

All specifications are subject to change without notice.  
Basic Four and MAI are registered trademarks of Management Assistance Inc.

Printed in the United States of America

Basic Four Information Systems Division/Management Assistance Inc.  
14101 Myford Road, Tustin, California 92680/(714) 731-5100

## TABLE OF CONTENTS

	Page
<b>CHAPTER 1      INTRODUCTION</b>	
1.1      General Description . . . . .	1-1
1.2      Purpose . . . . .	1-1
1.3      Physical Description . . . . .	1-1
1.4      Specifications . . . . .	1-3
<b>CHAPTER 2      INSTALLATION</b>	
2.1      Unpacking/Packing Procedure . . . . .	2-1
2.2      Preinstallation . . . . .	2-1
2.3      Voltage Connections . . . . .	2-2
2.3.1    Ac Power Connection . . . . .	2-2
2.3.2    Dc Voltage . . . . .	2-3
2.3.3    Dc Power Supply Differences . . . . .	2-4
2.4      System Initialization . . . . .	2-5
2.4.1    Loading and Unloading Disc Pack . . . . .	2-5
2.5      Controls and Indicators . . . . .	2-6
2.6      Operating Procedures and Adjustments . . . . .	2-7
2.7      Interconnection . . . . .	2-8
<b>CHAPTER 3      MAINTENANCE</b>	
3.1      Introduction . . . . .	3-1
3.2      General Description . . . . .	3-1
3.3      Special Tools . . . . .	3-1
3.4      Functional Description . . . . .	3-2
3.4.1    Disc Drive Operations . . . . .	3-2
3.4.2    Power-Up Sequencing . . . . .	3-4
3.4.3    Head Load Operation . . . . .	3-5
3.4.4    Seek-To-Cylinder Operation . . . . .	3-5
3.4.5    Track-Following Operation . . . . .	3-7
3.4.6    Rezero Operation . . . . .	3-8
3.4.7    Head-Retract Operation . . . . .	3-9
3.5      Diagnostic Tests . . . . .	3-9
3.5.1    Indicator Testing . . . . .	3-9
3.5.2    Basic All Purpose Service System (BASS) Diagnostics . . . . .	3-9
3.6      Adjustment Procedures . . . . .	3-10
3.6.1    Head Alignemtn Procedure Using VDT Boot Loader . . . . .	3-10
3.6.2    Data Separator PCB Adjustment Procedure . . . . .	3-15
3.7      Mechanical Adjustments . . . . .	3-19
3.7.1    Carriage-Actuated Microswitches . . . . .	3-19
3.7.2    Off-Rack Microswitch and Adjustment . . . . .	3-20
3.7.3    Cover Lid Spring Adjustment . . . . .	3-21
3.7.4    Lid-Closed Microswitch Checkout and Adjustment . . . . .	3-22
3.7.5    Spindle Lock Assembly Adjustment . . . . .	3-23
3.7.6    Speed Transducer Checkout and Adjustment . . . . .	3-24
3.7.7    Motor Bobbin Alignment . . . . .	3-25

TABLE OF CONTENTS (continued)

	Page
<b>CHAPTER 3 MAINTENANCE</b>	
3.8 Cleaning and Preventive Maintenance . . . . .	3-26
3.8.1 Read/Write Heads Check . . . . .	3-28
3.8.2 Spindle Grounding Brush and Belt Check . . . . .	3-28
3.8.3 Power Supply Checkout . . . . .	3-29
3.8.4 Cleaning the Disc Pack Area . . . . .	3-30
3.8.5 Cleaning and Lubricating the Spindle . . . . .	3-31
3.8.6 Cleaning the Intake Air Filter . . . . .	3-31
3.8.7 Cleaning the Read/Write Head . . . . .	3-32
<b>CHAPTER 4 REMOVAL/REPLACEMENT PROCEDURES</b>	
4.1 Spare Parts List . . . . .	4-1
4.2 Removal/Replacement Procedures . . . . .	4-3
4.2.1 Replacing the Absolute Air Filter . . . . .	4-3
4.2.2 Air Shroud Assembly Removal . . . . .	4-3
4.2.3 Card Cage Removal and Replacement . . . . .	4-4
4.2.4 Carriage and Way Assembly Replacement . . . . .	4-4
4.2.5 Cover Gasket Replacement . . . . .	4-6
4.2.6 Drive Belt Replacement . . . . .	4-7
4.2.7 Heads-Extended Microswitch Replacement . . . . .	4-7
4.2.8 Linear Motor Replacement . . . . .	4-8
4.2.9 Off-Rack Microswitch Replacement . . . . .	4-9
4.2.10 Relay Assembly Replacement . . . . .	4-10
4.2.11 Power Supply Removal/Replacement . . . . .	4-11
4.2.12 Read/Write Head Removal/Replacement . . . . .	4-12
4.2.13 Servo Head Installation . . . . .	4-15
4.2.14 Spindle Lock Assembly Replacement . . . . .	4-16
4.2.15 Spindle Drive Motor Replacement . . . . .	4-17
4.2.16 Spindle Assembly Replacement . . . . .	4-17
4.2.17 Velocity Transducer Replacement . . . . .	4-20
<b>CHAPTER 5 REFERENCE DATA</b>	
<b>APPENDIX A DISC CONTROLLER</b>	

## LIST OF ILLUSTRATIONS

Figure		Page
1-1	Locations of Major Components . . . . .	1-2
2-1	Voltage Select Terminal Board TB2 . . . . .	2-2
2-2	Dc Voltage Check Points . . . . .	2-3
2-3	Ac Power Distribution, Simplified . . . . .	2-4
2-4	Operator Control Panel . . . . .	2-6
2-5	Location of Maintenance Switches . . . . .	2-7
2-6	Interconnection Diagram 610/730 System . . . . .	2-9
3-1	Disc Drive Functional Block Diagram . . . . .	3-3
3-2	Plug-In Card Locations . . . . .	3-11
3-3	Read/Write Heads and Matrix Board Configuration . . . . .	3-13
3-4	Ideal Dibit Pattern . . . . .	3-14
3-5	Data Separator and Test Point Location (End View) . . . . .	3-16
3-6	Clock Frequency Adjustment . . . . .	3-17
3-7	Data Window Width . . . . .	3-18
3-8	Data Window/Clock Relationship . . . . .	3-18
3-9	Connector J30 Pin Locations . . . . .	3-22
3-10	Spindle Lock Assembly . . . . .	3-23
3-11	Speed Transducer Gap Limits . . . . .	3-24
3-12	Bobbin Mounting Screw Location . . . . .	3-25
3-13	Spindle Drive Component Checks . . . . .	3-29
3-14	Dc Voltage Check Points . . . . .	3-30
3-15	Disc Pack Area Components . . . . .	3-30
3-16	Read/Write Heads . . . . .	3-32
4-1	Bobbin Mounting Screw Location . . . . .	4-9
4-2	Sequence Relay Assembly Component Locations . . . . .	4-11
4-3	Head Camming Tool Installation . . . . .	4-13
4-4	Head Positioning and Mounting Components . . . . .	4-14
4-5	Spindle Lock Assembly . . . . .	4-16
4-6	Spindle Assembly . . . . .	4-18
4-7	Velocity Transducer Components and Tool . . . . .	4-20

## LIST OF TABLES

Table		Page
1-1	Specifications . . . . .	1-4
2-1	Operating Control Panel Indicators and Switches . . . . .	2-6
2-2	Maintenance Switches . . . . .	2-7
3-1	Special Tools and Test Equipment . . . . .	3-1
3-2	Recommended BASS Diagnostics . . . . .	3-10
3-3	Monthly Preventive Maintenance Schedule . . . . .	3-27
3-4	Semi-Annual Preventive Maintenance Schedule . . . . .	3-27
3-5	Power Supply Voltage Check . . . . .	3-29
4-1	Replacement Parts for Disc Drive . . . . .	4-1



## CHAPTER 1

### INTRODUCTION

#### 1.1 GENERAL DESCRIPTION

The Model 2500 Disc Storage Unit (hereafter referred to as the Disc Drive) is a modular memory storage device. The Disc Drive is an integral part of the 610/730 data processing system. The disc controller, located in the data processing system, consisting of five PCB's, provides a means to control; power sequencing, head positioning, data handling, error corrections and diagnostics aids for the Disc Drive.

The Disc Drive with its removable disc pack is a modular memory device capable of storing 80 million bytes of readily accessible data. The removable pack becomes a semipermanent extension of the CPU memory in a data processing system. Programs and files are stored on the disc. Access time is sufficiently short that storage and retrieval of data appears to be instantaneous to the operator.

#### 1.2 PURPOSE

This manual is the primary source of information for field maintenance. It contains the necessary information to repair and maintain the Disc Drive. It contains both physical and functional descriptions, installation/operation, maintenance procedures and equipment supplied. This information shall enable an experienced Service Engineer to identify, isolate, and repair the Disc Drive to a defective subassembly or printed circuit board.

#### 1.3 PHYSICAL DESCRIPTION

The Disc Drive is packed as a single unit. The three main parts of the Disc Drive are: (1) Cabinet, (2) Disc Drive Assembly, and (3) Removable Disc Packs. The Disc Drive Cabinet has a control panel, pack area lid, front cover and rear cover. Figure 1-1 illustrates the locations of the main parts and their subassemblies (the removable Disc Pack is not shown).




Figure 1-1. Locations of Major Components

The removable disc packs (BFC part number 902490) can be shipped with the Disc Drive or separately. The subassemblies located within the Disc Drive Assembly are the air shroud, spindle, spindle drive motor, head carriage, logic card cage, linear motor, power supply, relay assembly, and blower.

1. Air Shroud - The air shroud surrounds the disc pack. The air shroud contains and directs the filtered air which is forced through the Disc Drive.
2. Spindle/Spindle Drive Motor - The spindle drives the discs when the disc pack is in place. The spindle is driven by a spindle drive motor.
3. Head Carriage - The head carriage is the mounting for one servo read and five read/write heads. The carriage is moved to position the read/write heads over to a selected cylinder of the disc pack by reading the servo read head.
4. Logic Card Cage - The logic card cage holds six plug-in boards which contain the disc drive control logic, read/write logic, and servo circuits. The interface cables to the rest of the system also plug into the card cage.
5. Power Supply - The power supply provides all DC power for the Disc Drive. The power supply also contains the emergency head retracting circuits.
6. Relay Assembly - The relay assembly holds the relay and solid state switches that perform power-up and power-down sequencing.

#### 1.4 SPECIFICATIONS

**WARNING**

This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions manual, may cause interference to radio communications, as temporarily permitted by regulation. It has not been tested for compliance with the limits for Class A Computing Devices pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference. Operation of this equipment in a residential area is likely to cause interference, in which case the User at his own expense will be required to take whatever measures may be required to correct the interference.

Table 1-1 gives the operational specifications for the Disc Drive.

TABLE 1-1. SPECIFICATIONS

Parameters	Characteristics
PHYSICAL	
Height (with Cabinet)	29.8 inches (75.7 cm)
Height (without Cabinet)	10.5 inches (25.4 cm)
Width	17.8 inches (45.1 cm)
Depth	32.0 inches (81.3 cm)
Weight	285 pounds (129.3 kg)
POWER	
Voltage	115/230 VAC
Current	8.5/4.25 A 26/13 A to start
Power	977.5 VA
Frequency	60/50 Hz
Heat Output	2100 to 2550 Btu/hr
ENVIRONMENTAL	
Temperature	65°F to 75°F (18°C to 24°C)
Humidity	40% to 60% non-condensing
GENERAL	
Tracks per cylinder	5 (plus servo track)
Cylinders per pack	813 (numbered 000 thru 814)
Bytes per track	20,160
Bytes per cylinder	100,800
Bytes per pack (unformatted)	82.15 million M2580
Recording Density	6060 Bits per inch (nominal)

TABLE 1-1. SPECIFICATIONS (continued)

Parameters	Characteristics
GENERAL	
Access Time	
Track to Track	6 milliseconds
Maximum	55 milliseconds
Average	30 milliseconds
Pack rotational speed	3600 RPM $\pm$ 3%
Recording Method	Bit serial Triple Frequency (TFM)
Maximum latency time	17.6 milliseconds
Average latency time	8.3 milliseconds
Data transfer rate	1,209,000 Bytes/second
Start or stop time	20 seconds



## CHAPTER 2

### INSTALLATION

#### 2.1 UNPACKING/PACKING PROCEDURE

All replaceable spares are shipped in specially designed containers which provide protection against moisture, dust, and contact damage. The following procedures apply upon receipt of the replacement unit.

1. Examine the shipping container for dents or cracks. If any are found, they shall be reported to the Branch Office immediately so that corrective action can be taken.
2. Open the container and remove the units, then examine for damage or missing parts per the shipping list.

#### 2.2. PREINSTALLATION

Check that the ac line includes a third-wire earth ground that meets or exceeds the requirements of the National Electrical Code. This can be checked by the following procedures:

1. Locate the circuit breaker that supplies power to the Disc Drive. With a digital voltmeter set to measure 20 volts ac, and the circuit breaker turned on, measure the drop between the green and white wires at the power source (wall outlet). The measured voltage must be less than 1.8 volts ac.
2. Switch the source circuit breaker off. Measure the resistance between the green and white wires at the power source (wall outlet). The resistance must be less than the value shown below for the applicable circuit breaker rating.

<u>CB Rating</u>	<u>Resistance</u>
15 Amps	0.30 Ohms
20 Amps	0.25 Ohms
30 Amps	0.15 Ohms

If either measurement in step 1 or 2 above is not less than the value given, request the customer to provide a power source that meets these requirements.

## 2.3 VOLTAGE CONNECTIONS

The power supply for the Disc Drive is not contained in a single assembly. Single-phase AC power is brought to AC input control filter and then switched to the DC power supply. AC power connections must be verified and DC voltage checks made as a part of the installation procedures.

### 2.3.1 AC POWER CONNECTION

The unit power cable should be connected to the primary ac power source only after the preceding isolation checks and the following steps have been performed. This is a system of single phase units being connected to a three-phase power source. Proceed as follows:

1. Set START/STOP switch on the control panel to STOP and the PWR ON/OFF switch at the rear of the unit to OFF.
2. Verify that voltage, phase, and frequency of input power match the available power.
3. Check terminal board TB2 (Figure 2-1) on the power supply assembly for a jumper wire between the terminal marked 0B/NTL and the terminal corresponding to the voltage available.
4. Disconnect the power supply circuit board shorting jumper from the OPEN spade terminal. Reconnect it to the spade terminal marked AC/DC GRD SHORT (located at E2). Remove after test is completed for system use.




Figure 2-1. Voltage Select Terminal Board TB2

## CAUTION

Never operate the disc drive as a standalone unit without ac and dc grounds being shorted together at the power supply. A potential as high as 60 volts can develop between the logic ground and the frame, resulting in damage to the Disc Drive.

When operated in a system environment the ac and dc grounds must not be shorted together.

5. Connect unit power cable to ac power source.

### 2.3.2 DC VOLTAGE

The following dc voltage checks are mandatory and must be performed on all units before offline operational checkout.

1. Set PWR ON/OFF switch to ON. The blower motor should start and the green File Ready indicator on control panel may start flashing but should go out within 20 seconds.
2. Locate connector J10 on the Power Supply circuit board (see Figure 2-2) and check for in-tolerance dc voltages between the pins listed below.
  - a. +8.0 to +10.5 volts between pin 4(+) and pin 9.
  - b. +30 to +35 volts between pin 1(+) and pin 2.
  - c. -30 to -35 volts between pin 3 and pin 2(+).




Figure 2-2. Dc Voltage Check Points

3. Use the DVM to measure the voltage between logic ground (card cage terminal E11) and power pins on any circuit board connector (connector A or B, pin 59 or 60). Dc voltage should be +4.75 to +5.25 volts with an ac ripple component less than 75 millivolts peak to peak.

### 2.3.3 DC POWER SUPPLY DIFFERENCES

Disc drives may be shipped with one of two power ranges to match the single-phase AC power available. Figure 2-3 is a simplified illustration of the two power ranges.




Figure 2-3. AC Power Distribution, Simplified

## 2.4 SYSTEM INITIALIZATION

Verify the controller cables are connected to the formatter chassis.

Radial Cable at J04

BUS IN at J03

BUS OUT at J02

Ensure the shorting jumper referred to in paragraph 2.3.1, step 4, has been moved to the OPEN position for system operation.

### 2.4.1 LOADING AND UNLOADING DISC PACK

To install a disc pack on a disc drive, perform the following procedures.

1. Verify that the control panel START/STOP switch is set to STOP and the green File Ready indicator is out.
2. Unlatch the pack area lid of the disc drive and open the lid.
3. Verify heads are retracted and air shroud area is clean.
4. Remove lower cover from disc pack and lower the top cover with disc pack carefully onto the disc drive spindle.
5. Press down the top cover handle to engage the spindle locking mechanism. Rotate the handle clockwise to lock the disc pack to the spindle and to disengage the top cover.
6. Lift and carefully remove the top cover from the disc drive and close pack area lid. Verify lid latch locks.
7. If the installed disc pack is a permanent record or a head alignment pack, set READ/WRITE switch on control panel to READ ONLY to protect the pack from being written on. If writing is allowed set this switch to READ/WRITE.
8. Store the top and bottom covers of the disc pack together inside cabinet or on top of the disc drive to minimize dust accumulation inside the case.

To remove a disc pack from the disc drive, perform the following procedures.

1. Power down the disc drive by setting START/STOP switch to STOP. The green File Ready indicator should start flashing.
2. Wait until File Ready indicator starts flashing (approximately 20 seconds) and then unlatch and open pack area lid.
3. Separate the top and bottom covers of the disc pack. Carefully lower by the handle on the top cover.

## 2.5 CONTROLS AND INDICATORS

The control panel contains the following toggle switches and indicators: READ ONLY/READ/WRITE Switch, DEVICE CHECK indicator, FILE READY indicator, START/STOP Switch (Figure 2-4). The function of the control panel switches and indicators is given in Table 2-1.




Figure 2-4. Operator Control Panel

TABLE 2-1. OPERATING CONTROL PANEL INDICATORS AND SWITCHES

Switch	Function
READ ONLY/READ/WRITE	A two-position toggle switch that provides disc pack file protection. In the READ ONLY position inhibit writing on the pack. The READ/WRITE position enables writing on the pack.
START/STOP	A two-position that causes manual power-up and power-down sequencing in normal operations. Switch in START position turns on spindle drive motor and loads heads. The STOP position retracts heads and turns off the spindle drive motor.
Indicator	Function
DEVICE CHECK	Indicator illuminates whenever an internal failure or control error is detected. Reset by the Disc Controller or power down.
FILE READY	Green file indicator blinks during power-up or power-down sequences. When indicator stops blinking and illuminates, the drive is ready to accept commands from the controller. The address file letter is stamped on the lens.

Figure 2-5 shows the location of the maintenance switches. These two toggle switches are not normally used by the operator. The function of these switches is given in Table 2-2.

### WARNING

Ac power is still present at Ac Input Control Assembly when the PWR ON/OFF switch is OFF and poses a shock hazard if the terminal board cover is removed.




Figure 2-5. Location of Maintenance Switches

TABLE 2-2. MAINTENANCE SWITCHES

Switch	Function
PWR ON/OFF Switch	A two-position toggle switch that controls ac power to the disc drive's dc power supply. This switch is set to OFF before removing any circuit board or when replacing disc drive assemblies or components.
INTERFACE/DEGATE Switch	A two-position toggle switch located on the top edge of the Logic I card. (The switch is accessible only when the rear cover is off.) The INTERFACE position enables normal, online operation, permitting the disc drive to be selected by the controller. The DEGATE position disconnects the disc drive from the controller and enables T2000A Exerciser inputs for offline maintenance operation of the drive.

## 2.6 OPERATING PROCEDURES AND ADJUSTMENTS

Operating procedures for installing a disc pack are given in paragraph 2.4.1. The functions of the controls and indicators are given in paragraph 2.5. Besides changing disc packs, the only other operating procedures is clearing a Device Check. This occurs when the red DEVICE CHECK indicator comes on indicating a malfunction has occurred. Due to the DEVICE CHECK condition, use one of the four following methods to clear the DEVICE CHECK.

1. To clear a DEVICE CHECK, set the START/STOP switch to STOP. Wait for the green File Ready indicator to stop flashing and then set START/STOP switch to START.
2. The following Device Check conditions are reset using a Device Check Reset command from the controller firmware.
  - a. Setting a cylinder address while not ready.
  - b. Setting an offset while the drive is not ready.
  - c. Writing while drive is not ready.
  - d. Writing when more than 80 microinches off track center.
  - e. Writing when READ ONLY switch is active.
  - f. Writing while offset is active.
  - g. No write transitions for 25 microseconds while writing.
  - h. Write current is unsafe.
  - i. No head or more than one head is selected during reading or writing (heads unsafe).

The Device Check Reset command resets the head address register to zero.

3. The following Device Check conditions can be reset using a Rezero command.
  - a. SEEK INCOMPLETE.
  - b. Receiving an illegal cylinder address (greater than 814).
  - c. Offset active and SETCYLTAG.
4. Possible hardware problems are:
  - a. Power Supply
  - b. Cabling

If the Device Check Indicator lights up immediately after power up, the problem is probably the power supply.

## 2.7 INTERCONNECTION

A typical interconnection diagram is illustrated in Figure 2-6 for the 610/730 Data Processing System.




Figure 2-6. Interconnection Diagram 610/730 System



## CHAPTER 3

### MAINTENANCE

#### 3.1 INTRODUCTION

This chapter contains information and instructions required to keep the drive in proper operating condition. Maintenance information includes a functional description of circuit operation and preventative/corrective maintenance procedures.

#### 3.2 GENERAL DESCRIPTION

The Disc Drive Unit consists of two parts, the Disc Drive which is in its own cabinet, and the Disc Controller which consists of boards mounted in the CPU cabinet.

#### 3.3 SPECIAL TOOLS

Special tools and test equipment required for performing maintenance are given in Table 3-1.

TABLE 3-1. SPECIAL TOOLS AND TEST EQUIPMENT

BFC Part Number	Description
249110	Head Caming Tool
249020	Head Positioning Tool
249030	Head Positioning Tool, Inl.
249040	Torque Wrench, Head Mount
249050	Pin Safety
249060	Tach Rod Insert/Remo. Tool
249100	T80-CE Pack
249010	Extender, PCB

### 3.4 FUNCTIONAL DESCRIPTION

Figure 3-1 is a general block diagram and shows the functional groups that execute disc drive operations and the interfacing command, data, and status lines that connect the disc drive to the controller.

1. The Interface and Control Circuits control access to the drive, generates the control signals for head positioning from the controller signals, and prevents further operations until a device check failure is reset.
2. The Disc Pack Drive Circuits controls the power-up and power-down sequences, loads the heads initially, and controls emergency head retraction.
3. The Head Positioning Servo Circuits controls head positioning and generates the bit rate and byte rate clocks.
4. The Read/Write Circuits enable the addressed read/write head, converts NRZ data to TFM and writes to the disc, read from the disc and converts TFM to NRZ, detects address sector and index markers, and provides the data clock to the controller.
5. The Error Detection and Status Circuits monitors status from the other circuit groups, generates status signals for the controller, and operates the DEVICE CHECK indicator.
6. The Power Circuits include the power protection and distribution of input power and the regulated DC power supplies.

#### 3.4.1 DISC DRIVE OPERATIONS

The Disc pack contains five, 14-inch-diameter, ferrusoxide coated discs with precision spacers that are firmly mounted on a hub. Only the inner three discs are used; these provide five data-recording surfaces and one prerecorded track-reference servo surface. The top and bottom discs serve only as protective covers for the recording surface.

The five data-recording (read/write) heads and the servo (read-only) head are rigidly mounted to a head-positioning carriage as facing pairs and spaced and aligned to approach the upper and lower surfaces of the inner three discs precisely. The recording heads are assigned head address numbers 0 through 4 from top to bottom. The servo head reads from the top surface (servo surface) of the middle disc. Recording heads are aligned so their recording pole pieces are positioned axially within 50 microinches of the servo head pole pieces.




Figure 3-1. Disc Drive Functional Block Diagram

All heads are mounted on spring arms that are loaded to apply a pressure of approximately 350 grams toward their associated disc surfaces. However, the head pads and gimbaling are designed aerodynamically to "fly" the head on the air boundary layer that surrounds all moving surfaces. The aerodynamic lift equalizes the spring load pressure at some point above the disc surface so the heads never actually contact the rotating disc surface.

Head loading and unloading into and out of the disc pack area is carefully sequence-controlled to ensure that the disc pack is up to rotating speed before the heads are extended. When the heads are retracted, they are held apart by nylon camming surfaces that bear on the spring arms of each head.

The prerecorded servo surface in each disc pack is read continuously by the servo head whenever the heads are loaded onto the pack. Signals read by the servo head are processed by the head positioning servo system to provide references for a variety of functions. The servo signals are used to:

- a. Delineate guard band and recording zones on the disc recording surfaces.
- b. Position and space the data tracks on the recording surfaces.
- c. Generate seek operation track-crossing clocks for positive track location.
- d. Detect on-track null points and off-track error signals for servo track following.
- e. Detect start-of-track index markers.
- f. Used as a disc speed-related, byte-interval reference clock for synchronizing data recording and recovery.

Because the read/write heads are mechanically locked to the servo head by the carriage assembly, the data track positions are referenced to the pack servo tracks, rather than externally to the Disc Drive. This technique minimizes pack-to-pack and drive-to-drive interchangeability problems.

#### 3.4.2 POWER-UP SEQUENCING

Initially, the linear motor bobbin and attached head carriage are in the fully retracted position with the heads drawn apart by camming surfaces on the head arms that make contact with the cam tower. When power is turned on, only the blower motor, power supply, and disc drive logic circuits are activated. Power-up sequencing is initiated by activating the START switch on the front panel (or by the controller through a sequence control line).

### 3.4.3 HEAD LOAD OPERATION

Head loading (also called "first seek") is always the final operation performed during a normal power-up sequence. When the disc pack has come up to a speed sufficient to fly the heads (95 percent of 3600 RPM), a load speed voltage is applied to the linear motor bobbin to drive the carriage and heads forward at a nominal speed of 7 to 10 inches per second. The heads continue to move forward under direct load speed control until they reach the outer margin of the head load zone of the disc pack. At this point, the camming surfaces of the head arms leave the cam tower and allow facing heads to be lowered onto the disc surface air boundary layer.

The Disc Drive switches from direct load speed control of head motion to a track-following mode as soon as the servo head begins picking up a signal from the recorded outer guard band. Track following is a servo mode of operation under control of the servo head signal. Since all 22 tracks of the outer guard band are of the plus pattern, no dabit signal will be detected. Instead, these identical tracks generate a head position error voltage that causes the servo-controlled linear motor to continue to drive the heads in the forward direction.

When the servo head approaches the track 000 position (intersection of the outer guard band and the minus-track pattern of the recording zone), servo system will lock on track 000 when the dabit signal becomes symmetrical.

Locking in (detenting) on cylinder 000 completes the power-up sequence and head load operation, and the Disc Drive goes into the drive-ready condition, sending an attention signal to the controller. The entire operation, from the start of power-up sequencing through the first seek to cylinder 000 to the drive-ready condition, takes approximately 20 seconds.

### 3.4.4 SEEK-TO-CYLINDER OPERATION

A cylinder is defined as all five recording tracks that are accessible to the read/write heads for a given track position of the servo head. A new cylinder address and a seek-start command are required to move the heads to a new position.

The controller initiates a programmed seek by placing a cylinder address on the bus lines. A minimum of 200 nanoseconds later, the controller activates the Set Cylinder Tag line to strobe the bus address into the subtractor. Here it is compared with the current head position address by an arithmetic subtractor to obtain a cylinder difference count. If the cylinder address on the bus lines is a legal address, raising the tag line strobos the subtractor output into a difference counter. If the cylinder address is illegal, a device check will result. The new cylinder address is stored by the drive in its cylinder address register 350 nanoseconds after the Set Cylinder Tag line goes active.

The value strobed into the difference counter indicates the number of tracks to be crossed by the servo head to reach the location of the new address. This number can be positive, negative, or zero. If positive, a forward (toward the spindle) seek will be enabled. And if the difference count is zero, no seek operation will occur.

Seek-starting begins when the controller terminates the Set Cylinder Tag line signal a minimum of 800 nanoseconds later. If the difference count is not zero, dropping the tag line signal places the head-positioning servo system into the seek-enable mode by changing from track-following mode to velocity mode. Starting the seek operation puts the drive in the not-ready condition.

The maximum velocity that the forward- or reverse-seek operation will attain is controlled by the magnitude of the difference count. A difference count of 256 or more will cause the head-positioning servo system to be driven by maximum linear motor current to an absolute maximum velocity of about 90 inches per second. Maximum velocity is limited when a balance is reached between the voltage applied to the linear motor and the voltage fed back from a velocity transducer (stationary coil and moving tach rod) inside the linear motor.

Each time the servo head crosses a servo track, a clock pulse that reduces the difference counter count by one generated. Maximum velocity will be maintained until the difference count falls below 256. Below the count of 256, the drive signal to the servo system is reduced proportionally, with the linear motor responding to balance out the signal with the output of the velocity transducer.

Imbalance due to the momentum of the bobbin and carriage causes a braking voltage to be applied to the linear motor to slow the heads as they approach the correct cylinder (difference count of zero).

When the difference count is reduced to zero, the servo head will be within approximately 0.002 inch of the desired track, and the head-positioning servo system is switched back to operating in the track-following mode. The servo system then locks onto the closest symmetrical dabit null point. Once this occurs, the seek-to-cylinder operation is complete, and following a 1-millisecond delay, the drive returns to the ready condition and sends a seek-completed interrupt on the Attention line. Head repositioning times vary from 6 milliseconds for a single-cylinder seek to either adjacent track to as long as 55 milliseconds for seeks across all cylinders. These times are measured from drive ready-to-drive ready.

### 3.4.5 TRACK-FOLLOWING OPERATION

Switching the head-positioning servo system to the track-following mode (detent on track after first seek, programmed seek to cylinder, or rezero), places the servo system under control of the dabit signal picked up by the servo head. As long as the dabit signal is symmetrical, indicating that the servo head is exactly centered between two adjacent recording zone servo tracks, the integrated position-error voltage will be null, or zero volt.

Any asymmetry in the dabit signal indicates that the servo head has drifted off track and has produced an increasingly positive or negative position signal that is applied as a correction voltage to the linear motor to move the servo head back to the null point of dabit symmetry.

The position signal can swing positive or negative by as much as 2 volts if the servo head completely loses the signal from one of the adjacent plus or minus tracks. Also notice that the direction of correction (forward or reverse) to bring the servo head back on track, relative to the polarity of the position error voltage, depends upon whether the servo head is tracking an odd- or even-numbered cylinder. The least significant bit of the cylinder address is used as an odd or even indicator to ensure that error correction drive is always toward the position-error null point of track center.

An upper-threshold detector is activated whenever the position-error voltage indicates that the servo head is approximately 500 microinches off track. This upper-threshold detector produces a train of pulses from the sinusoidal position signal during seek-to-cylinder operations from which the difference counter down-count clocks are produced.

A fixed forward or reverse offset of 300 microinches can be applied to the servo system under program control for attempted recovery of data which cannot be read without errors when the heads are correctly positioned. This is accomplished by setting Bus bit 2 active and activating the Set Head Tag line. The direction of offset is specified by the state of Bus bit 3. Offset is produced by summing a positive or negative bias with the position-error voltage so that null is obtained with the heads offset.

Head offset must be reset before writing or head repositioning is attempted, otherwise a device check error will result. Offset reset is accomplished by making the Set Head Tag line active with Bus bit 2 reset.

#### 3.4.6 REZERO OPERATION

When an illegal cylinder address is received, or when a seek-to-cylinder operation is not completed within 700 milliseconds (seek incomplete), cylinder location reference is lost. A Rezero command is required to reestablish this location reference. This command is given by setting Rezero Bus bit 8 and activating the Control Tag line.

Rezero places the selected drive in the not-ready condition and causes a reverse-seek operation that repositions the heads over cylinder 000 and resets the head address to 0. It also resets the cylinder address to 000 and resets the error condition that made rezeroing necessary.

The rezero seek operation is initiated at the trailing edge of the Control Tag line signal after activating it with Rezero Bus bit 8 set. Servo control is switched to reverse drive, load-speed velocity is activated, and track following is disabled, causing the linear motor to move the heads toward the outer periphery of the disc at load speed. The heads continue their motion out of the recording zone, through the outer guard band, and into the head load zone of the disc pack.

As soon as the servo head signal is lost, servo control is switched to forward mode, reversing the head drive direction. As the heads move inward, still at load speed, the servo head begins to pick up a signal again from the outer guard band. Servo control is then switched from load speed to track following, and the heads continue to move forward under control of the position error voltage derived from the asymmetrical servo signal picked up in the outer guard

band. The servo locks in on the first dabit signal, which occurs over cylinder 000, stopping the heads on that cylinder with servo control in the track-following mode. After the rezero operation is completed, the Disc Drive ready signal is raised.

#### 3.4.7 HEAD-RETRACT OPERATION

A head-retract operation unloads the heads from the disc pack and retracts them fully from the disc pack area at the start of the power-down sequence when the START/STOP switch is set to STOP. As soon as the power-on START switch signal is lost, the servo control is enabled to drive the heads in the reverse direction at load speed. This disables track following and puts the Disc Drive in the not-ready condition.

When the heads move into the head load zone at the outer periphery of the discs, the camming surfaces of the head arms make contact with the cam tower; this forces the heads away from each other and away from the disc surfaces. The heads continue to move in the retract direction, causing the carriage to open the Heads-Extended microswitch. The microswitch action disables the head-positioning servo and permits the power relays for the spindle motor to drop out. A braking circuit is switched in and applies a 44 volt DC braking voltage to the field winding of the spindle motor for approximately 19 seconds. The disc pack should come to a complete stop in this time, completing the head-retract and power-down sequence operations.

### 3.5 DIAGNOSTIC TESTS

Use the following diagnostics that test the control panel and verify proper operation of the idsc drive.

#### 3.5.1 INDICATOR TESTING

A continuity check of the control panel indicators is recommended before running BASS diagnostics.

#### 3.5.2 BASIC ALL PURPOSE SERVICE SYSTEM (BASS) DIAGNOSTICS

It is recommended that the BASS diagnostics listed in Table 3-2 be run at the time of installing and repair to verify proper operation of the Disc Drive. For operating BASS, refer to BASIC ALL PURPOSE SERVICE SYSTEM (BASS) MANUAL by BFIS; manual #DM1102.

TABLE 3-2. RECOMMENDED BASS DIAGNOSTICS

Name	Description	Purpose
%D21	Long/Short Disc Seek Test	For burn-in verification of head seek functioning and head alignment.
%D22	Disc Scan Restore	For error isolation, or correction of marginally bad sectors or to check alignment.
%D23	Disc/DMA Write Verification	For burn-in verification of disc and DMA functioning.
%D24	Direct File Disc Exerciser	For exhaustive burn-in verification of disc and DMA functioning.

### 3.6 ADJUSTMENT PROCEDURES

The logic card age houses all the electronics on six plug-in circuit cards with the exception of circuits on the Read/Write Matrix and Servo Preamp cards. Figure 3-2 shows the correct locations for the plug-in circuit cards, as viewed from the Card locations are identified by slot numbers one thru six.

#### 3.6.1 HEAD ALIGNMENT PROCEDURE USING VDT BOOT LOADER

Perform the following steps:

1. Load Alignment Pack and set disk drive Read/Write switch to READ ONLY.

NOTE

The Alignment Pack requires 30 minutes of running time for temperature stabilization.

2. Set SENSE switches 1 and 4 on (to the left).
3. Press the LOAD switch on the CPU panel.
4. Set terminal 0 the half-duplex mode.




Figure 3-2. Plug-In Card Locations

5. Key in the following program on terminal 0 - starting with a four-digit address (0200); followed by the program; end the data input with the IV key. If a mistake is made, terminate data input with the IV key and restart with the address where the mistake was made.

0200-04  
0201-E778008  
0204-6906  
0206-E759F0  
0209-6901  
020B-00  
020C-0000  
020E-3947  
0210-2408  
0212-3967  
0214-63F6

NOTE

0201 - E78008=D0      D=disc  
E78009=D1  
E7800A=D2  
E7800B=D3

0206 - E759F0=cyl 496 head alignment track  
E75808=cyl 8 carriage way alignment check for 4219  
E75B20=cyl 800

6. Start the program by keying the starting address (0200) followed by the IV key. The disc will seek to the designated cylinder, and the system will halt. To restart, press the LOAD key and repeat step 5.
7. Remove the top rear cover held on by two screws and tilt the card cage back to access the read write matrix card. Attach the IC clip (P/N R999907) to IC A3 on the read write matrix card.
8. Attach a jumper on IC A3 pins to select the desired head as follows.

IC A3	From	To	Head
	12	1	0
	12	2	1
	12	3	2
	12	4	3
	12	5	4

9. Set up the oscilloscope as follows (see Figure 3-3).

Channel: 1 AC, 50 mV/div, TP6  
Channel: 2 Ac, 50 mV/div, TP7  
Sync: internal on channel 1, positive, 0.5 usec/div  
Mode: add, invert channel 2




Figure 3-3. Read/Write Heads and Matrix Board Configuration

10. The dabit pattern shown in Figure 3-4 should be displayed on the oscilloscope. Adjustment of the scope sync may be necessary to display a good trace for each head.

A comparison is made between amplitude arm A and B for equal amplitude (Figure 3-4). Alignment is accomplished when arm A and B are equal in amplitude.

NOTE

The alignment pack requires 30 minutes of running time for temperature stabilization.




Figure 3-4. Ideal Dibit Pattern

11. Proceed only when the alignment pack has stabilized. Remove the transparent air shroud (held down by four screws) covering the carriage and heads, and insert the safety pin down through the hole in the top of the cam tower and into the T block assembly.

**WARNING**

Never place hands or tools in the T block area without having the safety pin installed. If the carriage attempts to retract, remove all tools and the safety pin, then manually pull the heads off the alignment pack as quickly as possible. If the drive must be left unattended for any period of time, remove the safety pin.

12. Loosen the mounting screw for the head to be aligned and torque it to 20 inch-ounces (see Figure 3-3 for head location). Adjust the head (see Figure 3-4), equal amplitude of arms A and B. Torque the mounting screw to 80 inch-ounces and recheck alignment. Don't lean on the drive during alignment as this will cause the alignment to change slightly.
13. Select the next head to be aligned and repeat step 11 until all heads are aligned.
14. Remove all tools and the safety pin from the T block area.
15. With all heads aligned and the safety pin removed, install the air shroud and rear cover. Remove the alignment pack.
16. Reload boss and verify proper disc operation by performing a GET to all sectors with RTY=0. (GET 0, 1, RTY=0 A\$)

Alignment capability with this method has proven to give alignment tolerances as close as ±10 microinches.

### 3.6.2 DATA SEPARATOR PCB ADJUSTMENT PROCEDURE

Perform the following steps.

1. Degate the drive interface.
2. With the drive stopped and power turned off, remove the emergency retract relay from its socket on the servo amp/power supply chassis and plastic cover over the heads.
3. Turn power on, install a boss or scratch pack, and start the drive.
4. When the ready light stops blinking, (approximately 20 seconds) grasp the head-mounting area of the carriage and manually load the heads onto the spinning pack by moving the carriage firmly towards the spindle until the ready light goes on.



When the emergency retract relay is removed, the access mechanism is completely disabled. It is possible to damage the heads and pack by allowing pack to stop rotating with the heads extended. Do not, therefore, allow the drive to be stopped, turned off, or left unattended without first manually unloading the heads by returning the carriage to its fully retracted position.

## 5. Scope Settings

1 volt/division (use 10x probes).

100 nanoseconds/division (X10 magnifier off initially).

Display channel 1 - attach channel 1 probe to clock signal on TP1.

Trigger = INTERNAL/CH1/NEG SLOPE (auto or normal mode).

6. Adjust the trigger level control for a stable trace and verify that the full cycle time of the clock signal is approximately 103 nanoseconds (10 full cycles display in slightly more than 10 divisions).
7. Manually position the carriage slowly away from the spindle until the ready light goes out (the head-load area). The clock is now free-running, having no dabit signal to control the oscillator. Adjust R14, if necessary, to set the fre-running period to approximately 103 nanoseconds (Figure 3-5).




Figure 3-5. Data Separator and Test Point Location (End View)

8. Turn on the X10 magnifier and adjust the horizontal position to left until the last pulse is near the center of the screen. Center the trace vertically.
9. Move the carriage slowly toward the spindle until the ready light goes on. The servo head is now reading the outer servo band which may cause the trace to jitter. Move the heads further in, if necessary, to stabilize the trace. This is the vicinity of cylinder 0. Hold the carriage here for the first measurement.

10. Adjust the horizontal position control until the trailing edge of the last pulse is aligned with the center vertical line of the graticule at the mid amplitude point (Figure 3-6).




Figure 3-6. Clock Frequency Adjustment

11. Move the carriage toward the spindle slowly and observe that the pulse moves to the right as the VCO tracks the dabit signal. Allow 5 seconds for the speed to stabilize after reaching the vicinity of cylinder 800 and then note how far the pulse has shifted between cylinder 0 (highest pack speed) and cylinder 800 (lowest pack speed).
12. Move the carriage away from the spindle until the heads barely touch the lifting cams. With no dabit signal the clock is free-running at this time.
13. Adjust R14 (if necessary) to position the pulse halfway between the early and late extremes determined in step 11. (Approximately 5 nanoseconds of cumulative difference should exist for 10 clock cycles from track 0 to track 800).
14. Referring to Figure 3-6, verify that the clock pulse shifts left (earlier) when the heads are positioned in the vicinity of cylinder 0, then to the right of the free-running position (later) when positioned in the vicinity of cylinder 800. This completes the clock frequency adjustment.
15. Change the scope display to chop sweep mode and connect the channel 2 input to TP3 (data window). (See Figure 3-5).
16. Adjust the horizontal position control to display the second pulse of the channel 1 trace.

17. Position the carriage in the data cylinder area and adjust the scope vertical position controls to display the channel 2 waveform with its mid amplitude point centered vertically on the graticule.
18. Adjust R36 for a data window pulselwidth of 47.5 nanoseconds measured at the midamplitude points (Figure 3-7).




Figure 3-7. Data Window Width

19. Adjust the scope's position controls for the display shown in Figure 3-8.




Figure 3-8. Data Window/Clock Relationship

20. Adjust R31 for minimum delay (fully clockwise). This is important! Now adjust R31 counterclockwise so the trailing (negative) slope of the clock signal (CH1) is centered in the negative portion of the data window ±1 nanosecond.

### 3.7 MECHANICAL ADJUSTMENTS

Mechanical adjustments are: Heads-extended Microswitch, Off-Rack Microswitch, and Cover Lid Spring Adjustment.

#### 3.7.1 CARRIAGE-ACTUATED MICROSWITCHES

Two microswitches are actuated by the head carriage assembly over the full extent of its travel into the disc pack area. To gain access to these switches for checkout, adjustment, or replacement, raise the pack cover lid, remove the disc pack, and remove the access plate on the bottom of the air shroud, secured in place by four slotted screws. One microswitch is for head extended, the other is for off-rack adjustments.

Perform the following procedures for checkout and adjustments of the heads-extended microswitch.

1. Set the POWER ON/OFF switch to OFF, remove the disc pack, and make sure the heads are fully retracted.
2. Remove the maintenance access panel inside the air shroud (four slotted screws).
3. Disconnect plug P50 from the microswitch and measure contact resistances of the microswitch with an ohmmeter.
  - a. Between NO and C lugs (should be shorted).
  - b. Between NC and C lugs (should be open).
4. Actuate the microswitch manually by moving the carriage out slightly, and remeasure contact resistances to see if transfer occurs.
  - a. Between NO and C lugs (should be open).
  - b. Between NC and C lugs (should be shorted).

5. If a faulty microswitch was detected in steps 3 and 4, replace the microswitch, otherwise reconnect plug P50.

**CAUTION**

Do not extend heads past the cam tower or they will slam together, resulting in head damage.

6. Manually move the head carriage slightly forward. The microswitch should transfer (click heard) within 0.059 and 0.061 inch of travel from the fully retracted position. This can be measured with a dial indicator or with an inside caliper and feeler gauges.
7. If the step 6 check indicates the microswitch is out of adjustment, loosen the two screws that hold the switch mounting bracket to the way assembly, position the head carriage 0.060 inch from the fully retracted position, adjust the microswitch until the contacts just transfer, and tighten the screws. Check microswitch adjustment by repeating step 6.
8. Reinstall the maintenance access cover.

### 3.7.2 OFF-RACK MICROSWITCH AND ADJUSTMENT

The Off-Rack Microswitch adjustment is performed in the following manner for checkout and adjustment.

1. Set the POWER ON/OFF switch to OFF, remove the disc pack, and make sure the heads are fully retracted.
2. Remove the maintenance access panel inside the air shroud (four slotted screws).
3. Disconnect plug P51 from the microswitch and measure contact resistances of the microswitch with a ohmmeter.
  - a. Between NO and C lugs (should be open).
  - b. Between NC and C lugs (should be shorted).
4. Actuate the microswitch manually and remeasure contact resistances to see if transfer occurs.
  - a. Between NO and C lugs (should be shorted).
  - b. Between NC and C lugs (should be open).

5. If a faulty microswitch was detected in steps 3 and 4, replace the microswitch. Otherwise, reconnect plug P51.

**CAUTION**

When the heads are extended past the cam tower, the head pads must be protected from making physical contact with each other. This is done by placing folded Kimwipes (at least four thicknesses) between opposing heads and moving them out slowly so that they come together gently.

6. Protect the heads and move them off the cam tower slowly until they are resting on each other. Then move the carriage until contact is made with the forward end stop. The microswitch should transfer (click heard) within 0.000 and 0.005 inch before the carriage contacts the end stop. This measurement can be checked with feeler gauges.
7. If the step 6 check shows the microswitch to be out of adjustment, loosen the two screws that hold the switch mounting bracket to the way assembly, position the head carriage 0.0025 inch from the end stop, adjust the microswitch until the contacts just transfer, and tighten the screws. Check microswitch adjustment by repeating step 6.
8. Retract the heads manually and remove the tissue pads as the heads are cammed apart. Inspect the heads for contamination, and reinstall the maintenance access cover.

### 3.7.3 COVER LID SPRING ADJUSTMENT

The cover lid is held in the raised position by a torsion spring at the bottom of the lid. This spring, when adjusted properly, will maintain the lid in any position from half open to fully open. To adjust spring tension, proceed as follows:

1. Remove the air shroud assembly (refer to paragraph 4.2.2).
2. Put the lid in its half-open position, and tighten or loosen the self-locking nut on the underside of the right-hand spring keeper.
3. Lower the lid then raise it to the half-open position. The lid should remain in this position, if not, repeat step 2.

### 3.7.4 LID-CLOSED MICROSWITCH CHECKOUT AND ADJUSTMENT

The lid-closed microswitch is located beneath the air shroud and is actuated by a pin on the underside of the cover lid when the lid is closed. If the switch is suspected of faulty operation or misadjustment, proceed as follows:

1. Unplug connector P/J30.
2. Measure contact resistances of the microswitch at connector J30 by using an ohmmeter. (See Figure 3-9 for connector pin locations.)

With cover open:

Between pins 4 and 5 (should be shorted)

Between pins 5 and 8 (should be open)

With cover closed and latched:

Between pins 4 and 5 (should be open)

Between pins 5 and 8 (should be shorted)




Figure 3-9. Connector J30 Pin Locations

### 3.7.5 SPINDLE LOCK ASSEMBLY ADJUSTMENT

1. Set the PWR ON/OFF switch to OFF.
2. Remove the maintenance access plate inside the air shroud (four slotted screws).
3. Loosen both screws (Figure 3-10) that secure the spindle lock to the base plate.




Figure 3-10. Spindle Lock Assembly

4. Adjust the spindle lock level mounting bracket for  $7.100 \pm 0.010$  inches from the centerline of the spindle to the tip of the actuating button closest to spindle center. Tighten both screws to 100 inch-ounces.
5. Install a disc pack and cover on the spindle, and observe that the spindle locks with a pack cover on.
6. Remove the pack cover and observe that the spindle is free to rotate.
7. Remove the disc pack and install the maintenance plate.

### 3.7.6 SPEED TRANSDUCER CHECKOUT AND ADJUSTMENT

The Speed Transducer is a magnetic pickup coil located adjacent to the spindle pulley that generates one speed pulse per revolution of the spindle. The pickup is from a carbon steel pin embedded in the spindle pulley over which the transducer is aligned. Transducer adjustment is usually necessary only if there has been shipping damage or if the transducer has been replaced.

1. Set the PWR ON/OFF switch to OFF.
2. Extend the disc drive. Remove the bottom maintenance access cover.
3. Rotate the spindle pulley manually and check for noises that would indicate that the transducer is rubbing against the spindle pulley. If the transducer is rubbing, go directly to step 5.
4. Using nonmagnetic shim material as a feeler gauge, check the gap between the transducer and the carbon steel pin in the spindle pulley. It should be  $0.006 \pm 0.001$  inch, as indicated in Figure 3-11. Also check that the end of the transducer coil is aligned with the pin.




Figure 3-11. Speed Transducer Gap Limits

5. To adjust the gap between the transducer and the spindle, loosen the locknut on the bracket end of the transducer, turn the threaded transducer to move the transducer toward or away from the spindle until it lightly contact a feeler gauge of 0.006-inch-thick nonmagnetic shim stock, and tighten the locknut. Check output at connector backplane pin 6B 13. If a minimum of 5.0 volts cannot be attained with this new adjustment, replace the transducer.
6. Replace the bottom access cover and return the unit to its normal position.

### 3.7.7 MOTOR BOBBIN ALIGNMENT

The motor bobbin inside the linear motor is attached to the T-block and held in alignment by four screws (Figure 3-12). Bobbin alignment should not be necessary unless there has been shipping damage or the linear motor has been replaced. To align the bobbin, proceed as follows.




Figure 3-12. Bobbin Mounting Screw Location

1. Set the PWR ON/OFF switch to OFF.
2. Remove the rear cover and the transparent air shroud.
3. Swing out the logic card cage and power supply assemblies.
4. Make sure the carriage is fully retracted, and loosen the four bobbin-retaining screws (just enough so that the bobbin can be moved with the fingers).
5. Cut four 3/4 inch wide shims from filing card or punch card stock. These should be at least four inches long.
6. Place folded Kimwipe tissue pads (at least four thicknesses) between opposing heads to cushion the head pads, and move the heads out slowly so that they come together gently and just clear the camming tower.
7. Place the four paper shims between the bobbin and the linear motor housing lengthwise; space them evenly around the bobbin.

**CAUTION**

Make sure that the shims protrude far enough beyond the T-block end of the bobbin that they can be pulled out after alignment is complete. Otherwise, removal of the entire linear motor may be necessary to retrieve them.

8. Move the heads back to the retracted position; make sure that the shims are clearly in sight.
9. Tighten and torque the four bobbin-retaining screws to 100 inch-ounces.
10. Remove the four paper shims.
11. Replace the Kimwipe tissue pads between the heads, let them come together gently, and check for any indication of bobbin drag over the full distance of carriage travel.
12. Move the heads back to the retracted position; remove the pads as the heads cam apart. Inspect the heads for lint, and clean them in place if necessary.
13. Close and secure the logic card cage and power supply assemblies; reinstall the transparent air shroud and rear cover.

### 3.8 CLEANING AND PREVENTIVE MAINTENANCE

Cleanliness is probably the single most important element in the maintenance program for the disc drive. With the exception of the read/write heads, cleaning operations are normally limited to the use of lint-free cloths dampened with a solution of 91 percent isopropyl alcohol. The disc pack and the mechanical assemblies are cleaned with this solution and then wiped dry with the lint-free cloth. The exterior panels of the drive and the disc access cover may be cleaned with a soft detergent, wiped with a damp cloth, and then wiped dry.

**CAUTION**

Do not use abrasive cleaners and chemical cleaning agents that contain acetone, toluene, xylene, or benzene. These cleaners may cause equipment damage that requires major repair.

Table 3-3 gives the monthly periodic maintenance procedures while Table 3-4 gives the semi-annual procedures.

TABLE 3-3. MONTHLY PREVENTIVE MAINTENANCE SCHEDULE

Component	Procedure	Remarks
External cabinet surfaces	Clean	Use soft cloth and commercial (soft) detergent.
Disc packs	Inspect	Inspect packs; clean only if visible contamination is present or if read errors have been observed.
Read/write heads check	Inspect	Refer to paragraph 3.8.1.
Power Supply	Test	Refer to paragraph 3.8.3.
Air shroud	Clean	Refer to paragraph 3.8.4.
Spindle surface	Inspect, clean, and lubricate	Refer to paragraph 3.8.5.
Spindle grounding brush	Check resistance	Refer to paragraph 3.8.2.
Intake air filter	Clean	Refer to paragraph 3.8.6.

TABLE 3-4. SEMI-ANNUAL PREVENTIVE MAINTENANCE SCHEDULE

Component	Procedure	Remarks
Perform all Monthly Preventive Maintenance Procedures		
Internal cabinet surfaces	Clean	Use a soft brush or vacuum cleaner or both.
Absolute air filter	Replace	Refer to paragraph 4.2.1.
Read/write circuits	Check alignment	Refer to paragraph 3.6.1.
Carriage and Way		
Spindle drive circuits	Check operation	Refer to paragraph 3.7.5.

### 3.8.1 READ/WRITE HEADS CHECK

For routine head maintenance, inspect the read/write heads while they are in place for contamination. Proceed as follows.

1. Make sure that the Disc Drive is powered down. Open the Disc Drive lid and remove the disc pack.
2. Remove the rear cover from the unit and remove the four screws that hold the transparent air shroud. Remove the shroud for access to the heads.
3. Move the carriage outward by hand no more than 3/8 inch to separate the heads for easier inspection. Hold the carriage in this position.

**CAUTION**

The head spring arms against the cam surfaces tend to pull the carriage further outward if not restrained and cause the heads to crash together. In step 4 do not touch the head surfaces with the inspecting tools.

4. Using a pen flashlight or other light source and a dental mirror, inspect each head for possible damage and contamination .
5. If a head has been damaged, it must be replaced. Refer to paragraph 4.2.12 for the head removal procedure. Dirty heads can usually be cleaned in place by following the head cleaning procedure given in paragraph 3.8.7.
6. After inspection is complete, return the heads to the fully retracted position and reinstall the transparent air shroud.

### 3.8.2 SPINDLE GROUNDING BRUSH AND BELT CHECK

The spindle grounding brush provides a ground for static discharge of the disc pack and spindle.

1. Remove the front black door on the front of the Disc Drive so that the bottom access cover can be reached.
2. Remove the bottom access cover.
3. Check the resistance between the spindle contact arm (Figure 3-13) and the spindle. Resistance must be less than one-half ohm. If the resistance is too high, replace the grounding brush (refer to paragraph 4.2.18).




Figure 3-13. Spindle Drive Component Checks

4. Inspect the spindle drive belt (Figure 3-13) for fraying or other damage. If damage or belt stretch is apparent, replace the drive belt (refer to paragraph 4.2.6).
5. Replace the bottom access cover and return the Disc Drive to its normal position.

### 3.8.3 POWER SUPPLY CHECKOUT

Using a digital voltmeter, check the power supply voltages at power supply printed circuit board connector J10 as indicated in Table 3-5. The PWR ON/OFF switch must be turned ON. See Figure 3-14 for test point locations.

TABLE 3-5. POWER SUPPLY VOLTAGE CHECK

#### CONNECTOR J10

From Pin	To Pin	Output
02	01 (+)	+30 to +35V
02	03 (-)	-30 to -35V
09	04 (+)	+0.8 to +10.5V





Figure 3-14. Dc Voltage Check Points

Alternatively, these voltages may be checked at the fuse block located on the frame base beneath the card cage assembly. Check voltages at these fuses with reference to dc ground (card cage terminal E11).

There are no power supply adjustments for these voltages. If any one is out of tolerance, the power supply should be replaced (refer to paragraph 4.2.10).

#### 3.8.4 CLEANING THE DISC PACK AREA

1. Open the pack area lid and remove the disc pack.
2. Wipe the inside of the air shroud (Figure 3-15) with a lint-free cloth dampened with alcohol. Wipe it dry and remove all residue.



3. Clean the inside of the pack area lid with the alcohol-dampened cloth. Wipe it dry and remove all residue.
4. Inspect the lid gasket for evidence of deterioration and wipe the gasket clean, if necessary.

#### 3.8.5 CLEANING AND LUBRICATING THE SPINDLE

1. Open the pack area lid and remove the pack.
2. Inspect the spindle (Figure 3-15) for dirt or other contamination and for wear.



Do not saturate the spindle surface with alcohol. Alcohol runoff into the spindle bearing will cause damage.

3. Clean the spindle surface with alcohol and a lint-free cloth, and wipe the surface dry.
4. Use a lint-free cloth to remove contamination and grease from the threads of the spindle hole. Use a dry lint-free cloth to soak up any remaining alcohol.
5. Apply a light coat of Molybdenum Grease to a lint-free cloth, and lubricate the threads of the spindle hole. Do not allow lubricant to get on the surface of the spindle.
6. Place a disc pack on the spindle to make sure that it can be installed and removed easily.
7. Operate the spindle lock by hand to verify that it engages and disengages freely.

#### 3.8.6 CLEANING THE INTAKE AIR FILTER

The intake air filter is a foam filter element located behind the Basic Four logo on the front cover. It prefilters all air going to the blower and should be cleaned monthly, as follows.

1. Remove the front cover to gain access to the intake filter.
2. Pull out the foam filter element from its recess in the front of the unit; wipe the inside of the recess with a damp, lint-free cloth, and dry the recess well.

**CAUTION**

Do not operate the machine with the intake air filter removed. This will cause the absolute air filter inside the unit to load up prematurely.

3. Wash the foam filter element in a weak solution of detergent in warm water, rinse the element thoroughly in cold water, and blow the element absolutely dry with air before reinstalling it.
4. Reinstall the clean, dry filter element (or a new filter element if deterioration had occurred) in the filter recess, and replace the front cover.

#### 3.8.7 CLEANING THE READ/WRITE HEAD (Figure 3-16)

1. Dampen a lint-free cloth with Freon TF and clean the contaminated head pad surface.
2. Dry the head pad with a lint-free cloth.
3. Reinspect the head pad to make sure that the head is clean and free of residue. Also check adjacent heads to be sure they have not been contaminated by the cleaning operation.
4. If oxide cannot be removed in this way, the head will have to be removed for more thorough cleaning or for replacement.




Figure 3-16. Read/Write Heads

## CHAPTER 4

### REMOVAL/REPLACEMENT PROCEDURES

#### 4.1 SPARE PARTS LIST

TABLE 4-1. REPLACEMENT PARTS FOR DISC DRIVE

Item No.	MM Number	Manufacturer Part Number	Part Description
1	240010	12449-002	Assy , Power Supply 115V
2	240040	15847-001	PCB , Logic II
3	240080	18752-001	PCB , Servo Control T-80
4	240090	12452-002	Assy , Sequence Relay 115V
5	240330	R6060RGB3001R	Head , R/W 01 , T-80
6	240340	R6060RGB4001R	Head , R/W 00,03 , T-80
7	240350	R6060RGA1002	Head , R/W 02 , T-80
8	240360	R4040NSA2002R	Head , Servo
9	240420	17589-001	PCBA , Read/Write Matrix
10	240430	17530-001	PCB , Data Separator T-80
11	240440	17771-001	PCBA , Read Limiter
12	240450	19508-001	PCB , Logic III (N/S)
13	240460	903050	PCB , Logic I (2530) 35MB
14	240470	100575	PCB , Terinator
15	248010	1233275G-001	Filter , Absolute

TABLE 4-1. REPLACEMENT PARTS FOR DISC DRIVE

Item No.	MM Number	Manufacturer Part Number	Part Description
16	248020	12560-001	Filter , Preliminary
17	249010	12427-001	Extender , PCB
18	249021	17209-001A	Head Positioning Tool O/S
19	249030	97769-001	Head , Positioning Tool N/S
20	249040	TS-100 UTICA	Torque Wrench , Head Mount
21	249050	97722-001	Pin Safety
22	249060	13445-001	Tach Rod Insert/Remo. Tool
23	249070	13484-001	Tool , Way Roll Adjust
24	249080	13484-001	Tool , Carriage & Way Align
25	249090	99129-001	Wrench , Way Screw
26	249100	12541-001	T80-CE Pack
27	249110	96803-001	Read Camming Tool
28	249130	1QS-6-PU	Way Torque Driver
29	249140	13378-001	Head Wright Set
30	249150	TAN	Shim , 004+/-001 NON MAG
31	249190	BH 3/32	Hex Key (Ball 3/32)

## 4.2 REMOVAL/REPLACEMENT PROCEDURES

### 4.2.1 REPLACING THE ABSOLUTE AIR FILTER

The absolute air filter inside the disc drive should be replaced every six months of normal use or more often in extreme environments. To replace this filter, proceed as follows.

1. Set the PWR ON/OFF switch to OFF, and remove the front and rear covers from the unit.
2. Open the pack area lid, remove the disc pack, and make sure that the heads are fully retracted.
3. Remove the air shroud assembly with its absolute air filter attached by following the air shroud removal procedure in paragraph 4.2.2.
4. Remove the three screws (one upper and two lower) that attach the rectangular air filter end cap to the air shroud, and lift out the air filter element.
5. Install a new filter element; make sure that the air flow is correct (arrow on the filter element should point to the rear of the assembly) and reinstall the end cap with the three screws.
6. Reinstall the air shroud assembly, intake air filter, rear cover, and front cover.

### 4.2.2 AIR SHROUD ASSEMBLY REMOVAL

Access to certain parts and assemblies of the disc drive, such as the blower, spindle, and the absolute air filter, require the removal of the air shroud assembly with its attached lid. To remove and reinstall the air shroud assembly, proceed as follows.

1. Remove the disc pack, if applicable, and verify that the heads are fully retracted.
2. Set the PWR ON/OFF switch to OFF, and remove the front panel and rear cover from the disc drive.
3. Remove the front air intake (foam) filter element for access to the two screws, on the left-hand side of the filter recess, that fasten the air shroud to the blower plenum. Loosen these two captive screws.
4. Disconnect the connector leads from the lid-closed microswitch.
5. Raise the lid and remove the four slotted screws from the bottom of the air shroud access cover. Remove the four Phillips screws from the bottom of the air shroud to the standoffs on the deck plate.

6. Lift the air shroud carefully straight up and off.
7. Reinstall the air shroud assembly by following the removal procedures in reverse order. Check that the heads are fully retracted before starting the reinstallation. Also verify that the gasket along the baseplate and head cam tower is not damaged or deformed during installation.

#### 4.2.3 CARD CAGE REMOVAL AND REPLACEMENT

1. Set the PWR ON/OFF switch to OFF.
2. Remove the rear cover.
3. Remove all circuit cards from the card cage. Note their locations for reinstallation.
4. Disconnect all interface cables and the terminator, if present.
5. Disconnect P1 thru P8. Swing the card cage out.
6. Tag and disconnect wires from the backplane.
7. Disconnect the Molex connector near the hinged end of the card cage assembly.
8. Remove the ground strap.
9. Remove the restraining cable from the card cage.
10. Remove the card cage from the frame by removing three screws.
11. To install the replacement assembly, reverse the procedure. Be sure that the replacement assembly is positioned so that the hole lines up with the bracket in front of the card cage.

#### 4.2.4 CARRIAGE AND WAY ASSEMBLY REPLACEMENT

The carriage, carriage way, and head mounting T-block are precisely adjusted and aligned at the factory. They must be replaced as an assembly whenever any component wears, becomes misaligned, or is damaged. Replacement because of wear is indicated when the assembly cannot be brought into Carriage and Way Alignment Check tolerances by performing the alignment procedure.

NOTE

This is a precision assembly and is easily damaged and rendered useless if the way bearing surfaces are scratched or if disassembly is attempted. Replacement and alignment require a high level of technical skill. It is recommended that only factory trained personnel attempt replacement. Special tools are also necessary.

To replace the carriage and way assembly, proceed as follows:

1. Set the PWR ON/OFF switch to OFF, and disconnect the ac power cable from the source
2. Unload the disc pack, if installed, and remove the front and rear covers from the disc drive.
3. Remove the transparent air shroud, disconnect and remove all heads from the T-block, and store the heads safely.
4. Remove the air shroud assembly.
5. Remove the Read/Write Matrix board.
6. Remove the four screws, lockwashers, and flat washers that hold the head cam tower to the deck plate, and remove the cam tower.
7. Disconnect plugs P50 and P51 from the carriage-actuated microswitches, and remove the two microswitches with their mounting brackets attached. Remount the microswitches on the replacement assembly; torque the mounting screws to 100 inch-ounces.
8. Remove the four screws that attach the carriage to the linear motor bobbin. Note the position of the grounding wire for later reassembly.
9. Remove the three bolts and lockwashers that hold the carriage and way assembly to the deck plate, and carefully remove the assembly; tilt it to clear the conductor band support bracket.

**CAUTION**

Exercise great care in handling the replacement carriage and way assembly. Particularly the coating on the bearing surfaces which is easily damaged by careless tool handling.

10. Clean the mating surfaces of the dewck plate and the replacement carriage and way assembly with alcohol and wipe them dry.

11. Position the replacement carriage and way assembly on the base plate, and reinstall the three mounting bolts; leave them loose.
12. Perform the carriage and way alignment procedure.
13. Reconnect the carriage to the linear motor bobbin with the four screws removed in step 8, and perfpr , the motor bobbin alignment procedure (refer to paragraph 3.7.7).
14. Perform the heads-extended switch checkout and adjustment (refer to paragraph 3.7.1) and the off-rack switch checkout and adjustment procedures (refer to paragraph 3.7.2). Make sure that plugs P50 and P51 are reconnected to the microswitches after adjustment.
15. Reinstall the head cam tower by using the hardware removed in step 6. Torque the mounting screws to 45 inch-pounds.
16. Reinstall and reconnect the Read/Write Matrix board.
17. Reinstall the air shroud assembly.
18. Clean and reinstall the heads in their correct locations. Use the prepositioning tool for initial alignment, and torque the heads to the full 80 inch-ounces.
19. Reconnect the ac powre cable, set the PWR ON/OFF switch to ON, and perform the appropriate steps of the head alignment checkout and adjustment procedure to align the heads.
20. Perform the carriage and way alignment check procedure (refer to paragraph 3.6.1). If carriage and way alignment is out of tolerance, the alignment procedure will have to be repeated. The heads will have to be removed, but not that further disassembly is unnecessary, as the alignment procedure can be carried out through the access cutout in the air shroud.
21. When carriage and way alignment and head alignment check out, replace the transparent air shroud and the two covers.

#### 4.2.5 COVER GASKET REPLACEMENT

1. Remove the air shroud assembly (refer to paragraph 4.2.2) from the drive and the cover lid from the air shroud assembly.
2. Note that the cover gasket is not multipositional but has a slight locating protrusion at the bottom of the cover. The new gasket must be installed in the same position.
3. Reactivate the adhesive that holds the old gasket in place by soaking the edges of the gasket with an activator solution of 92 percent 1.1.1 Trichloroethane and 8 percent isopropyl alcohol by volume.
4. Continue to pry and soa the gasket with activator solution until the gasket is free of the cover.

5. Clean the lid surface free of adhesive with more activator solution, and dry the cleaned surface.
6. Moisten the adhesive side of the new gasket with activator solution, and position it on the cover lid. Verify that the gasket is not deformed by having been stretched and that all edges are held down tight.
7. Reinstall the cover lid and air shroud assembly. Keep the lid closed for several hours to ensure a good adhesive bond.

#### 4.2.6 DRIVE BELT REPLACEMENT

The spindle drive belt is made accessible by removing the bottom maintenance access cover. Replacement is required if there is any evidence of belt deterioration, such as fraying or stretching. Proceed as follows to replace the belt.

1. Set the PWR ON/OFF switch to OFF.
2. Extend the disc drive unit. Remove the bottom access cover.
3. Pull the spindle drive motor toward the spindle and against the tensioning spring to slacken the belt, and slip the belt off the motor pulley.
4. Install a new belt in the same manner as the old belt was removed in step 3.
5. Spin the drive motor, belt, and spindle by hand to make sure that the belt rides in the center of both pulleys.
6. If the belt is not centered on both pulleys, slacken the belt, center it on the spindle pulley, and adjust the motor pulley height as necessary. There are two setscrews on the motor pulley; one on the key and one on the flat part of the shaft.
7. Repeat step 5. When the belt rides correctly, replace the bottom access plate and return the unit to its normal position.

#### 4.2.7 HEADS-EXTENDED MICROSWITCH REPLACEMENT

If the heads-extended checkout procedure indicates that the microswitch is faulty, replace the switch as follows.

1. Disconnect plug P50 from the microswitch.
2. Remove the two screws that fasten the switch mounting bracket to the way assembly, and remove the microswitch and bracket as a unit.

3. Install the new microswitch on the mounting bracket by using the original switch mounting hardware.
4. Reinstall the microswitch and bracket on the way assembly; leave the two bracket screws slightly loose. Reconnect plug P50.
5. Position the head carriage 0.060 inch from the fully retracted position, adjust the microswitch until the contacts just transfer, and tighten the bracket screws.
6. Move the head carriage manually between the fully retracted position and the microswitch transfer point. The microswitch should transfer within 0.059 and 0.061 inch of travel. If not, repeat step 5.
7. Reinstall the maintenance access cover.

#### 4.2.8 LINEAR MOTOR REPLACEMENT

Linear motor replacement is necessary, usually, only if the bobbin is defective. The linear motor is supplied as a tested assembly that includes the motor housing, bobbin, front bracket, and conductor bands, but without velocity tachometer components. To replace the linear motor, proceed as follows.

1. Set the PWR ON/OFF switch to OFF, and disconnect the ac power cable from the source.
2. Remove the rear cover and the transparent air shroud. Make sure the heads are fully retracted.
3. Unlatch the power supply assembly and swing it out.
4. Disconnect and tag the two wires to the linear motor conductor band lugs.
5. Remove the tach rod and pickup coil from the linear motor. Refer to the Velocity Transducer Replacement procedure, paragraph 4.2.19.
6. Note the location of the ground wire, and remove the four screws that hold the bobbin to the T-block (Figure 4-1). When reinstalling the bobbin, verify that the ground wire is reconnected, and perform the Motor Bobbin Alignment procedure (paragraph 3.7.7).

**CAUTION**

Do not remove the T-block from the carriage. The T-block is factory aligned to the carriage and way assembly.




Figure 4-1. Bobbin Mounting Screw Location

7. Placed folded disposable tissue pads (at least four thicknesses) between opposing heads to cushion the head pads, and move the head out slowly so that they come together gently. Move the carriage forward to get it out of the way.
8. Remove the four screws that hold the linear motor to the deck plate. torque the screws to 80 inch-pounds when reinstalling them.
9. Lift the linear motor carefully straight up and out (a two-man job). Watch your fingers during replacement.
10. To install the replacement linear motor, reverse the procedure. Make sure that the mating surfaces of the linear motor and deck plate are clean and that the linear motor is positioned squarely over the deck plate locating pins. The motor bobbin must also be aligned as per step 6.

#### 4.2.9 OFF-RACK MICROSWITCH REPLACEMENT

If the Off-Rack Microswitch Checkout procedure indicates that the microswitch is faulty, replace the switch as follows.

1. Disconnect Plug P51 from the microswitch.
2. Remove the two screws that fasten the switch mounting bracket to the way assembly, and remove the switch and bracket as a unit.

3. Install the new microswitch on the mounting bracket by using the original switch mounting hardware.
4. Reinstall the microswitch and bracket on the way assembly; leave the two bracket screws slightly loose. Reconnect plug P51.

**CAUTION**

When the heads are extended past the cam tower, the pads must be protected from making physical contact with each other. This is done by placing folded disposable (at least four thicknesses) between opposing heads and moving them out slowly so that they come together gently.

5. Protect the heads and move them off the cam tower slowly until they are resting on each other. Then move the carriage until contact is made with the forward end stop.
6. Position the head carriage 0.0025 inch away from the end stop, adjust the microswitch until the contacts just transfer, and tighten the bracket screws.
7. Move the head carriage manually between the end stop and the microswitch transfer point. The microswitch should transfer within 0.000 and 0.005 inch of the end stop.
8. Retract the heads manually, and remove the tissue pads as the heads are cammed apart. Inspect the heads for contamination, and reinstall the maintenance access cover.

#### 4.2.10 RELAY ASSEMBLY REPLACEMENT

The Sequency Relay Assembly is located between the blower and the spindle drive motor. It is hinged to the frame assembly so that it can be swung out for service. See Figure 4-2 for locations of major component parts. To remove and reinstall the relay assembly as a unit, proceed as follows.

1. Set the PWR ON/OFF switch to OFF, and disconnect the ac power cable from the source.
2. Remove the front cover.




Figure 4-2. Sequence Relay Assembly Component Locations

3. Swing the relay assembly out to its service position, and disconnect connectors P20, P21, P22, P23, and J32. Clip any ties that attach the cables to the relay assembly.
4. Swing the relay assembly in, but not fully. Using a flathead screwdriver, spring the left-hand hinge from its pivot pin and remove the relay assembly.
5. To install the replacement relay assembly, reverse this procedure.

#### 4.2.11 POWER SUPPLY REMOVAL/REPLACEMENT

If power supply voltage checks given in paragraph 3.8.3 indicate that outputs are out of tolerance, the power supply must be removed for replacement. To remove and replace the power supply, proceed as follows.

1. Disconnect the disc drive ac power cable from the power source, and remove both front and rear covers.
2. Diconnect and tag the two wires coming from the Ac Input Control Assembly at power supply terminal board TB2, terminals 1 and 2.
3. Disconnect plug P21 from the Sequence Relay Assembly (cut the harness ties as necessary).
4. Loosen the captive retaining screw that secures the power supply in its normal position, and swing out the power supply on its hinges.

5. Disconnect plugs P10 and P13 from the bottom side of the power supply assembly.
6. Disconnect the two wires from the bobbin conductor band terminals.
7. Disconnect the two green wires from the ground stud under the front of the power supply chassis.
8. Slide the power supply assembly off its hinges and remove it.
9. To install the replacement power supply, reverse this procedure. Make sure that the connection from chassis ground to logic ground is reinstalled properly and that the voltage select jumper on terminal board TB2 matches the available voltage.

#### 4.2.12 READ/WRITE HEAD REMOVAL/REPLACEMENT

NOTE

Certain procedures in this book call for manually extending the heads without a pack. When this is done, folded strips of lint-free disposable tissues should be placed between the facing heads, and the heads should be moved slowly outward so that they contact one another as gently as possible.

To remove a read/write head or the servo head for thorough bench cleaning or replacement, proceed as follows.


1. Power down the disc drive and remove the disc pack.
2. Remove the rear cover, set the INTERFACE/DEGATE switch to DEGATE and the PWR ON/OFF switch to OFF.
3. Take out the four screws that secure the transparent air shroud covering the carriage assembly and cam tower, and pull the shroud straight up and off.
4. Remove the head cable plug retainer from the Read/Write Matrix board, and disconnect the cable plug of the head being removed.

**CAUTION**


Do not overflex the head arm when installing the head camming tool during the next step, or permanent damage to the head will result.

5. Install the head camming tool on the head assembly to be replaced as shown in Figure 4-3.

(A)



(B)



(C)




Figure 4-3. Head Camming Tool Installation

6. Unscrew the mounting screw that attaches the head assembly to the carriage T-block. Carefully remove the head.

To install a read/write head after bench cleaning and inspection (or to replace a head), proceed as follows.

**CAUTION**

Do not overflex the head arm when installing the head camming tool during the first step, or permanent damage to the head will result.

1. Install the head camming tool on the head assembly to be replaced, as shown in Figure 4-3.
2. Insert the head assembly with the camming tool installed in the correct position by setting the arm on the proper cam and then sliding the head to the rear so that both front and rear tangs on the head mount mate with the proper T-block slots on the carriage assembly (Figure 4-4).




Figure 4-4. Head Positioning and Mounting Components

**CAUTION**

If the arm is allowed to slide forward toward the spindle during any of the following steps, the rear tang may disengage from the T-block slot. If this occurs, the head can rotate and slam into the opposing head, resulting in damage to both heads.

3. While holding the head firmly against the T-block, remove the head camming tool.
4. Install the two-prong prepositioning tool in the hole in the T-block and the slot in the head mount, and tighten the head mounting screw just tight enough to hold the head in place. Remove the tool.
5. Connect the head cable plug to the appropriate head receptacle on the Read/Write Matrix board, and secure it with the cable plug retainer after all heads have been installed.
6. After all heads to be installed have been prepositioned according to steps 1 thru 5, perform the head alignment checkout and adjustment procedure (refer to paragraph 3.6.1).

#### 4.2.13 SERVO HEAD INSTALLATION

The servo head is installed with the head camming tool in a manner similar to the other read/write heads. However, the T-block has a positioning pin in the servo head locatin that makes the use of the prepositioning tool unnecessary. When installing the servo head, locate the head mount over the positioning pin, press the head rearward (into the T-block) against the pin, and tighten the securing screw with the head torque wrench to 80 inch-ounces.

When the servo head position has been disturbed by removal and replacement of the head, all other read/write heads must be realigned to the new servo head position by performing the head alignment checkout and adjustment procedure.

#### 4.2.14 SPINDLE LOCK ASSEMBLY REPLACEMENT

If the Spindle Lock Assembly (Figure 4-5) cannot be adjusted properly replace assembly.




Figure 4-5. Spindle Lock Assembly.

1. Set the PWR ON/OFF switch to OFF.
2. Remove the maintenance access plate inside the air shroud (four slotted screws).
3. Remove the spindle lock assembly (Figure 4-5).
4. Install the replacement spindle lock assembly with hardware removed
5. Perform the Spindle Lock Assembly Adjustment procedure (refer to paragraph 3.7.5).

#### 4.2.15 SPINDLE DRIVE MOTOR REPLACEMENT

The spindle drive motor is a single-phase, capacitor-start motor that provides high starting torque at low speed. A thermal cutout switch protects the motor against overheating. Repeated starting and stopping during troubleshooting may trip the thermal switch and is not necessarily an indication that the motor is defective. The motor may require up to 1 hour to cool depending on the ambient temperature.

Other drive motor components, such as starting capacitor C1, sequence relay and solid state switches K1, K2, and K3, can also prevent the drive motor from operating and should be checked out before drive motor replacement is considered. If the drive motor is defective, replace it as follows.

1. Set the PWR ON/OFF switch to OFF.
2. Remove the front and rear cover.
3. Remove the bottom maintenance access plate.
4. Disconnect P22 from the relay assembly.
5. Pull the drive motor toward the spindle and slip the drive belt from the motor pulley.
6. Remove the motor pulley from the end of the drive shaft.
7. Remove the four bolts that secure the drive motor to its mounting plate, swing out the power supply assembly, and remove the motor from the top.
8. To install the replacement motor, reverse the procedure.
9. Spin the pulley by hand to ensure that the drive belt runs straight and true. If necessary, adjust the vertical position of the pulley.

#### 4.2.16 SPINDLE ASSEMBLY REPLACEMENT

The spindle assembly (Figure 4-6) is a precision unit with sealed bearings that requires an occasional cleaning and relubrication of the pack mounting threads. It should never be removed from the deck plate unless replacement is necessary, as removal requires complete realignment of the head-positioning system. Replacement of the spindle assembly occurs only if pack mounting or unmounting difficulties are experienced (thread wear) or when bearing wear becomes excessive.




Figure 4-6. Spindle Assembly

To replace the spindle assembly proceed as follows:

1. Set the PWR ON/OFF switch to OFF.
2. Remove the maintenance access plate from the air shroud assembly (four slotted screws).
3. Remove the bottom maintenance access plate.
4. Remove the drive belt.
5. Remove the three bolts that secure the spindle to the deck plate. Clean old Loctite from the bolts.
6. Remove the spindle assembly from the deck plate by pulling the spindle assembly straight up and out.

**CAUTION**

The spindle and deck plate are machined to extremely close tolerances. Cocking the spindle will result in binding against the deck plate and may damage the machined surfaces.

7. Remove the grounding button and install it on the replacement spindle shaft, or use a new button as required.
8. Clean the deck plate and spindle mating surfaces with Freon TF to remove all foreign matter.
9. Install the replacement spindle. A notch on the spindle mounting flange provides clearance for the spindle lock mechanism during removal and installation. Do not force it!
10. Apply one drop of Locktite, grade C to the threads at the ends of the mounting bolts and install the bolts. Torque the bolts to 80 inch-pounds.
11. Install the drive belt.
12. To adjust the gap between the transducer and the spindle, loosen the locknut on the bracket end of the transducer. Turn the threaded transducer to move the transducer toward or away from the spindle until contacting a feeler gauge of 0.004 inch-thick nonmagnetic shim stock. Tighten the locknut.
13. Perform the spindle lock assembly adjustment procedure (paragraph 3.7.5).
14. Perform the carriage and way alignment check procedure (paragraph 3.6.1).
15. Perform the head alignment checkout and adjustment procedure (paragraph 3.6.1).
16. Reinstall all maintenance access covers.

#### 4.2.17 VELOCITY TRANSDUCER REPLACEMENT

The velocity transducer consists of two components: the tachometer rod (tach rod) and the tachometer rod housing (pickup coil). (See Figure 4-7.)




Figure 4-7. Velocity Transducer Components and Tool

Install and remove both of these components through the rear of the linear motor housing. The tach rod is fastened internally to the T-block, while the pickup coil is held stationary inside the linear motor. A spring holds the pickup coil in position. Replace velocity transducer a follows.

**CAUTION**

The tach rod is very brittle and will break if not handled carefully. Do not use a tach rod that has been dropped; even if it doesn't break, its magnetic characteristics may have been altered.

1. Set the PWR ON/OFF switch to OFF.
2. Remove the rear cover.
3. Swing out the logic card cage assembly.

4. Velocity transducer wires from the rear of the linear motor are connected to the card cage backplane.
5. Make sure that the heads are fully retracted.
6. Remove the velocity transducer retaining place from the rear of the linear motor (two slotted screws).
7. Remove the pickup coil and coil-retaining spring from the motor.
8. Note two pins on one end of the tach rod insertion tool, part no. 249-060. Insert this end of the tool as far as it will go into the linear motor location vacated by the pickup coil.
9. Turn the tool counterclockwise until the two pins engage holes in the tach rod flange. Continue turning it until the tach rod is free of the T-block, and remove the tool and rod together.
10. To install velocity transducer components, reverse this procedure. Place the tach rod inside the tool over the pins to install it. Make sure that the tach rod and tool are fully inserted into the linear motor (to the mark on the tool), and torque the tach rod to 80 inch-ounces with the head torque wrench.
11. When reinstalling the pickup coil, verify that it is inserted into the linear motor as far as it will go. Place the retainer spring over the wire leads, and use care in reinstalling the retainer plate to avoid cutting the leads.



## CHAPTER 5


### REFERENCE DATA


PCBA	Description	Logic Page Number
Servo Cont.	Power On	0010
Logic III	RETHDS , Clocks	0020
Logic III	Start/Stop & Micro Switches	0030
Logic III	Brake Latch , Pack On , RETHD	0040
Timing Chart		0050
Logic III	K1-Drive Motor , K2-AC , K3-Start Pick Signals	0060
Logic III	Up , Down Speed Counter	0070
Servo Cont.	Speed Transducer	0080
Logic III	Speed Counter	
Logic III	Ready , Spindle Alert	0090
Logic I	Bus 0-7	0100
Logic I	Bus 8 & 9 , Cyl , Control & Head Address Tag Lines	0110
Logic I	Select Drive , Degate	0120
Logic I	Set Cyl , LD Car , LD Difs.	0130
Logic I	Cylinder Address Reg.	0140
Logic I	Illegal Address for 80 & 35 Mbyte Drives	0150
Logic I	End of Cylinder	0160
Logic II	Head Address Reg	
Logic II	Offset , Offset FWD/REV	1070
Logic I	Offset Start	


PCBA	Description	Logic Page Number
Logic I	Control Tags & Bus Bits	0180
Logic III	Index Pulse	0190
Logic III	Sector Count	0200
Logic II	Load Speed , Seek Enable	0210
Logic I	Set Forward Control	0220
Logic II	Carriage Forward , Rezero	
Logic II	RETHD , 1st Seek , Track Following Mode	0230
Logic I	Initiate Seek	0240
Logic I	Difference Counter	0250
Logic I	Difference Counter	0260
Logic I	Difference Counter	0270
Servo Control	Fwd./Rev. Voltage	0280
Logic II	RDY , Seek Incomplete	0290
Servo Pre Amp	DIBIT + & - From Servo HD ,	0300
Servo Control	Phase Squared DIBITS	0310
Servo Control	Position Error Detect , Hod	0320
Servo Control	UTHP- , UTHM-	0330
Logic II	Difference Counter Clock , Heads Loaded Counter	0340
Servo Control	9.67 MHZ VCO (103.3 NSEC)	0350
Servo Control	1.6 MHZ , 806 KHZ , 403 KHZ Clocks	0360
Servo Control	Velocity Transducer	0370
Servo Control	Servo Drive + and -	0380
Logic III	Emergency Retract	0390
Servo Control	D.C. Voltage Unsafe	0400
Drive Amp	Carriage Motor Voltage & Current Feedback , K1 Retract Relay	0410

PCBA	Description	Logic Page Number
Read/Write Matrix	Head Address Decoder	0420
Read/Write Limiter	Heads Unsafe , Write Unsafe	0430
Data Separator	Write Data Look Ahead/Back F/F's	0440
Data Separator	Write Data	0450
Read/Write Matrix	Write Drive + & - (TP2&3) Cyl. Current Limiting	0460
Data Separator	Read To Controller , Write From Controller	0470
Data Separator	Write NRZ	480
R/W Matrix	Read Amplifiers	490
R/W Limiter	Read Data	500
R/W Limiter	Read Data	510
R/W Limiter	Read Data , Address Mark R/W	520
Data Separator	Read Address Mark , Write Address Mark	530
Data Separator	PLL	540
Data Separator	Address Mark Mode	550
Data Separator	Window Width	560
Data Separator	VCO Read	570
Logic II	Attention	580
Logic II	Read Only , Write Disable	590
Logic I	Device Check	600
Logic II	Reset Device Check , Error	
Logic III	Control Power Device Check Lamp	
Logic II	Error Circuits	610
Logic II	Bus Cable in Signals	620
Logic II	Bus Cable in Signals	630
Drive Amp	AC Power , + 9 , + 14 , + 30 , -30 VDC	640

PCBA	Description	Logic Page Number
Sequence Relay Assy	Drive, Blower Motor Relays, Spindle Alert	650
	+ 5, + 18, - 18 VDC	660
	+ 5, + 12, + 24 VDC	670
	Ground & DC Voltages on PCBAs	680
Read/Write Limiter	Location Slot - 1	
Logic I	Slot - 2	
Logic II	Slot - 3	
Data Separation	Slot - 4	
Logic III	Slot - 5	
Servo Control	Slot - 6	
Servo Pre Amp	Under Card Cage	
Read/Write Matrix	To Right Side of Head Assy	
Servo Drive Amp & Retract	Power Supply	









DISC STORAGE UNIT  
ILD 2040

0040

LOGIC III







THE FOLLOWING CONDITIONS MUST BE MET TO INITIATE PACK SEQUENCE DOWN


TERM	BACK PANEL PIN NUMBER	SIGNAL LEVEL
1	START	3819
2	HDEXT/	5A11
3	RETHD/S	H


THE FOLLOWING CONDITIONS MUST BE MET TO INITIATE PACK SEQUENCE UP


TERM	BACK PANEL PIN NUMBER	SIGNAL LEVEL
1	MODULSIN/	5A09
2	SEQUENCE	5A21
3	LIDCLSWSW	5A16
4	DCUSF	5A29
5	BRAKE/	H
6	HDEXT/	5A11
7	START	3B19




















LOGIC I




















DISC STORAGE UNIT  
ILD 2040

LOGIC III


0200

0190 LOAD COUNTER  
0360 PLO AT ONE-EIGHTH  
FREQUENCY

LD<sub>CNT-</sub> 806KHZ- < B6 <  
CNT128+ COUNT 128, 0200

CNT8+ COUNT 8, 0200  
CNT0+ COUNT ZERO, 0200

CNT128+ COUNT 128, 0200




0190 LOAD COUNTER  
0200 COUNT 128  
0200 COUNT 8  
0200 COUNT ZERO  
0360 PLO AT ONE-EIGHTH  
FREQUENCY


LD<sub>CNT-</sub>  
CNT128+  
CNT8+  
CNT0+  
CNT128-


806KHZ- < B6 <


INDEX PULSE


LOAD SPEED






































DISC STORAGE UNIT  
ILD 2040


LOGIC II

0340












ILD 2040  
DISC STORAGE UNIT


SERVO CONTROL


0370





















570 3B-11  
450 5C-11

NOT USED

NOTE

מו' ערכות

0570 4B-8

0570 4A-7

6C-B  
7B-8  
4B-9

00530 WRITE ADDRESS MARK  
00530 WRITE PLUS  
0120 DEGATE

PERCISON WRITER


0450 8C-14


0450 86-13


84-30


- 2 -


ILD 2040  
DISC STORAGE UNIT














0500 A1-7  
0500 Q19











ILD 2040  
DISC STORAGE UNIT

DATA SEPARATOR











DATA SEPARATOR


0570








DISC STOARGE UNIT  
MILD 2040


600












0640 PHASE A	J13-8	BLK OR LT BLU	1	0640 100 OR 190/200 VOLTS	J13-11	BRN	2	0640 115 OR 208/220 VOLTS	J13-7	GRY	3	0640 127 OR 230/240 VOLTS	J13-4	BLU OR BRN/WHT	4


+14V DC BRAKING VOLTAGE, 0650




## DISC STORAGE UNIT


SEQUENCE RELAY ASSEMBLY

0650





SERVO PREAMPLIFIER BOARD  
LOGIC I, II, III BOARDS  
DATA SEPARATOR BOARD  
READ LIMITER BOARD



APPENDIX A

DISC CONTROLLER



## APPENDIX A

### TABLE OF CONTENTS

	Page
SECTION 1      INTRODUCTION	
A1.1            General Description . . . . .	A1-1
SECTION 2      INSTALLATION	
A2.1            Installation . . . . .	A2-1
A2.2            Disc Controller Interconnection System 610 . . . . .	A2-1
A2.3            Disc Controller Interconnection System 730 . . . . .	A2-1
A2.4            Interface Requirements . . . . .	A2-1
SECTION 3      FUNCTIONAL DESCRIPTION	
A3.1            General . . . . .	A3-1
A3.2            Block Diagram . . . . .	A3-1
A3.3            Interconnection Diagram . . . . .	A3-4
SECTION 4      REFERENCE DATA	

### LIST OF ILLUSTRATIONS

Figure	Page
A-1            Disc Controller Block Diagram . . . . .	A1-1
A-2            Disc System Interconnection 610 . . . . .	A2-2
A-3            Disc System Interconnection 730 . . . . .	A2-3
A-4            Adapter Block Diagram . . . . .	A3-2
A-5            Formatter Block Diagram . . . . .	A3-3
A-6            Interconnection Diagram . . . . .	A3-4



## SECTION 1

### INTRODUCTION

#### A1.1 GENERAL DESCRIPTION

The Disc Controller consists of five cards located in the Central Processor Unit Cabinet. These provide the CPU with the means of controlling the power sequencing, head positioning, data handling, error corrections, and diagnostics aids for the Disc Storage Unit. Figure A-1 illustrates the Disc Controller Circuitry in a block diagram format.




Figure A-1. Disc Controller Block Diagram



## SECTION 2

### INSTALLATION

#### A2.1 INSTALLATION

Installation of the Disc Controller boards is divided in two functions:

1. Adapter PCB's (2)
2. Formatter PCB's (3)

The Adapter PCB's are located in the Data Processor (CPU) cabinet's card cage.

The Formatter PCB's are located in a special auxiliary card cage in the CPU.

Electrical requirements for the Disc Controller are DC voltages of +5 volts at 15A and -5 volts at 200 ma.

#### A2.2 DISC CONTROLLER INTERCONNECTION SYSTEM 610

The location of the controller PCB's for the Basic Four System 610 is illustrated in Figure A-2.

#### A2.3 DISC CONTROLLER INTERCONNECTION SYSTEM 700

The location of the Controller PCB's for the Basic Four System 700 is illustrated in Figure A-3.

#### A2.4 INTERFACE REQUIREMENTS

Signal levels with the single exception of the drive unit clock and data lines, all signals will be at standard TTL levels.

0.0 to + 0.4                    VDC equals logical low

+ 2.4 to Vcc                    VDC equals logical high

The clock and data lines to the disk units will be differential balanced line driver/receivers.




Figure A-2. Disc System Interconnection 610




Figure A-3. Disc System Interconnection 700

## SECTION 3

### FUNCTIONAL DESCRIPTION

#### A3.1 GENERAL

The Disc Controller consists of five boards. Their functions are described in the following paragraphs.

Two boards, referred to as the Adapter, located in the main CPU card cage, are responsible for interfacing the Formatter to the system. The Adapter must handle the I/O, DMA, and Keysearch functions. The following functional parameters apply to the Adapter:

1. Key Size (Min and Max)
2. Max Search Length, and
3. Max DMA transfer.

There are also three boards referred to as the Formatter. They are located in the Auxiliary Card Cage in the lower portion of the CPU cabinet. The Formatter is responsible for interfacing and controlling the Disc Drives and for generating the formatting and timing. The following Disc Drive parameters are controlled by the Formatter:

1. Bytes per Sector
2. Sector per Track
3. Formatted Capacity
4. Average Latency
5. Seek Time (Min., Avg., and Max.)
6. Total Tracks, and
7. Data Transfer Rate.

#### A3.2 BLOCK DIAGRAMS

Block diagrams of the two different PCB's which make up the Disc Controller are shown in Figures A-4 and A-5.




Figure A-4. Adapter Block Diagram





Figure A-5. Formatter Block Diagram

### A3.3 INTERCONNECTION DIAGRAM

Figure A-6 illustrates the interconnections with cable part numbers.



SECTION 4

REFERENCE DATA

Title	Drawing Number	Page
LD Formatter Backplane (Pin List)	902042	A4-2 - A4-4
PCB Assy , Formatter Radial	901930	A4-5 , A4-6
LD Formatter Radial	901932	A4-7 - A4-12
PCB Assy , Formatter Processer	901960	A4-13
LD Formatter Processor	901962	A4-14 - A4-27
PCB Assy , Formatter Bus	901920	A4-28
LD Formatter Bus	901922	A4-29 - A4-41
PCB Assy , Adapter Bus	901970	A4-42
LD Adapter Bus	901972	A4-43 - A4-53
PCB Assy , High Speed DMA	901980	A4-54
LD High Speed DMA	901982	A4-55 - A4-66

J1		RADIAL EXP.		RADIAL		RADIAL EXP.		RADIAL		RADIAL EXP.		RADIAL		
A	B	A	B	A	B	A	B	A	B	A	B	A	B	
GND	+5V	GND	+5V	GND	-16.75V	GND	-16.75V	GND	+5V	GND	+5V	GND	-16.75V	
GND	-16.75V	GND	-16.75V	GND	-16.75V	GND	-16.75V	GND	-16.75V	GND	-16.75V	GND	-16.75V	
CLK6P	R4ATTN-	41	R2ATTN-	9	ROATTN-	42	R6SEL-	43	R7SEL-	43	R6SEL-	43	R7SEL-	43
CLK6M	R4SLCTD-	42	R2SLCTD-	10	ROSLLCTD-	44	R5SEL-	44	R5SEL-	44	R5SEL-	44	R5SEL-	44
DATA6M	SEQ4-	43	SEQ2-	11	SEQ0-	45	R7SLCTD-	45	R7SLCTD-	45	R7SLCTD-	45	R7SLCTD-	45
DATA6P	SEL4-	44	SEL2-	12	SEL0-	46	R4SLCTD-	46	R4SLCTD-	46	R5SLCTD-	46	R5SLCTD-	46
SEL6-	DATA4P	45	DATA2P	13	DATA0P	47	R6SEQ	47	R5SEQ	47	R5SEQ	47	R5SEQ	47
SEQ6-	DATA4M	46	DATA2M	14	DATA0M	48	(RES)	48	(RES)	48	(RES)	48	(RES)	48
R6SLCTD-	CLK4P	47	CLK2P	15	CLK1P	49	MDOBUS3-	49	MDOBUS2-	49	MDOBUS1-	49	MDOBUS0-	50
R6ATTN-	CLK4M	48	CLK2M	16	CLK1M	50	MDOBUS1-	50	MDOBUS0-	50	MDOBUS1-	50	MDOBUS0-	50
16	51	52	53	54	55	56	57	58	59	59	59	59	59	59
17	51	52	53	54	55	56	57	58	59	59	59	59	59	59
18	52	53	54	55	56	57	58	59	59	59	59	59	59	59
19	53	54	55	56	57	58	59	59	59	59	59	59	59	59
20	54	55	56	57	58	59	59	59	59	59	59	59	59	59
21	55	56	57	58	59	59	59	59	59	59	59	59	59	59
22	56	57	58	59	59	59	59	59	59	59	59	59	59	59
23	57	58	59	59	59	59	59	59	59	59	59	59	59	59
24	58	59	59	59	59	59	59	59	59	59	59	59	59	59
25	59	59	59	59	59	59	59	59	59	59	59	59	59	59
26	59	59	59	59	59	59	59	59	59	59	59	59	59	59
27	60	61	62	63	64	65	66	67	68	69	70	71	72	73
28	61	62	63	64	65	66	67	68	69	70	71	72	73	74
29	62	63	64	65	66	67	68	69	70	71	72	73	74	75
30	63	64	65	66	67	68	69	70	71	72	73	74	75	76
31	64	65	66	67	68	69	70	71	72	73	74	75	76	77
32	65	66	67	68	69	70	71	72	73	74	75	76	77	78
33	66	67	68	69	70	71	72	73	74	75	76	77	78	79
GND	DATA5P	67	DATA5M	68	DATA5M	69	DATA5P	70	DATA5P	71	DATA5M	72	DATA5M	73


Reference Only - Will Not Be Maintained

RELEASED PRINT

<b>basic / four corporation</b>		1335 South Claudia Street Anaheim, California 92805	
TITLE		LOGIC DIAGRAM, FORMATTER BACKPLANE	
DRAWN	12-15-74	CHKD	12-17-74
ENG	12-17-74	MFG	12-17-74
APP	12-17-74	SIZE	DWG NO
MACHINED SURFACES		B	
1 ON PCBA	903284 ONLY.	SCALE	1-1/2
NOTES: UNLESS OTHERWISE SPECIFIED		REV	A4
NEXT ASSY	USED ON	SAFETY	SH 1 OF 3


1

NOTES: UNLESS OTHERWISE SPECIFIED




Reference Only - Will Not Be Maintained

A4-3




	<u>CH0</u>	<u>CH1</u>	<u>CH2</u>	<u>CH3</u>	<u>CH4</u>	<u>CH5</u>	<u>CH6</u>	<u>CH7</u>
1	+5V	1 +5V	+5V					
2	+5V	2 +5V	+5V					
3		3		3		3		3
4		4		4		4		4
5	GND	5 GND	GND					
6	ROATTN-(J2-B9)	6 RIATTN-(J2-B28)	6 R2ATTN-(J2-A9)	6 R3ATTN-(J2-A28)	6 R4ATTN-(J1-B9)	6 R5ATTN-(J1-B28)	6 R7ATTN-(J1-A22)	R7ATTN-(J1-A22)
7	GND	7 GND	GND					
8	ROSLCTD-(J2-B10)	8 RISLCTD-(J2-B29)	8 R2SLCTD-(J2-A10)	8 R3SLCTD-(J2-A29)	8 R4SLCTD-(J1-B10)	8 RSSLCTD-(J1-B29)	8 RSSLCTD-(J1-A15)	R7SLCTD-(J1-A23)
9	GND	9 GND	GND					
10	SEQ0-(J2-B11)	10 SEQ1-(J2-B30)	10 SEQ2-(J2-A11)	10 SEQ3-(J2-A30)	10 SEQ4-(J1-B11)	10 SEQ5-(J1-B30)	10 SEQ6-(J1-A14)	SEQ7-(J1-A24)
11	GND	11 GND	11 GND	11 GND	11 GND	11 GND	11 GND	GND
12	SEL0-(J2-B12)	12 SEL1-(J2-B31)	12 SEL2-(J2-A12)	12 SEL3-(J2-A31)	12 SEL4-(J1-B12)	12 SEL5-(J1-B31)	12 SEL6-(J1-A13)	SEL7-(J1-A25)
13		13		13		13		13
14	DATACP(J2-B13)	14 DATA1P(J2-B32)	14 DATA2P(J2-A13)	14 DATA3P(J2-A32)	14 DATA4P(J1-B13)	14 DATA5P(J1-B32)	14 DATA6P(J1-A12)	DATA7P(J1-A26)
15	GND	15 GND	15 GND	15 GND	15 GND	15 GND	15 GND	GND
16	DATA0M(J2-B14)	16 DATA1M(J2-B33)	16 DATA2M(J2-A14)	16 DATA3M(J2-A33)	16 DATA4M(J1-B14)	16 DATA5M(J1-B33)	16 DATA6M(J1-A11)	DATA7M(J1-A27)
17	GND	17 GND	17 GND	17 GND	17 GND	17 GND	17 GND	GND
18	CLKCP(J2-B15)	18 CLK1P(J2-B34)	18 CLK2P(J2-A15)	18 CLK3P(J2-A37)	18 CLK4P(J1-B15)	18 CLK5P(J1-B34)	18 CLK6P(J1-A28)	CLK7P(J1-A29)
19		19		19		19		19
20	CLK0M(J2-B16)	20 CLK1M(J2-B35)	20 CLK2M(J2-A16)	20 CLK3M(J2-A38)	20 CLK4M(J1-B16)	20 CLK5M(J1-B35)	20 CLK6M(J1-A10)	CLK7M(J1-A29)



Reference Only - Will Not Be Maintained


RELEASED PRINT


basic / four corporation	
SIZF DWG NO	REV A4
B	902042
SCALE 1/4	SH 3 OF 3



9019.30-001	WITHOUT PROMS	9019.30	WITH PROMS	PART NO	DESCRIPTION	TABULATION CHART
-------------	---------------	---------	------------	---------	-------------	------------------

SCE P/L 901930		EXCITATION CIRCUIT	
DIMENSIONS IN INCHES		EXCITATION CIRCUIT	
UNLESS OTHERWISE SPECIFIED		TYPE	REF. NO.
ALL DIMENSIONS ARE IN INCHES		PCB	901930
PRINTED CIRCUIT BOARD		PCB	901930
MANUFACTURED BY		PCB	901930
MATERIALS		PCB	901930
ASSEMBLED BY		PCB	901930
TESTED BY		PCB	901930
INSPECTED BY		PCB	901930








REVISIONS		DATE	
REV.	CHANGED BY	MONTH	YEAR
C	Initial Revision	01	00


  

BASIC / FOUR CORNERS CORPORATION		1450 South 400 East • Salt Lake City, Utah 84106	
TELEPHONE 801/458-2111		TELEX 223-7224 FAX 801/458-2111	
DATA SHEET NUMBER	PIA-A	REVISION	C
DATE ISSUED	10/20/88	DATE REVISED	10/20/88
APPROVED	W. J. H.	DESIGNED BY	R. J. T.
TESTED	J. M. S.	PRINTED BY	W. J. H.
MANUFACTURED BY		PRINT DATE	10/20/88
DO NOT SCALE DRAWING			







PRINTED ON PAGE		PRINTED ON PAGE	
1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16
17	18	19	20
21	22	23	24
25	26	27	28
29	30	31	32
33	34	35	36
37	38	39	40
41	42	43	44
45	46	47	48
49	50	51	52
53	54	55	56
57	58	59	60
61	62	63	64
65	66	67	68
69	70	71	72
73	74	75	76
77	78	79	80
81	82	83	84
85	86	87	88
89	90	91	92
93	94	95	96
97	98	99	100
101	102	103	104
105	106	107	108
109	110	111	112
113	114	115	116
117	118	119	120
121	122	123	124
125	126	127	128
129	130	131	132
133	134	135	136
137	138	139	140
141	142	143	144
145	146	147	148
149	150	151	152
153	154	155	156
157	158	159	160
161	162	163	164
165	166	167	168
169	170	171	172
173	174	175	176
177	178	179	180
181	182	183	184
185	186	187	188
189	190	191	192
193	194	195	196
197	198	199	200
201	202	203	204
205	206	207	208
209	210	211	212
213	214	215	216
217	218	219	220
221	222	223	224
225	226	227	228
229	230	231	232
233	234	235	236
237	238	239	240
241	242	243	244
245	246	247	248
249	250	251	252
253	254	255	256
257	258	259	260
261	262	263	264
265	266	267	268
269	270	271	272
273	274	275	276
277	278	279	280
281	282	283	284
285	286	287	288
289	290	291	292
293	294	295	296
297	298	299	300
299	300	301	302
303	304	305	306
307	308	309	310
311	312	313	314
315	316	317	318
319	320	321	322
323	324	325	326
327	328	329	330
331	332	333	334
335	336	337	338
339	340	341	342
343	344	345	346
347	348	349	350
351	352	353	354
355	356	357	358
359	360	361	362
363	364	365	366
367	368	369	370
371	372	373	374
375	376	377	378
379	380	381	382
383	384	385	386
387	388	389	390
391	392	393	394
395	396	397	398
399	400	401	402
403	404	405	406
407	408	409	410
411	412	413	414
415	416	417	418
419	420	421	422
423	424	425	426
427	428	429	430
431	432	433	434
435	436	437	438
439	440	441	442
443	444	445	446
447	448	449	450
451	452	453	454
455	456	457	458
459	460	461	462
463	464	465	466
467	468	469	470
471	472	473	474
475	476	477	478
479	480	481	482
483	484	485	486
487	488	489	490
491	492	493	494
495	496	497	498
499	500	501	502
503	504	505	506
507	508	509	510
511	512	513	514
515	516	517	518
519	520	521	522
523	524	525	526
527	528	529	530
531	532	533	534
535	536	537	538
539	540	541	542
543	544	545	546
547	548	549	550
551	552	553	554
555	556	557	558
559	560	561	562
563	564	565	566
567	568	569	570
571	572	573	574
575	576	577	578
579	580	581	582
583	584	585	586
587	588	589	590
591	592	593	594
595	596	597	598
599	600	601	602
603	604	605	606
607	608	609	610
611	612	613	614
615	616	617	618
619	620	621	622
623	624	625	626
627	628	629	630
631	632	633	634
635	636	637	638
639	640	641	642
643	644	645	646
647	648	649	650
651	652	653	654
655	656	657	658
659	660	661	662
663	664	665	666
667	668	669	670
671	672	673	674
675	676	677	678
679	680	681	682
683	684	685	686
687	688	689	690
691	692	693	694
695	696	697	698
699	700	701	702
703	704	705	706
707	708	709	710
711	712	713	714
715	716	717	718
719	720	721	722
723	724	725	726
727	728	729	730
731	732	733	734
735	736	737	738
739	740	741	742
743	744	745	746
747	748	749	750
751	752	753	754
755	756	757	758
759	760	761	762
763	764	765	766
767	768	769	770
771	772	773	774
775	776	777	778
779	780	781	782
783	784	785	786
787	788	789	790
791	792	793	794
795	796	797	798
799	800	801	802
803	804	805	806
807	808	809	810
811	812	813	814
815	816	817	



Reference Only - Will Not Be Maintained



Reference Only - Will Not Be Maintained





Reference Only - Will Not Be Maintained

A4-12


RELEASED BY FBI

PCR HISTORY	CORRESPONDING ASSY REV LETTER
90116-1-001	X
90116-1-001	A
90405-001	B
904290-0001	C







REF ID: P1962	
BASIC / FOUR CONNECTIONS	
1335 South Carolina Street Anaheim, California 92805	
TITLE	
LOGIC DIAGRAM -	
FORMATTER PROGRAM	
DRAWN BY	J.L.C.
CHKD BY	J.L.C.
ENG	J.L.C.
MFG	
REV	D
MACHINED SURFACES ✓	
APP	12-20
USED ON	DO NOT SCALE DRAWING
TEXT ASSY:	SH 1/4



Reference Only - Will Not Be Maintained




basic / four corporation	
1335 South Clarendon Street, Anaheim, California 92805	
DRAWN	TITLE
X : .1	
XXX : .03	
ANGLES : 1.0°	
REV C	DWG NO 901962
SIZE C	SCALE 1/4
MFG APP	DO NOT SCALE DRAWING
NEXT ASSY	USED ON
DIMENSIONS ARE IN INCHES	
TOLERANCES UNLESS OTHERWISE SPECIFIED	
X : .1	
XXX : .03	
ANGLES : 1.0°	
MACHINED SURFACES ✓	
NEXT ASSY	
USED ON	



basic / four corporation		1335 South Clethorne Street, Anaheim, California 92805	
		TITLE _____	
DRAWN	CHKO		
ENG	MFG		
APP			
DIMENSIONS ARE IN INCHES TOLERANCES UNLESS OTHERWISE SPECIFIED X : 1 XX : .03 XXX : .010 ANGLES : 1°			
MACHINED SURFACES			
NEXT ASSY	USED ON	DO NOT SCALE DRAWING	
P1-A3	IBUS4-	REV D	
P1-B4	IBUS5-	Dwg No C 901962	
(5)	C.3-	SCALE	SH 4 of 14


RELEASED PRINT

(4) SROTE -  
CARENAB  
P2-16



A4-18

Reference Only - Will Not Be Maintained




REF ID: A6512

DIMENSIONS ARE IN INCHES	
TOLERANCES UNLESS OTHERWISE SPECIFIED	
X ± 1	
XX : .03	
XXX : .010	
ANGLES ± 1°	
MACHINED SURFACES ✓	
NEXT ASSY	USED ON
DO NOT SCALE DRAWING	


**bASIC / FOUR corporation**  
1305 South Claudio Street, Anaheim, California 92805

REV D  
DWG NO C 901962  
SCALE  
SM L OF 1/4

HI SPEEDED RAM MEMORY (( ))




RELEASED [ ]	
basic / four corporation	
1335 South Chezanne Street Anaheim, California 92805	
TITLE	
DRAWN	
CHKD	
ENG	
MFG	
APP	
SIZE DWG NO C 301962 D	
SCALE SH 7 OF 14	
DIMENSIONS ARE IN INCHES	
TOLERANCES UNLESS OTHERWISE SPECIFIED	
X : 1 XX : .03 XXX : .010 ANGLES : 1°	
MACHINED SURFACES ✓	
NEXT ASSY USED ON DO NOT SCALE DRAWING	




Reference Only - Will Not Be Maintained

(8) ECC11-



(8) CLKG


(14) ST13-  
(8) ECC FD BK A



RELEASED BY:


ECC GENERATOR/CHECKER

BASIC / FOUR CORPORATION	
1335 South Clarendon Street, Anaheim, California 92805	
DRAWN	TITLE
CHKD	
ENG	
MFG	
APP	
DIMENSIONS ARE IN INCHES	
TOLERANCES UNLESS OTHERWISE SPECIFIED	
X : 1	
XX : .03	
XXX : .010	
ANGLES : 1.0°	
REV	
SIZE	DWG NO
C	901962
SCALE	SH 9 of 14
MACHINED SURFACES ✓	
DO NOT SCALE DRAWING	
NEXT ASSY	USED ON



Reference Only - Will Not Be Maintained


A4-23



ECC OUTPUT TO MP

RELEASED P/N: 1


basic / four corporation		1335 South Clarendon Street Anaheim, California 92805	
		TITLE	
		DRAWN	CHGD
		ENG	MFG
		APP	APP
SIZE	DRAG NO	REV	
C	901962	D	
SCALE			
NEXT ASSY	USED ON	DO NOT SCALE DRAWING	




DIVISIONS ARE IN INCHES		TOLERANCES UNLESS OTHERWISE SPECIFIED		DRAWN		TITLE		REV	
		X + 1 XX + 03 XXX: 010 ANGLES: 1° <sup>0</sup>		CHKO				D	
				ENG					
				MFG					
				APP					
MACHINED SURFACES		✓							
NEXT ASSY		USED ON		CO. % T SCALE DRAWING				SCALE	
								CH 12 OF 14	

**BASIC / FOUR Corporation**

1335 South Claudine Street Anaheim, California 92805




PRINTED [REDACTED]	
<b>bASIC / FOUR cororation</b>	
1335 South Claudio Street, Anaheim, California 92805	
TITLE	
DRAWN	
CHKD	
ENG	
MFG	
APP	
MACHINED SURFACES <input checked="" type="checkbox"/>	
NEXT ASSY USED ON 00 NOT SCALE DRAWING	
TOLERANCES UNLESS OTHERWISE SPECIFIED X : 1    XX : .03    XXX : .010    ANGLES : 1°	
DIMENSIONS ARE IN INCHES	
SCALE	SH 13 OF 14
REV D	DWG NO C 901962




Reference Only - Will Not Be Maintained

A4-27




"REWORK PER ECN 5189"  
BFC PART NO. 501920

ECB	HISTORY	RESPONDING ASSY REV LTA
901921	X4	
902181	A	
904055	B	




BASIC/FOUR corporation	
1335 South Claudine Street	Anaheim, California 92805
DRAWN	11-1-74
CHKD	11-1-74
APLICES: 1.0°	11-1-74
ENG	11-1-74
MFG	11-1-74
APP	11-1-74
NOTES	
MACHINED SURFACES ✓	
NOT ASSY	
USED ON	
DO NOT SCALE DRAWING	




REF ID: D1000000000000000000000000000000		REV J	
DRAFTED BY [Signature]		CHECKED BY [Signature]	
DESIGNED BY [Signature]		APPROVED BY [Signature]	
DATE: 01/09/2022		DATE: 01/09/2022	
SHEET NO. C		SCALE 1:1	
TOTAL SHEETS 3		SH 2 OF 3	


**BASIC / FOUR CORPORATION**  
1335 South Chezene Street, Anaheim, California 92805  
TITLE

DIMENSIONS ARE IN INCHES		TOLERANCES UNLESS OTHERWISE SPECIFIED	
X : 1	XX : .03	XXX : .010	ANGLES : .0°
DRAWN		CHKO	
ENG		MFG	
APP		✓	
VER ASSY		USED ON	
DO NOT SCALE DRAWING			




Reference Only - Will Not Be Maintained







Reference Only - Will Not Be Maintained



Reference Only - Will Not Be Maintained




RELEASED BY	
BASIC / FOUR corporation	
1335 South Cahuenga Street, Anaheim, California 92805	
DRAWN	CHKD
ENG	ENG
MFG	APP
DO NOT SCALE DRAWING	
REV	J
SIZE	DWG NO
SH	901922
SCALE	1/16
DATE	13




REFERENCE		PI-A9	
<b>BASIC / FOUR corporation</b> 1335 South Claudia Street, Anaheim, California 92805 TITLE _____			
DRAWN _____ CHK'D _____ ENG _____ MFG _____ APP _____			
SIZE C Dwg No 901922 J			
SCALE SH 8 OF 13			
MACHINED SURFACES _____ DO NOT SCALE DRAWING			
NEXT ASSY _____ USED ON _____			
DIMENSIONS ARE IN INCHES TOLERANCES UNLESS OTHERWISE SPECIFIED X : 1 XX : .03 XXX : .010 ANGLES : 1.0°			

Reference Only - Will Not Be Maintained




Reference Only - Will Not Be Maintained

74LS195  
4 PLACES




74173  
4 PLACES



(3) ENDATA -

SRO8



(3) PULLUP 1

SR11- (5)  
SRO7- (5)

SRBUF08 (12)  
SRBUF09 (12)  
SRBUF10 (12)  
SRBUF11 (12)

SR11- (5)  
SRO7- (5)

SRBUF04 (11)  
SRBUF05 (11)  
SRBUF06 (11)  
SRBUF07 (11)


SR03- (5)  
SRO2- (5)  
SRO1- (5)  
SRO0- (5)

SRBUF00 (11)  
SRBUF01 (11)  
SRBUF02 (11)  
SRBUF03 (11)


SHIFT REGISTER  
PRINTED

BASIC / FOUR CORPORATION	
1335 South Claudia Street, Anaheim, California 92805	
SIZE	DRAWN
SC NO.	CHKO
HFV	ENG
MACHINED SURFACES	NFG APP
USED ON	00101 SCALE DRAWING
NEXT ASSY	SH 10 of 13


(5) CNT15 -



		DIMENSIONS ARE IN INCHES	
		TOLERANCES UNLESS OTHERWISE SPECIFIED	
		X : 1	DRAWN
		XX : 03	CHKD
		XXX : 010	
		ANGLES : 10°	
		MACHINED SURFACES	APP
NEXT ASSY	USED ON	DO NOT SCALE DRAWING	
		REV J	
		SIZE	DRAWING NO.
		C	901922
		SCALE	
			SH / / OF 13
		TITLE	
		1335 South Claydon Street Anaheim, California 92805	
<b>basic / four corporation</b>		PRINT	




Reference Only - Will Not Be Maintained




Reference Only - Will Not Be Maintained

BFC PART N° 901970-001


9EE P/L 901970		CIRCUIT / PRINTED COMPOSITION	
Composants et autres détails		Liste des composants	
Cl +	C1	U1A	PCB ASSY
U6A	U2A	U2A	ADAPTER BUS
C20	U3A	U3A	
U7A	U4A	C22	
U6B	U2B	U2B	
U5B	U3B	U3B	
U6C	U4B	C23	
U7B	U2C	U2C	
U8C	U3C	U3C	
C19	U4C	U4C	
U7C	U3D	U3D	
U8D	U5D	U5D	
U7D	U6D	U6D	
U8E	U7D	U7D	
U7E	U6E	U6E	
P2	U5E	U5E	
U8F	U7F	U7F	
R2(8F)	U6F	U6F	
U8G	U7G	U7G	
P3	U6G	U6G	
R3(8H)	U7H	U7H	
U7H	U6H	U6H	
U7I	U5H	U5H	
C2	U5I	C26	
C25	U6I	U6I	
O4 +	U7I	U7I	
C2	U8I	U8I	
O4 +	U9I	U9I	
C25	U10I	U10I	
O4 +	U11I	U11I	
C2	U12I	U12I	
O4 +	U13I	U13I	
C25	U14I	U14I	
O4 +	U15I	U15I	
C2	U16I	U16I	
O4 +	U17I	U17I	
C25	U18I	U18I	
O4 +	U19I	U19I	
C2	U20I	U20I	
O4 +	U21I	U21I	
C25	U22I	U22I	
O4 +	U23I	U23I	
C2	U24I	U24I	
O4 +	U25I	U25I	
C25	U26I	U26I	
O4 +	U27I	U27I	
C2	U28I	U28I	
O4 +	U29I	U29I	
C25	U30I	U30I	
O4 +	U31I	U31I	
C2	U32I	U32I	
O4 +	U33I	U33I	
C25	U34I	U34I	
O4 +	U35I	U35I	
C2	U36I	U36I	
O4 +	U37I	U37I	
C25	U38I	U38I	
O4 +	U39I	U39I	
C2	U40I	U40I	
O4 +	U41I	U41I	
C25	U42I	U42I	
O4 +	U43I	U43I	
C2	U44I	U44I	
O4 +	U45I	U45I	
C25	U46I	U46I	
O4 +	U47I	U47I	
C2	U48I	U48I	
O4 +	U49I	U49I	
C25	U50I	U50I	
O4 +	U51I	U51I	
C2	U52I	U52I	
O4 +	U53I	U53I	
C25	U54I	U54I	
O4 +	U55I	U55I	
C2	U56I	U56I	
O4 +	U57I	U57I	
C25	U58I	U58I	
O4 +	U59I	U59I	
C2	U60I	U60I	
O4 +	U61I	U61I	
C25	U62I	U62I	
O4 +	U63I	U63I	
C2	U64I	U64I	
O4 +	U65I	U65I	
C25	U66I	U66I	
O4 +	U67I	U67I	
C2	U68I	U68I	
O4 +	U69I	U69I	
C25	U70I	U70I	
O4 +	U71I	U71I	
C2	U72I	U72I	
O4 +	U73I	U73I	
C25	U74I	U74I	
O4 +	U75I	U75I	
C2	U76I	U76I	
O4 +	U77I	U77I	
C25	U78I	U78I	
O4 +	U79I	U79I	
C2	U80I	U80I	
O4 +	U81I	U81I	
C25	U82I	U82I	
O4 +	U83I	U83I	
C2	U84I	U84I	
O4 +	U85I	U85I	
C25	U86I	U86I	
O4 +	U87I	U87I	
C2	U88I	U88I	
O4 +	U89I	U89I	
C25	U90I	U90I	
O4 +	U91I	U91I	
C2	U92I	U92I	
O4 +	U93I	U93I	
C25	U94I	U94I	
O4 +	U95I	U95I	
C2	U96I	U96I	
O4 +	U97I	U97I	
C25	U98I	U98I	
O4 +	U99I	U99I	
C2	U100I	U100I	
O4 +	U101I	U101I	
C25	U102I	U102I	
O4 +	U103I	U103I	
C2	U104I	U104I	
O4 +	U105I	U105I	
C25	U106I	U106I	
O4 +	U107I	U107I	
C2	U108I	U108I	
O4 +	U109I	U109I	
C25	U110I	U110I	
O4 +	U111I	U111I	
C2	U112I	U112I	
O4 +	U113I	U113I	
C25	U114I	U114I	
O4 +	U115I	U115I	
C2	U116I	U116I	
O4 +	U117I	U117I	
C25	U118I	U118I	
O4 +	U119I	U119I	
C2	U120I	U120I	
O4 +	U121I	U121I	
C25	U122I	U122I	
O4 +	U123I	U123I	
C2	U124I	U124I	
O4 +	U125I	U125I	
C25	U126I	U126I	
O4 +	U127I	U127I	
C2	U128I	U128I	
O4 +	U129I	U129I	
C25	U130I	U130I	
O4 +	U131I	U131I	
C2	U132I	U132I	
O4 +	U133I	U133I	
C25	U134I	U134I	
O4 +	U135I	U135I	
C2	U136I	U136I	
O4 +	U137I	U137I	
C25	U138I	U138I	
O4 +	U139I	U139I	
C2	U140I	U140I	
O4 +	U141I	U141I	
C25	U142I	U142I	
O4 +	U143I	U143I	
C2	U144I	U144I	
O4 +	U145I	U145I	
C25	U146I	U146I	
O4 +	U147I	U147I	
C2	U148I	U148I	
O4 +	U149I	U149I	
C25	U150I	U150I	
O4 +	U151I	U151I	
C2	U152I	U152I	
O4 +	U153I	U153I	
C25	U154I	U154I	
O4 +	U155I	U155I	
C2	U156I	U156I	
O4 +	U157I	U157I	
C25	U158I	U158I	
O4 +	U159I	U159I	
C2	U160I	U160I	
O4 +	U161I	U161I	
C25	U162I	U162I	
O4 +	U163I	U163I	
C2	U164I	U164I	
O4 +	U165I	U165I	
C25	U166I	U166I	
O4 +	U167I	U167I	
C2	U168I	U168I	
O4 +	U169I	U169I	
C25	U170I	U170I	
O4 +	U171I	U171I	
C2	U172I	U172I	
O4 +	U173I	U173I	
C25	U174I	U174I	
O4 +	U175I	U175I	
C2	U176I	U176I	
O4 +	U177I	U177I	
C25	U178I	U178I	
O4 +	U179I	U179I	
C2	U180I	U180I	
O4 +	U181I	U181I	
C25	U182I	U182I	
O4 +	U183I	U183I	
C2	U184I	U184I	
O4 +	U185I	U185I	
C25	U186I	U186I	
O4 +	U187I	U187I	
C2	U188I	U188I	
O4 +	U189I	U189I	
C25	U190I	U190I	
O4 +	U191I	U191I	
C2	U192I	U192I	
O4 +	U193I	U193I	
C25	U194I	U194I	
O4 +	U195I	U195I	
C2	U196I	U196I	
O4 +	U197I	U197I	
C25	U198I	U198I	
O4 +	U199I	U199I	
C2	U200I	U200I	
O4 +	U201I	U201I	
C25	U		



BASIC / FOUR CORPORATION		1325 South Clayline Street, Anaheim, California 92805	
		LOGIC DIAGRAM, ADAPTER BUS	
DRAWN BY	S. COLLINS	REV.	
CHKD BY	J. HARRIS	DATE	
ENG.	J. J. F.	SIZE	DWG. NO.
MFG.	✓	1/2-20	901972 D
APP.	✓	1/2-20	
MACHINED SURFACES		DO NOT SCALE DRAWING	
NEXT ASSY		USED ON	
		SH 1 OF 11	




Reference Only - Will Not Be Maintained





REFASER EDITION

DIMENSIONS ARE IN INCHES	
TOLERANCES UNLESS OTHERWISE SPECIFIED	
X ± .1	XX ± .03
	XXX ± .010
	ANGLES: 1°
MACHINED SURFACES ✓	
NEXT ASSY	USED ON
DO NOT SCALE DRAWING	
basic / four corporation	
1335 South Claudia Street Anaheim, California 92805	
DRAWN BY	SIGNATURE
CHKD	
ENG	
MFG	
APP	
TITLE	
DWG NO C 901972	
REV D	SH 3 OF 11

THE FUNCTION OF CODE




ADAPTER COMMANDS




RELEASER PRINT	
basic / four corporation	
1335 South Cleidene Street Anaheim, California 92805	
TITLE	
DRAWN	
CHKD	
ENG	
MFG	
APP	
REV	
SIZE	DRNG NO
C	901972
SCALE	D
SH	4 of 11
DIMENSIONS ARE IN INCHES	
TOLERANCES	
UNLESS OTHERWISE SPECIFIED	
X : 1	
XX : .03	
XXX : .010	
ANGLE : 10°	
MACHINED SURFACES	
NEXT ASSY	
USED ON	
DO NOT SCALE DRAWING	

RELEASED PRINT


basic / four corporation		1305 South Clarendon Street Anaheim, California 92805	
TITLE		S' DRAFTING	
DRAWN	CHKD	ENG	MFG
XX : 1 XXX : 0.03 ANGLES : 1.0°			
MACHINED SURFACES ✓		APP	
NEXT ASSY		DO NOT SCALE DRAWING	
REV	SCALE	SH	5 of 11
C	901972	D	





CONTES ET L'INE TERMINATIONS


Reference Only - Will Not Be Maintained




DATA RECEIVER

RELEASED PRINT

<b>BASIC / FOUR CORPORATION</b>	
1335 South Claudine Street, Anaheim, California 92805	
DRAWN	S. GUNN
CHKO	
ENG	
MFG	
APP	
TITLE	
SIZE	ORIG. NO.
C	901972
SCALE	REV D
SH 7 OF 11	




Reference Only - Will Not Be Maintained




Reference Only - Will Not Be Maintained

A4-51




Reference Only - Will Not Be Maintained

A4-52




Reference Only - Will Not Be Maintained

A4-53




SFF P/L 9019R0	
BASIC / POLY COMPOSITION	
100% Check Drawing Reference	
Dimensions Are In Inches	
TOLERANCES UNLESS OTHERWISE PROVIDED	
E.I. .005 IN. MAX. AND MIN. AMOUNTS	
C.H.D. .005 IN. MAX. AND MIN. AMOUNTS	
L.D. .005 IN. MAX. AND MIN. AMOUNTS	
M.G. .005 IN. MAX. AND MIN. AMOUNTS	
H.M.C. .005 IN. MAX. AND MIN. AMOUNTS	
M.A.C. .005 IN. MAX. AND MIN. AMOUNTS	
N.E.T. .005 IN. MAX. AND MIN. AMOUNTS	
U.S.D. .005 IN. MAX. AND MIN. AMOUNTS	
P.C.B. A.S.Y., H.I.G.H S.P.F.F.D. D.M.A.	
D 10/1980	
100% Check Drawing Reference	
Dimensions Are In Inches	
TOLERANCES UNLESS OTHERWISE PROVIDED	
E.I. .005 IN. MAX. AND MIN. AMOUNTS	
C.H.D. .005 IN. MAX. AND MIN. AMOUNTS	
L.D. .005 IN. MAX. AND MIN. AMOUNTS	
M.G. .005 IN. MAX. AND MIN. AMOUNTS	
H.M.C. .005 IN. MAX. AND MIN. AMOUNTS	
M.A.C. .005 IN. MAX. AND MIN. AMOUNTS	
N.E.T. .005 IN. MAX. AND MIN. AMOUNTS	
U.S.D. .005 IN. MAX. AND MIN. AMOUNTS	
P.C.B. A.S.Y., H.I.G.H S.P.F.F.D. D.M.A.	
D 10/1980	


Reference Only - Will Not Be Maintained




RELEASED BY		FBI	
BASIC / FOUR corporation			
1305 South Cleondine Street, Anaheim, California 92805			
TITLE		LOGIC DIAGRAM, HIGH SPEED DMA	
DRAWN	J. Kueck	1-11-76	
CHKD	L. T.	12-22-76	
ENG			
SIZE			
REV			
MFG			
APP	L. G.		
MACHINED SURFACES			
QC1220	F.F.		
NEXT ASSY		DO NOT SCALE DRAWING	
USED ON			
SCALE — SH 1 OF 12			
C			



Reference Only - Will Not Be Maintained




Reference Only - Will Not Be Maintained




Reference Only - Will Not Be Maintained


A4-58



Reference Only - Will Not Be Maintained



Reference Only - Will Not Be Maintained




RELEASER PRINT

DIMENSIONS ARE IN INCHES	
TOLERANCES UNLESS OTHERWISE SPECIFIED	
X : 1	XX : .03
	XXX : .010
	ANGLES : 1 <sup>o</sup>
MACHINED SURFACES ✓	
USED ON	DO NOT SCALE DRAWING
NEXT ASSY	
DRAWN	TITLE
CHKD	
ENG	
MFG	
APP	
SIZE DWG NO	REF
C	F
	SCALE
	SM 7 OF 12

A4-61


(12) DECBLK -




A4-62

Reference Only - Will Not Be Maintained

RELEASED PRINT	
BASIC / FOUR CORPORATION	
1335 South Cleidina Street Anaheim, California 92805	
TITLE	
DRAWN	
CHECKED	
ENG	
MFG	
APP	
SIZE	DWG NO
C	901982
SCALE	SH 8 of 12
DO NOT SCALE DRAWING	




RELEASER PRINT	
basic / FOUR corporation	
1335 South Claudine Street, Anaheim, California 92805	
TITLE _____	
DRAWN _____	
CHKD _____	
ENG _____	
MFG _____	
SIZE DNG NO. 901982 F	
SCALE	9 OF 12




Reference Only - Will Not Be Maintained

A4-64



A4-65

Reference Only - Will Not Be Maintained



DIMENSIONS ARE IN INCHES		TOLERANCES UNLESS OTHERWISE SPECIFIED		DRAWN		TITLE		SIZE DIV NO		P/T	
X ± .1	XX ± .03	XX ± .010	ANGLES ± 1.0°	CHD	ENG	MFG	APP	C	901982	1F	
MACHINED SURFACES ✓		DO NOT SCALE DRAWING		USED ON		NEXT ASSY				SCALE SH 1/2 OR 1/2	
UNLESS OTHERWISE SPECIFIED		DO NOT SCALE DRAWING		USED ON		NEXT ASSY				SCALE SH 1/2 OR 1/2	
1335 South Cedros Street Anaheim, California 92805		DO NOT SCALE DRAWING		USED ON		NEXT ASSY				SCALE SH 1/2 OR 1/2	
BASIC / FOUR corporation		DO NOT SCALE DRAWING		USED ON		NEXT ASSY				SCALE SH 1/2 OR 1/2	