

P/90 Maintenance Manual

98-40287.1 Ver C

February, 1988

P/90 Maintenance Manual

98-40287.1 Ver C February, 1988

PLEXUS COMPUTERS, INC.

3833 North First Street

San Jose, CA 95134

408/943-9433

Copyright 1988
Plexus Computers, Inc., San Jose, CA

All rights reserved.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language, in any form or by any means, without the prior written consent of Plexus Computers, Inc.

The information contained herein is subject to change without notice. Therefore, Plexus Computers, Inc. assumes no responsibility for the accuracy of the information presented in this document beyond its current release date.

Printed in the United States of America

PREFACE

Introduction

This P/90 Maintenance Manual (98-40287.1) describes the Plexus® P/90 computer system, a 32 bit supermicrocomputer system employing the UNIX † operating system. This manual is designed and written for system administrators, system integrators, and technicians who work on the P/90 computer system. As such, it provides both general and specific who work on the system.

Within this manual the following conventions apply:

1. Bold text (i.e. **A23** must be LOW), indicates a signal name, or user input (i.e. <cr>).
2. Signal names with an asterisk (i.e. **SELPROM*** must be LOW) indicates an active LOW signal line.
3. <cr> indicates a carriage return.
4. Component locations are in all capitals (i.e. U10A, U21B).

Manual Layout

Your *Plexus P/90 Maintenance Manual* is divided into five chapters.

Chapter One, Introduction, introduces the P/90 . Topics covered are general description, specifications (U.S. and overseas), environmental specifications, functional configuration, and physical configuration.

Chapter Two, Preventive Maintenance, details procedures to properly maintain your system and keep it at peak performance.

Chapter Three, Assembly/Disassembly Procedures, describes the correct procedures to dismantle and reassemble the major components in your system.

Chapter Four, Reference Information, lists cable connections, switch setting, power supply adjustments, etc.

Chapter Five, Board Descriptions, lists the individual boards that make-up the P/90. The board descriptions include card cage slot locations, switch and jumper settings, and safety procedures for board removal.

® Plexus is a registered trademark of Plexus Computers, Inc.

† UNIX is a trademark of ATT.

References

[1] Sys5 Administrator's Handbook (98-05133.x)

The telephone number that Plexus customers should use for all related software and/or hardware problems is: 1-800-553-PLEX.

Revision Record

98-40287.1 Ver. A	The initial release of this document.
98-40287.1 Ver. B	Power ratings and input current values are updated. Memory board error decode information is included. 300 Megabyte disk drive jumper settings are also included.
98-40287.1 Ver. C	Maintenance information for the expansion cabinet is integrated into the manual.

TABLE OF CONTENTS

INTRODUCTION.....	1-1
System Overview	1-1
Backplane Configuration	1-5
The Host Adapter Board	1-5
Space Requirements.....	1-7
System Cabinet Dimensions and Weight.....	1-7
Floor Area Requirements.....	1-7
Power Requirements	1-8
Voltage Characteristics	1-8
Input Current Characteristics.....	1-8
Grounding	1-9
Lightning Arrestors	1-9
Noise Suppression.....	1-9
Power Cords and Connectors	1-10
Environmental Requirements.....	1-10
Temperature and Humidity Ranges.....	1-11
Electrostatic Discharges.....	1-11
Cooling Requirements	1-13
Cabling.....	1-14
Cable Lengths	1-14
General Considerations	1-14
Cable Termination	1-15
Cable Wiring.....	1-15
VMEbus Backplane	1-18
VMEbus Electrical Specifications	1-20
Uninterruptable Power Supply (UPS)	1-20
PREVENTIVE MAINTENANCE.....	2-1
Equipment.....	2-1
Cleaning Your System's Fan Filters.....	2-2
Maintaining Your 1/4-inch Tape Drive	2-4
Replacing Your System Battery.....	2-6
Cleaning Your System's Exterior.....	2-8
Maintaining Your Hard Disk Drives.....	2-8
ASSEMBLY/DISASSEMBLY.....	3-1
Removing Your System's Exteriors	3-4
Removing Your System's Front Panel	3-6
Removing a LINC I/O Card.....	3-8
Removing Your 1/4-inch Tape Drive	3-10
Removing Your Hard Disk Drive.....	3-12
Removing Your Power Supply.....	3-14
Removing Your VCP Backplane Card	3-16
Removing Your Tape Controller.....	3-18
Removing Your Disk Drive Controller	3-20
Removing a Backplane Jumper Block	3-22
Adding Another Controller Board.....	3-24
Expansion Cabinet Assembly/Disassembly	3-26
Removing Your System's Exteriors	3-28
Removing Your System's Front Panel	3-30
Removing Your Expansion Cabinet's Media Tray	3-32

Removing Your Hard Disk Drive.....	3-35
Disk Drive Controller Removal.....	3-37
Power Supply Removal.....	3-39
REFERENCE INFORMATION	4-1
Indicators.....	4-1
Backplane.....	4-3
Test Points.....	4-10
Hard Disk Controller Board.....	4-11
Cartridge Tape Controller Board.....	4-11
135 Megabyte Fujitsu Disk Drive.....	4-14
Disk Drive Fault Lamps (LEDs).....	4-15
300 Megabyte Fujitsu Disk Drive.....	4-16
Disk Drive Fault Lamps (LEDs).....	4-17
300 Megabyte Maxtor Disk Drive.....	4-18
Power Supply.....	4-19
Power Supply Strapping.....	4-19
Main Cabinet Power Supply Adjustments.....	4-19
Expansion Cabinet Power Supply Adjustments.....	4-21
BOARD DESCRIPTIONS.....	5-1
Electrostatic Discharges.....	5-2
The Job Processor Board.....	5-3
Job Processor Switch Settings.....	5-4
Job Processor Jumper Settings.....	5-5
Job Processor LEDs.....	5-5
Job Processor Test Points.....	5-6
The Memory Board.....	5-7
Memory Board Switch Settings.....	5-8
Memory Board Error Decoding.....	5-9
Memory Board Jumper Settings.....	5-12
Memory Board LEDs.....	5-12
Memory Board Test Points.....	5-12
The VMEbus Arbiter Board.....	5-13
Bus Arbiter Board Switches.....	5-14
Bus Arbiter Board LEDs.....	5-17
Bus Arbiter Board Test Points.....	5-18
Bus Arbiter Board Jumpers.....	5-20
The VMEbus Communication Processor (VCP).....	5-21
VCP Switch Settings.....	5-23
VCP LEDs.....	5-23
VCP Jumper Settings.....	5-26
The VCP Backplane Card.....	5-27
The LINC I/O Cards.....	5-27
The Multibus Adapter Board.....	5-30
DDN Interface Communication Board.....	5-30
DDN Switch Settings.....	5-30
DDN Jumper Settings.....	5-31
DDN I/O Connector Plate.....	5-32
SNA Interface Communication Board.....	5-32
SNA Jumper Settings.....	5-33
Comm Ports I/O Connector Plate.....	5-35
The Ethernet Board.....	5-36

The SCSI Host Adapter Board	5-38
-----------------------------------	------

List of Figures

Figure 1-1. P/90 System, Front View	1-3
Figure 1-2. P/90 System, Rear View	1-4
Figure 1-3. P/90 System Internal Interface	1-6
Figure 1-4. Temperature Range	1-12
Figure 1-5. Humidity Range	1-12
Figure 1-6. Bus Grant Block Diagram	1-19
Figure 1-7. VMEbus Signal Levels	1-20
Figure 2-1. P/90 Fan Filter Removal	2-3
Figure 2-2. Cleaning the 1/4-inch Tape Drive	2-5
Figure 2-3. System Battery Replacement	2-7
Figure 3-1. P/90 Main Cabinet Front View with Access Door Open	3-2
Figure 3-2. P/90 Main Cabinet Rear View	3-3
Figure 3-3. Removing Your System's Exteriors	3-5
Figure 3-4. Removal of the System's Front Panel	3-7
Figure 3-5. Removing a LINC I/O Card	3-9
Figure 3-6. Removing Your 1/4-inch Tape Drive	3-11
Figure 3-7. Removing Your Hard Disk Drive	3-13
Figure 3-8. Removing Your Power Supply	3-15
Figure 3-9. VCP Backplane Removal	3-17
Figure 3-10. Removing the 1/4-inch Cartridge Tape Controller	3-19
Figure 3-11. Removing a Disk Drive Controller	3-21
Figure 3-12. Removing a Backplane Jumper Block	3-22
Figure 3-13. Rotating the Card Cage	3-23
Figure 3-14. Adding Another Controller Board	3-25
Figure 3-15. P/90 Expansion Cabinet Components	3-26
Figure 3-16. P/90 Expansion Cabinet Rear View	3-27
Figure 3-17. Removing Your System's Exteriors	3-29
Figure 3-18. Removal of the System's Front Panel	3-31
Figure 3-19. Removal of an Expansion Cabinet Tray	3-33
Figure 3-20. Removing Your Hard Disk Drive	3-36
Figure 3-21. Removing a Disk Drive Controller	3-38
Figure 3-22. Removing the Power Supply	3-40
Figure 4-1. P/90 Cabinet Power Indicators	4-2
Figure 4-2. P/90 Test Point Locations (Arbiter Board)	4-10
Figure 4-3. Hard Disk Controller	4-12
Figure 4-4. Tape Controller Board	4-13
Figure 4-5. Main Cabinet Power Supply Adjustments	4-20
Figure 4-6. Power Supply Component Location	4-21
Figure 5-1. Job Processor Component Locations	5-3
Figure 5-2. Job Processor LEDs	5-6
Figure 5-3. Memory Board Component Location	5-7
Figure 5-4. Base Address of the First Memory Board	5-8
Figure 5-5. Memory Board Jumpers	5-12
Figure 5-6. Memory Board's LEDs	5-12

Figure 5-7. VMEbus Arbiter Component Location	5-13
Figure 5-8. Arbiter LED Configuration.....	5-17
Figure 5-9. Arbiter Test Point Locations.....	5-18
Figure 5-10. VCP (Type 1) Component Location.....	5-21
Figure 5-11. VCP (Type 2) Component Location.....	5-22
Figure 5-12. VCP LED Configuration.....	5-25
Figure 5-13. VCP Jumper-Pak Examples.....	5-26
Figure 5-14. LINC V8 Card.....	5-28
Figure 5-15. LINC V16 Card.....	5-28
Figure 5-16. LINC P4 Card.....	5-29
Figure 5-17. Ethernet Board Components.....	5-36
Figure 5-18. SCSI Host Adapter Board	5-38

List of Tables

Table 1-1. P/90 Card Cage Slot Assignments	1-5
Table 1-2. Dimensions and Weight	1-7
Table 1-3. Service Clearance.....	1-7
Table 1-4. Minimum Area.....	1-8
Table 1-5. Plexus Power Options	1-8
Table 1-6. Environmental Requirements.....	1-10
Table 1-7. Sample Fixed Values for Temperature Rises.....	1-13
Table 1-8. Terminal/Serial Printer Cable Pinouts (DB-9).....	1-15
Table 1-9. Synchronous Modem Cable Pinouts (DB-9).....	1-15
Table 1-10. Asynchronous Modem Cable Pinouts (DB-9).....	1-16
Table 1-11. Terminal/Serial Printer Cable Pinouts (DB-25)	1-16
Table 1-12. Asynchronous Modem Cable Pinouts (DB-25)	1-16
Table 1-13. Synchronous Modem Cable Pinouts (DB-25)	1-17
Table 1-14. Parallel I/O Port Pinouts (P4).....	1-17
Table 1-15. Address and Data Path Bits.....	1-19
Table 2-1. Preventive Maintenance Time Schedule.....	2-1
Table 4-1. P/90 Connectors.....	4-3
Table 4-2. J1.(A,B,C) VMEbus Interface.....	4-4
Table 4-3. J2.(A,B,C) VMEbus Interface.....	4-6
Table 4-4. J3.(A,B,C) Plexus Proprietary Interface.....	4-8
Table 4-5. Disk Controller Switch Setting (F2).....	4-11
Table 4-6. Disk Controller Switch Setting (E9).....	4-11
Table 4-7. Tape Controller Switch Settings (U53)	4-11
Table 4-8. Tape Controller Switch Settings (U20)	4-11
Table 4-9. 135 Megabyte Disk Drive Jumper CNH5.....	4-14
Table 4-10. 135 Megabyte Disk Drive Jumper CNH7.....	4-14
Table 4-11. 135 Megabyte Disk Drive Jumper CNH6.....	4-14
Table 4-12. Disk Drive Fault Codes.....	4-15
Table 4-13. 300 Megabyte Disk Drive Jumper CNH5.....	4-16
Table 4-14. 300 Megabyte Disk Drive Jumper CNH7.....	4-16
Table 4-15. 300 Megabyte Disk Drive Jumper CNH6.....	4-16
Table 4-16. Disk Drive Fault Codes.....	4-17
Table 4-17. 300 Megabyte Disk Drive Jumpers JP16 - JP31	4-18
Table 4-18. 300 Megabyte Disk Drive Jumpers DS1 - DS7.....	4-18
Table 4-19. Power Supply Strapping.....	4-19

Table 4-20. DC Voltage Checks and Adjustments.....	4-20
Table 5-1. P/90 Card Cage Slot Assignments	5-1
Table 5-2. Job Processor Switch S1 Configuration	5-4
Table 5-3. Job Processor Switch Setting Options for Switchpak S1	5-4
Table 5-4. Job Processor Jumper Settings	5-5
Table 5-5. Job Processor LEDs	5-5
Table 5-6. Memory Board Error Decoding.....	5-9
Table 5-7. Memory Board Bank Select Decode	5-9
Table 5-8. Memory Board Bank Empty Decode	5-10
Table 5-9. Syndrome Error Code.....	5-10
Table 5-10. Memory Board Least Significant Bit (Diagnostic Latch)	5-11
Table 5-11. Memory Board Most Significant Bit (Diagnostic Latch)	5-11
Table 5-12. Arbiter Board Time Delay Switch Settings	5-14
Table 5-13. Arbiter Board Switch Settings for U3C (U3C).....	5-15
Table 5-14. Arbiter Board Interrupt Switch Settings U3A (U4A)	5-16
Table 5-15. Arbiter Board Power Supply Default Switch Settings	5-16
Table 5-16. Arbiter LED Functions	5-17
Table 5-17. Arbiter Board Test Points and Functions.....	5-19
Table 5-18. Arbiter Board Test Points	5-20
Table 5-19. Arbiter Board Jumper Settings	5-20
Table 5-20. VCP Switch Settings.....	5-23
Table 5-21. VCP Switch Setting Addresses.....	5-23
Table 5-22. VCP Jumper Settings	5-26
Table 5-23. LINC I/O Cards	5-27
Table 5-24. DDN Default Switch Settings.....	5-30
Table 5-25. DDN Default Jumper Settings.....	5-31
Table 5-26. DDN Serial Interface Settings.....	5-31
Table 5-27. DDN Comm Ports I/O Connector Plate.....	5-32
Table 5-28. SNA Jumper Settings.....	5-33
Table 5-29. SNA Comm Ports I/O Connector Plate.....	5-35
Table 5-30. Ethernet Board Jumper Settings.....	5-37
Table 5-31. Ethernet Board J3 — J6 Jumper Settings	5-37
Table 5-32. SCSI Host Adapter Jumper Settings	5-39
Table 5-33. SCSI Host Adapter Switch Settings.....	5-40

INTRODUCTION

This chapter describes your P/90 computer system. A system overview introduces the major components of your computer. The remaining sections describe the power, space, and environmental considerations required for your system.

System Overview

The P/90 is a powerful super-microcomputer system that can support up to 32 users with as much as 16 Megabytes of memory. Up to two expansion cabinets (each containing up to ten 5.25-inch media storage peripherals) can be supported by the main cabinet. Figures 1-1 and 1-2 illustrate the front and rear views, respectively, of your P/90 computer system (as it would appear with one expansion cabinet).

The equipment options of your P/90 Main Cabinet include:

- a Motorola† 68020 microprocessor based job processor board,
- up to 16 Megabytes of DRAM main memory,
- intelligent I/O processor boards,
- an eight slot industry-standard VMEbus backplane,
- SCSI host adapter boards, and
- up to four 5.25-inch peripherals including:
 - ¼-inch 60 Megabyte cartridge tape drive,
 - 135 Megabyte disk drive,
 - 300 Megabyte disk drive,

† Motorola is a trademark of Motorola.

Your P/90 Expansion Cabinet can contain up to ten 5.25-inch drives (eight of the ten drives must be Winchester disk drives). Peripheral options for your expansion cabinet include:

- ¼-inch 60 Megabyte cartridge tape drive,
- 135 Megabyte disk drive,
- 300 Megabyte disk drive,
- 1.2 Megabyte floppy disk drive,
- SCSI peripheral controller(s), and
- disk drive power supply(s).




Figure 1-1. P/90 System, Front View




Figure 1-2. P/90 System, Rear View

Backplane Configuration

The memory board, job processor board, and bus arbiter board occupy the first three slots of the card cage (see Table 1-1). A single VMEbus communication processor board (VCP) fills slot four or five depending on whether a modem is installed on the bus arbiter board. Slots five through eight are reserved for the Ethernet †, DDN/SNA, and/or host adapter boards, with host adapter board 0 in slot eight, host adapter board 1 in slot seven, host adapter board 2 in slot six, etc. The remaining slot(s) five and/or six can be filled with either the fourth host adapter board (3), the Ethernet board, or a network protocol board (DDN/SNA).

[WARNING] Board placement in the P/90 is very important. Slots four through eight require the installation of either a board or a jumper module.

Table 1-1. P/90 Card Cage Slot Assignments

Slot #	Board
8	Host Adapter 0
7	Host Adapter 1
6	Host Adapter 2, Ethernet, or DDN/SNA
5	VCP, Host Adapter 3, Ethernet, or DDN/SNA
4	no board or VCP (see NOTE below)
3	Arbiter
2	68020 CPU
1	Memory

[NOTE] Systems without modems installed on the arbiter board can have the VCP installed in slot four.

The Host Adapter Board

The host adapter board is the system interface to your system's peripherals (hard disk drives, tape drives, etc.). Each host adapter can support two hard disk drives, and one each of the tape drives, optical disk drives, and floppy drives. Figure 1-3 illustrates the P/90 system internal interface.

† Ethernet is a registered trademark of Xerox Corporation




Figure 1-3. P/90 System Internal Interface

Space Requirements

This section describes the overall dimensions of your system cabinet, the minimum floor area required to install and service your system and the area required to unpack it. The main cabinet and expansion cabinet have identical outside measurements and footprint.

System Cabinet Dimensions and Weight

The outside measurements of your P/90 computer are given in Table 1-2.

Table 1-2. Dimensions and Weight

Dimensions and Weight		
Height	29 in.	(73.6 cm)
Width	9.95 in.	(25.3 cm)
Depth	26.9 in.	(68.3 cm)
Weight-Main Cab.	54 to 175 lb	(24.5 to 79 kg)
Weight-Exp. Cab.†	85 to 175 lb	(38.6 to 79 kg)

† one media tray with two disk drives

Floor Area Requirements

From the dimensions in Table 1-2, the basic footprint of your P/90 cabinet (main or expansion) is 10 inches wide and 27 inches deep. Additional space around the cabinet(s) is required at the back, front, sides, and top of the cabinet(s) for servicing. Table 1-3 lists the service area requirements.

Table 1-3. Service Clearance

Service Clearance		
Front	60 in.	(152 cm)
Back	30 in.	(76 cm)
Sides	24 in.	(61 cm)
Top	24in.	(61 cm)

Combining the dimensions from Table 1-2 and 1-3, we can compute the minimum area required to service and install your P/90 main cabinet. For each expansion cabinet, you must allow an additional 24 inches (61 cm) to the minimum width dimension.

Table 1-4. Minimum Area

Minimum Required Area		
Height	53 in.	(135 cm)
Depth	118 in.	(229 cm)
Width	58 in.	(83 cm)

Power Requirements

This section describes the characteristics of the P/90 power requirements, the grounding of the unit, noise suppression, and types of power connectors required for proper installation and running.

Voltage Characteristics

Your computer is equipped with one of six power options which are set at the factory. When you ordered your system, you or your salesman ordered the correct power option. The voltage options are listed in Table 1-5.

Table 1-5. Plexus Power Options

115V	49 — 61 hz	(± 15%) †
230V	49 — 61 hz	(± 15%)
† Plexus default.		

Input Current Characteristics

The input current specifications for each P/90 cabinet is:

Steady State	9A @ 115V 4.5 @ 230V
Surge	30A avg.

[NOTE] Amperage figures are for the system only. All main and expansion cabinets require a separate 20-amp circuit breaker with a 20-amp grounded outlet.

Grounding

Your P/90 is provided with a three-conductor power cord terminated in a three-conductor plug with the green safety ground wire connected to the metal frame of the system. This safety ground protects you and your personnel against malfunctions such as short circuits and also helps to protect the equipment against natural events, such as lightning strikes. For this protection to work properly, the power cord must be plugged into an outlet which employs a ground connection, which in turn, must be connected to the distribution panel where your system's circuit breaker is installed.

Grounding wires for the outlets used by the P/90 and its peripheral equipment must be connected to the same ground wire (separate from the neutral) at the distribution panel. The grounding wire should go from the distribution panel to an earth ground. The earth ground could be the structural steel of the building, a ground rod, a building entrance earth ground connection or the earth ground of an existing computer system.

[CAUTION] All grounding wires used for your P/90 must be insulated; conduit must not be used for grounding wires.

Lightning Arrestors

If protection of power and communication lines are needed against lightning, it is recommended that an external line (suppressor) arrestor/filter be installed that is able to suppress a strike of 6KV to 440V on an average of 50usec., and that both common and transceiver suppressor absorption capability of 80 joules — 6500 Amp dissipation.

Noise Suppression

Office equipment, janitorial equipment, electric motors, etc. can create electromagnetic interference (noise) sufficient to cause computer malfunctions. To eliminate the noise, or reduce it to an acceptable level, your computer and its peripherals must be provided with circuit breakers and grounding systems separate from those used by other electrical equipment. Grounding of the equipment and of the power distribution circuit must be as described in the section *Grounding*.

[NOTE] For severe line noise conditions, Plexus recommends the use of a line conditioner/filter or a UPS.

Power Cords and Connectors

Many different types of power and power distribution systems are used throughout the world. Use one that is applicable to your local power system. The connector mounted on the rear panel of your computer is a standard 3-conductor connector.

[NOTE] Plexus only ships the standard U.S.A. power cord connector. All others must be installed by the user.

Environmental Requirements

This section details the environmental requirements of your computer. Table 1-6 lists the temperature, humidity, and heat dissipation required for the proper operation of your system.

Table 1-6. Environmental Requirements

Environmental Consideration	Environmental Requirement
Temperature (Operating)	40 - 85F (4 - 30C)
Temperature (Non-Operating)	-40 - 140F (-40 - 40C)
Temperature (Gradient)	±27 deg/hr max; ±15deg C/hr max.
Humidity (Operating)	20 - 80% RH
Humidity (Non-Operating)	5 - 89% RH (noncondensing)
Heat Dissipation	930 watts (per cabinet)
Altitude (Operating)	0 - 10,000 feet
Altitude (Non-Operating)	0 - 40,000 feet

Temperature and Humidity Ranges

The acceptable, recommended, and unacceptable temperature and humidity ranges for the operation of your computer are shown in Figures 1-4 and 1-5, respectively.

If your system is moved from one environment to another (from one room to another), Plexus recommends that the equipment not be powered up until the system has had time to acclimate to the new environment. You should wait one hour for each 10° C (18° F) temperature difference before powering up your system.

Excessively high humidity levels can cause improper operation of disk units and of paper-handling peripherals such as printers, while excessively low humidity levels can increase static electricity problems.

Electrostatic Discharges

In the course of walking, it is possible to accumulate large amounts of static electricity. If you discharge the static electricity around your computer, it can damage the equipment, cause errors in system operation, and damage the contents of software media such as floppy disks and magnetic tape. To prevent damage caused by static electricity, ground mats or wrist straps connected to earth ground must be used while working around your computer. These mats and straps are designed to dissipate a static charge.

[WARNING] Do not handle computer component or printed circuit boards unless you are properly grounded. Even the small electrostatic discharges which you cannot feel can damage components.




Figure 1-4. Temperature Range




Figure 1-5. Humidity Range

Cooling Requirements

Your computer system is equipped with cooling fans to circulate environmental (room air) air through the cabinet. The following equations are used to calculate the ability of an environment to maintain the proper operating temperatures.

$$\text{Heat output in watts} \times xxx = \text{Temperature rise}$$

where the heat output in watts is the wattage of your system and *xxx* is a fixed value determined by the size of the room. Table 1-7 lists several sample values.

Table 1-7. Sample Fixed Values for Temperature Rises

	Fahrenheit	Celsius
10'x10'(3m x 3m) Room	0.02	0.0112
Large Room	≈ 0.00	≈ 0.00

To determine the temperature of the room when the computer is running, add the temperature rise to the current room temperature.

For an example, consider the installation site of a computer to be a room ten foot by ten foot in size. The room is air conditioned to 76 degrees F (24 C) and is windowless. The formula used to calculate the rise in temperature caused by the installation of your computer is:

$$930 \text{ watts} \times 0.0112 = 10.4\text{C} + 24\text{C} = 34.4\text{C} (93.9\text{F})$$

In this example, additional cooling is not required, but additional cooling might be desirable.

If your system is operated continuously, you must determine if the air conditioning is turned off or down during weekends or during off-work hours. If the operation of the air conditioning is varied, measurements must be taken during the down or off periods to ensure that the temperature range of the system is not exceeded. In order to prevent damage to the system when its operating range is exceeded, additional air conditioning must be provided or the system must be powered down during these down periods.

Cabling

This section details the information and techniques needed to connect external equipment (cables) to your P/90 computer system.

Cable Lengths

The RS-232C technical standard recommends cables no longer than 50 foot, however, Plexus has found that cables up to 200 feet in length are acceptable if a low-capacitance, shielded cable is used. Longer runs are possible but have a greater probability of noise on the line.

Two types of add-on equipment are available for use in extending cable runs: current loop adapters and short-haul modems. When using a current loop adapter at the terminal end of a cable, lengths up to 1000 feet are allowed. Most terminals have a current loop interface available on unused pins of the RS-232C connector.

If your terminals lack current loop capability, or if the run required is longer than 1000 feet, short-haul modems must be used. This configuration requires two modems to be used: one at the terminal and one at the computer. The use of short-haul modems allows cable runs of up to several miles with the only limiting factor being the capability of the modems themselves.

General Considerations

To protect other equipment from noise radiation, an overall shield for the cable is required. If a shielded cable is used, the shield should be connected via a metallic connector hood to the I/O panel connector jackscrews, for maximum shielding effect. For terminal use, the shield should not be connected to any other pins on the RS-232C connector.

It is also recommended that cables not be run through electrically noisy areas, such as those areas containing large electric motors, welding apparatus, X-ray machines etc. Any wiring running outside of a building should be buried in conduit, not strung above ground. This provides protection against natural occurrences, such as lightning strikes that would damage the computer's communication board(s). Please note that such damage is not covered by the Plexus warranty. If lightning is a possibility at your installation site, it is highly recommended that fiber optic lines and modems be installed.

Cable Termination

Peripheral equipment connected to your system must remain connected, even when the peripherals are not in use. If you disconnect a cable from a peripheral, you must also disconnect the cable from the the system's I/O panel. Any cable connected to the system I/O panel, and not connected to anything else, can pick up noise, and cause system malfunctions. Cables not properly terminated at the peripheral end can also pick up noise, severely affecting system operation.

Cable Wiring

The number of wires (or pins) used in building cables depend on the application of the port being used (i.e. modem, terminal, DB-9, etc.). Tables 1-8 through 1-14 list the pinouts of the ports available for your P/90.

Table 1-8. Terminal/Serial Printer Cable Pinouts

LINC Card (DB-9)	To I/O Device (DB-25)	Signal Name
1	3	RXD
6	2	TXD
8	7	GND

Table 1-9. Synchronous Modem Cable Pinouts (DB-9)

LINC Card (DB-9)	Modem (DB-25)	Signal Name
1	2	TXD
2	4	RTS
3	17	RXC
4	20	DTR
5	15	TXC
6	3	RXD
7	5	CTS
8	7	GND
9	8	DCD

Table 1-10. Asynchronous Modem Cable Pinouts (DB-9)

LINC Card (DB-9)	Modem (DB-25)	Signal Name
1	2	TXD
2	4	RTS
4	20	DTR
6	3	RXD
7	5	CTS
8	7	GND
9	8	DCD

Table 1-11. Terminal/Serial Printer Cable Pinouts (DB-25 [with DTR Flow Control])

LINC Card DB-25	I/O Device DB-25	Signal Name
2	2	TXD
3	3	RXD
7	7	GND
20	20	DTR

Table 1-12. Asynchronous Modem Cable Pinouts (DB-25)

LINC Card DB-25	Modem DB-25	Signal Name
2	3	RXD
3	2	TXD
4	5	CTS
5	4	RTS
6	20	DTR
7	7	GND
8	8	DCD
20	6	DSR

[WARNING] Hardware damage will occur if you cross plug DB-25 connectors (both serial and parallel) with connector gender change devices.

Table 1-13. Synchronous Modem Cable Pinouts (DB-25)

LINC Card DB-25	Modem DB-25	Signal Name
2	3	RXD
3	2	TXD
4	5	CTS
5	4	RTS
6	20	DTR
7	7	GND
8	8	DCD
20	6	DSR
15	15	TXC
17	17	RXC

Table 1-14. Parallel I/O Port Pinouts (P4)

Pin #	Description	Direction
1	Strobe*	To Printer
2	Data Bit 0	To Printer
3	Data Bit 1	To Printer
4	Data Bit 2	To Printer
5	Data Bit 3	To Printer
6	Data Bit 4	To Printer
7	Data Bit 5	To Printer
8	Data Bit 6	To Printer
9	Data Bit 7	To Printer
10	Acknowledge*	To LINC
11	Busy	To LINC
12	Paper Empty	To LINC
13	Select	To LINC
14	not used, reserved	
15	Error*	To LINC
16	Initialize Printer*	To Printer
17	Select Input*	To Printer
18-25	Ground	To LINC

* = Active low signal

VMEbus Backplane

The VMEbus employs a four level bus request — bus grant scheme for allowing boards access to the VMEbus. Those slots not occupied by a board require a jumper plug installed in the upper connector bus of the unused slot (on the back of the backplane). This requirement assures the bus grant signal is passed to all board slots.

[WARNING] If an empty slot does not have a jumper plug installed, CPU selftest will fail.

Bus requests are initiated by controller board(s), and the job processor board to gain access to the VMEbus. When the bus is required, the board issues a bus request signal (**BR0-** through **BR3-**). The signal is processed by the bus arbiter chip on the VMEbus arbiter board and a bus grant signal is sent (**BG0** through **BG3**).

The bus grant signal is daisy-chained through the VMEbus to the board requesting the bus (starting at slot 8). For this scheme to work, each bus grant signal is actually two signals: bus grant in and bus grant out (see Figure 1-6).




Figure 1-6. Bus Grant Block Diagram

There are also four levels of bus requests and bus grants (**BS0** through **BS3**). Each board is hard-wired to a bus request level, with the highest level being the first level (**BS0**) and the lowest being the fourth level (**BS3**).

The VMEbus supports seven interrupt lines, **IRQ1*** through **IRQ7***. Interrupts are processed by the job processor to determine priority.

The VMEbus is capable of supporting 32 data and 32 address lines each. Table 1-15 lists the bits the address and data bus can support per cycle.

Table 1-15. Address and Data Path Bits

Bus	Bits
Address	32-, 24-, or 16-bits
Data	32-, 16-, or 8-bits

VMEbus Electrical Specifications

The VMEbus requires a 96-pin connector for each each backplane card slot. The 96-pin connector used by the VMEbus must provide: a voltage rating greater than or equal to 100 volts DC, isolation pin to pin; a contact resistance less than or equal to 50 milliohms, at rated current; and insulation resistance greater than or equal to 100 Megohms, pin to pin. The VMEbus signal levels thresholds are shown in Figure 1-7.




Figure 1-7. VMEbus Signal Levels

Uninterruptable Power Supply (UPS)

Your P/90 is designed to accept an optional uninterruptable power supply (see the UPS connector on the back of your system). Two UPS signals sense the power source of your system: **UPSINT1-** and **UPSINT2-**. When UPS signals are HIGH, power is being received from the standard AC power source (standard operation). When UPS signals are LOW the uninterruptable power supply is active and a graceful shutdown of your system is initiated (*/etc/shutdown*).

[WARNING] UPS systems not approved by Plexus Computers are used at your risk.

PREVENTIVE MAINTENANCE

This chapter describes the preventive maintenance of your P/90 computer. Please remember, preventive maintenance is important. Failure to perform routine maintenance can have a detrimental effect on your system's operation.

Equipment

Listed below is the equipment you need to service your new system. Table 2-1 lists the PM time schedule.

- Head Cleaning Applicators (NOT Cotton Swabs),
- 95% isopropyl alcohol,
- Formula 409† (or comparable) cleaning solution,
- one small whisk broom,
- several cloths,
- cutting pliers,
- 3" tie-wraps (or longer), and
- a vacuum.

Table 2-1. Preventive Maintenance Time Schedule

Scheduled Maintenance	Time Frame
Clean Tape Head & Capstan	After a new tape or eight hours of use.
Clean Fan Filter	Every Two Weeks
Clean Exterior	Every Month
Battery Replacement	Every Two Years

† Formula 409 is a trademark of Proctor and Gamble.

Cleaning Your System's Fan Filters

Every two weeks you should clean the fan filter in each cabinet. This is an easy task requiring no special equipment. The following procedure details the fan filter removal and cleaning. Refer to Figure 2-1.

1. Open the front access door.
2. Slide the fan filter grille to the side of the opening.
3. Gently pull the fan filter grille from the opening.
4. Remove the fan filter.
5. Gently wash the fan filter in warm water using a mild soap.
6. Thoroughly rinse the fan filter to remove any soap residue.
7. Thoroughly dry the fan filter before it's re-installation.




Figure 2-1. P/90 Fan Filter Removal

Maintaining Your 1/4-inch Tape Drive

Your new cartridge tape drive should be cleaned after: using a new tape, or eight hours of use. To properly service the tape drive, you must clean the cartridge read/write head and the tape hole sensor. The equipment needed to clean the cartridge tape drive components are:

- 6-inch or longer head cleaning applicators
- 95% isopropyl alcohol

The following procedure details the recommended cleaning sequence for the cartridge tape drive components. Refer to Figure 2-2. You can remove the side cover from the cabinet, for increased accessibility.

1. Make sure the power is OFF to the tape drive.
2. Slide the lever to extend the head assembly into the cartridge area.
3. Moisten the head cleaning applicator with the alcohol solution.
4. Thoroughly wipe the cartridge tape head, capstan, and the tape hole sensor.
5. Examine the roller guides and wipe any accumulated debris away.
6. Discard the used head cleaning applicator.
7. Buff the tape head, capstan, sensor, and the associated tape path dry with a clean and dry head cleaning applicator.




Figure 2-2. Cleaning the 1/4-inch Tape Drive

Replacing Your System Battery

The system clock is maintained by a Nickel-Cadium (NiCad), PC Mount, 3.6V battery. The battery is mounted to the bus arbiter board, and should be replaced every two years.

Three pieces of equipment are needed to replace the system's battery: a replacement battery, a pair of cutting pliers, and a 3" tie-wrap (or longer).

[NOTE] To keep the processor battery charged, you should run your system for at least 48 hours once every 60 days. Should the processor battery lose its charge due to extended system shutdown, it will be recharged the next time system is powered-up. Remember to reset the system clock before performing operations to the system.

1. Power down your system. See the *Sys5 Administrator's Handbook* for the correct procedure.
2. Turn the keyswitch OFF.
3. Disconnect the power cord.
4. Remove your system's top cover and store it in a safe location (see *Removing Your System's Exteriors* in Chapter Three).
5. Turn the card cage until it is parallel with the floor.
6. Remove the bus arbiter board from the card cage (slot three).
7. Cut the tie-wrap securing the battery.
8. Pull the battery straight out.
9. Discard the old battery.
10. Install the new battery.
11. Use a new tie-wrap to secure the battery.
12. Cut any excess tie-wrap.
13. Replace the bus arbiter board in the card cage.
14. Return the card cage to its upright position.
15. Replace the exterior cover.




Figure 2-3. System Battery Replacement

Cleaning Your System's Exterior

Once a month, the system's exterior should be cleaned. The only equipment needed to clean the exteriors are: a small cloth, Formula 409 (or equivalent), and a small whisk broom.

To clean your system's exteriors:

1. Use whisk broom to clean the vents at the front and back of your system.
2. Spray the Formula 409 solution onto the small cloth and wipe the exterior sides.

[WARNING] DO NOT spray liquid into the exterior vents, fan filters, tape, or floppy disk drive openings.

Maintaining Your Hard Disk Drives

The disk drives do not require preventive maintenance.

ASSEMBLY/DISASSEMBLY

This chapter details the disassembly of your P/90 computer. It is divided into two major sections, the main cabinet, and the expansion cabinet. The components comprising the P/90 main cabinet are:

Disk Drive Unit 0	Disk Drive Unit 1
Disk Drive Unit 2	Keypad
Tape Drive	Tape Drive Controller
Card Cage	Circuit Breaker
Power Cord	System I/O Panels
Power Supply	SCSI Interface Connectors
Fans	Fan Filters

Figures 3-1 and 3-2 illustrate the P/90 main cabinet components.




Figure 3-1. P/90 Main Cabinet Front View with Access Door Open




Figure 3-2. P/90 Main Cabinet Rear View

Removing Your System's Exteriors

Most assembly and disassembly procedures require the removal of the top and side covers. To remove your system's exteriors requires two steps: remove the top and pull away the sides.

To remove the exterior covers from your system:

1. Power down your system. See your *Sys5 Administrator's Handbook*.
2. Turn the keyswitch switch OFF.
3. Disconnect the system's power cable.
4. Remove the two (2) screws (A) in the back of your system near the top. See NOTE below.
5. Open the front door.
6. Remove the two (2) screws (B) in the front of your system near the top. See NOTE below.
7. Lift the top cover from the system.
8. Store the top cover in a safe place.
9. Slide each of the side covers up to disengage them from the system.
10. Store the sides in a safe place.

[NOTE] You must re-install the two front screws (B) and two rear screws (A) with the lock washers (as originally installed) before restoring power to your system.




Figure 3-3. Removing Your System's Exteriors

Removing Your System's Front Panel

Some of the assembly and disassembly procedures require the removal of the system's front panel. The only equipment required the front panel is a small flat-head screwdriver.

To remove the front panel:

1. Power down your system. See your *Sys5 Administrator's Handbook*.
2. Turn the keyswitch switch OFF.
3. Disconnect the system's power cable.
4. Remove the two (2) screws (A) at the top of the front panel (top cover screws).
5. Remove the six (6) screws (B) along each side of the front panel.
6. Gently pull the front panel from the system.




Figure 3-4. Removal of the System's Front Panel

Removing a LINC I/O Card

Your system can employ five LINC I/O cards, located at the back of your system. The removal of each is the same. The only equipment needed is a small flat-head screwdriver.

To remove a LINC I/O card:

1. Power down your system. See your *Sys5 Administrator's Handbook*.
2. Turn the keyswitch switch OFF.
3. Disconnect the system's power cable.
4. Unscrew the top and bottom captive screws (A) from the I/O card.
5. Gently pull the I/O card straight out from the back of the system (to remove the I/O card from the VCP backplane).




Figure 3-5. Removing a LINC I/O Card

Removing Your 1/4-inch Tape Drive

To remove the 1/4-inch tape drive requires the removal of the top and side covers, as well as the removal of the front panel.

To remove the 1/4-inch tape drive:

1. Power down your system (see your *Sys5 Administrator's Handbook*).
2. Turn the keyswitch OFF.
3. Disconnect the power cord.
4. Remove the exterior covers (see the section *Removing Your System's Exteriors* in this chapter).
5. Open the front door.
6. Remove the front panel (*Removing Your System's Front Panel* in this chapter).
7. Disconnect the attaching cables from the 1/4-inch tape drive controller board.
8. Slide the tape drive out of the system.
9. Remove the two (top and bottom) non-skid slides.
10. To install the tape drive, reverse the above procedure.




Figure 3-6. Removing Your 1/4-inch Tape Drive

Removing Your Hard Disk Drive

Your main cabinet can have as many as three different hard disk drives in three different locations. The remove of a disk drive requires the top and side covers be removed first, as well as the front panel.

To remove a disk drive:

1. Power down your system (see your *Sys5 Administrator's Handbook*).
2. Turn the keyswitch OFF.
3. Disconnect the power cord.
4. Remove the exterior cover. (see the section *Removing Your System's Exteriors* in this chapter).
5. Open the front door.
6. Remove the front panel.
7. Mark and disconnect any cables attached to the disk drive(s).
8. Slide the disk drive drawer out of your system and place it on a flat surface.
9. Depress the two clips at the front sides of the disk drive to be removed and gently pull the drive from the disk drive drawer. See NOTE below.
10. Remove the two non-skid slides from the sides of the disk drive.
11. Reverse these steps to install the disk drive.

[NOTE] The main cabinet of the P/90 can contain as many as three hard disk drives. Figure 3-7 illustrates the location of the three disk drives and the correct direction to employ in removing each.




Figure 3-7. Removing Your Hard Disk Drive

Removing Your Power Supply

Removing the power supply requires your first remove: the top cover, side covers, front panel, and the disk drive drawer.

To remove the power supply:

1. Power down your system. See your *Sys5 Administrator's Handbook*.
2. Turn the keyswitch switch OFF.
3. Disconnect the system's power cable.
4. Remove the top and side covers (see the section *Removing Your System's Exteriors* in this chapter).
5. Remove the front panel (see the section *Removing Your System's Front Panel* in this chapter).
6. Remove the disk drive drawer (see *Removing Your Hard Disk Drive* in this chapter).
7. Remove the nuts (A) from the two flanges at the front of the system cabinet.
8. Remove the two screws (B) from the power supply chassis.
9. Slide the power supply out the front of the system.




Figure 3-8. Removing Your Power Supply

Removing Your VCP Backplane Card

Removing the VCP backplane requires your first remove: the top cover, side covers, and all I/O panels.

To remove the VCP backplane:

1. Power down your system (see your *Sys5 Administrator's Handbook*).
2. Turn the keyswitch OFF.
3. Disconnect the power cord.
4. Remove the exterior covers (see the section *Removing Your System's Exteriors* in this chapter).
5. Remove all of the I/O panels (see the section *Removing an I/O Panel* in this chapter).
6. Disconnect the VCP backplane cable.
7. Remove the four nuts (A) holding the VCP backplane.
8. Gently pull the VCP backplane from the four mounting studs.
9. Slide the VCP backplane away from the chassis.




Figure 3-9. VCP Backplane Removal

Removing Your Tape Controller

Removing the 1/4-inch cartridge tape controller requires your first remove: the top cover and the side covers.

To remove the 1/4-inch cartridge tape drive controller:

1. Power down your system (see your *Sys5 Administrator's Handbook*).
2. Turn the keyswitch OFF.
3. Disconnect the power cord.
4. Remove the exterior covers (see the section *Removing Your System's Exteriors* in this chapter).
5. Locate the 1/4-inch cartridge tape controller (see Figure 3-10).
6. Remove any attaching cables by carefully grasping the cable connector and gently removing it from the controller connector.
7. Gently pull 1/4-inch cartridge tape controller from the four (4) board clips.




Figure 3-10. Removing the 1/4-inch Cartridge Tape Controller

Removing Your Disk Drive Controller

Removing the disk drive controller requires your first remove the top cover and side covers.

To remove the controller board:

1. Power down your system (see your *Sys5 Administrator's Handbook*).
2. Turn the keyswitch OFF.
3. Disconnect the power cord.
4. Remove the exterior covers (see the section *Removing Your System's Exteriors* in this chapter).
5. Disconnect the cables at the back of the controller panel. To remove the cables, firmly grasp one side of the cable connector and gently pull the two connectors apart.
6. Remove the six (A) screws holding the protective screen in place. Store the screen in a safe location.
7. Carefully remove the cable connectors from the controller board by firmly holding the controller board and gently pulling the cable free.
8. Using a small flathead screwdriver, remove the four (B) attaching screws.
9. The board is now free.




Figure 3-11. Removing a Disk Drive Controller

Removing a Backplane Jumper Block

Whenever you change the configuration of your card cage, you must determine if a backplane jumper block must be moved, added, or deleted. If in doubt, read *VMEbus Backplane* in Chapter One of this manual. Moving a backplane jumper block requires your first remove the top cover and side covers.

To remove a backplane jumper block:

1. Power down your system (see your *Sys5 Administrator's Handbook*).
2. Turn the keyswitch OFF.
3. Disconnect the power cord.
4. Remove the exterior covers (see the section *Removing Your System's Exteriors* in this chapter).
5. Disengage the three captive screws at the top of the card cage.
6. Rotate the card cage into the service position (see Figure 3-13).
7. At the back of the card cage, gently pull the jumper block straight out from the backplane (see Figure 3-12).




Figure 3-12. Removing a Backplane Jumper Block




Figure 3-13. Rotating the Card Cage

Adding Another Controller Board

Adding another controller board requires you first remove the top cover and side covers.

To add a controller board:

1. Power down your system (see your *Sys5 Administrator's Handbook*).
2. Turn the keyswitch OFF.
3. Disconnect the power cord.
4. Remove the exterior covers (see the section *Removing Your System's Exteriors* in this chapter).
5. Remove the six (A) screws holding the protective screen in place. Store the screen in a safe location.
6. Using a small flathead screwdriver, remove the three (B) screws at the front of the controller panel.
7. Attach the correct controller board adapter plate to the controller panel.
8. Attach the new controller board to the adapter plate.
9. Attach the SCSI cable connector to the board connector.
10. Replace the protective screen.
11. Re-install the top and side covers.




Figure 3-14. Adding Another Controller Board

Expansion Cabinet Assembly/Disassembly

This section describes the assembly and disassembly of your P/90 expansion cabinet. The main components of your P/90 expansion cabinet are:

Disk Drive Unit 0	Disk Drive Unit 1
Tape Drive	Tape Drive Controller
Media Tray	Circuit Breaker
Power Cord	Power Supply(s)
SCSI Controller	SCSI Interface Connectors
Fans	Fan Filters

Figures 3-15 and 3-16 illustrate the P/90 expansion cabinet components.




Figure 3-15. P/90 Expansion Cabinet Components




Figure 3-16. P/90 Expansion Cabinet Rear View

Removing Your System's Exteriors

Most of the assembly and disassembly procedures do not require the removal of the expansion cabinet exterior sides. However, you must remove the top cover from your expansion cabinet to access and remove the top ("removable") media tray. Removing your system's exteriors requires two steps: remove the top cover and pull away the sides. Refer to Figure 3-17.

To remove the exterior covers from your system:

1. Power down your system. See your *Sys5 Administrator's Handbook*.
2. Turn the P/90 main cabinet keyswitch to the OFF position.
3. Turn off the power switch on the expansion cabinet.
4. Disconnect the systems' power cables.
5. Remove the two upper screws on the rear panel of your system.
6. Lift the rear of the top cover from the cabinet and pull.
7. Store the top cover in a safe place.
8. Slide each of the side covers up to disengage them from the cabinet.
9. Store the sides in a safe place.




Figure 3-17. Removing Your System's Exteriors

Removing Your System's Front Panel

Your P/90 expansion cabinet is designed such that the hard disk drive media trays can be removed through the front access panel. The only equipment required to remove this panel is a small phillips screwdriver. Refer to Figure 3-18.

To remove the front panel:

1. Power down your system. See your *Sys5 Administrator's Handbook*.
2. Turn the P/90 main cabinet keyswitch to the OFF position.
3. Turn off the power switch on your expansion cabinet.
4. Disconnect the systems' power cables.
5. Remove the two screws from the bottom of the front access panel.
6. Remove the three screws along each side of the front access panel.
7. Gently pull the front panel from the system.

[NOTE] The +5V power indicator cable is routed through a cutout on the left side of the access panel. Be very careful not to snag the cable on the sharp edges of this cutout as you remove the access panel.




Figure 3-18. Removal of the System's Front Panel

Removing Your Expansion Cabinet's Media Tray

You must first remove the media tray from the expansion cabinet in order to access the drives, controllers, and power supplies for removal/replacement. The media trays are removed from the expansion cabinet with all of the drives, controllers, power supplies attached. This section contains two separate procedures: (1) removing a disk drive media tray; (2) removing the upper "removable" media tray.

To remove a hard disk media tray, you must first open the front door, remove the front access panel, remove the media tray retaining screws from the rear panel, and remove the front retaining brackets for the tray. The only equipment required is a small phillips screwdriver. Refer to Figure 3-19.

To remove a hard disk media tray from the expansion cabinet:

1. Power down your system. See your *Sys5 Administrator's Handbook*.
2. Turn the P/90 main cabinet keyswitch to the OFF position.
3. Turn off the power switch on your expansion cabinet.
4. Disconnect the systems' power cables.
5. Remove the front access panel.
6. Remove the two media tray retaining brackets.
7. Remove the two retaining screws (located above and below the tray's recessed SCSI port) from the rear panel.
8. Unplug the AC power plug from the front of the media tray.
9. Pull the tray out of the expansion cabinet.
10. Gently place the tray on a flat surface.

[NOTE] The weight of a media tray with two drives is 30 pounds. The weight of a media tray with four drives is 50 pounds. Be careful when you pull a tray out of the cabinet.




Figure 3-19. Removal of an Expansion Cabinet Tray

To remove the upper "removable media" tray, you must open the front door, remove the front access panel, remove the expansion cabinet top cover, remove the rear panel retaining screws, and remove the front retaining brackets for the tray. The only equipment required is a small phillips screwdriver.

To remove the upper media tray from the expansion cabinet:

1. Power down your system. See your *Sys5 Administrator's Handbook*.
2. Turn the P/90 main cabinet keyswitch to the OFF position.
3. Turn off the power switch on your expansion cabinet.
4. Disconnect the systems' power cables.
5. Remove the expansion cabinet front panel (see the section *Removing Your System's Front Panel*).
6. Remove the top cover.
7. Unplug the molex connector supplying power from the AC distribution panel (located at lower left of tray).
8. Remove the two media tray retaining bracket screws.
9. Remove the two retaining screws (located above and below the upper recessed SCSI port) from the rear panel.
10. Pull the tray out of the expansion cabinet.
11. Gently place the tray on a flat surface.

[NOTE] The weight of the removable media can be as much as 34 pounds. Take care when pulling the tray out of the expansion cabinet.

Removing Your Hard Disk Drive

Each media tray (excluding the top removable media tray) can have four hard disk drives installed. The two disk drive media trays are identical with respect to removing the drives. To remove a hard disk drive you must remove the media tray.

To remove a disk drive:

1. Remove the expansion cabinet media tray (see the section *Removing Your System's Expansion Cabinet Media Tray* and follow the 10 steps).
2. Disconnect all cables (power, data, signal) attached to the disk drive.
3. If you are removing one of the rear drives, you must remove the fan assembly from the media tray. Remove the two retaining screws from the bottom of the tray.

[CAUTION] The fans are loose in this assembly. They can be dropped and damaged if care is not exercised at this time.

4. Depress the two clips at the front sides of the disk drive to be removed and gently pull the drive from the media tray. See NOTE below.
5. Remove the two non-skid slides from the sides of the disk drive. Note, the slides are loose and will fall free when the drive is removed.
6. Reverse these steps to install the disk drive.

[NOTE] Figure 3-20 illustrates the positions and direction in removing a disk drive from an expansion cabinet tray.




Figure 3-20. Removing Your Hard Disk Drive

Disk Drive Controller Removal

As many as four disk drive controllers can be installed in a P/90 expansion cabinet, two each on a disk drive media tray (excluding the top removable media tray).

To remove a disk drive controller, you must first remove the media tray from the expansion cabinet, and the protective shield on the media tray. Refer to Figure 3-21.

To remove a disk drive controller:

1. Power down your system (see your *Sys5 Administrator's Handbook*).
2. Turn the P/90 main cabinet keyswitch to the OFF position.
3. Turn off the power switch on your expansion cabinet.
4. Disconnect the systems' power cords.
5. Remove the media tray from the expansion cabinet (see the section *Removing Your Expansion Cabinet's Media Tray* in this chapter).
6. Remove the four retaining screws securing the protective shield to the tray. Remove the shield from the tray.
7. Locate the disk drive controller(s).
8. Disconnect all attached cables.
9. Gently depress the plastic standoffs and remove the board.




Figure 3-21. Removing a Disk Drive Controller

Power Supply Removal

The power supply(s) for the disk drive media tray is located on top of the drive enclosure. To remove a power supply, you must first remove the media tray. Refer to Figure 3-22.

To remove a power supply:

1. Power down your system (see your *Sys5 Administrator's Handbook*).
2. Turn the P/90 main cabinet keyswitch to the OFF position.
3. Turn off the power switch on your expansion cabinet.
4. Disconnect the systems' power cords.
5. Remove the media tray (see the section *Removing Your Expansion Cabinet's Media Tray* in this chapter).
6. Locate the power supply.
7. Remove any attaching cables.
8. Remove the grounding screw from the remaining standoff.
9. Gently depress the three plastic standoffs securing the power supply board to the metallic plate.
10. The power supply is now free.




Figure 3-22. Removing the Power Supply

REFERENCE INFORMATION

This chapter lists general information regarding your P/90 such as connector pinouts, VMEbus signal references, reference information for the Fujitsu† and Maxtor‡ disk drives, SCSI controller configuration, and power supply voltage adjustments. Specific information about individual boards is located in *Chapter 5, Board Descriptions*.

Indicators

The P/90 cabinets have an exterior power indicator light located at the upper left corner (see Figure 4-1). The main cabinet LED lights to indicate +5V is being received from the arbiter. The expansion cabinet LED lights to indicate +5V is being received from the main cabinet.




Figure 4-1. P/90 Cabinet Power Indicators

† Fujitsu is a register trademark of Fujitsu Limited

‡ Maxtor is a register trademark of Maxtor Corporation

Backplane

This sections deals with the connectors of the VCP, the function of each, and their pinouts. Table 4-1 lists the connectors and function.

Table 4-1. P/90 Connectors

Connector	Function	Table
J1.(A,B,C) Connector	VMEbus Interface	4-2
J2.(A,B,C) Connector	VMEbus Interface	4-3
J3.(A,B,C) Connector	Plexus Proprietary Bus	4-4

Table 4-2. J1.(A,B,C) VMEbus Interface

Pin Number	Signal Name	Pin Number	Signal Name
J1A.01	D00	J1A.02	D01
J1A.03	D02	J1A.04	D03
J1A.05	D04	J1A.06	D05
J1A.07	D06	J1A.08	D07
J1A.09	GND	J1A.10	SYSCLK
J1A.11	GND	J1A.12	DS1*
J1A.13	DS0*	J1A.14	WRITE*
J1A.15	GND	J1A.16	DTACK*
J1A.17	GND	J1A.18	AS*
J1A.19	GND	J1A.20	IACK*
J1A.21	IACKIN*	J1A.22	IACKOUT*
J1A.23	AM4	J1A.24	A07
J1A.25	A06	J1A.26	A05
J1A.27	A04	J1A.28	A03
J1A.29	A02	J1A.30	A01
J1A.31	-12V	J1A.32	+5V
J1B.01	BBSY*	J1B.02	BCLR*
J1B.03	ACFAIL*	J1B.04	BG0IN*
J1B.05	BG0OUT*	J1B.06	BG1IN*
J1B.07	BG1OUT*	J1B.08	BG2IN*
J1B.09	BG2OUT*	J1B.10	BG3IN*
J1B.11	BG3OUT*	J1B.12	BR0*
J1B.13	BR1*	J1B.14	BR2*
J1B.15	BR3*	J1B.16	AM0
J1B.17	AM1	J1B.18	AM2
J1B.19	AM3	J1B.20	GND
J1B.21	SERCLK(1)	J1B.22	SERDAT*(1)
J1B.23	GND	J1B.24	IRQ7*
J1B.25	IRQ6*	J1B.26	IRQ5*
J1B.27	IRQ4*	J1B.28	IRQ3*
J1B.29	IRQ2*	J1B.30	IRQ1*
J1B.30	+5VSTDBY	J1B.32	+5V

Pin Number	Signal Name	Pin Number	Signal Name
J1C.01	D08	J1C.02	D09
J1C.03	D10	J1C.04	D11
J1C.05	D12	J1C.06	D13
J1C.07	D14	J1C.08	D15
J1C.09	GND	J1C.10	SYSFAIL*
J1C.11	BERR*	J1C.12	SYSRESET*
J1C.13	LWORD*	J1C.14	AM5
J1C.15	A23	J1C.16	A22
J1C.17	A21	J1C.18	A20
J1C.19	A19	J1C.20	A18
J1C.21	A17	J1C.22	A16
J1C.23	A15	J1C.24	A14
J1C.25	A13	J1C.26	A12
J1C.27	A11	J1C.28	A10
J1C.29	A09	J1C.20	A08
J1C.31	+12V	J1C.32	+5V

Table 4-3. J2.(A.B.C) VMEbus Interface

Pin Number	Signal Name	Pin Number	Signal Name
J2A.01	(NOT BUSSED)	J2A.02	(NOT BUSSED)
J2A.03	(NOT BUSSED)	J2A.04	(NOT BUSSED)
J2A.05	(NOT BUSSED)	J2A.06	(NOT BUSSED)
J2A.07	(NOT BUSSED)	J2A.08	(NOT BUSSED)
J2A.09	(NOT BUSSED)	J2A.10	(NOT BUSSED)
J2A.11	(NOT BUSSED)	J2A.12	(NOT BUSSED)
J2A.13	(NOT BUSSED)	J2A.14	(NOT BUSSED)
J2A.15	(NOT BUSSED)	J2A.16	(NOT BUSSED)
J2A.17	(NOT BUSSED)	J2A.18	(NOT BUSSED)
J2A.19	(NOT BUSSED)	J2A.20	(NOT BUSSED)
J2A.21	(NOT BUSSED)	J2A.22	(NOT BUSSED)
J2A.23	(NOT BUSSED)	J2A.24	(NOT BUSSED)
J2A.25	(NOT BUSSED)	J2A.26	(NOT BUSSED)
J2A.27	(NOT BUSSED)	J2A.28	(NOT BUSSED)
J2A.29	(NOT BUSSED)	J2A.31	(NOT BUSSED)
J2A.32	(NOT BUSSED)		
J2B.01	+5V	J2B.02	GND
J2B.03	RESERVED	J2B.04	A24
J2B.05	A25	J2B.06	A26
J2B.07	A27	J2B.08	A28
J2B.09	A29	J2B.10	A30
J2B.11	A31	J2B.12	GND
J2B.13	+5V	J2B.14	D16
J2B.15	D17	J2B.16	D18
J2B.17	D19	J2B.18	D20
J2B.19	D21	J2B.20	D22
J2B.21	D23	J2B.22	GND
J2B.23	D24	J2B.24	D25
J2B.25	D26	J2B.26	D27
J2B.27	D28	J2B.28	D29
J2B.29	D20	J2B.20	D31
J2B.31	GND	J2B.32	+5V

Pin Number	Signal Name	Pin Number	Signal Name
J2C.01	(NOT BUSSED)	J2C.02	(NOT BUSSED)
J2C.03	(NOT BUSSED)	J2C.04	(NOT BUSSED)
J2C.05	(NOT BUSSED)	J2C.06	(NOT BUSSED)
J2C.07	(NOT BUSSED)	J2C.08	(NOT BUSSED)
J2C.09	(NOT BUSSED)	J2C.10	(NOT BUSSED)
J2C.11	(NOT BUSSED)	J2C.12	(NOT BUSSED)
J2C.13	(NOT BUSSED)	J2C.14	(NOT BUSSED)
J2C.15	(NOT BUSSED)	J2C.16	(NOT BUSSED)
J2C.17	(NOT BUSSED)	J2C.18	(NOT BUSSED)
J2C.19	(NOT BUSSED)	J2C.20	(NOT BUSSED)
J2C.21	(NOT BUSSED)	J2C.22	(NOT BUSSED)
J2C.23	(NOT BUSSED)	J2C.24	(NOT BUSSED)
J2C.25	(NOT BUSSED)	J2C.26	(NOT BUSSED)
J2C.27	(NOT BUSSED)	J2C.28	(NOT BUSSED)
J2C.29	(NOT BUSSED)	J2C.20	(NOT BUSSED)
J2C.31	(NOT BUSSED)	J2C.32	(NOT BUSSED)

Table 4-4. J3.(A,B,C) Plexus Proprietary Interface

Pin Number	Signal Name	Pin Number	Signal Name
J3A.01	Not	Defined J3-A.02	Not Defined
J3A.03	CPD03	J3-A.04	CPD06
J3A.05	CPD08	J3-A.06	CPD11
J3A.07	CPD14	J3-A.08	CPD16
J3A.09	GND	J3-A.10	CPD20
J3A.11	GND	J3-A.12	CPD24
J3A.13	CPD27	J3-A.14	CPD30
J3A.15	GND	J3-A.16	CPADD02
J3A.17	GND	J3-A.18	CPADD07
J3A.19	GND	J3-A.20	CPADD11
J3A.21	CPADD13	J3-A.22	GND
J3A.23	CPADD18	J3-A.24	CPADD20
J3A.25	CPADD23	J3-A.26	CPADD25
J3A.27	GND	J3-A.28	CREQ-
J3A.29	MREAD-	J3-A.30	MSBE-
J3A.31	+5V	J3-A.32	+5V
J3B.01	Not	Connected	J3B.02
J3B.03	CPD04	J3B.04	CPD07
J3B.05	CPD09	J3B.06	CPD12
J3B.07	CPD15	J3B.08	CPD17
J3B.09	CPD19	J3B.10	CPD21
J3B.11	CPD23	J3B.12	CPD25
J3B.13	CPD28	J3B.14	CPD31
J3B.15	MEMCLK	J3B.16	CPADD02
J3B.17	CPADD05	J3B.18	GND
J3B.19	CPADD09	J3B.20	GND
J3B.21	CPADD14	J3B.22	CPADD16
J3B.23	GND	J3B.24	CPADD21
J3B.25	GND	J3B.26	CPADD26
J3B.27	MSTRB-	J3B.28	DREQ-
J3B.29	MCMPLT-	J3B.30	MMBE-
J3B.31	+5V	J3B.32	+5V

Pin Number	Signal Name	Pin Number	Signal Name
J3C.01	CPD00	J3C.02	CPD02
J3C.03	CPD05	J3C.04	GND
J3C.05	CPD10	J3C.06	CPD13
J3C.07	GND	J3C.08	CPD18
J3C.09	GND	J3C.10	CPD22
J3C.11	GND	J3C.12	CPD26
J3C.13	CPD29	J3C.14	GND
J3C.15	GND	J3C.16	CPADD04
J3C.17	CPADD06	J3C.18	CPADD08
J3C.19	CPADD10	J3C.20	CPADD12
J3C.21	CPADD15	J3C.22	CPADD17
J3C.23	CPADD18	J3C.24	CPADD22
J3C.25	CPADD24	J3C.26	CPADD27
J3C.27	GND	J3C.28	GND
J3C.29	GND	J3C.30	GND
J3C.31	+5V	J3C.32	+5V

Test Points

Test Points for the P/90 are located on the bus arbiter board (slot 0). See Figure 4-2 for the locations of the test points on the bus arbiter board. For more information regarding the test points, see *Chapter Five, Board Descriptions*.




Figure 4-2. P/90 Test Point Locations (Arbiter Board)

Hard Disk Controller Board

Tables 4-5 and 4-6 list the switch setting of the hard disk controller boards in both cabinets. Controller 0 is set to SCSI ID 5; Controller 1 is set to SCSI ID 6. In the expansion cabinet, each hard disk media tray can have two controllers. The forward controller is set to SCSI ID 6; the rear controller is set to SCSI ID 5. Figure 4-3 illustrates the hard disk controller.

Table 4-5. Disk Controller Switch Setting (F2)

1	2	3	4	5	6	7	8	SCSI ID
OFF	OFF	ON	ON	OFF	ON	ON	OFF	5
OFF	OFF	ON	ON	OFF	ON	OFF	ON	6

Table 4-6. Disk Controller Switch Setting (E9)

1	2	3	4	5	6	7	8
ON	ON	ON	OFF	ON	OFF	OFF	OFF

Cartridge Tape Controller Board

Tables 4-7 and 4-8 list the switch settings of the 1/4-inch cartridge tape controller board. Figure 4-4 illustrates the tape controller board.

Table 4-7. Tape Controller Switch Settings (U53)

1	2	3	4	5	6	7	8
CLOSED	CLOSED	OPEN	CLOSED	OPEN	OPEN	CLOSED	OPEN
OPEN = UP, CLOSE = DOWN							

Table 4-8. Tape Controller Switch Settings (U20)

1	2	3	4	5	6	7	8
OPEN	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	OPEN	OPEN
OPEN = UP, CLOSE = DOWN							




Figure 4-3. Hard Disk Controller




Figure 4-4. Tape Controller Board

135 Megabyte Fujitsu Disk Drive

Tables 4-9 through 4-11 list the jumper settings of the 135 Megabyte disk drive.

Table 4-9. 135 Megabyte Disk Drive Jumper CNH5

<u>Jumper</u>	<u>Settings</u>
11-12	OPEN
13-14	SHORT
15-16	SHORT

Table 4-10. 135 Megabyte Disk Drive Jumper CNH7

<u>Jumper</u>	<u>Setting</u>
1-2	SHORT
3-4	SHORT
5-6	OPEN
7-8	SHORT
9-10	OPEN
11-12	SHORT
13-14	OPEN
15-16	OPEN

Table 4-11. 135 Megabyte Disk Drive Jumper CNH6

<u>Jumper</u>	<u>Unit 0</u>	<u>Unit 1</u>
1-2	SHORT	OPEN
3-4	OPEN	SHORT
5-6	OPEN	OPEN
7-8	OPEN	OPEN
9-10	OPEN	OPEN
11-12	OPEN	OPEN
13-14	OPEN	OPEN
15-16	OPEN	OPEN

Disk Drive Fault Lamps (LEDs)

Two types of LEDs are used on the disk drive:

- Ready** The ready LED is ON when the drive is accepting commands and is selected. It is OFF during initial seeks and when commands are being executed.
- Fault** Creates a binary four-bit fault code. See Table 4-12.

Table 4-12. Disk Drive Fault Codes

3	2	1	0	State
X	X	X	O	Spindle motor revolutions fewer than 90% of standard
X	X	O	X	VCM over current
X	X	O	O	Initial seek time out
X	O	X	X	Write command during seek operation
X	O	X	O	+12V/+5V, less than 80% of standard
X	O	O	X	Offtrack command during write operation
X	O	O	O	Write echo check
O	X	X	X	Two or more head ICs selected during write operation
O	X	X	O	Seek time out
O	X	O	X	Guard band detection during normal seek operation
O	X	O	O	Guard band detection in linear mode
O	O	X	X	Overshoot check
O	O	X	O	Seek fault with seek command
O	O	O	X	Head load signal command
O	O	O	O	Read and write simultaneously issued or other miscellaneous faults
F	F	F	O	Invalid or unimplemented command fault
F	F	O	F	Interface fault
F	F	O	O	Command data parity fault
O = ON				
X = OFF				
F = Flashing				

300 Megabyte Fujitsu Disk Drive

Tables 4-13 through 4-15 list the jumper settings for the 300 Megabyte disk drive.

Table 4-13. 300 Megabyte Disk Drive Jumper CNH5

<u>Jumper</u>	<u>Settings</u>
11-12	OPEN
13-14	SHORT
15-16	SHORT

Table 4-14. 300 Megabyte Disk Drive Jumper CNH7

<u>Jumper</u>	<u>Setting</u>
1-2	SHORT
3-4	SHORT
5-6	OPEN
7-8	SHORT
9-10	OPEN
11-12	SHORT
13-14	OPEN
15-16	SHORT

Table 4-15. 300 Megabyte Disk Drive Jumper CNH6

<u>Jumper</u>	<u>Unit 0</u>	<u>Unit 1</u>
1-2	SHORT	OPEN
3-4	OPEN	SHORT
5-6	OPEN	OPEN
7-8	OPEN	OPEN
9-10	OPEN	OPEN
11-12	OPEN	OPEN
13-14	OPEN	OPEN
15-16	OPEN	OPEN

Disk Drive Fault Lamps (LEDs)

Two types of LEDs are used on the disk drive:

- Ready** The ready LED is ON when the drive is accepting commands and is selected. It is OFF during initial seeks and when commands are being executed.
- Fault** Creates a binary four-bit fault code. See Table 4-16.

Table 4-16. Disk Drive Fault Codes

3	2	1	0	State
X	X	X	O	Spindle motor revolutions fewer than 90% of standard
X	X	O	X	VCM over current
X	X	O	O	Initial seek time out
X	O	X	X	Write command during seek operation
X	O	X	O	+12V/+5V, less than 80% of standard
X	O	O	X	Offtrack command during write operation
X	O	O	O	Write echo check
O	X	X	X	Two or more head ICs selected during write operation
O	X	X	O	Seek time out
O	X	O	X	Guard band detection during normal seek operation
O	X	O	O	Guard band detection in linear mode
O	O	X	X	Overshoot check
O	O	X	O	Seek fault with seek command
O	O	O	X	Head load signal command
O	O	O	O	Read and write simultaneously issued or other miscellaneous faults
F	F	F	O	Invalid or unimplemented command fault
F	F	O	F	Interface fault
F	F	O	O	Command data parity fault
O = ON				
X = OFF				
F = Flashing				

300 Megabyte Maxtor Disk Drive

Tables 4-17 and 4-18 list the jumper settings for the 300 Megabyte disk drive.

Table 4-17. 300 Megabyte Disk Drive Jumpers JP16 - JP31

<u>Jumper</u>	<u>Setting</u>
JP16	SHORT
JP17	SHORT
JP18	SHORT
JP19	OPEN
JP20	OPEN
JP21	SHORT
JP22	SHORT
JP23	OPEN
JP24	OPEN
JP25	SHORT
JP26	OPEN
JP27	OPEN
JP28	OPEN
JP29	OPEN
JP30	SHORT
JP31	OPEN

Table 4-18. 300 Megabyte Disk Drive Jumpers DS1 - DS7

<u>Jumper</u>	<u>Unit 0</u>	<u>Unit 1</u>
DS1	SHORT	OPEN
DS2	OPEN	SHORT
DS3	OPEN	OPEN
DS4	OPEN	OPEN
DS5	OPEN	OPEN
DS6	OPEN	OPEN
DS7	OPEN	OPEN

Power Supply

Your power supply provides ground and four output DC voltages for your system's use: +5V, -12V, +12V, and +24V.

Power Supply Strapping

Your power supply can be strapped for the single phase input voltages (see Table 4-19).

Table 4-19. Power Supply Strapping

Voltage	100-120VAC	220-240VAC
Input Voltage	W1 to 110V	W1 to 220V
Jumper	Post	Post
Apply DC	Line and Neutral Connectors	Line and Neutral Connectors
Fuse	3A	2A

Main Cabinet Power Supply Adjustments

Your power supply can only be adjusted for the +5V and -5V output voltages. To check and adjust the power supply voltages:

1. Connect a D.C. voltmeter negative (common) lead to the GND test point.
2. Connect the voltmeter positive lead to the D.C. voltage test point you are checking.
3. Verify the processor D.C. voltage is within specification. Refer to Table 4-20.
4. Locate the voltage adjustment screw on the power supply. Refer to Figure 4-5.
5. Adjust the voltage with a flathead insulated screwdriver until your voltmeter reads with specifications.

Table 4-20. DC Voltage Checks and Adjustments

Voltage	Suggested	Minimum	Maximum	Ripple
+5V	+5.05V	+5.00V	+5.25V	.05V P/P
-5V	-5.25V	-5.00V	-5.50V	xxxV P/P
+12V	+12.00V	+11.90V	+12.30V	.24V P/P
-12V	-12.00V	-12.30V	-11.90V	.24V P/P
+24V	+24.00V	+23.80V	+24.40V	.48V P/P




Figure 4-5. Main Cabinet Power Supply Adjustments

Expansion Cabinet Power Supply Adjustments

This power supply has a single adjustment pot for +5V and +12V. Figure 4-6 illustrates the location of the adjustment pot, as well as the grounding lug, and input and output connectors. Access to the power supply in the upper media tray is through the cutout in the controller platform.




Figure 4-6. Power Supply Component Location

BOARD DESCRIPTIONS

This section details reference information concerning the circuit boards of the P/90 computer system. The boards discussed are:

- The Job Processor Board
- The Memory Board
- The VMEbus Arbiter Board
- The VMEbus Communication Board (VCP)
- The VCP Backplane Card
- The LINC I/O Boards
- The Multibus* Adapter Board
- The Ethernet Board, and
- The SCSI Host Adapter Board

The card cage slot assignments for P/90 are shown in Table 5-1.

Table 5-1. P/90 Card Cage Slot Assignments

Slot #	Board
8	Host Adapter 0
7	Host Adapter 1
6	Host Adapter 2, Ethernet, or DDN/SNA
5	VCP, Ethernet, DDN/SNA, or Host Adapter 3
4	no board or VCP (see NOTE below)
3	Arbiter
2	68020 CPU
1	Memory

[NOTE] Systems without modems installed on the arbiter board can have the VCP installed in slot four.

* Multibus is a trademark of Intel.

[WARNING] If there is an empty slot in your card cage, a jumper module must be inserted into the rear side of the backplane.

[NOTE] To allow space for the memory bus, the Plexus card cage is larger than the standard VMEbus card cage. Plexus designed circuit boards are 9Ux400mm while standard VMEbus circuit boards are 6Ux150mm. As a result, slots containing standard VMEbus boards must have a sizing bracket installed.

Electrostatic Discharges

It is possible for personnel to accumulate large amounts of static electricity. The discharge of static electricity can damage equipment, cause errors in system operation and can damage the contents of software media such as floppy disks and magnetic tape. To prevent damage from static electricity, ground mats and/or wrist straps connected to earth ground must be used around the computer. These mats/straps will dissipate any accumulated static charge.

[WARNING] Do not handle computer component or printed circuit boards unless you are properly grounded. Even the small electrostatic discharges which you cannot feel can damage components.

The Job Processor Board

The job processor board consists of a 68020 based microprocessor, memory map and interface, cache, DMA, VMEbus, interrupt handling, select logic, clock/calendar, scratch RAM, console and download ports, and various control and timing signals. In the P/90 card cage, the job processor is assigned slot number two (2) in all configurations. Figure 5-1 illustrates the component locations.




Figure 5-1. Job Processor Component Locations

Job Processor Switch Settings

Switches are used to set the system default baud rate, select console terminal port, enable the autoboot mode, and enable/disable the diagnostic mode. Table 5-2 lists the function of each switch.

Table 5-2. Job Processor Switch S1 Configuration

Switch #	Default	Enable	Disable	Function
SW0	OFF	Table 5-3	Table 5-3	Baud Rate
SW1	ON	Table 5-3	Table 5-3	Baud Rate
SW2	ON	Table 5-3	Table 5-3	Baud Rate
SW3	OFF	ON	OFF	Auto Boot Mode
SW4	ON	ON	OFF	Console Port A
SW5	OFF	ON	OFF	Console Port B
SW6	OFF	OFF	OFF	Unused
SW7	OFF	ON	OFF	Diag. Monitor

Switch 7 enables the diagnostic mode after the completion of selftest, and should be turned on for use only by trained Plexus personnel. Switch 6 is not used. Switches 5 and 4 enable console ports B and A respectively. Turning switch 3 ON enables Autoboot mode. The Plexus default is 9600 baud. Table 5-3 lists the switch settings for the baud rates, as well as the console port enables.

Table 5-3. Job Processor Switch Setting Options for Switchpak S1

SW2	SW1	SW0	Baud Rate
OFF	OFF	OFF	110
OFF	OFF	ON	300
OFF	ON	OFF	600
OFF	ON	ON	1200
ON	OFF	OFF	2400
ON	OFF	ON	4800
ON	ON	OFF	9600
ON	ON	ON	19200

SW3	SW4	Port Enabled
OFF	OFF	Port A
OFF	ON	Port A (P3)
ON	OFF	Port B (P4)
ON	ON	Port A and B

Job Processor Jumper Settings

The VMEbus job processor employs eight jumper settings, JP1 through JP8. Table 5-4 lists the settings and functions of the job processor jumpers.

Table 5-4. Job Processor Jumper Settings

Jumper	Pins	Setting	Function
JP1	1-2	Closed	Test jumper to enable a clock signal.
JP2	1-2	Closed	Test jumper to enable a clock signal.
JP3	1-2	Closed	Enables the 16-Kbyte PROM setting.
JP4	2-3	Closed	Disables the 32-Kbyte PROM setting.
JP5	1-2	Closed	Test jumper to enable a clock signal.
JP6	2-3	Closed	VMEbus clock cache select.
JP7	1-2	Closed	Test jumper to enable a clock signal.
JP8	1-2	Open	System debug interrupt select.

Job Processor LEDs

The LEDs are divided into two groups: L7 through L0 display a register content, while LEDs RUN, DMA, HALT, BERR, and VME display system and board status. Table 5-5 lists the functions of the LEDs, while Figure 5-2 illustrate the LED locations.

Table 5-5. Job Processor LEDs

LED	Function
L0 - L7	Register Status
RUN	System is up and running
DMA	Direct memory access is active
HALT	Job processor board not running or memory operation is occurring
BERR	CPU Bus error or DMA bus error
VME	Job processor is accessing the VMEbus




Figure 5-2. Job Processor LEDs

Job Processor Test Points

The VMEbus job processor employs two test points: TP1 for ground and TP2 for +5V.

The Memory Board

A single memory board capable of containing up to 64 Megabytes of DRAM is available in your P/90 and is located in slot one (1). Figure 5-3 illustrates the component location for the memory board.




Figure 5-3. Memory Board Component Location

Memory Board Switch Settings

When the memory board is installed, switch SW1 at board location U32A must be set to the value of the beginning address of the board. The memory board accessed **must** be set to: **0000 0000**, where 1=ON and 0=OFF. Figure 5-4 illustrates the switch position for the first memory board.




Figure 5-4. Base Address of the First Memory Board

Memory Board Error Decoding

The Read Latch register is latched when a single bit or multiple bit error occurs and is reset to a transparent mode by the reset error register (Reset Error). The bit assignment for the Read Latch register is listed in Tables 5-6, 5-7, 5-8. Table 5-9 lists the syndrome error code.

Table 5-6. Memory Board Error Decoding

Bit(s)	Function
0 – 7	Check bits 0 through 10
8 – 10	Number of the selected bank (See Table 5-7)
11 – 13	Number of empty banks (See Table 5-8)
14	Not Used
15	Chip size loaded 1 = 1 Meg memory chips 0 = 256k memory chips
16	Zero (used in sizing memory)
17	Multiple bit error (MBE-) 0 = Multiple bit error
18	Single bit error (SBE-) 0 = single bit error
19 – 31	not implemented

Table 5-7. Memory Board Bank Select Decode

Bank #	10	9	8
Bank 0	OFF	OFF	OFF
Bank 1	OFF	OFF	ON
Bank 2	OFF	ON	OFF
Bank 3	OFF	ON	ON
Bank 4	ON	OFF	OFF
Bank 5	ON	OFF	ON
Bank 6	ON	ON	OFF
Bank 7	ON	ON	ON

Table 5-8. Memory Board Bank Empty Decode

Bank #	13	12	11
Bank 0	ON	ON	ON
Bank 1	ON	ON	OFF
Bank 2	ON	OFF	ON
Bank 3	ON	OFF	OFF
Bank 4	OFF	ON	ON
Bank 5	OFF	ON	OFF
Bank 6	OFF	OFF	ON
Bank 7	OFF	OFF	OFF

Table 5-9. Syndrome Error Code

Code	Error Bit						
0b	bit 17	0e	bit 16	13	bit 18	15	bit 19
19	bit 21	1a	bit 22	1c	bit 23	23	bit 8
26	bit 10	29	bit 11	2a	bit 12	2c	bit 13
34	bit 15	4a	bit 33	4f	bit 32	52	bit 34
57	bit 36	58	bit 37	5b	bit 38	5d	bit 39
64	bit 57	67	bit 58	68	bit 59	6b	bit 60
70	bit 62	75	bit 63	8a	bit 49	8f	bit 48
94	bit 51	97	bit 52	98	bit 53	9b	bit 54
a2	bit 40	a4	bit 41	a7	bit 42	a8	bit 43
ad	bit 45	b0	bit 46	b5	bit 47	cb	bit 1
d3	bit 2	d5	bit 3	d6	bit 4	d9	bit 5
dc	bit 7	e3	bit 24	e5	bit 25	e6	bit 26
ea	bit 28	ec	bit 29	f1	bit 30	f4	bit 31

Table 5-10 lists the diagnostic latch for the least significant 49C460 bit assignments.

Table 5-10. Memory Board Least Significant Bit (Diagnostic Latch)

Bit	Function	Bit	Function
Bit 0	Diag Check Bit 0	Bit 1	Diag Check Bit 1
Bit 2	Diag Check Bit 2	Bit 3	Diag Check Bit 3
Bit 4	Diag Check Bit 4	Bit 5	Diag Check Bit 5
Bit 6	Diag Check Bit 6	Bit 7	Diag Check Bit 7
Bit 8	ID Code 0	Bit 9	ID Code 1
Bit 10	Diag Mode 0	Bit 11	Diag Mode 1
Bit 12	Correct		
Bit 13 - 31	Don't care		

Table 5-11 lists the diagnostic latch for the most significant 49C460 bit assignments.

Table 5-11. Memory Board Most Significant Bit (Diagnostic Latch)

Bit	Function	Bit	Function
Bits 32 - 39	Don't care		
Bit 40	ID Code 0	Bit 41	ID Code 1
Bit 42	Diag Mode 0	Bit 43	Diag Mode 1
Bit 44	Correct		
Bit 45 - 63	don't care		

Memory Board Jumper Settings

Figure 5-5 illustrates the positioning of the two memory board jumpers.




Figure 5-5. Memory Board Jumpers

Memory Board LEDs

Each memory board employs eight LEDs (Light Emitting Diodes), located at the right front corner of your memory board. These LEDs indicate the memory bank (7 through 0) currently being accessed. Figure 5-6 illustrates the sequence of the memory board LEDs.




Figure 5-6. Memory Board's LEDs

Memory Board Test Points

The memory board does not have test points.

The VMEbus Arbiter Board

The VMEbus arbiter board is installed in slot three (3) of the card cage and is responsible for system control, system monitoring, and bus arbitration. Figure 5-7 illustrates the component locations of the bus arbiter board.




Figure 5-7. VMEbus Arbiter Component Location

Bus Arbiter Board Switches

This section details the switch settings of the VMEbus arbiter board. The bus arbiter board employs three switch-paks controlling: the base number used in register, the base number used in the port configuration, and the shutdown delay time circuits. SW1 enables the shutdown function and therefore is always ON (closed). Each progressively higher switch double the shutdown time. Table 5-12 lists the time delay switch-pak U7C (U8C). The time delay can vary from 110 seconds to 7.8 hours (approximately).

The Plexus default setting is approximately four hours (SW1, SW7, and SW8 = ON).

Table 5-12. Arbiter Board Time Delay Switch Settings

Switch Setting	Plexus Default	Time Delay
SW8	ON	1:50 †
SW7	ON	3:40
SW6	OFF	7:20
SW5	OFF	14:40
SW4	OFF	29:20
SW3	OFF	58:40
SW2	OFF	1:57:20
SW1	ON	3:54:40

† Enables shutdown.

[NOTE] Times are approximate.

Table 5-13. Arbiter Board Switch Settings for U3C (U3C)

Switch #	State	Function
SW8	ON	Enable Port B
	OFF†	Disables Port B
SW7	ON	Modem Specific
	OFF†	Modem Specific
SW6	ON†	Modem Specific
	OFF	Modem Specific
SW5	ON†	Enables the Default Diagnostic Port
	OFF	Disables the Default Diagnostic Port
SW4	ON	Enables Power Supply Fail Warning
	OFF†	Disables Power Supply Fail Warning
SW3	ON	Power Supply Switch Settings
	OFF	Power Supply Switch Settings
SW2	ON	Power Supply Switch Settings
	OFF	Power Supply Switch Settings
SW1	ON	Power Supply Switch Settings
	OFF	Power Supply Switch Settings

† Denotes default.

[NOTE] Baud rate of the modem is set by software.

Table 5-14. Arbiter Board Interrupt Switch Settings U3A (U4A)

Switch #	State	Function
SW8	ON	Not Connected
	OFF	Not Connected
SW7	ON†	Interrupt 7 Enabled
	OFF	Interrupt 7 Disabled
SW6	ON	Interrupt 6 Enabled
	OFF	Interrupt 6 Disabled
SW5	ON	Interrupt 5 Enabled
	OFF	Interrupt 5 Disabled
SW4	ON	Interrupt 4 Enabled
	OFF	Interrupt 4 Disabled
SW3	ON	Interrupt 2 Enabled
	OFF	Interrupt 2 Disabled
SW2	ON	Interrupt 1 Enabled
	OFF	Interrupt 1 Disabled
SW1	ON	Interrupt 0 Enabled
	OFF†	Interrupt 0 Disabled

† Denotes default.

Table 5-15. Arbiter Board Power Supply Default Switch Settings

Switch #	State
U3C.1	OFF
U3C.2	ON
U3C.3	OFF

Bus Arbiter Board LEDs

The VMEbus arbiter board has eight LEDs, a four-pack LED to determine which priority level has access to the VMEbus, and four discrete LEDs used to indicate the status of the temperature and voltage sensing circuits/devices. Table 5-16 lists the arbiters LEDs and their function. Figure 5-8 illustrates the configuration of the arbiters LEDs.

Table 5-16. Arbiter LED Functions

LED	Function
OVRTMP	Air temperature indicator for all of the cabinets. When the temperature in any of the cabinets exceeds $70^{\circ}\text{C} \pm 5^{\circ}$ the LED = ON.
PWROK	Voltage indicator for all five of the D.C. voltages. LED = ON when all voltages are within tolerance.
OVRV	Voltage indicator for all five of the D.C. voltages. LED = ON when any one of the five D.C. voltages exceeds its tolerance on the high end.
UNDRV	Voltage indicator for all five of the D.C. voltages. LED = ON when any one of the five D.C. voltages exceeds its tolerance on the low end.
BUSY	Indicates the VMEbus is busy.
PORT B	Indicates port B is functional.
BG1 - BG4	Indicates the level of bus request.




Figure 5-8. Arbiter LED Configuration

Bus Arbiter Board Test Points

This section details the test points of the bus arbiter board (also the system test points). There are seven test points on the bus arbiter board (TP1 through TP7).




Figure 5-9. Arbiter Test Point Locations

Test points are listed on the arbiter board by test point reference voltage (ex. -5V), not their test point designation (ex. TP3). Table 5-17 lists the board reference, and function.

Table 5-17. Arbiter Board Test Points and Functions

Board Desig.	Function
BT	This test point is used to verify the voltage at the rechargeable 3.6V battery. It should be checked with the power OFF as well as ON.
+24V	This test point is used to verify the system +24V used to drive the disk and cartridge tape drives installed in the main cabinet.
-12V	This test point is used to verify the system -12V used by the RS232 drivers on the boards, as well as the disk drives installed in the main cabinet.
+12V	This test point is used to verify the +12V used by the RS232 drivers on the boards, as well as the disk and cartridge tape drives installed in the main cabinet.
-5V	This test point is the system -5V used by all boards and peripherals in the main cabinet.
+5V	This test point is the system +5V used by all boards and peripherals in the main cabinet.
GND	This test point is ground referencing for all other voltages.

Table 5-18 lists the test points and the minimum/maximum values that should be found.

Table 5-18. Arbiter Board Test Points

Nominal	Suggested	Minimum	Maximum
GND	0.00V	-0.70V	+0.70V
+5.00V	+5.05V	+5.00V	+5.10V
-5.00V	-5.00V	-5.25V	-4.75V
+12.00V	+12.00V	+11.40V	12.60V
-12.00V	-12.00V	-12.60V	-11.40V
+24.00V	+24.00V	+21.60V	+26.40V
+3.20V (BATT)†	+3.20V	+3.00V	+4.00V

†Battery test voltage with system power OFF.

Bus Arbiter Board Jumpers

The VMEbus arbiter board employs two jumpers: to enable/disable the xtal clock and to enable/disable a -5V (in some applications). Table 5-19 lists the jumpers, the settings, defaults, and meanings.

Table 5-19. Arbiter Board Jumper Settings

Jumper	Setting	Meaning
W1	Open	Disable -5V (for P/95)
	Closed	Enable -5V (for P/90)
W2	Open	Disable xtal clock
	Closed†	Enable xtal clock

† Plexus default

The VMEbus Communication Processor (VCP)

The VCP controls I/O between the system and the outside world. Your VCP is installed in slot 4 (if a modem chip is not installed on the bus arbiter board) or slot 5 (if a modem chip is installed on the bus arbiter board). Two versions of the VCP exist. Figure 5-10 illustrates the component locations of Type 1 VCP; Figure 5-11 illustrates the component locations of Type 2 VCP.




Figure 5-10. VCP (Type 1) Component Location

VCP Type 2 uses the following wire-wraps:

W1 - pin 4 - pin 8 W2 - pin 2 - pin 10; pin 7 - pin 15




Figure 5-11. VCP (Type 2) Component Location

VCP Switch Settings

The VCP employs one switch pak at location (see Figure 5-10). Table 5-20 lists the switches and their functional description.

Table 5-20. VCP Switch Settings

Switch Number	Functional Description
SW1	Sets the Boot-up/Diagnostic boot mode. OFF = Normal Boot-up (Plexus default). ON = Diagnostic Boot.
SW2	Spare (OFF Default)
SW3	Spare (OFF Default)
SW4	Spare (OFF Default)
SW5	Sets the VCP board address 0 through 4. See Table 5-21.
SW6	Sets the VCP board address 0 through 4. See Table 5-21.
SW7	Sets the VCP board address 0 through 4. See Table 5-21.
SW8	Sets the VCP board address 0 through 4. See Table 5-21.


Table 5-21. VCP Switch Setting Addresses

0	VCP Board #				Switch Number
	1	2	3	4	
0	0	0	0	0	SW5
0	0	0	0	1	SW6
0	0	1	1	0	SW7
0	1	0	1	0	SW8

where 1 = ON and 0 = OFF.

VCP LEDs

The VCP's LEDs employs eight LEDs, located at the edge of the board (see Figure 5-12).



Specific states:

LED #	7	6	5	4	3	2	1	0	
	0	0	0	0	F	0	0	F	Waiting for the download.
	0	0	0	F	F	0	0	0	VCP kernel up and running
	1	0	0	F	F	0	0	0	DMA bus error.
	1	0	0	X	X	0	0	0	68020 bus error.

where:

- F = Flashing
- X = Indeterminate
- 1 = On
- 0 = Off

Figure 5-12. VCP LED Configuration

VCP Jumper Settings


The VCP employs three jumpers and two jumper-paks. Table 5-22 lists the three jumper configurations and functions.

Table 5-22. VCP Jumper Settings

Location	Setting	Function
F22	Closed	Test jumper to enable/disable clock.
F18	Closed	Test jumper to enable/disable clock.
H3	Open	When Closed, enables a write to the EEPROM.

The two jumper-paks work together to set the bus request level setting for the board. The small 8-prong jumper-pak sets the bus request level while the 16-prong jumper-pak sets the bus grant in and out for the selected level. Figure 5-13 illustrates two examples of switch settings.

Bus Request Level 0:



Bus Request Level 3:




Figure 5-13. VCP Jumper-Pak Examples

The VCP Backplane Card

The VCP backplane cards interface between a VCP board in the card cage and up to five LINC cards mounted at the rear of the system.

LINC cards must be installed in a particular order, with the lowest tty ports servicing serial I/Os (LINC V4, LINC V8, and LINC V16) and the highest port numbers servicing the parallel ports (LINC P4).

[CAUTION] Do not skip LINC card slots. LINC cards must be installed sequentially. LINC P4 cards must be installed consecutively.

The LINC I/O Cards

The VCP's data bus is connected to the VCP backplane card, then to the I/O cards (LINC), forming the I/O ports of your system. Currently, four versions of the LINC cards exist: LINC V4 (DB-9), LINC V8 (DB-25), LINC V16 (Telco) and the LINC P4 (Parallel). Table 5-23 lists the LINC board numbers and their descriptions.

Table 5-23. LINC I/O Cards

Board	Description
LINC V4	A four port serial I/O linc card using a DB-25 pin connector.
LINC V8	An eight port serial I/O linc card using a DB-9 pin connector.
LINC V16	A 16 port serial I/O linc card using two Telco connectors.
LINC P4	A four port parallel I/O linc card using a Centronics interface.

Figures 5-14, 5-15, and 5-16 illustrate the LINC V8, LINC V16, and LINC P4 cards.




Figure 5-14. LINC V8 Card




Figure 5-15. LINC V16 Card




Figure 5-16. LINC P4 Card

The Multibus Adapter Board

The Multibus adapter board is a Plexus designed VMEbus board designed to accept Multibus controller boards without resetting switches or jumpers. Two boards require installation in a Multibus adapter board before installation in a P/90: the DDN and the SNA controller boards.

DDN Interface Communication Board

Plexus provides the hardware and software to support a Defense Data Network (DDN) interface. The DDN interface board usually is installed in slot eleven (11) and must be installed in a Multibus adapter board before installation in a P/90. Two cables are required to support the interface board: an RS-232 (63-00199) and an RS-449 (63-00192).

DDN Switch Settings

Table 5-24 lists the Plexus default switch setting for the DDN interface controller board.

Table 5-24. DDN Default Switch Settings

Switch	Function	Position
SW3-1	ADR17*	OFF
SW3-2	ADR16*	OFF
SW3-3	ADR15*	OFF
SW3-4	ADR14*	OFF
SW3-5	ADR13*	OFF
SW3-6	ADR12*	OFF
SW3-7	ADR11*	OFF
SW3-8	ADR10*	ON
SW2-1	ADRF*	OFF
SW2-2	ADRE*	OFF
SW2-3	ADRD*	OFF
SW2-4	ADRC*	OFF
SW2-5	ADRB*	OFF
SW2-6	ADRA*	OFF
SW2-7	ADR9*	OFF
SW2-8	ADR8*	OFF
SW1-1	ADR7*	ON
SW1-2	ADR6*	ON
SW1-3	ADR5*	OFF
SW1-4	ADR4*	ON

DDN Jumper Settings

Table 5-25 lists the Plexus default jumper settings for the DDN controller board while Table 5-26 lists the jumper settings for a serial I/O.

Table 5-25. DDN Default Jumper Settings

Jumper	Default	Function
JP1	In	EPR0M Setup
JP2	Open	
JP3	A to B	
JP4	A to B	
JP5	B to C	
JP10	A to B	Host access to 64k of shared RAM
JP11	A to B	Host access to 64k of shared RAM
JP12	Open	Disables maintenance diagnostics
JP13	A to B	Host uses 16-bit I/O addressing
JP14	A to B	Host inverts sense of ADR0*
JP15	A to B	Enables Host NMI interrupt for debug support
JP16	H to J	INT0*
JP17	H to J	INT0*
JP20	E to J	XACK* delay (312 nS)

Table 5-26. DDN Serial Interface Settings

Serial Port	Settings
RS-232	Install U11, U12 Remove U6 Jumper JP6 A-B JP7 A-G, JP7 B-G JP7 C-G, JP7 D-G JP7 E-G, JP7 F-G

DDN I/O Connector Plate

Table 5-27 lists the options available on the connector plate.

Table 5-27. DDN Comm Ports I/O Connector Plate

Opening	Connector
A	DB-9
B	DB-15 (Ethernet)
C,D,E	DB-25 (RS-232)
F,G	DB-37 (RS-449)

SNA Interface Communication Board

Plexus provides the hardware and software necessary to support an SNA interface. The SNA controller board is usually installed in slot eleven (11) and must be installed in a Multibus adapter board before installation in a P/90. An RS-232 (26-conductor) controller interface cable (63-00196) is required to connect the SNA controller board and the I/O panel.

SNA Jumper Settings

Table 5-28 lists the Plexus jumper settings for the SNA interface controller board.

Table 5-28. SNA Jumper Settings

Jumper	In/Open	Function
W1	Open	Serial I/F ground, channel A
W2	Open	Serial I/F multifunction, channel A
W3	In	Serial I/F RS-232C ground, channel A
W4	Open	Serial I/F RS-449 ground, channel A
W5	In	EPROM size select
W6	Open	EPROM size select
W7	In	64k or 256k RAM size select
W8	In	Bus Time Out enable
W9	In	No Byte Swap
W10	Open	Dual-port memory not mapped in Multibus memory space
W11	Open	ADRF bit compare
W12	Open	ADRE bit compare
W13	Open	Byte Swap
W14	Open	Enable BPRO out
W15	Open	Byte Swap
W16	In	Serial I/F RS-232C ground, channel B
W17	In	Enable BPRN in
W18	Open	Disable BPRN in
W19	Open	8289 arbiter, Any request
W20	Open	Serial I/F RS-449 ground, channel B
W21	Open	Serial I/F RS-232C ground, channel C
W22	In	256k & 512k EPROM select
W23	Open	64k & 128k EPROM select
W24	In	8289 arbiter, ground CBRQ
W25	Open	enable CBRQ out
W42	Open	I/O A-7 addr compare
W43	Open	I/O A-6 addr compare
W44	In	I/O A-5 addr compare
W45	Open	I/O A-4 addr compare
W46	In	Serial I/F ground, channel C
W47	In	Serial I/F RS-232C ground, channel D
W48	Open	Serial I/F ground, channel D
W49	Open	Serial I/F ground, channel C
W50	Open	Serial I/F ground, channel D

Jumper	In/Open	Function
W51	Open	Serial I/F ground, channel B
W52	Open	Serial I/F ground, channel B
W62	In	Enable I/O space Flag Byte
W63	Open	Enable Tri-state RS-449, channel C
W64	Open	Enable Tri-state RS-449, channel D
W65	Open	Enable Tri-state RS-449, channel A
W66	Open	Enable Tri-state RS-449, channel B
W67	In	TXC from DCE device, channel A
W68	Open	TXC from DCE device, channel B
W69	Open	TXC from DCE device, channel D
W70	Open	TXC from DCE device, channel C
W71	In	DMA address window select
W72	Open	DMA address window select
W73	Open	DMA address window select
W74	In	DMA address window select
W75	Open	DMA address window select
W76	In	DMA address window select
ADR-10	Open	Address compare bit 10
ADR-11	In	Address compare bit 11
ADR-12	Open	Address compare bit 12
ADR-13	Open	Address compare bit 13
ADR-14	Open	Address compare bit 14
ADR-15	Open	Address compare bit 15
ADR-16	Open	Address compare bit 16
ADR-17	Open	Address compare bit 17
I/O A-8	Open	I/O address compare bit 8
I/O A-9	Open	I/O address compare bit 9
I/O A-A	Open	I/O address compare bit A
I/O A-B	Open	I/O address compare bit B
I/O A-C	Open	I/O address compare bit C
I/O A-D	Open	I/O address compare bit D
I/O A-E	Open	I/O address compare bit E
I/O A-F	Open	I/O address compare bit F
INT-0	In	Interrupt bit 0
INT-1	Open	Interrupt bit 1
INT-2	Open	Interrupt bit 2
INT-3	Open	Interrupt bit 3
INT-4	Open	Interrupt bit 4
INT-5	Open	Interrupt bit 5
INT-6	Open	Interrupt bit 6

Jumper	In/Open	Function
INT-7	Open	Interrupt bit 7
OPT-0	Open	Optional jumper bit 0 (short self-test)
OPT-1	Open	Optional jumper bit 1
OPT-2	Open	Optional jumper bit 2
OPT-3	Open	Optional jumper bit 3

Comm Ports I/O Connector Plate

Table 5-29 lists the connector sizes supported by the comm ports connector plate.

Table 5-29. SNA Comm Ports I/O Connector Plate

Opening	Connector
A	DB-9
B	DB-15 (Ethernet)
C,D,E	DB-25 (RS-232)
F,G	DB-37 (RS-449)

The Ethernet Board

The Ethernet board is designed to run TCP/IP. Depending on your configuration, the Ethernet board can be installed in slot five (5) or six (6). The Ethernet board employs 47 jumpers to configure the board, J1 through J47. Figure 5-17 illustrates the Ethernet board. Table 5-30 lists the installed jumpers.




Figure 5-17. Ethernet Board Components

Table 5-30. Ethernet Board Jumper Settings

Jumper	Setting	Jumper	Setting
J1	Absent	J21	Absent
J2	Installed	J22	Absent
J3	Absent (see Table 5-31)	J23	Absent
J4	Boot from	J24	Installed
J5	Absent	J25	Absent
J6	Absent (Table 5-31)	J26	Absent
J7	Absent	J27-J34	Installed (All)
J8	Installed	J35	Installed
J9	Absent	J36	Absent
J10	Absent	J37	Absent
J11	Absent	J38	Absent
J12	Installed	J39	1 to 2
J13	Installed	J40	2 to 3
J14	Installed	J41	2 to 3
J15	Installed	J42	2 to 3
J16	Installed	J43	Installed
J17	Installed	J44	Absent
J18	Installed	J45	Absent
J19A	Installed	J46	Absent
J20	Absent	J47	Absent

Table 5-31. Ethernet Board J3 — J6 Jumper Settings

J3	J6	RAM
Absent	Absent	128K (factory setting)
Installed	Absent	Reserved
Absent	Installed	512K
Installed	Installed	Reserved

The SCSI Host Adapter Board

As many as four SCSI host adapter boards can be installed in your P/90. Figure 5-18 illustrates the SCSI Host Adapter board. Table 5-32 lists the jumper settings of the SCSI host adapter board while Table 5-33 lists the five rotary switch positions.




Figure 5-18. SCSI Host Adapter Board

Table 5-32. SCSI Host Adapter Jumper Settings

Jumper	Settings	Definition
LK1	SHORT between 2-3	Bus Arbitration
LK3	SHORT between 1-2	Bus Arbitration
LK5	SHORT between 1-2	Bus Arbitration
LK7	SHORT between 1-2	Bus Arbitration
LK2	SHORT between 1-3	Bus Arbitration
LK4	SHORT between 1-2	Bus Arbitration
LK6	SHORT between 1-2	Bus Arbitration
LK8	SHORT between 1-2	Bus Arbitration
LK9	OPEN	Address Modifiers
LK10	spare	Address Modifiers
LK11	OPEN	Address Modifiers
LK12	OPEN	Bus Request Level
LK13	OPEN	Bus Request Level
LK14	OPEN	Bus Request Level
LK15	SHORT	Bus Request Level
LK16	OPEN	Bus Hold Limit
LK17	SHORT	Bus Hold Limit
LK18	OPEN	Bus Hold Limit
LK19	SHORT between 1-2	Address Bus Width
LK20	OPEN	Terminator
LK21	SHORT between 1-2	Test Link
LK22	SHORT between 1-2, 4-6, 8-10, 12-13	SCSI ID and PROM size

Table 5-33. SCSI Host Adapter Switch Settings

Switch	Board 0	Board 1	Board 2	Board 3
SW1	2	2	2	2
SW2	0	0	0	0
SW3	0	1	2	3
SW4	0	0	0	0
SW5	0	0	0	0



INDEX

A, B, C

- adapter, description, 5-29
- arbiter jumpers, 5-20
- arbiter LEDs, 5-17
- arbiter switches, 5-14, 5-15, 5-16
- arbiter test points, 5-18, 5-19
- arrestors, 1-9
- backplane, 1-5, 4-2
- backplane, VCP, 5-26
- base address, 5-8
- battery, 2-6
- baud rates, 5-4
- bus arbiter jumpers, 5-20
- bus arbiter LEDs, 5-17
- bus arbiter switches, 5-14
- bus arbiter test points, 5-18, 5-19
- cable lengths, 1-14
- cable termination, 1-15
- cable wiring, 1-15
- cabling, 1-14
- capstan, 2-1, 2-5
- card cage, 5-1
- cartridge tape controller, 4-10, 4-12
- cartridge tape drive, cleaning, 2-1, 2-5
- circuit boards, 5-1
- clean system exterior, 2-8
- clean system fan filters, 2-2
- comm ports I/O connector plate, 5-31
- connectors, 1-10
- controller, 3-18
- cooling requirements, 1-13

D, E, F

- DB-25, 1-16, 1-17, 5-26
- DB-9, 1-15, 1-16, 5-26
- DDN I/O connector plate, 5-30
- DDN interface communication, 5-29
- DDN jumper settings, 5-30
- DDN switch settings, 5-29
- diagnostics, 5-4
- dimensions, 1-7
- disk controller, 4-10
- disk drive fault Lamps (LEDs), 4-14, 4-16
- disk drive, 4-13, 4-15, 4-17

electrostatic discharges, 1-11, 5-2
environmental requirements, 1-10
equipment, 2-1
Ethernet, 5-35
fan filter, 2-3
floor area requirements, 1-7

G, H, I

general considerations, 1-14
grounding, 1-9
host adapter, 1-5, 5-37
humidity, 1-11
indicators, 4-1
input current characteristics, 1-8

J, K, L

job processor diagnostics, 5-4
job processor jumper settings, 5-5
job processor LEDs, 5-5
job processor switch settings, 5-4
job processor test points, 5-6
job processor, 5-3
jumper setting, bus grant (VCP), 5-25
jumper setting, Ethernet, 5-36
lightning arrestors, 1-9
LINC I/O, description, 5-26

M, N, O

maintain 1/4-inch tape drive, 2-4
maintain hard disk drives, 2-8
memory error decode, 5-9
memory jumper settings, 5-12
memory LEDs, 5-12
memory switch settings, 5-8
memory test points, 5-12
memory, 5-7
Multibus adapter, 5-29
noise suppression, 1-9
135M-byte disk drive, 4-13
300M-byte Fujitsu disk drive, 4-15
300M-byte Maxtor disk drive, 4-17

P, Q, R

- P4, 1-17
- P4, description, 5-26
- power cords, 1-10
- power requirements, 1-8
- power supply adjustments, 4-18, 4-20
- power supply strapping, 4-18
- power supply, 4-18, 4-20
- processor jumper settings, 5-5
- processor LEDs, 5-5
- processor switch settings, 5-4
- processor test points, 5-6
- remove 1/4-inch tape drive, 3-10
- remove backplane jumper block, 3-22
- remove disk drive controller, 3-20, 3-37
- remove disk drive, 3-12, 3-35
- remove LINC I/O, 3-8
- remove media tray, 3-32
- remove power supply, 3-14, 3-39
- remove system exterior, 3-4, 3-30
- remove system front panel, 3-6, 3-30
- remove tape controller, 3-18
- remove VCP backplane card, 3-16
- replace system battery, 2-6

S, T, U

- SCSI host adapter, 5-37
- shutdown, 5-14
- SNA interface communication, 5-31
- SNA jumper settings, 5-32
- space requirements, 1-7
- static electricity, 5-2
- switch setting, shutdown delay timer, 5-14
- system overview, 1-1
- system, card cage, 5-1
- system, circuit boards, 5-1
- system, clock battery, 2-6
- system, slot assignment, 5-2
- tape head, 2-1, 2-5
- Telco, description, 5-26
- temperature, 1-11
- uninterruptable power supply, 1-20
- UPS, 1-20

V, W, X, Y, & Z

- VCP backplane card, 5-26
- VCP jumper settings, 5-26
- VCP LEDs, 5-24

VCP switch settings, 5-23
VMEbus arbiter, 5-13
VMEbus backplane, 1-19
VMEbus communication processor (VCP), 5-21
VMEbus electrical specifications, 1-20
voltage characteristics, 1-8
weight, 1-7