

Command Reference



Alteon OS™ 20.2

Layer 2-7 GbE Switch Module
for IBM @server BladeCenter

Part Number: 25K9199, October 2004

NORTEL
NETWORKS™

4655 Great America Parkway
Santa Clara, CA 95054
www.nortelnetworks.com
Reference: 215655-C

Copyright © 2004 Nortel Networks, Inc., 4655 Great America Parkway, Santa Clara, California, 95054, USA. All rights reserved. Part Number: 25K9199.

This document is protected by copyright and distributed under licenses restricting its use, copying, distribution, and decompilation. No part of this document may be reproduced in any form by any means without prior written authorization of Nortel Networks, Inc. Documentation is provided “as is” without warranty of any kind, either express or implied, including any kind of implied or express warranty of non-infringement or the implied warranties of merchantability or fitness for a particular purpose.

U.S. Government End Users: This document is provided with a “commercial item” as defined by FAR 2.101 (Oct. 1995) and contains “commercial technical data” and “commercial software documentation” as those terms are used in FAR 12.211-12.212 (Oct. 1995). Government End Users are authorized to use this documentation only in accordance with those rights and restrictions set forth herein, consistent with FAR 12.211- 12.212 (Oct. 1995), DFARS 227.7202 (JUN 1995) and DFARS 252.227-7015 (Nov. 1995).

Nortel Networks, Inc. reserves the right to change any products described herein at any time, and without notice. Nortel Networks, Inc. assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by Nortel Networks, Inc. The use and purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of Nortel Networks, Inc.

Originated in the USA.

Alteon OS, and Alteon are trademarks of Nortel Networks, Inc. in the United States and certain other countries. Cisco® and EtherChannel® are registered trademarks of Cisco Systems, Inc. in the United States and certain other countries. Any other trademarks appearing in this manual are owned by their respective companies.



Contents

Preface 13

- Who Should Use This Book 13
- How This Book Is Organized 13
- Typographic Conventions 15
- How to Get Help 16

Chapter 1: The Command Line Interface 17

- Connecting to the Switch 18
 - Management Module Setup 18
 - Factory-Default vs. MM assigned IP Addresses 18
 - Default Gateway 19
 - Configuring the Management Module for Switch Access 19
 - Connecting to the Switch via Telnet 21
 - Running Telnet 21
 - Using a BOOTP Server 22
 - Establishing an SSH Connection 22
 - Running SSH 23
- Accessing the Switch 24
- Setup Versus CLI 26
- Command Line History and Editing 26
- Idle Timeout 26

Chapter 2: First-Time Configuration 27

- Using the Setup Utility 27
 - Information Needed For Setup 27
 - Starting Setup When You Log In 28
 - Stopping and Restarting Setup Manually 29
 - Stopping Setup 29
 - Restarting Setup 29
 - Setup Part 1: Basic System Configuration 29

- Setup Part 2: Port Configuration 31
- Setup Part 3: VLANs 33
- Setup Part 4: IP Configuration 34
 - IP Interfaces 34
 - Default Gateways 35
 - IP Routing 36
- Setup Part 5: Final Steps 37
- Optional Setup for SNMP Support 38
- Optional Setup for Telnet Support 38
- Setting Passwords 39
 - Changing the Default Administrator Password 39
 - Changing the Default User Password 41
 - Changing the Default Layer 4 Administrator Password 42

Chapter 3: Menu Basics 45

- The Main Menu 45
- Menu Summary 46
- Global Commands 47
- Command Line History and Editing 49
- Command Line Interface Shortcuts 50
 - Command Stacking 50
 - Command Abbreviation 50
 - Tab Completion 50

Chapter 4: The Information Menu 51

- Information Menu 51
- System Information 53
- General System Information 54
- Show Last 30 Syslog Messages 55
- FDB Information Menu 57
 - Show All FDB Information 59
 - Clearing Entries from the Forwarding Database 59
- Link Aggregation Control Protocol menu 60
- Link Aggregation Control Protocol 60
- Spanning Tree Information 62
- Trunk Group Information 64
- VLAN Information 65
- IP Routing Information 68

Show All IP Route Information	69
ARP Information	70
Show All ARP Entry Information	71
ARP Address List Information	72
BGP Information Menu	73
BGP Peer information	73
BGP Summary information	74
Dump BGP Information	74
OSPF Information	75
OSPF General Information	76
OSPF Interface Information	77
OSPF Database Information	78
OSPF Information Route Codes	79
IGMP Multicast Group Information	80
IGMP Multicast Router Port Information	80
IGMP Multicast Router Port Information	81
IP Information	82
VRRP Information	82
SLB Information	84
Session Table Information	85
Samples of Session Dumps for Different Applications	87
Session dump information in Alteon OS	88
Show All Layer 4 Information	90
Link Status Information	91
Port Information	92
Information Dump	93

Chapter 5: The Statistics Menu 95

Statistics Menu	95
Port Statistics Menu	97
Bridging Statistics	98
Ethernet Statistics	99
Interface Statistics	102
Interface Protocol Statistics	104
Link Statistics	105
RMON Statistics	105
FDB Statistics	109
LACP Statistics	110

OSPF Statistics Menu	112
OSPF Global Statistics	113
IP Statistics	117
Route Statistics	119
ARP statistics	120
VRRP Statistics	121
DNS Statistics	122
ICMP Statistics	122
IGMP Statistics	124
Interface Statistics	125
TCP Statistics	127
UDP Statistics	129
Load Balancing Statistics Menu	130
Server Load Balancing SP statistics Menu	132
SP Real Server Statistics	133
Real Server SLB Statistics	135
Per Service Octet Counters	135
Real Server Group Statistics	136
Virtual Server SLB Statistics	137
Filter SLB Statistics	137
SLB Layer7 Statistics Menu	138
Layer7 Redirection Statistics	138
Layer 7 SLB String Statistics	139
Layer 7 SLB Maintenance Statistics	140
SLB Secure Socket Layer Statistics	142
File Transfer Protocol SLB and Filter Statistics Menu	143
Active FTP SLB Parsing and Filter Statistics	143
Passive FTP SLB Parsing Statistics	144
FTP SLB Maintenance Statistics	144
FTP SLB Statistics Dump	145
RTSP SLB Statistics	146
DNS SLB Statistics	146
WAP SLB Statistics	148
SLB TCP Rate Limiting Statistics	150
SLB Maintenance Statistics	150
Clearing the SLB Statistics	152
Management Processor Statistics	153
MP Packet Statistics	154

TCP Statistics	155
UCB Statistics	155
MP-Specific SFD Statistics	156
CPU Statistics	156
SP Specific Statistics Menu	156
SNMP Statistics	158
NTP Statistics	161
Statistics Dump	162

Chapter 6: The Configuration Menu 163

Configuration Menu	163
Viewing, Applying, and Saving Changes	164
Viewing Pending Changes	165
Applying Pending Changes	165
Saving the Configuration	165
System Configuration	167
System Host Log Configuration	169
SSH Server Configuration Menu	170
RADIUS Server Configuration	171
TACACS+ Server Configuration Menu	172
NTP Server Configuration	174
System SNMP Menu	176
System Access Menu	178
User Access Control Configuration	179
Port Configuration	181
Port Link Configuration	183
Temporarily Disabling a Port	184
Port Mirroring Menu	184
Port-Mirroring Menu	185
Layer 2 Menu	186
Spanning Tree Configuration	188
Bridge Spanning Tree Configuration	189
Spanning Tree Port Configuration	191
Trunk Configuration	192
IP Trunk Hash menu	193
Layer 2 IP Trunk Hash menu	193
Layer 3 IP Trunk Hash menu	194
Link Aggregation Control Protocol menu	196

LACP Port menu	196
VLAN Configuration	198
Layer 3 Menu	200
IP Interface Configuration	202
Default Gateway Configuration	203
Default Gateway Metrics	204
IP Static Route Configuration	205
IP Forwarding Configuration	206
Local Network Route Caching Definition	206
Defining IP Address Ranges for the Local Route Cache	207
Network Filter Configuration	208
Routing Map Configuration	209
IP Access List Configuration Menu	211
Autonomous System Filter Path	212
Routing Information Protocol Configuration	213
Open Shortest Path First Configuration	215
Area Index Configuration Menu	216
OSPF Summary Range Configuration Menu	218
OSPF Interface Configuration Menu	219
OSPF Virtual Link Configuration Menu	220
OSPF Host Entry Configuration Menu	222
OSPF Route Redistribution Configuration Menu.	223
OSPF MD5 Key Configuration Menu	224
Border Gateway Protocol Configuration	224
BGP Peer Configuration Menu	226
BGP Redistribution Configuration Menu	228
BGP Aggregation Configuration	229
IGMP Configuration	230
IGMP Snooping Configuration	231
IGMP Static Multicast Router Configuration	232
IP Port Configuration	233
Domain Name System Configuration	234
Bootstrap Protocol Relay Configuration	235
VRRP Configuration	236
Virtual Router Configuration	237
Virtual Router Priority Tracking Configuration	240
Virtual Router Group Configuration	242
Virtual Router Group Priority Tracking Configuration	244

VRRP Interface Configuration	246
VRRP Tracking Configuration	247
Default Gateway Metrics	248
Setup	249
Dump	249
Saving the Active Switch Configuration	250
Restoring the Active Switch Configuration	250
Chapter 7: The SLB Configuration Menu	251
SLB Configuration	251
Filtering and Layer 4 (Server Load Balancing)	254
Real Server SLB Configuration	254
Real Server Layer 7 Configuration	258
Real Server Group SLB Configuration	259
Server Load Balancing Metrics	262
Virtual Server SLB Configuration	264
Virtual Server Service Configuration	266
Virtual Server RTSP Configuration	270
Cookie-Based Persistence	271
SLB Filter Configuration	272
Defining IP Address Ranges for Filters	276
Advanced Filter Configuration	277
Advanced Filter TCP Configuration	279
IP Advanced Menu	280
Layer 7 Advanced Menu	281
ICMP Message Types	282
Port SLB Configuration	283
Layer 7 SLB Resource Definition Menu	285
Web Cache Redirection Configuration	286
Server Load Balance Resource Configuration Menu	287
WAP Configuration	288
Synchronize Peer Switch Configuration	289
Peer Switch Configuration	290
Advanced Layer 4 Configuration	291
SYN Attack Detection Configuration	293
Scriptable Health Checks Configuration	295
WAP Health Check Configuration	296
Proxy IP Address Configuration Menu	297

SLB Peer Proxy IP Address Configuration Menu 298

Chapter 8: The Operations Menu 299

- Operations Menu 299
- Operations-Level Port Options 301
- Operations-Level SLB Options 302
- Operations-Level VRRP Options. 303
- Operations-Level IP Options 303
 - Operations-Level BGP Options 304

Chapter 9: The Boot Options Menu 305

- Boot Menu 305
- Updating the Switch Software Image 306
 - Downloading New Software to Your Switch 306
 - Selecting a Software Image to Run 307
 - Uploading a Software Image from Your Switch 308
- Selecting a Configuration Block 309
- Resetting the Switch 310

Chapter 10: The Maintenance Menu 311

- Maintenance Menu 311
- System Maintenance Options 313
- Forwarding Database Options 313
- Debugging Options 315
- ARP Cache Options 316
- IP Route Manipulation 317
- IGMP Configuration 319
- IGMP Multicast Router Port Information 320
- IGMP Multicast Router Port Information 321
- Uuencode Flash Dump 321
- TFTP System Dump Put 322
- Clearing Dump Information 322
- Panic Command 323
- Unscheduled System Dumps 323

Appendix A: Alteon OS Syslog Messages 325

LOG_WARNING 325

LOG_ALERT 326

LOG_CRIT 326

LOG_ERR 327

LOG_NOTICE 333

LOG_INFO 335

Appendix B: Alteon OS SNMP Agent 337

Working with Switch Images and Configuration Files 340

 Loading a new switch image 341

 Loading a saved switch configuration 341

 Saving the switch configuration 342

 Saving a switch dump 342

 Saving a switch image 343

Glossary 345

Index 349



Preface

The *Alteon OS 20.2 Command Reference* describes how to configure and use the Alteon OS software with your GbE Switch Module.

For documentation on installing the switches physically, see the *Installation Guide* for your GbE Switch Module.

Who Should Use This Book

This *Command Reference* is intended for network installers and system administrators engaged in configuring and maintaining a network. The administrator should be familiar with Ethernet concepts, IP addressing, the IEEE 802.1d Spanning Tree Protocol, and SNMP configuration parameters.

How This Book Is Organized

Chapter 1 “The Command Line Interface,” describes how to connect to the switch and access the information and configuration menus.

Chapter 2 “First-Time Configuration,” describes how to use the Setup utility for initial switch configuration and how to change the system passwords.

Chapter 3 “Menu Basics,” provides an overview of the menu system, including a menu map, global commands, and menu shortcuts.

Chapter 4 “The Information Menu,” shows how to view switch configuration parameters.

Chapter 5 “The Statistics Menu,” shows how to view switch performance statistics.

Chapter 6 “The Configuration Menu,” shows how to configure switch system parameters, ports, VLANs, Spanning Tree Protocol, SNMP, Port Mirroring, IP Routing, Port Trunking, and more.

Chapter 7 “The SLB Configuration Menu,” shows how to configure Server Load Balancing, Filtering, Global Server Load Balancing, and more.

Chapter 8 “The Operations Menu,” shows how to use commands which affect switch performance immediately, but do not alter permanent switch configurations (such as temporarily disabling ports). The menu describes how to activate or deactivate optional software features.

Chapter 9 “The Boot Options Menu,” describes the use of the primary and alternate switch images, how to load a new software image, and how to reset the software to factory defaults.

Chapter 10 “The Maintenance Menu,” shows how to generate and access a dump of critical switch state information, how to clear it, and how to clear part or all of the forwarding database.

Appendix A, “Alteon OS Syslog Messages,” shows a listing of syslog messages.

Appendix B, “Alteon OS SNMP Agent,” lists the Management Interface Bases (MIBs) supported in the switch software.

“Glossary” includes definitions of terminology used throughout the book.

“Index” includes pointers to the description of the key words used throughout the book.

Typographic Conventions

The following table describes the typographic styles used in this book.

Table 1 Typographic Conventions

Typeface or Symbol	Meaning	Example
AaBbCc123	This type is used for names of commands, files, and directories used within the text. It also depicts on-screen computer output and prompts.	View the <code>readme.txt</code> file. Main#
AaBbCc123	This bold type appears in command examples. It shows text that must be typed in exactly as shown.	Main# sys
<AaBbCc123>	This italicized type appears in command examples as a parameter placeholder. Replace the indicated text with the appropriate real name or value when using the command. Do not type the brackets. This also shows book titles, special terms, or words to be emphasized.	To establish a Telnet session, enter: host# telnet <IP address> Read your <i>User's Guide</i> thoroughly.
[]	Command items shown inside brackets are optional and can be used or excluded as the situation demands. Do not type the brackets.	host# ls [-a]

How to Get Help

If you need help, service, or technical assistance, see the “Getting help and technical assistance” appendix in the Nortel Networks *Layer 2-7 GbE Switch Module for IBM eServer BladeCenter Installation Guide* on the IBM *BladeCenter Documentation CD*.



CHAPTER 1

The Command Line Interface

Your GbE Switch Module is ready to perform basic switching functions right out of the box. Some of the more advanced features, however, require some administrative configuration before they can be used effectively.

The extensive Alteon OS switching software included in your switch provides a variety of options for accessing and configuring the switch:

- A built-in, text-based command line interface and menu system for access via a Telnet session
- SNMP support for access through network management software such as IBM Director or HP OpenView
- Alteon OS Browser-Based Interface (BBI)

The command line interface is the most direct method for collecting switch information and performing switch configuration. Using a basic terminal, you are presented with a hierarchy of menus that enable you to view information and statistics about the switch, and to perform any necessary configuration.

This chapter explains how to access the Command Line Interface (CLI) for the switch.

Connecting to the Switch

You can access the command line interface in any one of the following ways:

- Using a Telnet via the management module
- Using a Telnet connection over the network
- Using a SSH connection to securely log into another computer over a network

Management Module Setup

The BladeCenter GbE Switch Module is an integral subsystem within the overall BladeCenter system. The BladeCenter chassis includes a management module (MM) as the central element for overall chassis management and control.

You can use the 100-Mbps Ethernet port on the Management Module to configure and manage the GbE Switch Module. The GbE Switch Module communicates with the management module through port MGT1 and port MGT2, which you can access through the 100 Mbps Ethernet port on the management module. The factory default settings will *only* permit management and control access to the switch module through the 10/100 Mbps Ethernet port on the management module. You can use the four external 10/100/1000 Mbps Ethernet ports on the switch module for management and control of the switch by selecting this mode as an option through the management module configuration utility program (see the applicable *BladeCenter Installation and User's Guide* publications on the IBM *BladeCenter Documentation* CD for more information).

Factory-Default vs. MM assigned IP Addresses

Each GbE Switch Module must be assigned its own Internet Protocol address, which is used for communication with an SNMP network manager or other transmission control protocol/Internet Protocol (TCP/IP) applications (for example, BootP or TFTP). The factory-default IP address is 10.90.90.9x, where x corresponds to the number of the bay into which the GbE Switch Module is installed. For additional information, see the *Installation Guide*). The management module assigns an IP address of 192.168.70.1xx, where xx corresponds to the number of the bay into which each GbE Switch Module is installed, as shown in [Table 1-1](#):

Table 1-1 GbE Switch Module IP addresses, based on switch-module bay numbers

Bay number	Factory-default IP address	IP address assigned by MM
Bay 1	10.90.90.91	192.168.70.127
Bay 2	10.90.90.92	192.168.70.128
Bay 3	10.90.90.94	192.168.70.129
Bay 4	10.90.90.97	192.168.70.130

Default Gateway

The default Gateway IP address determines where packets with a destination address outside the current subnet should be sent. Usually, the default Gateway is a router or host acting as an IP gateway to handle connections to other subnets of other TCP/IP networks. If you want to access the GbE Switch Module from outside your local network, use the management module to assign a default Gateway address to the GbE Switch Module. Choose **I/O Module Tasks > Management** from the navigation pane on the left, and enter the default Gateway IP address (for example, 192.168.70.125). Click **Save**.

Configuring the Management Module for Switch Access

Complete the following initial configuration steps:

1. **Connect the Ethernet port of the management module to a 10/100 Mbps network (with access to a management station) or directly to a management station.**
2. **Access and log on to the management module, as described in the *BladeCenter Management Module User's Guide* on the *IBM BladeCenter Documentation CD*. The management module provides the appropriate IP addresses for network access (see the applicable *BladeCenter Installation and User's Guide* publications on the *IBM BladeCenter Documentation CD* for more information).**

3. Select **Management on the I/O Module Tasks** menu on the left side of the **BladeCenter Management Module** window. See [Figure 1](#).




Figure 1 Switch management on the BladeCenter management module

4. You can use the default IP addresses provided by the management module, or you can assign a new IP address to the switch module through the management module. You can assign this IP address through one of the following methods:
 - Manually through the BladeCenter management module.
 - Automatically through the IBM Director Configuration Wizard (when it becomes available)

NOTE – If you change the IP address of the GbE Switch Module, make sure that the switch module and the management module both reside on the same subnet. Both management module ports (Ethernet 0 and Ethernet 1) must reside on the same subnet.

5. Enable the following features in the management module (Switch Tasks > Management > Advanced Management):

- External Ports
- External management over all ports (required if you want to access the management network through the four external ports on the GbE Switch Module)

The default value is Disabled for both features. If these features are not already enabled, change the value to **Enabled**, then **Save**.

NOTE – In the switch management Advanced Setup, enable “Preserve new IP configuration on all switch resets,” to retain the switch’s IP interface when you restore factory defaults. This setting preserves the management port’s IP address in the management module’s memory, so you maintain connectivity to the management module after a reset.

You can now start a Telnet session, Browser-Based Interface (Web) session, or a Secure Shell session to the GbE Switch Module.

Connecting to the Switch via Telnet

Use the management module to access the GbE Switch Module through Telnet. Choose **I/O Module Tasks > Management** from the navigation pane on the left. Select a bay number and click **Advanced Management > Start Telnet/Web Session > Start Telnet Session**. A Telnet window opens a connection to the Switch Module.

Once that you have configured the GbE Switch Module with an IP address and gateway, you can access the switch from any workstation connected to the management network. Telnet access provides the same options for user and administrator access as those available through the management module, minus certain Telnet and management commands.

To establish a Telnet connection with the switch, run the Telnet program on your workstation and issue the Telnet command, followed by the switch IP address:

```
telnet <switch IP address>
```

Running Telnet

Once the IP parameters on the GbE Switch Module are configured, you can access the CLI using a Telnet connection. From the management module, you can establish a Telnet connection with the switch.

You will then be prompted to enter a password as explained on [page 22](#).

Using a BOOTP Server

If you have a BOOTP server on your network, add the MAC address of the switch to the BOOTP configuration file located on the BOOTP server. The MAC address can be found on a small white label on the back panel of the switch. The MAC address can also be found in the System Information menu (see “System Information” on [page 54](#)).

Establishing an SSH Connection

Although a remote network administrator can manage the configuration of a GbE Switch Module via Telnet, this method does not provide a secure connection. The SSH (Secure Shell) protocol enables you to securely log into another computer over a network to execute commands remotely. As a secure alternative to using Telnet to manage switch configuration, SSH ensures that all data sent over the network is encrypted and secure.

The switch can do only one session of key/cipher generation at a time. Thus, a SSH/SCP client will not be able to login if the switch is doing key generation at that time or if another client has just logged in before this client. Similarly, the system will fail to do the key generation if a SSH/SCP client is logging in at that time.

The supported SSH encryption and authentication methods are listed below.

- Server Host Authentication: Client RSA-authenticates the switch in the beginning of every connection.
- Key Exchange: RSA
- Encryption: 3DES-CBC, DES
- User Authentication: Local password authentication, Radius

The following SSH clients have been tested:

- SSH 1.2.23 and SSH 1.2.27 for Linux (freeware)
- SecureCRT 3.0.2 and SecureCRT 3.0.3 (Van Dyke Technologies, Inc.)
- F-Secure SSH 1.1 for Windows (Data Fellows)

NOTE – The Alteon OS implementation of SSH is based on SSH version 1.5 and supports SSH-1.5-1.X.XX. SSH clients of other versions (especially Version 2) are not supported.

Running SSH

Once the IP parameters are configured and the SSH service is turned on the GbE Switch Module, you can access the command line interface using an SSH connection. The default setting for SSH access is disabled.

To establish an SSH connection with the switch, run the SSH program on your workstation by issuing the SSH command, followed by the switch IP address:

```
>> # ssh <switch IP address>
```

or, if SecurID authentication is required, use the following command:

```
>> # ssh -1 ace <switch IP address>
```

You will then be prompted to enter your user name and password.

Accessing the Switch

To enable better switch management and user accountability, seven levels or *classes* of user access have been implemented on the GbE Switch Module. Levels of access to CLI, Web management functions, and screens increase as needed to perform various switch management tasks. Conceptually, access classes are defined as follows:

- User interaction with the switch is completely passive—nothing can be changed on the GbE Switch Module. Users may display information that has no security or privacy implications, such as switch statistics and current operational state information.
- Operators can only effect temporary changes on the GbE Switch Module. These changes will be lost when the switch is rebooted/reset. Operators have access to the switch management features used for daily switch operations. Because any changes an operator makes are undone by a reset of the switch, operators cannot severely impact switch operation.
- Administrators are the only ones that may make permanent changes to the switch configuration—changes that are persistent across a reboot/reset of the switch. Administrators can access switch functions to configure and troubleshoot problems on the GbE Switch Module. Because administrators can also make temporary (operator-level) changes as well, they must be aware of the interactions between temporary and permanent changes.

Access to switch functions is controlled through the use of unique surnames and passwords. Once you are connected to the switch via local Telnet, remote Telnet, or SSH, you are prompted to enter a password. The default user names/password for each access level are listed in the following table.

NOTE – It is recommended that you change default switch passwords after initial configuration and as regularly as required under your network security policies. For more information, see [“Setting Passwords” on page 39](#).

Table 1-2 User Access Levels

User Account	Description and Tasks Performed	Password
User	The User has no direct responsibility for switch management. He or she can view all switch status information and statistics, but cannot make any configuration changes to the switch.	user

Table 1-2 User Access Levels

User Account	Description and Tasks Performed	Password
SLB Operator	The SLB Operator manages Web servers and other Internet services and their loads. In addition to being able to view all switch information and statistics, the SLB Operator can enable/disable servers using the Server Load Balancing operation menu.	slboper
Layer 4 Operator	The Layer 4 Operator manages traffic on the lines leading to the shared Internet services. This user currently has the same access level as the SLB operator. and the access level is reserved for future use, to provide access to operational commands for operators managing traffic on the line leading to the shared Internet services.	l4oper
Operator	The Operator manages all functions of the switch. In addition to SLB Operator functions, the Operator can reset ports or the entire switch.	oper
SLB Administrator	The SLB Administrator configures and manages Web servers and other Internet services and their loads. In addition to SLB Operator functions, the SLB Administrator can configure parameters on the Server Load Balancing menus, with the exception of not being able to configure filters or bandwidth management.	slbadmin
Layer 4 Administrator	The Layer 4 Administrator configures and manages traffic on the lines leading to the shared Internet services. In addition to SLB Administrator functions, the Layer 4 Administrator can configure all parameters on the Server Load Balancing menus, including filters and bandwidth management.	l4admin
Administrator	The superuser Administrator has complete access to all menus, information, and configuration commands on the GbE Switch Module, including the ability to change both the user and administrator passwords.	admin

NOTE – With the exception of the “admin” user, access to each user level can be disabled by setting the password to an empty value. All user levels below “admin” will (by default) be initially disabled (empty password) until they are enabled by the “admin” user. This is done in order to avoid inadvertently leaving the switch open to unauthorized users.

Setup Versus CLI

Once the administrator password is verified, you are given complete access to the switch. If the switch is still set to its factory default configuration, the system will ask whether you wish to run Setup (see [Chapter 2, “First-Time Configuration”](#)), a utility designed to help you through the first-time configuration process. If the switch has already been configured, the Main Menu of the CLI is displayed instead.

The following table shows the Main Menu with administrator privileges.

[Main Menu]	
info	- Information Menu
stats	- Statistics Menu
cfg	- Configuration Menu
oper	- Operations Command Menu
boot	- Boot Options Menu
maint	- Maintenance Menu
diff	- Show pending config changes [global command]
apply	- Apply pending config changes [global command]
save	- Save updated config to FLASH [global command]
revert	- Revert pending or applied changes [global command]
exit	- Exit [global command, always available]

NOTE – If you are accessing a user account or Layer 4 administrator account, some menu options will not be available.

Command Line History and Editing

For a description of global commands, shortcuts, and command line editing functions, see [“Menu Basics” on page 45.](#)

Idle Timeout

By default, the switch will disconnect your Telnet session after five minutes of inactivity. This function is controlled by the idle timeout parameter, which can be set from 1 to 60 minutes. For information on changing this parameter, see [“System Configuration” on page 167.](#)



CHAPTER 2

First-Time Configuration

To help with the initial process of configuring your switch, the Alteon OS software includes a Setup utility. The Setup utility prompts you step-by-step to enter all the necessary information for basic configuration of the switch. This chapter describes how to use the Setup utility and how to change system passwords. Before you run Setup, you must first connect to the switch (see [Chapter 1, “Connecting to the Switch”](#)).

Using the Setup Utility

Whenever you log in as the system administrator under the factory default configuration, you are asked whether you wish to run the Setup utility. Setup can also be activated manually from the command line interface any time after login.

Information Needed For Setup

Setup requests the following information:

- Basic system information
 - Date & time
 - Whether to use BOOTP or not
 - Whether to use Spanning Tree Group or not
- Optional configuration for each port
 - Speed, duplex, flow control, and negotiation mode (as appropriate)
 - Whether to use VLAN tagging or not (as appropriate)
- Optional configuration for each VLAN
 - Name of VLAN
 - Which ports are included in the VLAN

- Optional configuration of IP parameters
 - IP address, subnet mask, and VLAN for each IP interface
 - IP addresses for up to four default gateways
 - Destination, subnet mask, and gateway IP address for each IP static route
 - Whether IP forwarding is enabled or not
 - Whether the RIP supply is enabled or not

Starting Setup When You Log In

The Setup prompt appears automatically whenever you login as the system administrator under the factory default settings.

1. Connect to the switch.

After connecting, the login prompt will appear as shown below.

```
Enter Password:
```

2. Enter `admin` as the default administrator password.

If the factory default configuration is detected, the system prompts:

```
Connected to GbE Switch Module
18:44:05 Wed Jan 3, 2004

The switch is booted with factory default configuration.
To ease the configuration of the switch, a "Set Up" facility which
will prompt you with those configuration items that are essential to
the operation of the switch is provided.
Would you like to run "Set Up" to configure the switch? [y/n]:
```

NOTE – If the default `admin` login is unsuccessful, or if the administrator Main Menu appears instead, the system configuration has probably been changed from the factory default settings. If you are certain that you need to return the switch to its factory default settings, see [“Selecting a Configuration Block”](#) on page 309.

3. Enter `y` to begin the initial configuration of the switch, or `n` to bypass the Setup facility.

Stopping and Restarting Setup Manually

Stopping Setup

To abort the Setup utility, press <Ctrl-C> during any Setup question. When you abort Setup, the system will prompt:

```
Would you like to run from top again? [y/n]
```

Enter **n** to abort Setup, or **y** to restart the Setup program at the beginning.

Restarting Setup

You can restart the Setup utility manually at any time by entering the following command at the administrator prompt:

```
# /cfg/setup
```

Setup Part 1: Basic System Configuration

When Setup is started, the system prompts:

```
"Set Up" will walk you through the configuration of
System Date and Time, BOOTP, Spanning Tree, Port Speed/Mode,
VLANs, and IP interfaces. [type Ctrl-C to abort "Set Up"]
-----
Will you be configuring VLANs? [y/n]
```

- 1. Enter **y** if you will be configuring VLANs. Otherwise enter **n**.**

If you decide not to configure VLANs during this session, you can configure them later using the configuration menus, or by restarting the Setup facility. For more information on configuring VLANs, see the *Alteon OS 20.2 Application Guide*.

Next, the Setup utility prompts you to input basic system information.

- 2. Enter the year of the current date at the prompt:**

```
Enter year [2004] :
```

Enter the last two digits of the year as a number from 00 to 99. "00" is considered 2000. To keep the current year, press <Enter>.

NOTE – When the GbE Switch Module is reset, the date and time revert to default values. Use `/cfg/sys/date` and `/cfg/sys/time` to reenter the current date and time.

The system displays the date and time settings:

```
System clock set to 18:55:36 Wed Jan 3, 2004.
```

3. Enter the month of the current system date at the prompt:

```
System Date:  
Enter month [1]:
```

Enter the month as a number from 1 to 12. To keep the current month, press <Enter>.

4. Enter the day of the current date at the prompt:

```
Enter day [3]:
```

Enter the date as a number from 1 to 31. To keep the current day, press <Enter>.

5. Enter the hour of the current system time at the prompt:

```
System Time:  
Enter hour in 24-hour format [18]:
```

Enter the hour as a number from 00 to 23. To keep the current hour, press <Enter>.

6. Enter the minute of the current time at the prompt:

```
Enter minutes [55]:
```

Enter the minute as a number from 00 to 59. To keep the current minute, press <Enter>.

7. Enter the seconds of the current time at the prompt:

```
Enter seconds [37]:
```

Enter the seconds as a number from 00 to 59. To keep the current second, press <Enter>.

The system displays the date and time settings:

```
System clock set to 8:55:36 Wed Jan 3, 2004.
```

8. Enable or disable the use of BOOTP at the prompt:

```

BootP Option:
Current BOOTP:  disabled
Enter new BOOTP  [d/e] :

```

If available on your network, a BOOTP server can supply the switch with IP parameters so that you do not have to enter them manually. BOOTP must be disabled however, before the system will prompt for IP parameters.

Enter **d** to disable the use of BOOTP, or enter **e** to enable the use of BOOTP. To keep the current setting, press <Enter>.

9. Turn Spanning Tree Protocol on or off at the prompt:

```

Spanning Tree:
Current Spanning Tree Group 1 setting: ON
Turn Spanning Tree Group 1 OFF? [y/n]

```

Enter **y** to turn off Spanning Tree, or enter **n** to leave Spanning Tree on.

Setup Part 2: Port Configuration

NOTE – When configuring port options for your switch, some of the prompts and options may be different.

1. Select the port to configure, or skip port configuration at the prompt:

```

Port Config:
Enter port alias or port number (INT1-14, MGT1-2, EXT1-4) :

```

NOTE – The sample screens that appear in this document might differ slightly from the screens displayed by your system. Screen content varies based on the type of BladeCenter unit that you are using and the firmware versions and options that are installed.

If you wish to change settings for individual ports, enter the number of the port you wish to configure. To skip port configuration, press <Enter> without specifying any port and go to [“Setup Part 3: VLANs” on page 33](#).

2. Configure Gigabit Ethernet port flow parameters.

If you selected a port that has a Gigabit Ethernet connector, the system prompts:

```
Gig Link Configuration:
Port Flow Control:
Current Port EXT1 flow control setting:      both
Enter new value ["rx"/"tx"/"both"/"none"]:
```

Enter **rx** to enable receive flow control, **tx** for transmit flow control, **both** to enable both, or **none** to turn flow control off for the port. To keep the current setting, press <Enter>.

3. Configure Gigabit Ethernet port autonegotiation mode.

If you selected a port that has a Gigabit Ethernet connector, the system prompts:

```
Port Auto Negotiation:
Current Port EXT1 autonegotiation:          on
Enter new value ["on"/"off"]:
```

Enter **on** to enable port autonegotiation, **off** to disable it, or press <Enter> to keep the current setting.

4. If configuring VLANs, enable or disable VLAN tagging for the port.

If you have selected to configure VLANs back in Part 1, the system prompts:

```
Port VLAN tagging config (tagged port can be a member of multiple VLANs)
Current TAG support:                      disabled
Enter new TAG support [d/e]:
```

Enter **d** to disable VLAN tagging for the port or enter **e** to enable VLAN tagging for the port. To keep the current setting, press <Enter>.

5. The system prompts you to configure the next port:

```
Enter port alias or port number (INT1-14, MGT1-2, EXT1-4):
```

When you are through configuring ports, press <Enter> without specifying any port. Otherwise, repeat the steps in this section.

Setup Part 3: VLANs

If you chose to skip VLANs configuration back in Part 1, skip to [“Setup Part 4: IP Configuration”](#) on page 34.

1. Select the VLAN to configure, or skip VLAN configuration at the prompt:

```
VLAN Config:
Enter VLAN number from 2 to 4095, NULL at end:
```

If you wish to change settings for individual VLANs, enter the number of the VLAN you wish to configure. To skip VLAN configuration, press <Enter> without typing a VLAN number and go to [“Setup Part 4: IP Configuration”](#) on page 34.

2. Enter the new VLAN name at the prompt:

```
VLAN is newly created.
Pending new VLAN name: VLAN 2
Enter new VLAN name:
```

Entering a new VLAN name is optional. To use the pending new VLAN name, press <Enter>.

3. Configure jumbo frame support for the VLAN:

```
VLAN Jumbo Frame Support:
Current jumbo frame support: disabled
Enter new jumbo frame support [d/e]:
```

4. Enter the VLAN port numbers:

```
Define Ports in VLAN:
Current VLAN 2: empty
Enter ports one per line, NULL at end:
```

Enter each port, by port number or port alias, and confirm placement of the port into this VLAN. When you are finished adding ports to this VLAN, press <Enter> without specifying any port.

5. Configure Spanning Tree Group membership for the VLAN:

```
Spanning Tree Group membership:
Enter new Spanning Tree Group index [1-16]:
```

6. The system prompts you to configure the next VLAN:

```
VLAN Config:
Enter VLAN number from 2 to 4095, NULL at end:
```

Repeat the steps in this section until all VLANs have been configured. When all VLANs have been configured, press <Enter> without specifying any VLAN.

Setup Part 4: IP Configuration

The system prompts for IP parameters.

IP Interfaces

IP interfaces are used for defining subnets to which the switch belongs.

Up to 128 IP interfaces can be configured on the GbE Switch Module. The IP address assigned to each IP interface provide the switch with an IP presence on your network. No two IP interfaces can be on the same IP subnet. The interfaces can be used for connecting to the switch for remote configuration, and for routing between subnets and VLANs (if used).

1. Select the IP interface to configure, or skip interface configuration at the prompt:

```
IP Config:

IP interfaces:
Enter interface number: (1-128)
```

If you wish to configure individual IP interfaces, enter the number of the IP interface you wish to configure. To skip IP interface configuration, press <Enter> without typing an interface number and go to [“Default Gateways” on page 35](#).

NOTE – Interface 128 is reserved for switch management. If you change the IP address of IF 128, you can lose the connection to the management module. Use the management module to change the IP address of the Gbe Switch Module.

2. For the specified IP interface, enter the IP address in dotted decimal notation:

```
Current IP address:    0.0.0.0
Enter new IP address:
```

To keep the current setting, press <Enter>.

3. At the prompt, enter the IP subnet mask in dotted decimal notation:

```
Current subnet mask:          0.0.0.0
Enter new subnet mask:
```

To keep the current setting, press <Enter>.

4. If configuring VLANs, specify a VLAN for the interface.

This prompt appears if you selected to configure VLANs back in Part 1:

```
Current VLAN:      1
Enter new VLAN:
```

Enter the number for the VLAN to which the interface belongs, or press <Enter> without specifying a VLAN number to accept the current setting.

5. At the prompt, enter *y* to enable the IP interface, or *n* to leave it disabled:

```
Enable IP interface? [y/n]
```

6. The system prompts you to configure another interface:

```
Enter interface number: (1-128)
```

Repeat the steps in this section until all IP interfaces have been configured. When all interfaces have been configured, press <Enter> without specifying any interface number.

Default Gateways

1. At the prompt, select a default gateway for configuration, or skip default gateway configuration:

```
IP default gateways:
Enter default gateway number: (1-132)
```

Enter the number for the default gateway to be configured. To skip default gateway configuration, press <Enter> without typing a gateway number and go to [“IP Routing” on page 36](#).

2. At the prompt, enter the IP address for the selected default gateway:

```
Current IP address:      0.0.0.0
Enter new IP address:
```

Enter the IP address in dotted decimal notation, or press <Enter> without specifying an address to accept the current setting.

3. At the prompt, enter *y* to enable the default gateway, or *n* to leave it disabled:

```
Enable default gateway? [y/n]
```

4. The system prompts you to configure another default gateway:

```
Enter default gateway number: (1-132)
```

Repeat the steps in this section until all default gateways have been configured. When all default gateways have been configured, press <Enter> without specifying any number.

IP Routing

When IP interfaces are configured for the various subnets attached to your switch, IP routing between them can be performed entirely within the switch. This eliminates the need to send inter-subnet communication to an external router device. Routing on more complex networks, where subnets may not have a direct presence on the GbE Switch Module, can be accomplished through configuring static routes or by letting the switch learn routes dynamically.

This part of the Setup program prompts you to configure the various routing parameters.

1. At the prompt, enable or disable forwarding for IP Routing:

```
Enable IP forwarding? [y/n]
```

Enter *y* to enable IP forwarding. To disable IP forwarding, enter *n* and proceed to [Step 2](#). To keep the current setting, press <Enter>.

2. At the prompt, enable or disable the RIP supply:

```
Enable RIP supply? [y/n]
```

Setup Part 5: Final Steps

1. **When prompted, decide whether to restart Setup or continue:**

```
Would you like to run from top again? [y/n]
```

Enter **y** to restart the Setup utility from the beginning, or **n** to continue.

2. **When prompted, decide whether you wish to review the configuration changes:**

```
Review the changes made? [y/n]
```

Enter **y** to review the changes made during this session of the Setup utility. Enter **n** to continue without reviewing the changes. We recommend that you review the changes.

3. **Next, decide whether to apply the changes at the prompt:**

```
Apply the changes? [y/n]
```

Enter **y** to apply the changes, or **n** to continue without applying. Changes are normally applied.

4. **At the prompt, decide whether to make the changes permanent:**

```
Save changes to flash? [y/n]
```

Enter **y** to save the changes to flash. Enter **n** to continue without saving the changes. Changes are normally saved at this point.

5. **If you do not apply or save the changes, the system prompts whether to abort them:**

```
Abort all changes? [y/n]
```

Enter **y** to discard the changes. Enter **n** to return to the “Apply the changes?” prompt.

NOTE – After initial configuration is complete, it is recommended that you change the default passwords as shown in “Setting Passwords” on page 39.

Optional Setup for SNMP Support

NOTE – This step is optional. Perform this procedure only if you are planning on using SNMP-based tools.

1. **Enable SNMP and select one of the options.**

```
>> # /cfg/sys/snmp dis|read|write
```

2. **Set SNMP read or write community string. By default, they are public and private respectively.**

```
>> # /cfg/snmp/rcomm|wcomm
```

3. **Apply and save configuration if you are not configuring the switch with Telnet support. Otherwise apply and save after “[Optional Setup for Telnet Support](#)” on page 38.**

```
>> System# apply
>> System# save
```

Optional Setup for Telnet Support

NOTE – This step is optional. Perform this procedure only if you are planning on connecting to the GbE Switch Module through a remote Telnet connection.

1. **Telnet is enabled by default. To change the setting, use the following command:**

```
>> # /cfg/sys/telnet
```

2. **Apply and save SNMP and /or telnet configuration(s).**

```
>> System# apply
>> System# save
```

If your network uses Routing Interface Protocol (RIP), enter **y** to enable the RIP supply. Otherwise, enter **n** to disable it. When RIP is enabled, RIP listen is set by default.

Setting Passwords

It is recommended that you change the user and administrator passwords after initial configuration and as regularly as required under your network security policies.

To change both the user password and the administrator password, you must login using the administrator password. Passwords cannot be modified from the user command mode.

NOTE – If you forget your administrator password, call your technical support representative for help using the password fix-up mode.

Changing the Default Administrator Password

The administrator has complete access to all menus, information, and configuration commands, including the ability to change both the user and administrator passwords.

The default password for the administrator account is `admin`. To change the default password, follow this procedure:

1. **Connect to the switch and log in using the `admin` password.**
2. **From the Main Menu, use the following command to access the Configuration Menu:**

```
Main# /cfg
```

The Configuration Menu is displayed.

```
[Configuration Menu]
  sys      - System-wide Parameter Menu
  port     - Port Menu
  pmirr    - Port Mirroring Menu
  l2       - Layer 2 Menu
  l3       - Layer 3 Menu
  slb      - Server Load Balancing (Layer 4-7) Menu
  setup    - Step by step configuration set up
  dump     - Dump current configuration to script file
  ptcfg    - Backup current configuration to tftp server
  gtcfg    - Restore current configuration from tftp server
```

3. **From the Configuration Menu, use the following command to select the System Menu:**

```
>> Configuration# sys
```

The System Menu is displayed.

```
[System Menu]
  syslog   - Syslog Menu
  sshd     - SSH Server Menu
  radius   - RADIUS Authentication Menu
  tacacs   - TACACS+ Authentication Menu
  ntp      - NTP Server Menu
  ssnmp    - System SNMP Menu
  access   - System Access Menu
  date     - Set system date
  time     - Set system time
  idle     - Set timeout for idle CLI sessions
  notice   - Set login notice
  banrn    - Set login banner
  smtp     - Set SMTP host
  hprompt  - Enable/disable display hostname (sysName) in CLI prompt
  bootp    - Enable/disable use of BOOTP
  cur      - Display current system-wide parameters
```

4. From the System Menu, use the following command to select the System Access Menu:

```
>> System# access
```

The System Access Menu is displayed.

```
[System Access Menu]
  user     - User Access Control Menu (passwords)
  http     - Enable/disable HTTP (Web) access
  wport    - Set HTTP (Web) server port number
  mnet     - Set management network
  mmask    - Set management netmask
  snmp     - Set SNMP access control
  tnet     - Enable/disable Telnet access
  tnport   - Set Telnet server port number
  cur      - Display current system access configuration
```

5. Select the administrator password.

```
System Access# user/admpw
```

6. Enter the current administrator password at the prompt:

```
Changing ADMINISTRATOR password; validation required...
Enter current administrator password:
```

NOTE – If you forget your administrator password, call your technical support representative for help using the password fix-up mode.

7. Enter the new administrator password at the prompt:

```
Enter new administrator password:
```

8. Enter the new administrator password, again, at the prompt:

```
Re-enter new administrator password:
```

9. Apply and save your change by entering the following commands:

```
System# apply
System# save
```

Changing the Default User Password

The user login has limited control of the switch. Through a user account, you can view switch information and statistics, but you can't make configuration changes.

The default password for the user account is `user`. This password cannot be changed from the user account. Only the administrator has the ability to change passwords, as shown in the following procedure.

1. **Connect to the switch and log in using the `admin` password.**
2. **From the Main Menu, use the following command to access the Configuration Menu:**

```
Main# cfg
```

3. **From the Configuration Menu, use the following command to select the System Menu:**

```
>> Configuration# sys
```

4. From the System Menu, use the following command to select the System Access Menu:

```
>> System# access
```

5. Select the user password.

```
System# user/usrpw
```

6. Enter the current administrator password at the prompt.

Only the administrator can change the user password. Entering the administrator password confirms your authority.

```
Changing USER password; validation required...
Enter current administrator password:
```

7. Enter the new user password at the prompt:

```
Enter new user password:
```

8. Enter the new user password, again, at the prompt:

```
Re-enter new user password:
```

9. Apply and save your changes:

```
System# apply
System# save
```

Changing the Default Layer 4 Administrator Password

The Layer 4 administrator has limited control of the switch. Through a Layer 4 administrator account, you can view all switch information and statistics, but can configure changes only on the Server Load Balancing menus.

The default password for the Layer 4 administrator account is `l4admin`. To change the default password, follow this procedure:

1. Connect to the switch and log in using the administrator account.

To change any switch password, you must login using the administrator password. Passwords cannot be modified from the Layer 4 administrator account or the user account.

2. From the Main Menu, use the following command to access the System Menu:

```
Main# /cfg/sys/access/user
```

3. Select the Layer 4 administrator password:

```
System# 14apw
```

4. Enter the current *administrator* password (not the Layer 4 administrator password) at the prompt:

```
Changing L4 ADMINISTRATOR password; validation required...  
Enter current administrator password:
```

NOTE – If you forget your administrator password, call your technical support representative for help using the password fix-up mode.

5. Enter the new Layer 4 administrator password at the prompt:

```
Enter new L4 administrator password:
```

6. Enter the new administrator password, again, at the prompt:

```
Re-enter new L4 administrator password:
```

7. Apply and save your change by entering the following commands:

```
System Access# apply  
System Access# save
```




CHAPTER 3

Menu Basics

The GbE Switch Module's Command Line Interface (CLI) is used for viewing switch information and statistics. In addition, the administrator can use the CLI for performing all levels of switch configuration.

To make the CLI easy to use, the various commands have been logically grouped into a series of menus and sub-menus. Each menu displays a list of commands and/or sub-menus that are available, along with a summary of what each command will do. Below each menu is a prompt where you can enter any command appropriate to the current menu.

This chapter describes the Main Menu commands, and provides a list of commands and short-cuts that are commonly available from all the menus within the CLI.

The Main Menu

The Main Menu appears after a successful connection and login. The following table shows the Main Menu for the administrator login. Some features are not available under the user login.

```
[Main Menu]
  info      - Information Menu
  stats     - Statistics Menu
  cfg       - Configuration Menu
  oper      - Operations Command Menu
  boot      - Boot Options Menu
  maint     - Maintenance Menu
  diff      - Show pending config changes [global command]
  apply     - Apply pending config changes [global command]
  save      - Save updated config to FLASH [global command]
  revert    - Revert pending or applied changes [global command]
  exit      - Exit [global command, always available]
```

Menu Summary

■ Information Menu

Provides sub-menus for displaying information about the current status of the switch: from basic system settings to VLANs, Layer 4 settings, and more.

■ Statistics Menu

Provides sub-menus for displaying switch performance statistics. Included are port, IF, IP, ICMP, TCP, UDP, SNMP, routing, ARP, DNS, VRRP, and Layer 4 statistics.

■ Configuration Menu

This menu is available only from an administrator login. It includes sub-menus for configuring every aspect of the switch. Changes to configuration are not active until explicitly applied. Changes can be saved to non-volatile memory.

■ Operations Command Menu

Operations-level commands are used for making immediate and temporary changes to switch configuration. This menu is used for bringing ports temporarily in and out of service, performing port mirroring, and enabling or disabling Server Load Balancing functions. It is also used for activating or deactivating optional software packages.

■ Boot Options Menu

This menu is used for upgrading switch software, selecting configuration blocks, and for resetting the switch when necessary.

■ Maintenance Menu

This menu is used for debugging purposes, enabling you to generate a dump of the critical state information in the switch, and to clear entries in the forwarding database and the ARP and routing tables.

Global Commands

Some basic commands are recognized throughout the menu hierarchy. These commands are useful for obtaining online help, navigating through menus, and for applying and saving configuration changes.

For help on a specific command, type `help`. You will see the following screen:

```
Global Commands: [can be issued from any menu]
help          up          print          pwd
lines         verbose       exit          quit
diff          apply        save          revert
ping          traceroute  telnet       history
pushd         popd

The following are used to navigate the menu structure:
.   Print current menu
..  Move up one menu level
/   Top menu if first, or command separator
!   Execute command from history
```

Table 3-1 Description of Global Commands

Command	Action
<code>? <i>command</i></code> or <code>help</code>	Provides more information about a specific command on the current menu. When used without the <i>command</i> parameter, a summary of the global commands is displayed.
<code>. or print</code>	Display the current menu.
<code>.. or up</code>	Go up one level in the menu structure.
<code>/</code>	If placed at the beginning of a command, go to the Main Menu. Otherwise, this is used to separate multiple commands placed on the same line.
<code>lines</code>	Set the number of lines (n) that display on the screen at one time. The default is 24 lines. When used without a value, the current setting is displayed.
<code>diff</code>	Show any pending configuration changes.
<code>apply</code>	Apply pending configuration changes.
<code>save</code>	Write configuration changes to non-volatile flash memory.

Table 3-1 Description of Global Commands

Command	Action
revert	Remove pending configuration changes between “apply” commands. Use this command to restore configuration parameters set since last “apply” command.
exit or quit	Exit from the command line interface and log out.
ping	<p>Use this command to verify station-to-station connectivity across the network. The format is as follows:</p> <pre>ping <host name> <IP address> [tries (1-32)] [msec delay]] [-m -mgmt -d -data]</pre> <p>Where <i>IP address</i> is the hostname or IP address of the device, <i>tries</i> (optional) is the number of attempts (1-32), <i>msec delay</i> (optional) is the number of milliseconds between attempts. By default, the -d or -data option for network ports is in effect. If the management port is used, specify the -m or -mgmt option. The DNS parameters must be configured if specifying hostnames (see “Domain Name System Configuration” on page 234).</p>
traceroute	<p>Use this command to identify the route used for station-to-station connectivity across the network. The format is as follows:</p> <pre>traceroute <host name> <IP address> [<max-hops (1-32)> [msec delay]] [-m -mgmt -d -data]</pre> <p>Where <i>IP address</i> is the hostname or IP address of the target station, <i>max-hops</i> (optional) is the maximum distance to trace (1-16 devices), and <i>delay</i> (optional) is the number of milliseconds for wait for the response. By default, the -d or -data option for network ports is in effect. If the management port is used, specify the -m or -mgmt option. As with <code>ping</code>, the DNS parameters must be configured if specifying hostnames.</p>
pwd	Display the command path used to reach the current menu.
verbose n	<p>Sets the level of information displayed on the screen:</p> <ul style="list-style-type: none"> 0 =Quiet: Nothing appears except errors—not even prompts. 1 =Normal: Prompts and requested output are shown, but no menus. 2 =Verbose: Everything is shown. <p>When used without a value, the current setting is displayed.</p>
telnet	<p>This command is used to telnet out of the switch. The format is as follows:</p> <pre><hostname> <IP address> [port] [-m -mgmt -d -data].</pre> <p>Where <i>IP address</i> is the hostname or IP address of the device. By default, the -d or -data option for network ports is in effect. If the management port is used, specify the -m or -mgmt option.</p>
history	This command brings up the history of the last 10 commands.

Command Line History and Editing

Using the command line interface, you can retrieve and modify previously entered commands with just a few keystrokes. The following options are available globally at the command line:

Table 3-2 Command Line History and Editing Options

Option	Description
history	Display a numbered list of the last 10 previously entered commands.
!!	Repeat the last entered command.
!<i>n</i>	Repeat the <i>n</i> th command shown on the history list.
<Ctrl-p>	(Also the up arrow key.) Recall the <i>previous</i> command from the history list. This can be used multiple times to work backward through the last 10 commands. The recalled command can be entered as is, or edited using the options below.
<Ctrl-n>	(Also the down arrow key.) Recall the <i>next</i> command from the history list. This can be used multiple times to work forward through the last 10 commands. The recalled command can be entered as is, or edited using the options below.
<Ctrl-a>	Move the cursor to the beginning of command line.
<Ctrl-e>	Move cursor to the <i>end</i> of the command line.
<Ctrl-b>	(Also the left arrow key.) Move the cursor <i>back</i> one position to the left.
<Ctrl-f>	(Also the right arrow key.) Move the cursor <i>forward</i> one position to the right.
<Backspace>	(Also the Delete key.) Erase one character to the left of the cursor position.
<Ctrl-d>	<i>Delete</i> one character at the cursor position.
<Ctrl-k>	<i>Kill</i> (erase) all characters from the cursor position to the end of the command line.
<Ctrl-l>	Redraw the screen.
<Ctrl-u>	Clear the entire line.
Other keys	Insert new characters at the cursor position.

Command Line Interface Shortcuts

Command Stacking

As a shortcut, you can type multiple commands on a single line, separated by forward slashes (/). You can connect as many commands as required to access the menu option that you want. For example, the keyboard shortcut to access the Spanning Tree Port Configuration Menu from the `Main#` prompt is as follows:

```
Main# cfg/stg/port
```

Command Abbreviation

Most commands can be abbreviated by entering the first characters which distinguish the command from the others in the same menu or sub-menu. For example, the command shown above could also be entered as follows:

```
Main# c/st/p
```

Tab Completion

By entering the first letter of a command at any menu prompt and hitting <Tab>, the CLI will display all commands or options in that menu that begin with that letter. Entering additional letters will further refine the list of commands or options displayed. If only one command fits the input text when <Tab> is pressed, that command will be supplied on the command line, waiting to be entered. If the <Tab> key is pressed without any input on the command line, the currently active menu will be displayed.

CHAPTER 4

The Information Menu

You can view configuration information for the switch in both the user and administrator command modes. This chapter discusses how to use the command line interface to display switch information.

/info

Information Menu

```
[Information Menu]
  sys      - System Information Menu
  l2       - Layer 2 Information Menu
  l3       - Layer 3 Information Menu
  slb      - Layer 4-7 Information Menu
  link     - Show link status
  port     - Show port information
  dump     - Dump all information
```

The information provided by each menu option is briefly described in [Table 4-1 on page 51](#), with pointers to where detailed information can be found.

Table 4-1 Information Menu Options (/info)

Command Syntax and Usage

sys

Displays the System Information Menu. For details, see [page 53](#).

l2

Displays the Layer 2 Information Menu. For details, see [page 56](#).

l3

Displays the Layer 3 Information Menu. For details, see [page 66](#).

slb

Displays the Layer 4 Information Menu. For details, see [page 84](#).

Table 4-1 Information Menu Options (/info)

Command Syntax and Usage

link

Displays configuration information about each port, including:

- Port alias
- Port speed (10, 100, 10/100, or 1000)
- Duplex mode (half, full, or auto)
- Flow control for transmit and receive (no, yes, or auto)
- Link status (up or down)

For details, see [page 91](#).

port

Displays port status information, including:

- Port alias
- Whether the port uses VLAN Tagging or not
- Port VLAN ID (PVID)
- Port name
- VLAN membership

For details, see [page 92](#).

dump

Dumps all switch information available from the Information Menu (10K or more, depending on your configuration).

If you want to capture dump data to a file, set your communication software on your workstation to capture session data prior to issuing the dump commands.

/info/sys

System Information

```
[System Menu]
  general - Show general system information
  log     - Show last 30 syslog messages
  dump    - Dump all system information
```

The information provided by each menu option is briefly described in [Table 4-2 on page 53](#), with pointers to where detailed information can be found.

Table 4-2 System Menu Options (/info/sys)

Command Syntax and Usage

general

Displays system information, including:

- System date and time
- Switch model name and number
- Switch name and location
- Time of last boot
- MAC address of the switch management processor
- IP address of IP interface #1
- Hardware version and part number
- Software image file and version number
- Configuration name
- Log-in banner, if one is configured

For details, see [page 54](#).

log

Displays 30 most recent syslog messages. For details, see [page 55](#).

dump

Dumps all switch information available from the Information Menu (10K or more, depending on your configuration).

`/info/sys/general`

General System Information

```
System Information at 0:57:36 Thu Jul 1, 2004

Layer 2-7 Gigabit Ethernet Switch Module for IBM eServer BladeCenter

Switch is up 5 days, 1 hour, 1 minute and 21 seconds.
Last boot: 0:01:03 Thu Jul 1, 2004 (power cycle)

MAC Address: 00:09:97:ec:e6:00      Management IP Address (if 128):
10.90.90.97

Software Version 20.2.0 (FLASH image1), active configuration.

PCBA Part Number:      316210-A
FAB Number:            86
Serial Number:         YJIRTK3510
Manufacturing Date:    5120
Hardware Revision:     48
PLD Firmware Version:  3.4
```

NOTE – The display of temperature will come up only if the temperature of any of the sensors exceeds the temperature threshold. There will be a warning from the software if any of the sensors exceeds this temperature threshold. The switch will shut down if the power supply overheats.

System information includes:

- System date and time
- Switch model
- Switch name and location
- Time of last boot
- MAC address of the switch management processor
- IP address of IP interface #1
- Hardware version and part number
- Software image file and version number
- Configuration name
- Log-in banner, if one is configured

`/info/sys/log`

Show Last 30 Syslog Messages

Date	Time	Criticality level	Message
Jul 8	17:25:41	NOTICE	system: link up on port INT1
Jul 8	17:25:41	NOTICE	system: link up on port INT8
Jul 8	17:25:41	NOTICE	system: link up on port INT7
Jul 8	17:25:41	NOTICE	system: link up on port INT2
Jul 8	17:25:41	NOTICE	system: link up on port INT1
Jul 8	17:25:41	NOTICE	system: link up on port INT4
Jul 8	17:25:41	NOTICE	system: link up on port INT3
Jul 8	17:25:41	NOTICE	system: link up on port INT6
Jul 8	17:25:41	NOTICE	system: link up on port INT5
Jul 8	17:25:41	NOTICE	system: link up on port EXT4
Jul 8	17:25:41	NOTICE	system: link up on port EXT1
Jul 8	17:25:41	NOTICE	system: link up on port EXT3
Jul 8	17:25:41	NOTICE	system: link up on port EXT2
Jul 8	17:25:41	NOTICE	system: link up on port INT3
Jul 8	17:25:42	NOTICE	system: link up on port INT2
Jul 8	17:25:42	NOTICE	system: link up on port INT4
Jul 8	17:25:42	NOTICE	system: link up on port INT3
Jul 8	17:25:42	NOTICE	system: link up on port INT6
Jul 8	17:25:42	NOTICE	system: link up on port INT5
Jul 8	17:25:42	NOTICE	system: link up on port INT1
Jul 8	17:25:42	NOTICE	system: link up on port INT6

Each syslog message has a criticality level associated with it, included in text form as a prefix to the log message. One of eight different prefixes is used, depending on the condition that the administrator is being notified of, as shown below.

- EMERG: indicates the system is unusable
- ALERT: Indicates action should be taken immediately
- CRIT: Indicates critical conditions
- ERR: indicates error conditions or errored operations
- WARNING: indicates warning conditions
- NOTICE: indicates a normal but significant condition
- INFO: indicates an information message
- DEBUG: indicates a debug-level message

/info/l2

Layer 2 Menu

```
[Layer 2 Menu]
fdb      - Forwarding Database Information Menu
lACP     - Link Aggregation Control Protocol Menu
stg      - Show STG information
trunk    - Show Trunk Group information
vlan     - Show VLAN information
dump     - Dump all layer 2 information
```

The information provided by each menu option is briefly described in [Table 4-3 on page 56](#), with pointers to where detailed information can be found.

Table 4-3 Layer 2 Menu Options (/info/l2)

Command Syntax and Usage

fdb

Displays the Forwarding Database Information Menu. For details, see [page 57](#).

lACP

Displays the Link Aggregation Control Protocol Menu. For details, see [page 60](#).

stg

In addition to seeing if STG is enabled or disabled, you can view the following STG bridge information:

- Priority
- Hello interval
- Maximum age value
- Forwarding delay
- Aging time

You can also see the following port-specific STG information:

- Port alias and priority
- Cost
- State

For details, see [page 62](#).

trunk

When trunk groups are configured, you can view the state of each port in the various trunk groups. For details, see [page 64](#).

Table 4-3 Layer 2 Menu Options (/info/l2)

Command Syntax and Usage

vlan

Displays VLAN configuration information, including:

- VLAN Number
- VLAN Name
- Status
- Port membership of the VLAN

For details, see [page 65](#).

dump

Dumps all switch information available from the Layer 2 menu (10K or more, depending on your configuration).

If you want to capture dump data to a file, set your communication software on your workstation to capture session data prior to issuing the dump commands.

/info/l2/fdb

FDB Information Menu

[Forwarding Database Menu]	
find	- Show a single FDB entry by MAC address
port	- Show FDB entries on a single port
trunk	- Show FDB entries on a single trunk
vlan	- Show FDB entries on a single VLAN
refpt	- Show FDB entries referenced by a single port
dump	- Show all FDB entries

The forwarding database (FDB) contains information that maps the media access control (MAC) address of each known device to the switch port where the device address was learned. The FDB also shows which other ports have seen frames destined for a particular MAC address.

NOTE – The master forwarding database supports up to 2K MAC address entries on the MP per switch. Each SP port supports up to 1K entries.

Table 4-4 FDB Information Menu Options (/info/l2/fdb)

Command Syntax and Usage

find *<MAC address>* [*<VLAN>*]

Displays a single database entry by its MAC address. You are prompted to enter the MAC address of the device. Enter the MAC address using the format, *xx:xx:xx:xx:xx:xx*. For example, 08:00:20:12:34:56.

You can also enter the MAC address using the format, *xxxxxxxxxxxx*. For example, 080020123456.

port *<port number or alias>*

Displays all FDB entries for a particular port.

trunk *<Trunk Group number>*

Displays all FDB entries on a single trunk.

vlan *<VLAN number (1-4095)>*

Displays all FDB entries on a single VLAN.

refpt *<SP number (1-4)>*

Displays the FDB entries referenced by a single port.

dump

Displays all entries in the Forwarding Database. For more information, see [page 59](#).

`/info/l2/fdb/dump` Show All FDB Information

MAC address	VLAN	Port	Trunk	State	Referenced SPs	Learned port
00:02:01:00:00:00	300	EXT1		FWD	2	EXT1
00:02:01:00:00:01	300	INT1		FWD	1	INT1
00:02:01:00:00:02	300	INT1		FWD	2	INT1
00:02:01:00:00:03	300	INT7		FWD	1	INT7
00:02:01:00:00:04	300	INT3		FWD	1	INT3
00:02:01:00:00:05	300	INT4		FWD	2	INT4
00:02:01:00:00:06	300	INT6		FWD	2	INT6
00:02:01:00:00:07	300	INT2		FWD	2	INT2
00:02:01:00:00:08	300	INT5		FWD	1 2	INT5
00:02:01:00:00:09	300	INT4		FWD	1 2	INT4
00:02:01:00:00:0a	300	INT3		FWD	1 2	INT3
00:02:01:00:00:0b	300	INT2		FWD	1 2	INT2
00:02:01:00:00:0c	4095	MGT1		FWD	1	MGT1

An address that is in the forwarding (FWD) state, means that it has been learned by the switch. When in the trunking (TRK) state, the port field represents the trunk group number. If the state for the port is listed as unknown (UNK), the MAC address has not yet been learned by the switch, but has only been seen as a destination address. When an address is in the unknown state, no outbound port is indicated, although ports which reference the address as a destination will be listed under “Reference ports.”

If the state for the port is listed as an interface (IF), the MAC address is for a standard VRRP virtual router. If the state is listed as a virtual server (VIP), the MAC address is for a virtual server router—a virtual router with the same IP address as a virtual server.

Clearing Entries from the Forwarding Database

To delete a MAC address from the forwarding database (FDB) or to clear the entire FDB, refer to [“Forwarding Database Options” on page 313](#).

/info/l2/lacp

Link Aggregation Control Protocol menu

```
[LACP Menu]
  aggr      - Show LACP aggregator information for the port
  port      - Show LACP port information
  dump      - Show all LACP ports information
```

Use these commands to display LACP status information about each port on a GbE Switch Module.

Table 4-5 Link Aggregation Control Protocol (/info/l2/lacp)

Command Syntax and Usage

aggr

Displays detailed information of the LACP aggregator used by the selected port.

port

Displays LACP information about the selected port.

dump

Displays a summary of LACP information. For details, see [page 60](#).

/info/l2/lacp/dump

Link Aggregation Control Protocol

port	lacp	adminkey	operkey	selected	prio	attached	trunk
							aggr
EXT1	active	30	30	y	128	17	19
EXT2	active	30	30	y	128	17	19
EXT3	off	19	19	n	128	--	--
EXT4	off	20	20	n	128	--	--

LACP dump includes the following information for each external port in the GbESM:

- lacp
Displays the port's LACP mode (active, passive, or off)
- adminkey
Displays the value of the port's adminkey.

- operkey
Shows the value of the port's operational key.
- selected
Indicates whether the port has been selected to be part of a Link Aggregation Group.
- prio
Shows the value of the port priority.
- attached aggr
Displays the aggregator associated with each port.
- trunk
This value represents the LACP trunk group number.

/info/l2/stg

Spanning Tree Information

```
Spanning Tree Group 1: On
```

Current Root:	Path-Cost	Port	Hello	MaxAge	FwdDel	Aging
8000 00:03:42:fa:3b:80	0	0	2	20	15	300

Parameters:	Priority	Hello	MaxAge	FwdDel	Aging
	32768	2	20	15	300

Port	Priority	Cost	State	Designated Bridge	Des Port
----	-----	----	-----	-----	-----
INT1	128	5	FORWARDING	8000-00:03:42:fa:3b:80	32769
INT2	128	5	FORWARDING	8000-00:03:42:fa:3b:80	32770
INT3	128	0	DISABLED		
INT4	128	0	DISABLED		
INT5	128	0	DISABLED		
INT6	128	0	DISABLED		
INT7	128	0	DISABLED		
INT8	128	0	DISABLED		
INT9	128	0	DISABLED		
INT10	128	0	DISABLED		
INT11	128	10	FORWARDING	8000-00:03:42:fa:3b:80	32779
INT12	128	0	DISABLED		
INT13	128	0	DISABLED		
INT14	128	0	DISABLED		
EXT1	128	0	DISABLED		
EXT2	128	0	DISABLED		
EXT3	128	0	DISABLED		
EXT4	128	0	DISABLED		

NOTE – The sample screens that appear in this document might differ slightly from the screens displayed by your system. Screen content varies based on the type of BladeCenter unit that you are using and the firmware versions and options that are installed.

The switch software uses the IEEE 802.1d Spanning Tree Protocol (STP). In addition to seeing if STG is enabled or disabled, you can view the following STG bridge information:

- Priority
- Hello interval
- Maximum age value
- Forwarding delay
- Aging time

You can also see the following port-specific STG information:

- Slot number
- Port alias and priority
- Cost
- State

The following table describes the STG parameters.

Table 4-6 Spanning Tree Parameter Descriptions

Parameter	Description
Priority (bridge)	The bridge priority parameter controls which bridge on the network will become the STG root bridge.
Hello	The hello time parameter specifies, in seconds, how often the root bridge transmits a configuration bridge protocol data unit (BPDU). Any bridge that is not the root bridge uses the root bridge hello value.
MaxAge	The maximum age parameter specifies, in seconds, the maximum time the bridge waits without receiving a configuration bridge protocol data unit before it reconfigure the STG network.
FwdDel	The forward delay parameter specifies, in seconds, the amount of time that a bridge port has to wait before it changes from learning state to forwarding state.
Aging	The aging time parameter specifies, in seconds, the amount of time the bridge waits without receiving a packet from a station before removing the station from the Forwarding Database.
priority (port)	The port priority parameter helps determine which bridge port becomes the designated port. In a network topology that has multiple bridge ports connected to a single segment, the port with the lowest port priority becomes the designated port for the segment.

Table 4-6 Spanning Tree Parameter Descriptions (Continued)

Parameter	Description
Cost	The port path cost parameter is used to help determine the designated port for a segment. Generally speaking, the faster the port, the lower the path cost. A setting of 0 indicates that the cost will be set to the appropriate default after the link speed has been auto negotiated.
State	The state field shows the current state of the port. The state field can be either BLOCKING, LISTENING, LEARNING, FORWARDING, or DISABLED.

`/info/12/trunk` Trunk Group Information

```
Trunk group 1, failover ena, port state:
 1: STG 1 forwarding
 2: STG 1 forwarding
```

When trunk groups are configured, you can view the state of each port in the various trunk groups.

NOTE – If Spanning Tree Protocol on any port in the trunk group is set to `forwarding`, the remaining ports in the trunk group will also be set to `forwarding`.

/info/l2/vlan

VLAN Information

VLAN	Name	Status	Jumbo	Ports
1	Default VLAN	ena	n	EXT1 EXT3
2	pc03p	ena	n	INT2
7	pc07f	ena	n	INT7
11	pc04u	ena	n	INT11
14	8600-14	ena	n	INT14
15	8600-15	ena	n	INT5
16	8600-16	ena	n	INT6
17	8600-17	ena	n	INT8
18	35k-1	ena	n	INT9
19	35k-2	ena	n	INT10
20	35k-3	ena	n	INT12
21	35k-4	ena	n	INT13
22	pc07z	ena	n	INT6
24	redlan	ena	n	INT7
300	ixiaTraffic	ena	n	EXT1 INT12 INT13
4000	bpsports	ena	n	INT3-INT6
4095	Mgmt VLAN	ena	n	MGT1 MGT2

NOTE – The sample screens that appear in this document might differ slightly from the screens displayed by your system. Screen content varies based on the type of BladeCenter unit that you are using and the firmware versions and options that are installed.

This information display includes all configured VLANs and all member ports that have an active link state. Port membership is represented in slot/port format.

VLAN information includes:

- VLAN Number
- VLAN Name
- Status
- Jumbo frame support
- Port membership of the VLAN

/info/l3

Layer 3 Menu

```
[Layer 3 Menu]
route      - IP Routing Information Menu
arp        - ARP Information Menu
bgp        - BGP Information Menu
ospf       - OSPF Routing Information Menu
igmp       - IGMP Information Menu
ip         - Show IP information
vrrp       - Show Virtual Router Redundancy Protocol information
dump       - Dump all layer 3 information
```

The information provided by each menu option is briefly described in [Table 4-7 on page 66](#), with pointers to where detailed information can be found.

Table 4-7 Layer 3 Menu Options (/info/l3)

Command Syntax and Usage

route

Displays the IP Routing Menu. Using the options of this menu, the system displays the following for each configured or learned route:

- Route destination IP address, subnet mask, and gateway address
- Type of route
- Tag indicating origin of route
- Metric for RIP tagged routes, specifying the number of hops to the destination (1-15 hops, or 16 for infinite hops)
- The IP interface that the route uses

For details, see [page 68](#).

arp

Displays the Address Resolution Protocol (ARP) Information Menu. For details, see [page 70](#).

bgp

Displays BGP Information Menu. To view menu options, see [page 73](#).

ospf

Displays OSPF routing Information Menu. For details, see [page 75](#).

igmp

Displays IGMP Information Menu. For details, see [page 80](#).

Table 4-7 Layer 3 Menu Options (/info/l3)

Command Syntax and Usage

ip

Displays IP Information. For details, see [page 82](#).

IP information, includes:

- IP interface information: Interface number, IP address, subnet mask, VLAN number, and operational status.
 - Default gateway information: Metric for selecting which configured gateway to use, gateway number, IP address, and health status
 - IP forwarding information: Enable status, `lnet` and `lmask`
 - Port status
-

vrrp

Displays the VRRP Information Menu. For details, see [page 82](#).

dump

Dumps all switch information available from the Layer 3 Menu (10K or more, depending on your configuration).

If you want to capture dump data to a file, set your communication software on your workstation to capture session data prior to issuing the dump commands.

/info/l3/route

IP Routing Information

[IP Routing Menu]	
find	- Show a single route by destination IP address
gw	- Show routes to a single gateway
type	- Show routes of a single type
tag	- Show routes of a single tag
if	- Show routes on a single interface
dump	- Show all routes

Using the commands listed below, you can display all or a portion of the IP routes currently held in the switch.

Table 4-8 Route Information Menu Options (/info/l3/route)

Command Syntax and Usage

find <IP address (such as 192.4.17.101)>

Displays a single route by destination IP address.

gw <default gateway address (such as 192.4.17.44)>

Displays routes to a single gateway.

type indirect | direct | local | broadcast | martian | multicast

Displays routes of a single type. For a description of IP routing types, see [Table 4-9 on page 69](#).

tag fixed | static | addr | rip | ospf | bgp | broadcast | martian | vip

Displays routes of a single tag. For a description of IP routing types, see [Table 4-10 on page 70](#).

if <interface number (1-128)>

Displays routes on a single interface.

dump

Displays all routes configured in the switch. For more information, see [page 68](#).

/info/l3/route/dump

Show All IP Route Information

Status code: * - best					
Destination	Mask	Gateway	Type	Tag	Metr If
* 11.0.0.0	255.0.0.0	11.0.0.1	direct	fixed	211
* 11.0.0.1	255.255.255.255	11.0.0.1	local	addr	211
* 11.255.255.255	255.255.255.255	11.255.255.255	broadcast	broadcast	211
* 12.0.0.0	255.0.0.0	12.0.0.1	direct	fixed	12
* 12.0.0.1	255.255.255.255	12.0.0.1	local	addr	12
* 12.255.255.255	255.255.255.255	12.255.255.255	broadcast	broadcast	12
* 13.0.0.0	255.0.0.0	11.0.0.2	indirect	ospf	2 211
* 47.0.0.0	255.0.0.0	47.133.88.1	indirect	static	24
* 47.133.88.0	255.255.255.0	47.133.88.46	direct	fixed	24
* 172.30.52.223	255.255.255.255	172.30.52.223	broadcast	broadcast	2
* 224.0.0.0	224.0.0.0	0.0.0.0	martian	martian	
* 224.0.0.5	255.255.255.255	0.0.0.0	multicast	addr	

The following table describes the Type parameters.

Table 4-9 IP Routing Type Parameters (/info/l3/route/dump/type)

Parameter	Description
indirect	The next hop to the host or subnet destination will be forwarded through a router at the Gateway address.
direct	Packets will be delivered to a destination host or subnet attached to the switch.
local	Indicates a route to one of the switch's IP interfaces.
broadcast	Indicates a broadcast route.
martian	The destination belongs to a host or subnet which is filtered out. Packets to this destination are discarded.
multicast	Indicates a multicast route.

The following table describes the Tag parameters.

Table 4-10 IP Routing Tag Parameters (info/l3/route/tag)

Parameter	Description
fixed	The address belongs to a host or subnet attached to the switch.
static	The address is a static route which has been configured on the GbE Switch Module.
addr	The address belongs to one of the switch's IP interfaces.
rip	The address was learned by the Routing Information Protocol (RIP).
ospf	The address was learned by Open Shortest Path First (OSPF).
bgp	The address was learned via Border Gateway Protocol (BGP)
broadcast	Indicates a broadcast address.
martian	The address belongs to a filtered group.
vip	Indicates a route destination that is a virtual server IP address. VIP routes are needed to advertise virtual server IP addresses via BGP.

/info/l3/arp ARP Information

```
[Address Resolution Protocol Menu]
```

```
find      - Show a single ARP entry by IP address
port      - Show ARP entries on a single port
vlan      - Show ARP entries on a single VLAN
refpt     - Show ARP entries referenced by a single port
dump      - Show all ARP entries
help      - Show help on the fields of ARP entries
addr      - Show ARP address list
```

The ARP information includes IP address and MAC address of each entry, address status flags (see [Table 4-11 on page 70](#)), VLAN and port for the address, and port referencing information.

Table 4-11 ARP Information Menu Options (/info/l3/arp)

Command Syntax and Usage

```
find <IP address (such as, 192.4.17.101)>
      Displays a single ARP entry by IP address.
```

Table 4-11 ARP Information Menu Options (/info/l3/arp)**Command Syntax and Usage****port** <port alias or number>

Displays the ARP entries on a single port.

vlan <VLAN number (1-4095)>

Displays the ARP entries on a single VLAN.

refpt <port alias or number (1-4)>

Displays the ARP entries referenced by a single port.

dump

Displays all ARP entries, including:

- IP address and MAC address of each entry
- Address status flag (see below)
- The VLAN and port to which the address belongs
- The ports which have referenced the address (empty if no port has routed traffic to the IP address shown)

For more information, see [page 72](#).**help**

Displays Help information about ARP entries.

addr

Displays the ARP address list: IP address, IP mask, MAC address, and VLAN flags.

/info/l3/arp/dump

Show All ARP Entry Information

IP address	Flags	MAC address	VLAN	Port	Referenced Sps
47.80.22.1		00:e0:16:7c:28:86	1	INT6	empty
47.80.23.243	P	00:03:42:fa:3b:30	1		1 2
47.80.23.245		00:c0:4f:60:3e:c1	1	INT6	empty
190.10.10.1	P	00:03:42:fa:3b:30	10		1 2

Referenced ports are the ports that request the ARP entry. So the traffic coming into the referenced ports has the destination IP address. From the ARP entry (the referenced ports), this traffic needs to be forwarded to the egress port (port INT6 in the above example).

NOTE – If you have VMA turned on, the referenced port will be the designated port. If you have VMA turned off, the designated port will be the normal ingress port.

The Flag field is interpreted as follows:

Table 4-12 ARP Dump Flag Parameters

Flag	Description
P	Permanent entry created for switch IP interface.
P 4	Permanent entry created for Layer 4 proxy IP address or virtual server IP address.
R	Indirect route entry.
U	Unresolved ARP entry. The MAC address has not been learned.

`/info/l3/arp/addr` ARP Address List Information

IP address	IP mask	MAC address	VLAN	Flags
205.178.18.66	255.255.255.255	00:70:cf:03:20:04		P
205.178.50.1	255.255.255.255	00:70:cf:03:20:06	1	
205.178.18.64	255.255.255.255	00:70:cf:03:20:05	1	

`/info/l3/bgp` BGP Information Menu

```
[BGP Menu]
  peer      - Show all BGP peers
  summary   - Show all BGP peers in summary
  dump      - Show BGP routing table
```

Table 4-13 BGP Peer Information Menu Options

Command Syntax and Usage

peer

Displays BGP peer information. See [page 73](#) for a sample output.

summary

Displays peer summary information such as AS, message received, message sent, up/down, state. See [page 74](#) for a sample output.

dump

Displays the BGP routing table. See [page 74](#) for a sample output.

`/info/l3/ip/bgp/peer` BGP Peer information

Following is an example of the information that `/info/l3/ip/bgp/peer` provides.

```
BGP Peer Information:

3: 2.1.1.1          , version 0, TTL 1
  Remote AS: 0, Local AS: 0, Link type: IBGP
  Remote router ID: 0.0.0.0,   Local router ID: 1.1.201.5
  BGP status: idle, Old status: idle
  Total received packets: 0, Total sent packets: 0
  Received updates: 0, Sent updates: 0
  Keepalive: 0, Holdtime: 0, MinAdvTime: 60
  LastErrorCode: unknown(0), LastErrorSubcode: unspecified(0)
  Established state transitions: 0

4: 2.1.1.4          , version 0, TTL 1
  Remote AS: 0, Local AS: 0, Link type: IBGP
  Remote router ID: 0.0.0.0,   Local router ID: 1.1.201.5
  BGP status: idle, Old status: idle
  Total received packets: 0, Total sent packets: 0
  Received updates: 0, Sent updates: 0
  Keepalive: 0, Holdtime: 0, MinAdvTime: 60
  LastErrorCode: unknown(0), LastErrorSubcode: unspecified(0)
  Established state transitions: 0
```

`/info/l3/ip/bgp/summary` BGP Summary information

Following is an example of the information that `/info/l3/ip/bgp/summary` provides.

BGP Peer Summary Information:							
Peer	V	AS	MsgRcvd	MsgSent	Up/Down	State	

1: 205.178.23.142	4	142	113	121	00:00:28	established	
2: 205.178.15.148	0	148	0	0	never	connect	

`/info/l3/ip/bgp/dump` Dump BGP Information

Following is an example of the information that `/info/l3/ip/bgp/dump` provides.

```
>> BGP# dump
Status codes: * valid, > best, i - internal
Origin codes: i - IGP, e - EGP, ? - incomplete
  Network          Next Hop          Metr  LcPrf  Wght  Path
  -----
*> 10.0.0.0        205.178.21.147    1      256 147 148 i
*>i205.178.15.0    0.0.0.0           0      0 i
*                  205.178.21.147    1      128 147 i
*> 205.178.17.0    205.178.21.147    1      128 147 i
  13.0.0.0         205.178.21.147    1      256 147 {35} ?

The 13.0.0.0 is filtered out by rmap; or, a loop detected.
```

/info/l3/ospf

OSPF Information

```
[OSPF Information Menu]
general - Show general information
aindex  - Show area(s) information
if      - Show interface(s) information
virtual - Show details of virtual links
nbr     - Show neighbor(s) information
dbase   - Database Menu
sumaddr - Show summary address list
nsumadd - Show NSSA summary address list
routes  - Show OSPF routes
dump    - Show OSPF information
```

Table 4-14 OSPF Information Menu options

Command Syntax and Usage

general

Displays general OSPF information. See [page 76](#) for a sample output.

aindex <area index [0-2]>

Displays area information for a particular area index. If no parameter is supplied, it displays area information for all the areas.

if <interface number [1-128]>

Displays interface information for a particular interface. If no parameter is supplied, it displays information for all the interfaces. See [page 77](#) for a sample output.

virtual

Displays information about all the configured virtual links.

nbr <nbr router-id [A.B.C.D]>

Displays the status of a neighbor with a particular router ID. If no router ID is supplied, it displays the information about all the current neighbors.

dbase

Displays OSPF database menu. To view menu options, see [page 78](#).

sumaddr <area index [0-2]>

Displays the list of summary ranges belonging to non-NSSA areas.

nsumadd <area index [0-2]>

Displays the list of summary ranges belonging to NSSA areas.

Table 4-14 OSPF Information Menu options**Command Syntax and Usage****routes**

Displays OSPF routing table. See [page 79](#) for a sample output.

dump

Displays the OSPF information.

/info/l3/ospf/general

OSPF General Information

```

OSPF Version 2
Router ID: 10.10.10.1
Started at 1663 and the process uptime is 4626
Area Border Router: yes, AS Boundary Router: no
LS types supported are 6
External LSA count 0
External LSA checksum sum 0x0
Number of interfaces in this router is 2
Number of virtual links in this router is 1
16 new lsa received and 34 lsa originated from this router
Total number of entries in the LSDB 10
Database checksum sum 0x0
Total neighbors are 1, of which
                                2 are >=INIT state,
                                2 are >=EXCH state,
                                2 are =FULL state
Number of areas is 2, of which 3-transit 0-nssa
  Area Id : 0.0.0.0
  Authentication : none
  Import ASEextern : yes
  Number of times SPF ran : 8
  Area Border Router count : 2
  AS Boundary Router count : 0
  LSA count : 5
  LSA Checksum sum : 0x2237B
  Summary : noSummary

```

`/info/l3/ospf/if`

OSPF Interface Information

```
Ip Address 10.10.12.1, Area 0.0.0.1, Admin Status UP
Router ID 10.10.10.1, State DR, Priority 1
Designated Router (ID) 10.10.10.1, Ip Address 10.10.12.1
Backup Designated Router (ID) 10.10.14.1, Ip Address 10.10.12.2
Timer intervals, Hello 10, Dead 40, Wait 1663, Retransmit 5,
    Poll interval 0, Transit delay 1
Neighbor count is 1   If Events 4, Authentication type none
```

/info/l3/ospf/dbase

OSPF Database Information

```
[OSPF Database Menu]
advrtr  - LS Database info for an Advertising Router
asbrsum - ASBR Summary LS Database info
dbsumm  - LS Database summary
ext     - External LS Database info
nw      - Network LS Database info
nssa    - NSSA External LS Database info
rtr     - Router LS Database info
self    - Self Originated LS Database info
summ    - Network-Summary LS Database info
all     - All
```

Table 4-15 OSPF Database Information Menu (/info/l3/ospf/dbase)

Command Syntax and Usage

advrtr <router-id (A.B.C.D)>

Takes advertising router as a parameter. Displays all the Link State Advertisements (LSAs) in the LS database that have the advertising router with the specified router ID, for example: 20.1.1.1.

asbrsum <adv-rtr (A.B.C.D)> | <link_state_id (A.B.C.D)> | <self>

Displays ASBR summary LSAs. The usage of this command is as follows:

- a) `asbrsum adv-rtr 20.1.1.1` displays ASBR summary LSAs having the advertising router 20.1.1.1.
- b) `asbrsum link_state_id 10.1.1.1` displays ASBR summary LSAs having the link state ID 10.1.1.1.
- c) `asbrsum self` displays the self advertised ASBR summary LSAs.
- d) `asbrsum` with no parameters displays all the ASBR summary LSAs.

dbsumm

Displays the following information about the LS database in a table format:

- a) the number of LSAs of each type in each area.
- b) the total number of LSAs for each area.
- c) the total number of LSAs for each LSA type for all areas combined.
- d) the total number of LSAs for all LSA types for all areas combined.

No parameters are required.

ext <adv-rtr (A.B.C.D)> | <link_state_id (A.B.C.D)> | <self>

Displays the AS-external (type 5) LSAs with detailed information of each field of the LSAs. The usage of this command is the same as the usage of the command `asbrsum`.

Table 4-15 OSPF Database Information Menu (/info/l3/ospf/dbase)**Command Syntax and Usage**

nw <adv-rtr (A.B.C.D)> | <link_state_id (A.B.C.D)> | <self>

Displays the network (type 2) LSAs with detailed information of each field of the LSA.network LS database. The usage of this command is the same as the usage of the command `asbrsum`.

nssa <adv-rtr (A.B.C.D)> | <link_state_id (A.B.C.D)> | <self>

Displays the NSSA (type 7) LSAs with detailed information of each field of the LSAs. The usage of this command is the same as the usage of the command `asbrsum`.

rtr <adv-rtr (A.B.C.D)> | <link_state_id (A.B.C.D)> | <self>

Displays the router (type 1) LSAs with detailed information of each field of the LSAs. The usage of this command is the same as the usage of the command `asbrsum`.

self

Displays all the self-advertised LSAs. No parameters are required.

summ <adv-rtr (A.B.C.D)> | <link_state_id (A.B.C.D)> | <self>

Displays the network summary (type 3) LSAs with detailed information of each field of the LSAs. The usage of this command is the same as the usage of the command `asbrsum`.

all

Displays all the LSAs.

/info/l3/ospf/routes

OSPF Information Route Codes

```
Codes: IA - OSPF inter area,
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2
IA 10.10.0.0/16 via 200.1.1.2
IA 40.1.1.0/28 via 20.1.1.2
IA 80.1.1.0/24 via 200.1.1.2
IA 100.1.1.0/24 via 20.1.1.2
IA 140.1.1.0/27 via 20.1.1.2
IA 150.1.1.0/28 via 200.1.1.2
E2 172.18.1.1/32 via 30.1.1.2
E2 172.18.1.2/32 via 30.1.1.2
E2 172.18.1.3/32 via 30.1.1.2
E2 172.18.1.4/32 via 30.1.1.2
E2 172.18.1.5/32 via 30.1.1.2
E2 172.18.1.6/32 via 30.1.1.2
E2 172.18.1.7/32 via 30.1.1.2
E2 172.18.1.8/32 via 30.1.1.2
```

`/info/igmp`

IGMP Multicast Group Information

[IGMP Menu]	
<code>snoop</code>	- Show IGMP Snooping Multicast Group Information
<code>mrouter</code>	- Show IGMP Snooping Multicast Router Port information

Table 4-16 describes the commands used to display information about IGMP groups learned by the switch.

Table 4-16 IGMP Multicast Group Menu Options (`/info/igmp`)

Command Syntax and Usage

snoop

Displays a single IGMP multicast group information.

mrouter

Displays static Multicast Router information.

`/info/igmp/snoop`

IGMP Multicast Router Port Information

[IGMP Snooping Menu]	
<code>find</code>	- Show a single group by IP group address
<code>vlan</code>	- Show groups on a single vlan
<code>port</code>	- Show groups on a single port
<code>dump</code>	- Show all groups

Table 4-17 describes the commands used to display information about IGMP groups learned by the switch.

Table 4-17 IGMP Multicast Group Menu Options (`/info/igmp/snoop`)

Command Syntax and Usage

find <IP address>

Displays a single IGMP multicast group by its IP address.

vlan <VLAN number>

Displays all IGMP multicast groups on a single VLAN.

Table 4-17 IGMP Multicast Group Menu Options (/info/igmp/snoop)

Command Syntax and Usage

port <Port number or alias>

Displays all IGMP multicast groups on a single port.

dumpDisplays information for all multicast groups.

/info/igmp/mrouter

IGMP Multicast Router Port Information

```
[IGMP Multicast Router Ports Menu]
```

```
vlan - Show all learned multicast router ports on a single vlan
```

```
dump - Show all learned multicast router ports
```

```
versions - Show last detected multicast router IGMP versions
```

[Table 4-18](#) describes the commands used to display information about multicast routers learned through IGMP Snooping.

Table 4-18 IGMP Multicast Router Menu Options (/info/igmp/mrouter)

Command Syntax and Usage

vlan

Displays information for all multicast groups learned on the selected VLAN.

dump

Displays information for all multicast groups learned by the switch.

versionsDisplays the IGMP version of the most recent multicast group learned by the switch.

/info/l3/ip

IP Information

```

Interface information:
  1: 47.80.23.243    255.255.254.0    47.80.23.255,    vlan 1, up
Default gateway information: metric strict
  1: 47.80.22.1,    vlan any, up
Current IP forwarding settings: ON, dirbr disabled
Current local networks:
Current IP port settings:
  All other ports have forwarding ON
Current network filter settings:
  none
Current route map settings:
Current BGP settings:
  ON, pref 100
Current BGP peer settings:
Current BGP aggr settings:

```

/info/l3/vrrp

VRRP Information

Virtual Router Redundancy Protocol (VRRP) support on GbE Switch Module provides redundancy between routers in a LAN. This is accomplished by configuring the same virtual router IP address and ID number on each participating VRRP-capable routing device. One of the virtual routers is then elected as the master, based on a number of priority criteria, and assumes control of the shared virtual router IP address. If the master fails, one of the backup virtual routers will assume routing authority and take control of the virtual router IP address.

```

VRRP information:
  1: vrid 2, 205.178.18.210, if 1, reater, prio 100, master, server
  2: vrid 1, 205.178.18.202, if 1, reater, prio 100, backup
  3: vrid 3, 205.178.18.204, if 1, reater, prio 100, master, proxy

```

When virtual routers are configured, you can view the status of each virtual router using this command. VRRP information includes:

- Virtual router number
- Virtual router ID and IP address
- Interface number

- Ownership status
 - `owner` identifies the preferred master virtual router. A virtual router is the owner when the IP address of the virtual router and its IP interface are the same.
 - `renter` identifies virtual routers which are not owned by this device.
- Priority value. During the election process, the virtual router with the highest priority becomes master.
- Activity status
 - `master` identifies the elected master virtual router.
 - `backup` identifies that the virtual router is in backup mode.
 - `init` identifies that the virtual router is waiting for a startup event. Once it receives a startup event, it transitions to master if its priority is 255, (the IP address owner), or transitions to backup if it is not the IP address owner.
- Server status. The `server` state identifies virtual routers that support Layer 4 services. These are known as virtual *server* routers: any virtual router whose IP address is the same as any configured virtual server IP address.
- Proxy status. The proxy state identifies virtual proxy routers, where the virtual router shares the same IP address as a proxy IP address. The use of virtual proxy routers enables redundant switches to share the same IP address, minimizing the number of unique IP addresses that must be configured.

/info/slb

SLB Information

```
[Server Load Balancing Information Menu]
sess      - Session Table Information Menu
real      - Show real server information
virt      - Show virtual server information
filt      - Show filter information
port      - Show port information
idshash   - Show IDS server selected by hash or minmisses metric
bind      - Show real server selected by hash or minmisses metric
cookie    - Decode the HEX value to get the VIP and RIP
synatk    - Show SYN attack detection information
dump      - Show all layer 4 information
```

Layer 4 information includes the following:

Table 4-19 Layer 4 Information Menu Options (/info/slb)

Command Syntax and Usage

sess

Displays the Session Table Information Menu. To view menu options, see [page 85](#).

real <real server number (1-63)>

Displays Real server number, real IP address, MAC address, VLAN, physical switch port, layer where health check is performed, and health check result.

virt <virtual server number (1-64)>

- Displays Virtual Server State: Virtual server number, IP address, virtual MAC address
- Virtual Port State: Virtual service or port, server port mapping, real server group, group backup server.

filt <filter ID (1-1024)> | **list** | **allow** | **deny** | **redir** | **nat**

Displays the filter number, destination port, real server port, real server group, health check layer, group backup server, URL for health checks, and real server group, IP address, backup server, and status.

port <port alias or number>

Displays the physical port number, proxy IP address, filter status, a list of applied filters, and client and/or server Layer 4 activity.

idshash <IP address 1> <IP address 2>

Displays the Intrusion Detection System server selected by hash or minmisses metric.

bind <IP address> <mask> <group number>

Displays the real server selected by hash or minmisses metric.

Table 4-19 Layer 4 Information Menu Options (/info/slb)**Command Syntax and Usage**

cookie <16 bytes cookie value in hexadecimal format as 0XXXXXXXXXXXXXXXXXX>

Decodes the hexadecimal value to get the virtual server IP address and real server IP address.

synatk

Displays SYN attack detection information. To identify whether or not the server is under SYN attack, the number of new half open sessions is examined within a set period of time, for example, every two seconds. This feature requires `dbind` to be enabled.

dump

Displays all Layer 4 information for the switch. For details, see [page 90](#).

/info/slb/sess

Session Table Information

```
[Session Table Information Menu]
  cip      - Show all session entries with source IP address
  cport    - Show all session entries with source port
  dip      - Show all session entries with destination IP address
  dport    - Show all session entries with destination port
  pip      - Show all session entries with proxy IP address
  pport    - Show all session entries with proxy port
  filter   - Show all session entries with matching filter
  flag     - Show all session entries with matching flag
  port     - Show all session entries with ingress port
  real     - Show all session entries with real IP address
  sp       - Show all session entries on sp
  dump     - Show all session entries
  help     - Session entry description
```

Table 4-20 Session Information Menu Options (/info/slb/sess)**Command Syntax and Usage**

cip <IP address>

Displays all session entries with client's source IP address.

cport <real port>

Displays all session entries with source (client) port.

dip <IP address>

Displays all session entries with destination IP address.

Table 4-20 Session Information Menu Options (/info/slb/sess)

Command Syntax and Usage

dport <real port>

Displays all session entries with destination port.

pip <IP address>

Displays all session entries with proxy IP address.

pport <proxy port>

Displays all session entries with proxy port.

filter <filter ID (1-1024)>

Displays all session entries with matching filter.

flag <E|L|N|P|S|T|U|W>

Displays all session entries with matching flag.

port <port number or alias>

Displays all session entries on the ingress port.

real <IP address>

Displays all session entries with real server IP address.

sp <port number (1-4)>

Displays all session entries on switch processor.

dump

Displays all session entries. Information similar to the following may appear in a session entry dump:

```

3, 01: 1.1.1.1 4586, 2.2.2.1 http -> 1.1.1.2 3567 3.3.3.1 http age 6 f:10 EUSPT c
(1) (2) (3) (4) (5) (6) (7a) (7) (8) (9) (10) (11) (12) (13)

```

Note: The fields, 1 to 13 associated with a session as identified in the above example, are described in [“Session dump information in Alteon OS” on page 88](#).

helpDisplays the description of the session entry.

Samples of Session Dumps for Different Applications

L4 HTTP

3,01: 172.21.12.19 1040, 39.2.2.1 http -> 47.81.24.79 http age 4

L4-L7 WCR HTTP

2,16: 172.21.8.200 44687, 172.21.8.51 http -> 192.168.1.11 wcr age 4 f:12 E

3,01: 172.21.12.19 1040, 39.2.2.1 http -> 47.81.24.79 urlwcr age 6 f:123 E

RTSP

L4-L7 RTSP

3,01: 172.21.12.19 4586, 39.2.2.1 rtsp -> 47.81.144.13 rtsp age 10 EU

3,01: 172.21.12.19 6970, 39.2.2.1 21220 -> 47.81.144.13 21220 age 10 P

The first session is RTSP TCP control connection.

The second session is RTSP UDP data connection.

3,01: 172.21.12.19 6970, 39.2.2.1 rtsp -> 47.81.144.13 0 age 10 P

During client-server port negotiation, the destination port shows “rtsp” and server port shows “0”

L7 WCR RTSP

3,01: 172.21.12.19 4586, 39.2.2.1 rtsp -> 47.81.144.13 urlwcr age 10 f:100 EU

3,01: 172.21.12.19 6970, 39.2.2.1 21220 -> 47.81.144.13 21220 age 10 P

Filtering LinkLB

2,07: 10.0.1.26 1706, 205.178.14.84 http -> 192.168.4.10 linklb age 8 f:10 E

FTP

1,00: 172.31.4.215 80, 172.31.4.200 0 172.31.3.11 age 8 EP c:1

1,09: 172.31.4.215 4098, 172.31.4.200 ftp ->172.31.3.20 ftp age 10 EU

1,09: 172.31.4.215 4102, 172.31.4.200 ftp-data ->172.31.3.20 ftp-data age 10 E

NAT

2,05: 172.21.8.16 2559, 10.0.1.26 http NAT age 2 f:24 E

Persistent session

3,00: 237.162.52.123 160.10.20.30 age 4 EPS C:3

The destination port, real server IP and server port are not shown for persistent session.

Session dump information in Alteon OS

Field	Description
(1) SP number	This field indicates the Switch Port number that created the session.
(2) Ingress port	This field shows the physical port through which the client traffic enters the switch.
(3) Source IP address	This field contains the source IP address from the client's IP packet.
(4) Source port	This field identifies the source port from the client's TCP/UDP packet.
(5) Destination IP address	This field identifies the destination IP address from the client's TCP/UDP packet.
(6) Destination port	This field identifies the destination port from client's TCP/UDP packet.
(7a) Proxy IP address	<p>This field contains the Proxy IP address substituted by the switch. This field contains the real server IP address of the corresponding server that the switch selects to forward the client packet to, for load balancing. If the switch does not find a live server, this field contains the same as the destination IP address mentioned in field (5).</p> <p>This field also shows the real server IP address for filtering. No address is shown if the filter action is Allow, Deny or NAT. It will show "ALLOW", "DENY" or "NAT" instead.</p>
(7) Proxy Port	This field identifies the TCP/UDP source port substituted by the switch.
(8) Real Server IP Address	<p>For load balancing, this field contains the IP address of the real server that the switch selects to forward client packet to. If the switch does not find live server, this field is the same as destination IP address(5). For example: 3,01: 1.1.1.1 1040, 2.2.2.1 http -> 3.3.3.1 http age 10 3,01: 1.1.1.1 6970, 2.2.2.1 rtsp -> 2.2.2.1 21220 age 10 P</p> <p>For filtering, this field also shows the real server IP address. No address is shown if the filter action is Allow, Deny or NAT. It will show ALLOW, DENY or NAT instead. For example: 3,01: 1.1.1.1 1040, 2.2.2.1 http -> 3.3.3.1 http age 10 f:11 2,07: 1.1.1.1 1706, 2.2.2.1 http-> 192.168.4.10 linklb age 8 f:10 E</p>

Field	Description
(9) Server port	<p>This field is the same as the destination port (field 6) for load balancing except for the RTSP UDP session. For RTSP UDP session, this server port is obtained from the client-server negotiation.</p> <p>This field is the filtering application port for filtering. It is for internal use only. This field can be “urlwcr”, “wcr”, “idslb”, “linkslb” or “nonat”.</p>
(10) Age	<p>This is the session timeout value. If no packet is received within the value specified, the session is freed.</p>
(11) Filter number	<p>This field indicates the session created by filtering code as a result of the IP header keys matching the filtering criteria.</p>
(12) Flag	<p>“E”: Indicates the session is in use and will be aged out if no traffic is received within session timeout value.</p> <p>“P”: Indicates the session is a persistent session and is not to be aged out. Fields (6), (7) and (8) cannot not have persistent session.</p> <p>“U”: Indicates the session is L7 delayed binding and the switch is trying to open TCP connection to the real server.</p> <p>“S”: Indicates the session is persistent session and the application is special SSL or Cookie Pbind.</p> <p>“T”: Indicates the session is TCP rate limiting per-client entry.</p>
(13) Persistent session user count	<p>This counter indicates the number of client sessions created to associate with this persistent session.</p>

/info/slb/dump

Show All Layer 4 Information

```

Real server state:
  1: 210.1.2.200, 00:01:02:c1:4b:48, vlan 1, port 1, health 3, up
  2: 210.1.2.1, 00:01:02:70:4d:4a, vlan 1, port 8, health 3, up
 26: 20.20.20.102, 00:03:47:07:a4:9e, vlan 1, port 6, health 3, up
 27: 20.20.20.101, 00:01:02:71:9c:a6, vlan 1, port 7, health 3, up

Virtual server state:
  1: 20.20.20.200,    00:60:cf:47:5c:1e
    virtual ports:
      http: rport http, group 88, backup none, dbind
      HTTP Application: urlslb
        real servers:
          26: 20.20.20.102, backup none, 2 ms, up
              exclusionary string matching: disabled
              1: any
              2: urlone
          27: 20.20.20.101, backup none, 1 ms, up
              exclusionary string matching: disabled
              3: urltwo
              4: urlthree

Redirect filter state:
Action redir
dport http, rport 3128, vlan any
200: group 1, health 3, backup none
    proxy enabled, radius snoop disabled
    real servers:
      1: 210.1.2.200, backup none, 3 ms, up
      2: 210.1.2.1, backup none, 2 ms, up

Port state:
  1: filt disabled, filters: 80
  2: idslb filt  enabled, filters: 200
  3: idslb filt  enabled, filters: 200
  4: filt disabled, filters: 50 200

```

/info/link

Link Status Information

Alias	Port	Speed	Duplex	Flow Ctrl		Link
----	-----	-----	-----	--TX----	----RX--	-----
INT1	1	1000	full	yes	yes	up
INT2	2	1000	full	yes	yes	up
INT3	3	1000	full	yes	yes	up
INT4	4	1000	full	yes	yes	up
INT5	5	1000	full	yes	yes	down
INT6	6	1000	full	yes	yes	up
INT7	7	1000	full	yes	yes	up
INT8	8	1000	full	yes	yes	up
INT9	9	1000	full	yes	yes	up
INT10	10	1000	full	yes	yes	up
INT11	11	1000	full	yes	yes	up
INT12	12	1000	full	yes	yes	up
INT13	13	1000	full	yes	yes	up
INT14	14	1000	full	yes	yes	up
MGT1	15	100	full	yes	yes	up
MGT2	16	100	full	yes	yes	down
EXT1	17	any	any	yes	yes	up
EXT2	18	any	any	yes	yes	up
EXT3	19	any	any	yes	yes	up
EXT4	20	any	any	yes	yes	up

NOTE – The sample screens that appear in this document might differ slightly from the screens displayed by your system. Screen content varies based on the type of BladeCenter unit that you are using and the firmware versions and options that are installed.

Use this command to display link status information about each port on an GbE Switch Module slot, including:

- Port alias
- Port speed (10, 100, 10/100, or 1000)
- Duplex mode (half, full, any, or auto)
- Flow control for transmit and receive (no, yes, or auto)
- Link status (up or down)

/info/port

Port Information

Alias	Port	Tag	FAST	RMON	PVID	NAME	VLAN(s)
INT1	1	y	n	d	1	INT1	1 4095
INT2	2	y	n	d	1	INT2	1 4095
INT3	3	y	n	d	1	INT3	1 4095
INT4	4	y	n	d	1	INT4	1 4095
INT5	5	y	n	d	1	INT5	1 4095
INT6	6	y	n	d	1	INT6	1 4095
INT7	7	y	n	d	1	INT7	1 4095
INT8	8	y	n	d	1	INT8	1 4095
INT9	9	y	n	d	1	INT9	1 4095
INT10	10	y	n	d	1	INT10	1 4095
INT11	11	y	n	d	1	INT11	1 4095
INT12	12	y	n	d	1	INT12	1 4095
INT13	13	y	n	d	1	INT13	1 4095
INT14	14	y	n	d	1	INT14	1 4095
MGT1	15	y	n	d	4095	MGT1	4095
MGT2	16	y	n	d	4095	MGT2	4095
EXT1	17	n	n	d	1	EXT1	1
EXT2	18	n	n	d	1	EXT2	1
EXT3	19	n	n	d	1	EXT3	1
EXT4	20	n	n	d	1	EXT4	1

NOTE – The sample screens that appear in this document might differ slightly from the screens displayed by your system. Screen content varies based on the type of BladeCenter unit that you are using and the firmware versions and options that are installed.

Port information includes:

- Port alias
- Whether the port uses VLAN tagging or not (y or n)
- Port VLAN ID (PVID)
- Port name
- VLAN membership
- Whether RMON is enabled or disabled on the port

`/info/dump`

Information Dump

Use the dump command to dump all switch information available from the Information Menu (10K or more, depending on your configuration). This data is useful for tuning and debugging switch performance.

If you want to capture dump data to a file, set your communication software on your workstation to capture session data prior to issuing the dump commands.

CHAPTER 5

The Statistics Menu

You can view switch performance statistics in both the user and administrator command modes. This chapter discusses how to use the command line interface to display switch statistics.

/stats

Statistics Menu

```
[Statistics Menu]
  port      - Port Stats Menu
  l2        - Layer 2 Stats Menu
  l3        - Layer 3 Stats Menu
  slb       - Server Load Balancing (L4-7) Stats Menu
  mp        - MP-specific Stats Menu
  sp        - SP-specific Stats Menu
  pace      - Packet Acceleration Stats Menu
  snmp      - Show SNMP stats
  ntp       - Show NTP stats
  dump      - Dump all stats
```

Table 5-1 Statistics Menu Options (/stats)

Command Syntax and Usage

port <port alias or number>

Displays the Port Statistics Menu for the specified port. Use this command to display traffic statistics on a port-by-port basis. Traffic statistics are included in SNMP Management Information Base (MIB) objects. To view menu options, see [page 97](#).

l2

Displays the Layer 2 Stats Menu. To view menu options, see [page 108](#).

l3

Displays the Layer 3 Stats Menu. To view menu options, see [page 110](#).

slb

Displays the Server Load Balancing (SLB) Menu. To view menu options, see [page 130](#).

mp

Displays the Management Processor Statistics Menu. Use this command to view information on how switch management processes and resources are currently being allocated. To view menu options, see [page 153](#).

sp <SP number (1-4)>

Displays Switch Processor specific menu. To view menu options, see [page 156](#).

pace

Displays Packet Acceleration Stats Menu. To view menu options, see [page 157](#).

snmp

Displays SNMP statistics. See [page 158](#) for sample output.

ntp <clear>

Displays Network Time Protocol (NTP) Statistics. See page 216 for a sample output and a description of NTP Statistics.

You can execute the `clear` command option to delete all statistics.

dump

Dumps all switch statistics. Use this command to gather data for tuning and debugging switch performance. If you want to capture dump data to a file, set your communication software on your workstation to capture session data prior to issuing the dump command. For details, see [page 162](#).

`/stats/port <port alias or number>` **Port Statistics Menu**

This menu displays traffic statistics on a port-by-port basis. Traffic statistics include SNMP Management Information Base (MIB) objects.

```
[Port Statistics Menu]
brg      - Show bridging ("dot1") stats
ether    - Show Ethernet ("dot3") stats
if       - Show interface ("if") stats
ip       - Show Internet Protocol ("IP") stats
link     - Show link stats
rmon     - Show RMON stats
dump     - Dump port stats
clear    - Clear all port stats
```

Table 5-2 Port Statistics Menu Options (`/stats/port`)

Command Syntax and Usage

brg

Displays bridging ("dot1") statistics for the port. See [page 98](#) for sample output.

ether

Displays Ethernet ("dot1") statistics for the port. See [page 99](#) for sample output.

if

Displays interface statistics for the port. See [page 102](#) for sample output.

ip

Displays IP statistics for the port. See [page 104](#) for sample output.

link

Displays link statistics for the port. See [page 105](#) for sample output.

rmon

Displays RMON statistics for the port. See [page 105](#) for sample output.

dump

Displays all the port statistics.

clear

This command clears all the statistics on the port.

/stats/port <port alias or number>/brg **Bridging Statistics**

This menu option enables you to display the bridging statistics of the selected port.

```
Bridging statistics for port INT1:
dot1PortInFrames:           63242584
dot1PortOutFrames:         63277826
dot1PortInDiscards:        0
dot1TpLearnedEntryDiscards: 0
dot1BasePortDelayExceededDiscards: NA
dot1BasePortMtuExceededDiscards: NA
dot1StpPortForwardTransitions: 0
```

Table 5-3 Bridging Statistics of a Port (/stats/port/brg)

Statistics	Description
dot1PortInFrames	The number of frames that have been received by this port from its segment. A frame received on the interface corresponding to this port is only counted by this object if and only if it is for a protocol being processed by the local bridging function, including bridge management frames.
dot1PortOutFrames	The number of frames that have been transmitted by this port to its segment. Note that a frame transmitted on the interface corresponding to this port is only counted by this object if and only if it is for a protocol being processed by the local bridging function, including bridge management frames.
dot1PortInDiscards	Count of valid frames received which were discarded (that is, filtered) by the Forwarding Process.
dot1TpLearnedEntry Discards	The total number of Forwarding Database entries, which have been or would have been learnt, but have been discarded due to a lack of space to store them in the Forwarding Database. If this counter is increasing, it indicates that the Forwarding Database is regularly becoming full (a condition which has unpleasant performance effects on the subnetwork). If this counter has a significant value but is not presently increasing, it indicates that the problem has been occurring but is not persistent.
dot1BasePortDelay ExceededDiscards	The number of frames discarded by this port due to excessive transit delay through the bridge. It is incriminated by both transparent and source route bridges.
dot1BasePortMtu ExceededDiscards	The number of frames discarded by this port due to an excessive size. It is incremented by both transparent and source route bridges.
dot1StpPortForward Transitions	The number of times this port has transitioned from the Learning state to the Forwarding state.

`/stats/port <port alias or number>/ether` Ethernet Statistics

This menu option enables you to display the ethernet statistics of the selected port

```

Ethernet statistics for port INT1:
dot3StatsAlignmentErrors:                0
dot3StatsFCSErrors:                      0
dot3StatsSingleCollisionFrames:          0
dot3StatsMultipleCollisionFrames:        0
dot3StatsSQETestErrors:                  NA
dot3StatsDeferredTransmissions:          0
dot3StatsLateCollisions:                 0
dot3StatsExcessiveCollisions:            0
dot3StatsInternalMacTransmitErrors:      NA
dot3StatsCarrierSenseErrors:             0
dot3StatsFrameTooLongs:                  0
dot3StatsInternalMacReceiveErrors:       0
dot3CollFrequencies [1-15]:              NA

```

Table 5-4 Ethernet Statistics for Port (`/stats/port/ether`)

Statistics	Description
<code>dot3StatsAlignmentErrors</code>	<p>A count of frames received on a particular interface that are not an integral number of octets in length and do not pass the Frame Check Sequence (FCS) check.</p> <p>The count represented by an instance of this object is incremented when the <code>alignmentError</code> status is returned by the MAC service to the Logical Link Control (LLC) (or other MAC user). Received frames for which multiple error conditions obtained are, according to the conventions of IEEE 802.3 Layer Management, counted exclusively according to the error status presented to the LLC.</p>
<code>dot3StatsFCSErrors</code>	<p>A count of frames received on a particular interface that are an integral number of octets in length but do not pass the Frame Check Sequence (FCS) check.</p> <p>The count represented by an instance of this object is incremented when the <code>frameCheckError</code> status is returned by the MAC service to the LLC (or other MAC user). Received frames for which multiple error conditions obtained are, according to the conventions of IEEE 802.3 Layer Management, counted exclusively according to the error status presented to the LLC.</p>

Table 5-4 Ethernet Statistics for Port (/stats/port/ether)

Statistics	Description
dot3StatsSingleCollisionFrames	A count of successfully transmitted frames on a particular interface for which transmission is inhibited by exactly one collision. A frame that is counted by an instance of this object is also counted by the corresponding instance of either the <code>ifOutUcastPkts</code> , <code>ifOutMulticastPkts</code> , or <code>ifOutBroadcastPkts</code> , and is not counted by the corresponding instance of the <code>dot3StatsMultipleCollisionFrame</code> object.
dot3StatsMultipleCollisionFrames	A count of successfully transmitted frames on a particular interface for which transmission is inhibited by more than one collision. A frame that is counted by an instance of this object is also counted by the corresponding instance of either the <code>ifOutUcastPkts</code> , <code>ifOutMulticastPkts</code> , or <code>ifOutBroadcastPkts</code> , and is not counted by the corresponding instance of the <code>dot3StatsSingleCollisionFrames</code> object.
dot3StatsSQETestErrors	A count of times that the SQE TEST ERROR message is generated by the PLS sub layer for a particular interface. The SQE TEST ERROR message is defined in section 7.2.2.2.4 of ANSI/IEEE 802.3-1985 and its generation is described in section 7.2.4.6 of the same document.
dot3StatsDeferredTransmissions	A count of frames for which the first transmission attempt on a particular interface is delayed because the medium is busy. The count represented by an instance of this object does not include frames involved in collisions.
dot3StatsLateCollisions	The number of times that a collision is detected on a particular interface later than 512 bit-times into the transmission of a packet. Five hundred and twelve bit-times corresponds to 51.2 microseconds on a 10 Mbit/s system. A (late) collision included in a count represented by an instance of this object is also considered as a (generic) collision for purposes of other collision-related statistics.
dot3StatsExcessiveCollisions	A count of frames for which transmission on a particular interface fails due to excessive collisions.
dot3StatsInternalMacTransmitErrors	A count of frames for which transmission on a particular interface fails due to an internal MAC sub layer transmit error. A frame is only counted by an instance of this object if it is not counted by the corresponding instance of either the <code>dot3StatsLateCollisions</code> object, the <code>dot3StatsExcessiveCollisions</code> object, or the <code>dot3StatsCarrierSenseErrors</code> object. The precise meaning of the count represented by an instance of this object is implementation-specific. In particular, an instance of this object may represent a count of transmission errors on a particular interface that are not otherwise counted.

Table 5-4 Ethernet Statistics for Port (/stats/port/ether)

Statistics	Description
dot3StatsCarrier-SenseErrors	The number of times that the carrier sense condition was lost or never asserted when attempting to transmit a frame on a particular interface. The count represented by an instance of this object is incremented at most once per transmission attempt, even if the carrier sense condition fluctuates during a transmission attempt.
dot3StatsFrameTooLongs	A count of frames received on a particular interface that exceed the maximum permitted frame size. The count represented by an instance of this object is incremented when the <code>frameTooLong</code> status is returned by the MAC service to the LLC (or other MAC user). Received frames for which multiple error conditions obtained are, according to the conventions of IEEE 802.3 Layer Management, counted exclusively according to the error status presented to the LLC.
dot3StatsInternal-MacReceiveErrors	A count of frames for which reception on a particular interface fails due to an internal MAC sub layer receive error. A frame is only counted by an instance of this object if it is not counted by the corresponding instance of either the <code>dot3StatsFrameTooLongs</code> object, the <code>dot3StatsAlignmentErrors</code> object, or the <code>dot3StatsFCSErrors</code> object. The precise meaning of the count represented by an instance of this object is implementation-specific. In particular, an instance of this object may represent a count of received errors on a particular interface that are not otherwise counted.
dot3Coll-Frequencies	A count of individual MAC frames for which the transmission (successful or otherwise) on a particular interface occurs after the frame has experienced exactly the number of collisions in the associated <code>dot3CollCount</code> object. For example, a frame which is transmitted on interface <code>77</code> after experiencing exactly 4 collisions would be indicated by incrementing only <code>dot3CollFrequencies.77.4</code> . No other instance of <code>dot3CollFrequencies</code> would be incremented in this example.

`/stats/port <port alias or number>/if` **Interface Statistics**

This menu option enables you to display the interface statistics of the selected port.

Interface statistics for port EXT1:		
	ifHCIn Counters	ifHCOut Counters
Octets:	51697080313	51721056808
UcastPkts:	65356399	65385714
BroadcastPkts:	0	6516
MulticastPkts:	0	0
Discards:	0	0
Errors:	0	21187

Table 5-5 Interface Statistics for Port (`/stats/port/if`)

Statistics	Description
<code>ifInOctets</code>	The total number of octets received on the interface, including framing characters.
<code>ifInUcastPkts</code>	The number of packets, delivered by this sub-layer to a higher sub-layer, which were not addressed to a multicast or broadcast address at this sub-layer.
<code>ifInBroadcastPkts</code>	The number of packets, delivered by this sub-layer to a higher sub-layer, which were addressed to a broadcast address at this sub-layer.
<code>ifInMulticastPkts</code>	The total number of packets that higher-level protocols requested to be transmitted, and which were addressed to a multicast address at this sub-layer, including those that were discarded or not sent. For a MAC layer protocol, this includes both Group and Functional addresses.
<code>ifInDiscards</code>	The number of inbound packets which were chosen to be discarded even though no errors had been detected to prevent their being delivered to a higher-layer protocol. One possible reason for discarding such a packet could be to free up buffer space.
<code>ifInErrors</code>	For packet-oriented interfaces, the number of inbound packets that contained errors preventing them from being delivered to a higher-layer protocol. For character-oriented or fixed-length interfaces, the number of inbound transmission units that contained errors preventing them from being deliverable to a higher-layer protocol.

Table 5-5 Interface Statistics for Port (/stats/port/if)

Statistics	Description
<code>ifInUnknownProtos</code>	For packet-oriented interfaces, the number of packets received via the interface which were discarded because of an unknown or unsupported protocol. For character-oriented or fixed-length interfaces which support protocol multiplexing, the number of transmission units received via the interface which were discarded because of an unknown or unsupported protocol. For any interface which does not support protocol multiplexing, this counter will always be 0.
<code>ifOutOctets</code>	The total number of octets transmitted out of the interface, including framing characters.
<code>ifOutUcastPkts</code>	The total number of packets that higher-level protocols requested to be transmitted, and which were not addressed to a multicast or broadcast address at this sub-layer, including those that were discarded or not sent.
<code>ifOutBroadcastPkts</code>	The total number of packets that higher-level protocols requested to be transmitted, and which were addressed to a broadcast address at this sub-layer, including those that were discarded or not sent. This object is a 64-bit version of <code>ifOutBroadcastPkts</code> .
<code>ifOutMulticastPkts</code>	The total number of packets that higher-level protocols requested to be transmitted, and which were addressed to a multicast address at this sub-layer, including those that were discarded or not sent. For a MAC layer protocol, this includes both Group and Functional addresses. This object is a 64-bit version of <code>ifOutMulticastPkts</code> .
<code>ifOutDiscards</code>	The number of outbound packets which were chosen to be discarded even though no errors had been detected to prevent their being transmitted. One possible reason for discarding such a packet could be to free up buffer space.
<code>ifOutErrors</code>	For packet-oriented interfaces, the number of outbound packets that could not be transmitted because of errors. For character-oriented or fixed-length interfaces, the number of outbound transmission units that could not be transmitted because of errors.

`/stats/port <port alias or number>/ip` Interface Protocol Statistics

This menu option enables you to display the interface statistics of the selected port.

IP statistics for port INT1:			
ipInReceives:	0		
ipInAddrErrors:	0	ipForwDatagrams:	0
ipInUnknownProtos:	0	ipInDiscards:	0
ipInDelivers:	0		
ipTtlExceeds:	0		
ipLANDattacks:	0		

Table 5-6 Interface Protocol Statistics (`/stats/port/ip`)

Statistics	Description
ipInReceives	The total number of input datagrams received from interfaces, including those received in error.
ipInAddrErrors	The number of input datagrams discarded because the IP address in their IP header's destination field was not a valid address to be received at this entity (the switch). This count includes invalid addresses (for example, 0.0.0.0) and addresses of unsupported Classes (for example, Class E). For entities which are not IP Gateways and therefore do not forward datagrams, this counter includes datagrams discarded because the destination address was not a local address.
ipForwDatagrams	The number of input datagrams for which this entity (the switch) was not their final IP destination, as a result of which an attempt was made to find a route to forward them to that final destination. In entities which do not act as IP Gateways, this counter will include only those packets which were Source-Routed via this entity (the switch), and the Source-Route option processing was successful.
ipInUnknownProtos	The number of locally-addressed datagrams received successfully but discarded because of an unknown or unsupported protocol.
ipInDiscards	The number of input IP datagrams for which no problems were encountered to prevent their continued processing, but which were discarded (for example, for lack of buffer space). Note that this counter does not include any datagrams discarded while awaiting re-assembly.
ipInDelivers	The total number of input datagrams successfully delivered to IP user-protocols (including ICMP).
ipTtlExceeds	The number of IP datagram for which an ICMP TTL exceeded message was sent.

`/stats/port <port alias or number>/link` Link Statistics

This menu enables you to display the link statistics of the selected port.

```
Link statistics for port INT1:
linkStateChange:          1
```

Table 5-7 Link Statistics (/stats/port/link)

Statistics	Description
linkStateChange	The total number of link state changes.

`/stats/port <port alias or number>/rmon` RMON Statistics

This menu option enables you to display the remote monitor statistics of the selected port.

```
RMON statistics for port EXT1:
etherStatsDropEvents:          0
etherStatsOctets:              3727038769
etherStatsPkts:                69869242
etherStatsBroadcastPkts:      0
etherStatsMulticastPkts:      0
etherStatsCRCAlignErrors:     0
etherStatsUndersizePkts:      0
etherStatsOversizePkts:       0
etherStatsFragments:          0
etherStatsJabbers:             0
etherStatsCollisions:         0
etherStatsPkts64Octets:       102426
etherStatsPkts65to127Octets:  6050515
etherStatsPkts128to255Octets: 12293234
etherStatsPkts256to511Octets: 24586063
etherStatsPkts64Octets:       49171870
etherStatsPkts1024to1518Octets: 47539775
```

Table 5-8 Remote Monitor Statistics (/stats/port/rmon)

Statistics	Description
<code>etherStatsDropEvents</code>	The total number of events in which packets were dropped by the probe due to lack of resources. Note that this number is not necessarily the number of packets dropped; it is just the number of times this condition has been detected.
<code>etherStatsOctets</code>	<p>The total number of octets of data (including those in bad packets) received on the network (excluding framing bits but including FCS octets).</p> <p>This object can be used as a reasonable estimate of utilization (which is the percent utilization of the ethernet segment). If greater precision is desired, the <code>etherStatsPkts</code> and <code>etherStatsOctets</code> objects should be sampled before and after a common interval. The differences in the sampled values are <code>Pkts</code> and <code>Octets</code>, respectively, and the number of seconds in the interval is <code>Interval</code>. These values are used to calculate the utilization as follows:</p> $\text{Utilization} = \frac{\text{Pkts} \times (9.6 + 6.4) + (\text{Octets} \times 0.8)}{\text{Interval} \times 10,000}$ <p>The result of this equation is the percent value of utilization.</p>
<code>etherStatsPkts</code>	The total number of packets (including bad packets, broadcast packets, and multicast packets) received.
<code>etherStatsBroadcastPkts</code>	The total number of good packets received that were directed to the broadcast address. Note that this does not include multicast packets.
<code>etherStatsMulticastPkts</code>	The total number of good packets received that were directed to a multicast address. Note that this number does not include packets directed to the broadcast address.
<code>etherStatsCRCAlignErrors</code>	The total number of packets received that had a length (excluding framing bits, but including Frame Check Sequence (FCS) octets) of between 64 and 1518 octets, inclusive, but had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
<code>etherStatsUnder-sizePkts</code>	The total number of packets received that were less than 64 octets long (excluding framing bits, but including FCS octets) and were otherwise well formed.
<code>etherStatsOver-sizePkts</code>	The total number of packets received that were longer than 1518 octets (excluding framing bits, but including FCS octets) and were otherwise well formed.

Table 5-8 Remote Monitor Statistics (/stats/port/rmon)

Statistics	Description
etherStatsFragments	<p>The total number of packets received that were less than 64 octets in length (excluding framing bits but including FCS octets) and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).</p> <p>Note that it is entirely normal for etherStatsFragments to increment. This is because it counts both runts (which are normal occurrences due to collisions) and noise hits. (A runt is a packet that is less than 64 bytes.)</p>
etherStatsJabbers	<p>The total number of packets received that were longer than 1518 octets (excluding framing bits, but including FCS octets), and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).</p> <p>Note that this definition of jabber is different than the definition in IEEE-802.3 section 8.2.1.5 (10Base-5) and section 10.3.1.4 (10Base-2). These documents define jabber as the condition where any packet exceeds 20 ms. The allowed range to detect jabber is between 20 milliseconds and 150 milliseconds.</p>
etherStats-Collisions	<p>The best estimate of the total number of collisions on this Ethernet segment.</p> <p>The value returned will depend on the location of the RMON probe. Section 8.2.1.3 (10Base-5) and section 10.3.1.3 (10Base-2) of IEEE standard 802.3 states that a station must detect a collision, in the receive mode, if three or more stations are transmitting simultaneously. A repeater port must detect a collision when two or more stations are transmitting simultaneously. Thus a probe placed on a repeater port could record more collisions than a probe connected to a station on the same segment would. Probe location plays a much smaller role when considering 10Base-T. 14.2.1.4 (10Base-T) of IEEE standard 802.3 defines a collision as the simultaneous presence of signals on the DO and RD circuits (transmitting and receiving at the same time). A 10Base-T station can only detect collisions when it is transmitting. Thus probes placed on a station and a repeater, should report the same number of collisions.</p> <p>Note also that an RMON probe inside a repeater should ideally report collisions between the repeater and one or more other hosts (transmit collisions as defined by IEEE 802.3k) plus receiver collisions observed on any coax segments to which the repeater is connected.</p>
etherStatsPkts64-Octets	<p>The total number of packets (including bad packets) received that were 64 octets in length (excluding framing bits but including Frame Check Sequence (FCS) octets).</p>

Table 5-8 Remote Monitor Statistics (/stats/port/rmon)

Statistics	Description
etherStatsPkts65- to127Octets	The total number of packets (including bad packets) received that were between 65 and 127 octets in length (excluding framing bits but including FCS octets).
etherStatsPkts128- to255Octets	The total number of packets (including bad packets) received that were between 128 and 255 octets in length (excluding framing bits but including Frame Check Sequence (FCS) octets).
etherStatsPkts256- to511Octets	The total number of packets (including bad packets) received that were between 256 and 511 octets in length (excluding framing bits but including FCS octets).
etherStatsPkts512- to1023Octets	The total number of packets (including bad packets) received that were between 512 and 1023 octets in length (excluding framing bits but including FCS octets).
etherStatsPkts- 1024to1518Octets	The total number of packets (including bad packets) received that were between 1024 and 1518 octets in length (excluding framing bits but including FCS octets).

/stats/12

Layer 2 Statistics Menu

```
[Layer 2 Statistics Menu]
fdb      - Show FDB stats
lacp     - Show LACP stats
```

Table 5-9 Statistics Menu Options (/stats/l2)

Command Syntax and Usage

fdb

Displays FDB statistics. See [page 109](#) for sample output.

lacp <port alias or number>

Displays Link Aggregation Control Protocol (LACP) statistics. See [page 110](#) for sample output.

/stats/12/fdb

FDB Statistics

```
FDB statistics:
  creates:          30503   deletes:          30420
  current:           83     hiwat:           855
  lookups:          511889  lookup fails:    1126
  finds:            21801   find fails:      0
  find_or_c's:     36140   overflows:      0
```

This menu option enables you to display statistics regarding the use of the forwarding database, including the number of new entries, finds, and unsuccessful searches.

FDB statistics are described in the following table:

Table 5-10 Forwarding Database Statistics (/stats/fdb)

Statistic	Description
creates	Number of entries created in the Forwarding Database.
current	Current number of entries in the Forwarding Database.
lookups	Number of entry lookups in the Forwarding Database.
finds	Number of successful searches in the Forwarding Database.
find_or_c's	Number of entries found or created in the Forwarding Database.
deletes	Number of entries deleted from the Forwarding Database.
hiwat	Highest number of entries recorded at any given time in the Forwarding Database.
lookup fails	Number of unsuccessful searches made in the Forwarding Database.
find fails	Number of search failures in the Forwarding Database.
overflows	Number of entries overflowing the Forwarding Database.

`/stats/l2/lacp` *<port alias or number>* **LACP Statistics**

```

Port EXT1:
-----
Valid LACPDU's received:          - 870
Valid Marker PDUs received:      - 0
Valid Marker Rsp PDUs received:  - 0
Unknown version/TLV type:       - 0
Illegal subtype received:       - 0
LACPDU's transmitted:           - 6031
Marker PDUs transmitted:        - 0
Marker Rsp PDUs transmitted:    - 0

```

`/stats/l3` **Layer 3 Statistics Menu**

```

[Layer 3 Statistics Menu]
ospf      - OSPF Statistics Menu
ip        - Show IP stats
route    - Show route stats
arp      - Show ARP stats
vrrp     - Show VRRP stats
dns      - Show DNS stats
icmp     - Show ICMP stats
igmp     - Show IGMP stats
if       - Show IP interface ("if") stats
tcp      - Show TCP stats
udp      - Show UDP stats
ifclear  - Clear IP interface ("if") stats
ipclear  - Clear IP stats
igmpclear - Clear IGMP stats
dump     - Dump layer 3 stats

```

Table 5-11 Statistics Menu Options (/stats/l3)

Command Syntax and Usage

ospf

Displays OSPF statistics Menu. See [page 112](#) for sample output.

ip

Displays IP statistics. See [page 117](#) for sample output.

route

Displays route statistics. See [page 119](#) for sample output.

arp

Displays Address Resolution Protocol (ARP) statistics. See [page 120](#) for sample output.

vrrp

When virtual routers are configured, you can display the following protocol statistics for VRRP:

- Advertisements received (`vrrpInAdvers`)
- Advertisements transmitted (`vrrpOutAdvers`)
- Advertisements received, but ignored (`vrrpBadAdvers`)

See [page 121](#) for sample output.

dns

Displays Domain Name Server (DNS) statistics. See [page 122](#) for sample output.

icmp

Displays ICMP statistics. See [page 122](#) for sample output.

igmp

Displays IGMP statistics. See [page 122](#) for sample output.

if <interface number (1-128)>

Displays IP interface statistics. See [page 125](#) for sample output.

tcp

Displays TCP statistics. See [page 127](#) for sample output.

udp

Displays UDP statistics. See [page 129](#) for sample output.

ifclear

Clears IP interface statistics. Use this command with caution as it will delete all the IP interface statistics.

ipclear

Clears IP statistics. Use this command with caution as it will delete all the IP statistics.

igmpclear

Clears IGMP statistics.

Table 5-11 Statistics Menu Options (/stats/l3)

Command Syntax and Usage

dump

Dumps all Layer 3 statistics. Use this command to gather data for tuning and debugging switch performance. If you want to capture dump data to a file, set your communication software on your workstation to capture session data prior to issuing the dump command.

/stats/l3/ospf

OSPF Statistics Menu

```
[OSPF stats Menu]
  general - Show global stats
  aindex  - Show area(s) stats
  if      - Show interface(s) stats
```

Table 5-12 OSPF Statistics Menu (/stats/l3/ospf)

Command Syntax and Usage

general

Displays global statistics. See [page 113](#) for sample output.

aindex

Displays area statistics.

if

Displays interface statistics.

/stats/13/ospf/general

OSPF Global Statistics

The OSPF General Statistics contain the sum total of all OSPF packets received on all OSPF areas and interfaces.

```

OSPF stats
-----
Rx/Tx Stats:           Rx           Tx
-----
Pkts                   0           0
hello                  23          518
database                4           12
ls requests             3           1
ls acks                 7           7
ls updates              9           7

Nbr change stats:
hello                   2
start                   0
n2way                   2
adjoint ok              2
negotiation done       2
exchange done           2
bad requests            0
bad sequence            0
loading done            2
nlway                   0
rst_ad                  0
down                    1

Intf change Stats:
hello                   4
down                    2
loop                    0
unloop                  0
wait timer              2
backup                  0
nbr change              5

Timers kickoff
hello                   514
retransmit              1028
lsa lock                0
lsa ack                  0
dbage                   0
summary                 0
ase export               0

```

Table 5-13 OSPF General Statistics (stats/l3/ospf/general)

Statistics	Description
Rx/Tx Stats:	
Rx Pkts	The sum total of all OSPF packets received on all OSPF areas and interfaces.
Tx Pkts	The sum total of all OSPF packets transmitted on all OSPF areas and interfaces.
Rx Hello	The sum total of all Hello packets received on all OSPF areas and interfaces.
Tx Hello	The sum total of all Hello packets transmitted on all OSPF areas and interfaces.
Rx Database	The sum total of all Database Description packets received on all OSPF areas and interfaces.
Tx Database	The sum total of all Database Description packets transmitted on all OSPF areas and interfaces.
Rx ls Requests	The sum total of all Link State Request packets received on all OSPF areas and interfaces.
Tx ls Requests	The sum total of all Link State Request packets transmitted on all OSPF areas and interfaces.
Rx ls Acks	The sum total of all Link State Acknowledgement packets received on all OSPF areas and interfaces.
Tx ls Acks	The sum total of all Link State Acknowledgement packets transmitted on all OSPF areas and interfaces.
Rx ls Updates	The sum total of all Link State Update packets received on all OSPF areas and interfaces.
Tx ls Updates	The sum total of all Link State Update packets transmitted on all OSPF areas and interfaces.

Table 5-13 OSPF General Statistics (stats/l3/ospf/general) (Continued)

Statistics	Description
Nbr Change Stats:	
hello	The sum total of all Hello packets received from neighbors on all OSPF areas and interfaces.
Start	The sum total number of neighbors in this state (that is, an indication that Hello packets should now be sent to the neighbor at intervals of HelloInterval seconds.) across all OSPF areas and interfaces.
n2way	The sum total number of bidirectional communication establishment between this router and other neighboring routers.
adjoint ok	The sum total number of decisions to be made (again) as to whether an adjacency should be established/maintained with the neighbor across all OSPF areas and interfaces.
negotiation done	The sum total number of neighbors in this state wherein the Master/slave relationship has been negotiated, and sequence numbers have been exchanged, across all OSPF areas and interfaces.
exchange done	The sum total number of neighbors in this state (that is, in an adjacency's final state) having transmitted a full sequence of Database Description packets, across all OSPF areas and interfaces.
bad requests	The sum total number of Link State Requests which have been received for a link state advertisement not contained in the database across all interfaces and OSPF areas.
bad sequence	The sum total number of Database Description packets which have been received that either: <ul style="list-style-type: none"> a) Has an unexpected DD sequence number b) Unexpectedly has the init bit set c) Has an options field differing from the last Options field received in a Database Description packet. Any of these conditions indicate that some error has occurred during adjacency establishment for all OSPF areas and interfaces.
loading done	The sum total number of link state updates received for all out-of-date portions of the database across all OSPF areas and interfaces.
n1way	The sum total number of Hello packets received from neighbors, in which this router is not mentioned across all OSPF interfaces and areas.
rst_ad	The sum total number of times the Neighbor adjacency has been reset across all OPSF areas and interfaces.
down	The total number of Neighboring routers down (that is, in the initial state of a neighbor conversation.) across all OSPF areas and interfaces.

Table 5-13 OSPF General Statistics (stats/l3/ospf/general) (Continued)

Statistics	Description
Intf Change Stats:	
hello	The sum total number of Hello packets sent on all interfaces and areas.
down	The sum total number of interfaces down in all OSPF areas.
loop	The sum total of interfaces no longer connected to the attached network across all OSPF areas and interfaces.
unloop	The sum total number of interfaces, connected to the attached network in all OSPF areas.
wait timer	The sum total number of times the Wait Timer has been fired, indicating the end of the waiting period that is required before electing a (Backup) Designated Router across all OSPF areas and interfaces.
backup	The sum total number of Backup Designated Routers on the attached network for all OSPF areas and interfaces.
nbr change	The sum total number of changes in the set of bidirectional neighbors associated with any interface across all OSPF areas.
Timers Kickoff:	
hello	The sum total number of times the Hello timer has been fired (which triggers the send of a Hello packet) across all OPSF areas and interfaces.
retransmit	The sum total number of times the Retransmit timer has been fired across all OPSF areas and interfaces.
lsa lock	The sum total number of times the Link State Advertisement (LSA) lock timer has been fired across all OSPF areas and interfaces.
lsa ack	The sum total number of times the LSA Ack timer has been fired across all OSPF areas and interfaces.
dbage	The total number of times the data base age (Dbage) has been fired.
summary	The total number of times the Summary timer has been fired.
ase export	The total number of times the Autonomous System Export (ASE) timer has been fired.

/stats/l3/ip

IP Statistics

```

IP statistics:
ipInReceives:      3115873   ipInHdrErrors:      1
ipInAddrErrors:   35447     ipForwDatagrams:    0
ipInUnknownProtos: 500504   ipInDiscards:      0
ipInDelivers:     2334166   ipOutRequests:     1010542
ipOutDiscards:    4         ipOutNoRoutes:     4
ipReasmReqds:     0         ipReasmOKs:        0
ipReasmFails:     0         ipFragOKs:         0
ipFragFails:     0         ipFragCreates:     0
ipRoutingDiscards: 0         ipDefaultTTL:      255
ipReasmTimeout:   5

```

Table 5-14 IP Statistics (stats/l3/ip)

Statistics	Description
ipInReceives	The total number of input datagrams received from interfaces, including those received in error.
ipInHdrErrors	The number of input datagrams discarded due to errors in their IP headers, including bad checksums, version number mismatch, other format errors, time-to-live exceeded, errors discovered in processing their IP options, and so forth.
ipInAddrErrors	The number of input datagrams discarded because the IP address in their IP header's destination field was not a valid address to be received at this entity (the switch). This count includes invalid addresses (for example, 0.0.0.0) and addresses of unsupported Classes (for example, Class E). For entities which are not IP Gateways and therefore do not forward datagrams, this counter includes datagrams discarded because the destination address was not a local address.
ipForwDatagrams	The number of input datagrams for which this entity (the switch) was not their final IP destination, as a result of which an attempt was made to find a route to forward them to that final destination. In entities which do not act as IP Gateways, this counter will include only those packets, which were Source-Routed via this entity (the switch), and the Source-Route option processing was successful.
ipInUnknownProtos	The number of locally addressed datagrams received successfully but discarded because of an unknown or unsupported protocol.

Table 5-14 IP Statistics (stats/l3/ip)

Statistics	Description
<code>ipInDiscards</code>	The number of input IP datagrams for which no problems were encountered to prevent their continued processing, but which were discarded (for example, for lack of buffer space). Note that this counter does not include any datagrams discarded while awaiting re-assembly.
<code>ipInDelivers</code>	The total number of input datagrams successfully delivered to IP user-protocols (including ICMP).
<code>ipOutRequests</code>	The total number of IP datagrams which local IP user-protocols (including ICMP) supplied to IP in requests for transmission. Note that this counter does not include any datagrams counted in <code>ipForwDatagrams</code> .
<code>ipOutDiscards</code>	The number of output IP datagrams for which no problem was encountered to prevent their transmission to their destination, but which were discarded (for example, for lack of buffer space). Note that this counter would include datagrams counted in <code>ipForwDatagrams</code> if any such packets met this (discretionary) discard criterion.
<code>ipOutNoRoutes</code>	The number of IP datagrams discarded because no route could be found to transmit them to their destination. Note that this counter includes any packets counted in <code>ipForwDatagrams</code> , which meet this <i>no-route</i> criterion. Note that this includes any datagrams which a host cannot route because all of its default gateways are down.
<code>ipReasmReqds</code>	The number of IP fragments received which needed to be reassembled at this entity (the switch).
<code>ipReasmOKs</code>	The number of IP datagrams successfully re- assembled.
<code>ipReasmFails</code>	The number of failures detected by the IP re- assembly algorithm (for whatever reason: timed out, errors, and so forth). Note that this is not necessarily a count of discarded IP fragments since some algorithms (notably the algorithm in RFC 815) can lose track of the number of fragments by combining them as they are received.
<code>ipFragOKs</code>	The number of IP datagrams that have been successfully fragmented at this entity (the switch).
<code>ipFragFails</code>	The number of IP datagrams that have been discarded because they needed to be fragmented at this entity (the switch) but could not be, for example, because their Don't Fragment flag was set.
<code>ipFragCreates</code>	The number of IP datagram fragments that have been generated as a result of fragmentation at this entity (the switch).

Table 5-14 IP Statistics (stats/l3/ip)

Statistics	Description
ipRoutingDiscards	The number of routing entries, which were chosen to be discarded even though they are valid. One possible reason for discarding such an entry could be to free-up buffer space for other routing entries.
ipDefaultTTL	The default value inserted into the Time-To-Live (TTL) field of the IP header of datagrams originated at this entity (the switch), whenever a TTL value is not supplied by the transport layer protocol.
ipReasmTimeout	The maximum number of seconds, which received fragments are held while they are awaiting reassembly at this entity (the switch).

/stats/l3/route

Route Statistics

```

Route statistics:
ipRoutesCur:          7  ipRoutesHighWater:    7
ipRoutesMax:         1024

RIP statistics:
ripInPkts:           0  ripOutPkts:           0
ripBadPkts:          0  ripRoutesAgedOut:     0

BGP statistics:
bgpInPkts:           0  bgpOutPkts:           0
bgpBadPkts:          0  bgpSessFailures:     0
bgpRoutesAdded:      0  bgpRoutesRemoved:    0
bgpRoutesCur:        0  bgpRoutesFailed:     0
bgpRoutesIgnored:    0  bgpRoutesFiltered:   0

```

Table 5-15 Route Statistics (/stats/l3/route)

Statistics	Description
ipRoutesCur	The total number of outstanding routes in the route table.
ipRoutesHighWater	The highest number of routes ever recorded in the route table.
ipRoutesMax	The maximum number of routes that are supported.
RIP statistics:	
ripInPkts	The total number of good RIP advertisement packets received.

Table 5-15 Route Statistics (/stats/l3/route)

Statistics	Description
ripOutPkts	The total number of RIP advertisement packets sent.
ripBadPkts	The total number of RIP advertisement packets received that were dropped.
ripRoutesAgedOut	The total number of routes learned via RIP that has aged out.
BGP statistics:	
bgpInPkts	The total number of BGP packets received.
bgpOutPkts	The total number of BGP packets sent.
bgpBadPkts	The total number of BGP packets dropped.
bgpSessFailures	The total number of failed sessions.
bgpRoutesAdded	The total number of routes that were added to the routing table.
bgpRoutesRemoved	The total number of routes that were removed from the routing table.
bgpRoutesCur	The total number of current BGP routes.
bgpRoutesFailed	The total number of BGP routes that failed to add in the routing table.
bgpRoutesIgnored	The total number of routes ignored because the peer was not connected locally or multihop was not configured.
bgpRoutesFiltered	The total number of routes dropped by the filter.

/stats/l3/arp ARP statistics

This menu option enables you to display Address Resolution Protocol statistics.

```

ARP statistics:
arpEntriesCur:          3  arpEntriesHighWater:          4
arpEntriesMax:          4096

```

Table 5-16 ARP Statistics (/stats/l3/arp)

Statistics	Description
arpEntriesCur	The total number of outstanding ARP entries in the ARP table.

Table 5-16 ARP Statistics (/stats/l3/arp)

Statistics	Description
arpEntriesHighWater	The highest number of ARP entries ever recorded in the ARP table.
arpEntriesMax	The maximum number of ARP entries that are supported.

/stats/l3/vrrp

VRRP Statistics

Virtual Router Redundancy Protocol (VRRP) support on the GbE Switch Module provides redundancy between routers in a LAN. This is accomplished by configuring the same virtual router IP address and ID number on each participating VRRP-capable routing device. One of the virtual routers is then elected as the master, based on a number of priority criteria, and assumes control of the shared virtual router IP address. If the master fails, one of the backup virtual routers will assume routing authority and take control of the virtual router IP address.

When virtual routers are configured, you can display the following protocol statistics for VRRP:

- Advertisements received (vrrpInAdvers)
- Advertisements transmitted (vrrpOutAdvers)
- Advertisements received, but ignored (vrrpBadAdvers)

The statistics for the VRRP LAN are displayed:

```
VRRP statistics:
vrrpInAdvers:           0   vrrpBadAdvers:           0
vrrpOutAdvers:          0
```

Table 5-17 VRRP Statistics (/stats/l3/vrrp)

Statistics	Description
vrrpInAdvers	The total number of VRRP advertisements that have been received.
vrrpBadAdvers	The total number of VRRP advertisements received that were dropped.
vrrpOutAdvers	The total number of VRRP advertisements that have been sent.

/stats/l3/dns

DNS Statistics

This menu option enables you to display Domain Name System statistics.

```
DNS statistics:
dnsInRequests:      0  dnsOutRequests:      0
dnsBadRequests:    0
```

Table 5-18 DNS Statistics (/stats/dns)

Statistics	Description
dnsInRequests	The total number of DNS request packets that have been received.
dnsOutRequests	The total number of DNS response packets that have been transmitted.
dnsBadRequests	The total number of DNS request packets received that were dropped.

/stats/l3/icmp

ICMP Statistics

```
ICMP statistics:
icmpInMsgs:      245802  icmpInErrors:      1393
icmpInDestUnreachs:  41  icmpInTimeExcds:    0
icmpInParmProbs:  0  icmpInSrcQuenchs:  0
icmpInRedirects:  0  icmpInEchos:       18
icmpInEchoReps:   244350  icmpInTimestamps:  0
icmpInTimestampReps: 0  icmpInAddrMasks:   0
icmpInAddrMaskReps: 0  icmpOutMsgs:       253810
icmpOutErrors:    0  icmpOutDestUnreachs: 15
icmpOutTimeExcds: 0  icmpOutParmProbs:  0
icmpOutSrcQuenchs: 0  icmpOutRedirects:  0
icmpOutEchos:     253777  icmpOutEchoReps:   18
icmpOutTimestamps: 0  icmpOutTimestampReps: 0
icmpOutAddrMasks: 0  icmpOutAddrMaskReps: 0
```

Table 5-19 ICMP Statistics (/stats/l3/icmp)

Statistics	Description
icmpInMsgs	The total number of ICMP messages which the entity (the switch) received. Note that this counter includes all those counted by icmpInErrors.

Table 5-19 ICMP Statistics (/stats/l3/icmp)

Statistics	Description
icmpInErrors	The number of ICMP messages which the entity (the switch) received but determined as having ICMP-specific errors (bad ICMP checksums, bad length, and so forth).
icmpInDestUnreachs	The number of ICMP Destination Unreachable messages received.
icmpInTimeExcds	The number of ICMP Time Exceeded messages received.
icmpInParmProbs	The number of ICMP Parameter Problem messages received.
icmpInSrcQuenchs	The number of ICMP Source Quench (buffer almost full, stop sending data) messages received.
icmpInRedirects	The number of ICMP Redirect messages received.
icmpInEchos	The number of ICMP Echo (request) messages received.
icmpInEchoReps	The number of ICMP Echo Reply messages received.
icmpInTimestamps	The number of ICMP Timestamp (request) messages received.
icmpInTimestampReps	The number of ICMP Timestamp Reply messages received.
icmpInAddrMasks	The number of ICMP Address Mask Request messages received.
icmpInAddrMaskReps	The number of ICMP Address Mask Reply messages received.
icmpOutMsgs	The total number of ICMP messages which this entity (the switch) attempted to send. Note that this counter includes all those counted by icmpOutErrors.
icmpOutErrors	The number of ICMP messages which this entity (the switch) did not send due to problems discovered within ICMP such as a lack of buffer. This value should not include errors discovered outside the ICMP layer such as the inability of IP to route the resultant datagram. In some implementations there may be no types of errors that contribute to this counter's value.
icmpOutDestUnreachs	The number of ICMP Destination Unreachable messages sent.
icmpOutTimeExcds	The number of ICMP Time Exceeded messages sent.
icmpOutParmProbs	The number of ICMP Parameter Problem messages sent.
icmpOutSrcQuenchs	The number of ICMP Source Quench (buffer almost full, stop sending data) messages sent.
icmpOutRedirects	The number of ICMP Redirect messages sent. For a host, this object will always be zero, since hosts do not send redirects.

Table 5-19 ICMP Statistics (/stats/l3/icmp)

Statistics	Description
icmpOutEchos	The number of ICMP Echo (request) messages sent.
icmpOutEchoReps	The number of ICMP Echo Reply messages sent.
icmpOutTimestamps	The number of ICMP Timestamp (request) messages sent.
icmpOutTimestampReps	The number of ICMP Timestamp Reply messages sent.
icmpOutAddrMasks	The number of ICMP Address Mask Request messages sent.
icmpOutAddrMaskReps	The number of ICMP Address Mask Reply messages sent.

/stats/l3/igmp

IGMP Statistics

```

IGMP Snoop vlan 1 statistics:
-----
rxIgmpValidPkts:          0   rxIgmpInvalidPkts:          0
rxIgmpGenQueries:        0   rxIgmpGrpSpecificQueries:   0
rxIgmpLeaves:            0   rxIgmpReports:              0
txIgmpReports:           0   txIgmpGrpSpecificQueries:   0
txIgmpLeaves:            0
Current Groups:           0   Current M-cast Routers:     1

```

This menu option enables you to display statistics regarding the use of the IGMP Multicast Groups.

IGMP statistics are described in the following table:

Table 5-20 IGMP Statistics (/stats/igmp)

Statistic	Description
rxIgmpValidPkts	Total number of valid IGMP packets received
rxIgmpInvalidPkts	Total number of invalid packets received
rxIgmpGenQueries	Total number of General Membership Query packets received
rxIgmpGrpSpecificQueries	Total number of Membership Query packets received from specific groups

Table 5-20 IGMP Statistics (/stats/igmp)

Statistic	Description
rxIgmpLeaves	Total number of Leave requests received
rxIgmpReports	Total number of Membership Reports received
txIgmpReports	Total number of Membership reports transmitted
txIgmpGrpSpecificQueries	Total number of Membership Query packets transmitted to specific groups
txIgmpLeaves	Total number of Leave messages transmitted
Current Groups	Total number of active IGMP groups learned through IGMP Snooping
Current M-Cast Routers	Total number of static Multicast Routers configured on the switch

/stats/l3/if <interface number> **Interface Statistics**

```

IP interface 1 statistics:
ifInOctets:      48948386   ifInUcastPkts:      220553
ifInNUCastPkts: 167895   ifInDiscards:       0
ifInErrors:     0         ifInUnknownProtos: 0
ifOutOctets:    27100789   ifOutUcastPkts:    441938
ifOutNUcastPkts: 218652   ifOutDiscards:     0
ifOutErrors:    0         ifStateChanges      1

```

Table 5-21 Interface Statistics (/stats/l3/if)

Statistics	Description
ifInOctets	The total number of octets received on the interface, including framing characters.
ifInUcastPkts	The number of packets, delivered by this sub-layer to a higher (sub-layer), which were not addressed to a multicast or broadcast address at this sub-layer.

Table 5-21 Interface Statistics (/stats/l3/lf)

Statistics	Description
<code>ifInNUCastPkts</code>	The number of packets, delivered by this sub-layer to a higher (sub-layer), which were addressed to a multicast or broadcast address at this sub-layer. This object is deprecated in favor of <code>ifInMulticastPkts</code> and <code>ifInBroadcastPkts</code> .
<code>ifInDiscards</code>	The number of inbound packets that were chosen to be discarded even though no errors had been detected to prevent their being delivered to a higher-layer protocol. One possible reason for discarding such a packet could be to free up buffer space.
<code>ifInErrors</code>	For packet-oriented interfaces, the number of inbound packets that contained errors preventing them from being delivered to a higher-layer protocol. For character-oriented or fixed-length interfaces, the number of inbound transmission units that contained errors preventing them from being deliverable to a higher-layer protocol.
<code>ifInUnknownProtos</code>	For packet-oriented interfaces, the number of packets received via the interface which were discarded because of an unknown or unsupported protocol. For character-oriented or fixed-length interfaces which support protocol multiplexing the number of transmission units received via the interface which were discarded because of an unknown or unsupported protocol. For any interface which does not support protocol multiplexing, this counter will always be 0.
<code>ifOutOctets</code>	The total number of octets transmitted out of the interface, including framing characters.
<code>ifOutUcastPkts</code>	The total number of packets that higher-level protocols requested to be transmitted, and which were not addressed to a multicast or broadcast address at this sub-layer, including those that were discarded or not sent.
<code>ifOutNUcastPkts</code>	The total number of packets that higher-level protocols requested to be transmitted, and which were addressed to a multicast or broadcast address at this sub-layer, including those that were discarded or not sent. This object is deprecated in favor of <code>ifOutMulticastPkts</code> and <code>ifOutBroadcastPkts</code> .
<code>ifOutDiscards</code>	The number of outbound packets, which were chosen to be discarded even though no errors had been detected to prevent their being transmitted. One possible reason for discarding such a packet could be to free up buffer space.
<code>ifOutErrors</code>	For packet-oriented interfaces, the number of outbound packets that could not be transmitted because of errors. For character-oriented or fixed-length interfaces, the number of outbound transmission units that could not be transmitted because of errors.

Table 5-21 Interface Statistics (/stats/l3/if)

Statistics	Description
ifStateChanges	The number of times an interface has transitioned from either down to up or from up to down.

/stats/l3/tcp TCP Statistics

TCP statistics:			
tcpRtoAlgorithm:	4	tcpRtoMin:	0
tcpRtoMax:	240000	tcpMaxConn:	512
tcpActiveOpens:	252214	tcpPassiveOpens:	7
tcpAttemptFails:	528	tcpEstabResets:	4
tcpInSegs:	756401	tcpOutSegs:	756655
tcpRetransSegs:	0	tcpInErrs:	0
tcpCurBuff:	0	tcpCurConn:	3
tcpOutRsts:	417		

Table 5-22 TCP Statistics (/stats/l3/tcp)

Statistics	Description
tcpRtoAlgorithm	The algorithm used to determine the <code>timeout</code> value used for retransmitting unacknowledged octets.
tcpRtoMin	The minimum value permitted by a TCP implementation for the retransmission <code>timeout</code> , measured in milliseconds. More refined semantics for objects of this type depend upon the algorithm used to determine the retransmission <code>timeout</code> . In particular, when the <code>timeout</code> algorithm is <code>rsre(3)</code> , an object of this type has the semantics of the <code>LBOUND</code> quantity described in RFC 793.
tcpRtoMax	The maximum value permitted by a TCP implementation for the retransmission <code>timeout</code> , measured in milliseconds. More refined semantics for objects of this type depend upon the algorithm used to determine the retransmission <code>timeout</code> . In particular, when the <code>timeout</code> algorithm is <code>rsre(3)</code> , an object of this type has the semantics of the <code>UBOUND</code> quantity described in RFC 793.

Table 5-22 TCP Statistics (/stats/l3/tcp)

Statistics	Description
tcpMaxConn	The limit on the total number of TCP connections the entity (the switch) can support. In entities where the maximum number of connections is dynamic, this object should contain the value -1.
tcpActiveOpens	The number of times TCP connections have made a direct transition to the SYN-SENT state from the CLOSED state.
tcpPassiveOpens	The number of times TCP connections have made a direct transition to the SYN-RCVD state from the LISTEN state.
tcpAttemptFails	The number of times TCP connections have made a direct transition to the CLOSED state from either the SYN-SENT state or the SYN-RCVD state, plus the number of times TCP connections have made a direct transition to the LISTEN state from the SYN-RCVD state.
tcpEstabResets	The number of times TCP connections have made a direct transition to the CLOSED state from either the ESTABLISHED state or the CLOSE-WAIT state.
tcpInSegs	The total number of segments received, including those received in error. This count includes segments received on currently established connections.
tcpOutSegs	The total number of segments sent, including those on current connections but excluding those containing only retransmitted octets.
tcpRetransSegs	The total number of segments retransmitted - that is, the number of TCP segments transmitted containing one or more previously transmitted octets.
tcpInErrs	The total number of segments received in error (for example, bad TCP checksums).
tcpCurBuff	The total number of outstanding memory allocations from heap by TCP protocol stack.
tcpCurConn	The total number of outstanding TCP sessions that are currently opened.
tcpOutRsts	The number of TCP segments sent containing the RST flag.

/stats/13/udp

UDP Statistics

```

UDP statistics:
udpInDatagrams:      54    udpOutDatagrams:      43
udpInErrors:         0    udpNoPorts:          1578077
  
```

Table 5-23 UDP Statistics (/stats/13/udp)

Statistics	Description
udpInDatagrams	The total number of UDP datagrams delivered to the switch.
udpOutDatagrams	The total number of UDP datagrams sent from this entity (the switch).
udpInErrors	The number of received UDP datagrams that could not be delivered for reasons other than the lack of an application at the destination port.
udpNoPorts	The total number of received UDP datagrams for which there was no application at the destination port.

/stats/slb

Load Balancing Statistics Menu

```
[Server Load Balancing Statistics Menu]
  sp      - SLB Switch SP Stats Menu
  real    - Show real server stats
  group   - Show real server group stats
  virt    - Show virtual server stats
  filt    - Show filter stats
  layer7  - Show Layer 7 stats
  ssl     - Show SSL SLB stats
  ftp     - Show FTP SLB parsing and NAT stats
  rtsp    - Show RTSP SLB stats
  dns     - Show DNS SLB stats
  wap     - Show WAP SLB stats
  tcp     - Show TCP rate limiting stats
  maint   - Show maintenance stats
  clear   - Clear non-operational Server Load Balancing stats
  aux     - Show auxiliary session table stats
  dump    - Dump all SLB statistics
```

Table 5-24 SLB Statistics Menu Options (/stats/slb)

Command Syntax and Usage

sp <SP number (1-4)>

Displays the server load balancing statistics menu. To view menu options, see [page 132](#).

real <real server number (1-63)>

Displays the following real server statistics:

- Number of times the real server has failed its health checks
- Number of sessions currently open on the real server
- Total sessions the real server was assigned
- Highest number of simultaneous sessions recorded for each real server
- Real server transmit/receive octets

See [page 133](#) for sample output.

group <real server group number (1-64)>

Displays the following real server group statistics:

- Current and total sessions for each real server in the real server group.
- Current and total sessions for all real servers associated with the real server group.
- Highest number of simultaneous sessions recorded for each real server.
- Real server transmit/receive octets. For per-service octet counters, see [page 135](#).

See [page 136](#) for sample output.

Table 5-24 SLB Statistics Menu Options (/stats/slb)

Command Syntax and Usage

virt *<virtual server number (1-64)>*

Displays the following virtual server statistics:

- Current and total sessions for each real server associated with the virtual server.
- Current and total sessions for all real servers associated with the virtual server.
- Highest number of simultaneous sessions recorded for each real server.
- Real server transmit/receive octets. For per-service octet counters, see [page 135](#).

See [page 137](#) for sample output.

filt *<filter ID (1-1024)>*Displays the total number of times any filter has been used. See [page 137](#) for sample output.

layer7Displays Layer 7 statistics. See [page 138](#) for sample output.

sslDisplays SSL server load balancing statistics. See [page 142](#) for sample output.

ftpDisplays FTP SLB parsing and NAT statistics. See [page 143](#) for sample output.

rtspDisplays RTSP SLB statistics. See [page 146](#) for sample output.

dnsDisplays DNS SLB statistics. See [page 146](#) for sample output.

wapDisplays WAP SLB statistics. See [page 148](#) for sample output.

tcpDisplays statistics for TCP rate limiting. See [page 150](#) for sample output.

maintDisplays SLB maintenance statistics. See [page 150](#) for sample output.

clear [*y|n*]Clears all non-operating SLB statistics on the GbE Switch Module, resetting them to zero. This command does not reset the switch and does *not* affect the following counters:

- Counters required for Layer 4 and Layer 7 operation (such as current real server sessions).
- All related SNMP counters.

To view the statistics reset by this command, refer to [Table 5-42 on page 152](#).

auxDisplays auxiliary session table statistics.

Table 5-24 SLB Statistics Menu Options (/stats/slb)**Command Syntax and Usage****dump**

Dumps all switch SLB statistics. Use this command to gather data for tuning and debugging switch performance. To save dump data to a file, set your communication software on your workstation to capture session data prior to issuing the dump command.

/stats/slb/sp

Server Load Balancing SP statistics Menu

```
[Server Load Balancing SP Statistics Menu]
real      - Show real server stats
group    - Show real server group stats
virt     - Show virtual server stats
filt     - Show filter stats
maint    - Show maintenance stats
aux      - Show auxiliary session table stats
clear    - Clear SP stats
```

Table 5-25 SP Statistics Menu options (/stats/slb/sp)**Command Syntax and Usage**

real <real server number (1-63)>

Displays real server statistics of the switch port. See [page 133](#) for a sample output.

group <real server group number (1-64)>

Displays real server group statistics of the switch port. See [page 133](#) for a sample output.

virt <virtual server number (1-64)>

Displays statistics of the virtual server. See [page 133](#) for a sample output.

filt <filter ID (1-1024)>

Displays statistics of the filter. See [page 134](#) for a sample output.

maint

Displays the SP maintenance statistics. See [page 134](#) for a sample output.

aux

Displays the statistics of the auxiliary session table.

clear

Deletes all the SP statistics.

/stats/slb/sp/real <real server number>

SP Real Server Statistics

```

Port 1 Real server 1 stats:
Current sessions:           3
Total sessions:            3
Octets:                     24

```

/stats/slb/sp <sp number>/group <real group server number>

SP Real Group Server Statistics

```

Real server group 1 stats:
Real IP address           Current Sessions   Total Sessions   Highest Sessions   Octets
-----
  1 200.100.10.14          20              60              9                 480000
  2 200.100.10.15          20              77              12                616000
-----
                               40              137             21                1096000

```

/stats/slb/sp <sp number>/virt <virtual server number>

SP Virtual Server Statistics

```

Real server group 1 stats:
Real IP address           Current Sessions   Total Sessions   Highest Sessions   Octets
-----
  1 200.100.10.14          20              60              9                 480000
  2 200.100.10.15          20              77              12                616000
-----
  200.100.10.100          40              137             21                1096000

```

/stats/slb/sp *<sp number>/filt* *<filter number>*

SP Filter Statistics

```
Poet 1 Filter 30 stats:
Total Firings:      2
```

/stats/slb/sp *<sp number>/maint*

SP Maintenance Statistics

```
SP 1 SLB Maintenance stats:
Maximum sessions:          523264
Current sessions:          0
  4 second average:        0
 64 second average:        0
Terminated sessions:      0
Allocation failures:      0
Non TCP/IP frames:        0
TCP fragments:             0
UDP datagrams:             0
Incorrect VIPs:            0
Incorrect Vports:         0
No available real server:  0
Filtered (denied) frames:  0
LAND attacks:              0
Total IP fragment sessions: 0
IP fragment sessions:     0
IP fragment discards:     0
IP fragment table full:   0
```

`/stats/slb/real <real server number>` Real Server SLB Statistics

```
Real server 1 stats:
Health check failures:      0
Current sessions:          129
Total sessions:            65478
Highest sessions:          4343
Octets                     523824000
```

NOTE – Octets are provided per server, not per service, unless configured as described in “Per Service Octet Counters” on page 135.

Table 5-26 Real Server SLB Statistics (`/stats/slb/real`)

Statistics	Description
Current sessions	The total number of outstanding sessions that are established to the particular real server.
Total sessions	The total number of sessions that have been established to the particular real server.
Highest sessions	The highest number of sessions ever recorded for the particular real server.
Octets	The total number of octets sent by the particular real server.

Per Service Octet Counters

For each load-balanced real server, the octet counters represent the combined number of transmit and receive bytes (octets). These counters are then added to report the total octets for each virtual server.

The octet counters are provided per server—not per service. If you need octet counters on a per-service basis, you can accomplish this through the following configuration:

- 1. Configure a separate IP address for each service on each server being load balanced.**

For instance, you can configure IP address 10.1.1.20 for HTTP services, and 10.1.1.21 for FTP services on the same physical server.

2. **On the GbE Switch Module, configure a real server with a real IP address for each service above.**

Continuing the example above, two real servers would be configured for the physical server (representing each real service). If there were five physical servers providing the two services (HTTP and FTP), 10 real servers would have to be configured: five for the HTTP services on each physical server, and five for the FTP services on each physical server.

3. **On the GbE Switch Module, configure one real server group for each type of service, and group each appropriate real server IP address into the group that handles the specific service.**

Thus, in keeping with our example, two groups would be configured: one for handling HTTP and one for handling FTP.

4. **Configure a virtual server and add the appropriate services to that virtual server.**

`/stats/slb/group <real server group number>` Real Server Group Statistics

Real server group 1 stats:					
Real IP address	Current Sessions	Total Sessions	Highest Sessions	Octets	
1 200.100.10.14	20	60	9	480000	
2 200.100.10.15	20	77	12	616000	
-----		40	137	21	1096000

Real server group statistics include the following:

- Current and total sessions for each real server in the real server group.
- Current and total sessions for all real servers associated with the real server group.
- Highest number of simultaneous sessions recorded for each real server.
- Real server transmit/receive octets. For per-service octet counters, see the procedure on “Per Service Octet Counters” on page 135.

`/stats/slb/virt` <virtual server number> Virtual Server SLB Statistics

Virtual server 1 stats:					
Real IP address	Current Sessions	Total Sessions	Highest Sessions	Octets	
1 200.100.10.14	20	60	9	480000	
2 200.100.10.15	20	77	12	616000	
200.100.10.20	40	309	21	1096000	

NOTE – The virtual server IP address is shown on the last line, below the real server IP addresses.

Virtual server statistics include the following:

- Current and total sessions for each real server associated with the virtual server.
- Current and total sessions for all real servers associated with the virtual server.
- Highest number of simultaneous sessions recorded for each real server.
- Real server transmit/receive octets. For per-service octet counters, see [“Per Service Octet Counters”](#) on page 135.

`/stats/slb/filt` <filter number> Filter SLB Statistics

Filter 1 stats:	
Total firings:	1011

You can obtain the total number of times any filter has been used.

/stats/slb/layer7

SLB Layer7 Statistics Menu

```
[Layer 7 Statistics Menu]
  redir  - Show URL Redirection stats
  str    - Show SLB String stats
  maint  - Show Layer 7 Maintenance stats
```

Table 5-27 SLB Layer 7 Statistics Menu Options (/stats/slb/layer7)

Command Syntax & Usage

redir

Displays URL Redirection statistics. See [page 138](#) for a sample output.

str

Displays SLB string statistics. See [page 139](#) for a sample output.

maint

Displays Layer 7 maintenance statistics. See [page 140](#) for a sample output.

/stats/slb/layer7/redir

Layer7 Redirection Statistics

```
Total URL based web cache redirection stats:
Total cache server hits:                      0
Total origin server hits:                     0
Total straight to origin server hits:         0
Total none-GETs hits:                         0
Total 'Cookie: ' hits:                       0
Total no-cache hits:                         0
```

Table 5-28 Layer 7 Redirection Statistics (/stats/slb/layer7/redir)

Statistics	Description
Total cache server hits	The total number of HTTP requests redirected to the cache server.
Total origin server hits	The total number of HTTP requests forwarded to the origin server.
Total straight to origin server hits	The total number of HTTP requests forwarded from straight to the origin server.
Total none-GETs hits	The total number of none GET requests forwarded to the origin server.
Total 'Cookie:' hits	The total number of cookie requests forwarded to the origin server.

Table 5-28 Layer 7 Redirection Statistics (/stats/slb/layer7/redir)

Statistics	Description
Total no-cache hits	The total number of requests containing <i>no-cache header</i> forwarded to the origin server.

/stats/slb/layer7/str

Layer 7 SLB String Statistics

```

SLB String stats:
  ID SLB String                Hits
  1 any                        1527115
  2 www.[abcdefghijklm]*.com    0
  3 www.[nopqrstuvwxyz]*.com  0
  4 www.junk.com                0
  5 www.abc.com                 0
  6 www.[abcdefjhijklm]*.org   0
  7 www.[nopqrstuvwxyz]*.org   0

```

Table 5-29 Layer 7 SLB String Statistics (/stats/slb/layer7/str)

Statistics	Description
ID SLB String	The user-defined strings being used in URL matching.
Hits	The total number of instances that are load-balanced due to matching of the particular URL ID.

/stats/slb/layer7/maint

Layer 7 SLB Maintenance Statistics

Clients reset by switch on server side:	0		
Connection Splicing to support HTTP/1.1:	0		
Half open connections:	0		
Switch retries:	0		
Random early drops:	0		
Requests exceeded 4500 bytes:	0		
Invalid 3-way handshakes:	0		
Current SP[1] memory units:	327	Lowest:	327
Current SP[2] memory units:	327	Lowest:	327
Current SP[3] memory units:	327	Lowest:	327
Current SP[4] memory units:	327	Lowest:	327
Current SP memory units:	1308		
Current SEQ buffer entries:	0	Highest:	0
Current Data buffer use:	0	Highest:	0
Current SP buffer entries:	0	Highest:	0
Total Nonzero SEQ Alloc:	0		
Total SEQ Buffer Allocs:	0	Total SEQ Frees:	0
Total Data Buffer Allocs:	0	Total Data Frees:	0
Alloc Fails - Seq buffers:	0	Alloc Fails - Ubufs:	0
Max sessions per bucket:	0	Max frames per session:	0
Max bytes buffered (sess):	0		

Table 5-30 SLB Layer 7 Maintenance Statistics (/stats/slb/layer7/maint)

Statistics	Description
Clients reset by switch on server side	The number of reset frames sent to the server by the switch during server connection termination.
Connection Splicing to support HTTP/1.1	The total number of connection swapping between different real servers in supporting multiple HTTP/1.1 client requests.
Half open connections	The total numbers of outstanding TCP connections that are half opened. It is incremented when the switch responds to TCP SYN packet and decremented upon receiving TCP SYN ACK packet from the requester.
Switch retries	The total number of switch retries to connect to the real server.
Random early drops	The total number of SYN frames dropped when the buffer is low.
Requests exceeded 4500 bytes	The total number of GET requests that exceeded 4500 bytes.
Invalid 3-way handshakes	The total number of dropped frames because of invalid 3-way handshakes.

Table 5-30 SLB Layer 7 Maintenance Statistics (/stats/slb/layer7/maint)

Statistics	Description
Current SP memory units	The current available SP memory units.
Current SEQ buffer entries	The number of outstanding sequence buffers used.
Highest SEQ buffer entries	The highest number of sequence buffers ever used.
Current Data buffer use	The number of outstanding data buffers used.
Highest Data buffer use	The highest number of data buffers ever used.
Total Nonzero SEQ Alloc	The total number of sequence buffer allocated. ²
Total SEQ Buffer Allocs	The total number of sequence buffer allocations.
Total SEQ Frees	The total number of sequence buffer is freed.
Total Data Buffer Allocs	The total number of buffers allocated to store client request. ²
Total Data Frees	The total of number buffers freed.
Alloc Fails - Seq buffers	The number of times sequence buffer allocation failed.
Alloc Fails - Ubufs	The number of times the URL data buffer allocation failed.
Max sessions per bucket	The maximum number of items (sessions) allowed in the session table hash bucket chain.
Max frames per session	The maximum number of frames to be buffered per session.
Max bytes buffered (sess)	The maximum number of bytes to be buffered per session.

/stats/slb/ssl

SLB Secure Socket Layer Statistics

```

SSL SLB maintenance stats:
SessionId allocation fails:
                                Current      Total      Highest
                                Sessions     Sessions  Sessions
-----
Unique SessionIds                0           0           0
SSL connections                   0           0           0
Persistent Port Sessions          0           0           0

```

Table 5-31 SLB Secure Socket Layer Statistics (/stats/slb/ssl)

Statistics	Description
SSL SLB maintenance stats	Debug stats for SSL SessionId based persistence.
SessionId allocation fails	The number of times allocation of a session table entry failed when attempting to store a SessionId in the table.
The table shows the Current Sessions, the total sessions seen on the switch since last reset and the high water mark of current sessions for the following:	
Unique SessionIds	Many SSL sessions can use the same SessionId, these should all bind to the same server. This number shows the number of unique SSL sessions seen on the switch.
SSL connections	The number of different TCP connections using SSL service.
Persistent Port Sessions	The number of SessionIds, to allow for persistence across different client ports.

/stats/slb/ftp

File Transfer Protocol SLB and Filter Statistics Menu

```
[FTP SLB parsing and Filter Statistics Menu]
  active - Show active FTP NAT filter stats
  parsing - Show FTP SLB parsing server stats
  maint   - Show FTP maintenance stats
  dump    - Dump all FTP SLB/NAT stats
```

Table 5-32 FTP SLB Parsing and Filter Statistics Menu Options (/stats/slb/ftp)

Command Syntax and Usage

active

Shows active FTP SLB parsing and filter statistics. See [page 143](#) for sample output.

parsing

Shows parsing statistics. See [page 144](#) for sample output.

maint

Shows maintenance statistics. See [page 144](#) for sample output.

dump

Shows all FTP SLB/NAT statistics. See [page 145](#).

/stats/slb/ftp/active

Active FTP SLB Parsing and Filter Statistics

```
Total Active FTP NAT stats(PORT) :
Total FTP:                          0
Total New Active FTP Index:         0
Active FTP NAT ACK/SEQ diff:       0
```

Table 5-33 Active FTP Slb Parsing and Filter statistics (/stats/slb/ftp/active)

Statistics	Description
Total Active FTP NAT stats (PORT)	The number of times the switch receives the port command from the client.
Total FTP	The number of times the switch receives both active and passive FTP connections.
Total New Active FTP Index	The number of times the switch creates a new index due to port command from the client.
Active FTP NAT ACK/SEQ diff	The difference in the numbers of ACK and SEQ that the Switch needs for packet adjustment.

/stats/slb/ftp/parsing

Passive FTP SLB Parsing Statistics

Total FTP SLB Parsing Stats (PASV) :	
Total FTP:	0
Total New FTP SLB parsing Index:	0
FTP SLB parsing ACK/SEQ diff:	0

Table 5-34 Passive FTP SLB Parsing Statistics (/stats/slb/ftp/parsing)

Statistics	Description
Total FTP	The number of times the switch receives both active and passive FTP connections.
Total New FTP SLB parsing Index	The number of times the switch creates a new index in response to the pasv command from the client.
FTP SLB parsing ACK/SEQ diff	The difference in the numbers of ACK and SEQ that the switch needs FTP SLB parsing.

/stats/slb/ftp/maint

FTP SLB Maintenance Statistics

FTP mode switch error:	0
------------------------	---

Table 5-35 FTP SLB Maintenance Statistics (/stats/slb/ftp/maint)

Statistics	Description
FTP mode switch error	The number of times the switch is not able to switch modes from active to passive and vice versa.

/stats/slb/ftp/dump

FTP SLB Statistics Dump

Total FTP:	0
Total FTP NAT Filtered:	0
Total new active FTP NAT Index:	0
Total new FTP SLB parsing Index:	0
FTP Active FTP NAT ACK/SEQ diff:	0
FTP SLB parsing ACK/SEQ diff:	0
FTP mode switch error:	0

Table 5-36 FTP SLB Statistics Dump (/stats/slb/ftp/dump)

Statistics	Description
Total FTP	The total number of FTP sessions that occurred.
Total FTP NAT Filtered	The total number of FTP NAT filter sessions that occurred.
Total new active FTP NAT Index	The total number of new data sessions created for FTP NAT filter in active mode.
Total new FTP SLB parsing Index	The number of times the switch creates a new index in response to the pasv command from the client.
FTP Active FTP NAT ACK/SEQ diff	The total number of times the adjustment between ACK and SEQ occurred on the filter.
FTP SLB parsing ACK/SEQ diff	The difference in the numbers of ACK and SEQ that the switch needs for FTP SLB parsing.
FTP mode switch error	The number of times the switch could not switch mode from active to passive and vice versa.

`/stats/slb/rtsp` RTSP SLB Statistics

SP	Control Connection	UDP Streams	Redirect	Connection Denied	Buffer Allocs	Alloc Failures
1	0	0	0	0	0	0
2	0	0	0	0	0	0
3	0	0	0	0	0	0
4	0	0	0	0	0	0
--	-----	-----	-----	-----	-----	-----
	0	0	0	0	0	0

Table 5-37 RTSP SLB Statistics (`/stats/slb/rtsp`)

Statistics	Description
ControlConnection	The total number of TCP connections for RTSP control connection.
UDP Streams	The total number of UDP connections for data channels. The number depends upon the type of media player being used.
Redirect	The total number of times the connection got redirected.
ConnectionDenied	The total number of times the connections got denied due to shortage of resources or the real server being down.
BufferAllocs	The total number of buffer allocations used.
AllocFailures	The total number of times the buffer allocation failed.

`/stats/slb/dns` DNS SLB Statistics

Total number of TCP DNS queries:	0
Total number of UDP DNS queries:	0
Total number of invalid DNS queries:	0
Total number of multiple DNS queries:	0
Total number of domain name parse errors:	0
Total number of failed real server name matches:	0
Total number of DNS parsing internal errors:	0

Table 5-38 DNS SLB Statistics (/stats/slb/dns)

Statistics	Description
Total number of TCP DNS queries	The total number of DNS queries that received through TCP connections.
Total number of UDP DNS queries	The total number of DNS queries received through UDP requests.
Total number of invalid DNS queries	The total number of malformed DNS queries received.
Total number of multiple DNS queries	The total number of DNS queries that contain more than one domain name to be resolved. Currently only one domain name resolution per request is supported.
Total number of domain name parse errors	The total number of DNS queries that have short or invalid domain names to be resolved.
Total number of failed real server name matches	The total number of times the user failed to find a real server which has the same l7 strings that match the domain name to be resolved.
Total number of DNS parsing internal errors	The total number of out of memory and other unexpected errors the user gets while processing the DNS query.

/stats/slb/wap

WAP SLB Statistics

```

WAP Maintenance stats:
  current sessions:                0
  allocation failures:             0
  incorrect VIPs:                  0
  incorrect Vports:                0
  no available real server:        0
  requests to wrong SP:            0
-----
TCP External Notification stats:
  add session reqs:                0   del session reqs:                0
  req fails- q full:               0   req fails- q full:               0
  req fails- SP dead:              0   req fails- SP dead:              0
  entries in use:                   0   entries in use:                   0
  max entries in use:               0   max entries in use:               0
-----
RADIUS Snooping stats:
  acct reqs:                       0   acct wrap reqs:                  0
  acct start reqs:                 0   acct update reqs:                0
  acct stop reqs:                  0   acct bad reqs:                   0
  add session reqs:                0   del session reqs:                0
  req fails- q full:               0   req fails- SP dead:              0
  req fails- DMA:                  0   max entries in use:              0

```

Table 5-39 WAP SLB Statistics (/stats/slb/wap)

Statistics	Description
WAP Maintenance stats:	
current sessions	The number of session bindings currently in use.
allocation failures	Indicates instances where the switch ran out of available bindings for a port.
incorrect VIPs	Indicates the number of times the switch received a Layer 4 request for a virtual server which was not configured.
incorrect Vports	This dropped frames counter indicates that the virtual server has received frames for TCP/UDP services that have not been configured. Normally this indicates a mis-configuration on the virtual server or the client.
no available real server	This dropped frames counter indicates that all real servers are either out of service or at their maxcon limit.
requests to wrong SP	The number of session add/delete requests sent to the wrong SP.

Table 5-39 WAP SLB Statistics (/stats/slb/wap)

Statistics	Description
TPCP External Notification stats:	
add session reqs	The number of WAP session add requests via TPCP.
del session reqs	The number of WAP session delete requests via TPCP.
req fails- q full	The number of add-request failures due to request queue being full.
req fails- SP dead	The number of add-request failures due to dead target SP.
entries in use	The number of queue entries in use.
max entries in use	The maximum number of queue entries in use at one time for session delete requests via TPCP.
RADIUS Snooping stats:	
acct reqs	The number of RADIUS Accounting frames received.
acct wrap reqs	The number of wrapped RADIUS Accounting frames received.
acct start reqs	The number of RADIUS Accounting Start frames received.
acct update reqs	The number of RADIUS Accounting Update frames.
acct stop reqs	The number of RADIUS Accounting Stop frames received.
acct bad reqs	The number of bad RADIUS Accounting frames received.
add session reqs	The number of WAP session add requests via RADIUS snooping.
del session reqs	The number of WAP session delete requests via RADIUS snooping.
req fails- q full	The number of add/delete requests failed due to request queue being full.
req fails- SP dead	The number of add/delete request failures due to dead target SP.
req fails- DMA	The number of add/delete requests failed due to DMA write failure.
max entries in use	The maximum number of queue entries in use at a time for session add/delete requests via RADIUS snooping.

`/stats/slb/tcp` SLB TCP Rate Limiting Statistics

```
TCP rate limiting stats:
  Total hold downs triggered:          0
  Current per-client state entries:    0
```

Table 5-40 SLB TCP Rate Limiting Statistics (`/stats/slb/tcp`)

Statistics	Description
Total hold downs triggered	The total number of hold downs that occurred since the last stats clear.
Current per-client state entries	The current number of per client state entries in the session table.

`/stats/slb/maint` SLB Maintenance Statistics

```
SLB Maintenance stats:
Maximum sessions:          2093056
Current sessions:         0
  4 second average:       0
  64 second average:      0
Terminated sessions:      0
Allocation failures:      0
TCP fragments:            0
UDP datagrams:            0
Non TCP/IP frames:       0
Incorrect VIPs:           0
Incorrect Vports:         0
No available real server: 0
Backup server activations: 0
Overflow server activations: 0
Filtered (denied) frames: 0
LAND attacks:             0
Total IP fragment sessions: 0
Current IP fragment sessions 0
IP fragment discards:     0
IP fragment table full:   0
```

SLB Maintenance statistics are described in the following table.

Table 5-41 Server Load Balancing Maintenance Statistics (/stats/slb/maint)

Statistic	Description
Maximum sessions	The maximum number of simultaneous sessions supported.
Current Sessions	Number of session bindings currently in use (the last 4 and 64 seconds).
Terminated Sessions	Number of sessions removed from the session table because the server assigned to them failed and graceful server failure was not enabled.
Allocation Failures	Indicates instances where the Switch ran out of available sessions for a port.
TCP Fragments	Indicates the number of TCP fragments encountered by the switch. Layer 4 processing might not handle TCP fragments, depending on configuration.
UDP Datagrams	Indicates that the virtual server IP address and MAC are receiving UDP frames when UDP balancing is not turned on.
Non TCP/IP Frames	Indicates the number of non-IP based frames received by the virtual server.
Incorrect VIPs	Indicates the number of times the switch received a Layer 4 request for a virtual server which was not configured.
Incorrect Vports	This dropped frames counter indicates that the virtual server has received frames for TCP/UDP services that have not been configured. Normally this indicates a mis-configuration on the virtual server or the client, but it may be an indication of a potential security probing application like SATAN.
No Server Available	This dropped frames counter indicates that all real servers are either out of service or at their maxcon limit.
Backup Server Activations	This indicates the number of times a real server failure has occurred and caused a backup server to be brought online.
Overflow Server Activations	This indicates the number of times a real server has reached the maxcon limit and caused an overflow server to be brought online.
Filtered (Denied) Frames	This indicates the number of frames that were dropped because they matched an active filter with the deny action set.
LAND attacks	This counter increases whenever a packet has the same source and destination IP addresses and ports.
Total IP fragment sessions	This represents the total number of fragment sessions the switch has processed so far.
Current IP fragment sessions	This represents the current number of fragment sessions.
IP fragment dis-cards	The number of fragmented packets that are discarded due to lack of resources.
IP fragment table full	This counter indicates how many times session table is full.

`/stats/slb/clear`

Clearing the SLB Statistics

The following statistics are reset to zero when the clear command is given and confirmed:

Table 5-42 SLB Statistics Reset (`/stats/slb/clear`)

Statistics	Description
Real server stats:	Health check failures Total sessions Highest sessions Octets
Real server group stats:	Total sessions Highest sessions Octets
Virtual server stats	Total sessions Highest sessions Octets
Filter stats	Total firings
SLB switch port stats, per port	Real server stats: Octets, Total sessions Real server group: Octets, Total sessions Virtual server: Octets, Total sessions Total firings: Octets
Global SLB stats	Per real server: DNS handoffs HTTP redirects Per server group: DNS handoffs HTTP redirects
URL SLB and Redirection stats	Redir: Total cache server hits Total origin server hits Total none-GETs hits Total 'Cookie: ' hits Total no-cache hits LB: ID SLB String hits
SSL SLB stats	Total Sessions Highest Sessions

Table 5-42 SLB Statistics Reset (/stats/slb/clear)

Statistics	Description
FTP SLB parsing and NAT stats	Total FTP Total FTP NAT Filtered Total new active FTP NAT Index Total new FTP SLB parsing Index FTP Active FTP NAT ACK/SEQ diff FTP SLB parsing ACK/SEQ diff
Real server stats	Health check failures Total sessions Highest sessions Octets
Real server group stats	Total sessions Highest sessions Octets
Virtual server stats	Total sessions Highest sessions Octets

/stats/mp

Management Processor Statistics

```
[MP-specific Statistics Menu]
pkt      - Show Packet stats
tcb      - Show All TCP control blocks in use
ucb      - Show All UDP control blocks in use
cpu      - Show CPU utilization
mem      - Show memory stats
```

Table 5-43 Management Processor Statistics Menu Options (/stats/mp)

Command Syntax and Usage

pkt

Displays packet statistics, to check for leads and load. To view a sample output and a description of the stats, see [page 154](#).

tcb

Displays all TCP control blocks that are in use. To view a sample output and a description of the stats, see [page 155](#).

Table 5-43 Management Processor Statistics Menu Options (/stats/mp)

Command Syntax and Usage	
ucb	Displays all UDP control blocks that are in use. To view a sample output, see page 155 .
sfd	Displays all Socket File Descriptors that are in use. To view a sample output, see page 156 .
cpu	Displays CPU utilization for periods of up to 1, 4, and 64 seconds. To view a sample output and a description of the stats, see page 156 .
mem	Displays memory statistics.

/stats/mp/pkt

MP Packet Statistics

Packet counts:			
allocs:	1166996	frees:	1166996
mediums:	0	mediums hi-watermark:	7
smalls:	0	smalls hi-watermark:	7
failures:	0		

Table 5-44 Packet Statistics (/stats/mp/pkt)

Statistics	Description
allocs	Total number of packet allocations from the packet buffer pool by the TCP/IP protocol stack.
frees	Total number of times the packet buffers are freed (released) to the packet buffer pool by the TCP/IP protocol stack.
mediums	Total number of packet allocations with size between 128 to 1536 bytes from the packet buffer pool by the TCP/IP protocol stack.
smalls	Total number of packet allocations with size less than 128 bytes from the packet buffer pool by the TCP/IP protocol stack.
failures	Total number of packet allocation failures from the packet buffer pool by the TCP/IP protocol stack.
frees	Total number of packets freed from the packet buffer pool by the TCP/IP protocol stack.

Table 5-44 Packet Statistics (/stats/mp/pkt)

Statistics	Description
mediums hi-water-mark	The highest number of packet allocation with size between 128 to 1536 bytes from the packet buffer pool by the TCP/IP protocol stack.
smalls hi-watermark	The highest number of packet allocation with size less than 128 bytes from the packet buffer pool by the TCP/IP protocol stack.

/stats/mp/tcb

TCP Statistics

```
All TCP allocated control blocks:
10ad41e8:  0.0.0.0          0 <=> 0.0.0.0          80 listen
10ad5790:  47.81.27.5         1171 <=> 47.80.23.243    23 established
```

Table 5-45 MP Specified TCP Statistics (/stats/mp/tcb)

Statistics	Description
10ad41e8/10ad5790	Memory
0.0.0.0/47.81.27.5	Destination IP address
0/1171	Destination port
0.0.0.0/47.80.23.243	Source IP
80/23	Source port
listen/established	State

/stats/mp/ucb

UCB Statistics

```
All UDP allocated control blocks:
161: listen
```

`/stats/mp/sfd` MP-Specific SFD Statistics

```
All Socket FD allocated:
max_fdi=2
fdi=0 fd=15 pfdi=-1
10c27fd8: 0.0.0.0          0<=>47.133.108.161 80  listen TCP server
fdi=1 fd=16 pfdi=-1
10b9564c: 0.0.0.0          0<=>47.133.108.161 23  listen TCP server
fdi=2 fd=17 pfdi=1
10c27c78: 47.129.153.150 5341<=>47.133.108.161 23  accept TCP  server
```

`/stats/mp/cpu` CPU Statistics

This menu option enables you to display the CPU utilization statistics.

```
CPU utilization:
cpuUtil1Second:          53%
cpuUtil4Seconds:         54%
cpuUtil64Seconds:        54%
```

Table 5-46 CPU Statistics (stats/mp/cpu)

Statistics	Description
cpuUtil1Second	The utilization of MP CPU over 1 second. It shows the percentage.
cpuUtil4Seconds	The utilization of MP CPU over 4 seconds. It shows the percentage.
cpuUtil64Seconds	The utilization of MP CPU over 64 seconds. It shows the percentage.

`/stats/sp <SP Number>` SP Specific Statistics Menu

```
[SP-specific Statistics Menu]
  maint   - Show maintenance stats
  clear   - Clear maintenance stats
  cpu     - Show CPU utilization
```

Table 5-47 SP Specific Statistics (/stats/sp)

Statistics	Description
maint	Indicates the total number of all the letter statistics received or sent from this SP.
clear	Deletes all the maintenance statistics.
cpu	Displays what percentage of the CPU has been utilized.

/stats/pace

Packet Acceleration Statistics Menu

```
[Packet Acceleration Statistics Menu]
error      - PACE Error Stats
info       - PACE Informational Stats
maint      - PACE Maintenance Stats
fp         - PACE HFP Stats
clear      - Clear non-operational PACE stats
dump       - Dump all PACE statistics
```

Table 5-48 Packet Acceleration Statistics (/stats/pace)

Statistics	Description
error	Display error statistics on the PACE processor.
info	Display general information about PACE performance.
maint	Display session data about the utilization of PACE resources.
fp	Display hardware counts for data passed through the frame processor.
clear	Clear non-operational PACE statistics.
dump	Dump all PACE statistics.

/stats/snmp

SNMP Statistics

SNMP statistics:			
snmpInPkts:	54	snmpInBadVersions:	0
snmpInBadC'tyNames:	0	snmpInBadC'tyUses:	0
snmpInASNParseErrs:	0	snmpEnableAuthTraps:	0
snmpOutPkts:	54	snmpInBadTypes:	0
snmpInTooBig:	0	snmpInNoSuchNames:	0
snmpInBadValues:	0	snmpInReadOnly:	0
snmpInGenErrs:	0	snmpInTotalReqVars:	105
snmpInTotalSetVars:	0	snmpInGetRequests:	2
snmpInGetNexts:	52	snmpInSetRequests:	0
snmpInGetResponses:	0	snmpInTraps:	0
snmpOutTooBig:	0	snmpOutNoSuchNames:	2
snmpOutBadValues:	0	snmpOutReadOnly:	0
snmpOutGenErrs:	0	snmpOutGetRequests:	0
snmpOutGetNexts:	0	snmpOutSetRequests:	0
snmpOutGetResponses:	54	snmpOutTraps:	0

Table 5-49 SNMP Statistics (/stats/snmp)

Statistics	Description
snmpInPkts	The total number of Messages delivered to the SNMP entity from the transport service.
snmpInBadVersions	The total number of SNMP Messages, which were delivered to the SNMP protocol entity and were for an unsupported SNMP version.
snmpInBadC'tyNames	The total number of SNMP Messages delivered to the SNMP entity which used an SNMP community name not known to the said entity (the switch).
snmpInBadC'tyUses	The total number of SNMP Messages delivered to the SNMP protocol entity which represented an SNMP operation which was not allowed by the SNMP community named in the Message.
snmpInASNParseErrs	<p>The total number of ASN.1 or BER errors encountered by the SNMP protocol entity when decoding SNMP Messages received.</p> <p>Note: OSI's method of specifying abstract objects is called ASN.1 (Abstract Syntax Notation One, defined in X.208), and one set of rules for representing such objects as strings of ones and zeros is called the BER (Basic Encoding Rules, defined in X.209). ASN.1 is a flexible notation that allows one to define a variety of data types, from simple types such as integers and bit strings to structured types such as sets and sequences. BER describes how to represent or encode values of each ASN.1 type as a string of eight-bit octets.</p>

Table 5-49 SNMP Statistics (/stats/snmp)

Statistics	Description
snmpEnableAuthTraps	An object to enable or disable the authentication traps generated by this entity (the switch).
snmpOutPkts	The total number of SNMP Messages which were passed from the SNMP protocol entity to the transport service.
snmpInBadTypes	The total number of SNMP Messages which failed ASN parsing.
snmpInTooBig	The total number of SNMP Protocol Data Units (PDUs) which were delivered to the SNMP protocol entity and for which the value of the error-status field is <i>too big</i> .
snmpInNoSuchNames	The total number of SNMP Protocol Data Units (PDUs) which were delivered to the SNMP protocol entity and for which the value of the error-status field is <i>noSuchName</i> .
snmpInBadValues	The total number of SNMP Protocol Data Units (PDUs) which were delivered to the SNMP protocol entity and for which the value of the error-status field is <i>badValue</i> .
snmpInReadOnly	The total number of valid SNMP Protocol Data Units (PDUs), which were delivered to the SNMP protocol entity and for which the value of the error-status field is 'read-Only'. It should be noted that it is a protocol error to generate an SNMP PDU, which contains the value 'read-Only' in the error-status field. As such, this object is provided as a means of detecting incorrect implementations of the SNMP.
snmpInGenErrs	The total number of SNMP Protocol Data Units (PDUs), which were delivered to the SNMP protocol entity and for which the value of the error-status field is <i>genErr</i> .
snmpInTotalReqVars	The total number of MIB objects which have been retrieved successfully by the SNMP protocol entity as a result of receiving valid SNMP Get-Request and Get-Next Protocol Data Units (PDUs).
snmpInTotalSetVars	The total number of MIB objects, which have been altered successfully by the SNMP protocol entity as a result of receiving valid SNMP Set-Request Protocol Data Units (PDUs).
snmpInGetRequests	The total number of SNMP Get-Request Protocol Data Units (PDUs), which have been accepted and processed by the SNMP protocol entity.
snmpInGetNexts	The total number of SNMP Get-Next Protocol Data Units (PDUs), which have been accepted and processed by the SNMP protocol entity.
snmpInSetRequests	The total number of SNMP Set-Request Protocol Data Units (PDUs), which have been accepted and processed by the SNMP protocol entity.

Table 5-49 SNMP Statistics (/stats/snmp)

Statistics	Description
snmpInGetResponses	The total number of SNMP Get-Response Protocol Data Units (PDUs), which have been accepted and processed by the SNMP protocol entity.
snmpInTraps	The total number of SNMP Trap Protocol Data Units (PDUs), which have been accepted and processed by the SNMP protocol entity.
snmpOutTooBig	The total number of SNMP Protocol Data Units (PDUs), which were generated by the SNMP protocol entity and for which the value of the error-status field is <i>too big</i> .
snmpOutNoSuchNames	The total number of SNMP Protocol Data Units (PDUs), which were generated by the SNMP protocol entity and for which the value of the error-status is <i>noSuchName</i> .
snmpOutBadValues	The total number of SNMP Protocol Data Units (PDUs), which were generated by the SNMP protocol entity and for which the value of the error-status field is <i>badValue</i> .
snmpOutReadOnly	Not in use.
snmpOutGenErrs	The total number of SNMP Protocol Data Units (PDUs), which were generated by the SNMP protocol entity and for which the value of the error-status field is <i>genErr</i> .
snmpOutGetRequests	The total number of SNMP Get-Request Protocol Data Units (PDUs), which have been generated by the SNMP protocol entity.
snmpOutGetNexts	The total number of SNMP Get-Next Protocol Data Units (PDUs), which have been generated by the SNMP protocol entity.
snmpOutSetRequests	The total number of SNMP Set-Request Protocol Data Units (PDUs), which have been generated by the SNMP protocol entity.
snmpOutGetResponses	The total number of SNMP Get-Response Protocol Data Units (PDUs), which have been generated by the SNMP protocol entity.
snmpOutTraps	The total number of SNMP Trap Protocol Data Units (PDUs), which have been generated by the SNMP protocol entity.

/stats/ntp

NTP Statistics

Alteon OS uses NTP (Network Timing Protocol) version 3 to synchronize the switch's internal clock with an atomic time calibrated NTP server. With NTP enabled, the switch can accurately update its internal clock to be consistent with other devices on the network and generates accurate syslogs.

```
NTP statistics:
  Primary Server:
    Requests Sent:           17
    Responses Received:     17
    Updates:                 1
  Secondary Server:
    Requests Sent:           0
    Responses Received:     0
    Updates:                 0
```

Table 5-50 NTP Statistics Parameters (/stats/ntp)

Field	Description
Primary Server	<p>Requests Sent: The total number of NTP requests the switch sent to the primary NTP server to synchronize time.</p> <p>Responses Received: The total number of NTP responses received from the primary NTP server.</p> <p>Updates: The total number of times the switch updated its time based on the NTP responses received from the primary NTP server.</p>
Secondary Server	<p>Requests Sent: The total number of NTP requests the switch sent to the secondary NTP server to synchronize time.</p> <p>Responses Received: The total number of NTP responses received from the secondary NTP server.</p> <p>Updates: The total number of times the switch updated its time based on the NTP responses received from the secondary NTP server.</p>

`/stats/dump` **Statistics Dump**

Use the dump command to dump all switch statistics available from the Statistics Menu (40K or more, depending on your configuration). This data can be used to tune or debug switch performance.

If you want to capture dump data to a file, set your communication software on your workstation to capture session data prior to issuing the dump commands.

CHAPTER 6

The Configuration Menu

This chapter discusses how to use the Command Line Interface (CLI) for making, viewing, and saving switch configuration changes. Many of the commands, although not new, display more or different information than in the previous version. Important differences are called out in the text.

To make finding information easier, the menu options under the Server Load Balancing Menu (/cfg/slb) are in Chapter 7.

/cfg

Configuration Menu

```
[Configuration Menu]
  sys      - System-wide Parameter Menu
  port     - Port Menu
  pmirr    - Port Mirroring Menu
  l2       - Layer 2 Menu
  l3       - Layer 3 Menu
  slb      - Server Load Balancing (Layer 4-7) Menu
  setup    - Step by step configuration set up
  dump     - Dump current configuration to script file
  ptcfg    - Backup current configuration to tftp server
  gtcfg    - Restore current configuration from tftp server
```

Table 6-1 Configuration Menu Options (/cfg)

Command Syntax and Usage

sys

Displays the System Configuration Menu. To view menu options, see [page 167](#).

port <port alias or number>

Displays the Port Configuration Menu. To view menu options, see [page 181](#).

Table 6-1 Configuration Menu Options (/cfg)

Command Syntax and Usage

pmirr

Displays the Mirroring Configuration Menu. To view menu options, see [page 184](#).

l2

Displays the Layer 2 Configuration Menu. To view menu options, see [page 186](#).

l3

Displays the Layer 3 Configuration Menu. To view menu options, see [page 200](#).

slb

Displays the Server Load Balancing Configuration Menu. To view menu options, see [Chapter 7, “The SLB Configuration Menu”](#).

setup

Step-by-step configuration set-up of the switch. For details, see [page 249](#).

dump

Dumps current configuration to a script file. For details, see [page 249](#).

ptcfg *<host name or IP address of TFTP server>* *<filename on host>*

Backs up current configuration to TFTP server. For details, see [page 250](#).

gtcfg *<host name or IP address of TFTP server>* *<filename on host>*

Restores current configuration from TFTP server. For details, see [page 250](#).

Viewing, Applying, and Saving Changes

As you use the configuration menus to set switch parameters, the changes you make do not take effect immediately. All changes are considered “pending” until you explicitly apply them. Also, any changes are lost the next time the switch boots unless the changes are explicitly saved.

NOTE – Some operations can override the settings in the Configuration menu. Therefore, settings you view in the Configuration menu (for example, port status) might differ from run-time information that you view in the Information menu or on the management module. The Information menu displays current run-time information of switch parameters.

While configuration changes are in the pending state, you can do the following:

- View the pending changes
- Apply the pending changes
- Save the changes to flash memory

Viewing Pending Changes

You can view all pending configuration changes by entering `diff` at the menu prompt.

NOTE – The `diff` command is a global command. Therefore, you can enter `diff` at any prompt in the CLI.

Applying Pending Changes

To make your configuration changes active, you must apply them. To apply configuration changes, enter `apply` at any prompt in the CLI.

```
# apply
```

NOTE – The `apply` command is a global command. Therefore, you can enter `apply` at any prompt in the administrative interface.

NOTE – All configuration changes take effect immediately when applied, except for starting Spanning Tree Group. To turn STG on or off, you must apply the changes, save them (see below), and then reset the switch (see “Resetting the Switch” on page 310).

Saving the Configuration

In addition to applying the configuration changes, you can save them to flash memory on the GbE Switch Module.

NOTE – If you do not save the changes, they will be lost the next time the system is rebooted.

To save the new configuration, enter the following command at any CLI prompt:

```
# save
```

When you save configuration changes, the changes are saved to the *active* configuration block. The configuration being replaced by the save is first copied to the *backup* configuration block. If you do not want the previous configuration block copied to the backup configuration block, enter the following instead:

```
# save n
```

You can decide which configuration you want to run the next time you reset the switch. Your options include:

- The active configuration block
- The backup configuration block
- Factory default configuration

You can view all pending configuration changes that have been applied but not saved to flash memory using the `diff flash` command. It is a global command that can be executed from any menu.

For instructions on selecting the configuration to run at the next system reset, see [“Selecting a Configuration Block” on page 309](#).

/cfg/sys

System Configuration

```
[System Menu]
  syslog - Syslog Menu
  sshd   - SSH Server Menu
  radius - RADIUS Authentication Menu
  tacacs - TACACS+ Authentication Menu
  ntp    - NTP Server Menu
  ssnmp  - System SNMP Menu
  access - System Access Menu
  date   - Set system date
  time   - Set system time
  idle   - Set timeout for idle CLI sessions
  notice - Set login notice
  banr   - Set login banner
  smtp   - Set SMTP host
  hprompt - Enable/disable display hostname (sysName) in CLI prompt
  bootp  - Enable/disable use of BOOTP
  cur    - Display current system-wide parameters
```

This menu provides configuration of switch management parameters such as user and administrator privilege mode passwords, Web-based management settings, and management access lists.

Table 6-2 System Configuration Menu Options (/cfg/sys)

Command Syntax and Usage

syslog

Displays the Syslog Menu. To view menu options, see [page 169](#).

sshd

Displays the SSH Server Menu. To view menu options, see [page 170](#).

radius

Displays the RADIUS Authentication Menu. To view menu options, see [page 171](#).

tacacs

Displays the TACACS+ Authentication Menu. To view menu options, see [page 172](#).

ntp

Displays the Network Time Protocol (NTP) Server Menu. To view menu options, see [page 174](#).

ssnmp

Displays the System SNMP Menu. To view menu options, see [page 176](#).

Table 6-2 System Configuration Menu Options (/cfg/sys)

Command Syntax and Usage

access

Displays the System Access Menu. To view menu options, see [page 178](#).

date

Prompts the user for the system date. The date reverts to its default value when the switch is reset.

time

Configures the system time using a 24-hour clock format. The time reverts to its default value when the switch is reset.

idle *<idle timeout in minutes Telnet>*

Sets the idle timeout for CLI sessions, from 1 to 60 minutes. The default is 5 minutes.

notice *<max 1024 char multi-line login notice> <'-' to end>*

Displays login notice immediately before the “Enter password:” prompt. This notice can contain up to 1024 characters and new lines.

bannr *<string, maximum 80 characters>*

Configures a login banner of up to 80 characters. When a user or administrator logs into the switch, the login banner is displayed. It is also displayed as part of the output from the `/info/sys` command.

smtp *<SMTP host name or IP address>*

Sets the Simple Mail Transfer Protocol (SMTP) host, which is used for sending bandwidth management history information.

hprompt **disable** | **enable**

Enables or disables displaying of the host name (system administrator’s name) in the Command Line Interface (CLI).

bootp **disable** | **enable**

Enables or disables the use of BOOTP. If you enable BOOTP, the switch will query its BOOTP server for all of the switch IP parameters. This command is disabled by default.

cur

Displays the current system parameters.

/cfg/sys/syslog

System Host Log Configuration

```
[Syslog Menu]
  host      - Set IP address of first syslog host
  host2     - Set IP address of second syslog host
  sever     - Set the severity of first syslog host
  sever2    - Set the severity of second syslog host
  facil     - Set facility of first syslog host
  facil2    - Set facility of second syslog host
  console   - Enable/disable console output of syslog messages
  log       - Enable/disable syslogging of features
  cur       - Display current syslog settings
```

Table 6-3 System Configuration Menu Options (/cfg/sys/syslog)

Command Syntax and Usage

host <new syslog host IP address (such as, 192.4.17.223)>
Sets the IP address of the first syslog host.

host2 <new syslog host IP address (such as, 192.4.17.223)>
Sets the IP address of the second syslog host.

sever <syslog host local severity (0-7)>
This option sets the severity level of the first syslog host displayed. The default is 7, which means log all the seven severity levels.

sever2 <syslog host local severity (0-7)>
This option sets the severity level of the second syslog host displayed. The default is 7, which means, log all the seven severity levels.

facil <syslog host local facility (0-7)>
This option sets the facility level of the first syslog host displayed. The default is 0.

facil2 <syslog host local facility (0-7)>
This option sets the facility level of the second syslog host displayed. The default is 0.

console **disable** | **enable**
Enables or disables delivering syslog messages to the console. When necessary, disabling `console` ensures the switch is not affected by syslog messages. It is enabled by default.

log <feature | all> <enable | disable>
Displays a list of features for which syslog messages can be generated. You can choose to enable/disable specific features (such as vlans, gslb, filter), or enable/disable syslog on all available features.

cur
Displays the current syslog settings.

/cfg/sys/sshd

SSH Server Configuration Menu

```
[SSHD Menu]
  intrval - Set Interval for generating the RSA server key
  scpadm  - Set SCP-only admin password
  hkeygen - Generate the RSA host key
  skeygen - Generate the RSA server key
  sshport - Set SSH server port number
  ena     - Enable the SCP apply and save
  dis     - Disable the SCP apply and save
  on      - Turn SSH server ON
  off     - Turn SSH server OFF
  cur     - Display current SSH server configuration
```

For the GbE Switch Module, this menu enables Secure Shell access from any SSH client. SSH scripts can be viewed by using the `/cfg/dump` command (see [page 249](#)).

NOTE – Except for `cur`, the commands of this menu are only accessible through the management module interface.

Table 6-4 System Configuration Menu Options (`/cfg/sys/sshd`)

Command Syntax and Usage

intrval *<0 - 24>*

Set the interval for auto-generation of the RSA server key.

scpadm

Set the administration password for SCP access.

hkeygen

Generate the RSA host key.

skeygen

Generate the RSA server key.

sshport *<TCP port number>*

Sets the SSH server port number.

ena

Enables the SCP apply and save.

dis

Disables the SCP apply and save.

on

Enables the SSH server.

Table 6-4 System Configuration Menu Options (/cfg/sys/sshd)**Command Syntax and Usage****off**

Disables the SSH server.

cur

Displays the current SSH server configuration.

/cfg/sys/radius

RADIUS Server Configuration

```
[RADIUS Server Menu]
  prisrv - Set primary RADIUS server address
  secsrv - Set secondary RADIUS server address
  secret - Set RADIUS secret
  secret2 - Set secondary RADIUS server secret
  port - Set RADIUS port
  retries - Set RADIUS server retries
  timeout - Set RADIUS server timeout
  telnet - Enable or disable RADIUS backdoor for telnet
  on - Turn RADIUS authentication ON
  off - Turn RADIUS authentication OFF
  cur - Display current RADIUS configuration
```

Table 6-5 System Configuration Menu Options (/cfg/sys/radius)**Command Syntax and Usage****prisrv** <IP address>

Sets the primary RADIUS server address.

secsrv <IP address>

Sets the secondary RADIUS server address.

secret <1-32 character secret>

This is the shared secret between the switch and the RADIUS server(s).

secret2 <1-32 character secret>

This is the secondary shared secret between the switch and the RADIUS server(s).

port <RADIUS port configure, default 1645>

Enter the number of the UDP port to be configured, between 1500 - 3000. The default is 1645.

retries <RADIUS server retries (1-3)>Sets the number of failed authentication requests before switching to a different RADIUS server.
The default is 3 requests.

Table 6-5 System Configuration Menu Options (`/cfg/sys/radius`)**Command Syntax and Usage****timeout** *<RADIUS server timeout seconds (1-10)>*

Sets the amount of time, in seconds, before a RADIUS server authentication attempt is considered to have failed. The default is 3 seconds.

telnet disable|enable

Enables or disables the RADIUS backdoor for telnet. The `telnet` command also applies to SSH/SCP connections and the Browser-Based Interface (BBI). The default is `disabled`.

To obtain the RADIUS backdoor password for your GbESM, contact your IBM Service and Support line.

on

Enables the RADIUS server.

off

Disables the RADIUS server.

cur

Displays the current RADIUS server parameters.

`/cfg/sys/tacacs+` TACACS+ Server Configuration Menu

TACACS (Terminal Access Controller Access Control system) is an authentication protocol that allows a remote access server to forward a user's logon password to an authentication server to determine whether access can be allowed to a given system. TACACS is an encryption protocol, and therefore less secure than TACACS+ and Remote Authentication Dial-In User Service (RADIUS) protocols. (Both TACACS and TACACS+ are described in RFC 1492.)

TACACS+ protocol is more reliable than RADIUS, as TACACS+ uses the Transmission Control Protocol (TCP) whereas RADIUS uses the User Datagram Protocol (UDP). Also, RADIUS combines authentication and authorization in a user profile, whereas TACACS+ separates the two operations.

TACACS+ offers the following advantages over RADIUS as the authentication device:

- TACACS+ is TCP-based, so it facilitates connection-oriented traffic.
- It supports full-packet encryption, as opposed to password-only in authentication requests.
- It supports decoupled authentication, authorization, and accounting.

```
[TACACS+ Server Menu]
  prisrv   - Set primary TACACS+ server address
  secsrv   - Set secondary TACACS+ server address
  secret   - Set primary TACACS+ server secret
  secret2  - Set secondary TACACS+ server secret
  port     - Set TACACS+ TCP port
  retries  - Set TACACS+ server retries
  timeout  - Set TACACS+ server timeout (seconds)
  telnet   - Enable/disable TACACS+ backdoor for telnet
  cauth    - Enable/disable TACACS+ command authorization
  clog     - Enable/disable TACACS+ command logging
  on       - Turn TACACS+ authentication ON
  off      - Turn TACACS+ authentication OFF
  cur      - Display current TACACS+ configuration
```

Table 6-6 TACACS+ Server Menu Options (/cfg/sys/tacacs)

Command Syntax and Usage

prisrv <IP address>

Defines the primary TACACS+ server address.

secsrv <IP address>

Defines the secondary TACACS+ server address.

secret <1-32 character secret>

This is the shared secret between the switch and the TACACS+ server(s).

secret2 <1-32 character secret>

This is the secondary shared secret between the switch and the TACACS+ server(s).

port <TACACS port configure, default 49>

Enter the number of the TCP port to be configured, between 1 - 65000. The default is 49.

retries <TACACS server retries, 1-3>

Sets the number of failed authentication requests before switching to a different TACACS+ server. The default is 3 requests.

timeout <TACACS server timeout seconds, 4-15>

Sets the amount of time, in seconds, before a TACACS+ server authentication attempt is considered to have failed. The default is 5 seconds.

telnet **disable** | **enable**

Enables or disables the TACACS+ back door for telnet. The **telnet** command also applies to SSH/SCP connections, and the Browser-Based Interface (BBI). The default is **disabled**.

To obtain the TACACS+ backdoor password for your GbESM, contact your IBM Service and Support line.

Table 6-6 TACACS+ Server Menu Options (/cfg/sys/tacacs)**Command Syntax and Usage****cauth disable | enable**

Enables or disables TACACS+ command authorization.

clog disable | enable

Enables or disables TACACS+ command logging.

on

Enables the TACACS+ server. This is the default setting.

off

Disables the TACACS+ server.

cur

Displays current TACACS+ configuration parameters.

/cfg/sys/ntp

NTP Server Configuration

[NTP Server Menu]

```

prisrv - Set primary NTP server address
secsrv - Set secondary NTP server address
intrval - Set NTP server resync interval
tzone - Set NTP timezone offset from GMT
dlight - Enable or disable NTP daylight savings time
on - Turn NTP service ON
off - Turn NTP service OFF
cur - Display current NTP configuration

```

This menu enables you to synchronize the switch clock to a Network Time Protocol (NTP) server. By default, this option is disabled.

Table 6-7 System Configuration Menu Options (/cfg/sys/ntp)

Command Syntax and Usage

prisrv <NTP Server IP address>

Prompts for the IP addresses of the primary NTP server to which you want to synchronize the switch clock.

secsrv <NTP Server IP address>

Prompts for the IP addresses of the secondary NTP server to which you want to synchronize the switch clock.

intrval <resync interval in minutes>

Specifies the interval, that is, how often, in minutes (1-2880), to re-synchronize the switch clock with the NTP server.

tzone <timezone offset, in HH:MM>

Prompts for the NTP time zone offset, in hours and minutes, of the switch you are synchronizing from Greenwich Mean Time (GMT).

dlight **disable** | **enable**

Disables or enables daylight savings time in the system clock. When enabled, the switch will add an extra hour to the system clock so that it is consistent with the local clock. By default, this option is disabled.

on

Enables the NTP synchronization service.

off

Disables the NTP synchronization service.

cur

Displays the current NTP service settings.

cfg/sys/ssnmp

System SNMP Menu

```
[System SNMP Menu]
name      - Set SNMP "sysName"
locn      - Set SNMP "sysLocation"
cont      - Set SNMP "sysContact"
rcomm     - Set SNMP read community string
wcomm     - Set SNMP write community string
trap1     - Set first SNMP trap host address
trap2     - Set second SNMP trap host address
t1comm    - Set community string for first trap host
t2comm    - Set community string for second trap host
timeout   - Set timeout for the SNMP state machine
auth      - Enable/disable SNMP "sysAuthenTrap"
linkt     - Enable/disable SNMP link up/down trap
cur       - Display current system SNMP configuration
```

The Alteon OS software supports SNMP-based network management. If you are running an SNMP network management station on your network, you can manage the switch using the following standard SNMP MIBs:

- MIB II (RFC 1213)
- Ethernet MIB (RFC 1643)
- Bridge MIB (RFC 1493)

SNMP parameters that can be modified include:

- System name
- System location
- System contact
- Use of the SNMP system authentication trap function
- Read community string
- Write community string
- Trap hosts
- Trap community strings

Table 6-8 System SNMP Menu Options (/cfg/sys/ssnmp)

Command Syntax and Usage

name <new string, maximum 64 characters>

Configures the name for the system. The name can have a maximum of 64 characters.

locn <new string, maximum 64 characters>

Configures the name of the system location. The location can have a maximum of 64 characters.

cont <new string, maximum 64 characters>

Configures the name of the system contact. The contact can have a maximum of 64 characters.

rcomm <new SNMP read community string, maximum 32 characters>

Configures the SNMP read community string. The read community string controls SNMP “get” access to the switch. It can have a maximum of 32 characters. The default read community string is *public*.

wcomm <new SNMP write community string, maximum 32 characters>

Configures the SNMP write community string. The write community string controls SNMP “set” and “get” access to the switch. It can have a maximum of 32 characters. The default write community string is *private*.

trap1 <new SNMP trap host IP address (such as, 192.4.17.101)>

Configures the IP address of the first SNMP trap host using dotted decimal notation. The SNMP trap host is the device that receives SNMP trap messages from the switch.

trap2 <new SNMP trap host IP address (such as, 192.4.17.101)>

Configures the IP address of the second SNMP trap host using dotted decimal notation.

t1comm <new trap host community string, maximum 32 characters>

Configures the community string for the first trap host. The default community string for the first trap host is *public*.

t2comm <new trap host community string, maximum 32 characters>

Configures the community string for the second trap host. The default community string for the second trap host is *public*.

Table 6-8 System SNMP Menu Options (/cfg/sys/ssnmp)**Command Syntax and Usage****timeout**

Set the timeout value for the SNMP state machine.

auth disable | enable

Enables or disables the use of the system authentication trap facility. The default setting is disabled.

linkt <port> [disable | enable]

Enables or disables the sending of SNMP link up and link down traps. The default setting is enabled.

cur

Displays the current SNMP configuration.

cfg/sys/access

System Access Menu

```
[System Access Menu]
  user      - User Access Control Menu (passwords)
  http      - Enable/disable HTTP (Web) access
  wport     - Set HTTP (Web) server port number
  mnet      - Set management network
  mmask     - Set management netmask
  snmp      - Set SNMP access control
  tnet      - Enable/disable Telnet access
  tnport    - Set Telnet server port number
  cur       - Display current system access configuration
```

Table 6-9 System Configuration Menu Options (/cfg/sys/access)**Command Syntax and Usage****user**

Displays the User Access Control Menu. To view menu options, see [page 179](#).

http disable | enable

Enables or disables HTTP (Web) access to the Browser-Based Interface. It is enabled by default.

wport <TCP port number (1-65535)>

Sets the switch port used for serving switch Web content. The default is HTTP port 80. If Global Server Load Balancing is to be used, set this to a different port (such as 8080).

Table 6-9 System Configuration Menu Options (/cfg/sys/access)**Command Syntax and Usage****mnet** <IP subnet (such as 192.4.17.0)>

Sets the base source IP address that allows access to switch management through Telnet, SNMP, RIP, or the Alteon OS Browser-Based Interface. A range of IP addresses is produced when used with **mmask** (below). Specify an IP address in dotted-decimal notation.

mmask <IP subnet mask (such as 255.255.0.0)>

This IP address mask is used with **mnet** to set a range of source IP addresses allowed access to switch management functions. Specify the mask in dotted-decimal notation.

snmp disable | read-only | read-write

Disables or provides read-only/write-read SNMP access.

tnet

Enables or disables telnet access. This command is enabled by default. You will see this command only if you are connected to the switch through the management module.

tnport <TCP port number>

Sets an optional telnet server port number for cases where the server listens for telnet sessions on a non-standard port.

cur

Displays the current system access parameters.

/cfg/sys/access/user

User Access Control Configuration

```
[User Access Control Menu]
usrpw  - Set user password (user)
sopw   - Set SLB operator password (slboper)
l4opw  - Set L4 operator password (l4oper)
opw    - Set operator password (oper)
sapw   - Set Slb administrator password (slbadmin)
l4apw  - Set L4 administrator password (l4admin)
admpw  - Set administrator password (admin)
cur    - Display current user statistics
```

NOTE – Passwords can be a maximum of 15 characters.

Table 6-10 User Access Control Menu Options (/cfg/sys/user)

Command Syntax and Usage

usrpw

Sets the user (`user`) password. The user has no direct responsibility for switch management. He or she can view switch status information and statistics, but cannot make any configuration changes.

sopw

Sets the SLB operator (`slboper`) password. The SLB operator manages Web servers and other Internet services and their loads. He or she can view all switch information and statistics and can enable/disable servers using the Server Load Balancing configuration menus.

Access includes “`user`” functions.

l4opw

Sets the Layer 4 operator (`l4oper`) password. The Layer 4 operator manages traffic on the lines leading to the shared Internet services. He or she can view all switch information and statistics.

Access includes “`slboper`” functions.

opw

Sets the operator (`oper`) password. The operator password can have a maximum of 15 characters. The operator manages all functions of the switch. He or she can view all switch information and statistics and can reset ports or the entire switch.

Access includes “`l4oper`” functions.

sapw

Sets the SLB administrator (`slbadmin`) password. Administrator who configures and manages Web servers and other Internet services and their loads. He or she can view all switch information and statistics, but can configure changes only on the Server Load Balancing menus. Note that the Filter Menu options are not accessible to the SLB administrator.

Access includes “`l4oper`” functions.

l4apw

Sets the Layer 4 administrator (`l4admin`) password. The Layer 4 administrator configures and manages traffic on the lines leading to the shared Internet services. He or she can view all switch information and statistics and can configure parameters on the Server Load Balancing menus, with the exception of not being able to configure filters.

Access includes “`slbadmin`” functions.

Table 6-10 User Access Control Menu Options (/cfg/sys/user)

Command Syntax and Usage

admpw

Sets the administrator (admin) password. The super user administrator has complete access to all menus, information, and configuration commands on the GbE Switch Module, including the ability to change both the user and administrator passwords.

Access includes “oper” and “l4admin” functions.

cur

Displays the current user status.

/cfg/port <port alias or number>

Port Configuration

```
[Port INT1 Menu]
gig      - Gig Phy Menu
pvid     - Set default port VLAN id
name     - Set port name
rmon    - Enable/Disable RMON for port
tag      - Enable/disable VLAN tagging for port
iponly   - Enable/disable allowing only IP related frames
fastfwd  - Enable/disable Port Fast Forwarding mode
ena      - Enable port
dis      - Disable port
cur      - Display current port configuration
```

The Port Menu enables you to configure settings for individual switch ports (except MGT1 and MGT2). This command is enabled by default.

Table 6-11 Port Configuration Menu Options (/cfg/port)

Command Syntax and Usage

gig

If a port is configured to support Gigabit Ethernet, this option displays the Gigabit Ethernet Physical Link Menu. To view menu options, see [page 183](#).

pvid <VLAN number, 1-4095>

Sets the default VLAN number which will be used to forward frames which are not VLAN tagged. The default number is 1 for non-management ports.

Table 6-11 Port Configuration Menu Options (/cfg/port)

Command Syntax and Usage

name <64 character string> | **none**

Sets a name for the port. The assigned port name appears next to the port number on some information and statistics screens. The default is set to None.

rmon disable | **enable**

Disables or enables RMON for this port. It is disabled by default.

tag disable | **enable**

Disables or enables VLAN tagging for this port. It is disabled by default.

iponly disable | **enable**

Disables or enables allowing only IP-related frames. It is disabled by default.

fastfwd disable | **enable**

Disables or enables Port Fast Forwarding, which permits a port that participates in Spanning Tree to bypass the Listening and Learning states and enter directly into the Forwarding state. While in the Forwarding state, the port listens to the BPDUs to learn if there is a loop and, if dictated by normal STG behavior (following priorities, etc.), the port transitions into the Blocking state. This feature permits the GbESM to interoperate well within Rapid Spanning Tree networks.

ena

Enables the port.

dis

Disables the port. (To temporarily disable a port without changing its configuration attributes, refer to [“Temporarily Disabling a Port” on page 184.](#))

cur

Displays current port parameters.

`/cfg/port <port alias or number> gig` Port Link Configuration

```
[Gigabit Link Menu]
  speed - Set link speed
  mode  - Set full or half duplex mode
  fctl  - Set flow control
  auto  - Set auto negotiation
  cur   - Display current gig link configuration
```

Use these menu options to set port parameters for the port link.

NOTE – Since the `speed` and `mode` parameters cannot be set for Gigabit Ethernet ports, these options do not appear on the Gigabit Link Menu.

Link menu options are described in [Table 6-12](#) and appear on the `gig` port configuration menu for the GbE Switch Module. Using this configuration menu, you can set port parameters such as speed, flow control, and negotiation mode for the port link.

Table 6-12 Port Link Configuration Menu Options (`/cfg/port <alias or number> gig`)

Command Syntax and Usage

speed `10` | `100` | `any`

Sets the link speed. Not all options are valid on all ports. The choices include:

- “Any,” for automatic detection (default)
- 10 Mbps
- 100 Mbps

mode `full` | `half` | `any`

Sets the operating mode. The choices include:

- “Any,” for auto negotiation (default)
- Full-duplex
- Half-duplex

fctl `rx` | `tx` | `both` | `none`

Sets the flow control. The choices include:

- Receive flow control
- Transmit flow control
- Both receive and transmit flow control (default)
- No flow control

auto `on` | `off`

Enables or disables auto negotiation for the port.

Table 6-12 Port Link Configuration Menu Options (/cfg/port <alias or number> gig)

Command Syntax and Usage

curDisplays current port parameters.

Temporarily Disabling a Port

To temporarily disable a port without changing its stored configuration attributes, enter the following command at any prompt:

```
Main# /oper/port <port alias or number>/dis
```

Because this configuration sets a temporary state for the port, you do not need to use `apply` or `save`. The port state will revert to its original configuration when the GbE Switch Module is reset. See the “[Operations Menu](#)” on page 299 for other operations-level commands.

/cfg/pmirr Port Mirroring Menu

```
[Port Mirroring Menu]
  mirror - Enable/Disable Mirroring
  monport - Monitoring Port based PM Menu
  cur     - Display All Mirrored and Monitoring Ports
```

Port mirroring is disabled by default. For more information about port mirroring on the GbE Switch Module, see “Appendix A: Troubleshooting” in the *Alteon OS Application Guide*.

NOTE – Traffic on VLAN 4095 is not mirrored to the external ports.

The Port Mirroring Menu is used to configure, enable, and disable the monitored port. When enabled, network packets being sent and/or received on a target port are duplicated and sent to a monitor port. By attaching a network analyzer to the monitor port, you can collect detailed information about your network performance and usage.

Table 6-13 Port Mirroring menu options (/cfg/pmirr)

Command Syntax and Usage

mirror disable|enable

Enables or disables port mirroring

monport <port alias or number>

Displays port-mirroring menu. To view menu options, see [page 185](#).

cur

Displays current settings of the mirrored and monitoring ports.

/cfg/pmirr/monport Port-Mirroring Menu

[Port EXT1 Menu]

```

add      - Add "Mirrored" port and VLANs
rem      - Rem "Mirrored" port and VLANs
delete   - Delete this "Monitor" port
cur      - Display current Port Mirroring configuration

```

Table 6-14 Port-Based Port-Mirroring Menu Options (/cfg//pmirr/monport)**Command Syntax and Usage**

add *<mirrored port (port to mirror from)> <direction (in, out, or both)> <vlan index or Carriage Return for all vlans>*

Adds the port to be mirrored. This command also allows you to enter the direction of the traffic. It is necessary to specify the direction because:

If the source port of the frame matches the mirrored port and the mirrored direction is ingress or both (ingress and egress), the frame is sent to the mirrored port.

If the destination port of the frame matches the mirrored port and the mirrored direction is egress or both, the frame is sent to the monitoring port.

VLAN-based port mirroring allows the user to monitor traffic based on VLANs associated with a port. You can add specific VLAN(s) to be monitored even if there are multiple VLANs associated with that port. If you do not specify a VLAN, all traffic on that port will be mirrored.

rem *<mirrored port (port to mirror from)> <vlan index or Carriage Return for all vlans>*
Removes the mirrored port.

delete

Deletes this monitor port.

cur

Displays the current settings of the monitoring port.

/cfg/12

Layer 2 Menu

[Layer 2 Menu]

```

stg      - Spanning Tree Menu
trunk    - Trunk Group Menu
thash    - IP Trunk Hash Menu
lacp     - Link Aggregation Control Protocol Menu
vlan     - VLAN Menu
upfast   - Enable/disable Uplink Fast
update   - UplinkFast station update rate
cur      - Display current layer 2 parameters

```

Table 6-15 Configuration Menu Options (/cfg/l2)

Command Syntax and Usage

stg <group number [1-16]>Displays the Spanning Tree Configuration Menu. To view menu options, see [page 188](#).**trunk** <trunk group number (1-2)>Displays the Trunk Group Configuration Menu. To view menu options, see [page 192](#).**thash**Displays the IP Trunk Hash Menu. To view menu options, see [page 193](#).**lACP**Displays the Link Aggregation Control Protocol Menu. To view menu options, see [page 196](#).**vlan** <VLAN number (1-4095)>Displays the VLAN Configuration Menu. To view menu options, see [page 198](#).**upfast**

Enables or disables Fast Uplink Convergence, which provides rapid Spanning Tree convergence to an upstream switch during failover.

Note: When enabled, this feature increases bridge priorities to 65500 for all STGs and path cost by 3000 for all external STP ports.**update** <10-200>

Configures the station update rate for Fast Uplink convergence, in packets per second. The default value is 40.

curDisplays current Layer 2 parameters.

/cfg/l2/stg

Spanning Tree Configuration

```
[Spanning Tree Group 1 Menu]
brg      - Bridge parameter menu
port     - Port parameter menu
add      - Add VLAN(s) to Spanning Tree Group
remove   - Remove VLAN(s) from Spanning Tree Group
clear    - Remove all VLANs from Spanning Tree Group
on       - Globally turn Spanning Tree ON
off      - Globally turn Spanning Tree OFF
default  - Default Spanning Tree and Member parameters
cur      - Display current bridge parameters
```

Alteon OS supports the IEEE 802.1d Spanning Tree Protocol (STP). STG is used to prevent loops in the network topology. There are 16 spanning tree groups that can be configured on the switch (STG 16 is reserved for management). This command is turned on by default.

NOTE – When VRRP is used for active/active redundancy, STG must be enabled.

Table 6-16 Spanning Tree Configuration Menu (/cfg/l2/stg)

Command Syntax and Usage

brg

Displays the Bridge Spanning Tree Menu. To view menu options, see [page 189](#).

port <port alias or number>

Displays the Spanning Tree Port Menu. To view menu options, see [page 191](#).

add <VLAN number (1-4095)>

Associates a VLAN with a spanning tree and requires an external VLAN ID as a parameter.

remove <VLAN number (1-4095)>

Breaks the association between a VLAN and a spanning tree and requires an external VLAN ID as a parameter.

clear

Removes all VLANs from a spanning tree.

on

Globally enables Spanning Tree Protocol.

off

Globally disables Spanning Tree Protocol.

Table 6-16 Spanning Tree Configuration Menu (/cfg/l2/stg)**Command Syntax and Usage****default**

Restores a spanning tree instance to its default configuration.

cur

Displays current Spanning Tree Protocol parameters.

/cfg/l2/stg/brg

Bridge Spanning Tree Configuration

```
[Bridge Spanning Tree Menu]
prior   - Set bridge Priority [0-65535]
hello   - Set bridge Hello Time [1-10 secs]
mxage   - Set bridge Max Age (6-40 secs)
fwd     - Set bridge Forward Delay (4-30 secs)
aging   - Set bridge Aging Time (1-65535 secs, 0 to disable)
cur     - Display current bridge parameters
```

Spanning Tree bridge parameters affect the global STG operation of the switch. STG bridge parameters include:

- Bridge priority
- Bridge hello time
- Bridge maximum age
- Forwarding delay
- Bridge aging time

Table 6-17 Bridge Spanning Tree Menu Options (/cfg/l2/stg/brg)

Command Syntax and Usage

prior <new bridge priority (0-65535)>

Configures the bridge priority. The bridge priority parameter controls which bridge on the network is the STG root bridge. To make this switch the root bridge, configure the bridge priority lower than all other switches and bridges on your network. The lower the value, the higher the bridge priority. The range is 0 to 65535, and the default is 32768.

hello <new bridge hello time (1-10 secs)>

Configures the bridge hello time. The hello time specifies how often the root bridge transmits a configuration bridge protocol data unit (BPDU). Any bridge that is not the root bridge uses the root bridge hello value. The range is 1 to 10 seconds, and the default is 2 seconds.

mxage <new bridge max age (6-40 secs)>

Configures the bridge maximum age. The maximum age parameter specifies the maximum time the bridge waits without receiving a configuration bridge protocol data unit before it re configures the STG network. The range is 6 to 40 seconds, and the default is 20 seconds.

fwd <new bridge Forward Delay (4-30 secs)>

Configures the bridge forward delay parameter. The forward delay parameter specifies the amount of time that a bridge port has to wait before it changes from the listening state to the learning state and from the learning state to the forwarding state. The range is 4 to 30 seconds, and the default is 15 seconds.

aging <new bridge Aging Time (1-65535 secs, 0 to disable)>

Configures the forwarding database aging time. The aging time specifies the amount of time the bridge waits without receiving a packet from a station before removing the station from the forwarding database. The range is 1 to 65535 seconds, and the default is 300 seconds. To disable aging, set this parameter to 0.

current

Displays the current bridge STG parameters.

When configuring STG bridge parameters, the following formulas must be used:

- $2*(fwd-1) \geq mxage$
- $2*(hello+1) \leq mxage$

/cfg/l2/stg <STP Group Index>/port <port alias or number>

Spanning Tree Port Configuration

```
[Spanning Tree Port EXT1 Menu]
prior   - Set port Priority (0-255)
cost    - Set port Path Cost (1-65535, 0 for default)
on      - Turn port's Spanning Tree ON
off     - Turn port's Spanning Tree OFF
cur     - Display current port Spanning Tree parameters
```

Spanning Tree port parameters are used to modify STG operation on an individual port basis. STG port parameters include:

- Port priority
- Port path cost

The **port** option of STG is turned on by default.

Table 6-18 Spanning Tree Port Menu (/cfg/l2/stg/port)

Command Syntax and Usage

prior *<new port Priority (0-255)>*

Configures the port priority. The port priority helps determine which bridge port becomes the designated port. In a network topology that has multiple bridge ports connected to a single segment, the port with the lowest port priority becomes the designated port for the segment. The range is 0 to 255, and the default is 128.

cost *<new port Path Cost (1-65535, 0 for default)>*

Configures the port path cost. The port path cost is used to help determine the designated port for a segment. Generally speaking, the faster the port, the lower the path cost. The range is 1 to 65535. The default is 10 for 100Mbps ports, and 1 for Gigabit ports. A value of 0 indicates that the default cost will be computed for an auto negotiated link speed.

on

Enables STG on the port.

off

Disables STG on the port.

cur

Displays the current STG port parameters.

/cfg/l2/trunk <trunk group number> Trunk Configuration

```
[Trunk group 1 Menu]
  add    - Add port to trunk group
  rem    - Remove port from trunk group
  failovr - Enable/disable failover support
  ena    - Enable trunk group
  dis    - Disable trunk group
  del    - Delete trunk group
  cur    - Display current Trunk Group configuration
```

Trunk groups can provide super-bandwidth connections between GbE Switch Modules or other trunk capable devices. A *trunk* is a group of ports that act together, combining their bandwidth to create a single, larger port. Up to 2 trunk groups can be configured on the GbE Switch Module, with the following restrictions:

- Any physical switch port can belong to no more than one trunk group.
- Up to four ports/trunks can belong to the same trunk group.
- Best performance is achieved when all ports in a trunk are configured for the same speed.
- Trunking from non-Alteon devices must comply with Cisco® EtherChannel® technology.

By default, the trunk group is empty and disabled.

Table 6-19 Trunk Configuration Menu Options (/cfg/l2/trunk)

Command Syntax and Usage

add <port alias or number (EXT1-EXT4)>

Adds a physical port to the current trunk group.

rem <port alias or number (EXT1-EXT4)>

Removes a physical port from the current trunk group.

failovr

Sets trunk group failover to enabled or disabled.

ena

Enables the current trunk group.

dis

Turns the current trunk group off.

del

Removes the current trunk group configuration.

cur

Displays current trunk group parameters.

/cfg/l2/thash

IP Trunk Hash menu

```
[IP Trunk Hash Menu]
  l2      - L2 IP Trunk Hash Settings Menu
  l3      - L3 IP Trunk Hash Settings Menu
  cur     - Display current IP trunk hash configuration
```

Use the following commands to configure IP trunk hash settings for the GbESM.

Table 6-20 IP Trunk Hash commands (/cfg/l2/thash)

Command Syntax and Usage

l2

Displays the layer 2 Trunk Hash Settings menu. To view menu options, see [page 193](#).

l3

Displays the layer 3 Trunk Hash Settings menu. To view menu options, see [page 194](#).

cur

Display current trunk hash configuration.

/cfg/l2/thash/l2

Layer 2 IP Trunk Hash menu

```
[l2 IP Trunk Hash Settings Menu]
  smac    - Enable/disable smac hash
  dmac    - Enable/disable dmac hash
  sip     - Enable/disable sip hash
  dip     - Enable/disable dip hash
  cur     - Display current trunk hash setting
```

Trunk hash parameters are set globally for the GbE Switch Module. You can enable one or two parameters, to configure any of the following valid combinations:

- SMAC (source MAC only)
- DMAC (destination MAC only)
- SIP (source IP only)
- DIP (destination IP only)
- SIP + DIP (source IP and destination IP)

- SMAC + DMAC (source MAC and destination MAC)
- SMAC + SIP (source MAC and source IP)
- SMAC + DIP (source MAC and destination IP)

Use the following commands to configure layer 2 IP trunk hash parameters for the GbESM.

Table 6-21 Layer 2 IP Trunk Hash commands (/cfg/l2/thash/l2)

Command Syntax and Usage

smac enable|disable

Enable or disable trunk hashing on the source MAC.

dmac enable|disable

Enable or disable trunk hashing on the destination MAC.

sip enable|disable

Enable or disable trunk hashing on the source IP.

dip enable|disable

Enable or disable trunk hashing on the destination IP.

cur

Display current layer 2 trunk hash setting.

/cfg/l2/thash/l3

Layer 3 IP Trunk Hash menu

```
[13 IP Trunk Hash Settings Menu]
smac      - Enable/disable smac hash
dmac      - Enable/disable dmac hash
sip       - Enable/disable sip hash
dip       - Enable/disable dip hash
cur       - Display current trunk hash setting
```

Use the following commands to configure layer 3 IP trunk hash settings for the GbESM.

Table 6-22 Layer 3 IP Trunk Hash commands (/cfg/l2/thash/l3)

Command Syntax and Usage

smac enable|disable

Enable or disable trunk hashing on the source MAC.

dmac enable|disable

Enable or disable trunk hashing on the destination MAC.

sip enable|disable

Enable or disable trunk hashing on the source IP.

dip enable|disable

Enable or disable trunk hashing on the destination IP.

cur

Display current layer 3 trunk hash setting.

/cfg/l2/lacp

Link Aggregation Control Protocol menu

[LACP Menu]	
sysprio	- Set LACP system priority
timeout	- Set LACP system timeout scale for timing out partner info
port	- LACP port Menu
cur	- Display current LACP configuration

Use the following commands to configure Link Aggregation Control Protocol (LACP) for the GbESM.

Table 6-23 Link Aggregation Control Protocol (/cfg/l2/lacp)

Command Syntax and Usage

sysprio <1-65535>

Defines the priority value for the GbESM. Lower numbers provide higher priority. The default value is 32768.

timeout **short** | **long**

Defines the timeout period before invalidating LACP data from a remote partner. Choose **short** (3 seconds) or **long** (90 seconds). The default value is **long**.

Note: Nortel Networks recommends that you use a timeout value of **long**, to reduce LACPDU processing. If your GbESM's CPU utilization rate remains at 100% for periods of 90 seconds or more, consider using static trunks instead of LACP.

port <port alias or number>

Displays the LACP Port menu. To view menu options, see [page 196](#).

cur

Display current LACP configuration.

/cfg/l2/lacp/port <port alias or number>

LACP Port menu

[LACP Port EXT1 Menu]	
mode	- Set LACP mode
prio	- Set LACP port priority
adminkey	- Set LACP port admin key
cur	- Display current LACP port configuration

Use the following commands to configure Link Aggregation Control Protocol (LACP) for the selected port.

Table 6-24 Link Aggregation Control Protocol (/cfg/l2/lacp/port)

Command Syntax and Usage

mode **off** | **active** | **passive**

Set the LACP mode for this port, as follows:

- **off**
Turn LACP off for this port. You can use this port to manually configure a static trunk. The default value is **off**.
 - **active**
Turn LACP on and set this port to active. Active ports initiate LACPDU's.
 - **passive**
Turn LACP on and set this port to passive. Passive ports do not initiate LACPDU's, but respond to LACPDU's from active ports.
-

prio <1-65535>

Sets the priority value for the selected port. Lower numbers provide higher priority. Default is 128.

adminkey <1-65535>

Set the admin key for this port. Only ports with the same admin key and oper key (operational state) can form a LACP trunk group.

cur

Displays the current LACP configuration for this port.

`/cfg/l2/vlan <VLAN number>` VLAN Configuration

[VLAN 1 Menu]	
<code>name</code>	- Set VLAN name
<code>stg</code>	- Assign VLAN to a Spanning Tree Group
<code>add</code>	- Add port to VLAN
<code>rem</code>	- Remove port from VLAN
<code>def</code>	- Define VLAN as list of ports
<code>jumbo</code>	- Enable/disable Jumbo Frame support
<code>ena</code>	- Enable VLAN
<code>dis</code>	- Disable VLAN
<code>del</code>	- Delete VLAN
<code>cur</code>	- Display current VLAN configuration

The commands in this menu configure VLAN attributes, change the status of the VLAN, delete the VLAN, and change the port membership of the VLAN. For more information on configuring VLANs, see [“Setup Part 3: VLANs” on page 33](#).

By default, the VLAN menu option is disabled except VLAN 1, which is enabled all the time. Internal server ports (INTx) and external ports (EXT1-EXT4) are in VLAN 1 by default.

Table 6-25 VLAN Configuration Menu Options (`/cfg/l2/vlan`)

Command Syntax and Usage

name

Assigns a name to the VLAN or changes the existing name. The default VLAN name is the first one.

stg *<Spanning Tree Group index [1-16]>*

Assigns a VLAN to a Spanning Tree Group.

add *<port alias or number>*

Adds port(s) or trunk group(s) to the VLAN membership.

rem *<port alias or number>*

Removes port(s) or trunk group(s) from this VLAN.

def *<list of port numbers>*

Defines which ports are members of this VLAN. Every port must be a member of at least one VLAN. By default, internal server ports (INTx) and external ports (EXT1-EXT4) are in VLAN 1.

jumbo

Define support for jumbo frames (enable/disable).

Table 6-25 VLAN Configuration Menu Options (/cfg/l2/vlan)

Command Syntax and Usage

ena

Enables this VLAN.

dis

Disables this VLAN without removing it from the configuration.

del

Deletes this VLAN.

cur

Displays the current VLAN configuration.

NOTE – All ports must belong to at least one VLAN. Any port which is removed from a VLAN and which is not a member of any other VLAN is automatically added to default VLAN 1. You cannot remove a port from VLAN 1 if the port has no membership in any other VLAN.

Also, you cannot add a port to more than one VLAN unless the port has VLAN tagging turned on (see the `tag` command on [page 181](#)).

/cfg/l3

Layer 3 Menu

```
[Layer 3 Menu]
  if          - Interface Menu
  gw          - Default Gateway Menu
  route       - Static Route Menu
  frwd        - Forwarding Menu
  nwf         - Network Filters Menu
  rmap        - Route Map Menu
  rip1        - Routing Information Protocol Menu
  ospf        - Open Shortest Path First (OSPF) Menu
  bgp         - Border Gateway Protocol Menu
  igmp        - IGMP Menu
  port        - IP Port Menu
  dns         - Domain Name System Menu
  bootp       - Bootstrap Protocol Relay Menu
  vrrp        - Virtual Router Redundancy Protocol Menu
  rtrid       - Set router ID
  metrc       - Set default gateway metric
  cur         - Display current IP configuration
```

Table 6-26 Configuration Menu Options (/cfg/l3)

Command Syntax and Usage

if <interface number (1-128)>

Displays the IP Interface Menu. To view menu options, see [page 202](#).

gw <default gateway number (1-132)>

Displays the IP Default Gateway Menu. To view menu options, see [page 203](#).

route

Displays the IP Static Route Menu. To view menu options, see [page 205](#).

frwd

Displays the IP Forwarding Menu. To view menu options, see [page 206](#).

nwf <Network filter number [1-256]>

Displays the Network Filter Configuration Menu. To view menu options see [page 208](#).

rmap <route map number [1-32]>

Displays the Route Map Menu. To view menu options see [page 209](#).

rip1

Displays the Routing Interface Protocol version 1 Menu. To view menu options, see [page 213](#).

Table 6-26 Configuration Menu Options (/cfg/l3)

Command Syntax and Usage

ospf

Displays the OSPF Menu. To view menu options, see [page 215](#).

bgp

Displays the Border Gateway Protocol Menu. To view menu options, see [page 224](#).

igmp

Displays the IGMP Menu. To view menu options, see [page 230](#).

port <port alias or number>

Displays the IP Port Menu. To view menu options, see [page 233](#).

dns

Displays the IP Domain Name System Menu. To view menu options, see [page 234](#).

bootp

Displays the Bootstrap Protocol Menu. To view menu options, see [page 235](#).

vrrp

Displays the Virtual Router Redundancy Configuration Menu. To view menu options, see [page 236](#).

rtrid <<IP address (such as, 192.4.17.101)>

Sets the router ID.

metrc strict|roundrobin

Sets the default gateway metric for `strict` or `roundrobin`. The default gateway metric is `strict`. For more information on gateway metrics, see [page 248](#).

cur

Displays the current IP configuration.

`/cfg/l3/if` <interface number> IP Interface Configuration

```
[IP Interface 1 Menu]
  addr    - Set IP address
  mask    - Set subnet mask
  vlan    - Set VLAN number
  relay   - Enable or disable BOOTP relay
  ena     - Enable interface
  dis     - Disable interface
  del     - Delete interface
  cur     - Display current interface configuration
```

The GbE Switch Module can be configured with up to 128 IP interfaces. Each IP interface represents the GbE Switch Module on an IP subnet on your network. The Interface option is disabled by default.

NOTE – To maintain connection between the management module and the GbE Switch Module, use the management module interface to change the IP address of the switch.

Table 6-27 IP Interface Menu Options (`/cfg/l3/if`)

Command Syntax and Usage

addr <IP address (such as 192.4.17.101)>

Configures the IP address of the switch interface using dotted decimal notation.

mask <IP subnet mask (such as 255.255.255.0)>

Configures the IP subnet address mask for the interface using dotted decimal notation.

vlan <VLAN number (1-4095)>

Configures the VLAN number for this interface. Each interface can belong to one VLAN, though any VLAN can have multiple IP interfaces in it.

relay **disable** | **enable**

Enables or disables the BOOTP relay on this interface. It is enabled by default.

ena

Enables this IP interface.

dis

Disables this IP interface.

Table 6-27 IP Interface Menu Options (/cfg/l3/if)**Command Syntax and Usage****del**

Removes this IP interface.

cur

Displays the current interface settings.

/cfg/l3/gw <gateway number> Default Gateway Configuration

```
[Default gateway 1 Menu]
  addr      - Set IP address
  intr      - Set interval between ping attempts
  retry     - Set number of failed attempts to declare gateway DOWN
  vlan      - Set VLAN number
  arp       - Enable/disable ARP only health checks
  ena       - Enable default gateway
  dis       - Disable default gateway
  del       - Delete default gateway
  cur       - Display current default gateway configuration
```

NOTE – The switch can be configured with up to 132 gateways. Gateways one to four are reserved for default gateway load balancing. Gateway 132 is reserved for the management VLAN.

This option is disabled by default.

Table 6-28 Default Gateway Options (/cfg/l3/gw)**Command Syntax and Usage**

addr <default gateway address (such as, 192.4.17.44)>

Configures the IP address of the default IP gateway using dotted decimal notation.

intr <0-60 seconds>

The switch pings the default gateway to verify that it's up. The **intr** option sets the time between health checks. The range is from 1 to 120 seconds. The default is 2 seconds.

retry <number of attempts (1-120)>

Sets the number of failed health check attempts required before declaring this default gateway inoperative. The range is from 1 to 120 attempts. The default is 8 attempts.

Table 6-28 Default Gateway Options (/cfg/l3/gw)

Command Syntax and Usage

vlan <VLAN number (1-4095)>

Sets the VLAN to be assigned to this default IP gateway.

arp disable | enable

Enables or disables Address Resolution Protocol (ARP) health checks. This command is disabled by default.

ena

Enables the gateway for use.

dis

Disables the gateway.

del

Deletes the gateway from the configuration.

curDisplays the current gateway settings.

Default Gateway Metrics

For information about configuring which gateway is selected when multiple default gateways are enabled, see [page 204](#).

/cfg/l3/route

IP Static Route Configuration

```
[IP Static Route Menu]
  add      - Add static route
  rem      - Remove static route
  cur      - Display current static routes
```

Up to 128 static routes can be configured.

Table 6-29 IP Static Route Configuration Menu Options (cfg/l3/route)

Command Syntax and Usage

add <destination> <mask> <gateway> <interface number>

Adds a static route. You will be prompted to enter a destination IP address, destination subnet mask, and gateway address. Enter all addresses using dotted decimal notation.

rem <destination> <mask>

Removes a static route. The destination address of the route to remove must be specified using dotted decimal notation.

cur

Displays the current IP static routes.

/cfg/l3/frwd

IP Forwarding Configuration

[IP Forwarding Menu]	
local	- Local network definition for route caching menu
dirbr	- Enable or disable forwarding directed broadcasts
on	- Globally turn IP Forwarding ON
off	- Globally turn IP Forwarding OFF
cur	- Display current IP Forwarding configuration

Table 6-30 IP Forwarding Configuration Menu Options (/cfg/l3/frwd)

Command Syntax and Usage

local

Displays the menu used to define local network for route caching. Up to five local networks (Inets) can be configured. To view menu options, see [page 206](#).

dirbr disable | enable

Enables or disables forwarding directed broadcasts. This command is disabled by default.

on

Enables IP forwarding (routing) on the GbE Switch Module.

off

Disables IP forwarding (routing) on the GbE Switch Module. Forwarding is turned off by default.

cur

Displays the current IP forwarding settings.

/cfg/l3/frwd/local

Local Network Route Caching Definition

[IP Local Networks Menu]	
add	- Add local network definition
rem	- Remove local network definition
cur	- Display current local network definitions

Table 2 IP Local Networks Menu Options (/cfg/l3/frwd/local)**Command Syntax and Usage****add** <Local Network Address> <Local Network Mask>

Adds a definition for a local network. For details, see “Defining IP Address Ranges for the Local Route Cache” below.

rem <Local Network Address> <Local Network Mask>

Removes a definition for a local network.

cur

Displays the current local network definitions.

This menu is used for adding local networks by setting the local network address and netmask for the route cache, and to remove local networks.

Defining IP Address Ranges for the Local Route Cache

The Local Route Cache lets you use switch resources more efficiently, by reducing the size of the ARP table on the GbE Switch Module. The /cfg/l3/frwd/local/add parameters define a range of addresses that will be cached on the GbE Switch Module. The local network address is used to define the base IP address in the range which will be cached, and the local network mask is the mask which is applied to produce the range. To determine if a route should be added to the memory cache, the destination address is masked (bitwise AND) with the local network mask and checked against the local network address.

By default, the local network address and mask are both set to 0.0.0.0. This produces a range that includes all Internet addresses for route caching: 0.0.0.0 through 255.255.255.255.

Addresses to be cached are subnets that are directly connected and for which there is an interface configured on the GbE Switch Module. To limit the route cache to your local hosts, you could configure the parameters as shown in the examples in the following table.

Table 6-31 Local Routing Cache Address Ranges

Local Host Address Range	Address	Mask
0.0.0.0 - 127.255.255.255	0.0.0.0	128.0.0.0
128.0.0.0 - 255.255.255.255	128.0.0.0	128.0.0.0
205.32.0.0 - 205.32.255.255	205.32.0.0	255.255.0.0

NOTE – All addresses that fall outside the defined range are forwarded to the default gateway. The default gateways must be within range.

/cfg/l3/nwf

Network Filter Configuration

[IP Network Filter 1 Menu]	
addr	- IP Address
mask	- IP Subnet mask
enable	- Enable Network Filter
disable	- Disable Network Filter
delete	- Delete Network Filter
cur	- Display current Network Filter configuration

Table 6-32 IP Network Filter Menu Options (/cfg/l3/nwf)

Command Syntax and Usage

addr <IP address, such as 192.4.17.44>

Sets the starting IP address for this filter. The default address is 0.0.0.0.

mask <subnet mask, such as 255.255.255.0>

Sets the IP subnet mask that is used with /cfg/l3/nwf/addr to define the range of IP addresses that will be accepted by the peer when the filter is enabled. The default value is 0.0.0.0.

For Border Gateway Protocol (BGP), assign the network filter to a route map, then assign the route map to the peer.

enable

Enables the Network Filter configuration.

disable

Disables the Network Filter configuration.

delete

Deletes the Network Filter configuration.

cur

Displays the current the Network Filter configuration.

`/cfg/l3/rmap` *<route map number>*

Routing Map Configuration

NOTE – The *map number* (1-32) represents the routing map you wish to configure.

[IP Route Map 1 Menu]	
<code>alist</code>	- Access List number
<code>aspath</code>	- AS Filter Menu
<code>ap</code>	- Set as-path prepend of the matched route
<code>lp</code>	- Set local-preference of the matched route
<code>metric</code>	- Set metric of the matched route
<code>type</code>	- Set OSPF metric-type of the matched route
<code>prec</code>	- Set the precedence of this route map
<code>weight</code>	- Set weight of the matched route
<code>enable</code>	- Enable route map
<code>disable</code>	- Disable route map
<code>delete</code>	- Delete route map
<code>cur</code>	- Display current route map configuration

Routing maps control and modify routing information.

Table 6-33 Routing Map Menu Options (`/cfg/l3/rmap`)

Command Syntax and Usage

alist *<number 1-8>*

Displays the Access List menu. For more information, see [page 211](#).

aspath *<number 1-8>*

Displays the Autonomous System (AS) Filter menu. For more information, see [page 212](#).

ap *<AS number>* [*<AS number>*] [*<AS number>*] | **none**

Sets the AS path preference of the matched route. One to three path preferences can be configured.

lp *<(0-4294967294)>* | **none**

Sets the local preference of the matched route, which affects both inbound and outbound directions. The path with the higher preference is preferred.

metric *<(0-4294967294)>* | **none**

Sets the metric of the matched route.

Table 6-33 Routing Map Menu Options (/cfg/l3/rmap) (Continued)

Command Syntax and Usage

type <value (1|2)> | **none**

Assigns the type of OSPF metric. The default is type 1.

- Type 1—External routes are calculated using both internal and external metrics.
- Type 2—External routes are calculated using only the external metrics. Type 2 routes have more cost than Type 1.
- none—Removes the OSPF metric.

prec <value (1-256)>

Sets the precedence of the route map. The smaller the value, the higher the precedence. Default value is 10.

weight <value (0-65534)> | **none**

Sets the weight of the route map.

enable

Enables the route map.

disable

Disables the route map.

delete

Deletes the route map.

curDisplays the current route configuration.

/cfg/l3/rmap <route map number/>**alist** <access list number>

IP Access List Configuration Menu

NOTE – The *route map number* (1-32) and the *access list number* (1-8) represent the IP access list you wish to configure.

```
[IP Access List 1 Menu]
nwf      - Network Filter number
metric  - Metric
action   - Set Network Filter action
enable   - Enable Access List
disable  - Disable Access List
delete   - Delete Access List
cur      - Display current Access List configuration
```

Table 6-34 IP Access List Menu Options (/cfg/l3/rmap/alist)

Command Syntax and Usage

nwf <network filter number (1-256)>

Sets the network filter number. See “/cfg/l3/nwf” on page 208 for details.

metric <(1-4294967294) > | **none**

Sets the metric value in the AS-External (ASE) LSA.

action **permit** | **deny**

Permits or denies action for the access list.

enable

Enables the access list.

disable

Disables the access list.

delete

Deletes the access list.

cur

Displays the current Access List configuration.

/cfg/l3/rmap *<route map number>* **aspath** *<autonomous system path>*

Autonomous System Filter Path

NOTE – The *rmap number* (1-32) and the *path number* (1-8) represent the AS path you wish to configure.

```
[AS Filter 1 Menu]
as      - AS number
action  - Set AS Filter action
enable  - Enable AS Filter
disable - Disable AS Filter
delete  - Delete AS Filter
cur     - Display current AS Filter configuration
```

Table 6-35 AS Filter Menu Options (/cfg/l3/rmap/aspath)

Command Syntax and Usage

as *<AS number (1-65535)>*

Sets the Autonomous System filter's path number.

action *<permit|deny (p|d)>*

Permits or denies Autonomous System filter action.

enable

Enables the Autonomous System filter.

disable

Disables the Autonomous System filter.

delete

Deletes the Autonomous System filter.

current

Displays the current Autonomous System filter configuration.

/cfg/l3/rip1

Routing Information Protocol Configuration

```
[Routing Information Protocol Menu]
  updat    - Set update period in seconds
  sply     - Enable/disable supplying route updates
  lsten    - Enable/disable listening to route updates
  deflt    - Enable/disable listening to default routes
  statc    - Enable/disable supplying static routes
  poisn    - Enable/disable poisoned reverse
  vip      - Enable/disable vip advertisement
  on       - Globally turn RIP ON
  off      - Globally turn RIP OFF
  cur      - Display current RIP configuration
```

The RIP1 Menu is used for configuring Routing Information Protocol, version 1 (RIP1) parameters. This option is turned off by default.

NOTE – Do not configure RIP1 parameters if your routing equipment uses RIP version 2.

Table 6-36 Routing Information Protocol Menu (/cfg/l3/rip1)

Command Syntax and Usage

updat *<update period (1-120 seconds)>*

Sets the RIP update period in seconds. It is set at 30 seconds by default.

sply **disable** | **enable**

This command is disabled by default. When enabled, the switch supplies routes to other routers.

lsten **disable** | **enable**

This command is disabled by default. When enabled, the switch learns routes from other routers.

deflt **disable** | **enable**

When enabled, the switch accepts RIP default routes from other routers, but gives them lower priority than configured default gateways. When disabled, the switch rejects RIP default routes. This command is disabled by default.

statc **disable** | **enable**

This command is disabled by default. When enabled, the switch supplies static routes.

poisn **disable** | **enable**

This command is disabled by default. When enabled, the switch uses split horizon with poisoned reverse. When disabled, the switch uses only split horizon.

Table 6-36 Routing Information Protocol Menu (/cfg/l3/rip1)

Command Syntax and Usage

vip disable | enable

Enables or disables the advertisement of virtual IP addresses as Host Routes. If a VIP route exists in a routing table, it will always be advertised except when it is included in another network route that is already being advertised.

Note: If all real servers behind a VIP go down, the route gets removed from the routing table, and will not be advertised. If we disable all the real servers using operation command, the VIP route does not get eliminated from the routing table, and the switch will continue to advertise the route.

on

Globally turns RIP ON.

off

Globally turns RIP OFF.

cur

Displays the current RIP configuration.

/cfg/l3/ospf

Open Shortest Path First Configuration

```
[Open Shortest Path First Menu]
aindex - OSPF Area (index) menu
range  - OSPF Summary Range menu
if     - OSPF Interface menu
virt   - OSPF Virtual Links menu
md5key - OSPF MD5 Key Menu
host   - OSPF Host Entry menu
redist - OSPF Route Redistribute menu
lsdb   - Set the LSDB limit
default - Originate default route information
on     - Globally turn OSPF ON
off    - Globally turn OSPF OFF
cur    - Display current OSPF configuration
```

Table 6-37 OSPF Configuration Menu Options (/cfg/l3/ospf)

Command Syntax and Usage

aindex <area index (0-2)>

Displays the area index menu. This area index does not represent the actual OSPF area number. See [page 216](#) to view menu options.

range <range number (1-16)>

Displays summary routes menu for up to 16 IP addresses. See [page 218](#) to view menu options.

if <interface number (1-128)>

Displays the OSPF interface configuration menu. See [page 219](#) to view menu options.

virt <virtual link (1-3)>

Displays the Virtual Links menu used to configure OSPF for a Virtual Link. See [page 220](#) to view menu options.

md5key <key ID [1-255]>

Assigns a string to MD5 authentication key. See

host <host entry number (1-128)>

Displays the menu for configuring OSPF for the host routes. Up to 128 host routes can be configured. Host routes are used for advertising network device IP addresses to external networks to perform server load balancing within OSPF. It also makes Area Border Route (ABR) load sharing and ABR failover possible. See [page 222](#) to view menu options.

redist <fixed|static|rip|ebgp|ibgp>

Displays Route Distribution Menu See [page 223](#) to view menu options.

Table 6-37 OSPF Configuration Menu Options (/cfg/l3/ospf)**Command Syntax and Usage****lsdb** <LSDB limit (0-2000, 0 for no limit)>

Sets the link state database limit.

default <metric [1-16777215]> <metric-type 1|2> | **none**

Sets one default route among multiple choices in an area. Use none for no default.

on

Enables OSPF on the GbE Switch Module.

off

Disables OSPF on the GbE Switch Module.

cur

Displays the current OSPF configuration settings.

/cfg/l3/ospf/aindex

Area Index Configuration Menu

```

[OSPF Area (index) 1 Menu]
  areaid - Set area ID
  type   - Set area type
  metric - Set stub area metric
  auth   - Set authentication type
  spf    - Set time interval between two SPF calculations
  enable - Enable area
  disable - Disable area
  delete - Delete area
  cur    - Display current OSPF area configuration

```

Table 6-38 Area Index Configuration Menu Options (/cfg/l3/ospf/aindex)

Command Syntax and Usage

areaid <IP address (such as, 192.4.17.101)>

Defines the IP address of the OSPF area number.

type **transit** | **stub** | **nssa**

Defines the type of area. For example, when a virtual link has to be established with the backbone, the area type must be defined as transit.

Transit area: allows area summary information to be exchanged between routing devices. Any area that is not a stub area or NSSA is considered to be transit area.**Stub area:** is an area where external routing information is not distributed. Typically, a stub area is connected to only one other area.**NSSA:** Not-So-Stubby Area (NSSA) is similar to stub area with additional capabilities. For example, routes originating from within the NSSA can be propagated to adjacent transit and backbone areas. External routes from outside the Autonomous System (AS) can be advertised within the NSSA but are not distributed into other areas.

metric <metric value [1-65535]>

Configures a stub area to send a numeric metric value. All routes received via that stub area carry the configured metric to potentially influencing routing decisions.

Metric value assigns the priority for choosing the switch for default route. Metric type determines the method for influencing routing decisions for external routes.

auth **none** | **password** | **md5****None:** No authentication required.**Password:** Authenticates simple passwords so that only trusted routing devices can participate.**MD5:** This parameter is used when MD5 cryptographic authentication is required.

spf <interval [0-255]>

Sets time interval between two successive SPF (shortest path first) calculations of the shortest path tree using the Dijkstra's algorithm.

enable

Enables the OSPF area.

disable

Disables the OSPF area.

delete

Deletes the OSPF area.

curDisplays the current OSPF configuration.

/cfg/l3/ospf/range

OSPF Summary Range Configuration Menu

```
[OSPF Summary Range 1 Menu]
addr    - Set IP address
mask    - Set IP mask
aindex  - Set area index
hide    - Enable/disable hide range
enable  - Enable range
disable - Disable range
delete  - Delete range
cur     - Display current OSPF summary range configuration
```

Table 6-39 OSPF Summary Range Configuration Menu Options (/cfg/l3/ospf/range)

Command Syntax and Usage

addr <IP Address (such as, 192.4.17.101)>

Displays the base IP address for the range.

mask <IP address (such as, 192.4.17.101)>

Displays the IP address mask for the range.

aindex <area index [0-2]>

Displays the area index used by the GbE Switch Module.

hide **disable** | **enable**

Hides the OSPF summary range.

enable

Enables the OSPF summary range.

disable

Disables the OSPF summary range.

delete

Deletes the OSPF summary range.

current

Displays the current OSPF summary range.

/cfg/l3/ospf/if

OSPF Interface Configuration Menu

```
[OSPF Interface 1 Menu]
aindex - Set area index
prio   - Set interface router priority
cost   - Set interface cost
hello  - Set hello interval in seconds
dead   - Set dead interval in seconds
trans  - Set transit delay in seconds
retra  - Set retransmit interval in seconds
key    - Set authentication key
mdkey  - Set MD5 key ID
enable - Enable interface
disable - Disable interface
delete - Delete interface
cur    - Display current OSPF interface configuration
```

Table 6-40 OSPF Interface Configuration Menu Options (/cfg/l3/ospf/if)

Command Syntax and Usage

aindex <area index [0-2]>

Displays the OSPF area index.

prio <priority value (0-127)>

Displays the assigned priority value to the GbE Switch Module's OSPF interfaces.

(A priority value of 127 is the highest and 1 is the lowest. A priority value of 0 specifies that the interface cannot be used as Designated Router (DR) or Backup Designated Router (BDR).)

cost <cost value (1-65535)>

Displays cost set for the selected path—preferred or backup. Usually the cost is inversely proportional to the bandwidth of the interface. Low cost indicates high bandwidth.

hello <value [1-65535]>

Displays the interval in seconds between the hello packets for the interfaces.

dead <value [1-65535]>

Displays the health parameters of a hello packet, which is set for an interval of seconds before declaring a silent router to be down.

trans <value [0-3600]>

Displays the transit delay in seconds.

retra <value [0-3600]>

Displays the retransmit interval in seconds.

Table 6-40 OSPF Interface Configuration Menu Options (/cfg/l3/ospf/if)**Command Syntax and Usage****key** <key> | **none**

Sets the authentication key to clear the password.

mdkey <key ID [1-255]> | **none**

Assigns an MD5 key to the interface.

enable

Enables OSPF interface.

disable

Disables OSPF interface.

delete

Deletes OSPF interface.

cur

Displays the current settings for OSPF interface.

/cfg/l3/ospf/virt

OSPF Virtual Link Configuration Menu

```

[OSPF Virtual Link 1 Menu]
  aindex - Set area index
  hello  - Set hello interval in seconds
  dead   - Set dead interval in seconds
  trans  - Set transit delay in seconds
  retra  - Set retransmit interval in seconds
  nbr    - Set router ID of virtual neighbor
  key    - Set authentication key
  mdkey  - Set MD5 key ID
  enable - Enable interface
  disable - Disable interface
  delete - Delete interface
  cur    - Display current OSPF interface configuration

```

Table 6-41 OSPF Virtual Link Configuration Menu Options (/cfg/l3/ospf/virt)

Command Syntax and Usage

aindex <area index [0-2]>

Displays the OSPF area index.

hello <value [1-65535]>

Displays the authentication parameters of a hello packet, which is set to be in an interval of seconds.

dead <value [1-65535]>

Displays the health parameters of a hello packet, which is set to be in an interval of seconds. Default is 40 seconds.

trans <value [1-3600]>

Displays the delay in transit in seconds. Default is one seconds.

retra <value [1-3600]>

Displays the retransmit interval in seconds. Default is five seconds.

nbr <NBR router ID (IP address)>

Displays the router ID of the virtual neighbor. Default is 0.0.0.0.

key <password>

Displays the password (up to eight characters) for each virtual link. Default is none.

mdkey <key ID [1-256]> | none

Sets MD5 key ID for each virtual link. Default is none.

enable

Enables OSPF virtual link.

disable

Disables OSPF virtual link.

delete

Deletes OSPF virtual link.

curDisplays the current OSPF virtual link settings.

/cfg/l3/ospf/host

OSPF Host Entry Configuration Menu

```
[OSPF Host Entry 1 Menu]
addr      - Set host entry IP address
aindex    - Set area index
cost      - Set cost of this host entry
enable    - Enable host entry
disable   - Disable host entry
delete    - Delete host entry
cur       - Display current OSPF host entry configuration
```

Table 6-42 OSPF Host Entry Configuration Menu Options (/cfg/l3/ospf/host)

Command Syntax and Usage

addr <IP address (such as, 192.4.17.101)>
Displays the base IP address for the host entry.

aindex <area index [0-2]>
Displays the area index of the host.

cost <cost value [1-65535]>
Displays the cost value of the host.

enable
Enables OSPF host entry.

disable
Disables OSPF host entry.

delete
Deletes OSPF host entry.

cur
Displays the current OSPF host entries.

/cfg/l3/ospf/redist/ **<fixed | static | rip | ebgp | ibgp>**

OSPF Route Redistribution Configuration Menu.

```
[OSPF Redistribute Fixed Menu]
add      - Add rmap into route redistribution list
rem      - Remove rmap from route redistribution list
export   - Export all routes of this protocol
cur      - Display current route-maps added
```

Table 6-43 OSPF Route Redistribution Menu Options (/cfg/l3/ospf/redist)

Command Syntax and Usage

add (<route map [1-32]> <route map [1-32]>)| **all**

Adds selected routing maps to the rmap list. To add all the 32 route maps, enter **all**. To add specific route maps, enter routing map numbers one per line, **NULL** at the end.

This option adds a route map to the route redistribution list. The routes of the redistribution protocol matched by the route maps in the route redistribution list will be redistributed.

rem (<route map [1-32]> <route map [1-32]>)... **all**

Removes the route map from the route redistribution list.

Removes routing maps from the rmap list. To remove all 32 route maps, enter **all**. To remove specific route maps, enter routing map numbers one per line, **NULL** at end.

export <metric [1-16777215]><metric type [1|2]> | **none**

Exports the routes of this protocol as external OSPF AS-external LSAs in which the metric and metric type are specified. To remove a previous configuration and stop exporting the routes of the protocol, enter **none**.

cur

Displays the current route map settings.

/cfg/13/ospf/md5key

OSPF MD5 Key Configuration Menu

```
[OSPF MD5 Key 1 Menu]
key      - Set authentication key
delete   - Delete key
cur      - Display current MD5 key configuration
```

Table 6-44 OSPF MD5 Key Configuration Menu Options (/cfg/ip/ospf/md5key)

Command Syntax and Usage

key

Sets the authentication key for this OSPF packet.

delete

Deletes the authentication key for this OSPF packet.

cur

Displays the current MD5 key configuration.

/cfg/13/bgp

Border Gateway Protocol Configuration

```
[Border Gateway Protocol Menu]
peer      - Peer menu
aggr      - Aggregation menu
as        - Set Autonomous System (AS) number
pref      - Set Local Preference
on        - Globally turn BGP ON
off       - Globally turn BGP OFF
cur       - Display current BGP configuration
```

Border Gateway Protocol (BGP) is an Internet protocol that enables routers on a network to share routing information with each other and advertise information about the segments of the IP address space they can access within their network with routers on external networks. BGP allows you to decide what is the “best” route for a packet to take from your network to a destination on another network, rather than simply setting a default route from your border router(s) to your upstream provider(s). You can configure BGP either within an autonomous system or between different autonomous systems. When run within an autonomous system, it's called internal BGP (iBGP). When run between different autonomous systems, it's called external BGP (eBGP). BGP is defined in RFC 1771.

The BGP Menu enables you to configure the switch to receive routes and to advertise static routes, fixed routes and virtual server IP addresses with other internal and external routers. In the current Alteon OS implementation, the GbE Switch Module does not advertise BGP routes that are learned from other BGP “speakers”.

The BGP menu option is turned off by default.

NOTE – Fixed routes are subnet routes. There is one fixed route per IP interface.

Table 6-45 Border Gateway Protocol Menu (/cfg/l3/bgp)

Command Syntax and Usage

peer <peer number (1-16)>

Displays the menu used to configure each BGP *peer*. Each border router, within an autonomous system, exchanges routing information with routers on other external networks. To view menu options, see [page 226](#).

aggr <aggregate number (1-16)>

Displays the Aggregation Menu. To view menu options, see [page 229](#).

as <1 - 65535>

Set Autonomous System number.

pref <local preference (0-4294967294)>

Sets the local preference. The path with the higher value is preferred.

When multiple peers advertise the same route, use the route with the shortest AS path as the preferred route if you are using eBGP, or use the local preference if you are using iBGP.

on

Globally turns BGP on.

off

Globally turns BGP off.

cur

Displays the current BGP configuration.

/cfg/l3/bgp/peer <peer number> BGP Peer Configuration Menu

```
[BGP Peer 1 Menu]
  redistrib  - Redistribution menu
  addr      - Set remote IP address
  ras       - Set remote autonomous system number
  hold      - Set hold time
  alive     - Set keep alive time
  advert    - Set min time between advertisements
  retry     - Set connect retry interval
  orig      - Set min time between route originations
  ttl       - Set time-to-live of IP datagrams
  addi      - Add rmap into in-rmap list
  addo      - Add rmap into out-rmap list
  remi      - Remove rmap from in-rmap list
  remo      - Remove rmap from out-rmap list
  enable    - Enable peer
  disable   - Disable peer
  delete    - Delete peer
  cur       - Display current peer configuration
```

This menu is used to configure BGP peers, which are border routers that exchange routing information with routers on internal and external networks. The peer option is disabled by default.

Table 6-46 BGP Peer Configuration Options (/cfg/l3/bgp/peer)

Command Syntax and Usage

redist

Displays BGP Redistribution Menu. To view the menu options, see [page 228](#).

addr <IP address (such as 192.4.17.101)>

Defines the IP address for the specified peer (border router), using dotted decimal notation. The default address is 0.0.0.0.

ras <AS number (0-65535)>

Sets the remote autonomous system number for the specified peer.

hold <hold time (0, 3-65535)>

Sets the period of time, in seconds, that will elapse before the peer session is torn down because the switch hasn't received a "keep alive" message from the peer. It is set at 90 seconds by default.

alive <keepalive time (0, 1-21845)>

Sets the keep-alive time for the specified peer in seconds. It is set at 0 by default.

Table 6-46 BGP Peer Configuration Options (/cfg/l3/bgp/peer)**Command Syntax and Usage****advert** <min adv time (1-65535)>

Sets time in seconds between advertisements.

retry <connect retry interval (1-65535)>

Sets connection retry interval in seconds.

orig <min orig time (1-65535)>

Sets the minimum time between route originations in seconds.

ttl <number of router hops (1-255)>

Time-to-live (TTL) is a value in an IP packet that tells a network router whether or not the packet has been in the network too long and should be discarded. TTL specifies a certain time span in seconds that, when exhausted, would cause the packet to be discarded. The TTL is determined by the number of router hops the packet is allowed before it must be discarded.

This command specifies the number of router hops that the IP packet can make. This value is used to restrict the number of “hops” the advertisement makes. It is also used to support multi-hops, which allow BGP peers to talk across a routed network. The default number is set at 1.

addi <route map ID (1-32)>

Adds route map into in-route map list.

addo <route map ID (1-32)>

Adds route map into out-route map list.

remi <route map ID (1-32)>

Removes route map from in-route map list.

remo <route map ID (1-32)>

Removes route map from out-route map list.

ena

Enables this peer configuration.

dis

Disables this peer configuration.

del

Deletes this peer configuration.

cur

Displays the current BGP peer configuration.

/cfg/l3/bgp/peer/redist

BGP Redistribution Configuration Menu

```
[Redistribution Menu]
metric - Set default-metric of advertised routes
default - Set default route action
rip - Enable/disable advertising RIP routes
ospf - Enable/disable advertising OSPF routes
fixed - Enable/disable advertising fixed routes
static - Enable/disable advertising static routes
vip - Enable/disable advertising VIP routes
cur - Display current redistribution configuration
```

Table 6-47 BGP Redistribution Configuration Menu Options
(/cfg/l3/bgp/peer/redist)

Command Syntax and Usage

metric <metric (1-4294967294)> | **none**

Sets default metric of advertised routes.

default **none** | **import** | **originate** | **redistribute**

Sets default route action.

Defaults routes can be configured as import, originate, redistribute, or none.

None: No routes are configured

Import: Import these routes.

Originate: The switch sends a default route to peers even though it does not have any default routes in its routing table.

Redistribute: Default routes are either configured through default gateway or learned through other protocols and redistributed to peer. If the routes are learned from default gateway configuration, you have to enable static routes since the routes from default gateway are static routes. Similarly, if the routes are learned from a certain routing protocol, you have to enable that protocol in this redistribute submenu.

rip **disable** | **enable**

Enables or disables advertising RIP routes

ospf **disable** | **enable**

Enables or disables advertising OSPF routes.

fixed **disable** | **enable**

Enables or disables advertising fixed routes.

static **disable** | **enable**

Enables or disables advertising static routes.

Table 6-47 BGP Redistribution Configuration Menu Options
(/cfg/l3/bgp/peer/redist)

Command Syntax and Usage

vip **disable** | **enable**

Enables or disables advertising VIP routes.

current

Displays current redistribution configuration.

/cfg/l3/bgp/aggr (*aggregation number*)

BGP Aggregation Configuration

[BGP Aggr 1 Menu]	
addr	- Set aggregation IP address
mask	- Set aggregation network mask
enable	- Enable aggregation
disable	- Disable aggregation
delete	- Delete aggregation
cur	- Display current aggregation configuration

This menu enables you to configure filters that specify the routes/range of IP destinations a peer router will accept from other peers. A route must match a filter to be installed in the routing table. By default, the first filter is enabled and the rest of the filters are disabled.

Table 6-48 BGP Filter Configuration Options (/cfg/l3/bgp/aggr)

Command Syntax and Usage

addr <IP address (such as 192.4.17.101)>

Defines the starting IP address for this filter, using dotted decimal notation. The default address is 0.0.0.0.

mask <IP subnet mask (such as, 255.255.255.0)>

This IP address mask is used with **addr** to define the range of IP addresses that will be accepted by the peer when the filter is enabled. The default address is 0.0.0.0.

ena

Enables this BGP filter.

dis

Disables this BGP filter.

Table 6-48 BGP Filter Configuration Options (/cfg/l3/bgp/aggr)**Command Syntax and Usage****del**

Deletes this BGP filter.

cur

Displays the current BGP filter configuration.

/cfg/l3/igmp

IGMP Configuration

[IGMP Menu]

```

snoop      - IGMP Snooping Menu
mrouter    - Static Multicast Router Port Menu
robust     - Set IGMP robustness variable
qinterval  - Set IGMP query interval
qmrt       - Set IGMP query max response time
on         - Globally turn IGMP ON
off        - Globally turn IGMP OFF
cur        - Display current IGMP configuration

```

IGMP Snooping allows the switch to forward multicast traffic only to those ports that request it. IGMP snooping prevents multicast traffic from being flooded to all ports. The switch learns which server hosts are interested in receiving multicast traffic, and forwards it only to ports connected to those servers.

Table 6-49 IGMP Snoop Menu (/cfg/l3/igmp)**Command Syntax and Usage****snoop**Displays the IGMP Snoop Menu. To view menu options, see [page 231](#).**mrouter**Displays the Static Multicast Router Port Menu. To view menu options, see [page 232](#).**robust <2-10>**

Configures the IGMP Robustness variable, which allows you to tune the switch for expected packet loss on the subnet. If the subnet is expected to be lossy (high rate of packet loss), increase the value. The default value is 2.

Table 6-49 IGMP Snoop Menu (/cfg/l3/igmp)**Command Syntax and Usage****qinterval** <1-3600>

Configures the interval for IGMP Query Reports. The default value is 125 seconds.

qmrt <1-600>

Configures the maximum time allowed for IGMP Query responses from multicast routers, in tenths of a second. The default value is 100.

on

Turns IGMP on globally.

off

Turns IGMP off globally.

cur

Displays the current IGMP configuration parameters.

/cfg/l3/igmp/snoop

IGMP Snooping Configuration

[IGMP Snooping Menu]

```

mrto      - Override multicast router timeout
add       - Add VLAN(s) to IGMP Snooping
rem       - Remove VLAN(s) from IGMP Snooping
clear     - Remove all VLAN(s) from IGMP Snooping
fastlv   - Enable/disable quick-leave processing in VLAN
ena       - Enable IGMP Snooping
dis       - Disable IGMP Snooping
cur       - Display current IGMP Snooping configuration

```

Table 6-50 describes the commands used to configure IGMP Snooping.**Table 6-50** IGMP Snoop Menu (/cfg/l3/igmp/snoop)**Command Syntax and Usage****mrto** <1-255 seconds>

Configures the timeout value for IGMP Membership Queries (mrouter). Once the timeout value is reached, the switch removes the multicast router from its IGMP table, if the proper conditions are met. The range is from 1 to 255 seconds. The default is 60 seconds.

add <VLAN number>

Adds selected VLANs to IGMP Snooping.

Table 6-50 IGMP Snoop Menu (/cfg/l3/igmp/snoop)**Command Syntax and Usage****remove** <VLAN number>

Removes selected VLANs from IGMP Snooping.

clear

Removes all VLANs from IGMP Snooping.

fastlv <VLAN number> **disable** | **enable**

Enables or disables Fastleave processing. Fastleave allows the switch to immediately remove a port from the IGMP port list, if the host sends a Leave message, and the proper conditions are met. This command is disabled by default.

ena

Enables IGMP Snooping.

dis

Disables IGMP Snooping.

cur

Displays the current IGMP Snooping parameters.

/cfg/l3/igmp/mrouter

IGMP Static Multicast Router Configuration

```
[Static Multicast Router Port Menu]
  add - Add Static Multicast Router Port
  rem - Remove Static Multicast Router Port
  cur - Display current Static Multicast Router Port configuration
```

[Table 6-51](#) describes the commands used to configure a static multicast router.

NOTE – When you configure a static multicast router on a VLAN, the process of learning multicast routers is disabled for that VLAN.

Table 6-51 IGMP Static Multicast Router Menu (/cfg/l3/igmp/static)

Command Syntax and Usage

add <port number> <VLAN number> <IGMP version number>

Selects a port/VLAN combination on which the static multicast router is connected, and configures the IGMP version (1 or 2) of the multicast router.

Note: Port number must be an external port.

remove <port number> <VLAN number>

Removes a static multicast router from the selected port/VLAN combination.

cur

Displays the current IGMP Static Multicast Router parameters.

/cfg/l3/port <port alias or number> IP Port Configuration

[IP Forwarding Port INT1 Menu]	
on	- Turn Forwarding ON
off	- Turn Forwarding OFF
cur	- Display current port configuration

The IP Port Menu allows you to turn IP forwarding on or off on a port-by-port basis. By default, the port forwarding option is turned on.

Table 6-52 IP Forwarding Port Options (/cfg/l3/port)

Command Syntax and Usage

on

Enables IP forwarding for the current port.

off

Disables IP forwarding for the current port.

cur

Displays the current IP forwarding settings.

/cfg/l3/dns

Domain Name System Configuration

```
[Domain Name System Menu]
  prima   - Set IP address of primary DNS server
  secon   - Set IP address of secondary DNS server
  dname   - Set default domain name
  cur     - Display current DNS configuration
```

The Domain Name System (DNS) Menu is used for defining the primary and secondary DNS servers on your local network, and for setting the default domain name served by the switch services. DNS parameters must be configured prior to using hostname parameters with the ping, traceroute, and tftp commands.

Table 6-53 Domain Name Service Menu Options (/cfg/l3/dns)

Command Syntax and Usage

prima <IP address (such as 192.4.17.101)>

You will be prompted to set the IP address for your primary DNS server. Use dotted decimal notation.

secon <IP address (such as 192.4.17.101)>

You will be prompted to set the IP address for your secondary DNS server. If the primary DNS server fails, the configured secondary will be used instead. Enter the IP address using dotted decimal notation.

dname <dotted DNS notation> | **none**

Sets the default domain name used by the switch.
For example: mycompany.com

cur

Displays the current Domain Name System settings.

/cfg/l3/bootp

Bootstrap Protocol Relay Configuration

```
[Bootstrap Protocol Relay Menu]
  addr      - Set IP address of BOOTP server
  addr2     - Set IP address of second BOOTP server
  on        - Globally turn BOOTP relay ON
  off       - Globally turn BOOTP relay OFF
  cur       - Display current BOOTP relay configuration
```

The Bootstrap Protocol (BOOTP) Relay Menu is used to allow hosts to obtain their configurations from a Dynamic Host Configuration Protocol (DHCP) server. The BOOTP configuration enables the switch to forward a client request for an IP address to two DHCP/BOOTP servers with IP addresses that have been configured on the GbE Switch Module.

BOOTP relay menu is turned off by default.

Table 6-54 Bootstrap Protocol Relay Configuration Menu Options (/cfg/l3/bootp)

Command Syntax and Usage

addr <IP address (such as, 192.4.17.101)>
Sets the IP address of the BOOTP server.

addr2 <IP address (such as, 192.4.17.101)>>
Sets the IP address of the second BOOTP server.

on
Globally turns on BOOTP relay.

off
Globally turns off BOOTP relay.

cur
Displays the current BOOTP relay configuration.

/cfg/l3/vrrp

VRRP Configuration

```
[Virtual Router Redundancy Protocol Menu]
vr      - VRRP Virtual Router menu
group   - VRRP Virtual Router Group menu
if      - VRRP Interface menu
track   - VRRP Priority Tracking menu
hotstan - Enable/disable hot-standby processing
trnkfo  - Enable/disable trunk failover
on      - Globally turn VRRP ON
off     - Globally turn VRRP OFF
cur     - Display current VRRP configuration
```

Virtual Router Redundancy Protocol (VRRP) support on GbE Switch Modules provides redundancy between routers in a LAN. This is accomplished by configuring the same virtual router IP address and ID number on each participating VRRP-capable routing device. One of the virtual routers is then elected as the master, based on a number of priority criteria, and assumes control of the shared virtual router IP address. If the master fails, one of the backup virtual routers will assume routing authority and take control of the virtual router IP address.

By default, VRRP is disabled. Alteon OS has extended VRRP to include virtual servers as well, allowing for full active/active redundancy between its Layer 4 switches. For more information on VRRP, see the “High Availability” chapter in the *Alteon OS 20.2 Application Guide*.

Table 6-55 Virtual Router Redundancy Protocol Options (/cfg/l3/vrrp)

Command Syntax and Usage

vr <virtual router number (1-128)>

Displays the VRRP Virtual Router Menu. This menu is used for configuring up to 128 virtual routers on this switch. To view menu options, see [page 237](#).

group

Displays the VRRP virtual router group menu, used to combine all virtual routers together as one logical entity. Group options must be configured when using two or more Alteon switches in a hot-standby failover configuration where only one switch is active at any given time. To view menu options, see [page 242](#).

if <interface number (1-128)>

Displays the VRRP Virtual Router Interface Menu. To view menu options, see [page 246](#).

Table 6-55 Virtual Router Redundancy Protocol Options (/cfg/l3/vrrp)**Command Syntax and Usage****track**

Displays the VRRP Tracking Menu. This menu is used for weighting the criteria used when modifying priority levels in the master router election process. To view menu options, see [page 247](#).

hotstan disable|enable

Enables or disables hot standby processing, in which two or more switches provide redundancy for each other. By default, this option is disabled.

trnkfo disable|enable

When enabled, allows L2 Trunk Failover to be enabled when VRRP is enabled (but not hot standby processing). By default, this option is disabled.

on

Globally enables VRRP on this switch.

off

Globally disables VRRP on this switch.

cur

Displays the current VRRP parameters.

/cfg/l3/vrrp/vr <router number> **Virtual Router Configuration**

```
[VRRP Virtual Router 1 Menu]
  track - Priority Tracking Menu
  vrid  - Set virtual router ID
  addr  - Set IP address
  if    - Set interface number
  prio  - Set rener priority
  adver - Set advertisement interval
  preem - Enable or disable preemption
  ena   - Enable virtual router
  dis   - Disable virtual router
  del   - Delete virtual router
  cur   - Display current VRRP virtual router configuration
```

This menu is used for configuring up to 128 virtual routers for this switch. A virtual router is defined by its virtual router ID and an IP address. On each VRRP-capable routing device participating in redundancy for this virtual router, a virtual router will be configured to share the same virtual router ID and IP address.

Virtual routers are disabled by default.

Table 6-56 VRRP Virtual Router Options (/cfg/l3/vrrp/vr)

Command Syntax and Usage

track

Displays the VRRP Priority Tracking Menu for this virtual router. Tracking is an Alteon OS proprietary extension to VRRP, used for modifying the standard priority system used for electing the master router. To view menu options, see [page 240](#).

vrid <virtual router ID (1-255)>

Defines the virtual router ID. This is used in conjunction with `addr` (below) to define a virtual router on this switch. To create a pool of VRRP-enabled routing devices which can provide redundancy to each other, each participating VRRP device must be configured with the same virtual router: one that shares the same `vrid` and `addr` combination.

The `vrid` for standard virtual routers (where the virtual router IP address is not the same as any virtual server) can be any integer between 1 and 255. The default value is 1.

All `vrid` values must be unique within the VLAN to which the virtual router's IP interface belongs.

addr <IP address (such as, 192.4.17.101)>

Defines the IP address for this virtual router using dotted decimal notation. This is used in conjunction with the `vrid` (above) to configure the same virtual router on each participating VRRP device. The default address is 0.0.0.0.

if <interface number (1-128)>

Selects a switch IP interface (between 1 and 128). If the IP interface has the same IP address as the `addr` option above, this switch is considered the "owner" of the defined virtual router. An owner has a special priority of 255 (highest) and will always assume the role of master router, even if it must preempt another virtual router which has assumed master routing authority. This preemption occurs even if the `preem` option below is disabled. The default value is 1.

prio <priority (1-254)>

Defines the election priority bias for this virtual server. This can be any integer between 1 and 254. The default value is 100.

During the master router election process, the routing device with the highest virtual router priority number wins. If there is a tie, the device with the highest IP interface address wins. If this virtual router's IP address (`addr`) is the same as the one used by the IP interface, the priority for this virtual router will automatically be set to 255 (highest).

When priority tracking is used (/cfg/l3/vrrp/track or /cfg/l3/vrrp/vr #/track), this base priority value can be modified according to a number of performance and operational criteria.

Table 6-56 VRRP Virtual Router Options (/cfg/l3/vrrp/vr)

Command Syntax and Usage

adver <*seconds (1-255)*>

Defines the time interval between VRRP master advertisements. This can be any integer between 1 and 255 seconds. The default value is 1.

preem **disable** | **enable**

Enables or disables master preemption. When enabled, if this virtual router is in backup mode but has a higher priority than the current master, this virtual router will preempt the lower priority master and assume control. Note that even when **preem** is disabled, this virtual router will always preempt any other master if this switch is the owner (the IP interface address and virtual router **addr** are the same). By default, this option is enabled.

ena

Enables this virtual router.

dis

Disables this virtual router.

del

Deletes this virtual router from the switch configuration.

cur

Displays the current configuration information for this virtual router.

`/cfg/l3/vrrp/vr <router number>/track` Virtual Router Priority Tracking Configuration

```
[VRRP Virtual Router 1 Priority Tracking Menu]
vrs      - Enable/disable tracking master virtual routers
ifs      - Enable/disable tracking other interfaces
ports    - Enable/disable tracking VLAN switch ports
l4pts    - Enable/disable tracking L4 switch ports
reals    - Enable/disable tracking L4 real servers
hsrp     - Enable/disable tracking HSRP
hsrv     - Enable/disable tracking HSRP by VLAN
cur      - Display current VRRP virtual router configuration
```

This menu is used for modifying the priority system used when electing the master router from a pool of virtual routers. Various tracking criteria can be used to bias the election results. Each time one of the tracking criteria is met, the priority level for the virtual router is increased by an amount defined through the VRRP Tracking Menu (see [page 247](#)).

Criteria are tracked dynamically, continuously updating virtual router priority levels when enabled. If the virtual router preemption option (see `preem` in [Table 6-56 on page 238](#)) is enabled, this virtual router can assume master routing authority when its priority level rises above that of the current master.

Some tracking criteria (`vrs`, `ifs`, and `ports` below) apply to standard virtual routers, otherwise called “virtual interface routers.” Other tracking criteria (`l4pts`, `reals`, and `hsrp`) apply to “virtual server routers,” which perform Layer 4 Server Load Balancing functions. A virtual *server* router is defined as any virtual router whose IP address (`addr`) is the same as any configured virtual server IP address.

Table 6-57 VRRP Priority Tracking Options (`/cfg/l3/vrrp/vr #/track`)

Command Syntax and Usage

`vrs disable|enable`

When enabled, the priority for this virtual router will be increased for each virtual router in master mode on this switch. This is useful for making sure that traffic for any particular client/server pairing are handled by the same switch, increasing routing and load balancing efficiency. This command is disabled by default.

`ifs disable|enable`

When enabled, the priority for this virtual router will be increased for each other IP interface active on this switch. An IP interface is considered active when there is at least one active port on the same VLAN. This helps elect the virtual routers with the most available routes as the master. This command is disabled by default.

Table 6-57 VRRP Priority Tracking Options (/cfg/l3/vrrp/vr #/track)

Command Syntax and Usage

ports disable|enable

When enabled, the priority for this virtual router will be increased for each active port on the same VLAN. A port is considered “active” if it has a link and is forwarding traffic. This helps elect the virtual routers with the most available ports as the master. This command is disabled by default.

l4pts disable|enable

When enabled for virtual server routers, the priority for this virtual router will be increased for each physical switch port which has active Layer 4 processing on this switch. This helps elect the main Layer 4 switch as the master. This command is disabled by default.

reals disable|enable

When enabled for virtual server routers, the priority for this virtual router will be increased for each healthy real server behind the virtual server IP address of the same IP address as the virtual router on this switch. This helps elect the switch with the largest server pool as the master, increasing Layer 4 efficiency. This command is disabled by default.

hsrp disable|enable <priority (1-254)>

Hot Standby Router Protocol (HSRP) is used with some types of routers for establishing router failover. In networks where HSRP is used, enable this switch option to increase the priority of this virtual router for each Layer 4 client-only port that receives HSRP advertisements. Enabling HSRP helps elect the switch closest to the master HSRP router as the master, optimizing routing efficiency. This command is disabled by default.

hsrv disable|enable

Hot Standby Router on VLAN (HSRV) is used to work in VLAN-tagged environments. Enable this switch option to increment only that **vrrp** instance that is on the *same* VLAN as the tagged hsrp master flagged packet. This command is disabled by default.

cur

Displays the current configuration for priority tracking for this virtual router.

/cfg/l3/vrrp/group

Virtual Router Group Configuration

```
[VRRP Virtual Router Group Menu]
track    - Priority Tracking Menu
vrid     - Set virtual router ID
if       - Set interface number
prio     - Set reenter priority
adver    - Set advertisement interval
preem    - Enable or disable preemption
ena      - Enable virtual router
dis      - Disable virtual router
del      - Delete virtual router
cur      - Display current VRRP virtual router configuration
```

The Virtual Router Group menu is used for associating all virtual routers into a single logical virtual router, which forces all virtual routers on the GbE Switch Module to either be master or backup as a group. A virtual router is defined by its virtual router ID and an IP address. On each VRRP-capable routing device participating in redundancy for this virtual router, a virtual router will be configured to share the same virtual router ID and IP address.

NOTE – This option is required to be configured only when using at least two GbE Switch Modules in a hot-standby failover configuration, where only one switch is active at any time.

Table 6-58 VRRP Virtual Router Group Options (/cfg/l3/vrrp/group)

Command Syntax and Usage

track

Displays the VRRP Priority Tracking Menu for the virtual router group. Tracking is an Alteon OS proprietary extension to VRRP, used for modifying the standard priority system used for electing the master router. To view menu options, see [page 244](#).

vrid <virtual router ID (1-255)>

Defines the virtual router ID.

The `vrid` for standard virtual routers (where the virtual router IP address is not the same as any virtual server) can be any integer between 1 and 255. All `vrid` values must be unique within the VLAN to which the virtual router's IP interface (see `if` below) belongs. The default virtual router ID is 1.

if <interface number (1-128)>

Selects a switch IP interface (between 1 and 128). The default switch IP interface number is 1.

Table 6-58 VRRP Virtual Router Group Options (/cfg/l3/vrrp/group)

Command Syntax and Usage

prio <priority (1-254)>

Defines the election priority bias for this virtual router group. This can be any integer between 1 and 254. The default value is 100.

During the master router election process, the routing device with the highest virtual router priority number wins. If there is a tie, the device with the highest IP interface address wins. If this virtual router's IP address (addr) is the same as the one used by the IP interface, the priority for this virtual router will automatically be set to 255 (highest).

When priority tracking is used (/cfg/l3/vrrp/track or /cfg/l3/vrrp/vr #/track), this base priority value can be modified according to a number of performance and operational criteria.

adver <seconds (1-255)>

Defines the time interval between VRRP master advertisements. This can be any integer between 1 and 255 seconds. The default is 1.

preem **disable** | **enable**

Enables or disables master preemption. When enabled, if the virtual router group is in backup mode but has a higher priority than the current master, this virtual router will preempt the lower priority master and assume control. Note that even when preem is disabled, this virtual router will always preempt any other master if this switch is the owner (the IP interface address and virtual router addr are the same). By default, this option is enabled.

ena

Enables the virtual router group.

dis

Disables the virtual router group.

del

Deletes the virtual router group from the switch configuration.

cur

Displays the current configuration information for the virtual router group.

/cfg/l3/vrrp/group/track

Virtual Router Group Priority Tracking Configuration

```
[Virtual Router Group Priority Tracking Menu]
vrs      - Enable/disable tracking master virtual routers
ifs      - Enable/disable tracking other interfaces
ports    - Enable/disable tracking VLAN switch ports
l4pts    - Enable/disable tracking L4 switch ports
reals    - Enable/disable tracking L4 real servers
hsrp     - Enable/disable tracking HSRP
hsrv     - Enable/disable tracking HSRP by VLAN
cur      - Display current VRRP Group Tracking configuration
```

NOTE – If *Virtual Router Group Tracking* is enabled, then the tracking option will be available only under *group* option. The tracking setting for the other individual virtual routers will be ignored.

Table 6-59 Virtual Router Group Priority Tracking Options (/cfg/l3/vr/group/track)

Command Syntax and Usage

vrs disable|enable

When enabled, the priority for this virtual router will be increased for each virtual router in master mode on this switch. This is useful for making sure that traffic for any particular client/server pairing are handled by the same switch, increasing routing and load balancing efficiency. This command is disabled by default.

ifs disable|enable

When enabled, the priority for this virtual router will be increased for each other IP interface active on this switch. An IP interface is considered active when there is at least one active port on the same VLAN. This helps elect the virtual routers with the most available routes as the master. This command is disabled by default.

ports disable|enable

When enabled, the priority for this virtual router will be increased for each active port on the same VLAN. A port is considered “active” if it has a link and is forwarding traffic. This helps elect the virtual routers with the most available ports as the master. This command is disabled by default.

l4pts disable|enable

When enabled for virtual server routers, the priority for this virtual router will be increased for each physical switch port which has active Layer 4 processing on this switch. This helps elect the main Layer 4 switch as the master. This command is disabled by default.

Table 6-59 Virtual Router Group Priority Tracking Options (/cfg/l3/vr/group/track)

Command Syntax and Usage

reals disable | enable

When enabled for virtual server routers, the priority for this virtual router will be increased for each healthy real server. This helps elect the switch with the largest server pool as the master, increasing Layer 4 efficiency. This command is disabled by default.

hsrp disable | enable

Enables Hot Standby Router Protocol (HSRP) for this virtual router group. HSRP is used with some types of routers for establishing router failover. In networks where HSRP is used, enable this switch option to increase the priority of this virtual router for each Layer 4 client-only port that receives HSRP advertisements. This helps elect the switch closest to the master HSRP router as the master, optimizing routing efficiency. This command is disabled by default.

hsrv disable | enable

Hot Standby Router on VLAN (HSRV) is used to work in VLAN-tagged environments. Enable this switch option to increment only that **vrrp** instance that is on the *same* VLAN as the tagged hsrp master flagged packet. This command is disabled by default.

cur

Displays the current configuration for priority tracking for this virtual router.

`/cfg/l3/vrrp/if` <interface number> VRRP Interface Configuration

NOTE – The *interface-number* (1 to 128) represents the IP interface on which authentication parameters must be configured.

[VRRP Interface 1 Menu]	
<code>auth</code>	- Set authentication types
<code>passw</code>	- Set plain-text password
<code>del</code>	- Delete interface
<code>cur</code>	- Display current VRRP interface configuration

This menu is used for configuring VRRP authentication parameters for the IP interfaces used with the virtual routers.

Table 6-60 VRRP Interface Menu Options (`/cfg/l3/vrrp/if`)

Command Syntax and Usage

auth `none` | `password`

Defines the type of authentication that will be used: `none` (no authentication), or `password` (password authentication).

passw <password>

Defines a plain text password up to eight characters long. This password will be added to each VRRP packet transmitted by this interface when password authentication is chosen (see **auth** above).

del

Clears the authentication configuration parameters for this IP interface. The IP interface itself is not deleted.

cur

Displays the current configuration for this IP interface's authentication parameters.

/cfg/l3/vrrp/track

VRRP Tracking Configuration

[VRRP Tracking Menu]

<code>vrs</code>	- Set priority increment for virtual router tracking
<code>ifs</code>	- Set priority increment for IP interface tracking
<code>ports</code>	- Set priority increment for VLAN switch port tracking
<code>l4pts</code>	- Set priority increment for L4 switch port tracking
<code>reals</code>	- Set priority increment for L4 real server tracking
<code>hsrp</code>	- Set priority increment for HSRP tracking
<code>hsrv</code>	- Set priority increment for HSRP by VLAN tracking
<code>cur</code>	- Display current VRRP Priority Tracking configuration

This menu is used for setting weights for the various criteria used to modify priority levels during the master router election process. Each time one of the tracking criteria is met (see “VRRP Virtual Router Priority Tracking Menu” on [page 240](#)), the priority level for the virtual router is increased by an amount defined through this menu.

Table 6-61 VRRP Tracking Options (/cfg/l3/vrrp/track)

Command Syntax and Usage

vrs <0-254>

Defines the priority increment value (1 through 254) for virtual routers in master mode detected on this switch. The default value is 2.

ifs <0-254>

Defines the priority increment value (1 through 254) for active IP interfaces detected on this switch. The default value is 2.

ports <0-254>

Defines the priority increment value (1 through 254) for active ports on the virtual router’s VLAN. The default value is 2.

l4pts <0-254>

Defines the priority increment value (1 through 254) for physical switch ports with active Layer 4 processing. The default value is 2.

reals <0-254>

Defines the priority increment value (1 through 254) for healthy real servers behind the virtual server router. The default value is 2.

hsrp <0-254>

Defines the priority increment value (1 through 254) for switch ports with Layer 4 client-only processing that receive HSRP broadcasts. The default value is 10.

Table 6-61 VRRP Tracking Options (/cfg/l3/vrrp/track)**Command Syntax and Usage****hsrv** <0-254>

Defines the priority increment value (1 through 254) for vrrp instances that are on the same VLAN.

The default value is 10.

cur

Displays the current configuration of priority tracking increment values.

NOTE – These priority tracking options only define increment values. These options do not affect the VRRP master router election process until options under the VRRP Virtual Router Priority Tracking Menu (see [page 240](#)) are enabled.

/cfg/l3/metric <metric name>**Default Gateway Metrics**

If multiple default gateways are configured and enabled, a metric can be set to determine which primary gateway is selected. There are two metrics, which are described in the table .

Table 6-62 Default Gateway Metrics (/cfg/l3/metric)

Option	Description
strict	The gateway number determines its level of preference. Gateway #1 acts as the preferred default IP gateway until it fails or is disabled, at which point the next in line will take over as the default IP gateway.
roundrobin	This provides basic gateway load balancing. The switch sends each new gateway request to the next healthy, enabled gateway in line. All gateway requests to the same destination IP address are resolved to the same gateway.

/cfg/setup

Setup

The setup program steps you through configuring the system date and time, BOOTP, IP, Spanning Tree, port speed/mode, VLAN parameters, and IP interfaces.

To start the setup program, at the Configuration# prompt, enter:

```
Configuration# setup
```

For a complete description of how to use setup, see [Chapter 2, “First-Time Configuration.”](#)

/cfg/dump

Dump

The dump program writes the current switch configuration to the terminal screen. To start the dump program, at the Configuration# prompt, enter:

```
Configuration# dump
```

The configuration is displayed with parameters that have been changed from the default values. The screen display can be captured, edited, and placed in a script file, which can be used to configure other switches through a Telnet connection. When using Telnet to configure a new switch, paste the configuration commands from the script file at the command line prompt of the switch. The active configuration can also be saved or loaded via TFTP, as described on [page 250](#).

`/cfg/ptcfg <TFTP server> <filename>` Saving the Active Switch Configuration

When the `ptcfg` command is used, the switch's active configuration commands (as displayed using `/cfg/dump`) will be uploaded to the specified script configuration file on the TFTP server. To start the switch configuration upload, at the `Configuration#` prompt, enter:

```
Configuration# ptcfg <TFTP server> <filename>
```

Where *server* is the TFTP server IP address or hostname, and *filename* is the name of the target script configuration file.

NOTE – The output file is formatted with line-breaks but no carriage returns—the file cannot be viewed with editors that require carriage returns (such as Microsoft Notepad).

NOTE – If the TFTP server is running SunOS or the Solaris operating system, the specified `ptcfg` file must exist prior to executing the `ptcfg` command and must be writable (set with proper permission, and not locked by any application). The contents of the specified file will be replaced with the current configuration data.

`/cfg/gtcfg <TFTP server> <filename>` Restoring the Active Switch Configuration

When the `gtcfg` command is used, the active configuration will be replaced with the commands found in the specified configuration file. The file can contain a full switch configuration or a partial switch configuration. The configuration loaded using `gtcfg` is not activated until the `apply` command is used. If the `apply` command is found in the configuration script file loaded using this command, the `apply` action will be performed automatically.

To start the switch configuration download, at the `Configuration#` prompt, enter:

```
Configuration# gtcfg <TFTP server> <filename>
```

Where *server* is the TFTP server IP address or hostname, and *filename* is the name of the target script configuration file.

CHAPTER 7

The SLB Configuration Menu

This chapter discusses how to use the Command Line Interface (CLI) for configuring Server Load Balancing (SLB) on the GbE Switch Module.

/cfg/slb

SLB Configuration

```
[Layer 4 Menu]
  real      - Real Server Menu
  group     - Real Server Group Menu
  virt      - Virtual Server Menu
  filt      - Filtering Menu
  port      - Layer 4 Port Menu
  layer7    - Layer 7 Resource Definition Menu
  wap       - WAP Menu
  sync      - Config Synch Menu
  adv       - Layer 4 Advanced Menu
  advhc     - Layer 4 Advanced Health Check Menu
  pip       - Proxy IP Address Menu
  peerpip   - Peer Proxy IP Address Menu
  on        - Globally turn Layer 4 processing ON
  off       - Globally turn Layer 4 processing OFF
  cur       - Display current Layer 4 configuration
```

Table 7-1 Server Load Balancing Configuration Menu Options (/cfg/slb)

Command Syntax and Usage

real <real server number (1-63)>

Displays the menu for configuring real servers. To view menu options, see [page 254](#).

group <real server group number (1-64)>

Displays the menu for placing real servers into real server groups. To view menu options, see [page 259](#).

Table 7-1 Server Load Balancing Configuration Menu Options (/cfg/slb)

Command Syntax and Usage

virt <virtual server number (1-64)>Displays the menu for defining virtual servers. To view menu options, see [page 264](#).**filt** <filter ID (1-1024)>Displays the menu for Filtering and Application Redirection. To view menu options, see [page 272](#).**port** <port alias or number>Displays the menu for setting physical switch port states for Layer 4 activity. To view menu options, see [page 283](#).**layer7**Displays later 7 Resource Definition Menu. To view menu options, see [page 285](#).**wap**Displays WAP Menu. To view menu options, see [page 288](#)**sync**Displays the Synch Peer Switch Menu. To view menu options, see [page 289](#).**adv**Displays the Layer 4 Advanced Menu. To view menu options, see [page 291](#).**advhc**Displays the Layer 4 Advanced Health Check Menu. To view menu options, see [page 294](#).**pip**This menu is used to set the switch proxy IP address using dotted decimal notation. When the `pip` is defined, client address information in Layer 4 requests is replaced with this proxy IP address. To view options, see [page 297](#).**peerpip**

Displays Peer Proxy IP address Menu. When this command is enabled, the switch is able to forward traffic from the other switch, using Layer 2, without performing server processing on the packets of the other switch. This happens because the peer switches are aware of each other's proxy IP addresses. This prevents the dropping of a packet or being sent to the backup switch in the absence of the proxy IP address of the peer switch.

To view menu options, see [page 298](#).**on**

Globally turns on Layer 4 software services for Server Load Balancing and Application Redirection. Enabling Layer 4 services is not necessary for using filters only to allow, deny, or NAT traffic.

off

Globally disables Layer 4 services. All configuration information will remain in place (if applied or saved), but the software processes will no longer be active in the switch

Table 7-1 Server Load Balancing Configuration Menu Options (/cfg/slb)

Command Syntax and Usage

curDisplays the current Server Load Balancing configuration.

Filtering and Layer 4 (Server Load Balancing)

Filters configured to allow, deny, or perform Network Address Translation (NAT) on traffic do not require Layer 4 software to be activated. These filters are not affected by the Server Load Balancing `on` and `off` commands in this menu.

Application Redirection filters, however, require Layer 4 software services. Layer 4 processing must be turned on before redirection filters will work.

`/cfg/slb/real <server number>` Real Server SLB Configuration

```
[Real server 1 Menu]
layer7 - Real Server Layer 7 Command Menu
rip    - Set IP addr of real server
name   - Set server name
weight - Set server weight
maxcon - Set maximum number of connections
tmout  - Set minutes inactive connection remains open
backup - Set backup real server
inter  - Set interval between health checks
retry  - Set number of failed attempts to declare server DOWN
restr  - Set number of successful attempts to declare server UP
addport - Add real port to server
remport - Remove real port to server
proxy  - Enable/disable client proxy operation
fasthc - Enable/disable fast health check operation
submac - Enable/disable source MAC address substitution
ena    - Enable real server
dis    - Disable real server
del    - Delete real server
cur    - Display current real server configuration
```

This menu is used for configuring information about real servers that participate in a server pool for Server Load Balancing or Application Redirection. The required parameters are:

- Real server IP address
- Real server enabled (disabled by default)

Table 7-2 Real Server Configuration Menu Options (/cfg/slb/real)

Command Syntax and Usage

layer7

Displays the Layer 7 Menu. To view menu options, see [page 258](#).

rip <real server IP address>

Sets the IP address of the real server in dotted decimal format. When this command is used, the address entered is PINGed to determine if the server is up, and the administrator will be warned if the server does not respond.

name <string, maximum 31 characters>| none

Defines a 15-character alias for each real server. This will enable the network administrator to quickly identify the server by a natural language keyword value.

weight <real server weight (1-48)>

Sets the weighting value (1 to 48) that this real server will be given in the load balancing algorithms. Higher weighting values force the server to receive more connections than the other servers configured in the same real server group. By default, each real server is given a weight setting of 1. A setting of 10 would assign the server roughly 10 times the number of connections as a server with a weight of 1.

Weights are not applied when using the hash or minmisses metrics (see “[Server Load Balancing Metrics](#)” on [page 262](#)).

maxcon <maximum connections (0-200000)>

Sets the maximum number of connections that this server should simultaneously support. By default, the number of maximum connections is set at 20,000. This option sets a threshold as an artificial barrier, such that new connections will not be issued to this server if the maxcon limit is reached. New connections will be issued again to this server once the number of current connections has decreased below the maxcon setting.

If all servers in a real server group for a virtual server reach their maxcon limit at the same time, client requests will be sent to the backup/overflow server or backup/overflow server group. If no backup servers/server group are configured, client requests will be dropped by the virtual server.

Table 7-2 Real Server Configuration Menu Options (/cfg/slb/real)

Command Syntax and Usage

tmout *<even number of minutes (2-30)>*

Sets the number of minutes an inactive session remains open (in even numbered increments).

Every client-to-server session being load balanced is recorded in the switch's Session Table. When a client makes a request, the session is recorded in the table, the data is transferred until the client ends the session, and the session table entry is then removed.

In certain circumstances, such as when a client application is abnormally terminated by the client's system, TCP/UDP connections will remain registered in the switch's binding table. In order to prevent table overflow, these orphaned entries must be aged out of the binding table.

Using the `tmout` option, you can set the number of minutes to wait before removing orphan table entries. Settings must be specified in even numbered increments between 2 and 30 minutes. The default setting is 10.

This option is also used with the Persistent option (see `/cfg/slb/virt/pbind`). When persistent is activated, this option sets how long an idle client is allowed to remain associated with a particular server.

backup *<real server number (1-1023)>* | **none**

Sets the real server used as the backup/overflow server for this real server.

To prevent loss of service if a particular real server fails, use this option to assign a backup real server number. Then, if the real server becomes inoperative, the switch will activate the backup real server until the original becomes operative again.

The backup server is also used in overflow situations. If the real server reaches its `maxcon` (maximum connections) limit, the backup comes online to provide additional processing power until the original server becomes desaturated.

The same backup/overflow server may be assigned to more than one real server at the same time

inter *<number of seconds between health checks (0-60)>*

Sets the interval between real server health verification attempts.

Determining the health of each real server is a necessary function for Layer 4 switching. For TCP services, the switch verifies that real servers and their corresponding services are operational by opening a TCP connection to each service, using the defined service ports configured as part of each virtual service. For UDP services, the switch pings servers to determine their status.

The `inter` option lets you choose the time between health checks. The range is from 1 to 60 seconds. The default interval is 2 seconds. An interval of "0" disables health checking for the server.

retry *<number of consecutive health checks (1-63)>*

Sets the number of failed health check attempts required before declaring this real server inoperative. The range is from 1 to 63 attempts. The default is 4 attempts

restr *<number of consecutive health checks (1-63)>*

Sets the number of successful health check attempts required before declaring a UDP service operational. The range is from 1 to 63 attempts. The default is 8 attempts

Table 7-2 Real Server Configuration Menu Options (/cfg/slb/real)

Command Syntax and Usage

addport <real server port (2–65534)>Add multiple service ports to the server.

remport <real server port (2–65534)>Remove multiple service ports from the server.

proxy disable | enableEnables or disables proxy IP address translation. With this option enabled (default), a client request from any application can be proxied using a load-balancing Proxy IP address (PIP).

fasthc

Enables or disables Fast Health Check operation. When enabled, the real server goes down operationally as soon as the physical port connected to the real server goes down. When disabled, the real server will go down only after the configured health check interval.

This command is enabled by default.

submac disable | enableEnables or disables source MAC address substitution. By default, this option is disabled.

enableYou *must* perform this command to enable this real server for Layer 4 service. When enabled, the real server can process virtual server requests associated with its real server group. This option, when the `apply` and `save` commands are used, enables this real server for operation until explicitly disabled.See `/oper/slb/ena` on [page 302](#) for an operations-level command.

disDisables this real server from Layer 4 service. Any disabled server will no longer process virtual server requests as part of the real server group to which it is assigned. This option, when the `apply` is used, disables this real server until it is explicitly re-enabled. This option *does not* perform a graceful server shutdown.See `/oper/slb/dis` on [page 302](#) for an operations-level command.

delDeletes this real server from the Layer 4 switching software configuration. This removes the real server from operation within its real server groups. Use this command with caution, as it will delete any configuration options that have been set for this real server. This option *does not* perform a graceful server shutdown.

curDisplays the current configuration information for this real server.

/cfg/slb/real <server number>/layer7

Real Server Layer 7 Configuration

```
[Layer 7 Commands Menu]
  addlb      - Add URL path for URL load balance
  remlb      - Remove URL path for URL load balance
  cookser    - Enable/disable cookie assignment server
  exclude    - Enable/disable exclusionary string matching
  cur        - Display current real server configuration
```

This menu is used for entering commands and strings for Layer 7 processing.

Table 7-3 Layer 7 Commands Menu Options (/cfg/slb/real/layer7)

Command Syntax and Usage

addlb <URL path ID [1-512]>

Adds the predefined URL loadbalance string ID to the real server.

remlb <URL path ID [1-512]>

Removes the predefined URL loadbalance string ID from the real server.

cookser **disable** | **enable**

Enables or disables the real server to handle client requests that don't contain a cookie. This option is used if you want to designate a specific server to assign cookies only. This server gets the client request, assigns the cookie, and embeds the IP address of the real server that will handle the subsequent requests from the client.

By default, this option is disabled.

exclude **disable** | **enable**

Enables or disables *exclusionary string* matching. By default, this option is disabled.

cur

Displays the current real server configuration.

`/cfg/slb/group` *<real server group number>* Real Server Group SLB Configuration

```
[Real server group 1 Menu]
metric - Set metric used to select next server in group
rmetric - Set metric used to select next rport in server
content - Set health check content
health - Set health check type
backup - Set backup real server or group
name - Set real server group name
realthr - Set real server failure threshold
idsrprt - Set Intrusion Detection Port
mhash - Set minmisses hash parameter
viphlth - Enable/disable VIP health checking in DSR mode
ids - Enable/disable Intrusion Detection
idsfld - Enable/disable Intrusion Detection Group Flood
add - Add real server
rem - Remove real server
del - Delete real server group
cur - Display current group configuration
```

This menu is used for combining real servers into real server groups. Each real server group should consist of all the real servers which provide a specific service for load balancing. Each group must consist of at least one real server. Each real server can belong to more than one group. Real server groups are used both for Server Load Balancing and Application Redirection.

Table 7-4 Real Server Group Configuration Menu Options (`/cfg/slb/group`)

Command Syntax and Usage

metric `leastconns|roundrobin|minmisses|hash|response|bandwidth`

Set the load balancing metric used for determining which real server in the group will be the target of the next client request. The default setting is `leastconns`. See [“Server Load Balancing Metrics” on page 262](#).

rmetric

Sets the load balancing metric used for determining which port in the real server will be the target of the next client request.

content `<filename>|/ /<host> /<filename> | none`

This option defines the specific content which is examined during health checks. The content depends on the type of health check specified in the `health` option (see below).

Table 7-4 Real Server Group Configuration Menu Options (/cfg/slb/group)**Command Syntax and Usage**

health	link arp icmp tcp http dns pop3 smtp nntp ftp imap radius sslh script<n> udpdns wsp wtls ldap
	Sets the type of health checking performed. The default is <code>tcp</code> . The options are as follows:
<code>link</code>	For IDSLB group only, checks status of port for each server.
<code>arp</code>	For Layer 2 health checking, sends an ARP request.
<code>icmp</code>	For Layer 3 health checking, pings the server.
<code>tcp</code>	For TCP service, opens and closes a TCP/IP connection to the server.
<code>http</code>	For HTTP service, use HTTP 1.1 GETS when a <code>HOST:</code> header is required to check that the URL content is specified in <code>content</code> command. Otherwise, an HTTP/1.0 GET occurs. Note: If the content is not specified, the health check will revert back to TCP on the port that is being load balanced.
<code>dns</code>	For Domain Name Service, check that the domain name specified in <code>content</code> can be resolved by the server.
<code>pop3</code>	For user mail service, check that the <code>user:password</code> account specified in <code>content</code> exists on the server.
<code>smtp</code>	For mail-server services, check that the user specified in <code>content</code> is accessible on the server.
<code>nntp</code>	For newsgroup services, check that the newsgroup name specified in <code>content</code> is accessible on the server.
<code>ftp</code>	For FTP services, check that the filename specified in <code>content</code> is accessible on the server through anonymous login.
<code>imap</code>	For user mail service, check that the <code>user:password</code> value specified in <code>content</code> exists on the server.
<code>radius</code>	For RADIUS remote access server authentication, check that the <code>user:password</code> value specified in <code>content</code> exists on the GbE Switch Module and the server. To perform application health checking to a RADIUS server, the network administrator must also configure the <code>/cfg/slb/secre</code> parameter. The <code>secre</code> value is a field of up to 32 alphanumeric characters that is used by the switch to encrypt a password during the RSA Message Digest Algorithm (MD5) and by the RADIUS server to decrypt the password during verification.
<code>sslh</code>	Enables the switch to query the health of the SSL servers by sending an SSL client “Hello” packet and then verify the contents of the server’s “Hello” response. During the handshake, the user and server exchange security certificates, negotiate an encryption and compression method, and establish a session ID for each session.
<code>script</code>	Enables the use of script-based health checks in send/expect format to check for application and content availability. <code><n></code> denotes the health script number (1-8).
<code>wsp</code>	Enables connectionless WSP content health checks for WAP gateways. The content under <code>/cfg/slb/advhc/waphc</code> (see page 296) must also be configured.
<code>udpdns</code>	Allows the user to perform health checking using UDP DNS queries.
<code>wtls</code>	Provides Wireless Transport Layer Security (WTLS) Hello-based health check for encrypted and connection-oriented WTLS traffic on port 9203.
<code>ldap</code>	Sets the health check type to LDAP.

Table 7-4 Real Server Group Configuration Menu Options (/cfg/slb/group)

Command Syntax and Usage

backup **r**<real server number (1-64)> | **g**<group number> | **none**

Sets the real server or real server group used as the backup/overflow server/server group for this real server group.

To prevent loss of service if the entire real server group fails, use this option to assign a backup real server/real server group number. Then, if the real server group becomes inoperative, the switch will activate the backup real server /server group until one of the original real servers becomes operative again.

The backup server/server group is also used in overflow situations. If all the servers in the real server group reach their **maxcon** (maximum connections) limit, the backup server/server group comes online to provide additional processing power until one of the original servers becomes desaturated.

The same backup/overflow server/server group may be assigned to more than one real server group at the same time.

name <string, maximum 31 characters> | **none**

Defines a 15-character alias for each Real Server Group. This will enable the network administrator to quickly identify the server group by a natural language keyword value.

realthr <real servers (1-15, 0 for disabled)>

Specifies a minimum number of real servers available. If any time, the number reaches this minimum limit, a SYSLOG ALERT message is sent to the configured SYSLOG servers stating that the real server threshold has been reached for the concerned server load balancing group. The default threshold is 0, which also means the option is disabled

idsrprt <real server port (2-65534)> | **any**

Sets real server port for Intrusion Detection Server.

mhash **24** | **32** <number of sip bits used for minmisses hash>

Defines the minmisses hash parameter for this real server as either 24 or 32 bits. By default the **minmiss** algorithm uses the upper 24-bits of the source IP address to calculate the real server that the traffic should be sent to when the minmiss metric is selected. You can also select all 32-bits of the source IP address to hash to the real server.

viphlth **disable** | **enable**

Enables or disables VIP health checking in a service. This feature is enabled by default. However, it works only when the service has DSR (Direct Server Return) feature enabled. When **viphlth** is disabled, the switch uses RIP to perform all health checks, whether DSR is enabled or disabled.

ids **disable** | **enable**

Enables or disables this group of servers for IDS load balancing.

idsfld **disable** | **enable**

Enables or disables the Intrusion Detection flood.

Table 7-4 Real Server Group Configuration Menu Options (/cfg/slb/group)

Command Syntax and Usage

add <real server number (1-63)>

Adds a real server to this real server group. You will be prompted to enter the number of the real server to add to this group.

rem <real server number (1-63)>

Remove a real server from this real server group. You will be prompted for the ID number for the real server to remove from this group.

del

Deletes this real server group from the Layer 4 software configuration. This removes the group from operation under all virtual servers it is assigned to. Use this command with caution: if you remove the only group that is assigned to a virtual server, the virtual server will become inoperative.

cur

Displays the current configuration parameters for this real server group.

Server Load Balancing Metrics

Using the `metric` command, you can set a number of metrics for selecting which real server in a group gets the next client request. These metrics are described in the following table:

Table 7-5 Real Server Group Metrics (/cfg/slb/group/metric)

Option and Description

minmisses

Minimum misses. This metric is optimized for Application Redirection. When `minmisses` is specified for a real server group performing Application Redirection, all requests for a specific IP destination address will be sent to the same server. This is particularly useful in caching applications, helping to maximize successful cache hits. Best statistical load balancing is achieved when the IP address destinations of load balanced frames are spread across a broad range of IP subnets. Minmisses can also be used for Server Load Balancing. When specified for a real server group performing Server Load Balancing, all requests from a specific client will be sent to the same server. This is useful for applications where client information must be retained on the server between sessions. Server load with this metric becomes most evenly balanced as the number of active clients increases.

Table 7-5 Real Server Group Metrics (/cfg/slb/group/metric)

Option and Description

hash

Like `minmisses`, the `hash` metric uses IP address information in the client request to select a server.

For Application Redirection, all requests for a specific IP destination address will be sent to the same server. This is particularly useful for maximizing successful cache hits.

For Server Load Balancing, all requests from a specific client will be sent to the same server. This is useful for applications where client information must be retained between sessions.

The `hash` metric should be used if the statistical load balancing achieved using `minmisses` is not as optimal as desired. Although the `hash` metric can provide more even load balancing at any given instance, it is not as effective as `minmisses` when servers leave and reenter service.

If the Load Balancing statistics indicate that one server is processing significantly more requests over time than other servers, consider using the `hash` metric.

leastconns

Least connections. With this option, the number of connections currently open on each real server is measured in real time. The server with the fewest current connections is considered to be the best choice for the next client connection request.

This option is the most self-regulating, with the fastest servers typically getting the most connections over time, due to their ability to accept, process, and shut down connections faster than slower servers.

roundrobin

Round robin. With this option, new connections are issued to each server in turn: the first real server in this group gets the first connection, the second real server gets the next connection, followed by the third real server, and so on. When all the real servers in this group have received at least one connection, the issuing process starts over with the first real server.

response

Real server response time. With this option, the switch monitors and records the amount of time that each real server takes to reply to a health check. The response time is used to adjust the real server weights. The weights are adjusted so they are inversely proportional to a moving average of response time.

bandwidth

Bandwidth Metric. With this option, the real server weights are adjusted so they are inversely proportional to the number of octets that the real server processes during a given interval. The higher the bandwidth used, the smaller is the weight assigned to that server.

NOTE – Under the `leastconns` and `roundrobin` metrics, when real servers are configured with weights (see the `weight` option on [page 255](#)), a higher proportion of connections are given to servers with higher weights. This can improve load balancing among servers of different performance levels. Weights are not applied when using the `hash` or `minmisses` metrics.

`/cfg/slb/virt` <virtual server number> Virtual Server SLB Configuration

```
[Virtual Server 1 Menu]
  service - Virtual Service Menu
  vip      - Set IP addr of virtual server
  dname    - Set domain name of virtual server
  layr3    - Enable/disable layer 3 only balancing
  ena      - Enable virtual server
  dis      - Disable virtual server
  del      - Delete virtual server
  cur      - Display current virtual configuration
```

This menu is used for configuring the virtual servers which will be the target for client requests for Server Load Balancing. Configuring a virtual server requires the following parameters:

- Creating a virtual server IP address
- Adding TCP/UDP port and real server group
- Enabling the virtual server (disabled by default)

Table 7-6 Virtual Server Configuration Menu Options (`/cfg/slb/virt`)

Command Syntax and Usage

service <virtual port or name>

Displays the Virtual Services Menu. The virtual port name can be a well-known port name, such as `http`, `ftp`, the service number, and so on. To get more information about well-known ports, see the `sport` command on [page 274](#). To view services menu options, see [page 266](#).

vip <virtual server IP address>

Sets the IP address of the virtual server using dotted-decimal notation. The virtual server created within the switch will respond to ARPs and PINGs from network ports as if it was a normal server. Client requests directed to the virtual server's IP address will be balanced among the real servers available to it through real server group assignments.

Table 7-6 Virtual Server Configuration Menu Options (/cfg/slb/virt)

Command Syntax and Usage

dname <34 character domain name> | **none**

Sets the domain name for this virtual server. The domain name typically includes the name of the company or organization, and the Internet group code (.com, .edu, .gov, .org, and so forth). An example would be foocorp.com. It does not include the hostname portion (www, www2, ftp, and so forth). The maximum number of characters that can be used in a domain name is 34. To define the hostname, see `hname` below. To clear the `dname`, specify the name as **none**.

layr3 **disable** | **enable**

Normally, the client IP address is used with the client Layer 4 port number to produce a session identifier. When the `layr3` option is enabled (disabled by default), the switch uses only the client IP address as the session identifier. It associates all the connections from the same client with the same real server while any connection exists between them.

This option is necessary for some server applications where state information about the client system is divided across different simultaneous connections, and also in applications where TCP fragments are generated.

If the real server to which the client is assigned becomes unavailable, the Layer 4 software will allow the client to connect to a different server.

ena

Enables this virtual server. This option activates the virtual server within the switch so that it can service client requests sent to its defined IP address.

dis

This option disables the virtual server so that it no longer services client requests.

del

This command removes this virtual server from operation within the switch and deletes it from the Layer 4 switching software configuration. Use this command with caution, as it will delete the options that have been set for this virtual server.

cur

Displays the current configuration of the specified virtual server.

`/cfg/slb/virt <server number>/service <virtual port or name>`

Virtual Server Service Configuration

This menu is used for configuring services assigned to a virtual server. The following example shows a menu for http (port 80) services.

NOTE – Select virtual service port 554 to configure RTSP traffic. See [page 270](#) to view the menu options for configuring virtual services on port 554 for RTSP.

```
[Virtual Server 1 http Service Menu]
  group    - Set real server group number
  rport    - Set real port
  hname    - Set hostname
  httpslb  - Set HTTP SLB processing
  pbind    - Set persistent binding type
  rcount   - Set multi response count
  dbind    - Enable/disable delayed binding
  udp      - Enable/disable UDP balancing
  frag     - Enable/disable remapping UDP server fragments
  nonat    - Enable/disable only substituting MAC addresses
  dnsslb   - Enable/disable DNS query load balancing
  del      - Delete virtual service
  cur      - Display current virtual service configuration
```

Table 7-7 Virtual Server Service Configuration Options (/cfg/slb/virt/service)

Command Syntax and Usage

group <real server group number (1-64)>

Sets a real server group for this service. The default is set at 1. You will be prompted to enter the number (1 to 64) of the real server group to add to this service.

rport <real server port (0-65534)>

Defines the real server TCP or UDP port assigned to this service. By default, this is the same as the virtual port (service virtual port). If **rport** is configured to be different than the virtual port defined in /cfg/slb/virt <number>/service <virtual port>, the switch will map the virtual port to this real port.

hname <hostname> | **none**

Sets the hostname for a service added. This is used in conjunction with **dname** (above) to create a full host/domain name for individual services.

The format for this command is: # **hname** <hostname>

For example, to add a hostname for Web services, you could specify *www* as the hostname. If a **dname** of "foocorp.com" was defined (above), "www.foocorp.com" would be the full host/domain name for the service.

To clear the hostname for a service, use the command: # **hname none**

dbind **disable** | **enable**

Enables or disables Layer 4 Delayed Binding for TCP service and ports. Enabling this command protects the server from Denial of Service (DoS) attacks. This option is disabled by default.

httpslb **urlslb** | **host** | **cookie** | **browser** | **urlhash** | **headerhash** | **others** | **none**

Load balances on the following applications:

- **urlslb**: Enable or disable URL SLB
- **host**: Enable or disable for virtual hosting
- **cookie**: Enable or disable cookie-based SLB for cookie-based preferential load balancing. You will be prompted for the following: Cookie name, starting point of the cookie value, number of bytes to be extracted, enable/disable checking for cookie in URI
- **browser**: Enable or disable SLB, based on browser type
- **urlhash**: Enable or disable URL hashing based on URI
- **headerhash**: Hashes on any HTTP header value.
- **others**: Requires inputs for a particular header field
- **none**: To clear all applications for **httpslb**, specify **none**.

You may choose to combine or select applications to load balance using the commands *and* and/or *or*. For example:

- **httpslb** <application>
 - **httpslb** <application> and | or <application>
-

Table 7-7 Virtual Server Service Configuration Options (/cfg/slb/virt/service)**Command Syntax and Usage****pbind clientip | cookie <p | r | i > | sslid | disable**

Enables or disables persistent bindings for a real server (disabled by default). This may be necessary for some server applications where state information about the client system is retained on the server over a series of sequential connections, such as with SSL (Secure Socket Layer, HTTPS), Web site search results, or multi-page Web forms.

- The `clientip` option uses the client IP address as an identifier, and associates all connections from the same client with the same real server until the client becomes inactive and the connection is aged out of the binding table. The connection timeout value (set in the Real Server Menu) is used to control how long these inactive but persistent connections remain associated with their real servers. When the client resumes activity *after* their connection has been aged out, they will be connected to the most appropriate real server based on the load balancing metric.

An alternative approach may be to use the real server group metrics `minmisses` or `hash` (see [Server Load Balancing Metrics](#)).

- The `cookie` option uses a cookie defined in the HTTP header or placed in the URI for hashing. For more information on `cookie` option, see “[Cookie-Based Persistence](#)” on [page 271](#). For detailed information on Cookie-Based Persistence, see the *Persistence* chapter in the *Alteon OS Application Guide*.
- The `sslid` option is for Secure Sockets Layer (SSL), which is a set of protocols built on top of TCP/IP that allow an application server and user to communicate over an encrypted HTTP session. SSL provides authentication, non-repudiation, and security. The session ID is a value comprising 32 random bytes chosen by the SSL server that gets stored in a session hash table. By enabling the `sslid` option, all subsequent SSL sessions which present the same session ID will be directed to the same real server.
- The `disable` option enables you to disable persistent binding, if it has previously been enabled for a particular application.

rcount <response count number (1–16)>

Sets the maximum response counter for cookie-based persistence. The GbE Switch Module will examine each server response until the cookie is found, or until the maximum count is reached. The default number is 1.

udp disable | enable | stateless

Enables or disables UDP load balancing for a virtual port (disabled by default). You can configure this option if the service(s) to be load balanced include UDP and TCP: for example, DNS uses UDP and TCP. In those environments, you must activate UDP balancing for the particular virtual servers that clients will communicate with using UDP.

When stateless is enabled, no session table entry is created.

Since no session is created, you have to bind to a new server every time.

Note: If applying a filter to the same virtual server IP address on which UDP load balancing is enabled, *disable caching on that filter for optimal performance*. For more information, see the `cache` command in [Table 7-12](#) on [page 278](#).

Table 7-7 Virtual Server Service Configuration Options (/cfg/slb/virt/service)

Command Syntax and Usage

frag disable | enable

Enables or disables remapping server fragments for virtual port. This option is enabled by default.

nonat disable | enable

Enables or disables substituting only the MAC address of the real server (disabled by default). This option does not substitute IP addresses. This option is used for Direct Server Return (DSR) in a one-armed load balancing setup, so that frames returning from server to the client do not have to pass through the switch.

dnsslb disable | enable

Enables or disables DNS-based Layer 7 content load balancing.

del

This command removes this virtual service from operation within the switch and deletes it from the Layer 4 switching software configuration. Use this command with caution, as it will delete the options that have been set for this virtual service.

cur

Displays the current configuration of services on the specified virtual server.

`/cfg/slb/virt <server number>/service 554` Virtual Server RTSP Configuration

This menu displays virtual services configured on service port 554 for RTSP traffic.

See “`/cfg/slb/virt <server number>/service <virtual port or name>`” on page 266 to view the menu options for configuring virtual services on port 80.

```
[Virtual Server 1 rtsp Service Menu]
  group   - Set real server group number
  hname   - Set hostname
  rtspslb - Set RTSP URL load balancing type
  del     - Delete virtual service
  cur     - Display current virtual service configuration
```

Table 7-8 Virtual Server Service Configuration Menu Options
(`/cfg/slb/virt 1/service 554`)

Command Syntax and Usage

group *<real server group number (1-64)>*

Sets real server group number.

hname

Sets the hostname for a service added. This is used in conjunction with `dname` (above) to create a full host/domain name for individual services.

The format for this command is: # `hname <hostname>`

For example, to add a hostname for Web services, you could specify `www` as the hostname. If a `dname` of “foocorp.com” was defined (above), “www.foocorp.com” would be the full host/domain name for the service.

To clear the hostname for a service, use the command: # `hname none`

rtspslb hash | patternMatch | disable

This Layer 7 load balancing option sets the type of `rtspslb` (`hash` | `patternMatch`, thereby enabling the service), or disables `rtspslb` service altogether with `disable` command.

To enable Layer 7 load balancing for RTSP service, `group` must be configured under the menu `/cfg/slb/virt <virtual server number>/service 80`. If you don’t configure `group`, service 80 and service RTSP will load balance the default group, which is `group 1`. See command `group` in the table “[Virtual Server Service Configuration Options \(/cfg/slb/virt/service\)](#)” on page 267 for details on how to configure `group`.

del

Deletes this virtual service.

cur

Displays the current virtual service configuration.

Cookie-Based Persistence

The `cookie` option is used to establish cookie-based persistence, and has the following command syntax and usage:

```
pbind cookie <mode> <name> <offset> <length> <URI>
```

Each parameter is explained in the following table.

Table 7-9 Command Syntax and Usage for `pbind cookie` Options
(/cfg/slb/virt/service/pbind cookie)

Option	Description
<mode>	<p>Specify the mode for cookie-based persistence. The following three modes are available:</p> <ul style="list-style-type: none"> ■ p: Passive mode. In this mode, the network administrator configures the Web server to embed a cookie in the server response that the switch looks for in subsequent requests from the same client. ■ r: Rewrite mode. In active cookie mode (or cookie rewrite mode), the switch, and not the network administrator, generates the cookie value on behalf of the server. The switch intercepts this persistence cookie and rewrites the value to include server-specific information before sending it to the client. ■ i: Insert mode. When a client sends a request <i>without</i> a cookie, the server responds with the data, and the switch inserts an <i>Alteon persistence cookie</i> into the data packet. The switch uses this cookie to bind to the appropriate server. Insert cookie mode expiration parameters are as follows: Enter insert-cookie expiration as either: <ul style="list-style-type: none"> ■ ... a date <MM/dd/yy[@hh:mm]> (e.g. 12/31/01@23:59) ■ ... a duration <days[:hours[:minutes]]> (e.g. 45:30:90) ■ ... or none <return>
<name>	Enter the name of the cookie.
<offset>	Enter the starting point of the cookie value (1-64)
<length>	Enter number of bytes to extract (1-64). For cookie rewrite, the extracting length must be 8 or 16.
<URI>	Look for cookie in the URI. If you want to look for cookie name or value in the URI, enter e to enable this option. To look for cookie in the HTTP header, enter d to disable this option.

For more information on Cookie-Based Persistence, see the *Alteon OS 20.2 Application Guide*.

`/cfg/slb/filt <filter number>` **SLB Filter Configuration**

```

[Filter 1  Menu]
adv      - Filter Advanced Menu
name     - Set filter name
smac     - Set source MAC address
dmac     - Set destination MAC address
sip      - Set source IP address
smask    - Set source IP mask
dip      - Set destination IP address
dmask    - Set destination IP mask
proto    - Set IP protocol
sport    - Set source TCP/UDP port or range
dport    - Set destination TCP/UDP port or range
action   - Set action
group    - Set real server group for redirection
rport    - Set real server port for redirection
nat      - Set which addresses are network address translated
vlan     - Set vlan id
invert   - Enable/disable filter inversion
ena      - Enable filter
dis      - Disable filter
del      - Delete filter
cur      - Display current filter configuration

```

The switch supports up to 1024 traffic filters. Each filter can be configured to allow, deny, redirect or perform Network Address Translation on traffic according to a variety of address and protocol specifications, and each physical switch port can be configured to use any combination of filters. This command is disabled by default.

There are several options available in the Filter Advanced Menu (`/cfg/slb/filt/adv`, [page 277](#)) that can be used to provide more information through syslog. The types of information include:

- IP protocol
- TCP/UDP ports
- TCP flags
- ICMP message type

The following parameters are required for filtering:

- Set the address, masks, and/or protocol that will be affected by the filter
- Set the filter action (allow, deny, redirect, nat)
- Enable the filter
- Add the filter to a switch port
- Enable filtering on the GbE Switch Module port

Table 7-10 Filter Configuration Menu Options (/cfg/slb/filt)

Command Syntax and Usage

adv

Displays the Filter Advanced Menu. To view menu options, see [page 277](#).

name <31 character name> | **none**

Allows the user to assign a name to a filter.

smac <MAC address (such as, 00:60:cf:40:56:00)> | **any**

Sets the source MAC address. The default is any.

dmac <MAC address (such as, 00:60:cf:40:56:00)> | **any**

Sets the destination MAC address. The default is any.

sip <IP address> | **any**

If defined, traffic with this source IP address will be affected by this filter. Specify an IP address in dotted decimal notation, or any. A range of IP addresses is produced when used with the **smask** below. The default is any if the source MAC address is any.

smask <<IP subnet mask (such as, 255.255.255.0)>

This IP address mask is used with the **sip** to select traffic which this filter will affect. See details below for more information on producing address ranges. For more information, see “Defining IP Address Ranges for Filters” on [page 276](#).

dip <IP address> | **any**

If defined, traffic with this destination IP address will be affected by this filter. Specify an IP address in dotted decimal notation, or any. A range of IP addresses is produced when used with the **dmask** below. The default is any if the destination MAC address is any. For more information, see “Defining IP Address Ranges for Filters” on [page 276](#).

dmask <IP subnet mask (such as, 255.255.255.0)>

This IP address mask is used with the **dip** to select traffic which this filter will affect.

Table 7-10 Filter Configuration Menu Options (/cfg/slb/filt)

Command Syntax and Usage

proto <number> | <name> | **any**

If defined, traffic from the specified protocol is affected by this filter. Specify the protocol number, name, or “**any**”. The default is any. Listed below are some of the well-known protocols.

<u>Number</u>	<u>Name</u>
1	icmp
2	igmp
6	tcp
17	udp
89	ospf
112	vrrp

sport <name> | <port> | <port>-<port> | **any**

If defined, traffic with the specified TCP or UDP source port will be affected by this filter. Specify the port number, range, name, or “**any**”. The default is any. Listed below are some of the well-known ports::

<u>Number</u>	<u>Name</u>
20	ftp-data
21	ftp
22	ssh
23	telnet
25	smtp
37	time
42	name
43	whois
53	domain
69	tftp
70	gopher
79	finger
80	http
109	pop2
110	pop3

dport <name>|<port>|<port>-<port> | **any**

If defined, traffic with the specified real server TCP or UDP destination port will be affected by this filter. Specify the port number, range, name, or “**any**”, just as with **sport** above. The default is set at any.

Table 7-10 Filter Configuration Menu Options (/cfg/slb/filt)

Command Syntax and Usage

action **allow** | **deny** | **redir** | **nat**

Specify the action this filter takes:

allow	Allow the frame to pass (by default).
deny	Discard frames that fit this filter's profile. This can be used for building basic security profiles.
redir	Redirect frames that fit this filter's profile, such as for web cache redirection. In addition, Layer 4 processing must be activated (see the /cfg/slb/on command on page 251).
nat	Perform generic Network Address Translation (NAT). This can be used to map the source or destination IP address and port information of a private network scheme to/from the advertised network IP address and ports. This is used in conjunction with the nat option below and can also be combined with proxies.

group <real server group number (1-64)>This option applies only when **redir** is specified at the filter action. Define a real server group (1 to 16) to which redirected traffic will be sent. The default is group 1

rport <real server port (0-65535)>This option applies only when **redir** is specified at the filter action. This defines the real server TCP or UDP port to which redirected traffic will be sent. For valid Layer 4 health checks, this must be configured whenever TCP protocol traffic is redirected. Also, if transparent proxies are used for Network Address Translation (NAT) on the GbE Switch Module (see the **pip** option in [Table 7-17 on page 283](#)), **rport** must be configured for all Application Redirection filters. The default is set at 0.

nat **source** | **dest**When **nat** is set as the filter action (see above), this command specifies whether Network Address Translation (NAT) is performed on the source or the destination information. Destination (**dest**) is set as the default filter. If **source** is specified, the frame's source IP address (**sip**) and port number (**sport**) are replaced with the **dip** and **dport** values. If **dest** is specified, the frame's destination IP address (**dip**) and port number (**dport**) are replaced with the **sip** and **sport** values.

vlan <VLAN ID (1 - 4095)> | **any**Sets the ID of the VLAN that is to be filtered. This option allows you to match the VLAN ID of the switch against the VLAN ID of the incoming packet. The default is **any**, which means the switch will match any VLAN ID of the incoming packet

This command allows filters to be configured on per VLAN basis, and applies a filter to a VLAN that already has been configured. A VLAN has a set of member ports. But by applying this filter to a VLAN, the filter does not get applied to all the member ports of this VLAN. You have to manually add the filter to the port.

inver **disable** | **enable**Inverts the filter logic. If the conditions of the filter are met, *don't* act. If the conditions for the filter are *not met*, perform the assigned action. This option is disabled by default.

Table 7-10 Filter Configuration Menu Options (/cfg/slb/filt)**Command Syntax and Usage****ena**

Enables this filter.

dis

Disables this filter.

del

Deletes this filter.

cur

Displays the current configuration of the filter.

Defining IP Address Ranges for Filters

You can specify a range of IP address for filtering both the source and/or destination IP address for traffic. When a range of IP addresses is needed, the `sip` (source) or `dip` (destination) defines the base IP address in the desired range, and the `smask` (source) or `dmask` (destination) is the mask which is applied to produce the range.

For example, to determine if a client request's destination IP address should be redirected to the cache servers attached to a particular switch, the destination IP address is masked (bitwise AND) with the `dmask` and then compared to the `dip`.

As another example, you could configure the switch with two filters so that each would handle traffic filtering for one half of the Internet. To do this, you could define the following parameters:

Table 7-11 Filtering IP Address Ranges

Filter	Internet Address Range	dip	dmask
#1	0.0.0.0 - 127.255.255.255	0.0.0.0	128.0.0.0
#2	128.0.0.0 - 255.255.255.255	128.0.0.0	128.0.0.0

`/cfg/slb/filt <filter number>/adv` Advanced Filter Configuration

```
[Filter 2 Advanced Menu]
tcp      - TCP Advanced Menu
ip       - IP Advanced Menu
layer7   - Layer 7 Advanced Menu
icmp     - Set ICMP message type
tmout    - Set NAT session timeout
idshash  - Set hash parameter for intrusion detection SLB
thash    - Set hash parameter for Filter
cache    - Enable/disable caching sessions that match filter
log      - Enable/disable logging
linklb   - Enable/disable WAN link load balancing
dbind    - Enable/disable delayed binding for redirection
proxy    - Enable/disable client proxy
cur      - Display current advanced filter configuration
```

Table 7-12 Advanced Filter Menu (`/cfg/slb/filt/adv`)

Command Syntax and Usage

`tcp`

Displays the TCP Flags Advanced Menu. To view menu options, see [page 279](#).

`ip`

Sets IP advanced menu. To view menu options, see [page 280](#).

`layer7`

Displays the Layer 7 Advanced Menu. To view menu options, see [page 281](#).

`icmp <number> | <type; "icmp list" for list> | any`

Sets the ICMP message type. The default is set at any. For a list of ICMP message types, see [Table 7-16 on page 282](#). For a detailed description of filtering and ICMP, see the *Alteon OS 20.2 Application Guide*.

`tmout <even number of minutes, 4-30>`

Sets the Network Address Translation (NAT) session timeout in an even number of minutes (4–30). The default is set at 4 minutes.

`idshash sip | dip | both`

Sets the hash metric parameter for Intrusion Detection System Server Load Balancing

Table 7-12 Advanced Filter Menu (/cfg/slb/filt/adv)

Command Syntax and Usage

thash auto | sip | dip | both | sip+sport

Allows you to choose hash parameter to use for filter redirection. The Default is `auto`. The `sip` option allows you to perform tunable hash on source IP address for this filter. The option `dip` allows you to perform tunable hash on destination IP address for this filter. The option `both` allows you to perform tunable hash on both source IP address and the destination IP address at the same time. The option `sip+sport` allows you to perform tunable hash on both source IP address and source port at the same time.

cache disable | enable

Enables or disables caching sessions that match the filter. Exercise caution while applying cache-enabled and cache-disabled filters to the same switch port. A cache-enabled filter creates a session entry in the switch, so that the switch can bypass checking for subsequent frames that match the same criteria. Cache is enabled by default.

Note: Cache should be disabled if applying a filter to virtual server IP address while performing UDP load balancing (see “[udp disable/enable/stateless](#)” on page 268).

log disable | enable

Enables or disables logging filter messages. This option is disabled by default.

linklb disable | enable

Enables or disables WAN Link Load Balancing. By default, this option is disabled.

dbind disable | enable

Enables or disables delayed binding for redirection on this filter.

proxy disable | enable

Enables or disables client proxy. This option applies only when `redir` or `nat` is specified as the filter action. Enable or disable proxy IP address translation for traffic matching the filter criteria. By default, this is enabled. If disabled, any proxy defined for the switch port using the `pip` command (see [page 283](#)) is not performed for traffic meeting the filter criteria. This is useful when certain traffic must retain original IP address information, or when other forms of translation (such as Application Redirection or NAT) are preferred.

cur

Displays the current advanced filter configuration.

`/cfg/slb/filt <filter number>/adv/tcp` Advanced Filter TCP Configuration

```
[TCP advanced menu Menu]
urg      - Enable/disable TCP URG matching
ack      - Enable/disable TCP ACK matching
psh      - Enable/disable TCP PSH matching
rst      - Enable/disable TCP RST matching
syn      - Enable/disable TCP SYN matching
fin      - Enable/disable TCP FIN matching
ackrst   - Enable/disable TCP ACK or RST matching
tcplim   - Enable/disable TCP connection rate limiting
maxconn  - Set maximum connections for TCP rate limiting
cur      - Display current TCP configuration
```

These commands can be used to configure packet filtering for specific TCP flags.

Table 7-13 Advanced Filter TCP Menu (`/cfg/slb/filt/adv/tcp`)

Command Syntax and Usage

urg `disable` | `enable`

Enables or disables TCP URG (urgent) flag matching. By default, this option is disabled.

ack `disable` | `enable`

Enables or disables TCP ACK (acknowledgement) flag matching. By default, this option is disabled.

psh `disable` | `enable`

Enables or disables TCP PSH (push) flag matching. By default, this option is disabled.

rst `disable` | `enable`

Enables or disables TCP RST (reset) flag matching. By default, this option is disabled.

syn `disable` | `enable`

Enables or disables TCP SYN (synchronize) flag matching. By default, this option is disabled.

fin `disable` | `enable`

Enables or disables TCP FIN (finish) flag matching. By default, this option is disabled.

ackrst `disable` | `enable`

Enables or disables TCP acknowledgement or reset flag matching. By default, this option is disabled.

tcplim `disable` | `enable`

Enables or disables TCP connection rate limiting. By default, this option is disabled.

Table 7-13 Advanced Filter TCP Menu (/cfg/slb/filt/adv/tcp)**Command Syntax and Usage****maxconn** <number of connections in units of 10 (0-255)>

Sets the maximum limit for new TCP connections in units of 10. To set the maximum number of connections (2,550), enter 250. To set the minimum number of connections (10, from the same user), enter 1.

The default is 10 (100 connections).

cur

Displays the current Access Control List TCP filter configuration.

/cfg/slb/filt <filter number> **/adv/ip****IP Advanced Menu**

```
[IP advanced menu]
  tos      - Set IP Type of Service
  tmask    - Set IP TOS mask
  newtos   - Set new IP TOS
  option   - Enable/disable IP option matching
  cur      - Display current IP configuration
```

Table 7-14 IP Advanced Menu Options (/cfg/slb/filt #/adv/ip)**Command Syntax and Usage****tos** <0-255>

Sets IP type of service (ToS) and the value of the type of service. For more information on ToS, refer to RFC 1340 and 1349.

tmask <0-255>

Sets IP type of service mask.

newtos <0-255>

Sets new IP type of service.

option **disable** | **enable**

Enables or disables IP option matching.

cur

Displays current advanced IP settings for the selected filter.

`/cfg/slb/filt <filter number> /adv/layer7` Layer 7 Advanced Menu

```
[Layer 7 Advanced Menu]
  addstr   - Add string for layer 7 filtering
  remstr   - Remove string for layer 7 filtering
  rdsnp    - Enable/disable WAP RADIUS Snooping
  ftpa     - Enable/disable active FTP NAT
  l7lkup   - Enable/disable Layer 7 content lookup
  cur      - Display current layer 7 configuration
```

Table 7-15 Layer 7 Advanced Menu Options (`/cfg/slb/filt #/adv/layer7`)

Command Syntax and Usage

addstr <string id (1-512)>

Adds the string ID to this filter for L7 filtering. The string is defined under: `/cfg/slb/layer7/slb/add`.

remstr <string id (1-512)>

Removes the string ID for Layer 7 filtering. The string is defined under: `/cfg/slb/layer7/slb/add`.

rdsnp **disable** | **enable**

Enables or disables WAP RADIUS Snooping capability of a filter. By default, this option is disabled.

ftpa **disable** | **enable**

Enables or disables active FTP Client Network Address Translation (NAT). When a client in active FTP mode sends a `PORT` command to a remote FTP server, the switch will look into the data part of the frame and replace the client's private IP address with a proxy IP (PIP) address. The real server port (RPORT) will be replaced with a proxy port (PPORT), that is `PIP:PPORT`. By default, this option is disabled.

l7lkup

Enable/disable Layer 7 content lookup.

cur

Displays current advanced Layer 7 settings for the selected filter.

ICMP Message Types

The following ICMP message types are used with the `/cfg/slb/filt/adv/icmp` command. You can list all ICMP message types with the `/cfg/slb/filt/adv/icmp list` command.

Table 7-16 ICMP Message Types

Type #	Message Type	Description
0	echorep	ICMP echo reply
3	destun	ICMP destination unreachable
4	quench	ICMP source quench
5	redir	ICMP redirect
8	echoreq	ICMP echo request
9	rtradv	ICMP router advertisement
10	rtrsol	ICMP router solicitation
11	timex	ICMP time exceeded
12	param	ICMP parameter problem
13	timereq	ICMP timestamp request
14	timerep	ICMP timestamp reply
15	inforeq	ICMP information request
16	inforep	ICMP information reply
17	maskreq	ICMP address mask request
18	maskrep	ICMP address mask reply

`/cfg/slb/port <port alias or number>` **Port SLB Configuration**

```
[SLB port INT1 Menu]
  client - Enable/disable client processing
  server - Enable/disable server processing
  rts    - Enable/disable RTS processing
  hotstan - Enable/disable hot-standby processing
  intersw - Enable/disable inter-switch processing
  proxy  - Enable/disable use of PIP for ingress traffic
  filt   - Enable/disable filtering
  add    - Add filter to port
  rem    - Remove filter from port
  idslb  - Enable/disable intrusion detection server load balancing
  cur    - Display current port configuration
```

Alteon OS switch software allows you to enable or disable processing independently for each type of Layer 4 traffic (client and server) on a *per port* basis, expanding your topology options.

NOTE – When changing the filters on a given port, it may take some time before the port session information is updated so that the filter changes take effect. To make port filter changes take effect immediately, clear the session binding table for the port (see the `clear` command in Table 8-3 on page 302).

Table 7-17 Port Configuration Menu Options (`/cfg/slb/port`)

Command Syntax and Usage

`client disable|enable`

For Server Load Balancing, the port can be enabled or disabled to process client Layer 4 traffic. Ports configured to process client request traffic bind servers to clients and provide address translation from the virtual server IP address to the real server IP address, re-mapping virtual server IP addresses and port values to real server IP addresses and ports. Traffic not associated with virtual servers is switched normally. Maximizing the number of these ports on the Layer 4 switch will improve the switch's potential for effective Server Load Balancing. This option is disabled by default.

`server disable|enable`

Ports configured to provide real server responses to client requests require real servers to be connected to the Layer 4 switch, directly or through a hub, router, or another switch. When server processing is enabled, the switch port re-maps real server IP addresses and Layer 4 port values to virtual server IP addresses and Layer 4 ports. Traffic not associated with virtual servers is switched normally. This option is disabled by default.

Table 7-17 Port Configuration Menu Options (/cfg/slb/port)

rts disable|enable

Enables or disables Return to Sender (RTS) load balancing on this port. This option is used for firewall load balancing or VPN load balancing applications. Enable `rts` on all client-side ports to ensure that traffic ingresses and egresses through the same port. This option is disabled by default.

For more information on using `rts`, see the “Firewall Load Balancing” and “VPN Load Balancing” chapters in the *Alteon OS 20.2 Application Guide*.

hotstan disable|enable

Enables or disables hot-standby processing. Use this option and the `intersw` option in conjunction with VRRP hot-standby failover. This option is disabled by default.

intersw disable|enable

Enables or disables inter-switch processing. This option is enabled for ports connected to a peer switch and is disabled by default.

proxy disable|enable

Enables or disables a proxy for traffic that ingresses this port. When the PIP is defined, client address information in Layer 4 requests is replaced with this proxy IP address.

In Server Load Balancing applications, this forces response traffic to return through the switch, rather than around it, as is possible in complex routing environments.

Proxies are also useful for Application Redirection and Network Address Translation (NAT).

When `pip` is used with Application Redirection filters, each filter’s `rport` parameter must also be defined (see `rport` on [page 273](#)). This option is disabled by default.

filt disable|enable

Enables or disables filtering on this port. Enabling the filter sets up the Real Server to look into the VPN session table. This option is disabled by default.

add <filter ID (1 to 1024) | block of IDs (first-last)>

Adds a filter or a block of filters for use on this port. Enter filter ID (1 to 1024) or a contiguous block of filter IDs. For example, 1-100.

rem <filter ID (1 to 1024) | block of IDs (first-last)>

Removes a filter or a block of filters from use on this port. Enter filter ID (1 to 1024) or a contiguous block of filter IDs. For example, 1-100.

idslb disable|enable

Enables or disables Intrusion Detection System Server Load Balancing for this port. This option is disabled by default.

cur

Displays current system parameters.

/cfg/slb/layer7

Layer 7 SLB Resource Definition Menu

```
[Layer 7 Resource Definition Menu]
  redir   - Web Cache Redirection Menu
  slb     - Server Load Balancing Menu
  dbindtm - Set timeout for incomplete delayed binding connections
  cur     - Display current Layer 7 configuration
```

Table 7-18 Layer 7 Resource Definition Menu Options (/cfg/slb/layer7)

Command Syntax and Usage

redir

Displays the Web Cache Redirection Menu. To view menu options, see [page 286](#).

slb

Displays the Server Load Balancing Menu. To view menu options, see [page 287](#).

dbindtm <10-60 seconds>

Sets the timeout for incomplete delayed binding connections.

cur

Displays the current Layer 7 configuration.

/cfg/slb/layer7/redirect

Web Cache Redirection Configuration

[Web Cache Redirection Menu]	
urlal	- Enable/disable auto-ALLOW for non-GETs to origin servers
cookie	- Enable/disable auto-ALLOW for Cookie to origin servers
nocache	- Enable/disable no-cache control header to origin servers
hash	- Enable/disable URL hashing based on URI
header	- Enable/disable server loadbalance based on HTTP header
cur	- Display current WCR configuration

Table 7-19 Web Cache Redirection Menu Options (/cfg/slb/layer7/redirect)

Command Syntax and Usage

urlal **disable** | **enable**

Enables or disables auto-ALLOW for non-GETs to origin servers.

- If this command is enabled, the switch will redirect all non-GET requests to the origin server.
- If this command is disabled, the switch will compare the URI against the expression table to determine whether all non-GET requests should be redirected to a cache server or origin server.

This option is enabled by default.

cookie **disable** | **enable**

Enables or disables auto-ALLOW for cookie to origin servers.

- If this command is enabled, the switch will redirect all requests that contain *Cookie:* in the HTTP header to the origin server.
- If this command is disabled, the switch will compare the URI against the expression table to determine whether it should redirect all requests that contain *Cookie:* in the HTTP header to a cache server or origin server.

This option is disabled by default.

nocache **disable** | **enable**

Enables or disables no-cache control header to origin servers.

- If this command is enabled, the switch will redirect all requests that contain *Cache-Control: no-cache* in HTTP/1.1 header, or *Pragma: no-cache* in HTTP/1.0 header to the origin server.
- If this command is disabled, the switch will compare the URI against the expression table to determine whether it should redirect requests that contain *Cache-Control: no-cache* in HTTP/1.1 header, or *Pragma: no-cache* in HTTP/1.0 header to a cache server or origin server.

This option is enabled by default.

hash **disable** | **enable** <number (1-255)>

Enables or disables URL hashing based on the URI.

- If hashing is enabled, you can set the length of URI that will be used to hash into the cache server.
- If hashing is disabled, the switch will only use the host header field to calculate the hash key.

This option is disabled by default.

Table 7-19 Web Cache Redirection Menu Options (/cfg/slb/layer7/redirect)

Command Syntax and Usage

header *disable* | *enable*

Enables or disables server load balancing based on HTTP header. This option is disabled by default.

cur

Displays the current URL expression table.

/cfg/slb/layer7/slb

Server Load Balance Resource Configuration Menu

```
[Server Loadbalance Resource Menu]
message - Set HTTP error message
addstr  - Add SLB string for load balance
remstr  - Remove SLB string for load balance
rename  - Rename SLB string for load balance
addmeth - Add HTTP method type
remmeth - Remove HTTP method type
cur     - Display current configuration
```

Table 7-20 Server Load Balance Resource Menu Options (/cfg/slb/layer7/slb)

Command Syntax and Usage

message <64 byte error message>

Sets the message that will be displayed when an error occurs. The default message is “No available server to handle this request.”

addstr <SLB string>

Adds the SLB string for load balancing.

remstr <SLB string>

Removes the SLB string for load balancing.

rename <SLB string ID> <SLB string>

Renames the SLB string for load balancing.

Table 7-20 Server Load Balance Resource Menu Options (/cfg/slb/layer7/slb)**Command Syntax and Usage****addmeth** <Method, 1-32>

Allows you to add HTTP request methods of maximum 32 characters to your switch software. HTTP allows an open-ended set of methods to be used to indicate the purpose of a request. Alteon OS 20.2 supports 22 request methods by default. The methods GET and HEAD *must* be supported by all general-purpose servers. All other methods are optional.

You can see a list of supported default methods by using the command `cur` in this menu.

A method is case-sensitive.

The software supports both HTTP 1.0 and HTTP 1.1 to perform HTTP request methods.

remmeth <Method ID>

Allows you to remove HTTP methods from your switch software.

cur

Displays the current configuration of SLB string.

/cfg/slb/wap

WAP Configuration

```
[WAP Options Menu]
  tpcp      - Enable/disable WAP TPCP external notification
  debug     - WAP debug level
  cur       - Display current WAP configuration
```

Table 7-21 WAP Configuration Menu Options (/cfg/slb/wap)**Command Syntax and Usage****tpcp** **disable** | **enable**

Enables or disables the TPCP external notification for Add/Delete session requests. This option is disabled by default.

debug <wap debug level (0-9)>

Sets the debug level for tracing the WAP related messages. The default is set at 0.

cur

Displays the current WAP configuration

/cfg/slb/sync

Synchronize Peer Switch Configuration

```
[Config Synchronization Menu]
peer      - Synch peer switch menu
filt      - Enable or disable syncing filter configuration
ports     - Enable or disable syncing port configuration
prios     - Enable or disable syncing VRRP priorities
pips      - Enable or disable syncing proxy IP addresses
reals     - Enable/disable syncing real server configuration
state     - Enable or disable syncing persistent session state
update    - Set stateful failover update period
cur       - Display current Layer 4 sync configuration
```

To synchronize the configuration between two switches, a peer must be configured and enabled on each switch. Switches being synchronized must use the same administrator password. Peers are sent SLB, FILT, and VRRP configuration updates using `/oper/slb/synch`.

Table 7-22 Synchronization Menu Options (`/cfg/slb/sync`)

Command Syntax and Usage

peer <peer switch number (1-2)>

Displays the Sync Peer Switch Menu. This option is enabled by default. To view menu options, see [page 290](#).

filt **disable** | **enable**

Enables or disables synchronizing filter configuration.

ports **disable** | **enable**

Enables or disables synchronizing Layer 4 port configuration. This option is enabled by default.

prios **disable** | **enable**

Enables or disables syncing VRRP priorities. This option is enabled by default.

pips **disable** | **enable**

Enables or disables synchronizing proxy IP addresses. This option is disabled by default.

reals

Enables or disables synchronizing real server configuration. This option is disabled by default.

state **disable** | **enable**

Enables or disables stateful failover for synchronizing the persistent session state. This option is disabled by default.

Table 7-22 Synchronization Menu Options (/cfg/slb/sync)**Command Syntax and Usage****update** <seconds, 1–60>

Sets the stateful failover update interval. The active server sends update packets of persistent binding entries to the backup switch at the specified update interval. The default value is 30 seconds.

cur

Displays the current Layer 4 synchronization configuration.

/cfg/slb/sync/peer <peer switch number> **Peer Switch Configuration**

```
[Peer Switch 1 Menu]
addr    - Set peer switch IP address
ena     - Enable peer switch
dis     - Disable peer switch
del     - Delete peer switch
cur     - Display current peer switch configuration
```

To synchronize the configuration between two switches, a peer must be configured and enabled on each switch. Switches being synchronized must use the same administrator password.

Table 7-23 Peer Switch Configuration Menu Options (/cfg/slb/sync/peer)**Command Syntax and Usage****addr** <IP address>

Sets the peer switch IP address. The default is 0.0.0.0

ena

Enables the peer for this switch. By default, this option is disabled.

dis

Disables the peer for this switch.

del

Deletes the peer for this switch

cur

Displays the current peer switch configuration.

/cfg/slb/adv

Advanced Layer 4 Configuration

```
[Layer 4 Advanced Menu]
  synatk    - SYN Attack Detection Menu
  imask     - Set virtual and real IP address mask
  mnet      - Set management network
  mmask     - Set management subnet mask
  pmask     - Set persistent mask
  timewin   - Set time window for TCP rate limiting
  holddur   - Set hold down duration for TCP rate limiting
  submac    - Enable/Disable Source MAC address substitution
  direct    - Enable/disable Direct Access Mode
  grace     - Enable/disable graceful real server failure
  matrix    - Enable/disable Virtual Matrix Architecture
  tpcp      - Enable/disable Transparent Proxy Cache Protocol
  fastage   - Session table fast-age (1sec) period bit shift
  slowage   - Session table slow-age (2 min) period bit shift
  cur       - Display current Layer 4 advanced configuration
```

Table 7-24 Layer 4 Advanced Menu Options (/cfg/slb/adv)

Command Syntax and Usage

synatk

Displays SYN Attack Detection Menu. To view menu options, see [page 293](#).

imask <IP subnet mask (such as 255.255.255.0)>

Configures the real and virtual server IP address mask using dotted decimal notation. The default is 255.255.255.255.

mnet <IP address>

If defined, management traffic with this source IP address will be allowed direct (non-Layer 4) access to the real servers. Specify an IP address in dotted decimal notation. A range of IP addresses is produced when used with the `mmask` option.

mmask <IP subnet mask (such as 255.255.255.0)>

This IP address mask is used with the `mnet` to select management traffic which is allowed direct access to real servers. The default is 255.255.255.255.

pmask <IP subnet mask (such as 255.255.255.0)>

Sets persistent mask. The default is 255.255.255.255.

Table 7-24 Layer 4 Advanced Menu Options (/cfg/slb/adv)

Command Syntax and Usage

timewin <multiple of fastage period (1-65535)>

Sets the parameter for time window for TCP rate limiting, which is a multiple of the `fastage` period. For example, if the `fastage` parameter is 2 seconds, and the `timewin` is 3, then the resulting time window is 6 seconds.

holddur <multiple of slowage period (1-65535)>

This command configures the hold down duration, which is a multiple of `slowage`. Hold down (blocking of new TCP connections) occurs when the number of received SYN packets exceeds the threshold of a pre-defined time window. For example, the parameter of `slowage` is 2 minutes, and `holddur` is 5, then the resulting hold down duration is 10 minutes.

submac **disable** | **enable**

Enables or disables Source MAC address substitution. Typically, the source MAC is not modified for the packets going to the servers in an SLB environment. But if you enable this command, the switch will substitute the source MAC address (for the packets going to the server) with the mac address of the switch.

direct **disable** | **enable**

Enable/disables Direct Access Mode to real servers/services. This option also allows any virtual server to load balance any real server. By default, this option is disabled.

grace **disable** | **enable**

Enables or disables graceful real server failure. Allows existing connections to newly failed server to gracefully continue. By default, this option is disabled.

matrix **disable** | **enable**

Enables or disables the use of Virtual Matrix Architecture on the GbE Switch Module. By default, this option is enabled.

tcp **disable** | **enable**

Enables or disables the TPCP (Transparent Proxy Cache Protocol). This command is used for security reasons—the UDP port can be closed. By default, this option is disabled.

fastage <shift the fast-age (1sec) period 0-7 bits>

Controls how frequently a *fastage scan* is performed. The default interval is two seconds. Each incremental increase of the value doubles the length of the interval.

The *fastage scan* is used to remove TCP sessions that have been closed with a FIN and sessions that have been identified by the `slowage` scan as idle for the maximum allowed period. If a large value of `fastage` is used, a session can remain in the session table for a few minutes. The default is 0.

Table 7-24 Layer 4 Advanced Menu Options (/cfg/slb/adv)**Command Syntax and Usage**

slowage <shift the slow-age (2min) period 0-15 bits>

Controls how frequently a *slowage scan* is performed. The default interval is two minutes. Each incremental increase of the value doubles the length of the interval. (Value is set in bits rather than seconds, which causes the time to double per increment).

The `slowage` scan is used to remove idle or non-TCP sessions from the session at the specified intervals. If a large value of `slowage` is used, a session can remain in the session table for months. The default is 0.

cur

Displays the current Layer 4 advanced configuration.

/cfg/slb/adv/synatk

SYN Attack Detection Configuration

[SYN Attack Detection Menu]

`interval` - Set SYN attack detection interval

`thrshld` - Set SYN attack alarm threshold

`cur` - Display current SYN attack detection configuration

Table 7-25 SYN Attack Detection Menu Options (/cfg/slb/adv/synatk)**Command Syntax and Usage**

interval <SYN attack check interval in seconds (2-3600)>

Sets the interval of SYN attack inspection.

thrshld <SYN attack alarm threshold (new half-open sessions/second) (1-100000)>

Sets the threshold of SYN attack alarm.

cur

Displays the current SYN attack detection configuration.

/cfg/slb/advhc

Advanced Layer 4 Health Check

```
[Layer 4 Advanced Health Check Menu]
script      - Scriptable Health Check Menu
waphc      - WAP Health Check Menu
aphttp     - Enable/disable Allow HTTP Health Check on any port
ldapver    - LDAP version
secret     - Set RADIUS secret
minter     - Set interval of response and bandwidth metric updates
cur        - Display current Layer 4 advanced health check
             configuration
```

Table 7-26 Advanced Health Check Menu Options (/cfg/slb/advhc)

Command Syntax and Usage

script <health script number (1-8)>

Displays the Scriptable Health Check Menu. To view menu options, see [page 295](#).

waphc

Displays the WAP Health Check Menu. To view menu options, see [page 296](#).

aphttp **disable** | **enable**

Enables or disables HTTP health checks on any port. By default, this option is disabled. When disabled, you can use HTTP health checks only for HTTP service. Enabling it will allow you to use it on any port, like HTTPs.

ldapver <LDAP version>

Sets the LDAP version to 2 or 3. The default is 2.

secret <1-32 character secret>

To perform application health checking to a RADIUS server, the network administrator must configure two parameters in the switch: the /cfg/slb/advhc/secret value and the cntnt parameter with a *username:password* value. The secret value is a field of up to 32 alphanumeric characters that is used by the switch to encrypt a password during the RSA Message Digest Algorithm (MD5) and by the RADIUS server to decrypt the password during verification. The default is **none**.

minter <number of seconds between updates (1-256)>

This command sets the interval of response and bandwidth metric updates. The default is set at 10.

cur

Displays the current Layer 4 advanced health check configuration.

`/cfg/slb/advhc/script <health script number>`

Scriptable Health Checks Configuration

```
[Health Script 1 Menu]
  open   - Add open command to end of script
  send   - Add send command to end of script
  expect - Add expect command to end of script
  close  - Add close command to end of script
  rem    - Remove last command from script
  del    - Delete script
  cur    - Display current script configuration
```

The Health Script menu provides commands that can be used to define the health “script.” The total number of characters cannot exceed 1024 bytes. Up to eight scripts can be configured.

Table 7-27 Scriptable Health Check Menu Options (`/cfg/slb/advhc/script`)

Command Syntax and Usage

open *<real port or name (such as: http)>*

Sets the TCP port to be opened.

send *<text string>*

Sends an ASCII string through open TCP port. For example, an HTTP request, such as,
 "GET /default.asp HTTP/1.1\r\nHOST:
 www.alteon.com\r\n\r\n."

expect *<text string>*

Expects an ASCII string for successful health check on open TCP port, such as an HTTP response:
 HTTP/1.1 200

close

Closes TCP connection.

rem

Removes the last entered line from the script.

del

Deletes the current script.

cur

Lists the current script configuration.

/cfg/slb/advhc/waphc

WAP Health Check Configuration

```
[WAP Health Check Menu]
  wssport - WSP port number to health check
  wtlsprt - WTLS port number to health check
  offset  - Offset in received WSP packet
  sndcnt  - Content to be sent to the WAP gateway
  rcvcnt  - Content to be received from the WAP gateway
  cur     - Display current WAP health check configuration
```

Table 7-28 WAP Health Check Menu Options (/cfg/slb/advhc/waphc)

Command Syntax and Usage

wssport <port number (0-65534)>

Enter the port number on which WSP health checks will be performed. The default port number is 9200.

wtlsprt <port number (0-65534)>

Enter the port number on which WTLS health checks will be performed. The default port number is 9203.

offset <Offset in the received WSP packet (0-256)>

Enter the offset value content of the received WSP packages. An offset value of 0 (default) sets the switch to start comparisons from the beginning of the content of the received packet.

sndcnt <send content as a hexadecimal string>

Enter a hexadecimal string that represents a connectionless WSP request to a WSP gateway. This string will be delivered to the WSP gateway.

rcvcnt <receive content as a hexadecimal string>

Enter a hexadecimal string that represents the content that the switch expects to receive from the WSP gateway.

cur

Displays the current WAP Health Check configuration.

/cfg/slb/pip

Proxy IP Address Configuration Menu

```
[Proxy IP Address Menu]
  pip1    - Set Proxy IP address for odd-numbered ports
  pip2    - Set Proxy IP address for even-numbered ports
  cur     - Display current Proxy IP address configuration
```

Table 7-29 Proxy IP Address Configuration Menu Options (/cfg/slb/pip)

Command Syntax and Usage

pip1 <IP address>

Sets the proxy IP address for odd-numbered ports using dotted decimal notation. When the `pip` is defined, client address information in Layer 4 requests is replaced with this proxy IP address.

pip2 <IP address>

Sets the proxy IP address for even-numbered ports.

cur

Display current Proxy IP address configuration.

/cfg/slb/peerpip

SLB Peer Proxy IP Address Configuration Menu

When this command is enabled, the switch is able to forward traffic from the other switch, using Layer 2, without performing server processing on the packets of the other switch. This happens because the peer switches are aware of each other's proxy IP addresses. This prevents the dropping of a packet or being sent to the backup switch in the absence of the proxy IP address of the peer switch.

[Peer Proxy IP Address Menu]	
add	- Add peer Proxy IP address
rem	- Rem peer Proxy IP address
cur	- Display current peer Proxy IP address configuration

Table 7-30 Proxy IP Address Configuration Menu Options (/cfg/slb/peerpip)

Command Syntax and Usage

add <IP address>

Allows you to add a proxy IP address to the server load balancing peer.

remove <IP address>

Allows you to remove a proxy IP address from the server load balancing peer.

cur

Displays the current proxy address configuration of the peer.

CHAPTER 8

The Operations Menu

The Operations Menu is generally used for commands that affect switch performance immediately, but do not alter permanent switch configurations. For example, you can use the Operations Menu to immediately disable a port (without the need to apply or save the change), with the understanding that when the switch is reset, the port returns to its normally configured operation.

/oper

Operations Menu

```
[Operations Menu]
port      - Operational Port Menu
slb       - Operational Server Load Balancing Menu
vrrp      - Operational Virtual Router Redundancy Menu
ip        - Operational IP Menu
clrlog    - Clear syslog messages
```

The commands of the Operations Menu enable you to alter switch operational characteristics without affecting switch configuration.

Table 8-1 Operations Menu Options (/oper)

Command Syntax and Usage

port <port alias or number>

Displays the Operational Port Menu. To view menu options, see [page 301](#).

slb

Displays the Operational Layer 4 Menu. To view menu options, see [page 302](#).

vrrp

Displays the Operational Virtual Router Redundancy Menu. To view menu options, see [page 303](#).

Table 8-1 Operations Menu Options (/oper)

Command Syntax and Usage

ip

Displays the IP Operations Menu, which has one sub-menu/option, the Operational Border Gateway Protocol Menu. To view menu options, see [page 303](#).

clrlog

Clears all Syslog messages.

`/oper/port` *<port alias or number>* **Operations-Level Port Options**

[Operations Port INT1 Menu]	
<code>rmon</code>	- Enable/Disable RMON for port
<code>ena</code>	- Enable port
<code>dis</code>	- Disable port
<code>cur</code>	- Current port state

Operations-level port options are used for temporarily disabling or enabling a port, and for changing Remote Monitoring (RMON) status on a port.

Table 8-2 Operations-Level Port Menu Options (`/oper/port`)

Command Syntax and Usage

`rmon disable | enable`

Temporarily enables/disables Remote Monitoring on the port. The port will be returned to its configured operation mode when the switch is reset.

`ena`

Temporarily enables the port. The port will be returned to its configured operation mode when the switch is reset.

`dis`

Temporarily disables the port. The port will be returned to its configured operation mode when the switch is reset.

`cur`

Displays the current settings for the port.

/oper/slb

Operations-Level SLB Options

[Server Load Balancing Operations Menu]	
sync	- Synchronize SLB, VRRP and other configurations on peers
ena	- Enable real server
dis	- Disable real server
clear	- Clear session table
cur	- Current layer 4 operational state

When the optional Layer 4 software is enabled, the operations-level Server Load Balancing options are used for temporarily disabling or enabling real servers and synchronizing the configuration between the active/active switches.

Table 8-3 Server Load Balancing Operations Menu Options (/oper/slb)

Command Syntax and Usage

sync

Synchronizes the SLB, filter, VRRP, port, and VR priorities on a peer switch (a switch that owns the IP address). To take effect, peers must be configured on the GbE Switch Module and the administrator password on the switch must be identical.

ena <real server number (1-63)>

Temporarily enables a real server. The real server will be returned to its configured operation mode when the switch is reset.

dis <real server number (1-63)> p | n

The disable command is used to temporarily disable real servers as follows:

- Using the **n** (none) option, disables the real server entirely, removing it from operation within its real server group and virtual server
- Using the **p** (persistent) option, temporarily disables sessions except for persistent http 1.0 sessions.

The real server will be returned to its configured operation mode when the switch is reset.

clear

Clears all session tables and allows port filter changes to take effect immediately.

Note: This command disrupts current Server Load Balancing and Application Redirection sessions.

cur

Displays the current SLB operational state.

/oper/vrrp

Operations-Level VRRP Options.

```
[VRRP Operations Menu]
  back    - Set virtual router to backup
```

Table 8-4 Virtual Router Redundancy Operations Menu Options (/oper/vrrp)

Command Syntax and Usage

back <virtual router number (1-128)>

Forces the specified master virtual router on this switch into backup mode. This is generally used for passing master control back to a preferred switch once the preferred switch has been returned to service after a failure. When this command is executed, the current master gives up control and initiates a new election by temporarily advertising its own priority level as 0 (lowest). After the new election, the virtual router forced into backup mode by this command will resume master control in the following cases:

- This switch owns the virtual router (the IP addresses of the virtual router and its IP interface are the same)
 - This switch's virtual router has a higher priority and preemption is enabled.
 - There are no other virtual routers available to take master control.
-

/oper/ip

Operations-Level IP Options

```
[IP Operations Menu]
  bgp     - Operational Border Gateway Protocol Menu
```

Table 8-5 IP Operations Menu Options (/oper/ip)

Command Syntax and Usage

bgp

Displays the Border Gateway Protocol Operations Menu. To view the menu options see [page 304](#).

/oper/ip/bgp

Operations-Level BGP Options

[Border Gateway Protocol Operations Menu]	
start	- Start peer session
stop	- Stop peer session
current	- Current BGP operational state

Table 8-6 IP Operations Menu Options (/oper/ip)

Command Syntax and Usage

start <peer number (1-16)>

Starts the peer session.

stop <peer number (1-16)>

Stops the peer session.

cur

Displays the current BGP operational state.

CHAPTER 9

The Boot Options Menu

To use the Boot Options Menu, you must be logged in to the switch as the administrator. The Boot Options Menu provides options for:

- Selecting a switch software image to be used when the switch is next reset
- Selecting a configuration block to be used when the switch is next reset
- Downloading or uploading a new software image to the switch via TFTP

In addition to the Boot Menu, you can use SNMP to work with switch image and configuration files. Refer to [“Working with Switch Images and Configuration Files” on page 340](#).

/boot

Boot Menu

```
[Boot Options Menu]
  image - Select software image to use on next boot
  conf  - Select config block to use on next boot
  gtimg - Download new software image via TFTP
  ptimg - Upload selected software image via TFTP
  reset - Reset switch [WARNING: Restarts Spanning Tree]
  cur   - Display current boot options
```

Each of these options is discussed in greater detail in the following sections.

Updating the Switch Software Image

The switch software image is the executable code running on the GbE Switch Module. A version of the image ships with the switch, and comes pre-installed on the device. As new versions of the image are released, you can upgrade the software running on your switch. To get the latest version of software available for your GbE Switch Module, go to:

`http://www.ibm.com/pc/support`

Click on software updates. Use `/boot/cur` to determine the current software version.

Upgrading the software image on your switch requires the following:

- Loading the new image onto a TFTP server on your network
- Downloading the new image from the TFTP server to your switch
- Selecting the new software image to be loaded into switch memory the next time the switch is reset

Downloading New Software to Your Switch

The switch can store up to two different software images, called `image1` and `image2`, as well as boot software, called `boot`. When you download new software, you must specify where it should be placed: either into `image1`, `image2`, or `boot`.

For example, if your active image is currently loaded into `image1`, you would probably load the new image software into `image2`. This lets you test the new software and reload the original active image (stored in `image1`), if needed.

To download a new software to your switch, you will need the following:

- The image or boot software loaded on a TFTP server on your network
- The hostname or IP address of the TFTP server
- The name of the new software image or boot file

NOTE – The DNS parameters must be configured if specifying hostnames. See “Domain Name System Configuration” on page 234.

When the above requirements are met, use the following procedure to download the new software to your switch.

1. At the `Boot Options#` prompt, enter:

```
Boot Options# gting
```

2. Enter the name of the switch software to be replaced:

```
Enter name of switch software image to be replaced  
["image1"/"image2"/"boot"]: <image>
```

3. Enter the hostname or IP address of the TFTP server.

```
Enter hostname or IP address of TFTP server: <server name or IP address>
```

4. Enter the name of the new software file on the server.

```
Enter name of file on TFTP server: <filename>
```

The exact form of the name will vary by TFTP server. However, the file location is normally relative to the TFTP directory (usually `/tftpboot`).

5. The system prompts you to confirm your request.

You should next select a software image to run, as described below.

Selecting a Software Image to Run

You can select which software image (`image1` or `image2`) you want to run in switch memory for the next reboot.

1. At the `Boot Options#` prompt, enter:

```
Boot Options# image
```

2. Enter the name of the image you want the switch to use upon the next boot.

The system informs you of which image is currently set to be loaded at the next reset, and prompts you to enter a new choice:

```
Currently set to use switch software "image1" on next reset.  
Specify new image to use on next reset ["image1"/"image2"]:
```

Uploading a Software Image from Your Switch

You can upload a software image from the switch to a TFTP server.

1. **At the Boot Options# prompt, enter:**

```
Boot Options# ptimg
```

2. **The system prompts you for information. Enter the desired image:**

```
Enter name of switch software image to be uploaded  
["image1"|"image2"|"boot"]: <image> <hostname or server-IP-addr> <server-file-  
name>
```

3. **Enter the name or the IP address of the TFTP server:**

```
Enter hostname or IP address of TFTP server: <server name or IP address>
```

4. **Enter the name of the file into which the image will be uploaded on the TFTP server:**

```
Enter name of file on TFTP server: <filename>
```

5. **The system then requests confirmation of what you have entered. To have the file uploaded, enter Y.**

```
image2 currently contains Software Version 20.0.1.0  
Upload will transfer image2 (1889411 bytes) to file "test"  
on TFTP server 192.1.1.1.  
Confirm upload operation [y/n]: y
```

Selecting a Configuration Block

When you make configuration changes to the GbE Switch Module, you must save the changes so that they are retained beyond the next time the switch is reset. When you perform the `save` command, your new configuration changes are placed in the *active* configuration block. The previous configuration is copied into the *backup* configuration block.

There is also a *factory* configuration block. This holds the default configuration set by the factory when your GbE Switch Module was manufactured. Under certain circumstances, it may be desirable to reset the switch configuration to the default. This can be useful when a custom-configured GbE Switch Module is moved to a network environment where it will be re configured for a different purpose.

Use the following procedure to set which configuration block you want the switch to load the next time it is reset:

1. **At the `Boot Options#` prompt, enter:**

```
Boot Options# conf
```

2. **Enter the name of the configuration block you want the switch to use:**

The system informs you of which configuration block is currently set to be loaded at the next reset, and prompts you to enter a new choice:

```
Currently set to use active configuration block on next reset.  
Specify new block to use ["active"/"backup"/"factory"]:
```

Resetting the Switch

You can reset the switch to make your software image file and configuration block changes occur.

NOTE – Resetting the switch causes the Spanning Tree Group to restart. This process can be lengthy, depending on the topology of your network.

NOTE – Resetting the switch causes the date and time to revert to default values. Use `/cfg/sys/date` and `/cfg/sys/time` to reenter the current date and time.

To reset the switch, at the `Boot Options#` prompt, enter:

```
>> Boot Options# reset
```

You are prompted to confirm your request.

CHAPTER 10

The Maintenance Menu

The Maintenance Menu is used to manage dump information and forward database information. It also includes a debugging menu to help with troubleshooting.

/maint Maintenance Menu

NOTE – To use the Maintenance Menu, you must be logged in to the switch as the administrator.

```
[Maintenance Menu]
  sys      - System Maintenance Menu
  fdb      - Forwarding Database Manipulation Menu
  arp      - ARP Cache Manipulation Menu
  route    - IP Route Manipulation Menu
  igmp     - IGMP Multicast Menu
  debug    - Debugging Menu
  uudmp    - Uuencode FLASH dump
  ptdmp    - tftp put FLASH dump to tftp server
  cldmp    - Clear FLASH dump
  lsdmp    - List FLASH dump
  panic    - Dump state information to FLASH and reboot
  tsdmp    - Tech support dump
```

Dump information contains internal switch state data that is written to flash memory on the GbE Switch Module after any one of the following occurs:

- The switch administrator forces a switch *panic*. The `panic` option, found in the Maintenance Menu, causes the switch to dump state information to flash memory, and then causes the switch to reboot.
- The watchdog timer forces a switch reset. The purpose of the watchdog timer is to reboot the switch if the switch software freezes.
- The switch detects a hardware or software problem that requires a reboot.

Table 10-1 Maintenance Menu Options (/maint)

Command Syntax and Usage

sys

Displays the System Maintenance Menu. To view menu options, see [page 313](#).

fdb

Displays the Forwarding Database Manipulation Menu. To view menu options, see [page 313](#).

arp

Displays the ARP Cache Manipulation Menu. To view menu options, see [page 316](#).

route

Displays the IP Route Manipulation Menu. To view menu options, see [page 317](#).

igmp

Displays the IGMP Maintenance Menu.

debug

Displays the Debugging Menu. To view menu options, see [page 315](#).

uudmp

Displays dump information in uuencoded format. For details, see [page 321](#).

ptdmp hostname, filename [-mgmt|-data]

Saves the system dump information via TFTP. For details, see [page 322](#).

cldmp

Clears dump information from flash memory. For details, see [page 322](#).

lsdmp

Displays list flash dump.

panic

Dumps MP information to FLASH and reboots. For details, see [page 323](#).

tsdmp

Dumps all GbE Switch Module information, statistics, and configuration. You can log the tsdump output into a file.

/maint/sys

System Maintenance Options

This menu is reserved for use by IBM Service Support. The options are used to perform system debugging.

```
[System Maintenance Menu]
  flags    - Set NVRAM flag word
```

Table 10-2 System Maintenance Menu Options (/maint/sys)

Command Syntax and Usage

flags <new NVRAM flags word as 0XXXXXXXXX>

This command sets the flags that are used for debugging purposes by Tech support group.

/maint/fdb

Forwarding Database Options

```
[FDB Manipulation Menu]
  find    - Show a single FDB entry by MAC address
  port    - Show FDB entries for a single port
  trunk   - Show FDB entries on a single trunk
  vlan    - Show FDB entries for a single VLAN
  refpt   - Show FDB entries referenced by a single port
  dump    - Show all FDB entries
  del     - Delete an FDB entry
  clear   - Clear entire FDB
```

The Forwarding Database Manipulation Menu can be used to view information and to delete a MAC address from the forwarding database or clear the entire forwarding database. This is helpful in identifying problems associated with MAC address learning and packet forwarding decisions.

Table 10-3 FDB Manipulation Menu Options (/maint/fdb)

Command Syntax and Usage

find <MAC address> [<VLAN>]

Displays a single database entry by its MAC address. You are prompted to enter the MAC address of the device. Enter the MAC address using the `xx:xx:xx:xx:xx:xx` format (such as `08:00:20:12:34:56`) or `xxxxxxxxxxxx` format (such as `080020123456`).

port <port alias or number, 0 for unknown>>

Displays all FDB entries for a particular port. Use “0” for unknown port number.

trunk

Displays all FDB entries on a single trunk.

vlan <VLAN number (1-4095)>

Displays all FDB entries on a single VLAN.

refpt <SP number (1-4)>

Displays all FDB entries reference by a single port.

dump

Displays all entries in the Forwarding Database. For details, see [page 59](#).

del <MAC address> [<VLAN>]

Removes a single FDB entry.

clear

Clears the entire Forwarding Database from switch memory.

/maint/debug

Debugging Options

```
[Miscellaneous Debug Menu]
  tbuf      - Show MP trace buffer
  sptb     - Show SP trace buffer
  spall    - Show All SP trace buffers
  clrcfg   - Clear all flash configs
  vmasp    - Show designated SP for IP address
```

The Miscellaneous Debug Menu displays trace buffer information about events that can be helpful in understanding switch operation. You can view the following information using the debug menu:

- Events traced by the Management Processor (MP)
- Events traced by the Switch Processor (SP)
- Events traced to a buffer area when a reset occurs

If the switch resets for any reason, the MP trace buffer and SP trace buffers are saved into the snap trace buffer area. The output from these commands can be interpreted by IBM Service Support.

Table 10-4 Miscellaneous Debug Menu Options (/maint/debug)

Command Syntax and Usage

tbuf

Displays the Management Processor trace buffer. Header information similar to the following is shown:
 MP trace buffer at 13:28:15 Fri May 25, 2001; mask: 0x2ffdf748
 The buffer information is displayed after the header.

snap

Displays the Management Processor snap (or post-mortem) trace buffer. This buffer contains information traced at the time that a reset occurred.

sptb <port number (1-4)>

Displays the Switch Processor trace buffer. Header information similar to the following is shown:
 SP 1 trace buffer at 10:56:35 Tue Jul 30, 2002; mask: 0x00800008
 The buffer information is displayed after the header.

spall

Displays the Switch Processor trace buffer. Header information similar to the following is shown:
 SP 1 trace buffer at 10:56:35 Tue Jul 30, 2002; mask: 0x00800008.
 The buffer information is displayed after the header. Displays all SP trace buffers.

clrcfg

Deletes all flash configuration blocks.

Table 10-4 Miscellaneous Debug Menu Options (/maint/debug)

Command Syntax and Usage

vmasp <IP address>Displays the assigned SP (Switch Processor) for this IP address.

/maint/arp

ARP Cache Options

```
[Address Resolution Protocol Menu]
  find      - Show a single ARP entry by IP address
  port      - Show ARP entries on a single port
  vlan      - Show ARP entries on a single VLAN
  refpt     - Show ARP entries referenced by a single port
  dump      - Show all ARP entries
  add       - Add a permanent ARP entry
  del       - Delete an ARP entry
  clear     - Clear ARP cache
  addr      - Show ARP address list
```

Table 10-5 Address Resolution Protocol Menu Options (/maint/arp)**Command Syntax and Usage****find** <IP address (such as, 192.4.17.101)>

Shows a single ARP entry by IP address.

port <port alias or number>

Shows ARP entries on a single port.

vlan <VLAN number>

Shows ARP entries on a single VLAN.

refpt <SP number (1-4)>

Shows all ARP entries referenced by a single port.

dump

Shows all ARP entries.

add <IP address> <MAC address> <VLAN number> <port>

Adds a single ARP entry from switch memory.

del <IP address (such as, 192.4.17.101)>

Removes a single ARP entry from switch memory.

clear

Clears the entire ARP list from switch memory.

addr

Shows the list of IP addresses which the switch will respond to for ARP requests.

NOTE – To display all ARP entries currently held in the switch, or a portion according to one of the options listed on the menu above (find, port, vlan, refpt, dump), you can also refer to “ARP Information” on [page 70](#).

/maint/route

IP Route Manipulation

```
[IP Routing Menu]
  find - Show a single route by destination IP address
  gw   - Show routes to a single gateway
  type - Show routes of a single type
  tag  - Show routes of a single tag
  if   - Show routes on a single interface
  dump - Show all routes
  clear - Clear route table
```

Table 10-6 IP Route Manipulation Menu Options (/maint/route)

Command Syntax and Usage

find <IP address (such as, 192.4.17.101)>

Shows a single route by destination IP address.

gw <default gateway address (such as, 192.4.17.44)>

Shows routes to a default gateway.

type indirect|direct|local|broadcast|martian|multicastShows routes of a single type. For a description of IP routing types, see [Table 4-9 on page 69](#)**tag** fixed|static|addr|rip|ospf|bgp|broadcast|martian|vipShows routes of a single tag. For a description of IP routing tags, see [Table 4-10 on page 70](#)**if** <interface number (1-128)>

Shows routes on a single interface.

dump

Shows all routes.

clear

Clears the route table from switch memory.

NOTE – To display all routes, you can also refer to “IP Routing Information” on [page 68](#).

/maint/igmp

IGMP Configuration

[IGMP Menu]	
snoop	- IGMP Snooping Menu
mrouter	- IGMP Multicast Router Port Menu
dump	- Dump all IGMP items
clear	- Clear all IGMP tables

Table 10-7 describes the IGMP Maintenance commands.

Table 10-7 IGMP Multicast Group Menu Options (/maint/igmp)

Command Syntax and Usage

snoop

Displays IGMP multicast group information.

mrouter

Displays static Multicast Router information.

dump

Displays all IGMP information.

clear

Clears all IGMP tables.

/maint/igmp/snoop

IGMP Multicast Router Port Information

```
[IGMP Snooping Menu]
  find      - Show a single group by IP group address
  vlan      - Show groups on a single vlan
  port      - Show groups on a single port
  dump      - Show all groups
  clear     - Clear group table
```

Table 10-8 describes the IGMP Snooping Maintenance commands.

Table 10-8 IGMP Multicast Group Menu Options (/maint/igmp/snoop)

Command Syntax and Usage

find <IP address>

Displays a single IGMP multicast group by its IP address.

vlan <VLAN number>

Displays all IGMP multicast groups on a single VLAN.

port <Port number or alias>

Displays all IGMP multicast groups on a single port.

dump

Displays information for all multicast groups.

clear

Clears the IGMP group table.

/maint/igmp/mrouter

IGMP Multicast Router Port Information

```
[IGMP Multicast Router Ports Menu]
vlan - Show all learned multicast router ports on a single vlan
dump  - Show all learned multicast router ports
versions - Show last detected multicast router IGMP versions
clear  - Clear multicast router port table
```

Table 10-9 describes the multicast router maintenance commands.

Table 10-9 IGMP Multicast Router Menu Options (/maint/igmp/mrouter)

Command Syntax and Usage

vlan

Displays information for all multicast groups learned on the selected VLAN.

dump

Displays information for all multicast groups learned by the switch.

versions

Displays the IGMP version of the most recent multicast group learned by the switch.

clear

Clears the IGMP multicast router port table.

/maint/uudmp

Uuencode Flash Dump

Using this command, dump information is presented in uuencoded format. This format makes it easy to capture the dump information as a file or a string of characters.

If you want to capture dump information to a file, set your communication software on your workstation to capture session data prior to issuing the uudmp command. This will ensure that you do not lose any information. Once entered, the uudmp command will cause approximately 23,300 lines of data to be displayed on your screen and copied into the file.

Using the uudmp command, dump information can be read multiple times. The command does not cause the information to be updated or cleared from flash memory.

NOTE – Dump information is not cleared automatically. In order for any subsequent dump information to be written to flash memory, you must manually clear the dump region. For more information on clearing the dump region, see [page 322](#).

To access dump information, at the Maintenance# prompt, enter:

```
Maintenance# uudmp
```

The dump information is displayed on your screen and, if you have configured your communication software to do so, captured to a file. If the dump region is empty, the following appears:

```
No FLASH dump available.
```

`/maint/ptdmp <server> <filename>` TFTP System Dump Put

Use this command to put (save) the system dump to a TFTP server.

NOTE – If the TFTP server is running SunOS or the Solaris operating system, the specified `ptdmp` file must exist *prior* to executing the `ptdmp` command, and must be writable (set with proper permission, and not locked by any application). The contents of the specified file will be replaced with the current dump data.

To save dump information via TFTP, at the Maintenance# prompt, enter:

```
Maintenance# ptdmp <server> <filename>
```

Where *server* is the TFTP server IP address or hostname, and *filename* is the target dump file.

`/maint/cltmp` Clearing Dump Information

To clear dump information from flash memory, at the Maintenance# prompt, enter:

```
Maintenance# cltmp
```

The switch clears the dump region of flash memory and displays the following message:

```
FLASH dump region cleared.
```

If the flash dump region is already clear, the switch displays the following message:

```
FLASH dump region is already clear.
```

`/maint/panic` Panic Command

The `panic` command causes the switch to immediately dump state information to flash memory and automatically reboot.

To select `panic`, at the Maintenance# prompt, enter:

```
>> Maintenance# panic
A FLASH dump already exists.
Confirm replacing existing dump and reboot [y/n]:
```

Enter **y** to confirm the command:

```
Confirm dump and reboot [y/n]: y
```

The following messages are displayed:

```
Starting system dump...done.

Rebooted because of PANIC command.
Booting complete 0:01:01 Thu Jul 1, 2003:
Version 1.0.0.18 from FLASH image1, active config block.

No POST errors (0xff).

Production Mode.
```

Unscheduled System Dumps

If there is an unscheduled system dump to flash memory, the following message is displayed when you log on to the switch:

```
Note: A system dump exists in FLASH. The dump was saved
at 13:43:22 Wednesday October 30, 2002. Use /maint/uudmp to
extract the dump for analysis and /maint/cldmp to
clear the FLASH region. The region must be cleared
before another dump can be saved.
```


APPENDIX A

Alteon OS Syslog Messages

The following syntax is used when outputting syslog messages:

```
<Time stamp><Log Label>Web OS<Thread ID> : <Message>
```

where

■ **<Timestamp>**

The time of the message event is displayed in month day hour:minute:second format. For example: Aug 19 14:20:30

■ **<Log Label>**

The following types of log messages are recorded: LOG_EMERG, LOG_ALERT, LOG_CRIT, LOG_ERR, LOG_WARNING, LOG_NOTICE, LOG_INFO, and LOG_DEBUG

■ **<Thread ID>**

This is the software thread that reports the log message. The following thread IDs are recorded: stg, ip, slb, console, telnet, vrrp, system, web server, ssh, and bgp

■ **<Message>**: The log message

Following is a list of potential syslog messages. To keep this list as short as possible, only **<Thread ID>** and **<Message>** are shown. The messages are sorted by **<Log Label>**.

Where the **<Thread ID>** is listed as *mgmt*, one of the following may be shown: console, telnet, web server, or ssh.

LOG_WARNING

FILTER “filter <filter number> fired on port <port number>, <source IP address> -> <destination IP address>, [<ICMP type>], [<IP protocol>], [<layer-4 ports>], [<TCP flags>]”

LOG_ALERT

stp: own BPDU received from port <port_id>

IP cannot contact default gateway <ip_address>

vrrp: received errored advertisement from <ip_address>

vrrp: received incorrect password from <ip_address>

vrrp: received incorrect addresses from <ip_address>

vrrp: received incorrect advertisement interval <seconds> from <ip_address>

slb: cannot contact real server <ip_address>

slb: real server <ip_address> has reached maximum connections

slb: cannot contact real service <ip_address:real_port>

slb: real server failure threshold (<threshold>) has been reach for group <group_id>

slb: real server <ip_address> disabled through configuration

slb: Virtual Service Pool full. gSvcPool=MAX_SERVICES

bgp: notification (<reason>) received from <BGP peer ip_address>

bgp: session with <BGP peer ip_address> failed (<reason>)

vrrp: Synchronization from non-configured peer <ip_address>

vrrp: Synchronization from non-configured peer <ip_address> was blocked

dps: hold down triggered: <ip_address> for <min> minutes

dps: manual hold down: <ip_address>

syn_atk SYN attack detected: <count> new half-open sessions per second

tcplim hold down triggered: <ip_address> for <min> minutes

LOG_CRIT

SYSTEM: temperature at sensor <sensor_id> exceeded threshold

SYSTEM: internal power supply failed

SYSTEM: redundant power supply failed

LOG_CRIT (Continued)

SYSTEM: fan failure detected

SSH can't allocate memory in load_MP_INT

LOG_ERR

mgmt: PANIC at <file>:<line> in thread <thread id>

mgmt: VERIFY at <file>:<line> in thread <thread id>

mgmt: ASSERT at <file>:<line> in thread <thread id>

ntp: cannot contact NTP server <ip_address>

ntp: unable to listen to NTP port

isd: unable to listen to BOOTP_SERVER_PORT port

stp: Error: Error writing STG config to FLASH

stp: Error: Error writing config to FLASH

mgmt: Apply not done

mgmt: Save not done

mgmt: “ <““apply””|““save””> is issued by another user. Try later”

cli: Error: Error writing %s config to FLASH

cli: New Path Cost for Port <port_id> is invalid

cli: PVID <vlan_id> for port <port_id> is not created

cli: RADIUS secret must be 1-32 characters long

cli: Please configure primary RADIUS server address

cli: STP changes can't be applied since STP is OFF

cli: Switch reset is required to turn STP on/off

cli: Trunk group <trunk_id> contains ports with different PVIDs

cli: Trunk group <trunk_id> has more than <max_trunk_ports> ports

cli: Trunk group <trunk_id> contains no ports but is enabled

cli: Not all ports in trunk group <trunk_id> are in VLAN <vlan_id>

cli: Trunk groups <trunk_id> and <trunk_id> can not share the same port

LOG_ERR (Continued)

port_mirr: Port Mirroring changes are not applied

cli: Broadcast address for IP interface <interface_id> is invalid

cli: IP Interfaces <interface_id> and <interface_id> are on the same subnet

cli: Multiple static routes have same destination

cli: Virtual router <vr_id> must have sharing disabled when hotstandby is enabled

cli: Virtual router group must be enabled when hotstandby is enabled

cli: At least one virtual router must be enabled when group is enabled

cli: Virtual router group must have sharing disabled when hotstandby is enabled

cli: Virtual router group must have preemption enabled when hotstandby is enabled

cli: Virtual router <vr_id> must have an IP address

cli: Virtual router <vr_id> cannot have same VRID and VLAN as <vlan_id>

cli: Virtual router <vr_id> cannot have same IP address as <ip_address>

cli: Virtual router <vr_id> corresponding virtual server <server_id> is not enabled

cli: Hot-standby must be enabled when a virtual router has a PIP address

cli: Virtual router <vr_id> IP interface should be <interface_id>

cli: Enabled real server <server_id> has no IP address

cli: Real server <server_id> has same IP address as IP interface <interface_id>

cli: Real server <server_id> has same IP address as switch

cli: Real server <server_id> (Backup for <server_id>) is not enabled

cli: Real server <server_id> has same IP address as virtual server <server_id>

cli: Real server <server_id> has same IP address as real server <server_id>

cli: Real server group <group_id> cannot backup itself

cli: Real server <server_id> cannot be added to same group

cli: Enabled virtual server <server_id> has no IP address

cli: Virtual server <server_id> has same IP address as IP interface <interface_id>

cli: Virtual server <server_id> has same IP address as switch

LOG_ERR (Continued)

- cli: Virtual servers <server_id> and <server_id> with same IP address must support same layer3 configuration
- cli: Real server <server_id> cannot be backup server for both real server <server_id> and group <group_id>
- cli: Virtual server <server_id> has same IP address and vport as virtual server <server_id>
- cli: RS <server_id> can't exist for VS <server_id> vport <virtual_port>
- cli: Switch port <port_id> has same proxy IP address as port <port_id>
- cli: Switch port <port_id> has same IP address as IP interface <interface_id>
- cli: A hot-standby port cannot also be an inter-switch port
- cli: There must be at least one inter-switch port if any hot-standby port exist
- cli: "With VMA, ports 1-8 must all have a PIP if any one does"
- cli: Client bindings are not supported with proxy IP addresses
- cli: DAM must be turned on or a PIP must be enabled for port <port_id> in order for virtual server to support FTP parsing
- cli: Real server <server_id> and group %u cannot both have backups configured
- cli: Virtual server <server_id> : port mapping but layer3 bindings
- cli: Extracting length has to set to 8 or 16 for cookie rewrite mode
- cli: DAM must be turned on or a PIP must be enabled for port <port_id> in order for virtual server <server_id> to support URL parsing
- cli: Port filtering must be disabled on port <port_id> in order to support cookie based persistence for virtual server <server_id>
- cli: Virtual server <server_id>: port mapping but Direct Access Mode
- cli: Virtual server %lu: support nonat IP but not layer 3 bindings
- cli: Virtual servers: all that support IP must use same group
- cli: Virtual servers <server_id> and <server_id> that include the same real server <server_id> cannot map the same real port or balance UDP
- cli: Virtual server <server_id>: UDP service <virtual_port> with out-of-range port number
- cli: Switch cannot support more than <MAX_VIRT_SERVICES> virtual services
- cli: Switch cannot support more than <MAX_SMT> real services
- cli: Trunk group (<trunk_id>) ports must have same L4 config

LOG_ERR (Continued)

- cli: Trunk group (<trunk_id>) ports must all have a PIP
- cli: DAM must be turned on or a PIP must be enabled for ports <port_id> in order to do URL based redirection
- cli: “Two services have same hostname, <host_name>.<domain_name>”
- cli: Direct access mode is not supported with default gateway load balancing
- cli: SLB Radius secret must be 16 characters long
- cli: Dynamic NAT filter <filter_id> must be cached
- cli: NAT filter <filter_id> must have same smask and dmask
- cli: NAT filter <filter_id> cannot have port ranges
- cli: NAT filter <filter_id> must be cached
- cli: NAT filter <filter_id> dest range includes VIP <server_id>
- cli: NAT filter <filter_id> dest range includes RIP <server_id>
- cli: Redirection filter <filter_id> must be cached
- cli: Filter with L4 ports configured <port_id> must have IP protocol configured
- cli: Remote site <site_id> does not have a primary IP address
- cli: Primary and secondary remote site <site_id> switches must differ
- cli: Remote sites <site_id> and <site_id> must use different addresses
- cli: Remote site <site_id> and real server <server_id> must use different addresses
- cli: Remote site <site_id> and virtual server <server_id> must use different addresses
- cli: Only <MAX_SLB_SITES> remote servers are allowed per group
- cli: Only <MAX_SLB_SERVICES> remote services are supported
- cli: Enabled external lookup IP address has no IP address
- cli: domain name must be configured
- cli: Network <static_network_id> has no VIP address
- cli: duplicate default entry
- cli: BGP peer <bgp_peer_id> must have an IP address
- cli: BGP peers <bgp_peer_id> and <bgp_peer_id> have same address

LOG_ERR (Continued)

cli: BGP peer <bgp_peer_id> have same address as IP interface <ip_interface_id>

cli: BGP peer <bgp_peer_id> IP interface <ip_interface_id> is not enabled

cli: Filter with ICMP types configured (<icmp_type>) must have IP protocol configure to ICMP

cli: “Two services have same hostname, <host_name>.<domain_name>”

cli: Loadbalance string must be added to real server <server_id> in order to enable exclusion-ary string matching

cli: intrval input value must be in the range [0-24]

mgmt: unapplied changes reverted

mgmt: unsaved changes reverted

mgmt: Attempting to redirect a previously redirected output

vrrp: Attempting to redirect a previously redirected output

vrrp: cfg_sync_tx_putsn: ABORTED

vrrp: Synchronization TX Error

vrrp: Synchronization TX connection RESET

vrrp: Synchronization TX connection TIMEOUT

vrrp: Synchronization TX connection UNREACEABLE

vrrp: Synchronization TX connection UNKNOWN CLOSE

vrrp: Synchronization RX connection RESET

vrrp: Synchronization RX connection TIMEOUT

vrrp: Synchronization RX connection UNREACEABLE

vrrp: Synchronization RX connection UNKNOWN CLOSE

vrrp: Synchronization connection RCLOSE by peer

vrrp: Synchronization connection RCLOSE before RX

vrrp: Synchronization connection early RCLOSE in RX

vrrp: Synchronization connection Wait-For-Close Timeout

vrrp: Synchronization connection Transmit Timeout

vrrp: Synchronization Receive Timeout

LOG_ERR (Continued)

vrrp: Synchronization Receive UNKNOWN Timeout

vrrp: Sync transmit in progress ... cannot start Sync

vrrp: Sync receive in progress ... cannot start Sync

vrrp: Sync already in progress ... cannot start Sync

vrrp: Config Sync route find error

vrrp: Config Sync tcp_open error

vrrp: Config Synchronization Timeout - Resuming Console thread

vrrp: "<""apply""|""save""> is issued by another user. Try later"

vrrp: new configuration did not validate (rc =)

vrrp: new configuration did not apply (rc =)

vrrp: new configuration did not save (rc =)

vrrp: Sync config apply error

vrrp: Restoring Current Config

vrrp: Sync rx tcp open error

vrrp: Sync Version/Password Failed-No Version/Password Line

vrrp: Sync Version Failed - peer:%s config:%s

vrrp: Sync Password Failed-Bad Password

vrrp: Sync receive already in progress ... cannot start Sync receive

vrrp: Sync transmit in progress ... cannot start Sync receive

LOG_NOTICE

system: internal power supply ok

system: redundant power supply present and ok

system: temperature ok

system: fan ok

system: rebooted <last_reset_information>

system: rebooted <last_reset_information> administrator logged in

mgmt: boot config block changed

mgmt: boot image changed

mgmt: switch reset from CLI

mgmt: syslog host changed to <ip_address>

mgmt: syslog host changed to this host

mgmt: second syslog host changed to <ip_address>

mgmt: second syslog host changed to this host

mgmt: Next boot will use active config block

mgmt: user password changed

mgmt: SLB operator password changed

mgmt: L4 operator password changed

mgmt: operator password changed

mgmt: SLB administrator password changed

mgmt: L4 administrator password changed

mgmt: administrator password changed

ssh: scp <login_level> login

ssh: "scp <login_level> <""connection closed""|""idle timeout""|""logout"">"

mgmt: RADIUS server timeouts

mgmt: Failed login attempt via TELNET from host %s

mgmt: PASSWORD FIX-UP MODE IN USE

mgmt: <login_level> login on Console

LOG_NOTICE (Continued)

mgmt: “<login_level> <""idle timeout""|""logout""> from Console”

mgmt: PANIC command from CLI

port_mirr: “port mirroring is <""enabled""|""disabled"">”

vlan: Default VLAN can not be deleted

mgmt: <login_level> login from host <ip_address>

mgmt: “<login_level> <""connection closed""|""idle timeout""|""logout""> from”

IP “default gateway <ip_address> <""enabled""|""disabled"">”

IP default gateway <ip_address> operational

vrrp: virtual router <ip_address> is now master

vrrp: virtual router <ip_address> is now backup

slb: “backup server <ip_address> <""enabled""|""diabled""> for real server <server_id>”

slb: “backup server <ip_address> <""enabled""|""disabled""> for real server group <group_id>”

slb: “backup group server <ip_address> <""enabled""|""disabled""> for real server group <group_id>”

slb: “overflow server <ip_address> <""enabled""|""disabled""> for real server <server_id>”

slb: “overflow server <ip_address> <""enabled""|""disabled""> for real server group <group_id>”

slb: “overflow group server <ip_address> <""enabled""|""disabled""> for real server group <group_id>”

slb: real server <ip_address> operational

slb: real service <ip_address:real_port> operational

slb: No services are available for Virtual Server <virtual_server>

slb: Services are available for Virtual Server <virtual_server>

bgp: session established with <BGP_peer_ip_address>

LOG_INFO

SYSTEM: bootp response from <ip_address>

mgmt: new configuration applied

mgmt: new configuration saved

mgmt: unsaved changes reverted

mgmt: Could not revert unsaved changes

mgmt: " <image1|image2> downloaded from host <ip_address>, file <file_name>
<software_version>"

mgmt: serial EEPROM downloaded from host <ip_address> file <file_name>

ssh: scp <login_level> login

ssh: " scp <login_level> <""connection closed""|""idle timeout""|""logout"">"

mgmt: <login_level> login on Console

mgmt: " <login_level> <""idle timeout""|""logout""> from Console"

mgmt: <login_level> login from host <ip_address>

mgmt: " <login_level> <""connection closed""|""idle timeout""|""logout""> from Telnet/SSH."

ssh: server key autogen starts

ssh: server key autogen completes

ssh: server key autogen timer timeouts

vrrp: new synch configuration applied

vrrp: new synch configuration saved

vrrp: Synchronizing from <host_name>

vrrp: Synchronizing to <host_name>

vrrp: Config Synchronization Transmit Successful

vrrp: Config Synchronization Receive Successful

vrrp: new configuration VALIDATED

APPENDIX B

Alteon OS SNMP Agent

The Alteon OS SNMP agent supports SNMP Version 1. Security is provided through SNMP community strings. The default community strings are “public” for SNMP GET operation and “private” for SNMP SET operation. The community string can be modified only through the Command Line Interface (CLI). Alteon WebSystems is registered as Vendor 1872. Detailed SNMP MIBs and trap definitions of the Alteon OS SNMP agent can be found in the following Alteon OS enterprise MIB documents:

- Altroot.mib -
- AOSSwitch.mib
- AOSPhysical.mib
- AOSNetwork.mib
- AOSLayer4.mib
- AOSLayer7.mib
- AOSTrap.mib

Users may specify up to two trap hosts for receiving SNMP Traps. The agent will send the SNMP Trap to the specified hosts when appropriate. Traps will not be sent if there is no host specified.

Alteon OS SNMP agent supports the following standard MIBs:

- RFC 1213 - MIB II (System, Interface, Address Translation, IP, ICMP, TCP, UDP, SNMP Groups)
- RFC 1573 - MIB II Extension (IFX table)
- RFC 1643 - EtherLike MIB
- RFC 1493 - Bridge MIB
- RFC 1757 - RMON MIB (Statistics, History, Alarm, Event Groups)
- RFC 1850 for OSPF
- RFC 1657 for BGP
- RFC 2037

Alteon OS SNMP agent supports the following generic traps as defined in RFC 1215:

- ColdStart
- WarmStart
- LinkDown
- LinkUp
- AuthenticationFailure

The SNMP agent also supports two Spanning Tree traps as defined in RFC 1493:

- NewRoot
- TopologyChange

The following are the enterprise SNMP traps supported in Alteon OS:

Table 10-10 Alteon OS-Supported Enterprise SNMP Traps

Trap Name	Description
altSwDefGwUp	Signifies that the default gateway is alive.
altSwDefGwDown	Signifies that the default gateway is down.
altSwDefGwInService	Signifies that the default gateway is up and in service
altSwDefGwNotInService	Signifies that the default gateway is alive but not in service
altSwSlbRealServerUp	Signifies that the real server is up and operational
altSwSlbRealServerDown	Signifies that the real server is down and out of service
altSwSlbRealServerMaxConnReached	Signifies that the real server has reached maximum connections
altSwSlbBkupRealServerAct	Signifies that the backup real server is activated due to availability of the primary real server
altSwSlbBkupRealServerDeact	Signifies that the backup real server is deactivated due to the primary real server is available
altSwSlbBkupRealServerActOverflow	Signifies that the backup real server is deactivated due to the primary real server is overflowed
altSwSlbBkupRealServerDeactOverflow	Signifies that the backup real server is deactivated due to the primary real server is out from overflow situation

Table 10-10 Alteon OS-Supported Enterprise SNMP Traps

Trap Name	Description
altSwfltFilterFired	Signifies that the packet received on a switch port matches the filter rule
altSwSibRealServerServiceUp	Signifies that the service port of the real server is up and operational
altSwSibRealServerServiceDown	Signifies that the service port of the real server is down and out of service
altSwVrrpNewMaster	The newMaster trap indicates that the sending agent has transitioned to 'Master' state.
altSwVrrpNewBackup	The newBackup trap indicates that the sending agent has transitioned to 'Backup' state.
altSwVrrpAuthFailure	A vrrpAuthFailure trap signifies that a packet has been received from a router whose authentication key or authentication type conflicts with this router's authentication key or authentication type. Implementation of this trap is optional.
altSwLoginFailure	A altSwLoginFailure trap signifies that someone failed to enter a valid username/password combination.
altSwSibSynAttack	A altSwSibSynAttack trap signifies that a SYN attack has been detected.
altSwTcpHoldDown	A altSwTcpHoldDown trap signifies that new TCP connection requests from a particular client will be blocked for a pre-determined amount of time since the rate of new TCP connections from that client has reached a pre-determined threshold.
altSwTempExceedThreshold	A altSwTempExceedThreshold trap signifies that the switch temperature has exceeded maximum safety limits.

Working with Switch Images and Configuration Files

This section describes how to use MIB calls to work with switch images and configuration files. You can use a standard SNMP tool to perform the actions, using the MIBs listed in [Table 10-11](#).

The examples in this section use the MIB name, but you can also use the OID.

[Table 10-11](#) lists the MIBS used to perform operations associated with the GbESM Switch Image and Configuration files. These MIBS are contained within in the file “aossswitch.mib”

Table 10-11 MIBs for Switch Image and Configuration Files

MIB Name	MIB IOD
aqTftpServer	1.3.6.1.4.1872.2.5.1.1.7.1
aqTftpImage	1.3.6.1.4.1872.2.5.1.1.7.2
aqTftpImageFileName	1.3.6.1.4.1872.2.5.1.1.7.3
aqTftpCfgFileName	1.3.6.1.4.1872.2.5.1.1.7.4
aqTftpDumpFileName	1.3.6.1.4.1872.2.5.1.1.7.5
aqTftpAction	1.3.6.1.4.1872.2.5.1.1.7.6
aqTftpLastActionStatus	1.3.6.1.4.1872.2.5.1.1.7.7
aqTftpPort	1.3.6.1.4.1872.2.5.1.1.7.8

The following SNMP actions can be performed using the MIBs listed in [Table 10-11](#).

- Load a new Switch image (boot or running) from a TFTP server
- Load a previously saved switch configuration from a TFTP server
- Save the switch configuration to a TFTP server
- Save a switch dump to a TFTP server

Loading a new switch image

To load a new switch image with the name “MyNewImage-1.img” into image2, follow the steps below. This example assumes you have a TFTP server at 192.168.10.10.

1. **Set the TFTP server address where the switch image resides:**

```
Set aqTftpServer.0 "192.168.10.10"
```

2. **Set the area where the new image will be loaded:**

```
Set aqTftpImage.0 "image2"
```

3. **Set the name of the image:**

```
Set aqTftpImageFileName.0 "MyNewImage-1.img"
```

4. **Set the port for the TFTP data transfer. Enter 1 to perform the transfer across the data port. Enter 2 to perform the transfer across the management port:**

```
Set aqTftpPort.0 "1"
```

5. **Initiate the transfer. To transfer a switch image, enter 2 (gting):**

```
Set aqTftpAction.0 "2"
```

Loading a saved switch configuration

To load a saved switch configuration with the name “MyRunningConfig.cfg” into the switch, follow the steps below. This example assumes you have a TFTP server at 192.168.10.10.

1. **Set the TFTP server address where the switch Configuration File resides:**

```
Set aqTftpServer.0 "192.168.10.10"
```

2. **Set the name of the configuration file:**

```
Set aqTftpCfgFileName.0 "MyRunningConfig.cfg"
```

3. **Set the port for the TFTP data transfer. Enter 1 to perform the transfer across the data port. Enter 2 to perform the transfer across the management port.**

```
Set aqTftpPort.0 "1"
```

4. **Initiate the transfer. To restore a running configuration, enter 3:**

```
Set aqTftpAction.0 "3"
```

Saving the switch configuration

To save the switch configuration to a TFTP server follow the steps below. This example assumes you have a TFTP server at 192.168.10.10.

1. **Set the TFTP server address where the configuration file is saved:**

```
Set aqTftpServer.0 "192.168.10.10"
```

2. **Set the name of the configuration file:**

```
Set aqTftpCfgFileName.0 "MyRunningConfig.cfg"
```

3. **Set the port for the TFTP data transfer. Enter 1 to perform the transfer across the data port. Enter 2 to perform the transfer across the management port.**

```
Set aqTftpPort.0 "1"
```

4. **Initiate the transfer. To save a running configuration file, enter 4:**

```
Set aqTftpAction.0 "4"
```

Saving a switch dump

To save a switch dump to a TFTP, follow the steps below. This example assumes you have a TFTP server at 192.168.10.10.

1. **Set the TFTP server address where the configuration will be saved:**

```
Set aqTftpServer.0 "192.168.10.10"
```

2. **Set the name of dump file:**

```
Set aqTftpDumpFileName.0 "MyDumpFile.dmp"
```

3. **Set the port for the TFTP data transfer. Enter 1 to perform the transfer across the data port. Enter 2 to perform the transfer across the management port.**

```
Set aqTftpPort.0 "1"
```

4. **Initiate the transfer. To save a dump file, enter 5:**

```
Set aqTftpAction.0 "5"
```

Saving a switch image

To save a switch image with the name “MySavedImage.img” to a TFTP server, follow the steps below. This example assumes you have a TFTP server at IP address 192.168.10.10.

1. Set the TFTP server address where the switch image resides:

```
Set aqTftpServer.0 "192.168.10.10"
```

2. Set the Image that you want to save to TFTP:

```
Set aqTftpImage.0 "image2"
```

3. Set the name of the image:

```
Set aqTftpImageFileName.0 "MySavedImage.img"
```

4. Set the port for the TFTP data transfer. Enter 1 to perform the transfer across the data port. Enter 2 to perform the transfer across the management port:

```
Set aqTftpPort.0 "1"
```

5. Initiate the transfer. To transfer a switch image, enter 2 (img-put):

```
Set aqTftpAction.0 "7"
```




Glossary

DIP (Destination IP Address)	The destination IP address of a frame.
Dport (Destination Port)	The destination port (application socket: for example, http-80/https-443/DNS-53)
NAT (Network Address Translation)	Any time an IP address is changed from one source IP or destination IP address to another address, network address translation can be said to have taken place. In general, half NAT is when the destination IP or source IP address is changed from one address to another. Full NAT is when both addresses are changed from one address to another. No NAT is when neither source nor destination IP addresses are translated. Virtual server-based load balancing uses half NAT by design, because it translates the destination IP address from the Virtual Server IP address, to that of one of the real servers.
Preemption	In VRRP, preemption will cause a Virtual Router that has a lower priority to go into backup should a peer Virtual Router start advertising with a higher priority.
Priority	In VRRP, the value given to a Virtual Router to determine its ranking with its peer(s). Minimum value is 1 and maximum value is 254. Default is 100. A higher number will win out for master designation.
Proto (Protocol)	The protocol of a frame. Can be any value represented by a 8-bit value in the IP header adherent to the IP specification (for example, TCP, UDP, OSPF, ICMP, and so on.)
Real Server Group	A group of real servers that are associated with a Virtual Server IP address, or a filter.

Redirection or Filter-Based Load Balancing

A type of load balancing that operates differently from virtual server-based load balancing. With this type of load balancing, requests are transparently intercepted and “redirected” to a server group. “Transparently” means that requests are not specifically destined for a Virtual Server IP address that the switch owns. Instead, a filter is configured in the switch. This filter intercepts traffic based on certain IP header criteria and load balances it. Filters can be configured to filter on the SIP/Range (via netmask), DIP/Range (via netmask), Protocol, SPort/Range or DPort/Range. The action on a filter can be Allow, Deny, Redirect to a Server Group, or NAT (translation of either the source IP or destination IP address). In redirection-based load balancing, the destination IP address is not translated to that of one of the real servers. Therefore, redirection-based load balancing is designed to load balance devices that normally operate transparently in your network—such as a firewall, spam filter, or transparent Web cache.

RIP (Real Server)

Real Server IP Address. An IP addresses that the switch load balances to when requests are made to a Virtual Server IP address (VIP).

SIP (Source IP Address)

The source IP address of a frame.

SPort (Source Port)

The source port (application socket: for example, HTTP-80/HTTPS-443/DNS-53).

Tracking

In VRRP, a method to increase the priority of a virtual router and thus master designation (with preemption enabled). Tracking can be very valuable in an active/active configuration. You can track the following:

- Vrs: Virtual Routers in Master Mode (increments priority by 2 for each)
- Ifs: Active IP interfaces on the GbE Switch Module (increments priority by 2 for each)
- Ports: Active ports on the same VLAN (increments priority by 2 for each)
- l4pts: Active Layer 4 Ports, client or server designation (increments priority by 2 for each)
- reals: healthy real servers (increments by 2 for each healthy real server)
- hsrp: HSRP announcements heard on a client designated port (increments by 10 for each)

VIP (Virtual Server IP Address)

An IP address that the switch owns and uses to load balance particular service requests (like HTTP) to other servers.

VIR (Virtual Interface Router)

A VRRP address that is an IP interface address shared between two or more virtual routers.

Virtual Router

A shared address between two devices utilizing VRRP, as defined in RFC 2338. One virtual router is associated with an IP interface. This is one of the IP interfaces that the switch is assigned. All IP interfaces on the GbE Switch Module must be in a VLAN. If there is more than one VLAN defined on the GbE Switch Module, then the VRRP broadcasts will only be sent out on the VLAN of which the associated IP interface is a member.

Virtual Server Load Balancing

Classic load balancing. Requests destined for a Virtual Server IP address (VIP), which is owned by the switch, are load balanced to a real server contained in the group associated with the VIP. Network address translation is done back and forth, by the switch, as requests come and go.

Frames come to the switch destined for the VIP. The switch then replaces the VIP and with one of the real server IP addresses (RIP's), updates the relevant checksums, and forwards the frame to the server for which it is now destined. This process of replacing the destination IP (VIP) with one of the real server addresses is called half NAT. If the frames were not half NAT'ed to the address of one of the RIPs, a server would receive the frame that was destined for its MAC address, forcing the packet up to Layer 3. The server would then drop the frame, since the packet would have the DIP of the VIP and not that of the server (RIP).

VRID (Virtual Router Identifier)

In VRRP, a value between 1 and 255 that is used by each virtual router to create its MAC address and identify its peer for which it is sharing this VRRP address. The VRRP MAC address as defined in the RFC is 00-00-5E-00-01-**{VRID}**. If you have a VRRP address that two switches are sharing, then the VRID number needs to be identical on both switches so each virtual router on each switch knows whom to share with.

VRRP (Virtual Router Redundancy Protocol)

A protocol that acts very similarly to Cisco's proprietary HSRP address sharing protocol. The reason for both of these protocols is so devices have a next hop or default gateway that is always available. Two or more devices sharing an IP interface are either advertising or listening for advertisements. These advertisements are sent via a broadcast message to an address such as 224.0.0.18.

With VRRP, one switch is considered the master and the other the backup. The master is always advertising via the broadcasts. The backup switch is always listening for the broadcasts. Should the master stop advertising, the backup will take over ownership of the VRRP IP and MAC addresses as defined by the specification. The switch announces this change in ownership to the devices around it by way of a Gratuitous ARP, and advertisements. If the backup switch didn't do the Gratuitous ARP the Layer 2 devices attached to the switch would not know that the MAC address had moved in the network. For a more detailed description, refer to RFC 2338.

VSR (Virtual Server Router)

A VRRP address that is a shared Virtual Server IP address. VSR is Alteon WebSystems' proprietary extension to the VRRP specification. The switches must be able to share Virtual Server IP addresses, as well as IP interfaces. If they didn't, the two switches would fight for ownership of the Virtual Server IP address, and the ARP tables in the devices around them would have two ARP entries with the same IP address but different MAC addresses.

Index

Symbols

(MD5).....	294
(SLB real server group option)	
content	259
/ command.....	47
[].....	15

A

abbreviating commands (CLI)	50
access control	
user.....	179
action (SLB filtering option).....	275
active configuration block	166, 309
active FTP SLB parsing statistics	143
active IP interface.....	244
active Layer 4 processing	244
active port	
VLAN.....	244
active switch configuration	
gtcfg	250
ptcfg	250
restoring	250
active switch, saving and loading configuration....	250
add	
ARP entry	317
SLB port option.....	284
addr	
ARP entries.....	317
IP route tag	70
Address Resolution Protocol (ARP)	
add, delete entries	317
address list	317

administrator account	25, 27
admpw (system option)	181
advertisement of virtual IP addresses	214
aging	
STP bridge option	190
STP information	63
application redirection.....	254, 275
filter states.....	84
filters	254
within real server groups	259
apply (global command).....	165
applying configuration changes	165
autoconfiguration	
link.....	32
auto-negotiation	
enable/disable on port	183
setup.....	32
autonomous system filter action	212
autonomous system filter path	
action	212
as	212
aspath	212

B

backup	
SLB real server group option	261
backup configuration block.....	166, 309
backup server activations (SLB statistics)	151
banner (system option)	168
BBI	17

BGP	
configuration.....	224
eBGP.....	224
filters, aggregation configuration	229
iBGP.....	224
in route.....	227
IP address, border router.....	226
IP route tag	70
keep-alive time.....	226
peer	225
peer configuration.....	226
redistribution configuration.....	228
remote autonomous system	226
router hops.....	227
binding failure	151
binding table.....	268
BLOCKING (port state).....	64
boot options menu	305
BOOTP.....	22
setup (enable/disable).....	31
system option	168
bootstrap protocol	235
Border Gateway Protocol	70
configuration.....	224
Border Gateway Protocol (BGP)	
operations-level options.....	304
BPDU. <i>See</i> Bridge Protocol Data Unit.	
bridge parameter menu, for STP	188
bridge priority	63
Bridge Protocol Data Unit (BPDU)	63
STP transmission frequency.....	190
Bridge Spanning-Tree parameters	190
broadcast	
IP route tag	70
IP route type	69
Browser-Based Interface.....	17
C	
capture dump information to a file	321
Cisco Ether Channel.....	192
clear	
ARP entries	317
dump information	322
FDB entry.....	314
routing table.....	318
clearing SLB statistics	152
client traffic processing.....	283
command (help).....	47
Command-Line Interface (CLI)	17 to 26, 27, 45
commands	
abbreviations.....	50
conventions used in this manual.....	15
global commands.....	47
shortcuts	50
stacking	50
tab completion.....	50
configuration	
administrator password.....	181
apply changes.....	165
default gateway interval, for health checks	203
default gateway IP address	203
dump command.....	249
effect on Spanning-Tree Protocol.....	165
flow control.....	183
Gigabit Ethernet.....	181
IP static route	205
Layer 4 administrator password	180
operating mode	183
port link speed	183
port mirroring.....	184
port trunking	192
route cache.....	207
save changes	165
setup	249
setup command.....	249
switch IP address	202
TACACS+.....	172
user password.....	180
view changes.....	165
VLAN default (PVID).....	181
VLAN IP interface.....	202
VLAN tagging.....	182
VRRP.....	236
configuration block	
active	309
backup.....	309
factory	309
selection	309
configuration menu.....	163
configuring routing information protocol	213
connecting	
via console	18
connection timeout (Real Server Menu option).....	268
console port	
connecting	18
content	
SLB real server group option.....	259

cost	
STP information	64
STP port option	191
counters, No Server Available (dropped frames)...	151
CPU statistics.....	156
CPU utilization	156
cur (system option).....	172, 175, 179
current bindings	151

D

date	
setup	30
system option	168
daylight savings time	175
debugging.....	311
default gateway	
information	67
interval, for health checks	203
metrics	248
round robin, load balancing for.....	248
default password	25
delete	
ARP entry.....	317
FDB entry.....	314
deny (filtering)	151
designated port.	71
diff (global) command, viewing changes	165
dip (destination IP address for filtering).....	276
direct (IP route type).....	69
directed broadcasts	206
DISABLED (port state).....	64
disconnect idle timeout	26
dmask	
destination mask for filtering.....	276
DNS statistics	122
Domain Name System (DNS)	
health checks.....	260
downloading software.....	306
dropped frames (No Server Available) counter.....	151
dump	
configuration command.....	249
maintenance.....	311
state information.....	323
duplex mode	
link status	52, 91
dynamic routes	318

E

EtherChannel	
as used with port trunking	192

F

factory configuration block.....	309
factory default configuration	26, 27, 28
Fast Uplink Convergence	187
FDB statistics	109
File Transfer Protocol	143
filter statistics	137
filtered (denied) frames	151
filters	
IP address ranges	276
Final Steps	37
first-time configuration.....	26, 27 to 42
fixed	
IP route tag.....	70
flag field	72
flow control.....	52, 91
configuring.....	183
setup.....	32
forwarding configuration	
IP forwarding configuration.....	206
forwarding database (FDB).....	311
delete entry.....	314
Forwarding Database Information Menu	57
Forwarding Database Menu	313
forwarding state (FWD)	59, 63, 64
FTP server health checks	260
FTP SLB maintenance statistics	144
FTP SLB statistics dump	145
fwd (STP bridge option).....	190
FwdDel (forward delay), bridge port.....	63

G

gig (Port Menu option).....	181
Gigabit Ethernet	
configuration	181
Gigabit Ethernet Physical Link.....	181
global commands.....	47
grace	
graceful real server failure	292
Greenwich	175
Greenwich Mean Time (GMT).....	175
group.....	136
gtcfg (TFTP load command).....	250

H

hash metric	263
health checks	256
default gateway interval, retries	203
IDSLB	260
layer information	84
parameters for most protocols	260
redirection (rport)	275
retry, number of failed health checks	203
script	295
WAP	296
hello	
STP information	63
help	47
host routes	214
Hot Standby Router on VLAN (HSRV)	
use with VLAN-tagged environment	241
VRRP priority increment value	248
Hot Standby Router Protocol (HSRP)	
priority increment value for L4 client ports	247
use with VRRP	241, 245
VRRP priority increment value	247
Hot Standby Router VLAN (HSRV)	
use with VRRP	245
hot-standby failover	242
HP-OpenView	17
hprompt	
system option	168
HSRP. <i>See</i> Hot Standby Router Protocol.	
HSRV. <i>See</i> Hot Standby Router Protocol.	
HTTP	
application health checks	260
HTTP health checks	
on any port (aphttp)	294

I

ICMP statistics	122
idle timeout	
overview	26
IDSLB health checks	260
IEEE standards	
802.1d Spanning-Tree Protocol	63, 188
IGMP statistics	124
image	
downloading	306
software, selecting	307
IMAP server health checks	260

imask (IP address mask)	291
incorrect VIPs (statistic)	151
incorrect Vports (dropped frames counter)	151
indirect (IP route type)	69

Information

IGMP Information	80
IGMP Multicast Router Information. 80, 81, 320, 321	
Trunk Group Information	64
Information Menu	51
Interface change stats	116
interface statistics	125
IP address	34
ARP information	71
BOOTP	22
configuring default gateway	203
filter ranges	276
IP interface	34
local route cache ranges	207
IP address mask (mmask)	179
IP address mask for SLB	291
IP configuration via setup	34
IP forwarding	233
directed broadcasts	206
local networks for route caching	206
IP forwarding information	67
IP Information Menu	67, 82
IP interface	202
active	244
configuring address	202
configuring VLANs	202
IP interfaces	34, 69
information	67
IP route tag	70
priority increment value (ifs) for VRRP	247
IP network filter configuration	208
IP port configuration	233
IP Route Manipulation Menu	317
IP routing	34
tag parameters	70
IP Static Route Menu	205
IP statistics	117
IP subnet mask	35
IP switch processor statistics	111

L

l4apw (L4 administrator system option)	180
LACP	196

Layer 2 Menu.....	56
Layer 3 Menu.....	66
Layer 4	
administrator account	25
Layer 4 processing	
active	244
layer 7 SLB maintenance statistics	140
layer 7 SLB string statistics	139
layer7 redirection statistics	138
LDAP version	294
LEARNING (port state).....	63, 64
least connections (SLB Real Server metric)	263
link	
speed, configuring.....	183
Link Aggregation Control Protocol	196
link status	52
command.....	91
duplex mode	52, 91
port speed	52, 91
Link Status Information	91
linkt (SNMP option)	178
LISTENING (port state).....	64
lmask (routing option).....	67
lnet (routing option).....	67
local (IP route type)	69
local network for route caching.....	206
local route cache	
IP address ranges for	207
log	
syslog messages.....	169

M

MAC (media access control) address..	53, 54, 57, 71, 313
switch location	22
Main Menu	45
Command-Line Interface (CLI)	26
summary.....	46
Maintenance Menu	311
management module.....	18
Management Processor (MP).....	315
display MAC address	53, 54
manual style conventions	15
martian	
IP route tag (filtered).....	70
IP route type (filtered out).....	69

mask	
IP interface subnet address	202
mation	64
MaxAge (STP information)	63
mcon (maximum connections)	151, 261
MD5 cryptographic authentication	217
MD5 key.....	220
media access control. <i>See</i> MAC address.	
metric	
SLB real server group option	259
metrics, SLB	262
minimum misses (SLB real server metric).....	262
Miscellaneous Debug Menu.....	315
mmask	
system option	179
mnet	
system option	179
monitor port	185
mp	
packet.....	154
MP. <i>See</i> Management Processor.	
multicast	
IP route type	69
mxage (STP bridge option).....	190

N

nbr change statistics	115
Network Address Translation (NAT)	
filter action.....	275
network management	17
non TCP/IP frames	151
notice	168
NTP server menu.....	174
NTP synchronization.....	175
NTP time zone	175

O

octet counters	135
online help	47
operating mode, configuring	183
operations menu	299
operations-level BGP options.....	304
operations-level IP options	303
Operations-Level Port Options.....	301
operations-level SLB options	302
operations-level VRRP options	303

ospf	
area index	215, 216
authentication key	220
configuration	215
cost of the selected path	219
cost value of the host	222
dead, declaring a silent router to be down	219
dead, health parameter of a hello packet	221
export	223
fixed routes	225
general	113
global	113
hello, authentication parameter of a hello packet	221
host entry configuration	222
host routes	215
interface	215
interface configuration	219
link state database	216
Not-So-Stubby Area	217
priority value of the switch interface	219
range number	215
redistribution menu	215
route redistribution configuration	223
spf, shortest path first	217
stub area	217
summary range configuration	218
transit area	217
transit delay	219
type	217
virtual link	215
virtual link configuration	220
virtual neighbor, router ID	221
OSPF Database Information	78
OSPF general	75
OSPF General Information	76
OSPF Information	75
OSPF Information Route Codes	79
OSPF statistics	112
overflow server activations	151
overflow servers	256
P	
panic	
command	323
switch (and Maintenance Menu option)	311
parameters	
tag	70
type	69
Passive FTP SLB Parsing Statistics	144
Password	
user access control	180
password	
administrator account	25
default	25
L4 administrator account	25
user account	24
VRRP authentication	246
passwords	24
peer proxy IP address (PIP) configuration	298
PeerPIP	298
persistent bindings	
real server	268
ping	48, 255
PIP	297
poisoned reverse, as used with split horizon	213
POP3	
server health checks	260
port configuration	181
Port Fast Forwarding	182
port flow control. <i>See</i> flow control.	
Port Menu	
configuration options	181
configuring Gigabit Ethernet (gig)	181
port mirroring	
configuration	184
Port number	91
port speed	52, 91
port states	
UNK (unknown)	59
port trunking	
description	192
port trunking configuration	192
ports	
configuration	31
disabling (temporarily)	184
information	92
IP status	67
membership of the VLAN	57, 65
priority	63
SLB state information	84
STP port priority	191
VLAN ID	52, 92

preemption	
assuming VRRP master routing authority.....	240
virtual router	239, 243
priority	
virtual router	243
priority (STP port option).....	191
prisrv	
primary radius server.....	171
proxies	
IP address translation.....	257
proxy IP address (PIP)	84
proxy IP address (PIP) configuration	297
ptcfg (TFTP save command)	250
PVID (port VLAN ID).....	52, 92
pwd.....	48

Q

quiet (screen display option).....	48
------------------------------------	----

R

RADIUS	
server authentication	260
RADIUS server menu	171
read community string (SNMP option)	177
real server	
statistics.....	135
real server group options	
add.....	262
real server group SLB configuration.....	259
real server group statistics	136
real server groups	
combining servers into.....	259
statistics.....	136
real server SLB configuration	254
real servers	
backup.....	261
priority increment value (reals) for VRRP	247
SLB state information	84
reboot.....	311, 323
receive flow control	32, 183
redir (SLB filtering option).....	275
reference ports	59
referenced port	71
remote monitoring on the port (rmon).....	301
restarting switch setup.....	29
retries	
radius server.....	171

retry	
health checks for default gateway	203
rip	
IP route tag.....	70
RIP. <i>See</i> Routing Information Protocol.	
round robin	
as used in gateway load balancing	248
roundrobin	
SLB Real Server metric	263
route	
cache configuration	207
route statistics.....	119
router hops	227
routing information protocol	
configuration	213
Routing Information Protocol (RIP).....	70
options.....	213
poisoned reverse	213
split horizon	213
version 1 parameters	213
rport	
SLB virtual server option	267
RTSP SLB statistics	146
rx flow control.....	32
Rx/Tx statistics.....	114

S

save (global command)	165
noback option	166
save command.....	309
script	
health checks	295
scriptable health checks configuration.....	295
secret	
radius server	171
secsrv	
secondary radius server	171
Secure Shell	170
Server Load Balancing	
information	84
operations-level options	302
real server weights.....	255
server load balancing	
client traffic processing	283
metrics.....	262
port options	284
server traffic processing	283
server load balancing configuration options.....	251

Server Load Balancing Maintenance Statistics Menu...		SLB real server group option	
142, 143, 150		application health checking	260
server port mapping	84	health checking	260
server traffic processing	283	metric	259
Session Binding Table	256	SLB real server option	
session identifier	265	backup	256
setup		intr (interval)	256
configuration	249	maxcon (maximum connections)	255
setup command, configuration	249	name, alias for each real server	255
setup facility	26, 27	restr (restore) SLB real server UDP option	256
BOOTP	31	retry	256
IP configuration	34	RIP, real server IP address	255
IP subnet mask	35	submac	257
port auto-negotiation mode	32	tmout (time out)	256
port configuration	31	weights	255
port flow control	32	smask	
restarting	29	source mask for filtering	276
Spanning-Tree Protocol	31	smtp	168
starting	28	SMTP server health checks	260
stopping	29	snap traces	
system date	30	buffer	315
system time	30	SNMP	17, 96
VLAN name	33	HP-OpenView	17
VLAN tagging	32	menu options	177
VLANs	33	set and get access	177
SFD statistics		SNMP Agent	337
mp specific	156	SNMP statistics	158
shortcuts (CLI)	50	SNMP Support	
SIP (source IP address for filtering)	276	optional setup for SNMP support	38
SLB filtering option		software	
action	275	image	306
SLB Information	84	image file and version	53, 54
SLB layer7 statistics	138	SP specific statistics	156
SLB real server group health checks		spanning tree	
arp	260	configuration	188
dns	260	Spanning-Tree Protocol	64, 165
ftp	260	bridge aging option	190
http	260	bridge parameters	190
icmp	260	bridge priority	63
imap	260	port cost option	191
ldap	260	port priority option	191
radius	260	root bridge	63, 190
script	260	setup (on/off)	31
smtp	260	switch reset effect	310
sslh	260	split horizon	213
tcp	260	SSL	268
udpdns	260	secure socket layer statistics	142
wsp	260	stacking commands (CLI)	50
wtls	260	starting switch setup	28

state (STP information)	64
state information, client system	268
static	
IP route tag	70
static route	
rem	205
static routes	
Routing Information Protocol (RIP)	213
static route	
add	205
statistics	
group	136
management processor	153
Statistics Menu	95
stopping switch setup	29
subnet address mask configuration	
IP subnet address	202
subnet mask	35
subnets	34
IP interface	202
switch	
name and location	53, 54
resetting	310
Switch Processor (SP)	315
display trace buffer	315
SYN attack detection configuration	293
sync	302
synchronization	
VRRP switch	289, 302
syslog	
system host log configuration	169
system	
contact (SNMP option)	177
date and time	53, 54
information	54
location (SNMP option)	177
System Information	53
System Maintenance Menu	313

system options	
admpw (administrator password)	181
BOOTP	168
cur (current system parameters)	172, 175, 179
date	168
hprompt	168
l4apw (Layer 4 administrator password)	180
login banner	168
mmask	179
mnet	179
time	168
tnet	179
tport	179
usrpw (user password)	180
wport	178
system parameters, current	172, 175, 179

T

tab completion (CLI)	50
tacacs	172
TACACS+	172
TCP	111
fragments	151, 265
health checking using	256
health checks	260
source and destination ports	274
TCP statistics	127, 155
Telnet	
BOOTP	22
configuring switches using	249
telnet	
radius server	172
Telnet support	
optional setup for Telnet support	38
text conventions	15
TFTP	306
PUT and GET commands	250
TFTP server	250
thash	193
time	
setup	30
system option	168
timeout	
radius server	172
timeouts	
idle connection	26
timers kickoff	116

tnet	
system option	179
tnport	
system option	179
TPCP (Transparent Proxy Cache Protocol)	292
trace buffer	315
Switch Processor	315
traceroute	48
Tracking	
VRRP	238
transmit flow control	32, 183
transparent proxies, when used for NAT	275
trunk group failover	192
Trunk Group Information	64
trunk hash	193
trunk hash algorithm	193
tx flow control	32
type of area	
ospf	217
type parameters	69
typographic conventions, manual	15
tzone	175
U	
UCB statistics	155
UDP	111
datagrams	151
server status using	256
source and destination ports	274
UDP statistics	129
unknown (UNK) port state	59
Unscheduled System Dump	323
upgrade, switch software	306
URL for health checks	84
user access control configuration	179
user account	24
usrpw (system option)	180
Uuencode Flash Dump	321
V	
verbose	48
vip	
advertisement of virtual IP addresses as Host Routes	214
IP route tag	70
virtual IP address (VIP)	84
virtual port state, SLB information about	84
virtual router	
description	237
master mode	244
priority	243
tracking criteria	240
virtual router group	
VRRP priority tracking	242
virtual router group configuration	242
virtual router group priority tracking	244
Virtual Router Redundancy Protocol (VRRP)	
authentication parameters for IP interfaces	246
group options (prio)	243
operations-level options	303
password, authentication	246
priority election for the virtual router	238
priority tracking options	226, 229, 240
Virtual Router Redundancy Protocol configuration	236
virtual routers	
HSRP failover	241, 245
HSRP priority increment value	247
HSRV	245
HSRV priority increment value	248
increasing priority level of	240
incrementing VRRP instance	241
master preemption (preem)	243
master preemption (prio)	239
priority increment values (vrs) for VRRP	247
virtual server SLB statistics	137
virtual servers	262
SLB state information	84
statistics	137
VLAN	
active port	244
configuration	198
VLAN tagging	
port configuration	182
port restrictions	199
setup	32
VLANs	34
ARP entry information	71
information	65
interface	35
name	57, 65
name setup	33
port membership	57, 65
setting default number (PVID)	181
setup	33
tagging	32, 52, 92, 199
VLAN Number	65

VRID (virtual router ID)	238, 242
VRRP	
interface configuration.....	246
master advertisements	239
tracking	238
tracking configuration	247
VRRP Information	82
VRRP master advertisements	
time interval.....	243
VRRP statistics	121

W

WAP	
health checks.....	296

WAP health check	
wspport.....	296
wtlsprt	296
WAP health check configuration	296
WAP SLB statistics	148
watchdog timer.....	311
weights	
for SLB real servers.....	264
setting virtual router priority values	247
wport.....	178
write community string (SNMP option)	177
wspport	
WAP health check.....	296
wtlsprt	
WAP health check.....	296

