

Contents

About This Guide 1

Purpose and Structure of the Guide	1
Related Documents	3

PowerNet MIB Structure 4

Traps	4
OIDs	5

Manage Agents and Management Cards 8

Locate the OIDs	8
Monitor a PowerNet Agent	9
Manage an SNMP Agent of a Hardware Device	10

Manage an Uninterruptible Power Supply 14

Locate the OIDs	14
View and Set Uninterruptible Power Supply Identification Parameters	16
View Battery Status	17
View Data on Uninterruptible Power Supply Input/Output Voltage .	19
Configure an Uninterruptible Power Supply	22
Control the Operation of the Uninterruptible Power Supply	26
Test an Uninterruptible Power Supply	28
View Communication Status	29
Manage a 3-phase Uninterruptible Power Supply	30
Synchronize the Actions of Uninterruptible Power Supplies	35
View the State of an Uninterruptible Power Supply	37
Manage Outlet Groups of an Uninterruptible Power Supply	39
Perform Diagnostics on a Symmetra Uninterruptible Power Supply .	41

Manage an Environmental Monitor 50

Locate the OIDs	50
---------------------------	----



Manage an External Environmental Monitor	51
Manage an Integrated Environmental Monitor	54

Manage an Environmental Management System 57

Locate the OIDs	57
View Identification Parameters	58
Control an Environmental Management System	59
Configure an Environmental Management System	61
View Status of the Environmental Management System	64

Manage a Rack Air Removal Unit 68

Locate the OIDs	68
View Identification Parameters	69
Configure a Rack Air Removal Unit	70
View the Status of a Rack Air Removal Unit	71

Manage MasterSwitch 73

Locate the OIDs	73
View Identification Parameters	74
Control and Configure the MasterSwitch Unit.	75
Control and Configure Individual Outlets.	76

Manage MasterSwitch VM 77

Locate the OIDs	77
View Identification Parameters	78
Control and Configure MasterSwitch VM Units	79
View the Status of a MasterSwitch VM Unit	81
Control and Configure MasterSwitch VM Outlets	82
View Status of Outlets of a MasterSwitch VM Unit	84

Manage MasterSwitch Plus 85

Locate the OIDs	85
View Identification Parameters	86
Control and Configure MasterSwitch Plus Units	87



View Status about a MasterSwitch Plus Unit	89
Control and Configure Outlets of a Unit	90
View the Status of MasterSwitch Plus Outlets	98

Manage a Rack PDU 99

Locate the OIDs	99
Name the PDU and View Identification Parameters	100
View Rated Power and Number of Phases	101
View and Configure Load Thresholds by Phase.	102
View the Load Status of Each Phase	103
Control Outlets of a Rack PDU	104
Configure Outlets.	106
View Status of an Outlet and Power Supply	107

Manage an Automatic Transfer Switch 108

Locate the OIDs	108
View Identification Parameters of the ATS	109
View I/O Data, Power Supply Voltages, and Calibration Factors . .	110
Reset the ATS and Clear Its Alarms	111
Configure the ATS	112
View the Status of the ATS.	113
Name and View the Status of Input Feeds	114
Name and View the Status of Output Feeds.	115

Manage a NetworkAIR® FM System 117

Locate the OIDs	117
View Identification Parameters	118
View Status of the System and Modules.	119

Manage a NetworkAIR® Portable Air Conditioner 121

Locate the OIDs	121
View Identification Parameters	122
View Status	123

PowerNet MIB Traps 124

Overview	124
PowerNet MIB Trap Definitions.	127
Symmetra Uninterruptible Power Supply Subtraps.	165

Index 168

About This Guide

Purpose and Structure of the Guide

Purpose

This guide documents version 3.6.4 of the APC PowerNet® Management Information Base (MIB). Use this guide to assist you in managing products that can be monitored and configured with the Simple Network Management Protocol (SNMP).



The Management Information Base (MIB) has been updated a number of times since this guide has been revised. Therefore, if your product requires a MIB version later than 3.6.4, some Object Identifiers (OIDs) and traps related to your product might not be documented in this guide. For OIDs added in MIB versions later than 3.6.4, use your MIB browser to see their descriptions. Trap definitions for traps in MIB versions later than 3.6.4 are at the end of the MIB file itself (*powernetversion_number.mib*).

Structure

This guide contains the following sections:

- This initial section, **"About This Guide" on page 1.**
- Sections on individual products, the tasks you can perform with SNMP to manage those products, and the OIDs (Object Identifiers) you use for those tasks.



Not all products documented in this reference guide are available to IBM customers.

- A section on SNMP Traps, **"PowerNet MIB Traps" on page 124.**



See the section on the product you want to manage, find the OIDs listed under the task you need to perform, and then use your MIB browser to identify the values you can get or set with those OIDs.

Terminology

This guide uses the terms Network Management Card and Management Card to apply to the Embedded Network Module that is built into some models of IBM uninterruptible power supplies as well as to the Network Management Card that is installed in a card slot of an uninterruptible power supply.

Related Documents

This guide describes how to use the PowerNet MIB only.



See the *User's Guide* and any other documentation shipped with your product for information about the product and the other interfaces you can use to manage it.

See the documentation provided with your Network Management Station (NMS) for information about your NMS.

For assistance with any IBM uninterruptible power supply, contact IBM Customer Support.

PowerNet MIB Structure

Traps

Network Management Cards, devices, and agents can send traps to a Network Management Station (NMS) when specific events occur. The trap receiver definitions that a particular Network Management Card, device, or agent uses determines which NMSs can receive traps, and the MIB interprets the traps.



See **"PowerNet MIB Traps"** on page 124.

OIDs

APC products that can use OIDs

The PowerNet MIB OIDs allow an NMS to use its SNMP browser to manage the following:

- Any product that relies on an external, pre-installed, or embedded (built-in) Network Management Card for its network interface and that has its SNMP access controls set to allow an NMS to have SNMP access.
- A PowerNet Agent and the devices it controls. A PowerNet Agent has limited control over an uninterruptible power supply and does not use SNMP access controls.

SNMP access controls

The Network Management Card or the device with an embedded Network Management Card has a console program to define specific SNMP access values for up to four SNMP channels. You can use the program to set any of these access controls:

- Disable SNMP access completely to prevent SNMP access by any NMS.
- Use an NMS IP Address as a SNMP channel value to limit channel access to only the defined NMS.
- Define a non-default password for an SNMP channel so that only an NMS that knows the password can access the channel.
- Configure the access or an NMS to an SNMP channel as write access, read access, or no access.



For more information on SNMP access controls, see the *User's Guide* for your Network Management Card or for your device that has an embedded Network Management Card.

Structure of the OID hierarchy in the SNMP browser

The PowerNet MIB fits into a hierarchical structure within the categories of your SNMP browser. For example, for an HP OpenView for Windows SNMP browser, the OID categories from the top of the structure down to the top category of PowerNet MIB OIDs are as follows:

- **[iso]** (for International Standards Organization)
- **[org]** (for organization)
- **[dod]** (for Department of Defense)
- **[internet]**
- **[private]**
- **[enterprises]**
- **[apc]** (for American Power Conversion)

Structure of the OID hierarchy in the PowerNet MIB

In the hierarchical structure of the PowerNet MIB, the **[apc]** category of OIDs is at the top, and individual OIDs are in specific OID categories or within specific *OID tables*.



See **"Tabled OIDs" on page 7.**

There are two categories under **[apc]**:

- **[products]** for OIDs to manage specific products.
- **[apcmgmt]** for OIDs that affect the operation of hardware-based SNMP agents (for example, Network Management Cards and MasterSwitch units).



See **"Manage Agents and Management Cards" on page 8.**

There are three categories under **[products]**:

- **[hardware]** contains sub-categories for each type of hardware product that you can manage using PowerNet MIB OIDs. The remaining major sections of this manual (except for the last major section, on traps) provide lists and descriptions of these OIDs.
- **[software]** contains one sub-category **[powerNetSubAgent]**. The sub-category consists of read-only OIDs to monitor a software PowerNet agent only.



See **"Manage Agents and Management Cards" on page 8.**

- **[system]** contains read-only OIDs that identify models of uninterruptible power supplies and other devices by unique numbers that other OIDs can reference. For example, the system OIDs in other OID categories of the PowerNet MIB use a PowerNet MIB **[system]** OID number for the MIB-II **[sysObjectID]** value.

Tabled OIDs

For any PowerNet MIB OID category listed in the SNMP browser, you can access a list of the current values for all OIDs in that category and in all sub-categories below it in the hierarchy. However, OIDs grouped in a table do not appear in the list. To access the current values of OIDs in an OID table, select the OID table (always enclosed in braces { }) in the SNMP browser. For example, to access the OIDs that define all four trap receivers for a device, select **{mconfigTrapReceiverTable}** in the SNMP browser.

Manage Agents and Management Cards

Locate the OIDs

To find the OIDs to perform the tasks described in **"Monitor a PowerNet Agent" on page 9**, use your MIB browser to select, in order, the following OID categories:

- [apc]
- [products]
- [software]
- [powerNetSubAgent]
- [powerNetSoftwareSystem] or [powerNetSoftwareConfig]

To find the OIDs to perform the tasks described in **"Manage an SNMP Agent of a Hardware Device" on page 10**, use your MIB browser to select, in order, the following OID categories:

- [apc]
- [apcmgmt]
- Any of the following:
 - [mcontrol]
 - [mconfig]
 - [mtrapargs]
 - [mfiletransfer]

Monitor a PowerNet Agent

Use the **[powerNetSubAgent]** OIDs to view information about a PowerNet agent. These OIDs are in two sub-categories, **[powerNetSoftwareSystem]** and **[powerNetSoftwareConfig]**.

View information about an agent

Use the **[powerNetSoftwareSystem]** OIDs to view information about the agent, including its version number, the technology that it uses to implement the PowerNet MIB, and the length of time it has been running continuously on the network.

```
powerNetSoftwareSystemDescription
powerNetSoftwareOid
powerNetSoftwareSystemUpTime
```

View information about the software modules of an agent

Use the **[powerNetSoftwareConfig]** tabled OIDs to view the version number, name, and installation date (in the format *mm-dd-yy*) of any of the software modules of the agent.

```
powerNetSoftwareTableSize
{powerNetSoftwareTable}
  [powerNetSoftwareEntry]
    moduleNumber
    moduleName
    moduleVersion
    moduleDate
```

Manage an SNMP Agent of a Hardware Device

Use the **[apcmgmt]** OIDs to manage the SNMP agent of an APC hardware device, such as the following:

- The Network Management Card (installed, pre-installed, or embedded) of an uninterruptible power supply or other device.
- The PowerNet adapter for an uninterruptible power supply and Environmental Monitor.

The **[apcmgmt]** OIDs are in four subcategories: **[mconfig]**, **[mcontrol]**, **[mtrapargs]**, and **[mfiletransfer]**.

View BOOTP value; set trap receivers, date, and time

Use the **[mconfig]** OIDs to perform the following tasks:

- Identify whether BOOTP is enabled (so that BOOTP provides the IP configuration for the device) or disabled (so that the device uses its stored IP configuration).
- Configure up to four NMSs as trap receivers.



See **"How to define trap receivers" on page 125.**

- Configure the date and time on a Network Management Card or other device.

```

mconfigBOOTPEnabled
mconfigNumTrapReceivers
{mconfigTrapReceiverTable}
  [mconfigTrapReceiverEntry]
    trapIndex
    receiverAddr
    communityString
    severity
    acceptThisReceiver
    receiveTrapType
mconfigClock
mconfigClockDate
mconfigClockTime
    
```

Control the restarting behavior of the agent

Use the one **[mcontrol]** OID to control whether the agent restarts now, continues without restarting, or restarts the next time the system starts. (Value 3 is obsolete.)

```
mcontrolRestartAgent
```

Enable traps to use a specific argument type

Use the **[mtrapargs]** OIDs to enable traps to use an argument of a specific type (integer, IP address, octet string, Gauge, or TimeTicks), which might not be defined as part of the MIB.

```
mtrapsapargsInteger
mtrapsapargsIpAddress
mtrapsapargsString
mtrapsapargsGauge
mtrapsapargsTimeTicks.
```

Enable transfer of any file that an adapter recognizes

Use the **[mfiletransfer]** OIDs, which are supported only for a PowerNet adapter, to allow the transfer of any type of file that the adapter can recognize. The **[mfiletransfer]** OIDs are in three sub-categories: **[mfiletransferStatus]**, **[mfiletransferConfig]**, and **[mfiletransferControl]**.

View the results of the most recent file transfer attempt. Use the one OID in the **[mfiletransferStatus]** category to find out whether the most recent attempt to transfer a file succeeded or failed, and if it failed, the reason for the failure.

Provide the required parameters to transfer the file. Use the OIDs in the three subcategories under the **[mfiletransferConfig]** to provide the following parameters needed to transfer the file:

- The file name and path.
- The IP address for the remote TFTP server (if you are using TFTP for the transfer).
- The IP address, user name, and password for the remote FTP server (if you are using FTP for the file transfer).

The **[mfiletransferConfigSettings]** subcategory has one OID:

```
mfiletransferConfigSettingsFileName
```

The **[mfiletransferConfigTFTP]** subcategory has one OID:

```
mfiletransferConfigTFTPServerAddress
```

The **[mfiletransferConfigFTP]** subcategory has these OIDs:

```
mfiletransferConfigFTPServerAddress  
mfiletransferConfigFTPServerUser  
mfiletransferConfigFTPServerPassword
```

Perform the file transfer. Use the OID in the **[mfiletransferControl]** category to download the file from the TFTP server or from the FTP server.

```
mfiletransferControlInitiateFileTransfer
```

Manage an Uninterruptible Power Supply

Locate the OIDs

In a MIB browser, select, in order, these OID categories to locate the OIDs to manage an uninterruptible power supply through its Network Management Card or its PowerNet agent:

- [apc]
- [products]
- [hardware]
- [ups]
- Any of the following subcategories:
 - [upsIdent]
 - [upsBattery]
 - [upsInput]
 - [upsOutput]
 - [upsConfig]
 - [upsControl]
 - [upsTest]
 - [upsComm]
 - [upsPhase]
 - [upsSyncCtrlGroup]
 - [upsState]
 - [upsOutletGroups]
 - [upsDiagnostics]

In the subcategories of the **[ups]** category, the Network Management Card of an uninterruptible power supply can use all OIDs, but a PowerNet agent can use only OIDs supported for such agents in the MIB version 2.2. If the agent-to-uninterruptible power supply communication uses simple (basic) signaling, a PowerNet agent cannot use smart (advanced) signaling OIDs.

View and Set Uninterruptible Power Supply Identification Parameters

Use the **[upsIdent]** OIDs to view uninterruptible power supply identification parameters that were set at the factory and to configure a name for the uninterruptible power supply. The **[upsIdent]** OIDs are in two sub-categories, **[upsBasicIdent]** and **[upsAdvIdent]**.

View the model name and set the device name for an uninterruptible power supply

Use the **[upsBasicIdent]** OIDs to view the model name of the uninterruptible power supply and to configure a unique name for the uninterruptible power supply.

All Network Management Cards and PowerNet agents can use these OIDs.

```
upsBasicIdentModel  
upsBasicIdentName
```

Identify firmware revision, age, and serial number

Use the **[upsAdvIdent]** OIDs to identify the firmware version, date of manufacture, and serial number of the uninterruptible power supply.

All Network Management Cards can use these OIDs. A PowerNet agent can use these OIDs only if it communicates with the uninterruptible power supply by using smart signaling (advanced signaling).

```
upsAdvIdentFirmwareRevision  
upsAdvIdentDateOfManufacture  
upsAdvIdentSerialNumber
```

View Battery Status

Use the **[upsBattery]** OIDs to view the status of uninterruptible power supply batteries. The **[upsBattery]** OIDs are in two sub-categories, **[upsBasicBattery]** and **[upsAdvBattery]**.

Check adequacy of batteries, and set replacement date

Use the **[upsBasicBattery]** OIDs for these tasks:

- View whether batteries can support their load.
- View when the transfer to battery power occurred.
- Set or view the date of the last battery replacement in *mm/dd/yy* or *mm/dd/yyyy* format.

All Network Management Cards and PowerNet agents can use these OIDs.

```
upsBasicBatteryStatus
upsBasicTimeOnBattery
upsBasicBatteryLastReplaceDate
```

View number, capacity, and failure data of batteries

Use the **[upsAdvBattery]** OIDs to view remaining battery capacity, internal uninterruptible power supply temperature, estimated time batteries can provide output power, and (for Matrix-UPS and Smart-UPS XL uninterruptible power supplies), the total number of batteries and the number that need replacement.

All Network Management Cards can use these OIDs. A PowerNet agent can use these OIDs only if it communicates with the uninterruptible power supply by using smart signaling (advanced signaling).

```
upsAdvBatteryCapacity  
upsAdvBatteryTemperature  
upsAdvBatteryRunTimeRemaining  
upsAdvBatteryReplaceIndicator  
upsAdvBatteryNumOfBattPacks  
upsAdvBatteryNumOfBadBattPacks
```

View Data on Uninterruptible Power Supply Input/Output Voltage

View information on uninterruptible power supply input voltage

Use the **[upsInput]** OIDs to view information about the uninterruptible power supply input (utility line) voltage. These OIDs are grouped in two sub-categories, **[upsBasicInput]** and **[upsAdvInput]**.

View the current AC input voltage phase of the uninterruptible power supply. Use the one OID in the **[upsBasicInput]** category to view the current AC input voltage phase of the uninterruptible power supply.

All Network Management Cards and PowerNet agents can use this OID.

```
upsBasicInputPhase
```

View data on input voltage, frequency, and battery operation. Use the **[upsAdvInput]** OIDs to view the following:

- The current input voltage and frequency.
- The maximum and minimum input voltage during the last minute.
- The reason for the most recent transfer to battery operation. (A PowerNet agent can report all causes except a self-test and can report the rate of voltage change; a Network Management Card can report all data.)

All Network Management Cards can use these OIDs. A PowerNet agent can use these OIDs only if it communicates with the uninterruptible power supply by using smart signaling (advanced signaling).

```
upsAdvInputLineVoltage  
upsAdvInputMaxLineVoltage  
upsAdvInputMinLineVoltage  
upsAdvInputFrequency  
upsAdvLineFailCause
```

View information on uninterruptible power supply output voltage

Use the **[upsOutput]** OIDs to view information about the uninterruptible power supply output voltage. The **[upsOutput]** OIDs are in two sub-categories, **[upsBasicOutput]** and **[upsAdvOutput]**.

View the uninterruptible power supply operational status and mode of operation. Use the one OID in the **[upsBasicOutput]** category to view the current operational status of the uninterruptible power supply:

- Whether it is actively providing output power.
- Whether the power is from input voltage or from its batteries.
- Whether it is compensating for input voltage that is too high or too low.
- Whether it is in any type of bypass mode and how it entered that mode.
- Whether it is restarting.
- Whether it is in sleep mode, with outlets turned off waiting for input power to return, or in timed sleep mode.

All Network Management Cards and PowerNet agents can use this OID.

```
upsBasicOutputStatus
```

View output voltage, frequency, load, and current of the uninterruptible power supply. Use the **[upsAdvOutput]** OIDs to view the output voltage, the output voltage frequency, and the equipment load (as a percentage of rated load capacity) of the uninterruptible power supply.

All Network Management Cards can use these OIDs. A PowerNet agent can use these OIDs only if it communicates with the uninterruptible power supply by using smart signaling (advanced signaling).

```
upsAdvOutputVoltage  
upsAdvOutputFrequency  
upsAdvOutputLoad  
upsAdvOutputCurrent
```

Configure an Uninterruptible Power Supply

Use SETs (SNMP write commands) to the **[upsConfig]** OIDs to define how the uninterruptible power supply responds to specific operating conditions. The **[upsConfig]** OIDs are in two sub-categories, **[upsBasicConfig]** for basic-signaling uninterruptible power supplies, and **[upsAdvConfig]** for smart-signaling uninterruptible power supplies. All uninterruptible power supplies except Back-UPS models support smart signaling.

Name, add, delete, or set VA ratings for devices of an uninterruptible power supply

Use the OIDs in the **[upsBasicConfig]** category to do the following:

- View the number of devices connected to the uninterruptible power supply, and identify the outlet to which each device is connected.
- Configure a device name and VA rating for any of the devices.
- Add or delete a device.

The **[upsBasicConfig]** OIDs are for simple-signaling connections, which provide basic power management and protection but offer few additional configuration and monitoring options. (Back-UPS models support only simple signaling.)

```
upsBasicConfigNumDevices
{upsBasicConfigDeviceTable}
  [upsBasicConfigDeviceEntry]
    deviceIndex
    deviceName
    vaRating
    acceptThisDevice
```

Configure uninterruptible power supply operating and shutdown parameters

Use the OIDs in the **[upsAdvConfig]** category to configure or view operating and shutdown parameters for an uninterruptible power supply connected in smart-signaling mode.

A Management Card or PowerNet agent can use OIDs in the **[upsAdvConfig]** category to perform the following tasks:

- Define nominal output voltage of the uninterruptible power supply.
- Define the high and low thresholds for input voltage. When one of these thresholds is violated, the uninterruptible power supply uses its Boost or Trim feature to compensate for the out-of-range voltage, or, if the uninterruptible power supply does not support the feature, it switches to battery operation.
- Define whether the uninterruptible power supply generates an audible alarm in response to an input power failure, and set a delay for a timed alarm.
- Define the battery capacity required before the uninterruptible power supply returns from a low-battery shutdown.
- Define, for uninterruptible power supplies that have no voltage regulator, how sensitive the uninterruptible power supply is to input line abnormalities (“noise” on the line).
- Define the battery runtime at or below which a low-battery condition occurs.
- Define the delay time that occurs after power returns before the uninterruptible power supply returns from sleep mode.
- Obtain the allowed values for all OIDs that you can set in the **[upsAdvConfig]** group.

Only a Network Management Card can use OIDs in the **[upsAdvConfig]** category to perform these tasks:

- Define delay times for low-battery shutdown, graceful turn-off, restart, and sleep mode.
- Define how long an uninterruptible power supply remains in timed sleep mode.
- Reset all configurable EEPROM values to factory-set defaults.
- Set the front-panel password for Matrix-UPS and Symmetra uninterruptible power supply models.
- View the number of dip switch settings of the uninterruptible power supply and the status of each (on or off).
- Define how long before battery exhaustion the uninterruptible power supply will turn off power to its load.
- View the OID for any configurable uninterruptible power supply value and the set of values allowed.
- Configure the uninterruptible power supply Battery Cabinet amp-hour settings, the position of the mounted uninterruptible power supply (rack or tower), and the output frequency tolerance range of the uninterruptible power supply.
- Configure whether the uninterruptible power supply will switch to bypass mode or turn off power to its load when input frequency or voltage is out of range.
- Configure the alarm settings for inadequate redundancy, output overload, and insufficient runtime remaining.
- Configure how the uninterruptible power supply scales its output voltage readings.

```

upsAdvConfigRatedOutputVoltage
upsAdvConfigHighTransferVolt
upsAdvConfigLowTransferVolt
upsAdvConfigAlarm
upsAdvConfigAlarmTimer
upsAdvConfigMinReturnCapacity
upsAdvConfigSensitivity
upsAdvConfigLowBatteryRunTime
upsAdvConfigReturnDelay
upsAdvConfigShutoffDelay
upsAdvConfigUpsSleepTime
upsAdvConfigSetEEPROMDefaults
{upsAdvConfigDipSwitchSetting}
    [upsAdvConfigDipSwitchEntry]
        dipSwitchIndex
        dipSwitchStatus
upsAdvConfigBattExhaustThresh
upsAdvConfigPassword
{upsAdvConfigAllowedSetTable}
    [apcUpsConfigEntry]
        apcUpsConfigFieldIndex
        apcUpsConfigFieldOID
        apcUpsConfigFieldValueRange
upsAdvConfigBattCabAmpHour
upsAdvConfigPositionSelector
upsAdvConfigOutputFreqRange
upsAdvConfigUPSFail
upsAdvConfigAlarmRedundancy
upsAdvConfigAlarmLoadOver
upsAdvConfigAlarmRuntimeUnder
upsAdvConfigVoutReporting
    
```

Control the Operation of the Uninterruptible Power Supply

You can use SETs (SNMP write commands) to the **[upsControl]** OIDs to directly affect the current operation of the uninterruptible power supply. The **[upsControl]** OIDs are in two sub-categories, **[upsBasicOutput]** and **[upsAdvOutput]**.

Initiate sleep mode

Use the one OID in the **[upsBasicControl]** category to put an uninterruptible power supply that is running on battery power into sleep mode. Sleep mode turns off the outlets of an uninterruptible power supply until acceptable input power returns.

All Network Management Cards and PowerNet agents can use this OID.

```
upsBasicControlConserveBattery
```

Set uninterruptible power supplies to stop, start, test alarms, or go into bypass

Synchronized Control Groups are supported for most uninterruptible power supply models of the Smart-UPS and Symmetra uninterruptible power supply product lines and for IBM uninterruptible power supplies.

Use the **[upsAdvControl]** OIDs to set an uninterruptible power supply or a synchronized control group of uninterruptible power supplies to do any of the following actions immediately, gracefully, gracefully after a delay, or (for a synchronized control group) in a synchronized manner:

- Turn off.
- Enter sleep mode.
- Turn on.
- Restart.
- Test front panel lights and audible alarm (Smart-UPS only).



Only a Network Management Card can perform synchronized control group actions; synchronized actions are not supported by PowerNet agents. PowerNet agents also do not support graceful turn-off, graceful sleep mode initiation, or graceful restart for individual uninterruptible power supplies. If a PowerNet agent turns an uninterruptible power supply off with **upsAdvControlUpsOff**, you must restart the uninterruptible power supply by using its manual switch.

Use the **[upsAdvControl]** OIDs to perform the following actions for an individual uninterruptible power supply only:

- Simulate a power failure.
- Go into bypass mode (Matrix-UPS and Symmetra uninterruptible power supply only).

```
upsAdvControlUpsOff  
upsAdvControlRebootUps  
upsAdvControlUpsSleep  
upsAdvControlSimulatePowerFail  
upsAdvControlFlashAndBeep  
upsAdvControlTurnOnUPS  
upsAdvControlBypassSwitch
```

Test an Uninterruptible Power Supply

The **[upsTest]** category has a single subcategory, **[upsAdvTest]**, for use by Network Management Cards or smart-signaling PowerNet agents. You cannot perform self-tests and calibrations for uninterruptible power supplies connected in simple-signaling mode.

Use the **[upsAdvTest]** OIDs to do the following:

- Schedule or initiate uninterruptible power supply self-tests.
- Schedule, initiate, or cancel uninterruptible power supply runtime calibrations.
- View the results of uninterruptible power supply self-tests.
- View the date of the last self-test, in *dd/mm/yy* format.

Network Management Cards cannot use the **upsAdvTestLastDiagnosticsDate** OID.



PowerNet agents cannot use the **upsAdvTestRuntimeCalibration** OID.

```
upsAdvTestDiagnosticSchedule
upsAdvTestDiagnostics
upsAdvTestDiagnosticsResults
upsAdvTestLastDiagnosticDate
upsAdvTestRuntimeCalibration
upsAdvTestCalibrationResults
upsAdvTestCalibrationDate
```

View Communication Status

Use the **[upsComm]** OID to view the status of the SNMP agent-to-uninterruptible power supply communication link of the Network Management Card. You cannot access this OID through a PowerNet agent.

```
upsCommStatus
```

Manage a 3-phase Uninterruptible Power Supply

In the **[upsPhase]** category, use the OID in the three subcategories, **[upsPhaseResetValues]**, **[upsPhaseInput]**, and **[upsPhaseOutput]**, to manage a 3-phase uninterruptible power supply.

Reset the phase input and output counters

Use an **[upsPhaseResetValues]** OID to reset the counter for the corresponding OID in the **[upsPhaseInput]** or **[upsPhaseOutput]** subcategory. For example, to reset the counter for the **upsPhaseInputMaxCurrent** OID (which reports the maximum input current) in the **[upsPhaseInput]** subcategory, issue a SET command to the OID with the same name, **upsPhaseInputMaxCurrent**, in this **[upsPhaseResetValues]** subcategory.

```
upsPhaseInputMaxVoltage  
upsPhaseInputMinVoltage  
upsPhaseInputMaxCurrent  
upsPhaseInputMinCurrent  
upsPhaseInputMaxPower  
upsPhaseInputMinPower  
upsPhaseOutputMaxCurrent  
upsPhaseOutputMinCurrent  
upsPhaseOutputMaxLoad  
upsPhaseOutputMinLoad  
upsPhaseOutputMaxPercentLoad  
upsPhaseOutputMinPercentLoad  
upsPhaseOutputMaxPower  
upsPhaseOutputMinPower  
upsPhaseOutputMaxPercentPower  
upsPhaseOutputMinPercentPower
```

Obtain the number of input feeds to the uninterruptible power supply

In the **[upsPhase]** category, use the **upsPhaseNumInputs** OID to obtain the number of input feeds to the uninterruptible power supply.

```
upsPhaseNumInputs
```

Name and view status of input feeds (phases) of the uninterruptible power supply

In the **[upsPhase]** category, use the tabled OIDs under **{upsPhaseInputTable}** to name the input feeds to the uninterruptible power supply and obtain the following information about each feed:

- Its voltage orientation, for example, single-phase, split-phase, or 3-phase (phase-to-neutral, or phase-to-phase).
- Its frequency.
- Its type (main or bypass).

```
{upsPhaseInputTable}
 [upsPhaseInputEntry]
   upsPhaseInputTableIndex
   upsPhaseNumInputPhases
   upsPhaseInputVoltageOrientation
   upsPhaseInputFrequency
   upsPhaseInputType
   upsPhaseInputName
```

View data on voltage, current, and power of an input phase

In the `[upsPhase]` category, use the tabled OIDs under `{upsPhaseInputPhaseTable}` to obtain the following information for each input phase of the uninterruptible power supply:

- The input voltage, input current, and input power now.
- The minimum and maximum value recorded for the input voltage, input current, and input power since the corresponding counters were reset by the OIDs in the `[upsPhaseResetValues]` category.



See the `upsPhaseNumInputPhases` OID in **"Name and view status of input feeds (phases) of the uninterruptible power supply" on page 31** for the number of input phases.

```
{upsPhaseInputPhaseTable}
 [upsPhaseInputPhaseEntry]
   upsPhaseInputPhaseTableIndex
   upsPhaseInputPhaseIndex
   upsPhaseInputVoltage
   upsPhaseInputMaxVoltage
   upsPhaseInputMinVoltage
   upsPhaseInputCurrent
   upsPhaseInputMaxCurrent
   upsPhaseInputMinCurrent
   upsPhaseInputPower
   upsPhaseInputMaxPower
   upsPhaseInputMinPower
```

Obtain the number of output feeds to the uninterruptible power supply

In the **[upsPhase]** category, use the **upsPhaseNumOutputs** OID to obtain the number of output feeds to the uninterruptible power supply.

```
upsPhaseNumOutputs
```

View status of each output feed (phase) of the uninterruptible power supply

In the **[upsPhase]** category, use the tabled OIDs under **{upsPhaseOutputTable}** to obtain the following information about each output feed to the uninterruptible power supply:

- Its voltage orientation, for example, single-phase, split-phase, 3-phase (phase-to-neutral, or phase-to-phase).
- Its frequency.

```
{upsPhaseOutputTable}  
 [upsPhaseOutputEntry]  
   upsPhaseOutputTableIndex  
   upsPhaseNumOutputPhases  
   upsPhaseOutputVoltageOrientation  
   upsPhaseOutputFrequency
```

View data on voltage, current, load, and power of output phases

In the `[upsPhase]` category, under `{upsPhaseOutputPhaseTable}`, use the tabled OIDs to obtain the following information for each output phase of the uninterruptible power supply:

- The output voltage, output current, output load (in VA and as a percentage of total output load capacity), output power (in Watts and as a percentage of total output power capacity) now.
- The minimum and maximum value recorded for the output current, output load, percentage of load capacity being used, output power, and percentage of output power being used since the corresponding counters were reset by the OIDs in the `[upsPhaseResetValues]` category.



See the `upsPhaseNumOutputPhases` OID in **"View status of each output feed (phase) of the uninterruptible power supply" on page 33** for the number of output phases.

```
{upsPhaseOutputPhaseTable}
 [upsPhaseOutputPhaseEntry]
   upsPhaseOutputPhaseTableIndex
   upsPhaseOutputPhaseIndex
   upsPhaseOutputVoltage
   upsPhaseOutputCurrent
   upsPhaseOutputMaxCurrent
   upsPhaseOutputMinCurrent
   upsPhaseOutputLoad
   upsPhaseOutputMaxLoad
   upsPhaseOutputMinLoad
   upsPhaseOutputPercentLoad
   upsPhaseOutputMaxPercentLoad
   upsPhaseOutputMinPercentLoad
   upsPhaseOutputPower
   upsPhaseOutputMaxPower
   upsPhaseOutputMinPower
   upsPhaseOutputPercentPower
   upsPhaseOutputMaxPercentPower
   upsPhaseOutputMinPercentPower
```

Synchronize the Actions of Uninterruptible Power Supplies

Synchronized Control Groups are supported for most uninterruptible power supply models of the Smart-UPS and Symmetra uninterruptible power supply product lines and for IBM uninterruptible power supplies.

Configure synchronized control groups

Use the OIDs in the **[upsSyncCtrlGroupConfig]** category to configure a Network Management Card to be a Synchronized Control Group member, enable or disable the group membership of the Network Management Card and configure the following parameters to be used for Synchronized Control Group actions:

- The time in seconds that the initiator of a synchronized restart or sleep action waits for all group members to regain input power before completing the restart sequence of a restart or sleep action.
- A percentage of battery capacity (an offset) that is subtracted from the Return Battery Capacity of the initiator of a synchronized restart or sleep action before that Return Battery Capacity is required of other group members.
- The MultCast IP Address of the group.

```
upsSCGMembershipGroupNumber  
upsSCGActiveMembershipStatus  
upsSCGPowerSynchronizationDelayTime  
upsSCGReturnBatteryCapacityOffset  
upsSCGMultiCastIP
```

Check the status of uninterruptible power supplies in a Synchronized Control Group

Use the **[upsSyncCtrlGroupStatus]** OIDs to view the following information about the uninterruptible power supplies of Network Management Cards that are members of a Synchronized Control Group:

- The number of active communicating members in the Synchronized Control Group.
- The IP address of any active, communicating member.
- Whether the input power of the uninterruptible power supply of a specific member is acceptable (within tolerance) or not acceptable (not within tolerance).
- Whether the uninterruptible power supply of a specific member is providing output power to the load.

```
upsSCGNumOfGroupMembers  
{upsSCGStatusTable}  
  [upsSCGStatusEntry  
    upsSCGStatusTableIndex  
    upsSCGMemberIP  
    upsSCGACInputStatus  
    upsSCGACOutputStatus
```

View the State of an Uninterruptible Power Supply

Use the **[upsState]** OIDs to display ASCII character strings containing flags representing the current state and the current faults of an uninterruptible power supply. Read the flags from left to right. Not all flags are defined; some are reserved for future use. The **[upsState]** OIDs are in two sub-categories, **[upsBasicState]** for basic-signaling (simple-signaling) uninterruptible power supplies, and **[upsAdvState]** for advanced-signaling (smart-signaling) uninterruptible power supplies. All uninterruptible power supplies except Back-UPS models support smart signaling. Not all states and not all faults are supported by or relevant to any one uninterruptible power supply model.

View the state of a basic-signaling uninterruptible power supply

Use the single OID in the **[upsBasicState]** category to display an ASCII string containing the 64 flags representing the current state of a basic-signaling (simple-signaling) uninterruptible power supply.

`upsBasicStateOutputState`



For the meaning of each flag, use a MIB browser to view the description of the **upsBasicStateOutputState** OID in the MIB.

View the state of an advanced-signaling uninterruptible power supply

Use the OIDs in the **[upsAdvState]** category to display an ASCII string containing flags representing the current active faults of an advanced-signaling (smart-signaling) uninterruptible power supply:

- The ASCII string for the faults of most single-phase uninterruptible power supply models contains 32 flags.
- The ASCII strings for the faults of Symmetra 3-phase uninterruptible power supplies and Silcon uninterruptible power supplies each contain 64 flags.

For the meaning of each flag, use a MIB browser to view the descriptions of **upsAdvStateAbnormalConditions** for single-phase uninterruptible power supplies,



upsAdvStateSymmetra3PhaseSpecificFaults for Symmetra 3-phase uninterruptible power supplies, and **upsAdvStateDP300ESpecificFaults** for Silcon uninterruptible power supplies.

```
upsAdvStateAbnormalConditions  
upsAdvStateSymmetra3PhaseSpecificFaults  
upsAdvStateDP300ESpecificFaults
```

Manage Outlet Groups of an Uninterruptible Power Supply

Use the **[upsOutletGroups]** OIDs with uninterruptible power supply models that support outlet groups to start or stop devices sequentially, restart locked devices, or shed non-essential devices to preserve runtime for critical loads.

View the name, state, and command-pending status of a group

Use the OIDs in the **[upsOutletGroupStatus]** subcategory to obtain the name, state (on or off), and command-pending status of each outlet group of the uninterruptible power supply. The maximum number of outlet groups for an uninterruptible power supply is three.

```
{upsOutletGroupStatusTable}
  [upsOutletGroupStatusEntry]
    upsOutletGroupStatusIndex
    upsOutletGroupStatusName
    upsOutletGroupStatusGroupState
    upsOutletGroupStatusCommandPending
```

Name an outlet group and configure its delay times

Use the **[upsOutletGroupConfig]** OIDs to configure the name of each outlet group and the three delays that the outlet group uses when the uninterruptible power supply applies power to the group (power-on delay), removes power from the group (power-off delay), or restarts the group (restart duration). You can configure these delays to turn on or turn off the outlet groups and their attached equipment sequentially.

```
upsOutletGroupConfigTableSize
{upsOutletGroupConfigTable}
  [upsOutletGroupConfigEntry]
    upsOutletGroupConfigIndex
    upsOutletGroupConfigName
    upsOutletGroupConfigPowerOnDelay
    upsOutletGroupConfigPowerOffDelay
    upsOutletGroupConfigRebootDuration
```

Control an outlet control group

Use the **[upsOutletGroupControl]** OIDs to do the following for any outlet group:

- Obtain the identifying name and number of the group, and obtain the state (on, off, or unknown) of the group.
- Cause a group to do any of these actions:
 - Turn on, turn off, or restart immediately.
 - Turn off (immediately or after its power-off delay), wait its restart duration delay, wait its power-on delay, and restart.
 - Turn on after its power-on delay, or off after its power-off delay.
- Cancel a pending command for an outlet group.

```
upsOutletGroupControlTableSize  
{upsOutletGroupControlTable}  
  [upsOutletGroupControlEntry]  
    upsOutletGroupControlIndex  
    upsOutletGroupControlName  
    upsOutletGroupControlCommand
```

Perform Diagnostics on a Symmetra Uninterruptible Power Supply

Use the **[upsDiagnostics]** OIDs to perform diagnostic procedures on a Symmetra uninterruptible power supply. The **[upsDiagnostics]** OIDs are in the following subcategories:

- **[upsDiagnosticIM]**
- **[upsDiagnosticPowerModules]**
- **[upsDiagnosticBatteries]**
- **[upsDiagnosticSubsystem]**
- **[upsDiagnosticExternalDevices]**
- **[upsDiagnosticComBus]**

View information about each intelligence module

Use the **[upsDiagnosticIM]** tabled OIDS to view the following:

- The number of intelligence modules in or attached to the uninterruptible power supply.
- For each intelligence module:
 - Its type (main, redundant, or unknown).
 - Its status (on, off, not installed, on and failed, off and failed, not communicating).
 - Its model number; main firmware, secondary firmware, and hardware revisions; its date of manufacture; and its serial number. These parameters are set at the factory or in the firmware.

```
upsDiagIMTableSize
{upsDiagIMTable}
  [upsDiagIMEntry]
    upsDiagIMIndex
    upsDiagIMType
    upsDiagIMStatus
    upsDiagIMFirmwareRev
    upsDiagIMSlaveFirmwareRev
    upsDiagIMHardwareRev
    upsDiagIMSerialNum
    upsDiagIMManufactureDate
```

View information about the power modules

Use the **[upsDiagnosticPowerModules]** OIDs to view the following:

- The number of power modules in or attached to the uninterruptible power supply.
- For each power module:
 - Its status (on, off, not installed, on and failed, off and failed, not communicating).
 - Its model number, its firmware and hardware revisions, its date of manufacture, and its serial number. These parameters are set at the factory.

```
upsDiagPMTableSize  
{upsDiagPMTable}  
  [upsDiagPMEntry]  
    upsDiagPMIndex  
    upsDiagPMStatus  
    upsDiagPMFirmwareRev  
    upsDiagPMHardwareRev  
    upsDiagPMSerialNum  
    upsDiagPMManufactureDate
```

View information about the batteries

Use the **[upsDiagnosticBatteries]** OIDs to view the following:

- The number of battery frames containing batteries.
- The number of batteries in each battery frame of the uninterruptible power supply.
- For each battery:
 - The status (unknown, not installed, operating properly, failed, in a high-temperature condition, in need of immediate replacement, or in a low-capacity condition).
 - The serial number, hardware revision, date of manufacture, and type.

```
upsDiagBatteryTableSize
{upsDiagBatteryTable}
  [upsDiagBatteryEntry]
    upsDiagBatteryFrameIndex
    upsDiagBatteryIndex
    upsDiagBatteryStatus
    upsDiagBatterySerialNumber
    upsDiagBatteryHardwareRev
    upsDiagBatteryManufactureDate
    upsDiagBatteryType
```

View information about the frames and their devices

Use the **[upsDiagnosticSubsystem]** tabled OIDs to view the following:

- The number of frames associated with the uninterruptible power supply.
- For each frame, its type (unknown, not installed, Main, XR, or LXR), firmware revision, hardware revision, serial number, and date of manufacture.
- For each frame, the number of internal bypass switches, battery monitoring boards, and external switch gear cards that it contains and the following information about each of these switches, boards, and cards:
 - Its status (unknown, not installed, off but not failed, on and operational, off and failed, on and failed, or not communicating).
 - Its firmware revision, hardware revision, serial number, and date of manufacture.
- For each frame, the number of display interface cards, DC circuit breakers, system power supplies, XR communication cards, external power frame boards, and chargers that it contains and the status of each of these devices:
 - For a display interface card, system power supply, XR communication card, external power frame board, or charger, the status (unknown, not installed, off but not failed, on and operational, off and failed, on and failed, or not communicating).
 - For a DC circuit breaker, the status (unknown, not installed, open, or closed).

```
upsDiagSubSysFrameTableSize
{upsDiagSubSysFrameTable}
  [upsDiagSubSysFrameEntry]
    upsDiagSubSysFrameIndex
    upsDiagSubSysFrameType
    upsDiagSubSysFrameFirmwareRev
    upsDiagSubSysFrameHardwareRev
    upsDiagSubSysFrameSerialNum
    upsDiagSubSysFrameManufactureDate
upsDiagSubSysIntBypSwitchTableSize
{upsDiagSubSysIntBypSwitchTable}
  [upsDiagSubSysIntBypSwitchEntry]
    upsDiagSubSysIntBypSwitchFrameIndex
    upsDiagSubSysIntBypSwitchIndex
    upsDiagSubSysIntBypSwitchStatus
    upsDiagSubSysIntBypSwitchFirmwareRev
    upsDiagSubSysIntBypSwitchHardwareRev
    upsDiagSubSysIntBypSwitchSerialNum
    upsDiagSubSysIntBypSwitchManufactureDate
upsDiagSubSysBattMonitorTableSize
{upsDiagSubSysBattMonitorTable}
  [upsDiagSubSysBattMonitorEntry]
    upsDiagSubSysBattMonitorFrameIndex
    upsDiagSubSysBattMonitorIndex
    upsDiagSubSysBattMonitorStatus
    upsDiagSubSysBattMonitorFirmwareRev
    upsDiagSubSysBattMonitorHardwareRev
    upsDiagSubSysBattMonitorSerialNum
    upsDiagSubSysBattMonitorManufactureDate
```

```

upsDiagSubSysExternalSwitchGearTableSize
{upsDiagSubSysExternalSwitchGearTable}
    [upsDiagSubSysExternalSwitchGearEntry]
        upsDiagSubSysExternalSwitchGearFrameIndex
        upsDiagSubSysExternalSwitchGearIndex
        upsDiagSubSysExternalSwitchGearStatus
        upsDiagSubSysExternalSwitchGearFirmwareRev
        upsDiagSubSysExternalSwitchGearHardwareRev
        upsDiagSubSysExternalSwitchGearSerialNum
        upsDiagSubSysExternalSwitchGearManufactureDate
upsDiagSubSysDisplayInterfaceCardTableSize
{upsDiagSubSysDisplayInterfaceCardTable}
    [upsDiagSubSysDisplayInterfaceCardEntry]
        upsDiagSubSysDisplayInterfaceCardFrameIndex
        upsDiagSubSysDisplayInterfaceCardIndex
        upsDiagSubSysDisplayInterfaceCardStatus
upsDiagSubSysDCCircuitBreakerTableSize
{upsDiagSubSysDCCircuitBreakerTable}
    [upsDiagSubSysDCCircuitBreakerEntry]
        upsDiagSubSysDCCircuitBreakerFrameIndex
        upsDiagSubSysDCCircuitBreakerIndex
        upsDiagSubSysDCCircuitBreakerStatus
upsDiagSubSysSystemPowerSupplyTableSize
{upsDiagSubSysSystemPowerSupplyTable}
    [upsDiagSubSysSystemPowerSupplyEntry]
        upsDiagSubSysSystemPowerSupplyFrameIndex
        upsDiagSubSysSystemPowerSupplyIndex
        upsDiagSubSysSystemPowerSupplyStatus
upsDiagSubSysXRCommunicationCardTableSize
{upsDiagSubSysXRCommunicationCardTable}
    [upsDiagSubSysXRCommunicationCardEntry]
        upsDiagSubSysXRCommunicationCardFrameIndex
        upsDiagSubSysXRCommunicationCardIndex
        upsDiagSubSysXRCommunicationCardStatus
    
```

```

upsDiagSubSysExternalPowerFrameBoardTableSize
{upsDiagSubSysExternalPowerFrameBoardTable}
  [upsDiagSubSysExternalPowerFrameBoardEntry]
    upsDiagSubSysExternalPowerFrameBoardFrameIndex
    upsDiagSubSysExternalPowerFrameBoardIndex
    upsDiagSubSysExternalPowerFrameBoardStatus
upsDiagSubSysChargerTableSize
{upsDiagSubSysChargerTable}
  [upsDiagSubSysChargerEntry]
    upsDiagSubSysChargerFrameIndex
    upsDiagSubSysChargerIndex
    upsDiagSubSysChargerStatus

```

View information on external devices

Use the **[upsDiagnosticExternalDevices]** OIDs to view the following information on external devices:

- The status of the switch gear (unknown, not installed, operating correctly, failed, not communicating, or in an over-temperature condition).
- The status of the switch gear input, output, and bypass switches and the molded case circuit breaker (MCCB) box (unknown, not installed, opened, or closed).
- The status of the transformer (unknown, not installed, operating correctly, failed, not communicating, in an over-temperature condition, open, or closed).

```

upsDiagSwitchGearStatus
upsDiagSwitchGearInputSwitchStatus
upsDiagSwitchGearOutputSwitchStatus
upsDiagSwitchGearBypassSwitchStatus
upsDiagMCCBBoxStatus
upsDiagTransformerStatus

```

View status of the communication buses

Use the **[upsDiagnosticComBus]** OIDs to view the status (unknown, not installed, operating correctly, not communicating, or failing to receive or transmit data) of the following communication buses:

- The internal and external communication buses of the main intelligence module (MIM) and redundant intelligence module (RIM).
- The MIM-to-RIM communication bus.

`upsDiagComBusMIMStatus`

`upsDiagComBusRIMStatus`

`upsDiagComBusMIMtoRIMStatus`

`upsDiagComBusExternalMIMStatus`

`upsDiagComBusExternalRIMStatus`

Manage an Environmental Monitor

Locate the OIDs

To locate the OIDs to monitor, configure, and control an Environmental Monitor through its Network Management Card or PowerNet agent, use your MIB browser to select, in order, the following OID categories:

- **[apc]**
- **[products]**
- **[hardware]**
- **[environmentalMonitor]**
- One of the following subcategories:
 - **[external]**
 - **[integrated]**



The **[measureUps]** OIDs, a sub-category of **[hardware]** OIDs, are used to manage the older product line of Environmental Monitoring Units and Environmental Monitoring Cards.

Manage an External Environmental Monitor

Use the three sub-categories of **[external]** OIDs to manage an External Environmental Monitor:

- **[emIdent]**
- **[emConfig]**
- **[emStatus]**

View the firmware revision

Use the one **[emIdent]** OID to identify the firmware used by the External Environmental Monitor.

```
emIdentFirmwareRevision
```

Configure the probes and contacts

Use the **[emConfig]** OIDs to do the following:

- View the number of a probe and the setting for how the temperature of a probe is configured and reported (Fahrenheit or Celsius).
- For a probe, configure the name, temperature thresholds, humidity thresholds, and the threshold violations that will generate alarms.
- Configure a name for each input contact, and enable or disable the alarm for each contact.

```
emConfigProbesNumProbes
{emConfigProbesTable}
  [emConfigProbesEntry]
    emConfigProbeNumber
    emConfigProbeName
    emConfigProbeHighTempThreshold
    emConfigProbeLowTempThreshold
    emConfigProbeTempUnits
    emConfigProbeHighHumidThreshold
    emConfigProbeLowHumidThreshold
    emConfigProbeHighTempEnable
    emConfigProbeLowTempEnable
    emConfigProbeHighHumidEnable
    emConfigProbeLowHumidEnable
emConfigContactsNumContacts
{emConfigContactsTable}
  [emConfigContactsEntry]
    emConfigContactNumber
    emConfigContactName
    emConfigContactEnable
```

View the status of an External Environmental Monitor

Use the **[emStatus]** OIDs to view the status of an External Environmental Monitor:

- View the status of the communication to and from the agent.
- View the number of probes and, for each probe, its name, its connection status, the setting for how its temperature is reported (Fahrenheit or Celsius), its current temperature and humidity, and any violations of its temperature or humidity thresholds.
- View the number of input contacts and, for each contact, its name and status (normal, in a fault condition, or disabled).

```
emStatusCommStatus
emStatusProbesNumProbes
{emStatusProbesTable}
  [emStatusProbesEntry]
    emStatusProbeNumber
    emStatusProbeName
    emStatusProbeStatus
    emStatusProbeCurrentTemp
    emStatusProbeTempUnits
    emStatusProbeCurrentHumid
    emStatusProbeHighTempViolation
    emStatusProbeLowTempViolation
    emStatusProbeHighHumidViolation
    emStatusProbeLowHumidViolation
emStatusContactsNumContacts
{emStatusContactsTable}
  [emStatusContactsEntry]
    emStatusContactNumber
    emStatusContactName
    emStatusContactStatus
```

Manage an Integrated Environmental Monitor

Use the three sub-categories of **[integrated]** OIDs to manage an Integrated Environmental Monitor, which is a component of both the Network Management Card of the IBM UPS 7500XHV and IBM UPS 10000XHV:

- **[iemIdent]**
- **[iemConfig]**
- **[iemStatus]**

View the hardware revision

Use the one **[iemIdent]** OID to identify the hardware revision of the Integrated Environmental Monitor.

```
iemIdentHardwareRevision
```

Configure the probe, contacts, and relay

Use the **[iemConfig]** OIDs to configure the one probe, two input contacts, and one output relay of the Integrated Environmental Monitor:

- View the setting for how the temperature of the probe is reported (Fahrenheit or Celsius).
- For the probe, configure the name, the temperature and humidity thresholds, and the threshold violations that will generate alarms.
- Configure a name for each input contact and enable or disable its alarm.
- For the output relay, configure the name, the normal state of the relay (high or low), and the fault condition used to activate the relay.

```
iemConfigProbesNumProbes
{iemConfigProbesTable}
  [iemConfigProbesEntry]
    iemConfigProbeNumber
    iemConfigProbeName
    iemConfigProbeHighTempThreshold
    iemConfigProbeLowTempThreshold
    iemConfigProbeTempUnits
    iemConfigProbeHighHumidThreshold
    iemConfigProbeLowHumidThreshold
    iemConfigProbeHighTempEnable
    iemConfigProbeLowTempEnable
    iemConfigProbeHighHumidEnable
    iemConfigProbeLowHumidEnable
iemConfigContactsNumContacts
{iemConfigContactsTable}
  [iemConfigContactsEntry]
    iemConfigContactNumber
    iemConfigContactName
    iemConfigContactEnable
iemConfigConfigRelaysNumRelays
{iemConfigRelaysTable}
  [iemConfigRelaysEntry]
    iemConfigRelayNumber
    iemConfigRelayName
    iemConfigRelayNormalState
    iemConfigRelayFaultCondition
```

View the status of an Integrated Environmental Monitor

Use the **[iemStatus]** OIDs to view the status of an Integrated Environmental Monitor:

- View the number of probes and, for each probe, its name, its connection status, the setting for how its temperature is reported (Fahrenheit or Celsius), its current temperature and humidity, and any violations of its temperature or humidity thresholds.
- View the number of input contacts and, for each contact, its name and status (normal, in a fault condition, or disabled).

```
iemStatusProbesNumProbes
{iemStatusProbesTable}
  [iemStatusProbesEntry]
    iemStatusProbeNumber
    iemStatusProbeName
    iemStatusProbeStatus
    iemStatusProbeCurrentTemp
    iemStatusProbeTempUnits
    iemStatusProbeCurrentHumid
    iemStatusProbeHighTempViolation
    iemStatusProbeLowTempViolation
    iemStatusProbeHighHumidViolation
    iemStatusProbeLowHumidViolation
iemStatusContactsNumContacts
{iemStatusContactsTable}
  [iemStatusContactsEntry]
    iemStatusContactNumber
    iemStatusContactName
    iemStatusContactStatus
iemStatusRelaysNumRelays
{iemStatusRelaysTable}
  [iemStatusRelaysEntry]
    iemStatusRelayNumber
    iemStatusRelayName
    iemStatusRelayStatus
```

Manage an Environmental Management System

Locate the OIDs

To locate the OIDs to monitor, configure, and control an Environmental Management System, use your MIB browser to select, in order, the following OID categories:

- [apc]
- [products]
- [hardware]
- [environmentalMonitor]
- [envMgtSystem]

View Identification Parameters

Use the **[emsIdent]** OIDs to view the name, model number, firmware and hardware revision, date of manufacture, and serial number that uniquely identify your Environmental Management System. All parameters except the name and firmware revision are set at the factory and cannot be changed. See the **emsConfigName** OID in **"Configure the device name and check-log light" on page 61** to define the name.

```
emsIdentEMSName  
emsIdentProductNumber  
emsIdentFirmwareRev  
emsIdentHardwareRev  
emsIdentDateOfManufacture  
emsIdentSerialNumber
```

Control an Environmental Management System

Open or close an output relay immediately

Use the **[emsOutputRelayControl]** tabled OIDs to open or close an output relay of the Environmental Management System immediately or to display the current state of that relay.

```
{emsOutputRelayControlTable}
  [emsOutputRelayControlEntry]
    emsOutputRelayControlOutputRelayIndex
    emsOutputRelayControlOutputRelayName
    emsOutputRelayControlOutputRelayCommand
```

Turn on or turn off an outlet immediately

Use the **[emsOutletControl]** tabled OIDs to turn on or turn off an outlet of the Environmental Management System immediately or to display the current state of that outlet.

```
{emsOutletControlTable}
  [emsOutletControlEntry]
    emsOutletControlOutletIndex
    emsOutletControlOutletName
    emsOutletControlOutletCommand
```

Reset a sensor

Use the **[emsSensorControl]** tabled OIDs to reset a sensor of the Environmental Management System. To identify the sensor to reset, you can display its system name, which describes its general purpose (for example, leak sensor), and its user-defined name, which you can configure.



See the **emsSensorConfigSensorUserName** OID in **"Configure the sensors" on page 63** to configure the user-defined name.



Some sensors cannot be manually reset and will not be affected by this command.

```
{emsSensorControlTable}
 [emsSensorControlEntry]
   emsSensorControlSensorIndex
   emsSensorControlSensorSystemName
   emsSensorControlSensorUserName
   emsSensorControlSensorCommand
```

Turn an alarm device on or off

Use the **[emsAlarmDeviceControl]** tabled OIDs to activate or deactivate an alarm device of the Environmental Management System or learn whether a specific alarm device is installed. Responses are device-specific; for example, the command turns a beacon on or off.

```
{emsAlarmDeviceControlTable}
 [emsAlarmDeviceControlEntry]
   emsAlarmDeviceControlDeviceIndex
   emsAlarmDeviceControlDeviceName
   emsAlarmDeviceControlDeviceCommand
```

Configure an Environmental Management System

Configure the device name and check-log light

Use the **[emsConfig]** OIDs to name the Environmental Management System and to set the minimum level of event (informational, warning, or severe) that will cause the check-log light to illuminate. You can also disable the check-log light.

```
emsConfigName  
emsConfigCheckLogLight
```

Configure the probes

Use the **[emsProbeConfig]** tabled OIDs to configure the name and high and low temperature and humidity thresholds for each probe. Use whole numbers for relative humidity percentages and degrees of temperature. The **emsStatusSysTempUnits** OID determines which units of temperature measurement are used (Celsius or Fahrenheit).

```
{emsProbeConfigTable}  
  [emsProbeConfigEntry]  
    emsProbeConfigProbeIndex  
    emsProbeConfigProbeName  
    emsProbeConfigProbeHighTempThresh  
    emsProbeConfigProbeLowTempThresh  
    emsProbeConfigProbeHighHumidityThresh  
    emsProbeConfigProbeLowHumidityThresh
```

Configure the input contacts

Use the **[emsInputContactConfig]** tabled OIDs to configure the name and normal state (open or closed) of each input contact of the Environmental Management System.

```

{emsInputContactConfigTable}
  [emsInputContactConfigEntry]
    emsInputContactConfigInputContactIndex
    emsInputContactConfigInputContactName
    emsInputContactConfigInputContactNormalState
  
```

Configure the output relays

Use the **[emsOutputRelayConfig]** tabled OIDs to configure the name and normal state (open or closed) of each output relay of the Environmental Management System.

```

{emsOutputRelayConfigTable}
  [emsOutputRelayConfigEntry]
    emsOutputRelayConfigOutputRelayIndex
    emsOutputRelayConfigOutputRelayName
    emsOutputRelayConfigOutputRelayNormalState
  
```

Configure the outlets

Use the **[emsOutletConfig]** tabled OIDs to configure the name and normal state (on or off) of each outlet of the Environmental Management System.

```

{emsOutletConfigTable}
  [emsOutletConfigEntry]
    emsOutletConfigOutletIndex
    emsOutletConfigOutletName
    emsOutletConfigOutletNormalState
  
```

Configure the sensors

Use the **[emsSensorConfig]** tabled OIDs to configure each sensor of the Environmental Management System, as follows:

- Display the system name (for example, beacon) of the sensor to identify which sensor to configure.
- Configure a user-defined name for the sensor.
- For the AUX sensor only, configure the normal state (open or closed).
- Configure the delay (in seconds) after a sensor detects an alarm condition before the condition is reported.

```
{emsSensorConfigTable}  
  [emsSensorConfigEntry]  
    emsSensorConfigSensorIndex  
    emsSensorConfigSensorSystemName  
    emsSensorConfigSensorUserName  
    emsSensorConfigSensorNormalState  
    emsSensorConfigSensorAlarmDelay
```

View Status of the Environmental Management System

View the overall status of the system

Use the **[emsStatus]** OIDs to view the following information about the Environmental Management System:

- The name.
- The status of communication to and from the agent.
- The total number of each component supported: temperature and humidity probes (local and remote), input contacts, output relays, outlets, sensors, remote Air Removal Units (ARUs), remote temperature and humidity probes, and alarm devices.
- The temperature units (Celsius or Fahrenheit) used to measure and display temperature for the Environmental Management System.
- The configured setting for the minimum severity level of events that will cause the check-log light to illuminate.

```
emsStatusEMSName  
emsStatusCommStatus  
emsStatusProbeCount  
emsStatusInputContactCount  
emsStatusOutputRelayCount  
emsStatusOutletCount  
emsStatusSensorCount  
emsStatusAlinkAruDeviceCount  
emsStatusAlinkProbeDeviceCount  
emsStatusAlarmDeviceCount  
emsStatusSysTempUnits  
emsStatusCheckLogLight
```

View the status of the probes

Use the **[emsProbeStatus]** tabled OIDs to view the following information about each probe of the Environmental Management System:

- The name.
- The current temperature and the high and low temperature thresholds, displayed in the temperature scale (Celsius or Fahrenheit) determined by **emsStatusSysTempUnits** OID.
- The current humidity and the high and low humidity thresholds.
- The serial number of the remote (A-Link) probe.
- The state of communication to and from the agent.

```
{emsProbeStatusTable}
  [emsProbeStatusEntry]
    emsProbeStatusProbeIndex
    emsProbeStatusProbeName
    emsProbeStatusProbeTemperature
    emsProbeStatusProbeHighTempThresh
    emsProbeStatusProbeLowTempThresh
    emsProbeStatusProbeHumidity
    emsProbeStatusProbeHighHumidityThresh
    emsProbeStatusProbeLowHumidityThresh
    emsProbeStatusProbeSerialNumber
    emsProbeStatusProbeCommStatus
```

View the status of the input contacts

Use the **[emsInputContactStatus]** tabled OIDs to view the name, state (open or closed), and normal state (open or closed) of each input contact of the Environmental Management System.

```
{emsInputContactStatusTable}
  [emsInputContactStatusEntry]
    emsInputContactStatusInputContactIndex
    emsInputContactStatusInputContactName
    emsInputContactStatusInputContactState
    emsInputContactStatusInputContactNormalState
```

View the status of the output relays

Use the **[emsOutputRelayStatus]** tabled OIDs to view the name, state (open or closed), and normal state (open or closed) of each output relay of the Environmental Management System.

```
{emsOutputRelayStatusTable}
  [emsOutputRelayStatusEntry]
    emsOutputRelayStatusOutputRelayIndex
    emsOutputRelayStatusOutputRelayName
    emsOutputRelayStatusOutputRelayState
    emsOutputRelayStatusOutputRelayNormalState
```

View the status of the outlets

Use the **[emsOutletStatus]** tabled OIDs to view the name, state (on or off), and normal state (on or off) of each outlet of the Environmental Management System.

```
{emsOutletStatusTable}
  [emsOutletStatusEntry]
    emsOutletStatusOutletIndex
    emsOutletStatusOutletName
    emsOutletStatusOutletState
    emsOutletStatusOutletNormalState
```

View the status of the alarm devices

Use the **[emsAlarmDeviceStatus]** tabled OIDs to view the name and the state (on or active, off or inactive, or not installed) of each alarm device of the Environmental Management System.

```
{emsAlarmDeviceStatusTable}
  [emsAlarmDeviceStatusEntry]
    emsAlarmDeviceStatusDeviceIndex
    emsAlarmDeviceStatusDeviceName
    emsAlarmDeviceStatusDeviceState
```

View the status of the sensors

Use the **[emsSensorStatus]** tabled OIDs to view the following information about each sensor:

- The system name (for example, beacon) of the sensor.
- The user-defined name of the sensor.
- The state of the sensor (faulted, not faulted, or not installed).
- The delay, in seconds, after the sensor detects an alarm condition before the condition is reported.

```
{emsSensorStatusTable}
  [emsSensorStatusEntry]
    emsSensorStatusSensorIndex
    emsSensorStatusSensorSystemName
    emsSensorStatusSensorName
    emsSensorStatusSensorState
    emsSensorStatusSensorAlarmDelay
```

Manage a Rack Air Removal Unit

Locate the OIDs

To locate the OIDs to monitor, configure, and control a rack Air Removal Unit, use your MIB browser to select, in order, the following OID categories:

- [apc]
- [products]
- [hardware]
- [rARU]

View Identification Parameters

Use the [rARUIdent] tabled OIDs to view the name that uniquely identifies each rack Air Removal Unit accessible from this IP address. See the **rARUConfigAruName** OID in **"Configure a Rack Air Removal Unit" on page 70** to define the name.

```
{rARUIdentTable}
[rARUIdentEntry]
  rARUIdentIndex
  rARUIdentName
```

Configure a Rack Air Removal Unit

Use the **[rARUConfig]** tabled OIDs to perform the following configuration tasks for each rack Air Removal Unit accessible at this IP address:

- Name the probe of the ARU.
- As the setpoint (**rARUConfigAruRemoteSetpoint**), configure either of the following:
 - the temperature for the remote ARU to maintain.
 - one of four kilowatt mode settings for the ARU.
- Configure the remote temperature override threshold (**rARUConfigAruTepmOvrdsSetpoint**) at or above which the ARU will increase its fan speed to bring the temperature back in range. This setting is used only if the setpoint (**rARUConfigAruRemoteSetpoint**) is a kilowatt mode setting, and if the temperature override (**rARUConfigAruTempOvrdsEnableDisable**) is enabled.



For more information on kilowatt mode and on the temperature override function, see the *User's Manual* for the Air Removal Unit.

Use only a whole number of degrees when you define a temperature, and use the temperature units (Celsius or Fahrenheit) defined by the **rARUStatusSysTempUnits** OID.

```
{rARUConfigTable}
[rARUConfigEntry]
  rARUConfigAruIndex
  rARUConfigAruName
  rARUConfigAruRemoteSetpoint
  rARUConfigAruTempOvrdsEnableDisable
  rARUConfigAruTepmOvrdsSetpoint
```

View the Status of a Rack Air Removal Unit

Use the **[rARUStatus]** OIDs to view the following information for the rack Air Removal Units accessible from this IP address:

- The number of ARUs.
- The temperature scale (Celsius or Fahrenheit) that is set in the agent and that the ARUs use to report temperature.
- For each ARU:
 - The name.
 - The setpoint temperature to maintain.
 - The current value for the remote temperature setpoint and the manual setpoint. (The manual setting takes precedence unless you set the ARU to remote at the ARU itself. If the ARU is set to remote, the value of the **rARUStatusAruManualSetpoint** OID indicates that it is set to remote.)
 - The temperature reading for each of the three probes.
 - The alarm state (indicating any of three fan failures, the presence of smoke, or an exhaust temperature that is moderately or severely too high).
 - The status of communication to and from the agent.

```

rARUStatusAruDeviceCount
rARUStatusSysTempUnits
{rARUStatusTable}
  [rARUStatusEntry]
    rARUStatusAruIndex
    rARUStatusAruName
    rARUStatusAruRemoteSetpoint
    rARUStatusAruManualSetpoint
    rARUStatusAruTemp1
    rARUStatusAruTemp2
    rARUStatusAruTemp3
    rARUStatusAruTempOvrDEnableDisable
    rARUStatusAruTempOvrDSetpoint
    rARUStatusAruAlarmState
    rARUStatusAruCommStatus

```

Manage MasterSwitch

Locate the OIDs

To locate the OIDs to monitor, configure, and control a MasterSwitch unit, use your MIB browser to select, in order, the following OID categories:

- [apc]
- [products]
- [hardware]
- [masterswitch]
- Any of the following sub-categories:
 - [sPDUIdent]
 - [sPDUMasterControl]
 - [sPDUMasterConfig]
 - [sPDUOutletControl]
 - [sPDUOutletConfig]

View Identification Parameters

Use the **[sPDUIdent]** OIDs to view the hardware and firmware revision, date of manufacture, model number, and serial number that uniquely identify your MasterSwitch unit. All parameters are set at the factory or in the firmware and cannot be changed.

```
sPDUIdentHardwareRev  
sPDUIdentFirmwareRev  
sPDUIdentDateOfManufacture  
sPDUIdentModelNumber  
sPDUIdentSerialNumber
```

Control and Configure the MasterSwitch Unit

Control all the outlets

Use the **[sPDUMasterControl]** OIDs to turn on, restart, or turn off all outlets immediately or sequentially; view the status of each outlet (on or off); and identify whether any outlet has a command pending.

```
sPDUMasterControlSwitch  
sPDUMasterState  
sPDUMasterPending
```

Configure delays and a name for the MasterSwitch unit

Use the **[sPDUMasterConfig]** OIDs to do the following:

- Define a delay to occur before a MasterSwitch unit provides power to its outlets after power is applied to the unit.
- View the delay, in seconds, that will be used for a restart operation. For this delay, from the time power is turned off to the time power is re-applied to the unit, the MasterSwitch unit uses the maximum delay that is configured for any outlet (the maximum value of the **sPDUOutletRebootDuration** tabled OID).
- Define a name for the MasterSwitch unit.

```
sPDUMasterConfigPowerOn  
sPDUMasterConfigReboot  
sPDUMasterConfigPDUName
```

Control and Configure Individual Outlets

Control how an outlet turns on, turns off, and restarts

Use the **[sPDUOutletControl]** OIDs to do the following:

- View the parameters for each outlet by its name and number.
- Turn on or turn off an individual outlet of the MasterSwitch unit, either immediately or after a delay.
- Restart an individual outlet, either immediately or with a delay before the outlet is turned off and a delay before it is turned on.
- Identify whether an individual outlet has a command pending.

```
sPDUOutletControlTableSize
{sPDUOutletControlTable}
  [sPDUOutletControlEntry]
    sPDUOutletControlIndex
    sPDUOutletPending
    sPDUOutletCtl
    sPDUOutletCtlName
```

Name outlets, and configure delays for outlet operations

Use the **[sPDUOutletConfig]** tabled OIDs to name each outlet and to configure any outlet to do the following:

- Turn on or off immediately or after a delay period.
- Restart with a defined delay period before restarting.

```
{sPDUOutletConfigTable}
  [sPDUOutletConfigEntry]
    sPDUOutletConfigIndex
    sPDUOutletPowerOnTime
    sPDUOutletName
    sPDUOutletPowerOffTime
    sPDUOutletRebootDuration
```

Manage MasterSwitch VM

Locate the OIDs

To locate the OIDs to monitor, configure, and control a MasterSwitch VM unit, use your MIB browser to select, in order, the following OID categories:

- **[apc]**
- **[products]**
- **[hardware]**
- **[masterswitchVM]**
- Any of the following sub-categories:
 - **[sPDUIdentVM]**
 - **[sPDUMasterControlVM]**
 - **[sPDUMasterConfigVM]**
 - **[sPDUMasterStatusVM]**
 - **[sPDUOutletControlVM]**
 - **[sPDUOutletConfigVM]**
 - **[sPDUOutletdStatusVM]**

View Identification Parameters

Use the **[sPDUIdentVM]** tabled OIDs to view the following information:

- The number of MasterSwitch VM units accessible at this IP address.
- The name, hardware and firmware revision, date of manufacture, model number, and serial number that uniquely identify each MasterSwitch VM unit. All of these parameters except the name are set at the factory or in the firmware and cannot be changed.

```
sPUIdentVMTableSize
{sPDUIdentVMTable}
  [sPDUIdentVMEntry]
    sPDUIdentVMIndex
    sPDUIdentNameVM
    sPDUIdentHardwareRevVM
    sPDUIdentFirmwareRevVM
    sPDUIdentDateOfManufactureVM
    sPDUIdentModelNumberVM
    sPDUIdentSerialNumberVM
```

Control and Configure MasterSwitch VM Units

Control the outlets and the overload alarm for all units

Use the **[sPDUMasterControlVM]** OIDs to view information on each MasterSwitch VM unit controllable at this IP address, and specify commands to do the following for a unit:

- Turn on, turn off, or restart all the outlets immediately.
- Turn on all the outlets according to the power-on delay of each outlet.
- Turn off all the outlets according to the power-off delay of each outlet.
- Restart the outlets with delays:
 - Turn all outlets off immediately, and turn them on sequentially.
 - Turn all outlets off and on sequentially.
- Cancel all pending commands to the unit.
- Disable the unit alarm for the current overload condition for the duration of that overload only.

```
sPDUMasterControlVMTableSize
{sPDUMasterControlVMTable}
  [sPDUMasterControlVMEntry]
    sPDUMasterControlVMIndex
    sPDUMasterControlVMName
    sPDUMasterControlVMCommand
```

Configure unit name, startup delay, and overload parameters

Use the **[sPDUMasterConfigVM]** OIDs to do the following for each MasterSwitch VM unit accessible from this IP address:

- Configure its name.
- Define when power is supplied automatically to the outlets after power is applied to the unit (never, immediately, or after a specified delay).
- Set the overload warning threshold and low-load warning threshold and define when an audible alarm will sound:
 - Never.
 - When a warning threshold is violated, indicating that an overload or low-load condition is imminent.
 - When an overload or low-load condition exists.
- Configure when extra outlets will turn on in response to a request to turn on additional outlets:
 - Always.
 - Except when an overload condition is imminent (indicated by a violation of the overload warning threshold) or an overload condition exists.
 - Except when an overload condition exists.

```
sPDUMasterConfigVMTableSize
{sPDUMasterConfigVMTable}
  [sPDUMasterConfigVMEntry]
    sPDUMasterConfigVMIndex
    sPDUMasterConfigVMName
    sPDUMasterConfigVMColdstartDelay
    sPDUMasterConfigVMAudioAlarmActivated
    sPDUMasterConfigVMHighLoadWarningThreshold
    sPDUMasterConfigVMLowLoadWarningThreshold
    sPDUMasterConfigVMOverloadRestriction
```

View the Status of a MasterSwitch VM Unit

Use the **[sPDUMasterStatusVM]** OIDs to view the following information for a specified MasterSwitch VM unit:

- The name of the unit.
- Whether the unit has a pending command on any outlet.
- Whether the overload warning threshold or low-load threshold of the unit has been violated.
- The total power being used by the attached equipment as a percentage of full load, and the total power capacity of the unit.
- The number of controllable outlets for the unit.
- The longest restart duration configured for any outlet of the unit.

```
sPDUMasterStatusVMTableSize
{sPDUMasterStatusVMTable}
  [sPDUMasterStatusVMEntry]
    sPDUMasterStatusVMIndex
    sPDUMasterStatusVMName
    sPDUMasterStatusVMCommandPending
    sPDUMasterStatusVMOverloadCondition
    sPDUMasterStatusVMLowLoadCondition
    sPDUMasterStatusVMCurrentLoad
    sPDUMasterStatusVMMaxLoad
    sPDUMasterStatusVMOutletCount
    sPDUMasterStatusVMRebootDuration
```

Control and Configure MasterSwitch VM Outlets

Turn on, turn off, or restart an outlet, and view its state

Use the [sPDUOutletControlVM] tabled OIDs to perform the following tasks on a MasterSwitch VM outlet that you identify by name and number:

- View the state (on or off) of the outlet.
- Cause the outlet to do the following:
 - Turn on or off immediately or after a delay period.
 - Restart immediately or with a defined delay period before restarting.
- Cancel pending commands for the outlet.

```
{sPDUOutletControlVMTable}
  [sPDUOutletControlVMEntry]
    sPDUOutletControlVMIndex
    sPDUOutletControlVMName
    sPDUOutletControlVMOutletIndex
    sPDUOutletControlVMOutletName
    sPDUOutletControlVMOutletCommand
```

Configure the name, delays, and restart duration of an outlet

Use the **[sPDUOutletConfigVM]** tabled OIDs to configure the following for an outlet of a MasterSwitch VM unit:

- The name of the outlet.
- The response of the outlet when the unit is turned on or off or when it receives a command that requests a turn-on or turn-off delay:
 - Never turn on or off automatically.
 - Turn on or off immediately.
 - Turn on or off after a defined delay.
- The delay period before the outlet turns on during a restart sequence.

```
{sPDUOutletConfigVMTable}
  [sPDUOutletConfigVMEntry]
    sPDUOutletConfigVMIndex
    sPDUOutletConfigVMName
    sPDUOutletConfigVMOutletIndex
    sPDUOutletConfigVMOutletName
    sPDUOutletConfigVMPowerOnTime
    sPDUOutletConfigVMPowerOffTime
    sPDUOutletConfigVMRebootDuration
```

View Status of Outlets of a MasterSwitch VM Unit

Use the **[sPDUOutletStatusVM]** tabled OIDs to view the following information about a MasterSwitch VM outlet:

- The name of the MasterSwitch VM unit that contains the outlet.
- The name, number, and state (on or off) of the outlet.
- Whether a command is pending for the outlet.

```
{sPDUOutletStatusVMTable}
  [sPDUOutletStatusVMEntry]
    sPDUOutletStatusVMIndex
    sPDUOutletStatusVMName
    sPDUOutletStatusVMOutletIndex
    sPDUOutletStatusVMOutletName
    sPDUOutletStatusVMOutletState
    sPDUOutletStatusVMCommandPending
```

Manage MasterSwitch Plus

Locate the OIDs

To locate the OIDs to monitor, configure, and control a MasterSwitch Plus unit, use your MIB browser to select, in order, the following OID categories:

- **[apc]**
- **[products]**
- **[hardware]**
- **[masterswitchMSP]**
- Any of the following sub-categories:
 - **[sPDUIdentMSP]**
 - **[sPDUMasterControlMSP]**
 - **[sPDUMasterConfigMSP]**
 - **[sPDUMasterStatusMSP]**
 - **[sPDUOutletControlMSP}**
 - **[sPDUOutletConfigMSP]**
 - **[sPDUOutletStatusMSP]**

View Identification Parameters

Use the **[sPDUIdentMSP]** tabled OIDs to view the following information:

- The number of MasterSwitch Plus units accessible at this IP address.
- The name, hardware and firmware revision, date of manufacture, model number, and serial number that uniquely identify each MasterSwitch Plus unit. All of these parameters except the name are set at the factory or in the firmware and cannot be changed.

```
sPUIdentMSPTableSize
{sPUIdentMSPTable}
  [sPUIdentMSPEntry]
    sPUIdentMSPIndex
    sPUIdentNameMSP
    sPUIdentHardwareRevMSP
    sPUIdentFirmwareRevMSP
    sPUIdentDateOfManufactureMSP
    sPUIdentModelNumberMSP
    sPUIdentSerialNumberMSP
```

Control and Configure MasterSwitch Plus Units

Control a MasterSwitch Plus unit

Use the **[sPDUMasterControlMSP]** OIDs to view the name and number of each MasterSwitch VM unit controllable at this IP address, and specify commands to do the following for a unit:

- Turn on, turn off, or restart all the outlets immediately.
- Turn on all the outlets according to the power-on delay of each outlet, with an option to ignore the battery capacity threshold.
- Turn off all the outlets according to the power-off delay of each outlet.
- After the device running PowerChute confirms shutdown, do either of the following:
 - Graceful Restart: Turn all outlets off immediately, and turn each outlet on after its restart duration time.
 - Graceful Shutdown: Turn each outlet off after its power-off delay, and turn each outlet on after its power-on and restart delays.
- Cancel all pending commands to the unit.
- Restore all the settings of the unit to their defaults.

```
sPDUMasterControlMSPTableSize
{sPDUMasterControlMSPTable}
  [sPDUMasterControlMSPEntry]
    sPDUMasterControlMSPIndex
    sPDUMasterControlMSPName
    sPDUMasterControlMSPCommand
```

Configure a MasterSwitch Plus unit

For each MasterSwitch Plus unit accessible at this address, use the **[sPDUMasterConfigMSP]** OIDs to define the following:

- Define the name of the unit.
- Specify a delay period from the time power is applied to the unit until the unit supplies power to its outlets, or specify that the unit will supply power to its outlets immediately.
- Enable or disable the **Manual** button on the unit.

```
sPDUMasterConfigMSPTableSize
{sPDUMasterConfigMSPTable}
  [sPDUMasterConfigMSPEntry]
    sPDUMasterConfigMSPindex
    sPDUMasterConfigMSPName
    sPDUMasterConfigMSPPowerOnTimeDelay
    sPDUMasterConfigMSPManualButton
```

View Status about a MasterSwitch Plus Unit

Use the **[sPDUMasterStatusMSP]** OIDs to view the name of any MasterSwitch Plus unit accessible at this IP address and the number of controllable outlets at that unit.

```
sPDUMasterStatusMSPTableSize
{sPDUMasterStatusMSPTable}
[sPDUMasterStatusMSPEntry]
  sPDUMasterStatusMSPIndex
  sPDUMasterStatusMSPName
  sPDUMasterStatusMSPOutletCount
```

Control and Configure Outlets of a Unit

Control individual outlets of a MasterSwitch Plus unit

Use the [sPDUOutletControlMSP] tabled OIDs to control an outlet identified by the MasterSwitch Plus unit name, outlet name, and outlet number in any of the following ways:

- View or immediately change the outlet state (on or off).
- Immediately restart the outlet.
- Turn on the outlet after its power-on delay, with an option to ignore the battery capacity threshold.
- After the device running PowerChute confirms shutdown, do either of the following:
 - Graceful Restart: Turn the outlet off after its power-off delay, and turn it on after its restart duration time.
 - Graceful Shutdown: Turn the outlet off after its power-off delay, and turn it on after its power-on and restart delays.

```
{sPDUOutletControlMSPTable}  
  [sPDUOutletControlMSPEntry]  
    sPDUOutletControlMSPIndex  
    sPDUOutletControlMSPName  
    sPDUOutletControlMSPOutletIndex  
    sPDUOutletControlMSPOutletName  
    sPDUOutletControlMSPOutletCommand
```

Configure individual outlets of a MasterSwitch Plus unit

Use the `[sPDUOutletConfigMSPall]` tabled OIDs to configure values for individual outlets:

- Display the name of the MasterSwitch Plus unit and the number of the outlet to configure.
- Define the name of the outlet.
- Set the mode for the outlet as either graceful shutdown mode or annunciator control mode. In annunciator control mode, the outlet configuration options are “immediate on” and “immediate off” only. The purpose of annunciator control mode is to respond to environmental alarms.

See the `[sPDUOutConfigMSPgs]` OIDs in **“Configure outlet parameters for graceful shutdown mode” on page 92** for options you can set for graceful shutdown mode.



See the `[sPDUOutConfigMSPannun]` OIDs in **“Configure outlet parameters for annunciator mode” on page 96** for options you can set for annunciator mode.

```
{sPDUOutletConfigMSPallTable}
[sPDUOutletConfigMSPallEntry]
    sPDUOutletConfigMSPallIndex
    sPDUOutletConfigMSPallName
    sPDUOutletConfigMSPallOutletIndex
    sPDUOutletConfigMSPallOutletName
    sPDUOutletConfigMSPallOutletCtrlMode
```

Configure outlet parameters for graceful shutdown mode. Use the [sPDUOutletConfigMSPgs] tabled OIDs to configure individual outlets in relation to graceful shutdown mode:

- Display the MasterSwitch Plus unit number and name and the outlet number and name of the outlet to configure.
- Display the outlet control mode to confirm that the mode of the outlet is set to graceful shutdown.
- Configure how the outlet will behave during a graceful shutdown sequence:
 - Define whether it will turn off.
 - If it will turn off, define which conditions will initiate the turn-off, and configure values for those conditions where appropriate:
 - Confirmation from its device.
 - A specified amount of remaining battery runtime.
 - A low-battery warning.
 - A specified power-off delay.
 - A multiplier value that enables “load shedding” as uninterruptible power supply battery runtime decreases. Load-shedding turns outlets off in stages, so that power is maintained to your most important equipment for as long as possible. See **“Example of a load-shedding configuration” on page 93.**
 - Define whether it will turn on when input power is restored.
 - If it will turn on, define what conditions will imitate the turn-on, and configure values for those conditions:
 - A specified power-on delay.
 - A specified battery capacity.
- Define the restart duration time that the outlet will wait after turning off during a graceful restart sequence before turning on again.

```
{sPDUOutletConfigMSPgsTable}
  [sPDUOutletConfigMSPgsEntry]
    sPDUOutletConfigMSPgsIndex
    sPDUOutletConfigMSPgsName
    sPDUOutletConfigMSPgsOutletIndex
    sPDUOutletConfigMSPgsOutletName
    sPDUOutletConfigMSPgsOutletCtrlMode
    sPDUOutletConfigMSPgsDeviceConfirm
    sPDUOutletConfigMSPgsLowBattWarning
    sPDUOutletConfigMSPgsLowBattMult
    sPDUOutletConfigMSPgsRestartDelay
    sPDUOutletConfigMSPgsPowerOnDelay
    sPDUOutletConfigMSPgsPowerOffDelay
    sPDUOutletConfigMSPgsBattCapThresh
    sPDUOutletConfigMSPgsRebootDuration
```

Example of a load-shedding configuration. You can configure the eight outlets of the MasterSwitch Plus unit to turn off in up to seven stages during a power outage so that devices attached to those outlets shut down in an ordered sequence based on the importance you assign to them. Such *load-shedding* allows you to extend uninterruptible power supply runtime to more important equipment by eliminating less significant equipment in stages from the uninterruptible power supply load as a power outage continues to reduce available battery runtime.

In the table on the next page, which shows a sample load-shedding configuration, the following OID values are referenced:

- Low Battery Warning is the value of the **sPDUOutletConfigMSPgsLowBattWarning** OID.
- Low Battery Multiplier is the value of the **sPDUOutletConfigMSPgsLowBattMult** OID.



Uninterruptible Power Supply Parameters			MasterSwitch Plus Unit Parameters			
Low Battery Signal Time	Runtime Remaining	State	Outlet	Low Battery Warning	Low Battery Multiplier	Low Battery Multiplier x uninterruptible power supply Low Battery Signal Time
25 minutes	60 minutes	On battery	1	60 six-second intervals (60 x 6 seconds = 6 minutes)	7	7 x 25 = 175 minutes
			2	60 six-second intervals (60 x 6 seconds = 6 minutes)	6	6 x 25 = 150 minutes
			3	120 six-second intervals (120 x 6 seconds = 12 minutes)	2	2 x 25 = 50 minutes
			4	70 six-second intervals (70 x 6 seconds = 7 minutes)	2	2 x 25 = 50 minutes
			5	-1: (Turn off the outlet based on runtime remaining.)	3	3 x 25 = 75 minutes
			6	-1: (Turn off the outlet based on runtime remaining.)	2	2 x 25 = 50 minutes
			7	-1: (Turn off the outlet based on runtime remaining.)	1	1 x 25 = 25 minutes
			8	-2: (Do not turn off the outlet.)	3	3 x 25 = 75 minutes

If the Low Battery Signal Time of the uninterruptible power supply is set to 25 minutes, and the uninterruptible power supply switches to battery operation with 60 minutes of Runtime Remaining, the outlets will turn off as follows:

- Outlet 1 will begin its turn-off sequence immediately, without waiting the 6-minute Low Battery Warning period, because the Runtime Remaining of 60 minutes is already less than 175 minutes (Low Battery Multiplier x the Low Battery Signal Time of the uninterruptible power supply).
- Outlet 2 will begin its turn-off sequence immediately, without waiting the 6-minute Low Battery Warning period, because the Runtime Remaining of 60 minutes is already less than 150 minutes (Low Battery Multiplier x the Low Battery Signal Time of the uninterruptible power supply).
- Outlet 3 will begin its turn-off sequence after 10 minutes, when the Runtime Remaining is depleted to less than 50 minutes (Low Battery Multiplier x the Low Battery Signal Time of the uninterruptible power supply). The full 12-minute Low Battery Warning period will not yet have expired.
- Outlet 4 will begin its turn-off sequence when the 7-minute Low Battery Warning period expires, instead of waiting until after 10 minutes when the Runtime Remaining would be depleted to less than 50 minutes (Low Battery Multiplier x the Low Battery Signal Time of the uninterruptible power supply).
- Outlet 5 will begin its turn-off sequence immediately because the 60-minute Runtime Remaining is already less than 75 minutes (Low Battery Multiplier x the Low Battery Signal Time of the uninterruptible power supply).
- Outlet 6 will begin its turn-off sequence after 10 minutes, when the Runtime Remaining is depleted to less than 50 minutes (Low Battery

Multiplier x the Low Battery Signal Time of the uninterruptible power supply).

- Outlet 7 will begin its turn-off sequence after 35 minutes, when the Runtime Remaining is depleted to less than 25 minutes (Low Battery Multiplier x the Low Battery Signal Time of the uninterruptible power supply).
- Outlet 8 will remain on because the value defined for the Low Battery Warning indicates that the outlet should not turn off. The 75 minutes (Low Battery Multiplier x the uninterruptible power supply Low Battery Signal Time) is ignored.

Configure outlet parameters for annunciator mode. Use the [sPDUOutletConfigMSPannun] tabled OIDs to configure individual outlets in relation to annunciator mode:

- Display the MasterSwitch Plus unit number and name and the outlet number and name of the outlet to configure.
- Display the outlet control mode to confirm that the mode of the outlet is set to annunciator.
- Define the initial (default) state of the outlet as either on or off.
- Define the time in seconds that an alarm from an Environmental Monitor must continue before it causes an alarm condition, if the environmental alarm is enabled.

```
{sPDUOutletConfigMSPannunTable}
  [sPDUOutletConfigMSPannunEntry]
    sPDUOutletConfigMSPannunIndex
    sPDUOutletConfigMSPannunName
    sPDUOutletConfigMSPannunOutletIndex
    sPDUOutletConfigMSPannunOutletName
    sPDUOutletConfigMSPannunOutletCtrlMode
    sPDUOutletConfigMSPannunInitialState
    sPDUOutletConfigMSPannunAlarmActionDly
```

Configure outlets to respond to an environmental alarm. Use the **[sPDUOutletConfigMSPmups]** tabled OIDs to configure individual outlets to begin their turn-off sequence in response to alarm conditions from the Environmental Monitor or to ignore those alarm conditions:

- Display the MasterSwitch Plus unit number and name and the outlet number and name of the outlet to configure.
- For this outlet, enable or disable any of the alarms for the zone (1, 2, 3, or 4) that the Environmental Monitor is monitoring.
- Disable the low or high humidity or temperature alarms for probe 1 or 2.

```
{sPDUOutletConfigMSPmupsTable}
  [sPDUOutletConfigMSPmupsEntry]
    sPDUOutletConfigMSPmupsIndex
    sPDUOutletConfigMSPmupsName
    sPDUOutletConfigMSPmupsOutletIndex
    sPDUOutletConfigMSPmupsOutletName
    sPDUOutletConfigMSPmupsZone1
    sPDUOutletConfigMSPmupsZone2
    sPDUOutletConfigMSPmupsZone3
    sPDUOutletConfigMSPmupsZone4
    sPDUOutletConfigMSPmupsP1LowHum
    sPDUOutletConfigMSPmupsP1HiHum
    sPDUOutletConfigMSPmupsP1LowTemp
    sPDUOutletConfigMSPmupsP1HiTemp
    sPDUOutletConfigMSPmupsP2LowHum
    sPDUOutletConfigMSPmupsP2HiHum
    sPDUOutletConfigMSPmupsP2LowTemp
    sPDUOutletConfigMSPmupsP2HiTemp
```

View the Status of MasterSwitch Plus Outlets

Use the [sPDUOutletStatusMSP] tabled OIDs to view the status of any outlet of a MasterSwitch Plus unit:

- Display the number and name of the MasterSwitch Plus unit and the number and name of the outlet.
- View the current state (on or off) and the configured control mode (graceful shutdown or annunciator) of the outlet.
- View the status of commands (whether commands are pending) for the outlet.

```
{sPDUOutletStatusMSPTable}
  [sPDUOutletStatusMSPEntry]
    sPDUOutletStatusMSPIndex
    sPDUOutletStatusMSPName
    sPDUOutletStatusMSPOutletIndex
    sPDUOutletStatusMSPOutletName
    sPDUOutletStatusMSPOutletState
    sPDUOutletStatusMSPCommandPending
    sPDUOutletStatusMSPOutletCtrlMode
```

Manage a Rack PDU

Locate the OIDs

To locate the OIDs to monitor, configure, and control a rack power distribution unit (PDU), use your MIB browser to select, in order, the following OID categories:

- [apc]
- [products]
- [hardware]
- [rpdu]
- Any of the following sub-categories:
 - [rPDUIdent]
 - [rPDULoad]
 - [rPDUOutlet]
 - [rPDUPowerSupply]

Name the PDU and View Identification Parameters

Use the **[rPDUIdent]** OIDs to define a name for the rack PDU and view its hardware and firmware revision, date of manufacture, model number, and serial number. All of these parameters are set at the factory or in the firmware and cannot be changed.

```
rPDUIdentName  
rPDUIdentHardwareRev  
rPDUIdentFirmwareRev  
rPDUIdentDateOfManufacture  
rPDUIdentModelNumber  
sPDUIdentSerialNumberMSP
```

View Rated Power and Number of Phases

Use the [rPDULoadDevice] OIDs to view, for this rack PDU, the maximum rated power that each phase can provide and the number of phases available.

```
rPDULoadDevMaxPhaseLoad  
rPDULoadDevNumPhases
```

View and Configure Load Thresholds by Phase

Use the **[rPDULoadConfig]** tabled OIDs to view and configure the low-load, overload warning (near-overload), and overload thresholds for each phase of the rack PDU.

```
{rPDULoadConfigTable}
[rPDULoadConfigEntry]
  rPDULoadConfigIndex
  rPDULoadConfigLowLoadThreshold
  rPDULoadConfigNearOverloadThreshold
  rPDULoadConfigOverloadThreshold
```

View the Load Status of Each Phase

Use the **[rPDULoadStatus]** tabled OIDs to view the load of each phase of the rack PDU and whether that load is normal or is in violation of the low-load, near-overload, or overload threshold.

A trap is generated if the load is at or below the low-load threshold, is at or above the overload threshold, or returns to normal after either of those conditions.

```
{rPDULoadStatusTable}
  [rPDULoadStatusEntry]
    rPDULoadStatusIndex
    rPDULoadStatusPhaseLoad
    rPDULoadStatusPhaseLoadState
```

Control Outlets of a Rack PDU

Control power to all the outlets

Use the `[rPDUOutletDevice]` OIDs to view the number of controllable outlets at this rack PDU and control the outlets in any of the following ways:

- Immediately apply power to all outlets, remove power from all outlets, or restart all outlets.
- Apply power to each outlet after its power-on delay, or remove power from each outlet after its power-off delay.
- First turn off each outlet after its power-off delay, and then restart each outlet after the largest restart duration specified for an outlet and after the power-on delay of each outlet.
- Cancel all pending commands to outlets.
- After power is applied to the rack PDU, apply power to the outlets after a specified cold-start delay, immediately, or never. (A *cold-start* delay is the time that the PDU waits before applying power to its outlets when it is started from a completely off condition, not with only its outlets turned off.)

```
rPDUOutletDevCommand  
rPDUOutletDevColdstartDelay  
rPDUOutletDevNumCntrlOutlets
```

Control individual outlets by phase

Use the **[rPDUOutletControl]** tabled OIDs to identify an outlet by its name and the phase or phases with which it is associated, display the current state of the outlet, and control the outlet in any of the following ways:

- Immediately apply power to the outlet, remove power from the outlet, or restart the outlet.
- Apply power to the outlet after its power-on delay, or remove power from the outlet after its power-off delay.
- First turn off each outlet after its power-off delay, and then restart the outlet after its restart duration and its power-on delay.
- Cancel all pending commands to the outlet.

```
{rPDUOutletControlTable}
[rPDUOutletControlEntry]
  rPDUOutletControlIndex
  rPDUOutletControlOutletName
  rPDUOutletControlOutletPhase
  rPDUOutletControlOutletCommand
```

Configure Outlets

Set outlets by phase to correct or prevent overload

Use the **[rPDUOutletPhase]** tabled OIDs to configure, for a specified phase, whether to allow power to be supplied on request to additional outlets in response to either a near-overload condition or an overload condition, neither condition, or both conditions.

```
{rPDUOutletPhaseTable}
[rPDUOutletPhaseEntry]
rPDUOutletPhaseIndex
rPDUOutletPhaseOverloadRestriction
```

Configure the delays for outlet actions

Use the **[rPDUOutletConfig]** tabled OIDs to do the following:

- Identify an outlet by the phase or phases with which it is associated and by an outlet name that you can define here.
- Configure the power-on delay, power-off delay, and restart duration of the outlet.

```
{rPDUOutletConfigTable}
[rPDUOutletConfigEntry]
rPDUOutletConfigIndex
rPDUOutletConfigOutletName
rPDUOutletConfigOutletPhase
rPDUOutletConfigPowerOnTime
rPDUOutletConfigPowerOffTime
rPDURebootDuration
```

View Status of an Outlet and Power Supply

View the status of an outlet

Use the **[rPDUOutletStatus]** tabled OIDs to view the name of an outlet, the phase or phases with which the outlet is associated, the state of the outlet (on or off), and whether any command is pending for the outlet.

```
{rPDUOutletStatusTable}
  [rPDUOutletStatusEntry]
    rPDUOutletStatusIndex
    rPDUOutletStatusOutletName
    rPDUOutletStatusOutletPhase
    rPDUOutletStatusOutletState
    rPDUOutletStatusCommandPending
```

View the status of either power supply

Use the **[rPDUPowerSupplyDevice]** OIDs to view whether Power Supply 1 or Power Supply 2 is functioning properly.

```
rPDUPowerSupply1Status
rPDUPowerSupply2Status
```

Manage an Automatic Transfer Switch

Locate the OIDs

To locate the OIDs to monitor, configure, and control an Automatic Transfer Switch (ATS), use your MIB browser to select, in order, the following OID categories:

- [apc]
- [products]
- [hardware]
- [automaticTransferSwitch]
- Any of the following sub-categories:
 - [atsIdent]
 - [atsCalibration]
 - [atsControl]
 - [atsConfig]
 - [atsStatus]
 - [atsStatusinput]
 - [atsStatusOutput]



To manage the embedded Network Management Card of the Automatic Transfer Switch, see **"Manage Agents and Management Cards" on page 8.**

View Identification Parameters of the ATS

Use the **[atsIdent]** tabled OIDs to view the following information about the Automatic Transfer Switch:

- Its hardware and firmware revisions.
- The release date of its current firmware.
- Its date of manufacture, model number, and serial number.
- The RMS utility voltage in volts.
- The frequency of its input power frequency in Hz.

The first six OIDs are set at the factory or in the firmware.

```
atsIdentHardwareRev  
atsIdentFirmwareRev  
atsIdentFirmwareDate  
atsIdentDateOfManufacture  
atsIdentModelNumber  
sPDUIIdentSerialNumberMSP  
atsIdentNominalLineVoltage  
atsIdentNominalLineFrequency
```

View I/O Data, Power Supply Voltages, and Calibration Factors

Use the **[atsCalibration]** OIDs to view the following:

- The number of inputs, the number of phases per input, and, for each phase of each input, the line voltage calibration factor.
- The number of supported power supply voltages (24 V, 12 V, and 5 V), and for each power supply voltage, the type and calibration factor.
- The number of output lines for this device, the number of output phases for this device, and, for each phase, a description of each calibration factor (one for each output phase and one for neutral) and the output calibration factor in amps.

All calibration factors are set at the factory.

```
{atsCalibrationInputTable}
  [atsCalibrationInputPhaseEntry]
    atsCalibrationInputTableIndex
    atsCalibrationInputPhaseTableIndex
    atsLineVoltageCalibrationFactor
    atsCalibrationPowerSupplyVoltages
{atsCalibrationPowerSupplyVoltageTable}
  [atsCalibrationPowerSupplyVoltageEntry]
    atsCalibrationPowerSupplyVoltageTableIndex
    atsCalibrationPowerSupplyVoltage
    atsPowerSupplyVoltageCalibrationFactor
atsCalibrationNumOutputs
atsCalibrationNumOutputPhases
{atsCalibrationOutputTable}
  [atsCalibrationOutputEntry]
    atsCalibrationOutputTableIndex
    atsCalibrationOutputPhasesTableIndex
    atsOutputCurrentCalibrationFactor
```

Reset the ATS and Clear Its Alarms

Use the **[atsControl]** OIDs to reset the Automatic Transfer Switch when power is applied and to clear its alarms.

```
atsControlResetATS
```

```
atsControlClearAllAlarms
```

Configure the ATS

Use the **[atsConfig]** OIDs to name the Automatic Transfer Switch and configure the following:

- Set the preferred source of power.
- Disable the capability to set source preference from the front panel. (To re-enable the front panel, you must use the serial interface of the ATS.)
- Configure a wide, medium, or narrow range for acceptable voltage. The ATS switches to the alternative source of power when voltage is outside the selected range.
- Configure high or low sensitivity to frequent, small line voltage changes.
- Set the over-current alarm threshold.
- Reset the ATS to its default values.

```
atsConfigProductName  
atsConfigPreferredSource  
atsConfigFrontPanelLockout  
atsConfigVoltageSensitivity  
atsConfigTransferVoltageRange  
atsConfigCurrentLimit  
atsConfigResetValues
```

View the Status of the ATS

Use the **[atsStatus]** OIDs to reset to defaults all maximum and minimum ATS values for input voltage, input power, and output current recorded since the last time they were read or reset by this OID, and to view the following:

- The state of the communication of the ATS on the network (established, never established, or lost).
- The selected source of power, and whether both sources are available.
- Any violation of the output current threshold. (If the ATS exceeds the threshold, it cannot switch to the alternative power source.)
- The status of the 5 V and 24 V power supplies. A power supply has failed when it is not operating correctly and cannot be reconfigured through the internal **Configuration** menu.

```
atsStatusCommStatus  
atsStatusSelectedSource  
atsStatusRedundancyState  
atsStatusOverCurrentState  
atsStatus5VPowerSupply  
atsStatus24VPowerSupply  
atsStatusResetMaxMinValues
```

Name and View the Status of Input Feeds

Use the **[atsStatusInput]** OIDs to name each input feed and to view the following information about the input feeds:

- The number of input feeds.
- For each input feed, the number of phases, voltage orientation (single-phase, split phase, 3-phase phase-to-neutral, 3-phase phase-to-phase, or unknown), frequency, and type.
- For each phase of each input feed, the input voltage, current, and power, and the minimum and maximum values for input voltage, current, and power since they were last reset by the **atsStatusResetMaxMinValues** OID.

```
atsNumInputs
{atsInputTable}
  [atsInputEntry]
    atsInputTableIndex
    atsNumInputPhases
    atsInputVoltageOrientation
    atsInputFrequency
    atsInputType
    atsInputName
{atsInputPhaseTable}
  [atsInputPhaseEntry]
    atsInputPhaseTableIndex
    atsInputPhaseIndex
    atsInputVoltage
    atsInputMaxVoltage
    atsInputMinVoltage
    atsInputCurrent
    atsInputMaxCurrent
    atsInputMinCurrent
    atsInputPower
    atsInputMaxPower
    atsInputMinPower
```

Name and View the Status of Output Feeds

Use the **[atsStatusOutput]** OIDs to name each output feed and to view the following information about the output feeds:

- The number of output feeds and the number of phases for each.
- The description of each output phase used in this device and one for neutral.
- For each output feed, the number of phases, voltage orientation (single-phase, split phase, 3-phase phase-to-neutral, 3-phase phase-to-phase, or unknown), and frequency.
- For each phase of each output feed:
 - The output voltage.
 - The output current drawn by the load, and the output power.
 - The percentage of the ATS output capacity and the percentage of the ATS load capacity presently being used, both measured at a redundancy of (n + x).
 - Minimum and maximum values for output current, output power, percentage of output capacity, and percentage of output load since they were last reset by the **atsStatusResetMaxMinValues** OID.

```
atsNumOutputs
{atsOutputTable}
  [atsOutputEntry]
    atsOutputTableIndex
    atsNumOutputPhases
    atsOutputVoltageOrientation
    atsOutputFrequency
{atsOutputPhaseTable}
  [atsOutputPhaseEntry]
    atsOutputPhaseTableIndex
    atsOutputPhaseIndex
    atsOutputVoltage
    atsOutputCurrent
    atsOutputMaxCurrent
    atsOutputMinCurrent
    atsOutputLoad
    atsOutputMaxLoad
    atsOutputMinLoad
    atsOutputPercentLoad
    atsOutputMaxPercentLoad
    atsOutputMinPercentLoad
    atsOutputPower
    atsOutputMaxPower
    atsOutputMinPower
    atsOutputPercentPower
    atsOutputMaxPercentPower
    atsOutputMinPercentPower
```

Locate the OIDs

In a MIB browser, select, in order, these OID categories to locate the OIDs to manage a NetworkAIR FM System through its Network Management Card:

- **[apc]**
- **[products]**
- **[hardware]**
- **[airConditioners]**
- **[airFM]**
- Either of the following subcategories:
 - **[airFMIdent]**
 - **[airFMStatus]**

View Identification Parameters

Use the **[airFMIdent]** OIDs to view, for each NetworkAIR FM Module, the hardware and firmware revision, date of manufacture, model number, and serial number that uniquely identifies the unit. All parameters are set at the factory or in the firmware and cannot be changed.

```
airFMIdentName
airFMIdentTableSize
{airFMIdentTable}
  [airFMIdentTableEntry]
    airFMIdentModuleIndex
    airFMIdentModuleModelNumber
    airFMIdentModuleDateOfMfg
    airFMIdentModuleSerialNumber
    airFMIdentModuleFirmwareRev
    airFMIdentModuleHardwareRev
```

View Status of the System and Modules

Use the **airFMStatus** OIDs to view the following information:

- Whether the NetworkAIR FM System is on or off.
- The average temperature and humidity of returned air for the Modules in the System.
- The System action air temperature and humidity.
- The highest air temperature reading from the remote sensors connected to this System, and the lowest air temperature reading from the remote sensors connected to this System.
- The average air temperature and humidity of the remote sensors connected to the System.
- The state (enabled or disabled) of the cooling, reheating, humidifying, and dehumidifying functions of the System.
- Information for each Module:
 - The output capacity in kilowatts.
 - The current temperature and humidity of supplied air (to the room).
 - The current temperature and humidity of returned air (from the room).

For each type of temperature status, the OID you use determines whether the temperature is reported in Fahrenheit or Celsius.

```
airFMStatusSystemOn
airFMStatusSystemAverageRetTempC
airFMStatusSystemAverageRetTempF
airFMStatusSystemAverageRetHum
airFMStatusSystemActionTempC
airFMStatusSystemActionTempF
airFMStatusSystemActionHum
airFMStatusSystemRemoteHighTempC
airFMStatusSystemRemoteHighTempF
airFMStatusSystemRemoteAvgTempC
airFMStatusSystemRemoteAvgTempF
airFMStatusSystemRemoteAvgHum
airFMStatusSystemRemoteLowTempC
airFMStatusSystemRemoteLowTempF
airFMStatusSystemCoolingEnabled
airFMStatusSystemReheatingEnabled
airFMStatusSystemHumidifyEnabled
airFMStatusSystemDehumidifyEnabled
airFMStatusModuleTableSize
{airFMStatusModuleTable}
  [airFMStatusModuleEntry]
    airFMStatusModuleIndex
    airFMStatusModuleOutputCapacity
    airFMStatusModuleSupplyTempC
    airFMStatusModuleSupplyTempF
    airFMStatusModuleSupplyHum
    airFMStatusModuleReturnTempC
    airFMStatusModuleReturnTempF
    airFMStatusModuleReturnHum
```

Locate the OIDs

In a MIB browser, select, in order, these OID categories to locate the OIDs to manage a NetworkAIR Portable Air Conditioner through its Network Management Card:

- **[apc]**
- **[products]**
- **[hardware]**
- **[airConditioners]**
- **[airPA]**
- Either of the following subcategories:
 - **[airPAIdent]**
 - **[airPAStatus]**

View Identification Parameters

Use the **[airPAIdent]** OIDs to view the hardware and firmware revision, date of manufacture, model number, and serial number that uniquely identifies the NetworkAIR Portable Air Conditioner. All parameters are set at the factory or in the firmware and cannot be changed.

```
airPAIdentName  
airPAModelNumber  
airPADateOfManufacture  
airPASerialNumber  
airPAFirmwareRevision  
airPAHardwareRevision
```

View Status

Use the **[airPAStatus]** OIDs to view the following information:

- Whether the system power of the NetworkAIR Air Conditioner is on or off.
- The present operating mode of the NetworkAIR Air Conditioner (off, venting, or cooling).
- The temperature setpoint of the NetworkAIR Air Conditioner.
- The speed setting of the blower (high or low).
- Whether the compressor, condenser fan, and condensate pump of the NetworkAIR Air Conditioner are on or off.
- The temperature of the supplied air.
- The temperature of the returned air.
- The remote temperature and humidity.

For each type of temperature status, the OID you use determines whether the temperature is reported in Fahrenheit or Celsius.

```
airPASystemPower  
airPAOperatingMode  
airPASETpoint  
airPABlowerSpeed  
airPACompressor  
airPACondenserFan  
airPACondensatePump  
airPASupplyTempF  
airPASupplyTempC  
airPAReturnTempF  
airPAReturnTempC  
airPARemoteTempF  
airPARemoteTempC  
airPARemoteHumidity
```

PowerNet MIB Traps

Overview

This section provides the following information about SNMP traps:

- It describes the PowerNet MIB traps that various APC hardware devices (including Management Cards) and a PowerNet Agent can send to a Network Management Station (NMS) to alert the NMS that a specific event has occurred.



See **"PowerNet MIB Trap Definitions" on page 127.**

- It describes how to define which NMSs can receive those traps.



See **"How to define trap receivers" on page 125.**

No device can generate all traps, and no NMS can receive a trap until at least one of the four trap receiver definitions exists for the device. By default, all devices, Network Management Cards, and agents have no trap receivers defined.

Trap severity levels

Each trap has one of the following severity levels:

- **Severe:** Alerts a trap receiver of an event that requires immediate corrective action.
- **Warning:** Alerts a trap receiver of an event that can adversely affect the operation of a device if the situation worsens.
- **Informational:** Alerts a trap receiver of an event that cannot adversely affect the operation a device.

How to define trap receivers

Each PowerNet agent, Network Management Card, or other hardware device can send traps to as many as four trap receivers.

In a MIB browser, select, in order, these OID categories to access the PowerNet MIB OIDs that you use to define a trap receiver:

- [apc]
- [apcmgmt]
- [mconfig]

OID	Task
mconfigNumTrapReceivers	The number of NMSs to receive traps (always 4).
<pre>{mconfigTrapReceiverTable} [mconfigTrapReceiverEntry] trapIndex receiverAddr communityString severity acceptThisReceiver receiveTrapType</pre>	<p>A tabled set of OIDs to define parameters for each trap receiver:</p> <ul style="list-style-type: none"> • The trap receiver number (the read-only index to the trap receiver entry). • The IP address of the NMS. The default value, 0.0.0.0, prevents all NMSs from receiving traps. • The password (community name) that a trap must use to be sent to this trap receiver. • The severity of traps to send to this NMS. Traps of this severity or greater are sent. See "Trap severity levels" on page 125: • informational (1) • warning (2) • severe (3) • Enables or disables sending traps to this NMS. <ul style="list-style-type: none"> • yes (1): Enable • no (2): Disable • The type of traps that this NMS will receive. You must use powernet (1) with a Network Management Card.

PowerNet MIB Trap Definitions

Trap	Severity [†]	Number and Description
communicationLost	S	1: The SNMP Agent of a Network Management Card lost communication with the uninterruptible power supply.
upsOverload	S	2: The uninterruptible power supply sensed a load greater than the rated-load capacity.
upsDiagnosticsFailed	S	3: The uninterruptible power supply failed a self-test.
upsDischarged	S	4: A low-battery condition exists; runtime may not be sufficient if input power fails.
upsOnBattery	W	5: The uninterruptible power supply switched to battery power.
smartBoostOn	W	6: The uninterruptible power supply enabled its Boost feature.
lowBattery	S	7: The uninterruptible power supply batteries will be exhausted soon if power is not restored.
communicationEstablished	I	8: The SNMP agent of the Network Management Card established communication with the uninterruptible power supply.
powerRestored	I	9: Utility power restored.
upsDiagnosticsPassed	I	10: The uninterruptible power supply passed a self-test.
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
returnFromLowBattery	I	11: The uninterruptible power supply returned from a low-battery condition.
upsTurnedOff	W	12: The uninterruptible power supply was turned off.
upsSleeping	W	13: The uninterruptible power supply turned off its outlets (entered sleep mode) waiting for input power to be restored.
upsWokeUp	I	14: Input power was restored and the uninterruptible power supply exited sleep mode.
upsRebootStarted	W	15: The uninterruptible power supply started a restart sequence.
upsDipSwitchChanged	W	16: A DIP switch setting changed and could alter uninterruptible power supply performance.
upsBatteryNeedsReplacement	S	17: An uninterruptible power supply battery needs replacement.
contactFault	S	18: The Environmental Monitor contact x changed from its normal position.
contactFaultResolved	I	19: The Environmental Monitor contact x returned to its normal position.
hardwareFailureBypass	S	20: The uninterruptible power supply (Matrix-UPS) switched to bypass because of a hardware failure.
softwareBypass	W	21: The uninterruptible power supply (Matrix-UPS) was put on bypass by software or by the uninterruptible power supply front panel.
<p>† Severity: S = Severe, W = Warning, I = Informational</p>		

Trap	Severity [†]	Number and Description
switchedBypass	W	22: The uninterruptible power supply (Matrix-UPS) was put on bypass by the switch at the uninterruptible power supply.
returnFromBypass	I	23: The uninterruptible power supply (Matrix-UPS) returned from bypass mode.
bypassPowerSupplyFailure	S	24: The base module bypass power supply of the uninterruptible power supply (Matrix-UPS) needs repair.
baseFanFailure	S	25: The base module fan of the uninterruptible power supply (Matrix-UPS) needs repair.
batteryPackCommLost	S	26: Communication with the external battery packs of the uninterruptible power supply was lost (Matrix-UPS or Smart-UPS XL).
batteryPackCommEstablished	I	27: Communication with external battery packs was regained (Matrix-UPS or Smart-UPS XL).
calibrationStart	I	28: A runtime calibration has started.
restartAgent	I	29: The SNMP agent of the Network Management Card is restarting as commanded by the NMS.
upsTurnedOn	I	30: The uninterruptible power supply is turned on.
smartTrimOn	W	31: The uninterruptible power supply enabled its Trim feature.
codeAuthenticationDone	I	32: Authentication of the TFTP agent file code image is done.
<p>† Severity: S = Severe, W = Warning, I = Informational</p>		

Trap	Severity [†]	Number and Description
upsOverloadCleared	I	33: The uninterruptible power supply overload condition is corrected.
smartBoostOff	I	34: The uninterruptible power supply (Smart-UPS) returned from using its Boost feature.
smartAvrReducingOff	I	35: The uninterruptible power supply (Matrix-UPS) returned from using its Trim feature.
upsBatteryReplaced	I	36: A faulty battery was replaced.
calibrationEnd	I	37: A runtime calibration ended.
dischargeCleared	I	38: An uninterruptible power supply discharge condition ended.
gracefullShutdown	I	39: A graceful shutdown started.
<i>Not currently used.</i>	<i>none</i>	40: <i>Reserved for future use.</i>
outletOn	I	41: The MasterSwitch outlet specified by sPDUOutletControlIndex is turned on, or if the value is 0, all outlets are on.
outletOff	I	42: The MasterSwitch outlet specified by sPDUOutletControlIndex is turned off, or if that value is 0, all outlets are off.
outletReboot	I	43: The MasterSwitch outlet specified by sPDUOutletControlIndex was restarted, or if that value is 0, all outlets were restarted.
configChange	W	44: The MasterSwitch SNMP configuration changed.
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
configChangeOutlet	W	45: The configuration of the MasterSwitch outlet specified by sPDUOutletConfigIndex changed, or if that value is 0, the master outlet configuration changed.
accessViolationConsole	W	46: Three unsuccessful MasterSwitch console login attempts occurred.
accessViolationHTTP	W	47: An unsuccessful MasterSwitch HTTP login attempt occurred.
passwordChange	W	48: The MasterSwitch console password changed.
badVoltage	W	49: The uninterruptible power supply output voltage is not within the acceptable range.
badVoltageCleared	I	50: The uninterruptible power supply output voltage is again within the acceptable range.
chargerFailure	W	51: The uninterruptible power supply battery charger failed.
chargerFailureCleared	I	52: The uninterruptible power supply battery charger returned to normal operation.
batteryOverTemperature	W	53: The uninterruptible power supply battery temperature exceeded the temperature threshold.
batteryOverTemperatureCleared	I	54: The uninterruptible power supply battery temperature no longer exceeds the temperature threshold.
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity[†]	Number and Description
smartRelayFault	W	55: The Boost or Trim relay failed.
smartRelayFaultCleared	I	56: The Boost or Trim relay failure is corrected.
humidityThresholdViolation1	W	57: The Environmental Monitor probe 1 humidity threshold was violated.
humidityThresholdViolationCleared1	I	58: The Environmental Monitor probe 1 humidity threshold is no longer violated.
TemperatureThresholdViolation1	W	59: The Environmental Monitor probe 1 temperature threshold was violated.
TemperatureThresholdViolationCleared1	I	60: The Environmental Monitor probe 1 temperature threshold is no longer violated.
humidityThresholdViolation2	W	61: The Environmental Monitor probe 2 humidity threshold was violated.
humidityThresholdViolationCleared2	I	62: The Environmental Monitor probe 2 humidity threshold is no longer violated.
TemperatureThresholdViolation2	W	63: The Environmental Monitor probe 2 temperature threshold was violated.
TemperatureThresholdViolationCleared2	I	64: The Environmental Monitor probe 2 temperature threshold is no longer violated.
mupsCommunicationEstablished	I	65: Communication with the Environmental Monitor is established.
† Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
mupsCommunicationLost	W	66: Communication with the Environmental Monitor was lost.
batteryIncrease	I	67: The number of Symmetra uninterruptible power supply batteries was increased.
batteryDecrease	I	68: The number of Symmetra uninterruptible power supply batteries was decreased.
powerModuleIncrease	I	69: The number of Symmetra uninterruptible power supply power modules was increased.
powerModuleDecrease	I	70: The number of Symmetra uninterruptible power supply power modules was decreased.
intelligenceModuleInserted	I	71: An intelligence module was inserted into the Symmetra uninterruptible power supply.
intelligenceModuleRemoved	I	72: An intelligence module was removed from the Symmetra uninterruptible power supply.
rintelligenceModuleInserted	I	73: A redundant intelligence module was inserted into the Symmetra uninterruptible power supply.
rintelligenceModuleRemoved	I	74: A redundant intelligence module was removed from the Symmetra uninterruptible power supply.
extBatteryFrameIncrease	I	75: An external battery frame was added to the Symmetra uninterruptible power supply.
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
extBatteryFrameDecrease	I	76: An external battery frame was removed from the Symmetra uninterruptible power supply.
abnormalCondition	S	77: See " Symmetra Uninterruptible Power Supply Subtraps " on page 165 for the subtraps that identify which abnormal condition has occurred.
abnormalConditionCleared	I	78: See " Symmetra Uninterruptible Power Supply Subtraps " on page 165 for the subtraps that identify which abnormal condition is corrected.
deviceStatusChange	I	79: The status of the device being monitored has changed.
noBatteries	W	80: The uninterruptible power supply has no batteries attached.
noBatteriesCleared	I	81: Batteries have been attached to the uninterruptible power supply.
userAdded	I	82: A new user was added.
userDeleted	I	83: A user was deleted.
userModified	I	84: A user's parameters were modified.
msvmCommunicationEstablished	I	85: Communication with the MasterSwitch VM unit is established.
msvmCommunicationLost	S	86: Communication with the MasterSwitch VM unit was lost.
† Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
msvmOverload	S	87: The MasterSwitch VM unit is near or at an overload condition.
msvmOverloadCleared	I	88: The overload condition on the MasterSwitch VM unit is corrected.
msvmOutletOn	I	89: An outlet on the MasterSwitch VM unit turned on.
msvmOutletOff	I	90: An outlet on the MasterSwitch VM unit turned off.
msvmDeviceConfigChange	I	91: A device configuration change was made on the MasterSwitch VM unit.
msvmOutletConfigChange	I	92: An outlet configuration change was made on the MasterSwitch VM unit.
msvmLowLoad	I	93: The MasterSwitch VM unit has violated the low load threshold.
msvmLowLoadCleared	I	94: The low-load condition on the MasterSwitch VM unit is corrected.
msvmNearOverload	S	95: The MasterSwitch VM unit is near or at an overload condition.
msvmNearOverloadCleared	I	96: The overload condition on the MasterSwitch VM unit is corrected.
msvmPowerSupplyStatusChange	I	97: The status of the power supply on the MasterSwitch VM unit has changed.
mvpCommunicationEstablished	I	98: Communication with the MasterSwitch Plus unit is established.
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
mspCommunicationLost	I	99: Communication with the MasterSwitch Plus unit was lost.
mspOutletOn	I	100: An outlet on the MasterSwitch Plus unit turned on.
mspOutletOff	I	101: An outlet on the MasterSwitch Plus unit turned off.
mspDeviceConfigChange	I	102: A device configuration change was made on the MasterSwitch Plus unit.
mspOutletConfigChange	I	103: An outlet configuration change was made on the MasterSwitch Plus unit.
rsSourceSwitched	I	<p>104: The Redundant Switch has switched its source. Variables:</p> <ol style="list-style-type: none"> 1. The current source: 0 for A; 1 for B. 2. The 32-character name of the source. 3. An integer indicating the cause of the transfer: <ul style="list-style-type: none"> • 0: no transfers recorded • 1: user action or preferred switching • 3: line notch or spike • 5: low line voltage • 7: high line voltage • 9: frequency out of range 4. A character string describing the transfer cause.
<p>† Severity: S = Severe, W = Warning, I = Informational</p>		

Trap	Severity [†]	Number and Description
rsLostRedundancy	S	105: The Redundant Switch lost redundancy. Variables: <ol style="list-style-type: none"> 1. The unavailable source: 0 for A; 1 for B. 2. The 32-character name of the unavailable source.
rsRedundancyRestored	I	106: Redundancy is restored to the Redundant Switch. Variables: <ol style="list-style-type: none"> 1. The source to which power was restored: 0 for A; 1 for B. 2. The 32-character name of the restored source.
rsConfigChange	I	107: A configuration change was made on a Redundant Switch.
rsCommunicationEstablished	I	108: Communication with the Redundant Switch is established.
rsCommunicationLost	S	109: Communication with the Redundant Switch was lost.
Traps 110 through 120 are for DC-powered systems. See the <i>MIB Reference Guide (990-1375)</i> for DC systems.		
logicPowerSuppliesIncreased	I	121: The number of system power supplies increased at the uninterruptible power supply.
logicPowerSuppliesDecreased	I	122: The number of system power supplies decreased at the uninterruptible power supply.
externalSwitchGearClosed	I	123: The identified external switch gear at the uninterruptible power supply is closed.
† Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
externalSwitchGearOpened	I	124: The identified external switch gear at the uninterruptible power supply is open.
generalDeviceEvent	I	125: The identified general event occurred at the uninterruptible power supply.
atsSourceSwitched	I	126: The Automatic Transfer Switch has switched source.
atsLostRedundancy	S	127: The Automatic Transfer Switch lost redundancy.
atsRedundancyRestored	I	128: Redundancy was restored to the Automatic Transfer Switch.
atsConfigChange	I	129: A configuration change was made on the Automatic Transfer Switch.
atsCommunicationEstablished	I	130: Communication with the Automatic Transfer Switch is established.
atsCommunicationLost	S	131: Communication with the Automatic Transfer Switch was lost.
atsOverCurrent	S	132: The output current of the Automatic Transfer Switch exceeded the threshold.
atsOverCurrentCleared	I	133: The output current of the Automatic Transfer Switch is back below the threshold.
atsPowerSupplyFailure	S	134: The Automatic Transfer Switch power supply failed.
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
atsPowerSupplyFailureCleared	I	135: The Automatic Transfer Switch power supply failure is corrected.
Traps 136 through 162 are for DC-powered systems. See the <i>MIB Reference Guide (990-1375)</i> for DC systems.		
iemHighTempThresholdViolation	S	163: The high temperature threshold of the Integrated Environmental Monitor was exceeded.
iemHighTempThresholdViolationCleared	I	164: The high temperature threshold violation of the Integrated Environmental Monitor is corrected.
iemLowTempThresholdViolation	S	165: The low temperature threshold of the Integrated Environmental Monitor was violated.
iemLowTempThresholdViolationCleared	I	166: The low temperature threshold violation of the Integrated Environmental Monitor is corrected.
iemHighHumidThresholdViolation	S	167: The high humidity threshold of the Integrated Environmental Monitor was exceeded.
iemHighHumidThresholdViolationCleared	I	168: The high humidity threshold violation of the Integrated Environmental Monitor is corrected.
iemLowHumidThresholdViolation	S	169: The low humidity threshold of the Integrated Environmental Monitor was violated.
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
iemLowHumidThresholdViolationCleared	I	170: The low humidity threshold violation of the Integrated Environmental Monitor is corrected.
iemProbeDisconnected	W	171: The probe of the Integrated Environmental Monitor was disconnected.
iemProbeConnected	I	172: The probe of the Integrated Environmental Monitor is connected.
iemContactFault	S	173: A contact fault occurred in the Integrated Environmental Monitor.
iemContactFaultCleared	I	174: The contact fault of the Integrated Environmental Monitor is corrected.
iemRelayFault	W	175: The output relay of the Integrated Environmental Monitor has a fault condition.
iemRelayFaultCleared	I	176: The fault condition of the output relay of the Integrated Environmental Monitor is corrected.
bmBatManCommEstab	I	177: Serial communications is established with the Battery Management System.
bmBatManCommLost	S	178: Serial communications was lost with the Battery Management System.
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
bmBatManKneeAlarm	S	179: The Battery Management System detected a battery voltage knee threshold alarm. While supporting the equipment load, one or more batteries showed a rapid drop in voltage, indicating the approaching end of the charge of a battery. To avoid battery damage, do not allow the battery string to discharge further.
bmBatManKneeAlarmCleared	I	180: The cause of the battery voltage knee threshold alarm is corrected.
bmBatManChargerAlarm	W	181: The Battery Management System detected a charger alarm.
bmBatManChargerAlarmCleared	I	182: The cause of the charger alarm of the Battery Management System is corrected.
bmBatManBatteryAlarm	W	183: The Battery Management System detected a battery alarm.
bmBatManBatteryAlarmCleared	I	184: The cause of the battery alarm of the Battery Management System is corrected.
bmBatManEnvironmentAlarm	W	185: The Battery Management System detected an environment alarm.
bmBatManEnvironmentAlarmCleared	I	186: The cause of the environment alarm of the Battery Management System is corrected.
bmBatManMaintenanceAlarm	I	187: The Battery Management System detected a “maintenance due” alarm.
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
bmBatManMaintenanceAlarmCleared	I	188: The cause of the “maintenance due” alarm of the Battery Management System is corrected.
pduCommunicationEstablished	I	189: Communication is established with the PDU. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name
pduCommunicationLost	S	190: Communication was lost with the PDU. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name
pduUtilityLineUndervoltage	S	191: The utility line voltage is too low for the PDU. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name 3. The phase number
pduUtilityLineUndervoltageCleared	I	192: The utility line low-voltage condition of the PDU is corrected. Variables: the same as for trap 191.
pduUtilityLineOvervoltage	S	193: The utility line voltage is too high for the PDU. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name 3. The phase number
pduUtilityLineOvervoltageCleared	I	194: The utility line high-voltage condition of the PDU is corrected. Variables: the same as for trap 193.
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
pduGroundOvercurrent	S	195: The ground current is too high for the PDU. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name
pduGroundOvercurrentCleared	I	196: The ground high-current condition of the PDU is corrected. Variables: the same as for trap 195.
pduCircuitPanelInputUndervoltage	S	197: The circuit panel input voltage is too low for the PDU. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name 3. The phase number
pduCircuitPanelInputUndervoltageCleared	I	198: The circuit panel low input voltage condition of the PDU is corrected. Variables: the same as for trap 197.
pduCircuitPanelInputOvervoltage	S	199: The circuit panel input voltage is too high for the PDU. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name 3. The phase number
pduCircuitPanelInputOvervoltageCleared	I	200: The circuit panel high input voltage condition of the PDU is corrected. Variables: the same as for trap 199.
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
pduCircuitPanelInputUndercurrent	S	201: The circuit panel input current is too low for the PDU. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name 3. The phase number
pduCircuitPanelInputUndercurrentCleared	I	202: The circuit panel low input current condition of the PDU is corrected. Variables: the same as for trap 201.
pduCircuitPanelInputOvercurrent	S	203: The circuit panel input current is too high for the PDU. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name 3. The phase number
pduCircuitPanelInputOvercurrentCleared	I	204: The circuit panel high input current condition is corrected. Variables: the same as for trap 203.
pduCircuitPanelFrequencyOutOfRange	S	205: The circuit panel input frequency is out of range for the PDU. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name
pduCircuitPanelFrequencyOutOfRangeCleared	I	206: The circuit panel input frequency is no longer out of range. Variables: the same as for trap 205.
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
pduCircuitPanelNeutralOvercurrent	S	207: The neutral circuit panel input current is too high for the PDU. Variables: 1. The serial number 2. The device name
pduCircuitPanelNeutralOvercurrentCleared	I	208: The neutral circuit panel high input current condition of the PDU is corrected. Variables: the same as for trap 207.
pduSystemOff	S	209: The PDU system is off. Variables: 1. The serial number 2. The device name
pduOnBatteryMode	S	210: The PDU is running in on-battery mode. Variables: 1. The serial number 2. The device name
pduMaintenanceBypassMode	I	211: The PDU is running in maintenance bypass mode. Variables: 1. The serial number 2. The device name
pduAtypicalBypassMode	W	212: The PDU is running in atypical bypass mode. Variables: 1. The serial number 2. The device name
pduNoPanelFeedMode	S	213: The PDU is running with no feed from the circuit panel. Variables: 1. The serial number 2. The device name
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
pduUpsOperationMode	I	214: The PDU is running in uninterruptible power supply operation mode. Variables: 1. The serial number 2. The device name
pduForcedBypassMode	W	215: The PDU is running in forced bypass mode. Variables: 1. The serial number 2. The device name
pduInputTransformerOverTemperature	S	216: The temperature of the input transformer of the PDU is too high Variables: 1. The serial number 2. The device name
pduInputTransformerOverTemperatureCleared	I	217: The temperature of the input transformer of the PDU is no longer too high. Variables: the same as for trap 216.
pduUPSInputVoltageLost	S	218: The PDU input voltage for phase <i>N</i> was lost. Variables: 1. The serial number 2. The device name 3. The phase number
pduUPSInputVoltageRestored	I	219: The PDU input voltage for phase <i>N</i> is restored. Variables: the same as for trap 218.
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
pduContactFault	S	220: A contact closure in the PDU is in an abnormal position. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name 3. The number of the contact
pduContactFaultCleared	I	221: A contact closure in the PDU has returned to a normal position. Variables: the same as for trap 220.
rmPDUUndercurrent	S	222: The input current of a phase of the rack PDU is too low. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name 3. The phase number
rmPDUUndercurrentCleared	I	223: The low input current condition for a phase of the rack PDU is corrected. Variables: the same as for trap 222.
rmPDUOvercurrent	S	224: The input current of a phase of the rack PDU is too high. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name 3. The phase number
rmPDUOvercurrentCleared	I	225: The high input current condition for a phase of the rack PDU is corrected. Variables: the same as for trap 224.
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
rmPDUOverload	S	226: A phase of the rack PDU is overloaded. Variables: 1. The serial number 2. The device name 3. The phase number
rmPDUOverloadCleared	I	227: The output overload condition for a phase of the rack PDU is corrected. Variables: the same as for trap 226.
rmPDUCommunicationEstablished	I	228: Communication is established with the rack PDU. Variables: 1. The serial number 2. The device name
rmPDUCommunicationLost	S	229: Communication was lost with the rack PDU. Variables: the same as for trap 228.
emsCommunicationEstablished	I	230: Communication is established with the Environmental Management System. Variables: 1. The serial number 2. The device name
emsCommunicationLost	S	231: Communication was lost with the Environmental Management System. Variables: the same as for trap 230.
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
emsProbeConnected	I	232: A probe was connected to the Environmental Management System. Variables: <ol style="list-style-type: none"> 1. The host device serial number 2. The host device name 3. The probe number 4. The probe name
emsProbeDisconnected	S	233: A probe was disconnected from the Environmental Management System. Variables: the same as for trap 232.
emsSensorConnected	I	234: A sensor was connected to the Environmental Management System. Variables: <ol style="list-style-type: none"> 1. The host device serial number 2. The host device name 3. The sensor number 4. The sensor name
emsSensorDisconnected	S	235: A sensor was disconnected from the Environmental Management System. Variables: the same as for trap 234.
emsSensorFault	S	236: A sensor in the Environmental Management System is in a fault condition. Variables: <ol style="list-style-type: none"> 1. The host device serial number 2. The host device name 3. The sensor number 4. The sensor name
† Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
emsSensorFaultCleared	I	237: A sensor fault condition in the Environmental Management System is corrected. Variables: the same as for trap 236.
emsBeaconConnected	I	238 A beacon was connected to the Environmental Management System. Variables: <ol style="list-style-type: none"> 1. The host device serial number 2. The host device name
emsBeaconDisconnected	S	239: A beacon was disconnected from the Environmental Management System. Variables: the same as for trap 238.
emsBeaconOn	I	240: A beacon of the Environmental Management System turned on. Variables: <ol style="list-style-type: none"> 1. The host device serial number 2. The host device name
emsBeaconOff	I	241: A beacon of the Environmental Management System turned off. Variables: the same as for trap 240.
emsMajorAlarm	S	242: A major alarm is present in the Environmental Management System. Variables: <ol style="list-style-type: none"> 1. The Environmental Management System serial number 2. The Environmental Management System name
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
emsMajorAlarmCleared	I	243: A major alarm in the Environmental Management System is corrected. Variables: the same as for trap 242.
emsMinorAlarm	S	244: A minor alarm is present in the Environmental Management System. Variables: <ol style="list-style-type: none"> 1. The Environmental Management System serial number 2. The Environmental Management System name
emsMinorAlarmCleared	I	245: A minor alarm in the Environmental Management System is corrected. Variables: the same as for trap 244.
emsOutletStateAbnormal	W	246: An outlet on the Environmental Management System changed to its abnormal state. Variables: <ol style="list-style-type: none"> 1. The host device serial number 2. The host device name 3. The outlet number 4. The outlet name 5. The current outlet state (1 = On; 2 = Off) 6. The configured normal outlet state (1 = On; 2 = Off)
emsOutletStateNormal	I	247: An outlet on the Environmental Management System changed to its normal state. Variables: the same as for trap 246.
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
emsInputContactStateAbnormal	W	248: An input contact on the Environmental Management System changed to its abnormal state. Variables: <ol style="list-style-type: none"> 1. The host device serial number 2. The host device name 3. The input contact number 4. The input contact name 5. The input contact state (1 = On; 2 = Off) 6. The configured normal input contact state (1 = On; 2 = Off)
emsInputContactStateNormal	I	249: An input contact on the Environmental Management System changed to its normal state. Variables: the same as for trap 248.
emsOutputRelayStateAbnormal	W	250: An output relay on the Environmental Management System changed to its abnormal state. Variables: <ol style="list-style-type: none"> 1. The host device serial number 2. The host device name 3. The output relay number 4. The output relay name 5. The output relay state (1 = On; 2 = Off) 6. The configured normal output relay state (1 = On; 2 = Off)
† Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
emsOutputRelayStateNormal	I	251: An output relay on the Environmental Management System changed to its normal state. Variables: the same as for trap 250.
emsDeviceConfigChange	I	252: A device configuration change was made on the Environmental Management System. Variables: <ol style="list-style-type: none"> 1. The Environmental Management System serial number 2. The Environmental Management System name
envHighTempThresholdViolation	S	253: The high temperature threshold for an Environmental Management System probe was exceeded. Variables: <ol style="list-style-type: none"> 1. The host device serial number 2. The host device name 3. The current temperature 4. The temperature scale 5. The probe number (or probe serial number, if it is an external device) 6. The probe name
envHighTempThresholdViolationCleared	I	254: The high temperature threshold violation for an Environmental Management System probe is corrected. Variables: the same as for trap 253.
[†] Severity: S = Severe, W = Warning, I = Informational		



Trap	Severity [†]	Number and Description
envLowTempThresholdViolation	S	255: The low temperature threshold for an Environmental Management System probe was violated. Variables: <ol style="list-style-type: none"> 1. The host device serial number 2. The host device name 3. The current temperature 4. The temperature scale 5. The probe number (or probe serial number, if it is an external device) 6. The probe name
envLowTempThresholdViolationCleared	I	256: The low temperature threshold violation for an Environmental Management System probe is corrected. Variables: the same as for trap 255.
envHighHumidityThresholdViolation	S	257: The high humidity threshold for an Environmental Management System probe was exceeded. Variables: <ol style="list-style-type: none"> 1. The host device serial number 2. The host device name 3. The current humidity 4. The probe number (or probe serial number, if it is an external device) 5. The probe name
† Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
envHighHumidityThresholdViolationCleared	I	258: The high humidity threshold violation for an Environmental Management System probe is corrected. Variables: the same as for trap 257.
envLowHumidityThresholdViolation	S	259: The low humidity threshold for an Environmental Management System probe was violated. Variables: <ol style="list-style-type: none"> 1. The host device serial number 2. The host device name 3. The current humidity 4. The probe number (or probe serial number, if it is an external device) 5. The probe name
envLowHumidityThresholdViolationCleared	I	260: The low humidity threshold violation for an Environmental Management System probe is corrected. Variables: the same as for trap 259.
Traps 261 through 265 are reserved for future use.		
rPDUCommunicationEstablished	I	266: Communication is established with a rack PDU. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name
rPDUCommunicationLost	I	267: Communication was lost with a rack PDU. Variables: the same as for trap 266.
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
rPDUOutletOn	I	268: An outlet on a switched rack PDU turned on. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name 3. The outlet index number 4. The outlet name
rPDUOutletOff	I	269: An outlet on a switched rack PDU turned off. Variables: the same as for trap 268.
rPDUDeviceConfigChange	I	270: The configuration of a switched rack PDU changed. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name
rPDUOutletConfigChange	I	271: The outlet configuration of a switched rack PDU changed. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name 3. The outlet index number 4. The outlet name
rPDULowLoad	W	272: A rack PDU violated the low load threshold. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name 3. The phase index number
rPDULowLoadCleared	W	273: The low load threshold violation for a rack PDU is corrected. Variables: the same as for trap 272.
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
rPDUNearOverload	W	274: The equipment load of a rack PDU is almost at an overload condition. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name 3. The phase index number 4. The phase load
rPDUNearOverloadCleared	I	275: The near-overload condition of a rack PDU is corrected. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name 3. The phase index number
rPDUOverload	S	276: A rack PDU is in an overload condition. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name 3. The phase index number
rPDUOverloadCleared	I	277: The overload condition of a rack PDU is corrected. Variables: the same as for trap 276.
rPDUPowerSupply1Fail	S	278: Power Supply 1 on a rack PDU has failed. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name
rPDUPowerSupply1Ok	I	279: Power Supply 1 on a rack PDU is operating normally. Variables: the same as for trap 278.
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
rPDUPowerSupply2Fail	S	280: Power Supply 2 on a rack PDU failed. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name
rPDUPowerSupply2Ok	I	281: Power Supply 2 on a rack PDU is operating normally. Variables: the same as for trap 280.
rPDUPhaseConfigChange	I	282: A phase-configuration change was made on a rack PDU. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name 3. The outlet index number (0 indicates all outlets.) 4. The outlet name (or device name, if the change is for all outlets)
rPDUCancelPendingCommand	I	283: A command for a switched rack PDU was canceled. Variables: <ol style="list-style-type: none"> 1. The serial number 2. The device name 3. The outlet index number (0 indicates all outlets.) 4. The outlet name (or device name, if the command is for all outlets)
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
aruAlinkCommunicationEstablished	I	284: Remote communication is established with the air removal unit (ARU) of the Environmental Management System. Variables: <ol style="list-style-type: none"> 1. The host device serial number 2. The host device name 3. The ARU number 4. The ARU name
aruAlinkCommunicationLost	S	285: Remote communication was lost with the air removal unit (ARU) of the Environmental Management System. Variables: the same as for trap 284.
aruFanFail	S	286: The fan in a remote air removal unit (ARU) of the Environmental Management System failed. <ol style="list-style-type: none"> 1. The host device serial number 2. The host device name 3. The ARU number 4. The ARU name
aruFanFailCleared	I	287: The failure of the fan in a remote air removal unit (ARU) of the Environmental Management System is corrected. Variables: the same as for trap 286.
† Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
aruSmokeAlarm	S	288: A smoke alarm is active in a remote air removal unit (ARU) of the Environmental Management System. Variables: <ol style="list-style-type: none"> 1. The host device serial number 2. The host device name 3. The ARU number 4. The ARU name
aruSmokeAlarmCleared	I	289: The cause of a smoke alarm in a remote air removal unit of the Environmental Management System is corrected. Variables: the same as for trap 288.
aruHighTemperatureAlarm	S	290: The temperature in a remote air removal unit (ARU) of the Environmental Management System is too high. Variables: <ol style="list-style-type: none"> 1. The host device serial number 2. The host device name 3. The ARU number 4. The ARU name
aruHighTemperatureAlarmCleared	I	291: The temperature in a remote air removal unit (ARU) is back within the normal range. Variables: the same as for trap 290.
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
aruExhaustTemperatureAlarm	S	292: The exhaust temperature of a remote air removal unit (ARU) of the Environmental Management System is too high. Variables: <ol style="list-style-type: none"> 1. The host device serial number 2. The host device name 3. The ARU number 4. The ARU name
aruExhaustTemperatureAlarmCleared	I	293: The exhaust temperature of a remote air removal unit (ARU) of the Environmental Management System is back within normal range. Variables: the same as for trap 292.
envAlinkCommunicationEstablished	I	294: Communication is established with a remote probe of the Environmental Management System. Variables: <ol style="list-style-type: none"> 1. The host device serial number 2. The host device name 3. The probe number 4. The probe name
envAlinkCommunicationLost	S	295: Communication was lost with a remote probe of the Environmental Management System. Variables: the same as for trap 294.
emsAlinkPowerOverload	S	296: A power overload occurred in the remote Environmental Management System. Variables: <ol style="list-style-type: none"> 1. The host device serial number 2. The host device name
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
emsAlinkPowerOverloadCleared	I	297: A power overload is corrected in the remote Environmental Management System. Variables: the same as for trap 296.
upsOutletGroupTurnedOn	I	298: The specified outlet group turned on.
upsOutletGroupTurnedOff	W	299: The specified outlet group turned off.
smwCriticalCondition	S	300: A critical (severe) condition was detected in the Symmetra 3-Phase MW UPS. The variable is the fault condition.
smwCriticalConditionCleared	I	301: A critical (severe) condition in the Symmetra 3-Phase MW UPS is corrected. The variable is the fault condition.
smwWarningCondition	W	302: A serious (warning) condition in the Symmetra 3-Phase MW UPS was detected. The variable is the fault condition.
smwWarningConditionCleared	I	303: A serious (warning) condition in the Symmetra 3-Phase MW UPS is corrected. The variable is the fault condition.
smwICondition	I	304: A non-serious (informational) condition in the Symmetra 3-Phase MW UPS was detected. The variable is the fault condition.
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
smwInformationalConditionCleared	I	305: A non-serious (informational) condition in the Symmetra 3-Phase MW UPS is corrected. The variable is the fault condition.
airCriticalCondition	S	306: A NetworkAIR critical (severe) condition was detected. Variables: <ol style="list-style-type: none"> 1. The error condition text message 2. The error number
airCriticalConditionCleared	I	307: A NetworkAIR critical (severe) condition was corrected. Variables: the same as for trap 306.
airWarningCondition	W	308: A NetworkAIR serious (warning) condition was detected. Variables: <ol style="list-style-type: none"> 1. The error condition text message 2. The error number
airWarningConditionCleared	I	309: A NetworkAIR serious (warning) condition was corrected. Variables: the same as for trap 308.
airInformationalCondition	I	310: A NetworkAIR non-serious (informational) condition was detected. Variables: <ol style="list-style-type: none"> 1. The error condition text message 2. The error number
[†] Severity: S = Severe, W = Warning, I = Informational		

Trap	Severity [†]	Number and Description
airInformationalConditionCleared	I	311: A NetworkAIR non-serious (informational) condition was corrected. Variables: the same as for trap 310.
[†] Severity: S = Severe, W = Warning, I = Informational		

Symmetra Uninterruptible Power Supply Subtraps

The "**abnormalCondition**" on page 134 and "**abnormalConditionCleared**" on page 134 traps for the Symmetra uninterruptible power supply have the following subtraps that identify the abnormal condition:



If you receive a subtrap that is identified as subtrap number 41 or higher in the following table, check the APC Web site www.apc.com for the latest version of the MIB.

Subtrap	Description
SYMtrapstr1	An installed power module failed.
SYMtrapstr2	A failed power module condition is corrected.
SYMtrapstr3	An installed intelligence module failed.
SYMtrapstr4	A failed intelligence module condition is corrected.
SYMtrapstr5	An installed redundant intelligence module failed.
SYMtrapstr6	A failed redundant intelligence module condition is corrected.
SYMtrapstr7	An installed battery failed.
SYMtrapstr8	A failed battery condition is corrected.
SYMtrapstr9	The load is at or above the alarm threshold.
SYMtrapstr10	The load is back below the load alarm threshold.
SYMtrapstr11	The uninterruptible power supply lost its redundancy.
SYMtrapstr12	The loss of redundancy is corrected.
SYMtrapstr13	The redundancy of the uninterruptible power supply is at or below the alarm threshold.
SYMtrapstr14	The redundancy of the uninterruptible power supply is above the alarm threshold again.

Subtrap	Description
SYMtrapstr15	The uninterruptible power supply is on bypass. Input voltage and frequency were out of range.
SYMtrapstr16	The uninterruptible power supply returned from bypass. Input voltage and frequency are back in range.
SYMtrapstr17	The bypass contactor is stuck in the bypass position.
SYMtrapstr18	The bypass contactor is no longer stuck in the bypass position.
SYMtrapstr19	The bypass contactor is stuck in the online position.
SYMtrapstr20	The bypass contactor is no longer stuck in the online position.
SYMtrapstr21	The uninterruptible power supply is in bypass mode because of an internal fault.
SYMtrapstr22	The internal fault that put the uninterruptible power supply into bypass mode was corrected.
SYMtrapstr23	The uninterruptible power supply is in bypass mode because of an overload.
SYMtrapstr24	The overload that put the uninterruptible power supply in bypass mode has been corrected.
SYMtrapstr25	The uninterruptible power supply is in maintenance bypass mode.
SYMtrapstr26	The uninterruptible power supply is no longer in maintenance bypass mode.
SYMtrapstr27	The input circuit breaker was tripped to the open position.
SYMtrapstr28	The tripped input circuit breaker is reset.
SYMtrapstr29	A system level fan failure occurred.
SYMtrapstr30	The system level fan failure is corrected.
SYMtrapstr31	The redundant intelligence module is in control.
SYMtrapstr32	The redundant intelligence module is no longer in control.

Subtrap	Description
SYMtrapstr33	An internal uninterruptible power supply communication problem (an I2C failure) occurred.
SYMtrapstr34	The internal communication problem (the I2C failure) is corrected.
SYMtrapstr35	An uninterruptible power supply battery is overheated.
SYMtrapstr36	The overheated battery condition is corrected.
SYMtrapstr37	The load is shut down. AC input was lost while the uninterruptible power supply was in bypass.
SYMtrapstr38	The load shutdown condition is corrected.
SYMtrapstr39	Remaining runtime is below the alarm threshold.
SYMtrapstr40	Remaining runtime is above the alarm threshold again.
SYMtrapstr41 and above	Odd-numbered traps: Bit <i>nn</i> of the Abnormal Condition register is set. Even-numbered traps: Bit <i>nn</i> of the Abnormal Condition register is reset.

Index

A

Agents

- managing 8
- of hardware devices 10
- viewing information about 9

Air Removal Unit

- configuring 70
- identification parameters 69
- locating the OIDs 68
- status 71

Alarm devices, Environmental Management System

- controlling alarm devices 60
- status 67

Alarms

- Automatic Transfer Switch 111
- configuring response of MasterSwitch Plus outlets 97
- overload alarm for MasterSwitch VM 79
- testing for uninterruptible power supply 26

Annunciator mode, MasterSwitch Plus 96

Automatic Transfer Switch

- calibration factor 110
- communication status 113
- configuring 112
- I/O data 110
- identification parameters 109
- managing 108
- status 113
- supported power supply voltages 110

B

Batteries

- diagnostics for Symmetra uninterruptible power supply 44
- status of uninterruptible power supply batteries 17

BOOTP, viewing the value 11

Browsers

- OID hierarchy in MIB browser 6
- using your MIB browser 2

Bypass mode, controlling 26

C

Calibration factor, Automatic Transfer Switch 110

Calibrations, performing for uninterruptible power supply 28

Communication status

- Air Removal Unit 71
- Automatic Transfer Switch 113
- External Environmental Monitor 53
- uninterruptible power supply 29

Configuring

- Air Removal Unit 70
- Automatic Transfer Switch 112
- Environmental Management System 61
- External Environmental Monitor 52
- Integrated Environmental Monitor 54
- MasterSwitch Plus
 - load-shedding 93
 - outlets 91
 - unit 88
- rack PDU
 - load thresholds 102
 - outlets 106
- synchronized control groups 35
- uninterruptible power supply 22

Contacts

- External Environmental Monitor 52
- Integrated Environmental Monitor 54

Controlling

- Environmental Management System 59
- MasterSwitch
 - outlets 76

- unit 75
- MasterSwitch Plus
 - outlets 90
 - unit 87
- MasterSwitch VM
 - outlets 82
 - unit 79

Cooling mode, NetworkAIR Portable
Air Conditioner 123

D

Date, setting for a card or device 11

Delays

- MasterSwitch outlet actions 75, 76
- MasterSwitch Plus outlet actions 92
- MasterSwitch VM
 - outlet actions 83
 - start-up delay 80
- outlet groups 39
- rack PDU outlet actions 106

Devices, diagnostics for external
devices 48

E

Environmental Management System

- configuring
 - check-log light 61
 - input contacts 62
 - outlets 62
 - output relays 62
 - probes 61
 - sensors 63
- controlling
 - alarm devices 60
 - output relays 59
- identification parameters 58
- locating the OIDs 57
- resetting sensors 60
- status
 - alarm devices 67
 - input contacts 66
 - outlets 66

- output relays 66
- overall 64
- sensors 67
- turning outlets on and off 59

Environmental Monitors

- External
 - configuring 52
 - status 53
- Integrated
 - configuring 54
 - status 56

External devices, diagnostics 48

F

Files, transferring 12

Frames, diagnostics for Symmetra
uninterruptible power supply 45

G

Graceful shutdown mode,
MasterSwitch Plus 92

I

I/O data, Automatic Transfer Switch 110

Identification parameters

- Air Removal Unit 69
- Automatic Transfer Switch 109
- Environmental Management System 58
- External Environmental Monitor 51
- MasterSwitch 74
- MasterSwitch Plus 86
- MasterSwitch VM 78
- NetworkAIR FM Modules 118
- NetworkAIR Portable Air Conditioner 122
- rack PDU 100
- uninterruptible power supply 16

Input contacts, Environmental Management
System

- configuring 62
- status 66

- Input counters, resetting for
 - 3-phase uninterruptible power supply 30
- Input voltage of uninterruptible power supply 19
- Integrated Environmental Monitors
 - managing 54
 - status 56
- Intelligence modules, diagnostics 42

L

- Load thresholds, by phase for
 - rack PDU 102
- Load-shedding for MasterSwitch Plus 93
- Locating the OIDs
 - agents 8
 - Air Removal Unit 68
 - Automatic Transfer Switch 108
 - Environmental Management System 57
 - Environmental Monitors 50
 - MasterSwitch Plus 85
 - MasterSwitch VM 77
 - Network Management Cards 8
 - NetworkAIR FM system 117
 - NetworkAIR Portable Air Conditioner 121
 - rack PDU 99
 - uninterruptible power supply 14

M

- Managing
 - 3-phase uninterruptible power supply 30
 - agents 8
 - agents of a hardware device 10
 - Automatic Transfer Switch 108
 - Environmental Monitor
 - External 51
 - Integrated 54
 - Management Cards 8
 - MasterSwitch 73
 - MasterSwitch Plus 85
 - MasterSwitch VM 77

- NetworkAIR FM System 117
- NetworkAIR Portable Air Conditioner 121
- outlet groups of an uninterruptible power supply 39
- uninterruptible power supply 14

MasterSwitch

- configuring outlets 75
- controlling 75
- identification parameters 74
- managing 73
- restarting outlets 76
- turning outlets on and off 76

MasterSwitch Plus

- configuring
 - annunciator mode 96
 - graceful shutdown mode 92
 - outlet response to alarms 97
 - outlets 91
 - the unit 88
- controlling a unit
 - restarting 87
 - turning on and off 87
- controlling outlets 90
- identification parameters 86
- load-shedding 93
- locating the OIDs 85
- status
 - outlets 98
 - unit 89

MasterSwitch VM

- controlling
 - outlets 82
 - unit 79
- delays for outlet actions 83
- identification parameters 78
- managing 77
- overload alarm 79
- overload parameters 80
- start-up delay 80
- status
 - outlets 84
 - unit 81

- MIB
 - structure 4
 - using your MIB browser 2
 - version 1
- Monitoring a PowerNet agent 9
- N**
- Names, configuring
 - Automatic Transfer Switch 112
 - input feeds 114
 - output feeds 115
 - MasterSwitch
 - outlets 76
 - unit 75
 - MasterSwitch Plus
 - outlets 91
 - unit 88
 - MasterSwitch VM
 - outlets 83
 - unit 80
 - rack PDU 100
 - uninterruptible power supply 16
 - input feeds 31
 - outlet groups 39
- NetworkAIR FM
 - locating the OIDs 117
 - viewing identification parameters 118
- NetworkAIR Portable Air Conditioner
 - locating the OIDs 121
 - viewing identification parameters 122
- O**
- OIDs 7
 - categories above PowerNet MIB 6
 - categories within PowerNet MIB 6
 - major categories
 - [hardware] 7
 - [products] 7
 - [software] 7
 - [system] 7
 - products that use OIDs 5
 - table 7

- Operating mode, NetworkAIR Portable Air Conditioner 123
- Operating parameters, uninterruptible power supply 23
- Outlet groups
 - configuring delay times 39
 - controlling for an uninterruptible power supply 40
- Outlets
 - Environmental Management System
 - configuring 62
 - controlling 59
 - status 66
 - MasterSwitch
 - configuring 75
 - controlling 76
 - MasterSwitch Plus
 - configuring 91
 - controlling 90
 - status 98
 - rack PDU
 - configuring 106
 - controlling 104
 - status 107
- Output capacity, NetworkAIR FM Modules 119
- Output counters, resetting for 3-phase uninterruptible power supply 30
- Output relays, Environmental Management System
 - configuring 62
 - status 66
- Output voltage, uninterruptible power supply 19
- P**
- Power modules, diagnostics 43
- Power supplies
 - status for rack PDU 107
 - voltages supported for Automatic Transfer Switch 110

- PowerNet agent, monitoring 9
- Probes
 - Environmental Management System configuring 61
 - status 65
 - External Environmental Monitor 52
 - Integrated Environmental Monitor 54

R

- Rack Air Removal Unit. *See Air Removal Unit*
- Rack PDU
 - controlling outlets 104
 - identification parameters 100
 - load threshold by phase 102
 - number of phases 101
 - rated power 101
 - status
 - load by phase 103
 - outlets 107
 - power supplies 107
- Resetting
 - Automatic Transfer Switch 111
 - Environmental Management System sensor 60
 - phase input counters 30
 - phase output counters 30
- Restarting
 - outlets
 - MasterSwitch 76
 - MasterSwitch Plus 92
 - MasterSwitch VM 82

S

- Self-tests, performing for uninterruptible power supply 28
- Sensors, Environmental Management System
 - configuring 63
 - resetting 60
 - status 67

- Setpoint, for NetworkAIR Portable Air Conditioner temperature 123
- Severity levels, for traps 125
- Shutdown parameters, uninterruptible power supply 23
- Sleep mode, initiating for uninterruptible power supply 26
- SNMP, access control for NMSs 5
- Software modules of an agent 9
- State of uninterruptible power supplies 37
- Status
 - Air Removal Unit 71
 - Automatic Transfer Switch 113
 - communications buses, Symmetra uninterruptible power supply 49
 - Environmental Management System 64
 - alarm devices 67
 - input contacts 66
 - outlets 66
 - output relays 66
 - probes 65
 - sensors 67
 - External Environmental Monitor 53
 - Integrated Environmental Monitor 56
 - MasterSwitch Plus
 - outlets 98
 - unit 89
 - MasterSwitch VM
 - outlets 84
 - unit 81
 - NetworkAIR FM Systems and Modules
 - humidity-related OIDs 119
 - output capacity of each Module 119
 - temperature-related OIDs 119
 - NetworkAIR Portable Air Conditioner
 - operating mode 123
 - operational status of components (fan, blower, compressor, pump) 123
 - Remote humidity OID 123
 - temperature setpoint 123
 - temperature-related OIDs 123
 - rack PDU 103, 107

- uninterruptible power supply
 - batteries 17
 - communication 29
 - input feeds 31
 - output feeds 33
 - synchronized control groups 36

- Symmetra uninterruptible power supply
 - diagnostics 41
 - status of communication buses 49
 - subtraps 165

- Synchronizing
 - control groups 35
 - multiple uninterruptible power supplies 35

T

- Tabled OIDs 7
- Time, setting for a card or device 11
- Transferring files 12
- Trap receivers
 - defining 125
 - setting 11

Traps

- Air Removal Unit 159
- Automatic Transfer Switch 138
- Battery Management System 140
- defining trap receivers 125
- enabling argument types for 12
- Environmental Management System 148, 161
- External Environmental Monitor 132
- Integrated Environmental Monitor 139
- MasterSwitch 130
- MasterSwitch Plus 135
- MasterSwitch VM 134
- Matrix-UPS 129
- NetworkAIR 163
- PDU 142
- rack PDU 147, 155
- Redundant Switch 136
- severity levels 125
- Smart-UPS XL 129

- SNMP agent 127
- Symmetra MW uninterruptible power supply 162
- Symmetra uninterruptible power supply 133
- Symmetra uninterruptible power supply subtraps 165
- uninterruptible power supply 127, 131, 137
- uninterruptible power supply outlet groups 162

U

- Uninterruptible power supplies
 - configuring

- identification parameters 16
 - operating parameters 23
 - shutdown parameters 23
 - VA ratings for devices of an uninterruptible power supply 22

- controlling

- bypass mode 26
 - outlet groups 40
 - uninterruptible power supply operation 26

- diagnostics for Symmetra uninterruptible power supply 41

- initiating sleep mode 26

- input voltage 19

- locating the OIDs for 14

- managing

- 3-phase uninterruptible power supply 30
 - outlet groups 39

- outlet groups 39

- output voltage 19

- performing

- calibrations 28
 - self-tests 28

- state 37

- status

- batteries 17
 - communication 29
 - input feeds 31
 - output feeds 33

- Symmetra uninterruptible power supply communication buses 49

- synchronizing
 - control groups 35
 - multiple uninterruptible power supplies 35
- testing alarms 26

V

- VA ratings for devices of an uninterruptible power supply 22
- Venting mode, NetworkAIR Portable Air Conditioner 123
- Version
 - MIB 1
 - of an agent 9

Edition notice

© Copyright International Business Machines Corporation, 2004. All rights reserved.

U.S. Government Users – Documentation related to restricted rights – Use, duplication or disclosure is subject to restrictions set forth in GSA ADP Schedule Contract with IBM Corp.

Trademarks

IBM is a trademark of International Business Machines Corporation in the United States, other countries, or both.

APC, the APC logo, Back-UPS, MasterSwitch, Matrix-UPS, NetworkAIR, PowerNet, Silcon, Smart-UPS, and Symmetra are trademarks of American Power Conversion Corporation. Other company, product, or service names may be the trademarks or service marks of others.

Part Number:

991-0264B