


Syquest 312RD Installation Guide

Document: 49-531 R00

July 1985

1. Remove jumpers W3, W8, and W9 from the Syquest 312RD drive circuit board. (See Figure 1.)
2. Power down the Megaframe.
3. Open the rear door of the Megaframe. Pull out the hinged door containing the fan so the disk drives are accessible.
4. Disconnect the two ribbon cables from the Syquest 306 drive (drive 0).
5. Disconnect the AC power cable (0P3) from the power supply.
6. Remove the rails containing the Syquest 306 and the power supply from the Megaframe.
7. Remove the four screws which attach the Syquest 306 to the rails. Replace the Syquest 306 with the Syquest 312RD. Insert and tighten the screws.
8. Install the rails containing the Syquest 312RD into the Megaframe.
9. Connect the two ribbon cables to the corresponding connectors on the Syquest 312RD.
10. Reconnect 0P3, the AC power connector to the drive power supply.
11. Replace fan to original position.
12. Remove the file processor board from the Megaframe.



13. Remove the WD1010AL-00 chip from location 16D on the file processor board. (See Figure 2.)
14. Insert the WD1010AL-05 chip in location 16D. Ensure pin 1 orientation is correct.
15. Replace file processor board in the Megaframe.
16. Close the rear door of the Megaframe.
17. Power on the Megaframe.
18. Insert floppy diskette C3 Standard Software 2.2h (Part number C3-00475h) in drive f0.
19. Type in submit, press return. Type in [f0]<sys>hdinstall.sub, press GO. When the command has completed, reboot the system. The system is now ready for operation.

