SPECIFICATION MANUAL LARGE DISC ADAPTER

REV A

ZA-4036 F/N: 217304 REV. A



LARGE DISK ADAPTER Specifications

ZA-4036 F/N 217304

GENERAL

The Large Disk Adapter (LDA) allows the attachment of up to eight disk drives to a CHI central processor. The LDA is an integral part of the processor I/O. The standard LDA supports up to eight CHI 2330 model 2 disk drives.

The CHI 2330 model 2 disk drive with 79.3 megaword capacity has nineteen recording surfaces. Each recording surface has 815 data tracks with 16 sectors per track. Each sector has a capacity of 320 16 bit words. Cylinders 807 through 814 are reserved leaving 78.6 megaword user capacity. This drive is often referred to as a 200 megabyte drive which describes its raw unformatted capacity.

The CHI LDA is not format compatible with other disk controllers. Disk packs may only be interchanged between CHI systems equipped with the LDA.

The LDA incorporates a special form of cyclical redundancy check for data error detection and limited error correction. The error correction procedure requires a significant amount of time; therefore, operation retries will normally be done first under automatic control of the LDA.

The sectors as recorded on the disk pack will always contain 320 data words, not counting the sector address. A larger or smaller number of words, however, may be transferred with the LDA accessing additional sectors or making up the difference. When it is desired to transfer more than a single sector's worth of data, it is only necessary to provide the sector address for the beginning sector and the total word count desired. The LDA will compute successive sector addresses and will cause new head selects and seeks to occur when necessary.

The LDA incorporates a significantly different I/O protocol which requires programming concepts new to the 2130 system. There is only one XIO command. That command is a function control which provides a memory address to the LDA. The LDA then begins cycle stealing command words from successive memory locations beginning at that address. Completion of the operation specified by the command word will be flagged by an interrupt. All operations, including transfer of status information, will be terminated in this fashion. There are several special cases of the single XIO that do not result in cycle stealing command words. These special cases are flagged by modifier bits in the XIO.



These modifier bits are involved with the following immediate operations: unmask interrupt; mask interrupt; reset interrupt; and halt controller.

A sequence of operations may be begun with a single XIO and there will be only one interrupt at the end of the last operation as long as each operation in the sequence completes normally. This is done by chaining command words. When command words are chained, an interrupt will not occur at the end of the operation specified by each command word, but instead the LDA will go to the next command word in the command buffer. Multiple non-contiguous command word buffers may be used by linking between buffers with the 'alternate command buffer' command word. If any operation associated with chain commands does not complete in a normal manner, then the rest of the command chain will not be executed but an interrupt will be presented.




X10 START

EA	EA + 1
0	<u>15 0 4 5 7 8 10 11 15</u>
COMMAND ADDRESS	DEVICE X X X 0 0 0 0 ID
LOCATION OF FIRST COMMAND WORD IN MEMORY	
CONVENTIONAL 2130 AREA CODE ————————————————————————————————————	
FUNCTION FIELD -	
SPECIAL MODIFIER FIELD MU	JST BE ZERO
INDIVIDUAL CONTROLLER IDE	NTIFICATION (GROUP)



X10 SENSE ILSW




THERE ARE TWO ILSW BITS WHICH ARE INDIVIDUALLY ASSIGNABLE TO ANY POSITION. ONE IS FOR THE OP END INTERRUPT THE OTHER IS FOR THE PROGRAMMED INTERRUPT.

THE ADAPTER IS ASSIGNABLE TO ANY INTERRUPT LEVEL FROM 1 TO 5.




X10 IMMEDIATE






GENERAL COMMAND WORD FORMAT





WRITE COMMAND




NOTE:

<u>CAUTION</u> "INITIALIZE SECTOR ID FIELD" SHOULD ONLY BE DONE WHEN THE CAPABILITY TO FLAG DEFECTIVE TRACKS AND ASSIGN ALTERNATE TRACKS IS AVAILABLE.



READ COMMAND




NOTE:

WHEN A READ ID AND DATA FIELD IS SPECIFIED WITH A WORD COUNT OF 2, ONLY THE ID FIELD WILL BE READ (AND ERROR CHECKED).



READ OR WRITE COMMAND

SECTOR ADDRESS FORMAT




SECTOR ADDRESS IS FOR THE FIRST SECTOR. WHEN THE WORD COUNT EXCEEDS THE CAPACITY OF A SINGLE SECTOR, THE CONTROLLER WILL CALCULATE SUCCESSIVE SECTOR ADDRESSES IN A CYLINDER FORMAT.

RANGE OF DECIMAL VALUES

•	29	MEGAWORD DRIVE	79	MEGAWORD DRIVE
CYLINDER ADDRESS		0-821		0-814
HEAD ADDRESS		D-4		0-18
SECTOR ADDRESS		0-23		0-15




READ OR WRITE COMMAND




THE WORD COUNT MAY BE ANY VALUE BETWEEN 1 AND 65,535. THE ADAPTER WILL AUTOMATICALLY ACCESS SUCCESSIVE SECTORS IN A CYLINDER FORMAT.

CONTROL COMMAND





SET CYCLE STEAL DELAY.



DELAY IS BINARILY ENCODED IN INCREMENTS OF .66 MICROSECONDS FROM 0 TO 10 MICROSECONDS. THE DEFAULT CONDITION IS ZERO DELAY.

SEEK CONTROL COMMAND

	CM	CW + 1	
0	7.8	1505 6	15
0 0 R 0 0 1 1	S C P 1 T C O I D	0 0 0 X X X X X X CYLINDE	R ADDRESS

SET HEAD CONTROL COMMAND


Γ								-C	W								Γ				 (CW	+	1					7
	0							_7	8							15	0									1	0	11 1	 5
L	0	0	S R	0	1	0	1	1	S T	C	0	P I	o	0	0	0	х	x	x	X	Х	X	x	х	X	x	х	HEAD ADDRESS	



SELECT DRIVE CONTROL COMMAND


			/			- (CW														. CI	N :	+	1 -						\exists
0							7	_8_							15	0											11	12	1	<u>5</u>
0	0	S R	0	1	1	1	1	S T	C C	0	P I	0	0	0	0	x	х	x	x	x	x	X	X	x	X	X			IVE DRES	s

DESELECT DRIVE CONTROL COMMAND




THIS COMMAND IS ONLY REQUIRED BY SYSTEMS UTILIZING DUAL PORT DISK DRIVES. NORMALLY A NEW DRIVE SELECT CONTROL COMMAND WILL OVERLAY THE OLD.

SENSE COMMAND





ALTERNATE COMMAND BUFFER COMMAND



BIT	
0	OPERATION ERROR ABORT
. 1	SUCCESSFUL OPERATION END
2	NOT READY
3	INVALID COMMAND
4.	NINETEEN SURFACE ID
5	DATA ERROR
6	NON CORRECTABLE DATA ERROR
7	DRIVE SEEK ERROR
8	WRITE PROTECTED
9	UNAVAILABLE CYLINDER ADDRESS
10	UNAVAILABLE HEAD ADDRESS
11	UNAVAILABLE SECTOR ADDRESS
12	DRIVE FAULT
·13	INVALID COMMAND SEQUENCE
14	TRANSFER LOCKOUT
15	TWENTY-FOUR SECTOR TRACKS

OPERATION ERROR ABORT (WORD 1 BIT 0)

This bit is the logical "or" of all abnormal conditions.

If this bit is on, one or more of the following conditions will also be flagged.

DATA ERROR
NON CORRECTABLE DATA ERROR
WRITE PROTECTED ERROR
DRIVE SEEK ERROR
UNAVAILABLE CYLINDER ADDRESS
UNAVAILABLE HEAD ADDRESS
UNAVAILABLE SECTOR ADDRESS
READ/WRITE FAULT
UNAVAILABLE DRIVE
DRIVE RESERVED

The memory address of the command for which the error bit was set is provided in an additional status word.

If an error is still indicated at the end of the automatic error retry then the LDA will look for a sense command at the end of a command chain. The sense command will be executed if found and then an interrupt will be generated. If there is no sense command then the interrupt will be generated immediately.

SUCCESSFUL OPERATION END (WORD 1 BIT 1)

Indicates that all commands fetched as a result of the last START XIO were executed without any abnormal conditions occurring.

NOT READY (WORD 1 BIT 2)

Attached drive cannot be accessed.

WRITE PROTECTED (WORD 1 BIT 8)

Drive cannot be written to. Is turned on with error when read only sector is attempted to be written

NINETEEN SURFACE DR. (WORD 1 BIT 4)

Indicates selected drive has 19 surfaces instead of 5.

WORD TWO BIT	
0	UNAVAILABLE DRIVE
1	MULTIPLE DRÍVES SELECTED
2	DRIVE RESERVED
3	NO DRIVE SELECT ENABLED
4	MSB
5	
6	CURRENTLY SELECTED DRIVE
7	LSB
8)	
9 }	RESERVED
10	•
11	MSB
12	
13	NEXT AVAILABLE SECTOR
14	
15	LSB

WORD THREE

Memory address of last command fetched that was not a sense or transfer command buffer command.

If there was no error the address will be that of a read, write, or control command.

If there was an error the address will be that of the command for which the error occurred.

Will be all ones following DC reset

WORD FOUR

Will provide adapter control program version number in bits 0 thru 7, and modification number in bits 8 thru 15. Example: first controller will be version 1 mod 0 or /0100

WORD FIVE

WORD FIVE and beyond will be used for diagnostic status.




WORD FIVE	. DIAGNOSTIC STATUS
Bit	
0	Drive Fault
1	No Sync
2	ECC Error
3	Data Compare Error'
4	Offset Reverse
5	Offset Forward
6.	Retard Data Window
7	Advance Data Window
8	Sector Overrun
9	Data Overrun
10	Defective Sector
11	Defective Track
12	Sector ID OK
13	Primary Sector ID Bad
14	Re Zero
15	Offset Error


WORD SEVEN


Host memory Address of First Word in Error


WORD EIGHT

Bit Mask to Correct Error (if error burst crossed word boundary then bit mask is folded around into a single word).











COMPUTER HANDWARE INC








HEADER & COVER-

2049 JER

211762




DONE.)


<u>MOTE:</u> TERMINATOR PLUG TO BE USED <u>ONLY</u> ON <u>LAST</u> CARD IN RECEIVER / DRIVER CHAIN. USE LABEL DA-3498-1 SHOWN ABOVE.

DETAIL A


JUMPER WIRE CONFIGURATION



USED IN 3 PLACES (POSITIONS A, B, ÉC) ON <u>EACH</u> RECEIVER / DRIVER CARD.




LDA MEMORY FUNCTION (REFERENCE)




COMPUTER HAPDWARE INC

\$AC | 3403



C



NOTE: SALES ORDER MUST SPECIFY THE DISC DRIVE NUMBER WHEN ORDERING A DRIVE EXPANSION.

LARGE DISK ADAPTER GENERAL BLOCK DIAGRAM

