# HP 12897A DUAL CHANNEL PORT CONTROLLER

THEORY OF OPERATION

# NOTE

This document is part of the HP 1000 M, E, and F-Series Computers Engineering and Reference Documentation and is not available separately.

# CONTENTS

Paragraph		Page
1.0	Introduction	3
2.0	General Description	3
2.1	Basic Block Diagram	
2.1.1	Interrupt and I/O Control Logic	4
2.1.2	Initialization Logic	5
2.1.3	Cycle Stealing Logic	
2.2	Interface Signal Descriptions	5
2.2.1	Input Signals	5
2.2.2	Output Signals	6
3.0	Programming	
3.1	Initialization Instructions	7
3.2	Control Instructions	8
3.3	Status Instructions	8
4.0	Detailed Theory of Operation	8
4.1	Initialization Logic	
4.1.1	Control Word 1	9
4.1.2	Control Word 2	9
4.1.3	Control Word 3	10
4.2	I/O Control and Interrupt Logic	11
4.2.1	Timing Decoders	11
4.2.2	I/O Instruction Decoding	11
4.2.3	Interrupt Logic	12
4.3	Cycle Stealing Ligic	13
4.3.1	Cycle Request Logic	
4.3.2	Cycle Initiating Logic	14
4.3.3	Signal Generation Logic	15
4.4	DMA Input Transfers	15
4.5	DMA Output Transfers	
4.6	System Reset Signals	19
4.6.1	POPIO	19
4.6.2	CRS	19

### 12897 DUAL CHANNEL PORT CONTROLLER OPTION

### Theory of Operation

### 1.0 INTRODUCTION

This document provides a Theory of Operation for the 12897 Dual Channel Port Controller (called DMA in this document) option board for the 2105 , 2108: , and 2112. computers. Discussion is conducted on the functional block, programming, and detailed operation levels. Block diagrams, logic diagrams, and timing diagrams are used to show operation. A thorough understanding of this document is essential when performing maintenance or troubleshooting on the 12897 option.

### 2.0 GENERAL DESCRIPTION

The 12897 DMA option consists of a single 2100-size board which is inserted into the top connector of the memory backplane of the 2105, 2108, or 2112 computers. A 50-connector flat-cable connects between it and the power crossover PCA to provide additional signals.

The 12897A DMA option is functionally equivalent to the DMA option for the 2100A, and is programmed exactly the same.

The DMA option allows the user to initiate block word transfers between selected I/O devices and memory. DMA then controls the I/O device during the transfers, stealing memory and I/O cycles from the CPU, but not requiring CPU intervention until completion of the transfer.

DMA is capable of stealing every consecutive I/O cycle, (about 1.62 usec) and can therefore transfer around 616,666 words per second. There are two channels of DMA, each of which may be separately assigned to operate with any I/O interface, including those in the 12979 I/O Extender. When both channels are operating simultaneously, channel 1 has priority over channel 2. The combined total transfer rate is 616,666 words/second, IIIA -3

so channel 2's maximum rate is 616,666 minus channel 1's actual rate.

When DMA is operating, it takes priority over the CPU for both memory accesses and control of the I/O system. The CPU may not access memory nor initiate an I/O cycle while DMA is cycle-stealing. The CPU can normally complete a memory operation in 976 nanoseconds, (read and obtain data) which need not be synchronized with the I/O system. The transfer rate available to the CPU is about 1.6 times the difference between 616,666 words per second and the combined total transfer rate of both DMA channels.

DMA transfers are initiated by an initialization routine and then hardware controls the transfers automatically. The initialization routine tells DMA which direction to transfer the data (in or out), where in memory to put the data, which I/O channel to use and how much data to transfer. completion of the transfer is signalled by an interrupt to location 6 (channel 1) or 7 (channel 2), if the interrupt system is enabled. It is also possible to check for completion by testing the status of the flag of select code 6 (channel 1) or select code 7 (channel 2). A block transfer can be aborted by an STF 06 or STF 07 instruction.

# 2.1 Basic Block Diagram

Refer to figure 1 for the following discussion of the basic organization of the DMA option.

### 2.1.1 Interrupt and I/O Control Logic

The functions of this logic are: to decode I/O signals from the CPU and control other elements of the DMA logic; to decode timing signals which control DMA operation; to generate interrupt requests; to fit DMA to the I/O system as a standard interface card.

### 2.1.2 Initialization logic

This logic contains the three oeprator control words which determine the nature of the transfers to be done.

The word count, memory address, select code of the I/O device, and control information are stored there during the initialization routine. The word count and memory address are incremented during DMA cycles. This logic notifies the interrupt and cycle stealing logic when a block transfer is completed.

# 2.1.3 Cycle Stealing Logic

This logic determines if a device is to be serviced by DMA, and generates the proper signals to control the CPU, memory, and the I/O device during a cycle-steal.

### 2.2 Interface Signal Descriptions

This section describes the main signals which are important in operation of the 12897 DMA option. Standard I/O signals and busses are not included. All signals are TTL-compatible, ground true unless otherwise specified.

### 2.2.1 Input Signals

SRQ10-SRQ25 "Service Request". Positive true. CTL compatible. Generated by devices requesting service, synchronously or asynchronously with T2. If the particular I/O device has been assigned a DMA channel, the its SRQ alerts logic to initiate a DMA cycle.

DMARQ1, DMARQ2 "DMA Request". CTL compatible, ground true.

Generated by an I/O Extender when an I/O device in the

Extender has been assigned a DMA channel, and requests

service on it. DMARQ1 is a request for channel 1

(select code 6), and DMARQ2 is a request for DMA channel 2 (select code 7).

### 2.2.2 Output Signals

- DMACYC. "DMA Cycle". True through periods T6-T5 if a DMA cycle is being done. Used to notify the system that a DMA cycle is in progress.
- DMALO/RACLO. "DMA/Random Access Channel Lockout". Identical signals, both OR-tieable. True during T5-T2 if a DMA/RAC cycle has been requested. Used to assure DMA of unhindered access to memory and I/O system.
- DMAEN. "DMA Enable". Sent to CPU to switch control of M-bus to DMA during a DMA cycle, and to enable the DMA Memory Address Registers onto the M-bus.
- DMAREAD. "DMA Read". To memory, to allow memory to time refresh around DMA, if necessary. True during T6-T5 of DMA output transfer.
- READ. "Read". To memory. True during T2 of Read cycle.

  Downward edge initiates a Read cycle in memory. OR-tieable.
- DMAIOO. "DMA I/O Output" to CPU. Gates S-bus onto I/O Bus during T3 of output transfer.
- DMAFRZ "DMA Freeze" to the CPU. Freezes CPU clocks and prevents CPU from using the S-BUS while DMA uses it. True during T3.
- DMAIOI "DMA I/O Input" to CPU board. Gates the I/O-bus onto the S-bus. True during T2-T3 of a DMA input transfer.
- DMALCH "DMA Latch" to CPU board. Holds data on the I/O-bus through completion of DMA output transfer. True during T4-T5.




FIGURE 1
DMA OPTION BLOCK DIAGRAM

- TEN "T Register Enable" to memory. Gates the T-register in memory onto the S-bus. True during T3 of DMA output transfers. OR-tieable.
- TST "T Register Store" to memory. Informs memory to clock data on S-bus into the T-register. True during
  T3 of DMA input transfers. OR-tieable.

WRITE to memory. Downward edge initiates a write cycle in memory. True during T4 of input transfers. OR-tieable.

### 3.0 PROGRAMMING

The 12897 DMA option is programmed in exactly the same manner as the DMA option for the 2100A computer. Included below is only a brief summary of the actions performed by the I/O instructions affecting the 12897 DMA operation. Select codes 2 and 6 refer to DMA channel 1, while select codes 3 and 7 refer to channel 2.

### 3.1 Initialization Instructions

- OT\* 06 Load the A or B register via the S-bus into the Service
- OT\* 07 Select Register (bits 0-5, 13, 15). This is Control Word 1.
- STC 02 Set the CTL2FF or CTL3FF high. Used to prepare
- STC 03 DMA to receive Control Word 2.
- CLC 02 Set the CTL2FF or CTL3FF low. Used to prepare

  DMA to receive Control Word 3.
- OT\* 02 Load the A or B register via the S-bus into the DMA
- OT\* 03 Memory Address Register (Control Word 2) if STC\_FF is low or into the Word Count Register (Control Word 3) if STC FF is high. Each channel has its own such registers.

# 3.2 Control Instructions

STC	06	Turns on DMA to look for SRQ's from I/O devices
STC	07	specified to begin the transfer described by the control words.
STF	06	Set the channel Flag Buffer flip-flop, which disables
STF	07	further DMA cycles on that channel, and will set the
		flag at the proper time.
CLF	06	Clears the Flag flip-flop, Flag Buffer flip-flop, and
CLF	07	IRQ flip-flop for that channel.

# 3.3 Status Instructions

SFS	06	SKIP next instruction if flag flip-flop is set (or clear)
STS	07	on that channel. If set, the block transfer has been
SEC	06	completed.
SFC	07	
LI*	02	READS the remaining word count (2's complement of it)
LI*	03	for the channel. May be used to determine how much of
		a DMA block transfer has been completed.

# 4.0 DETAILED THEORY OF OPERATION

The following discussion describes each functional section in operational detail, followed by a discussion of overall DMA operation during initiation, input and output transfers, and interrupt request generation. Logic for channel 1 is identical to that for channel 2, so only channel 1 will be discussed. It is not difficult to discover the channel 2 counterparts to channel 1.

### 4.1 Initialization Logic

Information from Control Words 1, 2 and 3 are loaded into registers in this logic, and used for transfer control when DMA is activated. The registers are loaded from the S-bus during the I/O instructions listed in section 3.1. The S-bus is buffered (U53, U93) before being distributed to the six registers (3 per channel). Refer to figures 2 and 3.

### 4.1.1 Control Word 1: register and logic

During IOO of a OT\* O6, Control Word 1 is loaded into the Service Select Register (U64), Bits O-5 contain the select code of the device under control of channel 1, and are designated SSR1-O through SSR1-5. Bit 13 of the S-bus is stored as CLCSEL1, and is used to specify whether CLC is to be issued to the I/O device at the end of a block transfer. Bit 15 of the S-bus is stored as STCSEL1, and is used to specify if a STC is to be issued to the I/O device at the end of each word transfer (except the last, if it is an input transfer).

When DCYCl is high (cycle in progress on channel 1) the Service Select Register is buffered (U63) onto the Select Code Bus to select the specified device for DMA control. This buffer also outputs the signals INCWCl at T2, and INCMRl at P5 of T5 during DCYCl. These signals increment the Word Count Register and Memory Address Register, respectively.

### 4.1.2 Control Word 2: register and logic

CTL2FF (U115, pin 13) must be low in order to load the second control word into the Memory Address Register (MAR). This is assured by executing a CLC 02 instruction which clears the R-S flip-flop CTL2FF.

A succeeding OT\* 02 instruction will load the A or B register into the Memory Address Register (U11, 12, 131, 132) with the negative edge of LOADMARI. The MAR is a 15 bit register containing a 15-bit ripple counter (loaded from bits 0-14 of the S-bus) and a single D flip-flop (loaded from bit 15 of the S-bus) called INFF1 (U11-pin 5). If INFF1 is high, then a DMA input transfer is to be done on channel 1. If low, then an output transfer. This flip-flop does not change once the MAR is loaded. The MAR counter is incremented by the downward edge of INCMR1 at the start of P5 of T5 during a DMA cycle on channel 1 (DCYC1).

The MAR is enabled onto the M-bus through a set of buffers (U13, 133) during DMAEN in DCYCl. DMAEN also disables the CPU M-register from using the M-bus.

Note that M-bus bit 15 is forced low during DMAEN in DCYCl, and that it is forced high during DMAEN in DCYC2. Bit 15 is monitored by the Memory Management option board for distinguishing DMA channels during transfers

### 4.1.3 Control Word 3: register and logic

CTL2FF (Ull5 pin 13) must be high to be able to load the third control word into Word Count Register 1. This is effected by issuing an STC 02 instruction, which sets the R-S flip-flop.

A succeeding OT\* 02 instruction will enable the A or B register into the Word Count Register (U41, 42, 101, 102) via the S-bus on the downward edge of LOADWC1, and latch the data on the rising edge. The Word Count Register is a 16-bit synchronous counter loaded with the two's complement of the number of words to be transferred under DMA channel 1 control. It performs a carry-look-ahead for each group of four bits while

INCWCl is low. If all outputs of the low order bits are high when INCWCl goes low, then the carry output, pin 12, goes low, which goes to pin 5 of the next group, performing the same function. If all bits of the Word Count Register are high, then INCWCl going low will result in WCRl (Word Count rollover) going high, indicating that the current transfer is the last. The register increments at the rising edge of INCWCl. INCWCl is low during T2 of a channel 1 cycle (DCYCl).

The Word Count Register is enabled onto the S-bus through the buffer (U43, 103) during LI\* 02 instructions, and stored onto the A or B register on the CPU.

### 4.2 I/O Control and Interrupt Logic

### 4.2.1 Timing Decoders

To generate I/O signals at the proper times, DMA needs to have a way to generate T2-T6 in sync with the CPU. To do this, DMA receives the TA, TB, TC signals from the CPU, and decodes them (U47, U46) to provide the required time periods.

### 4.2.2 I/O Instruction Decoding

DMA decodes the Select Code Bus to SCL2, SCL3, SCL6, SCL7, which are high if the appropriate DMA channel is referenced on the bus. ANDed with IOG, they generate SSL2, SSL3, SSL6, SSL7, respectively, which are high during I/O instructions for the specified DMA select codes. These signals are used as described below:

SSL2 (a) in conjunction with STC or CLC, set or clear the SSL3 STC2FF or STC3FF.

- (b) in conjunction with IOG, generate LOADWC or LOADMAR
- (c) in conjunction with IOI, gate the Word Count Register onto the S-bus.
- SSL6 (a) enable buffer Ul34 or Ul36, respectively, which
  then enables STC, CLC, CLF, and STF to the
  appropriate DMA channel flip-flop. The buffers
  OR-tie the status of the two channel flags for the
  skip logic (pins 1, 2). Only one channel flag
  status is selected for test during SFS or SFC,
  since only one buffer may be enabled at a time.
  - (b) in conjunction with IOG, load the Service Select Register.

### 4.2.3 Interrupt logic

When DMA is turned on, an STC 06, C instruction sets the Channel Control, CONT6FF (Ull5), and clears the Flag, Flag Buffer, and IRQ flip-flops (Ul25).

The interrupt generating sequence may be initiated in two ways. It is assumed that CONT6FF is high, the interrupt system is enabled (IEN5 is high), and the priority chain is intact to DMA (PRH6 is high). Refer to figure 4. If any one of these conditions is not met, no interrupt will be requested.

- a. WCRl (Word Count Rollover) is high. This indicates that the last word transfer is in progress. This sets FBFFl and clears the transfer enable flip-flop (TRENFFl).
- b. Issuing an STF 06 instruction. This sets FBFF1.

T2 following setting of the Flag Buffer, the Flag (FLG6FF) is set high. T5 following setting of FBFF1, TRENFF1 is set low, disabling further channel 1 cycles.

The T5 following setting of FLG6FF, IRQ6FF is set. IRQ6FF is high during T5-T6 and low T2-T4 until the interrupt is granted. However, if a higher priority device (Powerfail, Parity, or Memory Protect) sets its flag, then PRH6 will go low, preventing DMA from interrunting until the other device has been serviced and PRH6 is high again.

When the DMA interrupt request is acknowledged, IAK occurs at P3, 4, 5 of T6. IAK in conjunction with IRQ6FF clears FBFF1.

### 4.3 Cycle Stealing Logic

The cycle stealing logic compares the Service Select Register to the SRQ lines coming from I/O interface cards to determine if a cycle is to be requested. It resolves access priorities between the two DMA channels, initiates the cycle, and controls the generation of various signals to memory, the CPU, and the I/O interface to effect the desired transfer. Refer to figure 5.

# 4.3.1 Cycle Request Logic

This consists primarily of a 16-to-1 multiplexor (U51).

SSR1-0 to SSR1-5 select a SRQ line to monitor. When that SRQ line goes high, indicating the Flag has been set on the interface card with the select code specified in the SSR, then the REQ1 line goes high. DMARQ1 indicates a request for DMA channel 1 from the I/O Extender. It also sets REQ1 high.

### 4.3.2 Cycle Initiating Logic

The Cycle Request Register (U16) is the focal point for initiating DMA cycles on either channel. Refer to figure 5. It is clocked every trailing edge of P5.

When an STC 06 instruction is executed, the Transfer Enable flip-flop (TRENFF1) is set. This allows the cycle initiating logic to monitor the REQ1 line (U35A). If there is no power failure (PRH5 is high), then when REQ1 goes high, the Cycle Request 1 flip-flop, CYCRQ1, will be set at the end of T4. As long as CYCRQ1 is high, DMA channel 2 cannot take a cycle (gate U26B). Once CYCRQ1 goes high, it is kept high until the end of the next T4. The NOR of CYCRQ1 and CYCRQ2 during T5 through T2 is DMALO.

DMALO goes to the CPU to perform the following functions:

- a. Prevent setting the I/O Group Enable flip-flop.
- b. Freeze the CPU if it attempts to access memory, perform I/O instructions, or load the central Interrupt Register.
- c. Set the Interrupt Override ff on the CPU to prevent interrupt recognition during the cycle.

The DCYCl flip-flop follows CYCRQl, delayed by one T-period. It is valid T6-T5, and enables the signal generation logic for a DMA transfer. The DCYC2 flip-flop may not be set until the end of T5 after CYCRQl goes low, if CYCRQ2 is high. Channel 2 may thus take a cycle immediately after channel 1. The NOR of DCYCl and DCYC2 is DMACYC, which is sent to the CPU to prevent granting of interrupt requests until DMA has prevented its controlled device from requesting CPU service.

When FB6FF is set, then TRENFF1 is set low on the next T5, to give control of the Select Code Bus to DMA and to prevent CPU I/O signals.

### 4.3.3 Signal Generation Logic (Figure 5)

DCYCl controls two multiplexers (U24, 34) which select transfer control information from one or the other DMA channel's initialization logic (INFF\_\_, STCSEL\_\_, and CLCSEL\_\_) and Flag Buffer status. These signals determine the exact combination of output signals necessary to execute a DMA transfer. Six flip-flops are used to assist in this generation (U14, U17, U27). See sections 4.4, 4.5 for timed signals for input and output transfers. The signal "IN" (U34) selects the proper set of signals for input or output transfers.

### 4.4 DMA Input Transfers

The following table describes the algorithm for executing an input transfer on DMA channel 1. Refer to figure 6 for a diagram of timing signals for (a) normal cycle and (b) end-of-block-transfer cycle. It is assumed that TRENFFl is high initially and that SRQ is asserted in time to generate REQl by P5 of T4.

Time	Signals Initiated	Action
Т5	DMALO	Prevent CPU from interfering with upcoming cycle. Prevent interrupt service in the CPU.
Т6	DMACYC	Start cycle, enable signals, give DMA control of Select Code Bus, servicing in CPU.
	DMAEN	Spilling MARl onto M-bus, removing CPU from M-bus.
Т2	INCWCl	Check for word count rollover, increment word count on trailing edge. If WCRl occurs, set FBFF1 high.
	IOI	Tel I/O card to spill buffer onto I/O bus.
т3	DMAFRZ	Freeze CPU, free the S-bus.
	DMAIOI	Gate I/O bus onto the S-bus.
	TST	Clock S-bus into T-register.
	STC	Issue STC to interface card if STCSELl is high and FBFF1 is low.
	CLC	Issue CLC to interface card if CLCSELl is high and FBFFl is high.
	CLF	Issue CLF to interface card if FBFFl is low.

Time	Signals Initiated	Action
Т4	WRITE	Initiate write cycle in memory at address on M-bus.
	EDT	Issue to interface card if FBFFl is high.
Т5	INCMRl	Increment the Memory Address Register. Set TRENFFl low if FBFFl is set.

# 4.5 DMA Output Transfers

The following table describes the algorithm for executing an output transfer on DMA channel 1. Refer to figure 7 for a diagram of the Timing signals. It is assumed that TRENFF1 is high initially, and that SRQ is asserted in time to generate REQ1 by P5 of T4. Both the case of (a) normal cycles and (b) end-of-transfer cycles are illustrated

Time Period	Signal Initiated	Action
<b>T</b> 5	DMALO	Prevent CPU from interfering with upcoming cycle.
т6	DMACYC	Start cycle, enable signals, prevent CPU interrupt servicing.
	DMAREAD	Tell memory to schedule refresh during T4-T5.
	DMAEN	Enable DMA Memory Address Register l onto M-bus.
Т2	INCWCl	Check for Word Count Rollover.  If WCRl high, then set FBFF1  Increment Word Count at trailing edge.
	READ	Initiate Read cycle.
Т3	DMAFRZ	Freeze CPU while DMA uses S-bus.
	TEN	Enable data in T-register onto S-bus.
	DMAIOO	Enable S-bus onto I/O-bus.
	DMALCH	Hold data on I/O-bus. This signal
		allows S-bus to be used by CPU during
		following time periods.
	100	Clock I/O-bus into input buffer on
		I/O interface card.
	CLF	Issue CLF to interface card.
	STC	Issue STC to interface card if
		STCSELl is high.
	CLC	Issue CLC to interface card if FBFF1
		is high and CLCSELl is high.
L		IIIA -1

IIIA -19

Time Period	Signal Initiated	Action
Т4	EDT	Issue to interface card if FBFFl is high.
Т5	INCMRL	Increment Memory Address Register Set TRENFFl low if FBFFl is high.

# 4.6 System Reset Signals

### 4.6.1 POPIO

POPIO occurs during power-up or by pressing the Preset button on the front panel in the HALT mode. POPIO clears the Flag buffers on both channels (FBFF1, FBFF2). This terminates any block transfers in progress.

### 4.6.2 CRS

CRS occurs during POPIO or during STC 0 instructions. CRS clears CTL2FF, CTL3FF, CTL6FF, CTL7FF, TRENFF1, and TRENFF2, which disables DMA from interrupting and terminates any block transfers in progress.

# CONTROL WORD 1

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
1	STC		CLC									_			_	
0	STC		CLC								I	Device	s Sel	ect (	ode:	

STC: issue STC at the end of every cycle, except the last, if input.

CLC: issue CLC at the end of last word transfer.

	CONT	'ROL	WORD	2												
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
1	IN						7	Mamor	y Add	racc						
0	OUT						1	Memor	у лаа	1633						




FIGURE 2

DMA CONTROL WORD FORMATS

FIGURE 3
INITIALIZATION LOGIC




FIGURE 4

INTERRUPT AND PRIORITY LOGIC




FIGURE 5

CYCLE STEALING LOGIC, CHANNEL 1





FIGURE 7

DMA OUTPUT TRANSFER TIMING, CHANNEL 1



12897A DCPC Assembly Parts List (12897-60001) Sht. 1 of 3


NO.	REFERENCE DESIGNATOR (FIRST SIX)	PART DESCRIPT	ON PARENT OPTION		OPTION C	QUANTITY PER
0 0	C1-26	CAP .01UF		0160-2055	U	26
0 1	C27,28	CAP 10UF 10	*	0180-0374	D	2
0 0	E1,2	STUD SOLDER	TERM	0360-0294	U	5
0 1	R13,14	RES 147 1	×.125	0698-3438	D	5
1 1	R8,10,	RES 1K 1	×.125	0757-0280	D	3
0 0	R6	RES 1.5K 1	×.125	0757-0427	U	1
) 1	R24,11	SOCKET 16 D 5	IP LO	1200-0482	U	S
		PIN GRV .06	2X.25	1480-0116	u	5
0.1		RES NET 7X1 ,11,16,17	.5K	1810-0020		6
0 0	R1,15	RES NET 7x1	к	1810-0030	U	5
0 0	R3	RES NET 7X5	000	1810-0080		İ
0 1	U26,44	IC MC3001F ,46,94,97	,	1820-0141	U	5
0 0	U 8 1	L/T BUY RES	. USE	1820-0205		1
		IC SN74193 ,41,42,101 11,112	i N	1820-0233	U	8
0 0	U86	IC \$N7402N	,	1820-0328		1
	U36,56		N	1820-0370	U	5
		IC SN74H10	N	1820-0371	U	2


12897A DCPC Assembly Parts List (12897-60001) Sht. 2 of 3


NO.	REFERENCE DESIGNATOR (FIRST SIX)	PART DESCRIPTION	PARENT OPTION PART NUMBER	OPTION C QUANTITY PER
001	J95 <b>,</b> 96		1820-0371	
011	J <b>45,5</b> 5	IC SN74H11N	1820-0372	U 2
01	J <b>54,1</b> 0	IC SN74H04N 4	1820-0424	U 2
01	124,34	IC 9322PC	1820-0616	o s
001	J <b>91</b>	L/T BUY RES. US	1820-0617	U 1
0 0	J <b>35</b>	IC \$N74H22N	1820-0619	U 1
0 1 0	J115,1	IC 9314PC 16,125,126	1820-0626	U a
0 1	J51 <b>,7</b> 1	IC SN74150N	1820-0640	u z
0 0 1	J <b>2</b> 5	IC 3N74803N	1820-0682	U 1
0 1	J4 <b>7,77</b>	IC SN74804N	1820-0683	0 5
0 01	137	IC SN74805N	1820-0684	1
0 01	J <b>117</b>	IC SN74S10N	1820-0685	U 1
001	J <b>92</b>	IC SN74S11N	1820-0686	1
014	J <b>14,27</b>	IC SN74S74N	1820-0693	0 5
0 01	J <b>17</b>	FC SN74H106N	1820-0715	1
011	164,84	IC 9308PC	1820-0742	u s
011	J13,23	IC HP147A ,33,43,	1820-0755	U 11
05	113,1	23,133,137 IC HP147B	1820-0756	U 2


12897A DCPC Assembly Parts List (12897 -60001) Sht. 3 of 3

TEM NO.	REFERENCE DESIGNATOR (FIRST SIX)	PART DESCRIPTION	PARENT OPTION	PART NUMBER	COMP. L.	QUANTITY PER
0 1	U134,1	36		1820-0756		
1	U53,93	IC HP106A		1820-0759		S
0	U <b>107</b>	IC SN7406N		1820-0761	U	i
		IC SN74197N ,21,22,121 31,132		1820-0765	U	8
0	J <b>73</b>	IC SN7427N		1820-0782	U	1
01	J16	IC SN74175N		1820-0839	U	1
1		IC 8T13B ,67,76,127		1820-1080	U	5
O.	J <b>87</b>	IC SN74S38N		1820-1451	U	1
		LABEL-USA		7120-6830	L	1
0		WIRE JUMPERS		8159-0005	D	1
		EXTRACTOR-PC		5040-6001	W	1
		EXTRACTOR-BLACK		5040-6068	W	1









# HP 12897B DUAL CHANNEL PORT CONTROLLER

THEORY OF OPERATION

# NOTE

This document is part of the HP 1000 M, E, and F-Series Computers Engineering and Reference Documentation and is not available separately.

# TABLE OF CONTENTS

Paragraph	Page
1.0	Introduction
2.0	General Description
2.1	Basic Block Diagram 4
2.1.1	Interrupt and I/O Control Logic
2.1.2	Initialization Logic
2.1.3	Cycle Stealing Logic
2.1.5 $2.2$	Interface Signal Descriptions
2.2.1	Input Signals
2.2.1	<u>.                                     </u>
	Output Signals
3.0	Programming
3.1	Initialization Instructions
3.2	Control Instructions
3.3	Status Instructions
4.0	Detailed Theory of Operation
4.1	Initialization Logic
4.1.1	Control Word 1
4.1.2	Control Word 2
4.1.3	Control Word 312
4.2	I/O Control and Interrupt Logic
4.2.1	Timing Decoders
4.2.2	I/O Instruction Decoding
4.2.3	Interrupt Logic
4.3	Cycle Stealing Logic
4.3.1	Cycle Request Logic
4.3.2	Cycle Initiating Logic
4.3.3	Signal Generation Logic
4.4	Input Transfers
4.5	Output Transfers
4.6	System Reset Signals
4.6.1	POPIO
4.6.2	CRS
Figure	
Figure	Page
1	DCPC Accessory Block Diagram8
<b>2</b>	DCPC Control Word Formats
3	Initialization Logic
4	Interrupt and Priority Logic
5	Cycle Stealing Logic, Channel 1
6	M-Series DMA Input Transfer Timing, Channel 1 Illustrated
	(MX Jumper Installed)
7	E-Series DMA Input Transfer Timing, Channel 1 Illustrated
	(MX Jumper Removed) 30
8	M-Series DMA Output Transfer Timing, Channel 1
	(MX Jumper Installed)31
9	E-Series DMA Output Transfer Timing, Channel 1
-	(MX Jumper Removed)
Tables	Page
1	M-Series Input Transfers
$\overset{1}{2}$	E-Series Input Transfers
3	M-Series Output Transfers
<b>4</b> .	E-Series Output Transfers 23

# 12897B DUAL CHANNEL PORT CONTROLLER OPTION

# Theory of Operation

# 1.0 INTRODUCTION

This document provides a Theory of Operation for the 12897 Dual Channel Port Controller (called DMA in this document) accessory for the 21MX Series computers. Discussion is conducted on the functional block, programming, and detailed operation levels. Block diagrams, logic diagrams, and timing diagrams are used to show operation. A thorough understanding of this document is essential when performing maintenance or troubleshooting on the 12897B accessory.

# 2.0 GENERAL DESCRIPTION

The 12897 DMA consists of a single 2100-size board which is inserted into the top connector of the memory backplane of the 21MX Series computers. A 50-connector flat-cable connects between it and the power crossover PCA to provide additional signals.

The 12897B DMA is functionally equivalent to the DMA for the 2100A, and is programmed exactly the same.

The DMA allows the user to initiate block word transfers between selected I/O devices and memory. DMA then controls the I/O device during the transfers, stealing memory and I/O cycles from the CPU, but not requiring CPU intervention until completion of the transfer.

DMA is capable of stealing every consecutive I/O cycle. There are two channels of DMA, each of which may be separately assigned to operate with any I/O interface, including those in the 12979 I/O Extender. When both channels are operating simultaneously, channel 1 has priority over channel 2.

In the 21MX E-series, the CPU may not access memory nor initiate an I/O cycle while DMA is cycle stealing. The 21MX M-series CPU may not initiate an I/O cycle but, is permitted one memory cycle per DMA cycle while DMA is cycle stealing.

DMA transfers are initiated by an initialization routine and then hardware controls the transfers automatically. The initialization routine tells DMA which direction to transfer the data (in or out), where in memory to put the data, which I/O channel to use and how much data to transfer. Completion of the transfer is signalled by an interrupt to location 6 (channel 1) or 7 (channel 2), if the interrupt system is enabled. It is also possible to check for completion by testing the status of the flag of select code 6 (channel 1) or select code 7 (channel 2). A block transfer can be aborted by an STF 06 or STF 07 instruction.

## 2.1 Basic Block Diagram

Refer to figure 1 for the following discussion of the basic organization of the DCPC accessory.

### 2.1.1 Interrupt and I/O Control Logic

The functions of this logic are: to decode I/O signals from the CPU and control other elements of the DMA logic; to decode timing signals which control DMA operation; to generate interrupt requests; to fit DMA to the I/O system as a standard interface card.

# 2.1.2 Initialization logic

This logic contains the three operator control words which determine the nature of the transfers to be done.

The word count, memory address, select code of the I/O device, and control information are stored there during the initialization

routine. The word count and memory address are incremented during DMA cycles. This logic notifies the interrupt and cycle stealing logic when a block transfer is completed.

## 2.1.3 Cycle Stealing Logic

This logic determines if a device is to be serviced by DMA, and generates the proper signals to control the CPU, memory, and the I/O device during a cycle-steal.

# 2.2 Interface Signal Descriptions

This section describes the main signals which are important in operation of the 12897 DCPC accessory. Standard I/O signals and busses are not included. All signals are TTL-compatible, ground true unless otherwise specified.

# 2.2.1 Input Signals

SRQ10-SRQ25 "Service Request". Positive true. CTL compatible. Generated by device requesting service, synchronously with T2. If the particular I/O device has been assigned a DMA channel, then its SRQ alerts logic to initiate a DMA cycle.

DMARQ1, DMARQ2 "DMA Request". OR-tieable, ground true. Generated by an I/O Extender when an I/O device in the Extender has been assigned a DMA channel, and requests service on it. DMARQ1 is a request for channel 1 (select code 6), and DMARQ2 is a request for DMA channel 2 (select code 7).

# 2.2.2 Output Signals

DMACYC. "DMA Cycle". Used to notify the system that a DMA cycle is in progress. True from P4 of T5 to P4 of the next T5 in the E-series. True T6 through T5 in the M-series.

- DMALO. "DMA Lockout". OR-tieable. Used to assure DMA of unhindered access to memory and the I/O system. True from P4 of T4 to P4 of the next T4 in the E-series. True during T5 through T2 in the M-series.
- DMAEN. "DMA Enable". Sent to the CPU to switch control of the M-bus to DMA during a DMA cycle, and to enable the DMA Memory Address Registers onto the M-bus. True from P4 of T6 to P4 of T4 in the E-series. In the M-series, DMAEN is true from T6 through T3 during output transfers and T6 through T4 during input transfers.
- DMAREAD. "DMA Read". To memory, to allow memory to time refresh around DMA, if necessary. True during DMACYC of DMA output transfer.
- READ. "Read". To memory. True during T2 of Read cycle. Downward edge initiates a Read cycle in memory. OR-tieable.
- DMAIOO. "DMA I/O Output" to CPU. Gates S-bus onto I/O Bus during T3 of output transfer.
- DMAFRZ. "DMA Freeze". OR-tieable. Freezes CPU clocks and prevents the CPU from using the S-bus while DMA uses it. True during T3 in the M-series. True during T2 and T3 in an E-series.
- DMAIOI. "DMA I/O Input" to CPU board. Gates the I/O-bus onto the S-bus. True during T3 of a DMA input transfer.
- DMALCH. "DMA Latch" to CPU board. Holds data on the I/O-bus through completion of DMA output transfer. True from P4 of T3 through P4 of T5.
- TEN "T Register Enable" to memory. Gates the T-register in memory onto the S-bus. True during T3 of DMA output transfers. OR-tieable.
- TST "T Register Store" to memory. Informs memory to clock data on S-bus into the T-register. True during T3 of DMA input transfers.

  OR-tieable.

- WRITE to memory. Downward edge initiates a write cycle in memory.

  True during T4 of input transfers. OR-tieable.
- EDT "END-DATA-TRANSFER" Positive true. CTL compatible. Informs I/O interface that this is the last transfer. Asserted during T4.
- IOO. "I/O Output". Positive true. CTL compatible. To I/O interfaces to clock the I/O Bus data into the interface output register.

  True during T3 and T4 of all DMA output transfers.
- IOI. "I/O Input". Positive true. CTL compatible. To I/O interface to enable input data onto the I/O Bus. True during T2 and T3 of all DMA input transfers.

NOTE: During a programmed Ll\*/Ml\*, IOI is true during T4 and T5.

STC. "Set Control". Positive true. CTL compatible. To I/O interface to initiate an input or output data transfer. If specified (See Control Word 1) STC is true during T3 of all DMA transfers except the last transfer of an input block.

NOTE: During a programmed STC, STC is true during T4.

CLC. "Clear Control". Positive true. CTL compatible. If specified (see Control Word 1), to I/O interface during T3 and T4 of last transfer of a block to inhibit an unwanted interrupt.

NOTE: During a programmed CLC, CLC is true during T4.

CLF. "Clear Flag". Positive true. CTL compatible. To I/O interface to reset the FLAG and FLAG BUFFER, and thereby acknowledge the SRQ. True during T3 of all DMA transfers except the last transfer of an input block.

NOTE: During a programmed CLF, CLF is true during T4.




FIGURE 1
DCPC ACCESSORY BLOCK DIAGRAM

## 3.0 PROGRAMMING

The 12897 DCPC accessory is programmed in exactly the same manner as the DMA option for the 2100A computer. Included below is only a brief summary of the actions performed by the I/O instructions affecting the 12897 DMA operation. Select codes 2 and 6 refer to DMA channel 1, while select codes 3 and 7 refer to channel 2.

## 3.1 Initialization Instructions

- OT\* 06 Load the A or B register via the S-bus into the Service
- OT\* 07 Select Register (bits 0-5, 13, 15). This is Control Word 1.
- CLC 02 Set the CTL2FF or CTL3FF high. Used to prepare
- CLC 03 DMA to receive Control Word 2.
- STC 02 Set the CTL2FF or CTL3FF low. Used to prepare
- STC 03 DMA to receive Control Word 3.
- OT\* 02 Load the A or B register via the S-bus into the DMA
- OT\* 03 Memory Address Register (Control Word 2) if CLC\_FF is low or into the Word Count Register (Control Word 3) if CLC\_FF is high. Each channel has its own such registers.

# 3.2 Control Instructions

- STC 06 Turns on DMA to look for SRQ's from I/O devices
- STC 07 specified to begin the transfer described by the control words.
- STF 06 Set the channel Flag Buffer flip-flop, which disables
- STF 07 further DMA cycles on that channel, and will set the flag at the proper time.
- CLF 06 Clears the Flag flip-flop, Flag Buffer flip-flop, and
- CLF 07 IRQ flip-flop for that channel.

# 3.3 Status Instructions

- SFS 06 SKIP next instruction if flag flip-flop is set (or clear)
- SFS 07 on that channel. If set, the block transfer has been
- SFC 06 completed.
- SFC 07

- LI\* 02 READS the remaining word count (2's complement of it)
- LI\* 03 for the channel. May be used to determine how much of a DMA block transfer has been completed.

#### 4.0 DETAILED THEORY OF OPERATION

The following discussion describes each functional section in operational detail, followed by a discussion of overall DMA operation during initiation, input and output transfers, and interrupt request generation. Logic for channel 1 is identical to that for channel 2, so only channel 1 will be discussed. It is not difficult to discover the channel 2 counterparts to channel 1.

### 4.1 Initialization Logic

Information from Control Words 1, 2 and 3 are loaded into registers in this logic, and used for transfer control when DMA is activated. The registers are loaded from the S-bus during the I/O instructions listed in section 3.1. The S-bus is buffered (U17, U107) before being distributed to the six registers (3 per channel). Refer to figures 2 and 3.

#### 4.1.1 Control Word 1: register and logic

During IOO of a OT\* 06, Control Word 1 is loaded into the Service Select Register (Ull3, Ull5), Bits 0-5 contain the select code of the device under control of channel 1, and are designated SSR1-0 through SSR1-5. Bit 13 of the S-bus is stored as CLCSEL1, and is used to specify whether CLC is to be issued to the I/O device at the end of a block transfer. Bit 15 of the S-bus is stored as STCSEL1, and is used to specify if a STC is to be issued to the I/O device at the end of each word transfer (except the last, if it is an input transfer).

When DCYCl is high (cycle in progress on channel 1) the Service Select Register is buffered (Ull6, Ull7) onto the Select Code Bus to select the specified device for DMA control. This buffer also outputs the signals INCWCl at T62, and INCMRl during DMAEN. These signals increment the Word Count Register and Memory Address Register, respectively.

### 4.1.2 Control Word 2: register and logic

CTL2FF (U64, pin 13) must be low in order to load the second control word into the Memory Address Register (MAR). This is assured by executing a CLC 02 instruction which clears the R-S flip-flop CTL2FF.

A succeeding OT\* 02 instruction will load the A or B register into the Memory Address Register (U16, 26, 96, 106) with the negative edge of LOADMAR1. The MAR is a 15 bit register containing a 15-bit ripple counter (loaded from bits 0-14 of the S-bus) and a single D flip-flop (loaded from bit 15 of the S-bus) called INFF1 (U16-pin 5). If INFF1 is high, then a DMA input transfer is to be done on channel 1. If low, then an output transfer. This flip-flop does not change once the MAR is loaded. The MAR counter is incremented by the downward edge of INCMR1 at the trailing edge of DMAEN.

The MAR is enabled onto the M-bus through a set of buffers (U47, 57) during DMAEN in DCYCl. DMAEN also disables the CPU M-register from using the M-bus.

Note that M-bus bit 15 is forced low during DMAEN in DCYCl, and that it is forced high during DMAEN in DCYC2. Bit 15 is monitored by the Memory Management option board to distinguish between channel 1 and channel 2 during transfers.

### 4.1.3 Control Word 3: register and logic

CTL2FF (U64 pin 9) must be low to be able to load the third control word into Word Count Register 1. This is effected by issuing an STC 02 instruction, which sets the R-S flip-flop.

A succeeding OT\* 02 instruction will enable the A or B register into the Word Count Register (U14, 24, 94, 104) via the S-bus on the downward edge of LOADWCl, and latch the data on the rising edge. The Word Count Register is a 16-bit synchronous counter loaded with the two's complement of the number of words to be transferred under DMA channel 1 control. It performs a carry-look-ahead for each group of four bits while INCWCl is low. If all outputs of the low order bits are high when INCWCl goes low, then the carry output, pin 12, goes low, which goes to pin 5 of the next group, performing the same function. If all bits of the Word Count Register are high, then INCWCl going low will result in WCRl (Word Count rollover) going high, indicating that the current transfer is the last. The register increments at the rising edge of INCWCl. INCWCl is low during T62 of a channel 1 cycle (DCYCl).

The Word Count Register is enabled onto the S-bus through the buffer (U27, 37) during LI\* 02 instructions, and stored onto the A or B register on the CPU.

# 4.2 I/O Control and Interrupt Logic

#### 4.2.1 Timing Decoders

To generate I/O signals at the proper times, DMA needs to have a way to generate T2-T6 in sync with the CPU. To do this, DMA receives the TA, TB, TC signals from the CPU, and decodes them (U66, U53, U73, U82) to provide the required time periods. Several timing signals must be different for the M-series than for the E-series; U32, controlled by W1, selects the timing required for each CPU type.

### 4.2.2 I/O Instruction Decoding

DMA decodes the Select Code Bus with IOG, they generate SC2, SC3, SC6, SC7, respectively, which are low during I/O instructions for the specified DMA select codes. These signals are used as described below:

- SC2 (a) in conjunction with STC or CLC, set or clear the SC3 STC2FF or STC3FF.
  - (b) in conjunction with IOG, generate LOADWC or LOADMAR
  - (c) in conjunction with IOI, gate the Word Count Register onto the S-bus.
- SC6 (a) enable buffer U45 or U55, respectively, which then enables

  SC7 STC, CLC, CLF, and STF to the appropriate DMA channel flipflop. The buffers OR-tie the status of the two channel flags
  for the skip logic (pins 1, 2). Only one channel flag status
  is selected for test during SFS or SFC, since only one buffer
  may be enabled at a time.
  - (b) in conjunction with IOO, load the Service Select Register.

### 4.2.3 Interrupt logic

When DMA is turned on, an STC 06, C instruction sets the Channel Control, CONT6FF (U64), and clears the Flag, Flag Buffer, and IRQ flip-flops (U44).

The interrupt generating sequence may be initiated in two ways. It is assumed that CONT6FF is high, the interrupt system is enabled (IEN5 is high), and the priority chain is intact to DMA (PRH6 is high). Refer to figure 4. If any one of these conditions is not met, no interrupt will be requested.

- a. WCRl (Word Count Rollover) is high. This indicates that the last word transfer is in progress. This sets FBFFl and clears the transfer enable flip-flop (TRENFFl).
- b. Issuing an STF 06 instruction. This sets FBFF1 and clears the transfer enable flip-flop (TRENFF1).

T2 following setting of the Flag Buffer, the Flag (FLG6FF) is set high.

The T5 following setting of FLG6FF, IRQ6FF is set. IRQ6FF is high during T5-T6 and low T2-T4 until the interrupt is granted. However, if a higher priority device (Powerfail, Parity, or Memory Protect) sets its flag, then PRH6 will go low, preventing DMA from interrupting until the other device has been serviced and PRH6 is high again.

When the DMA interrupt request is acknowledged, IAK occurs at P3, 4, 5 of T6. IAK in conjunction with IRQ6FF clears FBFF1.

# 4.3 Cycle Stealing Logic

The cycle stealing logic compares the Service Select Register to the SRQ lines coming from I/O interface cards to determine if a cycle is to be requested. It resolves access priorities between the two DMA channels, initiates the cycle, and controls the generation of various signals to memory, the CPU, and the I/O interface to effect the desired transfer. Refer to figure 5.

# 4.3.1 Cycle Request Logic

This consists primarily of a 16-to-1 multiplexor (U51).

SSR1-0 to SSR1-5 select a SRQ line to monitor. When that SRQ line goes high, indicating the Flag has been set on the interface card with the select code specified in the SSR, then the REQ1 line (U111-6) goes high. DMARQ1 indicates a request for DMA channel 1 from the I/O Extender. It also sets REQ1 high.

# 4.3.2 Cycle Initiating Logic

The Cycle Request Register (U46) is the focal point for initiating DMA cycles on either channel. Refer to figure 5. It is clocked every trailing edge of P5 in M-series and Leading edge of P4 in E-series.

When an STC 06 instruction is executed, the Transfer Enable flip-flop (TRENFF1) is set. This allows the cycle initiating logic to monitor the REQ1 line (U41B). If there is no power failure (PRH5 is high), then when REQ1 goes high, the Cycle Request 1 flip-flop, CYCRQ1, will be set at the end of T4. As long as CYCRQ1 is high, DMA channel 2 cannot take a cycle (gate U53B). Once CYCRQ1 goes high, it is kept high until the end of the next T4. The NOR of CYCRQ1 and CYCRQ2 during T5 through T2 is DMALO.

DMALO goes to the CPU to perform the following functions:

- a. Prevent setting the I/O Group Enable flip-flop.
- b. Freeze the CPU if it attempts to access memory, perform I/O instructions, or load the central Interrupt Register.
- c. Set the Interrupt Override ff on the CPU to prevent interrupt recognition during the cycle.

The DCYCl flip-flop follows CYCRQl, delayed by one T-period. It enables the signal generation logic for a DMA transfer. The DCYC2 flip-flop may not be set until the T5 after CYCRQl goes low, if CYCRQ2 is high. Channel 2 may thus take a cycle immediately after channel 1. The NOR of DCYCl and DCYC2 is DMACYC, which is sent to the CPU to prevent granting of interrupt requests until DMA has prevented its controlled device from requesting CPU service.

# 4.3.3 Signal Generation Logic (Figure 5)

DCYCl controls a multiplexer (U85) which selects transfer control information from one or the other DMA channel's initialization logic (INFF\_\_, STCSEL\_\_, and CLCSEL\_\_) and Flag Buffer status. These signals determine the exact combination of output signals necessary to execute a DMA transfer. Four flip-flops are used to assist in this generation (U62, 72). See sections 4.4, 4.5 for timed signals for input and output transfers. The signal "IN" (U85) selects the proper set of signals for input or output transfers.

# 4.4 Input Transfers

Tables 1 and 2 describe the algorithm for executing an input transfer on DMA channel 1. Refer to figure 6 and 7 for a diagram of timing signals for (a) normal cycle and (b) end-of-block-transfer cycle. It is assumed that TRENFF1 is high initially and that SRQ is asserted in time to generate REQ1.

Table 1. M-Series Input Transfers

Time	Signals Initiated	Action			
Т5	DMALO	Prevent CPU from interfering with upcoming cycle. Prevent interrupt service in the CPU.			
Т6	DMACYC	Start cycle, enable signals, give DMA control of Select Code Bus, servicing in CPU.			
	DMAEN	Low at P4, enabling MARl onto M-bus, removing CPU from M-bus.			
	INCWCl	Check for word count rollover, increment word count on trailing edge. If WCRl occurs, set FBFFl high.			
Т2	IOI	Tell I/O card to enable data buffer onto I/O bus.			
Т3	DMAFRZ	Freeze CPU, free the S-bus.			
	DMAIOI	Gate I/O bus onto the S-bus.			
	TST	Clock S-bus into T-register.			
	STC	Issue STC to interface card if STCSELl is high and FBFFl is low.			
,	CLC	Issue CLC to interface card if CLCSELl is high and FBFFl is high.			
	CLF	Issue CLF to interface card if FBFF1 is low.			

Table 1. M-Series Input Transfers (Continued)

Time	Signals Initiated	Action	
Т4	WRITE	Initiate write cycle in memory at address on M-bus.	
	EDT	Issue to interface card if FBFFl is high.	

Table 2. E-Series Input Transfers

Time	Signals Initiated	Action		
P4 of T4	DMALO	Prevent CPU from interfering with upcoming cycle. Prevent interrupt service in the CPU.		
P4 of T5	DMACYC	Start cycle, enable signals, give  DMA control of Select Code Bus,  servicing in CPU.		
Т6	IOG	Enable DMA select code onto select code bus.		
	INCWC	Check for word count roll-over, increment word count on trailing edge. If WCRl occurs, set FBFF1.		
P4 of T6	DMAEN	Enables MARl onto M-bus, removes  CPU from the M-bus. Increment MARl  on trailing edge.		
Т2	IOI	Tell I/O card to enable data onto		
	DMAFRZ	Freeze CPU, free the S-bus for use by DMA.		
Т3	DMAIOI	Gate I/O-bus onto the S-bus.		
	TST	Start cycle, enable signals, give DMA control of Select Code Bus, servicing in CPU.  Enable DMA select code onto select code bus.  Check for word count roll-over, increment word count on trailing edge. If WCRl occurs, set FBFF1.  Enables MARl onto M-bus, removes CPU from the M-bus. Increment MARl on trailing edge.  Tell I/O card to enable data onto I/O bus.  Freeze CPU, free the S-bus for use by DMA.		
	STC			
	CLC			

Table 2. E-Series Input Transfers (Continued)

Time	Signals Initiated	Action
T3 (cont.)	CLF	Issue CLF to interface card if FBFF1 is low.
Т4	WRITE	Initiate write cycle into memory at address on M-bus.
	EDT	Issue EDT to interface card if FBFFl is high.

# 4.5 Output Transfers

Tables 3 and 4 describe the algorithm for executing an output transfer on DMA channel 1. Refer to figure 7 and 8 for a diagram of the Timing signals. It is assumed that TRENFF1 is high initially, and that SRQ is asserted in time to generate REQ1 by P5 of T4. Both the case of (a) normal cycles and (b) end-of-transfer cycles are illustrated.

Table 3. M-Series Output Transfers

·			
Time	Signal	·	
Period	Initiated	Action	
Т5	DMALO	Prevent CPU from interfering with upcoming cycle.	
Т6	DMACYC	Start cycle, enable signals, prevent CPU interrupt servicing.	
	DMAREAD	Tell memory to schedule refresh during T4-T5.	
	DMAEN	Enable DMA Memory Address Register  l onto M-bus. Increment MARl on  trailing edge.	
	INCWCl	Check for Word Count Rollover.  If WCRl high, then set FBFFl  Increment Word Count at trailing edge.	
Т2	READ	Initiate Read cycle.	
Т3	DMAFRZ	Freeze CPU while DMA uses S-bus.	
	TEN	Enable data in T-register onto S-bus.	
	DMAIOO	Enable S-bus onto I/O-bus.	

Table 3. M-Series Output Transfers (Continued)

Time Period	Signal Initiated	Action			
P4 of T3	DMALCH	Hold data on I/O-bus. This signal allows S-bus to be used by CPU during following time periods.			
Т3	100	Clock I/O-bus into input buffer on I/O interface card.			
	CLF	Issue CLF to interface card.			
	STC	Issue STC to interface card if STCSELl is high.			
	CLC	Issue CLC to interface card if FBFF1 is high and CLCSELl is high.			
Т4	EDT	Issue to interface card if FBFF1 is high.			

# 4.6 System Reset Signals

### 4.6.1 POPIO

POPIO occurs during power-up or by pressing the Preset button on the front panel in the HALT mode. POPIO sets the Flag buffers on both channels (FBFF1, FBFF2). This terminates any block transfers in progress.

# 4.6.2 CRS


CRS occurs during POPIO or during CLC 0 instructions. CRS clears CTL2FF, CTL3FF, CTL6FF, CTL7FF, TRENFF1, and TRENFF2, which disables DMA from interrupting and terminates any block transfers in progress.

Table 4. E-Series Output Transfers

Time	Signals Initiated	Action
P4 of T4	DMALO	Prevent CPU from interfering with upcoming cycle.
P4 of T5	DMACYC	Start cycle, enable signals, prevent CPU interrupt servicing.
	DMAREAD	Tell memory to schedule refresh during T4-T5.
Т6	IOG	Enable DMA select code onto select code bus.
	INCWC	Check for word count roll-over, increment word count on trailing edge. If WCRl occurs set FBFF1.
P4 of T6	DMAEN	Enables MARl onto M-bus, remove CPU from M-bus. Increment MARl on trailing edge.
Т2	READ	Initiate Read cycle.
	DMAFRZ	Freeze CPU while DMA uses S-bus.
Т3	TEN	Enable data in T-register onto S-bus.
	DMAIOO	Enable S-bus onto I/O-bus.
	100	Clock I/O-bus into input buffer on I/O interface card.
	CLF	Issue CLF to interface card.


Table 4. E-Series Output Transfers (Continued)


Time	Signals Initiated	Action
T3 (cont.)	STC	Issue STC to interface card if STCSELl is high.
	CLC	Issue CLC to interface card if FBFFl is high and CLCSELl is high
P4 of T3	DMALCH	Hold data on I/O-bus. This signal allows S-bus to be used by CPU during following time periods.
Т4	EDT	Issue to interface card if FBFFl is high.



STC: issue STC at the end of every cycle, except the last, if input.

CLC: issue CLC at the end of last word transfer.








FIGURE 3
INITIALIZATION LOGIC




FIGURE 4

INTERRUPT AND PRIORITY LOGIC




FIGURE 5
CYCLE STEALING LOGIC, CHANNEL 1

FIGURE 6

M-SERIES DMA INPUT TRANSFER TIMING

CHANNEL 1 ILLUSTRATED (MX JUMPER INSTALLED)







FIGURE 7
E-SERIES DMA INPUT TRANSFER TIMING
CHANNEL 1 ILLUSTRATED (MX JUMPER REMOVED)



M-SERIES DMA OUTPUT TRANSFER TIMING, CHANNEL 1 (MX JUMPER INSTALLED)





12897B DCPC Assembly Parts List (12897-60004) Sht. 1 of 3

EM 10.	REFERENCE DESIGNATOR (FIRST SIX)	PART DESCRIPTION	PARENT OPTION PART NUMBE	R COMP. C	QUANTITY PER
10	1-3,6	CAP .01UF	0160-2055	u	8
00	24,5	CAP 10UF 10%	0180-0374	D	2
OE	E1,2	STUD SOLDER TERM	0360-0474	U	2
0	₹9	RES 1.0K 5% .25	0683-1025	D	1
	R10,11	RES 330 5% .2!	0683-3315	U	2
	₹7	RES 464 1%.12	0698-0082	D	1
		SOCKET PC SINGL	1251-1556	U	3
		JMPR PLUG .3"C=	1258-0124	u	1
		PIN GRV .062X.2	1480-0116		2
0	R2,3	NTWK RES 9X500	1810-0274	U	2
0	R1,5	NTWK RES 9X1K	1810-0275	U	2
0	R4,6	NTWK RES 9X1.5K	1810-0276	U	5
	U51,71	IC 8N74150N	1820-0640	U	s
	U111	IC SN74800N	1820-0681		1
	U <b>31,6</b> 3	IC 9N74804N	1820-0683	U	3
	U <b>3</b> 6	IC SN74810N	1820-0685	U	1
	U 4 1	IC 8N74822N	1820-0689	U	1
		IC 3N74874N	1820-0693		2

12897B DCPC Assembly Parts List (12897-60004) Sht. 2 of 3

NO.	REFERENCE DESIGNATOR (FIRST SIX)	PART	DESCRIPTION	PARENT OPTION	PART NUMBER	COMP. L OPTION C	QUANTITY PER
0 1	U62,72				1820-0693		
	U15,16 105,1	IC SN7, 25, 26, 06			1820-0765	u	8
0 0	U <b>32</b>	IC SN7	74S158N		1820-1015	u	1
1	U81,91	IC 8T1		,	1820-1080	U	5
0 0	U 1 1	IC SN7	4LS02N		1820-1144	U	1
0 0	U42	IC SN7	74851N		1820-1158	U	1
0 0	U46	IC SN7	748175N		1820-1191	U	1
) 1 ) 3	U13,14 103,1	,23,24,	4LS193N 93,94,		1820-1194	U	8
1	U34,75		'4LS00N		1820-1197	U	3
0 (	u <b>3 5</b>	IC SN7	74LS04N		1820-1199	U	1
0 0	U <b>7</b> 6	IC SN7	'4L\$05N		1820-1200	U	1
0	u <b>53</b>	IC SN7	4LS08N		1820-1201	U	1
0 (	n <b>22</b>	IC SN7	'4LS27N		1820-1206	U	1
1	U12,21	IC SN7 ,65,84	'4L\$32N		1820-1208	U	4
0 0	U <b>112</b>	IC SN7	'4ĻS86N		1820-1211	U	1
0	U <b>56</b>	IC SN7	'4LS138N		1820-1216	u	1
1	U45,55		1095N		1820-1254		5
			\$257N		1820-1301	u	8

12897B DCPC Assembly Parts List (12897-60004) Sht. 3 of 3

ITEM NO.	REFERENCE DESIGNATOR (FIRST SIX)	PART DESCRIPTION	PARENT OPTION	PART NUMBER	COMP. L OPTION O C	QUANTITY PER
0 1 0 3	U27,37 87,97	,47,57,67,77,		1820-1301		
01	J52,73	IC SN74S08N		1820-1367	U	5
0 0	J86	IC SN74LS14N		1820-1416	U	1
01		IC SN74LS279N ,64,74		1820-1440	U	4
0 0	J <b>43</b>	IC SN74837N		1820-1450	U	1
011	J <b>33,83</b>	IC SN74S38N		1820-1451	U	5
0 1	J <b>113,1</b>	IC SN74273N 15		1820-1461	U	2
001	J <b>85</b>	IC SN74LS157N		1820-1470	U	1
01		ICSN748241N 7,116,117		1820-1624	U	4
		LABEL-USA		7120-6830		1
		EXTRACTOR-PC		5040-6001	W	1
		EXTRACTOR-BLACK		5040-6068	W	1
01		DTS-70 TEST ADP Fixture		ET13460	1	0

