

**UNISYS**

**U 5000/20, U 5000/30,  
U 5000/35, U 5000/40,  
U 5000/50, and  
U 5000/55 Systems**

**Unpacking  
Guide**

July 1988

Priced Item

Printed in U S America  
UP-11785 Rev. 4

# UNISYS

**U 5000/20, U 5000/30,  
U 5000/35, U 5000/40,  
U 5000/50, and  
U 5000/55 Systems**

## **Unpacking Guide**

Copyright © 1988 Unisys Corporation.

All rights reserved.

Unisys is a trademark of Unisys Corporation.

Previous Title: Unisys U 5000/20, U 5000/30,

U 5000/35, U 5000/40, U 5000/50, and

U 5000/55 Systems U 5000 Series Operating System

Unpacking Guide

July 1988

Priced Item

Printed in U S America  
UP-11785 Rev. 4

**NO WARRANTIES OF ANY NATURE ARE EXTENDED BY THE DOCUMENT.** Any product and related material disclosed herein are only furnished pursuant and subject to the terms and conditions of a duly executed Program Product License or Agreement to purchase or lease equipment. The only warranties made by Unisys, if any, with respect to the products described in this document are set forth in such License or Agreement. Unisys cannot accept any financial or other responsibility that may be the result of your use of the information in this document or software material, including direct, indirect, special or consequential damages.

You should be very careful to ensure that the use of this information and/or software material complies with the laws, rules, and regulations of the jurisdictions with respect to which it is used.

The information contained herein is subject to change without notice. Revisions may be issued to advise of such changes and/or additions.

# **U 5000/20/30/35/40/50/55 Unpacking Guide**

The U 5000/20, U 5000/30, U 5000/35, U 5000/40, U 5000/50, or U 5000/55 system arrives in two packages. One package is the system itself. It is boxed and sitting on a pallet secured with banding straps. The second package is a small cardboard box containing printed materials.

## **System Package Checklist**

You should be certain the items on the following list are contained in the materials you receive from Unisys. If any of the items are missing, contact your Unisys representative.

1. As you unpack the cardboard box containing your printed materials, match the contents against the following list:

### **Unisys User Hardware Publications**

- *U 5000/20, U 5000/30, U 5000/35, U 5000/40, U 5000/50, and U 5000/55 Systems; U 5000 Series Operating System; Planning Guide, UP-11768 Rev. 3, Update A*
- *U 5000/20, U 5000/30, U 5000/35, U 5000/40, U 5000/50, and U 5000/55 Systems; U 5000 Series Operating System; Installation Guide, UP-12693 Rev. 1*

- *U 5000/20, U 5000/30, U 5000/35, U 5000/40, U 5000/50, and U 5000/55 Systems; U 5000 Series Operating System; Customer Setup Guide, UP-11770 Rev. 4*
- *U 5000/35 and U 5000/55 Capabilities Overview, UP-13746*
- *Customer Support Letter, UP-11354 Rev. 8*
- *Expansion Cabinet Unpacking Letter, UP-14103*

### **Unisys System V Operating System Publications**

- *U 5000/20, U 5000/30, U 5000/35, U 5000/40, U 5000/50, and U 5000/55 Systems; U 5000 Series Operating System; Installation and Implementation Guide, UP-12694 Rev. 1, Update A*
- *U 5000/20, U 5000/30, U 5000/35, U 5000/40, U 5000/50, and U 5000/55 Systems; U 5000 Series Operating System; Operations Guide, UP-11766 Rev. 2*
- *U 5000 and U 7000 Series Operating Systems; Menu System Operating Guide, UP-11763 Rev. 3*
- *U 5000/20, U 5000/30, U 5000/35, U 5000/40, U 5000/50, and U 5000/55 Systems; U 5000 Series Operating System; Administration Guide, UP-11765 Rev. 1*
- *U 5000 and U 7000 Series Operating Systems; User Reference Manual, Volume 1, UP-11760 Rev. 3, Update A*

# Unpacking Guide


---

- *U 5000 and U 7000 Series Operating Systems; User Reference Manual, Volume 2, UP-11760 Rev. 2, Update B*
- *U 5000 and U 7000 Series Operating Systems; Administration Reference Manual, UP-11761 Rev. 3, Update A*
- *U 5000 and U 7000 Series Operating Systems; Programming Reference Manual, Volume 1, UP-11762 Rev. 2, Update B*
- *U 5000 and U 7000 Series Operating Systems; Programming Reference Manual, Volume 2, UP-11762 Rev. 2, Update B*
- *U 5000/30, U 5000/35, U 5000/50, and U 5000/55 Systems; U 5000 Series Operating System; Diagnostics Reference Manual, UP-12644 Rev. 1, Update A*
- *U 5000/20, U 5000/30, U 5000/35, U 5000/40, U 5000/50, and U 5000/55 Systems; U 5000 Series Operating System; Device Driver Programming and Implementation Reference Manual, UP-12230 Rev. 1, Update A*
- *U 5000 Series Operating System Error Message Manual, UP-12218 Update B*
- *U 5000/30, U 5000/35, U 5000/50, and U 5000/55 Crypt Utilities; Software Release Announcement, UP-14117*
- *U 5000/30, U 5000/35, U 5000/50, and U 5000/55 Operating System Crypt Utilities Release Description, UP-14118*

- *U 5000/20, U 5000/30, U 5000/35, U 5000/40, U 5000/50 and U 5000/55 Systems; U 5000 Series Operating System; Tuning Guide, UP-12715 Rev. 1, Update A*

The packing slip lists the items shipped and the item serial number. It includes a list of all installed boards on the system and the board serial numbers, as well as a list of all major components of the system with the corresponding serial numbers. Keep this record in a safe place for future reference.

2. Before unpacking your system, inspect it for damage. In particular, look at the TIP-N-TELL sticker. If it indicates blue in the triangular area, then the container has been dropped or tipped over in transit.




# Unpacking Guide


---

Make a note on the Bill of Lading that hidden damage may have occurred. Also note any visible damage to the shipping containers. If the system is visibly damaged, contact the freight forwarder and your Unisys representative immediately to resolve any insurance claims before proceeding further with the unpacking procedure.

3. Allow the system to stand at its site long enough for it to come to room temperature (a minimum of 24 hours is recommended before unpacking).
4. With the shipping carton in the upright position (arrows pointed upward), cut the straps around the carton.



5. Lift the carton off the main unit.




**NOTE:**

Depending on which system you ordered, the front panel and size of your unit may differ from that of the unit shown in the following illustrations.

## Unpacking Guide

---


6. Remove the top packing cushion, the side packing cushions, and the plastic cover from the main unit and check the unit for damage.



7. Move the main unit off of the box bottom and shipping pallet and place in the installation area.

**NOTE:**

Be sure to lift the unit by the base, not by the cabinet.




## Unpacking Guide

---

8. Underneath the main unit, you will find a package containing the AC power cord, the battery fuse, and fuse cap. Set these aside for future use.

If your system has been preinstalled, the operating system tape will be included with this package. If your system has not been preinstalled, the operating system tape will be packed with your documentation, as will any other software you have ordered.



9. If you have ordered a unit with a diskette drive, open the disk door and remove the shipping card.

