PERIPHERAL HARDWARE MAINTENANCE MANUAL



Valid Logic Systems Incorporated 1395 Charleston Road Mountain View, CA 94043 (415) 940-4000

PREFACE

The Peripheral Hardware Maintenance Manual includes a number of vendor manuals that describe the various peripherals used in the SCALDsystem. The maintenance manual uses index tabs to separate the various manuals; in some cases, two manuals are included within the same index tab when a peripheral is supplied by two manufacturers. Also, several index tabs do not contain manuals; the manuals for these tabs are system-dependent and are packaged separately.