

## Intel DH61AG bios 0105 update alert!

*BIOS version 0099 added support for Microsoft Windows 8\*. Due to structural changes in this BIOS version, once a board has been converted to this version or later, it will no longer be possible to downgrade the BIOS to version 0045 or earlier. Attempting a BIOS downgrade to a previous version may fail – the board BIOS will remain at its current version.*

If your system's current BIOS version is 0039 through 0045:

1. Update to the transition version 0099.
2. Then update to 0104 or later.

If your system's current BIOS version is 0037 or earlier:

1. You must first update to version 0039.
2. Then update to the transition version 0099.
3. Finally you can update to 0104 or later.

### Issue:

After update bios to 0105 and load bios setup default, Realtek HD audio won't load or reinstall and audio does not work.

### Resolution:

Boot to BIOS setup -> Configuration -> Onboard Devices -> AUDIO: HDMI/DisplayPort Audio -> change to **Enabled** (This will enable Intel Display Audio)

Boot to BIOS setup -> Configuration -> Onboard Devices -> AUDIO: Internal SPDIF/DMIC header -> change to **Digital MIC** (This will enable Realtek HD Audio)

### ECS G11 Chassis Setup:

Boot to BIOS setup -> Configuration -> Video -> All-in-One Chassis = [ECS \(21.5"\)](#)

### LG Loop Chassis Setup:

Boot to BIOS setup -> Configuration -> Video -> All-in-One Chassis = [LP-215x \(21.5"\)](#)

### Disabled UEFI-base and Startup Sound:

Boot to BIOS setup -> Boot -> UEFI Boot = **Disabled**

Boot to BIOS Setup -> Boot -> Startup Sound = **Disabled**