

**T60 Setup Poster**  
**P/N 39T9415**  
 11/17/2005

Size : 11x14 inches  
 Color : 2 color job =? Process Black (This plate must be printed in PMS Process Black C)  
 Process Magenta (This plate must be printed in PMS 032cvc)  
 Font : IBM Fonts and Helvetica Neue Family  
 Material : 100 gsm gloss art paper (Use 100% recycled paper in only Japan.)  
 Blue line shows die-cut. DO NOT PRINT.  
 Please change the barcode No.  
 Please change the country name if the poster is printed in other than China.

**ThinkPad**



제품의 포장을 열고 내용물을 확인하십시오.

- ThinkPad(R) 컴퓨터
  - 배터리
  - 전원 코드
  - AC 어댑터
  - 트랙포인트(R) 캡(2)
  - 설명서
- 설치 가이드(본 인쇄물)  
 - 안전 수칙 및 보증 설명서  
 - 사용 설명서  
 - 기타 설명서 및 플라이어

목록에 없거나, 누락되었거나, 손상된 부품과 복구 CD에 관해서는 뒷면을 참고하십시오.


**설치 가이드**



컴퓨터를 사용하기 전에 사용 설명서에 수록된 안전 관련 사항을 읽으십시오.

- 1** 배터리를 장착하십시오.  
배터리는 장착 즉시 사용할 수 있습니다.
- 2** 전원을 연결하십시오.
- 3** 컴퓨터의 전원을 켜십시오.
- 4** UltraNav(TM)를 이용하여 포인터를 이동하거나 원하는 항목을 선택하십시오.  
포인터를 움직이려면 트랙포인트 캡을 손가락 끝으로 원하는 진행 방향으로 밀거나, 손가락을 터치패드 위에 올린 후 원하는 방향으로 움직이십시오. 스페이스바와 터치패드 아래에 있는 오른쪽 및 왼쪽 버튼은 마우스의 오른쪽 및 왼쪽 버튼과 동일한 기능을 가집니다. 일부 모델에는 터치패드가 없고 트랙포인트만 있습니다.
- 5** 화면의 지시에 따라 운영 체제를 설정하십시오.  
이 과정에서는 수 분 정도의 시간이 소요됩니다. 과정이 진행되는 동안, 컴퓨터가 수 차례 재시작할 수 있습니다.
- 6** 더 자세한 정보를 보려면 ThinkVantage 버튼을 누르십시오.

**ThinkVantageDesign**



- 11 Fn 키**  
Fn 키와 기능 키의 조합으로 ThinkPad 특수 기능을 사용할 수 있습니다.
- |                       |                                   |
|-----------------------|-----------------------------------|
| <b>F2</b> 컴퓨터 잠금      | <b>F12</b> 최대 절전 모드 진입            |
| <b>F3</b> 배터리 및 전원 관리 | <b>PgUp</b> ThinkLight 켜기/끄기      |
| <b>F4</b> 대기 모드 진입    | <b>Fn + [Navigation]</b> 멀티미디어 조절 |
| <b>F5</b> 네트워크 연결 관리  | <b>Home</b> 화면 밝기 조절              |
| <b>F7</b> 디스플레이 설정 변경 | <b>End</b> 화면 내용 확대 기능            |
| <b>F8</b> 입력 장치 설정 변경 |                                   |
| <b>F9</b> 외장 장치 관리    |                                   |