



Connecting IBM @server xSeries 335 servers to an ASM interconnect network

If you want to connect IBM® @server™ xSeries® 335 servers in a rack configuration to an Advanced System Management (ASM) interconnect network, the supported configuration consists of one IBM Remote Supervisor Adapter II installed in each xSeries 335 server.

When a Remote Supervisor Adapter II is installed in an xSeries 335 server, the video adapter on the Remote Supervisor Adapter II is used, and the integrated video controller on the xSeries 335 system board is disabled. Therefore, Cable Chain Technology (C2T), which is typically used among multiple xSeries 335 servers to share one monitor, keyboard, and pointing device (such as a mouse), is also disabled.

First Edition (March 2004)

IBM, e-business logo, @server, and xSeries are trademarks of International Business Machines Corporation in the United States, other countries, or both.

Other company, product, or service names may be trademarks or service marks of others.

© Copyright International Business Machines Corporation 2004. All rights reserved.

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

(1P) P/N: 25K8159

