



# Technical Update

---

## Netfinity Advanced System Management PCI Adapter Software User's Guide

### Important

The SPUTIL.EXE utility, described on page 56 of the *IBM® Netfinity® Advanced Systems Management PCI Adapter Software User's Guide*, has been replaced by the FLASH2.exe utility. You can use the FLASH2.exe utility to perform configuration tasks for your IBM Netfinity Advanced System Management PCI Adapter and to update the Advanced System Management PCI Adapter microcode. The FLASH2.exe utility is provided on the *IBM Advanced System Management Utilities CD* that comes with your Advanced System Management PCI Adapter option.

The FLASH2.exe utility is also available from a diskette image file that you can download from the <http://www.ibm.com/pc/support> IBM Support Web site. For the diskette image file that is appropriate for your server, refer to the following list:

- Servers - Advanced System Management PCI Adapter Firmware Update Diskette
- IBM @server xSeries 370 and IBM Netfinity 8500R - Advanced System Management Processor Firmware Update Diskette
- Netfinity 7000 M10 - Advanced System Management Processor Firmware Update Diskette

**Part Number: 32P0169**

**Printed in the United States of America.**

© Copyright International Business Machines Corporation 2001. All rights reserved.

Note to U.S. Government Users — Documentation related to restricted rights — Use, duplication or disclosure is subject to restrictions set forth in GSA ADP Schedule Contract with IBM Corp.