

Build the TVT-6: A Low-Cost DIRECT VIDEO DISPLAY

\$35 microcomputer "add-on" provides:

- User-selectable line lengths
- Scrolling
- Up to 4k on-screen characters with only 3-MHz bandwidth

BY DON LANCASTER

Thanks to some software tricks, a simple and low-cost add-on circuit, and a new way to speed up a microprocessor, you can now build a video interface for your microcomputer for an investment of only \$20 to \$35. The TVT-6 video system described here permits the choice of virtually any format including 16/32 (16 lines of 32 characters), 16/64, or 32/64. It also features full editing capability and full-performance cursor.

In spite of its simplicity (10 low-cost IC's), the circuit employs a new approach to video processing that permits up to 4000 characters to be displayed on-screen within a 3-MHz bandwidth. Although the TVT-6 was designed for the 6502 microprocessor based KIM-1, software can be used to easily map into the JOLT, EBKA, or Ohio Scientific microcomputers. In addition, the TVT-6 can be adapted to other microprocessors, including the popular 6800, 8080, and Z80. It is easiest to use with 16-address-line systems that operate on a single 5-volt supply and 1-μs cycle time.





Fig. 1. TVT-6 block diagram and truth table for the PROM.



Other systems will require software and microprogramming translation for their particular machine languages.

In this first of a two-part article, we will cover the hardware and construction details for the TVT-6. Next month, we will cover debugging, some useful software for the system, and provide instructions on how to couple the TVT-6 to other microprocessors.

Circuit Operation. A block diagram of the TVT-6, as used with the KIM-1 system, is shown in Fig. 1. The complete schematic diagram of the video system is shown in Figs. 2 through 4.

As shown in Fig. 1, bits ϕ through 6 from the "upstream tap" on the KIM display memory drive character generator IC7 whose blanking and formatting are helped along by the AND gates in IC6. The cursor bit (bit 7) is stripped off the upstream tap and routed to cursor blinker IC5, which introduces a blinking cursor into the character generator's enable input.

The parallel outputs from IC7 go to




Fig. 3. New SCAN instruction uses PROM IC1, which also has the line length option in its circuit.




Fig. 4. Video combiner (IC10), offset generator (Q1) and sync delay circuits deliver video to TV. Gated clock (IC4) controls parallel-to-serial converter.

C1, C7—0.01-µF Mylar capacitor C2—120-pF polystyrene capacitor

C3, C11, C12, C13-0.1-µF Mylar capacitor

C4-150-pF polystyrene capacitor

C5-2200-pF polystyrene or Mylar capacitor

C6-33-pF polystyrene capacitor

C8-0.047-µF Mylar capacitor

C9—330-pF polystyrene capacitor

C10-240-pF polystyrene capacitor

D1 through D5-IN4148 silicon diode

IC1—IM5610 32×8 PROM (or similar)

IC2-74LS00 quad tri-state NAND gate IC

IC3-4013 dual-D flip-flop IC

IC4-74LS04 hex inverter IC

1C5-4011 quad NAND gate IC

IC6-74LS08 quad AND gate IC

IC7—2513 character generator (must be single-supply type, such as General Instruments No. RO-3-2513) **PARTS LIST**

IC8-74165 PISO shift register

1C9-74LS32 quad OR gate IC

IC10-4066 quad analog switch IC

11, J2-Pe-mount phono jack (Molex No.

15-24-2181 or similar)

Q1-2N4402 or MPS6523 (Motorola) transistor

The following resistors are ¼ watt, 10% tolerance:

R1, R10-470 ohms

R2-10,000 ohms

R3,R7-220 ohms

R4,R16,R17,R18-2200 ohms

R5,R6--22,000 ohms

R8.R13.R19-4700 ohms

R9-2.2 megohms

R11-100 ohms

R12-1000 ohms

R14,R15—100,000-ohm pc-type (upright) potentiometer

Misc.—Sockets for IC's (seven 14-pin, two 16-pin, one 24-pin); 36-contact edge connector with 0.156" centers (Amphenol 225 or similar); solid hook-up wire for jumpers; insulated sleeving; test-point terminals (5); solder; etc.

Note: The following items are available from PAIA Electronics, Box 14359, Oklahoma City, OK 73114: No. PVI-1PC printed circuit board for \$5.95; complete kit of all parts, No. PVI-1K, for \$34.95 (specify blank or KIM-1 programmed IC1); KIM-1 coded cassette, with programs, No. PVI-1CC, for \$5.00. All prices postpaid.

shift register *ICB*, where they are converted into a serial video signal. The clock and load commands for *ICB* come from gated oscillator *IC4*, which derives its signals from the microcomputer's clock. It is important that the correct clock phase be selected to permit the loading of *ICB* to occur when the output of the character generator is valid and settled. This is phase 2 in the KIM-1. (If you are using a different µP based computer, check this detail.)

The serial video from IC8 goes to the TV Bandwidth Compensator in IC9, which predistorts the video by delaying the video output and OR'ing it against itself. This widens the vertical portions of all characters to generate clean and crisp characters that require minimum bandwidth. The amount of widening is determined by C2 (Fig. 4). The optimum value of C2 is obtained when the generated M or W in the video display just barely closes.

The vertical and horizontal timing signals from *IC2* in the gating circuit are delayed by *IC3*. The display positioning can be varied by potentiometers *R14* and *R15*. The vertical and horizontal sync signals are combined with the enhanced video from *IC9* into video combiner *IC10*. The output from *IC10*, available at *J1*, is composite video, with the sync tips at ground, black at 0.4 volt, and white at 1.6 volts. This output can be used to drive conventional video moni-

tors and converted TV receivers. The video output from *IC10* is also fed to *Q1*, which is offset to deliver a +4-volt output for the white level. This output, available at *J2*, can be connected directly to the first video amplifier of most transformer-powered solid-state TV receivers (see box for details) without requiring biasing, coupling, or translation circuits.

Two options are provided with the TVT-6, both of which are jumper selected. The LENGTH option allows a choice of either 32 or 64 characters/line. The CURSOR option gives the choice of either no cursor or allows the cursor to be displayed under software control.


Construction. The actual-size etching and drilling guide for the printed circuit board used in the TVT-6 is shown in Fig. 5, along with the component-installation diagram. Start assembly by installing and soldering into place the 21 jumpers and test points. (Note that insulated sleeving must be used on two of the long jumpers.) Install the IC sockets, resistors, capacitors, diodes, jacks, and position controls *R14* and *R15*. Do not install the IC's at this time. The correct IC installation sequence and the waveforms to be observed will be discussed in Part 2 next month.

Computer Interface. Detailed in Table I are the requirements of each of the edge connector contacts on the TVT-6 and how to use each contact. Table I also contains the KIM-1 interface connection instructions. The interface consists of adding a new connector and making some add-on connections. One circuit board trace is cut on the KIM-1's pc board to permit an optional change-over switch (or jumper) to be added to the microcomputers. This permits KIM-1 to be used with or without the TVT-6.

General Operation. Since most of today's TVT circuits are used with a microprocessor or microcomputer, it is best to do as much of the display control as possible with the microprocessor and some software. What may not be obvious is that almost all of the timing in the system can also be done using the microprocessor. All this takes is a few dozen words of code.

The four key secrets of operation for the TVT-6 are:

- 1. Carefully choose how the address lines are defined for TVT operation.
- Add a new instruction, which we call scan, to rapidly address 32 or 64 sequential memory locations.
 - 3. Permanently connect an upstream






Fig. 5. Actual-size foil pattern (top) and component installation (below). Use sockets for all IC's. Edge connectors go to KIM-1.

	TAB	LEI	
TVT-6 PINOUT	AND	KIM-1	INTERFACE

A4.

A3

A2.

A1

OB7,

DB6,

DB5.

DB4.

DB3

DB2.

DB1,

DBØ

R (A13)

S (A14)

T (A15)

F (A5)

E (A4)

D (A3)

C (A2)

B (A1)

KIM-1 contact:

8 (BD7)

9 (DB6)

10 (DB5)

11 (BD4)

12 (DB3)

13 DB2)

14 (DB1)

15 (DBØ)

20

21

22

23

24

25

26

27

to TVT-6 contact

28

29

30

31

32

33

34

35

μP data bus; tri-state active high from IC1

during active scan, not used at other times.

Regulated +5-volt (200-mA) power bus; should be heavy wire. From KIM-1 expansion contact 21 or similar point to contact 36

Connections to KIM-1 expansion

TVT-6				
CONTACT	NAME	REMARKS		
1,2	GND	Heavy wire to expansion	on contact 22 or simi-	
3, 4, 5	NC	lar point in KIM-1		
	-	Spares	and the second second	
6	VCL	1-MHz clock from expa (in other systems clock	k phase must be se-	
		lected so that load puls	e arrives when CG is	
		valid.)	The same of the sa	28, 29, 30,
7,8,9,10,	VD7.	Data output from mei		31,32,33,
11,12,13,	VD6,	character generator. F		34, 35
14	VD5,	any part of pages 00		
	VD4,	tions must be made		
	VD3,		o pin 12 of KIM-1 IC:	
	VD2,	7	U5	
	VD1,	8	U6	
	VD Ø	9	U7	
		10	U8	
		11	U9	
		12	U10	
		13	U11	36
		14	U12	
15	CSI	Display memory chip s		
		tive logic OR combined	and the second of the second o	
40	000	lect. From pin 1 of U4 or		11.1.1.101.1
16	CSO	Display memory chip se		Note: KIM-
		display memory when		adding a n
		or contact 15 is low. C	The state of the s	tion to be b
		through U12 in KIM-1		goes to me
		part of pages 00 thro		broken. Off
	OFN	connection in KIM-1 mu		remain inta
17	DEN	Decode enable; goes le		connector
		ated in normal mode,		should be n
		doing an active scan.		When Ki
		plications contact K. Ar		mally and
10 10 00	***	applications contact K s		dresses 80
18,19,20,	A11,	Address inputs from µ		ation with
21,22,23,	A12.	dresses A'd, A6 throu		other progr
24, 25, 26,	A13,	TVT-6. Connections to	Nim-1 expansion:	1 to pin 17

	in TVT-6.
ti c	Note: KIM-1 conversion consists of breaking one (oil trace and adding a new 36-pin socket (Amphenol 127 or similar). Connection to be broken originates as Kφ(pin 1 of U4). Routing of Kφthat goes to memory chip select pin 13 of U5 through U12 should be broken. Other Kφ connections, such as that to pin 1 of U16 should remain intact. Any external ground connections to Application connector contact K (decode-enable) must be removed. All wiring should be made with a wiring pencil.

When KtM-1 is used without displaying video, it will behave normally and transparently as long as TVT-6 is plugged in and addresses 8000 through DFFF are not used. To restore KtM-1 operation with TVT-6 out of socket, or to use available addresses for other programs, jumper pin 15 to pin 16 and separately jumper pin 1 to pin 17 in the KtM-1. Note that this jumpering is to be done only when TVT-6 is out of its connector. I you wish, a dpdt changeover switch can be added to perform the jumpering. Switch positions should be changed only when power is off.

memory tap to the character generator and display circuit.

A14.

A15,

A5,

27

KIM-1 contact:

N (A11)

P (A12)

to TVT-6 contact:

18

19

Create special software that will allow TVT-6 scanning.

All 16 address lines are used, assigned as shown in Fig. 6A for a 32-character/line system or as shown in Fig. 6B for a 64-character/line system. Address A15 is the horizontal sync pulse and the key to jumping to the new SCAN instruction. This pulse is followed in descending address order by the vertical sync (A14) and three lines (L4, L2, L1) that produce the "what row of dots do we want?" information for the character generator. The lower address lines are used to select a page of display memory and to select the character that goes into any particular horizontal and vertical location on the display.





Fig. 6. Bus definitions as used with the TVT-6. All 16 address lines are used as described in text.

DIRECT-VIDEO INPUT CONVERSION



Adding a TVT-6 direct-video input to a small-screen solid-state TV receiver requires only two short lengths of shielded coaxial cable, as illustrated in the schematic. (Important Note: Do not use a hot-chassis TV receiver! Make absolutely certain that the TV receiver you use is transformer powered from the ac line.) The conversion circuit shown here is for the Sears No. 562-50260500 (Sams Photofact No. 1565-1). Other TV receivers can be modified in a similar manner.

The earphone jack in the circuit provides automatic changeover from normal receiver performance to video access. Correct bias is provided by TV output of the TVT-6. As an option, you can defeat the sound trap in the Sears TV receiver by lifting one end of capacitor C201.

The data within the machine (see Fig. 6C) uses the lowest seven bits as ASCII character storage. This is arranged by putting the least-significant ASCII character bit in the least-significant data slot, and so on up through the more significant bits. The eighth data bit (DB7) is reserved for a cursor. If DB7 is a zero, a character is displayed, while if it is a one, a cursor box is optionally displayed.

The existing KIM-1 keypad can be used as an ASCII keyboard for many applications, particularly for setup and debugging. If you wish to add an external ASCII keyboard and encoder, connect it to the KIM-1's parallel interface A, following the assignments shown in Fig. 6D. The seven ASCII bits go to the seven low-order data lines, while PA7 is hard wired for a zero. The keypress, or strobe, signal from the keyboard must pull the IRQ (interrupt request line) to ground for 10 µs to enter a character or machine command.

The truth table for PROM IC1 is shown in Fig. 1. This truth table stores the scan instruction, activated by addresses 8000 through DFFF. When IC1 is enabled, it causes the microprocessor's program counter to appear on the address lines for 32 or 64 consecutive scans that advance one count per microsecond. This automatically and sequentially addresses the display memory and produces exactly the data needed for a horizontal scan of TVT characters. The scan instruction runs at least twice as fast as the microprocessor normally moves, which is the key to TVT timing with a microprocessor.

To use the scan instruction, jump to a subroutine whose starting address is within the 8000 to DFFF range. For example, if you call JRS 8200, the scan instruction will deliver a horizontal sync pulse and initiate operation on the top row of characters, starting with the first character on page 2. After a selected 32

interrupt and reset vectors on the KIM-1 so that the operating system will work compatibly and properly with the new scan instruction.

There are many possible codings for the scan program with the limitation that the last address is a return-to-subroutine (RTS) instruction. The obvious choice of NOP or EA runs at only half speed and can't be used. Of the three dozen instructions that operate at full speed, the choice of LDY is the one that does not disturb the accumulator or its flags. This adds flexibility to other programs. The Y register can be viewed as a write-only memory in the scan software and we can think of the whole scan instruction as a group of double-speed fetch-butdon't-execute instructions. Theoretically, a 64-word PROM would be required for a 64-character line, but this can be overcome by ignoring address A pand changing the PROM's address every second cycle of the machine.

Upstream Tap. The scan instruction will sequentially address 32 or 64 memory slots per horizontal scan line at a rate of one-per-clock cycle (1 μs). These addresses are presented to the entire memory in the computer, including the memory to be displayed. However, during the display times, the scan instruc-





Fig. 7. Adding the upstream tap to the memory to be displayed.

or 64 characters, the scan instruction automatically jumps back to the main program.

The scan instruction can be viewed as a "portable subroutine" because it readily moves around to automatically output the correct page and character generator's row information, starting with an easily computed JSR address. Addresses above DFFF will not activate the scan instruction. This includes the

tion and its PROM have control of the data bus so that the display memory (or anything else) cannot output information to the data bus.

The upstream tap is added as shown in Fig. 7. This tap is always outputting information to the character generator in the TVT-6. The output information is present even (and especially) when the display memory data bus drivers have been inactive.



BUILD THE TVT-6 Part II

System debugging, software, and how to interface to other processors.

BY DON LANCASTER

AST MONTH, we discussed construction of the TVT-6 TV typewriter and explained how it works and how it is connected to a KIM-1 microcomputer. We also started a discussion of the operating secrets of the TVT-6. Here, we complete the "secrets" discussion and go on to system debugging, some useful programs, and tell you how to interface the TVT-6 with other microprocessors.


Software. Four examples of tested, annotated, and workable KIM-1 software are given in the tables in this article. Table II contains a 16 × 32 scan program with full interlace. It automati-

cally generates almost all the timing required by the TVT-6 and its companion TV monitor for this display format. The program is run by jumping to memory location 17Ad. The display is stopped by interrupting with the operating system, the cursor, or other program.

Table III is an optional full-performance cursor for the 16×32 system and includes scrolling, full cursor motion, and erase-to-end-of-screen capabilities. It is run by allowing the keypress signal from the keyboard to interrupt the scan program (any of the three Tables) via the \overline{IRQ} interrupt line. Note that the cursor program is totally inde-

pendent of the SCAN program. The only things the two programs share in common are the same pages of display memory. The screen-read-to-cassette can be performed using the existing KIM-1 operating system programs. You can also load from cassette to display, using the automatic search firmware.

Table IV is a 16-line/64-character scan program that requires only 64 words to be written into memory for the entire program. This program can be used to display the entire 1k of minimum KIM-1 memory for use as a super front-panel display if desired. For display-only applications, 1k of contiguous memory




16 line X 32 character per line Interlaced TVT6 Reater Scan;

μP - 6502 System - EIM-1 Start - JMP 17Ad End - Interrupt Displayed 0200-0377 Program Space 1780-1782

HS VS L4 L2 L1 0 1 V8 V4 V2 V1 H16 H8 H4 H2 H1

Upper Address

Lower Address



NOTES:

TVT6 must be connected and scan microprogram PROM (IC1) must be in circuit for program to run.

Both 1764 and 17C1 require that page 17 be enabled when page 57 is addressed. This is done automatically with KIM-1 circuitry.


Step 1788 goes to where the upper address stored in 178A and the lower address stored in 1789 tells it to. Values in these slots continuously change throughout the program.

Por a 525-line system, use 1768 64 and 1705 65 and a KIM-1 crystal of 992.250 kHz. This is only needed for video superposition and titling applications.

Normal program horizontal frequency 15,873.015 Hz; Vertical frequency 60,0114 Hz. 63 us per line; 264.5 lines.


- * Denotes a relative branch that is program length sensitive.
- () Denotes an absolute address that is program location sensitive.

TV76 length jumper must be in "32" position.



is required. Keep in mind that the KIM-1 has some operating system slots in the top of page zero and the stack at the top of page one. Unless you actually want to display the stack and operating system parameters, do not use these slots.

The 64-character line makes the TV receiver's horizontal frequency run considerably lower than normal. This will require a readjustment of the horizontalhold control or some extra capacitance across the existing horizontal-hold capacitor. The width of the raster may also have to be reduced; this is most easily accomplished by adding a low-value inductor in series with the voke. These changes are best made in a smallscreen, transformer-powered monochrome TV receiver. The tradeoff of a lowered horizontal frequency produces a long character line but still allows 1 μs/character. This will not tax the bandwidth restrictions of TV receivers or r-f modulators. (Editor's Note: The smallscreen Sears TV receiver we used required adjustment of horizontal size and linearity, a 0.033-µF Mylar capacitor in parallel with the 0.068-µF capacitor used for C408 in the receiver, and an inductor consisting of 60 turns of No. 24 enameled wire on a 1/2" Nylon form in series with the red yoke lead in the receiver. In addition, it was necessary to disconnect one side of C201 in the receiver



to defeat the sound trap. Never attempt to modify a TV receiver that is powered directly from the ac line without an isolating transformer.)

Table V contains a program that we call "Cruncher the Bear." This program produces 64 fully interlaced characters in each of 32 rows, for a total of 2048 sharp ASCII characters on-screen at one time within the 3-MHz bandwidth. You can add a hex-to-ASCII converter that slowly sequences high- and low-order machine code characters in the same slot and end up with 4096 hex characters displayed in only 3 MHz of bandwidth.

Table V requires a contiguous 2k of memory with a common upstream tap and separate chip enables. However, it is easily incorporated if you really want or need to display as many characters as the program allows.

Other software is easily written and developed for the TVT-6. For example, you may wish to have a 32 × 44 or a 32 × 48 character display and still use normal, or nearly normal, horizontal scanning rates. This allows for video titling and superimposition, oversize characters, color graphics, lower-case characters, and game displays. There is no lower limit to the number of character rows or characters per line you can use. If you have limited memory available,

Table III

16 X 32 Full-performance Cursor:

µP -- 6502 Start -- IRQ Displayed 0200-03FF System -- KIM-1 End --- RTI Program Space 0100-01dF Input to Parallel Word A B A7 A6 A5 A4 A3 A2 /1 - 10 um Cursor Home - SOH (\$A) Scroll Up - DC1 (11) Erase to End - DC2 (12) Spare Hook - DC3 (13) Clear - CAN (18) Carriage Return - CR (6d) Cursor Up - VT (6b) Cursor Down - LF (6A) Enter -- All characters Ignore -- All other CTRL Cursor Left - BS (#8) Cursor Right - HT (#9) Enter via Save A Reset Y Index Get Cursor and test for range 0100 PHA 48 A0 A5 C9 LDY 0101 00 (EE) 0103 Is cursor on page 3? BEQ CHP BNE FO C9 d0 Yes, OK to continue Is cursor on page 2? No. Home cursor Get old cursored character 0109 -010b 02 3A* -0104 0147 29 91 Ad C9 Erase old cursor Replace character without cursor Get new character from A parallel Int. Is it a character to be entered? OIOF AND 77 (Ed) 0111 STA LDA CMP 00 b0 Yes, go and enter character Clear Screen? 0118 PCS. 29. 011A CHIP BEO P0 40* Yes, clear screen 0115 Return Carriage? od 100 0120 BEG Yes, Return carriage Cursor Up? Yes. Up Cursor Cursor Down? 0122 C9 0124 BEQ 65 PU C9 PO C9 0128 Yes, Down Cursor Cursor Right? Yes, Right Cursor Cursor Left? 012A CMD 09 0128 01A7 -0130 BEQ F0 Yes, Left Cursor Cursor Home? Yes, Home Cursor Scroll Up? 0132 0134 BEQ PU C9 PO C9 Yes, Scroll Up 013A CMP 12 Spare Hook? Ignore--Restore Cursor 0132 CHT Erase to BOS? PO 67* 20 (D3) Yes, Brase to EOS ////Enter Character//// End of Screen? 0140 0142 JSR (01) 40 (32) BNE 0147 (01) Yes, Home Cursor 014A 014C 014E ///Restore Cursor//// Add cursor to cursored character Replace cursored character (24) ORA 91 (84) Return to Scan ////Carriage Return//// Move Gursor to Right End Restore Cursor 0152 0154 0156 RTI A5 (S4) LDA 0158 ISR (45) (45) (C2) Increment Cursor Pinish ////Clear///Home Cursor 0155 JSR 20 Clear Screen 0147 SEQ LDA CLC PO E1* A5 (Ed) 16 ////Cursor Down//// Get Gursor Clear Carry Move Cursor Down 0166 Restore Cursor Overflow of page? Yes, increment upper page Finish STA 85 016d JSR 0172 ///Scroll Up/// Home Gursor Add Offset to Index Get Offset Indexed Character Remove Offset from Index 0175 JSR 20 (C2) (01) AO LDY b1 (Ed) 017A LDA AO 017E JSR 20 (43) (01) Enter Moved Character and Increment Repeat? Clear Carry Set A to page 3 0181 BHE 18 0184 LDA 49 01 Set Cursor to Page 3 Set A to start of last line Set Cursor to Start of last line Finish if carry set 0186 85 (KE) 0188 LDA (Sd) 018A STA -018C 014A -

	JSR :	(GD) OS	(01)	Clear last line
		38		Set Carry
0192	BCS	bo Pos		Restore Cursor to start of last line
	LDA .	A5 (E4)		////Cursor Up////Get Cursor
0196	SEC	38		Set Carry
0197	SBC	B9 20		Move up one line
	STA	85 (84)		Restore Cursor
	BCS	PO VI		Underflow of page?
0194	DEC	C6 (EB)		Yes, decrement page
019P	LDA	A9 01		Set A to Page 1
01A1	CMP	C5 (EB)		Did acreen underflow?
0144-0143	BNE	40 A5*		No, Pinish
0147-01A5	BEQ	PO AO*		Yes, Home Cursor
01A7		C6 (Ed)		///Cursor Left////Decrement Cursor
01A9		A9 PF		Set A to page underflow
OTAB		05 (84)		Test for page underflow
GIAD	OIL			
0194 01Ad		PO EE*		Change Page 1f off Page
014A 01Af	BNE	do 99*		Finish if on page
0161	LDA	A5 (EE)		///Erase to EOS///Get Cursor
0163	PHA	48		Save Upper cursor location
0164	LDA	A5 (3d)		Get lower cursor location
0166		48		Save lower cursor location
0167		20 (Cb)	(01)	Clear to End of Screen
		68		Get lower cursor location
0166	STA	85 (Sá)		Restore lower cursor
O1bd	PLA			Get upper cursor location
0168		85 (BE)		Restore upper cursor
014A - 01CO		40 BB*		Finish
0102	LDA	A9 UO		///SUB//Home Curaor///
0104	STA	85 (Ed)		Set lower cursor to zero
0106	LDA	A9 02		Put page 2 in A
0108	STA	85 (BE)		Set upper cursor to U200
OICA	RTS	60		Return to main program
-01Cb		A9 20		///SUB//Enter Space///
D1Cd		20 (43)	(01)	Enter space via Sub
-01d0		d0 79*		Repeat if not to end
0142	RTS	60		Return to main program
0143		91 (Ed)		///SUB//Enter, Increment// store
0145	INC	B6 (Bd)		Increment Curaor
		40 06*		Overflow?
0147		mc (mm)		Yes, Increment cursor page to 03
0147	THO			
01d7 01d9		E6 (EE)		
01d7 01d9 01db	LDA	A9 04		Load A with page 4
0147	LDA			

NOTES: IRQ vector must be stored in 17PS 00 and 17PF 01.

Total available stack length is 32 words. Approximately 16 are used by operating system, cursor, and scan program. Stack must be initialized to 01FP as is done in KIM-1 operating system. For 30 additional stack locations, relocate subroutines starting at 01CZ elsewhere.

To protect page, load COFS 04. To enable entry load COFS 00.

Cursor address is stored at COEd low and COEE high on page zero.

To display cursor load 014d 80. To not display cursor load 014d 00.

- Denotes a relative branch that is program length sensitive.
- () Denotes an absolute address that is program location sensitive.

you can run 8×32 , 4×64 , 1×64 , or even 1×8 character formats. All this takes is software changes, and the circuitry of the TVT-6 remains the same.

Initial Debugging. At this point, there should be no IC's in the sockets of the TVT-6 board assembly. Start by connecting the LENGTH jumper to 32 and the CURSOR jumper to YES on the TVT-6 board. (Note: These points are pads located at the center of the circuit board, not the edge-connector contacts.) Temporarily insert a jumper wire between

pins 3 and 14 on the IC5 socket. Center the two position control potentiometers and install IC1, IC2, and IC6 in their respective sockets.


Connect your video monitor to the TVT-6 board and power up the system. Check for the presence of the SCAN instructions (see PROM Truth Table in Fig. 1 of Part 1) at hex locations 8000 through 8020. Write a simple program that jumps to a subroutine at location 8000 and then loops. Single-step through this program to verify proper operation of the SCAN instruction. Do not



USING THE TVT-6 WITH OTHER POPULAR MICROPROCESSORS

Both parts of this article have used the TVT-6 with the 6502 microprocessor-based KIM-1 microcomputer. Here is how to use the TVT-6 in μC's that use other popular microprocessors.

6800. The 6800 μP is very similar to the 6502 and, therefore, is easiest to convert. The SCAN microprogram can be LDAB(C6) for words 0 through 30 and RTS(39) for word 31. A literal translation of the tightest part of the SCAN program (1D:1782 through 178C) is: STA(B7); JSR(BD), ADDA(8B); CMPA(81); BCC(24). This routine requires 25 μs to cycle through as compared to the 21 μs required for the 6502



8080. A stock 8080 µP can normally change its program counter once every 2 µs, but it can be "tricked" into doubling its speed during a SCAN microprogram by driving the usual address line A9 of the display memory from SYNC. The SCAN microprogram is then NOP(00) for words 0 through 30 and RET(A9) for word 31. A tighter than literal translation of the SCAN program (1D:1782 through 178C) is: STAXB(02); CALL(AD); ADD(82); CMP(BB); JNC(DB), which requires 24 µs to cycle through. Here, the TVT-6 address lines A5 through A1 must be relabelled A4 through AØ, respectively.

280. The Z80 μP can use 8080-developed software with speed-doubling scans, or it can simply be run faster, al-

lowing the program counter to change once every microsecond. Use a literal translation of the program for the 6502.

12 Address Line μP's. The four upper address lines of 12 address line μP's can be decoded to allow normal operation, 8 to 12 lines of scan, a vertical sync pulse, an operating return system, and an optional "page-change" command. This leaves a 256-character page on the bottom eight bits, and the "page-change" command can be latched to change to any number of additional pages, as required.

General Hints. Horizontal scan should last at least 62, 63.5, or 64 μs for conventional horizontal-frequency operation. The microprogram scan must end exactly this number of microseconds lat-

er for each horizontal line in the total scan program. The total number of lines must produce a vertical frequency between 59.9 and 60.1 Hz per field. Note that a portion of the RTS time will be spent during the active (microprogram) scan time. Horizontal scans that last longer than 85 µs may make it difficult to obtain TV interface.

You can shorten a blank microprogram active scan by an even number simply by jumping ahead when you call your subroutine. For example, a JSR 8000 may produce a 32-character scan, while a JSR 8002 can produce a 30-character scan. This approach can come in handy when there is a need for equalizing scan lengths between character rows and during vertical retrace.


16 line X 64 character per line TVT6 Raster Scan:

µP - 6502 System - KIM-1 Start - JMP 17AA End - Interrupt Displayed 0000 - 03FF Program Space 1780-17bE

HS VS L4 L2 L1 0 V8 V4 V2 V1 H32 H16 H8 H4 H2 H1

Upper Address

Lower Address



NOTES: TVT6 must be connected and scan bicroprogram PROM (101) must be in circuit for program to run

Step 1785 goes to where the upper address stored in 1787 and the lower address stored in 1786 tells it to. Valuer in these slots continuously change throughout the program.

Normal program horizontal frequency is 11,764,705 Hz. Vertical Frequency is 60,024 Hz. 85 us per line; 196 lines. Character time 1 us. 160 active lines, 36 retrace. Needs TV set adjustment and possible modification (hold and width).

 Denotes a relative branch that is program length sensitive.

() Denotes an absolute address that is program location sensitive.


TV76 length jumper oust be in "64" position.


proceed beyond this point until you are certain that the SCAN subroutine is operating properly. (Critical waveforms to be observed with an oscilloscope are illustrated in Fig. 7 using the program listed in Table II.)

Insert IC3 into its socket and load the program given in Table II. (Never install an IC in a powered circuit; always turn off the power, install the IC, and power up again.) Set the address to 17Ad and depress GO. Using an oscilloscope, check at test point VR for the presence of a 60-Hz pulse. Switch the scope to line-sync and observe that the pulse remains fixed or drifts very slowly across the screen. Again, do not proceed until you are certain that the SCAN program is operating properly.

Install all remaining IC's, except IC5, in their respective sockets on the TVT-6 board. At this point, the screen should be filled with a stable display of 512 cursor boxes. Viewed up close, the boxes should appear to be "hiding" characters. Do not proceed until you have the indicated display.

Checking with Fig. 7, particularly with respect to the LOAD and CLOCK on IC8 (Fig. 7A) verify whether or not the appropriate waveforms are present. If they are, remove the jumper wire from the IC5 socket and install IC5. Now, the screen of the monitor should have displayed on it a full array of characters with about half of them winking cursor blocks. Load the following hex numbers into memory, starting at location 0200:





20, 20, 20, 50, 4F, 50, 55, 4C, 41, 52, 20, 20, 45, 4C, 45, 43, 54, 52, 4F, 4E, 49, 43, 53, 20, 20, 54, 56, 54, 2D, 36, 20, 20. Return to address 17Ad and depress GO. The top display line should now read "POPULAR ELECTRONICS TVT-6" and be indented three spaces. If all is well to this point, you can begin feeding in your cursor programs, add external keyboard and/or cassette loads and dumps, etc.

Should you encounter problems with your TVT-6, always begin debugging by using the 16 × 32 format on a KIM-1, even if you plan on using longer line lengths or plan to translate the code into another coding system. Note that the translation *must* be at the machine-language level because the SCAN program must provide the exact number of machine cycles as well as the proper sequencing. The 64-character lines will require some adjustments to be made in the monitor TV receiver's horizontal circuit as detailed earlier.

Closing Remarks. We have presented here full construction and operating details for a very versatile and inexpensive TV typewriter for use with the KIM-1 microcomputer. If you have a computer that uses a microprocessor other than the 6502 used in the KIM-1, we refer you to the box for use details.




TABLE Y

CRUNCHER THE BEAR Program for a 32 line X 64 character per line TVT6 raster scan:

μP - 6502 Start - JMP 17C0 D System - KIM-1 End - Interrupt P

Displayed 0000-07FF Program Space 1780-17dA

HS VS L4 L2 L1 V16 V8 V4 V2 V1 H32 H16 H8 H4 H2 H1

Upper Address

Lower Address

1792 ADD 1797 PLJ 1798 JSR 1799 ADD 1799 BGC 17A1 LDA 17A4 ADD 17A6 BCC 17A8 LDA 17A4 LDA 17A5 LDA 17A	69 CO 88 90 Z1 90	17AA 17A6 17A6 17A8 17A8 17A8 17A8 17A8 17A9 17b1 17b2 17b2 17b2 17b2 17c2 17c2 17c2 17c3 17c4 17c4 17c6 17d1 17d1 17d3	(17) (57) (17) (17) (17) (17) 80	Get Upper Word ////Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 33"? No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished Start Swen Field if Carry Clear Load Even number of V Scans ~2 Load Even Pield Upper Start Even Field V Sync + Restore Interlace Sven Field Line 33 CMP Value Store Even 33 CMP Value Clear Accusulator Initialize Lower Address Equalize 31 cycles continued Jump If even field Load Odd Field Upper Start Odd Field V Sync * Restore Interlace Odd Field V Sync * Restore Interlace Odd Field V Sync * Restore Interlace Odd Field Upper Start Odd Field V Sync * Restore Interlace Odd Field Upper Start Odd Field Sync * Restore Interlace Odd Field Upper Start Odd Field Sync * Restore Interlace Odd Field Sync * Restore
1794 STA 1797 PL 1798 JSR 1799 ADO 1794 GMF 1799 BCG 1791 EDA 1786 EDX 1786 EDX 1787 LDA 1788 LDX 1788 LDX 1788 LDX 1789 LDX 1789 LDX 1788 BCS 1788 BC	69 CO 88 90 Z1 90	17AA 17A6 17A8 17AA 17AB 17AA 17AB 17AB 17AB 17AB 17AB	(17) (57) (17) (17) (17) (17) 80	Get Upper Word ////Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 33"? No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished Start Sven Field if Carry Clear Load Even Pield Upper Start Even Fielo V Sync + Restore Interlace Sven Field Line 33 CMP Value Store Even 33 CMP Value Glear Accumulator Initialize Lower Address Equalize 31 cycles continued Jump If even field Load Odd Field Upper Start Odd Field V Sync + Restore Interlace Odd Field V Sync + Restore Interlace Odd Field Upper Start Odd Field Upper Start Odd Field Upper Start Odd Field Upper Start Odd Field V Sync + Restore Interlace Odd Field V Sync + Restore Interlace Odd Field V Sync + Restore Interlace Odd Field Upper Start Odd Field
1794 STA 1797 PLL 1798 JSR 1799 JSR 1799 BCC 1797 BCC 1798 BCC 1798 BCC 1746 BCC 1746 BCC 1746 BCC 1746 BCC 1747 LDA 1746 BCC 1748 LDA 1740 STA 1751 STA 1752 BCS 1762 STA 1762 STA 1764 LDX 1765 STA 1767 STA 1764 LDX 1767 PHA 1764 CLD	69 CO 88 90 Z1 90	17AA 17A6 17A6 17AB 17AB 17AB 17b1 17b1 17b2 17b2 17b2 17b2 17b2 17b2	(17) (57) (17) (17) (57) (17)	Get Upper Word ////Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 3)"? No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished Start Swen Field if Carry Clear Load Even number of V Scans ~2 Load Even Pield Upper Start Even Field V Sync + Restore Interlace Sven Field Line 53 CMP Value Store Even 33 CMP Value Clear Accusulator Initialize Lower Address Equalize 31 cycles continued Jump If even field Load Odd Field Upper Start Odd Field V Sync + Restore Interlace Odd Field V Sync + Restore Odd Field
1794 STA 1797 PLL 1798 JSR 1799 GM 1794 GM 1796 GM 1797 BCC 1797 BCC 1798 BCC 1741 LDA 1746 BCC 1748 LDA 1744 LDA 1744 LDA 1744 LDA 1754 LDA 1754 LDA 1754 LDA 1755 STA 1756 STA 1756 STA 1757 STA 1767 STA 1767 STA 1767 STA 1767 PHA 1761 PLA	69 CO 88 90 Z1 90	17A4 17A6 17A8 17A8 17A7 17A7 17b1 17b4 17b6 17b8 17b8 17b8 17b8 17b8 17b8 17c0 17c2 17c5 17c2 17c5 17c7 17c7	(17) (57) (17) (17) (57) (17)	Get Upper Word ///Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 33"? No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished Start Sven Field if Carry Clear Load Even number of V Scans ~2 Load Even Pield Upper Start Even Field V Sync + Restore Interlace Sven Field Line 33 CMF Value Store Even 33 CMF Value Clear Accumulator Initialize Lower Address Equalize 31 cycles continued Jump If even field Load Odd Field Upper Start Odd Field V Sync + Restore Interlace Odd Field Upper Start Odd Field V Sync + Restore Interlace Odd Field V Sync + Restore Interlace Odd Field Upper Start Odd Field Sync + Restore Interlace
1794 STA 1797 PL 1798 JSR 1798 JSR 1799 ADO 1794 GMF 1799 BCC 1741 LDA 1746 BCC 1748 LDA 1748 LDA 1749 LDA 1749 LDA 1749 LDA 1749 LDA 1749 BCC 1749 BCC 1750 BCC 1750 BCC 1750 BCC 1762 STA 1763 LDA 1764 LDA 1765 BCS 1765 LDA 1767 LDA 1767 STA 1767 LDA 1767 STA 1767 LDA 1767 STA 1767 LDA	69 CO 88 90 Z1 90	17AA 17A6 17AB 17AB 17AB 17AB 17AB 17bb 17bb 17bb 17bb 17bb 17bb 17bb 17b	(17) (57) (17) (17) (57) (17)	Get Upper Word ///Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 33"? No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished Start Sven Field if Carry Clear Load Even number of V Scans ~2 Load Even Pield Upper Start Even Field V Sync + Restore Interlace Sven Field Line 33 CMP Value Store Even 33 CMP Value Clear Accumulator Initialize Lower Address Equalize 31 cycles continued Jump If even field Load Odd Field Upper Start Odd Field V Sync * Restore Interlace
1794 STA 1797 PLI 1798 JSR 1799 ADO 1794 GME 1799 BGG 1741 LDA 1746 BGG 1746 LDA 1748 LDA 1749 LDA 1749 LDA 1749 LDA 1749 LDA 1750 BEY 1750 BPI 1750 BPI 1750 BPI 1752 STA 1763 LDA 1764 LDA 1765 STA 1767 STA 1767 STA 1764 LDA	69 CO 88 90 Z1 90	17A4 17A6 17A8 17A8 17A7 17A7 17b1 17b4 17b6 17b9 17bb 17bc 17bc 17bc 17bc 17bc	(17) (57) (17) (17) (57) (17)	Get Upper Word ///Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 33"? No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished Start Sven Field if Carry Clear Load Even number of V Scans ~2 Load Even Pield Upper Start Even Field V Sync + Restore Interlace Sven Field Line 33 CMP Value Store Even 33 CMP Value Clear Accumulator Initialize Lower Address Equalize 31 cycles continued Jump If even field Load Odd Field Upper Start Odd Field V Sync * Restore Interlace
1794 STA 1797 PLA 1798 JSR 1798 JSR 1799 ADO 1794 GMF 1799 BCC 1781 LDA 1784 BCC 1788 LDA 1784 LDA 1784 LDA 1785 LDA 1785 LDA 1786 STA 1789 LDY 1786 BCS 1786 BCS 1786 BCS 1786 BCS 1786 LDA 1786 BCS 1786 LDA 1786 BCS 1786 LDA 1786 BCS 1786 LDA 1786 BCS 1786 LDA 1787 STA 1787 LDA	69 CO C9 88 90 Z1 A4 (81) 69 78 90 00 A2 22 A9 80 84 (81) A9 98 84 (92) A9 00 84 (86) A9 06 88 89 (81) A9 90 84 (81) A9 90 84 (92) A9 90 85 86 (81) A9 90 86 (92) A9 90 87	17AA 17A6 17A6 17AB 17AB 17AB 17b1 17b1 17b2 17b6 17b6 17b6 17b6 17b6 17b6 17b6 17b6	(17) (57) (17) (17) (57) (17)	Get Upper Word ////Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 3)-? No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished Start Sven Field if Carry Clear Load Even number of Y Scans -2 Load Even number of Y Scans -2 Load Even Field Upper Start Sven Field V Sync + Restore Interlace Sven Field Line 33 CMP Value Store Even 33 CMP Value Glear Accusulator Initialize Lower Address Equalize 31 cycles continued Jump If even field Load Odd Field Upper Start Odd Field V Sync + Restore Interlace Odd Field Vine 33 CMP Value Store Odd 33 CMP Value Load Odd number of V Scans
1794 STA 1797 PLL 1798 JSR 1799 JSR 1799 GME 1799 BCC 17741 LDA 17746 BCC 1746 LDX 1746 LDX 1747 LDA 1748 LDX 1749 LDX 1741 LDA 1749 LDX 1741 LDA 1741 LDA 1745 STA 1745 BCC 1746 BCC 1	69 CO C9 88 90 Z1 Ad (81) 69 78 90 OC A2 22 A9 80 84 (81) A9 98 84 (93) A9 00 84 (86) A9 00 85 (86) A9 00 86 (86) A9 00 86 (86) A9 00 87 88 88 88 89 89 89 89	17A4 17A6 17A8 17A3 17A2 17A2 17A2 17b4 17b4 17b6 17b9 17bb 17bb	(17) (57) (17) (17)	Get Upper Word ///Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 3)"? No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished Start Swen Field if Carry Clear Load Even number of V Scans ~2 Load Even Pield Upper Start Even Fielo V Sync + Restore Interlace Sven Field Line 53 CMF Value Store Even 33 CMF Value Clear Accumulator Initialize Lower Address Equalize 31 cycles continued Jump if even field Load Odd Field Upper Start Odd Field V Sync + Restore Interlace Odd Field V Sync + Restore Interlace Odd Field Upper Start Odd Field Upper Start Odd Field Upper Start Odd Field Inne 33 CMF Value Store Odd 33 CMF Value
1794 START 1797 PLDA 1798 JSR 1799 JSR 1799 ADO 1794 GMF 1799 BCC 17A1 LDA 17A6 BCC 17A6 LDX 17A6 BCC 17A6 LDX 17AA LDA 17AF LDA	69 CO 88 90 Z1 90	17A4 17A6 17A8 17A8 17A7 17A7 17b1 17b4 17b6 17b9 17b6 17b6 17b6 17b6 17b6	(17) (57) (17) (17)	Get Upper Word ///Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 33"? No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished Start Sven Field if Carry Clear Load Even number of V Scans ~2 Load Even Pield Upper Start Even Field V Sync + Restore Interlace Sven Field Line 33 CMP Value Store Even 33 CMP Value Glear Accumulator Initialize Lower Address Equalize 31 cycles continued Jump If even field Load Odd Field Upper Start Odd Field V Sync + Restore Interlace Odd Field V Sync + Restore Interlace Odd Field V Sync + Restore Interlace Odd Field Upper Start
1794 STA 1797 PLI 1798 ADO 1794 GME 1799 BCC 1791 LDA 1774 LDA 1775 STA 1775 BPI 1776 BPI 1776 BPI 1776 BPI 1776 LDA	69 CO C9 88 90 Z1 Ad (81) 69 78 90 0C A2 22 A9 80 84 (81) A9 98 84 (93) A9 00 84 (86) A9 06 88 10 74 88 88 88 88 88 88 88	17A4 17A6 17A8 17A3 17A2 17A2 17A2 17A4 17b4 17b4 17b6 17b9 17b8	(17) (57) (17)	Get Upper Word ///Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 3)-"? No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished Start Swen Field if Carry Clear Load Even number of V Scans -2 Load Even Pield Upper Start Even Field V Sync + Restore Interlace Sven Field Line 53 CMP Value Store Even 33 CMP Value Glear Accusulator Initialize Lower Address Equalize 31 cycles continued Jump If even field Load Odd Field Upper Start Odd Field V Sync + Restore Interlace
1794 STA 1797 PLI 1798 JSR 1798 ADO 1794 GME 1799 BCO 17A1 LDA 17A6 BCO 17A6 BCO 17A6 LDX 17AA LDA 17A7 LDA 17A8 LDA 17A8 LDA 17A8 LDA 17A9 LDA 17A1 LDA 17A1 LDA 17A2 LDA 17A4 LDA 17A5 LDA 17A4 LDA 17A5 LDA 17A5 LDA 17A6 STA 17A6 BCO 17A	69 CO C9 88 90 Z1 Ad (81) 69 78 90 0C A2 22 A9 80 84 (81) A9 98 84 (93) A9 00 84 (86) A9 06 88 10 74 88 88 88 88 88 88 88	17A4 17A6 17A8 17A3 17A2 17A2 17A2 17A4 17b4 17b4 17b6 17b9 17b8	(17) (57) (17)	Get Upper Word ///Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 3)-"? No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished Start Swen Field if Carry Clear Load Even number of V Scans -2 Load Even Pield Upper Start Even Field V Sync + Restore Interlace Sven Field Line 53 CMP Value Store Even 33 CMP Value Glear Accusulator Initialize Lower Address Equalize 31 cycles continued Jump If even field Load Odd Field Upper Start Odd Field V Sync + Restore Interlace
1794 STA 1797 PLI 1798 JSR 1799 ADC 1794 GMF 1799 BCC 17A1 LDA 17A4 BCC 17A6 BCC 17A6 LDX 17AA LDA 17A	69 CO 88 90 Z1 90	17A4 17A6 17A8 17A8 17A2 17A2 17A3 17b4 17b4 17b6 17b9	(17) (57) (17)	Get Upper Word ///Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 33"? No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished Start Sven Field if Carry Clear Load Even number of V Scans ~2 Load Even Pield Upper Start Even Field V Sync + Restore Interlace Sven Field Line 33 CMP Value Store Even 33 CMP Value Glear Accumulator Initialize Lower Address Equalize 31 cycles continued Jump If even field Load Odd Field Upper Start
1794 STA 1797 PL 1798 JSR 1798 JSR 1799 GMF 1799 BCC 17741 LDA 17746 BCC 1746 LDA 1746 LDA 1747 LDA 1749 LDA 1754 LDA 1755 LDA 1759 LDY 1756 BPI 1756 BPI	69 CO C9 88 90 Z1* Ad (81) 69 78 90 OC* A2 22 A9 80 84 (91) A9 98 84 (92) A9 00 Bd (86) A0 D6 B8 10 Fd bo nc*	17AA 17A6 17A6 17AB 17AA 17AP 17b1 17b4 17b6 17b6 17b6	(17) (57) (17)	Get Upper Word ////Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 3)-? No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished Start Swen Field if Carry Clear Load Even number of Y Scans -2 Load Even Pield Upper Start Even Fielo V Sync + Restore Interlace Swen Field Line 33 CMP Value Store Even 33 CMP Value Glear Accusulator Initialize Lower Address Equalize 31 cycles continued Jump 1f even field
1794 STA 1797 PL 1798 JSR 1798 JSR 1799 GMF 1799 BCC 1741 LDA 1746 BCC 1748 LDX 1748 LDX 1749 LDX 1754 LDA 1754 LDA 1755 LDA 1759 LDY	69 CO C9 88 90 Z1• Ad (81) 69 78 90 OC• A2 22 A9 80 84 (61) A9 98 84 (92) A9 OO 84 (86) A0 O6 88	17AA 17A6 17A6 17AA 17AC 17AP 17b1 17b4 17b6 17b9	(17) (57) (17)	Get Upper Word ////Character Scans 8,9 //// Add Carry; Reset Upper Address Is it "Line 33-7 No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished Stort Sven Field if Carry Clear Load Even number of Y Scans -2 Load Even Field Upper Start Even Fielo V Sync + Restore Interlace Sven Field Line 33 CMP Value Store Even 33 CMP Value Glear Accumulator Initialize Lower Address Equalize 31 cycles continued
1794 STA 1797 PL 1798 JSR 1798 JSR 1799 GMF 1799 BCC 17A1 LDA 17A4 BCC 17A6 BCC 17A6 BCC 17A6 LDA 17AC STA 17AC BCC 17AC BC	69 CO C9 88 90 Z1• Ad (81) 69 78 90 OC• A2 22 A9 80 84 (61) A9 98 84 (92) A9 OO 84 (86) A0 O6 88	17AA 17A6 17A6 17AA 17AC 17AP 17b1 17b4 17b6 17b9	(17) (57) (17)	Get Upper Word ////Character Scans 8,9 //// Add Carry; Reset Upper Address Is it "Line 33-7 No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished Stort Sven Field if Carry Clear Load Even number of Y Scans -2 Load Even Field Upper Start Even Fielo V Sync + Restore Interlace Sven Field Line 33 CMP Value Store Even 33 CMP Value Glear Accumulator Initialize Lower Address Equalize 31 cycles continued
1794 STA 1797 PLL 1798 JSR 1798 GME 1799 BCC 1791 EDA 1784 EDA 1786 EDA 1784 LDA 1784 LDA 1785 LDA 1787 LDA 1788 LDA 1789 LDA 1781 EDA 1781 EDA 1781 EDA 1781 EDA 1781 EDA 1781 EDA 1785 EDA 1786 STA 1786 STA	69 CO C9 88 90 Z1• Ad (81) 69 78 90 OC• A2 22 A9 80 84 (81) A9 98 84 (92) A9 OO 84 (96) A9 OO	17A4 17A6 17A6 17A7 17A7 17A7 17A7 17b1 17b4	(17) (57) (17)	Get Upper Word ////Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 3)"? No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished Start Swen Field if Carry Clear Load Even number of V Scans ~2 Load Even Pield Upper Start Even Field V Sync + Restore Interlace Sven Field Line 53 CMP Value Store Even 33 CMP Value Clear Accusulator Initialize Lower Address Equalize 51 cycles
1794 STA 1797 PLJ 1798 JSR 1796 GMF 1796 GMF 1797 BCC 17A1 LDA 17A4 ADC 17A6 BCC 17A8 LDA 17A8 LDA 17A8 LDA 17A7 LDA 17A7 LDA 17A8 LDA	69 CO C9 88 90 Z1• Ad (81) 69 78 90 OC• A2 22 A9 80 84 (61) A9 98 84 (92) A9 00	17A4 17A6 17A6 17AA 17AC 17AP 17AP 17AP	(17) (57) (17)	Get Upper Word ////Character Scans 8,9 //// Add Carry; Reset Upper Address Is it "Line 33-7 No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished Stort Even Field if Carry Clear Load Even number of Y Scans -2 Load Even Field Upper Start Even Fielo V Sync + Restore Interlace Sven Field Line 33 CMP Value Store Even 33 CMP Value Glear Accumulator
1794 STA 1797 PLI 1798 JSR 1798 ADO 1799 GOM 1799 BCC 17A1 LDA 17A4 BCC 17A6 BCC 17A6 LDX 17AA LDA 17A7 LDA 17AF LDA	69 C0 C9 88 90 Z1• Ad (81) 69 78 90 0C• A2 22 A9 80 84 (81) A9 98 Bd (92)	17A4 17A6 17A8 17AA 17AC 17AP 17AP	(17)	Get Upper Word ////Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 33"? No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished Start Even Field if Carry Clear Load Even number of V Scans -2 Load Even Field Upper Start Even Fielo V Sync + Restore Interlace Syen Field Line 53 CMF Value Store Even 33 CMF Value
1794 STA 1797 PLI 1798 JSR 1798 ADO 1799 GOM 1799 BCC 17A1 LDA 17A4 BCC 17A6 BCC 17A6 LDX 17AA LDA 17A7 LDA 17AF LDA	69 C0 C9 88 90 Z1* Ad (81) 69 78 90 OC* A2 22 A9 80 84 (61) A9 98	17A4 17A6 17A8 17AA 17AC 17AP 17AP	(17)	Get Upper Word ////Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 33"? No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished Start Even Field if Carry Clear Load Even number of V Scans -2 Load Even Field Upper Start Even Fielo V Sync + Restore Interlace Syen Field Line 53 CMF Value Store Even 33 CMF Value
1794 STA 1797 PLI 1798 JSP 1798 GME 1799 BCC 1791 LDA 1784 BCC 1786 BCC 1786 LDX 1784 LDX	69 C0 C9 88 90 Z1* Ad (81) 69 78 90 OC* A2 22 A9 80 8d (81)	17A4 17A6 17A8 17AA	(17)	Get Upper Word ////Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 33"? No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished Start Even Field if Carry Clear Load Even number of V Scans -2 Load Even Pield Upper Start Even Fielo V Sync + Restore Interlace
1794 STA 1797 PH 1798 JSR 1798 ADO 1794 CMF 1797 BCC 17A1 LDA 17A4 BCC 17A6 BCC 17A8 LDA	69 C0 C9 88 90 Z1• Ad (81) 69 78 90 OC• A2 22 A9 80	17A4 17A6 17A6 17AA	(17)	Get Upper Word ////Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 33"? No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished Start Even Field if Carry Clear Load Even number of Y Scans -2 Load Even Field Upper Start
1794 STA 1797 PLI 1798 JSR 1798 ADO 1794 GMF 1799 BGO 17A1 LDA 17A4 BGO 17A6 BGO 17A6 LDX	69 C0 C9 88 90 Z1• Ad (81) 69 78 90 OC• A2 22	17A4 17A6 17A8		Get Upper Word ////Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 33"? No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished Start Even Field if Carry Clear Load Even number of V Scans -2
1794 STA 1797 PLJ 1798 JSR 1796 ADG 1799 BCG 1741 LDA	69 C0 C9 88 90 21• Ad (81) 69 78 90 00•	1744		Get Upper Word ////Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 33"? No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished Start Sven Field if Carry Clear
1794 STA 1797 PLJ 1798 JSR 1796 GMF 1799 BCC 1741 LDA	69 CO C9 88 90 Z1• Ad (81)	1744		Get Upper Word ////Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 33"? No, repeat Character Scans Get Interlace word Set Carry if Odd Field finished
1794 STA 1797 PL 1798 JSR 1796 ADO 1796 GMF 1797 BCC 17A1 LDA	69 CO C9 88 90 Z1• Ad (81)	3 3 3 3 3		Get Upper Word ////Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 33"? No, repeat Character Scans Get Interlace word
1794 STA 1797 PLJ 1798 JSR 1796 GMF 1799 BCC	69 CO C9 88 90 Z1•	1741		Get Upper Word ///Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 33"? No, repeat Character Scans
1794 STA 1797 PLA 1798 JSR 1796 ADO 1794 CMF	69 CO C9 88			Get Upper Word ///Character Scans 8,9 //// Add Carry: Reset Upper Address Is it "Line 33"? No, repeat Character Scans
1794 STA 1797 PLA 1798 JSR 1796 ADO	69 00	1797		Get Upper Word ////Character Scans 8,9 //// Add Carry: Reset Upper Address
1794 STA 1797 PLA 1798 JSR				Get Upper Word ////Character Scans 8,9 ////
1794 STA	20 00	1798		Get Upper Word
1794 STA		1798	80	Get Upper Word
	68			
1792 ADO			(17)	Restore L: Save carry
The same of the sa	69 39	1792		Increment L; Set Carry on V2 overflow
178F LDA	Ad (86)	178F	(17)	Get Lower address
178E PHA				Save Upper Address
→1780 BC0				No. Do next character scan
178A CM3				I= VS = 1?
11.50 425	-3. 10	11.00		instant sime with our by t
1788 ADO			OU	Increment Character Gen by 2
1782 STA			(17)	
1780 LDA	20 00			Store Upper Address ////Character Scans C-7///

NOTES: TYT6 must be connected and scan microprogram PROM IC1 must be in circuit for program to run. TYT6 length jumper must be in "64" position.

Step 1785 goes to where the upper address stored in 1787 and the lower address stored in 1789 tells it to. Values in these slots continuously change throughout the program.

Step 1781 is 80 for even fields and 88 for odd fields. Step 179E is 88 for even fields and 90 for odd fields.

Both 17AC and 17C2 require that page 17 be enabled when page 57 is addressed. This is done automatically with KIM-1 circuitry.

Note that 2K worth of contiguous memory from 0000 to 07FF is needed. This takes a KIM-1 modification. Both sets of 1k words must share a common upstream tap but be separately enabled.

Normal program horizontal frequency is 11,764,705 Hz. Vertical Prequency is 59.8712 Hz. For 60 Hz vertical use 1.002150 MHz crystal. 85 us per line; 196.5 interlaced lines per field; two fields per frame. One us character time, 160 active lines per field. Needs TV set adjustment and possible modification (hold and width).

- . Denotes a relative branch that is program length sensitive.
- () Denotes an absolute address that is program location sensitive.