

.REM _

IDENTIFICATION

PRODUCT CODE: AC-E842E-MC
PRODUCT NAME: CXLPCEO LPS11/LPS-VC MODULE
PRODUCT DATE: SEPTEMBER 1978
MAINTAINER: DEC/X11 SUPPORT GROUP

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITALS COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1973,1978 DIGITAL EQUIPMENT CORPORATION

1. ABSTRACT:

LPC IS A IOMOD THAT EXERCISES THE LPS-VC SCOPE CONTROLLER. A CONFIDENCE LOGIC TEST IS EXECUTED ON THE CONTROL/STATUS, X POSITION AND Y POSITION REGISTERS. ALL LOGIC ERRORS ARE REPORTED TO THE CONSOLE TELETYPE. THE MAJOR PORTION OF THIS MODULE IS DEFERRED TO LEVEL 0 SERVICE. A SIX LETTER MESSAGE (LPS-11) WILL BE PLOTTED ON THE SCREEN DURING EXECUTION. IF A 611/613 SCOPE IS CONNECTED, ALTERNATING CHARACTERS MAY APPEAR TO HAVE ALTERNATING INTENSITY LEVELS. WHEN A VR14 SCOPE IS CONNECTED CHANGING THE CHANNEL SWITCH TO CHANNEL ONE ONLY WILL DISPLAY "L S 1". PLACING THE SWITCH TO CHANNEL TWO ONLY WILL DISPLAY "P - 1".

2. REQUIREMENTS:

HARDWARE: LPS-11 INTERFACE WITH A LPS-VC SCOPE CONTROL INSTALLED

STORAGE:: LPC REQUIRES:
1. DECIMAL WORDS: 442
2. OCTAL WORDS: 0672
3. OCTAL BYTES: 1564

3. PASS DEFINITION:

ONE PASS OF THE LPC MODULE CONSISTS OF DISPLAYING 55,296 POINTS ON THE SCREEN. THIS MEANS THAT 55,296 DATA TRANSFERS OCCURED ON THE UNIBUS.

4. EXECUTION TIME:

VARIABLES WITH SCOPE DELAY BUT SHOULD TAKE AN AVERAGE OF THIRTY SECONDS TO COMPLETE ONE PASS. WHEN RUNNING ALONE.

5. CONFIGURATION PARAMETERS:

DEFAULT PARAMETERS:

DVA: 170416, VCT: 1, BR1: 4

REQUIRED PARAMETERS:

AT CONFIGURATION TIME THE USER MUST SPECIFY:

VCT: VECTOR ADDRESS OF LPS-VC

6. DEVICE OPTION SETUP:

A. TURN ON SCOPE POWER.

B. PLACE CHANNEL SW TO 1 & 2 (IF VR14)

7. MODULE OPERATION:

7.1 TEST SEQUENCE:

A. START: USING THE DEVICE ADDRESS, THIS SECTION OF CODE, DETERMINES THE CONTROL, X AND Y POSITION ADDRESSES, AND VECTORS.

B. TESTVC: THIS SECTION OF CODE PREFORMS A CONFIDENCE REGISTER TEST OF THE CONTROL, X AND Y AXIS REGISTERS.

C. PRIME: IN THIS SECTION, THE X AXIS, Y AXIS AND CONTROL REGISTERS ARE LOADED. THE SCOPE IS ENABLED AND AN "EXIT" RETURN TO THE MONITOR.

D. LPSVC: UPON A SCOPE INTERRUPT, THE PROGRAM WILL RETURN TO THIS CODE. ENTER DEFERRED SERVICE MODE AND TEST FOR A MODE FLAG. IF NO MODE FLAG, REPORT IT AS AN ERROR.

E. LPSVCA: THRU CHAR13: THIS SECTION SELECTS
THE PROPER POINTS TO BE INTENSIFIED
ON THE SCREEN.

F. CHAR11: IN THIS CODE, THE COLOR AND
CHANNEL BITS ARE ALTERNATED
TO DISPLAY EACH CHANNEL AND COLOR
IF A 611/613 SCOPE IS CONNECTED
ALTERNATING CHARACTERS WILL HAVE
ALTERNATING INTENSITY LEVELS.

G. CHAR20: ENDIT CALL TO THE MONITOR.

8. OPERATOR OPTIONS:

A. LOCATION (VCPASS) CAN BE MODIFIED TO VARY THE NO.
LOOPS THRU TEST BEFORE END OF PASS IS REPORTED.

9. NON-STANDARD PRINTOUTS:

NONE: ALL PRINTOUTS HAVE THE STANDARD FORMAT.

```
174  
175  
176 ;LPS-11 VC DFC/X11 EXERCISER MODULE  
177 000000 IOMOD <LPCE >170416,144,2000,47  
178 000000 MODUL 140000,LPCE 170416,144,2000,47  
179 ; TITLE LPCE DEC/X11 SYSTEM EXERCISER MODULE  
180 ; DDXCUM VERSION 6 23-MAY-78  
181 ; LIST BIN  
182 ;*****  
183 000000 BEGIN:  
184 000000 MODNAM: .ASCII /LPCE / ;MODULE NAME  
185 000005 XFLAG: .BYTE OPEN ;USED TO KEEP TRACK OF WBUFF USAGE  
186 000006 ADDR: 170416 ;LIST DEVICE ADDR  
187 000010 VECTOR: 1+0 ;LIST DEVICE VECTOR.  
188 000012 BPI: .BYTE PRTY4+0 ;LIST BR LEVEL.  
189 000013 BR2: .BYTE PRTY+0 ;2ND BR LEVEL.  
190 000014 DVTD1: +1 ;DEVICE INDICATOR 1.  
191 000016 SR1: OPEN ;SWITCH REGISTER 1  
192 000020 SR2: OPEN ;SWITCH REGISTER 2  
193 000022 SR3: OPEN ;SWITCH REGISTER 3  
194 000024 SR4: OPEN ;SWITCH REGISTER 4  
195 ;*****  
196 000026 STAT: 140000 ;STATUS WORD  
197 000030 INIT: START ;MODULE START ADDR.  
198 000032 SPOINT: MODSP ;MODULE STACK POINTER.  
199 000034 PASCNT: 0 ;PASS COUNTER  
200 000036 ICNT: 2000 ;# OF ITERATIONS PER PASS=2000  
201 000040 ICOUNT: 0 ;LOC TO COUNT ITERATIONS  
202 000042 SOFCNT: 0 ;LOC TO SAVE TOTAL SOFT ERRORS  
203 000044 HRDCNT: 0 ;LOC TO SAVE TOTAL HARD ERRORS  
204 000046 SOFPAS: 0 ;LOC TO SAVE SOFT ERRORS PER PASS  
205 000050 HRDPAS: 0 ;LOC TO SAVE HARD ERRORS PER PASS  
206 000052 SVSCNT: 0 ;# OF SVS ERRORS ACCUMULATED  
207 000054 RANNUM: 0 ;HOLDS RANDNO # WHEN RAND MACPG IS CALLED  
208 000056 CONFIG: 0 ;RESERVED FOR MONITOR USE  
209 000056 RES1: 0 ;RESERVED FOR MONITOR USE  
210 000060 RES2: 0 ;RESERVED FOR MONITOR USE  
211 000062 SVR0: OPEN ;LOC TO SAVE R0.  
212 000064 SVR1: OPEN ;LOC TO SAVE R1.  
213 000066 SVR2: OPEN ;LOC TO SAVE R2.  
214 000070 SVR3: OPEN ;LOC TO SAVE R3.  
215 000072 SVR4: OPEN ;LOC TO SAVE R4.  
216 000074 SVR5: OPEN ;LOC TO SAVE R5.  
217 000076 SVR6: OPEN ;LOC TO SAVE R6.  
218 000100 CSRA: OPEN ;ADDR OF CURRENT CSR.  
219 000102 SBADR: ;ADDR OF GOOD DATA, OR  
220 000102 ACSR: OPEN ;CONTENTS OF CSR.  
221 000104 WASADR: ;ADDR OF BAD DATA, OR  
222 000104 ASAT: OPEN ;STATUS REG CONTENTS.  
223 000106 ERRTYP: OPEN ;TYPE OF ERROR  
224 000106 ASB: OPEN ;EXPECTED DATA.  
225 000110 AWAS: OPEN ;ACTUAL DATA.  
226 000112 RSTRT: RSTRT ;RESTART ADDRESS AFTER END OF PASS  
227 000114 WDMTO: OPEN ;WORDS TO MEMORY PER ITERATION  
228 000116 WDFR: OPEN ;WORDS FROM MEMORY PER ITERATION  
229 000120 INTR: OPEN ;# OF INTERUPTS PER ITERATION
```

```
230 000122 IDNUM: 47 ;MODULE IDENTIFICATION NUMBER=47  
231 .REPT SPSIZ ;MODULE STACK STARTS HERE.  
232 .NLIST  
233 .WORD 0  
234 .LIST  
235 .ENDR  
236 000224 MODSP: ;*****  
237 ;*****  
238
```

```
239  
240 ;LPS-VC OPERATOR CHANGEABLE LOCATIONS  
241  
242  
243 ; COMMON LPS-VC DEVICE ADDRESSES  
244  
245  
246 000224 170416 VCSTAT: 170416 ;SCOPE STATUS REGISTER  
247 000226 170420 VCXREG: 170420 ;SCOPE X AXIS REGISTER  
248 000230 170422 VCYREG: 170422 ;SCOPE Y AXIS REGISTER  
249  
250 ;COMMON LPS-VC DEVICE VECTOR  
251  
252 000232 000320 VCIV: 320 ;SCOPE INTERRUPT VECTOR  
253 000234 000322 VCIVS: 322  
254  
255 ;NOW SFT UP THE ADDRESS AND VECTOR DISPATCH LOC.  
256  
257 START: MOV ADDR,VCSTAT ;LOAD DEVICE ADDRESS  
258 MOV ADDR,VCXREG ;18 INTERRUPTS/ITERATION  
259 ADD #2,VCXREG ;6 WDS FROM PEM  
260 MOV ADDR,VCYREG  
261 ADD #4,VCYREG  
262 MOV VECTOR,VCIV  
263 MOV VECTOR,VCIVS  
264 ADD #2,VCIVS  
265 MOV VCSTAT,CSRA  
266 MOV #18,INTC  
267 MOV #6,WDFR  
268
```

```
269 ;LPS-VC LOGIC TEST  
270  
271 000340 005077 177660 RESTR: CLR @VCSTAT ;CLEAR STATUS  
272 000344 005077 177656 CLR @VCXREG ;CLEAR X  
273 000350 005077 177654 CLR @VCYREG ;CLEAR Y  
274 000354 005067 177524 CLR ASTAT ;CLEAR POINTER  
275  
276 000360 005777 177642 TST @VCXREG ;TEST X AXIS  
277 000364 001100 BNE IS ;BR IF SET  
278  
279 000366 012777 002525 177632 MOV #2525,@VCXREG ;LOAD X  
280 000374 012767 002525 177502 MOV #2525,ASTAT ;LOAD POINTER  
281 000402 022777 002525 177616 CMP #2525,@VCXREG ;TEST X  
282 000410 001066 BNE IS ;BR IF ERROR  
283  
284 000412 012777 005252 177606 MOV #5252,@VCXREG ;LOAD X  
285 000420 012767 005252 177456 MOV #5252,ASTAT ;LOAD POINTER  
286 000426 022777 005252 177572 CMP #5252,@VCXREG ;TEST X  
287 000434 001054 BNE IS ;BR IF ERROR  
288  
289 000436 005777 177566 TST @VCYREG ;TEST Y AXIS  
290 000442 001071 BNE IS ;BR IF ERROR  
291  
292 000444 012777 002525 177556 MOV #2525,@VCYREG ;LOAD Y  
293 000452 012767 002525 177424 MOV #2525,ASTAT ;LOAD POINTER  
294 000460 022777 002525 177542 CMP #2525,@VCYREG ;TEST Y  
295 000466 001057 BNE IS ;BR IF ERROR  
296  
297 000470 012777 005252 177532 MOV #5252,@VCYREG ;LOAD Y  
298 000476 012767 005252 177400 MOV #5252,ASTAT ;LOAD POINTER  
299 000504 022777 005252 177516 CMP #5252,@VCYREG ;TEST Y  
300 000512 001045 BNE IS ;BR IF ERROR  
301  
302 000514 012777 002324 177502 MOV #2324,@VCSTAT ;LOAD STATUS  
303 000522 012767 002324 177354 MOV #2324,ASTAT ;LOAD POINTER  
304 000530 022777 002324 177466 CMP #2324,@VCSTAT ;TEST STATUS  
305 000536 001053 BNE IS ;BR IF ERROR  
306  
307 000540 012777 005212 177456 MOV #5212,@VCSTAT ;LOAD STATUS  
308 000546 012767 005212 177330 MOV #5212,ASTAT ;LOAD POINTER  
309 000554 022777 005212 177442 CMP #5212,@VCSTAT ;TEST STATUS  
310 000562 001041 BNE IS  
311 000564 000460 BR PRIME ;START DYNAMIC TEST
```

```
312  
313  
314  
315 000566 017767 177434 177306 1S: MOV @VCXREG,ACSR ;LOAD CONTENTS  
316 000574 016767 177426 177276 MOV @VCXREG,CSRA ;LOAD ADDRESS  
317 000607 005077 177416 177236 CLR @VCSTAT ;ENSURE CLEAR STATUS  
318 000606 012767 000025 177272 MOV #25,ERRTYP ;BIT STUCK IN REGISTER  
319 ***** ;*****  
320 000614 104405 000000 000000 HRDRS,BEGIN,NULL ;X AXIS REGISTER BIT IN ERROR  
321 ***** ;*****  
322 ENDS,BEGIN ;  
323  
324 000622 104410 000000 000000  
325  
326 000626 017767 177376 177246 2S: MOV @VCYREG,ACSR ;LOAD CONTENTS  
327 000634 016767 177370 177236 MOV @VCYREG,CSRA ;LOAD ADDRESS  
328 000642 005077 177356 177232 CLR @VCSTAT ;ENSURE CLEAR STATUS  
329 000646 012767 000025 177232 MOV #25,ERRTYP ;BIT STUCK IN Y AXIS REGISTER  
330 ***** ;*****  
331 HRDRS,BEGIN,NULL ;Y AXIS REGISTER BIT IN ERROR  
332 ***** ;*****  
333 ENDS,BEGIN ;  
334  
335 000666 017767 177332 177206 3S: MOV @VCSTAT,ACSR ;LOAD CONTENTS  
336 000674 016767 177324 177176 MOV @VCSTAT,CSRA ;LOAD ADDRESS  
337 000702 005077 177316 177172 CLR @VCSTAT ;ENSURE CLEAR STATUS  
338 000706 012767 000025 177172 MOV #25,ERRTYP ;BIT STUCK IN C/S REG  
339 ***** ;*****  
340 HRDRS,BEGIN,NULL ;CONTROL/STATUS BIT IN ERROR  
341 ***** ;*****  
342 ENDS,BEGIN ;  
343  
344 ; PRIMER ROUTINE  
345 PRIME: CLR @VCSTAT ;ENSURE CLEAR STATUS  
346 MOV @LPSVC,@VCIV ;SET UP LPSVC VECTOR  
347 MOVB BR,@VCIVS ;SET UP  
348 MOV #101,@VCSTAT ;START DISPLAY AND INTERRUPT ENABLE  
349 EXITS,BEGIN ;EXIT TO MONITOR. MODULE WAIT FOR INTERRUPT.
```

```
350 ;LPS VC DISPLAY TEST  
351 ;DISPLAY "LPS-11" ON THE SCOPE  
352  
353 000760 LPSVC:-----  
354 @IRQS,BEGIN,IS ; GUEUE UP TO CONTINUE AT IS AND RTI  
355 -----  
356 000760 000004 000000 000766 1S: ;STB @VCSTAT  
357 000766 105777 177232 BMI @LPSVCA ;LOAD VALUE  
358 000772 100415 177224 177100 MOV @VCSTAT,ACSR ;LOAD VALUE  
359 000774 017767 177216 177100 CLR @VCSTAT ;NOT READY  
360 001002 005077 177216 177072 MOV #6,ERRTYP ;NOT READY  
361 001006 012767 000006 177072 ***** ;*****  
362 HRDRS,BEGIN,NULL ; NO DISPLAY READY FLAG  
363 ***** ;*****  
364 ENDS,BEGIN ;  
365  
366 001026 012767 002000 000502 LPSVCA: MOV #2000,XPOS ;LOAD X AXIS  
367 001034 012767 005000 000476 MOV #5000,YPOS ;LOAD Y AXIS  
368 001042 012767 000006 000472 MOV #6,CNTP ;SET UP FOR 6 CHARACTERS  
369 001050 012767 001470 000466 TXT1: MOV @TEXT,@PTR ;TEXT LPS-11  
370 001056 012767 001204 177146 MOV @CHAR3,@VCIV ;LOAD INTERRUPT VECTOR  
371 001064 017767 000454 000462 MOV @PTR,@AR2 ;LOAD  
372  
373 ;PLOT CHARACTER  
374  
375 CHAR: MOV YPOS,YPT ;INIT POINT  
376 @IC #16,@VCSTAT  
377 MOV XPOS,@VCXREG  
378 MOV YPOS,@VCYREG  
379 BIS #10,@VCSTAT ;LOAD STATUS  
380 MOV #5,AR0 ;MATRIX COUNT <ROW>  
381 MOV #7,AR1 ;MATRIX COUNT <COLUMN>  
382 CHAR1: MOVB @AR2,AR3 ;GET CHARACTER  
383 INCL AR2  
384 ROLB AR3  
385 BPL CHAR13 ;LOAD X  
386 MOV XPOS,@VCXREG  
387 MOV YPOS,@VCYREG  
388 EXITS,BEGIN ;EXIT TO MONITOR. MODULE WAIT FOR INTERRUPT.  
389  
390 CHAR3:-----  
391 @IRQS,BEGIN,IS ; GUEUE UP TO CONTINUE AT IS AND RTI  
392 -----  
393 001204 000004 000000 001212 1S: ;STB @VCSTAT  
394 001212 105777 177006 BMI @CHAR13 ;LOAD VALUE  
395 001216 100415 177000 176654 MOV @VCSTAT,ACSR ;LOAD VALUE  
396 001226 005077 176772 176654 CLR @VCSTAT ;NOT READY  
397 001232 012767 000006 176646 MOV #6,ERRTYP ;NOT READY  
398 ***** ;*****  
399 HRDRS,BEGIN,NULL ; NO DISPLAY READY  
400 ***** ;*****  
401 ENDS,BEGIN ;  
402 001246 104410 000000 000000
```

```

403
404 001252 062767 000070 000260 CHAR13: ADD #70,YPOS ;NEXT POINT
405 001260 05267 000266 ;ALL POINTS IN THE COLUMN
406 001264 001534 RNE CHAR2
407 001266 016767 000254 000244 MOV YPT,YPOS ;LOAD NEXT COLUMN
408 001274 062767 000070 000234 ADD #70,XPOS ;ADD SCALCE
409 001302 05267 000242 INC AAR0 ;DONE ALL COLUMN
410 001306 001513 RNE CHAR1
411 001310 062767 000070 000220 ADD #70,XPOS ;YES, NEXT CHARACTER
412 001316 062767 000002 000240 ADD #2,PNTN
413 001324 032777 000400 176672 BIT #BIT9,@VCSTAT ;TEST COLOR
414 001332 001004 RNE IS
415 001334 052777 001400 176662 BIS #BIT8|BIT9,@VCSTAT
416 001342 000403 BR CHAR11
417 001344 042777 001400 176652 BIC #BIT8|BIT9,@VCSTAT
418 001352 015777 001364 176652 CHAR11: MOV #CHAR4,@VCIV
419 001360 104400 000000 EXITS,BEGIN ;EXIT TO MONITOR. MODULE WAIT FOR INTERRUPT.
420
421 001364 CHAR4:
422
423 001364 000004 000000 001372 ;-----
424 ;IRQS,BEGIN,IS ; QUEUE UP TO CONTINUE AT IS AND PTI
425
426 001372 105777 176626 1S:
427 ;STB @VCSTAT
428 RMI CHAR20
429 001400 016767 176620 176472 MOV VCSTAT,CSRA ;LOAD DEVICE ADDRESS
430 001406 017767 176612 176466 MOV @VCSTAT,ACSR ;LOAD VALUE
431 001414 050777 176604 CLR @VCSTAT
432 001420 012767 000006 176460 MOV #6,ERRTYP ;NOT READY
433 ;*****
434 001426 104405 000000 000000 HRDR$,BEGIN,NULL ;NO DISPLAY READY AFTER COLOR CHANGE
435 ;*****
436 001434 104410 000000 ENDS,BEGIN ;

```

```

435
436 001440 005367 000076 CHAR20: DEC CNTR
437 001444 001007 RNE 2S
438 001446 042777 000002 176550 BIC #2,@VCSTAT
439 001454 104413 000000 ENDS,BEGIN ;SIGNAL END OF ITERATION.
440
441 001460 000167 177342 JMP LPSVCA ;MONITOR SHALL TEST END OF PASS
442
443 001464 000167 177366 2S: JMP TXT1
444
445 ;TEXT FOR THE LPSVC SCOPE OPTION
446 ;TEXT = "LPS-11"
447
448 TEXT: L
449 P
450 001470 001504 S
451 001472 001511 DASH
452 001474 001516 NI
453 001476 001523 NI
454 001500 001530
455 001502 001530
456
457 001504 177 100 L: .BYTE 177,100,100,100,100
458 001511 177 011 011 P: .BYTE 177,11,11,11,6
459 001514 011 006 111 S: .BYTE 46,111,111,111,62
460 001516 046 111
461 001521 111 062
462 001523 000 010 010 DASH: .BYTE 0,10,10,10,0
463 001526 010 000
464 001530 000 177 N1: .BYTE 0,102,177,100,0
465 001533 100 000
466
467 001536 .EVEN
468
469 001536 000000 XPOS: 0
470 001540 000000 YPOS: 0
471 001542 000000 CNTR: 0
472 001544 000000 PNTN: 0
473 001546 000000 YPT: 0
474 001550 000000 AAR0: 0
475 001552 000000 AAR1: 0
476 001554 000000 AAR2: 0
477 001556 000000 AAR3: 0
478 001560 000000 TEMP1: 0
479 001562 000000 TEMP2: 0
480
481 000001 .END

```

AARO	001550R	381*	409*	474#																
AAR1	001552R	382*	405*	475#																
AAR2	001554R	372*	383	384#	476#															
AAR3	001556R	383*	385*	477#																
ACSR	000102R	270#	314*	323#	332*	359*	396*	428*												
ADDR	000066R	186#	257	258	260															
ADDR22=	001000	224#																		
ASB	000106R	224#																		
ASTAT	000104R	222#	274*	280*	285*	293*	298*	303*	308*											
AWAS	000110R	225#	319	321	329	330	337	339	348	355	363	365	389	392						
BEGIN	000000R	183#	400	402	419	423	432	434	440											
BIT0	000001	238#																		
BIT1	000002	240#																		
BIT10	002006	238#																		
BIT11	004000	240#																		
BIT12	010000	238#																		
BIT13	020000	240#																		
BIT14	040000	238#																		
BIT15	100000	240#																		
BIT2	000004	238#																		
BIT3	000010	240#																		
BIT4	000020	238#																		
BIT5	000040	240#																		
BIT6	000100	238#																		
BIT7	000200	240#																		
BIT8	000400	238#			413	415	417													
BIT9	001000	240#			415	417														
BREAKS	104407	238#																		
BS1	000102R	188#	345																	
BR2	00013R	188#																		
BTODS	104421	238#																		
CDATAS	104412	238#																		
CHAR1	001072R	376#																		
CHAR11	001352R	416	410	418#																
CHAR13	001252R	386	404#																	
CHAR2	001420R	452#																		
CHAR20	001440R	452#																		
CHAR3	001204R	371																		
CHAR4	001364R	418																		
CHAR5	001422R	369#																		
CONF1G	000056R	206#																		
CSRA	000100R	218#																		
DASH	001523R	452#	265*	315*	324*	333*	427*													
DATES	104415	238#																		
DATER5	104404	238#																		
DVID1	000014R	190#																		
END1	104413	238#																		
END15	104410	238#	440																	
ERR1YP	000106R	223#	371*	326*	335*	361*	402	434												
EXITS	104400	238#	348	389	419															
GETP1S	104414	238#																		
GWBUS	104414	238#																		
HRDCNT	000044R	203#																		

HRDRS	104405	238#	319	328	337	363	400	432													
HRDPAS	00036R	200#																			
ICONT	000036R	201#																			
ICOUNT	000040R	201#																			
IDNUM	000122R	230#																			
INIT	000000	197#																			
INTR	000120R	229#																			
L	001504R	449	266*																		
LPSVC	000760R	344	456#																		
LPSVCA	001026R	344	353#	442																	
MODNAM	000000R	184#																			
MODSP	000224R	198#	236#																		
MSCS	104402	238#																			
MSCS2	104402	238#																			
MSCS3	104401	238#																			
NULL	000000	238#	319	328	337	363	400	432													
NI	001530R	453	454	464#																	
OPEN	000000	185	191	192	193	194	211	212	213	214	215	216	217	216							
		220	222	224	225	227	228	229	238#												
OTOAS	104420	238#																			
P	001511R	450#	458#																		
PASCNT	000034R	180#																			
PIRQS	000004	238#																			
PNTR	001544R	370#	355	392	412*	423	472#														
POPSP	005726	238#																			
POPSP2	022526	238#																			
PRIME	000726R	311	343#																		
PRTY	000000	189	238#																		
PRTY0	000000	238#																			
PRTY1	000040	198#																			
PRTY2	000100	238#																			
PRTY3	000140	238#																			
PRTY4	000200	188#																			
PRTY5	000240	238#																			
PRTY6	000300	238#																			
PRTY7	000340	238#																			
PS	177776	238#																			
PSW	177776	238#																			
PUSH	005746	238#																			
PUSH2	024646	238#																			
RANDS	104417	238#																			
RANRND	00054R	217#																			
RESTR1	000340R	226	271#																		
RES1	000056R	209#																			
RES2	000060R	210#																			
RSTR1	000112R	226#																			
S	001516R	451#	460#																		
SBADR	000102R	219#																			
SDFCNT	000042R	202#																			
SDFERS	104406	238#																			
SDFPAS	000046R	204#																			
SPOINT	000032R	198#																			
SP1Z	000040	198#	231																		
SR1	000016R	192#																			
SR2	000020R	192#			</																

