

MAINTAIN III

TYTEST

1 * THIS IS A COPYRIGHTED PROGRAM. COPYRIGHT 1970 BY VARIAN DATA MACHINES
2 * V.D.M. PART NO. 92L0107-005E

RELEASED 7/10/74

620 TELETYPE TEST PROGRAM

10 *
11 *
12 *
13 *
14 *
15 *
16 *
17 *
18 *
19 *
20 *
21 *
22 *
23 *
24 *
25 *
26 *
27 *
28 *
29 *
30 *
31 *
32 *
33 *
34 *
35 *
36 *
37 *
38 *
39 *
40 *
41 *
42 *
43 *
44 *
45 *
46 *
47 *
48 *
49 *
50 *
51 *
52 *
53 *
54 *
55 *
56 *
57 *
58 *
59 *
60 *
61 *
62 *
63 *
64 *
65 *
66 *
67 *
68 *
69 *
70 *
71 *
72 *
73 *
74 *
75 *
76 *
77 *
78 *
79 *
80 *
81 *
82 *
83 *
84 *
85 *
86 *
87 *
88 *

THIS TEST PROGRAM IS A PART OF THE SIX TWENTY
TEST EXECUTIVE PROGRAM SYSTEM (STEPS)

THE TTY TEST IS DESIGNED TO PROVIDE A SET OF ROUTINES
TO TEST THE OPERATIONAL STATUS OF THE TELETYPE UNIT. THE PROGRAM
IS APPLICABLE TO VDM-MODIFIED TELETYPE MODELS 33 ASR, 35 ASR,
AND 35 KSR.

* AREAS RESERVED BY EXECUTIVE *

ORG 0
JMP EXECUTIVE
ORG 040
JMPM POWER DOWN ROUTINE
JMPU POWER UP ROUTINE

NOTE: THE TEST EXECUTIVE ALSO RESERVES LOCATIONS 0400 TO 0477
FOR A POINTER TABLE TO STANDARD ROUTINES, AND AS AN AREA
FOR EXECUTIVE DATA. ALL TEST PROGRAMS WORKING WITH THE
EXECUTIVE MUST PRESERVE THIS BLOCK.
STANDARD ROUTINES WILL BE CALLED INDIRECTLY THRU
THIS TABLE

000400 A
000403 A
000416 A

000500 006010 A
000501 000224 A
000502 002000 A
000503 100400 A
000504 006010 A
000505 000223 A
000506 002000 A
000507 100400 A
000510 006010 A
000511 000201 A
000512 002000 A
000513 100400 A
000514 006030 A
000515 000675 A
516 002000 A

25 DU1C SET 0400 (OUTA)
26 DUMG SET 0403 (OUTD)
27 IOCT SET 0416 (INPG)

79 ORG 0500
80 *
81 TKCP LDAI 0224 PNCH OFF
82 CALL* DU1C
83 LDAI 0223 RDR OFF
84 CALL* DU1C
85 LDAI 0201 PRINT ENABLE
86 CALL* DU1C
87 TTPI LDXI HDG1 TAPE LOADED
88 CALL* DUMG

000517	100403	A					01 00089	
000520	006030	A	89	TRDA	LDXI	HDG2	DA=?	01 00090
000521	000716	A	90		CALL*	DUMG		O
000522	002000	A						
000523	100403	A	91	TIDA	CALL*	IDCT	INPUT DA END WITH PERIOD	01 00092
000524	002000	A						
000525	100416	A	92		JMP	TSSR	RESET SSS	01 00093
000526	001000	A						
000527	000655	A	93		JMP	TRDA	BACKSLASH	01 00094
000530	001000	A						
000531	000520	A	94		JMP	*+2	*	
000533	000534	A						
000534	006030	A	95	*	NORMAL RETURN FROM INPG			01 00095
			96		LDXI	\$TTY		01 00096
000535	002644	A						
000536	055000	A	97		STA	0,1	STORE DA	01 00097
000537	006010	A	98	TATT	LDAI	0207	RING BELL ON APPROPRIATE TTY	01 00098
000540	000207	A						
000541	002000	A	99		CALL	OUTA	AND INITIALIZE APPROPRIATE TTY	01 00099
000542	002613	A	100		LDAI	0224	PUNCH OFF	01 00100
000543	006010	A						
000544	000224	A	101		CALL	OUTA		01 00101
000545	002000	A						
000546	002613	A	102		LDAI	0223	RDR OFF	01 00102
000547	006010	A						
000550	000223	A	103		CALL	OUTA		01 00103
000551	002000	A						
000552	002613	A	104		LDAI	0201	PRINT ENABLE	01 00104
000553	006010	A						
000554	000201	A	105		CALL	OUTA		01 00105
000555	002000	A						
000556	002613	A	106		CALL	OUTC	CR/LF	01 00106
000557	002000	A						
000560	003210	A	107		LDA	\$TTY		
000561	012644	A	108		DRAI	0102500		01 00107
000562	006110	A						01 00108
000563	102500	A						
000564	050565	A	109		STA	*+1		01 00109
000565	102500	A	110		CIA	0	CLEAR TTY INPUT BUFFER	01 00110
000566	006030	A	111	TRID	LDXI	HDG3	TEST ID=?	01 00111
000567	000726	A						
000570	002000	A	112		CALL	OUTD		01 00112
000571	003243	A						
000572	002000	A	113	TIID	CALL	INPE	INPUT ID END WITH PERIOD	01 00113
000573	003007	A						
000574	001000	A	114		JMP	TRSS	RESET SSS	01 00114
000575	000665	A						
000576	001000	A	115		JMP	TRID	BACKSLASH	01 00115
000577	000566	A						
000600	001000	A	116		JMP	TRID	BACKARROW	01 00116
000601	000566	A						O
000602	051010	A	117	*	NORMAL RETURN FROM INPE			
000603	002000	A	118		STA	STID		01 00117
000604	003047	A	119		CALL	INPF	, OR .	01 00118
000605	001000	A	120		JMP	TATT	EXIT TO KEYBOARD CONTROL PROGRAM	01 00119
000606	000537	A						
000607	001000	A	121		JMP	TRID	BACKSLASH	01 00121
000610	000566	A						
000611	001000	A	122		JMP	TRID	BACKARROW	01 00122
000612	000566	A						
000613	001000	A	123		JMP	*+2	,	01 00123
000614	000615	A						
000615	002000	A	124	*	NORMAL RETURN FROM INPF			01 00124
			125		CALL	OUTC		01 00125
000616	003210	A						
000617	011010	A	126		LDA	STID		01 00126
000620	141002	A	127		SUB	KC	KEYBD CHAR	01 00127
000621	001010	A	128		JAZ	TKCT		01 00128
000622	001011	A						
000623	011010	A	129		LDA	STID		01 00129
000624	141003	A	130		SUB	KE		01 00130
000625	001010	A	131		JAZ	TKET		01 00131
000626	001233	A						
000627	011010	A	132		LDA	STID		01 00132
000630	141004	A	133		SUB	PR	PNCH/RDR	01 00133
000631	001010	A	134		JAZ	TPRT		01 00134
000632	001445	A						
000633	011010	A	135		LDA	STID		01 00135
000634	141005	A	136		SUB	PS		01 00136
000635	001010	A	137		JAZ	TPST		01 00137
000636	001326	A						
000637	011010	A	138		LDA	STID		01 00138
000640	141006	A	139		SUB	PT		01 00139
000641	001010	A	140		JAZ	TPTT		01 00140
000642	001261	A						
000643	011010	A	141		LDA	STID		01 00141
000644	141007	A	142		SUB	RT		01 00142
000645	001010	A	143		JAZ	TRTT		01 00143
000646	002120	A						
000647	006030	A	144		LDXI	HDG4	INVALID TEST ID	01 00144
000650	000743	A						
000651	002000	A	145		CALL	OUTD		01 00145
000652	003243	A						O

		MAINTAIN III		TYTEST	PAGE	3
000653	001000	A 146	JMP	TRID	01	00146
000654	000566	A 147	TSSR	LDXI HDG5	01	00147
000655	000600	A 148	CALL*	DUMG	01	00148
000656	000762	A 149	JSS3 *		01	00149
000660	100403	A 150	JMP	TRDA	01	00150
000661	001400	A 151	TRSS	LDXI HDG5	01	00151
000662	000661	A 152	CALL*	DUMG	01	00152
000663	001000	A 153	JSS3 *		01	00153
000664	000520	A 154	JMP	TRID	01	00154
000665	000600	A 155 *	MESSAGE TABLE		01	00155
000675	106612	A 156	HDG1	DATA 0106612,'THE TELETYPE TEST IS LOADED',0	01	00156
000676	152310	A				
000677	142640	A				
000700	152305	A				
000701	146305	A				
000702	152331	A				
000703	150305	A				
000704	120324	A				
000705	142723	A				
000706	152240	A				
000707	144723	A				
000710	120314	A				
000711	142701	A				
000712	142305	A				
000713	142240	A				
000714	106612	A				
000715	000000	A				
000716	106612	A 157	HDG2	DATA 0106612,'TELETYPE DA=',0	01	00157
000717	152305	A				
000720	146305	A				
000721	152331	A				
000722	150305	A				
000723	120304	A				
000724	140625	A				
000725	000000	A				
000726	106612	A 158	HDG3	DATA 0106612,'TTY TEST IDENTIFIER =',0	01	00158
000727	152324	A				
000730	154640	A				
000731	152305	A				
000732	151724	A				
000733	120311	A				
000734	142305	A				
000735	147324	A				
000736	144706	A				
000737	144705	A				
000740	151240	A				
000741	136640	A				
000742	000000	A				
000743	106612	A 159	HDG4	DATA 0106612,'INVALID TEST IDENTIFIER',0	01	00159
000744	144716	A				
000745	153301	A				
000746	146311	A				
000747	142240	A				
000750	152300	A				
000751	151724	A				
000752	120311	A				
000753	142305	A				
000754	147324	A				
000755	144706	A				
000756	144705	A				
000757	151240	A				
000760	106612	A				
000761	000000	A				
000762	106612	A 160	HDG5	DATA 0106612,'PLEASE RESET SENSE SWITCH 3',0	01	00160
000763	150314	A				
000764	142701	A				
000765	151705	A				
000766	120322	A				
000767	142723	A				
000770	142724	A				
000771	120323	A				
000772	142716	A				
000773	151705	A				
000774	120323	A				
000775	153711	A				
000776	152303	A				
000777	144240	A				
001000	131640	A				
001001	000000	A 161 *	TABLE		01	00161
001002	145703	A 162	KC	DATA 0145703	01	00162
001003	145705	A 163	KE	DATA 0145705	01	00163
001004	150322	A 164	PR	DATA 0150322	01	00164
001005	150323	A 165	PS	DATA 0150323	01	00165
001006	150324	A 166	PT	DATA 0150324	01	00166
001007	151324	A 167	RT	DATA 0151324	01	00167

PAGE 4

MAINTAIN III

TYTEST

001010	000000	A	168	STID	DATA	0		01 00168
			169	*				01 00169
			170	*	TELETYPE KEYBOARD CHARACTER TEST			01 00170
			171	*				01 00171
001011	002000	A	172	TKCT	CALL	DUTC		01 00172
001012	003210	A	173	LDXI	TKK1		PRINT L/C CHAR LINE	01 00
001013	006030	A	174	CALL	DUTD			01 00174
001014	001126	A	175	LDXI	TKK1		FIRST L/C CHAR	01 00175
001015	002000	A	176	LDDBI	42		#L/C CHAR	01 00176
001020	001126	A	177	TKC2	CALL	TCS1	INPUT CHAR SUBR	01 00177
001023	002000	A	178	TKC3	LDA	TKW2	ERROR CHAR	01 00178
001024	001071	A	179	JMP	*+3			01 00179
001025	011232	A	180	LDA	TKW1		VALID CHAR	01 00180
001026	001000	A	181	CALL	DUTA		PRINT CHAR	01 00181
001027	001031	A	182	IXR				01 00182
001034	005322	A	183	DBR				01 00183
001035	001020	A	184	JBZ	TKC4		LAST CHAR INPUT?	01 00184
001036	001041	A	185	JMP	TKC2		NOT LAST	01 00185
001037	001000	A	186	TKC4	CALL	DUTC		01 00186
001042	003210	A	187	LDXI	TKK2		PRINT U/C CHAR LINE	01 00187
001044	001202	A	188	CALL	DUTD			01 00188
001046	003243	A	189	LDXI	TKK2		FIRST U/C CHAR	01 00189
001047	006030	A	190	LDDBI	21		# U/C CHAR	01 00190
001052	000025	A	191	TKC5	CALL	TCS1	INPUT CHAR SUBR	01 00191
001054	001071	A	192	TKC6	LDA	TKW2	ERROR CHAR	01 00192
001055	011232	A	193	JMP	*+3			01 00193
001056	001000	A	194	LDA	TKW1		VALID CHAR	01 00194
001057	001061	A	195	CALL	DUTA		PRINT CHAR	01 00195
001060	011231	A	196	IXR				01 00196
001064	005322	A	197	DBR				01 00197
001065	001020	A	198	JBZ	TKCT		LAST CHAR INPUT?	01 00198
001066	001011	A	199	JMP	TKC5		NOT LAST	01 00
001070	001053	A	200	*	INPUT CHARACTER SUBROUTINE			01 00200
001071	000000	A	201	TCS1	ENTR			01 00201
001072	015000	A	202	LDA	0:1			01 00202
001073	051231	A	203	STA	TKW1		SAVE EXPECTED CHAR	01 00203
001074	002000	A	204	CALL	INPA		INPUT CHARACTER	01 00204
001075	002610	A	205	JMP	TATT		EXIT TO KEYBOARD CONTROL PROGRAM	01 00205
001077	000537	A	206	*	NORMAL RETURN FROM INPA			01 00206
001100	006140	A	207	SUBI	0240			01 00207
001101	000240	A	208	JAZ*	TCS1		SPACE ?	01 00208
001102	001010	A	209	ADDI	0240		NOT SPACE - RESTORE CHAR	01 00209
001103	01071	A	210	ERA	TKW1			01 00210
001104	006120	A	211	JAZ	CS01		VALID CHAR ?	01 00211
001105	000240	A	212	ERA	TKW1		INVALID - RESTORE CHAR	01 00212
001106	131231	A	213	STA	TKW2		SAVE INVALID CHAR	01 00213
001107	001010	A	214	LDAI	0207			01 00214
001109	001121	A	215	CALL	DUTA		RING BELL - OPERATOR ATTN!	01 00215
001110	131231	A	216	JMP	TCS1+3		RE-TYPE CHAR (OR SPACE BAR)	01 00216
001120	001074	A	217	CS01	INR	TCS1		01 00217
001121	041071	A	218	INR	TCS1			01 00218
001122	041071	A	219	INR	TCS1			01 00219
001123	041071	A	220	JMP*	TCS1			01 00220
001124	001000	A	221	*	DATA TABLE			01 00221
001125	101071	A	222	TKK1	DATA	0261,0262,0263,0264,0265,0266,0267,0270,0271,0260		01 00222
001130	000263	A	223	DATA	0272,0255,0321,0327,0305,0322,0324,0331,0325,0311			01 00

001141	000255	A							
001142	000321	A							
001143	000327	A							
001144	000305	A							
001145	000322	A							
001146	000324	A							
001147	000331	A							
001150	000325	A							
001151	000311	A							
001152	000317	A	224	DATA	0317,0320,0301,0323,0304,0306,0307,0310,0312,0313	01	00224		
001153	000320	A							
001154	000301	A							
001155	000323	A							
001156	000304	A							
001157	000306	A							
001160	000307	A							
001161	000310	A							
001162	000312	A							
001163	000313	A							
001164	000314	A	225	DATA	0314,0273,0332,0330,0303,0326,0302,0316,0315,0254	01	00225		
001165	000273	A							
001166	000332	A							
001167	000330	A							
001170	000303	A							
001171	000326	A							
001172	000302	A							
001173	000316	A							
001174	000315	A							
001175	000254	A							
001176	000256	A	226	DATA	0256,0257,0106612,0	01	00226		
001177	000257	A							
001200	106612	A							
001201	000000	A							
001202	000241	A	227	TKK2	DATA	0241,0242,0243,0244,0245,0246,0247,0250,0251,0252	01	00227	
001203	000242	A							
001204	000243	A							
001205	000244	A							
001206	000245	A							
001207	000246	A							
001210	000247	A							
001211	000250	A							
001212	000251	A							
001213	000252	A							
001214	000275	A	228	DATA	0275,0337,0300,0333,0334,0253,0336,0335,0274,0276	01	00228		
001215	000337	A							
001216	000300	A							
001217	000333	A							
001220	000334	A							
001221	000253	A							
001222	000336	A							
001223	000335	A							
001224	000274	A							
001225	000276	A							
001226	000277	A	229	DATA	0277,0106612,0	01	00229		
001227	106612	A							
001230	000000	A							
001231			230	TKW1	BSS 1 TEMP STOR INPUT CHAR	01	00230		
001232				231	TKW2 BSS 1 TEMP STOR INVALID CHAR	01	00231		
			232	*		01	00232		
			233	*	KEYBOARD ECHO TEST	01	00233		
			234	*		01	00234		
001233	000000	A	235	TKE1 LDAT	HNG6 KEYBD ECHO TEST	01	00235		
001234	001245	A	236	CALL	DUTD	01	00236		
001235	002000	A	237	CALL	INPB INPUT & PRINT CHAR	01	00237		
001236	003243	A	238	JMP	TATT EXIT TO KEYBOARD CONTROL PROGRAM	01	00238		
001237	002000	A							
001240	002656	A							
001241	001000	A							
001242	000537	A							
001243	001000	A	239	*	NORMAL RETURN FROM INPB	01	00239		
001244	001237	A	240	JMP	*-4	01	00240		
001245	106612	A	241	HNG6 DATA	0106612,'KEYBOARD ECHO TEST',0106612,0	01	00241		
001246	145705	A							
001247	154702	A							
001250	147701	A							
001251	151304	A							
001252	120305	A							
001253	141710	A							
001254	147640	A							
001255	152305	A							
001256	151724	A							
001257	106612	A							
001260	000000	A							
			242	*		01	00242		
			243	*	PRINTER TEST	01	00243		
			244	*		01	00244		
001261	006010	A	245	TPTT LDAI	0237 INITIALIZE	01	00245		
001262	000237	A							
001263	051325	A	246	STA TPW1	FIRST CHAR (-1)	01	00246		
001264	006030	A	247	TPT1 LDXI	72 INIT FOR NEW LINE	01	00247		
001265	000110	A	248	CALL DUTC	CR/LF	01	00248		
001266	002000	A	249	LDA TPW1	FIRST CHAR OF PREVIOUS LINE	01	00249		

PAGE 6

MAINTAIN III

				TYTEST				
001271	002000	A	250	CALL	TPT3	SUBR	01 00250	
001272	001307	A	251	STA	TPW1	FIRST CHAR OF NEW LINE	01 00251	
001273	0051325	A	252	TPT2	OUTA	PRINT CHAR	01 00252	
001274	002000	A	253	JSS3	TATT	EXIT TO KEYBOARD CONTROL PROGRAM	01 00253	
001275	002613	A	254	CALL	TPT3	NEXT CHAR	01 00254	
001277	000537	A	255	DXR			01 00255	
001300	002000	A	256	JXZ	TPT1	END OF LINE ?	01 00256	
001301	001307	A	257	JMP	TPT2	NO	01 00257	
001302	005344	A	258 *	INCREMENT CHARACTER SUBROUTINE			01 00258	
001303	001040	A	259	TPT3	ENTR		01 00259	
001304	001264	A	260	IAR			01 00260	
001305	001000	A	261	ERAI	0340		01 00261	
001306	001274	A	262	JAZ	*+6	LAST CHAR OF SET ?	01 00262	
001314	001321	A	263	ERAI	0340	NO - RESTORE CHAR	01 00263	
001315	006130	A	264	JMP*	TPT3		01 00264	
001316	000340	A	265	LDAI	0240	SET TO FIRST CHAR OF SET	01 00265	
001320	101307	A	266	JMP*	TPT3	RETURN	01 00266	
001321	006010	A	267	TPW1	BSS	1 WORK AREA	01 00267	
001322	000240	A	268	*			01 00268	
001323	001000	A	269	*	PRINT SUPPRESSION TEST			01 00269
001324	101307	A	270	*			01 00270	
001325	*		271	*	IF ANY FAILURES OCCUR *'S WILL APPEAR WITHIN			01 00271
			272	*	THE MESSAGE			01 00272
			273	*			01 00273	
001326	006030	A	274	TPST	LDXI	(PSTBL) TABLE POINTER	01 00274	
001327	001345	A	275	PS20	LDA	0,1	01 00275	
001330	015000	A	276	CALL	OUTA	PICK A PAIR	01 00276	
001331	002000	A	277	LSRA	8		01 00277	
001332	002613	A	278	CALL	OUTA		01 00278	
001333	004350	A	279	JSS3	TATT	EXIT TO KEYBOARD CONTROL PROGRAM	01 00279	
001337	00537	A	280	IXR			01 00280	
001340	005144	A	281	JAZ	TPST		01 00281	
001341	001010	A	282	JMP	PS20		01 00282	
001342	001326	A	283	PSTBL	DATA	CRLF,0102301,STAR,0102323,STAR	01 00283	
001344	001330	A	284	DATA		0102322,STAR,0102240,STAR,0102324,STAR,0102324	01 00284	
001345	1005215	A	285	DATA		STAR,0102331,STAR,0102240,STAR	01 00285	
001346	102301	A	286	DATA		0102320,STAR,0102322,STAR,0102311	01 00286	
001347	100452	A	287	DATA		STAR,0102316,STAR,0102324,STAR	01 00287	
001350	102323	A	288	DATA		0102240,STAR,0102323,STAR,0102325	01 00288	
001351	100452	A	289	DATA		STAR,0102320,STAR,0102320,STAR	01 00289	
001352	102322	A	290	DATA		0102322,STAR,0102305,STAR,0102323	01 00290	
001353	100452	A	291	DATA		STAR,0102323,STAR,0102311,STAR	01 00291	

001421	100452	A					
001422	102311	A					
001423	100452	A					
001424	102317	A	292	DATA	0102317,STAR,0102316,STAR,0102240		01 00292
001425	100452	A					
001426	102316	A					
001427	100452	A					
001430	102240	A					
001431	100452	A	293	DATA	STAR,0102324,STAR,0102305,STAR		01 00293
001432	102324	A					
001433	100452	A					
001434	102305	A					
001435	100452	A					
001436	102323	A	294	DATA	0102323,STAR,0102324,STAR		01 00294
001437	100452	A					
001440	102324	A					
001441	100452	A					
001442	102256	A	295	DATA	PERIOD+EOTX,STAR,0		01 00295
001443	100452	A					
001444	000000	A					
	100452	A	296	STAR	EQU	0100452	* AND SOM
	102000	A	297	EOTX	EQU	0102000	
	105215	A	298	CRLF	EQU	0105215	
	000256	A	299	PERIOD	EQU	0256	
	300	*					
	301	*		PUNCH / READER TEST			
	302	*					
001445	006030	A	303	TPRT	LDXI	HDG7	33 OR 35 TTY ?
001446	002067	A	304	CALL	OUTD		
001447	002000	A					01 00304
001450	003243	A	305	CALL	INPG		01 00305
001451	002000	A					
001452	003143	A	306	JMP	TATT		01 00306
001453	001000	A					
001454	000537	A	307	JMP	*+2		01 00307
001455	001000	A					
001456	001457	A					
001457	001000	A	308	JMP	TPRT		BACKSLASH
001460	001445	A					
	309	*		NORMAL RETURN FROM INPG			
001461	006150	A	310	ANAI	04		
001462	000004	A					01 00310
001463	006130	A	311	ERAI	04		
001464	000004	A					01 00311
001465	001010	A	312	JAZ	*+4		
001466	001471	A					
001467	006110	A	313	DRAI	0377	33	
001470	000377	A					
001471	006110	A	314	DRAI	0224	35	
001472	000224	A					01 00314
001473	052066	A	315	STA	TYPE		
001474	002000	A	316	CALL	OUTC		
001475	003210	A					
001476	006010	A	317	LDAI	(TBEP)		INIT ERR TBL PTR
001477	003330	A					
001500	052561	A	318	STA	PRW4		
001501	002000	A	319	PR01	CALL	TTYC,0221	RDR ON
001502	002551	A					
001503	000221	A					
001504	002000	A	320	CALL	TTYC,0222	PUNCH ON	
001505	002551	A					
001506	000000	A					
001507	006020	A	321	LDBI	100		PUNCH 100 BLANKS
001510	000144	A					
001511	005001	A	322	TZA			
001512	002000	A	323	PR02	CALL	OUTA	PUNCH 10" LEADER
001513	002613	A					
001514	005322	A	324	DBR			
001515	001020	A	325	JBZ	PR03		
001516	001521	A					
001517	001000	A	326	JMP	PR02		
001520	001512	A					
	327	*					
	328	*		OPERATOR MUST INSERT LEADER, AND SET READER CONTROL TO RUN POSITION			01 00328
	329	*		*****			01 00329
	330	*					01 00330
001521	002000	A	331	PR03	CALL	INPA	WAIT FOR OPERATOR TO INSERT LDR
001522	002610	A					
001523	001000	A	332	JMP	PRND		
001524	002036	A					
001525	002000	A	333	CALL	TTYC,0223		TURN RDR OFF
001526	002551	A					
001527	000223	A					
001530	005001	A	334	TZA			
001531	052557	A	335	STA	PRW2		PRW2 = 0 #CYC
001532	052560	A	336	STA	PRW3		PRW3 = 0 #ERR
001533	052562	A	337	STA	PRW5		PRW5 = 0 #PUNCH ON/OFF ERRORS
001534	006020	A	338	LDBI	100		PUNCH LEADER
001535	000144	A					
001536	002000	A	339	CALL	OUTA		PUNCH
001537	002613	A					
001540	001400	A	340	JSS3	PRND		
001541	002036	A					
001542	005322	A	341	DBR			DEC R CTR
001543	001020	A	342	JBZ	*+4		LAST CHAR ?

PAGE 8 MAINTAIN III TYTEST

```

001544 001547 A 343 JMP *-7 NO 01 00343
001545 001000 A 343 LDAI 0377 PUNCH RUBOUT 01 00344
001546 001536 A 344 CALL DUTA 01 00345
001547 006010 A 344 TZA 01 00346
001550 000377 A 345 JMP PR05 01 00347
001551 002000 A 345 TZA 01 00348
001552 002613 A 346 JMP PR05 01 00349
001553 005001 A 346 TZA 01 00350
001554 001000 A 347 TZA 01 00351
001555 001572 A 347 TZA 01 00352
001556 005122 A 348 PR04 IBR INC TO NEXT CHAR 01 00353
001557 005021 A 349 TBA SAVE IT 01 00354
001558 002000 A 350 CALL TPS4 TEST FOR CONTROL CHAR 01 00355
001561 001767 A 350 CALL TPS4 01 00356
001562 001010 A 351 JAZ *-4 YES 01 00357
001563 001556 A 351 JAZ *-4 01 00358
001564 005021 A 352 TBA RETURN 01 00359
001565 006150 A 353 ANAI 0377 REMOVE EXCESS BITS 01 00360
001566 000377 A 353 ANAI 0377 01 00361
001567 005012 A 354 TAB (RANGE = 0-0377) 01 00362
001570 001020 A 355 JBZ B=0 JMP PUNCH ON/OFF TEST 01 00363
001571 001600 A 355 JBZ 01 00364
001572 002000 A 356 PR05 CALL DUTA PUNCH CHAR 01 00365
001573 002613 A 356 PR05 CALL DUTA 01 00366
001574 001400 A 357 JSS3 PRND SSS EXIT 01 00367
001575 002036 A 357 JSS3 PRND 01 00368
001576 001000 A 358 JMP PR04 CONTINUE 01 00369
001577 001556 A 358 JMP PR04 01 00370
001600 002000 A 359 PR06 CALL TTYC,0224 PUNCH OFF 01 00371
001601 002551 A 359 PR06 CALL TTYC,0224 01 00372
001602 000224 A 360 CALL TTYC,0377 TRY TO PUNCH RUBOUT 01 00373
001603 002000 A 360 CALL TTYC,0377 01 00374
001604 002551 A 361 CALL TTYC,0222 PUNCH ON 01 00375
001605 000377 A 361 CALL TTYC,0222 01 00376
001606 002000 A 362 TZA PUNCH LEADER 01 00377
001607 002551 A 362 TZA 01 00378
001610 000222 A 363 LDBI 100 01 00379
001611 005001 A 363 LDBI 100 01 00380
001612 006020 A 364 CALL DUTA PUNCH 01 00381
001613 000144 A 364 CALL DUTA 01 00382
001614 002000 A 365 JSS3 PRND SSS EXIT 01 00383
001615 002613 A 365 JSS3 PRND 01 00384
001616 001400 A 366 DBR DECR CTR 01 00385
001617 002036 A 366 DBR 01 00386
001620 005322 A 367 JBZ *+4 01 00387
001621 001020 A 367 JBZ *+4 01 00388
001622 001625 A 368 JMP *-7 NO 01 00389
001623 001000 A 368 JMP *-7 01 00390
001624 001614 A 369 CALL TTYC,0224 TURN PUNCH OFF 01 00391
001625 002000 A 369 CALL TTYC,0224 01 00392
001626 002551 A 370 CALL TTYC,0221 TURN RDR ON +LOOKING FOR RUBOUT 01 00393
001630 002000 A 370 CALL TTYC,0221 01 00394
001631 002551 A 371 PR07 CALL INPA INPUT CHAR 01 00395
001632 002221 A 371 PR07 CALL INPA 01 00396
001633 002000 A 372 JMP PRND SSS EXIT 01 00397
001634 002610 A 372 JMP PRND 01 00398
001635 001000 A 373 ERAI 0377 A = 0377 01 00399
001636 002036 A 373 ERAI 0377 01 00400
001637 006130 A 374 JAZ *+4 YES 01 00401
001640 000377 A 374 JAZ *+4 01 00402
001641 001010 A 375 JMP PR07 NO 01 00403
001642 001645 A 375 JMP PR07 01 00404
001643 001000 A 376 TZX INIT TO EXPECTED CHAR 01 00405
001644 001633 A 376 TZX INPUT A CHARACTER 01 00406
001645 005004 A 377 PR08 CALL INPA 01 00407
001646 002000 A 377 PR08 CALL INPA 01 00408
001647 002610 A 378 JMP PRND SSS EXIT 01 00409
001650 001000 A 378 JMP PRND 01 00410
001651 002036 A 379 STA PRW1 SAVE 01 00411
001652 0052556 A 380 TXA COMPARE 01 00412
001653 005041 A 380 TXA 01 00413
001654 132556 A 381 ERA PRW1 ARE EQUAL 01 00414
001655 001010 A 381 ERA *+4 YES 01 00415
001656 001661 A 382 JAZ NO 01 00416
001657 002000 A 383 CALL TTBL 01 00417
001660 002017 A 384 IXR INC EXP TO NXT CHAR 01 00418
001661 005144 A 385 TXA 01 00419
001662 005041 A 385 TXA 01 00420
001663 002000 A 386 CALL TPS4 CONTROL CHAR ? 01 00421
001664 001767 A 386 CALL TPS4 01 00422
001665 001010 A 387 JAZ *-4 YES 01 00423
001666 001661 A 387 JAZ *-4 01 00424
001667 005041 A 388 TXA REMOVE HIGH ORDER 01 00425
001670 006150 A 389 ANAI 0377 BITS 01 00426
001671 000377 A 389 ANAI 0377 01 00427
001672 005014 A 390 TAX LAST CHAR? 01 00428
001673 001040 A 391 JXZ *+4 YES 01 00429
001674 001677 A 391 JXZ *+4 01 00430
001675 001000 A 392 JMP PR08 NO JUMP TO PR08 01 00431
001676 001646 A 392 JMP PR08 01 00432
001677 002000 A 393 CALL INPA INPUT CHAR FOR PUNCH ON/OFF 01 00433
001700 002610 A 393 CALL INPA 01 00434
001701 001000 A 394 JMP PRND SSS EXIT. TEST 01 00435
001702 002036 A 394 JMP PRND 01 00436

```

	MAINTAIN III			TYTEST			PAGE 9	
001703	052556	A	395	STA	PRW1	SAVE CHAR	01 00395	
001704	002000	A	396	CALL	TTYC,0223	TURN RDR OFF	01 00396	
001705	002551	A						
001706	002223	A						
001707	012556	A	397	LDA	PRW1	INPUT CHAR	01 00397	
001710	132066	A	398	ERA	TYPE	=TYPE	01 00398	
001711	001010	A	399	JAZ	PR10	YES	01 00399	
001712	001731	A						
001713	012066	A	400	LDA	TYPE	MOD=35	01 00400	
001714	005130	A	401	ERAI	0224		01 00401	
001715	000224	A						
001716	001010	A	402	JAZ	PR09	YES,PUNCH OFF ERROR	01 00402	
001717	001725	A						
001720	012556	A	403	LDA	PRW1	TRY NEW TYPE MOD 33 (ACTS LIKE 35)	01 00403	
001721	006130	A	404	ERAI	0224		01 00404	
001722	000224	A						
001723	001010	A	405	JAZ	PR11	YES,OK CHANGE TYPE = 35	01 00405	
001724	001762	A						
001725	072556	A	406	PR09	STX	PRW1	01 00406	
001726	002000	A	407	CALL	TTBL	PUT 0 INTO TBL	01 00407	
001727	002017	A						
001730	042562	A	408	INR	PRWS	PUNCH ON/OFF CTR INC	01 00408	
001731	002000	A	409	PR10	DET	PRINT ERR TBL	01 00409	
001732	002415	A						
001733	001000	A	410	JMP	PRND	SS3 EXIT	01 00410	
001734	002036	A						
001735	005010	A	411	LDAI	0377	PUNCH RUBOUT	01 00411	
001736	000377	A						
001737	002000	A	412	CALL	DUTA		01 00412	
001740	002613	A						
001741	002000	A	413	CALL	TTYC,0222	TURN PUNCH ON	01 00413	
001742	002551	A						
001743	002222	A						
001744	012066	A	414	LDA	TYPE		01 00414	
001745	006130	A	415	ERAI	0377		01 00415	
001746	000377	A						
001747	001010	A	416	JAZ	*+5		01 00416	
001750	001754	A						
001751	002000	A	417	CALL	TTYC,0377	PUNCH RUBOUT	01 00417	
001752	002551	A						
001753	000377	A						
001754	001400	A	418	JSS3	PRND	SS3 EXIT	01 00418	
001755	002036	A						
001756	005001	A	419	TZA		JMP TO PUNCH PATTERN	01 00419	
001757	005002	A	420	TZB		(INIT)	01 00420	
001760	001000	A	421	JMP	PR05	JMP TO READ ROUTINE	01 00421	
001761	001572	A						
001762	006010	A	422	PR11	LDAI	CHANGE TYPE = 35	01 00422	
001763	000224	A						
001764	052066	A	423	STA	TYPE		01 00423	
001765	001000	A	424	JMP	PR10		01 00424	
001766	001731	A						
001767	000000	A	425	*	CHECK FOR CONTROL CODE SUBROUTINE		01 00425	
001770	006110	A	426	TPS4	ENTR	CHECK A FOR CONTROL CHAR	01 00426	
001771	000200	A	427	TPS4	ORAI	0200	01 00427	
001772	006140	A	428	SUBI	0204		01 00428	
001773	000204	A						
001774	006140	A	429	SUBI	010		01 00429	
001775	000010	A						
001776	001010	A	430	JAZ*	TPS4		01 00430	
001777	101767	A						
002001	000005	A	431	SUBI	05		01 00431	
002002	001010	A	432	JAZ*	TPS4		01 00432	
002003	101767	A						
002004	005311	A	433	DAR			01 00433	
002005	001010	A	434	JAZ*	TPS4		01 00434	
002006	101767	A						
002007	005311	A	435	DAR			01 00435	
002010	001010	A	436	JAZ*	TPS4		01 00436	
002011	101767	A						
002012	005311	A	437	DAR			01 00437	
002013	001010	A	438	JAZ*	TPS4		01 00438	
002014	101767	A						
002015	001000	A	439	JMP*	TPS4		01 00439	
002016	101767	A						
002017	000000	A	440	TTBL	ENTR	X + ACT TO TBER	01 00440	
002020	072032	A	441	STX	TTS1+1		01 00441	
002021	005041	A	442	TXA			01 00442	
002022	032561	A	443	LDX	PRW4		01 00443	
002023	055000	A	444	STA	0,1		01 00444	
002024	012556	A	445	LDA	PRW1		01 00445	
002025	055001	A	446	STA	1,1		01 00446	
002026	005144	A	447	IXR			01 00447	
002027	005144	A	448	IXR			01 00448	
002030	072561	A	449	STX	PRW4		01 00449	
002031	006030	A	450	TTS1	LDXI	0	01 00450	
002032	000000	A						
002033	042560	A	451	INR	PRW3		01 00451	
002034	001000	A	452	JMP*	TTBL		01 00452	
002035	102017	A						
002036	002000	A	453	PRND	CALL	DUTC	OUTPUT #CYC,#ERR,#PUNCH ON/OFF ERRS	01 00453
002037	003210	A						
002040	002000	A	454	CALL	DUTC	CR/LF	01 00454	

002041	003210	A						
002042	002000	A	455	CALL	TTYC,0201	PRINT ENABLE		01 00455
002043	002551	A						
002044	000201	A						
002045	012557	A	456	LDA	PRW2	#CYC		01 00456
002046	002000	A	457	CALL	DUTE			01 00457
002047	003217	A						
002048	002000	A	458	CALL	DUTC	CR/LF		01 00458
002049	003210	A						
002050	002000	A	459	LDA	PRW3	#ERR		01 00459
002051	003210	A						
002052	012560	A	460	CALL	DUTE			01 00460
002053	002000	A						
002054	003217	A						
002055	002000	A	461	CALL	DUTC	CR/LF		01 00461
002056	003210	A						
002057	012562	A	462	LDA	PRW5	#PUNCH ON/OFF ERRS		01 00462
002058	002000	A	463	CALL	DUTE			01 00463
002059	003217	A						
002060	002000	A	464	CALL	DUTC	CR/LF		01 00464
002061	003210	A						
002062	002000	A	465	JMP	TATT	EXIT TO KEYBOARD CONTROL PROGRAM		01 00465
002063	003210	A						
002064	001000	A						
002065	000537	A						
002066	466	TYPE	BSS		1	TTY TYPE # STORAGE		01 00466
002067	106612	A	467	HDG7	DATA	0106612,"TYPE OF TTY (33 OR 35) = ",0		01 00467
002068								
002069	106612	A						
002070	152331	A						
002071	150305	A						
002072	120317	A						
002073	143240	A						
002074	152324	A						
002075	154640	A						
002076	124263	A						
002077	131640	A						
002100	147722	A						
002101	120263	A						
002102	132631	A						
002103	120275	A						
002104	000000	A						
002105	106612	A	468	HDG8	DATA	0106612,0106612,"EXPECTED ACTUAL",0		01 00468
002106	106612	A						
002107	142730	A						
002110	150305	A						
002111	141724	A						
002112	142704	A						
002113	120301	A						
002114	141724	A						
002115	152701	A						
002116	146240	A						
002117	000000	A						
002118	469	*						
002119	470	*						
002120	471	*						
002121	472	READER TEST	TRTT	CALL	TTYC,0224	INIT TTY PUNCH OFF		01 00469
002122	002551	A						01 00470
002123	000224	A						01 00471
002124	002000	A	473	CALL	TTYC,0204	*	PRINT OFF	
002125	002551	A						
002126	000204	A						
002127	002000	A	474	CALL	TTYC,0221	*	RDR ON	
002128	002551	A						
002129	000221	A						
002130	005004	A	475	TZX		X = NXT CHAR EXPECTED		
002131	022557	A	476	STX	PRW2	INIT PWR2 #CYC		01 00475
002132	022556	A	477	STX	PRW3	PRW3 #ERR		01 00476
002133	022562	A	478	STX	PRW5	# RDR OFF ERRORS		01 00477
002134	022562	A	479	STX	PRW6	# RDR ON ERRORS		01 00478
002135	022563	A				PRW4 TBL PTR		01 00479
002136	006010	A	480	LDAI	(TBER)			01 00480
002137	003330	A						
002138	052561	A	481	STA	PRW4			01 00481
002139	002000	A	482	TR00	CALL	INPA	FIND FIRST BLANK	01 00482
002140	02610	A						
002141	001000	A	483	JMP	TATT	EXIT TO KEYBOARD CONTROL PROGRAM		01 00483
002142	00537	A						
002143	001000	A	484	JAZ	*+4	*		01 00484
002144	001010	A	485	JAZ	*-6	*		01 00485
002145	002151	A						
002146	001000	A						
002147	002141	A	486	CALL	INPA	INPUT CHAR		
002148	002000	A	487	JMP	RTND	SS3 EXIT		
002149	001000	A						
002150	002346	A						
002151	052556	A	488	STA	FRW1	SAVE IT		01 00488
002152	05144	A	489	IXR		INC EXPECTED CHAR		01 00489
002153	05041	A	490	TXA		*		01 00490
002154	002000	A	491	CALL	TPS4	IS IT A CONTROL CHAR ?		01 00491
002155	001767	A						
002156	001010	A	492	JAZ	*-4	YES		01 00492
002157	002156	A						
002158	005041	A	493	TXA		NO		01 00493
002159	006150	A	494	ANAI	0377	REMOVE ANY HIGH ORDER BITS		01 00494
002160	000377	A						
002161	005014	A	495	TAX		*		01 00495
002162	001010	A	496	JAZ	TR02	LAST CHAR ? JMP TO ON/OFF TEST		01 00496
002163	002201	A						
002164	132556	A	497	ERA	PRW1	EXP = ACT ?		01 00497
002165	001010	A	498	JAZ	TR01	YES		01 00498
002166	002151	A						

MAINTAIN III

TYTEST

PAGE 11

002175	002000	A	499	CALL	TTBL	NO ENTER ERR INTO TBL	01	00499
002176	002017	A	500	JMP	TR01		01	00500
002177	001000	A	500	JMP	TR01		01	00501
002200	002151	A	501	TR02	LDA	RDR ON/OFF TEST.	01	00502
002202	001010	A	502	JAZ	PRW1 *+4	DID IT READ THE BLANK OK?	01	00503
002203	002206	A	503	CALL	TTBL	NO	01	00503
002204	002000	A	503	CALL	TTBL		01	00504
002205	002017	A	504	LDAI	0223	TURN RDR OFF	01	00504
002206	006010	A	504	LDAI	0223		01	00505
002207	002223	A	505	CALL	OUTA	*	01	00505
002210	002000	A	505	CALL	OUTA		01	00506
002211	002613	A	506	LDBI	(TRBF)	B POINTS TO BUFFER	01	00506
002212	006020	A	506	LDBI	32000		01	00507
002213	002403	A	507	LDXI	32000		01	00507
002214	006030	A	507	LDXI	32000		01	00507
002215	076400	A	508	LDA	\$TTY		01	00508
002216	012644	A	508	LDA	0101200	ADJ. TTY DA	01	00509
002217	006110	A	509	ORAI	0101200		01	00509
002220	101200	A	510	STA	TR03		01	00510
002221	052225	A	510	ADDI	01300		01	00511
002222	006120	A	511	STA	TR03		01	00512
002223	001300	A	512	STA	TR04		01	00513
002224	052235	A	512	SEN	0,TR04	READ REG RDY	01	00513
002225	101000	A	513	TR03	SEN		01	00514
002226	002235	A	514	CALL	TOUT	TIME OUT	01	00514
002227	002000	A	514	JMP	TR05	EXIT	01	00515
002230	003301	A	515	JMP	TR05		01	00515
002231	001000	A	516	JMP	TR03	LOOP BACK	01	00516
002233	001000	A	516	JMP	TR03		01	00516
002234	002225	A	517	TR04	CIA		01	00517
002235	102500	A	518	STA	0,2	INPUT A CHAR	01	00518
002236	056000	A	518	IBR		STORE CHAR INTO BFR	01	00518
002237	005122	A	519	JMP	TR03	INCR BFR PTR	01	00519
002240	001000	A	520	JMP	TR03	CONTINUE INPUT	01	00520
002241	002225	A	521	TR05	TBA		01	00521
002242	005021	A	521	SUBI	(TRBF+2)	CHECK # FRAMES READ	01	00521
002243	006140	A	522	SUBI	(TRBF+2)	AFTER RDR TURNED OFF	01	00522
002244	002405	A	523	JAN	TR07		01	00523
002245	001004	A	523	JAN	TR07	LESS THAN 2	01	00523
002246	002334	A	524	SUBI	2	OR	01	00524
002250	000002	A	525	JAP	TR07		01	00525
002251	001002	A	525	JAP	TR07	MORE THAN 3	01	00525
002252	002334	A	526	STB	TR08+1		01	00526
002253	062274	A	526	TZX		SAVE BFR PTR	01	00527
002254	003004	A	527	LDBI	(TRBF)	X = EXP CHAR-1	01	00527
002255	006020	A	528	LDBI	(TRBF)	B = BFR PTR	01	00528
002256	002403	A	529	TR06	LDA	GET CHAR FROM BFR	01	00529
002260	052556	A	530	STA	PRW1	PUT IT INTO ACT (PRW1)	01	00530
002261	005144	A	531	IXR		INC EXP CHAR	01	00531
002262	072264	A	532	STX	*+2		01	00532
002263	006130	A	533	ERAI	0	ACT = EXP?	01	00533
002264	000000	A	534	JAZ	*+4	YES	01	00534
002265	001010	A	534	JAZ	*+4		01	00534
002266	002271	A	535	CALL	TTBL	NO	01	00535
002267	002000	A	535	CALL	TTBL		01	00535
002270	002017	A	536	IBR		INC BFR PTR	01	00536
002271	005122	A	537	TBA		DONE?	01	00537
002273	006140	A	538	TR08	SUBI	*	01	00538
002274	000000	A	539	JAZ	*+4	YES	01	00539
002276	002301	A	540	JMP	TR06	NO	01	00540
002300	002257	A	541	CALL	DET	OUTPUT ERR TBL	01	00541
002301	002000	A	541	CALL	DET		01	00541
002302	002415	A	542	JMP	RTND	SS3 EXIT	01	00542
002303	001000	A	542	JMP	RTND		01	00542
002304	002346	A	543	LDAI	0221	TURN RDR ON	01	00543
002305	006010	A	543	LDAI	0221		01	00543
002306	000221	A	544	CALL	OUTA	*	01	00544
002307	002000	A	544	CALL	OUTA	*	01	00544
002310	002613	A	545	CALL	INPA	INPUT A CHAR	01	00545
002311	002000	A	545	CALL	INPA		01	00545
002312	002610	A	546	JMP	RTND	SS3 EXIT	01	00546
002313	001000	A	546	JMP	RTND		01	00546
002314	002346	A	547	IXR		NEXT CHAR THE EXP?	01	00547
002315	005144	A	547	STX	*+2		01	00548
002316	072320	A	548	SUBI	0		01	00549
002317	006140	A	549	CALL	TTBL		01	00549
002320	000000	A	550	JAZ	TR01	JMP IF YES	01	00550
002321	001010	A	550	JAZ	TR01		01	00550
002322	002151	A	551	INR	PRW6		01	00551
002323	042563	A	551	LRLA	9	NO ,INC # RDR ON ERRORS	01	00552
002324	004251	A	552	DECRL	04	INTO	01	00552
002325	005304	A	553	STA	PRW1	PUT EXP=-1,ACT=#FRAMES	01	00553
002326	052556	A	554	CALL	TTBL	ERROR TBL	01	00554
002327	002000	A	555	JMP	TR00		01	00555
002330	002017	A	556	TZX		LOOK FOR FIRST BLANK	01	00556
002331	005004	A	557	JMP	TR00		01	00557
002332	001000	A	557	JMP	TR00		01	00557
002333	002141	A						

002334	005021	A	558	TR07	TBA		PUT ERR FRAME	01 00558
002335	006140	A	559	SUBI	(TRBF-1)		# INTO	01 00559
002336	002402	A	560	LRLA	9		ERROR	01 00560
002337	004251	A	561	STA	PRW1		TABLE	01 00561
002340	052556	A	562	CALL	TTBL		TO INDICATE	01 00562
002341	002000	A	563	INR	PRW5		INC # RDR OFF ERRORS	01 00563
002344	001000	A	564	JMP	TR06-4		RDR ON/OFF ERR	01 00564
002345	002253	A	565	RTND	CALL	OUTC	OUTPUT	01 00565
002346	002000	A	566	CALL	TTYC,0201		PRINT ENABLE	01 00566
002351	002551	A	567	CALL	OUTC	CR/LF		01 00567
002353	002000	A	568	LDA	PRW2		#CYC	01 00568
002355	012557	A	569	CALL	OUTE			01 00569
002356	002000	A	570	CALL	OUTC			01 00570
002357	003217	A	571	LDA	PRW3		#ERR	01 00571
002360	012560	A	572	CALL	OUTE			01 00572
002361	003210	A	573	CALL	OUTC	CR/LF		01 00573
002362	003210	A	574	LDA	PRW5		# PUNCH ON/OFF OR RDR OFF ERRORS	01 00574
002363	002000	A	575	CALL	OUTE			01 00575
002364	003217	A	576	CALL	OUTC	CR/LF		01 00576
002365	002000	A	577	LDA	PRW6	0	OR RDR ON ERRORS	01 00577
002366	003210	A	578	CALL	OUTE			01 00578
002367	012562	A	579	CALL	OUTC	CR/LF		01 00579
002370	002000	A	580	JMP	TATT		EXIT TO KEYBOARD CONTROL PROGRAM	01 00580
002402	000537	A	581	TRBF	BSS	10		
002415	000000	A	582	DET	EMTR		OUTPUT ERROR TABLE	01 00581
002416	052513	A	583	STA	DETS		SAVE REG A	01 00582
002417	062514	A	584	STB	DETS+1		B	01 00583
002420	072515	A	585	STX	DETS+2		X	01 00584
002421	042557	A	586	INR	PRW2			01 00585
002422	002000	A	587	CALL	TTYC,0201		PRINT ENABLE	01 00586
002423	002551	A						01 00587
002424	000201	A	588	LDAI	(TBER)	JMP IF		01 00588
002426	003330	A	589	SUB	PRW4		NO ERRS	01 00589
002427	142561	A	590	JAZ	DETS			01 00590
002430	001010	A	591	JSS2	DET2-2			01 00591
002431	002501	A						
002432	001200	A	592	LDXI	HOG8	*	YES	01 00592
002434	006030	A	593	CALL	OUTD	*	PRINT	01 00593
002436	002000	A	594	LDXI	(TBER)			01 00594
002437	003243	A						
002440	006030	A	595	DET2	JSS1	DETS3	SSI BYPASS ERR HLT	01 00595
002441	003330	A	596	LDA	0,1		A = DATA IN ERROR	01 00596
002444	015000	A	597	LDB	1,1			01 00597
002445	025001	A	598	HLT	0777		HLT TO DISPLAY ERR	01 00598
002446	000777	A	599	DET3	JSS2	DETA4	SS2 BYPASS ERR PRINTOUT	01 00599
002450	002467	A						
002451	002000	A	600	CALL	OUTC	CR/LF		01 00600
002452	003210	A						
002453	015000	A	601	LDA	0,1			01 00601
002454	002000	A	602	CALL	OUTE			01 00602
002455	003217	A						
002456	005042	A	603	TXB			PRINT 2 SPACES	01 00603
002457	006010	A	604	LDAI	0120240		SAVE X	01 00604
002460	120240	A					PRINT	
002461	002000	A	605	CALL	OUTB			01 00605
002462	003175	A						
002463	005024	A	606	TBX			RETURN X	01 00606
002464	015001	A	607	LDA	1,1			01 00607
002465	002000	A	608	CALL	OUTE			01 00608
002466	003217	A						
002467	005144	A	609	DET4	IXR		CONTINUE	01 00609
002470	005144	A	610	IXR				01 00610
002471	005041	A	611	TXA				01 00611
002472	142561	A	612	SUB	PRW4			01 00612
002473	001400	A	613	JSS3	(DET)*		SS3 EXIT	01 00613
002474	102415	A						
002475	001010	A	614	JAZ	DETS		DONE	01 00614
002476	002501	A						
002477	001000	A	615	JMP	DET2			01 00615
002500	002442	A						
002501	006010	A	616	DET5	LDAI		RESET TBL PTR	01 00616
002502	003330	A	617	STA	PRW4			01 00617

002504 012513 A	618	LDA	DETS	RESTORE REG A	01 00618
002505 022514 A	619	LDB	DETS+1	B	01 00619
002506 032515 A	620	LDX	DETS+2	X	01 00620
002507 042415 A	621	INR	DET	SET RETURN	01 00621
002510 042415 A	622	INR	DET		01 00622
002511 001000 A	623	JMP*	DET		01 00623
002512 102415 A					
002513	624	DETS	BSS	SAVE REGS	01 00624
002516 000000 A	625	TTBC	ENTR	CLEAR TTY RD BFR	01 00625
002517 012644 A	626	LDA	STTY	*	01 00626
002520 006110 A	627	ORAI	0102500	*	01 00627
002521 102500 A					
002522 052523 A	628	STA	*+1	*	01 00628
002523 102500 A	629	CIA	0	*	01 00629
002524 001000 A	630	JMP*	TTBC	CLEAR BFR	01 00630
002525 102516 A				RETURN	
002526 052554 A	631	TTY1	STA	SAVE A	01 00631
002527 072555 A	632	STX	TTYC+4	SAVE X	01 00632
002530 032551 A	633	LDX	TTYC	A=CONTROL	01 00633
002531 015000 A	634	LDA	0,1	CHARACTER	01 00634
002532 002000 A	635	CALL	OUTA	OUTPUT CHARACTER	01 00635
002533 002613 A					
002534 005004 A	636	TZX		TIME DELAY	01 00636
002535 002000 A	637	CALL	TDLY		01 00637
002536 003304 A					
002537 002000 A	638	CALL	TDLY		01 00638
002540 003304 A					
002541 002000 A	639	CALL	TDLY		01 00639
002542 003304 A					
002543 002000 A	640	CALL	TDLY		01 00640
002544 003304 A					
002545 042551 A	641	INR	TTYC	SET RETURN	01 00641
002546 012554 A	642	LDA	TTYC+3	RESTORE A	01 00642
002547 032555 A	643	LDX	TTYC+4	RESTORE X	01 00643
002550 001000 A	644	JMP	0	RETURN	01 00644
002551 000000 A					
002552 001000 A	645	TTYC	BES	ENTRY	01 00645
002553 002526 A	646	JMP	TTY1	LOOP	01 00646
002554	647	BSS	2	STORAGE FOR A + X	01 00647
002556	648	PRW1	BSS	ACT	01 00648
002557	649	PRW2	BSS	#CYC	01 00649
002560	650	PRW3	BSS	#ERR	01 00650
002561	651	PRW4	BSS	TBER PTR	01 00651
002562	652	PRW5	BSS	#PUNCH ON/OFF OR RDROFF ERRS	01 00652
002563	653	PRW6	BSS	# RDR OM ERRS	01 00653
002564	654	BSS	2	STORAGE FOR A + X	01 00654
	655	*			01 00655
	656	*	INPUT ONE CHARACTER FROM TTY TO A REGISTER		01 00656
	657	*			01 00657
002566 012644 A	658	INA1	LDA	STTY	01 00658
002567 006110 A	659	ORAI	0101200	ADJUST TTY DA	01 00659
002570 101200 A					
002571 052575 A	660	STA	*+4		01 00660
002572 006120 A	661	ADDI	001300		01 00661
002573 001300 A					
002574 052604 A	662	STA	*+8		01 00662
002575 101000 A	663	SEN	0,*+7	READ REGISTER READY	01 00663
002576 002604 A					
002577 005011 A	664	MERG	011	NOP	01 00664
002600 001400 A	665	JSS3*	INPA	TERMINATE EXIT	01 00665
002601 102500 A					
002602 001000 A	666	JMP	*-5		01 00666
002603 002575 A					
002604 102500 A	667	CIA	0	INPUT CHARACTER	01 00667
002605 042610 A	668	INR	INPA		01 00668
002606 042610 A	669	INR	INPA		01 00669
002607 001000 A	670	JMP*	0	EXIT	01 00670
002610 100000 A					
002610	671	INPA	BES	0	01 00671
002611 001000 A	672	JMP	INA1		01 00672
002612 002566 A					
	673	*			01 00673
	674	*	OUTPUT ONE CHARACTER FROM A REG TO TTY		01 00674
	675	*			01 00675
002613 000000 A	676	OUTA	ENTR	0	01 00676
002614 073312 A	677	STX	TS01	SAVE X	01 00677
002615 005014 A	678	TAX			01 00678
002616 012644 A	679	LDA	STTY		01 00679
002617 006110 A	680	ORAI	0101100	ADJUST TTY DA	01 00680
002620 101100 A					
002621 052630 A	681	STA	*+7		01 00681
002622 006120 A	682	ADDI	002000		01 00682
002623 002000 A					
002624 052640 A	683	STA	OUT1		01 00683
002625 005041 A	684	TXA			01 00684
002626 006030 A	685	LDXI	32767	TIME-OUT CONSTANT	E 01 00685
002627 072727 A					
002630 101000 A	686	SEN	0,OUT1	WRITE REGISTER READY	01 00686
002631 002640 A					
002632 002000 A	687	CALL	TOUT		01 00687
002633 003301 A					
002634 005011 A	688	MERG	011		01 00688
002635 000115 A	689	HLT	77		01 00689
002636 001000 A	690	JMP	*-6		01 00690

002637	002630	A	691	DUT1	BAR	0		01 00691
002640	103100	A	692	LDX	TS01			01 00692
002641	033312	A	693	JMP*	DUTA			01 00693
002642	001000	A	694	STTY	DATA	01		01 00694
002643	102613	A	695	*				01 00695
002644	0000001	A	696	*	INPUT ONE CHARACTER + PRINT FROM TTY TO A REGISTER			01 00696
002645	002000	A	697	*				01 00697
002646	002610	A	698	INB1	CALL	INPA	INPUT ONE CHARACTER	01 00698
002647	001000	A	699	JMP*	INPB		TERMINATE EXIT	01 00699
002650	102656	A	700	CALL	DUTA		OUTPUT ONE CHARACTER	01 00700
002651	002000	A	701	INR	INPB			01 00701
002652	002613	A	702	INR	INPB			01 00702
002653	042656	A	703	JMP*	0		EXIT	01 00703
002654	042656	A	704	INPB	BES	0		01 00704
002655	001000	A	705	JMP	INB1			01 00705
002656	100000	A	706	*				01 00706
002657	001000	A	707	*	INPUT ONE CHARACTER (EDITED)			01 00707
002660	002645	A	708	*				01 00708
002661	002000	A	709	INC3	CALL	INPB		01 00709
002662	002656	A	710	JMP*	INPC		TERMINATE EXIT	01 00710
002663	001000	A	711	ERAI	'\'		BACKSLASH	01 00711
002664	102710	A	712	JAZ	INC2		ABORT INPUT EXIT	01 00712
002665	006130	A	713	ERAI	'\'		RESTORE A	01 00713
002666	000334	A	714	ERAI	0337		BACKARROW	01 00714
002667	001010	A	715	JAZ	INC1		DELETE ONE CHARACTER EXIT	01 00715
002668	002703	A	716	ERAI	0337		RESTORE A	01 00716
002670	000337	A	717	INR	INPC			01 00717
002670	042710	A	718	INR	INPC			01 00718
002670	042710	A	719	INC1	INR	INPC		01 00719
002670	042710	A	720	INR	INPC			01 00720
002670	042710	A	721	INC2	INR	INPC		01 00721
002670	042710	A	722	INR	INPC			01 00722
002670	001000	A	723	JMP*	0		EXIT	01 00723
002671	100000	A	724	INPC	BES	0		01 00724
002671	001000	A	725	JMP	INC3			01 00725
002672	002661	A	726	*				01 00726
002672	*		727	*	INPUT ONE ALPHA CHARACTER FROM TTY KEYBOARD TO A REG			01 00727
002672	*		728	*				01 00728
002673	001000	A	729	JMP	INPD+1		GET CORRECT INPUT	01 00729
002674	002747	A	730	IND4	CALL	INPC	INPUT ONE CHAR	01 00730
002675	002000	A	731	JMP*	INPD		TERMINATE EXIT	01 00731
002676	002710	A	732	JMP	IND2		ABORT INPUT EXIT	01 00732
002677	001000	A	733	JMP	IND1		DELETE PREVIOUS CHARACTER EXIT	01 00733
002678	002743	A	734	SUBI	0301		CHAR A	01 00734
002679	006140	A	735	JAN	IND3		INVALID INPUT	01 00735
002679	000301	A	736	SUBI	032		CHAR Z	01 00736
002679	001004	A	737	JAP	IND3		INVALID INPUT	01 00737
002680	002751	A	738	ADDI	0333		RESTORE A	01 00738
002681	006140	A	739	INR	INPD		NORMAL EXIT	01 00739
002682	000032	A	740	INR	INPD			01 00740
002683	001002	A	741	IND1	INR	INPD	DELETE PREVIOUS CHARACTER EXIT	01 00741
002684	002751	A	742	INR	INPD			01 00742
002685	006120	A	743	IND2	INR	INPD	ABORT INPUT EXIT	01 00743
002686	000333	A	744	INR	INPD			01 00744
002687	001000	A	745	JMP*	0		EXIT	01 00745
002688	100000	A	746	INPD	BES	0		01 00746
002689	001000	A	747	JMP	IND4			01 00747
002690	002715	A	748	IND3	CALL	DUTG	INVALID INPUT--PRINT MESSAGE	01 00748
002691	002000	A	749	JMP	IND4			01 00749
002692	003052	A	750	*				01 00750
002693	001000	A	751	*				01 00751
002694	002715	A	752	*	INPUT TWO LETTER CHARACTERS FROM TTY			01 00752
002695	002754	A	753	*				01 00753
002696	002000	A	754	INES3	CALL	INPD	INPUT ALPHA CHAR	01 00754

002756	002746	A	755	JMP*	INPE	TERMINATE EXIT	01 00755	
002757	001000	A	756	JMP	INE2	ABORT INPUT EXIT	01 00756	
002760	103007	A	757	JMP	INE1	DELETE PREVIOUS CHARACTER EXIT	01 00757	
002761	001000	A	758	LRLA	8		01 00758	
002762	003004	A	759	STA	TS02		01 00759	
002763	001000	A	760	CALL	INPD	INPUT ALPHA CHAR	01 00760	
002764	003002	A	761	JMP*	INPE	TERMINATE EXIT	01 00761	
002765	004250	A	762	JMP	INE2	ABORT INPUT EXIT	01 00762	
002766	053313	A	763	JMP	INE1	DELETE PREVIOUS CHARACTER EXIT	01 00763	
002767	002000	A	764	DRA	TS02		01 00764	
002770	002746	A	765	IMR	INPE	NORMAL EXIT	01 00765	
002771	001000	A	766	IMR	INPE		01 00766	
002772	103007	A	767	INE1	INR	DELETE PREVIOUS CHARACTER EXIT	01 00767	
002773	001000	A	768	IMR	INPE		01 00768	
002774	003004	A	769	INE2	INR	ABORT INPUT EXIT	01 00769	
002775	001000	A	770	IMR	INPE		01 00770	
002776	003002	A	771	JMP*	0	EXIT	01 00771	
002777	113313	A	772	INPE	BES	0	01 00772	
003000	043007	A	773	JMP	INES		01 00773	
003011	002755	A	774	*			01 00774	
			775	*	INPUT PERIOD, COMMA FOR MESSAGE TERMINATOR		01 00775	
			776	*			01 00776	
003012	002000	A	777	INF5	CALL	INPC	INPUT ONE CHARACTER	01 00777
003013	002710	A	778	JMP*	INPF	TERMINATE EXIT	01 00778	
003014	001000	A	779	JMP	INF2	ABORT INPUT EXIT	01 00779	
003015	103047	A	780	JMP	INF1	DELETE PREVIOUS CHARACTER EXIT	01 00780	
003016	001000	A	781	SUBI	0254	COMMA	01 00781	
003017	003044	A	782	JAZ	INF3	COMMA EXIT	01 00782	
003020	001000	A	783	SUBI	02	PERIOD	01 00783	
003021	003042	A	784	JAZ	INF4	PERIOD EXIT	01 00784	
003022	006140	A	785	CALL	DUTG	PRINT INVALID MESSAGE	01 00785	
003023	000254	A	786	JMP	INF5	GET CORRECT INPUT	01 00786	
003024	001010	A	787	INF4	INR	NORMAL EXIT	01 00787	
003025	003040	A	788	IMR	INPF		01 00788	
003026	006140	A	789	INF3	INR	COMMA EXIT	01 00789	
003027	000002	A	790	INR	INPF		01 00790	
003028	001010	A	791	INF1	INR	DELETE PREVIOUS CHARACTER EXIT	01 00791	
003029	003043	A	792	IMR	INPF		01 00792	
003030	0043047	A	793	INF2	INR	ABORT INPUT EXIT	01 00793	
003031	003036	A	794	IMR	INPF		01 00794	
003032	002000	A	795	JMP*	0	EXIT	01 00795	
003033	003052	A	796	INPF	BES	0	01 00796	
003034	001000	A	797	JMP	INF5		01 00797	
003035	003012	A	798	*			01 00798	
003036	043047	A	799	*	INVALID INPUT--PRINT MESSAGE		01 00799	
003037	043047	A	800	*			01 00800	
003040	043047	A	801	DUTG	ENTR	0	01 00801	
003041	043047	A	802	LDXI	MSG5	INVALID MESSAGE	01 00802	
003042	043047	A	803	CALL	DUTD	OUTPUT MESSAGE	01 00803	
003043	002000	A	804	JMP*	DUTG		01 00804	
003045	043047	A	805	*			01 00805	
003046	001000	A	806	*	INPUT OCTAL NUMBER FROM TTY KEYBOARD		01 00806	
003047	100000	A	807	*	ASSEMBLE AS 16 BIT NUMBER IN A REG		01 00807	
003048	003052	A	808	*	ONLY OCTAL NUMBERS ACCEPTED		01 00808	
003049	*	A	809	*			01 00809	
003051	003012	A	810	ING7	TZA		01 00810	
003052	000000	A	811	STA	TS02	TEMP STORAGE FOR OCTAL NUMBER	01 00811	
003053	006030	A	812	STA	TS03	TEMP STORAGE FOR OCTAL NUMBER	01 00812	
003054	003321	A	813	STA	TS04	TEMP STORAGE FOR DIGIT COUNTER	01 00813	
003055	003243	A	814	STB	TS07		01 00814	
003056	003243	A	815	TZB			01 00815	
003057	001000	A	816	ING5	CALL	INPC	INPUT ONE CHARACTER	01 00816
003058	103052	A	817	JMP*	INPG	TERMINATE EXIT	01 00817	
003059	002600	A	818	JMP	ING2	ABORT INPUT EXIT	01 00818	
003060	002710	A	819	JMP	ING1	DELETE PREVIOUS CHARACTER EXIT	01 00819	
003061	005001	A	820	STA	TS05	SAVE INPUT	01 00820	

003100	006140	A	821	SUBI	0260		01 00821
003101	000260	A	822	JAN	ING6	INVALID IF NOT OCTAL NUMBER	01 00822
003102	001004	A	823	SUBI	010		01 00823
003103	003146	A	824	JAP	ING6	INVALID IF NOT OCTAL NUMBER	01 00824
003104	006140	A	825	ADDI	010	RESTORE DIGIT	01 00825
003105	000010	A	826	DRA	TS02		01 00826
003106	001002	A	827	STA	TS03		01 00827
003107	003146	A	828	LLRL	3		01 00828
003108	000010	A	829	JBZ	*+4		01 00829
003109	006120	A	830	JMP	IMG8		01 00830
003110	000010	A	831	STA	TS02		01 00831
003111	113313	A	832	INR	TS04	ADVANCE DIGIT COUNTER	01 00832
003112	003314	A	833	LDA	TS04		01 00833
003113	004443	A	834	SUBI	7		01 00834
003114	001020	A	835	JAP	ING8	TOO MANY DIGITS. START INPUT OVER	01 00835
003115	003121	A	836	JMP	IMG5	GET NEXT DIGIT	01 00836
003116	001000	A	837	ING3	INR	NORMAL EXIT	01 00837
003117	003157	A	838	INR	INPG		01 00838
003118	000000	A	839	ING4	INR	COMMA EXIT	01 00839
003119	003143	A	840	INR	INPG		01 00840
003120	006140	A	841	ING2	INR	ABORT INPUT EXIT	01 00841
003121	000007	A	842	INR	INPG		01 00842
003122	001002	A	843	LDB	TS07		01 00843
003123	003134	A	844	LDA	TS03	GET ASSEMBLED OCTAL NUMBER	01 00844
003124	001000	A	845	JMP*	0	EXIT	01 00845
003125	100000	A	846	INPG	BES		01 00846
003126	001000	A	847	JMP	IMG7		01 00847
003127	003061	A	848	ING6	LDA	GET LAST INPUT	01 00848
003128	013316	A	849	SUBI	0254	IS IT A COMMA	01 00849
003129	006140	A	850	JAZ	IMG4	YES	01 00850
003130	000254	A	851	SUBI	02	IS IT A PERIOD	01 00851
003131	001010	A	852	JAZ	IMG3	YES	01 00852
003132	003134	A	853	ING8	CALL	PRINT INVALID MESSAGE	01 00853
003133	006140	A	854	JMP	IMG7	START OVER WITH OCTAL INPUT	01 00854
003134	003061	A	855	*			01 00855
003135	013314	A	856	IMG1	LDA	TS03	
003136	004343	A	857	LSRA	3		01 00856
003137	053314	A	858	STA	TS03		01 00857
003138	004243	A	859	LRLA	3		01 00858
003139	053313	A	860	STA	TS02		01 00859
003140	013315	A	861	LDA	TS04		01 00860
003141	005311	A	862	BAR		REDUCE DIGIT COUNT	01 00861
003142	053315	A	863	STA	TS04		01 00862
003143	001000	A	864	JMP	IMG5		01 00863
003144	003061	A	865	*			01 00864
003145	000000	A	866	*	OUTPUT TWO CHARACTERS FROM A REG TO TTY (HIGH ORDER FIRST)		01 00865
003146	063317	A	867	*	ENTER WITH CHARACTERS IN A REG		01 00866
003147	*		868	*			01 00867
003148	*		869	DUTB	ENTR	0	01 00868
003149	*		870	STB	TS06	SAVE B	01 00869
003150	004550	A	871	LLSR	8		01 00870
003151	002000	A	872	CALL	OUTA	OUTPUT FIRST CHAR	01 00871
003152	002613	A	873	LLRL	8		01 00872
003153	004450	A	874	CALL	OUTA	OUTPUT SECOND CHAR	01 00873
003154	002000	A	875	LDB	TS06	RESTORE B	01 00874
003155	023317	A	876	JMP*	OUTB	RETURN	01 00875
003156	001000	A	877	*			01 00876
003157	103175	A	878	*	OUTPUT CARRIAGE RETURN AND LINE FEED TO TTY		01 00877
003158	*		879	*	OUTPUT OCTAL WORD AND A SPACE TO TTY		01 00878
003159	*		880	DUTC	ENTR	0	01 00879
003160	000000	A	881	LDAI	0106612	CR AND LF	01 00880
003161	006010	A	882	CALL	OUTB	OUTPUT 2 CHAR	01 00881
003162	106612	A	883	JMP*	OUTC	RETURN	01 00882
003163	003175	A	884	*			01 00883
003164	001000	A	885	*	OUTPUT OCTAL WORD AND A SPACE TO TTY		01 00884
003165	103210	A	886	*			01 00885
003166	*		887	DUTE	ENTR	0	01 00886
003167	005002	A	888	TZB			01 00887
003168	004557	A	889	LLSR	15		01 00888
003169	005122	A	890	IBR			01 00889
003170	*		891	*			01 00890

MAINTAIN III

TYTEST

PAGE 17

003223	006110	A	891	DUT2	DRAI	'0'	MAKE DIGIT	01 00891
003224	000260	A	892	CALL	DUTA		OUTPUT ONE DIGIT	01 00892
003225	002000	A	893	TZA				01 00893
003226	002613	A	894	LLRL	3			01 00894
003227	005001	A	895	JBZ	*+4		OCTAL OUTPUT COMPLETE	01 00895
003230	004443	A	896	JMP	DUT2			01 00896
003232	003235	A	897	LDAI	0240		ASCII BLANK CODE	01 00897
003233	001000	A	898	CALL	DUTA		OUTPUT SPACE	01 00898
003235	006010	A	899	JMP*	DUTE		RETURN	01 00899
003242	103217	A	900	*				01 00900
			901	*	OUTPUT MESSAGE TO TTY (X REG CONTAINS ADDRESS OF MESSAGE)			01 00901
			902	*				01 00902
003243	000000	A	903	DUTD	ENTR	0		01 00903
003244	015000	A	904	LDA	0,1			01 00904
003245	001010	A	905	JAZ*	DUTD			01 00905
003246	103243	A	906	CALL	DUTB			01 00906
003247	002000	A	907	IXR				01 00907
003250	003175	A	908	JMP	DUTD+1			01 00908
003253	003244	A	909	*				01 00909
			910	*	OUTPUT OCTAL MEMORY ADDRESS TO TTY PRINTER			01 00910
			911	*				01 00911
003254	000000	A	912	DUTF	ENTR	0		01 00912
003255	053313	A	913	STA	TS02		SAVE WORD	01 00913
003256	006010	A	914	LDAI	'('		PAREN SPACE	01 00914
003257	124240	A	915	CALL	DUTB		PRINT CHAR	01 00915
003261	003175	A	916	LDA	TS02			01 00916
003262	013313	A	917	JMPM	DUTE		OUTPUT OCTAL WORD	01 00917
003263	002000	A	918	LDAI		RIGHT PARENTHESIS	01 00918	
003264	003217	A	919	CALL	DUTA		PRINT CHAR	01 00919
003265	006010	A	920	JMP*	DUTF			01 00920
003266	000251	A	921	*				01 00921
003267	002000	A	922	*	I/O TIME-DUT SUBROUTINE			01 00922
003268	103301	A	923	*				01 00923
003273	005344	A	924	TOUI	DXR		TIME-DUT RETURN	01 00924
003274	001040	A	925	JXZ*	TOUT			01 00925
003275	103301	A	926	INR	TOUT		SET UP FOR	01 00926
003276	043301	A	927	INR	TOUT		NORMAL EXIT	01 00927
003277	043301	A	928	JMP	0			01 00928
003300	001000	A	929	TOUT	BES	0		01 00929
003301	000000	A	930	JMP	TOUI			01 00930
003302	001000	A	931	*				01 00931
003303	003273	A	932	*	TIME DELAY SUBROUTINE			01 00932
			933	*				01 00933
003304	000000	A	934	TDLY	EMIK	0		01 00934
003305	005344	A	935	DXR				01 00935
003306	001040	A	936	JXZ*	TDLY		RETURN	01 00936
003307	103304	A	937	JMP	*-3			01 00937
003310	001000	A	938	*				01 00938
003311	003305	A	939	*	DATA TABLE			01 00939
			940	*				01 00940
003312	000000	A	941	TS01	DATA	0	TEMPORARY STORAGE	01 00941
003313	000000	A	942	TS02	DATA	0	TEMPORARY STORAGE	01 00942
003314	000000	A	943	TS03	DATA	0	TEMPORARY STORAGE	01 00943
003315	000000	A	944	TS04	DATA	0	TEMPORARY STORAGE	01 00944
003316	000000	A	945	TS05	DATA	0	TEMPORARY STORAGE	01 00945
003317	000000	A	946	TS06	DATA	0	TEMPORARY STORAGE	01 00946
003320	000000	A	947	TS07	DATA	0	TEMPORARY STORAGE	01 00947
			948	*				01 00948
			949	*	MESSAGE TABLE			01 00949
			950	*				01 00950
003321	120240	A	951	MSG5	DATA	' INVALID',0106612, 0		01 00951
003322	144716	A						
003323	153301	A						
003324	146311	A						
003325	142240	A						
003326	106612	A						
003327	000000	A						
003330	000500	A	952	TBER	BSS	1	ERROR TABLE	01 00952
			953	END	TKCP			01 00953

ENTRY NAMES
EXTERNAL NAMES
SYMBOLS02644 A STTY 105215 A CRLF 001121 A CS01 102000 A EDTX
00675 A HDG1 000716 A HDG2 000726 A HDG3 000743 A HDG4

000762	A	HDG5	001245	A	HDG6	002067	A	HDG7	002105	A	HDG8
002566	A	IMAI	002545	A	INB1	002703	A	INC1	002705	A	INC2
002661	A	IMC3	002741	A	IMB1	002743	A	IND2	002751	A	IND3
002715	A	IND4	003002	A	INE1	003004	A	INE2	002755	A	INE3
003042	A	INF1	003044	A	INF2	003040	A	INF3	003036	A	INF4
003012	A	INF5	003163	A	ING1	003136	A	ING2	003132	A	ING3
003134	A	ING4	003067	A	ING5	003146	A	ING6	003061	A	ING7
003157	A	ING8	002610	A	INPA	002656	A	INPE	002710	A	INPC
002746	A	INPD	003007	A	IMPE	003047	A	INPF	003143	A	IMPG
000416	A	I OCT	001002	A	KC	001003	A	KE	003321	A	MSSG
002415	A	DET	002442	A	DET2	002447	A	DET3	002467	A	DETA
002501	A	DET5	002513	A	DETS	000400	A	DU1C	000403	A	DUMB
002640	A	DUT1	003223	A	DUT2	002613	A	DUTA	003175	A	DUTB
003210	A	DUTC	003243	A	DUTD	003217	A	DUTE	003254	A	DUTF
003052	A	OUTG	000256	A	PERIOD	001004	A	PR	001501	A	PRO1
001512	A	PRO2	001521	A	PR03	001556	A	PR04	001572	A	PRO5
001600	A	PRO6	001633	A	PR07	001646	A	PR08	001725	A	PRO9
001731	A	PR10	001762	A	PR11	002036	A	PRND	002556	A	PRW1
002557	A	PRW2	002560	A	PRW3	002561	A	PRW4	002562	A	PRW5
002563	A	PRW6	001005	A	PS	001330	A	PS20	001345	A	PSTBL
001006	A	PT	001007	A	RT	002346	A	RTND	100452	A	STAR
001010	A	STID	000537	A	TATT	003330	A	TBER	001071	A	TCS1
003304	A	T DLY	000524	A	TIDA	000572	A	TIID	001023	A	TKC2
001025	A	TKC3	001041	A	TKC4	001053	A	TKC5	001055	A	TKC6
000500	A	TKCP	001011	A	TKCT	001233	A	TKET	001126	A	TKK1
001202	A	TKK2	001231	A	TKW1	001232	A	TKW2	003273	A	TOU1
003301	A	T DUT	001445	A	TPRT	001767	A	TPS4	001326	A	TPST
001264	A	TPT1	001274	A	TPT2	001307	A	TPT3	001261	A	TPTT
001325	A	TPW1	002141	A	TR00	002151	A	TR01	002201	A	TR02
002225	A	TR03	002235	A	TR04	002242	A	TR05	002257	A	TR06
002334	A	TR07	002273	A	TR08	002403	A	TRBF	000520	A	TRDA
000566	A	TRID	000665	A	TRS8	002120	A	TRTT	003312	A	TS01
003313	A	TS02	003314	A	TS03	003315	A	TS04	003316	A	TS05
003317	A	TS06	003320	A	TS07	000655	A	TSRR	002516	A	TTBC
002017	A	TTBL	000514	A	TTPI	002031	A	TTSI	002526	A	TTY1
002551	A	TTYC	002561	A	TYDE						

002531 A TYPE 002066 A TYPE
0 ERRORS ASSEMBLY COMPLETE

GERMAN
LITERATURE

INTERVIEW
POINTERS

MAINTAIN III

TYTEST

616	DETS	590	614						
624	DETS	583	584	585	618	619	620		
75	DVIC	82	84	86					
76	DUMG	88	90	148	152				
691	DUT1	683	686						
891	DUT2	896							
676	DUTA	99	101	103	105	181	195	215	252
		278	323	339	345	356	364	412	505
		635	693	700	872	874	892	898	919
869	DUTB	605	876	882	906	915			
880	DUTC	106	125	172	186	248	316	453	454
		461	464	565	567	570	573	576	579
		883							600
903	DUTD	112	145	174	188	236	304	593	803
		908							905
887	DUTE	457	460	463	569	572	575	578	602
		899	917						
912	DUTF	920							
801	DUTG	748	785	804	853				
299	PERIOD	295							
164	PR	133							
319	PRO1	*							
323	PRO2	326							
331	PRO3	325							
348	PRO4	358							
356	PRO5	347	421						
359	PRO6	355							
371	PRO7	375							
372	PRO8	392							
406	PRO9	402							
409	PRO10	399	424						
422	PR11	405							
453	PRND	332	340	357	365	372	378	394	410
648	PRW1	379	381	395	397	403	406	445	488
		501	530	554	561				
649	PRW2	335	456	476	568	586			
650	PRW3	336	451	459	477	571			
651	PRW4	318	443	449	481	589	612	617	
652	PRW5	337	408	462	478	563	574		
653	PRW6	479	551	577					
165	PS	136							
275	PS20	282							
283	PSTBL	274							
166	PT	139							
167	RT	142							
565	RTMD	487	542	546					
296	STAR	283	283	284	284	285	285	285	286
		286	287	287	288	288	289	289	289
		290	291	291	292	292	292	293	293
168	STID	118	126	129	132	135	138	141	
98	TATT	120	205	238	253	279	306	465	483
952	TEER	317	480	588	594	616			580
201	TCS1	177	191	208	216	217	218	219	220
934	TDLY	637	638	639	640	936			
91	TIIDA	*							
113	TIID	*							
177	TKC2	185							
178	TKC3	*							
186	TKC4	184							
191	TKC5	199							
192	TKC6	*							
81	TKCP	953							
172	TKCT	128	198						
235	TKET	131							
222	TKK1	173	175						
227	TKK2	187	189						
230	TKW1	180	194	203	210	212			
231	TKW2	178	192	213					
924	TDU1	930							
929	TOUT	514	687	925	926	927			
303	TPRT	134	308						
426	TPS4	350	386	430	432	434	436	438	439
874	TPST	137	281						
247	TPT1	256							
252	TPT2	257							
259	TPT3	250	254	264	266				
245	TPTT	140							
267	TPW1	246	249	251					
482	TR00	557							
486	TR01	498	500	550					
501	TR02	496							
513	TR03	510	516	520					
517	TR04	512	513						
521	TR05	515							
529	TR06	540	564						
558	TR07	523	525						
538	TR08	526							
581	TRBF	506	522	528	559				
89	TRDA	93	150						
111	TRID	115	116	121	122	146	154		
151	TRSS	114							
472	TRTT	143							
941	TS01	677	692						
942	TS02	759	764	811	826	831	860	913	916

943	TS03	812	827	844	856	858			
944	TS04	813	832	833	861	863			
945	TS05	820	848						
946	TS06	870	875						
947	TS07	814	843						
147	TSSR	92							
625	TTBC	630							
440	TTBL	383	407	452	499	503	535	555	562
87	TTPI	*							
450	TTS1	441							
631	TTY1	646							
645	TTYC	319	320	333	359	360	361	369	370
		413	417	455	472	473	474	566	587
		632	633	641	642	643			631
466	TYPE	315	398	400	414	423			