

Burroughs

B 1000 Series SMCS


Reference Card

(Relative to SMCS 10.0.007)

ATTACH

Attaches a station to a program or remote file.


Controller and system ODT syntax:



BROADCAST

Sends a message to all logged-on stations.

Syntax:



BYE

Logs the user off the SMCS program.


Workstation, remote ODT, and controller syntax:



CHANGE

Changes various station attributes.


Controller and system ODT syntax:



CLEAR

Clears a remote file.

Controller and system ODT syntax:



CLOSE Command

Closes the JOBS file.


Controller and system ODT syntax:



CONTINUE Command

Causes a step macro procedure to resume.


Workstation, remote ODT, and controller syntax:



DETACH

Detaches a station from a program or remote file.

Controller and system ODT syntax:



DUMP

Causes an SMCS program dump to be created.


Controller and system ODT syntax:



DYNAMIC

Controls the method by which stations are marked off-line.


System ODT syntax:



FILE

Provides information on a file.


Syntax:



HARDWARE

Specifies the recordsize of the TRACE file.

System ODT syntax:



HELP

Provides a list of all valid commands for the station.

Syntax:

HELP

ID

Assigns an identifier to the station.

Workstation, remote ODT, and controller syntax:

ID <identifier> [<command string>] [<macro procedure>]

INITIATE

Initiates a program in the JOBS file at the system ODT.

System ODT syntax:

INITIATE <program-id>

JOB

Returns information on jobs in the mix.

Workstation, remote ODT, and controller syntax:

JOB

LOGON

Adds, changes, deletes, or lists the default log-on command.

Workstation, remote ODT, and controller syntax:

LOGON ADD <logon command>
CHANGE [<macro procedure>]
DELETE
LIST

MACRO

Adds, changes, deletes, or lists macro procedures.

Controller syntax:

MACRO ADD <macro name> <macro text>
CHANGE
DELETE <macro name>
LIST <macro name>
ON

Workstation and remote ODT syntax:

MACRO ADD <macro name> <macro text>
CHANGE
DELETE <macro name>
LIST <macro name>

System ODT syntax:

MACRO ON

MAIL

Writes messages to the MAIL file.

Syntax:

MAIL <identifier> <message string>

MAKE

Changes certain station attributes.

Workstation and remote ODT syntax:

MAKE SCROLL REVERSE
NOT SIGNAL <character>

Controller syntax:

MAKE STATION <lsn> NOT CON
SIGNAL <character>
SCROLL REVERSE
NOT

System ODT syntax:

MAKE STATION <station name> NOT CON READY
ODT

MOVE

Reroutes messages from one station to another station.

Controller and system ODT syntax:

MOVE <number> ALL FROM STATION <station name>
ONE
> TO STATION <dest lsn>
<dest name>

NEWS

Displays or changes the news message.

Workstation and controller syntax:

NEWS

Remote ODT and system ODT syntax:

NEWS <news message>

PASS

Requests a function of a program without signing on to the program.

Workstation, remote ODT, and controller syntax:

PASS <program-id> <data string>

PASSWORD

Sets or resets the COBOL74 password.

System ODT syntax:

PASSWORD <password>

READY

Makes a station ready.

Syntax:


READY <lsn> <station name>

To obtain a cobol XREF
* EX COBOL/XREF FILE CANDYNAME (CASECODE)/PROGRAMNAME.PHRD.RK

REMOVE

Removes messages from a station.


Controller and system ODT syntax:



REPORT

Displays information on the status of a station or stations.


Syntax:



SEND

Sends a message to the specified stations.


Syntax:



SIGN OFF

Detaches a user from a program.


Workstation, remote ODT, and controller syntax:



SIGN ON

Attaches a user to the specified program.


Workstation, remote ODT, and controller syntax:



SIGNAL

Changes the SMCS signal character for all stations.


Controller and system ODT syntax:



STATUS

Displays the current status of a station, program, or remote file.

Syntax:



STOP

Terminates the SMCS program in an orderly manner.


System ODT syntax:




SYSTEM

Displays information on the SMCS version, translate option, and system Hostname, and changes the translate option.

Workstation syntax:




Remote ODT and system ODT syntax:



TABS

Sets the tab stops on a terminal.

Syntax:



TERMINATE

Terminates a step macro procedure.


Workstation, remote ODT, and controller syntax:



TRACE

Invokes the SMCS tracing facilities.


Controller and system ODT syntax:



TRANSLATE

Sets or resets the translate option for a station.


Workstation, remote ODT, and controller syntax:



USER

Logs a user on to the SMCS program.


Workstation, remote ODT, and controller syntax:



ZIP

Spawns an unsecured MCP control string.


Remote ODT syntax:



? < MCP control instruction >

Spawns a secured MCP control string.

Workstation, remote ODT, and controller syntax:



NOTES