


74700600



**COMMUNICATIONS CONTROL
PROGRAM, VERSION 1.0
SOFTWARE DIAGNOSTIC
HANDBOOK**

**CONTROL DATA®
2550 SERIES MODELS 2550-1, 2550-2**




74700600



**COMMUNICATIONS CONTROL
PROGRAM, VERSION 1.0
SOFTWARE DIAGNOSTIC
HANDBOOK**

**CONTROL DATA®
2550 SERIES MODELS 2550-1, 2550-2**



PREFACE

This handbook describes messages associated with Version 1.0 of the Communications Control Program (CCP 1.0), that is used with the CONTROL DATA® 2550 Series Host Communications Processor (HCP). The CCP is the operating software for the HCP, which provides front-end functions for a CDC 6000 or CYBER 70/170 host computer system. The CYBER host system operates under control of the SCOPE 3.4 operating system.

The purpose of these descriptions is to assist system operators and system analysts (CES) in the isolation of system faults. Any codes appearing within these messages are also described and defined, and brief instructions on dump interpretation are also provided.

Only two types of messages useful in trouble isolation are reported by the CCP. These are halt code messages and on-line diagnostic response messages. Additionally, upline memory dumps of the contents of the 2550 main memory, micromemory, and file registers are also useful for fault isolation. Section 1 of this handbook describes the halt code messages, Section 2 describes the on-line diagnostic response messages, Section 3 provides instructions for dump interpretation, and Section 4 describes procedures to be taken to isolate problems relating to communications lines. The procedures in Section 4 include use of the on-line diagnostic programs and descriptions of help obtainable from the telephone company.

Within Sections 1 and 2, the messages are arranged in alphanumeric order by halt code or diagnostic response code.

Further information related to the 2550 Series HCP software as well as hardware is contained in the publications listed below. These publications are available through the nearest Control Data Corporation sales office.

<u>Publication</u>	<u>Pub. No.</u>
Communications Control Program, Version 1.0 - Software Operator's Guide	74701400
SCOPE 3.44 Installation Handbook	60307400
Communications Control Program, Version 1.0 - Software Reference Manual	74701200
2550-2 Host Communications Processor - Hardware Reference Manual	74700500
Communications Handbook	60405100
MSMP Diagnostic Reference Manual	96700000
Bell System Data Communications Technical Reference Data Communications Using Voiceband Private Line Channels, October 1973	41004
Bell System Technical Reference - Data Set 208A Interface Specification, November 1973	41209

The following specialized terms used in this handbook are explained below to facilitate understanding of the message descriptions:

<u>Term</u>	<u>Meaning</u>		
BSN	Block Serial Number	HIP	Host Interface Program
CCP	Communications Control Program	Host	CDC 6000/CYBER 70/170 Computer for which the 2550 HCP acts as a "front end"
CE	Customer Engineer - system maintenance and repairman	MLIA	Multiplex Loop Interface Adapter
CLA	Communications Line Adapter	Modem	Modulator-demodulator equipment used to send digital information over telephone lines
CN	Connection Number	Mux	Multiplexer
Data Set	Telephone company equivalent of Modem	POI	Point of Interface
DN	Destination Node	PT	Port - Physical CLA Slot
Dump	Printout of 2550 HCP core memory, micro-memory, and file registers contents	RC	Response Code
HCP	2550 Host Communications Processor	SN	Source Node
Hex	Hexadecimal (base 16) notation	SP	Subport (N/A on this system)
		TIP	Terminal Interface Program

CONTENTS


1. HALT CODE MESSAGES	1-1	3. DUMP INTERPRETATION	3-1
Introduction	1-1	Introduction	3-1
Code Categories	1-1	Interpretation Instructions	3-1
2. DIAGNOSTIC TEST RESPONSES	2-1	4. COMMUNICATIONS LINE FAULT ISOLATION	4-1
Introduction	2-1	Introduction	4-1
Message Categories	2-1	CLA Internal and External Loopback Test Modes	4-1
Diagnostic TIP Command	2-1	Information Required	4-1
CLA Command Error	2-1	External Data Loopback	
CLA Turnaround Error	2-1	Tests	4-4
CLA Command or Data Turn- around Error	2-1	Suggested Loopback Test	
Diagnostic Test Responses	2-2	Sequence	4-4
Codes			

APPENDIXES

A System Messages	A-1	D Data Line Problem Solving	D-1
B Telephone Company Assistance	B-1		
C Everything You've Always Wanted to Know About the Telephone Company	C-1		

TABLES

1-1 System Halt Codes	1-2	4-1 Common Modems and Loopback Tests Available	
2-1 Diagnostic Test Response Codes	2-3		4-2
3-1 Address Table Contents	3-3		



HALT CODE MESSAGES

1

INTRODUCTION

When the CCP 1.0 system detects an unrecoverable condition caused by either a hardware or software malfunction, an appropriate halt code message is printed. When such a halt occurs, the host processor normally executes an upline dump of the 2550 main memory, micromemory, and file registers. Thereafter, the host attempts to reload the 2550 memory. If the halt condition persists, the 2550 operator is requested to switch the 2550 coupler off-line (to prevent the host from continuing its reloading attempts) and to attempt to correct the fault causing the persistent halts. The following halt code descriptions are provided in correcting these faults.

CODE CATEGORIES

Halt codes can be divided into three categories: 1) Those primarily resulting from incorrect switch settings, 2) those caused by hardware malfunctions, and 3) those that can be either hardware or software problems.

In the first category falls detection of a duplicate CLA address (halt code 12). This condition is usually caused by two CLA switches being set to the same address. Such a fault can normally be corrected by the operator correctly setting the switches.

Under the second category of halt codes are the following:

- Power failures (code 01)
- Memory parity error (code 02)
- Memory protect bit error (code 03)
- Bad MLIA initialization status (code 11)
- Real-time clock lost count (code 18)
- Bad coupler initialization status (code 0E)
- MLIA failure (code 1F)
- Coupler detection of memory parity or program protect errors (code 28)

Such conditions are usually caused by some type of hardware failure and normally must be repaired by a CE.

The third category of halt codes (all those not already specified) may be caused either by a hardware failure or by a software error. For the first three months following installation, these halts are more likely to result from software problems. After three months of service, most software problems will have been found and corrected and, thereafter, most such halts will be caused by hardware malfunctions. To correct this category of problems, the CE should normally first be called to check the hardware. If the hardware is functioning properly, a system analyst should be called.

NOTE

Make available all upline dumps taken by the host to the CE and system analyst.

Table 1-1 lists all the halt codes, their meanings, and the suggested action to be taken when they occur.

TABLE 1-1. SYSTEM HALT CODES

Halt Code	Meaning	Suggested Action
000	Not a valid halt code	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
001	Power failure	Hardware problem. Call CE to check power problem.
002	Memory parity error detected by 2550	Hardware problem. Call CE to check memory parity.
003	Program protect bit error detected by 2550	Hardware problem. Call CE to check memory program protect bit logic.
004	Interrupt count less than zero (Pascal tried to enable interrupts more times than it inhibited them)	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
005	TIMAL (base system timing services) worklist error	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
006	Active line control block list error	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.

TABLE 1-1. SYSTEM HALT CODES (CONT'D)

Halt Code	Meaning	Suggested Action
007	No buffer left	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
008	Size error in stamp	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
009	Duplicate GET buffer	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
00A	Duplicate RELEASE buffer	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
00B	Buffer CHAIN error	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
00C	Buffer out-of-range	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
00D	BAD Command, not Type 1 or Type 2	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.

TABLE 1-1. SYSTEM HALT CODES (CONT'D)

Halt Code	Meaning	Suggested Action
00E	Bad coupler initialization status.	Hardware problem. Call CE to run coupler diagnostics.
00F	Attempted to clear an enabled line	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
010	Not a valid halt code	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
011	Bad MLIA (Multiplex Loop Interface Adapter) initialization status	Hardware problem. Call CE to run multiplexer subsystem diagnostics on MLIA and loop.
012	Duplicated CLA address detected	Either two CLAs are set to the same address (check CLA address switches on handles of CLA circuit cards) or a CLA circuit card is bad (hardware problem). To check duplicate CLA address, access first entry in NPINTAB table in ADDRESS table (fixed core location). The first entry in NPINTAB table contains duplicate CLA address. If two CLAs are not set to that address, call CE to run off-line CLA diagnostics. Provide upline dumps to CE.

TABLE 1-1. SYSTEM HALT CODES (CONTD)

Halt Code	Meaning	Suggested Action
013	Attempt to redefine an existing destination node (DN) directory entry	May be either hardware or software problem or host software error. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
014	Attempt to redefine an existing connection number (CN) directory entry	May be either hardware or software problem or host software error. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
015	Attempt to remove a non-existing destination node directory entry	May be either hardware or software problem or host software error. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
016	Attempt to remove a non-existing source node (SN) directory entry	May be either hardware or software problem or host software error. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
017	Attempt to remove a non-existing connection number directory entry	May be either hardware or software problem or host software error. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.

TABLE 1-1. SYSTEM HALT CODES (CONT'D)

Halt Code	Meaning	Suggested Action
018	Real-time clock lost count	Real-time clock or firmware problem. Call CE to run real-time clock and firmware diagnostics.
019	Illegal point of interface (POI) key	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
01A	Attempt to add a zero connection number (CN) to the directories	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
01B	Program selected to run is not in core.	May be hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
01C	Monitor did not run for B2TIME/2 seconds	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
01D	Service module called with worklist empty.	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.

TABLE 1-1. SYSTEM HALT CODES (CONT'D)

Halt Code	Meaning	Suggested Action
01E	Service module workcode out-of-range	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
01F	Multiplex Loop Interface Adapter (MLIA) failure	Hardware problem. Call CE to run MLIA and loop diagnostics.
020	Pointer to read next loop cell from CIB (circular input buffer) exceeded present line frame pointer	May be either hardware or software problem. Call CE to run Multiplexer Subsystem diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
021		May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
022		
023	Reserved for firmware use (not valid halt codes)	
024		
025		
026		
027		
028	Coupler Alarm Condition (Coupler detected Memory Parity Error or Program Protect Bit Error during data transfer)	Hardware problem. Call CE to run Memory diagnostics.

TABLE 1-1. SYSTEM HALT CODES (CONT'D)

Halt Code	Meaning	Suggested Action
029	No queue control block available for terminal control block build. (Implemented but not called by CCP 1.0)	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
02A	Bad line number from TIP. (Invalid line number passed from TIP to service module as worklist entry. Out-of-range line number.)	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
02B	Unknown TASKNR (task number) selected. Non-existent task number for Mode 4 TIP.	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
02C	Unknown block/command received. (No command, block, message, or service message in TIP output queue. Part of Mode 4 TIP.)	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.

TABLE 1-1. SYSTEM HALT CODES (CONT'D)

Halt Code	Meaning	Suggested Action
02D	Improper multiplex subsystem operation. (Non-reject, non-ack, non-error, non-read E1, non-read E2, or non-read E3 worklist entry made following input.)	May be hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
02E	Improper Mode 4 TIP operation (unacceptable task)	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
02F	Control for disabled line. (Mode 4 TIP attempted to run on disabled line.)	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
030	Reserved for Mode 4 TIP (not a valid halt code)	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
031	Error in header builder (PNHDRBLD)	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.

TABLE 1-1. SYSTEM HALT CODES (CONT'D)

Halt Code	Meaning	Suggested Action
032	Not a valid halt code	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
033	Illegal line status software condition detected by PTCLAS (CIA status)	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
034	Not a valid halt code	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
035	Attempt to queue message to NPU console when console not configured into system	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
036	Directory function attempted with Directory Number (DN) out-of-range. (DN C3MAXDN)	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.
037	Not valid halt codes and up	May be either hardware or software problem. Call CE to run 2550 diagnostics. If hardware checks good, call System Analyst and provide upline dumps.

DIAGNOSTIC TEST RESPONSES

2

INTRODUCTION

The CCP 1.0 programs include an on-line diagnostic test that can be invoked from the 2550 console to perform data and status tests on one or more communications lines. Performance of these tests does not impact services to other lines in the system.

The on-line diagnostic test programs can test a communications line in any of three different modes:
1) CLA internal loopback mode (tests all CLA logic except modem drivers and receivers), 2) external data loopback mode (isolates modem and transmission line problems), or
3) CLA external loopback (modem drivers and receivers). Directions for operating these programs are found in the CCP 1.0 Operator's Guide. (Refer to Preface.)

MESSAGE CATEGORIES

While running the on-line diagnostic test programs, various diagnostic test responses may be received at the 2550 console. These messages fall into four categories: 1) responses to commands to the diagnostic TIP, 2) CLA command errors detected, 3) CLA data turnaround errors detected, or 4) either a CLA command or data turnaround error.

DIAGNOSTIC TIP COMMAND

Responses to commands to the diagnostic TIP are informational in nature. They concern the state of a line (line in service or line out of service), state of the diagnostic test (test started or completed), or indicate improper command information has been given (such as an invalid CLA type or invalid test

mode). Responses in this category do not indicate the source of any problems for the line or lines being tested, but rather indicate the status of the test or some improper operation of the test.

Included in this category are diagnostic test responses A0 through AA and CE.

CLA COMMAND ERROR

Diagnostic test responses indicating CLA command errors generally imply that an expected status response from the CLA has not been received. Such errors are usually detected while running the status and command portion of either the CLA internal or external loopback tests and normally indicate a faulty CLA. Included in this category of diagnostic test responses are B5, BA through C4, and CF.

CLA DATA TURNAROUND ERROR

Responses indicating CLA data turnaround errors are caused either by receipt of status information from the CLA that indicates a data error or by a faulty data comparison upon loopback. Again, this type of error is normally detected during the CLA internal or external loopback tests and indicates a faulty CLA. If the errors are detected only in the external loopback test, a faulty modem or transmission line is indicated. Included in this category are diagnostic test responses AF through B2 and C5 through CD.

CLA COMMAND OR DATA TURNAROUND ERROR

The fourth category of diagnostic test responses, indicating either a

CLA command error or a data turn-around error, could occur during any portion of the tests. If detected during the CLA internal or external loopback tests, it normally indicates a faulty CLA. If the errors are detected only during the external data loopback mode, it normally indicates either a bad modem or transmission line. Included in this category are diagnostic test responses AB through AE, B3 and B4, and B6 through B9.

DIAGNOSTIC TEST RESPONSE CODES

Table 2-1 lists all of the on-line diagnostic test responses, gives their meanings, and suggests actions to be taken when the error message occurs.

NOTE

Even though good, a CLA may fail the diagnostic test the first time that the test is run after the CLA is installed in the system. Therefore, disregard the results of the first run and rerun the diagnostic test a second time.

The message format is as follows:

0	1	2	3	4	5	6	7	8	9	
DN	SN	00	01	BSN	00	04	00	RC	PT	SP

where:
DN = Destination node
SN = Source node
BSN = Block serial number
RC = Response code
PT = Port (CLA address)
SP = Subport (not applicable = 00)

TABLE 2-1. DIAGNOSTIC TEST RESPONSE CODES

Response Code	Meaning	Suggested Action
A0	Line is out of service. Normal response to "place line out of service" command.	None
A1	Command rejected. System temporarily low on buffers	Reissue command
A2	Line in service. Normal response to "place line in service" command	None
A3	Diagnostics in process. Response to "place line in service" command if diagnostic tests are in process	Wait for response at completion of diagnostic tests before placing line back into service
A4	Diagnostic started. Normal response to "start CLA loop internal test", "start CLA loop external test", or "start external data loopback test"	None
A5	Invalid line number or bad command. Invalid line number or byte 5 in command	Check for proper line number or proper command and reissue

TABLE 2-1. DIAGNOSTIC TEST RESPONSE CODES (CONT'D)

Response Code	Meaning	Suggested Action
A6	Invalid CLA type issued in command	Check for proper CLA type and reissue command
A7	Invalid test mode issued in command (byte 6)	Check for proper test mode and reissue command
A8	Line not out of service.	Check for proper line number and, if correct, issue "line out of service" command and restart diagnostic
A9	Response to start of diagnostic mode if line is not out of service	Check for proper line number and, if incorrect, reissue command with correct line number. If correct, wait for previous diagnostic test to complete and reissue command.
AA	Test already in process.	None
	Response to start of diagnostic mode if line specified is already running a diagnostic	
AB	Test completed - no errors. Normal response upon completion of diagnostic test Unsolicited input detected. In either CLA loop internal or external test, indicates bad CLA. If only occurs in data loopback test mode, indicates bad modem or transmission line	If bad CLA indicated, call CE to replace CLA. If bad modem or transmission line indicated, follow directions under Line Problem Solving section, Appendix D.

TABLE 2-1. DIAGNOSTIC TEST RESPONSE CODES (CONT'D)

Response Code	Meaning	Suggested Action
AC	Unsolicited output data demand detected	Same action as for code AB.
AD	Input loop error (IIE status detected)	Same action as for code AB.
AE	Output loop error (OIE status detected)	Same action as for code AB.
AF	Parity error (PES status detected)	Same action as for code AB.
B0	Framing error (FES status detected)	Same action as for code AB.
B1	Data transfer overrun (DID status detected)	Same action as for code AB.
B2	Next character not available (NCA status detected)	Same action as for code AB.
B3	No CLA status after CLA status was requested. (ISR command did not cause status to be reported.	Bad CLA, call CE to replace CLA.

TABLE 2-1. DIAGNOSTIC TEST RESPONSE CODES (CONT'D)

Response Code	Meaning	Suggested Action
B4	Unsolicited CLA status.	Same action as for code AB.
B5	CLA status not cleared after ISON (Input Supervision On) sent.	Bad CLA, call CE to replace CLA.
B6	No status after RTS (Request to Send) or ISR (Input Status Request) sent.	Same action as for code AB.
B7	CTS status not responding correctly to RTS on/off commands.	Same action as for code AB.
B8	No status after DTR (Data Terminal Ready). DTR command did not cause DSR status.	Same action as for code AB.
B9	DSR status not responding correctly to DTR on/off commands or other status received rather than DSR.	Same action as for code AB.
BA	SQD status not responding correctly to DTR on/off commands.	Bad CLA, type 2560-1. Call CE to replace CLA.

74700600 A

TABLE 2-1. DIAGNOSTIC TEST RESPONSE CODES (CONT'D)

Response Code	Meaning	Suggested Action
BB	No RI (Ring) after cycling DTR command on and off.	Bad CLA, type 2560-1. Call CE to replace CLA.
BC	No status after SRTS (Secondary Request to Send). SRTS command did not cause SRLSD status.	Bad CLA, type 2561-1. Call CE to replace CLA.
BD	SRLSD (Secondary Received Signal Detector) status not responding correctly to SRTS on/off commands, or other status received rather than SRLSD.	Bad CLA, type 2561-1. Call CE to replace the CLA.
BE	No CLA status after commanding on LM (Local Mode). Expected RLSD (Received Signal Detector) status.	Bad CLA, type 2561-1. Call CE to replace CLA.
BF	RLSD status not responding correctly to LM on/off commands.	Bad CLA, type 2561-1. Call CE to replace CLA.
CO	Unsolicited CLA status after OM (Originate Mode) on command.	Bad CLA, type 2561-1. Call CE to replace CLA.

TABLE 2-1. DIAGNOSTIC TEST RESPONSE CODES (CONT'D)

Response Code	Meaning	Suggested Action
C1	No CLA status or improper RI (Ring Indicator) status after toggling TB (Terminal Busy) command.	Bad CLA, type 2561-1. Call CE to replace CLA.
C2	NO CLA status after turning on NSYN (New Sync) command.	Bad CLA, type 2560-1, 2, or 3. Call CE to replace CLA.
C3	Improper RLSD or RI or QM status when commanding NSYN on/off.	Bad CLA, type 2560-1, 2, or 3. Call CE to replace CLA.
C4	Unwanted RI (Ring Indicator) status. RTS (Request to Send) command just turned on.	Bad CLA. Call CE to replace CLA.
C5	Input data timeout during data verification test.	Same action as for code AB.
C6	Data compare error (CLA Type 2561-1, 9600 baud, even parity, 1 stop bit)	Same action as for code AB.
C7	Data compare error (CLA type 2561-1, 1200 baud, odd parity, 2 stop bits)	Same action as for code AB.

TABLE 2-1. DIAGNOSTIC TEST RESPONSE CODES (CONT'D)

Response Code	Meaning	Suggested Action
C8	Data compare error (CLA Type 2561-1, 800 baud, no parity, 1 stop bit)	Same action as for code AB.
C9	Data compare error (CLA Type 2561-1, 85.4 baud, no parity, 2 stop bits)	Same action as for code AB.
CA	Data compare error (CLA Type 2561-1, 40 baud, even parity, 1 stop bit)	Same action as for code AB.
CB	Data compare error (CLA Type 2560-1, 2, or 3. No parity, Sync Char = 16 hex)	Same action as for code AB.
CC	Data compare error (CLA Type 2560-1, 2 or 3. Even parity, Sync Char = 16 hex)	Same action as for code AB.
CD	Data compare error (CLA Type 2560-1, 2 or 3. Odd parity, Sync Char = 16 hex)	Same action as for code AB.

TABLE 2-1. DIAGNOSTIC TEST RESPONSE CODES (CONT'D)

Response Code	Meaning	Suggested Action
CE	Diagnostic not in progress. Response to a "Terminate Test Command" if not preceded by a "Start Diagnostic" command.	Check that proper CLA address used in each message.
CF	Unsolicited status after LM (Local Mode) command to CLA.	Bad CLA, Type 2561-1. Call CE to replace CLA.

INTRODUCTION

At most times when a halt occurs and at all times when using the on-line diagnostic programs, halt codes and diagnostic test responses are printed at the 2550 console and dump interpretation is not needed. However, 1) if a halt occurs after loading but before completion of initialization or 2) if the system becomes trapped in a looping condition during initialization (before the CCP 1.0 header prints), dump interpretation may be necessary to determine which halt has occurred or in which subroutine of the initiation section the program is looping.

INTERPRETATION INSTRUCTIONS

When interpreting the upline dump printout to determine the cause of a halt or looping condition, first examine the contents of memory loca-

tion 30 (hexadecimal) as reflected in the dump printout. If nonzero, a halt has occurred and the halt code value is contained in that location. Refer to that value in table 1-1 and perform the suggested action for that halt.

If memory location 30 (hexadecimal) equals zero, examine the contents of the NPINTAB entry in the Address table which begins at fixed memory address 150 (hexadecimal). Table 3-1 lists the contents of the Address table. Entry NPINTAB gives the starting address for the NPINTAB table, the format of which is illustrated below. The NPISFL entry in the NPINTAB table contains the flags of the initialization subroutines that have completed running when the looping condition occurred. This information should be given to the system analyst along with the dump printouts.

	Bits	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
WORD 0 (NPSODD)		0	0	0	0	0	0	0	X	X	X	X	X	X	X	X	X
WORD 1 (NPISFL)		B15	0	0	0	0	0	0	B7	B6	B5	B4	B3	B2	B1	B0	
WORD 2 (NPBMLS)		Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	
WORD 3 (NPBCOS)		Z	Z	Z	Z	Z	Z	Z	Z	Z	Z	Z	Z	Z	Z	Z	

NPSODD = Duplicate CLA address, where XX...XX is the duplicated CLA address between hexadecimal 01 and FE. Hexadecimal 00 indicates preset value (no duplicates) and hexadecimal FF indicates no response.

NPISFL = Initialization completion sequence flags, where
B15 and B7 through B0 indicate completion of
various tasks as follows:

B15 = All buffers initialized, system initiali-
zation completed

B7 = Initialize lines completed

B6 = Initialize MLIA completed

B5 = Miscellaneous console initialization
completed

B4 = Initialize monitor tables completed

B3 = Initialize worklist control blocks com-
pleted

B2 = Initialize buffers completed

B1 = Set up program protect bits completed

B0 = Initialize multiplexer firmware completed

NPEMLS = Bad MLIA initialization status, where any value
for YY...YY other than hexadecimal 0009 indicates
bad status. Call CE to run MLIA diagnostics.

NPBCOS = Bad coupler initialization status, where any
value for ZZ...ZZ other than hexadecimal 0000
indicates bad status. Call CE to run coupler
diagnostics.

TABLE 3-1. ADDRESS TABLE CONTENTS

Entry	Meaning
BYWLCB	Worklist control block
JSWLADDR	Worklist entry addresses by LEVELNO
B1TCB	Internal processing terminal control block (TCB)
B1BUFF	Internal processing block pointer
JKMASK	Interrupt masks
JKTMASK	PBAMask save area
CBTIMTBL	Timer table
JACT	PD controller table
BECTLBK	Buffer control block
BEBSA	Buffer stamp area
CLBFSPACE	Total buffer space in number of small buffers
BKPIKT	Point of interface (POI) table
J1UERRSTAT	Upline error statistics message routing
J1USVM	Upline service message routing
J1DSVM	Downline service message routing
NAPORT	PORT table
BQCIB	Circular input buffer
NFCCST	CLA command status table
MLSTABLE	CLA current status table
CGLCBS	Line control blocks (LCB)
CHSUBLCB	Sub line control blocks
BJTIPTYPT	Terminal interface program (TIP) type table
NJTECT	Terminal characteristics table
NPINTAB	Initialization sequences completed and errors table

NOTE

Fixed core address table starts
at location 150 hexadecimal.



COMMUNICATIONS LINE FAULT ISOLATION

3

INTRODUCTION

The on-line diagnostic test programs can be used to isolate suspected faulty communications line problems to a particular piece of equipment. Three basic program modes are available within the on-line diagnostic terminal interface program (TIP) to accomplish this testing.

Two of the available test modes (CLA internal loopback mode and CLA external loopback mode using an external data loopback mode), used after CLA operation is verified by the CLA modes, test the local and remote modems and the transmission line facilities. The external data loopback mode includes analog and digital loopback tests, remote tests, self-tests, and transceiver analog loopback tests.

CLA INTERNAL AND EXTERNAL LOOPBACK TEST MODES

In the CLA internal loopback test mode, all CLA logic except the modem signal drivers and receivers are tested.

The CLA external loopback mode can be used only with CLA types 2560-1 and 2561-1. CLA type 2560-1 uses external test connector type 74715000 and CLA type 2561-1 uses external connector type 74715600. These connectors are installed at the CLA in place of the normal connector to the local modem.

EXTERNAL DATA LOOPBACK MODE

The external data loopback mode is used after CLA operation is verified by running the CLA internal and external loopback mode tests.

INFORMATION REQUIRED

Before running the external data loopback tests, the following information must be known:

1. The type of modem or data set (Bell 208A, Bell 207C, CDC 358-2, etc.) used on the line or lines to be tested.
2. The test modes (analog loopback, digital loopback, self-test, etc.) available for use with the modem or modems to be tested. See the applicable modem manual or Bell Telephone data set specifications for this information and/or step-by-step instructions for testing. Table 4-1 also lists some of the more common modems and the test modes available for each.
3. The type of service (dial-up or dedicated). Dedicated lines have more loopback points than do dial-up lines.
4. The type of line operation used (simplex, half-duplex, or full-duplex). Simplex lines cannot be looped back past the analog loopback of the local modem. Half-duplex lines echo back transmitted data to the received data line at the modem interface. Full-duplex lines handle all types of loopback points.

After obtaining the foregoing information, use figure 4-1 to select a loopback test from the available loopback points illustrated. The suggested sequence of the tests is described in subsequent paragraphs. This sequence should be adapted for the particular configuration to be tested.

TABLE 4-1. COMMON MODEMS AND LOOPBACK TESTS AVAILABLE

Modem Type	Loopback Tests Available
Bell 103-non A	Remote test
Bell 103A	Analog test, remote test
Bell 113A	Remote test
Bell 201A	Remote test
Bell 201B	Remote test
Bell 201C	Analog test, digital test, self-test
Bell 202-non S,T	Remote test
Bell 202S	Analog test, remote test
Bell 202T	Analog test, remote test
Bell 208A	Analog test, digital test, self-test
Bell 208B	Analog test, self-test
CDC 358-2	Transceiver analog loopback test


Analog Test - Local modem looped back toward local terminal
(the CLA is considered to be a terminal to the
modem).

Remote Test - Modem looped back toward telephone lines for
testing of the modem and telephone lines by
the telephone company. Only used when
requested by telephone company maintenance
personnel.

Digital Test - Depressed on remote modem for digital looping
back a remote mode toward telephone lines to
test telephone lines and remote mode locally.

Self-Test - Built-in test generator and comparator.

Transceiver Analog Loopback - Analog loopback toward local terminal by
connecting transmit data back to receive data
on the analog terminal block with a jumper
wire.



74700600 A

4-3

Figure 4-1. Loopback Points for Test Selection

EXTERNAL DATA LOOPBACK TESTS

The external data loopback mode includes analog and digital loopback tests, remote tests, self-tests, and transceiver analog loopback tests. Refer to table 4-1 for the test mode or modes that apply to each of the common types of modems or data sets.

In the analog loopback test, activated by the analog loopback test mode switch on the modem, either the local or remote modem can be caused to loop analog data back toward the terminal (with the CLA acting as a terminal). The digital loopback test is activated by the digital loopback test switch on the modem and loops digital data from the modem back toward the communications lines (local or remote central office).

The remote test mode is used only when requested by the telephone company maintenance personnel for telephone company testing of the modem and telephone lines.

If the modem being tested includes word generator and word comparator facilities, activating the self-test mode switch at the modem enables the modem to test its own logic. Additionally, for the CDC type 358-2 modem, the transceiver analog loopback test mode connects transmit data by jumper wire back to the receive data side of the modem.

SUGGESTED LOOPBACK TEST SEQUENCE

When a communications line failure is suspected, run the following tests in the sequence indicated to isolate the problem to a particular piece of equipment or section of the transmission line or system cabling. If any test fails, call a CE and report the test indications so that the trouble may be corrected.

1. Execute the CLA internal loopback test to test all CLA logic

except the modem signal drivers and receivers.

- a. If the test fails, it indicates that the CLA is faulty. Have CE replace CLA.
b. If the test does not fail, proceed to the next step.
2. If the CLA is type 2560-1, install external test connector type 74715000, and if type 2561-1, install external test connector type 74715600. Execute the CLA external loopback test to test all logic of the CLA, including the modem signal drivers and receivers.
 - a. If the test fails, it indicates that the CLA modem signal drivers or receivers are faulty. Have CE replace CLA.
b. If the test does not fail, proceed to the next step.
3. With the analog test button on the local modem depressed, execute the external data loopback test. This tests the data transmission capability of the local modem and the CLA-to-local modem cable.
 - a. If the test fails, either the local modem or the CLA-to-local modem cable is faulty. Proceed to step 6.
b. If the test does not fail, proceed to the next step.
4. Release the analog test button on the local modem and arrange to have the digital test button on the remote modem depressed (by telephoning remote terminal end of line - the Customer). Again run the external data loopback test. This tests the transmission line and remote modem.
 - a. If the test fails, either the transmission line or remote modem is faulty. Proceed to step 8.

- b. If the test does not fail, proceed to the next step.
5. Arrange to have the digital test button on the remote modem released. If no errors were detected in steps 1 through 4, the CLA, modems, and transmission line may be assumed to be working properly. Test the remote terminal and the remote terminal-to-remote modem cable using any available diagnostics. See steps 10 through 12.
6. Enter this step from step 4. Release the analog test button on the local modem. If the local modem has an analog loopback self-test mode (such as Bell 208A modem), run that test as described in the modem (data set) manual.
 - a. If the test fails, the local modem is bad. Call CE to replace the local modem.
 - b. If the test does not fail or if the modem does not have a self-test mode, proceed to the next step.
7. Have CE replace the CLA-to-local modem cable and, with the analog test button on the local modem depressed, execute the external data loopback test.
 - a. If the test fails and the modem is a telephone company modem without the self-test mode, read appendix B, C, and D before calling the telephone company repair service and requesting assistance to test the modem and telephone line. Follow telephone company directions to test the modem and line.
 - b. If the test does not fail, the trouble was in the CLA-to-local modem cable and has been corrected.
8. Enter this step from step 4 or step 5. If the remote modem has an analog loopback self-test mode, run that test as described in the modem (data set) manual.
- a. If the test fails, the remote modem is bad. Call CE to replace the remote modem.
- b. If the test does not fail or if the modem does not have a self-test mode, proceed to the next step.
9. If the modem is a telephone company modem without self-test mode, read appendix B, C, and D before calling the telephone company repair service and requesting assistance to test the modem and telephone line. Follow the telephone company directions to test the modem and line.
 - a. If the test fails, call CE to replace the indicated faulty equipment.
 - b. If the test does not fail or the modem is not a telephone company modem, proceed to the next step.
10. If the local and remote modems both tested good, but step 4 continues to fail, a transmission line problem is indicated. Request the telephone company to loop back the telephone line at the voice frequency test panel (in the local central office), which returns the signal toward the CLA. Execute the external data loopback test to verify that the telephone line is working properly to the local central office.
 - a. If this test fails, the telephone line between the local modem and local central office is bad. Have the telephone company check that line.
 - b. If this test does not fail, proceed to next step.
11. Request the telephone company to loop back the telephone line at the voice frequency test panel in the remote central office and again run the external data loopback test.

- a. If this test fails, have the telephone company check the telephone line.
 - b. If this test does not fail, proceed to next step.
12. If the remote terminal is capable of self-test or, if the remote

terminal can send messages that the terminal can copy on a looped-back line, have the customer perform that test. This test will indicate a fault in the remote terminal. Have customer's maintenance personnel replace or repair the terminal as needed.

APPENDIX A SYSTEM MESSAGES

Message	Significance
"NO PRINTED MESSAGE"	System did not complete load and initialization. Indicates either: <ol style="list-style-type: none">Initialization halt. Check location 30 (hexadecimal) and, if non-zero, interpret halt code according to table 1-1 of this manual. If zero, program did not halt.Program is looping in an initialization routine. Look up NPINTAB entry in Address table (see Interpretation Instructions paragraph, section 3) to obtain address of NPINTAB table. Examine second entry of NPINTAB table to determine where program is looping.
C C P 1.0 HOST ID: 00 NPU ID : 01	Message indicating load and initialization has ended.
*HALT XXXX YYY	An irrecoverable error has caused 2550 to halt. XXXX will be the return address of the program requesting the halt. YYY will be the halt code specifying the type of error causing halt (see table 1-1 of this manual).



APPENDIX B

TELEPHONE COMPANY ASSISTANCE

If Bell System data sets (modems) are used, the telephone company assumes responsibility for finding and clearing trouble conditions for the overall data service between the interfaces of the data sets.

If customer-owned and maintained data sets are used, the telephone company will test the transmission characteristics of the channel. However, they will not provide guidance or assume responsibility for locating the overall system difficulty. The telephone company will not demodulate a customer signal or provide a compatible data set to test with customer-owned equipment. The telephone company does not guarantee the recommendations of an outside supplier of data modems or advise whether the modems can perform satisfactorily over the channel or if the data transmission system is compatible.

If customer-owned and maintained data sets are used and a trouble report is given to the telephone company indicating problems in the telephone line, the telephone company action is limited to testing and restoring the telephone line to prescribed parameters. If no problem is found in the telephone lines, the customer is billed for the service call.

By telephoning either the local or remote central office of the telephone company, a private dedicated telephone line can be arranged to be looped back in either direction (toward the 2550 or toward the remote terminal). On voice-grade interfaced lines, this is done on the voice frequency AC test board. On loop current interfaced lines, this is done on the local loop DC test board. In this case, the customer should be advised that the telephone company may require more than 30 minutes to complete such a loopback connection.



APPENDIX C


EVERYTHING YOU'VE ALWAYS WANTED TO KNOW ABOUT THE TELEPHONE COMPANY

"Telephone Company" is a general term used when discussing "communications common carriers." The business of a telephone company is to supply communications facilities to the general public. Since these companies serve the public, they must comply with regulations set up by the Federal Communications Commission (FCC) at the Federal level and many state regulatory agencies. These agencies regulate the companies by setting rates which may be charged and generally regulating all phases of their business.

There are many "telephone companies" in the United States. By far the largest is the "Bell System" companies operated by American Telephone and Telegraph Company (AT&T) and its subsidiaries. The Bell System is a system of local companies (Northwestern Bell, Mountain Bell, etc.) which serves the various geographic areas. The U.S. is also broken into

geographic areas known as "Long Lines" areas. "Long Lines" is a division of AT&T which provides interstate service between territories of the various associated companies and the many independent companies in the U.S. Therefore, if your line goes interstate or connects to an independent company, Long Lines has responsibility for that line in the Bell System.

The independent phone companies noted above consist of some 2550 companies owned and operated outside of the Bell System. These companies all connect to the Bell System giving the capability to communicate with anyone on the Bell System or with other independents. It might be noted here that Bell has more experience with data lines than many of the independents. Therefore, problem solving with the independents will require patience and perseverance.



APPENDIX D

DATA LINE PROBLEM SOLVING

CIRCUIT NUMBER

This number identifies the line to the telephone company and should be kept at some location (besides the site log) where it is readily accessible. A good place is the demarcation strip.* Placement of the number on the modem is not recommended because it would be removed if the data set is replaced.

STRAPPING OPTIONS

If your data set becomes inoperable and has to be replaced, the replacement may not have the correct strapping options. Therefore, you should keep a list of strapping options for future reference. This list should be kept in the site log and a copy in the terminal cabinet if convenient.

When a problem develops on your data line, there is certain information that is necessary to help isolate the problem. Therefore, you should take time to find and record this information so that it is readily available when a problem arises.

Information required when requesting help from the telephone company:

LINE TYPE

- a. Dedicated (sometimes called "private" or "leased line").
- b. Dial-up.

EMERGENCY SERVICE PHONE NUMBER

An "emergency service" phone number should be available on your modem or near the demarcation strip.* If a number is not posted there, it will have to be obtained from your local sales representative. This number should be obtained and kept handy. This number will put you in contact with the "Private Line Service Board." For "Long Lines," this board is manned 24 hours a day, 7 days a week.


Now that you have all the necessary information, you can start checking your phone line problem.

If your phone line is a dial-up line, you can try "hanging-up" and dialing again. This may give you a different line of better quality. If re-dialing does not solve your problem or if re-dialing is necessary too often, your customer may have to work with his account representative to resolve the problem.

*A demarcation strip is the point at which the telephone line terminates. This point is then connected to the modem.

Dedicated lines present unique problems which may prove difficult to define and correct. After you are reasonably sure that the problem is in the phone line, you should proceed as follows:

1. Call the "emergency service" number.
2. Identify yourself and your line number. A typical line number would be:



The test board man will then check your line to see if it is properly terminated. If the problem cannot be resolved by talking to the test board man, it is advisable to call Regional Tech Support. They will have the test equipment and experience necessary to check further into the problem.

COMMENT SHEET

MANUAL TITLE Communications Control Program Version 1.0
— Software Diagnostic Handbook

PUBLICATION NO. 74700600 REVISION A

FROM: NAME: _____
BUSINESS
ADDRESS: _____

COMMENTS:

CUT ALONG DOTTED LINE

FOLD ON DOTTED LINES AND STAPLE

STAPLE

STAPLE

FOLD

FOLD


CUT ALONG LINE

PLACE
STAMP
HERE

CONTROL DATA CORPORATION
Technical Publications Department
3519 W. Warner Avenue
P. O. Box 5007
Santa Ana, California 92704

FOLD

FOLD



CORPORATE HEADQUARTERS, P.O. BOX 0, MINNEAPOLIS, MINNESOTA 55440
SALES OFFICES AND SERVICE CENTERS IN MAJOR CITIES THROUGHOUT THE WORLD

LITHO IN U.S.A.

