

sgen-dos

utility program

digital

DEC-15-USGNA-A-D

P D P - 1 5

SGEN - DOS Utility Program

Order additional copies as directed on the Software
Information page at the back of this document.

digital equipment corporation • maynard, massachusetts

First Printing, October, 1971
Second Printing, August, 1974

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this manual.

The software described in this document is furnished to the purchaser under a license for use on a single computer system and can be copied (with inclusion of DIGITAL's copyright notice) only for use in such system, except as may otherwise be provided in writing by DIGITAL.

Digital Equipment Corporation assumes no responsibility for the use or reliability of its software on equipment that is not supplied by DIGITAL.

Copyright © 1971, 1974, by Digital Equipment Corporation

The HOW TO OBTAIN SOFTWARE INFORMATION page, located at the back of this document, explains the various services available to DIGITAL software users.

The postage prepaid READER'S COMMENTS form on the last page of this document requests the user's critical evaluation to assist us in preparing future documentation.

The following are trademarks of Digital Equipment Corporation:

CDP	DIGITAL	INDAC	PS/8
COMPUTER LAB	DNC	KAI0	QUICKPOINT
COMSYST	EDGRIN	LAB-8	RAD-8
COMTEX	EDUSYSTEM	LAB-8/e	RSTS
DDT	FLIP CHIP	LAB-K	RSX
DEC	FOCAL	OMNIBUS	RTM
DECCOMM	GLC-8	OS/8	RT-11
DECTAPE	IDAC	PDP	SABR
DIBOL	IDACS	PHA	TYPESET 8
			UNIBUS

CONTENTS

	<u>Page</u>
PREFACE	vii
APPLICATION GUIDE, PDP-15 UTILITY PROGRAM MANUALS	viii
CHAPTER 1 USING DOSGEN	1-1
1.1 CONTEXT	1-1
1.2 ORGANIZATION	1-1
1.3 ANSWERS TO DOSGEN QUESTIONS	1-2
1.3.1 Teleprinter Command Mode	1-2
1.3.2 DOSGEN Batching Command Mode	1-3
1.4 ERROR MESSAGES	1-4
1.5 OPERATION	1-4
CHAPTER 2 DETAILED DESCRIPTION OF OPERATION	2-1
2.1 A. ALTER SYSTEM PARAMETERS? (N)	2-1
2.1.1 API? { (Y) } { (N) }	2-1
2.1.2 33TTY { (Y) } { (N) }	2-1
2.1.3 LA3Ø? { (Y) } { (N) }	2-3
2.1.4 MIC [mic]	2-3
2.1.5 DEFAULT # BUFFERS[n]	2-3
2.1.6 # ORDS/BUFFER [nnn]	2-4
2.1.7 UC15 CONFIG { (Y) } { (N) }	2-4
2.1.7.1 SPOOLER START BLK. # [nnnnn]	2-4
2.1.7.2 SPOOLER SIZE [nnnn]	2-6
2.1.8 LXTRA 4K? { (Y) } { (N) }	2-6
2.1.9 DEFAULT FILES PROTECTION CODE [n]	2-6
2.1.10 RESIDENT PATCH AREA SIZE [nnn]	2-7
2.1.11 PAGE MODE SYSTEM? { (Y) } { (N) }	2-7
2.1.12 60 CPS? { (Y) } { (N) }	2-7
2.2 B. ALTER I/O DEVICES OR HANDLERS? (N)	2-8
2.2.1 XXX? (Y)	2-10
2.2.2 NEW HANDLERS:	2-10
2.2.3 Old Skips	2-11
2.2.4 NEW SKIPS:	2-11
2.3 C. ADD NEW DEVICE? (N)	2-12
2.3.1 DEVICE CODE []	2-12
2.3.2 NEW HANDLERS:	2-14
2.3.3 NEW SKIPS:	2-14

		Page
A.4	TAPE STRUCTURE	A-6
A.5	DOSSAV Restrictions	A-6
APPENDIX B	DIRECTORY LISTINGS: BNK, PAG AND IOS	B-1
APPENDIX C	PER UFD AND SOURCE ASSEMBLY PARAMETERS	C-1
APPENDIX D	SYSBLK AND SGNBLK LISTINGS	D-1
INDEX		INDEX-1

PREFACE

This manual describes the DOS-15 System Generator Utility Program, DOSGEN, and gives other information needed by the System Manager for installation and maintenance of the DOS-15 system.

In the preparation of this manual, it was assumed that the reader is familiar with the Disk Operating System (DOS-15), including its Monitor, and the several Utility Programs -- especially PIP, PATCH, and UPDATE. The DOS USER'S MANUAL (DEC-15-ODUMA-B-D) describes the general operating procedures for DOS-15.

PDP-15 UTILITY PROGRAMS

The PDP-15 Utility Programs manual is comprised of a set of individual manuals, each of which describes the operation and use of a PDP-15 Utility program. The set of manuals which make up the Utility Programs manual are listed in an Applications Guide located on the following page; the Guide also lists the order number of each manual and indicates the currently available monitor systems under which the program will operate. Individual utility manuals may be ordered by referencing the titles and order numbers specified in the Applications Guide.

Chapters 1 and 2 of this manual describe DOSGEN and its use. Chapter 3 describes the general sequence of operations to be followed when using DOSGEN. It is recommended that the user read the entire manual before installing DOS-15.

APPLICATION GUIDE

PDP-15 UTILITY PROGRAM MANUALS

PDP-15 Utility Program Manuals and the Application of Each

Title	Manual Order Number (DEC-15-	Applies to Monitor:		
		DOS	ADSS	B/F
DDT Utility Program	YWZB-DN1	✓	✓	✓
CHAIN & EXECUTE Utility Program	YWZB-DN2	✓	✓	✓
SGEN ADVANCED Monitor	YWZB-DN3		✓	
MTDUMP Utility Program	YWZB-DN4	✓	✓	
PATCH Utility Program	UPATA-A-D	✓	✓	✓
EDIT Utility Program	YWZB-DN6	✓	✓	✓
UPDATE Utility Program	YWZB-DN7	✓	✓	✓
LINKING LOADER	YWZB-DN8	✓	✓	✓
PIP ADVANCED Monitor	YWZB-DN9		✓	✓
SRCCOM Utility Program	YWZB-DN11	✓	✓	✓
SGEN DOS Monitor	USGNA-A-D	✓		
PIP DOS Monitor	UPIPA-A-D	✓		

CHAPTER 1
USING DOSGEN

1.1 CONTEXT

The DOS System Generator, DOSGEN Vnn, allows the system manager to modify an existing DOS system to suit the needs of a particular installation. DOSGEN does not create a system, but modifies an existing one. The DOS disk-restore DECTapes or magtape that Digital Equipment Corporation distributes will produce a working Disk Operating System when restored to the disk via the DOSSAV program¹. The system manager can initiate a system generation operation in order to tailor this basic system to his own needs by issuing the following series of commands to the DOS Monitor:

```
$MICLOG SYS Required System Manager Password for the basic
              system
$ { A RK -14 } (for system generation on RK Disk cartridge) { Required
  { A DK -14 } (for system generation on RF DECdisk)         { ASSIGN
  { A DP -14 } (for system generation on RP Disk Pack)       { statement }
```

```
$SGEN Load command for DOSGEN
```

When DOSGEN is loaded, it automatically starts an interactive SGEN procedure. Once system generation is complete, the system manager should save the changed system via the DOSSAV program. He should always retain at least two copies of the system: the original tape(s) from DEC, and a copy of the new system.

When the system manager wishes to do a subsequent system generation, he should type the same command series given above, substituting the Monitor Identification Code which he supplied during the last system generation.

1.2 ORGANIZATION

DOSGEN is a single, core-image system program with no overlays. When loaded into core DOSGEN tests to ensure that the system owner is currently logged in and that the "A" handler of the RF DECdisk or RK Disk cartridge or RP Disk Pack is assigned to .DAT-14. DOSGEN exits if these requirements are not met. DOSGEN then types out its name, version number, and the device and unit number on which the new system will reside.

¹Appendix A describes the DOSSAV program.

DOSGEN then proceeds with eight sequentially presented sets of questions that can modify three basic areas of the system: (1) system parameters, (2) I/O, and (3) system programs. The eight sets of questions are identified by the letters A through H. Each set is started by a key question that describes the drift of the questions in that particular set. Key questions start at the left margin, questions within a set are tabbed one stop (8 spaces) to the right.

The user can save time by refusing to consider questions in a particular set involving an area not to be modified. He can do this by responding to the key question of any set with a Carriage Return, which effects the acceptance of a set of default answers. This means that the parameters covered by the rejected set remain as in the previous system.

DOSGEN provides restart points which coincide with the beginning of each set of questions. In general, a CTRL P from the keyboard at any point before the end of the current set of questions causes a return to the start of the current set of questions, and the deletion of all answers previously supplied for the current set. Before the user terminates a particular set, he should then check all answers for that set. If he later finds a mistake after a set is completed, he must abort the operation and go through another complete system generation to correct the error. A CTRL C, at any time before the end of Section H, terminates the system generation, leaving the old system unchanged.

1.3 ANSWERS TO DOSGEN QUESTIONS

1.3.1 Teleprinter Command Mode

To save time, DOSGEN supplies a default answer in either parentheses or square brackets, with each question. The default answer always shows how the previous system looked or in some way indicates no change is required. A Carriage RETURN response indicates the user accepts the default answer. In the illustration of each question where the default may be more than one, this manual indicates the possibility with brackets ({}). Thus:

```
API  {(Y)}  
      {(N)}
```

Y and N are 1-character answers for many of the Yes/No, On/Off class of questions. They are self-explanatory. In the case of some questions, however, a third 1-character choice is required. In such questions, the third choice implies "Yes, but ask me questions about the details of the subject." For example, Section B, which concerns devices and device handlers, first asks about each device, deferring questions about its handlers until necessary. Thus, the question:

PR? (\$)

asks whether the user wants the Paper Tape Reader. "N" says "NO, delete the Paper Tape Reader and all of its handlers and skips from the system." Response "\$" or Carriage Return says, "YES, keep the Paper Tape Reader and all its handlers and skips as they are." Response "Y" says, "YES, keep the Paper Tape Reader, but ask me questions about its handlers and skips." ALT MODE alone is echoed "\$", and substitutes for "\$". For the Y/N/\$ type of question, which accepts a 1-character answer, a left arrow implies the default and gives a visible answer on the printout. (Carriage RETURN is not a printing character.)

Some questions cannot be answered by a simple yes/no multiple choice type of question; for example, the specification of the monitor identification code (MIC) (paragraph 2.1.4). For such questions the present value (or default) is supplied in square brackets rather than parentheses. The user may type a single carriage return to continue with the present value, or a new value followed by a carriage return. The exact form a new value must take is given in the paragraphs on the appropriate questions.

Some questions allow multiple answers; for example, "SKIP MNEMONICS IN ORDER" (paragraph 2.4.2). In such instances, the user may type several answers on one line, separating each answer from the next by a comma.

Other answers are explained in the relevant parts of Chapter 2.

1.3.2 DOSGEN Batching Command Mode

Like other DOS Monitor system programs, DOSGEN may be used in the DOS Batching Command Mode. In fact, some features have been added which make the batching process easier. These features are required for the following reason: For those answers whose defaults are specified in

parentheses, DOSGEN reads teleprinter input in Image Alphanumeric Mode. Hence, it does not require a Carriage RETURN to complete a .READ. System considerations, however, require that Batching Mode tapes or decks be in IOPS ASCII. This means that each line of input must be terminated by a Carriage RETURN. Since lines containing one Carriage RETURN only cannot be generated by the Editor, the default answer must always be specified by a left arrow (+). One-character answers in teleprinter mode have their Batching Mode equivalents as follows:

Teleprinter	Batching
Y	Y)
N	N)
\$	\$)
Carriage RETURN	+)
or	
Left-arrow (+)	

All of the above types of answers go with questions where the default is specified in parentheses. In any case where the default is not specified in parentheses (i.e., no default, or one in brackets), the user should have xx.x) in the batching command string.

1.4 ERROR MESSAGES

DOSGEN checks all answers for syntax and acceptability to the DOS software. It also does some limited checking for acceptability within the current hardware configuration. Whenever DOSGEN finds a wrong answer, it types an error message two tabs to the right of the left hand margin (16 spaces in). DOSGEN does not check for multiple errors; any answers that follow an erroneous answer on the same line are not processed, and must be retyped.

1.5 OPERATION

When DOSGEN starts operation, it saves an image of the three parameter blocks from the system device plus the Storage Allocation Table. These blocks contain the old image of the three system information blocks: SGNBLK, SYSBLK and COMBLK. SGNBLK contains information about the default settings of key .SCOM registers, the .DAT and .UFDT, plus an ordered skip chain, the names of all the handlers, and certain information about the devices that the system recognizes. Together, SYSBLK and COMBLK occupy two contiguous blocks on the system device. They describe the system programs. Figure 1-1, SGNBLK, and Figure 1-2, SYSBLK and COMBLK, illustrate the contents of these information blocks.

<u>Location</u>	<u>Value</u>	<u>Description</u>
0	000nnn	Pointer to first free entry in SGNBLK
1	000017	Number of miscellaneous parameters
2	000nnn	Size of .DAT plus size of .UFDT = (number of positive .DAT slots + 16)*2. (Initial value is 20 positive .DAT slots.)
3	000nnn	Number of skips in Skip Chain.
4	221300	System device code.
5	nnnnnn	Original contents of .SCOM+4.
6	nnnnnn	Original contents of .SCOM+20.
7	nnnnnn	Number of words per buffer (.SCOM+27).
10	nnnnnn	Default number of buffers (.SCOM+26).
11	.SIXBT	Monitor Identification Code.
12	nnnnnn	Information on VT and CTRL X (.SCOM+33).
13	00000n	Default files protection code (.SCOM+54).
14	00nnnn	Size of the Resident Monitor Patch Area.
15	7777nn	Minus the number of clock ticks in a second (-74 for 60 hz, -62 for 50 hz)
16	0nnnnn	Spooler area last block #.
17	00nnnn	Spooler area size.
20	000nnn	Device assignments for the .DAT (made by handler numbers). (Termination at 55 assumes 20 ₈ positive slots.)
.	.	
55	000nnn	
56	.SIXBT	
.	.	
.	.	UIC assignments for the .UFDT. (Termination at 113 assumes 20 ₈ positive slots.)
113	.SIXBT	
114	nnnnnn	
.	.	
.	.	
.	.	Skip Chain Table (Negative skips in 1's complement.) (Termination at 145 assumes 32 ₈ skips in chain.)
145	nnnnnn	
146	.SIXBT	
.	.	
.	.	
.	.	The last part of the SGNBLK is the Device Handler-Skip IOT Table. Each entry starts with the .SIXBT representations of all handlers for a particular device. (First two characters equal device code, for all handlers.) Zeroes in the first six bits of a word indicates the end of the handler names, and says that the rest of the word contains the number of skips for this entry's device. The skip IOT's follow immediately. As above, 1's complement skips indicate negative skips. Note, however, the confusing fact that a 1's complement of a skip IOT is a positive number. Thus, 70nnnn complemented is 07nnnn.
.	.	
.	.	
.	.	
.	.SIXBT	
.	.SIXBT	
.	.	
.	.	
.	.SIXBT	
.	000003	
.	nnnnnn	
.	nnnnnn	
.	nnnnnn	
.	.SIXBT	
.	000001	
.	nnnnnn	
.	.	
.	.	
.	.	
344	.	SGNBLK ends at 344 in the DOS-15 RK05 system distributed by Digital Equipment Corporation.

Figure 1-1
SGNBLK for RK05 Based System

	<u>Word #</u>	<u>Value</u>	<u>Description</u>
	0	000nnn	Pointer to first free word after SYSBLK
	:	:	(There is one set of seven words/core image program.)
	7N+1	.SIXBT	Name of System Program or overlay
	7N+2	.SIXBT	
S	7N+3	nnnnnn	Number of first block on system device occupied by this program or overlay
Y	7N+4	0000nn	Number of blocks occupied by this program or overlay
S	7N+5	address	Thirteen-bit first address for this program or overlay
B	7N+6	0nnnnn	Program size
L	7N+7	address	Thirteen-bit starting address for this program or overlay
K	:	:	:
	:	:	:

(free area)			

	400	000010	Number of words in this entry (in this case, 10)
	401	.SIXBT	Name of this system program (left-justified and zero-filled)
	402	.SIXBT	
	403	.SIXBT	Name of an overlay (left-justified and zero-filled) -- overlays are optional
	404	.SIXBT	
C	405	000002	Number of buffers required by this system program (Bits 0-6=0 means the end of any overlay names. This is why program and overlay names must be left-justified.)
O			
M			
B			
L			
K	406	.DAT&777	Active .DAT slot
	407	.DAT&777	Active .DAT slot (Note: 777777 for a .DAT slot means all positive .DAT slots.)
	410	000005	Number of words for this entry (in this case, 5)
	411	.SIXBT	Name of this system program
	412	.SIXBT	
	413	000001	Number of buffers required by this program (Note that this program has no overlays.)
	414	.DAT&777	.DAT slot for this program
	:	:	:
	:	:	:
	777	000400	Pointer to first word in COMBLK (equals count from first word in SYSBLK). The two contiguous blocks on the system device that hold SYSBLK and COMBLK are treated by the system as one large block. In this case, COMBLK happens to start at location 400 of the two blocks combined.

Figure 1-2

SYSBLK and COMBLK

Appendix D contains listings of these information blocks, as supplied by DEC.

Most of DOSGEN's operations consist of building new images of SGNBLK, COMBLK and SYSBLK and the Storage Allocation Table. On completion of the last set of questions (the "H" set), the DOSGEN disallows commands from the teleprinter, writes out the new system block images, and deletes any discarded handlers from the IOS User File Directory. (Up to that point, the current system has remained unchanged.) It is up to the user to insert added handlers and system programs. Handlers can be added via PIP. PATCH can be used to add core-image system programs for which DOSGEN has allocated space.

CHAPTER 2
DETAILED DESCRIPTION OF OPERATION

This section describes the options available to the DOSGEN user, and explains some of the planning necessary for determining an optimum configuration for a particular installation. Each first order (2-digit) paragraph denotes a new set of questions. Each second order (3-digit) paragraph presents an individual question and a description of its meaning and use.

2.1 A. ALTER SYSTEM PARAMETERS? (N)

The "A" section defines those system parameters that do not fall under I/O or system program categories. Some are default parameters which can be modified by commands to the Nonresident Monitor. Others can only be modified by DOSGEN. Figure 2-1, Section A Questions, illustrates this section.

2.1.1 API? { ^(Y)
(N) }

This asks whether API is available on the system, and whether the user wishes the default to be API on or off. A "Y" response makes "API ON" the default condition. An "N" answer makes "API OFF" the default. The Nonresident Monitor's API ON/OFF command can change the state of API temporarily.

2.1.2 33TTY? { ^(Y)
(N) }

This asks which keyboard (KSR-33 or KSR-35) is usually available for command inputs. The Resident Monitor's teleprinter handler handles both machines with no modification. It simply needs to know which console it is talking to. An "N" response makes the Model 35 keyboard the default machine. A "Y" response makes Model 33 the default. The Nonresident Monitor's 33TTY command can change the default temporarily. The KSR-33 MODE causes the TTA handler to simulate the TAB function on the KSR-33 and LA30 Teleprinter. Use of an LA30 for the console device requires that KSR-33 mode be on; i.e. a "Y" response is required.

DOSGEN V3A000

SYSTEM UPDATE ON DK0

A. ALTER SYSTEM PARAMETERS? (N) Y

API? (N) Y

33TTY? (N) Y

LA30? (N) N

MIC[SYS] F00

DEFAULT # BUFFERS[3] 4

WORDS/BUFFER[500] 475

UC15 CONFIG? (N) N

EXTRA 4K? (N) N

DEFAULT FILES PROTECTION CODE[2] 1

RESIDENT PATCH AREA SIZE[0] 1200

PAGE MODE SYSTEM? (N) N

60 CPS? (Y) Y For an RF15 or RP02 system.

DOSGEN V3A000

SYSTEM UPDATE ON RK0

A. ALTER SYSTEM PARAMETERS? (N) Y

API? (Y) Y

33TTY? (Y) Y

LA30? (Y) Y

MIC[SYS] XYZ

DEFAULT # BUFFERS[3] 4

WORDS/BUFFER[500] 525

UC15 CONFIG? (Y)

SPOOLER START BLK # [11207]

SPOOLER SIZE [5006] 4000

EXTRA 4K? (N) Y

DEFAULT FILES PROTECTION CODE[2] 1

RESIDENT PATCH AREA SIZE[0] 1200

PAGE MODE SYSTEM? (Y) Y

For an RK05 system.

60 CPS? (Y) Y

Figure 2-1

Section A Questions

2.1.3 LA3Ø? { (Y) (N)}

This question asks if the system has a 3Ø CPS, LA3Ø as the console device. An "N" response makes the Model 35 keyboard the default console device. A "Y" response makes 3Ø CPS, LA3Ø the default. The Non-resident Monitor's LA3Ø command can change the default temporarily. LA3Ø mode causes the TTA handler to insert several Null characters after a CARRIAGE RETURN to improve LA30 Timing on output. LA3Ø mode and KSR-33 mode (paragraph 2.1.2) are totally independent; both must be on ("Y" responses) for an LA3Ø console device.

2.1.4 MIC [mic]

This question prints the current Monitor Identification Code (MIC) in square brackets. A Carriage Return entry retains the old MIC. If the user wishes to change the current MIC, he should type exactly three printing characters, followed by a Carriage Return. If possible, the user should avoid MIC codes that equal User Identification Codes (UIC's) current to the system. In particular, he must avoid the following UIC's: ???, PAG, BNK, IOS, CTP and SCR. DOSGEN does not accept non-printing characters as part of an MIC.

2.1.5 DEFAULT # BUFFERS[n]

This command requests a default number of buffers to be allocated for user programs and non-core image system programs. The number in square brackets is the old number. If the user wishes to retain the old default number, he should type a Carriage Return. DOSGEN accepts any set of six or fewer octal digits followed by a Carriage Return as the octal number. The Master Tapes which Digital Equipment Corporation distributes indicate three (3) as a default number. The user must consider the trade-off of the available core in his installation (systems with little memory might need a smaller number of buffers) versus the convenience of a large number of buffers.

This parameter does not affect core-image system programs, which always get as many buffers as they need. Users whose programs need a different number of buffers may use the BUFFS Nonresident Monitor command to allocate the exact number of buffers needed.

2.1.6 # WORDS/BUFFER [nnn]

This requests the number of words per buffer, and prints the old number (in octal) in square brackets. A decision regarding an efficient size for the buffers requires some knowledge of the disk handlers which use them. The handlers break buffers from the pool into three parts: (1) File Information (about 40₈ words), (2) the Block List -- addresses of pre-allocated blocks (between 4 and 374₈ addresses, inclusive), and (3) the data buffer (400₈ words). Thus, buffers must be at least 444₈ words long.

The disk handlers do not use extra words in buffers longer than 1034₈. This, therefore, may be an upper limit on buffer size, unless other programs need more space in their buffers. The larger the Block List -- that is, the larger the buffer -- the faster is the output. Smaller Block Lists may give more efficient allocation of disk space, and certainly save core.

Any number typed is interpreted as an octal number.

2.1.7 UC15 CONFIG? { (Y) }¹ (N)

This asks whether the system is the RK05 based dual processor UNICHANNEL-15. DOSGEN uses this information to determine if further questioning is necessary.

If the answer to this question is "Y" the following two questions are asked. If the answer is "N", DOSGEN does not ask the following two questions and skips to item 2.1.8.

2.1.7.1 SPOOLER START BLK. # [nnnnn]

This requests the spooler area starting block number on the RK disk and prints the current number in square brackets. Normally the end portion (based on block numbers) of the RK disk (currently only unit 0) is pre-allocated for the SPOOLER. This area is defined by the spooler area start block number and the spooler size in blocks, as indicated by the shaded area in Figure 2-2.

¹If the RK05 is not the system disk (UC15 option), then an "N" reply must be given to this question.




Figure 2-2
Spooler Start Block Area

Spooled data is stored starting from block BB (computed from the start block number and size).

Users who are not familiar with the disk file structure and Storage Allocation Table (SAT) should not change this starting block number for the following reason: The current system is built for the maximum possible size of spooler area. As a result the only possible change in size is a reduction of it. This facility is provided by reducing the value of the spooler size only. Values of BB like BB" (resulting from a smaller value of the start block # with no change in the spooler size) are illegal unless the SAT blocks are suitable updated (new blocks pre-allocated) to reflect this change.

For users who are familiar with the disk file structure and the SAT block this provides the facility for changing the location of the spooler area on the disk.

2.1.7.2 SPOOLER SIZE [nnnn]

This requests the spooler area size (in block numbers) on the disk and prints the current size in square brackets. All users are provided with the facility of reducing the spooler area (to free space on disk) by reducing this size. Figure 2-2 illustrates an instance where this is done to result in a new value of BB, BB'. DOSGEN deallocates the disk blocks between BB and BB'.

The smallest legal value of the spooler size is 64 if spooling of data is still desired. Users are warned that as the spooler size is reduced the system is generally slowed down if data is being spooled. This is because spooling of data normally occurs at a much faster rate than the de-spooling of data and, as a result, after a certain period of time, the entire spooler area is full of spooled data. The spooler then temporarily halts spooling operations until disk blocks are freed by de-spooling of data.

The entire spooler area can be completely freed if spooling is not desired.

2.1.8 EXTRA 4K? { (Y) (N)}

For systems with an odd number of memory pages, a "Y" answer allows the loaders to use the highest page in memory. For systems with no extra 4K page, the user should type "N".

2.1.9 DEFAULT FILES PROTECTION CODE [n]

This requests the default file protection code, and prints the old code in square brackets. The possible codes and their meanings are:

- Code = 1 Unprotected, with the exception that the file may not be deleted and the number of blocks may not change, if the directory is protected.
- Code = 2 Write protected, if directory protected.
- Code = 3 Read/Write protected, if directory protected.

DOSGEN accepts any 1-digit octal number, but the numbers 0, 4, 5, 6, and 7 are meaningless in this system.

The default protection code for User File Directories is always 1, protected, and may not be changed by DOSGEN.

A user may temporarily change the default protection by means of the Nonresident Monitor Command PROTECT.

2.1.10 RESIDENT PATCH AREA SIZE [nnn]

This requests the Resident Monitor's Patch area size and prints the old number in square brackets. The Resident Monitor's Patch Area is a number of reserved registers (no bigger than 3000₈) located just above the Resident Monitor. The System Loader does not refresh it, except on Bootstrap loads, restarts, and any of the QFILE GET commands. The area may be used for patching the system or for communication among several programs in different core loads.

DOSGEN interprets any number typed as an octal number. The digits 8 and 9, therefore, are not accepted.

2.1.11 PAGE MODE SYSTEM? { (Y) } { (N) }

This requests the default addressing mode. A "Y" response makes page addressing the default mode. An "N" response makes bank mode the default. Users may temporarily change the mode via the PAGE ON/OFF or BANK ON/OFF Nonresident Monitor commands.

2.1.12 60 CPS? { (Y) } { (N) }

This requests the line frequency at the installation. Installations with 60hz line frequency require a "Y" answer; those with 50hz require an "N" response.

2.2 B. ALTER I/O DEVICES OR HANDLERS? (N)

This set of questions allows the user to delete or retain devices and all their handlers, and allows a third option of retaining the reference to the device, and then retaining, deleting or adding handlers and skips for a particular device. The printout given in Figure 2-3 illustrates the use of this section.

Section B refers to all devices currently in the system by a 2-character device code. The device codes for those device handlers included in the Master Tapes supplied by the Digital Equipment Corporation are:

CD	Card Reader (CR03B or CR15 or CR11)
DK	RF15 Disk Control
DP	RP15 Disk Pack Control
DT	DEctape (TC15 DEctape Control)
LK	LK35 Keyboard
LP	Line Printer (either LP15C or LP15F or LP11/LS11)
LT	LT15/LT19 Terminal Interface (Dummy Handler)
MT	MAGtape
PP	Paper Tape Punch (PC15)
PR	Paper Tape Reader (PC15)
RK	RK05 Disk Cartridge Control
VP	VP Point Plotting Display
VT	VT15 Graphic Display Console
VW	Writing Tablet
XY	XY11 Plotter

(TT, which means teleprinter, is not included in this set of questions, because DOS uses the teleprinter as a console command device.)

The device handler names used in Section B are printed as 3-character names. In reality, handler names are four characters long, but this section truncates the last character, a period (.). The first two characters must be the 2-character device code for the handler's device. The third character must be alphabetic.

DOSGEN starts this set of questions by asking whether the user wishes to delete discarded handlers from IOS. Deletion saves space on the system device.

DOSGEN then begins asking key questions for each device currently on the system:

XX? (\$) (where XX stands for any device code)

```

B. ALTER I/O DEVICES OR HANDLERS? (N) Y
    DELETE DISCARDED HANDLERS? (Y) Y
    TO BE KEPT:
    PK? ($) $
    PP? ($) $
    DT? ($) $
    DK? ($) Y
    DKR? (Y) Y
    DKC? (Y) N
    NEW HANDLERS:
    >DKD
    >DKF
    >
    DSSF=707001? (Y) Y
    NEW SKIPS:
    >
    DP? ($) N
    MI? ($) N
    LP? ($) $
    CD? ($) N
    VP? ($) $
    VI? ($) N
    VW? ($) N
    LK? ($) N
    LI? ($) N

```

Figure 2-3

For RK05 based UC15 system RK and XY are also included.

If the user answers with a Carriage Return or "\$", DOSGEN retains the device and all its skips and handlers as they were in the previous system. If the user answers "N", DOSGEN deletes all information about that device and its handlers, and all its skips from the Skip Chain. (Deletion of handlers from the handler UFD, IOS, does not occur until the termination of Section H.)

If the user answers "Y", DOSGEN asks specific questions about the handlers and skips for the device in question.

2.2.1 XXX? (Y)

(where XXX stands for any handler name)

DOSGEN asks this question for each handler the device has in IOS. A "Y" response retains the handler; an "N" response deletes it.

NOTE

DOSGEN does not allow the user to delete the "A" handler for the system device (DKA., RKA. or DPA.).

2.2.2 NEW HANDLERS:

When DOSGEN has asked a question for each of the device handlers currently in IOS, it asks whether the user wishes to add any new handlers. It makes no sense to "add" a handler name which has just been deleted. If the user wishes to change a handler, he may use PIP to transfer a new one to IOS. PIP automatically deletes the old one if the user transfers a new one with the same name. New handler names should follow the rules outlined in paragraph 2.2. When the user has no more handlers to add, he should simply type a Carriage Return.

Adding handler names only makes them "logically" present. The user must call PIP to transfer the handlers to the IOS UFD, in order to make handlers physically present. DOSGEN warns the user about missing handlers at the end of Section C. File names for handlers in IOS must have the same name as the handler global and the entry point label and a "BIN" extension (e.g., .GLOBL DKA. ,DKA. DAC CALP, OR DKA. BIN).

2.2.3 OLD SKIPS

Presumably, the user changes old skips only in the case where they were incorrectly inserted. In any case, after the user has indicated he has no more handlers to add for the current device, DOSGEN prints the skips for this device that are in SGNBLK (whether or not these skips are in the skip chain). DOSGEN prints skips in the following format:

```
devskp = nnnnnn? (Y)
```

A Carriage RETURN or "Y" accepts the old skip; an "N" deletes the skip.

2.2.4 NEW SKIPS:

When DOSGEN has exhausted the skips for the current device as they were in the old system, it requests any new skips. New skips should be typed in the following format:

```
devskp = nnnnnn
```

where devskp has no more than six characters, and nnnnnn is a legitimate device skip. DOSGEN performs the following tests to determine if a skip is legitimate:

- 1) Must be IOT. I.e., must be of the form 7Ønnnnn.
- 2) Bit 14 must be zero -- the skip may not clear the accumulator.
- 3) The low order octal digit must be a 1 -- it must be a skip IOT and not some other kind. This check may be overridden by the user by typing "Y" to the question:

```
devskp=nnnnnn IS NOT A STANDARD SKIP IOT.
```

```
DO YOU WISH IT ACCEPTED? (N)
```

Any other answer causes the skip to be ignored.

If a skip is rejected for any of the above reasons, DOSGEN re-prompts with the ">" symbol which requests another skip.

Users should not insert skips (IOT's) which can in any way modify the contents of the accumulator. Such IOT's will cause serious, timing-dependent bugs in DOS-15. For similar reasons users are also cautioned

against using skip IOT's which in any way modify device status information.

When the user types a Carriage RETURN after the ">", DOSGEN proceeds to the next device. Negative skips (that is, those which skip on "OFF", not "ON") should be preceded by a minus sign (-), to indicate that they are negative:

```
devskip = -nnnnnn
```

2.3 C. ADD NEW DEVICE? (N)

When DOSGEN has finished with Section B, it asks whether the user wishes to add a new device. Section C differs from other sections in that restarts (CTRL P) only delete information added for the current device.

That is, if the user adds devices AA, BB, and CC, but types CTRL P during the CC operation, DOSGEN returns to a point just after the completion of the BB device insertion.

When the user has no more devices to add -- that is, when he answers the key question with an "N" or Carriage Return, DOSGEN reminds him of all the handlers he has added to the system, but which are not yet present in IOS. He can add them later, via PIP. The printout shown in Figure 2-4 illustrates the use of this Section.

2.3.1 DEVICE CODE []

Here, the user may type any two alphameric characters that DOSGEN cannot interpret as an octal number. It is recommended, however, that the user give only alphabetic characters, as any numerals might be confused with a unit number. DOSGEN does not accept any input other than two alphameric characters. There is no default for this question; DOSGEN assumes that if the user answered the Section C question with a "Y", he has a device code to add. DOSGEN makes no assumption about which device it is.

```
C. ADD NEW DEVICE? (N) Y
    DEVICE CODE[] AD
    NEW HANDLERS:
    >ADA
    >
    NEW SKIPS:
    >701301      ("701301" ISN'T SYMBOL)
    >ADSF=701301
    >NCSF=701341
    >MSDF=701321
    >

C. ADD NEW DEVICE? (N) N
    MISSING HANDLERS:
    BKD.
    DKF.
    ADA.
```

Figure 2-4

2.3.2 NEW HANDLERS:

Here, the user should add all the handlers he will use for the new device. The names should follow the rules for handler names outlined in paragraph 2.2 with the exception that the user must not type the final period (.).

2.3.3 NEW SKIPS:

The new skips for the device should follow the format outlined in Paragraph 2.2.4 DOSGEN adds all new skips to the end of the Skip Chain. The user may change the order of the Skip Chain in Section D.

When the user has no more skips to add, DOSGEN repeats the key question for Section C.

C. ADD NEW DEVICE? (N)

If the user has another new device, he may add it now.

2.4 D. CHANGE SKIP CHAIN? (N)

When the user has responded to the key question for Section C with an "N" or a Carriage Return, DOSGEN proceeds to Section D, which allows the user to change the Skip Chain order and delete skips. The user may not add any skips in this section. The printout of Figure 2-5 illustrates the uses of this Section.

2.4.1 DISPLAY SKIP CHAIN? (Y)

In most instances, the user wishes to see all skip mnemonics and acronyms in the old system, plus those he has just added. If he answers "Y" or Carriage Return, DOSGEN types: DEFAULT SKIP CHAIN ORDER, followed by the old Skip Chain with new skips at the end.

2.4.2 SKIP MNEMONICS IN ORDER:

Users have two basic options for this part: accept the whole chain as is, or retype the entire chain, in a new order. The user may type a single Carriage RETURN in response to the "SKIP MNEMONICS IN ORDER:" question, and obtain the old chain order, with any new skips at the end of the chain. If he types any mnemonic, however, he must account for all of the skips. When the user responds to DOSGEN's request for the next skip (>) with an ALT MODE, DOSGEN types "\$" and the first skip in the old chain that has not already been selected. When the user responds to the ">" with a Carriage RETURN, DOSGEN deletes all unlisted skips, freezes the new order, and continues on to Section E.

Two warnings are in order: (1) Negative skips should be at the end of the chain. Illegal interrupts may otherwise occur when the peripheral device is down. (No standard DOS devices have negative skips.) (2) Beware of changing the relative order of the chain, as supplied by DEC. For instance, the clock interrupt must come before the printer.

2.5 E. ALTER DEVICE PARAMETERS? (N)

2.5.1 7-CHANNEL MAGTAPE { (Y) } (N)

The user should choose the proper default. "N" gives 9-channel. The printout for this section is shown in Figure 2-6.

E. ALTER DEVICE PARAMETERS? (N) Y

7 CHANNEL MAGTAPE? (Y) N

LINE PRINTER LINE SIZE(80,120, OR 132)[80] 120

VT ON? (N) ←

HALF ON? (N) Y

Figure 2-6

F. ALTER .DAT SLOTS? (N) Y

OF POSITIVE .DAT SLOTS[20] 15

DISPLAY .DAT SLOTS? (Y) Y

.DAT	DEVICE	UIC
-15	DKA	UIC
-14	DKA	UIC
-13	DKA	UIC
-12	TTA	UIC
-11	DKA	UIC
-10	TTA	UIC
-7	DKL	SYS
-6	DKA	UIC
-5	NONE	UIC
-4	DKA	UIC
-3	TTA	UIC
-2	TTA	UIC
-1	DKA	SYS
1	DKA	UIC
2	DKA	UIC
3	DKA	UIC
4	TTA	UIC
5	PPA	UIC
6	PPA	UIC
7	DTA1	UIC
10	DTA2	UIC
11	NONE	UIC
12	NONE	UIC
13	NONE	UIC
14	NONE	UIC
15	NONE	UIC

NEW ASSIGNMENTS:

>A AD 11,12,13,14,15

>A <ARC> 1/CDE\\\

>

Figure 2-7

2.5.2 LINE PRINTER SIZE (80, 120, OR 132) [nnn]

Acceptable responses to this question are 80, 120, or 132, or a Carriage Return. A Carriage Return retains the old line size, printed in square brackets.

2.5.3 VT ON: { (Y) } { (N) }

This requests the default setting for the CTRL X option. A "Y" makes VT ON the default. An "N" makes VT OFF the default. DOSGEN does not ask this question or the next one if the VT is not on the system.

2.5.4 HALF ON? { (Y) } { (N) }

This requests the default setting for the half-screen setting for the CTRL X option. An "N" response makes HALF OFF the default. A "Y" response makes HALF ON the default.

2.6 F. ALTER .DAT SLOTS? (N)

This section allows the user to alter the number of .DAT slots, which is a permanent change to the system (until the next System Generation), and to make the default assignments to both the .DAT slots and the .UFDT slots. The operator may temporarily change the assignments via the ASSIGN (A) command to the Nonresident Monitor. (See Figure 2-7.)

2.6.1 # OF POSITIVE .DAT SLOTS [nn]

This asks the number of positive .DAT slots for the new system, and indicates the old number in square brackets. The number of negative .DAT slots is fixed at 15. DOSGEN accepts any octal number from 1 to 77, inclusive. Each .DAT slot adds two registers to the size of the Resident Monitor and two parameters to SGNBLK -- one for the .DAT slot entry, and one for the .UFDT entry. Users with a great deal of core should still be careful about too many .DAT slots. That might cause SGNBLK overflow and an abort from the system generation. Further, OTS users must reassemble FIOPS and .FLTB in order to use more than 20₈ .DAT slots. See Appendix C.

2.6.2 DISPLAY .DAT SLOTS (Y)

If the user wishes to change any assignments, he may request their current assignments by answering "Y" or Carriage Return. This has the effect of a REQUEST command to the Nonresident Monitor.

2.6.3 NEW ASSIGNMENTS:

The user may make new default assignments to the .DAT and/or .UFDT by using the same ASSIGN (A) commands he would use to the Nonresident Monitor. When the user has no more new assignments, he should type Carriage Return when DOSGEN types a new angle bracket (>). UIC in a .UFDT slot means the UIC currently logged in is given to that .UFDT slot. SYS in a .UFDT slot means either BNK or PAG will be assigned to that slot by the loaders (depending on the addressing mode of the load). Any other three letters are retained unless changed via an ASSIGN command.

2.7 G. CHANGE SYS FILES? (N)

With the exception of the first question, which refers to the size of the ↑QAREA, this refers to the core-image system programs currently listed in SYSBLK and COMBLK. This section allows no additions. The printout given in Figure 2-8 illustrates the use of this section.

2.7.1 ↑Q AREA SIZE (NONE,16K,20K,24K,28K,32K) [nn]

DOSGEN does not ask this question for Disk Pack or Disk Cartridge systems -- they always receive 32K.

This questions allows the DECdisk user to set the ↑Q AREA size. Users with an RF disk system device may wish to delete the ↑Q AREA. In that case, they should type NONE, in response to this question. The Resident Monitor does not allow dumps to a ↑Q AREA on the RF disk that is smaller than the current core size, or to a nonexistent area. The user should therefore avoid having an area which is smaller than his core size -- it would simply waste space. "K)" must follow the number 16, 20, 24, 28, or 32.

If the user needs to make the ↑Q AREA larger, DOSGEN tries to find enough contiguous free blocks to hold the new one. If this proves impossible, special steps may need to be taken. Refer to paragraph 2.7.2.2 for those steps.

```

G. CHANGE SYS FILES? (N) Y

      ↑Q AREA SIZE(NONE,16K,20K,24K,28K,32K)[32K] 16K

      TO BE KEPT:

      DOS15? ($) $
      EDIT? ($) N

      EDITVP? ($) $
      EDITVT? ($) N

      PIP? ($) $
      MACRO? ($) $
      CHAIN? ($) $
      F4? ($) $
      DUMP? ($) $
      DTCOPY? ($) $
      PATCH? ($) $
      UPDATE? ($) $
      SPCCOM? ($) N

      8TRAN? ($) N

      89TRAN? ($) N

      MTDUMP? ($) N

      QFILE? ($) $
      SGEN? ($) $

```

Figure 2-8

for RK05 based UC15 systems DOSGEN will type:

```

      MAC11($)
      SPOOL($)

```

after SGEN (\$).

2.7.2 TC BE KEPT:

syspro? (\$)

After the ↑Q AREA size has been defined, DOSGEN asks questions about each core-image system program currently on the system, in the order that it finds them in COMBLK. A response of "\$" or Carriage Return instructs DOSGEN to retain all information about the last-named system program. A response of "Y" instructs DOSGEN to retain the program's name in SYSBLK and COMBLK, but implies that the user wishes to change some of the information about the program, as listed in SYSBLK and COMBLK. An "N" deletes the program from the system. DOSGEN does not allow DOS15 to be deleted.

2.7.2.1 overlay (Y) (where "ovrlay" is the name of any currently listed overlay)

If the user responds to a system program name with a "Y", DOSGEN first lists each of the program's overlays, if any. These are Yes/No answers.

A "Y" or Carriage Return response retains that overlay, and an "N" response deletes it.

2.7.2.2 OVERLAY NAME []

If the user wishes to add any overlays to the current system program, he should type the names at this point. DOSGEN rejects names which are more than six characters long, or are the same as any Nonresident Monitor or PATCH command. If the named overlay is already listed in SYSBLK, DOSGEN requests the next overlay. If not, DOSGEN requests:

2.7.2.3 # OF BLOCKS []

The user should type the number of blocks required for the new system program. If the number is legal, DOSGEN tests whether there are as many contiguous free blocks on the system device as are necessary to hold the new overlay. DOSGEN starts testing at block 0 of the system device, and stops as soon as it finds enough blocks. DOSGEN then updates its image of the Storage Allocation Table (SAT) to indicate that those blocks are occupied.

Note that when disk space is tight, and the user wishes to add several system programs and overlays, DOSGEN may not allocate disk space efficiently. In an extreme case, the user may need to first transfer the BNK and PAG UFD's (or even all of IOS, except the system device's "A" handler) off the disk via PIP, and then do one pass through DOSGEN to delete all unwanted system programs. Then the user must do enough succeeding passes to ensure that system programs are added in order of size, with the largest first. Finally, the user should transfer the BNK and PAG UFD's back, via PIP. This allows the UFD files, which need not be in contiguous blocks, to use the noncontiguous blocks.

Ordinarily, the procedure outlined in Chapter 3 should be sufficient to free all necessary disk space.

NOTE

New overlays or system programs must run in Bank Mode. Use CHAIN for Page Mode programs.

2.7.2.4 BUFFS [nn]

This question indicates the number of buffers previously allocated for this system program, and asks whether the user wishes to change the number. DOSGEN does not check whether the number of buffers allocated is compatible with the program. That is the user's responsibility.

2.7.2.5 .DAT SLOT nn? (Y)

After the user has indicated the number of buffers for this program, DOSGEN asks him to check the .DAT slots required. It first lists the old ones. If the user types Y or Carriage Return, DOSGEN retains the listed .DAT slot. An "N" deletes the listed .DAT slot.

2.7.2.6 .DAT SLOTS

After checking the old .DAT slots, the user should add any new ones the program needs. The .DAT slots added must be legal, as determined in Section F. All positive .DAT slots may be obtained by typing "ALL". If the user has added an overlay, he should add any .DAT slots needed by the overlay but not listed by DOSGEN for the system program.

2.8 H. ADD SYS PROG? (N)

This section allows users to add the names of new core-image system programs and their overlays to SYSBLK and COMBLK. Restarts in this section delete only the current system program, just as they do for new devices, Section C.

The printout given in Figure 2-9 illustrates the use of this section.

2.8.1 PROG NAME []

Names must conform to the rules for system program names outlined in paragraph 2.7.2.2. There is no default for this question.

2.8.2 # OF BLOCKS []

This question works just like that for overlays, described in paragraph 2.7.2.2. There is no default for this question.

2.8.3 OVERLAY NAME []

Any overlay names must conform to the rules for system program names outlined in Paragraph 2.7.2.2. If the overlay name is not already listed in SYSBLK, DOSGEN requests:

```
# OF BLOCKS []
```

2.8.4 BUFFS [0]

The user should enter the octal number of buffers needed for the new system program.

2.8.5 .DAT SLOTS:

The user should list the octal numbers of all .DAT slots needed by the new system program, or any of its overlays. The response "ALL)" obtains all positive .DAT slots.

After the user has entered all necessary .DAT slots, he should type a Carriage Return in response to the ">" symbol typed by DOSGEN. This returns him to the start of Section H.

H. ADD SYS PROG? (N) Y

PROG NAME[] ADMON

OF BLOCKS[] 7

OVERLAY NAME[] ADMON1

OF BLOCKS[] 3

OVERLAY NAME[]

BUFFS[0] 4

.DAT SLOTS:

>11,12,13,14,15

>

H. ADD SYS PROG? (N) N

MODIFYING SYSTEM(↑P,↑C IGNORED)

DELETED HANDLERS:

DKC.

DPA.

DPB.

DPC.

MIA.

MTC.

MTF.

CDR.

VTA.

VWA.

LKA.

SGEN COMPLETE

Figure 2-9

If the user types Carriage Return or "N" to the key question for Section H, DOSGEN disallows CTRL P or CTRL C, modifies the system, and returns to the monitor. At this point, the user must do a Bootstrap restart, in order to bring in the modified system.

CHAPTER 3
DOSGEN AND ITS CONTEXT

3.1 BUILDING DOS-15 FOR THE FIRST TIME

Digital Equipment Corporation supplies DOS-15 on disk restore tapes -- either one 7- or 9-track magnetic tape, or two DECTapes for RF15 and RP02 systems and eight DECTapes for RK05 systems. In addition, users with optional, Floating Point Hardware should obtain a tape with the Floating Point FORTRAN; and users with Object Time Systems or UNICHANNEL-15 hardware (for RF15 and RP02 based systems) should obtain a DECTape or magnetic tape and five paper tapes for PDP-11 and PDP-15 related software to accommodate those options. The disk restore tape(s) should be copied onto the system device via the DOSSAV program. Appendix A describes DOSSAV operation.

After the completion of a DOSSAV run from the DEC restore tapes to the system device (disk), the disk contains:

1. A working DOS-15 system
2. Completed images of three system information blocks:
SGNBLK, SYSBLK, and COMBLK.
3. Core-image files of the following system programs:
DOS15, the Nonresident Monitor
RESMON, the Resident Monitor
.SYSLD, the System Loader
EDIT
EDITVP
EDITVT
PIP
QFILE
MACRO
CREF, MACRO's overlay for pass three
CHAIN
F4, the FORTRAN program for PDP-15 machines without
floating point hardware
DUMP
DTCOPY
PATCH
UPDATE
SRCCOM
8TRAN
89TRAN

MTDUMP

DOSGEN

and the following for RK05 based UC15 systems only

MAC11 (for 8K, PDP-11 local memory configuration)

SPOOL (for LP11/LS11 line printer and XY11 plotter)

The DOS-15 User's Manual, DEC-15-ODUMA-B-D gives brief descriptions of all these system programs.

4. Relocatable binary files in the IOS UFD. These files are handlers for the following devices:

RK05 Disk Cartridge Control (for RK05 based UC15 systems only)

RF15 DECdisk Control

RP15 Disk Pack Control

PC15 High-Speed Paper Tape Reader and Punch Control

VP15 Point Plotting Display

VT15 Graphic Display Processor

TC59 Magnetic Tape Control

LP15C and LP15F Line Printers or LP11 and LS11 Line Printers (for RK05 based UC15 systems only)

LK35 Keyboard

TC15 DECTape Control

CR03B Card Reader Control

VW01 Writing Tablet

XY11 Plotter (for RK05 based UC15 systems only)

LT15/LT19 Terminal Interface (Dummy Handler)

Appendix B contains a listing of IOS, as supplied by the Digital Equipment Corporation.

5. Relocatable binary files in the BNK and PAG UFD's. These files are the relocatable system programs: EXECUTE, .LOAD, FOCAL, and DDT, plus .LIBR, the system library. They load in Bank and Page Mode systems, respectively. Appendix B contains a listing of the BNK and PAG UFD's as supplied by DEC.
6. Several source and binary files in the PER UFD. These files are for optional peripherals not included in the majority of the systems served by DOS-15, and for PDP-9 owners who wish to use DOS-15. Appendix C lists the PER UFD, as supplied by DEC, and describes the use of the routines contained in PER. These files are supplied to RF15 systems on a separate DECTape or magnetic tape.

7. A 32K CTRL Q Area.
8. SCR, the default UFD. SCR will be empty.

The above-mentioned files and information blocks fit on the smallest system device supported by DOS-15 (a single-platter RF15 DECdisk or a single drive RP02/RK05 disk). Part of the system generation process is designed to free the system device blocks occupied by unneeded handlers and system programs. This is especially important on a 1- or 2-platter DECdisk system or a 1-drive RK05 system to which the user intends to add his own system programs. The following procedure frees disk storage and sets up a new system in an orderly fashion:

NOTE

The user should be logged in under the Monitor Identification Code for all the following operations.

3.1.1 Preliminary DOSGEN Run

Call DOSGEN, set up the correct system parameters, and delete all undesired device handlers and system programs. Do not add any new handlers or programs. If a DECdisk system and the computer's main memory hold less than 32K words, reduce the CTRL Q area.

Users with neither an LT15 nor an LT19 terminal interface should delete the LT device handler (LTX.) and all its associated skips. Users with an LT15 or LT19 should delete skips which correspond to lines that do not exist on their system. Skip mnemonics are of the form KSF_n, where n is a line number between 1 and 16 inclusive. Installations with an LT15 or LT19 should retain the LTX. handler and skips for any lines which are present regardless of whether or not the installation plans to use this equipment under DOS-15. (Exception -- users with only a single line who are keeping the LKA. LK35 keyboard handler with which to drive it should delete LTX. and all of its skips). Furthermore, the skips must be retained in the skip chain. In handling spurious interrupts (such as might be caused by accidentally striking a key on an LT19 keyboard) DOS-15 determines whether or not a particular line is present -- and thus whether an interrupt should be ignored or cause an error -- by whether or not a skip for that line is in the skip chain. The dummy handler LTX. is present solely for the purpose of

getting the appropriate skips into the skip chain -- any attempt to use LTX. to perform any function will cause an IOPS6 error.

For similar reasons the VPA. device handler should be retained on installation with a VP15 regardless of whether or not the VP15 is going to be used. If this is not done, spurious interrupts (caused by depressing the VP15 erase button) may crash the system.

Users with a single drive RK05 system are recommended to reduce the spooler area (as explained in section 2.1.7) if the spooled I/O devices are not going to be used heavily. To give users an idea, the current spooler size 5006 blocks (\approx .64 million words) can hold approximately 20,000 cards or 132-column lines.

3.1.2 One Mode Addressing

Users who intend to have a Bank or Page mode system only should delete the appropriate UFD:

$$\begin{array}{l} \$PIP \\ >N \quad \left\{ \begin{array}{l} DK \\ DP \\ RK \end{array} \right\} \left\{ \begin{array}{l} < PAG > \\ < BNK > \end{array} \right\} (K) \end{array}$$

3.1.3 FORTRAN Considerations

The user should next consider the system's FORTRAN capabilities. PDP-9 users should call PATCH, and replace F4 supplied with the system with the binary file, F4X9, supplied in the PER UFD or separate tape, mounted on unit '0' (for RF15 system).

```
$A { DP } <PER> -10 ) (For RF15 system: $A { DT } -10 )
   { RK }
$PATCH )
>F4 )
>READR F4X9 )
>EXIT )
```

PDP-15 users whose systems have the Floating Point Hardware should replace the system libraries in BNK and PAG with the libraries found in the extra DOS-15 Vnn Floating Point FORTRAN Option tape, DEC-15-ODFPA-A-UB. Before doing so, however, the system manager should consider

whether FOCAL will be used at the installation. If so, he must make an Execute file out of FOCAL. (FOCAL has not been modified to take advantage of Floating Point Hardware, and uses non-Floating Point OTS routines.) If the user has his own FOCAL routines, he should add them to FNEW (see Appendix C).

```

$PAGE  ON (or OFF, as desired)
$A  SYS  -4 (assign desired output UIC)
$CHAIN
.
.
.
>FOCAL (ALT MODE)
.
>(ALT MODE)
.
>FOCAL, FNEW (ALT MODE)
.
>(ALT MODE)

```

Then the system manager should replace the standard library with the Floating Point Library, found on the option tape mounted on unit '1':

```

$PIP
>T  {  DK 
      {  DP 
      {  RK }  { <BNK> }  .LIBR  BIN+ {  DT1 }  {  .FPAG  BIN }
      {  <PAG> }  {  MT1 }  {  .FBNK  BIN }

```

Users should then replace the F4. (FORTRAN) supplied as a system program with the one from the Floating Point Tape:

```

$A  {  DT1 }
      {  MT1 }  -10 )
$PATCH )
>F4 )
>READR FPF4X )
>EXIT )

```

3.1.4 Graphics

When the proper FORTRAN routines have been installed, the user with a VT15 Graphics Display Processor should add the Graphics routines in the PER UFD or separate tape (for RF15 systems) to the system libraries in BNK or PAG. Before doing this, CIRCLE and ROTATE should be assembled under the current F4 compiler to produce the binaries:

```

$A_{(DP)}_{(RK)} <PER> -10 / { (DK) (DP) (RK) } { (<PAG>) (<BNK>) } -14,-15) (for RF15 system:
$UPDATE)
>US+)
>I ROTATE)
>I CIRCLE)
>I VTPRIM)
>I DYLDL)
>I TRACK)
>I LTORPB)
>C)
$A_{(DT)}_{(MT)} -10)

```

3.1.5 VP15 Point Plotting Display

The user with a VP15 Point Plotting Display should add the following routines to the libraries:

```

$A_{(DP)}_{(RK)} <PER> -10 / { (DK) (DP) (RK) } { (<PAG>) (<BNK>) } -14,-15 (for RF15 system
$A_{(DT)}_{(MT)} -10)

$UPDATE)
>UPDATE Vnn)
>US+)
>I VECTOR)
>I FORT)
>I NUVAL)
>C)

```

The user can transfer VPA.S BIN into IOS, UIC and rename it to VPA.BIN.

3.1.6 Unichannel Based System Considerations

The MAC11 Assembler is delivered as an 8K (Local-11 memory) version. This version will not work on the 4K and 12K unichannels. Before altering PIREX or the spooler the proper MAC11 assembler must be installed. See the DOS Assembly Parameters manual (DEC-15-ODAPA-A-D) for the procedure to install a 4K or 12K MAC11.

The PIREX paper tape (DEC-15-XUCMA-A-D) is supplied in its initial configuration with RK and LP drivers.

The spooler, resident on disk under UIC PER, is configured for line printer (LP) only.

1. The following procedure permits reconfiguration of PIREX to produce a version compatible with a specific site's configuration.

a. Under UIC PER, utilize the editor (EDIT) to include or delete from PIREX for the following assembly parameters:^{1,2}

- 1) \$RK=1000000 ; (RK05 disk)
- 2) \$LP=400000 ; (LP/LS/LV Printer)
- 3) \$CD=200000 ; (CR11 Card Reader)
- 4) \$PL=100000 ; (XY11 Plotter)

b. Assemble the source with MAC11 to produce a new PIREX paper tape.

Typing:

\$MAC11

>B+PIREX XXX (ALT)

will cause the assembly of a new PIREX onto paper tape.³

2. To change the Spooler's configuration utilize the following procedure.

a. Under UIC PER with Editor (EDIT) to include or delete from the Spooler (SPOL11) the following assembly parameter.

- 1) \$LP=400000 ; (RK05 disk)
- 2) \$CD=200000 ; (CR11 card reader)
- 3) \$PL=100000 ; (XY11 Plotter)

b. Assemble the source with MAC11 to produce a new SPOL11 Paper tape.

Typing:

\$MAC11

>LB+SPOL11 XXX (ALT)

¹Deleting a parameter deletes the device driver, adding a parameter includes the associated driver.

²The initial parameters are \$RK and \$LP.

³For more information on MAC11, see the MAC11 User's Manual (DEC-15-IMCMA-A-D).

will cause the assembly of a New SPOL11 onto paper tape and produce a listing.

- c. Assemble SPLIMG XXX under MACRO-15 using the assembly SPOLSZ. (The value of the assembly parameter SPOLSZ may be found on about the fourth page of the SPOLSZ listing.)
- d. Turn API OFF.
- e. Place the new SPOL11 paper tape in the reader.
- f. Using GLOAD run SPLIMG.

\$GLOAD

>+SPLIMG (ALT)

- g. Assemble SPOL15 XXX using the SPOLSZ assembly parameter (See c above) and the FB assembly parameter. (Use PIP: L TT+RK (L) to acquire the FB parameter.)
- h. Under the MICLOG Patch the new SPOL15 absolute binary into the SPOOL program.

\$A RK <PER> -10

\$PATCH

>SPOOL

>READ SPOL15

>EXIT

- i. Reassemble the PDP-15 side handlers corresponding to the devices to be spooled. These are located under the PER UFD.
 - 1. For those devices to be spooled do not use the NOSPL=Ø parameter.
 - 2. For any device that is to be no longer spooled, use the NOSPL=Ø parameter.
 - 3. See the DOS-15 Assembly Parameters Manual for any other relevant assembly parameters.
- j. Transfer the newly assembled and suitably renamed DOS-15 handler binaries to the IOS UFD.

The updated spooler is now ready to run.

3.1.7 UNICHANNEL-15 Option¹

Users who have the UC15 optional hardware are supplied with a DOS-15 Vnn UC15 option tape, DEC-15-ODUCA-A-UC, containing the required software. This tape contains software to permit the RF or RP to be the system device. To use RK as the systems device users must obtain the RKØ5 disk restore tapes. In the following illustration to add the UC15 option software to the existing system, RP is the systems device.

¹The UC-15 option is a non-spooled UC-15 package intended for use with systems utilizing an RPØ2 or RF15 as the primary system's disk.

The installation of the UC15 option is completely described in the "UC15 OPTION" Appendix in the UNICHANNEL-15 Software Manual (DEC-15-XUCMA-A-D).

A summary of the required steps is provided for purposes of reference only:

- 1) Assemble the UC15 OPTION-RBOOT¹ producing a new papertape.
- 2) Patch the special RESMON, DOSNRM, DOSBCD and SGNBLK RPA¹ onto the system.
- 3) Load the supplied PIREX papertape using ABSL11.
- 4) REBOOT DOS-15 using the new UC15-RPBOOT¹.
- 5) RUN SGEN to install MAC11² as a system program.
- 6) Use patch to update FA, PS, SA for MAC11.
- 7) Assemble MACINT, MACIMG and load the MAC11 papertape.
- 8) Patch MACINT onto the system.
- 9) Tailor PIREX for your installation's configuration.
- 10) Assemble and move the UNICHANNEL DOS-15 handlers into [IOS].
- 11) Run SGEN to install new devices (XY and RK) and new skips (LP and CD).
- 12) Load the tailored PIREX using ABSL11.
- 13) REBOOT DOS-15 using the UC15 OPTION-RPBOOT¹ papertape.

¹Substitute RF for RP where appropriate.

²Remember to reply "N" to the "UC15 Config?" question.

3.1.8 Source Files in PER UFD or Separate Tape (For RF15 Systems)

The user should next decide whether he needs any of the source files supplied in PER UFD or separate tape (for RF15 system). If so, he should assemble them via MACRO/MAC11. Appendix C describes the assembly parameters relevant to all the source files in PER. Appendix C also describes where in the system the assembled files should be inserted.

3.1.9 Second DOSGEN Run

The user should run through DOSGEN, to add any devices and system programs needed for the system.

3.1.10 PATCH

The user should call PATCH, to add any system programs for which DOSGEN has reserved space.

3.1.11 PIP

The user should call PIP, and transfer to IOS any handlers added to the system.¹ The user should then save the PER UFD on a tape, if not already present, for future reference, and delete the PERUFD from the system in order to recoup space.

3.1.12 Copy the System

Finally, the user should make at least one copy of the new system, via the DOSSAV program.

3.2 USING DOSGEN AFTER THE FIRST TIME

The system manager may call DOSGEN at any time, in order to modify the system. Changes in system parameters, and deletion of devices, device handlers or system programs require no advance preparation. Addition of core-image system programs, however, may require some preliminary work with PIP.

¹Once device handlers have been transferred to IOS, they must be renamed, if necessary, to the names assigned in Sections B and C. The PIP "R" command will rename files.

Core image system programs and the spooler area must occupy contiguous blocks on the system device. A running system may have sufficient free blocks to accept a new core image file, but no set of contiguous, free blocks. In such an instance, the user will have to transfer files from any of the UFD's on the system device to another mass storage medium, and then run DOSGEN. After the DOSGEN run, PATCH can add the system files, and PIP can bring back the transferred UFD's. UFD's need not have contiguous disk storage.

APPENDIX A

DOSSAV OPERATING INSTRUCTIONS

DOSSAV is the save/restore system for DOS-15.

DOSSAV saves and restores to/from DECdisk, Disk Cartridges, Disk Packs, DECTape and magtape. A DECdisk system can be saved on and restored from DECTape, magtape, Disk Cartridge and Disk Pack. A Disk Pack or Disk Cartridge system can use DECTape and magtape.

Once loaded, DOSSAV asks for all necessary information, such as input and output device, unit numbers and, in the case of magtape, parity and density.

GENERAL INSTRUCTION:

The user must type a Carriage Return after all entries, including the character typed to restart after errors. For UC15 system, start up PIREX as indicated below.

To load PIREX, place the ABS11 paper tape in the PDP-15's paper tape reader. Place the ENABLE/HALT switch on the PDP-11 in the HALT position. Press the STOP and RESET switches on the PDP-15 simultaneously. Set the ADDRESS switches on the PDP-15 to 177000. Press the READIN switch on the PDP-15. When the readin operation is completed and the PDP-15 has halted, set the PDP-11 switch register to:

600000 for 4K local memory on the PDP-11
1000000 for 8K local memory on the PDP-11
1200000 for 12K local memory on the PDP-11

and depress the PDP-11 LOAD ADDR switch, then set the ENABLE/HALT switch on the PDP-11 to ENABLE, and finally depress the PDP-11 START switch.

Remove ABS11 from the paper tape reader, and reload it with the PIREX paper tape. Press CONTINUE on the PDP-15. This will cause the ABS11 program (which has two segments: A PDP-11 segment, and a PDP-15 segment) to read in PIREX (which is a PDP-11 absolute binary tape) via the PDP-15 segment and load it into PDP-11 lower memory via the PDP-11 segment.

When the PIREX paper tape has been read in, the PDP-15 will halt, and the PDP-11 will be running PIREX. Remove the PIREX paper tape from the reader. At this point the UNICHANNEL Peripheral Processor has been loaded and is waiting for an I/O request from DOS-15.

A.1 RESTORING SYSTEMS

The following examples illustrate how to put the systems distributed by Digital on DECTape or magtape onto a DECdisk, Disk Pack or Disk Cartridge. The user responses are underlined. The RK05 based systems start up PIREX as described in GENERAL INSTRUCTION, above, before starting up DOSSAV. DOSSAV resides on a paper tape, which must be (HRM) loaded at 37720 (restart 342000).

1. To restore a DECdisk system from DECTape (1 of 2 on Unit 1 and 2 of 2 on Unit 2)

```
DOSSAV Vnn
INPUT DEVICE? DT
UNIT NO? 1
OUTPUT DEVICE? DK
DATE CREATED: 06 Jun 73 /Note that if DK is typed no
                        /unit number is requested.
TAPE DONE. MOUNT ANOTHER /At this point,
2 /type 2 on the key-
                        /board followed by Carriage
                        /RETURN.
```

2. To restore a DECdisk system from magtape (on Unit 0):

```
DOSSAV Vnn
INPUT DEVICE? MT
UNIT NO? 0
TRACK (7 OR 9)? 7
DENSITY (2,5,8)? 8
PARITY (E OR O)? O
OUTPUT DEVICE: DK
DATE CREATED: 06-JUN-73
```

NOTE

All DOS-15 System Restore magtapes distributed by Digital are 800 BPI, odd parity. For 9 track units, DOSSAV assumes 800 BPI.

3. To restore a Disk Pack system from DECTape (1 of 2 on Unit 1 and 2 of 2 on Unit 2):

```
DOSSAV Vnn
INPUT DEVICE? DT
UNIT NO? 1
OUTPUT DEVICE? DP
UNIT NO? 0
DATE CREATED: 06-JUN-73

TAPE DONE, MOUNT ANOTHER At this point, type 2 on the
2 teleprinter followed by a
                        Carriage RETURN.
```

4. To restore a Disk Pack system from magtape (on Unit 1):

```
DOSSAV Vnn
INPUT DEVICE? MT)
UNIT NO? 1)
TRACK (7 OR 9)? 7)
DENSITY (2,5,8)? 8)
PARITY (E OR O)? O)
OUTPUT DEVICE? DP)
UNIT NO? Ø)
DATE CREATED: 06-JUN-73
```

5. To restore a Disk Cartridge system from DECTapes on Units 1, 2, 3, and 4:

```
DOSSAV Vnn
INPUT DEVICE? DT)
UNIT NO? 1)
OUTPUT DEVICE? RK)
UNIT NO? 0)
DATE CREATED: 06-JUN-73
TAPE DONE. MOUNT ANOTHER (The user mounted the next tape on
2) unit number 2, then typed 2)
to continue)
TAPE DONE. MOUNT ANOTHER (The user mounted the next tape on
3) unit number 3, then typed 3)
to continue)
TAPE DONE. MOUNT ANOTHER (The user mounted the next tape on
4) unit Number 4, then typed 4)
to continue)

DOSSAV Vnn
INPUT DEVICE? (Operation complete)
```

6. To restore a Disk Cartridge from magtape Unit 1:

```
DOSSAV Vnn
INPUT DEVICE? MT)
UNIT NO? 1)
TRACK (7 OR 9)? 7)
DENSITY (2,5,8)? 8)
PARITY (E OR O)? O)
OUTPUT DEVICE? RK)
UNIT #? Ø)
DATE CREATED: 06-JUN-73
```

```
DOSSAV Vnn
INPUT DEVICE? (Operation complete)
```

It is possible to restore to the DECdisk a software system which was created for a machine smaller (different number of DECdisk platters) than the one being restored to. DOSSAV does all the necessary adjustments of the SAT's¹. Therefore, the restore tapes issued by Digital for a 1-platter system can be restored to any system. Note that this should only be done with the master tape(s) which have block 1775_g

¹SAT's: Storage Allocation Tables - i.e., bit maps.

free. That block is needed during the restore for five or more DECdisk platters. It is not possible to restore a software system which is larger than the hardware. (For example, one cannot restore a 3-platter system onto a 1-platter configuration.)

The system can then be bootstrapped from the appropriate disk. See the DOS Keyboard Command Guide (DEC-15-ODKCA-A-D).

A.2 SAVING SYSTEMS

Once the user has tailored the system to his specific configuration, he will want to save that system for future restorations. To do that, simply reverse the procedure above. To illustrate, consider Example 1 above and the changes necessary to it to create a restore tape.

To save a DECdisk system to DECTape (on Units 1 and 2);

```
DOSSAV Vnn
INPUT DEVICE? DK
OUTPUT DEVICE? DT
UNIT No? 1
TAPE DONE. MOUNT ANOTHER      At this point, type 2 on the
                                keyboard followed by a Carriage
                                RETURN.
2
```

Note that DOSSAV allows for as many DECTapes and magtapes as are necessary to hold the system.

A.3 ERROR CONDITIONS AND MESSAGES

Recoverable errors during command string decoding: If a question is answered incorrectly, DOSSAV outputs an appropriate error message and then repeats the question. These error messages are:

ILLEGAL DEVICE	An illegal device mnemonic was typed (something other than DP, DK, RK, DT, or MT) or an illegal combination of devices was typed (i.e., input = DT and output = MT).
BAD TRACK	Something other than 7 or 9 was typed.
BAD DENSITY	Something other than 2 (200), 5 (556), or 8 (800) was typed.
BAD PARITY	Something other than E (even) or O (odd) was typed.

Recoverable errors during operations: If it is possible to recover from an error, DOSSAV attempts to do it. The error message is output to the console. After the problem has been corrected, any character on the keyboard followed by a Carriage RETURN resumes operation.

TAPE NOT READY	The DECTape or magtape unit is off line or not write enabled.
DISK NOT READY	DECdisk is write locked.
DISK PACK NOT READY	The Disk Pack or Disk Cartridge unit is not ready.

Unrecoverable errors: Primarily hardware errors, from which DOSSAV cannot recover. After the error message has been output, DOSSAV restarts. DOSSAV retries five times on parity error, before issuing an unrecoverable error message.

DECTAPE ERROR
MAGTAPE ERROR
DISK ERROR
DISK PACK ERROR

ATTEMPT TO RESTORE SYSTEM TO WRONG DISK

To protect users who have access to more than one type of disk and who may have several sets of restore tapes, all restore tapes are created with the mnemonic of the disk type in the first SAT. DOSSAV checks this code against the output device code. If they differ, this message is output.

BLK 1775 OCCUPIED. NO 2ND SAT CREATED

A DECdisk system created for 4 or fewer platters is restored to a machine with 5 or more platters and block 1775 is already used. Therefore, no second SAT is created. A master tape was not used to make the restore.

XX ERR IGN

where xx = DK or DP or RK.

This error is typed on the console, and the PDP-15 halts. This reports that "Read/Write check" errors occurred more than 12₈ time during a save or restore process. The bad block number is present in the PDP-15 AC. Users can continue the save or restore process by pressing the continue switch on the console of the machine.

A.4 TAPE STRUCTURE

The restore tapes are structured as follows: The first SAT of the system is the first block put on the tape. This SAT, which is never restored to the disk, has two words modified: word 2 contains the creation date (taken from .SCOM+47) and word 376 contains the device mnemonic (.SIXBT, right justified). All the occupied blocks referenced by this SAT are then put sequentially on the tape. The second SAT, if there is one, is then put on, and so on. This structure enables use of magtape, which is a sequential only device.

A.5 DOSSAV Restrictions

1. It is not possible to save or restore magtapes with even parity.
2. DOSSAV fails when two DECTapes are on line with the same unit number. It is necessary to restart under such circumstances

APPENDIX B

DIRECTORY LISTINGS: BNK, PAG AND IOS

DIRECTORY LISTING (BNK)
662 FREE BIKS
13 USER FILES
176 USER BIKS
DDT RTN 13 22-MAR-74
EXFOUT RTN 3 22-MAR-74
FODAI RTN 22 22-MAR-74
.LTER RTN 107 25-MAR-74
.LOAD RTN 11 22-MAR-74
INSALL SRP 6 22-MAR-74
INSEPP SRP 7 22-MAR-74
INSTRP RTN 1 22-MAR-74

DIRECTORY LISTING (PAG)
662 FREE BIKS
13 USER FILES
176 USER BIKS
DDT RTN 13 22-MAR-74
EXFOUT RTN 3 22-MAR-74
FODAI RTN 22 22-MAR-74
.LTER RTN 107 25-MAR-74
.LOAD RTN 11 22-MAR-74
INSALL SRP 6 22-MAR-74
INSEPP SRP 7 22-MAR-74
INSTRP RTN 1 22-MAR-74

```

25-JUL-74
DIRECTORY LISTING (IOS)
1242 FREE BLKS
36 USER FILES
273 USER BLKS
CDB.  BIN      3  25-JUL-74
DKA.  BIN     16  25-JUL-74
DKB.  BIN     14  25-JUL-74
DKC.  BIN      7  25-JUL-74
DPA.  BIN     17  25-JUL-74
DPB.  BIN     15  25-JUL-74
DPC.  BIN     10  25-JUL-74
DTA.  BIN     11  25-JUL-74
DTC.  BIN      3  25-JUL-74
DTD.  BIN     10  25-JUL-74
DTE.  BIN      7  25-JUL-74
DTF.  BIN      4  25-JUL-74
LKA.  BIN      3  25-JUL-74
LPA.  BIN      3  25-JUL-74
LTX.  BIN      1  25-JUL-74
MTA.  BIN     12  25-JUL-74
MTC.  BIN      3  25-JUL-74
MTF.  BIN      5  25-JUL-74
PPA.  BIN      3  25-JUL-74
PPB.  BIN      2  25-JUL-74
PPC.  BIN      2  25-JUL-74
PRA.  BIN      3  25-JUL-74
PRB.  BIN      2  25-JUL-74
*RKA.  BIN     10  25-JUL-74
*RKB.  BIN     14  25-JUL-74
*RKC.  BIN     10  25-JUL-74
VPA.  BIN      4  25-JUL-74
VTA.  BIN      3  25-JUL-74
*VWA.  BIN      2  25-JUL-74
*XYA.  BIN      4  25-JUL-74

```

*Only for RK05/RK15 systems. CDB.BIN will be the CR03B, DEC 029 code handler for RF15 and RP15 systems while for RK05/RK15 systems it will be the CR11, DEC 029 code unspooled handler LPA.BIN will be the LP15 handler for the RF15 and RP15 systems while for RK05/RK15 systems it will be the LP11/LS11 spooled handlers. XYA.BIN present in RK05/RF15 system will be the spooled version of the handler.

APPENDIX C

PER UFD AND SOURCE ASSEMBLY PARAMETERS

The following is a listing of the PER UFD:

```

DIRECTORBY LISTING (PER)
  860 FREE RIKS
  31 USER FTIES
 1431 USER RIKS
CD.DOS XXX      105  10-MAR-74
DIRPLF SRC       7   22-MAR-74
DOSBCD XXX      49   23-APR-74
DYI00  BIN       2   10-MAR-74
FNEW  XXX       20   10-MAR-74
FORT  BIN        1   10-MAR-74
F4X0  BIN       55   25-MAR-74
LPA100 BIN       3   10-MAR-74
LPA15  XXX      32   10-MAR-74
LP.847 BIN       3   10-MAR-74
LTOR00 BIN       1   10-MAR-74
NIIVAI BIN       1   10-MAR-74
ROTATE SRC       3   22-MAR-74
TRACK  BIN       2   10-MAR-74
VECTOR SRC       4   22-MAR-74
VPA15  BIN       5   10-MAR-74
VTP014 BIN       7   10-MAR-74
LPU1   XXX      43   10-MAR-74
MACTMG XXX      15   10-MAR-74
MACTNT XXX      47   10-MAR-74
PIREY  XXX     315   22-APR-74
SPLTMG XXX      13   10-MAR-74
SP0111 E04     234   10-MAR-74
SP0115 XXX      52   10-MAR-74
XYU1   XXX      65   10-MAR-74

```

PER contains--source files:

NOTE:

DOSBCD XXX
CD.DOS XXX
FNEW XXX
LPA.15 XXX

XXX is the current version
number - see DOS Assembly
Parameters document
(DEC-15-ODAPA-A-D).

Those installations which have their own FOCAL routines may want to use EDIT's GET command to add their sources for FNEW. If these sources substitute for others already present, EDIT can delete the old routines. Once FNEW is completed, MACRO produces FNEW BIN on

some device. Assign this device to .DAT -10. Then, the following commands to UPDATE delete the old FNEW, and insert the new one:

```
$UPDATE
UPDATE Vnn
>US+ )
>D FNEW )
>I FNEW )
>C )
```

The Assembly Parameters document (DEC-15-ODAPA-A-D) shows the assembly parameters that produce all the possible variations of binary files. Note that once assembled, programs put in the IOS UFD must be renamed. For example, the binary produced from assembling LPA.15 048 is LPA.15 BIN. When this program is put in the IOS UFD, it must be renamed to LPA. BIN.

Any number of positive .DAT slots over 20_8 requires reassembly of FIOPS and .FLTB. These sources may be purchased from Digital Equipment Corporation. Assembly parameter for .FLTB is: $FLTB=n<77_8$. Assembly parameter for FIOPS is: $DKTBSZ=n<77_8$.

On RK05/RK15 the PER UIC, also contains the following source files:

MACIMG XXX	15	11-FEB-74
MACINT XXX	47	11-FEB-74
PIREX XXX	313	11-FEB-74
SPLIMG XXX	13	11-FEB-74
SPOL11 XXX	230	11-FEB-74
SPOL15 XXX	62	11-FEB-74
LPU. XXX	43	11-FEB-74
XYU. XXX	66	11-FEB-74

NOTE

XXX is the current version number-see DOS Assembly Parameters document (DEC-15-ODAPA-A-D).

APPENDIX D
 SYSBLK AND SGNBLK LISTINGS

SYSBLK #13

SYSBLK DOS15

```

/
/COPYRIGHT 1971,72,73 DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.
/
/EDIT #010      9-22-71
/      011      S,KRISH 5-OCT-73      UC15 CTL 'Q' + TKB UPDATE
/      012      SK      11-FEB-74      V3A UPDATE
/      013      SK      23-JUL-74      V3A000 UPDATE
/
/      PARAMETERS:      RF15 SYSTEM      NONE
/                        RP02 SYSTEM      RP02
/                        RK05 SYSTEM      RK05
/
/      SYSBLK (SYSTEM BLOCKS #34 AND 35(8)) CONTAINS THE PARAMETERS FOR
/LOADING ALL THE CORE IMAGE FILES (SYS FILES) ON THE DOS15
/SYSTEM EXCEPT FOR THE DATA FILES SGNBLK(#36)
/AND SYSBLK, SYSBLK IS PART OF THE SYSTEM LOADER AND NON-RESIDENT MONITOR AND
/STARTS AT LOCATION 16100(8). THE ORDER OF ENTRIES IN SYSBLK IS
/UNIMPORTANT EXCEPT FOR THE FIRST 3 PERMANENT ENTRIES. THIS TABLE IS USED BY
/PATCH, SGEN, THE SYSTEM LOADER, AND THE NON-RESIDENT MONITOR.
/THIS TABLE IS MODIFIED WHEN
/NECESSARY BY SGEN AND PATCH. THE FIRST WORD OF SYSBLK CONTAINS
/THE UNRELOCATED ADDRESS OF THE FIRST FREE WORD OF SYSBLK. THE
/ENTRIES CONSIST OF 7 WORDS. THE FOLLOWING
/DESCRIPTION APPLIES TO ALL 7 WORD ENTRIES:
/      WD1,WD2      .SIXBT 'NAME'
/      WD3          FIRST BLOCK # (FB)
/      WD4          # OF BLOCKS OCCUPIED (NB)
/      WD5          FIRST ADDRESS (FA) (13 BITS)
/      WD6          PROGRAM SIZE (PS) (HIGHEST ADDRESS - FA+1)
/      WD7          START ADDRESS (SA) (13 BITS)
/
/      .ABS
/      .LOC      0
/      .EJECT
SYSBLK END-.      /POINTER TO FIRST FREE WORD OF SYSBLK

```

00000
 00000 000233

SYSBLK #13

SYSBLK LOS15

/
/ THE FOLLOWING THREE ENTRIES ARE FIXED IN SYSBLK AND CAN NEVER
/ BE DELETED. THEY REPRESENT THE BASIC SYS FILE CUSPS TO RUN THE
/ SYSTEM AND THE CONTROL Q AREA.
/

00001 220523
00002 151716
00003 000000
00004 000040
00005 000100
00006 017400
00007 000000

SE1 .SIXBT 'RESMON'

0
40
100
17400
0

00010 562331
00011 231404
00012 000040
00013 000013
00014 011000
00015 005100
00016 011000

SE2 .SIXBT 'SYSLD'

40
13
11000
5100
11000

00017 362101
00020 220501

SE3 .SIXBT 'AQAREA'

.IFUND RP02
.IFUND RK05
101
.ENDC
.ENDC
.IFDEF RP02
117030
.ENDC
.IFDEF RK05
1120/
.ENDC
200
5
77773
0

00022 000200
00023 000005
00024 077773
00025 000000

00026 041723
00027 616500
00030 002727
00031 000024

00032 004531
00033 011347
00034 005101

SE4 ,SIXBT 'DOS15'

727
24
,IFUND RK05
4531
11347
5101
.ENDC
,IFDEF RK05
4320
11550
4710

.ENDC
,EJECT

D-3

00035 066400
00036 000000
00037 000101
00040 000036
00041 001150
00042 016467
00043 001277

/ /
/ THIS ENTRY BEGINS THE DELETED CORE IMAGE CUSPS
/ SE5 ,SIXBT 'F400'

101
36
1150
16467
1277

00044 201120
00045 000000
00046 000137
00047 000035
00050 002004
00051 015575
00052 002147

/ SE6 ,SIXBT 'PIPE'

137
35
2004
15575
2147

00053 150103
00054 221700
00055 000174
00056 000033
00057 002530
00060 015106
00061 002530

/ SE7 ,SIXBT 'MACRO'

174
33
2530
15106
2530
.EJECT

00062	032205	/		
00063	060000	SE10	.SIXBT	'CREFI'
00064	000054		54	
00065	000005		5	
00066	015600		15600	
00067	002012		2012	
00070	015601		15601	
00071	230705	/		
00072	160000	SE11	.SIXBT	'SGENI'
00073	000227		227	
00074	000022		22	
00075	005312		5312	
00076	010611		10611	
00077	005355		5355	
00100	031001	/		
00101	111600	SE12	.SIXBT	'CHAIN'
00102	000251		251	
00103	000022		22	
00104	007200		7200	
00105	010412		10412	
00106	007200		7200	
00107	050411	/		
00110	242624	SE13	.SIXBT	'EDITVT'
00111	000273		273	
00112	000017		17	
00113	010130		10130	
00114	006773		6773	
00115	010406		10406	
00116	050411	/		
00117	242620	SE14	.SIXBT	'EDITVP'
00120	000312		312	
00121	000017		17	
00122	010121		10121	
00123	006755		6755	
00124	010402		10402	

00125	050411	SE15	.SIXBT	'EDIT'
00126	240000			
00127	000331		331	
00130	000015		15	
00131	011135		11135	
00132	006007		6007	
00133	011404		11404	
00134	252004	SE16	.SIXBT	'UPDATE'
00135	012405			
00136	000346		346	
00137	000013		13	
00140	012370		12370	
00141	005247		5247	
00142	012371		12371	
		/		
00143	232203	SE17	.SIXBT	'SRCCOM'
00144	031715			
00145	000361		361	
00146	000013		13	
00147	012635		12635	
00150	005002		5002	
00151	012740		12740	
		/		
00152	152404	SE20	.SIXBT	'MTDUMP'
00153	251520			
00154	000374		374	
00155	000012		12	
00156	013121		13121	
00157	004460		4460	
00160	013212		13212	
		/		
00161	702422	SE21	.SIXBT	'STRAN'
00162	011600			
00163	000406		406	
00164	000011		11	
00165	013550		13550	
00166	004031		4031	
00167	013632		13632	

00170	707124	SE22	.SIXBT	'89TRAN'
00171	220115			
00172	000417		417	
00173	000011		11	
00174	013522		13522	
00175	004057		4057	
00176	013604		13604	
		/		
00177	200124	SE23	.SIXBT	'PATCH'
00200	031000			
00201	000430		430	
00202	200010		10	
00203	012700		12700	
00204	003470		3470	
00205	012700		12700	
		/		
00206	042515	SE24	.SIXBT	'DUMP'
00207	200000			
00210	000440		440	
00211	000005		5	
00212	015300		15300	
00213	002350		2350	
00214	015300		15300	
		/		
00215	042403	SE25	.SIXBT	'DTCOPY'
00216	172031			
00217	000445		445	
00220	000003		3	
00221	016660		16660	
00222	000757		757	
00223	016677		16677	
		/		
00224	210611	SE26	.SIXBT	'QFILE'
00225	140500			
00226	000062		62	
00227	000002		2	
00230	017041		17041	
00231	000437		437	
00232	017045		17045	
		/		
			.IFDEF	RR05

000233

```

/
SE27  ,SIXBT  'SPOOL'
      451
      45
      1
      4000
      3500
SE30  ,SIXBT  'MAC11'
      516
      40
      1
      17625
      17500
      .ENDC
END=,  ,TITLE  COMBLK DOS15
/
/
/      COMBLK CONTAINS INFORMATION THE SYSTEM LOADER, THE
/      /NON=RESIDENT MONITOR, AND SYSTEM GENERATOR NEED TO REMEMBER
/      /ABOUT CURRENT SYS FILE CUSPS.
/      /THE LAST LOCATION IN SYSBLK CONTAINS THE
/      /UNRELOCATED ADDRESS OF THE FIRST ENTRY IN COMBLK. THE
/      /REMAINDER OF COMBLK CONSISTS OF VARIABLE LENGTH ENTRIES ASSOCIATED
/      /WITH SYS FILE CUSPS (CORE IMAGE SYSTEM PROGRAM FILES). EACH
/      /ENTRY IS OF THE FOLLOWING FORM:
/      (1) THE FIRST WORD IS AN OFFSET NUMBER INDICATING THE
/      /      NUMBER OF WORDS IN THE ENTRY INCLUDING THE OFFSET
/      /      WORD.
/      (2) THE NEXT TWO WORDS CONTAIN THE NAME OF THE CUSP IN ,SIXBT
/      /      IF THE NAME IS LESS THAN SIX CHARACTERS IN LENGTH, THE
/      /      TRAILING CHARACTER POSITIONS ARE ZEROED. THE FIRST
/      /      .CHARACTER POSITION MUST BE NON=ZERO.
/      (3) IF THERE ARE ANY OVERLAY SEGMENTS, THEIR TWO WORD NAMES
/      /      ARE ENTERED AFTER THE FIRST NAME ABOVE (2).
/      (4) WHEN A WORD HAS 0'S IN BIT POSITIONS 0-5, AND IT
/      /      IS RIGHT AFTER THE CUSP NAME OR AN OVERLAY NAME,
/      /      IT TERMINATES THE LIST OF SEGMENT NAMES. THE REMAINDER
/      /      OF THIS WORD CONTAINS THE DEFAULT VALUE FOR THE 'FILES'
/      /      COMMAND FOR THE CUSP.
/      (5) THE REMAINDER OF THE COMBLK ENTRY CONTAINS THE ACTIVE
/      /      .DAT SLOT NUMBERS FOR THE CUSP WITH BITS 0-8 ZEROED
/

```

```

/          (EXCEPT THAT -1 INDICATES THAT ALL POSITIVE .DAT SLOTS
/          ARE TO BE LOADED).
/
/ THE SYSTEM GENERATOR ADDS CUSPS TO COMBLK BY MAKING THEM THE NEW
/ FIRST ENTRY. IN THIS WAY SYSBLK AND COMBLK BUILD TOWARD THE CENTER.
/

```

00610

```

. IFUND RK05
. LOC   610
. ENDC
. IFDEF RK05
. LOC   574
. ENDC

```

00610 000005
00611 041723
00612 616500
00613 000001
00614 000766

```

/
E1      E3-E1
        .SIXBT  'DOS15'
        1
        -12&777
        .EJECT

```

00615 000007
00616 050411
00617 240000
00620 000002
00621 000763
00622 000764
00623 000770

```

E3      E4-E3
        .SIXBT  'EDIT'
        2                      /# OF BUFFERS REQ FOR EDIT.
        -15&777
        -14&777
        -10&777

```

00624 000010
00625 050411
00626 242620
00627 000002
00630 000763
00631 000764
00632 000770
00633 000010

```

/
E4      E4A-E4
        .SIXBT  'EDITVP'
        2                      /# OF BUFFERS REQ FOR EDITVP.
        -15&777
        -14&777
        -10&777
        10

```

00634 000007
00635 050411
00636 242624
00637 000002
00640 000763
00641 000764
00642 000770

```

/
E4A     E5-.
        .SIXBT  'EDITVT'
        2
        -15&777
        -14&777
        -10&777

```

00643	000005	E5	E6-E5	
00644	001120		.SIXBT	'PIP'
00645	000000			
00646	000004		4	/# OF BUFFERS REQ FOR PIP.
00647	777777		-1	/ALL POSITIVE .DAT SLOTS
/				
00650	000013	E6	E7-E6	
00651	150103		.SIXBT	'MACRO'
00652	221700			
00653	032205		.SIXBT	'CREF'
00654	060000			
00655	000003		3	
00656	000764		-14&777	
00657	000765		-13&777	
00660	000766		-12&777	
00661	000767		-11&777	
00662	000770		-10&777	
/				
00663	000010	E7	E8-E7	
00664	031001		.SIXBT	'CHAIN'
00665	111600			
00666	000003		3	
00667	000772		-6&777	
00670	000773		-5&777	
00671	000774		-4&777	
00672	000777		-1&777	
			.EJECT	
/				
00673	000007	E8	E9-E8	
00674	066400		.SIXBT	'F400'
00675	000000			
00676	000003		3	
00677	000765		-13&777	
00700	000766		-12&777	
00701	000767		-11&777	
/				
00702	000006	E9	E10-E9	
00703	042515		.SIXBT	'DUMP'
00704	200000			
00705	000002		2	
00706	000764		-14&777	
00707	000766		-12&777	

00710	000000	E10	E11-E10
00711	042400		.SIXBT 'DTCOPY'
00712	172031		
00713	000002		2
00714	000763		-15&777
00715	000764		-14&777
		/	
00716	000000	E11	E12-E11
00717	200124		.SIXBT 'PATCH'
00720	031000		
00721	000002		2
00722	000764		-14&777
00723	000770		-10&777
		/	
00724	000010	E12	E13-E12
00725	252004		.SIXBT 'UPDATE'
00726	012400		
00727	000004		4
00730	000763		-15&777
00731	000764		-14&777
00732	000766		-12&777
00733	000770		-10&777
		/	
00734	000007	E13	E13A-E13
00735	232203		.SIXBT 'SRCCOM'
00736	031715		
00737	000003		3
00740	000763		-15&777
00741	000764		-14&777
00742	000766		-12&777
			.EJECT
00743	000000	E13A	E13B-
00744	702422		.SIXBT '8TRAN'
00745	011600		
00746	000002		2
00747	000763		-15&777
00750	000764		-14&777
00751	000006	E13B	E13C-
00752	707124		.SIXBT '89TRAN'
00753	220116		

```

00754 000002
00755 000763
00756 000764
00757 000006
00760 152404
00761 251520
00762 000002
00763 000001
00764 000003
00765 000005
00766 210611
00767 140500
00770 000001
00771 000764

00772 000005
00773 230705
00774 160000
00775 000001
00776 000764
000777

E13C 2
      -15&777
      -14&777
      E13D=,
      ,SIXBT 'MTDUMP'

E13D 2
      1
      3
      E14=,
      ,SIXBT 'QFILE'

      1
      -14&777

/
E14  E15=,
      ,SIXBT 'SGEN'

      1
      -14&777

E15=,
      ,IFDEF RK05
      E16=,
      ,SIXBT 'MAC11'
      2
      -12&777
      -11&777

E16=,
      E17=,
      ,SIXBT 'SPOOL'
      2
      -11&777
      -5&777

E17=,
      ,ENDC
      CUMBLK E1-SYSBLK
      ,END
      NO ERROR LINES

```

```

00777 000610
      000002
      SIZE=01000

```

/POINTER TO THE FIRST ENTRY IN COMBLK

CUMBLK	00777	260	429*	
END	000233	61	259*	
F1	00617	300*	300	429
E1M	00717	357	363*	363
E11	00716	363	369*	369
E12	00724	360	375*	375
E13	00734	375	383*	383
E13A	00743	383	390*	
E13B	00751	390	395*	
E13C	00757	395	400*	
E13D	00765	400	405*	
E14	00772	405	410*	
E15	000777	410	414*	
E3	00615	300	305*	305
E4	00624	305	312*	312
E4A	00634	312	320*	
E5	00643	320	327*	327
E6	00650	327	332*	332
E7	00663	332	342*	342
E8	00673	342	350*	350
E9	00702	350	357*	357
SE1	00001	60*		
SE10	00062	130*		
SE11	00071	145*		
SE12	00100	150*		
SE13	00107	150*		
SE14	00116	165*		
SE15	00125	173*		
SE16	00134	181*		
SE17	00143	188*		
SE2	00010	75*		
SE20	00152	195*		
SE21	00161	202*		
SE22	00170	209*		
SE23	00177	216*		
SE24	00206	223*		
SE25	00215	230*		
SE26	00224	237*		
SE3	00017	80*		
SE4	00026	90*		
SE5	00035	116*		
SE6	00044	123*		
SE7	00053	130*		
SYSBLK	00000	1	61*	429

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27

!TITLE SGNBLK DOS15

FIRST PRINTING, FEBRUARY 1974

/ THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO
/ CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED
/ AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.
/ DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPON-
/ SIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS
/ DOCUMENT.

/ THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FUR-
/ NISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON
/ A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH
/ INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR
/ USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PRO-
/ VIDED IN WRITING BY DIGITAL.

/ DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY
/ FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIP-
/ MENT THAT IS NOT SUPPLIED BY DIGITAL.

/ COPYRIGHT (C) 1974, BY DIGITAL EQUIPMENT CORPORATION

!EJECT

```

28 /
29 /COPYRIGHT 1971,72,73 DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.
30 /
31 /EDIT #010 XXXX 6-OCT-71
32 /EDIT #014 S.KRISH 17-SEP-73 UC15 GENERAL FIXUP
33 /EDIT #015 S.KRISH 25-SEP-73 UC15 SYSDEV CODE BUG FIX
34 /EDIT #016 S.KRISH 10-OCT-73 SPOOLER START BLK # CHANGE TO
35 / 11207 TO PERMIT CTL 'Q'
36 /EDIT #017 S.ROOT 13-OCT-73 FIX RKSF FROM 706121 TO 706101
37 /EDIT #018 S.KRISH 15-OCT-73 NO LPU,CDU & XYU. BOSS15 PERMITS
38 / ONLY ONE LP & CD HANDLER IN
39 / SYSTEM CALLED LPA & CDB !!!!!
40 / #019 15-JUL-74 BY ED GARDNER FIX DEVICE SKIP MNEMONICS TO AGREE
41 / WITH THOSE IN 15 USERS HANDBOOK.
42 / INSERT STUFF FOR LTX. DUMMY HANDLER.
43 / #020 22-JUL-74 BY ED GARDNER REDUCE NUMBER OF LT19 SKIPS FROM
44 / 16 LINES TO 5 LINES SO SGNBLK WILL
45 / FIT IN ONE DISK BLOCK.
46 /
47 / SGNBLK (SYSTEM BLOCK #36(8)) CONTAINS ALL THE SYSTEM PARAMETERS
48 /NOT ASSOCIATED DIRECTLY WITH SYS FILE CUSPS. THE BULK OF SGNBLK
49 /IS CONCERNED WITH I/O (.DAT SLOTS, .UFD SLOTS, SKIP CHAIN ORDER, HANDLERS,
50 /SKIP IOT NUMBERS AND MNEMONICS). THE FIRST FEW REGISTERS OF SGNBLK
51 /HOLD SUCH IMPORTANT SYSTEM PARAMETERS AS THE SYSTEM DEVICE,
52 / .SCOM+4 CONTENTS, ETC. SGNBLK IS PART OF THE
53 /SYSTEM LOADER AND NON-RESIDENT MONITOR AND STARTS AT LOCATION
54 /17100(8). THE FIRST
55 /WORD IN SGNBLK POINTS TO THE UNRELOCATED ADDRESS OF THE FIRST FREE
56 /WORD IN THE BLOCK. THE NEXT ENTRY IS AN OFFSET WORD INDICATING
57 /THE TOTAL LENGTH (INCLUDING ITSELF) OF THE MISCELLANEOUS
58 /SYSTEM PARAMETER TABLE TO FOLLOW. THIS TABLE INCLUDES THE SIZE OF
59 /THE .DAT SLOT TABLE AND THE SIZE OF THE SKIP CHAIN TABLE. THE END
60 /OF THE HANDLER AND SKIP IOT TABLE IS THE FIRST FREE ENTRY OF THE BLOCK.
61 /
62 /ABS
63 17100 .LOC 17100
64 17100 000341 SGNBLK $GEND=17100 /POINTER TO FIRST FREE ENTRY IN SGNBLK
65 .EJECT

```

```

66          ' IFUND RK05
67          ' IFDEF RP02
68          SYSDEV=17
69          ' ENDC
70          ' IFUND RP02
71          000014      SYSDEV=14
72          ' ENDC
73          ' ENDC
74          ' IFDEF RK05
75          SYSDEV=33
76          ' ENDC
77          /
78          /BASIC SYSTEM PARAMETERS
79          /
80          17101      000015      NOPAR      SGNDAT=.          /NUMBER OF MISCELLANEOUS PARAMETERS
81          17102      000074      NODAT       SGNSKP=SGNDAT      /((NUMBER OF POSITIVE .DAT SLOTS + 16)*2
82                                     /EQUALS SIZE OF .DAT SLOT TABLE AND .UFD TABLE
83          17103      000033      NOSKP       SGNTAB=SGNSKP      /NUMBER OF SKIPS IN THE SKIP CHAIN
84          017104      SDEV1=.          /SYSTEM DEVICE CODE
85          ' IFUND RK05
86          ' IFDEF RP02
87          ' SIXBT /DP/
88          ' ENDC
89          ' IFUND RP02
90          17104      041300      ' SIXBT /DK/
91          ' ENDC
92          ' ENDC
93          ' IFDEF RK05
94          ' SIXBT /RK/
95          ' ENDC
96          17105      300500      SCOM4      300500          /ORIGINAL CONTENTS OF .SCOM+4
97          17106      000000      SCOM20     0              /ORIGINAL CONTENTS OF .SCOM+20
98          17107      000500      X1         500           /NUMBER OF DATA REGISTERS PER OPEN FILE ON MASS
99                                     /STORAGE (.SCOM+27)
100         17110      000003      FILES      3              /DEFAULT NUMBER OF FILES TO BE OPEN AT SAME TIME (.SCOM+26)
101                                     /FOR USE WITH THE LINKING LOADER AND EXECUTE
102         17111      233123      MIC        'SIXBT 'SYS'          /THE MONITOR IDENTIFICATION CODE
103         17112      000000      SCOM33     0              /AX INFORMATION (.SCOM+33)
104         17113      000002      PROTCT     2              /DEFAULT PROTECTION CODE FOR FILES (.SCOM+54)
105                                     / 1      READ/WRITE (WITH RANDOM ACCESS)
106                                     / 2      READ/NO WRITE
107                                     / 3      NO READ/NO WRITE
108         17114      000000      PCHS7      0              /SIZE OF THE RESIDENT MONITOR PATCH AREA
109         17115      777704      CLKCON     =74           /-# OF TICKS IN A SECOND (-74 FOR
110          ' IFDEF RK05
111          SCOM76     11207          /SPOOLER AREA START BLOCK #
112          SCOM77     5006          /SPOOLER AREA SIZE
113          ' ENDC
114                                     /60 CPS AND -62 FOR 50 CPS)
115          /

```

116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158

```

        .TITLE .DAT SLOTS TABLE
/
/      THIS .DAT SLOT TABLE CORRESPONDS TO THE LEGAL RANGE
/OF .DAT SLOTS WITH THE MAXIMUM NEGATIVE .DAT SLOT SET TO -15 AND
/THE MAXIMUM POSITIVE .DAT SLOT SET TO A SYSTEM PARAMETER NOT TO
/EXCEED 77(8). THE .DAT SLOTS ARE IN THE SAME FORM AS BEFORE. THE
/UNIT NUMBER IS IN BITS 0=2 AND THE NUMBER OF THE HANDLER RIGHT
/JUSTIFIED IN BITS 3=18. THE HANDLER NUMBER FOR THE FIRST HANDLER IN
/THE DEVICE HANDLER-SKIP IOT TABLE IS 0 (FOR THE PSEUDO-HANDLER NON).
/TTA IS 1 ETC. THE CONSTANT 100000 INDICATES A FIXED OR ILLEGAL
/.DAT SLOT. THESE SLOTS ARE NOT SET BY SGEN.
/
SGNDAT  SYSDEV      /-15
        SYSDEV      /-14
        SYSDEV      /-13
        1            /-12
        SYSDEV      /-11
        1            /-10
        100000      /-7
        SYSDEV      /-6
        0            /-5
        SYSDEV      /-4
        100000      /-3
        100000      /-2
        SYSDEV      /-1
        100000      /0
        SYSDEV      /1
        SYSDEV      /2
        SYSDEV      /3
        1            /4
        2            /5
        4            /6
        100007      /7
        200007      /10
        0            /11
        0            /12
        0            /13
        0            /14
        0            /15
        0            /16
        0            /17
        0            /20
    
```

159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197

```

      .TITLE .UFD TABLE
      /
      / .UFD TABLE IS IN 1 TO 1 CORRESPONDENCE WITH THE .DAT SLOT
      /TABLE. AN ENTRY OF .SIXBT 'UIC' INDICATES THAT THE LOGIN
      /UIC IS TO BE SUBSTITUTED FOR THE NAME UIC IN THE TABLE. OTHERWISE
      /THE CONTENTS OF EACH LOCATION WILL BE THE .SIXBT REPRESENTATION OF
      /THE CORRESPONDING .UFD SLOT.
      /
      SGNUFD .SIXBT 'UIC' /-15
            .SIXBT 'UIC' /-14
            .SIXBT 'UIC' /-13
            .SIXBT 'UIC' /-12
            .SIXBT 'UIC' /-11
            .SIXBT 'UIC' /-10
            .SIXBT 'SYS' /-7
            .SIXBT 'UIC' /-6
            .SIXBT 'UIC' /-5
            .SIXBT 'UIC' /-4
            .SIXBT 'UIC' /-3
            .SIXBT 'UIC' /-2
            .SIXBT 'SYS' /-1
            .SIXBT 'SYS' /0 MIC
            .SIXBT 'UIC' /1
            .SIXBT 'UIC' /2
            .SIXBT 'UIC' /3
            .SIXBT 'UIC' /4
            .SIXBT 'UIC' /5
            .SIXBT 'UIC' /6
            .SIXBT 'UIC' /7
            .SIXBT 'UIC' /10
            .SIXBT 'UIC' /11
            .SIXBT 'UIC' /12
            .SIXBT 'UIC' /13
            .SIXBT 'UIC' /14
            .SIXBT 'UIC' /15
            .SIXBT 'UIC' /16
            .SIXBT 'UIC' /17
            .SIXBT 'UIC' /20
  
```

```

17154 251103
17155 251103
17156 251103
17157 251103
17160 251103
17161 251103
17162 233123
17163 251103
17164 251103
17165 251103
17166 251103
17167 251103
17170 233123
17171 233123
17172 251103
17173 251103
17174 251103
17175 251103
17176 251103
17177 251103
17200 251103
17201 251103
17202 251103
17203 251103
17204 251103
17205 251103
17206 251103
17207 251103
17210 251103
17211 251103
  
```

198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246

D-18

TITLE SKIP CHAIN TABLE

```

/
/ THE SKIP CHAIN TABLE LISTS THE SYSTEM SKIP IOTS IN ORDER
/ A NEGATIVE SKIP APPEARS IN THE TABLE IN 1'S COMPLEMENT(POSITIVE).
/ NOT ALL THE SKIPS IN THE HANDLER-SKIP IOT TABLE NEED TO BE INCLUDED IN
/ THIS TABLE. THE DONE COMMAND IN SGEN CAN BE USED TO TERMINATE
/ THE SKIP CHAIN BUILDING AT ANY SIZE. THIS EFFECTIVELY DELETES THE
/ REMAINING, UNLISTED SKIPS FROM THE SKIP CHAIN.
/
SGNSKP 703201 /SPFAL
        707601 /DTDF
        .IFUND RB09
        707001 /DSSF
        .ENDC
        .IFDEF RB09
        707121 /DSSF
        .ENDC
        .IFDEF RK05
        706101 /RKSF
        .ENDC
        706341 /DPSJ
        707341 /MTSF
        703121 /SPDI
        703261 /WTSK
        700521 /SDDF
        706701 /CRSI
        706721 /CRSD
        706501 /LPSF
        700001 /CLSF
        700101 /RSF
        700201 /PSF
        700301 /KSF
        704101 /KSF1
        700401 /TSF
        707561 /DTEF
        706361 /DPSE
        701741 /MPSNE
        701701 /MPSK
        702701 /SPE
        .IFDEF RK05
        706121 /CDSF
        706141 /LSSF
        706161 /XYSF
        .ENDC
        704101 /KSF1
        704121 /KSF2
        704141 /KSF3
        704161 /KSF4
        704301 /KSF5
    
```

```

247           'TITLE  DEVICE HANDLER-SKIP IOT TABLE
248           /
249           /      THE DEVICE HANDLER-SKIP IOT TABLE CONTAINS ALL THE HANDLER NAMES
250           /AND SKIP IOT NUMBERS AND MNEMONICS FOR EACH I/O DEVICE KNOWN TO THE
251           /SYSTEM.  EVERY DEVICE HAS AN ENTRY IN THE TABLE.  A HANDLER
252           /NAME MUST BE EXACTLY 3 CHARACTERS IN LENGTH WITH THE LAST CHARACTER
253           /NOT AN OCTAL DIGIT.  THE DEVICE CODE FOR A DEVICE IS EXACTLY 2
254           /CHARACTERS.  THE FIRST 2 CHARACTERS OF EACH HANDLER NAME FOR A
255           /DEVICE MUST BE THE DEVICE CODE.  THIS FACT IS ESSENTIAL FOR UNDERSTAND-
256           /ING THE FORMAT OF A DEVICE ENTRY, SINCE THE DEVICE CODE IS NEVER
257           /STORED AS SUCH IN AN ENTRY, BUT IS INFERRED FROM THE DEVICE HANDLER
258           /NAMES.  THE TYPICAL ENTRY FOR A DEVICE IS THE FOLLOWING:
259           /      (1) THE FIRST WORDS OF AN ENTRY CONTAIN THE HANDLER NAMES
260           /      FOR A DEVICE IN .SIXBT.  EACH HANDLER NAME IS DIFFERENT.
261           /      A 3 CHARACTER HANDLER NAME IN .SIXBT NEATLY FITS INTO
262           /      1 COMPUTER WORD.  THE END OF THE LIST IS DETERMINED
263           /      BY A WORD WITH 0'S IN BITS 0-5 (FIRST CHARACTER POSITION).
264           /      (2) THE WORD THAT TERMINATED (1) CONTAINS THE NUMBER OF SKIP
265           /      IOTS FOR THE DEVICE.  FOR EACH SKIP IOT 3 WORDS ARE IN THE
266           /      TABLE.  THE FOLLOWING IS A REPRESENTATION OF THESE 3 WORDS:
267           /      (A) THE FIRST 2 WORDS ARE THE SKIP MNEMONIC USED FOR
268           /      REFERRING TO THE SKIP SYMBOLICLY IN .SIXBT WITH
269           /      TRAILING CHARACTER POSITIONS CONTAINING 0'S.  THE
270           /      SKIP MNEMONIC MUST NOT EXCEED 6 CHARACTERS.
271           /      (B) THE LAST WORD ABOUT THE SKIP IS THE ACTUAL MACHINE
272           /      INSTRUCTION NUMBER FOR THE SKIP IOT.  IF THE
273           /      SKIP IS NEGATIVE THIS NUMBER WILL BE 1'S COMPLEMENT
274           /      OF THE ACTUAL MACHINE INSTRUCTION (POSITIVE).
275           /THE NEXT DEVICE ENTRY FOLLOWS THE LAST SKIP FOR THE PREVIOUS DEVICE.
276           /A HANDLER MAY BE ENTERED WITHOUT ANY SKIPS, BUT NO DEVICES MAY BE
277           /ENTERED WITHOUT AT LEAST ONE HANDLER NAME.
278           /
279           17245 161716 SGNTAB 'SIXBT 'NON'           /DEV 0 HAND. 0
280           17246 000005           5           /5 SKIPS
281           17247 031423           'SIXBT 'CLSF'           /CLOCK DONE
282           17250 060000
283           17251 700001           700001
284           17252 152023           'SIXBT 'MPSNE'           /NON-EXISTENT MEMORY REFERENCE
285           17253 160500
286           17254 701741           701741
287           17255 152023           'SIXBT 'MPSK'           /MEMORY PROTECT VIOLATION
288           17256 130000
289           17257 701701           701701
290           17260 232005           'SIXBT 'SPE0'           /MEMORY PARITY ERROR
291           17261 000000
292           17262 702701           702701
293           17263 232006           'SIXBT 'SPFAL'           /POWER FAIL
294           17264 011400
295           17265 703201           703201
296           'EJECT

```

D-19

PAGE	8	SGNBLK	020	DEVICE	HANDLER=SKIP	IOT	TABLE
292		17266	242401	DEV1	'SIXBT	'TTA'	/DEV1 HAND.1
293		17267	000002		'	'	/2 SKIPS
294		17270	132306		'SIXBT	'KSF0'	/KEYBOARD DONE
		17271	000000				
295		17272	700301		700301		
296		17273	242306		'SIXBT	'TSF0'	/TELEPRINTER DONE
		17274	000000				
297		17275	700401		700401		
298		17276	202201	DEV2	'SIXBT	'PRA'	/DEV2 HAND.2
299		17277	202202		'SIXBT	'PRB'	/HAND.3
300		17300	000001		'	'	/1 SKIP
301		17301	222306		'SIXBT	'RSF0'	/READER DONE
		17302	000000				
302		17303	700101		700101		
303		17304	202001	DEV3	'SIXBT	'PPA'	/HAND.4
304		17305	202002		'SIXBT	'PPB'	/HAND.5
305		17306	202003		'SIXBT	'PPC'	/HAND.6
306		17307	000001		'	'	/1 SKIP
307		17310	202306		'SIXBT	'PSF0'	/PUNCH DONE
		17311	000000				
308		17312	700201		700201		
309		17313	042401	DEV4	'SIXBT	'DTA'	/HAND.7
310		17314	042403		'SIXBT	'DTC'	/HAND.10
311		17315	042404		'SIXBT	'DTD'	/HAND.11
312		17316	042405		'SIXBT	'DTE'	/HAND.12
313		17317	042406		'SIXBT	'DTE'	/HAND.13
314		17320	000002		'	'	
315		17321	042404		'SIXBT	'DTEF'	/DECTAPE DONE
		17322	060000				
316		17323	707601		707601		
317		17324	042405		'SIXBT	'DTEF'	/DECTAPE ERROR
		17325	060000				
318		17326	707501		707501		
319		17327	041301	DEV5	'SIXBT	'DKA'	/HAND.14
320		17330	041302		'SIXBT	'DKB'	/HAND.15
321		17331	041303		'SIXBT	'DKC'	/HAND.16
322		17332	000001		'	'	/1 SKIP
323		17333	042323		'SIXBT	'DSSP'	/DISK DONE
		17334	060000				
324					'IFUND	RB09	
325		17335	707001		707001		
326					'ENDC		
327					'IFDEF	RB09	
328					707121		
329					'ENDC		
330					'EJECT		

D-20

PAGE	9	SGNBLK 020	DEVICE HANDLER=SKIP	IOT TABLE	
331	17336	042001	DEV6	'SIXBT 'DPA'	/HAND. 17
332	17337	042002		'SIXBT 'DPB'	/HAND. 20
333	17340	042003		'SIXBT 'DPC'	/HAND. 21
334	17341	000002		2	
335	17342	042023		'SIXBT 'DPSJ'	/DISK DONE
	17343	120000			
336	17344	706341		706341	
337	17345	042023		'SIXBT 'DPSE'	/DISK ERROR
	17346	050000			
338	17347	706361		706361	
339	17350	152401	DEV7	'SIXBT 'MTA'	/HAND. 22
340	17351	152403		'SIXBT 'MTC'	/HAND. 23
341	17352	152406		'SIXBT 'MTF'	/HAND. 24
342	17353	000001		1	/1 SKIP
343	17354	152423		'SIXBT 'MTSF'	/MAGNETIC TAPE DONE ON ERROR
	17355	060000			
344	17356	707341		707341	
345	17357	142001	DEV10	'SIXBT 'LPA'	/HAND. 25
346				'IFUND RK05	
347	17360	000001		1	/1 SKIP
348				'ENDC	
349				'IFDEF RK05	
350				2	
351				'ENDC	
352	17361	142023		'SIXBT 'LPSF'	/LINE PRINTER DONE
	17362	060000			
	17363	706501		706501	
353				'IFDEF RK05	
354				'SIXBT 'LSSF'	
355				706141	
356				'ENDC	
357				'SIXBT 'COB'	/HAND. 26
358	17364	030402	DEV11	'IFUND RK05	
359				2	/2 SKIPS
360	17365	000002		'ENDC	
361				'IFDEF RK05	
362				3	
363				'ENDC	
364				'SIXBT 'CRSI'	/CARD READER
365	17366	032223			
	17367	110000			
366	17370	706701		706701	
367	17371	032223		'SIXBT 'CRSD'	
	17372	040000			
368	17373	706721		706721	
369				'IFDEF RK05	
370				'SIXBT 'CDSF'	
371				706121	
372				'ENDC	
373	17374	262001	DEV12	'SIXBT 'VPA'	/HAND. 27
374	17375	000001		1	/1 SKIP
375	17376	230404		'SIXBT 'SDDF'	/DISPLAY
	17377	060000			

376	17400	700521		700521	
377	17401	262401	DEV13	'SIXBT 'VTA'	/HAND. 30; VT SCOPE DISPLAY
378	17402	000001		1	/1 SKIP; LIGHT PEN; PUSH BUTTON;
379	17403	232004		'SIXBT 'SPDI'	/INTERNAL AND EXTERNAL STOP
	17404	110000			
380	17405	703121		703121	/OR EDGE VIOLATION ON VT
381	17406	262701	DEV14	'SIXBT 'VWA'	/HAND. 31; WRITING TABLET
382	17407	000001		1	/1 SKIP
383	17410	272423		'SIXBT 'WTSK'	/PEN CONTACT WITH TABLET
	17411	130000			
384	17412	703261		703261	
385	17413	141301	DEV15	'SIXBT 'LKA'	/HAND. 32; VT KEYBOARD LK35
386	17414	000001		1	/1 SKIP
387	17415	132306		'SIXBT 'KSF1'	/LK35 KEYBOARD DONE
	17416	610000			
388	17417	704101		704101	
389				'IFDEF RK05	
390			DEV16	'SIXBT 'RKA'	/(HAND. 33; RK05 DISK CARTRIDGE)
391				'SIXBT 'RKB'	/(HAND. 34)
392				'SIXBT 'RKC'	/(HAND. 35)
393				1	
394				'SIXBT 'RKSF'	
395				706101	
396			DEV17	'SIXBT 'XYA'	/(HAND. 36; XY PLOTTER)
397				1	
398				'SIXBT 'XYSF'	
399				706161	
400				'ENDC	
401	17420	142430	DEV20	'SIXBT 'LTX'	/HAND. 37; LT15/LT19 DUMMY HANDLER
402	17421	000005		5	
403	17422	132306		'SIXBT 'KSF1'	
	17423	610000			
404	17424	704101		704101	
405	17425	132306		'SIXBT 'KSF2'	
	17426	620000			
406	17427	704121		704121	
407	17430	132306		'SIXBT 'KSF3'	
	17431	630000			
408	17432	704141		704141	
409	17433	132306		'SIXBT 'KSF4'	
	17434	640000			
410	17435	704161		704161	
411	17436	132306		'SIXBT 'KSF5'	
	17437	650000			
412	17440	704301		704301	
413		017441	SGEND=.	'END	
414		000000		'END	
		SIZE=17441	NO ERROR	LINES	

PAGE 11 SGNBLK CROSS REFERENCE

CLKCON	17115	109*							
DEV1	17266	292*							
DEV10	17357	345*							
DEV11	17364	358*							
DEV12	17374	373*							
DEV13	17401	377*							
DEV14	17406	381*							
DEV15	17413	385*							
DEV2	17276	298*							
DEV20	17420	401*							
DEV3	17304	303*							
DEV4	17313	309*							
DEV5	17327	319*							
DEV6	17336	331*							
DEV7	17350	339*							
FILES	17110	100*							
MIC	17111	102*							
NODAT	17102	81*							
NOPAR	17101	80*							
NOSKP	17103	83*							
PCHSZ	17114	108*							
PROTCT	17113	104*							
SCOM20	17106	97*							
SCOM33	17112	103*							
SCOM4	17105	96*							
SDEV1	017104	84*							
SGEND	017441	64	413*						
SGNBLK	17100	1	84*						
SGNDAT	17116	80	81	128*					
SGNSKP	17212	81	83	207*					
SGNTAB	17245	83	279*						
SGNUFD	17154	167*							
SYSDEV	000014	68*	71*	75*	128	129	130	132	135
		137	140	142	143	144			
X1	17107	98*							

INDEX

Absolute Loader, A-1
 ADD NEW DEVICE (Section C), 2-12
 Addressing, 3-4
 default mode, 2-7
 ADD SYS PROG (Section H), 2-23
 ALTER .DAT SLOTS? (Section F), 2-18
 ALTER DEVICE PARAMETERS (Section E),
 2-15
 ALTER I/O DEVICE OR HANDLERS?
 (Section B), 2-8
 ALTER SYSTEM PARAMETERS (Section A),
 2-1
 Answers, default, 1-2, 1-4
 API? (Section A), 2-1
 A section, 2-1, 2-2
 Assembly of PIREX, 3-7

 Bank mode, 2-22
 Batching Command Mode, 1-3
 Binary files, 3-2
 Blocks, free, 3-11
 Block size for spooler, 2-4
 Blocks on system device, 2-21
 BNK directory listings, B-1
 Bootstrap restart, 2-25
 B Section, 2-8, 2-9
 Buffer allocation, 2-3, 2-22
 Buffer size, 2-4
 BUFFS,
 Section G, 2-22
 Section H, 2-23
 BUILDING DOS-15, 3-1

 Carriage return, 1-2, A-1
 CHAIN, 2-22
 CHANGE SKIP CHAIN (Section D),
 2-15
 CHANGE SYS FILES (Section G),
 2-19
 CIRCLE subroutine, 3-5
 COMBLK, 1-4, 1-6, 3-1
 Copy the system, 3-10
 Core image files, 3-1
 Core image system programs, 3-11
 C Section, 2-12, 2-13
 CTRL C, 1-2
 CTRL P, 1-2, 2-12

 .DAT SLOTS
 Section G, 2-22
 Section H, 2-23
 DECdisk system, 3-3
 Default addressing mode, 2-7
 Default answers, 1-2, 1-4
 DEFAULT FILES PROTECTION CODE,
 (Section A), 2-6
 DEFAULT # BUFFERS, (Section A), 2-3
 Default settings of .SCOM registers,
 1-4

 DEVICE CODE (Section C), 2-12
 Device handler LTX., 3-3
 Device handler names, 2-8
 Device handlers, 1-7, 2-14, 3-2
 Directory listings, B-1
 Disk contents, 3-1
 Disk restore tapes, 3-1
 Disk storage, freeing of, 3-3
 DISPLAY .DAT SLOTS (Section F),
 2-18
 DISPLAY SKIP CHAIN (Section D),
 2-15
 Display, VP15, 3-6
 DOSSAV operating instructions, A-1
 DOSSAV restrictions, A-6
 D Section, 2-15, 2-16

 Error conditions, A-5
 Error messages, 1-4, A-5
 E Section, 2-15, 2-17
 EXTRA 4K? (Section A), 2-6

 File Protection code, 2-6
 Files, 3-2
 Floating Point library, 3-5
 FORTRAN considerations, 3-4
 F Section, 2-17, 2-18

 Graphics, 3-5
 G Section, 2-19, 2-20

 HALF ON (Section E), 2-18
 Handlers, 1-7, 2-8, 2-14, 3-2, 3-3
 H Section, 2-23, 2-24

 IOS directory listings, B-1
 IOT's, 2-11

 KSR-33/35, 2-1

 LA30 (Section A), 2-3
 Left arrow (←) usage, 1-3, 1-4
 Libraries, 3-5
 Line frequency, 2-7
 LINE PRINTER SIZE (Section E), 2-18
 Listings,
 directory, B-1
 PER UFD, C-1
 SGNBLK, D-1
 SYSBLK, D-1
 Loading DOSGEN, 1-1
 Loading PIREX, A-1
 LT device handler (LTX.), 3-3

 MAC11 Assembler, 3-6
 MIC (Section A), 2-3
 Modification of system, 1-1

Names,
 of device handlers, 2-8
 of overlays, 2-23
 of programs, 2-23
Negative skips, 2-12, 2-15
NEW ASSIGNMENTS (Section F), 2-19
NEW HANDLERS,
 Section B, 2-10
 Section C, 2-14
NEW SKIPS,
 Section B, 2-11
 Section C, 2-14
OF BLOCKS,
 Section G, 2-21
 Section H, 2-23
OF POSITIVE .DAT SLOTS (Section F),
 2-18
WORDS/BUFFER (Section A), 2-4

Octal numbers, 2-7
Old skips (Section B), 2-11
One-mode addressing, 3-4
Operation of DOSGEN, 1-4, 2-1
Options, 2-1
Organization of DOSGEN, 1-1
OVERLAY NAME,
 Section G, 2-21
 Section H, 2-23
Overlays, 2-21

PAG directory listings, B-1
Page mode, 2-22
PAGE MODE SYSTEM (Section A), 2-7
Parentheses usage, 1-3
PATCH, 1-7, 3-10
PER UFD, 3-10
 listing, C-1
PIP, 1-7, 3-10
PIREX, 3-6
 loading, A-1
 reconfiguration, 3-7
Point plotting display, 3-6
Preliminary DOSGEN run, 3-3
PROG NAME (Section H), 2-23

↑Q AREA SIZE (Section G), 2-19
Questions and answers, 1-2

Recoverable errors, A-4
Registers, 2-18
Relocatable binary files, 3-2
REQUEST command, 2-18
Restart by bootstrap, 2-25
Restart points, 1-2
Restarts in Section C, 2-12
RESIDENT PATCH AREA SIZE (Section
 A), 2-7
Restoring systems, A-2
Restore tapes, A-6
RF disk system device, 2-19, 3-8
RK as system device, 3-8
RK05 system, 3-3, 3-4

ROTATE subroutine, 3-5
RP as system device, 3-8

Saving systems, A-4
Second run, 3-10
Section A, 2-1, 2-2
Section B, 2-8, 2-9
Section C, 2-12, 2-13
Section D, 2-15, 2-16
Section E, 2-15, 2-17
Section F, 2-17, 2-18
Section G, 2-19, 2-20
Section H, 2-23, 2-24
7-CHANNEL MAGTAPE (Section E),
 2-15
SGNBLK, 1-4, 1-5, 2-18, 3-1
 listings, D-1
60 CPS? (Section A), 2-7
Skip chain, 2-11, 3-3
SKIP MNEMONICS IN ORDER (Section
 D), 2-15
Skips, 2-14
Source assembly parameters, C-1
Source files, 3-2
 in PER UFD, 3-10
Specification of MIC, 1-3
Spooler alterations, 3-6
Spooler area, 3-4, 3-11
Spooler configuration, 3-7
SPOOLER SIZE (Section A), 2-6
SPOOLER START BLK. # (Section A),
 2-4, 2-5
Spurious interrupts, 3-3, 3-4
Storage Allocation Table (SAT),
 2-21, A-3
SYSBLK, 1-4, 1-6, 3-1
 listings, D-1
System device, 3-3, 3-8
System modification, 1-1
System programs, 1-7, 3-1

Tape structure, A-6
Teleprinter command mode, 1-2
33TTY (A section), 2-1
TO BE KEPT (Section G), 2-21

UC15 CONFIG? (Section A), 2-4
Unichannel-based system considera-
 tions, 3-6
UNICHANNEL-15 option, 3-8
Unrecoverable errors, A-5
USING DOSGEN, 3-11

VPA. device handler, 3-4
VP15 point plotting display, 3-6
VT ON (Section E), 2-18
VT15 Graphics Display Processor,
 3-5

HOW TO OBTAIN SOFTWARE INFORMATION

SOFTWARE NEWSLETTERS, MAILING LIST

The Software Communications Group, located at corporate headquarters in Maynard, publishes newsletters and Software Performance Summaries (SPS) for the various Digital products. Newsletters are published monthly, and contain announcements of new and revised software, programming notes, software problems and solutions, and documentation corrections. Software Performance Summaries are a collection of existing problems and solutions for a given software system, and are published periodically. For information on the distribution of these documents and how to get on the software newsletter mailing list, write to:

Software Communications
P. O. Box F
Maynard, Massachusetts 01754

SOFTWARE PROBLEMS

Questions or problems relating to Digital's software should be reported to a Software Support Specialist. A specialist is located in each Digital Sales Office in the United States. In Europe, software problem reporting centers are in the following cities.

Reading, England	Milan, Italy
Paris, France	Solna, Sweden
The Hague, Holland	Geneva, Switzerland
Tel Aviv, Israel	Munich, West Germany

Software Problem Report (SPR) forms are available from the specialists or from the Software Distribution Centers cited below.

PROGRAMS AND MANUALS

Software and manuals should be ordered by title and order number. In the United States, send orders to the nearest distribution center.

Digital Equipment Corporation Software Distribution Center 146 Main Street Maynard, Massachusetts 01754	Digital Equipment Corporation Software Distribution Center 1400 Terra Bella Mountain View, California 94043
--	--

Outside of the United States, orders should be directed to the nearest Digital Field Sales Office or representative.

USERS SOCIETY

DECUS, Digital Equipment Computer Users Society, maintains a user exchange center for user-written programs and technical application information. A catalog of existing programs is available. The society publishes a periodical, DECUSCOPE, and holds technical seminars in the United States, Canada, Europe, and Australia. For information on the society and membership application forms, write to:

DECUS Digital Equipment Corporation 146 Main Street Maynard, Massachusetts 01754	DECUS Digital Equipment P.O. Box 340 1211 Geneva 26 Switzerland
---	---

READER'S COMMENTS

NOTE: This form is for document comments only. Problems with software should be reported on a Software Problem Report (SPR) form (see the HOW TO OBTAIN SOFTWARE INFORMATION page).

Did you find errors in this manual? If so, specify by page.

Did you find this manual understandable, usable, and well-organized? Please make suggestions for improvement.

Is there sufficient documentation on associated system programs required for use of the software described in this manual? If not, what material is missing and where should it be placed?

Please indicate the type of user/reader that you most nearly represent.

- Assembly language programmer
- Higher-level language programmer
- Occasional programmer (experienced)
- User with little programming experience
- Student programmer
- Non-programmer interested in computer concepts and capabilities

Name _____ Date _____

Organization _____

Street _____

City _____ State _____ Zip Code _____

or
Country

If you do not require a written reply, please check here.

