

**RL01/RL02
POCKET SERVICE GUIDE**

**digital equipment corporation
colorado springs, colorado**

1st Edition, September 1979
(Revision) June 1980
(2nd Revision) October 1980

Copyright © 1979, 1980 by Digital Equipment Corporation

The material in this manual is for informational purposes and is subject to change without notice.

Digital Equipment Corporation assumes no responsibility for any errors which may appear in this manual.

Printed in U.S.A.

The following are trademarks of Digital Equipment Corporation, Maynard, Massachusetts:

| | | |
|--------------|--------------|-----------|
| DEC | DECUS | DECnet |
| DECsystem-10 | DECSYSTEM-20 | DECwriter |
| DIBOL | Digital Logo | EduSystem |
| IAS | LSI-11 | MASSBUS |
| OMNIBUS | PDP | PDT |
| Q-BUS | RSTS | RSX |
| UNIBUS | VAX | VMS |
| | VT | |

CONTENTS

| | | |
|----------|--|-----------|
| 1 | INTRODUCTION | 1 |
| 1.1 | Description | 1 |
| 1.2 | Option Descriptions | 3 |
| 1.3 | Sector Format | 4 |
| 1.4 | Bad Sector File | 4 |
| 2 | FIELD REPLACEABLE UNITS | 7 |
| 3 | FRONT PANEL | 21 |
| 4 | DRIVE CONDITIONS | 23 |
| 5 | REGISTER SUMMARY | 25 |
| 5.1 | RL11/RLV11 Register Summary | 25 |
| 5.2 | RL8-A Register Summary | 32 |
| 6 | BOOTSTRAPS | 41 |
| 6.1 | RL11/RLV11 Bootstrap | 41 |
| 6.2 | RL8-A Bootstrap | 41 |
| 7 | TOGGLE-IN PROGRAMS | 43 |
| 7.1 | Head Selection Program for RL11/RLV11 | 43 |
| 7.2 | Head Selection Program for RL8-A | 44 |
| 7.3 | Get Status (With or Without Reset) on an RL11/RLV11 Subsystem | 44 |
| 7.4 | Get Status on an RL8-A Subsystem | 45 |
| 7.5 | Oscillating Seek for RL11/RLV11 | 46 |
| 7.6 | Oscillating Seek for RL8-A | 47 |

| | | |
|-----------|--|----|
| 8 | DIAGNOSTICS | 49 |
| 8.1 | RL11 Diagnostics | 49 |
| 8.2 | RLV11 Diagnostics | 50 |
| 8.3 | RL8-A Diagnostics | 50 |
| 8.4 | Diagnostic Supervisor | 50 |
| 8.4.1 | Hardcore Questions | 50 |
| 8.4.2 | Console Controls | 53 |
| 8.4.3 | Hardware Questions | 53 |
| 8.4.4 | Software Question | 53 |
| 9 | CHECKS, ADJUSTMENTS AND ALIGNMENTS | 55 |
| 9.1 | Introduction | 55 |
| 9.2 | Voltage Checks | 56 |
| 9.3 | Sector Transducer Output Check | 57 |
| 9.4 | Sector Pulse Timing Check | 58 |
| 9.5 | Positioner Radial Alignment | 58 |
| 9.6 | Head Alignment | 63 |
| 9.7 | Read Signal Amplitude Check | 68 |
| 9.8 | Spindle Runout Check | 69 |
| 9.9 | Position Signal Gain Check | 71 |
| 9.10 | Tachometer AC Noise Pick-Up Check | 72 |
| 9.11 | Velocity Profile Check | 74 |
| 9.12 | Servo Drive Motor Current Check | 75 |
| 9.13 | Access Time Check | 76 |
| 10 | SERVICE TIPS | 81 |
| 10.1 | Loss of +5V Symptom | 81 |
| 10.2 | Loss of +5V Causes | 81 |
| 10.3 | Heads Retract Immediately After Loading | 81 |
| 10.4 | LOAD, READY, and FAULT Indicators All On | 81 |
| 10.5 | RL11 I/O Cabling | 81 |
| 10.6 | Early RL11/RLV11 Vector Assignment | 81 |
| 10.7 | Role of Checks, Adjustments and Alignments in Troubleshooting | 82 |
| 10.8 | Intermittent Read Check Errors | 82 |


FIGURES

| | | |
|------|---|----|
| 1-1 | Sector Format | 5 |
| 1-2 | Bad Sector File | 6 |
| 2-1 | Interconnection of FRUs | 9 |
| 2-2 | Signal and Function Diagram of Power Panel, AC Servo, Brush Drive Assembly | 10 |
| 2-3 | Signal and Function Diagram of DC Servo, Positioner | 11 |
| 2-4 | Signal and Function Diagram of R/W Module, R/W Heads | 12 |
| 2-5 | Signal and Function Diagram of Front Panel ... | 13 |
| 2-6 | Signal and Function Diagram of Drive Logic Module | 14 |
| 2-7 | Physical Location of FRUs | 15 |
| 2-8 | Rear View | 15 |
| 2-9 | Drive Logic Module Layout | 17 |
| 2-10 | R/W Module Layout — Top View | 18 |
| 2-11 | Power Panel Layout — Front View | 18 |
| 2-12 | DC Servo Module Layout — Bottom View . | 19 |
| 2-13 | AC Servo Module Layout — Front View ... | 20 |
| 2-14 | Front Panel Layout — Rear View | 20 |
| 9-1 | Sector Transducer Output | 57 |
| 9-2 | Sector Pulse Timing | 59 |
| 9-3 | Positioner and Read/Write Module Box Assembly | 60 |
| 9-4 | Servo Bursts and Sector Pulse | 61 |
| 9-5 | Positioner Assembly | 62 |
| 9-6 | Adjusting the Head Cables | 67 |
| 9-7 | Position Signal | 70 |
| 9-8 | Position Signal Gain Check Waveform | 72 |
| 9-9 | Summing Amplifier Output | 73 |
| 9-10 | Tachometer Output Velocity Signal | 75 |
| 9-11 | Positioner Motor Current Check | 76 |
| 9-12 | Access Time Check (One Track Seek) | 77 |
| 9-13 | Access Time Check (85 or 170 Track Seek) . | 78 |
| 9-14 | Access Time Check (255 or 511 Track Seek) | 79 |

TABLES

| | | |
|-----|--|----|
| 1-1 | Voltage Ranges | 2 |
| 2-1 | FRU Part Numbers and Interchangeability | 7 |
| 2-2 | Cables | 8 |
| 2-3 | Test Points — Drive Logic Module 54-12175 (Version 1) | 16 |
| 2-4 | Test Points — Drive Logic Module 54-13531 (Version 2) | 16 |
| 2-5 | Test Points — Drive Logic Module 54-14025 (Version 3) | 16 |
| 4-1 | Drive Conditions | 23 |
| 5-1 | Controller Addressable Registers | 25 |
| 5-2 | RL8-A Instruction Set | 32 |
| 8-1 | RL11/RL01 Diagnostics | 49 |
| 8-2 | RL11/RL02 Diagnostics | 49 |
| 8-3 | RL8-A/RL01 Diagnostics | 50 |
| 8-4 | RL8-A/RL02 Diagnostics | 50 |
| 9-1 | Service Jumpers for Drive Logic Module | 55 |
| 9-2 | Methods for Selecting Heads | 56 |

| | | |
|------------|------------------------------------|--|
| CHAPTER 1 | INTRODUCTION | |
| CHAPTER 2 | FIELD REPLACEABLE UNITS | |
| CHAPTER 3 | FRONT PANEL | |
| CHAPTER 4 | DRIVE CONDITIONS | |
| CHAPTER 5 | REGISTER SUMMARY | |
| CHAPTER 6 | BOOTSTRAPS | |
| CHAPTER 7 | PROGRAMMING EXAMPLES | |
| CHAPTER 8 | DIAGNOSTICS | |
| CHAPTER 9 | CHECKS, ADJUSTMENTS AND ALIGNMENTS | |
| CHAPTER 10 | SERVICE TIPS | |



MA 0192

RL01/RL02 Disk Drive

The following RL01/RL02 documents are in the microfiche library.

| Name | Number |
|---|---------------|
| RL01/RL02 Disk Drive Technical Manual | EP-RL012-TM |
| RL11 Controller Technical Description Manual | EP-0RL11-TD |
| RLV11 Controller Technical Manual | EP-RLV11-TD |
| RL8A Omnibus Controller Technical Manual | EP-0RL8A-TM |
| RL01 Disk Drive Illustrated Parts Breakdown | EP-00016-IP |
| RL02 Disk Drive Illustrated Parts Breakdown | EP-00016-IP |
| RL01/RL02 Preventive Maintenance Procedures | EP-00008-PM |

CHAPTER 1

INTRODUCTION

1.1 DESCRIPTION

An RL01/RL02 Disk Subsystem consists of one to four RL01 or RL02 Disk Drives, daisy-chained via an I/O drive bus cable to one of three controllers. The controller may be an RL11, RLV11 or an RL8-A, depending upon the processor. The RL02 (using an RL02K-DC Cartridge) is the double density version of the RL01 (which uses an RL01K-DC Cartridge). Below is a list of subsystem characteristics.

- Single platter, top-loading disk cartridge similar to the 5440 type (physically but not functionally)
- The RL01K-DC and RL02K-DC cartridges are not functionally interchangeable but are physically interchangeable.
- RL01K-DC=5.2 megabytes (formatted), RL02K-DC=10.4 megabytes
- RL01K-DC=256 cylinders, RL02K-DC=512 cylinders
- RL01K-DC=125 tracks/inch, RL02K-DC=250 tracks/inch
- Both platter surfaces are used for data (upper=0, lower=1)
- 40 sectors per track — hub notched for sector marks, no index notch
- 256 eight bit bytes per sector (128 16-bit words or 170 12-bit words)
- Platter rotates at 2400 r/min — 25 ms/rev
- 3725 bits/in — 147 bits/mm max bit density
- 244 ns cell time — 4.1 megabits/sec
- MFM (Miller coding) recording technique
- Peak transfer rate=3.9 μ s/16-bit word, 1.9 μ s/8-bit byte, 2.9 μ s/12-bit word
- Average transfer rate=4.9 μ s/16-bit word, 2.4 μ s/8-bit byte, 3.7 μ s/12-bit word
- Positioner control=track-following servo information imbedded in data track during sector pulse time (servo information is read with data R/W head)
- Positioner type=D.C. servo motor with capstan/cable drive and tachometer feedback
- Factory-formatted servo and header information cannot be reformatted in the field

2 INTRODUCTION

- Seek to next cylinder = 17 ms (max)
- Seek to next surface (switch heads) = 15 ms (max)
- Above two operations combined = 17 ms (max)
- Maximum seek=100 ms
- Average seek=55 ms
- Average rotational latency=12.5 ms
- No hardware (implicit) seek
- No hardware spiral (mid-transfer) seek
- Seeks can be overlapped but subsystem gives no end of seek interrupt
- Sectors are staggered to optimize software spiral seeks
- Automatic detection of inner, outer guard bands (unique servo patterns)
- Brush cycle on cartridge spin-up
- Two separate air systems with heat exchanger
 - 1) Open-air cooling system for modules with muffin fan and coarse filter
 - 2) Closed-loop (recirculated) clean air system for cartridge using blower on spindle drive motor and absolute filter
- Spindle is belt driven from spindle drive/blower motor
- Spindle speed feedback/correction loop compensates for speed variations and allows for ac power frequency range of 50-60 Hz \pm 5%
- Two reversible connectors allow for four ranges of ac power voltage (see Table 1-1)

Table 1-1 Voltage Ranges

| Range | 110/220 Connector | LOW/NOM Connector |
|--------------|------------------------------|------------------------------|
| 90-105 | 110 | LOW |
| 100-128 | 110 | NOM |
| 180-210 | 220 | LOW |
| 200-256 | 220 | NOM |

- No change for 50-60 Hz
- RL11 Controller for PDP-11 UNIBUS
M7762 hex-height SPC module
16-bit word format
Normal address=774400
Normal vector=160
Normal interrupt level=BR5
Can handle RL01s and/or RL02s — can mix
Can handle up to four drives, and a total of 100 feet of daisy-chain drive bus

- RLV11 Controller for LSI-11 Q-Bus
M8013 and M8014 quad height modules
16-bit word format
Normal address=174400
Normal vector=160
Interrupt level=standard (there is only one)
Can handle RL01s and/or RL02s — can mix
Can handle up to four drives, and a total of 100 feet of
daisy-chain drive bus
- RL8-A Controller for PDP-8 OMNIBUS
M8433 hex-height module
8-bit byte or 12-bit word format — program selectable
12-bit word mode=max transfer of one sector/
operation
Normal device code = 60, 61 for first controller, 62, 63
for second (if two controllers, only one can transfer
data at a time)
Normal data break priority 0, can be jumpered for 1
Jumper selection of RL01 or RL02. If jumpered for
RL02, controller can handle either or both —
can mix
Can handle up to four drives, and a total of 100 feet of
daisy-chain drive bus.

1.2 OPTION DESCRIPTIONS

- RL01A=RL01 unit, BC20J-10 I/O cable, chassis slide,
mounting hardware
RL02A=RL02 unit, BC20J-10 I/O cable, chassis slide,
mounting hardware
RL01K-DC=RL01 Data Cartridge
RL02K-DC=RL02 Data Cartridge
RL01-AK=RL01A, RL01K-DC
RL02-AK=RL02A, RL02K-DC
RL11-AK=RL01-AK, RL11, BC06R, transition connector,
terminator
RL211-AK=RL02-AK, RL11, BC06R, transition connec-
tor, terminator
RLV11-AK=RL01-AK, RLV11, BC06R, transition con-
nector, terminator
RLV21-AK=RL02-AK, RLV11, BC06R, transition con-
nector, terminator
RL8A-AK=RL01-AK, RL8A, BC80J, terminator
RL28A-AK=RL02-AK, RL8A, BC80J, terminator

4 INTRODUCTION

CABLE DESCRIPTIONS

- BC06R-XX** = Flat Berg to Berg. Used on RL11 and RLV11 subsystems to connect the controller module to a transition connector which converts Berg to ZIF.
- BC20J-XX** = Round ZIF to ZIF I/O drive bus cable. Used to daisy chain one unit to another. Also used on RL11 and RLV11 subsystems to connect the transition connector to the first unit. Can also be ordered as 70-12122-XX.
- BC80J-XX** = Round Berg to ZIF cable used on RL8-A subsystems to connect the controller module to the first unit.
- Terminator** = Required on last unit of a subsystem.

1.3 SECTOR FORMAT

See Figure 1-1. Each sector consists of:

- Servo data during the sector pulse time
- Header preamble of 48 bits (47 zeroes followed by one "1" marker bit)
- First header information of 16 bits (this is the address and indicates cylinder, surface, and sector)
- Second header word of 16 zero bits
- Third header word of 16 bits of CRC
- Header postamble of 16 zero bits
- Data preamble of 48 bits (47 zeros followed by one "1" marker bit)
- Data — 2048 bits (can be considered as 256 8-bit bytes or 128 16-bit word or 170 12-bit words with 8 unused bits)
- Data CRC of 16 bits
- Data postamble of 16 zero bits
- Idle time waiting for next sector pulse. Varies but is approximately 20 microseconds

The user-writable area starts with the data preamble and ends with the data postamble. The remainder is factory writable only.

1.4 BAD SECTOR FILE

The Bad Sector File is located on the last track (last cylinder, last surface) of the cartridge. It occupies all forty sectors. The layout is illustrated in Figure 1-2.




Figure 1-1 Sector Format

CZ-3007




Figure 1-2 Bad Sector File

CHAPTER 2

FIELD REPLACEABLE UNITS

Table 2-1 is a list of RL01/RL02 Field Replaceable Units (FRUs). Some of the FRUs contain components that are easily checked and replaced. In these cases, an FRU may be repaired instead of replaced. For example, a lamp may be replaced on the front panel or a pico fuse replaced on the DC Servo module. The decision to replace or repair an FRU should be based on such local considerations as part availability, etc.

Some of the FRUs are interchangeable between the RL01 and RL02 and some are not. The interchangeability is indicated in Table 2-1.

Table 2-1 FRU Part Numbers and Interchangeability

The following FRUs are downward-compatible only. The RL02 modules can be used on either drive with just a jumper change. The RL02 spindle can be used on either drive.

| FRU | RL01 Part Number | RL02 Part Number |
|--------------------------|------------------|--------------------------------------|
| Read/Write Module | 54-11844 | 54-13536 |
| DC Servo Module | 54-11850 | 54-13534 |
| Template for DC Servo | 74-18588 | 74-20826 |
| Drive Logic Module (DLM) | 54-12175 | 54-13531 (early) 54-14025 (later) |
| Spindle | 70-12120 | 70-15116 |

The following FRUs are the same for both drives.

| FRU | RL01/RL02 Part Number |
|--------------------------|-----------------------|
| 5 amp fuse (DC Servo) | 12-05747-00 |
| AC Servo Module | 54-11848 |
| Front Panel | 54-11846 |
| Front Panel Lamp (GE 73) | 12-12716-01 |
| Sector Transducer | 70-12137 |
| Positioner | 70-12117 |
| Brush Drive Assembly | 70-12112 |
| Brush Assembly | 70-16726 |
| Spindle/Blower Motor | 70-12114 |
| Spindle Drive Belt | 12-13369 |
| Spindle Ground Brush | 74-15294 |

8 FIELD REPLACEABLE UNITS

| FRU | RL01/RL02 Part Number |
|---|--|
| Head Cable Guide | 70-16983 |
| Insulating Sticker | 74-22834 |
| Coarse Filter | 74-15297 |
| Absolute Filter | 12-13097-03 |
| I/O Terminator | 70-12293-00 |
| Power Panel | 70-12130 |
| <ul style="list-style-type: none"> ● Terminator Block (voltage selection) ● Circuit Breaker ● Line Filter ● Rectifier ● Transformer ● Cap, 66,000 μF for + Vunreg ● Cap, 20,000 μF for - Vunreg ● Cap, for spindle motor ● Fan | 74-16852-01A 12-14360-02 12-12877-00 11-10051-00 16-13897-00 10-13530-00 10-13531-00 10-13102-00 12-09403-01 |

The following FRUs are not interchangeable between an RL01 and an RL02.

| FRU | RL01 Part Number | RL02 Part Number |
|------------|------------------|------------------|
| Upper Head | 74-17178-01 | 70-15637-01 |
| Lower Head | 74-17178-00 | 70-15637-00 |

Table 2-2 lists the cables used in the subsystem.

Table 2-2 Cables

| Cable Description | Part Number | Comments |
|--|-------------|--------------------------------|
| Controller (RL11 or RLV11) to transition connector | BC06R-10 | |
| Controller (RL8-A) to first drive | BC80J-20 | |
| I/O drive cable | BC20J-XX | Also 70-12122-XX |
| Front panel to DLM | 70-12107 | |
| I/O connector to DLM | 70-12123-0H | Stocked as part of 70-14262-00 |
| AC Servo to DLM | 70-12139-0M | Stocked as part of 70-14262-00 |
| Above two cables assembled together | 70-14262-00 | Normally stocked |
| DC Servo to DLM | 70-12139-0F | Signal cable |
| DC Servo to DLM | 70-12140 | Power cable |
| R/W to DLM | 70-12139-0F | |
| Brush drive assy harness | 70-12126 | Part of Brush Drive assy |

Table 2-2 Cables (Cont)

| Cable Description | Part Number | Comments |
|---------------------------------|-------------|---------------------|
| Power panel harness | 70-12108 | Part of power panel |
| Line cord | 70-12109 | Part of power panel |
| DC Servo to power panel harness | 70-12142 | Part of power panel |
| DC Servo to positioner harness | 70-12136-0 | Part of positioner |
| Fan cable | 70-12110 | Part of power panel |

NOTE

All cables are the same part for both the RL01 and the RL02.

Figure 2-1 illustrates the interconnection of the FRUs and shows their approximate physical positions.




Figure 2-1 Interconnection of FRUs on RL01/RL02

Figures 2-2 thru 2-6 illustrate the functional flow and inter-connection of the FRUs.






Figure 2-2 Signal and Function Diagram of Power Panel, AC Servo, Brush Drive Assembly




CZ-2041

Figure 2-3 Signal and Function Diagram of DC Servo, Positioner



CZ-2042

Figure 2-4 Signal and Function Diagram of R/W Module, RW Heads



CZ-2043

Figure 2-5 Signal and Function Diagram of Front Panel

14 FIELD REPLACEABLE UNITS





Figure 2-6 Signal and Function Diagram of Drive Logic Module


Figures 2-7 and 2-8 illustrate the physical location of the FRUs.

Figures 2-9 through 2-14 illustrate the essential component layout of the major FRUs and identify the different versions when appropriate.



CZ-2045

Figure 2-7 Physical Location of FRUs



CZ-1056

Figure 2-8 Rear View

Table 2-3 Test Points — Drive Logic Module 54-12175 (Version 1)

| TP | SIGNAL | TP | SIGNAL |
|----|-------------------|----|------------------|
| 1 | Logic Ground | 9 | Sector Time |
| 2 | Logic Ground | 10 | +8V |
| 3 | Logic Ground | 11 | -8V |
| 4 | Logic Ground | 12 | VEL SIG |
| 5 | Logic Ground | 13 | Signal Ground |
| 6 | Logic Ground | T1 | Input to POS SIG |
| 7 | Integrator Ground | T2 | E1 |
| 8 | Filtered POS SIG | T3 | E2 |

Table 2-4 Test Points — Drive Logic Module 54-13531 (Version 2)


| TP | SIGNAL | TP | SIGNAL |
|----|-------------------|----|------------------|
| 1 | Logic Ground | 12 | Logic Ground |
| 2 | Logic Ground | 13 | Borrow |
| 3 | Logic Ground | 14 | Raw Sector Pulse |
| 4 | Logic Ground | 15 | POS SIG |
| 5 | Integrator Ground | 16 | Ready To R/W |
| 6 | Filtered POS SIG | 17 | Clock Error |
| 7 | Signal Ground | 18 | Clock Error |
| 8 | VEL SIG | T1 | Input to POS SIG |
| 9 | +8V | T2 | E1 |
| 10 | -8V | T3 | E2 |
| 11 | Sector Time | | |

Table 2-5 Test Points — Drive Logic Module 54-14025 (Version 3)

| TP | SIGNAL | TP | SIGNAL |
|----|-------------------|----|------------------|
| 1 | Logic Ground | 16 | Ready to R/W |
| 2 | Logic Ground | 17 | Clock Error |
| 3 | Logic Ground | 18 | Clock Error |
| 4 | Logic Ground | 19 | Cover Open |
| 5 | Integrator Ground | 20 | GND |
| 6 | Filtered POS SIG | 21 | +5V |
| 7 | Signal Ground | 22 | Select Head 1 |
| 8 | VEL SIG | 23 | Seek Error |
| 9 | +8V | | Timer |
| 10 | -8V | 24 | GND |
| 11 | Sector Time | 25 | GND |
| 12 | Logic Ground | 26 | POS SIG |
| 13 | Borrow | T1 | Input to POS SIG |
| 14 | Raw Sector Pulse | T2 | E1 |
| 15 | POS SIG | T3 | E2 |



NOTE

**T1, T2 and T3 are pads for the formatter
 TP 17 and 18 are normally jumpered (except for mfg. checkout)**




54-12175
RL01 ONLY

NOTE:
J11 AND J4
POINT DOWN



54-13531
RL02 OR RL01
W1 IN FOR RL01
W1 OUT FOR RL02

NOTE:
J4 AND J11 POINT UP
NO TP19 THRU 26



NOTE: R DENOTES RED STRIPE

54-14025
RL02 OR RL01
W1 IN FOR RL01
W1 OUT FOR RL02

NOTE:
J4 AND J11 POINT UP
HAS TP19 THRU 26

JUMPER
TEST LUGS EFFECT
19-20 DEFEAT COVER CLOSED
21-22 SELECT HEAD 1
23-24 DISABLE SKTO

(THESE TEST LUGS ARE CIRCLED)

CZ-2046

Figure 2-9 Drive Logic Module Layout

18 FIELD REPLACEABLE UNITS




Figure 2-10 R/W Module Layout — Top View




Figure 2-11 Power Panel Layout — Front View





Figure 2-12 DC Servo Module Layout — Bottom View


NOTE

Later versions of the DC Servo Module have the jumpers (W1 and W2) on top of the module. Thus, they are accessible through the plastic template.



CZ-2049

Figure 2-13 AC Servo Module Layout—Front View



CZ-2051

Figure 2-14 Front Panel Layout — Rear View

CHAPTER 3

FRONT PANEL

FRONT PANEL SWITCHES AND INDICATORS

- **LOAD** indicator is on when the spindle is stopped and the cover is unlocked. This indicates that the operator can open the cover to load or unload the cartridge.
- **LOAD** switch is an alternate action switch that is used to start or stop the spindle. The **IN** position corresponds to **RUN** and the **OUT** position to **STOP**.
- **UNIT NUMBER** plug has cams on the back to encode the unit number into electrical signals. The corresponding number is stamped on the front for the operator to read. The number can be 0 through 3. The plug also serves as a **READY** indicator.
- **READY** indicator is on when the cartridge is up to speed, brush cycle finished, heads loaded, and the heads are "on track". The unit is ready to perform a Read, Write, or Seek operation.
- **FAULT** indicator is on when certain drive conditions exist. These conditions are shown in Table 4-1 — Drive Conditions.
- **WRITE PROT** indicator is on when the Write Protect condition is true. It is the result of the state of the **WRITE PROT** switch.
- **WRITE PROT** switch is an alternate action switch that establishes the Write Protect condition. The **IN** position corresponds to the Write Protect state.

CHAPTER 4 DRIVE CONDITIONS

Table 4-1 Drive Conditions

| Condition | Bit* | FAULT Light | Drive Error | Heads Unld. | Comment |
|---------------------------|------|-------------|-------------|-------------|--|
| Device Select Error (DSE) | 8 | Yes | Yes | No | Set by Drive Select and SEC PLS from another unit. Cleared by Reset or Power On Reset (POR). |
| Volume Check (VC) | 9 | No | Yes | No | Set by Load Heads cycle. Cleared by Reset or POR. |
| Write Gate Error (WGE) | 10 | Yes | Yes | No | Set during Write Gate if one or more of the following occur: <ul style="list-style-type: none"> • Drive is not "Ready to Read/Write" • Drive is Write Protected • Sector pulse is occurring • Drive has another error Cleared by Reset or POR. |
| Spin Error (SPE) | 11 | Yes | Yes | | Spin-up Timeout prevents loading of heads. Set by Spin-up Timeout (40 sec) or Over-speed. Cleared by Reset or POR. |
| Seek Timeout (SKTO) | 12 | Yes | Yes | No | Set by timeout of approximately 1.5 sec. Cleared by Reset or POR. |

*Bit in Multipurpose Register after a Get Status command

MPR= 774406

Table 4-1 Drive Conditions (Cont)

| Condition | Bit* | FAULT Light | Drive Error | Heads Unld. | Comment |
|------------------------------|------|-------------|-------------|-------------|--|
| Write Lock Status (WLS) | 13 | No | No | No | Not an error condition. Set and cleared by WRITE PROT switch. |
| Current In Heads Error (CHE) | 14 | Yes | Yes | Yes | Set by Current in Heads AND NOT Write Gate. Cleared by Reset or POR. |
| Write Data Error (WDE) | 15 | Yes | Yes | Yes | Set by Write Gate AND No Write Data Transitions. Cleared by Reset or POR. |
| Clock Error (---) | -- | Yes | Yes | Yes | Does not latch. No status bit. Set by loss of SYS CLK from controller. Clears itself if condition corrects itself. |

*Bit in Multipurpose Register after a Get Status command


CHAPTER 5 REGISTER SUMMARY

5.1 RL11/RLV11 Register Summary

Table 5-1 Controller Addressable Registers

| Address (octal) | Type (read/ write) | Register Name/ Mnemonic | Basic Function |
|--------------------|--------------------------|-------------------------------|---|
| 774400 | R/W | Control Status (CS) | Indicates drive ready condition; de- codes drive commands and provides overall control functions and error indications |
| 774402 | R/W | Bus Address (BA) | Indicates memory location involved in data transfer during a normal read or write operation |
| 774404 | R/W | Disk Address (DA) | (1) Holds disk address during a data transfer such as Read or Write; or (2) holds the drive command word for a Seek command; or (3) holds the drive command word for a Get Status command |
| 774406 | R/W | Multi- purpose (MP) | (1) Functions as word counter when transferring read/write data between UNIBUS and drives; or (2) holds results of a Get Status command; or (3) holds results of a Read Header com- mand. |

774400
CONTROL STATUS REGISTER (CSR)



CZ-2008

| Bit(s) | Name | Function |
|--------|-----------------------|--|
| 0 | Drive Ready (DRDY) | When set, this bit indicates that the selected drive is ready to receive a command. The bit is cleared when a seek operation is initiated and set when the seek operation is com- pleted. |


26 REGISTER SUMMARY

| Bit(s) | Name | Function | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--------|---|--|--------------------------------|------------|----|---------|------------|---|---|---|--------------------------------|---|---|---|---|-------------|---|---|---|---|------------|---|---|---|---|------|---|---|---|---|-------------|---|---|---|---|------------|---|---|---|---|-----------|---|---|---|---|--------------------------------|---|
| 1-3 | Function Code | <p>These bits are set by software to indicate the command to be executed.</p> <p>Command execution requires that Bit 7 (Controller Ready) be cleared by software. A zero bit being transferred into bit 7 of the CSR can be considered as a Go bit.</p> <table border="1"> <thead> <tr> <th>F2</th> <th>F1</th> <th>F0</th> <th>Command</th> <th>Octal Code</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0</td> <td>No Op (RL11) or Maint. (RLV11)</td> <td>0</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>Write Check</td> <td>1</td> </tr> <tr> <td>0</td> <td>1</td> <td>0</td> <td>Get Status</td> <td>2</td> </tr> <tr> <td>0</td> <td>1</td> <td>1</td> <td>Seek</td> <td>3</td> </tr> <tr> <td>1</td> <td>0</td> <td>0</td> <td>Read Header</td> <td>4</td> </tr> <tr> <td>1</td> <td>0</td> <td>1</td> <td>Write Data</td> <td>5</td> </tr> <tr> <td>1</td> <td>1</td> <td>0</td> <td>Read Data</td> <td>6</td> </tr> <tr> <td>1</td> <td>1</td> <td>1</td> <td>Read Data Without Header Check</td> <td>7</td> </tr> </tbody> </table> | F2 | F1 | F0 | Command | Octal Code | 0 | 0 | 0 | No Op (RL11) or Maint. (RLV11) | 0 | 0 | 0 | 1 | Write Check | 1 | 0 | 1 | 0 | Get Status | 2 | 0 | 1 | 1 | Seek | 3 | 1 | 0 | 0 | Read Header | 4 | 1 | 0 | 1 | Write Data | 5 | 1 | 1 | 0 | Read Data | 6 | 1 | 1 | 1 | Read Data Without Header Check | 7 |
| F2 | F1 | F0 | Command | Octal Code | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 0 | 0 | No Op (RL11) or Maint. (RLV11) | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 0 | 1 | Write Check | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 1 | 0 | Get Status | 2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 1 | 1 | Seek | 3 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 0 | 0 | Read Header | 4 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 0 | 1 | Write Data | 5 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 1 | 0 | Read Data | 6 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 1 | 1 | Read Data Without Header Check | 7 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4-5 | Bus Address Extension Bits (BA16, BA17) | The two most significant bus address bits. Read and written as data bits 4 and 5 of the CS register but considered as address bits 16 and 17 of the bus address register. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Interrupt Enable (IE) | When this bit is set by software, the controller is allowed to interrupt the processor at the normal command or error termination. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | Controller Ready (CRDY) | When cleared by software, this bit indicates that the command in bits 1-3 is to be executed. When set, this bit indicates the controller is ready to accept another command. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8-9 | Drive Select (DS0, DS1) | These bits determine which drive will communicate with the controller via the drive bus. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | Operation Incomplete (OPI) | When set, this bit indicates that the current command was not completed within 200 ms. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |


| Bit(s) | Name | Function | |
|----------------------|---|---|-----------|
| 11 | Data CRC (DCRC) or Header CRC (HCRC) or Write Check (WCE) | <p>If OPI (bit 10) is cleared and this bit is set, a CRC error has occurred when reading the data (DCRC).</p> <p>If OPI (bit 10) is set and bit 11 is also set, the CRC error has occurred on the header (HCRC).</p> <p>If OPI (bit 10) is cleared and bit 11 is set and the function command was a write check, a write check error (WCE) has occurred.</p> | |
| 12 | Data Late (DLT) or Header Not Found (HNF) | <p>This bit is set during a write when the silo is empty but the word count has not yet reached zero (meaning that the bus request was ignored for too long). The OPI bit will not be set.</p> <p>This bit will be set during a read when the silo is full (meaning that the word being read could not enter the silo and the bus request has been ignored for too long). The OPI bit will not be set.</p> <p>When this bit and OPI are both set, a 200 ms timeout occurred while the controller was searching for the correct sector to read or write (no header compare – HNF).</p> | |
| Error Summary | | | |
| Bits | | | |
| Error | 12 | 11 | 10 |
| OPI | 0 | 0 | 1 |
| Read Data | | | |
| CRC | 0 | 1 | 0 |
| Write Check | 0 | 1 | 0 |
| Header CRC | 0 | 1 | 1 |
| Data Late | 1 | 0 | 0 |
| Header Not Found | 1 | 0 | 1 |
| 13 | Non-Existent Memory (NXM) | <p>This bit is set when the addressed memory does not respond within the proper time frame during a direct memory access (DMA) data transfer.</p> | |

28 REGISTER SUMMARY

| Bit(s) | Name | Function |
|--------|-----------------------|---|
| 14 | Drive Error (DE) | This bit is tied directly to the DE interface line. When set, it indicates that the selected drive has flagged an error. (The source of the error can be determined by executing a Get Status command.) DE can be cleared by executing a Get Status command with bit 3 of the DA register set. |
| 15 | Composite Error (ERR) | When set, this bit indicates that one or more of the error bits (bits 10-14) is set. If the IE bit (bit 6 of CS) is set and an error occurs (which sets bit 7), an interrupt will be initiated. |



| Bit(s) | Name | Function |
|--------|---------------|--|
| 0-15 | BA0 thru BA15 | These bits point to the Unibus address that data is to be transferred to/from. Normally a memory address. BA16 and BA17 are in the CSR bits 4 and 5. |



| Bit(s) | Name | Function |
|--------|-----------------|--|
| 0 | - | Must be a 1. |
| 1 | - | Must be a 0. |
| 2 | Direction (DIR) | This bit indicates the direction in which a seek is to take place. When the bit is set, the heads move toward the spindle (to a higher cylinder address). When the bit is cleared, the heads move away from the spindle (to a lower cylinder address). The actual distance moved depends on the cylinder address difference (bits 7-15). |

| Bit(s) | Name | Function |
|--------|---|--|
| 3 | - | Must be a 0. |
| 4 | Head Select (HS) | Indicates which head (disk surface) is selected. A one indicates the lower head; a zero, the upper head. |
| 5-6 | - | Reserved. |
| 7-15 | Cylinder Address Difference DF 08:00 | Indicates the number of cylinders the heads are to move on a seek. |

774404

DAR DURING READING OR WRITING DATA COMMANDS

| | | | | | | | | | | | | | | | |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|----|-----|-----|-----|-----|-----|-----|
| 15 | 14 | 13 | 12 | 11 | 10 | 09 | 08 | 07 | 06 | 05 | 04 | 03 | 02 | 01 | 00 |
| CA8 | CA7 | CA6 | CA5 | CA4 | CA3 | CA2 | CA1 | CA0 | HS | SA5 | SA4 | SA3 | SA2 | SA1 | SA0 |

CZ-2011

| Bit(s) | Name | Function |
|--------|------------------------------|---|
| 0-5 | Sector Address SA 05:00 | Address of one of the 40 sectors on a track. |
| 6 | Head Select (HS) | Indicates which head (disk surface) is to be selected. A one indicates the lower head; a zero, the upper head. The correct track (head and cylinder) must be previously selected by a Seek. |
| 7-15 | Cylinder Address CA 08:00 | Address of the cylinder being accessed. |

774404

DAR DURING GET STATUS COMMAND

| | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|-----|----|----|----|
| 15 | 14 | 13 | 12 | 11 | 10 | 09 | 08 | 07 | 06 | 05 | 04 | 03 | 02 | 01 | 00 |
| X | X | X | X | X | X | X | X | 0 | 0 | 0 | 0 | RST | 0 | 1 | 1 |

CZ-2037

| Bit(s) | Name | Function |
|--------|-----------------|--|
| 0 | - | Must be a 1. |
| 1 | Get Status (GS) | Must be a 1, indicating to the drive that the status word is being requested. At the completion of the Get Status command, the drive status word is read into the controller Multipurpose (MP) register. |
| 2 | - | Must be a 0. |

30 REGISTER SUMMARY

| Bit(s) | Name | Function |
|--------|-------------|---|
| 3 | Reset (RST) | When this bit is set, the drive clears its error register before sending a status word to the controller. |
| 4-7 | - | Must be a 0. |
| 8-15 | - | Not used during a Get Status. |

774406

MPR AFTER GET STATUS COMMAND

| 15 | 14 | 13 | 12 | 11 | 10 | 09 | 08 | 07 | 06 | 05 | 04 | 03 | 02 | 01 | 00 |
|-----|-----|----|------|-----|-----|----|-----|----|----|----|----|----|-----|-----|-----|
| WDE | CHE | WL | SKTO | SPE | WGE | VC | DSE | DT | HS | CO | HO | BH | STC | STB | STA |

CZ-2012

| Bit(s) | Name | Function |
|--------|---------------------|---|
| 0-2 | State C:A ST C:A | These bits define the state of the drive. |

State Bit Definitions

| Bit | Bit | Bit | Definition |
|-----|-----|-----|----------------------------|
| C | B | A | |
| 0 | 0 | 0 | Load Cartridge |
| 0 | 0 | 1 | Spin Up |
| 0 | 1 | 0 | Brush Cycle |
| 0 | 1 | 1 | Load Heads |
| 1 | 0 | 0 | Seek (Track Counting) |
| 1 | 0 | 1 | Lock On (Keeping on track) |
| 1 | 1 | 0 | Unload Heads |
| 1 | 1 | 1 | Spin Down |

| | | |
|---|--------------------------|--|
| 3 | Brush Home (BH) | Set when the brushes are home. |
| 4 | Heads Out (HO) | Set when the heads are over the disk. |
| 5 | Cover Open (CO) | Set when the drive access cover is open or the dust cover is not in place. |
| 6 | Head Select (HS) | Indicates the currently selected head. A zero indicates the upper head; a one, the lower head. |
| 7 | Drive Type (DT) | A zero indicates an RL01; a one, an RL02. |
| 8 | Drive Select Error (DSE) | Set when a multiple drive selection is detected. |
| 9 | Volume Check (VC) | Set when a cartridge is spun up. Cleared by execution of a Get Status command with Bit 3 asserted. |

| Bit(s) | Name | Function |
|--------|----------------------------|--|
| 10 | Write Gate Error (WGE) | Set during Write Gate if one or more of the following conditions occur. <ul style="list-style-type: none"> • Drive is not "Ready to Read/Write" • Drive is Write Protected • Sector pulse is occurring • Drive has another error |
| 11 | Spin Error (SPE) | Set when spindle has not reached speed in the required time during spin-up or when spindle speed is too high. |
| 12 | Seek Time Out Error (SKTO) | Set when the heads do not come on track in the required time during a Seek command or when "Ready to Read/Write" is lost while the drive is in position (lock-on) mode. |
| 13 | Write Lock (WL) | Set when the drive is Write Protected. |
| 14 | Current Head Error (CHE) | Set if Write Current is detected in the heads when Write Gate is not asserted. |
| 15 | Write Data Error (WDE) | Set if Write Gate is asserted but no transitions are being detected on the Write Data line. |

774406

MPR AFTER READ HEADER COMMAND

| | | | | | | | | | | | | | | | |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|----|-----|-----|-----|-----|-----|-----|
| 15 | 14 | 13 | 12 | 11 | 10 | 09 | 08 | 07 | 06 | 05 | 04 | 03 | 02 | 01 | 00 |
| CA8 | CA7 | CA6 | CA5 | CA4 | CA3 | CA2 | CA1 | CA0 | HS | SA5 | SA4 | SA3 | SA2 | SA1 | SA0 |

| | | | | | | | | | | | | | | | |
|-------|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 15 | 14 | 13 | 12 | 11 | 10 | 09 | 08 | 07 | 06 | 05 | 04 | 03 | 02 | 01 | 00 |
| ZEROS | | | | | | | | | | | | | | | |

| | | | | | | | | | | | | | | | |
|-----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 15 | 14 | 13 | 12 | 11 | 10 | 09 | 08 | 07 | 06 | 05 | 04 | 03 | 02 | 01 | 00 |
| CRC | | | | | | | | | | | | | | | |

CZ-2013

| Bit(s) | Name | Function |
|--------|---------|--|
| 0-5 | SA0:SA5 | Sector Address |
| 6 | HS | Head Select — Upper head=0, lower head=1 |
| 7-15 | CA0:CA8 | Cylinder Address |

32 REGISTER SUMMARY

774406

MPR DURING READ/WRITE COMMANDS FOR WORD COUNT

| | | | | | | | | | | | | | | | |
|----|----|----|------|------|------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 15 | 14 | 13 | 12 | 11 | 10 | 09 | 08 | 07 | 06 | 05 | 04 | 03 | 02 | 01 | 00 |
| 1 | 1 | 1 | WC12 | WC11 | WC10 | WC9 | WC8 | WC7 | WC6 | WC5 | WC4 | WC3 | WC2 | WC1 | WC0 |

C2-2036

| Bit(s) | Name | Function |
|--------|------------------------|---|
| 0-12 | Word Count WC 12:00 | Contains the two's complement of total number of words to be transferred. |
| 13-15 | | Must be ones. |

MP Register Programming Note — The RL01/RL02 Disk Drive will not do spiral read/writes. If data is to be transferred past the end of the last sector of a track, it is necessary to break up the operation into the following steps.

- 1. Program the data transfer to terminate at the end of the last sector of the track.**
- 2. Program a seek to the next track. This can be either a head switch to the other surface but same cylinder or a head switch and move to the next cylinder.**
- 3. Program the data transfer to continue at the start of the first sector at the next track.**


5.2 RL8-A Instruction Set and Register Summary

Table 5-2 RL8-A Instruction Set

| Octal Code | Mnemonic | Function |
|------------|----------|---|
| 6600 | RLDC | Clear controller, all registers, AC and flags. (Do not use to terminate a disk function.) |
| 6601 | RLSD | Skip on function done. Then clear if set to a one. |
| 6602 | RLMA | Load break MA register from AC 0:11 |
| 6603 | RLCA | Load command register A from AC 0:11 |
| 6604 | RLCB | Load command register B from AC 0:11, execute command |
| 6605 | RLSA | Load sector address register from AC 0:5 |

Table 5-2 RL8-A Instruction Set (Cont)


| Octal Code | Mnemonic | Function |
|------------|----------|--|
| 6607 | RLWC | Load word count register from AC 0:11 |
| 6610 | RRER | Read error register into AC 0, 1, 2, 10, 11 |
| 6611 | RRWC | Read word count register into AC 0:11 |
| 6612 | RRCA | Read command register A into AC 0:11 |
| 6613 | RRCB | Read command register B into AC 0:11 |
| 6614 | RRSA | Read sector address register into AC 0:5 |
| 6615 | RRSI | Read silo word into AC 0:11 |
| 6617 | RLSE | Skip on composite error, then clear if set to a one. |



CZ-2016


| Bit(s) | Name | Function |
|--------|-----------------------------|--|
| AC0 | Direction (DIR) | This bit indicates the direction in which a seek is to take place. When the bit is set, the heads move toward the spindle (to a higher cylinder address). When the bit is cleared, the heads move away from the spindle (to a lower cylinder address). The actual distance moved depends on the cylinder address difference (bits 3-11). |
| AC1 | Head Select (HS) | Indicates which head (disk surface) is to be selected. A one indicates the lower head; a zero, the upper head. |
| AC2 | - | Spare |
| AC3:11 | Cylinder Address Difference | Indicates the number of cylinders the heads are to move on a seek. |

34 REGISTER SUMMARY



CZ-2017

| Bit(s) | Name | Function |
|--------|------------------|---|
| AC0 | - | Must be zero |
| AC1 | Head Select (HS) | Indicates which head (disk surface) is to be selected. A one indicates the lower head; a zero, the upper head. The correct track (head and sector) must be previously selected by a Seek. |
| AC2 | - | Must be zero |
| AC3:11 | Cylinder Address | Cylinder address. |




CZ-2018

| Bit(s) | Name | Function |
|--------|-----------------------|--|
| AC0 | - | Reserved |
| AC1 | Maintenance | The contents of the Disk Address (DA) register are looped back to the silo for maintenance purposes. Bit 2 of Command Register B must also be set for this function to work correctly. |
| AC2 | Mode | When set, this bit indicates that the data field will be 256 8-bit words per sector. When zero, the data field will be truncated to 170 12-bit words per sector. This bit must be set when a Maintenance, a Get Status or a Read Header command is to be executed. |
| AC3 | Interrupt Enable (IE) | When this bit is set, the controller is allowed to interrupt the processor at the conclusion of a normal command or error termination. |

| Bit(s) | Name | Function |
|--------|---------------------------------|--|
| AC4:5 | Drive Select (DS0, DS1) | These bits determine which drive will communicate with the controller via the drive bus. |
| AC6:8 | Extended Memory Addressed (EMA) | These three bits define the memory field location. This allows up to 32K memory locations to be addressed on processors having more than 4K of memory. |
| AC9:11 | Function Code (FC, FB, FA) | These bits indicate the command to be executed by the controller/disk subsystem. |

| Bit 9 | Bit 10 | Bit 11 | Command |
|-------|--------|--------|--------------------------------|
| 0 | 0 | 0 | Maintenance |
| 0 | 0 | 1 | Reset |
| 0 | 1 | 0 | Get Status |
| 0 | 1 | 1 | Seek |
| 1 | 0 | 0 | Read Header |
| 1 | 0 | 1 | Write Data |
| 1 | 1 | 0 | Read Data |
| 1 | 1 | 1 | Read Data Without Header Check |


BREAK MEMORY ADDRESS REGISTER



CZ-2019


| Bit(s) | Name | Function |
|--------|--------|----------------|
| AC0:11 | BM0:11 | Memory Address |

WORD COUNT REGISTER



CZ-2020

| Bit(s) | Name | Function |
|--------|--------|------------|
| AC0:11 | WC0:11 | Word Count |



CZ-2025

WORD 1 — HEADER

| Bit(s) | Name | Function |
|--------|---------|--|
| AC0:3 | - | Undefined |
| AC4 | Cyl Add | LSB of Cylinder Address |
| AC5 | HS | Head Select — lower head = 1, upper head = 0 |
| AC6:11 | Sec Add | Sector Address |

WORD 2 — HEADER

| Bit(s) | Name | Function |
|--------|---------|--|
| AC0:3 | - | Undefined |
| AC4:11 | Cyl Add | Cylinder Address — eight high order bits |

WORD 3 — HEADER

| Bit(s) | Name | Function |
|--------|------|-----------|
| AC0:3 | - | Undefined |
| AC4:11 | - | Zeros |

WORD 4 — HEADER


| Bit(s) | Name | Function |
|--------|------|-----------|
| AC0:3 | - | Undefined |
| AC4:11 | - | Zeros |

WORD 5 — HEADER

| Bit(s) | Name | Function |
|--------|------|-----------------------|
| AC0:3 | - | Undefined |
| AC4:11 | CRC | Eight LSB of CRC word |

WORD 6 — HEADER

| Bit(s) | Name | Function |
|--------|------|-----------------------|
| AC0:3 | - | Undefined |
| AC4:11 | CRC | Eight MSB of CRC word |



CZ-2023

| Bit(s) | Name | Function |
|--------|------------------|---|
| AC0:3 | - | Undefined |
| AC4 | Drive Type | A zero indicates an RL01; a one, an RL02. |
| AC5 | Head Select (HS) | Indicates currently selected head. A zero indicates the upper head; a one, the lower head. |
| AC6 | Cover Open (CO) | Set when the drive access cover is open or the dust cover is not in place. |
| AC7 | Heads Out (HO) | A one indicates that the heads are over the disk; a zero indicates that the heads are home. |


38 REGISTER SUMMARY

| Bit(s) | Name | Function |
|--------|-----------------|--|
| AC8 | Brush Home (BH) | Set when the brushes are home. |
| AC9:11 | State Bits | These bits define the state of the disk drive. |

State Bit Definitions

| Bit C | Bit B | Bit A | Definition |
|-------|-------|-------|----------------------------|
| 0 | 0 | 0 | Load Cartridge |
| 0 | 0 | 1 | Spin-up |
| 0 | 1 | 0 | Brush Cycle |
| 0 | 1 | 1 | Load Heads |
| 1 | 0 | 0 | Seek (Track Counting) |
| 1 | 0 | 1 | Lock-on (keeping on track) |
| 1 | 1 | 0 | Unload Heads |
| 1 | 1 | 1 | Spin-down |

SILO BUFFER — STATUS WORD 2




WORD 2

CZ-2024


| Bit(s) | Name | Function |
|--------|----------------------------|---|
| AC0:3 | - | Undefined |
| AC4 | Write Data Error (WDE) | This bit is set when the Write Gate is on but no transitions were detected on the Write Data line. |
| AC5 | Current Head Error (CHE) | This bit is set when Write Current is detected in the heads but the Write Gate was not asserted. |
| AC6 | Write Lock (WL) | Set when the drive is Write Protected. |
| AC7 | Seek Time Out Error (SKTO) | Set when the heads do not come on track in the required time during a Seek command or when "Ready to Read/Write" is lost while the drive is in position (lock-on) mode. |
| AC8 | Spin Error (SPE) | Set when the spindle does not come up to speed within 40 seconds or when the spindle speed is too high. |

- AC9 Write Gate Error (WGE)** Set if Write Gate is asserted and one or more of the following conditions is true.
1. Drive is not "Ready to Read/Write"
 2. Drive is Write Protected
 3. Drive is in the midst of sector time
 4. Drive has another error asserted
- AC10 Volume Check (VC)** Set when a cartridge has been spun up. This bit is reset by a Reset command.
- AC11 Drive Select Error (DSE)** Set when one or more drives have the same number (unit select plug) or have responded to the same number.



CZ-2021

| Bit(s) | Name | Function |
|---------------|-------------|-----------------|
| AC0:5 | SA0:5 | Sector Address |



CZ-2022

- | Bit(s) | Name | Function |
|---------------|--------------------------------------|--|
| AC0 | Data CRC (DRCR) or Header CRC (HCRC) | If OPI is cleared and this bit is set, the CRC error occurred in the data (DCRC). If OPI is set and this bit is also set, the CRC error occurred on the header (HCRC). |
| AC1 | Operation Incomplete (OPI) | When set, this bit indicates that the current command was not completed within 200 ms. It is also used in conjunction with bits 0 and 2 of this register. |

| Bit(s) | Name | Function | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---------------|---|---|-------|------|--|--|--|----|----|----|-----|---|---|---|-----|---|---|---|-----|---|---|---|------|---|---|---|------|---|---|---|
| AC2 | Data Late (DLT) or Header Not Found (HNF) | <p>This bit is set during a Write if the silo is empty and the word count is not yet zero (meaning that no word was available for writing). OPI will not be set.</p> <p>This bit is set during a Read if the silo is full and the word count is not yet zero (meaning that the word being read could not enter the silo). OPI will not be set.</p> <p>When this bit and OPI are both set, then a 200 ms timeout occurred while the controller was searching for the correct sector to read or write (no header compare – HNF).</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| AC0:2 | Error Code | <p>Summary</p> <table border="0" style="margin-left: 20px;"> <thead> <tr> <th style="text-align: left;">Error</th> <th colspan="3" style="text-align: center;">Bits</th> </tr> <tr> <td></td> <th style="text-align: center;">00</th> <th style="text-align: center;">01</th> <th style="text-align: center;">02</th> </tr> </thead> <tbody> <tr> <td>DLT</td> <td style="text-align: center;">0</td> <td style="text-align: center;">0</td> <td style="text-align: center;">1</td> </tr> <tr> <td>OPI</td> <td style="text-align: center;">0</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> <tr> <td>HNF</td> <td style="text-align: center;">0</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> <tr> <td>DCRC</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> <td style="text-align: center;">0</td> </tr> <tr> <td>HCRC</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> </tbody> </table> | Error | Bits | | | | 00 | 01 | 02 | DLT | 0 | 0 | 1 | OPI | 0 | 1 | 0 | HNF | 0 | 1 | 1 | DCRC | 1 | 0 | 0 | HCRC | 1 | 1 | 0 |
| Error | Bits | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 00 | 01 | 02 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DLT | 0 | 0 | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OPI | 0 | 1 | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| HNF | 0 | 1 | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DCRC | 1 | 0 | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| HCRC | 1 | 1 | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| AC10 | Drive Error (DE) | <p>This bit is tied directly to the Drive Error interface line. When set, it indicates that the selected drive has flagged an error. The source of the error can be determined by a Get Status.</p> <p>The DE bit is cleared with a Reset command to the drive.</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| AC11 | Drive Ready (DRDY) | <p>When set, this bit indicates that the selected drive is ready to receive a command. The bit is cleared when a Seek operation is initiated and set again when the Seek operation is completed.</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

CHAPTER 6 BOOTSTRAPS

6.1 RL11/RLV11 BOOTSTRAP

Ensure that the heads are over cylinder 0 and head 0 is selected by releasing the LOAD switch, waiting for the LOAD indicator to light, then depressing the LOAD switch. After the drive is READY, initialize the controller with a system INITIALIZE. Perform a bit status clear. Load the following program into memory.

| LOC | Contents | Comments |
|-------|----------|----------|
| 10000 | 012737 | Load CSR |
| 10002 | 000014 | |
| 10004 | 174400 | |
| 10006 | 000001 | Wait |

Start the program at 10000 and allow it to run for a few seconds. Halt the program and restart at 00000.

6.2 RL8-A BOOTSTRAP

Ensure that the heads are over cylinder 0 and head 0 is selected by releasing the LOAD switch, waiting for the LOAD indicator to light, then depressing the LOAD switch. Load the following program into memory.

| LOC | Contents | Comments |
|-----|----------|-----------------------|
| 21 | 7600 | Clear AC and constant |
| 22 | 6600 | Clear RL8-A |
| 23 | 7332 | Generate constant |
| 24 | 6605 | Load SAR with 20 |
| 25 | 1021 | Load constant into AC |
| 26 | 6607 | Load WC |
| 27 | 7327 | Generate constant |
| 30 | 6604 | Load CMD B |
| 31 | 6601 | Skip on done |
| 32 | 5031 | Loop |

Start program at 21. The OS-8 monitor will overlay this bootstrap.

CHAPTER 7

TOGGLE-IN PROGRAMS

7.1 HEAD SELECTION PROGRAM FOR RL11/RLV11

The following program causes Head 1 (lower head) to be selected (on unit 0) if the WRITE PROTECT switch is in and Head 0 (upper head) to be selected if the switch is out.

| | | |
|------|--------|--------------------|
| 1000 | 012700 | Housekeeping |
| 1002 | 174400 | |
| 1004 | 012701 | |
| 1006 | 174404 | |
| 1010 | 105710 | Wait |
| 1012 | 100376 | |
| 1014 | 012711 | Get Status Command |
| 1016 | 000013 | |
| 1020 | 012710 | |
| 1022 | 000004 | |
| 1024 | 105710 | Wait |
| 1026 | 100376 | |
| 1030 | 013702 | Status Word |
| 1032 | 174406 | |
| 1034 | 006302 | |
| 1036 | 010203 | |
| 1040 | 006303 | |
| 1042 | 105702 | Check HS Bit |
| 1044 | 100405 | |
| 1046 | 005703 | Check WL Bit |
| 1050 | 100357 | Equal, Loop |
| 1052 | 012711 | Set HS Bit |
| 1054 | 000021 | |
| 1056 | 000404 | Go to Seek Command |
| 1060 | 005703 | Check WL Bit |
| 1062 | 100752 | Equal, Loop |
| 1064 | 012711 | Reset HS Bit |
| 1066 | 000001 | |
| 1070 | 012710 | Seek Command |
| 1072 | 000006 | |
| 1074 | 000745 | Loop |

7.2 HEAD SELECTION PROGRAM FOR RL8-A

The following program causes Head 1 (lower head) to be selected (on unit 0) if the WRITE PROTECT switch is in and Head 0 (upper head) to be selected if the switch is out.

| | | |
|-----|------|-------------------------------|
| 200 | 6600 | Clear Controller |
| 201 | 1234 | |
| 202 | 6604 | Get Status Command |
| 203 | 6601 | Wait |
| 204 | 5203 | |
| 205 | 6615 | First Word of Status |
| 206 | 0232 | |
| 207 | 7640 | Check HS Bit |
| 210 | 5217 | HS=1, Go to 217 |
| 211 | 6615 | Second Word of Status |
| 212 | 0233 | |
| 213 | 7650 | Check WL Bit |
| 214 | 5201 | HS=WL, Go to 201 |
| 215 | 7332 | |
| 216 | 5224 | |
| 217 | 6615 | Second Word of Status |
| 220 | 0233 | |
| 221 | 7640 | Check WL |
| 222 | 5201 | HS=WL, Go to 201 |
| 223 | 7300 | |
| 224 | 6603 | HS to Command REG A |
| 225 | 7325 | |
| 226 | 6604 | Seek Command to Command REG B |
| 227 | 6601 | Wait |
| 230 | 5227 | |
| 231 | 5201 | Loop to 201 |
| 232 | 0100 | Constant |
| 233 | 0040 | Constant |
| 234 | 1002 | |

7.3 GET STATUS (WITH OR WITHOUT RESET) ON AN RL11/RLV11 SUBSYSTEM

To accomplish this it is necessary to:

- 1) Deposit a 3 into DAR at 774404 (or 13 to Reset)
- 2) Deposit a 4 into CSR at 774400 (or 404, 1004, 1404 for units 1, 2, 3)
- 3) Wait for operation to be complete
- 4) Examine contents of MPR at 774406.

On some PDP-11 systems this can be accomplished manually using the console. On other PDP-11 systems it is necessary to run a program such as given below. Start at 1000 and when it halts, examine memory location 1032.

To get status on unit 1, 2, or 3 modify location 1010 to 404, 1004, or 1404.

To reset drive modify location 1002 to 13.

| | | |
|------|--------|---------------------------------------|
| 1000 | 012737 | Get Status Command |
| 1002 | 000003 | Use 13 to Reset |
| 1004 | 174404 | |
| 1006 | 012737 | |
| 1010 | 000004 | Use 404, 1004, 1404 for Units 1, 2, 3 |
| 1012 | 174400 | |
| 1014 | 105737 | Wait |
| 1016 | 174400 | |
| 1020 | 100375 | |
| 1022 | 013737 | Move Result to Memory |
| 1024 | 174406 | |
| 1026 | 001032 | |
| 1030 | 000000 | Halt |
| 1032 | 000000 | Result |

7.4 GET STATUS ON AN RL8-A SUBSYSTEM

The following program will GET STATUS from unit 0. To access unit 1, 2, 3 change location 212 to 1102, 1202, 1302.

Start the program at 200 — at the first halt, the first byte of the status word is displayed in the accumulator — at the second halt, the second byte is displayed.

| | | |
|-----|------|------------------------------|
| 200 | 7300 | |
| 201 | 1212 | Get Status |
| 202 | 6604 | |
| 203 | 6601 | Wait |
| 204 | 5203 | |
| 205 | 6615 | Get First Byte |
| 206 | 7402 | Halt and Display First Byte |
| 207 | 6615 | Get Second Byte |
| 210 | 7402 | Halt and Display Second Byte |
| 211 | 5200 | Jump to Start |
| 212 | 1002 | Constant |

7.5 OSCILLATING SEEK FOR RL11/RLV11

The following program will cause unit zero to perform an oscillating seek. To drive units other than unit 0, swap the unit number plugs or modify locations 1044 and 1054 to reflect the unit number in bits 8 and 9.

The number of cylinders involved is inserted into bits 15 through 7 and bit 0 is set in the switch register before starting the programs at 1000. If no switch register is available, modify location 1012 from 177570 to 001060 and put the number of cylinders in bits 15 through 7 and set bit 0 in location 1060.

The common values for the switch register are:

| Number of cylinders (in decimal) | Value of Switch Register (in octal) |
|---|--|
| 1 | 000205 |
| 85 | 025205 |
| 170 | 052405 |
| 255 | 077605 |
| 511 | 177605 |

| | | |
|------|--------|----------------------------|
| 1000 | 012706 | Set Stack Pointer |
| 1002 | 001000 | |
| 1004 | 012700 | Set Device Address into R0 |
| 1006 | 174400 | |
| 1010 | 013701 | Set Difference into R1 |
| 1012 | 177570 | |
| 1014 | 004537 | Go Seek |
| 1016 | 001032 | |
| 1020 | 042701 | Change direction bit in R1 |
| 1022 | 000004 | |
| 1024 | 004537 | Go Seek |
| 1026 | 001032 | |
| 1030 | 000767 | Loop back |
| 1032 | 105710 | Wait |
| 1034 | 100376 | |
| 1036 | 010137 | Seek |
| 1040 | 174404 | |

| | | |
|------|--------|------------------------------------|
| 1042 | 012710 | |
| 1044 | 000006 | |
| 1046 | 105710 | Wait |
| 1050 | 100376 | |
| 1052 | 012710 | Read Header to kill time for SKTO. |
| 1054 | 000010 | |
| 1056 | 000205 | Return |

7.6 OSCILLATING SEEK FOR RL8-A

The following program will cause unit 0 to perform an oscillating seek. To drive units other than 0, swap unit number plugs. Insert the number of cylinders into the switches before starting at location 200. The usual values for the switch register are: 1 cylinder=1, 85 cyl=125, 170 cyl=252, 255 cyl=377 and 511 cyl=777.

| | | |
|-----|------|-------------------------------|
| 200 | 7201 | Reset |
| 201 | 6604 | |
| 202 | 7604 | Get number |
| 203 | 4221 | Go Wait for Ready |
| 204 | 3225 | Store number |
| 205 | 1225 | |
| 206 | 6603 | Seek |
| 207 | 7325 | |
| 210 | 6604 | |
| 211 | 4221 | Go Wait for Ready |
| 212 | 7307 | Read Header to Delay for SKTO |
| 213 | 6604 | |
| 214 | 1225 | |
| 215 | 1226 | Change Direction Bit |
| 216 | 7500 | Check for Time to Restore |
| 217 | 5202 | Loop to Start |
| 220 | 5203 | Loop |
| 221 | 0000 | Wait for Ready |
| 222 | 6601 | |
| 223 | 5222 | |
| 224 | 5621 | |
| 225 | 0000 | Temp |
| 226 | 4000 | Constant |

CHAPTER 8 DIAGNOSTICS

8.1 RL11 DIAGNOSTICS

The original set of six diagnostics (Table 8-1) drove an RL01 only. They were replaced by a new set of seven diagnostics (Table 8-2) that can handle RL01s and RL02s. The kit number for the new set is ZB283. One of the programs (CZRLMA0) in the new set is a utility rather than a test. It is used to examine the Bad Sector File and to write entries into the field-written portion of that file. The original DECX11 module (RLAA) can handle RL01 only while revision B (RLAB) can handle both RL01 and RL02. This module is part of Option Library #5 (DXQLQ). There is an RL driver available for M.P.G.

Table 8-1 RL11/RL01 Diagnostics

| Name | Description |
|-------------|-----------------------|
| CZRLAB0 | Controller Test #1 |
| CZRLBB0 | Controller Test #2 |
| CZRLCB0 | Drive Test #1 |
| CZRLDB0 | Drive Test #2 |
| CZRLFB0 | Performance Exerciser |
| CZRLFB0 | Compatibility Test |

Table 8-2 RL11/RL02 Diagnostics

| Name | Description |
|-------------|-------------------------|
| CZRLGA0 | Controller Test #1 |
| CZRLHA0 | Controller Test #2 |
| CZRLIA0 | Drive Test #1 |
| CZRLJA0 | Drive Test #2 |
| CZRLKA0 | Performance Exerciser |
| CZRLLA0 | Compatibility Test |
| CZRLMA0 | Bad Sector File Utility |

8.2 RLV11 DIAGNOSTICS

The RLV11 subsystem is tested with the same set of diagnostics as the RL11 except that the RLV11 required an additional test (CVRLAA0) for the MAINT command. Kit number ZJ285 includes kit ZJ283 plus CVRLAA0. Since CVRLAA0 is a diskless controller test it can handle either an RL01 or an RL02.

8.3 RL8-A DIAGNOSTICS

The original set of diagnostics (Table 8-3) could handle only the RL01 drives. The new set of diagnostics (Table 8-4) can handle RL02 only (except AJRLAC0 which can handle either an RL01 or an RL02). Kit number ZF241 includes the six diagnostics plus the DECX8 module.

Table 8-3 RL8-A/RL01 Diagnostics

| Name | Description |
|-------------|----------------------------|
| AJRLAA0 | Diskless Control Test |
| AJRLBA0 | Drive Test #1 |
| AJRLCA0 | Drive Test #2 |
| AJRLDA0 | Compatibility Verification |
| AJRLEA0 | Performance Exerciser |
| AXRLAA0 | DECX8 Module |
| AJRLGA0 | Pack Verification |

Table 8-4 RL8-A/RL02 Diagnostics

| Name | Description |
|-------------|-----------------------|
| AJRLAC0 | Diskless Control Test |
| AJRLHA0 | Seek/Function |
| AJRLIA0 | Read/Write |
| AJRLJA0 | Drive Compatibility |
| AJRLKA0 | Performance Exerciser |
| AJRLLA0 | Pack Verify |
| AXRLBA0 | DECX8 Module |

8.4 DIAGNOSTIC SUPERVISOR

8.4.1 Hardcore Questions

1. The statement "TYPE TWO CHARACTERS FOUR SECONDS APART" will be asked when no clock is on the system. The system will then subdivide the spacing for use as a clock.

2. The prompt "DS-C>" is requesting one of eleven superior "commands," which are:
 - STA — STArt diagnostic and then produce questions for generation of the diagnostic parameter ("P") tables.
 - RES — REStart diagnostic at the point following the hardware questions. The "P" tables set up by the STA command will be used.
 - CON — CONtinue the diagnostic at the beginning of the subroutine that was being executed when the diagnostic was halted by an error or a control "C".
 - PRO — PROceed testing with the diagnostic at the starting address of the subroutine following the one that caused the error report.
 - DIS— DISplay the hardware "P" tables for all the drives being tested.
 - DRO — DROp the desired units from being tested. "UNITS," in this case refers to the "P" table unit numbers, not necessarily the device unit numbers. The DIS command will give the operator the device unit number.
 - ADD — ADD units back into the testing sequence after they had been dropped by the DRO command.
 - PRI — PRInt any performance or statistical tables accumulated by the diagnostic.
 - FLA — FLAgs command — The current setting of all the flags set up under the STA command are printed out for inspection.
 - ZFL — Zero FLAgs command — All current flags set up by the STA command are cleared by this command.
 - CCI — Create Core Image command — This command enables a BIC file to be created on these diagnostics to be run under the XXDP media. (See listing for directions.)

3. **Program Parameter Changes** — Type in any combination of the following parameters to affect the indicated commands.

With the STA command:

- a. **DS-C>STA/TESTS:** Insert test numbers shown in the appropriate diagnostic listing; e.g., 1:2 means tests 1 and 2, or 1-5:8-10 means tests 1 through 5 and 8 through 10.
- b. **DS-C>STA/TESTS:6/PASS:** Insert the number of passes the diagnostic should take before halting.
- c. **DS-C>STA/TESTS:6/PASS:2/FLAGS:** Insert any of these mnemonic(s) representing a program flag(s):
 - **HOE** — Halt On Error
 - **LOE** — Loop On Error
 - **IER** — Inhibit Error Report
 - **IBE** — Inhibit Basic Error reporting
 - **IXE** — Inhibit eXtended Error reporting
 - **PRI** — PRInt messages on line printer
 - **PNT** — PriNT test numbers as they are being executed
 - **BOE** — Bell On Error
 - **UAM** — Bypass manual intervention tests
 - **ISR** — Inhibit Statistical Reports
 - **IDR** — Inhibit DRopping of units
- d. **DS-C>STA/TESTS:BOE:IDR/EOP:** Insert a number equalling the pass intervals at which the end of pass message will be printed; e.g., every other pass, every third pass, etc.

EXAMPLE:

Using all the possible parameter changes, the STA command would look like this:

```
DS-C>STA/TESTS:6/PASS:2/FLAGS:IER:PNT:  
BOE:IDR/EOP:3
```

With the RES command: Use TESTS, PASS, FLAGS and/or UNITS to be tested; e.g., DS-C>RES/TESTS:6/UNITS:1 (this will run only test 6 on the device specified in "P" table 1).

With the other commands:

CON command: Use PASS or FLAGS only
 PRO command: use FLAGS only
 DRO command: use UNITS only
 DIS command: use UNITS only
 ADD command: use UNITS only
 PRI command: no variations
 FLA command: no variations
 ZFL command: no variations
 CCI command: use TESTS, PASS or FLAGS

8.4.2 Console Controls

1. Control "C" causes testing to cease and a return to the start (DS-C>).
2. Control "Z" causes default values to be taken in any of the three operator dialogues.
3. Control "O" causes a suppression of typeouts for the remainder of the diagnostic or until another control "O" is typed.

8.4.3 Hardware Questions

1. Supervisor "P" (Parameter) tables are built here, one for every unit to be tested.
2. "UNITS" pertains to the "P" table number, not the device unit number. If there is doubt as to which unit number has been assigned to which drive, the DIS command (see above) will supply the necessary information.

8.4.4 Software Question

"CHANGE SW(L)?" asks if any of the software parameters are to be changed. A "Y" will cause various questions to be asked. For details, refer to the individual program document.

CHAPTER 9

CHECKS, ADJUSTMENTS AND ALIGNMENTS

9.1 INTRODUCTION

Many of the checks, adjustments and alignments described in this chapter deal with the Drive Logic Module (DLM). Because there are three different versions of the DLM, it is necessary to first identify the particular type of module on the drive being serviced. The three versions are shown in Figure 2-9.

- Version 1 (Part No. 54-12175) can be identified by the fact that the two Berg connectors in the lower right hand of the module point down, while the other two along the bottom row point up. This board will only operate in an RL01.
- Version 2 (Part No. 54-13531), has all four connectors in the bottom row pointing up, as in Figure 2-9. This module will function in an RL01 or an RL02.
- Version 3 (Part No. 54-14025) has the same arrangement of Berg connectors as Version 2, but it also has test lugs (shown in Figure 2-9) that are not on either of the other two modules.

The service jumpers used in these checks and adjustments are listed in Table 9-1.

Table 9-1 Service Jumpers for Drive Logic Module

| Version | Defeat Cover Switch | Defeat POS SIG | Defeat SK TO | Select Head 1 |
|---------|---------------------|------------------|----------------|---------------|
| 1 | E33-3 to E33-7 | TP8 to ground | E17-6 to E17-7 | — |
| 2 | E54-12 to E54-7 | TP6 to ground | E10-8 to E10-7 | — |
| 3 | TP19 to TP20 | TP6 to ground(3) | TP23 to TP24 | TP21 to TP22 |

Tables 2-3, 2-4 and 2-5 list ground points.

In the course of performing some of the alignments, it is necessary to select Head 1 and then later reselect Head 0. The methods for accomplishing this are shown in Table 9-2.

Table 9-2 Methods for Selecting Heads

For a PDP-11-based subsystem:

| DLM Version 1 or 2 | DLM Version 3 |
|--|---|
| Load DZRLCXX or CZRLIXX and run head alignment routine. Having the WRIT PROT switch in selects Head 1; having it out selects Head 0. | Jumper TP21 to TP22 to select Head 1. Removing the jumper selects Head 0. |

For a PDP-8-based subsystem:

| | |
|--|---------------|
| Load AJRLBXX or AJRLHXX and run head alignment routine. Having the WRIT PROT switch in selects Head 1; having it out selects Head 0. | Same as above |
|--|---------------|

NOTE

If diagnostics are not available, toggle in the appropriate program shown in Chapter 7.

9.2 VOLTAGE CHECKS

The DC Servo module template indicates voltage test points. Check the following voltages.

| Voltage | Limits |
|----------------|------------------|
| $+V_{un}$ | +14V to +18V |
| $-V_{un}$ | -14V to -18V |
| +5V | +4.85V to +5.35V |
| +8V | +7.7V to +8.3V |
| -8V | -7.7V to -8.3V |

The regulators on the DC Servo module are not adjustable. If a voltage is out of tolerance, the faulty FRU should be replaced.

The +5V can be killed by a blown pico fuse, a thermal switch on the DC Servo heat sink, an overvoltage crowbar, or a home switch on the positioner not closed during power up.

9.3 SECTOR TRANSDUCER OUTPUT CHECK


This check verifies a correct output of the sector transducer.

A. Required Tools:

1. Oscilloscope with probe
2. DIP clip

B. Check:

1. Remove both top cover assemblies.
2. Install cartridge.
3. Defeat the cover interlock (Table 9-1).
4. Depress LOAD switch.
5. While waiting for the heads to load onto the pack, set up the oscilloscope (sync internal negative-going). Set vertical coupling to AC.
- 6a. Version 1 of DLM: Place oscilloscope probe on E8 pin 8.
- 6b. Version 2 of DLM: Place oscilloscope probe on TP14.
- 6c. Version 3 of DLM: Place oscilloscope probe on TP14.
7. The signal displayed on the oscilloscope should be similar to that shown in Figure 9-1. The peak output of the negative portion of the waveform should be between 0.35Vp and 1.5Vp.



MA-1602

Figure 9-1 Sector Transducer Output

NOTE

The waveform must be negative-going first.

8. If the specification cannot be met, the sector transducer must be replaced.

9.4 SECTOR PULSE TIMING CHECK

This is a check of the sector pulse width and repetition rate. The repetition rate is a function of spindle speed.

A. Required Tools:

Oscilloscope with probe.


B. Check:

1. Remove both top cover assemblies.
2. Defeat cover interlock (Table 9-1).
3. Install cartridge.
4. Depress LOAD switch.
- 5a. Version 1 of DLM: Place the probe on TP9.
- 5b. Version 2 of DLM: Place the probe on TP11.
- 5c. Version 3 of DLM: Place the probe on TP11.
6. Set the oscilloscope to sync internal, negative-going. The signal displayed on the oscilloscope should be the same as in Figure 9-2. Sector pulse width should be 62.5 microseconds. Correct disk speed ranges from 594 microseconds to 639 microseconds, with 624 being the desired norm. The sector pulses should be stable at some time period within that range.

9.5 POSITIONER RADIAL ALIGNMENT

The positioner radial alignment checks assure that the conditions listed below are true.

- The servo bursts (as read by the read/write heads) must occur during the correct time relative to the sector pulse (as detected by the sector transducer at the hub). Because the sector transducer is fixed, changing the head positioner location will affect this timing relationship.
- The servo burst/sector timing relationship must be the same at track 0 as it is at the innermost track because the head carriage moves straight toward the center of the disk.



TIME = 100 μ s/DIV.

VOLTS = 2V/DIV.

CZ-1078

Figure 9-2 Sector Pulse Timing

A. Tools Required:

1. Oscilloscope with two probes
2. Two flat-blade screwdrivers
3. One Phillips head screwdriver
- 4a. One DIP clip, one pin-to-pin jumper and one test lead, or
- 4b. Two pin-to-pin jumpers and two DIP clips
5. Diagnostic listed in Table 9-2.

B. Positioner Alignment Check:

1. Remove both top cover assemblies.
2. Defeat POS SIG, SKTO and cover interlock (Table 9-1).
3. Place the Read/Write module box assembly up and out of the way of the carriage assembly.
4. Install cartridge.
5. Depress LOAD switch.
6. Wait for heads to load onto the pack.
7. Disable servo drive to the carriage by disconnecting the in-line connector (Figure 9-3).
8. Select Head 1 (Table 9-2).

9. Place the Channel B oscilloscope probe on TP2 of the Read/Write module (data) and Channel B ground on any signal ground (TP1 - TP4).
- 10a. Version 1 of DLM: Place Channel A probe on TP9 (SEC TIME) and Channel A ground on any signal ground (TP1-TP4).
- 10b. Version 2 of DLM: Place Channel A probe on TP11 (SEC TIME) and Channel A ground on any signal ground (TP1-TP4).
- 10c. Version 3 of DLM: Place Channel A probe on TP11 (SEC TIME) and Channel A ground on any signal ground (TP1-TP4).
11. Set the oscilloscope to sync internal, negative-going on Channel A and observe the waveform shown in Figure 9-4.




Figure 9-3 Positioner and Read/Write Module Box Assembly

NOTE

S1 and S2 servo bursts may not appear in the positive/negative proportions shown in Figure 9-4, depending upon which track the head is centered on.




Figure 9-4 Servo Bursts and Sector Pulse

12. Measure the time between the negative-going edge of the sector pulse and the beginning of the S1 servo burst when the positioner is at Cylinder 0. Record this value. $20-1$
 $18-0$
13. Select Head 0 (Table 9-2).
14. Repeat Step 12 for Head 0. Record this value.
15. If the difference between these two values is greater than six microseconds, replace Head 0 (see the *RL01/RL02 Disk Drive Technical Manual*) and go back to Step 14. If either of these two values falls outside of the 15 ± 3 microsecond specification, perform the alignment procedure (Part C) below. Otherwise, continue.
16. Manually move the carriage to the last data track (track 255 on an RL01 or track 511 on an RL02). As Head 0 enters the inner guard band, S1 disappears. Move the positioner back until S1 appears.
17. Measure the time between the negative-going edge of the sector pulse and the beginning of the S1 servo burst when the positioner is at the last cylinder. It should be 15 ± 3 microseconds. If so, the check is complete. Otherwise perform the adjustment (Part C) below.

C. Positioner Alignment

1. Using Figure 9-5 as a guide, locate the six largest Phillips screws on the positioner base-plate.
2. Loosen (but do not remove) the six screws holding down the positioner.




Figure 9-5 Positioner Assembly

3. Take the two flat-blade screwdrivers and insert them into the adjusting slots on the positioner.
4. Move the positioner assembly against the right hand side of the drive (toward the Read/Write module).
5. Manually move the carriage to its approximate center of travel.
6. Using the two flat-blade screwdrivers in the adjusting slots, slide the positioner baseplate until the 15 ± 3 microsecond specification between the fall of the sector pulse and the rise of the S1 servo burst can be met. (See Figure 9-4.)

NOTE

Equal pressure must be exerted on the screwdrivers when sliding the positioner to ensure that the baseplate is kept straight.

7. Tighten the six retaining screws in small increments.
8. Check the 15 ± 3 microseconds specification for Head 0 at track 0 and the last track. If the head is within the specification, the check is complete. Otherwise, repeat the adjustment (Part C) above.

9.6 HEAD ALIGNMENT

This procedure will ensure that the two heads are in line with each other to cut down on the servo tracking time when switching heads.

NOTE

The Positioner Radial Alignment (Paragraph 9.5) should be done before attempting the head alignment, so that any head skew that may be present will be detected BEFORE the head alignment.

A. Required Tools:

1. Oscilloscope with one probe
2. 3/32" Allen wrench
3. Flat-blade screwdriver
- 4a. One DIP clip, one pin-to-pin jumper and one test lead (alligator clip), or
- 4b. Two pin-to-pin jumpers and two DIP clips
5. Diagnostic listed in Table 9-2

NOTE

No alignment cartridge is required.

B. Alignment Check:

1. Remove both top cover assemblies.
2. Defeat SKTO, POS SIG and cover interlock (Table 9-1).

NOTE

These jumpers enable the diagnostic routine to work by disabling the Seek Timeout Error.

3. Place the Read/Write module box assembly up and out of the way of the carriage assembly.
4. Install cartridge.
5. Depress the LOAD switch.
6. Wait for the heads to load onto the pack.
7. Disable servo drive to the carriage by disconnecting the servo in-line connector (Figure 9-3).
8. Select Head 1 (Table 9-2).
9. Place oscilloscope probe A on POS SIG and connect probe A ground lead to ground. Set the vertical gain for 1 volt per division. Set oscilloscope horizontal circuit to free run (unsynched). The horizontal sweep rate is not important.
10. Manually move the positioner back to the head loading ramp and then forward toward the center of the disk while watching the READY indicator and the oscilloscope presentation of POS SIG. These two will indicate the position of the head relative to the tracks written on the disk surface.

*SEE
ADDENDUM*

When the head is over the head loading zone (outside the outer guard band), POS SIG floats slowly toward +8 V and the READY indicator is on. When the head is over the outer guard band, POS SIG is at maximum negative (about -1.5 V) and the READY indicator is off. As the head approaches cylinder 0, POS SIG starts to move up toward 0 V and the READY indicator turns on.

As the positioner continues to move forward, the READY indicator remains on and POS SIG is 0 V when the head is directly over the center of cylinder 0. POS SIG continues to move in the positive direction as the head passes cylinder 0 and reaches its maximum normal value of about +1.5 V as the head is halfway between cylinder 0 and cylinder 1. POS SIG then starts down as cylinder 1 is approached and is at 0 V when the head is over cylinder 1. If cylinder 1 is overshoot, POS SIG goes negative, then back to 0 V over cylinder 2, and so on.

By observing the oscilloscope and READY indicator, it is possible to locate cylinder 0 by moving the positioner into the outer guard band (POS SIG is negative and the READY indicator is off), and then moving the positioner forward to cylinder 0 (POS SIG rises to 0 V and the READY indicator turns on). The verification process is to move the positioner in reverse and observe the POS SIG go negative as the reverse and observe the POS SIG go negative as the READY indicator goes off and see the POS SIG stay negative as the head moves over the outer guard band.

11. Position Head 1 directly over cylinder 0.
12. Hold the positioner still and select Head 0.
13. If POS SIG is within 0.5 V of 0 V, then verify that Head 0 is over cylinder 0. If both of these criteria are met, the head alignment is satisfactory. Be sure to reconnect the in-line servo connector before unloading the heads. The head alignment check is complete. Go on to the next check.

If either of these criteria is met, go to Step 14.

14. If POS SIG was not within 0.5 V of ground or Head 0 was over a cylinder other than 0, perform the head alignment procedure (below).

C. Head Alignment Procedure

- HD
IS
TOP
1. Move the positioner all the way back to the home position so that the heads are up on the ramp. Loosen the mounting screw for Head 0 and move Head 0 all the way back to its extreme position against the stop.
 2. Select Head 1.
 3. Move the positioner so that Head 1 is directly over cylinder 0.
 4. Select Head 0.
 5. Hold the positioner still while sliding Head 0 forward by twisting a screwdriver between the end of the head assembly and the stop. Observe the READY indicator and POS SIG and move Head 0 until it is over cylinder 0.
 6. Select Head 1.
 7. Verify that Head 1 is within 0.5 V of 0 V and that Head 1 is still over cylinder 0. If these two criteria are not met, repeat the procedure.
 8. Snug the mounting screw for Head 0 while the heads are over the surface. Move the positioner to its home position before tightening the mounting screw. Do not overtighten the screw.
 9. Verify that tightening the mounting screw did not change the alignment enough to make it unsatisfactory. To do this, select Head 1, move it over cylinder 0, select head 0, and verify that it, too, is over cylinder 0 and within 0.5 V. If these specifications cannot be met, repeat the procedure. Otherwise, continue with Step 10.
 10. If the head cable clips are on the Read/Write module box, replace the head cables in the clips, and go to Step 14.
If the head cable clips are on the positioner, proceed with Step 11.
 11. Manually move the heads toward the spindle, as far as they will go.
 12. Mount the head cables into the clips on the cable guide. The cable for the lower head should go into the lower clip.

13. Ensure that the cables do not touch the corner of the cable guide bracket (as shown in Figure 9-6). If they do, readjust the cables in the clips so that they do not touch the corner of the bracket.




Figure 9-6 Adjusting the Head Cables

NOTE

The positioner **MUST** be fully extended when performing this check.

NOTE

The Read/Write module box assembly will have to be removed from the baseplate holding flanges and held in one hand to readjust the cables, as the cables are not long enough to reach.

14. Replace the servo in-line connector to unload the heads. At this point, the procedure is finished.

9.7 READ SIGNAL AMPLITUDE CHECK

This procedure checks the amplitude of the read signal in the read amplifier.

A. Required Tools:

1. Oscilloscope with two probes
- 2a. One DIP clip, one pin-to-pin jumper and one test lead (alligator clip), or
- 2b. Two pin-to-pin jumpers and two DIP chips
3. Diagnostic listed in Table 9-2

B. Check:

1. Remove both top cover assemblies.
2. Defeat SKTO, POS SIG and the cover interlock (Table 9-1).
3. Place the Read/Write module box assembly up and out of the way on the carriage assembly.
4. Install cartridge.
5. Depress the LOAD switch.
6. Wait for the heads to load.
7. Disable the servo drive to the carriage by disconnecting the servo in-line connector.
- 8a. Version 1 of DLM: Place Channel A probe on TP9 (Sector Time).
- 8b. Version 2 of DLM: Place Channel A probe on TP11 (Sector Time).
- 8c. Version 3 of DLM: Place Channel A probe on TP11 (Sector Time).
9. Place the Channel B oscilloscope probe on TP2 of the Read/Write module (Servo Data).
10. Set the oscilloscope to sync internal on Channel A, negative-going, and observe the waveform shown in Figure 9-4.
11. Move the positioner forward until the S1 servo burst loses amplitude and finally disappears. This will be the inner guard band area of the disk.
12. Pull the positioner back slowly until the S1 servo burst returns. This will be the last data track on the disk (track 255 on an RL01, track 511 on an RL02).

- 0-6.6
1-6.7
13. Measure and record the peak-to-peak amplitude of the S1 burst for both heads (see Table 9-2 to select heads). The minimum allowable amplitude at the innermost track is 500 mv.
 14. Reposition the carriage to track 0 by moving the positioner back until S2 disappears (outer guard band) and then forward until S2 reappears.
 - 0-10.8
1-10.8
 15. Measure and record the peak-to-peak amplitude of S1 for both heads. The maximum allowable amplitude of the S1 burst on track 0 is 2.25 V.
 16. Replace either or both heads that do not meet the specification.

NOTE

If both heads fail to meet the specification, it is possible that the Read/Write module is bad. Replace the module (see the *RL01/RL02 Technical Manual*) and repeat the procedure. If a head is replaced, it must be aligned (see Paragraph 9.6). The radial alignment must also be checked (Paragraph 9.5).

9.8 · SPINDLE RUNOUT CHECK

Excessive runout in the spindle assembly or cartridge can cause severe tracking problems for the positioning system. This check will determine whether:

1. Runout exists or does not exist
2. Runout is in the cartridge
3. Runout is in the spindle

A. Required Tools:

1. Oscilloscope with probe and ground leads
2. DIP clip
3. Jumper
4. Several test cartridges

B. Runout Check:

1. Remove both top cover assemblies.
2. Place the Read/Write module box assembly up and out of the way of the carriage assembly.
3. Defeat cover interlock (Table 9-1).
4. Install cartridge.
5. Depress LOAD switch.

6. Wait for heads to load onto the pack.
7. Disable servo drive to the carriage by disconnecting the in-line connector (Figure 9-3).
- 8a. Version 1 of DLM: Place Channel A oscilloscope probe on E11 pin 7 (Position Signal) and place Channel A ground on TP7 (Integrator Ground).
- 8b. Version 2 of DLM: Place Channel A oscilloscope probe on TP15 (Position Signal) and place Channel A ground on TP5 (Integrator Ground).
- 8c. Version 3 of DLM: Place Channel A oscilloscope probe on TP15 (Position Signal) and place Channel A ground on TP5 (Integrator Ground).
9. Set the oscilloscope to sync internal, negative-going, and observe the waveform in Figure 9-7.

NOTE

Ideally, the oscilloscope will display a nearly straight line of dots.




Figure 9-7 Position Signal

10. The amplitude of the runout should be no greater than 350 mv.
11. If the specification cannot be met, runout exists and another cartridge is needed to determine if the runout exists in the cartridge or the spindle.

12. To confirm a seating problem, re-seat the cartridge and repeat the runout check. If the runout is within specification, the problem has been solved. If the runout is still out of specification, continue with Step 13.
13. Spindle and cartridge are still suspect, so install a second cartridge and repeat check. If runout is now within the specification, the first cartridge is bad. If the runout check fails once more, assume that the spindle bearings are bad and replace the spindle assembly.

9.9 POSITION SIGNAL GAIN CHECK

Insufficient amplitude of the Position Signal could result in the carriage not being able to hold itself on track, resulting in read errors and possible seek errors. Too high an amplitude could result in a jitter which, in turn, emits a vibrating-type noise from the carriage that may generate seek timeout errors.

A. Required Tools:

1. Oscilloscope with probe and ground leads
2. One DIP clip, one pin-to-pin jumper

B. Gain Check:

1. Remove both top cover assemblies.
2. Place the Read/Write module box assembly up and out of the way of the carriage assembly.
3. Defeat SKTO and cover interlock (Table 9-1).
4. Install cartridge.
5. Depress LOAD switch.
6. Wait for heads to load onto the pack.
7. Disable servo drive to the carriage by disconnecting the in-line connector (Figure 9-3).
- 8a. Version 1 of DLM: Place Channel A oscilloscope probe on E11 pin 7 (Position Signal) and place Channel A ground on TP7 (Integrator Ground).
- 8b. Version 2 of DLM: Place Channel A oscilloscope probe on TP15 (Position Signal) and place Channel A ground on TP5 (Integrator Ground).
- 8c. Version 3 of DLM: Place Channel A oscilloscope probe on TP15 (Position Signal) and place Channel A ground on TP5 (Integrator Ground).

9. Observe the waveform in Figure 9-8 while manually moving the carriage back and forth.
10. Measure the peak-to-peak deviation of the Position Signal amplitude about the ground reference. It should be 3.7 ± 0.7 volts.




Figure 9-8 Position Signal Gain Check Waveform

9.10 TACHOMETER AC NOISE PICK-UP CHECK

This procedure checks the amount of noise being picked up by the tachometer. If the noise is excessive, the positioner will have a hard time holding on to a track signal. In this case, the READY light may flicker.


A. Required Tools:

1. Oscilloscope with probe and ground leads
2. DIP clip
3. Jumper

B. Check:

1. Remove both top cover assemblies.
2. Place the Read/Write module up and out of the way of the carriage assembly.
3. Defeat cover interlock (Table 9-1).
4. Install cartridge.
5. Depress LOAD switch.
6. Wait for heads to load onto the pack.

7. Disable servo drive to the carriage by disconnecting the in-line connector (Figure 9-3).
8. Set the oscilloscope (sync internally) as follows:
 - a. Channel A probe should be on TP1 of the DC Servo module (Summing Amp).
 - b. Channel A ground should be on TP11 of the DC Servo module (Signal Ground).
9. Each drive's summing amplifier output at this point will look slightly different, but it should be similar to the waveform shown in Figure 9-9.



CZ-1070

Figure 9-9 Summing Amplifier Output

10. The signal seen should have a peak-to-peak value of no more than 600 mv.
11. If the signal is out of tolerance, the DC Servo module could be bad or the drive motor may be too noisy. Replace the module, and if that does not solve the problem, replace the drive motor (see the *RL01/RL02 Disk Drive Technical Manual*).

9.11 VELOCITY PROFILE CHECK

By causing the positioner to perform an oscillating seek, the velocity profile can be checked for duration, amplitude, and waveshape.

A. Required Tools:

1. Oscilloscope with probe and ground leads
2. Toggle-in oscillating seek program shown in Chapter 7
3. DIP clip
4. Jumper

B. Check:

1. Remove both top cover assemblies.
2. Install cartridge.
3. Defeat top cover interlock (Table 9-1).
4. Depress LOAD switch.
5. Wait for heads to load onto the pack.
6. Using the oscillating program shown in Chapter 7, cause an oscillating seek from track 0 to track 255 (RL01) or track 511 (RL02).
- 7a. Version 1 of DLM: Place the Channel A oscilloscope probe on TP12, place the Channel A ground on any of the DLM ground points (TP1 through TP6 are ground) and place the external trigger on E38 pin 12 (SIGN FWD).
- 7b. Version 2 of DLM: Place the Channel A oscilloscope probe on TP8, place the Channel A ground on any of the DLM ground test points (TP1 through TP4 are ground) and place the external trigger on E25 pin 12 (SIGN FWD).
- 7c. Version 3 of DLM: Place the Channel A oscilloscope probe on TP8, place the Channel A ground on any of the DLM ground points (TP1 through TP4 are ground) and place the external trigger on E25 pin 12 (SIGN FWD).
8. Set the oscilloscope to sync internal, positive-going, and observe the waveform shown in Figure 9-10.
9. The peak amplitude of the waveform should be between 4.6 and 5.0 volts.
10. The maximum seek time should be between 80 and 86 milliseconds.




Figure 9-10 Tachometer Output Velocity Signal

11. Observe the trailing edge of the waveform (as indicated by an asterisk in Figure 9-10). There should be a slight "stepping" slope. If the observed slope has spikes in it, the positioner needs replacing as it is not rolling smoothly.
12. If the other specifications (in Steps 9 and 10) cannot be met, the DC Servo module is probably at fault.

9.12 SERVO DRIVE MOTOR CURRENT CHECK

One possible cause of seek errors is excessive drive motor current. This check will determine if there is too much current.


A. Required Tools:

1. Oscilloscope with probes and ground leads
2. Toggle-in oscillating seek program shown in Chapter 7
3. DIP clip
4. Jumper

B. Check:

1. Remove both top cover assemblies.
2. Defeat top cover interlock (Table 9-1).
3. Install cartridge.
4. Depress LOAD switch.
5. Wait for heads to load onto the pack.

6. Using the oscillating seek program listed in Chapter 7, cause an oscillating seek from track 0 to track 255 (RL01) or track 511 (RL02).
7. Place Channel A oscilloscope probe on TP3 of the DC Servo module.
- 8a. Version 1 of DLM: Place the external trigger on E38 pin 12 (SIGN FWD).
- 8b. Version 2 of DLM: Place the external trigger on E25 pin 12 (SIGN FWD).
- 8c. Version 3 of DLM: Place the external trigger on E25 pin 12 (SIGN FWD).
9. Observe the waveform shown in Figure 9-11.



CZ-1072

Figure 9-11 Positioner Motor Current Check

10. Measure the points called out in the figure and compare them to the following:
 - # 1 should be between 750 and 780 mv.
 - # 2 and # 3 are the midpoints of the waveform and should be less than or equal to 500 mv.
11. Failure to meet specifications requires replacement of the positioner/drive motor assembly or DC Servo module (see the *RL01/RL02 Disk Drive Technical Manual*).

9.13 ACCESS TIME CHECK


The access time is checked by performing oscillating seeks and observing the "ready to read/write" signal.

A. Required Tools:

1. Oscilloscope with probes and ground leads
2. Toggle-in oscillating seek program shown in Chapter 7.
3. DIP clip
4. Jumper

B. Check:

1. Remove both top cover assemblies.
2. Defeat the top cover interlock (Table 9-1).
3. Install cartridge.
4. Depress LOAD switch.
5. Wait for heads to load onto the pack.
6. Using the oscillating seek program shown in Chapter 7, issue a one track seek.
- 7a. Version 1 of DLM: Place Channel A oscilloscope probe on E25 pin 12 (Ready to Read/Write).
- 7b. Version 2 of DLM: Place Channel A oscilloscope probe on TP 16 (Ready to Read/Write).
- 7c. Version 3 of DLM: Place Channel A oscilloscope probe on TP 16 (Ready to Read/Write).
8. Observe the waveform depicted in Figure 9-12.




TIME=2 MS/DIV

VOLTS=2 V/DIV

CZ-2063

Figure 9-12 Access Time Check (One Track Seek)

9. Measure the time the "Ready to Read/Write" signal is low. It should be less than or equal to 17 milliseconds.
10. Issue a seek from track 0 to track 85 (RL01) or track 170 (RL02) and check to see that "Ready to Read/Write" is low for slightly less than 55 milliseconds. See Figure 9-13.




TIME=10MS/DIV

VOLTS=2V/DIV

CZ-2064

Figure 9-13 Access Time Check (85 or 170 Track Seek)

11. Issue a seek from track 0 to track 255 (RL01) or track 511 (RL02) and check to see that "Ready to Read/Write" is low for slightly less than 100 milliseconds. See Figure 9-14.
12. If the specifications are not met, the DLM, DC Servo module or the positioner itself could be at fault. (See Paragraph 9.11.)



TIME=20 MS/DIV
VOLTS=2 V/DIV

CZ-2065

Figure 9-14 Access Time Check (255 or 511 Track Seek)

CHAPTER 10

SERVICE TIPS

10.1 LOSS OF +5V SYMPTOM

If the unit does not function and the WRITE PROTECT lamp is dim, check the +5V.

10.2 LOSS OF +5V CAUSES

If the +5V is missing but the +8V is present the following causes should be checked (in addition to a defective regulator).

1. Pico fuse on DC Servo Module.
2. Thermal switch on DC Servo Module heat sink.
3. +5V overvoltage crowbar.
4. Home switch on positioner not closed.

10.3 HEADS RETRACT IMMEDIATELY AFTER LOADING

If the heads retract immediately after loading, the head cables may be reversed. Also, the positioner radial alignment may be off. (Positioner radial alignment is described in Paragraph 9.5.)

10.4 LOAD, READY, AND FAULT INDICATORS ALL ON

If those three indicators are all on, check the cabling from the controller. See Paragraph 10.5.

10.5 RL11 I/O CABLING

On RL11 systems it is fairly easy to have the I/O cabling reversed because of early documentation errors. The correct method is to have the BC06R red stripe toward the top of the M7762, the BC06R red stripe up at the transition connector, and the BC20J cable pointing down at the transition connector.

10.6 EARLY RL11/RLV11 VECTOR ASSIGNMENT

Early RL11/RLV11 Controllers were shipped with a vector address of 330 instead of 160.

10.7 ROLE OF CHECKS, ADJUSTMENTS AND ALIGNMENTS IN TROUBLESHOOTING

A prerequisite to module swapping as a troubleshooting procedure is to perform one or more of the checks, adjustments and alignments described in Chapter 9.

Example 1: Header Not Found and Seek Timeout errors

Typical action taken: All modules replaced; head alignment checked—problem not solved.

Solution: Radial alignment is off due to excessive head skew. This can be determined and corrected by the Positioner Radial Alignment procedure (Paragraph 9.5).

Example 2: Write Gate errors

Typical action taken: All modules replaced; head alignment checked; radial alignment checked—problem not solved.

Solution: Excessive spindle runout requires replacement of spindle. This can be determined by the Spindle Runout Check (Paragraph 9.8).

Many other problems can be solved by the checks and adjustments described in Chapter 9.

10.8 INTERMITTENT READ CHECK ERRORS

There is a new head cable guide designed to reduce the number of intermittent read check errors. See Paragraph II/2.7.1 of the *RL01/RL02 Technical Manual*.

NOTES

NOTES

NOTES

NOTES

NOTES