


**Finished Size:**  
6" x 8-1/4" inches

**SPINE: 5/16"**



124792-001



**COMPAQ**

**COMPAQ**

## User's Guide

Compaq S500 Color Monitor

Manuel de l'utilisateur  
Moniteur couleur Compaq S500

Benutzerhandbuch  
Compaq S500 Farbmonitor

Guida utente  
Monitor a colori Compaq S500

Guía del Usuario  
Monitor a Color S500 de Compaq

用户指南  
Compaq S500 彩色显示器

使用手册  
Compaq S500 彩色显示器

User's Guide

Compaq S500 Color Monitor

COMPAQ

## IMPORTANT SAFEGUARDS

1. Read all of these instructions.

2. Save these instructions for later use.



3. Unplug this monitor from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

4. Do not use attachments not recommended by the monitor manufacturer as they may cause hazards.

5. Do not use this monitor near water, e.g., near a bathtub, washbowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, etc.



6. Do not place this monitor on an unstable cart, stand, or table. The monitor may fall, causing serious injury to a child or adult, and serious damage to the appliance.



7. Slots and openings in the cabinet and the back or bottom are provided for ventilation, to ensure reliable operation of the monitor, and to protect it from overheating.

These openings must not be blocked or covered. The openings should never be blocked by placing the monitor on a bed, sofa, rug, or other similar surface. This monitor should never be placed near or over a radiator or heat register. This monitor should not be placed in a built-in installation such as a bookcase unless proper ventilation is provided.

8. This monitor should be operated only from the type of power source indicated on the marking label. If you are not sure of the power supplied to your home, consult your monitor dealer or local power company.



9. This monitor is equipped with a 3-wire grounding-type plug. That is, a plug having a third (grounding) pin. This plug will only fit into a grounding-type power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the purpose of the grounding-type plug.



10. Do not allow anything to rest on the power cord. Do not locate this monitor where the cord will be abused by people walking on it.



11. Follow all warnings and instructions marked on the monitor.



12. For added protection for this monitor during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet. This will prevent damage to the monitor and/or the computer due to lightning and power line surges.

13. Do not overload wall outlets and extension cords as this can result in fire or electric shock.

14. Never push objects of any kind into this monitor through cabinet slots, as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the monitor.

15. Do not attempt to service this monitor yourself, as opening or removing covers may expose you to dangerous voltages or other hazards. Refer all servicing to qualified service personnel.



16. Unplug this monitor from the wall outlet and refer servicing to qualified service personnel under the following conditions:

a. When the power cord or plug is damaged or frayed.

b. If liquid has been spilled into the monitor.

c. If the monitor has been exposed to rain or water.

d. If the monitor does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions, as improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore normal operation.

e. If the monitor has been dropped or the cabinet has been damaged.

f. When the monitor exhibits a distinct change in performance, this indicates a need for service.

17. When replacement parts are required be sure the service technician has used replacement parts specified by the manufacturer that have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.



18. Upon completion of any service or repairs to this monitor, ask the service technician to perform routine safety checks to determine that the monitor is safe to operate.

## FEDERAL COMMUNICATIONS COMMISSION RADIO FREQUENCY INTERFERENCE STATEMENT

**NOTE :** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures :

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio or TV technician for help.

**CAUTION :** Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## CANADIAN DEPARTMENT OF COMMUNICATIONS COMPLIANCE STATEMENT

This digital apparatus does not exceed the Class A/Class B (whichever is applicable) limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

Avis de conformité aux normes du Ministère des Communications du Canada.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de Class A/de Class B (selon le cas) prescrites dans le règlement sur le brouillage radioélectrique édicté par le ministère des communications du Canada.

## WICHTIGE INFORMATIONEN

Bitte lesen Sie alle diese Informationen, bevor Sie das Gerät in Betrieb nehmen! Lesen Sie sich außerdem die Bedienungsanleitung komplett und sorgfältig durch, da nur in diesem Fall eine problemlose Inbetriebnahme erwartet werden kann.

- Achten Sie darauf, daß das Gerät nur in eine 230V Schuko-Steckdose eingesteckt wird.
- Die Steckdose sollte jederzeit frei zugänglich sein um bei einem evtl. auftretenden Notfall das Gerät schnell vom Netz zu trennen.
- Achten Sie desweiteren darauf, daß die Netzanschlußleitung nicht mechanisch beansprucht oder sonstwie beschädigt wird.
- Öffnen Sie das Gerät niemals! Im Inneren befinden sich Teile mit gefährlicher Spannung.
- Bevor Sie das Gerät reinigen, ziehen Sie bitte den Netzstecker aus der Steckdose. Säubern Sie dann das Gerät mit einem feuchten (keinesfalls tropfnassen) Lappen.
- Die in diesem Gerät entstehende Röntgenstrahlung ist ausreichend abgeschirmt (Ortsdosisleistung in 0.1m Abstand weniger als 1.0 $\mu$  Sv/h). Beschleunigungsspannung maximal 25Kv.
- Stellen Sie das Gerät an einem ergonomisch günstigen Ort auf und sorgen Sie dafür, daß der Monitor mit nach ZH1/618/10.80 geprüfter Peripherie betrieben wird, da nur unter diesen Umständen ein optimaler ergonomischer Betrieb des Gerätes sichergestellt ist.

Falls Sie dennoch Fragen haben, auf die die Bedienungsanleitung keine hinreichende Antwort geben kann, so kontaktieren Sie bitte den nächsten Fachhändler.

Maschinenlärminformationsverordnung 3. GSGV, 18.01 1991:  
Der arbeitsplatzbezogene Schalldruckpegel beträgt 70 dB (A) oder weniger gemäß ISO 7779.

The power cord is used as a main disconnect device. Disconnect the power cord before servicing.  
The outlet must be installed near the monitor and must be easily accessible.

As an **ENERGY STAR** Partner, Compaq Computer Corporation has determined that this product meets the Energy Star guidelines for energy efficiency.

The appliance is not intended for use by young children or infirm persons, without supervision.  
Young children should be supervised to ensure that they do not play with the monitor.

### Emission Characteristics Tested by SEMKO

A sample of this type has been tested and has shown compliance with the guidelines in the Swedish document MPR II.

This product is also designed for IT power system with a phase-to-phase voltage of 230V.

# CONTENTS

---

<b>Introduction</b> .....	1
Product Features .....	2
<b>Setup</b> .....	3
Installing the Tilt/Swivel Stand .....	3
Connecting the D-Sub Signal Cable .....	4
Connecting to the External Speakers (optional) .....	4
Connecting the Power Cord .....	4
Power Management System .....	5
Display Data Channel (DDC) for Plug and Play .....	5
<b>Operation and Adjustment</b> .....	6
<b>Specifications</b> .....	9
<b>Factory Preset Timings</b> .....	10
<b>Troubleshooting</b> .....	11

## Appendix

Description for D-Sub Connector

# INTRODUCTION

---

This manual explains how to correctly install, operate, and get the best performance from your monitor. Please read this user's guide carefully before installing your monitor, then keep it near your monitor for quick reference.

First, please check that the contents of the box corresponds with the following checklist :

- Color monitor
- Power cord
- Tilt/swivel stand
- User's Guide

If any item is missing or damaged, please contact your dealer. Please keep the box and packing materials so that you may properly store or transport your monitor.


## PRODUCT FEATURES

- The convenient and user-friendly on-screen display allows for easy and accurate adjustments of horizontal and vertical screen size and position, geometry, and screen color.
- The monitor supports a safe working environment in strict compliance with the MPR II standard for low emissions.
- The monitor complies with the VESA Display Data Channel (DDC) specification for Plug and Play compatibility. Advanced microcircuitry makes setup and configuration fast and effortless.
- The monitor features Advanced Color Controls for fine-tuning to meet your own personal tastes or application requirements. Use the on-screen controls to adjust the color temperature and RB gain value for the best possible screen color and intensity.
- Activate the higher refresh rates of the monitor to stabilize the screen and eliminate the annoying flicker that contributes to eye-strain and headaches.
- The “borderless” full-screen display capability works under all graphic modes and provides a larger viewing area than conventional monitors, giving you a better picture with more workspace.

## SETUP

### INSTALLING THE TILT/SWIVEL STAND

1. Ensure that the power is off to the monitor.
2. Set the monitor face down with the underside facing you. Please be careful not to scratch the monitor screen.
3. Align the four hooks on the stand with the guide holes on the bottom chassis of the monitor.
4. Insert the hooks into the guide holes.
5. Slide the tilt/swivel stand toward the front of the monitor until the latch locks in position.
6. Turn the monitor and the stand upright.



If you want to remove the tilt/swivel stand on the monitor, press the latch and pull the tilt/swivel stand toward the back of the monitor. Lift the stand to separate.

---

## CONNECTING THE D-SUB SIGNAL CABLE

1. Turn off the computer and monitor.
2. Connect the 15-pin D-sub connector to the output port of the video card in your computer.
3. Tighten the screws of the connector.

---

## CONNECTING TO THE EXTERNAL SPEAKERS (OPTIONAL)

1. Ensure the monitor is facing you.
2. Align the two hooks on the speaker with each hole on the monitor.
3. Insert each hook into each hole.
4. Push the speaker toward the bottom of the monitor.
5. Plug the connector on the left speaker into the *Left out* socket of the right speaker.
6. Plug the *Stereo in* cable on the right speaker into the audio port on your computer.
7. Plug the adapter into the *DC in* socket on the right speaker.

---

## CONNECTING THE POWER CORD

1. Plug the power cord into the AC receptacle located on the back of the monitor.
2. Plug the other end of the power cord into the AC outlet.

If your power cord is PC-to-Monitor type, plug the other end of the power cord into the AC receptacle in the computer.

---

## POWER MANAGEMENT SYSTEM


If you use the monitor with a computer that complies with the power-saving program, you can set the monitor to go blank when the system has remained unused for a period of time. To specify the period or to disable this feature, set the system timeout field of the computer's system setup program or use special software for power-saving. See the computer user's manual for the details of using the system setup. While the monitor is in power-saving mode (blank screen), it consumes less power than when it is in its normal state. The color of the power LED will indicate the state. To restore the screen image, press any key of your keyboard or move your mouse. If the signal cable is connected loosely or disconnected, the power-saving feature will not operate.

---

## DISPLAY DATA CHANNEL FOR PLUG AND PLAY


If you use the monitor with a computer that complies with DDC1/2B of VESA, the host video card automatically configures itself without your intervention in a way that best fits the attached monitor. The Display Data Channel (DDC) allows the monitor to inform the host system about configuration information for optimum use of the monitor. Use of the video card utility is not required to match the resolutions and refresh rates of the monitor and video card.

# OPERATION & ADJUSTMENT



- : Launch OSD (On-Screen Display) Menus
- : Select the next function
- : Select the previous function
- : Increase the value of any selected function
- : Decrease the value of any selected function
- : Exit OSD Menus & Launch OSD Menus, when there is no OSD

## Key Process



## 1. OSD (On-Screen Display) Menu 1

	<p>Adjust the contrast of the image, which is the difference between light and dark areas on the screen.</p>
	<p>Adjust the brightness of the entire display.</p>
	<p>Adjust the position of the display horizontally (left or right).</p>
	<p>Adjust the display width (horizontal size).</p>
	<p>Adjust the position of the display vertically (up or down).</p>
	<p>Adjust the display height (vertical size).</p>

## 2. OSD (On-Screen Display) Menu 2

	<p>Adjust the left and right margins for more convex or more concave margins.</p> <ul style="list-style-type: none"> <li>Image turns to  by .</li> <li>Image turns to  by .</li> </ul>
	<p>Adjust the trapezoid of the screen by moving the lines inward or outward.</p> <ul style="list-style-type: none"> <li>Image turns to  by .</li> <li>Image turns to  by .</li> </ul>
	<p>Choose different preset color temperatures or set your own customized color parameters.</p>
	<p>Adjust the red gain.</p>
	<p>Adjust the blue gain.</p>
	<p>Degauss the display and restore image quality.</p>
	<p>Reset the screen to the Factory Preset Display Settings.</p>

## SPECIFICATIONS

<b>Picture Tube</b>	<p>Type : 15-inch, Flat Square Tube type (13.8-inch, viewing area)</p> <p>Dot Pitch : 0.28mm, MPR II</p> <p>Face Treatment : Nonglare/Antistatic</p>															
<b>Video</b>	<p>Input Signal : RGB Analog</p> <p>Amp. Bandwidth : 65 MHz</p> <p>Input Sync : TTL, separate negative/positive</p>															
<b>Scan Frequency</b>	<p>Horizontal : 30 - 54 KHz</p> <p>Vertical : 50 - 120 Hz</p>															
<b>Max. Resolution</b>	<p>1024 dots × 768 lines (at 60 Hz)</p>															
<b>Power Source</b>	<p>Free Voltage (100-240 Vac, 50/60 Hz)</p>															
<b>Display Area</b>	<p>Standard Display Area : 264mm(H) × 198mm(V)</p> <p>Full Screen Size : 284mm(H) × 212mm(V)</p>															
<b>Power Consumption</b>	<p>Max. 75W</p> <table border="1" data-bbox="1518 999 2063 1222"> <thead> <tr> <th>State</th> <th>Recovery Time</th> <th>Power LED</th> </tr> </thead> <tbody> <tr> <td>On</td> <td>None</td> <td>Green</td> </tr> <tr> <td>Standby Suspend</td> <td>3 seconds</td> <td>Green : 0.5 second Amber : 0.5 second</td> </tr> <tr> <td>Sleep</td> <td>-</td> <td>Amber</td> </tr> <tr> <td>Off</td> <td>-</td> <td>Off</td> </tr> </tbody> </table>	State	Recovery Time	Power LED	On	None	Green	Standby Suspend	3 seconds	Green : 0.5 second Amber : 0.5 second	Sleep	-	Amber	Off	-	Off
State	Recovery Time	Power LED														
On	None	Green														
Standby Suspend	3 seconds	Green : 0.5 second Amber : 0.5 second														
Sleep	-	Amber														
Off	-	Off														

## TROUBLESHOOTING

Symptom	Check
<b>No picture.</b>	Check if power switch and computer power switch are in the on position. ↓ Check if the signal cable is correctly connected to the video card. ↓ Check if the pins of D subconnector are not bent. ↓ Check if the computer is in the power-saving mode.
<b>POWER LED is not lit.</b>	Check if power switch is in the on position. ↓ Check if the power cord is correctly connected.
<b>Image is unstable.</b>	Check if the signal cable is suitable to the video card.
<b>Image is not centered, too small or too large.</b>	Adjust H&V Size or H&V Position to get the proper image.
<b>Picture bounces or a wave pattern is present in the picture.</b>	Keep the devices that may cause electrical interference away from the monitor. ↓ See the FCC information at the front cover of the manual.
<b>Color looks blotchy.</b>	Operate Degauss once.
<b>Picture is blurred.</b>	Adjust Contrast and Brightness. ↓ Operate Degauss once.
<b>Edges of available area on the screen are not straight.</b>	Adjust Pincushion/Trapezoid.

**Tilt/Swivel Range** Tilt : 5 degrees forward, 10 degrees backward  
Swivel : ± 45 degrees leftward, rightward

**Dimension** 368(W) × 394(D) × 382(H)mm  
(set with stand)

**Weight(net/gross)** 12.5/14.2 Kg  
27.6/31.4 lbs

**Operating Environment**  
Temperature : 50 ~ 104°F / 10 ~ 40°C  
Relative Humidity : 8 ~ 80%

**Storage Environment**  
Temperature : - 4 ~ 113°F / - 20 ~ 45°C  
Relative Humidity : 5 ~ 90%

## FACTORY PRESET TIMINGS


Pixel Format	V.Freq (Hz)	H.Freq(KHz)	Pixel Clock(MHz)	Remark
640 X 480	59.94	31.47	21.175	Noninterlaced
640 X 480	85.01	43.27	36.000	Noninterlaced
640 X 480	75.00	37.5	31.500	Noninterlaced
720 X 400	70.08	31.47	28.321	Noninterlaced
800 X 600	75.00	46.88	49.500	Noninterlaced
800 X 600	85.06	53.67	56.250	Noninterlaced
832 X 624	74.55	49.72	57.283	Noninterlaced
1024 X 768	60.00	48.4	65.000	Noninterlaced

This monitor has stored the above-mentioned eight timings in the factory. You can save up to 10 modes in the user memory automatically. Please note that if you save to user memory more than 10 times, the first mode saved will be replaced with your 11th mode.

# APPENDIX

## DESCRIPTION FOR D-SUB CONNECTOR

Pin	Signal
1	Red Video
2	Green Video
3	Blue Video
4	Open
5	Return
6	Red GND
7	Green GND
8	Blue GND
9	Blank(No Pin)
10	Sync GND
11	Open
12	DDC DATA
13	Horizontal Sync
14	Vertical Sync
15	DDC CLOCK



\* GND=Ground