



**Intel<sup>®</sup> N440BX Server  
System Event Log (SEL)  
Error Messages**

**Revision 1.00**

**5/11/98**



## DISCLAIMERS

Copyright ©1998 Intel Corporation

Information in this document is provided in connection with Intel products. No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted by this document. Except as provided in Intel's Terms and Conditions of Sale for such products, Intel assumes no liability whatsoever, and Intel disclaims any express or implied warranty, relating to sale and/or use of Intel products including liability or warranties relating to fitness for a particular purpose, merchantability, or infringement of any patent, copyright or other intellectual property right. Intel products are not intended for use in medical, life saving, or life sustaining applications. Intel may make changes to specifications and product descriptions at any time, without notice.

Designers must not rely on the absence or characteristics of any features or instructions marked "reserved" or "undefined." Intel reserves these for future definition and shall have no responsibility whatsoever for conflicts or incompatibilities arising from future changes to them.

I<sup>2</sup>C is a two-wire communications bus/protocol developed by Philips. SMBus is a subset of the I<sup>2</sup>C bus/protocol and was developed by Intel. Implementations of the I<sup>2</sup>C bus/protocol or the SMBus bus/protocol may require licenses from various entities, including Philips Electronics N.V. and North American Philips Corporation.

The SEL Viewer may contain design defects or errors known as errata which may cause the product to deviate from published specifications. Current characterized errata are available on request.

\*Third-party brands and names are the property of their respective owners.

# Contents

<b>1</b>	<b>INTRODUCTION .....</b>	<b>1</b>
1.1	DOCUMENT ORGANIZATION .....	1
1.2	CONVENTIONS AND TERMINOLOGY .....	1
1.3	OVERVIEW .....	2
1.3.1	<i>Sensors</i> .....	4
1.3.2	<i>Event Generator</i> .....	4
1.3.3	<i>Event Receiver</i> .....	4
1.3.4	<i>BIOS</i> .....	4
1.3.5	<i>System Event Log (SEL)</i> .....	4
1.4	SEL VIEWER SCREEN .....	5
<b>2</b>	<b>SENSOR TYPE CODES .....</b>	<b>7</b>
2.1	USING THE SENSOR TABLE .....	7
<b>3</b>	<b>BIOS ERROR MESSAGES .....</b>	<b>10</b>
3.1.1	<i>Using The System Event logging Format Table</i> .....	10
3.2	POST ERROR .....	11
3.2.1	<i>Using the Post Error Table</i> .....	11

## Tables

Table 1-1: Glossary .....	1
Table 2-1: Sensor Type Codes .....	8
Table 3-1: System Event Logging Format .....	10
Table 3-2: POST Error Messages .....	12

## Figures

Figure 1-1: Event Message Flow .....	3
Figure 1-2: SEL Viewer Screen .....	5
Figure 2-1: SEL Viewer in verbose mode .....	7
Figure 3-1: SEL Viewer in hex mode .....	11

# 1 Introduction

This document is provided as a reference to the information displayed by the System Event Log (SEL) Viewer on the Intel® N440BX server boards and server systems. It provides a tabular description of the event that has been recorded in the SEL.

## 1.1 Document Organization

This document is primarily composed of tables containing possible conditions that occur in the SEL along with a definition of the SEL data.

**Section 1** contains a brief introduction to the SEL and the SEL Viewer, along with a glossary of terms and acronyms used in this document.

**Section 2** contains a table of SEL information generated from the sensors on the Intel® N440BX server platform.

**Section 3** contains tables of SEL information generated from the N440BX BIOS System Events and POST Errors.

## 1.2 Conventions and Terminology

This document uses the following terms and abbreviations:

*Table 1-1: Glossary*

Term	Definition
BIOS	Basic Input Output System.
BSP	Boot Strap Processor.
BMC	Baseboard Management Controller.
Byte	An 8-bit quantity.
CMOS	In terms of this specification, this describes the PC/AT* compatible region of battery-backed 128 bytes of memory, which normally resides on the baseboard.
DIMM	Dual-inline Memory Module. Name for the plug in modules used to hold the system's DRAM (Dynamic Random Access Memory).
ECC	Error-correcting Code. Refers to a set of additional bits on system RAM that are used to provide a check code that is used to verify memory data integrity.
EMP	Emergency Management Port.
EvMRev	Event Message Revision
FRB	Fault Resilient Booting. A term used to describe system features and algorithms that improve the likelihood of the detection of, and recovery from, processor failures in a multiprocessor system.
FRU	Field Replaceable Unit.
HSC	Hot-Swap Controller. Name for the microcontroller that implements the SAF-TE command set and controls the fault lights and drive power on a N440BX Backplane.
IERR	Internal Error. A signal from the Pentium® II Xeon™ processor indicating an internal error condition.

Term	Definition
IPMB	Intelligent Platform Management Bus. Name for the architecture, protocol, and implementation of a special bus that interconnects the baseboard and chassis electronics and provides a communications media for system platform management information.
IPMI	Intelligent Platform Management Interface. This protocol is used for communication between microcontrollers, System Management Software, and other 'intelligent' devices on the IPMB.
NMI	Non-maskable Interrupt. The highest priority interrupt in the system, after SMI. This interrupt has traditionally been used to notify the operating system fatal system hardware error conditions, such as parity errors and unrecoverable bus errors.
NVRAM	Non-Volatile RAM.
PERR	Parity Error. A signal on the PCI bus that indicates a parity error on the bus.
POST	Power On Self Test.
SAF-TE	SCSI Accessed Fault-tolerant Enclosure specification. Describes a set of SCSI commands whereby drive fault status can be sent to an enclosure for the purpose of presenting that fault information with external indicators, such as fault lights. Other commands are provided so certain management information about the enclosure, such as temperature, voltage, number of drive bays, power status, etc., can be retrieved.
SCU	System Configuration Utility.
SDR	Sensor Data Record. A data record that provides platform management sensor type, locations, event generation, and access information.
SEL	System Event Log. A non-volatile storage area and associated interfaces for storing system platform event information for later retrieval.
SERR	System Error. A signal on the PCI bus that indicates a 'fatal' error on the bus.
SM	Server Management.
SMI	System Management Interrupt.
SMS	Server Management Software.
SSU	System Setup Utility.

### 1.3 Overview


The System Event Log (SEL) is a non-volatile repository for system events. The SEL Viewer provides an interface for the server administrator to view the SEL. The administrator can use this information to:

- Monitor the server for both warnings, such as when the chassis door on a server has been opened, or potential critical problems, such as when a processor has failed or a temperature threshold has been crossed.
- Examine all system event log entries recorded by the Baseboard Management Controller (BMC). These events can be generated from the BMC, Hot Swap Controller (HSC), BIOS and all the events generated by the firmware.
- Examine SEL records by sensor Type and Number in hex or verbose mode
- Examine SEL records by event Type in hex or verbose mode
- Examine SEL records from a previously stored binary file in hex or verbose mode.

Information moves from the Intel® N440BX server system to the SEL Viewer as

demonstrated in the following diagram:

*Figure 1-1: Event Message Flow*



### **1.3.1 Sensors**

The Intel® N440BX Server System contains sensors that monitor System Health. For example, a management controller that scans temperatures and voltages provides an interface to this information as ‘temperature sensors’ and ‘voltage sensors’.

In the event that a sensor reading exceeds the predefined range, an Event Message is generated. This Event Message is passed to the Baseboard Management Controller (BMC). The BMC passes the event message to the System Event Log (SEL) where it becomes available for querying by the System Event Log Viewer.

### **1.3.2 Event Generator**

The BMC itself will typically be responsible for monitoring and managing the system board. For example, monitoring baseboard temperatures and voltages. As such, the BMC will also be an Event Generator, sending the Event Messages that it generates internally to its Event Receiver functionality.

### **1.3.3 Event Receiver**

The Event Receiver is the device that receives Event Messages. In the main computing unit, a particular management controller, referred to as the Baseboard Management Controller (BMC), is normally the Event Receiver for the system.

### **1.3.4 BIOS**

The system BIOS (Basic I/O System) firmware serves many important roles in platform management. It loads and initializes the system management hardware interfaces so they can be accessed later by System Management Software and the Operating System. The BIOS works with the system hardware and management controllers during POST to implement checks of the system and management hardware.

### **1.3.5 System Event Log (SEL)**

The System Event Log (SEL) is the repository for the Event Messages. The System Event Log is implemented as non-volatile storage to ensure that Critical Events entered into the SEL can be retrieved for ‘post-mortem analysis’ should a system failure occur. The platform’s System Event Log is typically of limited size (~3 to ~8 KB, depending on the implementation). On Intel® N440BX server systems, the SEL can hold up to 206 entries or about 3 KB. Therefore, it is important to clear the SEL periodically.

If the SEL becomes full it will not delete previous entries. This prevents the first event record, which may provide the most important information on a critical event, from being deleted before it can be viewed. If, however, management software

such as Intel<sup>®</sup> Server Control (ISC) has been installed on the server system, it will manage the SEL. ISC will automatically delete older SEL entries and prevent the Log from completely filling. Since ISC provides a variety of alerting capabilities for critical events, it eliminates the need to retain older SEL entries until they are viewed.

## 1.4 SEL Viewer Screen

The SEL Viewer is the user interface to the SEL. This interface can be run both from the Emergency Management Port (EMP) and the System Setup Utility (SSU). It extracts information from the SEL and presents it to the user in either a hex or verbose format. It also provides support for the user to save the current SEL data to a file for later use or clear the current SEL records at the server. If using SSU, the records can be cleared directly from the interface. If using the EMP, clearing the log has to be done through the BIOS set up.

Figure 1-2 gives a better idea of the type of information that can be gathered by looking at the SEL Viewer. For documentation purposes, the EMP interface is used here.




Figure 1-2: SEL Viewer Screen

**Rec. ID** – A unique id that is generated for each event in the SEL.

**Event Type** - Indicates what the event pertains to. Currently holds the value of “System Event”. This field is for future use.

**Time Stamp** - The time and the date that the error was generated (Pre\_Init Timestamp means no timestamp is available. This should not appear on a post production system).

**Generator ID** - This field identifies the device that has generated the Event Message.

**EmvRev.** - This field is used to identify different revisions of the Event Message format. Currently hold the value of “#02”. This field is for future use.

**Sensor Type** - Indicates the event class or type of sensor that generated the Event Message. See table 2-1 for the list of Sensor Types.

**Sensor Number** - A unique number (within a given sensor device) representing the ‘sensor’ within the management controller that generated the Event Message. Sensor numbers are used for both identification and access of sensor information, such as getting and setting sensor thresholds. See table 2-1 for the list of Sensor Types.

**Event Description** - Short description of the event that generating the entry in the SEL Viewer.

## 2 Sensor Type Codes

The Sensor Type Code Table provides information regarding:

- The type of sensor generating the SEL entry
- The name of the sensor
- The microcontroller which initiated the SEL entry
- The warning or error which initiated the SEL entry

### 2.1 Using The Sensor Table

Compare the **Sensor Type and Number** message from the SEL Viewer to the **Sensor Type / Number in Verbose** column in the table below. Use the **Sensor Name** column in the table to determine the physical component which has generated the SEL message and the **Generator ID** column to locate the microcontroller which reported the event to the SEL. If more detailed information regarding the event is available from the Event Description column in the SEL Viewer.

For example, if there is a “Fan #10” entry in the **Sensor Type and Number** column of the SEL Viewer, by looking at the Sensor Type Codes table (figure 2-1 below) it can be determined that the Baseboard Fan 1 caused this entry. The entry was reported through the Baseboard Management Controller on the Intel® N440BX server board.

Rec. ID	Event Type	Time Stamp	Generator ID	Emv Rev	Sensor Type and Number	Event Description
0x8005	System Event	04/19/98 - 15:52:20	BIOS	#02	System Event #EF	System Boot Event OEM Or Unsp
0xC005	System Event	Pre-Init Timestamp	Primary HSC - LU...	#02	Drive Bay #0B	Device Inserted
0xD005	System Event	Pre-Init Timestamp	BMC - LUN #0	#02	Physical Security #26	Unspecified Event Trigger
0xE005	System Event	Pre-Init Timestamp	BMC - LUN #0	#02	Fan #10	Lower Critical - going low Trigger
0xF005	System Event	04/19/98 - 15:55:42	BIOS	#02	System Event #EF	System Boot Event OEM Or Unsp
0x0006	System Event	Pre-Init Timestamp	BMC - LUN #0	#02	Physical Security #26	Unspecified Event Trigger
0x1006	System Event	Pre-Init Timestamp	BMC - LUN #0	#02	Fan #10	Lower Critical - going low Trigger
0x2006	System Event	Pre-Init Timestamp	Primary HSC - LU...	#02	Drive Bay #0B	Device Inserted
0x3006	System Event	04/19/98 - 15:57:28	BIOS	#02	System Event #EF	System Boot Event OEM Or Unsp
0x4006	System Event	04/23/98 - 09:35:42	BMC - LUN #0	#02	Secure Mode Violation Attempt #27	Unspecified Event Trigger
0x5006	System Event	Pre-Init Timestamp	BMC - LUN #0	#02	Physical Security #26	Unspecified Event Trigger
0x6006	System Event	Pre-Init Timestamp	BMC - LUN #0	#02	Fan #10	Lower Critical - going low Trigger
0x7006	System Event	Pre-Init Timestamp	Primary HSC - LU...	#02	Drive Bay #0B	Device Inserted
0x8006	System Event	04/23/98 - 09:38:39	BIOS	#02	System Event #EF	System Boot Event OEM Or Unsp
0x9006	System Event	04/23/98 - 09:38:39	BMC - LUN #0	#02	Post Error #25	Unspecified Event Trigger
0xA006	System Event	04/23/98 - 09:38:39	BMC - LUN #0	#02	Post Error #25	Unspecified Event Trigger

SERVER NAME:      LINE: Direct      MODE: EMP      LINE STATUS: Connected

Figure 2-1: SEL Viewer in verbose mode

Table 2-1: Sensor Type Codes

Sensor Type and Number in Verbose	Sensor Name	Generator ID
Reserved	00h	
Temperature #13	Primary Processor Socket Temp (disabled by default)	BMC
Temperature #14	Secondary Processor Socket Temp (disabled by default)	BMC
Temperature #15	Baseboard Temp1 (disabled by default)	BMC
Temperature #16	Baseboard Temp2 (disabled by default)	BMC
Temperature #17	Processor1 Temp	BMC
Temperature #18	Processor2 Temp	BMC
Temperature #19	Baseboard Temp1	BMC
Temperature #1A	Baseboard Temp2	BMC
Temperature #01	Backplane Temperature	HSC
Voltage #01	Baseboard 5V	BMC
Voltage #02	Baseboard 3.3V	BMC
Voltage #03	Primary Processor	BMC
Voltage #04	Secondary Processor	BMC
Voltage #05	Processor 2.5V	BMC
Voltage #06	5v Standby	BMC
Voltage #07	Baseboard SCSI-A Term1	BMC
Voltage #08	Baseboard SCSI-A Term2	BMC
Voltage #09	Baseboard SCSI Term3	BMC
Voltage #0A	Baseboard -12V	BMC
Voltage #0B	Baseboard SCSI-B Term1	BMC
Voltage #0C	Processor 1.5V	BMC
Voltage #0D	Baseboard -5V	BMC
Voltage #0E	Baseboard 12	BMC
Fan #0F	Baseboard Fan0	BMC
Fan #10	Baseboard Fan1	BMC
Fan #11	Processor Fan0	BMC
Fan #12	Processor Fan1	BMC
Fan #0C	Backplane Fan1 speed	HSC
Fan #0D	Backplane Fan2 speed	HSC
Physical Security #26	Chassis Intrusion	BMC
Secure Mode Violation Attempt #27	EMP Password (at the time of connecting to the server)	BMC
Secure Mode Violation Attempt #28	Secure Mode (violation while the system is in the secure mode)	BMC
Processor #1B	Processor1 Status	BMC
Processor #1C	Processor2 Status	BMC
Memory #1F	DIMM1 Presence	BMC
Memory #20	DIMM2 Presence	BMC
Memory #21	DIMM3 Presence	BMC
Memory #22	DIMM4 Presence	BMC
Drive Bay #02	Drive Slot 0 Status	HSC
Drive Bay #03	Drive Slot 1 Status	HSC
Drive Bay #04	Drive Slot 2 Status	HSC
Drive Bay #05	Drive Slot 3 Status	HSC
Drive Bay #06	Drive Slot 4 Status	HSC
Drive Bay #07	Drive Slot 0 Presence	HSC

Sensor Type and Number in Verbose	Sensor Name	Generator ID
Drive Bay #08	Drive Slot 1 Presence	HSC
Drive Bay #09	Drive Slot 2 Presence	HSC
Drive Bay #0A	Drive Slot 3 Presence	HSC
Drive Bay #0B	Drive Slot 4 Presence	HSC
POST Error #25	See Section 3.2	BIOS
Watchdog #25	Watchdog Event	BMC
System Event #EF	See Table 3.1	BIOS

## 3 BIOS Error Messages

The BIOS is responsible for monitoring and logging certain System Events, Memory Errors and Critical Interrupts. The BIOS sends an event request message to BMC to log the event. Some errors such as the processor failure are logged during early POST.

### 3.1.1 Using The System Event logging Format Table

In the table below, **Sensor Type and Number** both in verbose and hex, the first 2 bytes of the **Event Description** in hex, the **Event Type** and The **Event Description** in verbose for the BIOS generated error are listed in the table below.

For example, if in verbose mode, the **Sensor Type and Number** is “Memory #EF” and the **Event Description** begins with the words “Correctable ECC...”, the event type is a “Single bit memory Error”.

*Table 3-1: System Event Logging Format*

Sensor Type and Number in verbose	Sensor Type and Number in hex	Event Description in hex	Event Type	Event Description
System Event #EF	12 EF	E7 01 -- --	System Boot Event	System Boot Event ...
System Event #EF	12 EF	E7 00 -- --	System Reconfiguration	System Boot Event ...
Memory #EF	0C EF	E7 20 -- --	Single Bit Memory Error	Correctable ECC ...
Memory #EF	0C EF	E7 21 -- --	Double Bit Memory Error	Non-Correctable ECC ...
Memory #EF	0C EF	E7 02 -- --	Memory Parity Error	Parity ...
Critical Interrupt #EF	13 EF	E7 01 -- --	Bus Timeout	Bus Timeout ...
Critical Interrupt #EF	13 EF	E7 02 -- --	I/O CHK	I/O Channel check NMI ...
Critical Interrupt #EF	13 EF	E7 03 -- --	Software NMI	Software NMI ...
Critical Interrupt #EF	13 EF	E7 04 -- --	PCI PERR	PCI PERR ...
Critical Interrupt #EF	13 EF	E7 05 -- --	PCI SERR	PCI SERR ...

### 3.2 Post Error

Currently the BIOS events that are generated in the pre boot period, such as clearing CMOS, are logged during early stage as POST Error #25 under the Sensor

Type and Number column. This section contains a table of the POST Errors, which help the user clarify the error message.

### 3.2.1 Using the Post Error Table

To use this table, view the SEL Viewer entries in hex mode. The Event Description contains 4 bytes. Reverse the last two bytes of the description and look for the corresponding information in the **Code** column of the table below. Use the **Error Message** column to determine the error that caused the entry in the SEL and the **Pause on Error** column to determine how the BIOS will react to this error.

For example, if in hex mode, the Event Description is “00 a1 52 81”, the last two bytes are “52 81”, as shown in figure below. Look at the corresponding Error message in the table. In this example the corresponding error message to the **Code** “52 81” is “NVRAM (CMOS) Data Invalid, NVRAM cleared” meaning the CMOS was cleared.

Note: In other documents in which the POST Error Message table is used, the 2 bytes of the Codes are going to be in reverse order. In this document, the **Code** column in table 3-2 has been modified to help the user access information easily.

Rec. ID	Event Type	Time Stamp	Generator ID	Emv Rev	Sensor Type and Number	Event Description
9006	02	353f0c1f	0020	02	0f 25	00 a1 50 81
a006	02	353f0c1f	0020	02	0f 25	00 a1 52 81

SERVER NAME:      LINE: Direct      MODE: EMP      LINE STATUS: Connected

Figure 3-1: SEL Viewer in hex mode

Table 3-2: POST Error Messages

Code	Error Message	Pause on Error
62 01	BIOS unable to apply BIOS update to processor 1	Yes
63 01	BIOS unable to apply BIOS update to processor 2	Yes
64 01	BIOS does not support current stepping for processor 1	Yes
65 01	BIOS does not support current stepping for processor 2	Yes
00 02	Failure Fixed Disk	No
10 02	Stuck Key	No
11 02	Keyboard error	No
12 02	Keyboard Controller Failed	Yes
13 02	Keyboard locked - Unlock key switch	Yes
20 02	Monitor type does not match CMOS - Run SETUP	No
30 02	System RAM Failed at offset:	No
31 02	Shadow Ram Failed at offset:	No
32 02	Extended RAM Failed at offset:	No
50 02	System battery is dead - Replace and run SETUP	Yes
51 02	System CMOS checksum bad - Default configuration used	Yes
60 02	System timer error	No
70 02	Real time clock error	No
97 02	ECC Memory error in base (extended) memory test in Bank xx	Yes
B2 02	Incorrect Drive A type - run SETUP	No
B3 02	Incorrect Drive B type - run SETUP	No
D0 02	System cache error - Cache disabled	No
F5 02	DMA Test Failed	Yes
F6 02	Software NMI Failed	No
01 04	Invalid System Configuration Data - run configuration utility	No
None	System Configuration Data Read Error	No
03 04	Resource Conflict	No
04 04	Resource Conflict	No
05 04	Expansion ROM not initialized	No
06 04	Warning: IRQ not configured	No
04 05	Resource Conflict	Error
05 05	Expansion ROM not initialized	No
06 05	Warning: IRQ not configured	No
01 06	Device configuration changed	No
02 06	Configuration error - device disabled	No
00 81	processor 0 failed BIST	Yes
01 81	processor 1 failed BIST	Yes
04 81	processor 0 Internal Error (IERR) failure	Yes
05 81	processor 1 Internal Error (IERR) failure	Yes
06 81	processor 0 Thermal Trip failure	Yes
07 81	processor 1 Thermal Trip failure	Yes
08 81	Watchdog Timer failed on last boot, BSP switched.	Yes
0A 81	processor 1 failed initialization on last boot.	Yes
0B 81	processor 0 failed initialization on last boot.	Yes
0C 81	processor 0 disabled, system in Uni-processor mode	Yes
0D 81	processor 1 disabled, system in Uni-processor mode	Yes
0E 81	processor 0 failed FRB Level 3 timer	Yes
0F 81	processor 1 failed FRB Level 3 timer	Yes
10 81	Server Management Interface failed to function	Yes
20 81	IOP sub-system is not functional	Yes

Code	Error Message	Pause on Error
50 81	NVRAM (CMOS) Cleared by Jumper	Yes
51 81	NVRAM (CMOS) Checksum Error, NVRAM cleared	Yes
52 81	NVRAM (CMOS) Data Invalid, NVRAM cleared	Yes