

Technical Information Manual

PC 365 (Type 6589)

S84H-0334-01



Technical Information Manual

S84H-0334-01

PC 365 (Type 6589)

Note

Before using this information and the product it supports, be sure to read the general information under Appendix E, "Notices and Trademarks" on page 51.

Second Edition (March 1997)

The following paragraph does not apply to the United Kingdom or any country where such provisions are inconsistent with local law: INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time.

This publication was developed for products and services offered in the United States of America. IBM may not offer the products, services, or features discussed in this document in other countries, and the information is subject to change without notice. Consult your local IBM representative for information on the products, services, and features available in your area.

Requests for technical information about IBM products should be made to your IBM reseller or IBM marketing representative.

© **Copyright International Business Machines Corporation 1996, 1997. All rights reserved.**

Note to U.S. Government Users — Documentation related to restricted rights — Use, duplication or disclosure is subject to restrictions set forth in GSA ADP Schedule Contract with IBM Corp.

Contents

Preface	vii
Manual Style	vii
Related Publications	viii
Chapter 1. System Overview	1
Hardware Features	1
System Software Features	2
Chapter 2. System Board Features	4
Microprocessor	4
Dual Processing Support	4
Chip Set Control	5
Input/Output Controller	9
Riser Card	13
Physical Layout	14
Chapter 3. Adapters and Internal Drives	17
Graphics Adapters	17
SCSI Adapter	18
Internal Drives	19
Chapter 4. Power Supply	20
Power Input	20
Power Output	20
Component Outputs	21
Output Protection	22
Power Connectors	23
Chapter 5. Physical Specifications	24
Chapter 6. System Compatibility	26
Hardware Compatibility	26
Software Compatibility	29
Appendix A. Connector Pin Assignments	30
System Memory Connectors	30
EIDE Connectors	33
Diskette Drive Connector	34
Serial Port Connector	35
Parallel Port Connector	35
Keyboard and Mouse Port Connectors	36
USB Connector	37
Infrared Port Connector	37
ISA Connectors	38
PCI Connector	40
Appendix B. System Address Maps	42
System Memory Map	42
Input/Output Address Map	43
DMA I/O Address Map	44

Appendix C. IRQ and DMA Channel Assignments	46
Appendix D. Error Codes	48
POST Error Codes	48
Beep Codes	50
Appendix E. Notices and Trademarks	51
References	52
Index	53

Tables

1.	System Resource Assignments for PCI-to-ISA Bridge	6
2.	System Resource Assignments for EIDE Interface	7
3.	System Resource Assignments for USB Interface	8
4.	Serial Port Assignments	9
5.	Parallel Port Assignments	10
6.	System Resource Assignments for the Keyboard and Mouse	11
7.	System Resource Assignments for the Real-Time Clock	12
8.	Riser Card Characteristics	13
9.	J3 - System Power Connection	15
10.	J11, J13 - Wake on Modem Ring Connections	15
11.	J15 - Wake on LAN Connection	15
12.	J8 - CMOS-Clear Jumper	15
13.	Switches 1 to 6 for Microprocessor Speeds	16
14.	Switch 8 for Diskette Write-Protection	16
15.	System Resource Assignments for the S3 Trio64V+ Adapter	17
16.	System Resource Assignments for the Matrox Adapter	18
17.	Diskette Drives	19
18.	Hard Disk Drives	19
19.	Drives with Optical Media	19
20.	Power Input Requirements	20
21.	Power Output	20
22.	System Board	21
23.	Keyboard Port	21
24.	Auxiliary Device Port	21
25.	ISA-Bus Adapters (Per Slot)	21
26.	PCI-Bus Adapters (Per Slot)	21
27.	Internal Devices (DASD)	22
28.	Pin Assignments for 4-Pin Power Connectors	23
29.	Pin Assignments for 6-Pin Power Connectors	23
30.	Pin Assignments for 3-Pin Power Connectors	23
31.	Size	24
32.	Cables	24
33.	Air Temperature	24
34.	Humidity	25
35.	Heat Output	25
36.	Electrical	25
37.	5.25-Inch Diskette Drive Reading, Writing, and Formatting Capabilities	28
38.	3.5-Inch Diskette Drive Reading, Writing, and Formatting Capabilities	28
39.	168-Pin Assignments for the System Memory Connector	30
40.	40-Pin Assignments for the EIDE Connectors	33
41.	34-Pin Assignments for the Diskette Drive Connector	34
42.	9-Pin Assignments for the Serial Port Connector	35
43.	25-Pin Assignments for the Parallel Port Connector	35
44.	6-Pin Assignments for the Keyboard Connector	36
45.	6-Pin Assignments for the Mouse Connector	36
46.	4-Pin Assignments for the USB Connector	37
47.	9-Pin Assignments for the Infrared Connector	37
48.	98-Pin Assignments for the ISA Connector	38
49.	124-Pin Assignments for the PCI Connector	40
50.	System Memory Map	42

51.	I/O Address Map	43
52.	DMA I/O Addresses	44
53.	IRQ Channel Assignments	46
54.	DMA Channel Assignments	47
55.	POST Error Codes	48
56.	Beep Codes	50

Figures

1.	System Board	14
2.	System Memory (DIMM) Connector	30
3.	EIDE Connector	33
4.	Diskette Drive Connector	34
5.	Serial Port Connector	35
6.	Parallel Port Connector	35
7.	Keyboard and Mouse Port Connectors	36
8.	USB Connector	37
9.	Infrared Port Connector	37
10.	ISA Connector	38
11.	PCI Connector	40

Preface

This *Technical Information Manual* provides information for the IBM PC 365 (Type 6589). It is intended for developers who want to provide hardware and software products to operate with this IBM computer and provides a more in-depth view of how this computer works. Users of this publication should have an understanding of computer architecture and programming concepts.

Manual Style

Warning: The term *reserved* describes certain signals, bits, and registers that should not be changed. Use of reserved areas can cause compatibility problems, loss of data, or permanent damage to the hardware. When the contents of a register are changed, the state of the reserved bits must be preserved. When possible, read the register first and change only the bits that must be changed.

In this manual, some signals are abbreviated. A minus sign in front of the signal indicates that the signal is active low. No sign in front of the signal indicates that the signal is active high.

The use of the letter “h” indicates a hexadecimal number. Also, when numerical modifiers such as “K”, “M” and “G” are used, they typically indicate powers of 2, not powers of 10. For example, 1 KB equals 1 024 bytes (2^{10}), 1 MB equals 1 048 576 bytes (2^{20}), and 1 GB equals 1 073 741 824 bytes (2^{30}).

When expressing storage capacity, MB equals 1 000 KB (1 024 000). The value is determined by counting the number of sectors and assuming that every two sectors equals 1 KB.

Note: Depending on the operating system and other system requirements, the storage capacity available to the user might vary.

Related Publications

In addition to this manual, the following IBM publications provide information related to the operation of the PC 365. To order publications in the U.S. and Puerto Rico, call 1-800-879-2755. In other countries, contact an IBM reseller or an IBM marketing representative.

- *Using Your Personal Computer*
This publication contains information about configuring, operating, and maintaining the PC 365. Also, information on diagnosing and solving problems, how to get help and service, and warranty issues is included.
- *Installing Options in Your Personal Computer*
This publication contains instructions for installing options in the PC 365.
- *Understanding Your Personal Computer*
This publication includes general information about using computers and detailed information about the features of the PC 365.
- *PC 365 System (Type 6589) Compatibility Report*
This publication contains information about compatible hardware and software for the PC 365. This publication is available at <http://www.pc.ibm.com/cdt>.
- *S3 Trio64V+ SVGA Device Driver Installation Instructions*
This publication contains instructions for installing device drivers for the S3 Trio64V+ SVGA Graphics Adapter installed in some models.
- *Matrox MGA Millennium Graphics Adapter Software Installation Guide*
This publication contains instructions for installing device drivers for the Matrox MGA Millennium Graphics Adapter installed in some models. Also, this publication includes troubleshooting information for related video problems.
- *Adaptec SCSI Support Package*
This documentation, which is provided with models that have an IBM-installed SCSI adapter, includes information on configuring the adapter and instructions for installing and configuring SCSI devices.
- *PC 365 Microprocessor Upgrade Installation Instructions*
This publication contains information about installing a second Pentium Pro microprocessor on the system board.

Chapter 1. System Overview

The IBM PC 365 (Type 6589) is a versatile product designed to provide state-of-the-art computing power with room for future growth. Several model variations are available.

Hardware Features

Standard features in all models:

- Intel Pentium Pro microprocessor with 256 KB of internal L2 cache
- Dual processing support
- Support for up to 512 MB of system memory
- Enhanced IDE (EIDE) interface
- Hard disk drive (EIDE or Fast/Wide SCSI)
- One 3.5-inch, 1.44 MB diskette drive
- One high-speed serial port
- One high-speed parallel port
- One monitor port provided with the graphics adapter
- One universal serial bus port
- One infrared port capable of supporting a 4 Mbps infrared transceiver
- Keyboard and mouse ports
- 104-key keyboard and mouse provided

Standard features that vary by model:

- Graphics adapter - S3 Trio64V+ SVGA Graphics Adapter *or* Matrox MGA Millennium Graphics Adapter
- Riser card - 3 shared ISA/PCI connectors, 2 dedicated ISA connectors *or* 3 shared ISA/PCI connectors, 2 dedicated PCI connectors
- Drive with optical media¹ - CD-ROM drive *or* PD/CD-ROM drive

Standard features in some models only:

- Adaptec AHA-2940 Ultra Wide SCSI Adapter
- Fast/Wide SCSI hard disk drive
- Multimedia port for optional video features (provided with the Matrox MGA Millennium Graphics Adapter)

¹ Some models do not have this IBM-installed feature.

System Software Features

The PC 365 supports a variety of operating systems. Refer to *Using Your Personal Computer* for a listing of supported operating systems

Note: Some models are shipped with a preloaded version of Windows NT Workstation. Also, a Ready-to-Configure (RTC) CD-ROM is included with all models. The RTC CD-ROM has applications and device driver support for Windows NT Workstation, Windows 95, and OS/2 Warp.

System software includes:

- Basic input/output system (BIOS)
- Plug and Play
- Power-on self-test (POST)
- Configuration/Setup Utility program
- Advanced Power Management (APM)
- Flash update utility program
- Diagnostic programs

BIOS

The computer system uses the IBM SurePath BIOS. Enhancements to the BIOS software have been added to provide support for the following features:

- PCI bus, according to *PCI BIOS Specification 2.1*
- PCI bus-master EIDE interface
- Plug and Play, according to *Plug and Play BIOS Specification 1.1*
- Advanced Power Management (APM), according to *APM BIOS Interface Specification 1.2*
- APIC (advanced programmable interrupt controls)
- Multiple microprocessors, according to *Multiprocessor Specification 1.4*
- Matrox video BIOS for the Matrox MGA Millennium Graphics Adapter
- Bootable CD-ROM

Plug and Play

The system conforms to the following:

- *Plug and Play BIOS Specification 1.1*
- *Plug and Play BIOS Specification, Errata and Clarification 1.0*

The system follows the guidelines described in the following:

- *Plug and Play BIOS Extension Design Guide 1.0*
- *Guide to Integrating the Plug and Play BIOS Extensions with System BIOS 1.2*
- *Plug and Play Kit for DOS and Windows*

POST

The computer uses IBM power-on self-test (POST) software. Also, initialization code is included for the Pentium Pro microprocessor, the 82440FX chip set, the I/O chip, and the Matrox MGA Millennium Graphics Adapter.

POST software locates any hardware problems or configuration changes. If an error occurs while POST is running, an error code in the form of a text message displays on the screen. For a description of a POST error code, see "POST Error Codes" on page 48.

Configuration/Setup Utility Program

The Configuration/Setup Utility program provides menus for selecting options for devices, I/O ports, date and time, system security, start options, advanced setup, ISA legacy resources, and power management. More information on using the Configuration/Setup Utility program is provided in *Using Your Personal Computer*.

Advanced Power Management

The PC 365 comes with energy-saving software that meets Energy Star requirements. Advanced Power Management (APM) is a feature that reduces the power consumption when the entire system or components of the computer system are not in use. When enabled, APM initiates reduced-power modes for the monitor, microprocessor, hard disk drive, or the entire system after a specified period of inactivity is reached.²

APM is implemented according to *APM BIOS Interface Specification 1.2*. For more information on APM, see *Using Your Personal Computer* and *Understanding Your Personal Computer*.

Flash Update Utility Program

The flash update utility is a stand-alone program to support flash code updates. This utility program updates the BIOS code in flash and the MRI to different languages. The flash update utility program is available on a 3.5-inch diskette.

Diagnostic Programs

Two diagnostic products are supplied with the PC 365: QAPlus/WIN-WIN, a Windows program, provides the best software coverage; QAPlus/PRO for DOS provides the best hardware coverage. For more information on these diagnostic programs, see *Using Your Personal Computer*.

² APM does not support small computer system interface (SCSI) hard disk drives.

Chapter 2. System Board Features

This section includes information about system board features. To view an illustration of the system board, see “System Board” on page 14.

For a list of features provided with the PC 365, see “Hardware Features” on page 1.

Microprocessor

The primary microprocessor in the PC 365 is the Intel P6, called the Pentium Pro. A voltage regulator circuit on the system board provides the required power for the primary microprocessor. The Pentium Pro microprocessor features:

- Dynamic execution technology
- Multiprocessing support
- Optimization for 32-bit software
- Internal L2 cache
 - 4-way set associative
 - Non-blocking
 - 1 GB/second bandwidth communication with the microprocessor core
- 64-bit data bus
- 36-bit address bus
- Upgradable to future Overdrive microprocessors
- Math coprocessor

Note: Refer to <http://www.intel.com> for more information on the Intel Pentium Pro microprocessor.

The microprocessor plugs directly into a zero-insertion-force (ZIF) socket (socket 8) on the system board. Socket 8 allows for a performance upgrade. After an upgrade is installed, the internal speed of the primary microprocessor is updated by setting switches on the system board (see “Switches” on page 16).

Dual Processing Support

The combined technologies of the system board and the microprocessor provide support for dual processing. The dual processing configuration is known as symmetric multiprocessing (SMP). The PC 365 provides:

- Power-supply margins for dual processing
- Thermal margins for dual processing
- A multiprocessor interrupt controller (for advanced programmable interrupt controls (APIC) on the system board)
- Code for APIC initialization

On the system board, directly beside the primary microprocessor, a second socket 8 is provided for installing a second Pentium Pro microprocessor. Also, sockets are provided for connecting a voltage-regulator module which supplies power to the second microprocessor, and a fan (part of a fan-sink assembly), which helps cool the second microprocessor. To locate these connectors, see “System Board” on page 14.

An upgrade kit for the PC 365 is an available option from IBM. The upgrade kit includes a Pentium Pro microprocessor, a fan-sink assembly, a voltage-regulator module, and instructions for installation.

Chip Set Control

The PC 365 uses the second-generation Intel 82440FX chip set. This chip set provides a bridge between the peripheral component interconnect (PCI) bus and the microprocessor bus. (For information on the PCI bus, see “PCI-to-ISA Bridge” on page 6.) Also, this chip set controls the system memory interface.

The PC 365 also uses the PIIX3 chip. This chip provides a bridge between the PCI and the industry standard architecture (ISA) buses, a bus-master, enhanced integrated drive electronics (EIDE) interface, and a universal serial bus (USB) port.

System Memory

Four dual inline memory module (DIMM) connectors are provided on the system board. The DIMM connectors are powered by + 3.3 volts. Each DIMM connector is a 168-pin, gold-lead socket. For the pin assignments, see “System Memory Connectors” on page 30.

The system board supports:

- A maximum of 512 MB (128 MB modules in all four connectors).
- Dynamic random access memory (DRAM) only.
- 64-bit (EDO) and 72-bit (ECC) wide memory modules.

Any configuration of DIMMs is acceptable. Characteristics *required* by DIMMs include:

- 168-pin, unbuffered +3 V modules only.
- Gold-lead tabs only.
- 60 nanosecond access speeds only.
- Height of no more than 3.81 cm (1.5 in.).
- To enable error-correcting code, all installed memory must be of the ECC type (a combination of ECC and nonparity types is configured as nonparity)

Note: Single inline memory modules (SIMMs) are not supported in the PC 365.

PCI-to-ISA Bridge

The PIIX3 chip provides the bridge between the peripheral component interconnect (PCI) and industry standard architecture (ISA) buses. The chip is used to convert PCI bus cycles to ISA bus cycles.

The PCI bus is compliant with *PCI Local Bus Specification 2.1*. The PCI bus runs synchronously to the host bus and is driven at a frequency of 30 or 33 MHz, depending on the speed of the microprocessor bus (60 MHz or 66 MHz). The ISA bus operates at speeds of 7.5 MHz or 8.33 MHz (one-quarter of the PCI bus speed).

For information on the expansion connectors to the PCI and ISA buses, see “Riser Card” on page 13.

The following table shows the system resources used for the PCI-to-ISA bridge.

System Resource	Assignment
ROM	None
RAM	None
I/O (hex)	00-0F, 20-43, 61, 70, 80-8F, 92, A0-BF, C0-DE, EE-F1, F4-F5
IRQ	NMI, 0, 2
DMA	None

Note: When the computer is started, the resource assignments are subject to change during the power-on self-test (POST).

The chip that provides the PCI-to-ISA bridge also includes all the subsystems of the ISA bus. These ISA-compatible subsystems are:

- Two cascaded 82C59 interrupt controllers
- Two 82C37 DMA controllers with four 8-bit and three 16-bit channels
- Three counters equivalent to a 82C54 programmable interval timer
- Power management features

Bus Master EIDE Interface

The system board incorporates a PCI bus master, enhanced integrated drive electronics (EIDE) interface that complies with *AT Attachment Interface with Extensions*; this allows concurrent operations on the PCI and EIDE buses.

The subsystem that controls internal devices is integrated with the EIDE interface. Up to four IDE devices can be attached to the system board through a ribbon cable that connects to one of two connectors on the system board. The IDE devices receive their power through a four-position power cable containing +5, +12, and ground voltage.

When devices are added to the EIDE interface, one device is designated as the primary, or master, device and another is designated as the secondary, or subordinate, device. These designations are determined by switches or jumpers on each device. A bootable hard disk drive can be installed on either EIDE connector.

Note: An IDE expansion adapter is not supported.

For a list of devices that might be installed in the computer, see “Internal Drives” on page 19.

The following table shows the system resources used by the EIDE interface.

System Resource	Assignment
ROM	None
RAM	None
I/O (hex)	170-177, 1F0-1F7, 376-377, 3F6-3F7
IRQ	14, 15
DMA	None

Note: When the computer is started, the resource assignments are subject to change during the power-on self-test (POST).

Two 40-pin connectors are provided on the system board for the EIDE interface. For information on the pin assignments, see “EIDE Connectors” on page 33.

USB Interface

Universal serial bus (USB) technology is a standard feature of the computer. The system board provides the USB interface with one connector. A USB-enabled device can be attached to the connector, and if that device is a hub, multiple peripheral devices can be attached to the hub and be used by the system. The USB connector uses Plug and Play technology for installed devices. The speed of the USB is up to 12 Mb/second with a maximum of 255 peripheral devices.

The USB is compliant with *Universal Host Controller Interface Design Guide 1.0*. Features provided by USB technology include:

- Support for hot pluggable devices
- Support for concurrent operation of multiple devices
- Suitable for different device bandwidths
- Connections of up to five meters in length from host to hub or hub to hub
- Guaranteed bandwidth and low latencies appropriate for specific devices
- Wide range of packet sizes
- Limited power to hubs

The following table shows the system resources used by the USB interface.

System Resource	Assignment
ROM	None
RAM	None
I/O (hex)	Assigned by POST
IRQ	Assigned by POST
DMA	None

Note: When the computer is started, the resource assignments are subject to change during the power-on self-test (POST).

At the rear of the computer, one 4-pin connector is provided for the USB interface. For information on the pin assignments, see “USB Connector” on page 37.

Input/Output Controller

Control of the integrated input/output (I/O) ports and diskette drive is provided by a single chip, the National Semiconductor PC87308. This chip, which is compatible with *Plug and Play ISA Specification 1.0*, is a controller for the following:

- Diskette drive support
- Serial port
- Parallel port
- Keyboard and mouse ports
- Infrared port
- General-purpose I/O ports
- Real-time clock

Diskette Drive Support

The cable provided with your computer supports a maximum of two diskette drives and one tape backup drive (see “Internal Drives” on page 19 for more information). The following is a list of devices that the diskette drive subsystem will support:

- 1.44 MB, 3.5-inch diskette drive
- 1.2 MB, 5.25-inch diskette drive
- 1 Mbps, 500 Kbps, or 250 Kbps tape drive

Note: A 2.88 MB, 3.5-inch diskette drive is not supported.

One 34-pin, berg-strip connector is provided on the system board for the diskette drive. For information on the connector pin assignments, see “Diskette Drive Connector” on page 34.

Serial Port

Two universal asynchronous receiver/transmitter (UART) serial ports are integrated into the system board. Both ports include a 16-byte data first-in first-out (FIFO) buffer, are 16550A compatible, and have programmable baud-rate generators.

One of the UART serial ports is used in the normal mode. The other serial port is configured as an infrared port (see “Infrared Port” on page 10).

The following table shows the default port assignments for the serial port used in the configuration.

Port Assignment	Address Range	IRQ Level
Serial 1	03F8h–03FFh	IRQ4
Serial 2	02F8h–02FFh	IRQ3
Serial 3	03E8h–03FFh	IRQ4
Serial 4	02E8h–02FFh	IRQ3

Note: When the computer is started, the resource assignments are subject to change during the power-on self-test (POST).

On the system board, one 9-pin, male connector is provided for the serial port. For information on the connector pin assignments, see “Serial Port Connector” on page 35.

Infrared Port

Two UART serial ports are integrated into the system board. One of these ports is configured into an infrared port. When an optional infrared module is attached to the port, the computer is capable of transmitting and receiving wireless communications with other infrared-enabled devices.

The infrared module plugs directly into the infrared port and provides a link of up to one meter. The infrared port uses any of the same four assignments as the serial port. The infrared port is compliant with:

- IrDA-2, including 4 Mbps, 1.2 Mbps, and 1.15 Mbps baud rates
- Sharp-IR
- TV-Remote mode

The system board has one 9-pin connector for the infrared port. For information on the connector pin assignments for the infrared port, see “Infrared Port Connector” on page 37.

Parallel Port

Support for extended capabilities port (ECP), enhanced parallel port (EPP), and standard parallel port (SPP) modes is integrated into the system board. The modes of operation are selected through the Configuration/Setup Utility program with the default mode set to SPP. The ECP and EPP modes are compliant with IEEE 1284.

The following table shows the default port assignments for the parallel port used in configuration.

Port Assignment	Address Range	IRQ Level
Parallel 1	03BCh–03BEh	IRQ7
Parallel 2	0378h–037Fh	IRQ5
Parallel 3	0278h–027Fh	IRQ5

Note: When the computer is started, the resource assignments are subject to change during the power-on self-test (POST).

On the system board, one 25-pin connector is provided for the parallel port. For information on the connector pin assignments, see “Parallel Port Connector” on page 35.

Keyboard and Mouse Ports

The keyboard-and-mouse subsystem is controlled by a general purpose 8-bit microcontroller. The controller consists of 256 bytes of data memory and 2 KB of read-only memory (ROM).

The controller has two logical devices; one controls the keyboard, and the other controls the mouse. The keyboard has two fixed I/O addresses and a fixed IRQ line and can operate without the mouse. The mouse cannot operate without the keyboard because, although it has a fixed IRQ line, the mouse relies on the addresses of the keyboard for operation. The following table shows the resource assignments for the keyboard and mouse.

<i>Table 6. System Resource Assignments for the Keyboard and Mouse</i>	
System Resource	Assignment
ROM	None
RAM	None
I/O (hex)	60, 64
IRQ	1 (keyboard), 12 (mouse)
DMA	None

Note: When the computer is started, the resource assignments are subject to change during the power-on self-test (POST).

The system board has one 6-pin connector for the keyboard port and another 6-pin connector for the mouse port. For information on the connector pin assignments, see “Keyboard and Mouse Port Connectors” on page 36.

General-Purpose I/O Ports

The system board has up to 16 general-purpose input/output (GPIO) pins, which are implemented by two 8-bit GPIO ports. The use of GPIO pins is dependent upon system design. Features of the GPIO ports are:

- Open-drain outputs with internal pull-ups and transistor-transistor logic (TTL) inputs
- Software-configurable base address
- Programmable direction
- 4-byte I/O address

Real-Time Clock

The real-time clock is a low-power clock that provides a time-of-day clock and a calendar. The clock settings are maintained by an external battery source of +3 volts.

The system uses 242 bytes of memory to store complementary metal-oxide semiconductor (CMOS) memory. Moving a jumper (J8) on the system board erases CMOS memory. To locate the battery or J8, see "System Board" on page 14.

The following table shows the system resources used by the real-time clock.

System Resource	Assignment
ROM	None
RAM	None
I/O (hex)	70, 71
IRQ	8
DMA	None

Note: When the computer is started, the resource assignments are subject to change during the power-on self-test (POST).

Riser Card

The system board uses a riser card for expansion. The riser card plugs into the system board, and adapters plug into the ISA-expansion or PCI-expansion connectors on the riser card. Signals from adapters are routed to the ISA or PCI buses. Each ISA-expansion connector provides a 16-bit-wide data path; each PCI-expansion connector provides a 32-bit-wide data path.

Each PCI-expansion connector is capable of driving one low-power Schottky load. Each ISA-expansion connector is capable of driving two low-power Schottky loads. The ISA bus is permanently set to the PCI bus speed divided by four.

The PCI bus shares interrupts with the ISA bus. IRQ 3, 5, 9, 10, or 11 is automatically assigned to PCI adapters during POST. If no interrupts are available for the PCI adapters during POST, an error message is generated.

One of two types of riser cards is used for expansion. Although both types of riser cards have five expansion connectors, the number of dedicated PCI and ISA connectors varies. The following table shows the characteristics of the two types of riser cards.

<i>Table 8. Riser Card Characteristics</i>		
Expansion Connectors	5x5 Riser Card	Enhanced 5x5 Riser Card
Shared ISA/PCI	3	3
Dedicated ISA	2	0
Dedicated PCI	0	2

Note: The enhanced 5x5 riser card has a PCI-to-PCI bridge chip that enables the card to support five PCI slots.

The computer comes standard with adapters plugged into the expansion slots of the riser card. For more information, see Chapter 3, “Adapters and Internal Drives” on page 17.

For information on the connector pin assignments, see “ISA Connectors” on page 38 and “PCI Connector” on page 40.

Physical Layout

The system board might look slightly different from the one shown.

Note: A diagram of the system board, including switch and jumper settings, is attached to the underside of the computer top cover.

System Board




Figure 1. System Board

Connections and the CMOS-Clear Jumper

Connections and jumpers on the system board allow custom configurations. The following tables list the pin descriptions for specific connections and the CMOS-clear jumper. To locate these components, see “System Board” on page 14.

<i>Table 9. J3 - System Power Connection</i>	
Pin	Description
1	Auxiliary (+5 V dc)
2	Power switch input

<i>Table 10. J11, J13 - Wake on Modem Ring Connections</i>	
Pin	Description
1	Ground
2	Wake on Modem/Ring

<i>Table 11. J15 - Wake on LAN Connection</i>	
Pin	Description
1	Ground
2	External Wake on LAN/Ring

<i>Table 12. J8 - CMOS-Clear Jumper</i>	
Pin	Description
1 and 2	Normal
2 and 3	Clear CMOS

Switches

On the system board, a row of switches allows custom configuration of the microprocessor speed and diskette write-protection. Refer to *Installing Options in Your Personal Computer* for information on accessing the switches.

After installing a microprocessor with a different speed, switches 1 through 6 are used for updating the microprocessor speed. The following table shows the different configurations available.

Switch	166 MHz	180 MHz	200 MHz	233 MHz
1	Off	On	On	Off
2	On	Off	Off	Off
3	On	On	On	On
4	On	On	On	On
5	Off	On	Off	Off
6	On	Off	On	On

Note: Switch 7 has no function.

The following table shows the configuration of switch 8 used for diskette write-protection.

Switch	Diskette Write-Enabled	Diskette Write-Protected
8	Off	On

Chapter 3. Adapters and Internal Drives

The PC 365 comes standard with a graphics adapter and, in some models, a SCSI adapter. The graphics adapter provides support for video, and the SCSI adapter provides an interface between the PCI bus and SCSI devices.

Note: The IBM PCMCIA adapter for PCI or an IDE expansion adapter is not supported.

Graphics Adapters

The video subsystem is provided by one of two types of graphics adapters: the S3 Trio64V+ SVGA Graphics Adapter or the Matrox MGA Millennium Graphics Adapter. Each adapter plugs into the riser card and connects to the PCI bus; both adapters are compliant with *PCI Local Bus Specification 2.1*. (For more information on the riser card, see “Riser Card” on page 13.) The graphics adapters support DDC 1.1 and DDC 2B standards.

Also, each adapter provides a 15-pin monitor connector (the Matrox MGA Millennium Graphics Adapter also provides a multimedia connector for attaching optional video features).

Instructions for installing device drivers for each graphics adapter are provided in *S3 Trio64V+ SVGA Device Driver Installation Instructions* and *Matrox MGA Millennium Graphics Adapter Software Installation Guide*.

S3 Trio64V+ SVGA Graphics Adapter

If an S3 Trio64V+ SVGA Graphics Adapter comes standard in the computer, the following major features are provided:

- 2 MB of 60 ns EDO DRAM
- One monitor connector
- Support for all VGA modes
- VESA 1.2 compliance for SVGA modes
- Complete Plug and Play support
- Local peripheral bus interface

The following table shows the system resources used by the S3 Trio64V+ SVGA Graphics Adapter.

System Resource	Assignment (hex)
ROM	C0000-C7FFF (32 KB)
RAM	A0000-BFFFF, (LFBBASE - (LFBBASE + 3FFFFFF)), 64 MB linear frame buffer
I/O (hex)	3B4-3B5, 3BA, 3C0-3CA, 3CC, 3CE-3CF, 3D4-3D5, 3DA, 42E8-42E9, 4AE8-4AE9, 8180-81A3, 81C0-81FF, 82E8-82EB, 86E8-86EB, 8AE8-8AEB, 8EE8-8EEB, 92E8-92EB, 96E8-96EB, 9AE8-9AEB, 9EE8-9EE9, A2E8-A2EB, A6E8-A6EB, AAE8-AAEB, B2E8-B2EB, B6E8-B6E9, BAA38-BAE9, BEE8-BEE9, E2E8-E2EB, EAE8-EAE9, FF00-FF37, FF40-FF5F
IRQ	PCI interrupt #2 (typically assigned to ISA IRQ 9 by POST or can be disabled in the Configuration/Setup Utility program)
DMA	None

Note: When the computer is started, the resource assignments are subject to change during the power-on self-test (POST).

Matrox MGA Millennium Graphics Adapter

If a Matrox MGA Millennium Graphics Adapter comes standard in the computer, the following major features are provided:

- 4 MB of Windows RAM (WRAM), upgradable to 8 MB
- One 15-pin monitor connector
- One multimedia connector for attaching video devices
- Support for all VGA modes
- VESA 2.0 compliance for SVGA modes
- Video POST/BIOS code

The following table shows the system resources used by the Matrox MGA Millennium Graphics Adapter.

System Resource	Assignment (hex)
ROM	C0000-C7FFF (32 KB)
RAM	A0000-BFFFF, (MGABASE1 - (MGABASE1 + 3FFF)), (MGABASE2 - (MGABASE2 + 7FFFF)), 8 MB linear frame buffer
I/O (hex)	3B4-3B5, 3BA, 3C0-3C2, 3C4-3CA, 3CC, 3CE-3CF, 3D4-3D5, 3DA, 3DE-3DF
IRQ	PCI interrupt #2 (typically assigned to ISA IRQ 9 by POST or can be disabled in the Configuration/Setup Utility program)
DMA	None

Note: When the computer is started, the resource assignments are subject to change during the power-on self-test (POST).

SCSI Adapter

Some models come with the Adaptec AHA-2940 Ultra Wide SCSI Adapter. This adapter provides the interface between the PCI bus and SCSI devices. Multiple internal and external drives can be attached to the SCSI adapter. SCSI technology is useful with multitasking operating environments because instructions can be sent concurrently to every drive in the system. The Adaptec AHA-2940 Ultra Wide SCSI Adapter has:

- One external 68-pin, 16-bit connector
- One internal 50-pin, 8-bit connector
- One internal 68-pin, 16-bit connector

Up to a total of fifteen internal and external SCSI devices can be attached to the SCSI adapter, but the number of internal devices installed is dependent upon the number of drive bays available. The PC 365 has five drive bays.

Note: A maximum of three internal SCSI hard disk drives are supported with the standard PD/CD-ROM drive installed. A maximum of four internal hard disk drives are supported when Ultra SCSI hard disk drives are installed.

An extra cable is provided with SCSI models. This cable provides five identical connectors for attaching the SCSI adapter to internal SCSI devices.

For more information on connecting SCSI devices, see the *Adaptec SCSI Support Package*.

Internal Drives

The EIDE, SCSI (in some models only), and diskette interfaces provide connectors for attaching internal drives. The PC 365 comes standard with an EIDE or Fast/Wide SCSI hard disk drive, a diskette drive, and a CD-ROM or a PD/CD-ROM drive.³

Note: The appropriate device drivers are provided for the IBM-installed drives.

The following tables show the characteristics of internal drives that come standard with or are available for the computer.

<i>Table 17. Diskette Drives</i>	
Characteristics	Number/Size
Standard	One 3.5-inch, 1.44 MB
Maximum installed	Three (the cable provided allows for a maximum of two diskette drives)
Optional drives	5.25-inch, 1.2 MB and 3.5-inch, 1.44 MB

<i>Table 18. Hard Disk Drives</i>	
Characteristics	Number/Size
Standard	One EIDE or one Fast/Wide SCSI (size varies by model)
Maximum installed (internal)	Four on the EIDE interface and four on the SCSI interface

Note: Although the maximum number of internal and external drives that can be connected to the SCSI adapter is fifteen, the actual number of internal SCSI devices that can be installed is limited by the number of available drive bays in the computer. Only three internal SCSI hard disk drives are supported when the PD/CD-ROM drive is installed. Also, a maximum of four hard disk drives are supported when Ultra Wide SCSI hard disk drives are installed.

<i>Table 19. Drives with Optical Media</i>	
Characteristics	Number/Size
Standard (some models only)	One CD-ROM or one PD/CD-ROM ⁴ (size varies by model)

Note: The PD/CD-ROM drive is a dual-function drive that can be used as a standard CD-ROM reader or as an optical backup and storage device. When used as a backup and storage device, the PD/CD-ROM drive uses a rewritable optical disk encased in a cartridge.

³ In some models, a CD-ROM or PD/CD-ROM drive is not a standard feature.

⁴ Both the CD-ROM and PD/CD-ROM drives connect to the EIDE interface.

Chapter 4. Power Supply

Power is supplied by a 200-watt power supply that operates at either 115 V ac or 230 V ac. The voltage setting is manually selected with a switch on the rear of the computer. The power supply converts ac input voltages into dc output voltages and provides power for the following components:

- System board
- Keyboard and auxiliary ports
- Riser card (ISA and PCI adapters)
- Internal drives
- Local area network device

Power Input

The following table shows the input power specifications.

Description	Measurements
Input voltage, low range	90 V ac (min) to 137 V ac (max)
Input voltage, high range	180 V ac (min) to 265 V ac (max)
Input frequency	50 Hz \pm 3 Hz or 60 Hz \pm 3 Hz

Power Output

The power supply outputs shown in the following tables include the current supply capability of all the connectors, including system board, internal drives, PCI, and auxiliary outputs.

Output Voltage	Regulation	Minimum to Maximum (amps)
+5 V dc	+5% to -4%	1.5 to 20.0 ⁵
+12 V dc	+5% to -5%	0.2 to 8.0
-12 V dc	+10% to -9%	0.0 to 0.5
-5 V dc	+10% to -10%	0.0 to 0.5
+3.3 V dc	+5% to -4%	0.0 to 20.0 ⁵
+5 V dc (auxiliary)	+5% to -10%	0.0 to .02
+5 V dc (Wake on LAN)	+5% to -10%	0.0 to .70

⁵ Simultaneous loading of +3.3 V dc and +5 V dc must not exceed 120 watts.

Component Outputs

The power supply provides separate voltage sources for the system board and internal storage devices. The following tables show the approximate power that is provided for specific system components. Many components draw less current than the maximum shown.

<i>Table 22. System Board</i>		
Supply Voltage	Maximum Current	Regulation Limits
+3.3 V dc	3000 mA	+5.0% to -4.0%
+5.0 V dc	4000 mA	+5.0% to -4.0%
+12.0 V dc	25.0 mA	+5.0% to -5.0%
-12.0 V dc	25.0 mA	+10.0% to -9.0%

<i>Table 23. Keyboard Port</i>		
Supply Voltage	Maximum Current	Regulation Limits
+5.0 V dc	275 mA	+5.0% to -4.0%

<i>Table 24. Auxiliary Device Port</i>		
Supply Voltage	Maximum Current	Regulation Limits
+5.0 V dc	300 mA	+5.0% to -4.0%

<i>Table 25. ISA-Bus Adapters (Per Slot)</i>		
Supply Voltage	Maximum Current	Regulation Limits
+5.0 V dc	4500 mA	+5.0% to -4.0%
-5.0 V dc	200 mA	+5.0% to -5.0%
+12.0 V dc	1500 mA	+5.0% to -5.0%
-12.0 V dc	300 mA	+10.0% to -9.0%

<i>Table 26. PCI-Bus Adapters (Per Slot)</i>		
Supply Voltage	Maximum Current	Regulation Limits
+5.0 V dc	5000 mA	+5.0% to -4.0%
+3.3 V dc	5000 mA	+5.0% to -4.0%

Note: For each PCI connector, the maximum power consumption is rated at 25 watts for +5 V and +3.3 V combined.

Chapter 4. Power Supply

Supply Voltage	Maximum Current	Regulation Limits
+5.0 V dc	1400 mA	+5.0% to -5.0%
+12.0 V dc	1500 mA	+5.0% to -5.0%

Note: Some adapters and hard disk drives draw more current than the recommended limits. These adapters and drives can be installed in the system; however, the power supply will shut down if the total power used exceeds the maximum power that is available.

Output Protection

The power supply protects against output overcurrent, overvoltage, and short circuits. Please see the power supply specifications for details.

A short circuit that is placed on any dc output (between outputs or between an output and dc return) latches all dc outputs into a shutdown state, with no damage to the power supply.

If this shutdown state occurs, the power supply returns to normal operation only after the fault has been removed and the power switch has been turned off for at least one second.

If an overvoltage fault occurs (in the power supply), the power supply latches all dc outputs into a shutdown state before any output exceeds 130% of the nominal value of the power supply.

Power Connectors

Note: The total power used by the any of following connectors must not exceed the amount shown in “Component Outputs” on page 21.

The power supply provides 4-pin connectors for attaching internal devices. The following table lists the pin assignments for these connectors.

Connector	Location	Pin 1	Pin 2	Pin 3	Pin 4
P3	3.5-inch diskette drive	+5 V	Ground	Ground	+12 V
P4	–	+12 V	Ground	Ground	+5 V
P5	DASD	+12 V	Ground	Ground	+5 V
P6	DASD	+12 V	Ground	Ground	+5 V
P7	DASD	+12 V	Ground	Ground	+5 V
P8	DASD	+12 V	Ground	Ground	+5 V

Connectors with 6 pins are used to connect the power supply to the system board and riser card. The following table lists the pin assignments for these connectors.

Connector	Location	Pin 1	Pin 2	Pin 3	Pin 4	Pin 5	Pin 6
P1	System board	Power Good	+5 V	+12 V	–12 V	Ground	Ground
P2	System board	Ground	Ground	–5 V	+5 V	+5 V	+5 V
P10	Riser 3 V	+3.3 V	+3.3 V	+3.3 V	Ground	Ground	Ground
P11	System board 3 V	+3.3 V	+3.3 V	+3.3 V	Ground	Ground	Ground

Connectors with 3 pins are provided to connect the power supply with the system board and a LAN feature. The following table lists the pin assignments for these connectors.

Connector	Location	Pin 1	Pin 2	Pin 3
P9 ⁶	System board	+5 V	Control	Ground
P12	LAN	+5 V	Control	Ground

⁶ AUX 5

Chapter 5. Physical Specifications

The section lists the physical specifications for the PC 365. The PC 365 has five drive bays for adding internal drives and five expansion slots for adding adapters.

Note: The PC 365 is electromagnetically compatible with FCC Class B.

The following tables list the physical attributes.

<i>Table 31. Size</i>	
Description	Measurement
Width	420 mm (16.5 in.)
Depth	455 mm (17.9 in.)
Height	160 mm (6.3 in.)
Weight, minimum configuration	12.7 kg (28.0 lb)
Weight, maximum configuration	14.1 kg (31.0 lb)

<i>Table 32. Cables</i>	
Description	Measurement
Power cable	1.63 m (5 ft 4 in.)
Keyboard cable	1.83 m (6 ft)
Ribbon cable (IDE interface)	0.51 m (1 ft 8 in.)
SCSI cable (some models only)	0.91 m (3 ft)

<i>Table 33. Air Temperature</i>	
Description	Measurement
System on	10.0 to 32.0°C (50.0 to 89.6°F)
System off	10.0 to 43.0°C (50.0 to 110.0°F)

Note: The maximum altitude at which the specified air temperatures apply is 2133.6 m (7000 ft). At higher altitudes, the maximum air temperatures are lower than those specified.

<i>Table 34. Humidity</i>	
Description	Measurement
System on	8% to 80%
System off	8% to 80%

<i>Table 35. Heat Output</i>	
Description	Measurement
Minimum configuration	35 W (120 Btu per hour)
Maximum configuration	204 W (700 Btu per hour)

<i>Table 36. Electrical</i>	
Description	Measurement
Low range	90 (min) to 137 (max) V ac
Low range nominal	100 to 127 V ac
High range	180 (min) to 265 (max) V ac
High range nominal	200 to 240 V ac
Frequency	50 ± 3 Hz or 60 ± 3 Hz
Input, minimum configuration	0.08 kVA
Input, maximum configuration	0.52 kVA

Chapter 6. System Compatibility

This chapter discusses some of the hardware, software, and BIOS compatibility issues for the computer. Refer to *PC 365 System (Type 6589) Compatibility Report* for a list of compatible hardware and software options.

Hardware Compatibility

This section discusses hardware and BIOS compatibility issues that must be considered when designing application programs.

Many of the interfaces are the same as those used by the IBM Personal Computer AT. In most cases, the command and status organization of these interfaces is maintained.

The functional interfaces are compatible with the following interfaces:

- The Intel 8259 interrupt controllers (edge-triggered mode)
- The National Semiconductor NS16450 and NS16550A serial communication controllers
- The Motorola MC146818 Time of Day Clock command and status (CMOS reorganized)
- The Intel 8254 timer, driven from a 1.193 MHz clock (channels 0, 1, and 2)
- The Intel 8237 DMA controller, except for the Command and Request registers and the Rotate and Mask functions; the Mode register is partially supported
- The Intel 8272 or 82077 diskette drive controllers
- The Intel 8042 keyboard controller at addresses 0060h and 0064h
- All video standards using VGA, EGA, CGA, MDA, and Hercules modes
- The parallel printer ports (Parallel 1, Parallel 2, and Parallel 3) in compatibility mode

Use the following information to develop application programs. Whenever possible, use the BIOS as an interface to hardware to provide maximum compatibility and portability of applications among systems.

Hardware Interrupts

Hardware interrupts are level-sensitive for PCI interrupts and edge-sensitive for ISA interrupts. The interrupt controller clears its in-service register bit when the interrupt routine sends an End of Interrupt (EOI) command to the controller. The EOI command is sent regardless of whether the incoming interrupt request to the controller is active or inactive.

The interrupt-in-progress latch is readable at an I/O-address bit position. This latch is read during the interrupt service routine and might be reset by the read operation, or it might require an explicit reset.

Note: For performance and latency considerations, designers might want to limit the number of devices sharing an interrupt level.

With level-sensitive interrupts, the interrupt controller requires that the interrupt request be inactive at the time the EOI command is sent; otherwise, a new interrupt request will be detected. To avoid this, a level-sensitive interrupt handler must clear the interrupt condition (usually by a read or write operation to an I/O port on the device causing the interrupt). After processing the interrupt, the interrupt handler:

1. Clears the interrupt
2. Waits one I/O delay
3. Sends the EOI
4. Waits one I/O delay
5. Enables the interrupt through the Set Interrupt Enable Flag command

Hardware interrupt IRQ9 is defined as the replacement interrupt level for the cascade level IRQ2. Program interrupt sharing is implemented on IRQ2, interrupt 0Ah. The following processing occurs to maintain compatibility with the IRQ2 used by IBM Personal Computer products:

1. A device drives the interrupt request active on IRQ2 of the channel.
2. This interrupt request is mapped in hardware to IRQ9 input on the second interrupt controller.
3. When the interrupt occurs, the system microprocessor passes control to the IRQ9 (interrupt 71h) interrupt handler.
4. This interrupt handler performs an EOI command to the second interrupt controller and passes control to the IRQ2 (interrupt 0Ah) interrupt handler.
5. This IRQ2 interrupt handler, when handling the interrupt, causes the device to reset the interrupt request before performing an EOI command to the master interrupt controller that finishes servicing the IRQ2 request.

Diskette Drives and Controller

The following tables show the reading, writing, and formatting capabilities of each type of diskette drive.

Diskette Drive Type	250/500 KB Mode	300/500 KB Mode	1 MB Mode
Single sided (48 TPI)	RWF	—	—
Double sided (48 TPI)	RWF	RWF	—
High capacity (1.2 MB)	RWF	RWF	RWF

Diskette Drive Type	720 KB Mode	1.44 MB Mode	2.88 MB Mode
1.44 MB drive	RWF	RWF	Not supported

Notes:

1. Do not use 5.25-inch diskettes that are designed for the 1.2 MB mode in either a 250/500 KB or 300/500 KB diskette drive.
2. Low-density 5.25-inch diskettes that are written to or formatted by a high-capacity 1.2 MB diskette drive can be reliably read only by another 1.2 MB diskette drive.

Copy Protection

The following methods of copy protection might not work in systems using the 3.5-inch, 1.44 MB diskette drive.

- Bypassing BIOS routines:
 - Data transfer rate: BIOS selects the proper data transfer rate for the media being used.
 - Diskette parameter table: Copy protection, which creates its own diskette parameter table, might not work in these drives.
- Diskette drive controls:
 - Rotational speed: The time between two events in a diskette drive is a function of the controller.
 - Access time: Diskette BIOS routines must set the track-to-track access time for the different types of media that are used in the drives.
 - 'Diskette change' signal: Copy protection might not be able to reset this signal.
- Write-current control: Copy protection that uses write-current control does not work, because the controller selects the proper write current for the media that is being used.

Hard Disk Drives and Controller

Reading from and writing to the hard disk is initiated in the same way as in IBM Personal Computer products; however, new functions are supported.

Software Compatibility

To maintain software compatibility, the interrupt polling mechanism that is used by IBM Personal Computer products is retained. Software that interfaces with the reset port for the IBM Personal Computer positive-edge interrupt sharing (hex address 02Fx or 06Fx, where x is the interrupt level) does not create interference.

Software Interrupts

With the advent of software interrupt sharing, software interrupt routines must daisy-chain interrupts. Each routine must check the function value, and if it is not in the range of function calls for that routine, it must transfer control to the next routine in the chain. Because software interrupts are initially pointed to address 0:0 before daisy chaining, check for this case. If the next routine is pointed to address 0:0 and the function call is out of range, the appropriate action is to set the carry flag and do a RET 2 to indicate an error condition.

Machine-Sensitive Programs

Programs can select machine-specific features, but they must first identify the machine and model type. IBM has defined methods for uniquely determining the specific machine type. The machine model byte can be found through Interrupt 15H, Return System Configuration Parameters function ((AH)=C0H).

Appendix A. Connector Pin Assignments

The following tables show the pin assignments for various system board connectors.

System Memory Connectors




Figure 2. System Memory (DIMM) Connector

Note: Each system memory connector is a 168-pin, gold-lead socket.

Table 39 (Page 1 of 3). 168-Pin Assignments for the System Memory Connector

Pin	Signal Name	I/O	Pin	Signal Name	I/O
1	Ground	NA	85	Ground	NA
2	MD0	I/O	86	MD32	I/O
3	MD1	I/O	87	MD33	I/O
4	MD2	I/O	88	MD34	I/O
5	MD3	I/O	89	MD35	I/O
6	VDD	I/O	90	VDD	NA
7	MD4	I/O	91	MD36	NA
8	MD5	I/O	92	MD37	I/O
9	MD6	I/O	93	MD38	I/O
10	MD7	I/O	94	MD39	I/O
11	MD8	I/O	95	MD40	I/O
12	GND	NA	96	Ground	NA
13	MD9	I/O	97	MD41	I/O
14	MD10	I/O	98	MD42	I/O
15	MD11	O	99	MD43	I/O
16	MD12	O	100	MD44	I/O
17	MD13	O	101	MD45	I/O
18	VDD	O	102	VDD	NA
19	MD14	O	103	MD46	I/O
20	No connect/CB0	I/O	104	MD47	I/O
21	No connect/CB1	I/O	105	No connect/CB4	I/O
22	PAR2	I/O	106	No connect/CB5	I/O
23	Ground	I/O	107	Ground	NA
24	No connect	NA	108	No connect	NA
25	No connect	NA	109	No connect	NA
26	VDD	O	110	VDD	NA
27	WE0	O	111	DU	NA
28	CAS0	O	112	CAS4	O

Table 39 (Page 2 of 3). 168-Pin Assignments for the System Memory Connector

Pin	Signal Name	I/O	Pin	Signal Name	I/O
29	CAS1	O	113	CAS5	O
30	RAS0	O	114	RAS1	O
31	OE0	O	115	DU	NA
32	Ground	O	116	Ground	NA
33	A0	O	117	A1	O
34	A2	O	118	A3	O
35	A4	O	119	A5	O
36	A6	O	120	A7	O
37	A8	O	121	A9	O
38	A10	O	122	A11	O
39	A12	O	123	A13	O
40	VDD	NA	124	VDD	NA
41	No connect	NA	125	DU	NA
42	No connect (DU)	NA	126	DU	NA
43	Ground	NA	127	Ground	NA
44	OE2	O	128	DU	NA
45	RAS2	O	129	RAS3	O
46	CAS2	O	130	CAS6	O
47	CAS3	O	131	CAS7	O
48	WE2	O	132	DU	NA
49	VDD	O	133	VDD	NA
50	No connect	NA	134	No connect	NA
51	No connect	NA	135	No connect	NA
52	No connect/CB2	I/O	136	No connect/CB6	I/O
53	No connect/CB3	I/O	137	No connect/CB7	I/O
54	Ground	NA	138	Ground	NA
55	MD16	I/O	139	MD48	I/O
56	MD17	I/O	140	MD49	I/O
57	MD18	I/O	141	MD50	I/O
58	MD19	I/O	142	MD51	I/O
59	VDD	NA	143	VDD	NA
60	MD20	I/O	144	MD52	I/O
61	No connect	NA	145	No connect	NA
62	DU	NA	146	DU	NA
63	No connect	NA	147	No connect	NA
64	Ground	NA	148	Ground	NA
65	MD21	I/O	149	MD53	I/O
66	MD22	I/O	150	MD54	I/O
67	MD23	I/O	151	MD55	I/O
68	Ground	NA	152	Ground	NA
69	MD24	I/O	153	MD56	I/O
70	MD25	I/O	154	MD57	I/O
71	MD26	I/O	155	MD58	I/O

Appendix A. Connector Pin Assignments

Table 39 (Page 3 of 3). 168-Pin Assignments for the System Memory Connector

Pin	Signal Name	I/O	Pin	Signal Name	I/O
72	MD27	I/O	156	MD59	I/O
73	VDD	NA	157	VDD	NA
74	MD28	I/O	158	MD60	I/O
75	MD29	I/O	159	MD61	I/O
76	MD30	I/O	160	MD62	I/O
77	MD31	I/O	161	MD63	I/O
78	Ground	NA	162	Ground	NA
79	No connect	I/O	163	No connect	NA
80	No connect	I/O	164	No connect	NA
81	No connect	I/O	165	SA0	I/O
82	SDA	I/O	166	SA1	I/O
83	SCL	I/O	167	SA2	I/O
84	VDD	NA	168	VDD	I/O

EIDE Connectors




Figure 3. EIDE Connector

Note: Each EIDE connector is a 40-pin, shrouded berg strip.

Pin	Signal Name	I/O	Pin	Signal Name	I/O
1	Reset	O	2	Ground	NA
3	D7	I/O	4	D8	I/O
5	D6	I/O	6	D9	I/O
7	D5	I/O	8	D10	I/O
9	D4	I/O	10	D11	I/O
11	D3	I/O	12	D12	I/O
13	D2	I/O	14	D13	I/O
15	D1	I/O	16	D14	I/O
17	D0	I/O	18	D15	I/O
19	Ground	NA	20	Key connector	NA
21	No connect	NA	22	Ground	NA
23	IOW#	O	24	No connect	NA
25	IOR#	O	26	Ground	NA
27	IOCHRDY	I	28	ALE	O
29	No connect	NA	30	Ground	NA
31	IRQ	I	32	CS16#	I
33	SA1	O	34	PDIAG	I
35	SA0	O	36	SA2	O
37	CS0#	O	38	CS1	O
39	Active#	I	40	Ground	NA

Diskette Drive Connector




Figure 4. Diskette Drive Connector

Note: The connector for the diskette drive is a 34-pin, berg strip.

Table 41. 34-Pin Assignments for the Diskette Drive Connector

Pin	Signal Name	I/O	Pin	Signal Name	I/O
1	Reserved	I	2	High density select	O
3	Not connected	NA	4	Not connected	NA
5	Ground	NA	6	Data rate 0	NA
7	Ground	NA	8	Index#	I
9	Reserved	NA	10	Motor enable 0	O
11	Ground	NA	12	Drive select 1	O
13	Ground	NA	14	Drive select 0	O
15	Ground	NA	16	Motor enable 1	O
17	MSEN1	I	18	Direction in#	O
19	Ground	NA	20	Step#	O
21	Ground	NA	22	Write data#	O
23	Ground	NA	24	Write enable#	O
25	Ground	NA	26	Track0#	I
27	MSEN0	I	28	Write protect#	I
29	Ground	NA	30	Read data#	I
31	Ground	NA	32	Head 1 select#	O
33	Data rate 1	NA	34	Diskette change#	I

Serial Port Connector




Figure 5. Serial Port Connector

Note: The external interface for the serial port is a male, 9-pin D-shell connector.

Table 42. 9-Pin Assignments for the Serial Port Connector

Pin	Signal Name	I/O	Pin	Signal Name	I/O
1	Data carrier detect	I	2	Receive data#	I
3	Transmit data#	O	4	Data terminal read	O
5	Ground	NA	6	Data set ready	I
7	Request to send	O	8	Clear to send	I
9	Ring indicator	I			

Parallel Port Connector




Figure 6. Parallel Port Connector

Note: The external interface for the parallel port is a female, 25-pin D-shell connector.

Table 43. 25-Pin Assignments for the Parallel Port Connector

Pin	Signal Name	I/O	Pin	Signal Name	I/O
1	STROBE#	I/O	2	D0	I/O
3	D1	I/O	4	D2	I/O
5	D3	I/O	6	D4	I/O
7	D5	I/O	8	D6	I/O
9	D7	I/O	10	ACK#	I
11	BUSY	I	12	PE	I
13	SLCT	I	14	AUTO FD XT#	O
15	ERROR#	I	16	INIT#	O
17	SLCT IN#	O	18	Ground	NA
19	Ground	NA	20	Ground	NA
21	Ground	NA	22	Ground	NA
23	Ground	NA	24	Ground	NA
25	Ground	NA			

Keyboard and Mouse Port Connectors




Figure 7. Keyboard and Mouse Port Connectors

Note: The external interface for the keyboard and mouse ports are 6-pin, mini-DIN connectors.

Table 44. 6-Pin Assignments for the Keyboard Connector

Pin	Signal Name	I/O	Pin	Signal Name	I/O
1	Data	I/O	2	Aux data	I/O
3	Ground	NA	4	+5 V dc	NA
5	Clock	I/O	6	Aux clock	I/O

Table 45. 6-Pin Assignments for the Mouse Connector

Pin	Signal Name	I/O	Pin	Signal Name	I/O
1	Data	I/O	2	Reserved	NA
3	Ground	NA	4	+5 V dc	NA
5	Clock	I/O	6	Reserved	NA

USB Connector




Figure 8. USB Connector

Pin	Signal Name
1	VCC
2	-Data
3	+Data
4	Ground

Infrared Port Connector




Figure 9. Infrared Port Connector

Note: The external interface for the infrared port is a female, 9-pin D-shell connector.

Pin	Signal Name	Pin	Signal Name
1	IR transmitted data (output)	2	Ground
3	Reserved	4	IR module select 2
5	IR module select 1	6	IR received data (input)
7	Voltage (+5 V dc)	8	IR module select 0
9	No connect		

ISA Connectors




Figure 10. ISA Connector

Note: The ISA connectors are part of the riser card.

Table 48 (Page 1 of 2). 98-Pin Assignments for the ISA Connector

Pin	Signal Name	I/O	Pin	Signal Name	I/O
B1	Ground	NA	A1	IOCHCK#	I
B2	RESET DRV	O	A2	SD7	I/O
B3	+5 V dc	NA	A3	SD6	I/O
B4	IRQ2	I	A4	SD5	I/O
B5	-5 V dc	NA	A5	SD4	I/O
B6	DRQ2	I	A6	SD3	I/O
B7	-12 V dc	NA	A7	SD2	I/O
B8	OWS#	I	A8	SD1	I/O
B9	+12 V dc	NA	A9	SD0	I/O
B10	Ground	NA	A10	IOCHRDY	I
B11	SMEMW#	O	A11	AEN	O
B12	SMEMR#	O	A12	SA19	I/O
B13	IOW#	I/O	A13	SA18	I/O
B14	IOR#	I/O	A14	SA17	I/O
B15	DACK3#	O	A15	SA16	I/O
B16	DRQ3	I	A16	SA15	I/O
B17	DACK1#	O	A17	SA14	I/O
B18	DRQ1	I	A18	SA13	I/O
B19	REFRESH#	I/O	A19	SA12	I/O
B20	CLK	O	A20	SA11	I/O
B21	IRQ7	I	A21	SA10	I/O
B22	IRQ6	I	A22	SA9	I/O
B23	IRQ5	I	A23	SA8	I/O
B24	IRQ4	I	A24	SA7	I/O
B25	IRQ3	I	A25	SA6	I/O
B26	DACK2#	O	A26	SA5	I/O
B27	TC	O	A27	SA4	I/O
B28	BALE	O	A28	SA3	I/O
B29	+5 V dc	NA	A29	SA2	I/O
B30	OSC	O	A30	SA1	I/O
B31	Ground	NA	A31	SA0	I/O
D1	MEMCS16#	I	C1	SBHE#	I/O

Appendix A. Connector Pin Assignments

Table 48 (Page 2 of 2). 98-Pin Assignments for the ISA Connector

Pin	Signal Name	I/O	Pin	Signal Name	I/O
D2	IOCS16#	I	C2	LA23	I/O
D3	IRQ10	I	C3	LA22	I/O
D4	IRQ11	I	C4	LA21	I/O
D5	IRQ12	I	C5	LA20	I/O
D6	IRQ15	I	C6	LA19	I/O
D7	IRQ14	I	C7	LA18	I/O
D8	DACK0#	O	C8	LA17	I/O
D9	DRQ0	I	C9	MEMR#	I/O
D10	DACK5#	O	C10	MEMW#	I/O
D11	DRQ5	I	C11	SD8	I/O
D12	DACK6#	O	C12	SD9	I/O
D13	DRQ6	I	C13	SD10	I/O
D14	DACK7#	O	C14	SD11	I/O
D15	DRQ7	I	C15	SD12	I/O
D16	+5 V dc	NA	C16	SD13	I/O
D17	MASTER#	I	C17	SD14	I/O
D18	Ground	NA	C18	SD15	I/O

PCI Connector




Figure 11. PCI Connector

Note: The PCI connectors are part of the riser card.

Table 49 (Page 1 of 2). 124-Pin Assignments for the PCI Connector

Pin	Signal Name	I/O	Pin	Signal Name	I/O
A1	TRST#	O	B1	-12 V dc	NA
A2	+12 V dc dc	NA	B2	TCK	O
A3	TMS	O	B3	Ground	NA
A4	TDI	O	B4	TDO	I
A5	+5 V dc	NA	B5	+5 V dc	NA
A6	INTA#	I	B6	+5 V dc	NA
A7	INTC#	I	B7	INTB#	I
A8	+5 V dc	NA	B8	INTD#	I
A9	Reserved	NA	B9	PRSNT1#	I
A10	+5 V dc (I/O)	NA	B10	Reserved	NA
A11	Reserved	NA	B11	PRSNT2	I
A12	Ground	NA	B12	Ground	NA
A13	Ground	NA	B13	Ground	NA
A14	Reserved	NA	B14	Reserved	NA
A15	RST#	O	B15	Ground	NA
A16	+5 V dc (I/O)	NA	B16	CLK	O
A17	GNT#	O	B17	Ground	NA
A18	Ground	NA	B18	REQ#	I
A19	Reserved	NA	B19	+5 V dc (I/O)	NA
A20	Address/Data 30	I/O	B20	Address/Data 31	I/O
A21	+3.3 V dc	NA	B21	Address/Data 29	I/O
A22	Address/Data 28	I/O	B22	Ground	NA
A23	Address/Data 26	I/O	B23	Address/Data 27	I/O
A24	Ground	NA	B24	Address/Data 25	I/O
A25	Address/Data 24	I/O	B25	+3.3 V dc	NA
A26	IDSEL	O	B26	C/BE 3#	I/O
A27	+3.3 V dc	NA	B27	Address/Data 23	I/O
A28	Address/Data 22	I/O	B28	Ground	NA
A29	Address/Data 20	I/O	B29	Address/Data 21	I/O
A30	Ground	NA	B30	Address/Data 19	I/O
A31	Address/Data 18	I/O	B31	+3.3 V dc	NA
A32	Address/Data 16	I/O	B32	Address/Data 17	I/O
A33	+3.3 V dc	NA	B33	C/BE 2#	I/O

Table 49 (Page 2 of 2). 124-Pin Assignments for the PCI Connector

Pin	Signal Name	I/O	Pin	Signal Name	I/O
A34	FRAME#	I/O	B34	Ground	NA
A35	Ground	NA	B35	IRDY#	I/O
A36	TRDY#	I/O	B36	+3.3 V dc	NA
A37	Ground	NA	B37	DEVSEL#	I/O
A38	STOP#	I/O	B38	Ground	NA
A39	+3.3 V dc	NA	B39	LOCK#	I/O
A40	SDONE	I/O	B40	PERR#	I/O
A41	SBO#	I/O	B41	+3.3 V dc	NA
A42	Ground	NA	B42	SERR#	I/O
A43	+3.3 V dc	NA	B43	+3.3 V dc	NA
A44	C/BE(1)#	I/O	B44	C/BE 1#	I/O
A45	Address/Data 14	I/O	B45	Address/Data 14	I/O
A46	Ground	NA	B46	Ground	NA
A47	Address/Data 12	I/O	B47	Address/Data 12	I/O
A48	Address/Data 10	I/O	B48	Address/Data 10	I/O
A49	Ground	NA	B49	Ground	NA
A50	Key	NA	B50	Key	NA
A51	Key	NA	B51	Key	NA
A52	Address/Data 8	I/O	B52	Address/Data 8	I/O
A53	Address/Data 7	I/O	B53	Address/Data 7	I/O
A54	+3.3 V dc	NA	B54	+3.3 V dc	NA
A55	Address/Data 5	I/O	B55	Address/Data 5	I/O
A56	Address/Data 3	I/O	B56	Address/Data 3	I/O
A57	Ground	NA	B57	Ground	NA
A58	Address/Data 1	I/O	B58	Address/Data 1	I/O
A59	+5 V dc (I/O)	NA	B59	+5 V dc (I/O)	NA
A60	ACK64#	I/O	B60	ACK64#	I/O
A61	+5 V dc	NA	B61	+5 V dc	NA
A62	+5 V dc	NA	B62	+5 V dc	NA

Appendix B. System Address Maps

System Memory Map

Memory can be mapped differently if POST detects an error.

<i>Table 50. System Memory Map</i>		
Address Range (hex)	Size	Description
00000000–0007FFFF	512 KB	DOS applications
	640 KB	Memory gap
	768 KB	Video buffer
	1 MB	Expansion and BIOS region
	15 MB	Cacheable
	16 MB	Optional memory space gap
	512 MB	Always cacheable
FEC00000–FEC01000	4 KB	I/O APIC default
FEE00000–FE010000	4 KB	APIC default
FFF80000–FFDF000	384 KB	Extended BIOS
FFFE0000–FFFFFFF	128 KB	BIOS memory shadowed

Input/Output Address Map

The following table lists resource assignments for the I/O address map. Any addresses that are not shown are reserved.

Address (Hex)	Device
0000–000F	DMA 1
0020–0021	Interrupt controller 1
0040–0043	Timer 1
0048–004B	Timer 2
0060	Keyboard controller data byte
0061	NMI, speaker control
0064	Keyboard controller command/status byte
0070, bit 7	Enable NMI
0070, bits 6:0	Real-time clock, address
0071	Real-time clock, data
0078	Reserved (system board configuration)
007C	Reserved (system board configuration)
0080–008F	DMA page register
00A0–00A1	Interrupt controller 2
00C0–00DE	DMA 2
00F0	Reset numeric error
0170–0177	Secondary IDE channel
01F0–01F7	Primary IDE channel
0278–027B	Parallel port 2
02F8–02FF	Onboard serial port 2
0376	Secondary IDE channel command port
0377	Secondary IDE channel status port
0378–037F	Parallel port 1
03BC–03BF	Parallel port x
03E8–03EF	Serial port 3
03F0–03F5	Diskette channel 1
03F6	Primary IDE channel command port
03F7 (Write)	Diskette channel 1 command
03F7, bit 7	Diskette change channel 1
03F7, bits 6:0	Primary IDE channel status port
03F8–03FF	Onboard serial port 1
LPT + 400h	ECP port, LPT + 400h
0CF8–0CFB	PCI configuration address register
0CFC–0CFF	PCI configuration data register
FF00–FF07	IDE bus master register

Appendix B. System Address Maps

DMA I/O Address Map

The following table lists resource assignments for the DMA address map. Any addresses that are not shown are reserved.

Table 52 (Page 1 of 2). DMA I/O Addresses

Address (Hex)	Description	Bits	Byte Pointer
0000	Channel 0, Memory Address register	00–15	Yes
0001	Channel 0, Transfer Count register	00–15	Yes
0002	Channel 1, Memory Address register	00–15	Yes
0003	Channel 1, Transfer Count register	00–15	Yes
0004	Channel 2, Memory Address register	00–15	Yes
0005	Channel 2, Transfer Count register	00–15	Yes
0006	Channel 3, Memory Address register	00–15	Yes
0007	Channel 3, Transfer Count register	00–15	Yes
0008	Channels 0–3, Read Status/Write Command register	00–07	
0009	Channels 0–3, Write Request register	00–02	
000A	Channels 0–3, Write Single Mask register bits	00–02	
000B	Channels 0–3, Mode register (write)	00–07	
000C	Channels 0–3, Clear byte pointer (write)	NA	
000D	Channels 0–3, Master clear (write)/temp (read)	00–07	
000E	Channels 0–3, Clear Mask register (write)	00–03	
000F	Channels 0–3, Write All Mask register bits	00–03	
0081	Channel 2, Page Table Address register ⁷	00–07	
0082	Channel 3, Page Table Address register ⁷	00–07	
0083	Channel 1, Page Table Address register ⁷	00–07	
0087	Channel 0, Page Table Address register ⁷	00–07	
0089	Channel 6, Page Table Address register ⁷	00–07	
008A	Channel 7, Page Table Address register ⁷	00–07	
008B	Channel 5, Page Table Address register ⁷	00–07	
008F	Channel 4, Page Table Address/Refresh register	00–07	
00C0	Channel 4, Memory Address register	00–15	Yes
00C2	Channel 4, Transfer Count register	00–15	Yes
00C4	Channel 5, Memory Address register	00–15	Yes
00C6	Channel 5, Transfer Count register	00–15	Yes
00C8	Channel 6, Memory Address register	00–15	Yes
00CA	Channel 6, Transfer Count register	00–15	Yes
00CC	Channel 7, Memory Address register	00–15	Yes
00CE	Channel 7, Transfer Count register	00–15	Yes
00D0	Channels 4–7, Read Status/Write Command register	00–07	
00D2	Channels 4–7, Write Request register	00–02	
00D4	Channels 4–7, Write Single Mask register bit	00–02	
00D6	Channels 4–7, Mode register (write)	00–07	
00D8	Channels 4–7, Clear byte pointer (write)	NA	
00DA	Channels 4–7, Master clear (write)/temp (read)	00–07	

Table 52 (Page 2 of 2). DMA I/O Addresses

Address (Hex)	Description	Bits	Byte Pointer
00DC	Channels 4–7, Clear Mask register (write)	00–03	
00DE	Channels 4–7, Write All Mask register bits	00–03	
00DF	Channels 5–7, 8- or 16-bit mode select	00–07	

⁷ Upper byte of memory address register.

Appendix C. IRQ and DMA Channel Assignments

The following tables list the interrupt request (IRQ) and direct memory access (DMA) channel assignments.

IRQ	System Resource
NMI	Critical system error
SMI	System/power management interrupt
0	Reserved (internal timer)
1	Reserved (keyboard)
2	Reserved (interrupt controller) timer in APIC mode ⁹
3 ⁸	Infrared
4 ⁸	Serial port
5	Available
6	Diskette
7 ⁸	Parallel port
8	Real-time clock
9	Available
10	Available
11	Available
12 ⁸	Mouse
13	Coprocessor
14	IDE drives (0, 1) if installed
15	IDE drives (2, 3) if installed

⁸ Can be modified to alternate settings or disabled.

⁹ With dual processing, the advanced programmable interrupt controller (APIC) manages hardware interrupts to the system BIOS. The following interrupts are available only in the dual-processing APIC mode.

IRQ	System Resource
16	PCI device
17	PCI device
18	PCI device
19	PCI device
20	Not available
21	Not available
22	Not available
23	Not available
24	SMI

Table 54. DMA Channel Assignments

DMA Channel	Data Width	System Resource
0	Available	8 bits
1	Infrared ¹⁰	8 bit
2	Reserved (diskette drive)	8 bits
3	Parallel port ¹⁰	8 bits
4	Available	–
5	Available	16 bits
6	Available	16 bits
7	Available	16 bits

¹⁰ Can be modified to alternative settings or disabled.

Appendix D. Error Codes

The following tables list the POST error codes and beep error codes for the computer.

POST Error Codes

POST error messages appear when POST finds problems with the hardware during power-on or when a change in the hardware configuration is found. POST error messages are 3-, 4-, 5-, 8-, or 12-character alphanumeric messages. An x in an error message can represent any number.

<i>Table 55 (Page 1 of 2). POST Error Codes</i>	
Code	Description
101	Interrupt failure
102	Timer failure
103	Timer-interrupt failure
104	Protected mode failure
105	Last 8042 command not accepted – keyboard failure
106	System board failure
108	Timer bus failure
109	Low MB chip select test
110	System board parity error 1 (system board parity latch set)
111	I/O parity error 2 (I/O channel check latch set)
112	I/O channel check error
113	I/O channel check error
114	External ROM checksum error
115	DMA error
116	System board port read/write error
120	Microprocessor test error
121	Hardware error
151	Real time clock failure
161	Bad CMOS Battery
162	CMOS RAM checksum/configuration error
163	Clock not updating
164	CMOS RAM memory size does not match
167	Clock not updating
175	Riser card or system board error
176	System cover has been removed
177	Corrupted administrator password
178	Riser card or system board error
183	Administrator password has been set and must be entered
184	Password removed due to checksum error
185	Corrupted boot sequence
186	System board or hardware security error
189	More than three password attempts were made to access system
201	Memory data error

<i>Table 55 (Page 2 of 2). POST Error Codes</i>	
Code	Description
202	Memory address line error 00-15
203	Memory address line error 16-23
221	ROM to RAM remapping error
225	Unsupported memory type installed or memory pair mismatch
301	Keyboard error
302	Keyboard error
303	Keyboard to system board interface error
304	Keyboard clock high
305	No keyboard +5 V dc
601	Diskette drive or controller error
602	Diskette IPL boot record not valid
604	Unsupported diskette drive installed
605	POST cannot unlock diskette drive
662	Diskette drive configuration error
762	Math coprocessor configuration error
11xx	Serial port error (xx = serial port number)
1762	Hard disk configuration error
1780	Hard disk 0 failed
1781	Hard disk 1 failed
1782	Hard disk 2 failed
1783	Hard disk 3 failed
1800	PCI adapter has requested an unavailable hardware interrupt
1801	PCI adapter has requested an unavailable memory resource
1802	PCI adapter has requested an unavailable I/O address space, or a defective adapter
1803	PCI adapter has requested an unavailable memory address space, or a defective adapter
1804	PCI adapter has requested unavailable memory addresses
1805	PCI adapter ROM error
1962	Boot sequence error
2401	System board video error
8601	System board - keyboard/pointing device error
8602	Pointing device error
8603	Pointing device or system board error
12092	Level 1 cache error (Processor chip)
12094	Level 2 cache error
I9990301	Hard disk failure
I9990305	No operating system found

Beep Codes

For the following beep codes, the numbers indicate the sequence and number of beeps. For example, a “2-3-2” error symptom (a burst of two beeps, three beeps, then two beeps) indicates a memory module problem. An x in an error message can represent any number.

<i>Table 56. Beep Codes</i>	
Beep Code	Probable Cause
1-1-3	CMOS write/read failure
1-1-4	BIOS ROM checksum failure
1-2-1	Programmable interval timer test failure
1-2-2	DMA initialization failure
1-2-3	DMA page register write/read test failure
1-2-4	RAM refresh verification failure
1-3-1	1st 64 K RAM test failure
1-3-2	1st 64 K RAM parity test failure
2-1-1	Slave DMA register test in progress or failure
2-1-2	Master DMA register test in progress or failure
2-1-3	Master interrupt mask register test failure
2-1-4	Slave interrupt mask register test failure
2-2-2	Keyboard controller test failure
2-3-2	Screen memory test in progress or failure
2-3-3	Screen retrace tests in progress or failure
3-1-1	Timer tick interrupt test failure
3-1-2	Interval timer channel 2 test failure
3-1-4	Time-of-Day clock test failure
3-2-4	Comparing CMOS memory size against actual
3-3-1	Memory size mismatch occurred

Appendix E. Notices and Trademarks

References in this publication to IBM products, programs, or services do not imply that IBM intends to make these available in all countries in which IBM operates. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Subject to IBM's valid intellectual property or other legally protectable rights, any functionally equivalent product, program, or service may be used instead of the IBM product, program, or service. The evaluation and verification of operation in conjunction with other products, except those expressly designated by IBM, are the responsibility of the user.

IBM may have patents or pending patent applications covering subject matter in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to:

IBM Director of Licensing
 IBM Corporation
 500 Columbus Avenue
 Thornwood, NY 10594
 U.S.A.

The following terms are trademarks of the IBM Corporation in the United States or other countries or both:

AT	IBM	OS/2
Personal Computer AT	SurePath	Wake on LAN

The following terms are trademarks of other companies:

Adaptec	Adaptec, Inc.
AHA	Adaptec, Inc.
Hercules	Hercules Computer Technology
Matrox	Matrox Electronic Systems, Ltd.
MGA Millennium	Matrox Graphics, Inc.
Motorola	Motorola, Inc.
National Semiconductor	National Semiconductor Corporation
PCMCIA	Personal Computer Memory Card International Association
QAPIus/PRO	DiagSoft, Inc.
QAPIus/WIN	Diagsoft, Inc.
S3	S3 Incorporated
Sharp	Sharp Corporation
VESA	Video Electronics Standards Association

Intel and Pentium are trademarks or registered trademarks of Intel Corporation.

Microsoft, Windows, and Windows NT are trademarks or registered trademarks of Microsoft Corporation.

Other company, product, and service names may be trademarks or service marks of others.

References

General Sources

Advanced Power Management (APM) BIOS Interface Specification 1.2

Source: Intel Corporation

AT Attachment Interface with Extensions

Source: American National Standard of Accredited Standards Committee

Extended Capabilities Port: Specification Kit

Source: Microsoft Corporation

Intel Microprocessor and Peripheral Component Literature

Source: Intel Corporation

PCI BIOS Specification 2.1

Source: PCI Special Interest Group

PCI Local Bus Specification 2.1

Source: PCI Special Interest Group

Plug and Play BIOS Specification, Errata and Clarifications

Source: Microsoft Corporation

World Wide Web Sources

82441FX PCI and Memory Controller (PMC)

Source: Intel Corporation; available at <http://www.intel.com/design/pcisets/datashts>

82371SB PCI ISA IDE Xcelerator (PIIX3)

Source: Intel Corporation; available at <http://www.intel.com/design/pcisets/datashts>

Plug and Play BIOS Specification 1.1

Source: Microsoft Corporation; available at <http://www.microsoft.com/hwdev>

S3 Trio64V+ SVGA Graphics Adapter

Source: S3 Incorporated; available at <http://www.s3.com/products>

Universal Serial Bus Specifications

Source: <http://www.teleport.com/~usb>

Video Electronics Standards Association 1.2

Source: <http://www.vesa.org>

Index

A

adapters
 graphics 17
 SCSI 18
 address map
 DMA 44
 I/O 43
 system memory 42
 advanced power management 3
 altitude 24
 APM 3

B

beep codes 50
 BIOS 2
 BIOS data areas 42
 bus
 EIDE 7
 ISA 6, 13
 PCI 6, 13
 universal serial bus 8
 bypassing BIOS 28

C

cables 24
 chip sets
 control 5
 PCI 5
 clock, real-time 12
 CMOS RAM 12
 CMOS-clear jumper
 configuration 12, 15
 location 14
 compatibility
 hardware 26
 software 29
 component maximum current 21
 configuration/setup utility program 3
 connections 14, 15
 connector
 DIMM 30
 diskette drive 34
 EIDE 33
 infrared port 37
 ISA 38
 keyboard/mouse ports 36
 parallel port 35
 PCI 40
 power supply 23
 serial port 35

connector (*continued*)
 USB 37
 controller
 diskette drive 9, 28
 I/O 9
 keyboard/mouse 11
 parallel 10
 serial 9
 copy protection 28
 current, electrical 25

D

depth, system unit 24
 diagnostic programs 3
 DIMM connectors 5
 diskette drive
 change signal 28
 compatibility 28
 controller 9
 write current 28
 diskette drives 28
 DMA (direct memory access) channel assignments 47
 DMA I/O address map 44
 DRAM (dynamic random access memory) 5
 drives, internal 19
 dual inline memory modules (DIMMs) 5
 dual processing 4

E

EIDE interface 7
 electromagnetic compatibility 24
 enhanced riser card 13
 environment, operating 24
 error codes, POST 48
 expansion 13

F

fault, overvoltage 22
 features
 hardware 1
 software 2
 flash update 3
 frequency 25
 frequency, input power 20

G

GPIO ports 11

Index

H

- hard disk drive
 - compatibility 28
 - controller 28
- hardware compatibility 26
- hardware features 1
- hardware interrupts 27
- heat output 25
- height, system unit 24
- humidity 25

I

- I/O
 - controller 9
- I/O address map 43
- IDE, enhanced 7
- information, related viii
- infrared port 10
- input power
 - frequency 20
 - requirements 20
 - voltage 20
- internal drives 19
- interrupt request assignments 46
- ISA
 - bus 6, 13
 - connectors 13

K

- keyboard
 - cable 24
 - connector 36
 - port 11

L

- level-sensitive interrupts 27
- load currents 21

M

- machine-sensitive programs 29
- measurements, system unit 24
- mechanical specifications 24
- memory
 - error in 42
 - map, system 42
 - RAM 42
 - system memory map 42
- messages, POST error 48
- microprocessor
 - features 4
 - upgrade socket 4

- modes, power management 3
- mouse
 - connector 36
 - port 11

O

- operating systems 2
- outputs, power supply 21
- overvoltage fault 22

P

- parallel port 10
- PCI
 - bus 6, 13
 - connectors 13
- PCI-to-ISA bridge 6
- Pentium Pro microprocessor 4
- pin descriptions
 - connections 15
 - diskette drive connector 34
 - EIDE connectors 33
 - infrared connector 37
 - ISA connector 38
 - keyboard/mouse connectors 36
 - parallel port connector 35
 - PCI connector 40
 - serial port connector 35
 - system memory 30
 - USB connector 37
- Plug and Play 2
- polling mechanism 29
- port
 - GPIO 11
 - keyboard/mouse 10, 11
 - parallel 10
 - serial 9
- POST 2
- POST error codes 48
- power
 - APM modes 3
 - cable 24
 - connectors 23
 - consumption 21
 - description 20
 - for components 21
 - load currents 21
 - output protection 22
 - outputs 21
 - specifications 25
- protection, power supply 22
- publications, related viii

Q

QAPIus/PRO 3
 QAPIus/WIN-WIN 3

R

RAM (random access memory) 42
 random access memory (RAM) 42
 references 52
 related information viii
 reserved areas vii
 riser card 13

S

SCSI
 cable 24
 serial port 9
 short circuit 22
 size, system unit 24
 socket, microprocessor upgrade 4
 software
 compatibility 29
 features 2
 interrupts 29
 switches, configuration 16
 system
 memory map 42
 specifications 24
 system board, layout of 14
 system memory
 connectors 30
 DIMMs 5
 expansion 5
 system resources
 EIDE interface 7
 graphic adapters 17, 18
 keyboard/mouse 11
 PCI-to-ISA bridge 6
 real-time clock 12
 system memory map 42
 USB interface 8

T

temperature 24

U

universal serial bus
 connector 37
 port 8
 technology 8

V

voltage, input power 20
 voltage, output power 20

W

warning, reserved areas vii
 weight, system unit 24
 width, system unit 24
 write current, diskette 28



Part Number: 84H0334

Printed in U.S.A.

