INSTALLATION AND SERVICE MANUAL

HP 91200B TV INTERFACE KIT

Manual part no. 91200-90001 Microfiche part no. 91200-90002

Printed: NOV 1976



INSTALLATION AND SERVICE MANUAL

HP 91200B TV INTERFACE KIT

Manual part no. 91200-90001 Microfiche part no. 91200-90002

Printed: NOV 1976

Card Assembly 91200-60007

LIST OF EFFECTIVE PAGES

Changed pages are identified by a change number adjacent to the page number. Changed information is indicated by a vertical line in the outer margin of the page. Original pages do not include a change number and are indicated as change number 0 on this page. Insert latest changed pages and destroy superseded pages.

NOTICE

The information contained in this document is subject to change without notice.

HEWLETT-PACKARD MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance or use of this material.

This document contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied or reproduced without the prior written consent of Hewlett-Packard Company.

CONTENTS


Section I Page	General	3
GENERAL INFORMATION	Modes of Operation	
Introduction	Video Signals	3_
General Description	Computer I/O Signals	3
Equipment Supplied1-2	External I/O Signals	
Options	Functional Block Description	
Identification	Control Section	ا-د
Specifications	Timing Section	
Card Repair 1-4	Memory Section	
	Video Section	3-1
Section II Page		
INSTALLATION		
Introduction		
Unpacking and Initial Inspection2-1	Section IV	Page
User Prerequisites 2-1	SERVICE	1 450
TV Monitor Requirements	Introduction	4-1
Cables	Equipment Required for Test	4_1
Installation	Diagnostic Test Procedure	
Black-and-White Operation2-1	Test Program Configuration	
Color Monitor Operation	Gray Scale or Color	4-9
Multi-Level Gray Operation2-5	Go No-Go Test	4-9
Remote TV Monitors2-9	Super Test	
Reshipment2-9	RAM Test	4_6
	Color Bar Test	
Section III Page	HP 2100A/S Computer BBL	
PRINCIPLES OF OPERATION	HP 21MX Computer IBL	4-0. ۱۶
Introduction 3-1	Error Halts	

TABLES

Title Page	Title	Page
Specifications	External I/O Signals	3-9
Scanning-Mode Jumper Positions2-3	Multiple-Card Mode Word Signals	
Single or Multiple-Card Jumper Positions 2-5	Color and Gray Scale Codes	
Operating Mode Specifications 3-2	Super Test Selections and Conditions	
Computer I/O Interface Signals 3-7	Starting Address for Basic Binary Loader	

ILLUSTRATIONS

Title Page	Title Pag
HP 91200B TV Interface Kit with Options 1-0	Video Signal, Horizontal Line Waveform 3-
Simplified Block Diagram1-3	Video Signal, Vertical Retrace Waveform
TV Interface Card2-4	(Mode I)3-
Cable Fabrication	Video Signal, Vertical Retrace Waveform
Multi-Level Gray and Color	(Mode II)3-
Installation Diagram2-7	Video Signal, Vertical Retrace Waveform
Triple-Hood Assembly for Color or	(Mode III)
Multi-Level Gray	TV Interface Card, Functional Diagram 3-
Multi-Level Gray Adjustment Waveform 2-10	Diagnostic Test Patterns 4-
Multiple Monitor Connection Diagram 2-11	Color Bar or Multi-Level Gray Test Pattern 4-



7202-4

Figure 1-1. HP 91200B TV Interface Kit with Options

GENERAL INFORMATION

1-1. INTRODUCTION

- 1-2. This manual contains general information, installation instructions, a functional description, and service instructions for the Hewlett-Packard 91200B TV Interface Kit. The kit is shown in figure 1-1 along with optional crystals, software, cable adapters, and cards with triple-hooded output connector for color or multiple gray level operation. The basic kit includes the TV interface card assembly, output connector assembly, diagnostic software tape, and this installation and service manual. Other required or accessory items are options to the HP 91200B Kit. Refer to paragraphs 1-14 and 1-16 for listings of equipment supplied and options, respectively.
- 1-3. The HP 91200B TV Interface Kit is compatible with the HP 2100A/S and HP 21MX Computers. The TV Interface Software is described in the HP 91200B TV Interface Kit Programming and Operating Manual, part no. 91200-90006.

1-4. GENERAL DESCRIPTION

- 1-5. A single TV interface card can be programmed to provide displays which combine both graphic images and alphanumeric characters on standard television monitors. Systems having two or three cards can display variable levels of gray on black and white (BW) monitors or color on color tube monitors. The monitors should be designed for EIA RS-170 composite video signals. The card video and sync outputs are designed to drive up to five monitors, connected in series, through 75-ohm coaxial cable. The furthest monitor can be up to 500 meters (1640 ft) away from the computer.
- 1-6. The display information of up to 65,536 individually addressable bits is stored on the card in Random Access Memory (RAM). A 256 by 256 dot matrix format is used. All points of the display are covered in a single complete TV scan using the card generated sync and the RAM point-by-point picture information. Because of the RAM, no CPU time is needed to refresh the display.
- 1-7. There are three modes of scan operation available which are selected by jumpers and the scan oscillator crystal. Mode I is the American Broadcast Standard of 525 lines-per-frame at 60 fields-per-second. Mode II is the European Broadcast Standard of 625 lines-per-frame at 50 fields-per-second. Mode III is a non-standard scan of 288 lines-per-frame and 60 frames or fields-per-second. Mode I and Mode II have a 2:1 interlace and Mode III is without interlace. Mode I uses a 256 by 240 data matrix and Modes II and III use the full 256 by 256 data matrix. The Ameri-

- can and European modes can be operated without interlace if it is not necessary to be compatible with broadcast video systems. For interlaced scans, the second scan can be a duplicate of the first or it can be blanked. Scan specifications are covered in table 1-1.
- 1-8. The user can program the TV interface card with FORTRAN, ALGOL, Real-Time BASIC and Assembly language calls to generate different sized characters, vectors, and illuminated areas as well as to erase and update any portion of the picture without having to reenter the entire displayed information. The card is supported in memory-based RTE-B and RTE-C operating systems and disc-based RTE operating systems.
- 1-9. The user can program for control of gray scale or color when multiple TV interface cards are installed in the system. For color, using a color monitor, a separate card is required for each of the red, green, and blue primary screen colors to be used. Three cards can provide displays of six saturated colors plus white and black on a color monitor; or eight levels of black and white from 7/8ths white to black on a BW monitor. Two cards can provide displays of three saturated colors plus black on a color monitor, or 1/2 and 3/4ths white and black on a BW monitor.
- 1-10. Synchronization and video amplification is provided on the cards. In multiple card operation for gray scale on a BW monitor, the raw video outputs are summed on a master card to provide a composite signal with sync. To maintain sync on all cards providing video to the master card, the clock signal of the master card (designated card A) is forwarded to slave cards (designated as cards B and C). A separate sync signal is provided for TV monitors which have difficulty synchronizing to a composite video signal. Industry standard synchronization in the TV interface card enables the user to mix the card generated video with other video signals to create split-screen effects and composite TV pictures.
- 1-11. The display may be program written as either white on black background or black on a white background. The stored image is reversible by changing one bit so the user can easily select either way. This causes the display to flash back and forth as an attention getter without loss of message. The same bit will cause all colors to change to their complements if switched to its opposite state; i.e., red becomes cyan, blue becomes yellow, etc.
- 1-12. Figure 1-2 is a simplified block diagram of the TV interface card. The memory section stores the data for output to the display. The section is composed of an input register, mode register, multiplexer, memory address register, RAM select storage, RAM select decoder, and the

random access memory (RAM). A 16-bit computer word is used to address any point in memory. The timing section produces the timing, blanking, and sync pulses for card and display operation. The control section contains the logic necessary for communication with the computer and also controls the memory section. The video section converts the memory output from parallel to serial form and provides sync and video outputs.

1-13. The address of the displayed point is available to the user at the instant it is scanned to facilitate the addition of a light pen. The lower 8-bit byte addresses the X (horizontal) axis of 256 locations and the upper 8-bit byte addresses the Y (vertical) axis of 256 locations. Address "0,0" is displayed on the lower left-hand corner of the monitor screen.

1-14. EQUIPMENT SUPPLIED

- 1-15. The basic kit contains the following:
- a. TV Interface Card Assembly, part no. 91200-60007.
- b. TV Interface Diagnostic Tape, part no. 91200-16003.
- c. Connector Assembly, part no. 02313-60010.
- d. HP 91200B TV Interface Kit Installation and Service Manual, part no. 91200-90001.

Table 1-1. Specifications

Operating System Compatibility	Supported for use in RTE-B, RTE-C, RTE-II and RTE-III operating systems only.			
Electrical Power Consumption (max.) Output Impedance Video Polarity Video Levels† White Black Sync Ext. Sync Level	75 ohms Programmable 0 volt -1 volt (approx.) -1.4 volts	@ 0.05A, $+$ 12V @ 0.32A, $-$ 12V composite video from 75 Ω so oing pulse (nominal)		
Operating Modes Lines per Frame Lines per Field Fields per Frame Fields per Second Interlace Lines of Data per Field Horizontal Scan Rate Point Rate Crystal Oscillator Frequency‡ Frames per Second	American I 525 262.5** 2 60 2:1** 240 15,750 Hz 5.040 MHz 10.080 MHz 30**	European II 625 312.5** 2 50 2:1** 256 15,625 Hz 5.000 MHz 10.000 MHz 25**	Non-Standard III 288 288 1 60 none 256 17,281.25 Hz 5.530 MHz 11.060 MHz	
TV Monitors Maximum Cable Length Environmental Operating Conditions	Up to five monitors may be connected to one TV interface card. 500 meters (1640 feet) 0° to 55°C (32° to 131°F)*, same as for HP 2100A/S and HP 21MX Computers; up to 15°C (27°F) should be allowed for temperature rise inside HP system cabinets.			
Physical Weight Dimensions	Shipping 1.82 kg (4 lbs) 220.7 mm (8-11/16 in.) x 196.9 mm (7-3/4 in.)			

^{*}Temperature range outside computer.

^{**}American and European modes may be operated without interlace if it is not necessary to be compatible with broadcast video systems.

[†] The specified voltage levels have a tolerance of $\pm 5\%$ on the peak-to-peak value of the composite video signal when driving a 75-ohm load.

^{\$\}pm\$+0.05%, thus providing this general tolerance to all time and frequency specifications.




Figure 1-2. Simplified Block Diagram

1-16. OPTIONS

- 1-17. Options are available to allow configuration flexibility. These options are described below:
- a. Option 442 Software Package:
 - RTE Driver DVA13 Binary Tape, part no. 91200-16001.
 - DVA13 Manual, part no. 91200-90005.
 - TV Interface Library Tape, part no. 91200-16002.
 - TV Interface Verification Tape, part no. 91200-16004.
 - Programming and Operating Manual, part no. 91200-90006.
- b. Option 001, Coaxial Cable Assembly for single cards:
 - Coaxial Cable Assembly, part no. 91200-60006.
 - Coaxial Connector Adapters (2), BNC to UHF, part no. 1250-0071.
 - Removes connector assembly 02313-60010 from basic kit.

- c. Option 003, Coaxial Cable Assembly for triple cards:
 - Coaxial Cable Assembly, part no. 91200-60008.
 - Coaxial Connector Adapters (4), BNC to UHF, part no. 1250-0071.
 - Removes connector assembly 02313-60010 from basic kit.
- d. Option 010, Quartz Crystal for American Scan:
 - Crystal for 10.0800 MHz, part no. 0410-0592.
- e. Option 011, Quartz Crystal for Non-Standard Scan:
 - Crystal for 11.0600 MHz, part no. 0410-0591.
- f. Option 015, Quartz Crystal for European Scan:
 - Crystal for 10.0000 MHz, part no. 0410-0035.

1-18. IDENTIFICATION

1-19. The TV interface card is identified by a part number and a revision code (see figure 2-1). The ten-digit part number 91200-60007 is the same for all cards. The revision code consists of a letter, a series code, and a

General Information 91200B

division code (e.g., A-1503-22). The letter code identifies the version of the etched trace pattern on the unloaded board. The series code (four middle digits) refers to the electrical characteristics of the loaded assembly and the positions of the components. The division code (last two digits) identifies the Hewlett-Packard division that manufactured the card. Cards having the same part number but different revision codes are interchangeable unless noted otherwise in this manual or by a manual supplement. Manual supplements are available from HP Sales and Service Offices (see list at the back of this manual).

1-20. SPECIFICATIONS

1-21. Table 1-1 lists the major electrical, environmental, and physical specifications of the TV interface card.

1-22. CARD REPAIR

1-23. The TV interface card is a field replaceable item and should be maintained on an exchange basis. To verify card operation within an RTE environment, use the online RTE verification procedure given in the programming and operating manual; otherwise, perform the off-line diagnostic test given in Section IV. If a malfunction is confirmed by the diagnostic, the card should be replaced with an exchange assembly. The exchange card, part no. 91200-69007, is available at a reduced rate. The nearest Hewlett-Packard Sales and Service Office can provide all procurement details.

2-1. INTRODUCTION

2-2. This section provides installation instructions which includes recommended procedures on preparing the TV interface card for operation with the computer in the user's system. Card installation instructions include unpacking and initial inspection, cable preparation, and card installation. Single cards, multiple cards for gray scale and for color are covered.

2-3. UNPACKING AND INITIAL INSPECTION

2-4. Any shipping container that appears damaged should be unpacked with the carrier's agent present. Carefully inspect the TV interface card for damage, scratches, cracks, etc. Check that all equipment specified in the purchase order has been delivered; refer to Section I for the list of components supplied with the kit. If any equipment is missing, damaged, or fails to meet specifications, immediately notify the carrier and the nearest Hewlett-Packard Sales and Service Office listed at the back of this manual. Retain the shipping containers and packing material for the carrier's inspection and for future use.

2-5. USER PREREQUISITES

2-6. TV MONITOR REQUIREMENTS

2-7. The customer must provide a suitable TV monitor designed for EIA RS-170 composite video signals. The monitor input should match a 75-ohm source impedance. Refer to table 1-1 for operating mode specifications. For Mode III, the monitor must be capable of synchronizing to a horizontal rate of 17,280 Hz and a vertical rate of 60 Hz. For Mode II the monitor must sync at a horizontal rate of 15.625 Hz and a vertical rate of 50 Hz. For Mode I, the American broadcast standard, the horizontal sync rate is 15,750 Hz and the vertical rate is 60 Hz. The TV sets or studio monitors operated from the TV interface card may be equipped with a composite video input or separate picture and sync inputs. The sets or monitors should sync properly if designed for the sync rates of the card operating mode. For best dot definition, it is desirable that the monitor have a video bandwidth of 8 MHz or more. Additional desirable features are good linearity, dc restoration, dc sync pick-off or external sync input, non-glare screen. and wide-range high-voltage regulation. If more than one monitor is to be used with one card, it is necessary that the monitor have chaining connectors, and be able to switch from a 75-ohm termination to a high impedance. In operation, a slight "underscan" of the monitor screen is desirable so that the entire display is visible.

2-8. CABLES

The user shall furnish 75-ohm coaxial chaining 2-9. cables (e.g., RG-59/U or RG-59B/U) for the connection of extra monitors or for additional cable lengths. The last monitor should have no more than 500 meters (1640 feet) of cable between it and the TV interface card. A coaxial cable pair, 7.5 meters (25 feet) long is furnished with option 001. Option 003 includes three video cables and one sync cable, all 7.5 meters (25 feet) long. The cables are connected into a triple-hooded edge connector for three TV interface cards. Lengths of cable may be joined by using straight female-to-female couplers. BNC to UHF (PL-259) plug adapters are furnished for each cable (with options 001 and 003) to mate with monitors having UHF (SO-239) type chassis receptacles. If the composite video/sync signal is used, the separate sync cable will not be necessary. It may be rolled up and stored at the rear of the equipment in case it may be needed at some time in the future.

2-10. INSTALLATION

2-11. BLACK-AND-WHITE OPERATION

- 2-12. The following procedure describes how to install a single TV interface card for black-and-white (BW) operation. The procedure is as follows:
- a. Determine if the computer power supply will provide the additional current required for operation of the TV interface card. The power required is given in table 1-1, specifications. If the addition of the card will overload the computer power supply, an appropriate computer I/O extender must be used. (HP 2100A/S and HP 21MX Computers work with HP 2155A and HP 12979A I/O Extenders, respectively.)

Note: If the TV interface card is to be used in a system under DMA (or DCPC) control, the card must be installed in a computer mainframe having DMA (or DCPC). The card could also be operated in an I/O extender having DMA (or DCPC) as long as the computer also has the DMA (or DCPC) capability. An RTE environment requires DMA (or DCPC).

- b. Determine mode of operation. Refer to table 2-1 which describes the functions of the jumpers on the TV interface card for the three scanning modes. Jumper location is shown in figure 2-1.
- Install crystal after making sure it is the right one for scanning mode selected (see table 2-1).
- d. Set jumpers for single or multiple card operation.
 Refer to table 2-2 for jumper positions. Refer to figure
 2-1 for location of jumpers. Place unused jumpers in the jumper storage socket on the card for future use.
- e. When fabricating cable assemblies, use the hooded connector, part no. 02313-60010, supplied with each HP 91200B Kit unless this item was deleted by the use of one of the cable assembly options (001 and 003). Construction details are shown in figure 2-2.
- f. If two or more monitors are to be connected to the TV interface card, fabricate cables to link them together from the first monitor. Use RG-59/U or RG-59B/U 75-ohm coaxial cable and appropriate connectors to mate with the monitor connectors.

CAUTION

Always make sure that the computer power is in either *standby* for HP 21MX or *off* for HP 2100A/S Computers when installing or removing the interface card or interconnecting cable. Failure to observe this caution may damage the card.

- g. Insert card in the computer card cage in the following manner:
 - (1) Turn computer power to standby (HP 21MX) or off (HP 2100A/S) and gain access to I/O card cage.
 - (2) Hold card vertically with components on the left for the HP 2100A/S Computers. Hold card horizontally with components up for the HP 21MX Computer and the HP 12979A I/O Extender. Plastic card extractors should face away from the computer.
 - (3) Carefully slide card into its assigned slot.
 - (4) Seat card fully in its mating backplane receptacle by pressing firmly inward on its card extractors.
- h. To install the 7.5 meter (25 ft) cable and hood assembly on the card(s) in the computer or I/O extender, proceed as follows:
 - (1) For the HP 2100A/S Computer, orient the hood so that the cable exits towards the rear of the cabinet. For the HP 21MX Computer and rear of the HP 12979A I/O Extender, orient the hood so

- the cable exits toward the right side when facing the rear of the cabinet. For the HP 12979A I/O Extender front access, orient the hood so the cable exits the hood towards the right. The cable should run up the right cabinet wall and cross over to the left side then out the rear cable port.
- (2) Carefully slide cable hood connector onto the 48-pin edge connector of the card and press into place.
- (3) Connect VIDEO connector to the TV monitor. Note that some monitors may also require connection of the SYNC output (see paragraph 4-23).

Note: It is the user's responsibility to provide an appropriate TV monitor in good operating condition. The diagnostic and verification tests require that the TV monitor be connected to the card.

2-13. After installation, a performance check can be made in one of two ways. For off-line checking, use the diagnostic test procedure described in Section IV. For RTE on-line checking (except for RTE-B operating systems), use the verification program described in the HP 91200B TV Interface Kit Programming and Operating Manual, part no. 91200-90006. The verification and diagnostic programs provide a convenient means of checking the TV monitor's adjustments. The RTE software operating system must be generated for the verification test to function.

2-14. COLOR MONITOR OPERATION

- 2-15. Color monitors require a separate TV interface card for each color input of a color CRT. For this application, three cards are used with one option 003 triplehooded connector. Two color inputs require two cards and two part no. 02313-60010 hooded connectors (supplied with the basic kit) with connectors and cables fabricated according to figures 2-2 and 2-4. The cards should sit side-by-side in either the computer I/O card cage or I/O extender. The master card (designated as card A) must be placed in the highest numbered slot of the group and will be addressed by the select code (or LU number in RTE systems) assigned to the TV interface subsystem. The master card is followed in descending order by slave card B and slave card C. Perform the following procedures to install a set of cards for color operation:
- a. Review the black-and-white operation installation procedure given in paragraph 2-11. Observe the power supply and current requirements of the cards and other considerations such as I/O with DMA (or DCPC) and all cautions and notes.
- b. The wiring of three-card cables and the triple PC card connector for color is shown in figure 2-4, using option 003. Two card setups, using single hoods, should be wired according to figure 2-4 with card C deleted and the hoods assembled as shown in figure 2-2.

Table 2-1. Scanning-Mode Jumper Positions

	AMERICAN STANDARD (MODE I)
JUMPER	DISPLAY OR USE
W2-A W3-A W3-B W4-X W5-A W6-IN W6-OUT W7-OUT W8-IN W9-IN W9-OUT W10-OUT W11-IN W11-OUT W12-IN	American Standard. Single or master card clock enable. Slave card (B and C) clock disable, external clock connect. American Standard - not used (don't care). American Standard. Horizontal display points defined. Horizontal lines, points undefined. American Standard. American Standard. Interlace enabled (2 fields, 525 lines). Interlace disabled (1 field, 524 lines). American Standard. Second field blanked (262.5 lines with W9-IN, 262 lines with W9-OUT). Both fields. American Standard.
	EUROPEAN STANDARD (MODE II)
JUMPER	DISPLAY OR USE
W2-B W3-A W3-B W4-A W5-B W6-IN W6-OUT W7-IN W8-IN W9-IN W9-OUT W10-IN W11-IN W11-OUT W12-OUT	Sync. Single or master card clock enable. Slave card (B and C) clock disable, external clock connect. Timing. Timing. Horizontal display, points defined. Horizontal display, points undefined. Timing. Timing. Interlaced (2 fields, 625 lines). Interlace disabled (1 field, 624 lines). Sync 2nd field blanked (312.5 lines with W9-IN, "don't care" with W9-OUT). Both fields with W9-IN, "don't care" with W9-OUT. Sync.
	NON-STANDARD (MODE III)
JUMPER	DISPLAY OR USE
W2-B W3-A W3-B W4-B W5-B W6-IN W6-OUT W7-IN W8-OUT W9-OUT W10-IN W11-IN W11-OUT W12-OUT	Sync. Single or master card clock enable. Slave card (B and C) clock disable, external clock connect. Timing. Timing. Horizontal display, points defined. Horizontal display, points undefined. Timing. Timing. Timing. 1 field of 288 lines. Sync. Don't care. Don't care. Sync.
CRYSTALS	
Mode II European Stand	lard. 10.080 MHz, part no. 0410-0592. lard. 10.000 MHz, part no. 0410-0035. 11.060 MHz, part no. 0410-0591.




Figure 2-1. TV Interface Card

- c. Place a small strip of tape on each card and label them A, B, and C for master, slave 1, and slave 2, respectively.
- d. Set jumpers on cards according to table 2-1 for scanning requirements and table 2-2 for multiple card operation.

Table 2-2. Single or Multiple-Card Jumper Positions

JUMPER	DESCRIPTION OF USE
W1-A	Black-and-white or color (solder-in type).
W _{1-B}	Multi-level gray.
W13-A	Single or master card (card A).
W13-B	Slave card (cards B and C).
W14-IN	Single or master card (card A).
W14-OUT	Slave card (cards B and C).
W15-IN	Single or master card (card A).
W15-OUT	Slave card (cards B and C).
W16-A	Single or master card (card A).
W16-B	Slave card (cards B and C).
W17-IN	Single or master card (card A).
W17-OUT	Slave card (cards B and C).
W18-A	Single or master card (card A).
W18-B	Slave card B (first slave).
W18-C	Slave card C (second slave).
W19-IN	Single or master card (card A).
W19-OUT	Slave card (cards B and C).
W20	For factory use only (solder-in type).

- e. Connectors for option 003 are prewired. The supplied cables are 7.5 meters (25 ft) in length. Fabricate extension cables if necessary.
- f. Check out any fabrication work and then install cards in appropriate slots of computer or I/O extender card cage. Use procedure given in paragraph 2-12, step g.
- g. Install TV interface cable 48-pin connectors on appropriate cards. Roll up and tie back or remove cables which are not used. Cabling is shown in figure 2-3.
- h. Connect the RED video connector from card A to the TV monitor RED video input connector. Similarly, connect the BLUE and GREEN connectors. Use coaxial adapter, part no. 1250-0071, if necessary.
- If the TV monitor requires external synchronization, connect the SYNC connector from card A to the TV monitor EXT SYNC connector.
- j. The only adjustment necessary for color operation is to ensure that the blanking level on all composite video outputs is the same.
- k. Using a multiple input oscilloscope display, display the pedestal of the three composite video signals. Connect the oscilloscope inputs to the composite video output (TP1) of each card (see figure 2-1).

l. On card A (master card) adjust the blanking level to -1.0 volt with the pedestal control R5. Adjust the blanking levels of cards B and C to match the level set on card A, also with pedestal.

m. Refer to the programming and operating manual for instructions on checkout in an RTE system (except RTE-B) for color operation using a color bar pattern. For off-line checkout and other operating systems ,use the color bar pattern of the diagnostic program described in Section IV.

2-16. MULTI-LEVEL GRAY OPERATION

- 2-17. Two or three cards must be used in multi-level gray operation. Four or eight levels of gray can be produced by two or three cards, respectively. The cards must sit side by side in either the computer I/O card cage or I/O extender. The master card (designated as card A) must be placed in the highest numbered slot of the group and will be addressed by the select code (or LU number in RTE systems) assigned to the TV interface subsystem. The master card is followed in descending order by slave card B and slave card C. The card and cabling setup is shown in figure 2-3. Perform the following procedure to install multiple gray level cards:
- a. Review the black and white operation installation procedure given in paragraph 2-11. Observe the power supply and current requirements of the cards and other considerations such as I/O with DMA (or DCPC) and all cautions and notes.
- b. The wiring of three-card cables and the triple PC card connector for gray scale is shown in figure 2-4, using option 003. Two-card setups, using single hoods, should be wired according to figure 2-4 with card C deleted and the hoods assembled as shown in figure 2-2.
- c. Place a small piece of tape on each card and label them A (master), B (slave 1), and C (slave 2).
- d. Set jumpers on cards according to table 2-1 for scanning requirements and table 2-2 for multiple card operation.
- e. Connectors for option 003 are prewired. The supplied cables are 7.5 meters (25 ft) in length. Fabricate extension cables if necessary.
- f. Check out any fabrication work and then install cards in appropriate slots of computer card cage. Use procedure given in paragraph 2-12, step g.
- g. Install TV interface cable 48-pin connectors on appropriate cards. Roll up and tie back unused cables, or remove cables if their future use is unlikely. Cabling is shown in figure 2-3.
- h. Connect the composite VIDEO connector from card A to the TV monitor VIDEO IN connector. Use coaxial adapter, part no. 1250-0071, if necessary.




Figure 2-2. Cable Fabrication




Figure 2-3. Multi-Level Gray and Color Installation Diagram




Figure 2-4. Triple-Hood Assembly for Color or Multi-Level Gray

 If the TV monitor requires external synchronization, connect the SYNC connector from card A to the TV monitor EXT SYNC connector.

j. Connect an oscilloscope to card A (master) composite video output test point (see figure 2-1). Run verification or diagnostic program and display the color bar pattern. Adjust oscilloscope to display a staircase waveform between two sync pulses. The staircase waveform is shown in figure 2-5.

Note: There is an interaction between the three card A adjustment controls. Repositioning of one or more of these controls may be necessary.

- k. Use offset control R6 to position the top of the staircase at 0 volt. Set the blanking level at -1.0 volt using pedestal control R5. Use contrast control R7 to equalize each step in the staircase waveform. Refer to figure 2-1 for control location. An eight-level staircase waveform is shown in figure 2-5. With two cards, only steps 0,2,4, and 6 are present such that the white level is actually a 3/4 white.
- Refer to the programming and operating manual for instructions on checkout in a RTE system (except for RTE-B operating systems). For off-line checkout, the vertical bar pattern used in the diagnostic program described in Section IV may be used.

2-18. REMOTE TV MONITORS

2-19. One to five TV monitors, with parallel high impedance connectors, may be connected to one TV interface card. Refer to figure 2-6 for an example connection of TV monitors using the daisy chaining technique. The total permissible cable length is 500 meters (1640 ft). Refer to paragraphs 2-6 and 2-8 for monitor and cable requirements.

2-20. When operating in color applications, the connection of additional monitors is similar to figure 2-6. Each video cable is treated the same as the single video cable shown.

2-21. RESHIPMENT

2-22. If an item of the kit is to be shipped to Hewlett-Packard for service or repair, attach a tag to the item identifying the owner and indicating the service or repair to be accomplished. Include the model number of the interface card.

Note: Do not ship crystals with the TV interface card.

- 2-23. Package the item in the original factory packaging material, if available. If the original material is not available, standard factory packaging material can be obtained from a local Hewlett-Packard Sales and Service Office.
- 2-24. If standard factory packaging material is unavailable, wrap the item in Air Cap TH-240 cushioning (or equivalent) manufactured by Sealed Air Corp. Hawthorne, N.J. and place in a corrugated carton (200 pounds test material). Seal the shipping carton securely and mark it "FRAGILE" to ensure careful shipping.

Note: In any correspondence, identify the TV interface card by part number. Refer any questions to the nearest Hewlett-Packard Sales and Service Office.




Figure 2-5. Multi-Level Gray Adjustment Waveform




Figure 2-6. Multiple Monitor Connection Diagram

PRINCIPLES OF OPERATION

3-1. INTRODUCTION

3-2. This section provides block diagram functional descriptions of the TV interface card.

3-3. GENERAL

3-4. Mnemonics are used to abbreviate signal names; e.g., NSTB (strobe) and NCLK (clock). The polarity convention used is that when a mnemonic beginning with the letter N is active, the logic level is low. Mnemonics for the same signals after logic inversion have the letter N removed. Thus, a strobe makes NSTB low and STB high. Similarly, a clock makes NCLK low and CLK high.

3-5. MODES OF OPERATION

3-6. The TV interface card is capable of three modes of operation to satisfy requirements for three different scanning rates. Operating modes are controlled by jumper placement and the selection of a crystal as specified in table 2-1. Mode I is the American Broadcast Standard, Mode II is the European Broadcast Standard, and Mode III is a non-standard scan to achieve full 256 vertical resolution with a 60 Hertz vertical scan rate. Table 3-1 lists the card and signal specifications for each mode. Figures 3-1 through 3-4 show idealized waveforms and relationships for each mode of operation.

3-7. VIDEO SIGNALS

- 3-8. There are 256 points of data and 64 clock counts for horizontal blanking on each video signal horizontal line. A clock count is defined as a clock pulse interval, shown as (T) in figure 3-1. Thus, each horizontal line has the equivalent of 320 clock counts, 256 for data and 64 for blanking. Figure 3-1 illustrates the typical video signal horizontal line for the TV interface card. Each data point in the video signal is clocked and displayed as a discrete dot if jumper W6 on the card is IN. Each data point will be unclocked, blending in with adjacent points to be displayed as a line, if jumper W6 is OUT. The video polarity can be programmed through the computer so that the data points can be written black-on-white or white-on-black.
- 3-9. Figures 3-2, 3-3, and 3-4 show the retrace portion of the video field for the three scan modes. The timing information for the included equalizing pulses, sync pulses, and intervals is given in table 3-1.

- 3-10. The vertical retrace interval is constructed through the use of groups of equalizing, horizontal, and vertical sync pulses. The duration of the vertical retrace interval is dependent on operating mode (I, II, or III). For example, in figure 3-2 showing the American Standard, the retrace interval from the end of the first field is 1.397 msec (22 horizontal line scans). In order to interlace the fields, the vertical retrace interval is extended an extra horizontal line scan, or 23h, after the second field. When used without interlace, all fields are the same as the first field with 22 horizontal line scans during vertical blanking (262 lines per field, 60 fields per second).
- 3-11. The TV interface card provides the option of blanking the second field through the use of jumper W11. Normally, both fields contain identical information with jumper W11 out. If the second field is blanked, it may be necessary to use a monitor with a long persistence phosphor screen CRT. The long persistence phosphor screen CRT's are generally green instead of white.

3-12. COMPUTER I/O SIGNALS

3-13. Since the TV interface kit is designed to be compatible with HP 2100A/S and HP 21MX Computers, reference should be made to the appropriate computer manual for a comprehensive discussion of I/O signals. A brief description of the computer I/O signals and their interaction with the TV interface card is given in Table 3-2. The 86-pin edge connector serves as the interface point between card and computer. Refer to figure 3-5, the functional diagram for the TV interface card, which identifies input and output signals and their pin numbers.

3-14. EXTERNAL I/O SIGNALS

3-15. The primary output from the TV interface card is the composite VIDEO signal for driving TV monitors. A SYNC signal is also available for TV monitors which require external synchronization. For color or gray-scale operation using multiple TV interface cards, the following signals are connected between the cards: MCLK, RVID, BIN, CIN, LINK, and ADDR. These signal connections are described under installation procedures in Section II. There is a CLK and RAO through RA15 signals for user implementation of a light pen. The 48-pin edge connector serves as the interface point between the card and external devices (TV monitors and other interface cards). Refer to table 3-3 for a brief description of the external I/O signals and to figure 3-5 for the edge-connector pin location of these signals.

Table 3-1. Operating Mode Specifications

	MODE I	MODE II	MODE III	UNITS
Lines per Frame	525	625	288	_
Lines per Field	262.5	312.5	288	
Fields per Frame	2	2	1	_
Fields per Second	60	50	60	
Frames per Second	30	25	60	
Interlace	2:1	2:1	None	
Lines of data per Field	240	256	256	_
Horizontal Scan Rate	15750	15625	17281.25	Hz
*	1.587	1.600	1.447	μsec
s*	4.762	4.800	4.340	μsec
b*	6.349	6.400	5.787	μsec
h*	63.492	64.000	57.866	μsec
e*	2.381	2.400	2.170	μsec
V*	26.984	27.200	24.593	μsec
Τ*	198.413	200.000	180.832	nsec
Point Rate	5.040	5.000	5.530	MHz
Crystal Osc. Freq.	10.080	10.000	11.060	MHz
*Refer to figures 3-1 through		1	11.000	I




Figure 3-1. Video Signal, Horizontal Line Waveform




Figure 3-2. Video Signal, Vertical Retrace Waveform (Mode I)




Figure 3-3. Video Signal, Vertical Retrace Waveform (Mode II)





Figure 3-4. Video Signal, Vertical Retrace Waveform (Mode III)






Figure 3-5. TV Interface Card, Functional Diagram

Table 3-2. Computer I/O Interface Signals

MNEMONIC	PIN	SIGNAL	DESCRIPTION
STC	22	Set control	Enables interrupt capability. Also initiates write or erase depending on the mode.
CLC	21	Clear control	Clears interrupt control upon execution of the CLC instruction. Sets mode control so that the next OTA will be interpreted as MODE information.
CRS	13	Control reset	Generated by EXTERNAL PRESET button on computer front panel or CLC 0 instruction or power on. Same effect as CLC signal. Also, resets all counters in the timing module.
ENF(T2)	46	Enable flag	Positive pulse at computer time T2. Sets flag if flag buffer is set.
IAK	10	Interrupt acknowledge	After detecting an interrupt, the computer responds with IAK which sets the interlock, causing the interrupt request to be cleared, preventing another interrupt from the same flag signal.
T3(B)	11	Computer time T3 (buffered)	Subcycle 3 of computer timing. Used to set flag buffer for MODE outputs.
SRQ	19	Service request	Output of flag used to initiate DMA (or DCPC) cycles.
IRQL FLGL	6 4	Lower select code Interrupt request and flag signals	IRQL and FLGL are signals used to initiate an interrupt.
PRH	23	Priority high	When high, indicates that no device of higher priority is requesting an interrupt. If low it prevents this card from interrupting. The interrupt is saved until PRH goes high.
PRL	3	Priority low	When low, prevents any interface card of lower priority from interrupting computer program. Will be low whenever processing an interrupt on this card or higher priority card.
LSCM	14	Lower select code most significant digit	The LSCM, LSCL, and IOG(B) signal
LSCL	16	Lower select code least significant digit	combination determines the computer I/O slot to which the instruction portion
IOG(B)	15	I/O group instruction	of the computer I/O command word is directed. When the TV interface card is selected, all three signals will be high. Generates ADDR signal on card.
IOBO0 thru IOBO15	35,38,41,45, 42,51,53,52, 54,56,58,55, 57,61,65,74	16-bit data word	16-bit parallel binary data word being output from computer to TV interface card.

Principles of Operation 91200B

Table 3-2. Computer I/O Interface Signals (Continued)

MNEMONIC	PIN	SIGNAL	DESCRIPTION
SIR(T5)	32	Set interrupt request	Positive pulse that occurs at computer time T5. If other prerequisites are met, sets interrupt request if flag is set or clears interrupt request following an IAK.
STF	9	Set flag	Sets interface card flag high.
100	20	I/O output operation	Strobes computer data word into interface card on OTA/OTB.
IOI	24	I/O input operation	Input strobe from LIA/LIB. Initiates bulk erase.
CLF	7	Clear flag	Clears flag and interlock. Also allows mode control to be cleared by T3(B).
SFS	25	Skip if flag set	Used to determine if flag is set. Causes SKF if flag is set.
SFC	5	Skip if flag clear	Used to determine if flag is clear. Causes SKF if flag is clear.
SKF	12	Skip flag	If issued it will cause program to skip an instruction. See SFS and SFC above.
IEN	8	Interrupt enable	High when the computer interrupt system is on, low when it is off. Must be high if an interrupt is to occur.
POPIO(B)	17	Power-on preset	Initialization command which presets interface card to known starting condition when power is applied to computer. Also issued by PRESET button. Causes bulk erase. Also see CRS.

3-16. FUNCTIONAL BLOCK DESCRIP-TION

3-17. CONTROL SECTION

Refer to figure 3-5, functional block diagram, 3-18. throughout the following description. The control section is contained in a single IC package called the Control Module. Within it are the standard flag and interrupt circuitry used in HP 2100-Series Computer interfaces, and the memory control functions. The control signals set up the card for memory read or write operations. During an I/O operation, an interrupt acknowledge sets a flag interlock flip-flop which inhibits further interrupt requests. A clear flag (CLF) must be programmed and issued by the computer to re-enable the interrupt circuit. (Most HP 2100-Series Computer interface cards do not include the flag interlock feature.) A CRS command from the computer resulting from a CLC0 program mnemonic (or computer front panel EXT PRESET, or LINK from the Master

Card to a Slave Card) will generate a clear (CLR) signal on the card and its opposite polarity NCLR signal. These signals reset the timing module and sync selector.

When either (CLC SC) or (CLC 0) occurs the 3-19. control module is set so that the next OTA will be interpreted as mode information. The least significant bits (IOBO 0 through IOBO 3, depending on jumper W18 settings) of the next word are strobed into the mode register by the mode strobe (NMSTB) signal. IOO initiates NMSTB and NSTB signals. Normally, mode bit 1 is zero (white-on-black on BW monitors) unless polarity reversal has been programmed (POL high). The mode signals for color are given in table 3-4. Bulk erase is caused by either POPIO (power-on preset) or IOI from program LIA, MIA, etc. POPIO also sets CRS high which resets the counters. Bulk erase is initiated by NBEE (low) from the control module at input 1 of U101A forcing W/E high at the input D_{IN} of the RAM's, which is the erase condition.

91200B Principles of Operation

Table 3-3. External I/O Signals

MNEMONIC	PIN	SIGNAL	DESCRIPTION
LINK OUT	2	Multi-card Synchronization (Master Card)	When connected to LINK IN, resets counters and registers.
LINK IN	В	Multi-card Synchronization (Slave Card)	Receives LINK OUT from master card for frame sync.
VIDEO	4, D	Composite Video Output	Video signal with sync pulses to drive TV monitors through 75-ohm coaxial cable.
SYNC	6, F	Sync Output	Synchronization pulse train only. This is an auxiliary output for TV monitors requiring external sync.
RVID	8, J	Raw Video Output (Slave Card)	Video without sync, connects to BIN or CIN of master card for multi-level gray operation (TTL level).
BIN	10	Card B Input (Master Card)	Raw video input signal from slave card B for multilevel gray operation.
CIN	L	Card C Input (Master Card)	Raw video input signal from slave card C for multilevel gray operation.
ADDR OUT	12	Select Code Addressed (Master Card)	Indicates master card addressed by computer.
ADDR IN	N	Input for Addressed Encode (Slave Card)	Slave card input for addressed signal. Enabled by jumper W16 in position B.
RA0 thru RA15	13-20 and P-X	Read Address	A 16-bit word (ground true) indicating the read address of the point being displayed. Current point read address bits are auxiliary output for user implementation of a light pen.
CLK OUT	21, Y	Clock	Point clock to aid in light pen implementation.
MCLK OUT	23	Master Clock Output	Clock signal for locking multiple cards together for color or multi-level gray operation.
EXT MCLK IN	AA	External Master Clock Input	Card can operate from an external clock when this signal is present and jumper W3 is in position B. For slave cards.

3-20. The mode bit 1 gives normal polarity of the video when logic 0 (low) and the inverse polarity when logic 1 (high) which gives the complements of the colors. Mode bit 1 exits the mode register as the polarity reference (POLR) signal to a polarity flip-flop in the control module. The POLR signal is gated through by the vertical blanking (VB) signal to enable the polarity signal (POL) which goes to the shift register. Therefore, signal polarity can only be changed at the end of a field during the blanking period.

3-21. The clock timing signals (CLK, CLK/2, CLK/4, CLK/8, CLK/16) are used to generate the following: read/write (R/W), word select (WS), chip enable (CE), and address clock enable (ACE). WS is the same as R/W inverted as long as bulk erase is not in effect. The R/W signal is routed through two "nand" gates for pulse shap-

ing and becomes the write enable signal (NWE) which goes to the WE terminal on all 16 RAM's. A low (logic 0) NWE signal selects the write mode. All memory read/write functions take place when the clock signal CE, through the clock driver, is high. The ACE can only occur when the RAM's are not clocked (absence of CE). ACE gates NCLK through U101D producing the address clock signal (NAC) for the RAM address storage and memory address register. This ensures that the address lines to memory are settled before a pulse arrives on the CE line.

3-22. Multiple cards for color or gray scale are addressed simultaneously by LSCM, LSCL, and IOG(B) generating ADDR through U41 as though they were located in the one computer select code position of the master card. The parallel addressing comes from the positioning of jumper

W16 at "A" for the master and "B" for the slaves. This sends the ADDR OUT signal through the 48-pin connector to ADDR IN on the slaves. IOO initiates NMSTB and/or NSTB to strobe the TV interface card(s). Mode bit 0 on each card is selected by jumper W18 which applies IOBO 0 to master card A, IOBO 2 to slave card B and IOBO 3 to slave card C. Thus, the mode programming word, according to the three-bit combinations listed in table 3-4, will provide a color display or gray scale.

Table 3-4. Multiple-Card Mode Word Signals

IOBO BITS	3-CARD	3-CARD	2-CARD	2-CARD
3-2-0	COLOR	BW	COLOR	BW
0-0-0 0-0-1 0-1-0 0-1-1 1-0-0 1-0-1 1-1-0	white cyan magenta blue yellow green red black	7/8 wh 3/8 5/8 1/8 3/4 1/4 1/2 black	yellow green red black yellow green red black	3/4 wh 1/4 1/2 black 3/4 wh 1/4 1/2 black

Note: IOBO 1 is 0 (low) for the above. Programming IOBO 1 as 1 (high) reverses the video polarity. This reverses black and white on BW monitors and gives complementary pairs on color monitors as follows: three card colors are white - black, red - cyan, green - magenta, blue - yellow; two card colors are yellow - black, red - green.

3-23. TIMING SECTION

- 3-24. The timing section consists of the crystal oscillator, the timing module, the sync selector, and the blanking generator.
- 3-25. The repetition rate of the master clock signal is dependent on the selected oscillator crystal. During color or multiple level gray operation, two or three TV interface cards (designated as cards A, B, and C) may be employed. On master card A, jumper W3 is placed in position A for the clock signal MCLK to be applied to the timing module. Jumper W3 on slave cards B and C is set to position B so the clock signal comes from EXT CLK IN. In this manner all cards are clocked by one master clock (MCLK) signal, thus ensuring synchronization of all cards as a group.
- 3-26. Slave card operation requires a LINK signal into the control module from the master card to maintain sync between cards. The link signal comes from the sync generator during the vertical blanking period of field one when all counters pass through zero. This ensures that the master and slave cards are synchronized.
- 3-27. The MCLK signal is routed to the timing module where it is divided by two to produce the basic clock pulse (CLK,NCLK) which is the point time used to shift the registers, control basic card timing, clock the discrete display points, etc. An 8-bit horizontal point counter divides

the basic clock pulse to produce the CLK/2, CLK/4, CLK/8, CLK/16, CLK/32, CLK/64, CLK/128, and CLK/256 clock pulses. The total of 256 is normal for one horizontal line of the visible display. Upon entering horizontal blanking, the counter counts to 64. The counter resets and begins counting for the next visible line to repeat the count of 256. The value of the 8-bit horizontal point counter during the visible portion of the horizontal line provides the displayed point horizontal address for the memory section. The total count cycle is 320 counts providing in addition to the 256 point line, one horizontal (HS) sync pulse, two equalizing (EQ) pulses, two vertical sync (VS) pulses and the horizontal blanking (HB) pulse.

- 3-28. An 8-bit vertical line counter divides the horizontal sync pulses by 240 or 256, according to the scan mode settings of jumpers W5 and W7. At the last count, the timer switches from line scan to the vertical blanking period, applying blanking VB and counting a predetermined number of counts based on the mode of operation selected by jumpers W4 and W8. At the end of the blanking count, the counter resets VB. The vertical line counter provides the timing pulses HS/2, HS/4, HS/8, HS/16, HS/32, HS/64, HS/128, HS/256. Each time the vertical blanking period is started or stopped, a flip-flop is toggled to produce the field signals FLD1 and FLD2 when the jumper W9 is set for interlace in the American or European scan modes.
- 3-29. The clear (CLR, NCLR) inputs from the control module serve to reset all counters, flip-flops, and registers. Refer back to table 2-1 for the effect of jumpers on the scan parameters.
- 3-30. The sync selector operates only during vertical blanking. A 5-bit counter, when enabled during the vertical blanking period, counts the vertical sync (VS) pulses. When not in the vertical blanking period (display visible), the vertical blanking (VB) signal holds the entire counter in the zero state. During this time VB is low and the ground-true vertical blanking NVB signal is high.
- 3-31. Jumpers W2, W10, and W12 are employed to reset the counter after counting the appropriate number of VS pulses for the operating mode. W10 provides vertical sync (VS) reset for Modes II and III, W12 provides counter reset for Mode I, and W2 establishes the number of equalizing pulses for the mode selected.

3-32. MEMORY SECTION

3-33. The TV interface card contains a 65,536-bit solid-state memory made up of sixteen 4096-bit random-access memory packages (RAM's). The bits in the memory are directly related to the points displayed on the TV monitor in a 256-by-256 point array. One 16-bit computer word is used to address any point in memory with the lower 8-bit byte addressing the X (horizontal) axis of 256 (0-255) locations, and the upper 8-bit byte addressing the Y (vertical) axis of the 256 (0-255) locations.

91200B Principles of Operation

3-34. The input 16-bit computer word (IOBO 0 through IOBO 15) contains the address of the particular point in memory which is to be written or erased. The control signal NSTB strobes the memory input register and at NAC the computer word goes into the memory input register. The four least significant bits go into the RAM select storage. At the appropriate time, the word select (WS) signal goes high which enables the RAM select decoder to select a RAM. At the same time, the upper twelve bits are stored in the memory address register.

- 3-35. The 12 address lines from the memory address register are common to all 16 RAM's. Within each RAM package there is a 64-by-64 array (4,096 points). The lower six address lines (A0 through A5) are used for row selection and the upper six address lines (A6 through A11) are used for column selection. The output of the RAM select decoder (which is a pair of 256-bit read only memorys) will select only one RAM package. This pre-programmed ROM applies the chip select (NCS) signal to the addressed RAM.
- 3-36. The previously issued control word with mode information will determine whether a write or erase operation is to take place. NWE becomes low for write enable or high for read enable according to the gating (by U31) of the R/W signal from the control module and the CLK/8 signal from the timing module. The write/erase (W/E) signal is applied to all 16 RAM data input terminals. A logic low writes the point and a logic high erases the point.
- 3-37. On the selected RAM, the select terminal receiving the NCS signal effects the data-in, data-out, and write enable inputs. An NCS low enables data-in and data-out terminals to perform read/write operations. The NCS input must be low and all address lines must be stabilized on or before the rising edge of the clock CE signal. All read/write operations take place when the clock CE input is high. When the clock CE line is low, no operation can take place.
- 3-38. Refresh of the RAM's takes place more than ten times every two milliseconds by reading through the 64 row addresses of each of the 16 RAM's. The refresh takes place by reading in the following manner: When the WS signal high is present, the timing signals from the timing module (HS and CLK) are stored in the memory address register. WS also holds the select decoder in a preprogrammed state where all NCS lines are low to select all 16 RAM's simultaneously. Upon application of the NAC signal to the clock input of the memory address register, the timing signals are transferred onto the address lines. The read cycle continues when the CE input goes high on all RAM's.
- 3-39. The memory output 16-bit shift register operates with parallel input from the RAM's and serial shift output to U61 to provide the video output bit stream for each point of the video display in sixteen 16-bit increments for each 256 point line. The state of the NLD signal, applied to the shift/load input, establishes the input or output mode. When NLD goes low, parallel loading of DOUT 0 through DOUT 15 from the addressed RAM occurs on the next

NCLK clock pulse. Bit DOUT 0 is immediately available to U61. When NLD goes high, serial shifting of the data into U61 occurs with each NCLK clock pulse starting with DOUT 1. The polarity signal (POL) shifts in, replacing the data bits shifting out to fill the register.

3-40. When the 16th NCLK pulse after NLD high occurs, NLD goes low again which will load a second set of 16-bits from the addressed RAM. DOUT 0 of the second data word becomes immediately available to U61 followed by NLD high and NCLK to shift DOUT 1 to the output position, etc. Starting at the beginning of a horizontal line, after 16 parallel loads and shifts a total of 256 points have been output. Then NLD remains high so no more loading occurs, NCLK continues and the shift register output bits resulting from POL are applied to U61 pin 1 for blanking. The horizontal blanking period continues as long as NLD is high, lasting for 64 clock pulses. NLD then goes low to repeat loading data for the next line.

3-41. VIDEO SECTION

- 3-42. During the blanking period, the output (pin 3) of exclusive "or" gate U61 will be low. This is because POL, direct and through the register, is applied to the gate's two inputs (when both inputs of an exclusive "or" are the same, the output is low). The level is inverted in U81 "nand" gate to apply a high level to the video amplifier. A high level at this point results in a black (or blanked) level in the display.
- The blanking activity described above for the horizontal line is repeated for the vertical period after the bottom line has been displayed. The blanking period for vertical retrace is determined by the operating mode (I, II, or III). The blanking generator inhibits NLD (ground-true signal) to provide a high whenever either vertical (NVB), horizontal blanking (HB, NHB), or FLD1 through jumper W11 occurs. The load signal (LD), the source of NLD, appears once every 16 clock pulses at the blanking generator input. The CLK/64 and CLK/256 timing signals function as control in selecting the blanking period, being "and" gated with the horizontal blanking signals HB and NHB. Normally, jumper W11 is absent and therefore field one input is always high. Installation of jumper W11 inhibits the second field in the interlace mode to accentuate discrete points in the Y axis. (Information in only one field is displayed.) In this case, the TV monitor should have a long persistence phosphor screen CRT to reduce screen flicker. When FLD1 goes low coincident with the second field, the output NLD signal is inhibited (signal is high) and provides blanking for the entire second field as explained in paragraph 3-40.
- 3-44. U81 clocks each display bit as long as jumper W6 is installed. When W6 is removed, the pull-up resistor on pin 1 holds the gate continuously open so that the discrete data points in memory merge together as lines (refer to figure 3-1B showing clocked and unclocked waveforms).

- 3-45. Polarity inversion of the video display is controlled in U61 in the following manner. When the polarity line POL is low and the display bit is high, the output of U61 is high resulting in white (or color) which is the normal convention. If POL is programmed high, then when the display bit is also high, the result is a low output for black. Therefore, programming POL from the normal low to high inverts the video display from white-on-black to black-on-white (or color complements in color displays).
- 3-46. The video circuitry includes three transistors (Q1, Q2, and Q3), an inverter (U70), and operational amplifier (U1) and 5 volt regulator U10. The output from "nand" gate U81 is the raw video routed to inverter U70 then to the operational amplifier U1 for multiple gray-scale operation or routed through jumper W1-A to video amplifier Q1 for single BW or color operation.
- 3-47. During black-and-white or color operation jumper W1-A is installed. Raw video is applied to Q1 and

the sync signal is applied to Q2. The collectors of transistors Q1 and Q2 are tied together to provide the output composite video signal with sync. The composite video output has a 75-ohms source impedance to drive 75-ohm coaxial cable with the video levels of white at 0 volt, black at -1 volt, and sync at -1.4 volts. The sync output from Q3 is a 4.0-volt (nominal) negative-going pulse.

3-48. In multi-level gray or color operation, two or three TV interface cards may be used. Refer to Section II for card configuration information. One card is designated the master (card A) and the others are slaves (cards B and C). During multi-level gray operation, the raw video signals from all the cards are summed at the input of the operational amplifier (U1) on the master card to produce a single video signal going to Q1 through jumper W1-B. Sync is added by Q2 as in single card operation. Three controls (R5, R6, and R7) allow minor level adjustments (refer to figure 2-5).

SERVICE

SECTION

IV

4-1. INTRODUCTION

4-2. This section describes a diagnostic test procedure which checks the TV interface card for proper operation. The description of the test procedure is supported by example test patterns.

4-3. EQUIPMENT REQUIRED FOR TEST

- 4-4. The following items are required to run a diagnostic test of the TV interface card:*
- a. An HP 2100A/S or HP 21MX Computer.
- The diagnostic paper tape, part no. 91200-16003, furnished as part of the kit.
- c. An input device to enter the program into memory (e.g., an HP 2748B Tape Reader) with its interface card and cable.
- d. The TV monitor interconnecting cable, part no. 91200-60006, or multiple-card cable assembly, part no. 91200-60008, or user fabricated cables according to figures 2-2 and 2-4.
- e. User supplied TV monitor.

4-5. DIAGNOSTIC TEST PROCEDURE

- 4-6. The diagnostic program consists of a go no-go test, a super test for examination of individual patterns, a RAM test, and a color bar or gray-level bar test pattern. The test results appear on the display register of the computer and the test patterns are shown on the TV monitor.
- 4-7. The purpose of the diagnostic is to allow the operator to do the following:
- a. Check the TV interface card for proper operation.
- Check and adjust the TV monitor horizontal and vertical gain and positioning.
- c. Check and adjust the TV monitor focus.
- d. Check and adjust the TV monitor for pin cushion distortion and linearity.
- e. For multiple card installations, adjust gray scale or color.
- *Next lower priority (higher numbered) I/O slot must have an interrupt type I/O card installed in it or an "error 7" will occur.

- f. Check the TV interface card for missing storage bits.
- g. Check the erase time using a 44 ms software timer.

4-8. TEST PROGRAM CONFIGURATION

- 4-9. The following procedure assumes the programmer/operator is familiar with the operation of his computer. The diagnostic is an absolute program that can be loaded into the computer at any time, off-line from the main operating system. The procedure is as follows:
- a. Examine the TV interface card jumpers to be certain of the scan mode of operation.
- b. Be sure that the TV interface card (or cards) is installed in the computer I/O slot in the proper order. The proper order is determined by the required I/O slot order of the system in which it is being used. Ensure that the card is seated firmly, and see that the video cable is connected to the TV monitor. (Installation of the TV interface card must follow the rules for I/O card installation in HP 2100-Series Computers. Refer to the appropriate manuals as required.)
- c. Refer to the applicable procedure in paragraph 4-31 or 4-34, respectively, for basic binary loader (BBL) in HP 2100A/S Computers or initial binary loader (IBL) in HP 21MX Computers.
- d. Load the diagnostic program, HP part no. 91200-16003. This is an absolute program requiring the BBL, or IBL, to load. Re-roll and store the tape.
- e. Set up the P-register to display on the DISPLAY RE-GISTER and enter 000003 (octal), the starting address of the diagnostic program. Press STORE on the HP 21MX Computer only, on this and subsequent storage steps for the S- and P-registers.
- f. Set the switch register bits 0 through 5 to the select code of the TV interface card (computer I/O slot of the one card or I/O slot of master card).
- g. Press PRESET, then RUN. The program should halt, displaying 102000 (octal).
- h. Set and store** the switch register bit 0 through 2 for the model number of the computer using the following octal codes:

HP 2100A/S 000000

HP 21MX 000003

^{**}HP 21MX-Series Computers only.

- Press RUN. The program will HALT with a display of 102001 (octal).
- Set and store* the switch register bit 0 for the scan mode used according to the following codes:

American Scan

Set to 1

European Scan

Set to 0

Non-Standard Scan

Set to 0

k. Press RUN. The program will halt with a display of 102077 (octal). This is a final halt for initial setup. Proceed to one of the tests below.

4-10. GRAY SCALE OR COLOR

For all the following tests where gray scale or color operation is used, the switch register bits 0 through 3 must be set for the desired BW or color display. For single BW monitors these bits should be 0 for normal operation. Use one of the codes listed in table 4-1.

Table 4-1. Color and Gray Scale Codes

SW REG. 2-1-0	3-CARD COLOR	3-CARD BW	2-CARD COLOR	2-CARD BW
0-0-0	White	7/8 wh	Yellow	3/4 wh
0-0-1	Black	Black	Black	Black
0-1-0	Red	1/2	Red	1/2
0-1-1	Green	1/4	Green	1/4
1-0-0	Blue	1/8	Black	Black
1-0-1	Yellow	3/4	Yellow	3/4 wh
1-1-0	Magenta	5/8	Red	1/2
1-1-1	Cyan	3/8	Green	1/4
	I	1	1	1

Notes: 1. If black is selected, no pattern will appear on the

2. Switch register bit 3, when set to 1, reverses video porarity. Refer to table 3-4 for details.

4-12. GO NO-GO TEST

- 4-13. The go no-go test is a quick operational check of the TV interface card. This test contains subroutines which allow an I/O check, display of the test patterns, and a flashing HP logo. Subsequent steps in the following procedure give the starting addresses of these subroutines. The procedure assumes that the diagnostic test setup specified in paragraph 4-8 has been implemented. The procedure is as follows:
- Select the P-register of the computer, enter and store* 00002 (octal).
- Select the S-register CLEAR DISPLAY, and change and store* any bits from 0 to 1 for the desired option as follows:

table 4-1). Bit 15 If set, test repeats. Bit 14 If set, colors will automatically

be cycled by incrementing bits 0, 1, and 2 of the switch register giving a new color for each pass.

Color and video polarity (refer to

Black is skipped.

Press PRESET, then RUN.

Bits 0 thru 3

The first part of the test checks all I/O instruc-4-14. tions. Program halt octal codes showing in the display register indicate the following conditions:

102077 Test passed after all patterns displayed and HP logo flashed.

102002 Test failed. Indicated bulk erase is not completing.

Test failed. Indicates I/O failure accord-102005 ing to the code stored in A- and B-registers as follows:

0 — Flag not set, or bad SFS.


1 - SFC bad.

- 2 Mode problem, flag not setting at end of mode.
- 3 Flag not clearing, or mode not clearing.
- 4 SFC bad.
- 5 Select code decoding bad (LSB).
- 6 Select code decoding bad (MSB).
- 7 Priority chain bad in TV card, or interrupt card not installed in next lower priority slot.
- 10 No interrupt.
- 11 No write response.


Following an error halt 102005 (octal), pushing RUN will cause the I/O check to be repeated without continuing with the other tests.

If no errors are detected, the test continues with pattern displays. Each pattern is held briefly in the following order: gain, crosshatch, settling time, all points, and HP logo. The patterns (except for all points) are shown in figure 4-1. The crosshatch pattern is modified to selectively erase all points in the pattern in the same order as they were written. The all points pattern erases selectively all points of the screen in the opposite order from the writing order.


^{*}HP 21MX-Series Computers only.




(A) NON-STANDARD & EUROPEAN STANDARD GAIN TEST PATTERN 256X256



(B) GAIN TEST PATTERN (AMERICAN) 256X240



(C) CROSSHATCH TEST PATTERN (NON-STD, EUROPEAN) 256X256



(D) CROSSHATCH TEST PATTERN (AMERICAN STD) 256X240




Figure 4-1. Diagnostic Test Patterns (continued)

- 4-16. After patterns, the test continues with a test of video polarity switching. If white is selected, the HP logo is displayed in white with a black background then changes to black on white. If color was selected, the display first shows the background in the complementary color followed by the logo in the selected color, then the polarity reverses at half the rate of the white-to-black flashing.
- 4-17. To continuously repeat the I/O check for troubleshooting, set the octal starting address in the P-register to 000103 (octal) and enter 1 in bit 15 of the S-register. Press RUN. To repeat the test only once, set bit 15 in the switch register to 0. The program will start by pressing RUN at this address following a halt 102005 (octal).
- 4-18. To display patterns only, set the octal starting address in the P-register to 000101 (octal). Press RUN.
- 4-19. To perform only the video polarity test with the flashing logo, set the octal starting address in the P-register to 000102 (octal). Press RUN.

4-20. SUPER TEST

4-21. The super test provides six different test patterns to allow adjustment of the TV monitor. They will also assist in finding defects in point writing. The patterns may be displayed singly or sequentially at the users discretion. Time delay between sequential patterns is selectable and any one pattern can be continuously flashed in a video polarity reversal mode at a user selected rate. The color may be selected for the patterns at any time. Super test selections and conditions using the computer switch register are listed in table 4-2.

- 4-22. To run the super test, proceed as follows:
- a. If the program is not already loaded and configured, perform the procedure described in paragraph 4-8.
- b. Set up the starting address 000100 (octal) in the P-register.
- c. Clear the S-register.
- d. Press RUN.
- e. Select the desired test selections and conditions from table 4-2 and enter them in the S-register.
- f. Perform the following test familiarization procedures if desired:
 - (1) Set switch 4 to display the gain test once. See figure 4-1(A) for the 256 by 256 scan and figure 4-1(B) for the 256 by 240 scan.
 - (2) To change the display to the crosshatch test pattern, set switch 5. This display is shown in figures 4-1(C) and (D) for the two different scan modes.
 - (3) Set switches 6 through 8, one after the other, to view the remainder of the displays.
 - (4) To repeat a pattern, or patterns, continuously with approximately 5 seconds delay between patterns, set switch 15 then the switches for the test patterns desired.
 - (5) To shorten the delay time between patterns to about 1 second, set switch 13.

Table 4-2. Super Test Selections and Conditions

SWITCH REGISTER OPTIONS:

TEST CONDITIONS

SW NO.	SETTING	ACTION
0-2*		Color or Gray Scale selection as given in table 4-1.
3*	0 1	Video polarity normal. Video polarity inverted.
15	0 1	Individual test occurs once when test switch set to 1**. Tests continue, showing patterns selected by switches 4-8, and repeat at intervals set by time delay (switches 11-13 below).
14	0 1	Tests continue. Halt 102077 (octal) at end of test (super test may be restarted by pressing RUN). This bit will clear upon halt.
13*	0 1	Time delay is about 5 seconds unless switch 12 is set. Time delay is about 1 second unless switch 12 is set.
12*	0 1	Time delay is selected by switch 13. Time delay is less than 1 second.
11*	0 1	Standard time delays. Repetition speed-up (about 3 times faster).
10	0 1	Normal operation. Alternating video polarity (flashing pattern) at the rate set by switches 11-13, if switch 15 is 0.

TEST

Switches 4-8 select the test:

4	GAIN	Approximate gain, position, and focus adjust. A square or rectangle is drawn around the circumference of the TV (256 x 256 or 256 x 240), enclosing a pattern of arrows pointing to the center. Shown in figures 4-1(A) and (B).	
5	CROSS	Crosshatch for precision adjustments. A grid of horizontal and vertical lines are drawn covering the entire TV screen. The center lines are heavy, allowing adjustment of position. Shown in figures 4-1(C) and (D).	
6	ALL PTS	All Points Test. All matrix points are written.	
7	SQUARES	Corner and Settling Time Test. An 8 x 8 square is drawn in each of the four corners of the TV screen. Shown in figure 4-1(E).	
8	LOGO	Writes title with HP logo. Shown in figure 4-1(F).	
9	BLANK	Erases screen.	

^{*}Can be changed at any time. Takes effect on next generated pattern.

Note: HALT 102002 (octal) indicates that the erase time exceeded the specification. You may proceed by pressing RUN.

^{**}Test switch clears automatically.

- (6) To shorten the delay times to less than 1 second, set switch 12. Note that switch 12 overrides switch 13.
- (7) For minimum delay, set switches 11 and 12.
- 4-23. A combination of patterns is usually desired for TV monitor adjustment. A typical method using the super test is as follows:
- Gain pattern to adjust the controls for monitor gain position, and focus.
- b. Crosshatch pattern to adjust pattern curvature (pin cushion), linearity, and color monitor convergence.
- c. All points test to determine if all points are being written and to check sync capability by immediately setting another test switch to see if sync is momentarily lost. If sync is marginal, possibly external sync should be considered.
- d. Settling time pattern (squares in corners) to check monitor settling time (if specified by TV monitor manufacturer).
- e. Check of the inverting video polarity writing capability by selecting the appropriate test condition (switch 3 set to 1).

4-24. RAM TEST

- 4-25. The random access memory (RAM) test allows the test of RAM's individually. The super test, described under paragraph 4-20, allows writing of all matrix points. Thus, if a point is detected in the super test as not being written or erased, the malfunctioning RAM may be quickly identified. In the super test pattern, the unwritten point may be marked with a grease pencil to locate it during the RAM test. In this test, each RAM is addressed individually and the resultant display is comprised of 16 vertical lines positioned according to the locations written by that particular RAM. Absence of a line, or part of it identifies a faulty RAM.
- 4-26. There are 16 RAM's numbered from 0 through 17 (octal) to cover 256 horizontal points. RAM 0 contains all points with horizontal (X) addresses of 0,16,32 to 240 with 0 being furthest on the left side of the screen. RAM 1 contains all points with horizontal (X) addresses of 1,17,33 to 241. Similarly RAM's 2 through 17 cover the remaining addresses with RAM 17 containing all points with horizontal (X) addresses of 15,31,63 to 255.
- 4-27. The procedure for operating the RAM test is as follows:
- a. If the program is not already loaded and configured, perform the procedure specified in paragraph 4-8.
- b. Enter the starting address of 002000 (octal) in the P-register.

- c. Set the RAM number desired from 0 through 17 (octal) (as described above) in switch register bits 12 through 15; e.g., 120000 (octal).
- d. For color, set bits 0 through 2, according to table 4-1, in the switch register along with the RAM number.
- e. Press PRESET, then RUN. A halt is always observed — for convenience the halt code contains the RAM number selected; e.g., 102012 (octal) for RAM 12 (octal). Normally, this will display all points of 16 vertical lines.

Note: HALT 102002 (octal) may indicate that the erase time exceeded specification if RAM 2 were not programmed and the RAM pattern was not displayed. To distinguish from RAM 2, try another RAM. Proceed by pressing RUN.

- f. Press RUN again. Observe a HALT with all points in the selected RAM selectively erased. The halt code will agree with the RAM selected.
- g. Repeat steps c,d,e, and f until all RAM's have been checked or a faulty RAM isolated. The RAM number (octal 0 through 17) in this procedure corresponds with the RAM numbers shown in figure 2-1.

4-28. COLOR BAR TEST

- 4-29. For multicard systems, all colors (or all levels of gray) can be displayed in a bar pattern. The pattern is shown in figure 4-2(A) for three cards and 4-2(B) for two cards. Each bar is a different color (or gray level) with black on the left and white on the right as labeled on the bars in figure 4-2. If this pattern is selected for a one-card system, the screen is black on the left half and white on the right half and lower portion. To select the color bar pattern, proceed as follows:
- a. Enter the starting address of 000104 (octal) into the P-register.
- b. Set bits into the switch register the same as in the super test for switch register bits 15,13,12,11, and 10, if repeating or flashing of the pattern is desired.
- 4-30. The color bar pattern can be used for setting tint controls on color monitors or for setting the three adjustment controls on the TV interface master card for multilevel gray. Also the black-and-white monitor can be adjusted for contrast and brightness.

4-31. HP 2100A/S COMPUTER BBL

4-32. The Basic Binary Loader (BBL) is a sequence of instructions which will load, into the computer memory, programs prepared with absolute addresses, using defined input devices. The instructions are stored in the highest

91200B




Figure 4-2. Color Bar or Multilevel Gray Test Pattern

64 memory locations of your computer. Whenever you encounter a procedure directing the use of the Basic Binary Loader to load an absolute binary tape, use the procedure described here. The procedure will identify the particular tape to be loaded.

- 4-33. The standard input device for these procedures will be a high-speed tape reader or the teleprinter tape reader (no high-speed tape reader in the system). Loading is accomplished as follows:
- a. Turn on the input device and prepare for reading (e.g., load tape in tape reader). The input program must be in binary form, containing absolute addresses.
- b. Press S to select the S-register. This will cause the S-register contents to be displayed in the DISPLAY REGISTER.
- c. Clear bits 0 and 15 of the display. (These bits are to be set only for certain nonloading check operations; refer to software operating manual.) The status of the remaining bits is not significant.
- d. Press P to select the P-register. This will cause the P-register contents to be displayed in the DISPLAY REGISTER.
- e. Set the display to the starting address of the basic binary loader, according to table 4-3.

Table 4-3. Starting Address for Basic Binary Loader

MEMORY SIZE	OCTAL STARTING ADDRESS
4K	07700
8K	17700
12K	27700
16K	37700
24K	57700
32K	77700

- f. Press EXTERNAL PRESET and INTERNAL PRE-SET. This initializes the external hardware (I/O channels) and the internal hardware (central processor).
- g. Press LOADER ENABLE, and then press RUN. The lights for both switches will remain on while the input operation is in progress.
- h. When the input device stops, the HALT light will go on, RUN and LOADER ENABLE lights will go off, and the DISPLAY REGISTER should indicate 102077 (octal), with MEMORY DATA automatically selected. The load is complete.

4-34. HP 21MX COMPUTER IBL

4-35. This procedure describes a cold start using the standard paper tape loader ROM, which will allow a pro-

gram to be loaded via a punched-tape reader. At the rear of the computer, set the \sim LINE and BATTERY switches to ON and proceed as follows:

- a. On the operator panel, set key-operated switch to OPERATE.
- b. Press left half (◀) or right half (▶) of Register Select switch to select S-register.
- c. Press CLEAR DISPLAY and set bits 6 through 11 to display octal select code of tape reader.
- d. Set bits 15 and 14 to zeros to select standard paper tape loader ROM.
- e. Press STORE and then press IBL. The paper tape loader is now loaded into the uppermost 64 locations of memory and the select code of the tape reader is patched according to the contents of the S-register. The P-register is now pointing to the first instruction of the loader.
- f. Turn on tape reader and prepare it for reading. Press PRESET and then press RUN. The program will now be read into memory and the computer will halt with the T-register selected automatically. A successful load is indicated if the Display Register contents are 102077 (octal).

To run a program after it has been loaded, proceed as follows:

- a. Press left half (◀) or right half (▶) of Register Select switch to select P-register.
- b. Press CLEAR DISPLAY and set Display Register to starting address of program.
- c. Press STORE, PRESET, and RUN.

The RUN indicator will remain lighted as long as the program is running. If the key-operated switch is set to OPERATE, all operator panel controls except the Display Register, CLEAR DISPLAY, and HALT switches are disabled. The S-register is displayed automatically and can be changed manually via the Display Register bit switches. If the key-operated switch is set to LOCK, the RUN and HALT switches are disabled and all other switches are enabled within the constraints of the run and halt modes.

4-36. ERROR HALTS

4-37. If the halt code is not 102077 (octal) when the device stops, there has been an error in the loading process. Two possible error conditions are indicated by the loader, which changes the halt code to identify the type of error. A halt code of 102055 (octal) indicates an address error, check if the proper tape is being read, or if it is in backwards. A halt code of 102011 (octal) indicates a checksum error; check for possible bad tape, or dirty tape reader or tape.



SALES & SERVICE OFFICES AFRICA, ASIA, AUSTRALIA

ANGOLA
Telectra
Empresa Técnica de
Equipamentos
Eléctricos, S.A.R.L.
R. Barbosa Rodrigues, 42-1°DT.ª
Caixa Postal, 6487

Luanda Tel: 35515/6 Cable: TELECTRA Luanda

AUSTRALIA
Hewlett-Packard Australia
Pty. Ltd.
31-41 Joseph Street
Blackburn, Victoria 3130
P. 0. 8bx 36
Doncaster East, Victoria 3109
Tel: 89-6351

Telex: 31-024 Cable: HEWPARD Melbourne Hewlett-Packard Australia Pty. Ltd. 31 Bridge Street

Pymble
New South Wales, 2073
Tel: 449-6566
Telex: 21561
Cable: HEWPARD Sydney

Cable: HEWPARD Sydney
Hewlett-Packard Australia
Pty. Ltd.
153 Greenhill Road
Parkside, S. A., 5063
Tel: 272-5911
Telex: 82536 ADEL
Cable: HEWPARD ADELAIDe

Cable: HEWPARD ADELAI(
Hewlett-Packard Australia
Pty.Ltd.
141 Stirling Highway
Nedlands, W.A. 6009
Tel: 86-5455
Telex: 93859 PERTH
Cable: HEWPARD PERTH

Cable: HEWPARD PERTH
Hewlett-Packard Australia
Pty. Ltd.
121 Wollongong Street
Fyshwick, A. C. T. 2609
Tel. 95-2733
Telex: 62650 Canberra
Cable: HEWPARD CANBERRA

Hewlett Packard Australia
Pty. Ltd.
Sth Floor
Teachers Union Building
495-499 Boundary Street
Spring Hill, 4000 Queensland
Tel: 229-1544
Cable: HEWPARD Brisbane

GUAM Medicai/Pocket Calculators Only Guam Medical Supply, Inc. Jay Ease Building, Room 210 P.O. Box 8947 P.U. Box 8947 Tamuning 96911 Tel: 646-4513 Cable: EARMED Guam

HONG KONG Schmidt & Co. (Hong Kong) Ltd. P. 0. Box 297 Connalight Centre 39th Floor Connaught Road. Central Hong Kong Tel: H-252291-5 Telex: 74766 SCHMC HX Cable: SCHMIDTCO Hong Kong

INDIA Blue Star Ltd. Kasturi Buildings Jamshedji Tata Rd. Bombay 400 020 Tel: 29 50 21 Telex: 2156 Cable: BLUEFROST Blue Star Ltd. Sahas 414/2 Vir Savarkar Marg

Prabhadevi Bombay 400 025 Tel: 45 78 87 Telex: 4093 Cable: FROSTBLUE Blue Star Ltd. Band Box House Prabhadevi Bombay 400 025 Tel: 45 73 01

Telex: 3751 Cable: BLUESTAR Blue Star Ltd. 14/40 Civil Lines Kanpur 208 001 Tel: 6 8 82 Tel: 6 88 02 Telex: 292 Cable: BLUESTAR

7 Hare Street 7 Hare Street P.O. Box 506 Calcutta 700 001 Tel: 23-0131 Telex: 7655 Cable: BLUESTAR Blue Star Ltd.
7th & 8th Floor
Bhandari House
91 Nehru Place
New Delhi 110024
Tel: 634770 & 635166
Telex: 2463
Cable: BLUESTAR

Cable: BLUESTAR
Blue Star Ltd.
Blue Star House
11/11A Magarath Road
Bangalore 560 025
Tel: 5568
Telex: 430
Cable: BLUESTAR

Blue Star Ltd. Meeakshi Mandiran wiedaksni Mandiran xxx/1678 Mahatma Gandhi Rd. Cochin 682 016 Tel: 32069, 32161, 32282 Telex: 046-514 Cable: BLUESTAR Blue Star Ltd.
1-1-117/1
Sarojiini Devi Road
Secunderabad 500 003
Tel: 70126, 70127
Cable: BLUEFROST
Telex: 459

Telex: 459 Blue Star Ltd. 2/34 Kodambakkan High Road Madras 600034 Tel: 82056 Telex: 041-379 Cable: BLUESTAR Blue Star Ltd.
Nathraj Mansions
2nd Floor Bistupur
Jamshedpur 831 001
Tel: 7383
Cable: BLUESTAR
Telex: 240

INDONESIA BERCA Indonesia P.T. P.O. Box 496 1st Floor JL, Cikini Raya 61 Tel: 56038, 40369, 49886 Tel: 56038, 40369, 49886 Telex: 42895 Cable: BERCACON BERCA Indonesia P.T. 63 JL. Raya Gubeng

ISRAEL ISRAEL
Electronics & Engineering Div. of Motorola Israel Ltd.
17. Kremenetski Street
P. O. Box 25016
Tel-Aviv
Tel: 38973
Telex: 33569
Cable: BASTEL Tel-Aviv

JAPAN JAPAN
Yokogawa-Hewlett-Packard Ltd.
Ohashi Building
59-1 Yoyogi 1-Chome
Shibuya-ku, Tokyo 151
Tel: 03-370-2281/92 Telex: 232-2024YHP Gable: YHPMARKET TOK 23-724 Yokogawa-Hewlett-Packard Ltd. Seiko Ibaraki Building 2-8 Kasuga 2-chome, Ibaraki-shi Osaka, 567

Yokogawa-Hewlett-Packard Ltd. Nakamo Building 24 Kami Sasajima-cho Nakamura-ku, **Nagoya**, 450 Tel: (052) 571-5171

Tel: (US2) 5/1-51/7
Yokogawa-Hewlett-Packard Ltd.
Tanigawa Building
2-24-1 Tsuruya-cho
Kanagawa-Ku
Yokohama, 221
Tel: 045-312-1252
Telex: 382-3204 YHP YOK

Osaka,567 Tel: (0726) 23-1641 Telex: 5332-385 YHP OSAKA

Yokogawa-Hewlett-Packard Ltd. Mito Mitsu Building 105. Chome-1, San-no-maru Mito, Ibaragi 310 Tel:: 0292-25-7470

Yokogawa-Hewlett-Packard Ltd. Inoue Building 1348-3. Asahi-cho. 1-chome Atsugi. Kanagawa 243 Tel: 0462-24-0452

Tel: 0462-24-0452
Yokogawa-Hewlett-Packard Ltd.
Kimura Building
3rd Floor 20
2-chome, Tsukuba
Kumagaya, Saitama 360
Tel: 0485-24-6563

KENYA Technical Engineering Services (E A.)Ltd..

P.O. Box 18311 **Nairobi** Tel: 557726/556762 Cable: PROTON Medical Only International Aeradio(E.A.)Ltd.. P.O. Box 19012 Nairobi Airport

Nairobi Tel: 336055/56 Telex: 22201/22301 Cable: INTAERID Nairobi

Cable: INTACHID Nairobi
KOREA
Semsung Electronics Co., Ltd.
20th Fi. Dongbang Bildg 250,2-KA
C.P.O. Box 2775
Taepyung-Ro. Chung-Ku
Seoul
Tel: (23) 6811
Telex: 22575
Cable: ELEKSTAR Seoul
MALA MASUA

MALAYSIA
Teknik Mutu Sdn. Bhd.
2 Lorong 13/6A
Section 13
Petaling Jaya, Selangor
Tel: 54994/5496
Telex: MA 37605 Protel Engineering P.O. Box 1917 Lot 259. Satok Road Kuching, **Sarawak** Tel: 2400 Cable: PROTEL ENG

MOZAMBIQUE
A.N. Goncalves, Lta.
162, 1° Apt. 14 Av. D. Luis
Caixa Postal 107 Lourenco Marques
Tel: 27091, 27114
Telex: 6-203 NEGON Mo
Cable: NEGON

NEW ZEALAND Hewlett-Packard (N.Z.) Ltd. P.O. Box 9443 Courtney Place Wellington Tel: 877-199 Telex: NZ 3839 Cable: HEWPACK Wellington

Hewlett-Packard (N.Z.) Ltd. Pakuranga Professional Centre 267 Pakuranga Highway Box 51092 Pakuranga Telex: NZ 3839 Cable: HEWPACK,Auckland

Cable: HEWPACK, Auckland
Analytical/Medical Only
Medical Supplies N. Z. Ltd.
Scientific Division
79 Cartion Gore Rd. . Newmarket
P. O. Box 1234
Auckland
Tel: 75-289
Telex: 2958 MEDISUP
Cable: DENTAL Auckland
Applical/Medical Only
Applications of the Auckland
Applications of the Auckland
Applications of the Auckland

Analytical/Medical Only Medical Supplies N.Z. Ltd. P. O. Box 1994 147-161 Tory St. Wellington Tel: 850-799 Telex: 3858 Cable: DENTAL, Wellington

Analytical/Medical Only Medical Supplies N.Z. Ltd. P.O. Box 309 239 Stammore Road Christchurch Tel: 892-019 Cable: DENTAL, Christchurch

Analytical/Medical Only Medical Supplies N.Z. Ltd 303 Great King Street P.O. Box 233

Dunedin Tel: 88-817 Cable: DENTAL, Dunedin

NIGERIA The Electronics
Instrumentations Ltd.
N6B/770 Oyo Road Oluseun House
P.M.B. 5402
Ibadan
Tel: 61577
Telex: 31231 TEIL Nigeria
Cable: THETEIL Ibadan The Electronics Instrumenta-tions Ltd 144 Agege Motor Road, Mushin P.O. Box 6645

Lagos Cable: THETEIL Lagos

PAKISTAN Mushko & Company, Ltd. Oosman Chambers Addullah Harroon Road Karachi-3 Tel: 511027, 512927 Telex: KR894 Cable: COOPERATOR Karachi Cable: COOPERATOR Karai Mushko & Company, Ltd. 38B. Satellite Town Rawalpindi Tel: 41924 Cable: FEMUS Rawalpindi

PHILIPPINES
The Online Advanced Systems Corporation 6th Floor, Yujui Co. Bldg. 560 Quintin Paredes St. Binondo, **Manila**Tel: 48-71-49, 48-68-53
In Makati: 85-35-81, 85-34-91
Telex: 3274 ONLINE

RHODESIA Field Technical Sales 45 Kelvin Road North P.O. Box 3458 Salisbury Tel: 705231 (5 lines) Telex: RH 4122

SINGAPORE SINGAPORE
Hewlett-Packard Singapore
(Pte.) Ltd.
3841F. Jalan Bukit Merah
Bik. 2. 6th Floor, Jalan
Redmill Industrial Estate
Alexandra P. 0. Box 58.
Singapore 3.
Tel: 633022
Telex: HPSG RS 21486
Cable: HEWPACK, Singapore

Cable: HEWPACK. Singapore
SOUTH AFRICA.
Hewlett-Packard South Africa
(Pty.), Ltd.
Private Bag Wendywood
Sandton. Transvaal 2144
Hewlett-Packard Center
Daphne Street. Wendywood.
Sandton. Transvaal 2144
Tel: 802-104018
Telex. 8-4782
Cable: HEWPACK JOHANNESBURG
Service Penartment

Service Department Hewlett-Packard South Africa (Pty.), Ltd. P.O. Box 39325 Gramley, Sandton, 2018 451 Wynberg Extension 3. Sandton, 2001 Tel: 636-8188/9 Telex: 8-2391 Hewlett-Packard South Africa

(Pty.), Ltd.
P. O. Box 120
P. O. Box 120
Pine Park Center, Forest Drive,
Pinelands, Cape Province, 7405
Tel: 53-7955 thu 9
Telex, 57-0006

Service Department
Hewlett-Packard South Africa
(Pty.), Ltd.
P.O. Box 37099
Overport, Durban 4067 Braby House 641 Ridge Road **Durban**, 4001 Tel: 88-7478 Telex: 6-7954

TAIWAN Hewlett-Packard Far East Ltd.. Taiwan Branch 39 Chung Shiao West Road Sec. 1, 7th Floor Sec. 1, 7th Floor

Taipei
Tel: 3819160-4
Telex: 21824 HEWPACK
Cable: HEWPACK TAIPEI
HEWPACK TAIPEI
HEWPACK TAIPEI
HEWPACK TO TAIPEI
HEWPAC

68*2. Chung Cheng 3rd Road Kaohsiung Tei: (07) 242318-Kaohsiung Analytical Only San Kwang Instruments Co.. Ltd. No. 20, Yung Sui Road Taipei Teli 3715/7-4 (5 lines) Teleix 22894 SANKWANG Cable: SANKWANG TAIPEI

TANZANIA
Medical Only
International Aeradio (E.A.), Ltd.
P.O. Box 861
Dar es Salaam
Tel: 21251 Ext. 265
Telex: 41030

THAILAND
UNIMESA Co., Ltd.
Elcom Research Building
Bangjak Sukumvit Ave.
Bangkok
Tel: 932387, 930338
Cable: UNIMESA Bangkok

UGANDA UGANDA Medical Only International Aeradio(E.A.), Ltd P.O. Box 2577 Kampala Tel: 54388 Cable: INTAERIO Kampala

ZAMBIA
R.J. Tilbury (Zambia) Ltd
P.O. Box 2792
Lusaka
Tel: 73793
Cable: ARJAYTEE. Lusaka

OTHER AREAS NOT LISTED CONTACT: OTHER AREAS NOT LISTE Hewlett-Packard Intercontinental 3200 Hilliview Ave. Palo Alto. California 94304 Tel. (415) 493-1501 TWX: 910-373-1267 Cable: HEWPACK Palo Alto Telex: 034-8300, 034-8493

CANADA

ALBERTA Hewlett-Packard (Canada) Ltd 11620A - 168 Street 11620A - 168 Street EdmontonT5M 3T9 Tel: (403) 452-3670 TWX: 610-831-2431 EDTH Hewlett-Packard (Canada) Ltd 915-42 Ave S.E. Suite 102 Calgary T2G 121 Tel: (403) 287-1672 Twx: 610-821-6141

BRITISH COLUMBIA Hewlett-Packard (Canada) Ltd. 837 E. Cordova Street Vancouver V6A 3R2 Tel: (604) 254-0531 TWX: 610-922-5059 VCR

MANITOBA Hewlett-Packard (Canada) Ltd. 513 Century St. St. James St. James **Winnipeg** R3H OL8 Tel: (204) 786-7581 TWX: 610-671-3531

NOVA SCOTIA
Hewlett-Packard (Canada) Ltd.
800 Windmill Road
P.O. Box 9331
Dartmouth B2Y 3Z6
Tat. (2021, 459, 7820)

ONTARIO

ONTARIO
Hewiett-Packard (Canada) Ltd.
1020 Morrison Dr.
Ottawa K2H 8K7
Tel: (613) 820-6483
TWX: 610-513-1636 Hewlett-Packard (Canada) Ltd 6877 Goreway Drive Mississauga L4V 1M8 Tel: (416) 678-9430 TWX: 610-492-4246

QUEBEC Hewiett-Packard (Canada) Ltd 275 Hymus Blvd. Pointe Claire H9R 1G7 Tei: (514) 697-4232 TWX: 610-422-3022 TLX 05-821521 HPCL

FOR CANADIAN AREAS NOT LISTED: Contact Hewlett-Packard (Canada) Ltd. in Mississauga.

CENTRAL AND SOUTH AMERICA

ARGENTINA
Hewlett-Packard Argentina
S.A.
Av. Leandro N. Alem 822 - 12*
1001Buenos Aires
Tel: 31-6063.4,5,6 and 7
Telex: Public Booth N* 9
Cable: HEWPACK ARG

BOLIVIA Stambuk & Mark (Bolivia) Ltda. Av. Mariscal, Santa Cruz 1342 La Paz Tel: 40626, 53163, 52421 Telex: 3560014 Cable: BUKMAR

BRAZIL

Hewiett-Packard do Brasil I.e.C. Ltda. Avenida Rio Negro, 980 Alphaville 06400 Barueri **Sao Paulo** Tel: 429-2148/9;429-2118/9 Tel: 4.69-2140/9/4.63-2110/9 Hewlett-Packard do Brasil I.e.C. Ltda. Rua Padre Chagas, 32 90000-Pôrto Alegre RS Tel: (0512) 22-2998, 22-5621 Cable: HEWPACK porto Alegre Hewlett-Packard do Brasil I.E.C. Lttda. Rua Siqueira Campos. 53 Copacabana 20000-Rio de Janeiro Tel: 257-80-94-DDD (021) Telex: 39I-212-1905 HEWP-BR Cabie: HEWPACK Rio de Janeiro

CHILE
Calcagni y Metcalfe Ltda
Alameda 580-01. 807
Casilla 2118
Santiago, 1
Tel: 398613
Telex: 3520001 CALMET
Cable: CALMET Santago

COLOMBIA COLOMBIA
Instrumentación
Henrik A. Langebaek & Kier S.A.
Carrera 7 No. 48-75
Apartado Aéreo 6287
Bogotás, 10-Tel: 69-88-77
Cable: AARIS Bogotá
Teles: 044-400 COSTA RICA

COSTA RICA Científica Costarricense S.A. Calle Central, Avenidas 1 y 3 Apartado 10159 San José Tel: 21-86-13 Cable: GALGUR San José

ECUADOR Medical Only A.F. Viscalno Compañía Ltda Av. Rio Amazonas No. 239 P.O. Box 2925 Quito Tel: 242-150,247-033/034 Cable: Astor Quito

Calculators Only Computadoras y Equipos Electrónicos P.O. Box 2695 990 Toledo (y Cordero) Quito
Tel: 525-982
Telex: 02-2113 Sagita Ed
Cable: Sagita-Quito

EL SALVADOR Instrumentacion y Procesamiento Electronico de el Salvador Bulevar de los Heroes II-48 San Salvador Tel: 252787

GUATEMALA IPESA Avenida La Reforma 3-48. Zona 9 Guatemala City Tel: 63627. 64786 Telex: 4192 Teletro Gu

MEXICO Hewlett-Packard Mexicana. S.A. de C.V Torres Adalid No. 21, 111 Piso Col. del Valle Mexico 12, D.F. Tel: (905) 543-42-32 Telex: 017-74-507

Hewlett-Packard Mexicana. S.A. de C.V. Ave. Constitución No. 2184 Monterrey, N.L. Tel: 48-71-32, 48-71-84 Telex: 038-843

NICARAGUA NICARAGUA Roberto Terán G. Apartado Postal 689 Edificio Terán Managua Tel: 25114, 23412,23454 Cable: ROTERAN Managua

PANAMA Electrónico Balboa, S.A. P.O. Box 4929 Calle Samuel Lewis Cuidad de Panama Tel: 64-2700 Telex: 3431103 Curunda, Canal Zone Cable: ELECTRON Panama

PARAGUAY
Z J Melamed S R L
División: Aparatos y Equipos
Médicos
División: Aparatos y Equipos
Científicos y de Investigación
P. 0. 80x 676
Chile-482, Edificio Victoria Asunción Tel: 91-271, 91-272 Cable: RAMEL PERU

PARAGUAY

PERU
Compañía Electro Médica S.A.
Los Flamencos 145
San Isidro Casilla 1030
Lima 1
Tel. 41-4325
Cable: ELMED Lima

PUERTO RICO
Hewlett-Packard Inter-Americas
Puerto Rico Branch Office
Calle 272.
No 203 Urb. Country Club
Carolina 00924
Tel: (809) 762-7255
Telex: 345 0514

URUGUAY Pablo Ferrando S.A Comercial e Industrial Avenida Italia 2877 Avenida Italia 2877 Casilla de Correo 370 **Montevideo** Tel: 40-3102 Cable: RADIUM Montevideo

VENEZUELA Hewlett-Packard de Venezuela Hewiett-Packard de venez C.A. P.O. Box 50933 Caracas 105 Los Rúices Norte 3a Transversal Edificio Segre Caracas 107 Tel: 35-00-11 (20 lines) Telex: 25146 HEWPACK Cable: HEWPACK Caracas

FOR AREAS NOT LISTED, CONTACT:

FOR AREAS NOT LISTED
Hewlett-Packard
Inter-Americas
3200 Hillview Ave
Palo Alto, California 94304
Tel. (415) 493-1501
TWX: 910-373-1501
TWX: 910-373-1500
Cabie. HEWPACK Palo Alto
Telex: 034-8300. 034-8493

EUROPE, NORTH AFRICA AND MIDDLE EAST

AUSTRIA Hewlett-Packard Ges.m.b.H Handelskai 52 Handelskai 52 P.O. box 7 A-1205 **Vienna** Tel: (0222) 351621 to 27 cable: HEWPAK Vienna Telex: 75923 hewpak a

BELGIUM
Hewlett-Packard Benelux
S.A.N.V.
Avenue de Col-Vert, 1.
(Groenkraaglaan)
B-1170 Brussels
Tel: (02) 672 22 40
Cable: PALOBEN Brussels
Telex: 23 494 paloben bru

CYPRUS Kypronics & Xenopoulos Rd. P. O. Box 1152 CY-Nicosia Tel: 45628/29 Cable: KYPRONICS PANDEHIS Telex: 3018

CZECHOSLOVAKIA
Vyvojova a Provozni Zakladna
Vyzkumnych Ustavu v Bechovicich
CSSR-25097
Bechovice u Prahy
Tel: 89 93 41
Telex: 121333

Institute of Medical Bionics Vyskumny Ustav Lekarskej Bioniky Jedlova 6 CS-88346 Bratislava-Kramare Tel: 44-551 45-541

DDR Entwicklungslabor der TU Dresden Forschungsinstitut Meinsberg DDR-7305 Waldheim/Meinsberg

Tel: 37 667 Telex: 112145 retex: 112145
Export Contact AG Zuerich
Guenther Forgber
Schlegelstrasse 15
1040 Berlin
Tel: 42-74-12
Telex: 111889

DENMARK
Hewlett-packard A'S
Datavej 52
DK-3460 Birkerod
Tel: (02) 81 66 40
Cable: HEWPACK AS
Telex: 166 40 hpas Hewlett-Packard A S Navervej 1 DK-8600 Silkeborg Tel (06) 82 71 66 Telex 166 40 hpas Cable: HEWPACK AS

FINLAND Hewlett-Packard OY Nahkahousuntie 5 P O. Box 6 SF-00211 **Helsinki** 21 Tel (90) 6923031 Tel (90) 6923031 Cable HEWPACKOY Helsinki Telex: 12-1563 HEWPA SF

FRANCE FRANCE
Hewlett-Packard France
Quarter de Courtaboeuf
Boite Postale No 6
F-91401 Orsay Cédex
Tel (1) 907 78 25
Cable HEWPACK Orsay
Telex 600048 Hewlett-Packard France Agency Régionale "Le Saquin" Chemin des Mouilles B.P. 162 F-69130 **Ecully** Tel: (78) 38 B1 25. Cable: HEWPACK Eculy Telex: 31 06 17

relex 31 06 17
Hewlett-Packard France
Agence Régionale
Péricentre de la Cépière
Chemin de la Cépière, 20
F-31300 Toulouse-Le Mirail
Tel.(61) 40 11 12
Cable: HEWPACK 51957
Telex: 510957

Telex: 510957
Hewlett-Packard France
Agence Régionale
Aéroport principal de
Marseille-Marignane
F-13721 Marignane
Tel: (91) 89 12 36
Cable: HEWPACK MARGN
Telex: 410770
Hewlett-Packard France
Agence Régionale

Hewlett-Packard France Agence Régionale 63. Avenue de Rochester B.P. 1124 F-35014 **Rennes** Cédex Tel: (99) 36 33 21 Cable: HEWPACK 74912 Telex: 740912

reiex: 74U912
Hewlett-Packard France
Agence Régionale
74. Allée de la Robertsau
F-67000 Strasbourg
Tel: (88) 35 23 20'21
Telex: 890141
Cable: HEWPACK STRBG Hewlett-Packard France Agence Régionale Centre Vauban

Centre Vauban 201, rue Colbert Entrée A2 F-59000 Lille Tel: (20) 51 44 14 Telex: 820744 Telex: 820744
Hewlett-Packard France
Centre d' Attaires Paris-Nord
Bătiment Ampére
Rue de La Commune de Paris
B. P. 300
F-93153
Le Blanc Mesnil Cédex
Tel. (01) 931 88 50

GERMAN FEDERAL
REPUBLIC
Hewlett-Packard GmbH
Vertnebszentrale Frankfurt
Bernerstrasse 117
Postlach 560 Frankfurt
Cable HewPackSA Frankfurt
Telex: 04 13249 hpffmd Telex: 04 13249 hpthmd Hewlett-Packard GmbH Technisches Buero Böblingen Herrenbergerstrasse 110 D-7030 Böblingen. Wurttemberg Tei: (07031) 667-1 Cable. HEPAR Böblingen Telex: 07265739 bbn

reiex: 07/205/39 DON Hewlett-Packard GmbH Technisches Buero Düsseldorf Emanuel-Leutze-Str 1 (Seesterni D-4000 **Düsseldorf** 11 Tel: (0211) 59711 Telex: 085:86 533 hpdd Hewlett-Packard GmbH Technisches Buero Hamburg Wendenstrasse 23 D-2000 **Hamburg** 1 Tel: (040) 24 13 93 Cable: HEWPACKSA Hamburg Telex: 21 63 032 hphh d

Hewlett-Packard GmbH Technisches Buero Hannover Am Grossmarkt 6 D-3000 Hannover-Kleefeld 91 Tel: (0511) 46 60 01 Telex: 092 3259

reiex: 092 3259
Hewlett-Packard GmbH
Technisches Buero Nuremberg
Neumeyer Str. 90
D-8500 Nuremberg
Tel: (0911) 56 30 83/85
Telex: 0623 860

Hewlett-Packard GmbH
Technisches Buero München
Unterhachinger Strasse 28
ISAR Center
D-8012 Ottobrunn
Tel: (089) 601 30 61/7
Cable: HEWPACKSA München
Telex: 0524985

Telex: 0524985 Hewlett-Packard GmbH Technisches Buero Berlin Keith Strasse 2-4 D-1000 **Berlin** 30 Tel: (030) 24 90 86 Telex: 18 3405 hpbln d

GREECE Kostas Karayannis 18, Ermou Street GR-**Athens** 126 Tel: 3237731 Tel: 3237731 Cable: RAKAR Athens Telex: 21 59 62 rkar gr Analytical Only

NTECO G. Papathanassiou & Co. Marni 17 GR - Athens 103 Tel: 522 1915 Cable: INTEKNIKA Athens Telex: 21 5329 INTE GR

Telex: 21 5329 INTE GR Medical Only Technomed Hellas Ltd. 52.Skouta Street GR - Athens 135 Tel: 362 6972 363 3830 Cable:etalak athens Telex: 21-4693 ETAL GR

HUNGARY MTA Müszerügyi és Méréstechnikai Szolgalata Lenin Krt. 67 1391 **Budapest** VI Tel: 42 03 38 Telex: 22 51 14

ICELAND Medical Only
Elding Trading Company Inc.
Hafnarhvoli - Tryggvatotu
IS-Reykjavik
Tel: 1 58 20
Cable: ELDING Reykjavik

IRAN
Hewlett-Packard Iran Ltd.
No. 13, Fourteenth St.
Miremad Avenue
P.O. Box 41:2419
IR-Tehran
Tel: 851082-7
Telex: 213405 HEWP IR

IRAQ Hewlett-Packard Trading Co Mansoor City Baghdad Tel: 5517827 Telex: 2455 Hepairag ik Cable: HEWPACOAD. Baghdad Iraq

IRELAND Hewlett-Packard Ltd. King Street Lane GB-Winnersh,Wokingham Berks, RG11 5AR Tel: (0734) 78 47 74 Telex: 847178/848179

TraLY
Hewlett-Packard Italiana S.p.A.
Via Amengo Vespucci 2
Casella postale 3645
I-20100 Milano
Tel: (2) 6251 (10 lines)
Cable: HEWPACKIT Milano
Telex: 32046

Telex: 32046 Hewlett-Packard Italiana S.p.A. Via Pietro Maroncelli 40 (ang. Via Visentin) I-35100 Padowa Tel: (49) 66 48 88 Telex: 41612 Hewpacki Telex: 41612 Hewpacki Medical only Hewlett-Packard Italiana S. p.A. Via d'Aphiardio; 7 I-56100 Pisa Tel: (050) 2 32 04 Telex: 32046 via Milano Hewlett-Packard Italiana S. p.A. Via G. Armellini 10 I-00143 Roma Tel: (06) 54 69 61 Telex: 61514 Cable: HEWPACKIT Roma Hewlett-Packard Italiana S. p.A.

ietex: b1514
Cable: HEWPACKIT Roma
Hewlett-Packard Italiana S. p. A.
Corso Giovanni Lanza 94
I-10130 Torrino
Tel: (011) 682245/659308
Medical/Calculators Only
Hewlett-Packard Italiana S. p. A.
Via Principe Nicola 43 G/C
I-95126 Catania
Tel: (095) 37 05 04
Hewlett-Packard Italiana S. p. A.
Via Amerigo Vespucci. 9
I-80142 Napoli
Tel: (081) 33 77 11
Hewlett-Packard Italiana S. p. A.
Via E. Masi. 98
I-40137 Bologna
Tel: (051) 30 78 87
KUWAIT

KUWAIT
Al-Khaldiya Trading &
Contracting Co.
P.O. Box 830
Kuwait
Tel: 42 49 10
Cable: VISCOUNT

capie: VISCOUNT
LUXEMBURG
Hewlett-Packard Benelux
S.A./N.V.
Avenue du Col-Vert. 1.
(Groenkraaglaan)
B-1170 Brussels
Tel: (02) 672 22 40
Cable: PALOBEN Brussels
Telex 23 494

MOROCCO Gerep 190, Blvd. Brahim Roudani Casablanca Tel: 25-16-76/25-90-99 Cable: Gerep-Casa Telex: 23739

NETHERLANDS Hewlett-Packard Beneiux N V. Van Heuven Goedhartlaan 121 P.O. Box 657 NL-1134 Amstelveen Tel: (020) 47 20 21 Cable: PALOBEN Amsterdam Telex: 13 216 hepa nl

NORWAY Hewlett-Packard Norge A/S Nesveien 13 Box 149 N-1344 Haslum Tel: (02) 53 83 60 Telex: 16621 hpnas n

POLAND
Biuro Informacji Technicznej
Hewlett-Packard
U1 Stawki 2. 6P
00-950Warszawa
Tel: 395962/395187
Telex: 81 24 53 hepa pl

Telex: 81 24 53 hepa pl
UNIPAN
Zaklad Doswiadczalny
Waldowy Aparatury Naukowej
U1 Krajowej Rady Narodowej 51/55
00-800 Warszawa
Tel 36190
Telex: 81 46 48
Zaklady Naprawcze Sprzetu
Medycznego
Plac Komuny Panyskiej 6
90-007 Lodź
Tel: 334-41, 337-83

PORTUGAL
Telectra-Empresa Técnica de
Equipamentos Eléctricos S.a.r.l.
Rua Rodrigo da Fonseca 103
P.O. Box 2531

P. O. Box 2531
P-Lisbon T.
Tel: (19) 68 60 72
Cable: TELECTRA Lisbon
Telex: 12598
Medical only
Mundinter
Intercambio Mundial de Comércio
S.a.r.l.
Av. A. A. de Aguiar 138
P. O. Box 2761
P. Lisbon
Tel: (19) 53 21 317
Cable: INTERCAMBIO Lisbon

Cable: INTERCAMBIO Lisbon
RUMANIA
Hewlett-Packard Reprezentanta
Bd. N. Balcescu 16
Bucharest
Tel: 158023/138885
Telex: 10440
1.I.R.U.C.
Intreprinderea Pentru
Intrelinerea
Si Repararea Utiajelor de Calcul
B-dul prol. Dimitire Pompei 6
Bucharest-Sectorul 2
Tel: 12 64 30
Telex: 11716

SAUDI ARABIA Modern Electronic Establishment King Abdul Azız str. (Head office) P.O. Box 1228 Jeddah Tel: 31173-332201 Cable: ELECTRA

P.O. Box 2728 (Service center) Riyadh Tel: 62596-66232 Cable: RAOUFCO

SPAIN Hewlett-Packard Española, S.A. Terez No. 3 E-**Madrid** 16 Tel:(1) 458 26 00 (10 lines) Telex: 23515 hpe Hewlett-Packard Española S.A. Milanesado 21-23 E-Barcelona 17 Tel: (3) 203 6200 (5 lines) Telex: 52603 hpbe e

Hewlett-Packard Española. S A Av Ramón y Cajal. 1 Edificio Sevilla, planta 9. E-Seville 5 Tel: 64 44 54 58

Hewlett-Packard Española S.A. Edificio Albia II 7° B -Bilbao-1 Tel: 23 83 06/23 82 06 Calculators Only Hewlett-Packard Española S.A. Gran Via Fernando El Católico, 67 E-Valencia-8 Tel: 326 67 28/326 85 55

SWEDEN
Hewlett-Packard Sverige AB
Enighetsvägen 1-3
Fack Fack S-161 20 **Bromma** 20 Tel: (08) 730 05 50 Cable: MEASUREMENTS Stockholm Telex: 10721

Hewlett-Packard Sverige AB Ostra Vintergatan 22 S-702 40 **Orebro** Tel: (019) 14 07 20 Hewlett-Packard Sverige AB Frötalisgatari 30 S-421 32 **Västra Frölunda** Tel: (031) 49 09 50 Telex: 10721 Via Bromma Office

SWITZERLAND
Hewlett-Packard (Schweiz) AG
Zürcherstrasse 20
P. 0. 8ox 307
CH-8952 Schlieren-Zurich
Tel: (01) 730 52 40/730 18 21
Cable: HPAG CH
Telex: 53933 hpackard (schweiz) AG Hewlett-Packard (schweiz) AG Château Bloc 19 CH-1219 Le Lignon-Geneva Tel: (022) 96 03 22 Cable: HEWPACKAG Geneva Telex: 27 333 hpag ch

Telex: 27 333 hpag ch SYRIA Medical/Calculator only Sawah & Co. Place Aziné B.P. 2308 SYR-Damascus Tel: 16367, 19697, 14268 Cable: SAWAH, Damascus TURKEY
Telekom Engineering Bureau
P.O. Box 437

P.O. Box 437 Beyodju TR-**Istanbui** Tel: 49 40 40 Cable: TELEMATION Istanbul Telex: 23609

Telex: 23609 Medical only E.M.A. Muhendislik Kollektif Sirketi Adakale Sokak 41/6 TR-**Ankara** Tel: 175622 Analytical only Yilmaz Ozyurek Milli Mudafaa Cad No. 16/6 Kizilay TR-**Ankara** Tel: 25 03 09 Telex: 42576 Ozek tr

VINITED KINGDOM
Hewlett-Packard Ltd.
King Street Lane
GB-Winnersh, Wokingham
Berks. R611 5AR
Tel: (0734) 78 47 74
Cable: Hewpie London
Telex 847178/9

reiex:847178/9
Hewlett-Packard Ltd.
Trafalger House.
Navagation Road
Altrincham
Cheshire WA14 NU
Tel: (061) 928 6422
Cable: Hewpie Manchester
Telex: 668068

Hewlett-Packard Ltd Lygon Court Hereward Rise Dudley Road Halesowen. West Midlands B62 8SD Tel: (021) 550 9911 Telex: 339105

Hewlett-Packard Ltd Wedge House 799, London Road GB-**Thornton Heath** Surrey CR4 6XL Tel: (01) 684 0103/8 Telex: 946825

Hewlett-Packard Ltd.
c/o Makro
South Serviceholesale Centre
Wear Industrial Estate
Washington
GB-New Town, County Durham
Tel: Washington 464001 ext. 57/58

Hewlett-Packard Ltd 10, Wesley St. GB-Castleford West Yorkshire WF10 1AE Tel: (09775) 50402 Telex: 557355

Hewlett-Packard Ltd 1, Wallace Way GB-Hitchin Herts Tel: (0462) 52824/56704 Telex: 825981

USSR
Hewlett-Packard
Representative Office USSR
Pokrovsky Boulevard 4/17-KW 12
Moscow 101000
Tel: 294-2024
Telex: 7825 hewpak su

YUGOSLAVIA ISKra-standard/Hewlett-Packard Miklosiceva 38/VII 61000 Ljubljana Tel: 31 58 79/32 16 74 Telex: 31583

SOCIALIST COUNTRIES NOT SHOWN PLEASE CONTACT: Hewlett-Packard Ges.m.b.H Pev. Box 7
A-1205 Vienna, Austria
Tel: (0222) 35 16 21 to 27
Cable: HEWPAK Vienna
Telex: 75923 hewpak a

MEDITERRANEAN AND
MIDDLE EAST COUNTRIES
NOT SHOWN PLEASE CONTACT:
Hewlett-Packard S. A.
Mediterranean and Middle Mediterranean and Middle East Operations 35. Kolokotroni Street Platia Kefallariou GR-Kifissia-**Athens**, Greece Tet: 8080337/359/429 Telex: 21-6588 Cable: HEWPACKSA Athens

FOR OTHER AREAS NOT LISTED CONTACT NOT LISTED CONTACT Hewleth-Packard S.A. 7. rue du Bois-du-Lan P.O. 8bx CH-1217 Meyrin 2 - Geneva Switzerland Tel. (022) 82 70 00 Cable: HEWPACKSA Geneva Telex: 2 24 86

UNITED STATES

ALABAMA ALABAMA 8290 Whitesburg Dr., S.E. P.O. Box 4207 Huntsville 35802 Tel: (205) 881-4591 Medical Only 228 W. Valley Ave. Room 220 Birmingham 35209 Tel: (205) 942-2081/2

ARIZONA
2336 E. Magnolia St.
Phoenix 85034
Tel: (602) 244-1361
2424 East Aragon Rd.
Tucson 85706
Tel: (602) 294-3148

*ARKANSAS Medical Service Only P.O. Box 5646 Brady Station Little Rock 72205 Tel: (501) 376-1844

CALIFORNIA 1430 East Orangethorpe Ave Fullerton 92631 Tel: (714) 870-1000 3939 Lankershim Boulevard North Hollywood 91604 Tel: (213) 877-1282 TWX: 910-499-2671 6305 Arizona Place **Los Angeles** 90045 Tel: (213) 649-2511 TWX: 910 328-6147

*Los Angeles Tel: (213) 776-7500 3003 Scott Boulevard **Santa Clara** 95050 Tel: (408) 249-7000 TWX: 910-338-0518

'Ridgecrest Tel: (714) 446-6165 646 W. North Market Blvd Sacramento 95834 Tel: (916) 929-7222 9606 Aero Drive P.O. Box 23333 San Diego 92123 Tel: (714) 279-3200

COLORADO 5600 South Ulster Parkway Englewood 80110 Tel: (303) 771-3455

CONNECTICUT 12 Lunar Drive New Haven 06525 Tel: (203) 389-6551 TWX: 710-465-2029

FLORIDA P.O. Box 24210 2806 W. Oakland Park Blvd. Ft. Lauderdale 33311 Tel: (305) 731-2020

*Jacksonville Medical Service only Tel: (904) 398-0663 P. O. box 13910 6177 Lake Ellenor Dr. **Orlando** 32809 Tel: (305) 859-2900 P.O. Box 12826 Pensacola 32575 Tel: (904) 476-8422

GEORGIA P.O. Box 105005 P.O. Box 105005 Atlanta 30348 Tel: (404) 955-1500 TWX:810-766-4890 Medical Service Only *Augusta 30903 Tel: (404) 736-0592 P.O. Box 2103 **Warner Robins** 31098 Tel: (912) 922-0449

HAWAII 2875 So. King Street Honolulu 96814 Tel: (808) 955-4455 Telex: 723-705

ILLINOIS 5201 Tollview Dr. Rolling meadows 60008 Tel: (312) 255-9800 TWX: 910-687-2260

INDIANA 7301 North Shadeland Ave Indianapolis46250 Tel. (317)842-1000 TWX: 810-260-1797

IOWA 1902 Broadway Iowa City 52240 Tel: (319) 338-9466

KENTUCKY Medical Only
Atkinson Square
3901 Atkinson Dr.
Sbite 207
Louisville 40218
Tel: (502) 456-1573

LOUISIANA P.O. Box 840 3229-39 Williams Boulevard Kenner 70063 Tel: (504) 443-6201

MARYLAND 6707 Whitestone Road Baltimore 21207 Tel: (301) 944-5400 TWX: 710-862-9157 2 Choke Cherry Road Rockville 20850 Tel: (301) 948-6370 TWX: 710-828-9684

MASSACHUSETTS 32 Hartwell Ave. Lexington 02173 Tel: (617) 861-8960 TWX: 710-326-6904

MICHIGAN 23855 Research Drive Farmington Hills 48024 Tel: (313) 476-6400

MINNESOTA 2400 N. Prior Ave. St. Paul 55113 Tel: (612) 636-0700

MISSISSIPPI "Jackson Medical Service only Tel: (601) 982-9363

MISSOURI 11131 Colorado Ave. Kansas City 64137 Tel: (816) 763-8000 TWX: 910-771-2087

148 Weldon Parkway Maryland Heights 63043 Tel: (314) 567-1455 TWX: 910-764-0833

NEBRASKA Medical Only 7171 Mercy Road Suite II0 Omaha 68106 Tel: (402) 392-0948

NEW JERSEY W. 120 Century Rd. Paramus 07652 Tel: (201) 265-5000 TWX: 710-990-4951

Crystal Brook Professional Building Eatontown 07724 Tel:(201) 542-1384

NEW MEXICO P.O. Box 11634 Station E 11300 Lomas Blvd., N.E. Albuquerque 87123 Tel: (505) 292-1330 TWX: 910-989-1185 156 Wyatt Drive Las Cruces 88001 Tel: (505) 526-2484 TWX: 910-983-0550

NEW YORK 6 Automation Lane Computer Park Albany 12205 Tel: (518) 458-1550

201 South Avenue **Poughkeepsie** 12601 Tel: (914) 454-7330 TWX: 510-253-5981 39 Saginaw Drive Rochester 14623 Tel: (716) 473-9500 TWX: 510-253-5981

5858 East Molloy Road Syracuse 13211 Tel: (315) 454-2486 TWX: 710-541-0482 1 Crossways Park West **Woodbury** 11797 Tel: (516) 921-0300 TWX: 710-990-4951

NORTH CAROLINA P.O. Box 5188 1923 North Main Street High Point 27262 Tel: (919) 885-8101

OHIO 16500 Sprague Road Cleveland 44130 Tel: (216) 243-7300 TWX: 810-423-9430 330 Progress Rd. **Dayton** 45449 Tel: (513) 859-8202 1041 Kingsmill Parkway Columbus 43229 Tel: (614) 436-1041

OKLAHOMA P.O. Box 32008 Oklahoma City 73132 Tel: (405) 721-0200

OREGON 17890 SW Lower Boones Ferry Road Tualatin 97062 Tei (503) 620-3350

PENNSYLVANIA 111 Zeta Drive Pittsburgh 15238 Tel: (412) 782-0400

1021 8th Avenue King of Prussia Industrial Park **King of Prussia** 19406 Tel: (215) 265-7000 TWX: 510-660-2670

SOUTH CAROLINA 6941-0 N Trenholm Road **Columbia** 29260 Tel: (803) 782-6493 TENNESSEE Medical Service only Tel: (615) 523-5022

1473 Madison Avenue **Memphis** 38104 Tel: (901) 274-7472 Nashville Medical Service only Tel: (615) 244-5448

TEXAS P.O. Box 1270 201 E. Arapaho Rd. Richardson 75080 tel: (214) 231-6101 P.O. Box 27409 6300 Westpark Drive Houston 77057 Tel: (713) 781-6000 205 Billy Mitchell Road San Antonio 78226 Tel. (512) 434-8241

UTAH 2160 South 3270 West Street Salt Lake City 84119 Tel: (801) 487-0715

VIRGINA P.O. Box 12778 No. 7 Koger Exec. Center Suite 212 Suite 212 Norfolk 23502 Tel:(804) 461-4025/6 P.O.Box 9669 2914 Hungary Springs Road **Richmond** 23228 Tel: (804) 285-3431

WASHINGTON Beliefield Office Pk. 1203-114th Ave. S.E Believue 98004 Tel: (206) 454-3971 TWX: 910-443-2446

*WEST VIRGINIA Medical/Analytical Only Charleston Tel: (304) 345-1640

WISCONSIN #13CUNSIN 9004 West Lincoln Ave. West Allis 53227 Tel: (414) 541-0550

FOR U.S. AREAS NOT LISTED: Contact the regional office nearest you: Atlanta, Georgia... North Hollywood, California... Rockville, Maryland...Rolling Meadows, Illinois. Their complete addresses are listed above.

'Service Only

