

COMPUTER GRAPHICS DISPLAY SYSTEM

ACCEPTANCE TEST PROCEDURE 1088690 REV F



OCIATES, INC. DANIEL WEBSTER HIGHWAY, SOUTH - NASHUA, NEW HAMPSHIRE 03061

Copyright 1981, Sanders Associates, Inc.

Sanders Associates Inc. reserves the right to modify the products described in this manual and to make corrections or alterations to this manual at any time without notice.

February 1981 - 200 Copies

May 1981 - 200 Copies

		—		
APPLICATION		R E V I S I O N S		
NEXT ASSY USED ON	LTR	DESCRIPTION	DATE	APPROVED
	-	ADDED CONIC GENERATOR &	10/7/77	467
	A	LADDED TESTS FOR 2-D COORD. CONV & 23 INCH DISPLAY ENDICATOR.	//18/78	aor
	- 1	PREL FOR DEVELOPMENT	1-26-78	RT/OOT
Final GRAPHIC 7	B	CORRECTED SHEETS 16, 40, 58 REVISED PHOTOPEN TEST 4.3.3 REVISED HARD COPY TEST 4.4.3	HAR 13,78	OOT
	C	ADDED 64K MEMORY TEST SECTION 4. 2.5	JAN. 19,79	OOT
	0	ADDED HARD COPY MULTIPLEX SWITCH TEST, SECTION 4.4.4 REVISED 3.1.1, 2. & 3.2.1, 2. UPDATED TEST RECORD FOR NEW TEST	MAY 4, 79	OOT
	E	ADDED THE FOLLOWINGTESTS; 3D COORD. CONV. EXPANSION MODULE, MULTI- PORT I/O (SWITCH OPTIONS), DATA TABLET, MODEL 5783+5784 KEY- BOARDS, 700 SERIES INDICATORS, DRIIB (D) PARALLEL INTERFACE, HARRIS ABC/CBC/UBC PARALLEL INTERFACE	APR21,80	GOT
	F	CORRECTIONS AND CLARIFICATIONS MADE TO PAGES 21,23,61,77,79 & 82	DEC 16,80	QJ6

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES .XX DECIMAL .XXX DECIMAL	CONT NO.	SANDERS NASHUA, NEW HAMPSHIRE ASSOCIATES, INC
± ± ANGLES SURFACE QUALITY ∴ ✓ MAX INTERPRET DWG PER 815002	CHK PEVO Jonie 20 JUL 77	ACCEPTANCE TEST PROCEDURE GRAPHIC 7 DISPLAY SYSTEM
DEVELOPMENT CHANGE BY REV.	BROW TANK 19 JAN 79	SIZE CODE IDENT NO. DWG NO. 1088690
MFG W. Koch 2-22-78		SCALE SHEET 1 OF 107

			• 	REVIS	IONS		
		LTR		DESCRIPTION		DATE	APPROVE
			TABLE OF	CONTENTS			
			111011111 01	0011441141			- · ·
			INTROD	UCTION			
			IMIROD	00110N	•		
	•	***	SECT	ION 1			
			TEST REC	UIREMENTS			
Paragraph	**************************************						Page
1.1	General						8
1.2	Equipment Conf	i ourst	ion				9
1.3	Test Results	164141	1011				9
1.4	Acceptance Cri	teria.			•		9
1.5	Test and Suppo		ipment				10
1.6	Test Environme						12
			SECT	ION 2			
			מסטים שונים מיי	CONDITTONS			
			PRE-IESI	CONDITIONS		•	
2.1	Introduction						13
2.2	Pre-Turn-On Ch	ecks a	nd Settings				13
2.3	Equipment Conn	ection	ıs				14
2.4	Turn-On/Turn-O	ff Seq	uence				15
2.5	Equipment Warm	-Up	•				15
			SECT	ION 3			
		ST	ANDARD GRAPH	IC 7 ATP TESTS			
3.1	General						16
3.2	Terminal Verif	icatio	n Pattern Te	st			18
3.3	ROM Comparison		weechil .c	tar tar			21
	Jompar Laoii						. • • • · · · · · · · · · · · · · · · ·
		•					
		S	IZE CODE IDE	NT NO. DWG NO.			
			941	17	108869	0	
		1	7 241	1	10000		
			ALE			SHEET 2	OF 107

REVISIONS					
LTR	DESCRIPTION	DATE	APPROVED		

TABLE OF CONTENTS (Cont)

SECTION 4

GRAPHIC 7 OPTIONS, ATP TESTS

Paragrap	h	Page
4.1	General	25
4.2	Terminal Controller Options Tests	27
4.2.1	Multiport Serial Interface Test	28
4.2.2	Parallel Interface Test, Model 5712	33 a
4.2.3	Conic Generator Test	39
4.2.4	2D Coordinate Converter Test	40
4.2.5	Large R/W Memory Test	43
4.2.6	2-D/3-D Coordinate Converter Test	50 .
4.2.7	Expansion Module Test	51
4.2.8	Floating Point Converter Test	52
4.3	Data Entry Options Tests	55
4.3.1	Alphanumeric Keyboard Tests	56
4.3.1.2	Procedure, Model 5782 Keyboard Test	56
4.3.1.3	Procedure, Model 5783 Keyboard Test	60
4.3.1.4	Procedure, Model 5784 Keyboard Test	64
4.3.1.5	Procedure, Model 5785 Keyboard Test	66
4.3.2	PED Tests	70
4.3.3	PHOTOPEN Test	72
4.4	Display Indicator Options Tests	76
4.4.1	21-Inch Display Indicator Test	77
4.4.2	23-Inch Round Display Indicator Test	78
4.4.3	Hardcopy Unit Test	80
4.4.4	Hardcopy Multiplex Switch Test	82
4.5	Software/Firmware Tests	85
4.5.1	GSS-4 Test	86
4.5.2	GET-2 Tektronix Emulator Test	86

SIZE	CODE IDE	NT NO.	DWG NO.							
Α	941	17			108869	0				
SCALE				· · · · · · · · · · · · · · · · · · ·		SHEET	3	OF	107	

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

TABLE OF CONTENTS (Cont)

Paragraph		Page
4.6	Special Tests	87
4.6.1	Data Load Test	88
4.7	Non-Standard Parallel Interface Tests	95
4.7.1	Introduction	96
4.7.2	Parallel Interface to DEC DR11-B(D)	97
4.7.3	Parallel Interface to Interdata 7/16, 7/32, 8/32, SELCH; ULI	99 -
4.7.4	Parallel Interface to SEL-32; HSD-9132	99 ,
4.7.5	Parallel Interface to Harris ABC/CBC/UBC	100
4.7.6	Parallel Interface to HP2100/21MXE; 12930 A-002	103
4.7.7	Parallel Interface to Data General NOVA and ECLIPSE	103
4.7.8	Parallel Interface, NTDS Fast, to Univac Military Computers	103
4.7.9	Parallel Interface, NTDS Slow to Univac Military Computers	103
4.7.10	Parallel Interface to Honeywell 516 DMC	103
4.7.11	Parallel Interface to NORD-10	103
	SECTION 5 EQUIPMENT ACCEPTANCE TEST RECORD	
5.1	Equipment Acceptance Test Record	104

APPENDIX A

TAPE LOADING PROCEDURE

SIZE	CODE IDENT NO.	DWG NO.	
Α	94117	1088690	
SCALE		SHEET 4 OF	: 107

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

LIST OF ILLUSTRATIONS

Number		Page
3-1	Terminal Verification Test Pattern	19
3-2	ROM Comparison Test GO Display	23
3-3	ROM Comparison Test, Typical Error Display	24
4-1	Serial Multiport Test, GO Display	30
4-2	Serial Multiport Test, Typical Error Display (Part l Failure)	- 31
4-3	Serial Multiport Test, Typical Error Display (Parts 1, 4 and 6 Failures)	32
4-4	Parallel Interface Test Display, All Tests Pass	35
4-5	Parallel Interface Test Display, Interrupt Tests Fail	36
4-6	Parallel Interface Test Display, All Tests Fail	38
4-7	2D Coordinate Converter Test Display	41
4-8	Printout for Model 7704 (64K Memory)	46
4-9	Printout for Special 32K Memory Card	47
4-10	Printout for Model 7703 (32K Memory)	48
4-11	Printout for Model 7702 (16K Memory)	49
4-12	Model 5785 Keyboard Layout	67
4-13	PHOTOPEN Test Display Pattern	75
4-14	Data Load Test, Test Set-Up	89
4-15	Format A	91
4-16	Format B	92
4-17	Format C	93
4-18	Composite Format	94

LIST OF TABLES

Number		Page
4-1	Model 5782 Keyboard Codes	57
4-2	Model 5783 Key Codes	61

I	SIZE	CODE IDEN	IT NO.	DWG NO.						
	A	941	17		108869	0				
Ī	SCALE					SHEET	5	OF	107	

REVISIONS						
LTR	DESCRIPTION	DATE	APPROVED			

INTRODUCTION

The GRAPHIC 7 is a high performance, intelligent, refreshed graphics terminal system. It can be operated in a stand-alone configuration or it can be connected to a host computer. The system includes standard computer interfaces, built-in automatic self-test and diagnostics for fault isolation, and complete interactive graphics processing. The GRAPHIC 7 system comprises a terminal controller, display indicators, data entry devices, host computer interfaces, and various other options.

This document is the Acceptance Test Procedure for the GRAPHIC 7 Computer Graphics Display System. The procedures detailed herein provide for acceptance testing for each of the GRAPHIC 7 system elements configured for a customer's application.

The tests included in this document apply to the following equipment models:

MODEL NO.	EQUIPMENT NAME	TEST PARAGRAPH
5709, 7709	Terminal controller	3.0
5713	Multiport serial interface	4.2.1
5712	Parallel interface, PDP-11, DR11C	4.2.2
5743	Conic Generator	4.2.3
5752	2D coordinate converter	4.2.4
7702 thru 7704	Large read/write memory	4.2.5
5753	2-D/3-D coordinate converter	4.2.6
7750	Expansion module	4.2.7
5744	Floating point converter	4.2.8
5782 thru 5785	Alphanumeric/function keyboards	4.3.1
5786	Trackball	4.3.2
5787	Forcestick	4.3.2
5788	Data tablet	4.3.2
5781	PHOTOPEN	4.3.3
530 series		
730 series	21-inch display indicators	4.4.1
740 series		

SIZE	CODE IDENT NO.	DWG NO.						
Α	94117		10886	690				
SCALE				SHEET	6	OF	107	-

REVISIONS						
LTR	DESCRIPTION	DATE	APPROVED			

MODEL NO.	EQUIPMENT NAME	TEST PARAGRAPH
0565 750, 753 760, 763	23-inch display indicators	4.4.2
570	Hardcopy unit	4.4.3
575	Hardcopy multiplex switch	4.4.4
_	GSS-4 software	4.5.1
7775	GET-2 Tektronix simulator	4.5.2
5714	Parallel interface, PDP-11, DR11B	4.7.2
5715	Parallel interface, Interdata 7/16,	,
	7/32, 8/32 SELCH; ULI	4.7.3
5716	Parallel interface, SEL-32; HSD-9132	4.7.4
5717	Parallel interface, Harris ABC, CBC,	
	UBC	4.7.5
5718	Parallel interface, HP2100/21MXE	4.7.6
5719	Parallel interface, Data General	
	NOVA and ECLIPSE	4.7.7
5720	Parallel interface, NTDS Fast	4.7.8
5721	Parallel interface, NTDS Slow	4.7.9
5722	Parallel interface, Honeywell 516 DMC	4.7.10
5723	Parallel interface, NORD-10	4.7.11
5734	Long line parallel interface, PDP-11,	•
•	DR11B	4.7.12

SIZE	CODE IDENT NO.	DWG NO.
A	94117	1088690
SCALE		SHEET 7 OF 107

LTR	DESCRIPTION	DATE	APPROVED

SECTION 1

TEST REQUIREMENTS

1.1 General

Acceptance testing will be performed on each GRAPHIC 7 display system manufactured as a contract end item prior to customer delivery. The testing will verify that each item conforms to the customer's requirements of configuration and performance.

Section 3.0 describes those tests required to verify correct performance of a GRAPHIC 7 terminal controller without options.

All GRAPHIC 7 display system options are tested as part of Section 4.0. A complete ATP therefore would include the tests of Section 3.0 and those portions of Section 4.0 applicable to that customer's configuration.

1.1.1 Responsibility for Testing

Sanders Associates, Inc. shall be responsible for the performance of all test requirements herein. The testing shall be performed in strict accordance with this test procedure by employees of Sanders Associates.

1.1.2 Customer Representative(s)

A customer representative(s) may witness the testing but shall not have procedural jurisdiction. He shall have final acceptance/rejection authority within the guidelines of paragraph 1.4. He shall have the authority to have certain tests repeated if the test data is inconclusive.

1.1.3 Quality Assurance

A Sanders quality assurance representative shall witness the performance of this test to ensure that all aspects of the test are conducted within the provisions of this procedure. Customer acceptance test shall be conducted

SIZE	CODE IDENT NO.	DWG NO.
A 94117		1088690
SCALE		SHEET 8 OF 107

REVISIONS					
LTR	DESCRIPTION	DATE	APPROVED		
	•				

1.1.3 (continued)

under the direction of Sanders Quality Assurance who shall interface with the customer representative, and shall resolve all procedural disputes.

1.2 Equipment Configuration

The acceptance test article shall be of the approved configuration.

1.3 Test Results

All test results shall be entered on the Equipment Acceptance Test Record in the appropriate place. All test data taken shall remain on file at Sanders Associates and be available for customer review upon request.

1.4 Acceptance Criteria

Final acceptance of the GRAPHIC 7 display system is contingent upon successful completion of procedures contained herein. Any deviation from the performance specified in this procedure shall be classified as non-conformance. Non-conformance shall be categorized as follows:

- a. Display format presentation error
- b. Parameter out of tolerance

1.4.1 Display Format Presentation Error

A display format presentation error shall be defined as the displaying of incorrect data. The error shall not be a subjective measurement but shall be a hard data presentation error. It shall constitute a failure.

1.4.2 Parameter Out of Tolerance

A parameter out of tolerance is defined as a procedural parameter measurement that falls outside the limits defined on the Test Record. The measurement may be repeated a second time to verify the parameter value. A second non-conformance shall constitute a failure.

SIZE	CODE IDE	NT NO.	DWG NO.						
Α	941	17		10886	90				
SCALE			•		SHEET	9	OF	107	

REVISIONS							
LTR	DESCRIPTION	DATE	APPROVED				

1.4.3 Operator or Test Set-Up Error

Upon the occurrence of an operator, support equipment failure, or test set—up error, Sanders may restart the test at a point that will assure test validity after corrective action has been taken.

1.4.4 Occurrence of Non-Conformance

Upon the occurrence of a display format error, all further testing shall cease. The failure shall be analyzed to determine where it occurred. If support equipment failed, 1.4.3 shall apply. If the unit under test failed, it shall be rejected.

1.4.5 Certification of Test Data

Section 5 contains Test Record sheets for recording all observation and measurements required by this procedure. When signed at the conclusion of the test, these sheets shall serve as certification that the equipment under test has successfully met the requirements contained herein.

1.5 Test and Support Equipment

The following test and support equipment shall be used in the performance of this test procedure. Equivalent test or support equipment may be used subject to customer approval.

Prior to the start of testing, verification shall be made that all test equipment subject to calibration has been maintained in accordance with the calibration system requirements of MIL-C-45662 as evidenced by the presence of a valid, stamped, calibration sticker on the equipment.

Additional items other than those called out here may be included in the individual procedures for testing of special options (Section 4.0). These items will be so noted in the appropriate section.

SIZE	CODE IDENT NO.	DWG NO.	
Α	94117	108869	0
SCALE			SHEET 10 OF 107

	REVISIONS							
LTR	DESCRIPTION	DATE	APPROVED					

1.5.1 Support Equipment Required

1.5.1.1 Hardware

; l
35
1

^{*} These items are required for terminal controller tests. If the customer's configuration includes display indicators and keyboards, those items shall be tested as described in Section 4.0.

1.5.1.2 <u>Test Software</u>

ITEM	DESCRIPTION	PART NUMBER
1	ROM comparison test program paper tape	
2	ROM comparison master source paper tape	
3	Multiport serial test program paper tape	
4	Parallel interface test program paper tape	
5	2-D coordinate converter ATP tape	
6	2-D/3-D coordinate converter ATP tape	
7	16K/32K/64K read/write memory test tape	
8	Expansion module test tape	
9	Floating point converter test tape	
10	Model 5784 keyboard test tape	G7 KEYS.LDA
11	T2C data load test program	

	SIZE	CODE IDENT NO.	DWG NO.
	Α	94117	1088690
-	SCALE		SHEET 11 OF 107

^{**} Vendor is Sanders Associates, Inc. unless otherwise noted.

^{***}Not required if serial interface is part number 5976251.

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

1.5.2 <u>Test Equipment</u>

ITEM	DESCRIPTION	VENDOR	PART/MODEL NUMBER
1.	Oscilloscope	Tektronix	Model 465
2.	Harris I/O channel interface simulator	Sanders	
3.	Data General I/O channel interface simulator	Sanders	
4.	Digital Equipment Corp. I/O channel interface simulator	Sanders	
5.	SEL I/O channel interface simulator	Sanders	

1.6 Test Environment

The operating conditions shall be as follows:

Ambient temperature	Normal room
Relative humidity	Normal room
Primary voltage	One of the following (per customer's configuration):
	100 Vac \pm 10% 115 Vac \pm 10% 120 Vac \pm 10% 220 Vac \pm 10% 230 Vac \pm 10% 240 Vac \pm 10%

Primary frequency

60 Hz + 5%

SIZE	CODE IDENT NO.	DWG NO.				
A	94117		108869	90		
SCALE				SHEET 12	OF	107

REVISIONS						
LTR	DESCRIPTION		DATE	APPROVED		

SECTION 2

PRE-TEST CONDITIONS

2.1 Introduction

The following paragraphs are for reference information only. The ATP can begin with Sections 3.0 and 4.0 (if applicable). This assumes that the unit or system under test is already operational prior to the start of the ATP. Additional items, such as options, will be connected as indicated in the appropriate sections.

The pre-turn-on checks listed below must be made before the system can be energized from a full power-off condition to a full power-on condition.

2.2 Pre-Turn-On Checks and Settings

Prior to connecting AC power cords or energizing the main power bus, all units must be checked for proper switch and control settings as follows:

2.2.1 Voltage Selection Tabs and Jumpers

- a. Verify that the removable printed circuit tab in the power control panel is inserted in the appropriate voltage position (120 or 240). (Not applicable to Model 5709 terminal controller.)
- b. Verify that the low voltage power supply in the display indicator is properly strapped for the designated voltage (refer to drawing 5978887). (Not applicable to 0530-series display indicators.)
- c. If a hardcopy unit is included in the configuration, verify that the removable printed circuit tab in the power control panel is inserted in the appropriate voltage position (120 or 240).

2.2.2 Terminal Controller

a. POWER ON/OFF switch to OFF.

SIZE	CODE IDENT I	10.	DWG NO.		· · · · · · · · · · · · · · · · · · ·					
Α	9411	7			108869	90				
SCALE				•		SHEET	13	OF	107	

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

2.2.3 Display Indicator

MODEL 0530

MODEL 730

MODEL 740

a. POWER switch to OFF

Press 0 side of power switch

Press 0 side of power switch

- b. CONTRAST control fully counterclockwise
- c. INTENSITY control fully counterclockwise

Intensity control (sunburst) fully counterclockwise Intensity control (sunburst) fully counterclockwise

- 2.2.4 Paper Tape Reader
 - a. POWER switch to OFF.
- 2.3 Equipment Connections

Before performing the ATP, interconnect the terminal controller and the following units:

- 1. Paper tape reader to multiport serial interface assembly port 1 (J3).
- Teletypewriter to ROM and status card assembly (A9 slot), serial I/O port (J2)

οr

keyboard to multiport serial interface assembly port 3 (J5).

- 3. Display indicator X, Y, Z inputs to the appropriate X, Y, and Z outputs on the output channel card assembly:
 - a. X J1
 - b. Y J3
 - c. Z J5
- 4. Connect all AC power cords.

	SIZE	CODE IDENT NO.	DWG NO.				
ĵ.	Α	94117	4117				
	SCALE			SHEET 14	of 107		

	REVISIONS							
LTR	DESCRIPTION	DATE	APPROVED					

2.4 Turn-On/Turn-Off Sequence

After all AC power cords are connected and main power bus is energized, perform turn-on sequence as follows (turn-off is the reverse of turn-on):

- 1. At teletypewriter, set rotary switch to ON LINE.
- 2. At terminal controller, set POWER switch to ON. Verify that proper indicator lights (Model 5709, red POWER indicator; Model 7709, RUN/SYS indicator lit).
- 3. Turn on display indicator (Model 0530: press ON side of POWER switch; Models 730 or 740, press 1 side of power switch).

2.5 Equipment Warm-Up

All test and support equipment and the GRAPHIC 7 system under test shall be turned on at least 30 minutes before the start of the ATP.

SIZE	CODE IDENT NO.	DWG NO.
A	94117	1088690
SCALE		SHEET 15 OF 107

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

SECTION 3

STANDARD GRAPHIC 7 ATP TESTS

3.1 General

These tests are designed to verify performance of the basic GRAPHIC 7 terminal controller, without options. The test assumes that the display indicator, teletypewriter and/or keyboard have been previously verified and are part of the test set—up.

If a display indicator is being tested as part of this ATP, it can be substituted for the indicator normally used as support equipment. This applies to the keyboard also. These items will then be tested as part of Section 4.0.

The basic terminal controller consists of the following assemblies:

NAME		in the second	ASSEMBLY NUMBER	
Display processor			1086779	
ROM and status			1086746 or []
Graphic controller			1086758 or []
R/W memory (RAM)	• • • • • • • • • • • • • • • • • • •		(See note)	
D/A converter (2)		•	1086775	
Ramp generator			1086798	
Character generator			1086783	
Output channel			1086771 or []

SIZE	CODE IDENT NO.	DWG NO.	
Α	94117	1088690	
SCALE		SHEET 16	OF 107

REVISIONS							
LTR	DESCRIPTION	DATE	APPROVED				

NOTES

- 1. A multiport serial interface shall be installed. Even if a multiport serial interface is not part of the basic terminal controller, it is required for loading ROM comparison test tapes (paragraph 3.3).
- 2. R/W (RAM) memory can be any of the following configurations:
 - a. 8K to 24K, consisting of one, two, or three Model 5702 8K modules.
 - b. 16K to 64K, consisting of a single Model 7702, 7703, or 7704 large R/W memory card.
 - c. 80K to 128K, consisting of a Model 7704 large R/W memory card plus a Model 7702, 7703, or 7704 card.
 - d. 48K, consisting of a Model 7703 large R/W memory card plus a Model 7702 card.

Acceptance testing of configuration a. above is performed as part of the terminal verification memory diagnostic test (paragraph 3.1.1). A separate section 4.0 test is not required.

Acceptance testing of configurations b_{\bullet} , c_{\bullet} , or d_{\bullet} above is described in paragraph 4.2.5.

3.1.1 Standard Tests

- 1. The standard tests for the terminal controller are:
 - a. Terminal verification pattern test
 - b. ROM comparison test
- 2. The standard controller tests of this section are run prior to testing the various system options. Note that in the terminal verification pattern test, circles and conics and/or translated, rotated data

1	SIZE	CODE IDEN	NT NO.	DWG NO.						
	A 94117		`	10886	90					
	SCALE					SHEET	17	OF	107	

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

3.1.1 (continued)

elements will be missing or present in the test pattern depending on the options configured. This fact must be taken into consideration prior to verifying test pattern results.

For example, if the conic generator option is not installed, the circles and ellipses of figure 3-1 will be displayed as diamonds. Character generators containing special symbols will have the special symbols displayed below the standard character set shown in figure 3-1. Installation of a 2-D coordinate converter will result in the center ellipses rotated and translated to the upper left-hand corner of the display.


3.2 Terminal Verification Pattern Test

This test utilizes the built-in, ROM diagnostic program of the GRAPHIC 7. The terminal verification pattern (figure 3-1) is used to verify correct operation of the vector/position generator, 2-D coordinate converter, conic generator, character generator, and output channel. It also provides a go/no-go readout that verifies the digital processing circuits in the terminal controller by means of a display processor diagnostic, memory diagnostic, display generator diagnostic, and an interface diagnostic. All of these diagnostics are contained in ROM and are run automatically without operator intervention required.

3.2.1 Procedure

1. With all equipment energized, place the terminal controller in the LOCAL mode by pressing the LOCAL pushbutton on the GRAPHIC 7 control panel. The terminal verification test pattern (figure 3-1) is displayed on the display indicator.

SIZE	CODE IDEN	IT NO.	DWG NO.					•		
Α	941	17		•	10886	90		•		
SCALE						SHEET	18	OF	107	



1	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

3.2.1 (continued)

- 2. Verify that the pattern displayed on the display indicator is the same as the pattern shown in figure 3-1. Ensure that:
 - (1) No X-axis ghosting appears in the letters H at the left vertical edge.
 - (2) The 3/4 screen box is composed of the four types of line structure shown in figure 3-1.
 - (3) The bold vertical bars located at the full, 1/4 and 1/2 screen horizontal positions consist of nine parallel lines each with no offset evident at the tops or bottoms.
 - (4) The boxes appear as shown in figure 3-1 without excessive bright spots.
 - (5) In the "EM" displays at the lower left of the screen, the upper edge of the largest E is aligned with the topmost dot and the right side edge of the largest M is aligned with the right-most dot. (Note: This assumes a 12 x 12 inch display area.)
 - (6) The complete set of alphanumeric characters shown at the bottom center of figure 3-1 is displayed on the screen.
 - (7) The numbers 7 through 0 (0 not visible) are shown rotated 90° counterclockwise at the lower left corner of the 3/4 screen box in vertically oriented descending order with brightness levels varying from greatest intensity for 7 to fully blanked for 0.
 - (8) The number at the top center of the screen reflects the Z-axis channel (1 through 4) of the output channel card to which the display indicator Z input is connected (in figure 3-1, channel 1 is used).

SIZE	CODE IDEN	NT NO.	DWG NO.				
A	941	17		108869	90		
SCALE					SHEET 20	OF	107

REVISIONS					
LTR	DESCRIPTION	DATE	APPROVED		

3.2.1 (continued)

(9) The readout box at the lower right of the display contains Ø7Ø (a go indication) in the left field with a "T" above it (indicating test). The right field of the readout box indicates the initialized state with the code "XX". The single changing number is the real-time clock test changing at a one-second interval. Verify that the code Ø7Ø is displayed.**

3.3 ROM Comparison Test

3.3.1 General

Supplied with the GRAPHIC 7 terminal controller is a control, or monitor program, called the graphics control program (GCP)*. GCP is contained in firmware located on the ROM and status card. The contents of the GCP firmware is tested by the ROM comparison test. This test verifies that the bit pattern stored in the GCP PROM's agrees with a software master source tape which contains the master GCP ROM bit patterns.

3.3.2 Procedure

- Position the ROM comparison test program tape in the paper tape reader and load it according to the loading procedure contained in Appendix A.
- 2. After the test program is loaded, the terminal controller will be in the MONITOR mode. This is indicated by the alphabetic character M (BØ M for GCP+) in the center of the display.
- * Unless otherwise specified, all statements with respect to GCP also apply to GCP+ (Graphic Control Program Enhanced).
- ** For systems containing optional circuit cards, see Section 2.2.1 of the Programmers Reference Manual for the correct code.

SIZE	CODE IDEN	IT NO.	DWG NO.					
Α	941	17		108869	90			· ·
SCALE		,			SHEET	21	OF	107

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

3.3.2 (continued)

- 3. Position the ROM comparison master source tape in the paper tape reader and type the following command: 3000G RETURN or 3000G NEW LINE.
- 4. Upon execution, verify that the ROM comparison master source tape has been read and loaded and that the display indicator display is as shown in figure 3-2.
- 5. If FAILED should be displayed instead of PASSED, the number of errors detected will be displayed on the ERROR COUNT IN BYTES line and the location of the last error detected will be displayed on the ERROR LOCATION line. Figure 3-3 shows a typical (software simulated) failure display in which one error was detected at location 151112.
- 6. This test may be rerun by pressing the LOCAL pushbutton on the terminal controller, pressing the RETURN key on the teletypewriter or NEW LINE on the keyboard, and rerunning the ROM comparison master source tape according to paragraph 3.3.2, step 3.

SIZE	CODE IDENT NO.	DWG NO.
Α	94117	1088690
SCALE		SHEET 22 OF 107

·	REVISIONS					
LTR	DESCRIPTION	DATE	APPROVED			

SANDERS ASSOCIATES GRAPHIC 7 ATP ROM TEST

CURRENT MEMORY LOCATION: 173777*
ERROR COUNT IN BYTES: ØØØØØØ
ERROR LOCATION: ØØØØØØ

PASSED

*This location is for REV1 of GCP+. For any other version of GCP this listing must be consulted for the highest byte address in the program. This address is the one which will be displayed as the Current Memory Location.

Figure 3-2. ROM Comparison Test, GO Display

SIZE	CODE IDEN	NT NO.	DWG NO.						-
Α	941	17		10886	90				
SCALE	-				SHEET	23	OF	107	

REVISIONS

LTR DESCRIPTION DATE APPROVED

SANDERS ASSOCIATES
GRAPHIC 7
ATP ROM TEST

CURRENT MEMORY LOCATION: 157777
ERROR COUNT IN BYTES: ØØØØØ1
ERROR LOCATION: 151112

FAILED

Figure 3-3. ROM Comparison Test, Typical Error Display

SIZE	CODE IDENT NO.	DWG NO.	
Α	94117	1088690	
SCALE		SHEET 24	OF 107

-	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED
		[

SECTION 4

GRAPHIC 7 OPTIONS, ATP TESTS

4.1 General

These tests are designed to verify performance of the various GRAPHIC 7 options. These options can be classified into five groups:

- Terminal controller options
- Data entry options
- Display indicator options
- Software/firmware options
- Special options

A further breakdown of these groups is as follows:

1.	Terminal Controller Options	Model Number
	 Multiport serial interface Parallel interface Ramp/conic generator 2-D coordinate converter 2-D/3-D coordinate converter Large R/W memory Expansion module Floating point converter 	5713 Various 5734 5752 5753 7702/7703/7704 7750 5744
2.	Data Entry Options	
	 Alphanumeric/function keyboard Lighted alphanumeric/function keyboard PED - Trackball or forcestick Data tablet PHOTOPEN 	5782/5783 5784/5785 5786/5787 5788 5781
3.	Display Indicator Options	Model Number
	 21-inch rectangular, monochrome 23-inch round, monochrome 21-inch rectangular, four color 23-inch round, four color 	0530 series/ 0730 series 0565/750/753 740 series 760 series

SIZE	CODE IDENT	NO.	DWG NO.	·						
Α	9411	7			108869	90				
SCALE						SHEET	25	OF	107	

REVISIONS					
LTR	DESCRIPTION	DATE	APPROVED		

4.1 (continued)

3. <u>Display Indicator Options (Cont)</u>

Model Number

Hardcopy Unit

0570

Hardcopy Multiplex Switch

0575

4. Software/Firmware Options

Model Number

• GSS-4

• Special GCP (multitask)

• GET-2 Tektronix® Emulator

7775

4.1.1 Option Testing Sequence

The GRAPHIC 7 display system can be assembled in any number of different configurations using the various options and subsystem elements. The testing sequence for any of these configurations should be as follows:

- 1. Test the basic terminal controller as per Section 3.0.
- 2. Test each option as per the applicable paragraph of Section 4.0.
- 3. Perform special tests as per the applicable paragraph of Section 4.0.
- 4. Repeat the tests for duplicate options.

SIZE	CODE IDENT NO.	DWG NO.
Α	94117	1088690
_		
SCALE		SHEET 26 OF 107

REVISIONS						
LTR	DESCRIPTION	DATE	APPROVED			

SECTION 4.2

TERMINAL CONTROLLER OPTIONS TESTS

SIZE	CODE IDE	NO.	DWG NO.
Α	941	17	1088690
SCALE			SHEET 27 OF 107

	REVISIONS						
LTR	DESCRIPTION	DATE	APPROVED				

4.2.1 Multiport Serial Interface Test

4.2.1.1 General

This test verifies that each multiport serial interface sends and receives a table of test characters with the transmit and receive interrupt both enabled and disabled. This test is performed in a "wrap-around" mode. That is, the output of each port is fed directly back to the input, thereby verifying the correct transmission and reception of data without requiring another device.

NOTE

Two models of serial interface are now in use. To test part number 1086750 requires that an external jumper be connected between pins 1 and 5 of each of the ports. Part number 5976251 can be tested without external jumpers; it contains an internal loopback circuit.

4.2.1.2 Procedure

NOTES

This test can be conducted with either one or two multiport serial interfaces installed in the terminal controller. The test shall be conducted on every port. On part number 1086750, more than one port can be tested without external jumpers; it contains an internal loopback circuit.

SIZE	CODE IDENT NO.	DWG NO.				1.74
A	94117	1088690)			
SCALE			SHEET	28	OF	107

REVISIONS					
LTR	TR DESCRIPTION DATE APPROVED				

4.2.1.2 (continued)

- 1. (Part number 1086750 only) Connect multiport test plugs to 10-pin connectors of multiport serial interface card.
- 2. (Both models) Position multiport serial test program tape in paper tape reader and load it as described in Appendix A.
- 3. Verify that the tape has been read and loaded and the display indicator presentation is as shown in figure 4-1.

NOTE

Figure 4-1 is for the case of a part number 5976251. The display for part number 1086750 pays "EXTERNAL LOOPBACK TEST." In the latter case, each port with a test plug connected should show as passing. Ports without test plugs connected should show as failing. See figures 4-2 and 4-3.

- 4. If necessary, move the multiport test plug to the next port to be tested. Rerun the test as follows:
 - a. Press LOCAL pushbutton.
 - b. Type NEW LINE or RETURN to get back to monitor mode.
 - c. Type 3000G RETURN on teletypewriter or NEW LINE on keyboard.

SIZE	CODE IDENT NO	DWG NO.
Α	94117	1088690
SCALE		SHEET 29 OF 107

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

SANDERS ASSOCIATES GRAPHIC 7

SERIAL MULTIPORT ATP INTERNAL LOOPBACK TEST

PORT	PASS	FAIL
Ø1	**	
Ø2	**	
Ø3	**	
Ø4	**	
Ø5	**	
Ø6	**	
Ø7	**	
Ø8	**	

****** DONE *****

Figure 4-1. Serial Multiport Test, GO Display

SIZE	CODE IDEN	T NO.	DWG NO.	
Α	941	17	1088690	
SCALE			SHEET 30 OF	107

REVISIONS								
LTR		DESCRIPTION	DATE	APPROVED				

SANDERS ASSOCIATES
GRAPHIC 7
SERIAL MULTIPORT ATP

INTERNAL LOOPBACK TEST

PORT	PASS	FAIL
Ø1		**
Ø2	**	
Ø3	**	
Ø4	**	
Ø5	**	
Ø6	**	
Ø7	**	
Ø8	**	

****** DONE *****

Figure 4-2. Serial Multiport Test, Typical Error Display (Port 1 Failure)

SIZE	CODE IDENT NO.	DWG NO.
A	94117	1088690
SCALE		SHEET 31 OF 107

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

SANDERS ASSOCIATES
GRAPHIC 7
SERIAL MULTIPORT ATP

INTERNAL LOOPBACK TEST

PORT	PASS	FAIL
Ø1		**
Ø2	**	
Ø3	**	
Ø4		**
Ø5	**	
Ø6		**
Ø7	**	
Ø8	**	

****** DONE *****

Figure 4-3. Serial Multiport Test, Typical Error Display (Ports 1, 4 and 6 Failures)

SIZE	CODE IDENT N	Ο.	DWG NO.							
Α	94117	7		•	108869	90				
SCALE						SHEET	32	OF	107	

	REVISIO	N S	-
LTR	DESCRIPTION	DATE	APPROVED

4.2.2 Parallel Interface Test, Model 5712

NOTE

If parallel interface is not Model 5712, go to paragraph 4.7.

4.2.2.1 General

This test verifies that the parallel interface transmits and receives data under the following conditions:

- 1. Single word transfer without any interrupts enabled (DMA OFF).
- 2. DMA IN transfer without any interrupts enabled.
- 3. DMA OUT transfer without any interrupts enabled.
- 4. Single word transfer with input interrupt enabled (DMA OFF).
- 5. Single word transfer with output interrupt enabled (DMA OFF).
- 6. DMA IN transfer with input interrupt enabled.
- DMA OUT transfer with output interrupt enabled.

This test is performed in a "wrap-around" mode. That is, output data is fed directly back to the input; this allows for a standalone test without benefit of a host computer.

4.2.2.2 Procedure

1. Connect the parallel interface test cable between input and output connectors (J2 and J3) on the parallel interface card.

NOTE

When connecting the test cable, ensure that the red edge of the cable ribbon faces upward at both connectors.

SIZE	CODE IDE	NT NO.	DWG NO).						
A	941	17			10886	90				
			<u>.l</u>							
SCAL	E					SHEET	33	OF	107	

	REVISIONS		and the second second
LTR	DESCRIPTION	DATE	APPROVED

4.2.2.2 (continued)

- 2. Position the parallel interface test program tape in the paper tape reader and load it according to the loading procedure described in Appendix A.
- 3. Upon execution, verify that the tape has been read and the display indicator displays that all tests have passed. See figure 4-4.
- 4. Change the processor priority level of the test program in order to test the parallel interface board interrupt level. This is done by performing the following:
 - a. Restart system by pressing LOCAL pushbutton on terminal controller
 - b. Type RETURN or NEW LINE to enter MONITOR mode.
 - c. Type 3010/
 - d. The contents of location 3010 is displayed with the teletypewriter readout now being 3010/000230.
 - e. Change contents of location 3010 from 230 to 237 (priority level set to 7) by typing 237 RETURN.
 - f. The teletypewriter readout is now:

3010/000230 237 RETURN

- 5. Execute program again by typing 3000G RETURN.
- 6. Upon execution, verify that the display indicator displays that the tests without interrupts enabled still pass while those with interrupts enabled have failed. (See figure 4-5.)
- 7. Disconnect one end of the parallel interface test cable from the parallel interface card and change contents of location 3010 back to 230 using the procedure established in step 4.

94117		

REVISIONS								
LTR DESCRIPTION DATE APPROVE								

SANDERS ASSOCIATES GRAPHIC 7 PARALLEL INTERFACE ATP PASS FAIL

WITHOUT INTERRUPTS

DMA OFF **
DMA IN **
DMA OUT **

WITH INTERRUPTS

DMA OFF **
DMA IN **
DMA OUT **

****** DONE *****

Figure 4-4. Parallel Interface Test Display, All Tests Pass

SIZE	CODE IDEN	IT NO.	DWG NO.			
Α	941	17		108869	90	
SCALE	·				SHEET 35	OF 107 ·

	REVISIONS								
LTR	DESCRIPTION	DATE	APPROVED						

SANDERS ASSOCIATES GRAPHIC 7

PARALLEL INTERFACE ATP

PASS FAIL

WITHOUT INTERRUPTS

DMA OFF **
DMA IN **
DMA OUT **

WITH INTERRUPTS

DMA OFF **
DMA IN **
DMA OUT **

****** DONE *****

Figure 4-5. Parallel Interface Test Display, Interrupt Tests Fail

SIZE	CODE IDENT NO.	DWG NO.				
Α	94117		1088690			
SCALE			SHI	ET 36	OF 107	

REVISIONS								
LTR	DESCRIPTION	DATE	APPROVED					

4.2.2.2 (continued)

- 8. Execute program again by typing 3000G RETURN.
- 9. Upon execution, verify that the display indicator displays that all tests have failed (see figure 4-6).

SIZE	CODE IDE	NO.	DWG NO.	:						
Α	941	17			108869	90				
SCALE						SHEET	37	OF	107	

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

SANDERS ASSOCIATES GRAPHIC 7

PARALLEL INTERFACE ATP

PASS FAIL

WITHOUT INTERRUPTS

WITH INTERRUPTS

****** DONE *****

Figure 4-6. Parallel Interface Test Display, All Tests Fail

SIZE	CODE IDEN	IT NO.	DWG NO.					
Α	94117		117					
SCALE					SHEET	38	OF	107

REVISIONS							
LTR	DESCRIPTION	DATE	APPROVED				

4.2.3 Conic Generator Test

4.2.3.1 General

This test verifies that the conic generator is capable of generating circles and on-axis ellipses. The conic generator option replaces the ramp generator that is normally part of the basic terminal controller, and serves both as a ramp generator and a conic generator.

4.2.3.2 Procedure

- 1. Place the terminal controller in the LOCAL mode by pressing the LOCAL pushbutton on the GRAPHIC 7 control panel.
- 2. Verify that the pattern displayed on the display indicator is as shown in figure 3-1.
- 3. In particular, note the following:
 - a. A circle is drawn tangent to the four cardinal points of the inner square.
 - b. Two on-axis ellipses are drawn about the center cross. The larger ellipse has its major axis in the X-plane, the smaller ellipse has its major axis in the Y-plane.

SIZE	CODE IDE	NT NO.	DWG NO.						
Α	941	17		10886	9 0	•			
SCALE					SHEET	39	OF	107	

REVISIONS								
LTR	DESCRIPTION	DATE	APPROVED					

4.2.4 2D Coordinate Converter Test

4.2.4.1 General

This test verifies that the 2D coordinate converter option provides for programmed translation and rotation of displayed data (characters and vectors).

4.2.4.2 Procedure

- Using the tape loading procedure of Appendix A, load the 2-D coordinate converter ATP test tape. The test is self-starting and requires no operator intervention after it is loaded.
- 2. Verify that the test pattern displayed on the display indicator is the same as that shown in figure 4-7 and as described below:
 - a. This is a dynamic test pattern and as such requires approximately six seconds for a complete cycle.

NOTE

The pattern cycle time is <u>not</u> an acceptance requirement and does not require measurement.

- b. The two logo boxes located above the ROTATION nomenclature rotate 360° about a center axis in a counterclockwise rotation.
- c. The two logo boxes located above the ZOOM nomenclature zoom in and out from a point. In addition, the box orientation is upside down during part of the cycle.
- d. In particular note the following:
 - 1. No jumping or discontinuous action such as stopping and starting.
 - Rotation and zooming shall each be a continuous, smooth operation.

SIZE	CODE IDEN	IT NO.	DWG NO.				
Α	94117			1088690			
SCALE			1	SHEET	40 OF	107	





SANDERS GRAPHIC SEVEN COMPUTER GRAPHICS DISPLAY SYSTEM 2-D COORDINATE CONVERTER ATP



CA COLOR

ZOOM -X TRANSLATION +Y TRANSLATION ROJATION +X TRANSLATION +Y TRANSLATION



ROTATION
-X TRANSLATION
-Y TRANSLATION



ZOOM +X TRANSLATION -Y TRANSLATION

Figure 4-7. 2D Coordinate Converter Test Display

SIZE CODE IDENT NO. DWG NO.

A 94117 1088690

SCALE SHEET 41 OF 107

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

4.2.4.2 (continued)

- 3. The boxes shall only move about a center axis and not be displaced as they rotate or zoom.
- 3. The complete cycle that the test pattern goes through is as follows:
 - a. At the start (0°) , all four logo boxes are the same size and oriented in the same direction (horizontal).
 - b. As the two boxes rotate, the zoom logos recede to a dot this is at the 90° point of rotation.
 - c. The zoom logos now zoom out from a point to full size, upside down. They are full size at the 180° point of rotation.
 - d. As the rotation continues counterclockwise, the boxes again recede to a dot; this occurs at 270°.
 - e. The boxes zoom out from a dot, reaching full size at the 360° point of rotation, and with all boxes in the correct orientation The cycle now repeats.

	REVISIONS	3	•		
LTR	DESCRIPTION	DATE	APPROVED		
1					

4.2.5 Large R/W Memory Test

4.2.5.1 <u>General</u>

The large R/W memory test verifies operation of:

- a. Single Model 7702, 7703, or 7704 memory cards.
- b. Various two-card combinations up to a total of 128K words of memory.
- c. The special (discontinuous) 32K memory card.

The large R/W memory test consists of the following sub-tests:

- a. Memory sizing check, direct
- b. Memory sizing check, indirect
- c. Memory exerciser check, direct
- d. Memory mapping test (not applicable to Model 7702)

The Model 7702 16K memory consists of four 4K blocks of R/W memory (each 4K block is called a page). The model 7703 has eight such pages and the model 7704 has sixteen such pages. The special (discontinuous) memory card contains pages 0-3 and 8-11.

Models 7703, 7704, and the special memory card have three designated map areas.

The program resides in the first 4K words of memory (page 0).

4.2.5.2 <u>Test Description</u>

When the program is loaded via a paper tape reader, a prompt is given by the teletypewriter printing "*". This prompt is given by a debugger program which resides along with the test program.

The program begins by checking for memory size by direct addressing. Next, using one of the page registers and mapper (initially checked), the memory is sized for the number of pages — either 8 or 16. Once the memory

SIZE	CODE IDE	NT NO.	DWG NO.						
Α	941	17		1088	690				
SCALE					SHEET	43	OF	107	

REVISIONS					
LTR	DESCRIPTION	DATE	APPROVED		

4.2.5.2 (continued)

is sized, an exhaustive check of page l (second 4K of memory) is made. The program then relocates to this page and performs the same test on page 0, where the program normally resides. After this test the program relocates itself back to page 0. This completes sub-tests 1-3.

The fourth sub-test now performs the following checks (not applicable to Model 7702):

- 1. Verifies page register operation.
- Verifies that data can be mapped anywhere in memory using the page register feature.
- 3. Verifies that mapped data appears only in the map area that is supposed to be in and no other.
- 4. Using the mapper, the program checks every location of each page for integrity.

Test times are as follows (assuming a 64K memory is undergoing test):

Subtest		Time	(approximat	e)
l and 2		1	minute	
3		2	minutes	
4		1	minute	

Total test time is approximately 4 minutes.

4.2.5.3 Procedure

- 1. Using the tape loading procedure of Appendix A, load the 16 K/32 K/64 K R/W memory test tape.
- 2. After the tape loading procedure is complete, using the teletypewriter, type the following after the * prompt:

*	15050/ØØØ726	24Ø
*	15240/Ø12737	47Ø
مله	1/200. 0	

* 14200: G

1	SIZE	CODE IDENT NO.	DWG NO.
	Α	94117	1088690
	SCALE		SHEET 44 OF 107

REVISIONS				
LTR	DESCRIPTION	DATE	APPROVED	

4.2.5.3 (continued)

NOTE: The /000726 and /012737 will be printed by the debugger.

3. The program will now print the title

GRAPHIC 7 MEMORY TEST 128K

and additional data as shown in figures 4-8 through 4-11.

4. After "PAGE $\#\emptyset1$ " is printed, type control C (C) on the teletypewriter.

The * prompt will now be typed signifying the end of the test.

5. There is a 2-second delay loop in the program which allows the operator time enough to hit any teletypewriter character and interrupt the program. Once hit, the program goes to the debugger and the * prompt appears on the teletypewriter. If the operator misses the 2-second debug, he can still interrupt the program by hitting a control character. However, response to this interrupt will take about 1 minute.

SIZE ·	CODE IDE	NT NO.	DWG NO.						
Α	941	17		10	88690				
SCALE					SH	EET 45	OF	107	

REVISIONS				
LTR	DESCRIPTION	DATE	APPROVED	

PAGE	MEM.	
NO.	TYPE	COMMENT
Ø1	RAM	
Ø2	RAM	
Ø3	RAM	
Ø4	RAM.	
Ø5	RAM	
Ø6	ROM	

MEM. SIZING-VIA MAPPER

PAGE NO.	MEM. TYPE	COMMENT
Ø1	RAM	
Ø2	RAM	
Ø3	RAM	
Ø4	RAM	
Ø5	RAM	
Ø6	RAM	•
Ø7	RAM	
Ø8	RAM	
Ø9	RAM	
1Ø	RAM	•
11	RAM	
12	RAM	
13	RAM	
14	RAM	
15	RAM	

RAM TESTING-DIRECT PAGE # Ø1 PAGE # ØØ

BEGIN MAP TEST PAGES Ø1 - 15

END OF PASS # Ø1

RAM TESTING-DIRECT PAGE # Ø1

Figure 4-8. Printout for Model 7704 (64K Memory)

SIZE	CODE IDEN	NO.	DWG NO.						
Α	941	17		108869	90	•			
SCALE					SHEET	46	OF	107	

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

PAGE	MEM.	
NO.	TYPE	COMMENT
Ø1	RAM	
Ø2	RAM	
Ø3	RAM	
Ø4	RAM	
Ø5	RAM	
Ø6	ROM	

MEM. SIZING-VIA MAPPER

PAGE	MEM.	
NO.	TYPE	COMMENT
d.		
Ø1	RAM	
Ø2	RAM	
Ø3	RAM	
Ø4	RAM	NONE
Ø5	R.AM	NONE
Ø6	RAM	NONE
Ø7	RAM	NONE
Ø8	RAM	
Ø9	RAM	
1Ø	RAM	
11	RAM	
12	RAM	NONE
13	RAM	NONE
14	RAM	NONE
15	RAM	NONE

RAM TESTING-DIRECT PAGE # Ø1 PAGE # ØØ

BEGIN MAP TEST

PAGES \emptyset - 15 END OF PASS # \emptyset 1

RAM TESTING-DIRECT

RAM TESTING-DIRECT PAGE # Ø1

Figure 4-9. Printout for Special 32K Memory Card

SIZE	CODE IDE	NT NO.	DWG NO.						
Α	941	17		10886	90				
SCALE		,			SHEET	47	OF	107	

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

MEM. TYPE	COMMENT
RAM	
RAM	•
RAM	
RAM	
RAM	
ROM	
	TYPE RAM RAM RAM RAM RAM

MEM. SIZING-VIA MAPPER

PAGE	MEM.	
NO.	TYPE	COMMENT
Ø1	RAM	
Ø2	RAM	
Ø3	RAM	
Ø4	RAM	
Ø5	RAM	
Ø6	RAM	
Ø7	RAM	

RAM TESTING-DIRECT

PAGE # Ø1 PAGE # ØØ

BEGIN MAP TEST

PAGES Ø1 - Ø7

END OF PASS # Ø1

RAM TESTING-DIRECT

PAGE # Ø1

Figure 4-10. Printout for Model 7703 (32K Memory)

SIZE	CODE IDE	NT NO.	DWG NO.					-		
Α	941	17			10886	90				
SCALE						SHEET	48	OF	107	

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

 PAGE NO.
 MEM.

 NO.
 TYPE
 COMMENT

 Ø1
 RAM

 Ø2
 RAM

 Ø3
 RAM

RAM TESTING-DIRECT

PAGE # Ø1
PAGE # ØØ

END OF PASS # Ø1

RAM TESTING-DIRECT

PAGE # Ø1

Figure 4-11. Printout for Model 7702 (16K Memory)

SIZE	CODE IDEN	IT NO.	DWG NO.							
A	941	17		•	108869	90				
SCALE				. •		SHEET	49	OF	107	

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

4.2.6 2-D/3-D Coordinate Converter Test

4.2.6.1 General

This test verifies that the 2-D/3-D coordinate converter option performs three-dimensional translation with zoom.

4.2.6.2 Procedure

- 1. Using the tape loading procedure of Appendix A, load the 2-D/3-D coordinate converter ATP tape. The test is self-starting and requires no operator intervention after it is loaded.
- Verify that the test pattern presented on the display indicator is as follows:

NOTE

This is a dynamic test pattern and requires approximately ten seconds for a complete cycle. Pattern cycle time is not an acceptance requirement and does not require measurement.

- a. The display consists of a cube, tumbling in all directions.
- b. As the cube tumbles, it zooms in and out from a point.
- c. In particular observe the following:
 - 1. No jumping or discontinuous action such as stopping and starting.
 - Tumbling and zoom shall each be a continuous, smooth operation.

SIZE	CODE IDENT NO.	DWG NO.
Α	94117	1088690
SCALE		SHEET 50 OF 107

REVISIONS					
LTR	DESCRIPTION	DATE	APPROVED		

4.2.7 Expansion Module Tests

The expansion module assembly is tested as a function of the programs installed on it. Refer to the appropriate software test in Section 4.5.

SIZE	CODE IDEN	IT NO.	DWG NO.						-
Α	941	17	,	108869	90				-
SCALE		•			SHEET	51	OF	107	

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

4.2.8 Floating Point Converter Test

4.2.8.1 <u>General</u>

This procedure tests the ability of the Model 5744 floating point converter to make input and output conversions.

NOTE

When the floating point converter is installed in the GRAPHIC 7, the ROM and Status card must be part number 1088682G2 (8K model) with the floating point converter program installed in the lower 4K. The operating program must be the basic GCP. The floating point converter does not work with GCP+.

4.2.8.2 Procedure

- 1. Using the tape loading procedure of Appendix A, load the floating point converter test tape.
- On the teletypewriter (connected to the ROM and status card), press the % key. The display shows DATA CONVERTER TEST and the teletypewriter prints *.
- 3. From this point on, the test is fully automatic. Proper operation is indicated by the following sequences on the display indicator:

1	SIZE	CODE IDENT NO.	DWG NO.
	Α	94117	1088690
	SCALE		SHEET 52 OF 107

REVISIONS				
LTR	DESCRIPTION	DATE	APPROVED	

4.2.8.2 (continued)

SEQUENCE	DURATION	DISPLAY
1		00000000,0000 00000000,0000
. 2		- 2 - 2
3	Too fast to see. If you want to see them, go to	00,50000E+01EAST 00,50000E+01EAST
4	step 6.	00000000,0000
5		- 2
6		00.50000E+01EAST
7	5 seconds	+55555.555 +55555.555
8	5 seconds	+999999. +999999.
9	5 seconds	+999999 +999999
10	5 seconds	99:59:59 99:59:59
11	5 seconds	+299:59:59 +299:59:59
12	5 seconds	+299:59:59.9 +299:59:59.9
13	5 seconds	FFFFFFF FFFFFFF
14	5 seconds	. 177777 177777
15	5 seconds	1111111111111111 11111111111111111
16	5 seconds	YES YES
17	5 seconds	E179.999 E179.999
18	5 seconds	E099.999 E099.999

SIZE	CODE IDEN	NT NO.	DWG NO.					
Α	941	17		10886	90			
SCALE					SHEET	53	OF	107

	REVISIONS	1000	4.2
LTR	DESCRIPTION	DATE	APPROVED

4.2.8.2 (continued)

4. If the test program detects an error, it produces the following display:

BE nnnnnn

where n (octal) is the step number in the program at the point of failure.

5. On successful completion of the test, the teletypewriter prints an asterisk and the display indicator shows the following:

DATA CONVERTER TEST

- 6. To rerun the test and examine the sequences at a slower pace:
 - a. Press CTRL C to reinitialize the program.
 - b. Press the ! key. Now each of the first six sequences remains displayed until you press the space bar. Subsequent sequences advance at 5-second intervals but you can hurry them along by pressing the space bar after each display.

SIZE	CODE IDENT NO.	DWG NO.	
Α	94117	1088690	
SCALE		SHEET 54 OF	107

REVISIONS						
LTR	DESCRIPTION	DATE	APPROVED			

SECTION 4.3

DATA ENTRY OPTIONS TESTS

SIZE CODE IDENT NO. DWG NO.

1088690

SCALE

SHEET 55 OF 107

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

4.3.1 Alphanumeric Keyboard Tests

4.3.1.1 General

These tests are designed to verify performance of the following keyboard options:

- 1. Model 5782
- 2. Model 5783
- 3. Model 5784
- 4. Model 5785

The keyboard test program, which is also part of the terminal verification test, verifies operation of the alphanumeric keys, matrix keys, and function keys. When a key is pressed, the ASCII code for that key is displayed on the CRT screen. If a code represents a displayable character, the character symbol is also displayed. Pressing a matrix or function key causes the octal equivalent of the ASCII code for that key to be displayed. In the Model 5785, alternate depressions light and turn out the lighted keys. In the Models 5784 and 5785, function/matrix key lamps are lit and turned off by instructions from the host.

4.3.1.2 Procedure, Model 5782 Keyboard Test

- 1. Follow the procedure of paragraph 3.2.1 to display the terminal verification pattern.
- Verify that the flying lead connector from the Model 5782 is connected to J5 of the multiport serial interface.
- 3. Observe the box in the lower right-hand quadrant of the display.

 Displayable characters are drawn in the upper left portion of the box with the octal code displayed directly underneath.

SIZE	CODE IDE	NT NO.	DWG NO.						
Α	941	17		10886	90				
SCALE					SHEET	56	ÓF	107	

	REVISIONS				
LTR	DESCRIPTION	DATE	APPROVED		

4.3.1.2 (continued)

Press each alphanumeric, function, and matrix key in turn, and verify that each code displayed is as per table 4-1.

4. The following keys are tested using the SHIFT, CONTROL, and combined SHIFT and CONTROL functions as indicated.

KEY	SHIFT	CODE CONTROL	SHIFT AND CONTROL
Ø	260	260	260
K	333 ([)	213	233
L	334 (\)	214	234
M	335 (])	215	235
N	336 (†)	216	236
0	337 (←)	217	237
P	300 (@)	220	200

Displayable characters are shown in parenthesis where appropriate.

TABLE 4-1. MODEL 5782 KEYBOARD CODES

KEY	CODE	KEY	CODE
МО	000	М9	011
Ml	001	M10	012
M2	002	M11	013
мз	003	M12	014
M4	004	M13	015
М5	005	M14	016
М6	. 006	M15	017
м7	007	FO	020
М8	010	F1	021

SIZE	CODE IDENT NO.	DWG NO.
Α	94117	1088690
SCALE		SHEET 57 OF 107

R E V I S I O N S

LTR DESCRIPTION DATE APPROVED

TABLE 4-1. MODEL 5782 KEYBOARD CODES (continued)

KEY	CODE	KEY	CODE
F2	022	K	313
F3	023	L	314
F4	024	М	315
F5	025	N	316
F6	026	0	317
F7	027	P	318
F8	030	Q	321
F9	031	R	322
F10	032	S	323
F11	033	Т	324
F12	034	U	325
F13	035	V	326
F14	036	W	327
F15	037	x	330
		Y	331
A	301	Z	332
В	302	•	254
С	303	-	255
D	304	•	256
E	305	/	257
F	306	Ø	260
G	307	1	261

SIZE	CODE IDENT NO.	DWG NO.
Α	94117	1088690
SCALE		SHEET 58 OF 107

R E V I S I O N S

LTR DESCRIPTION DATE APPROVED

TABLE 4-1. MODEL 5782 KEYBOARD CODES (continued)

KEY	CODE	KEY*	CODE
H	310	2 .	262
I	311	3	263
J	312	4	264
5	265	<	274
6	266	=	275
7	267	>	276
8	270	?	277
9	271	1	241
:	272	**	242
;	273	#	243
•	256	%	245
		&	246
ADV →	200	/	247
BS ←	210	()	250
TAB	211)	251
·LF	212	*	252
RETURN	215	+	253
ESC	233		
RUBOUT	377	·	
SPACE (bar)	240	·	

*Keyboard in SHIFT mode of operation

SIZE	CODE IDEN	NT NO.	DWG NO.							
Α	941	17		10	8869	90				
SCALE						SHEET	59	OF	107	

REVISIONS						
LTR	DESCRIPTION	DATE	APPROVED			

4.3.1.3 Procedure, Model 5783 Keyboard Test

- 1. Verify that the Model 5783 keyboard is connected to port number 3(J5) of the multiport serial interface.
- 2. Refer to paragraph 3.2.1 and display the terminal verification pattern.
- 3. Press each alphanumeric key. Verify that the octal code displayed (lower left corner of small box) agrees with the normal codes of table 4-2. Verify that the proper alphanumeric character is displayed (upper left corner of small box).

NOTE

Lower case letters typed on the keyboard may be displayed as capitals in the verification test pattern. The octal code should be that of the lower case letter.

- 4. Press CAPS LOCK key. Observe that CAPS LOCK lamp lights.
- 5. While CAPS LOCK lamp is lit, press each alphanumeric key. Verify that the octal code displayed (lower left corner of small box) agrees with the shifted codes of table 4-2. Verify that the proper alphanumeric character is displayed.
- 6. Release CAPS LOCK key. Observe that CAPS LOCK lamp goes out.
- 7. Press and hold CTRL key, then press each alphanumeric key. Verify that the octal code displayed agrees with the control codes of table 4-2.
- 8. Release CTRL key. Press each function and matrix key in turn.
 Verify that the octal code displayed agrees with table 4-2.

SIZE	CODE IDENT NO.	DWG NO.
Α	94117	1088690
SCALE		SHEET 60 OF 107

REVISIONS

LTR DESCRIPTION DATE APPROVED

Table 4-2. Model 5783 Key Codes

Unshifted ASCII Character	Unshifted	Shifted	Control	Shift and Control	
M0 M1 M2 M3 M4 M5 M6 M7 M8 M9 M10 M11 M12 M13 M14	000 001 002 003 004 005 006 007 010 011 012 013 014 015 016	000 001 002 003 004 005 006 007 010 011 012 013 014 015 016	000 001 002 003 004 005 006 007 010 011 012 013 014 015 016	000 001 002 003 004 005 006 007 010 011 012 013 014 015 016	
M15 F0 F1 F2 F3 F4 F5 F6 F7 F8 F9 F10 F11 F12 F13 F14 F15	017 020 021 022 023 024 025 026 027 030 031 032 033 034 035 036 037	010 017 020 021 022 023 024 025 026 027 030 031 032 033 034 035 036 037	016 017 020 021 022 023 024 025 026 027 030 031 032 033 034 035 036 037	016 017 020 021 022 023 024 025 026 027 030 031 032 033 034 035 036 037	
LF RETURN ESC RUBOUT BACKSPACE SPACE (bar) TAB , / 0	212 215 233 377 210 240 211 254 255 256 257 260	232 215 233 377 230 240 231 274 (<) 275 (=) 276 (>) 277 (?) 260	212 215 233 377 210 240 231 254 255 256 257 260	212 215 233 377 210 240 231 254 255 256 257 260	

SIZE	CODE IDENT NO.	DWG NO.
Α	94117	1088690
SCALE		SHEET 61 OF 107

REVISIONS

LTR DESCRIPTION DATE APPROVED

Table 4-2. Model 5783 Key Codes (continued)

Unshifted ASCII Character	Unshifted	Shifted	Control	Shift and Control	
1 2 3 4 5 6 7 8 9 :; • • • • • • • • • • • • • • • • • •	261 262 263 264 265 266 267 270 271 272 273 333 334 335 336 337 300 341 (a) 342 (b) 343 (c) 344 (d) 345 (e) 346 (f) 347 (g) 350 (h) 351 (i) 352 (j)	241 (!) 242 (") 243 (#) 244 (\$) 245 (%) 246 (&) 247 (') 250 (() 251 ()) 252 (*) 253 (+) 373 ({) 374 (:) 375 (}) 376 (~) 337 340 (`) 301 302 303 304 305 306 307 310 311 312	261 262 263 264 265 266 267 270 271 272 273 233 234 235 236 237 200 201 202 203 204 205 206 207 210 211 212	261 262 263 264 265 266 267 270 271 272 273 233 234 235 236 237 200 201 202 203 204 205 206 207 210 211 212	
K L M N O	353 (k) 354 (1) 355 (m) 356 (n) 357 (o) 360 (p)	313 314 315 316 317 320	P1 P2 233 213 234 214 235 215 236 216 237 217 200 200	233 234 235 236 237 200	
Q R S T U V W X Y Z	361 (q) 362 (r) 363 (s) 364 (t) 365 (u) 366 (v) 367 (w) 370 (x) 371 (y) 372 (z)	321 322 323 324 325 326 327 330 331 332	221 222 223 224 225 226 227 230 231 232	221 222 223 224 225 226 227 230 231 232	

SIZE CODE IDENT NO. DWG NO.

A 94117

1088690

SCALE SHEET 62 OF 107

	REVISIONS	1	
LTR	DESCRIPTION	DATE	APPROVED

4.3.1.3 (continued)

NOTE

The following steps test the repeat function. Not all Model 5783 keyboards contain this function.

- 9. Put the GRAPHIC 7 in teletype emulator mode, half duplex, as follows:
 - a. Press SHIFT and Y.
 - b. Press RETURN.
 - Press function key F0.
 - d. Display indicator screen clears except for G7 at the top, followed by an F or an H. F stands for full duplex, H for half duplex. Every time you press the Fl key, the duplex mode changes.
- 10. Now anything you type appears on the screen and you can test the repeat function. Press and hold any alphanumeric key. After the initial strike and a one second delay, the character repeats at a 10 Hz rate. Use the LF (line feed) key to start a new line. (Line feed can also repeat, dropping your next line further down the page.)
- 11. To return to local mode, press the LOCAL pushbutton on the GRAPHIC 7.

 You cannot go from teletype emulator mode to local mode from the keyboard.

SIZE	CODE IDEN	NT NO.	DWG NO.	_
A	941	17	1088690	
SCALE			SHEET 63 OF 107	

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

4.3.1.4 Procedure, Model 5784 Keyboard Test

NOTE

You can test all the functions of the Model 5784 keyboard except the lamps in the function and matrix switches by following the procedure of paragraph 4.3.1.3 (Model 5783 keyboard). All Model 5784 keyboards have the repeat function.

The following procedure tests the lamplighting circuits for the function and matrix key lamps. The graphic control program must be GCP+.

- 1. Using the tape loading procedure of Appendix A, load the Model 5784 keyboard test tape (G7KEYS.LDA). The test is self starting.
- Observe the following sequence of events:
 - a. All function and matrix key lamps are lit.
 - b. All function and matrix key lamps go out.
 - c. Each function and matrix key lamp lights, then goes out, in sequence.
 - d. All function and matrix key lamps are lit.
 - e. Each function and matrix key lamp goes out, then back on, in sequence.
 - f. The cycle repeats from step a.
- 3. To stop the lamp test, hit the space bar.

SIZE	CODE IDENT	T NO.	DWG NO.						
Α	941	17		10886	90				
SCALE					SHEET	64	OF	107	

	REVISIONS	}	
LTR	DESCRIPTION	DATE	APPROVED

4.3.1.4 (continued)

NOTE

At this point you can make another test of all keys. If you press any key, the display shows the key code, the port of the multiport serial interface, and a count of the number of keys struck. If you strike a function or matrix key, its lamp lights.

4. To return to the lamplighting cycle, press RETURN.

SIZE	CODE IDE	NO.	DWG NO.	<u>.</u>						
Α	941	17			108869	90				
SCALE						SHEET	65	OF	107	

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED
	• .		


4.3.1.5 Procedure, Model 5785 Keyboard Test

- 1. Verify that the 5785 keyboard is connected to port number 3 (J5) of the multiport serial interface.
- 2. Refer to the procedure of paragraph 3.2.1 and display the terminal verification pattern.
- 3. Press each alphanumeric key and verify that octal code displayed (lower left-hand corner of small box) agrees with figure 4-12 for unshifted keys and that, for displayable characters, the proper character symbol is displayed.
- 4. Press SHIFT LOCK and repeat step 3 except use figure 4-12 for shifted characters.
- 5. Press SHIFT and then depress and hold CTRL. Then repeat step 3, except use figure 4-12 for control characters.
- 6. Press, in turn, all matrix and function keys and verify that the code agrees with figure 4-12.

The lamp functions of the matrix and function keys of the 5785 are verified with the following procedure. This procedure tests the lamps in four steps:

- a. Turn off all (32) lamps at once.
- b. Light all (32) lamps at once.
- c. Light alternate lamps (every other one).
- d. Light lamps opposite to c.

SIZE	CODE IDENT NO.	DWG NO.	
Α	94117	1088690	
SCALE		SHEET 66 OF 1	L07



į,

í

4.3.1.5 (continued)

7. Type the following:

```
176526/ØØØØØØ

176530/ØØØØØØ

176526/ØØØØØØ

176530/ØØØØØØ

176530/ØØØØØØ

176526/ØØØØØØ

176530/ØØØØØØ

176526/ØØØØØØ

176530/ØØØØØØ

176530/ØØØØØØ

176530/ØØØØØØ

176530/ØØØØØØØ
```

Verify that all 32 lamps are out.

8. Using the keyboard type the following:

```
176526/ØØØØØØ
                           224/
176530/0000000
                            \wedge
176526/ØØØØØØ
                           377/
176530/ØØØØØØ
                           \wedge
176526/ØØØØØØ
                           377/
176530/ØØØØØØ
                           \wedge
176526/ØØØØØØ
                           377/
176530/0000000
                           \wedge
176526/ØØØØØØ
                           377/
```

Verify that all 32 lamps are lit.

9. Repeat step 7. To light lamps, type the following:

```
      176526/ØØØØØØ
      224/

      176530/ØØØØØØ
      252/

      176530/ØØØØØØ
      ^

      176526/ØØØØØØ
      252/

      176526/ØØØØØØ
      ^

      176526/ØØØØØØ
      ^

      176526/ØØØØØØ
      ^

      176526/ØØØØØØ
      252/
```

Verify that every other lamp (16) is lit.

10. Type the following to light 16 lamps opposite to those of step 9.

```
176526/ØØØØØØ 224/
176530/ØØØØØØ 125/
176530/ØØØØØØ ^
```

SIZE	CODE IDEN	NT NO.	DWG NO.						
Α	941	17		108869	90				
SCALE					SHEET	68	OF	107	

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED
			·

4.3.1.5 (continued)

176526/ØØØØØØ	125/
176530/ØØØØØØ	^
176526/ØØØØØØ	125/
176530/ØØØØØØ	^
176526/ØØØØØØ	125/

Verify that every other lamp (16), opposite to those in step 9, is lit.

NOTE

The above test is for a single Model 5785 configuration. If a system has two Model 5785's connected, change the second instruction address for each test from 176530/ to 176566/ to test the second keyboard.

SIZE	CODE IDENT NO.	DWG NO.	
Α	94117	1088690	
SCALE			SHEET 69 OF 107

REVISIONS					
LTR	DESCRIPTION	DATE	APPROVED		

4.3.2 PED Tests

4.3.2.1 General

The PED tests verify the operation of the position entry device (track-ball, forcestick, or data tablet) at each display station. The test is performed using the terminal verification test pattern.

NOTE

All PED's connect to port 4 (J7 of the first multiport serial interface) or to port 8 (J7 of the second multiport serial interface). Each terminal controller can support two PED's.

When the terminal verification pattern is first called up, the symbols 1* and 2* appear in the upper left corner of the display (see figure 3-1). When these symbols appear, the GRAPHIC 7 interprets all messages at ports 4 and 8 as coming from trackball or forcestick. To test a data tablet, press function switch Fl on the keyboard. The symbols now change to 1# and 2# and the GRAPHIC 7 interprets incoming messages at ports 4 and 8 as coming from a data tablet. Pressing Fl again restores the 1* and 2* symbols.

4.3.2.2 Trackball/Forcestick Procedure

- 1. Verify that the trackball/forcestick being tested is connected to J7 of the multiport serial interface.
- 2. Verify that the verification test pattern shows the 1* and 2* symbols.
- 3. Operate the PED. Verify that the asterisk for the selected PED can be located anywhere on the display. The asterisk should move smoothly, without jumping. Moving the PED beyond the programmable boundaries causes the asterisk to "wrap around" and reappear on the opposite side of the screen.

SIZE	CODE IDENT NO.	DWG NO.				
Α	94117		1088690	•		
SCALE			SHEE	r 70	OF 107	

	REVISIONS	3	
LTR	DESCRIPTION	DATE	APPROVED
		·	•

4.3.2.3 Data Tablet Procedure

- 1. Verify that the data tablet being tested is connected to J7 of the multiport serial interface.
- 2. Verify that the verification test pattern shows the 1# and 2# symbols.
- 3. Press the data table pen switch and move the pen over the active area of the data tablet. The appropriate symbol (1# or 2#) shall follow the movement of the pen.

SIZE	CODE IDE	NO.	DWG NO.							
Α	941	17		1	.08869	0	•			
SCALE						SHEET	71	OF	107	

	REVISIONS		÷
LTR	DESCRIPTION	DATE	APPROVED

4.3.3 PHOTOPEN® Test

4.3.3.1 General

Each terminal controller can support two PHOTOPEN's and each should operate independently of the other. This test verifies proper operation of up to two PHOTOPEN units.

NOTES

It is assumed that the PHOTOPEN is connected to the PHOTOPEN intensifier panel mounted on the display indicator. Display brightness should be set for <u>normal</u> viewing. Brightness levels should not be dim or barely viewable.

4.3.3.2 Procedure

- 1. Refer to the procedure of section 3.2.1 and display the terminal verification test pattern as shown on figure 3-1.
- PHOTOPEN indicators are displayed in the upper right corner of the verification test pattern. The "*1S" with an arrow is associated with a PHOTOPEN connected to the PPN1 connector on the front of the terminal controller. The "*2S" with an arrow is associated with a PHOTOPEN connected to the PPN2 connector. Like the trackball/ forcestick indicators, the PHOTOPEN indicators appear on the verification test pattern whether or not PHOTOPEN's are connected to the system.
- 3. If a PHOTOPEN is connected to the system, its associated indicator, *1S or *2S, responds as light from various data items is sensed by the PHOTOPEN. Whenever an item of data is sensed, the sensed point is

®PHOTOPEN is a registered trademark of Sanders Associates, Inc.

SIZE	ZE CODE IDEN		DWG NO.						
Α	941	17		1088690					
SCALE					SHEET	72	OF	107	

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

4.3.3.2 (continued)

the PHOTOPEN. Whenever an item of data is sensed, the sensed point is intensified and the indicator moves so that the arrow points to the location at which the data item ends.

Do not point the PHOTOPEN at data such that ambiguous results occur with the indicator pointing at the extreme end of lines or at the end of a character, for example.

Circles and/or vectors are processed in the same manner. Operations of the PHOTOPEN on this type of data is identical; therefore separate tests are not called out.

- 4. Point the PHOTOPEN at various types of graphics data, as called out in the following sections, and observe operation of the indicator. The graphics data to be sensed is noted by the circled numbers as shown on figure 4-14.
- 5. Character Data Alphanumeric data is normally stored with two characters per word (TEXT command). Therefore the indicator arrow should point to the right of the second character in a pair. Select a character to be sensed from the groups noted by 1.
- Verify that if the PHOTOPEN is pointed at either of the two characters in a pair, the indicator points to the right of the second character. In addition, verify that if the PHOTOPEN is pointed at the first character in a pair, the asterisk (*) is not displayed.
- 7A. This step applies if the program is GCP:

 Verify that if the PHOTOPEN is pointed at any of the characters in the center block, all characters after the indicator are blanked or removed.

SIZE	CODE IDEN	IT NO.	DWG NO.							
Α	941	17		10	8869	90				
SCALE						SHEET	73	OF	107	

	REVISIONS								
LTR	DESCRIPTION	DATE	APPROVED						

4.3.3.2 (continued)

previously.

- 7B. This step applies if the program is GCP+:


 Verify that if the PHOTOPEN is pointed at any of the characters in the center block, the intensifier works but the characters are insensitive to PHOTOPEN strikes.
- 8. Vector Data Point the PHOTOPEN at a point on any line denoted by

 2. Verify that the indicator points to the end of that line. The
 asterisk is not displayed for any line selected.

 As the PHOTOPEN is moved along the line, the indicator should remain
 fixed. At the extreme end of the line, the indicator is not solid.

 Operating the PHOTOPEN in this manner should be avoided, as noted
- 9. Points (or Dots) Data Verify that the PHOTOPEN is pointed to any dot in the group noted by 3, the indicator (less asterisk) points to the same point or dot that is being sensed.
- 10. The "S" in each indicator provides an indication of PHOTOPEN switch operation. With the "S" displayed, while pointing the PHOTOPEN at a data item, actuate the switch by pressing the PHOTOPEN against the CRT screen. Verify that the "S" is removed or blanked. Verify that a second actuation of the switch causes the "S" to reappear with indicator (arrow and number).

SIZE	CODE IDENT	NO.	DWG NO.					
A	9411	L7		10886	90		1	• .
SCALE					SHEET	74	OF	107



REVISIONS

LTR DESCRIPTION DATE APPROVED

SECTION 4.4

DISPLAY INDICATOR OPTIONS TESTS

SIZE CODE IDENT NO. DWG NO.

A 94117 1088690

SCALE SHEET 76 OF 107

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

4.4.1 21-Inch Display Indicator Test

4.4.1.1 General

This test verifies operation of the 21-inch diagonal display indicator, either vertically or horizontally oriented. These units can be configured for either desk top or rack mounted operation.

4.4.1.2 Procedure

- 1. Refer to paragraph 3.1. In place of the display indicator normally provided as support equipment for the terminal controller test, substitute the display indicator being tested.
- 2. Follow the procedure of paragraph 3.2.1 to display the terminal verification test pattern.
- 3. Verify that the display indicator displays the test pattern shown in figure 3-1. (If UUT is four-color display, see step 5.)
- 4. Verify that the display field is 12 x 12 inches. If customer requirements are for a non-standard display field, the display indicator gain adjustments will be set prior to the ATP and so noted as a special requirement.
- 5. For display indicators Models 740-743, verify that the four colors appear as shown in figure 3-1 and that the color controls operate smoothly and are effective.
- 6. For display indicators Models 730-733 and 740-743, test internal pattern generator as follows:
 - a. At rear of display indicator, press SELF TEST pushbutton.
 - b. Display shall be a circle, approximately tangent to the edges of the display area.

SIZE	CODE IDE	NT NO.	DWG NO.			1		
Α	94117		1088690	8690				
SCALE				SHEET	77	OF	107	

REVISIONS							
LTR	DESCRIPTION	DATE APPROV					
		-					

4.4.2 23-Inch Round Display Indicator Test

4.4.2.1 General

This test verifies operation of the 23-inch diameter high speed display indicator.

4.4.2.2 Procedure

- 1. Refer to paragraph 3.1. In place of the display indicator normally provided as support equipment for the terminal controller test, substitute the display indicator being tested.
- 2. Follow the procedure of paragraph 3.2.1 to display the terminal verification test pattern.
- 3. Verify that the display indicator displays the test pattern shown in figure 3-1. (If UUT is four color display, see step 5.)
- 4. Verify that the display size is 20 inches in diameter as follows:
 - using a ruler, measure from the center cross to the lines of the full screen box. This dimension shall be 10 inches in both the horizontal and vertical axes.

NOTE

The lines of the full screen box shall be just visible inside the edge of the indicator bezel only at the cardinal points due to the circular viewing area.

- 5. For display indicators Models 760 or 763, verify that the four colors appear as in figure 3-1 and that the color controls operate smoothly and are effective.
- 6. For display indicators 750, 753, 760, or 763, test internal pattern generator as follows:

	A 94117		108869			90		
.	SCALE			SHEE	r 78	OF	107	

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

4.4.2.2 (continued)

- a. At rear of display indicator, press SELF TEST pushbutton.
- b. Display shall be a circle, approximately tangent to the edges of the display area.

SIZE	CODE IDENT	Γ NO.	DWG NO.			
Α	94117			108869	90	
SCALE				•	SHEET 79	OF 107

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

4.4.3 Hardcopy Unit Test

4.4.3.1 General

This test verifies that the hardcopy unit can produce a paper copy of a displayed graphics presentation in the LOCAL mode. The test assumes that the hardcopy unit has been previously connected to one of the output channels of the terminal controller. There is a 10 minute warm-up for the hardcopy developer to come to temperature, after the initial power-on.

4.4.3.2 Procedure

- 1. With all equipment energized, place the terminal controller in the LOCAL mode by pressing the LOCAL pushbutton on the GRAPHIC 7 control panel.
- Verify that the terminal verification pattern of figure 3-1 is displayed on the display indicator.

NOTE

The display indicator used can either be a unit undergoing test as part of this ATP or one provided as support test equipment.

- 3. Set brightness control on hardcopy unit to 12 o'clock setting.
- 4. Press the COPY switch on the hardcopy unit (right-hand side).
- 5. Verify that a paper copy of the terminal verification pattern is produced within 20 seconds.
- 6. The hardcopy should be a faithful rendition of the test pattern; however, the three groups of vertical bars located at the full, 1/4, and 1/2 screen horizontal positions respectively, may show up as solid bars on the paper copy. In addition, those graphics elements such as circles, conics, translated and rotated data, will not be present in

SIZE	CODE IDEN	1 -7	DWG NO.	108869) (
Α	941.	1/		10000	, 0			3. 3.	
SCALE					SHEET	80	OF	107	

	REVISIONS										
LTR	DESCRIPTION	DATE	APPROVED								

4.4.3.2 (continued)

the copy unless the appropriate function generators are present in the system configuration.

NOTES

- The single digit number used for display ID over the center bar may or may not be copied. This is a blinking number.
- The small box in the lower right hand quadrant has a number, in its right corner, which is sequentially counting. This could be copied as two numbers overlaying each other.
- 7. Paper Size

Paper length should be approximately ll inches top to bottom.

8. Image Size

Square format: (CRT image 12" x 12") 7 1/2" long x 7 1/2" wide (Measure large outside box only)

or

Vertical format: (CRT image 16" x 12")
8 1/2" long x 6 3/8" wide
(L = measure outside box
W = measure small inside box)

or

Horizontal format: (CRT image 12" x 16")
6 3/8" long x 8 1/2" wide
(L = measure small inside box
W = measure large outside box
Image axis must be changed by
swapping X & Y coax input)

9. Brightness Control

As brightness setting goes from "light" to "dark" in a clockwise direction (12 o'clock to 3 o'clock setting): Verify that within this range, a legible hardcopy print is obtained.

SIZE	CODE IDEN	T NO.	DWG NO.						
Α	941	17		1088	690				
SCALE					SHEE	81	OF	107	

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED
		·	

4.4.4 Hardcopy Multiplex Switch Test

4.4.4.1 General

This test verifies that the hardcopy multiplex switch can control the generation of copies by allowing a single hardcopy unit to service four terminal controllers. This procedure assumes that a Model 0570 hardcopy unit (HCU) is available to run the test. If a HCU is not available, then a display indicator may be substituted for it. Refer to paragraph 4.4.4.4 for this optional procedure.

4.4.4.2 Initial Setup

- Connect three cables from the XYZ outputs on the rear of the multiplex switch to the XYZ inputs on the hardcopy unit.
- 2. Connect the data cable from the J2 connector on the rear of the multiplex switch to the input connector in the hardcopy unit.
- 3. Connect a set of X, Y, and Z cables between the terminal controller output channel and the X_1 , Y_1 , and Z_1 inputs on the front of the multiplex switch.
- 4. Connect the data cable between the multiport serial interface card, port number 4, and J1 on the front of the multiplex switch. This assumes port number 4 is configured as Port 5, a hardcopy unit.

4.4.4.3 Procedure

- 1. Energize all equipment and place the terminal controller in the LOCAL mode by pressing the LOCAL pushbutton on the GRAPHIC 7 control panel.
- 2. Verify that the terminal verification pattern of figure 3-1 is displayed on the display indicator.
- 3. Allow a 10 minute warm-up for the hardcopy unit.
- 4. Set the AUTO switch on the front of the multiplex switch to position 1.

SIZE	CODE IDEN	NT NO.	DWG NO.							
A 94117		1088690			90	0				
SCALE	•					SHEET	82	OF	107	

	REVISIONS	3	
LTR	DESCRIPTION	DATE	APPROVED
		·	

4.4.4.3 (continued)

- 5. Press the COPY switch on the hardcopy unit.
- 6. Verify that a paper copy of the terminal verification pattern is produced.
- 7. Repeat steps 4, 5 for positions 2, 3, and 4 of the AUTO switch.
- 8. Verify that a blank copy is produced.
- 9. Set the AUTO switch to the AUTO position.
- 10. Generate a software-initiated copy as follows:
 - a. Press the RETURN key on the keyboard.
 - b. Enter 176546/ from the keyboard.
 - c. Enter a non-zero value (1 for example).
 - d. Press RETURN.
- 11. Verify that a copy with an M in the center is produced.
- 12. Repeat step 10 for positions 1-4 of the AUTO switch.
- 13. Verify that no copy is generated.
- 14. De-energize the terminal controller and multiplex switch.
- 15. Move the data cable from Jl to J2 and the signal cables (XYZ) from X_1 , Y_1 , Z_1 to X_2 , Y_2 , Z_2 on the multiplex switch.
- 16. Re-energize the multiplex switch and terminal controller.
- 17. Repeat the procedure, steps 2 through 13.
- 18. Repeat steps 14 through 17 for the remaining two sets of inputs: (J3, X_3 , Y_3 , Z_3); (J4, X_4 , Y_4 , Z_4).

4.4.4.4 Optional Procedure

As noted in 4.4.4.1, this procedure is to be used if a hardcopy unit is not available.

SIZE	CODE IDENT	NO.	DWG NO.						
A	9411	17		108869	9 0				
SCALE					SHEET	83	OF	107	

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

4.4.4.4.1 Initial Set-Up

- 1. Connect the X, Y, and Z video cables from the multiplex switch to the X, Y, and Z inputs of the display.
- 2. Connect the data cable between terminal controller multiport number 4 and Jl on the front panel of the multiplex switch.

4.4.4.4.2 <u>Procedure</u>

- 1. Follow steps 1 through 8 of 4.4.4.3. Instead of generating a paper copy, verify that the terminal verification pattern appears on the display.
- 2. Follow steps 9 through 13 and verify that the M appears on the screen for 20 seconds, then goes off.
- 3. Follow steps 14 through 18 of 4.4.4.3 in the manner outlined in 1 and 2 above.

SIZE	CODE IDENT	NO.	DWG NO.					
A 94117			10886	90				
SCALE					SHEET	84	OF	107

	REVISIONS	3	
LTR	DESCRIPTION	DATE	APPROVED

SECTION 4.5

SOFTWARE/FIRMWARE TESTS

SIZE	CODE IDE	NT NO.	DWG NO.						
Α	941	17		10886	90				
SCALE					SHEET	85	OF	107	

1	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

4.5.1 GSS-4 Test

See Acceptance Test Procedure 1089696 for the GSS-4 acceptance test.

4.5.2 GET-2 Tektronix Emulator Test

4.5.2.1 General

This test verifies that the expansion module with the GET-2 Tektronix Emulator program installed can be device-accessed; that the program can be downloaded to RAM; and that the checksum of the downloaded program is correct.

4.5.2.2 Procedure

- 1. Follow the procedure of paragraph 3.2.1 to display the terminal verification test pattern.
- 2. At the keyboard, press RETURN. You are now in debug mode.
- 3. Using the keyboard, load the following:

MEMORY LOCATION	VALUE	TERMINATOR	MEMORY LOCATION	VALUE	TERMINATOR
2000/	5000	LINE FEED	2016/	2375	LINE FEED
2002/	12702	LINE FEED	2020/	10037	LINE FEED
2004/	13736	LINE FEED	2022/	2030	LINE FEED
2006/	12701	LINE FEED	2024/	137	LINE FEED
2010/	3000	LINE FEED	2026/	157750	LINE FEED
2012/	62100	LINE FEED	2030/	0	RETURN
2014/	20201	LINE FEED		_	

- 4. At keyboard, type 4002L RETURN. This instruction downloads the GET-2 program to RAM.
- 5. At keyboard, type 2000G RETURN. This instruction executes the routine. Display indicator shows "BØM" at center of screen.
- At keyboard, type 2030/. Display shall show 2030/ 121313.

SIZE	CODE IDEI	NT NO.	DWG NO.			-			
Α	941	17		10886	90				
SCALE		l			SHEET	86	OF	107	

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

SECTION 4.6

SPECIAL TESTS

SIZE CODE IDENT NO. DWG NO.

A 94117 | 1088690 | SHEET 87 OF 107

ļ.	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

4.6.1 Data Load Test

4.6.1.1 General

This test verifies the data load capability of the GRAPHIC 7 display system using a data load display program consisting of three different display formats. Each format contains the following types and quantities of data:


DISPLAY DATA TYPE	QUANTITY	PER DISPLAY	FORMAT
	A	В	С
Alphanumerical characters, small	1000	750	750
Alphanumerical characters, large	1000	250	250
Vectors, short		100	500
Vectors, long	15	60	30
Circle, small	Mates Gallery	15	30
Circle, large	-	15	10
Average positioning	40	60	100

Each format will be displayed simultaneously on a different display indicator with a fourth indicator displaying a composite pattern consisting of formats A, B, and C combined.

4.6.1.2 Procedure

- 1. Verify that four display indicators are connected as per figure 4-14. It is assumed that each indicator was previously tested as part of paragraph 4.4 (display indicator options tests).
- Position the GRAPHIC 7 T2C data load test program in the paper tape reader and load it according to the loading procedure contained in Appendix A.
- 3. Start the program as follows using the keyboard:

SIZE	CODE IDEN	NT NO.	DWG NO.			<u> </u>			
Α	941	17		108869	90				
SCALE					SHEET	88	OF	107	



	REVISIONS	-	
LTR	DESCRIPTION	DATE	APPROVED

4.6.1.2 (continued)

- a. Carriage return
- b. 1000 G
- c. Carriage return
- 4. Verify that the display patterns of figures 4-15, 4-16, 4-17, and 4-18 appear simultaneously on all four display indicators.
- 5. Verify that there is no observable flicker (see note).

NOTE

No observable flicker for P39 phosphor only.

6. Verify, using an oscilloscope, that the frame time is less than 33 ms when measured on the terminal controller output channel for indicator number 4 (composite picture), figure 4-18.

SIZE	CODE IDENT NO.	DWG NO.						
A	94117		108869	90				
SCALE			•	SHEET	90	OF	107	

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED




Figure 4-15. Format A

SIZE	CODE IDENT NO	DWG NO.	
Α	94117	1088690	
SCALE		SHEET 91 OF 107	






Figure 4-16. Format B

SCALE		SHEET 92 OF 107
Α	94117	1088690
SIZE	CODE IDENT NO.	DWG NO.

 R E V I S I O N S

 LTR
 DESCRIPTION
 DATE
 APPROVED





Figure 4-17. Format C

SCALE					SHEET	93	OF	107	 _
Α	941	17		10886	90				
SIZE	CODE IDEN	NT NO.	DWG NO.						






Figure 4-18. Composite Format

1	SIZE	CODE IDENT NO	DWG NO.	
	Α	94117	1088690	
	SCALE		SHEET 94 OF 107	

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

SECTION 4.7

NON-STANDARD PARALLEL INTERFACE TESTS

SIZE CODE IDENT NO. DWG NO.

A 94117 1088690

SCALE SHEET 95 OF 107

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

4.7.1 <u>Introduction</u>

This section contains acceptance test instructions for the following parallel interfaces.

Model	Description	Paragraph
5714	Parallel interface to PDP-11/DR11B	4.7.2
5715	Parallel interface to Interdata 7/16, 7/32, 8/32 SELCH; ULI	4.7.3
5716	Parallel interface to SEL32; HSD-9132	4.7.4
5717	Parallel interface to Harris ABC, CBC, UBC	4.7.5
5718	Parallel interface to HP2100/21MXE; 12930 A-002	4.7.6
5719	Parallel interface to Data General NOVA and ECLIPSE	4.7.7
5720	Parallel interface, NTDS Fast, to Univac military computers	4.7.8
5721	Parallel interface, NTDS Slow, to Univac military computers	4.7.9
5722	Parallel interface to Honeywell 516 DMC	4.7.10
5723	Parallel interface to NORD-10	4.7.11
5734	Long line parallel interface to DEC PDP-11, DR11B, including 200-foot cable	4.7.2

SIZE	CODE IDENT NO.	DWG NO.		
Α	94117		1088690	
SCALE			SHEET	96 OF 107

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

4.7.2 Parallel Interface to PDP-11/DR11B(D)

4.7.2.1 General

This procedure tests the ability of the Model 5714 or 5734 to pass messages from the GRAPHIC 7 to a simulated host and from a simulated host to the GRAPHIC 7.

This procedure requires a test fixture that simulates the DR11-B(D) interface.

4.7.2.2 Procedure

- 1. Connect +5V and GND to the test fixture from the back of the GRAPHIC 7.
- 2. Connect the cable between the test fixture and the interface. In the case of the long line cable, Model 5734, a DEC long line adapter board, DEC Model 5947, is required.
- 3. Select either single step or continuous operation. Single step operation does not operate on the Model 5734.
- 4. Push the reset button on the test fixture.
- 5. If single step operation was chosen, the step button must be pressed after each transfer. The data lights indicate what word is being sent or received during each transfer.
- 6. At the end of the test, G7 should appear on the display, the send and receive lights should be on, and the error light should be off.
- 7. If an error occurs, the error light lights, and the data lights display the last word that should have been transferred.

SIZE	CODE IDEN	NO.	DWG NO.			,			
Α	941	17		108869	0				
SCALE					SHEET	97	OF	107	

				REVIS	SIONS		
		LTR	DI	ESCRIPTION		DATE	APPROVE
•"							
		•				•	1
4.7.2.2	(continued)					•	
	(00110111111111111111111111111111111111		•				
			<u>M</u>	essage			
,			Poset -	Puts GRAPHI	C 7 into	CVCTEM mode	•
			(054130	ruts GRAFHI	C / IIILO	SISIEM Mode	
	Initializatio	on	100000	100020			
			101114	107731			
			000000	207732			
•			046525				
			002000				
	This is sent		000012				•
	to the GRAPHI	rc 7	016313				
	At the end of		013707				
	the SENT ligh		140136				, <u>t</u>
	turns on.	1.6	020000				
	curns on.		060000				
			003000				
			007000				
			133707				
			001000				
			002000				
	Disales ince		√ 051520			*	
	Display image	=	002000				
	0 1 111		043511				1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1
	Send back the	2	{ 002000				
	data sent		000012				
			051111				
			002000				
			000012				
			000000				
	en 1 • •		053114				Ĩ
	This is recei		000012				
	back from the		016313				
	GRAPHIC 7. A	¥t .	013707				
	the end, the		140136				
	RECEIVED ligh	nt	020000				
	is lit.		060000				
			003000				
			007000			•	
			133707				
			001000				
			002000				

SIZE	CODE IDEN	IT NO.	DWG NO.					
Α	941	17		1088690)			
SCALE					SHEET	98	OF 107	

REVISIONS								
LTR	DESCRIPTION	DATE	APPROVED					

4.7.3 Parallel Interface to Interdata 7/16, 7/32, 8/32, SELCH; ULI

To be supplied

4.7.4 Parallel Interface to SEL-32; HSD-9132

To be supplied

SCALE CODE IDENT NO. DWG NO. 1088690

SCALE SHEET 99 OF 107

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

4.7.5 Parallel Interface to Harris ABC/CBC/UBC

4.7.5.1 General

This procedure tests the ability of the Model 5717 to pass messages from the GRAPHIC 7 to a simulated host and from a simulated host to the GRAPHIC 7.

This procedure requires a test fixture that simulates the Harris I/O channel interface.

4.7.5.2 Procedure

- 1. Connect the test fixture cables to the parallel interface (UUT) and plug the interface into the GRAPHIC 7.
- 2. Place the Terminal Controller in the local mode by pressing the LOCAL pushbutton on the GRAPHIC 7.
- 3. Set switches A, B, C, and D on the test fixture to match the address of the parallel interface set by the DIP switches on the interface.
- 4. Push the DISC button on the test fixture. When the button is pushed, the DISC lamp lights. When the button is released, the CNCT lamp lights if the interface has been addressed properly.
- 5. Place the terminal controller in the SYSTEM mode by pressing the SYSTEM pushbutton.
- of the GRAPHIC 7 initialization message (IZ) appears on the data lights. Successively pressing the SS pushbutton causes the rest of the message to be displayed. Verify that the data displayed is as shown below:

1	SIZE	CODE IDENT NO.	DWG NO.		
	Α	94117	1088690		
	SCALE		SHEET 100	OF 107	

REVISIONS								
LTR	DESCRIPTION	DATE	APPROVED					
			·					

4.7.5.2 (continued)

Data Word			Lam	p Data		
1	0	101	100	001	011	000
2	1	000	000	000	000	000
3	1	000	001	001	001	100
4	0	000	000	000	000	000
5	0	000	000	000	000	000

7. The test fixture is now used to send data to the GRAPHIC 7. The first word to be sent is loaded into the data switches and the SEND and the SS pushbuttons are pressed. This operation is repeated for each successive data word shown below by loading the next data word and then pressing SS:

Data Word	Switch Data						
1	0	100	110	101	010	101	
2	0	000	010	000	000	000	
3	0	000	000	000	001	010	
4	0	001	110	011	001	011	
5	0	001	011	111	000	111	
6	1	100	000	001	011	110	
7	0	010	000	000	000	000	
8	0	110	000	000	000	000	
9	0	000	011	000	000	000	
10	0	000	111	000	000	000	
11	1	011	011	111	000	111	
12	0	000	001	000	000	000	
13	0	000	010	000	000	000	
14	0	101	001	101	010	000	
15	0	000	010	000	000	000	

- 8. After sending the above data words, verify that a G7 appears on the display screen.
- 9. Continue sending the following data words in the same manner; load the word, then press the SS pushbutton:

SIZE	CODE IDE	NT NO.	DWG NO.							
A	941	17		10	8869	90				
SCALE						SHEET	101	OF	107	

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED
			. •

4.7.5.2 (continued)

Data Word		Switch Data					
16	0	100	011	101	001	001	
17	0	000	010	000	000	000	
18	0	000	000	000	001	010	

10. Continue pressing the SS pushbutton and the following message, sent back from the GRAPHIC 7, appears on the data lights:

Data Word			Swite	ch Data		
1	0	101	001	001	001	001
2	0	000	010	000	000	000
3	0	000	000	000	001	010
4	0	000	000	000	000	000
5	0	101	011	001	001	100
6	0	000	000	000	001	010
7	0	001	110	011	001	011
8	0	001	011	111	000	111
9 .	1	100	000	001	011	110
10	0	010	000	000	000	000
11	0	110	000	000	000	000
12	0	000	011	000	000	000
13	0	000	111	000	000	000
14	1.	011	011	111	000	111
15	0	000	001	000	000	000
16	0	000	010	000	000	000

I	SIZE	CODE IDENT	T NO.	DWG NO.							
	Α	941	17		- , · · · · · · · · · · · · · · · · · ·	10886	90				
	SCALE						SHEET	102	OF	107	

			V		
			REVISIONS		
		LTR	DESCRIPTION	DATE	APPROVE
	· .				
4.7.6	Parallel Inte	erface to I	HP2100/21MXE; 12930 A-002		
	To be supplie	ed			
4.7.7	Parallel Inte	erface to I	Data General NOVA and ECLIPSE	<u>.</u>	
	To be supplie	ed			
4.7.8	Parallel Inte	erface, NTI	OS Fast, to Univac Military C	omputers	
	To be supplie	ed			
4.7.9	Parallel Inte	erface, NTI	OS Slow, to Univac Military C	omputers	
	To be supplie	ed			
4.7.10	Parallel Inte	erface to H	loneywell 516 DMC		•
	To be supplie	eđ			
4.7.11	Parallel Inte	rface to N	ORD-10		
	To be supplie	:d			

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

SECTION 5

EQUIPMENT ACCEPTANCE TEST RECORD

SIZE CODE IDENT NO. DWG NO.

1088690

SCALE SHEET 104 OF 107

		REVISIONS						
		LTR		DESC	RIPTION		DATE	APPROVED
							!	
5.1	Equipment Acc	ceptance '	Test Reco	<u>rd</u>				
	CUSTOMER				SSO NO.			
	DATE				SYSTEM/PART	NO		
	PERFORMED BY				SERIAL NO.			
	WITNESSED BY							
	SANDERS QA							
PARAGRAPH	TES	T PERFORI	MED		REQUIRED	MEASURE	D/VERIFIED	
-	Visual and Complete	Mechanica	al Inspect	ion	Verify			*
	Terminal Co	ntroller	Tests					· · · · · · · · · · · · · · · · · · ·
3.2	Terminal Ve	rification	on Test	4	Verify			
3.3	ROM Compari	son Test			Verify			
	Terminal Co	ntroller	Option Te	ests				
4.2.1	Multiport S	Serial Int	erface Te	est	Verify			•
4.2.2	Parallel In	terface :	Test .		Verify	-		
4.2.3	Conic Gener	ator Test	=		Verify			
4.2.4	2D Coordina	te Conve	rter Test		Verify			ì.
4.2.5	Large Read/	Write Mer	mory Test		Verify			
4.2.6	2-D/3-D Coo	rdinate (Converter	Test	Verify	****	·.	
4.2.8	Floating Po	int Conve	erter Test	:	Verify			
	Data Entry	Options 1	<u> Tests</u>					
4.3.1	Alphanumeri	c Keyboar	d Test		Model No. Verify			
4.3.2	PED Test				Verify .			·
4.3.3	PHOTOPEN® I	'est			Verify			
		SIZE	CODE IDE	NT NO.	DWG NO.			
		Α	941	17		1088	690	
		SCALE					SHEET 10.	5 OF 107

	REVISIONS		
LTI	DESCRIPTION	DATE	APPROVED
			•

5.1 (continued)

PARAGRAPH	TEST PERFORMED	REQUIRED	MEASURED/VERIFIED
1	Display Indicator Options Tests		
4.4.1	21-Inch Display Indicator	Verify	
4.4.2	23-Inch Round Indicator	Verify	
4.4.3	Hardcopy Unit Test	Verify	
4.4.4	Hardcopy Multiplex Switch Test	Verify	
	Software/Firmware Options Tests		
4.5.1	GSS-4 Test	Verify	-
4.5.2	GET-2 Tektronix Emulator Test	Verify	
	Special Tests		
4.6.1	Data Load Test	Verify	
4.7	Non-Standard Parallel Inter- face Test	Model No. Verify	
	QUALITY ASSURANCE STAMP		

NOTES

- 1. Place N/A on MEASURED line if test is not applicable.
- 2. When multiple quantities of items are being tested, note quantity in parenthesis after MEASURED entry.
- 3. Acceptance to be noted by a check mark or initialed.

SIZE	CODE IDENT N	DWG NO.	
Α	94117	1088690	
SCALE		SHEET 106 OF 107	'

	REVISIONS		
LTR	DESCRIPTION	DATE	APPROVED

APPENDIX A

TAPE LOADING PROCEDURE

To load programs into the GRAPHIC 7 terminal controller from paper tape, proceed as follows:

- a. Position the paper tape in the paper tape reader.
- b. Press the LOCAL button on the terminal controller.
- c. Type RETURN on the teletypewriter or NEW LINE on the keyboard.
- d. Type L RETURN on the teletypewriter or type L NEW LINE on the keyboard.
- e. Observe paper tape being read by the paper tape reader and loaded into the terminal controller.

SIZE	CODE IDEN	IT NO.	DWG NO.							
Α	941	17		10	8869	0				•
SCALE						SHEET	107	OF	107	

THE INTENT AND PURPOSE OF THIS PUBLICATION IS TO PROVIDE ACCURATE AND MEANINGFUL INFORMATION TO SUPPORT EQUIPMENT MANUFACTURED BY SANDERS ASSOCIATES, INC. YOUR COMMENTS AND SUGGESTIONS ARE REQUESTED.

PLEASE USE THE FORM ON THE REVERSE SIDE TO REPORT ANY PROBLEMS YOU HAVE HAD WITH THIS PUBLICATION OR THE EQUIPMENT IT DESCRIBES.

FOLD

FOLD

BUSINESS REPLY MAIL

NO POSTAGE STAMP NECESSARY IF MAILED IN THE UNITED STATES

Postage will be paid by

Sanders Associates, Inc.
Information Products Division
Daniel Webster Highway South
Nashua, New Hampshire 03061

ATTN: DEPARTMENT 1-2894 (NHQ 1-447)

FIRST CLASS PERMIT NO. 568 NASHUA, N.H.



FOLD

FOLD



Name:	Sanders Equipment	
Company:	Part Number	
Address:	Software/Firmware System	
	Version	
Telephone:	Host computer	
Date:	Host operating systemVersion	
	Host-GRAPHIC 7 interface	
	My problem is: hardware □ software □	
Description of problem (or suggestion for improvement):	firmware □ manual □	

Related tech manual number _____