

Application Note



Replacing An SA850/851 With An SA860















Shugart



APPLICATION NOTE FOR REPLACING A SHUGART SA850/851 WITH A SHUGART SA860

1.1 INTRODUCTION

This application note provides the information required to replace a Shugart SA850/851 with a Shugart SA860. For a more detailed description of the SA860, refer to the SA810/860 OEM Manual (P/N 39216).

1.2 MOUNTING

The SA860 is exactly one half the height of the SA850/851. The width and mounting holes are the same as the SA850/851 with rack mount casting. Only the height of the side mounting holes is different due to the half-height packaging. A kit for strapping two drives together is available (P/N 51592).

1.3 AC/DC POWER REQUIREMENTS

The SA860 requires no ac power so the ac power connector may be discarded. DC power is supplied via a 5 pin AMP Mate-N-Lok connector P/N 1-350945-0 (J2). The recommended mating connector (P2) is AMP P/N 1-480763 utilizing AMP pins P/N 350689-1.

Since the SA850/851 uses a 6 pin AMP connector P/N 1-380999-0 (J5) connected to AMP P/N 1-480270-0 utilizing AMP pins P/N 61117-1 (P5), the SA850/851 dc plug is not directly compatible with the SA860. Because of this, a dc SA850/851 to SA810/860 dc plug adapter P/N 51438 must be used, or if preferred, the P5 connector may be replaced with the recommended P2 connector.

1.4 INTERFACE CONNECTIONS

The SA860 uses the same 50 pin cable as the SA850/851. All the interface lines used on the SA850/851 are also on the SA860. Additionally, the SA860 has an I/O line called TRUE READY which is not present on the SA850/851. This output signals that the drive is ready to handle data. This signal may be used in place of motor start and seek complete timers, but is not required. To replace an SA850/851 (jumpered as shipped from the factory) with an SA860, follow these steps:

- a. If the step rate is 6 ms or slower, jumper trace designator PD. This will ensure quiet stepping.
- b. Adjust the head load delay to 165 ms. Since the SA860 has no head load solenoid, starting the dc spindle motor performs the complementary function. This timing delay (measured from the leading edge of DRIVE SELECT to the beginning of valid read/write data) is performed by the controller and may be software or hardware controlled. Another method of measuring this delay is to monitor the TRUE READY line (pin 8). When TRUE READY is active low, read/write activity may begin.
- c. Remove terminator pack at location U9 on all drives except for the last drive on the daisy chain.
- d. All other jumpers are positioned as shipped from the factory.

See table 1-1 for a comparison of SA850/851 and SA860 interface connections.

If the SA850/851 being replaced has been jumpered differently than the standard factory configuration, see table 1-2. This table can be used as a quick cross reference between the trace designators on the SA850/851 and the trace designators on the SA860.

For example, if the jumper configuration for your system calls for trace designator C to be jumpered, table 1-2 indicates that trace designator MO must be plugged on the SA860 PCB.

TABLE 1-1. SA850/851 VERSUS SA860 INTERFACE CONNECTIONS

PIN	SA850/851	SA860
2:	EXTERNAL WRITE CURRENT SWITCH	EXTERNAL WRITE CURRENT SWITCHING*
4	ALTERNATE I/O	ALTERNATE I/O
6	ALTERNATE I/O	ALTERNATE I/O
8	ALTERNATE I/O	TRUE READY
10	TWO SIDED STATUS	TWO SIDED STATUS*
12	DISK CHANGE	DISK CHANGE*
14 5-1	SIDE SELECT	SIDE SELECT
16	IN USE	IN USE*
18 🔀	HEAD LOAD	MOTOR ON*
20 🗸	INDEX	INDEX
22 1	READY	READY
24	SECTOR	SECTOR
26 1 -	DRIVE SELECT 1	DRIVE SELECT 1
28	DRIVE SELECT 2	DRIVE SELECT 2
30	DRIVE SELECT 3	DRIVE SELECT 3
32 >	DRIVE SELECT 4	DRIVE SELECT 4
34	DIRECTION SELECT	DIRECTION SELECT
36 :	STEP	STEP
38	WRITE DATA	WRITE DATA
40	WRITE GATE	WRITE GATE
42	TRACK 00	TRACK 00
44	WRITE PROTECT	WRITE PROTECT
46	READ DATA	READ DATA
48	SEPARATED DATA	SEPARATED DATA
50	SEPARATED CLOCK	SEPARATED CLOCK

^{*}Jumper enabled alternate I/O lines.

39221-01

TABLE 1-2. CUSTOMER CUT/ADD TRACE OPTIONS

DESCRIPTION DESIGNATOR FACTORY OPEN SHORT DESIGNATOR OPEN SHORT O		SA850/851			SA860		
DESIGNATOR DESIGNATOR OPEN SHORT DESIGNATOR OPEN SHORT SHORT STANDARD INPUTS 5E		SHIPPED FROM		SHIPPED FROM			
STANDARD INPUTS 5E							SHORT
DRIVE SELECT 2, 3, 4 INPUT PINS DS 2, 3, 4 X DS 2, 3, 4 X SIDE SELECT OPTION USING 3B, 4B RADIAL READY RR RR X RADIAL READY RR RR X RADIAL INDEX AND SECTOR RI X RADIAL INDEX OUTPUT R X R X R X X R X X R X X		5E		Plugged	U9		Plugged
SIDE SELECT OPTION USING	DRIVE SELECT 1 INPUT PIN	DS1		Plugged	DS1		Plugged
DRIVE SELECT	DRIVE SELECT 2, 3, 4 INPUT PINS	DS 2, 3, 4	х		DS 2, 3, 4	х	
RADIAL INDEX AND SECTOR RI			Х			х	
OPTION SHUNT FOR READY OUTPUT R X R X TWO SIDED STATUS OUTPUT 2S X 2S X SECTOR OPTION ENABLE 850/851 850 851 NOTE 1 INDEX OUTPUT PAD I X N/A IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII	RADIAL READY	RR		x	RR		х
TWO SIDED STATUS OUTPUT 2S	RADIAL INDEX AND SECTOR	RI		х	N/A		
SECTOR OPTION ENABLE	OPTION SHUNT FOR READY OUTPUT	R		X	R		х
NOTE 2	TWO SIDED STATUS OUTPUT	28	Х		28	Х	
SECTOR OUTPUT PAD S X N/A DISK CHANGE OPTION DC X DC X STEPPER POWER FROM HEAD LOAD HL X NOTE 2 STEPPER POWER FROM DRIVE SELECT INHIBIT WRITE WHEN WRITE PROTECTED WP ALLOW WRITE WHEN WRITE PROTECTED NP X NP X ALTERNATE INPUT · IN USE D D DOOR LOCK LATCH OPTION DL X NOTE 4 RADIAL HEAD LOAD A, B, X X MO* X ALTERNATE INPUT · MULTIPLEXED HEAD LOAD ALTERNATE INPUT · MULTIPLEXED IN USE FROM DRIVE SELECT Z X X X X X X X X X X X X	SECTOR OPTION ENABLE	850/851	850	851	NOTE 1		
DISK CHANGE OPTION	INDEX OUTPUT PAD	1		х	N/A		
STEPPER POWER FROM HEAD LOAD	SECTOR OUTPUT PAD	S		х	N/A		
STEPPER POWER FROM DRIVE SELECT DS	DISK CHANGE OPTION	DC	Х		DC	Х	
NATIONAL	STEPPER POWER FROM HEAD LOAD	HL		х	NOTE 2	-	
PROTECTED	STEPPER POWER FROM DRIVE SELECT	DS	Х		NOTE 2		
ALLOW WRITE WHEN WRITE PROTECTED NP X	INHIBIT WRITE WHEN WRITE PROTECTED	WP		х	WP		×
MULTI-MEDIA OPTION	ALLOW WRITE WHEN WRITE PROTECTED	NP	Х			Х	
DOOR LOCK LATCH OPTION DL	ALTERNATE INPUT - IN USE	D	Х		D	Х	
RADIAL HEAD LOAD A, B, X X MS* Plugged ALTERNATE INPUT - HEAD LOAD C X ALTERNATE INPUT - MULTIPLEXED HEAD LOAD (X) (A,B,C) MMO* X IN USE FROM DRIVE SELECT Z X X Plugged IN USE FROM HEAD LOAD Y X SIDE SELECT OPTION USING DIRECTION SELECT S1 X STANDARD SIDE SELECT INPUT S2 X S3 X Plugged SIDE SELECT OPTION USING DRIVE SELECT S3 X S3 X Plugged TS WRITE CURRENT SWITCH (EXTERNAL) READY STANDARD RS Plugged NOTE 4 READY MODIFIED RM X N/A HEAD LOAD LATCH	MULTI-MEDIA OPTION	М		Plugged	NOTE 3		
ALTERNATE INPUT - HEAD LOAD ALTERNATE INPUT - MULTIPLEXED HEAD LOAD IN USE FROM DRIVE SELECT IN USE FROM HEAD LOAD Y X SIDE SELECT OPTION USING DIRECTION SELECT SI STANDARD SIDE SELECT INPUT SIDE SELECT OPTION USING DRIVE SELECT SI STANDARD SIDE SELECT INPUT SIDE SELECT OPTION USING DRIVE SELECT SI STANDARD SIDE SELECT INPUT SIDE SELECT OPTION USING DRIVE SELECT SI SI SI SI SI SI SI SI SI S	DOOR LOCK LATCH OPTION	DL		x	NOTE 4		
ALTERNATE INPUT - MULTIPLEXED HEAD LOAD (X) (A,B,C) MMO* X Plugged IN USE FROM DRIVE SELECT X X X Y X SIDE SELECT OPTION USING DIRECTION SELECT S1 X STANDARD SIDE SELECT INPUT S2 X S3 X S3 X DATA SEPARATION OPTION SELECT TS, FS Plugged TS X Plugged TS X READY STANDARD RS Plugged NOTE 4 READY MODIFIED RM X N/A N/A PLAD LOAD LATCH	RADIAL HEAD LOAD	A, B, X		х	MS*		Plugged
HEAD LOAD (X) (A,B,C) MMO* X IN USE FROM DRIVE SELECT Z X Z Plugged IN USE FROM HEAD LOAD Y X Y X SIDE SELECT OPTION USING DIRECTION SELECT S1 X S2 Plugged S1DE SELECT OPTION USING DRIVE SELECT OPTION USING DRIVE SELECT OPTION USING DRIVE SELECT S3 X S3 X DATA SEPARATION OPTION SELECT TS, FS TS Plugged NOTE 4 READY STANDARD RS Plugged NOTE 4 READY MODIFIED RM X N/A HEAD LOAD LATCH HLL X N/A	ALTERNATE INPUT - HEAD LOAD	С	Х		MO*	Х	
IN USE FROM DRIVE SELECT Z X Z IN USE FROM HEAD LOAD Y X SIDE SELECT OPTION USING DIRECTION SELECT S1 X S1 Plugged TS X S1 X S	ALTERNATE INPUT - MULTIPLEXED HEAD LOAD		(X)	(A.B.C)	MMO*	×	
IN USE FROM HEAD LOAD Y X SIDE SELECT OPTION USING DIRECTION SELECT S1 X STANDARD SIDE SELECT INPUT S2 X S2 Plugged SIDE SELECT OPTION USING DRIVE SELECT S3 X S3 X DATA SEPARATION OPTION SELECT TS, FS TS Plugged TS X Plugged SE X READY STANDARD RS Plugged NOTE 4 READY MODIFIED RM X N/A HEAD LOAD LATCH HLL X N/A	IN USE FROM DRIVE SELECT	Z					Plugged
DIRECTION SELECT S1	IN USE FROM HEAD LOAD	Υ	X ·		Υ	×	
STANDARD SIDE SELECT INPUT S2 X S2 Plugged DRIVE SELECT OPTION USING DRIVE SELECT S3 X DATA SEPARATION OPTION SELECT TS, FS Plugged TS X Plugged TS X READY STANDARD RS Plugged NOTE 4 READY MODIFIED RM X N/A HEAD LOAD LATCH HLL X N/A	SIDE SELECT OPTION USING DIRECTION SELECT	S1	Х		S1	x	100.2
SIDE SELECT OPTION USING DRIVE SELECT S3 X S3 X DATA SEPARATION OPTION SELECT TS, FS TS Plugged TS X WRITE CURRENT SWITCH (EXTERNAL) IW Plugged SE X READY STANDARD RS Plugged NOTE 4 READY MODIFIED RM X N/A HEAD LOAD LATCH HLL X N/A	STANDARD SIDE SELECT INPUT			х			Plugged
DATA SEPARATION OPTION SELECT TS, FS TS Plugged TS X WRITE CURRENT SWITCH (EXTERNAL) IW Plugged SE X READY STANDARD RS Plugged NOTE 4 READY MODIFIED RM X N/A HEAD LOAD LATCH HLL X N/A	SIDE SELECT OPTION USING DRIVE SELECT	S3	Х		\$3	Y	33**
WRITE CURRENT SWITCH (EXTERNAL) IW Plugged SE X READY STANDARD RS Plugged NOTE 4 READY MODIFIED RM X N/A HEAD LOAD LATCH HLL X N/A	DATA SEPARATION OPTION SELECT						
READY STANDARD RS Plugged NOTE 4 READY MODIFIED RM X N/A HEAD LOAD LATCH HLL X N/A	WRITE CURRENT SWITCH (EXTERNAL)		<u>-</u>				
READY MODIFIED RM X N/A HEAD LOAD LATCH HLL X N/A	READY STANDARD	RS			NOTE 4		
	READY MODIFIED	RM	Х		N/A		
N USE TERMINATOR IT Plugged U9 Plugged	HEAD LOAD LATCH	HLL	Х		N/A		
	IN USE TERMINATOR	IT		Plugged	U9		Plugged

39221-02

TABLE 1-2. CUSTOMER CUT/ADD TRACE OPTIONS (Continued)

	SA850/851			SA860		
	TRACE	SHIPPED FROM FACTORY		TRACE	SHIPPED FROM FACTORY	
DESCRIPTION	DESIGNATOR	OPEN	SHORT	DESIGNATOR	OPEN	SHORT
HEAD LOAD OR IN USE TO THE IN USE CIRCUIT	HI	Х		N/A		
REMOVE FOR MFM ENCODING INSTALL FOR MFM	F	х		NOTE 3		
INSTALL FOR FM OR MFM ENCODING	AF		Plugged	NOTE 3		
INSTALL FOR M2FM ENCODING	NF	×		NOTE 3		
INTERNAL WRITE CURRENT SWITCH	N/A		!	SI		Plugged
TRUE READY OUTPUT	N/A			TR		Plugged
RADIAL TRUE READY	N/A			RTR		х
MOTOR OFF DELAY	N/A			MD	X	
STEPPER POWER DOWN	N/A			PD	Х	
STANDARD READY	N/A			SR		Plugged
MODIFIED TRUE READY	N/A			МТ	×	

39221-02

NOTES

- 1. The SA860 automatically adjusts depending on whether hard or soft sectored diskettes are being used.
- 2. The operation of the SA860 is automatically identical to that of the SA850/851. The stepper motor is enabled whenever the drive is selected or the dc spindle motor is up to speed or anytime a step pulse has been received.
- 3. The SA860 does not require jumpers for specific media or encoding types. It will operate with all approved media and specified encoding methods.
- 4. The operation of the SA860 is automatically identical to that of the SA850/851 with this jumper installed.

^{*}MOTOR ON is the compliment of HEAD LOAD on the SA850/851 disk drives. The only difference in the operation of MOTOR ON compared with HEAD LOAD is that MOTOR ON requires a 165 ms minimum delay before read/write activity is begun. HEAD LOAD on the SA850/851 requires a 50 ms minimum delay.



Copryight 1982

475 Oakmead Parkway Telephone: (408) 733-0100

Sunnyvale, California 94086 TWX: 910 339 9355 SHUGART SUVL